

**(Off-side Window with Automatic Raising Device\*)**

WIRING DIAGRAM . . . . .	22-2
GENERAL DESCRIPTION . . . . .	22-3
FUNCTIONAL DESCRIPTION . . . . .	22-3
TROUBLESHOOTING TABLE . . . . .	22-3
COMPONENTS AND CONNECTORS . . . . .	22-4
LOCATION OF COMPONENTS . . . . .	22-7
TROUBLESHOOTING . . . . .	22-8

P. F 1000002

[illegible]

### GENERAL DESCRIPTION

Operation of the left-hand power window (driver's side) is of the automatic type (\*), controlled by a control unit which actuates it in accordance with the following logic:

- acting on one of the two buttons and keeping it pressed, the window is raised or lowered normally until the button is released;
- a short impulse (less than 300 ms. approx.) actuates the electric motor which automatically stops when the stop limit is reached (window completely open or closed);
- an even shorter impulse (less than 50 ms. approx.) is considered by the control unit as an accidental shock and no action will result.

All the power windows are turn-key operated.  
The electrical mechanism which actu-

ates the front right-hand window is of the traditional type: when the button is pressed the window is raised or lowered; it is equipped with two control switches, one on the right-hand door and one on the left-hand door.

### FUNCTIONAL DESCRIPTION

The power window control unit N38 is supplied at pin 2 of connector A by voltage from the battery via fuse G311 (25A) protecting the left-hand power window.

The key operated supply reaches pin 1 of connector B via fuse G310 (25A) which also protects the right-hand power window. Consensus signals for the raising and lowering of the window reach pins 3 and 4 of connector B from the left-hand window control switch B53.

This double switch sends and ground to the control unit and then to the electric

motor **P15** on the side where the contact was closed, determining in this way the direction of rotation of the motor.

The actuation signals (raising or lowering) for the left-hand window motor **P15** leave from pins 3 and 4 of connector **A** of **N38**.

Pin 1 of connector A of N38 is connected to ground.

The actuation of the right-hand power window is directly controlled by one of the two switches B21 (B21a located on the right-hand door, B21b on the left) connected in series.

The key operated supply passes fuse **G310** (25A) and the negative signal from ground **G148b**.


The motor of the right-hand window P14 is in this way actuated by the double switch B21 in either one direction or the other depending on the origin of the positive or negative signal.

## TROUBLESHOOTING TABLE


Malfunction	Component							Test
	N38	G310	G311	B21	B53	P14	P15	
Front left power window	•	•	•		•		•	A
Front right power window		•		•		•		B

(\*) If the off-side window **does not have an automatic raising device** see successive **Section 22A**

## COMPONENTS AND CONNECTORS




(\*) Up to chassis N.2520 (\*\*) from chassis N.2521



(\*) in chassis N.2521

00000000000000000000


11-1993



(\*\*) from chassis N.2521

11-1993

## LOCATION OF COMPONENTS



From chassis N.30.733

Up to chassis N.30.732

G311 = WHITE fuse holder

G310 = BROWN fuse holder

## TROUBLESHOOTING

## FRONT LEFT-HAND POWER WINDOW NOT WORKING

## TEST A

TEST PROCEDURE	RESULT	CORRECTIVE ACTION
<b>A1</b> CHECK FUSE	OK	Carry out step A2
- Check for damage of wander fuse G311	<del>OK</del>	Replace fuse (25A)
<b>A2</b> CHECK FUSE	OK	Carry out step A3
- Check for damage of wander fuse G310	<del>OK</del>	Replace fuse (25A) N.B. in this case the front right hand power window will also not be working (see successive test B)
<b>A3</b> CHECK VOLTAGE	OK	Carry out step A5
- Verify 12V between pins A2 and A1 of power windows control unit N38	<del>OK</del>	Carry out step A4
<b>A4</b> CHECK VOLTAGE	OK	Restore wiring between pin A1 of N38 and ground G148b (BLK)
- Verify 12 V at pin A2 of control unit N38	<del>OK</del>	Restore wiring between pin A2 of N38 and pin Q of G1, across wander fuse G311 and the solder (RED)
<b>A5</b> CHECK VOLTAGE	OK	Carry out step A6
- With ignition key engaged, verify 12 V at pin B1 of control unit N38	<del>OK</del>	Restore wiring between pin B1 of N38 and pin E9 of G1, across wander fuse G310 (RED) and PNK)
<b>A6</b> CHECK VOLTAGE	OK	Carry out step A10
- With ignition key engaged and activating switch B53 in one of the two directions, verify 12 V between pins B3 and B4 of control unit N38	<del>OK</del>	Carry out step A7

(Continued)

## FRONT LEFT-HAND POWER WINDOW NOT WORKING

## TEST A

TEST PROCEDURE		RESULT	CORRECTIVE ACTION
A7	CHECK VOLTAGE	OK	Restore wiring between: • pin 1 of B53 and pin B4 of N38, across pin A4 of connector G23 (ORN) • pin 2 of B53 and pin B3 of N38, across pin A2 of connector G23 (ORN-BLK)
		OK	Carry out step A8
A8	CHECK GROUND	OK	Carry out step A9
		OK	Restore wiring between pin 4 of B53 and ground G148b (*) across pin 4 of connector G306 (BLK) (**) across pin B1 of connector G23 (BLK-PPL and BLK)
A9	CHECK VOLTAGE	OK	Replace switch B53
		OK	Restore wiring between: • pin 3 of B53 and fuse G310, across pin 3 of B21b and pin C3 of connector G23 (RED) • pin 5 of B53 and pin 5 of B21b (RED)
A10	CHECK VOLTAGE	OK	Carry out step A11
		OK	Replace control unit N38
A11	CHECK MOTOR	OK	Replace motor P15
		OK	Restore wiring between: • pin A4 of N38 and pin B of P15, across pin A1 of connector G23 (WHT-GRN) • pin A3 of N38 and pin A of P15, across pin A3 of connector G23 (PPL-YEL)

(\*) up to chassis N.2520

(\*\*) from chassis N.2521

## FRONT RIGHT-HAND POWER WINDOW NOT WORKING

## TEST B

TEST PROCEDURE		RESULT	CORRECTIVE ACTION
B1	CHECK FUSE	OK	Carry out step B2
		OK	Replace fuse (25A)
B2	CHECK VOLTAGE	OK	Carry out step B3
		OK	Carry out step B4
B3	CHECK MOTOR	OK	Replace motor P14
		OK	Restore wiring between: • pin 1 of B21a and pin A of P14 (WHT-RED) • pin 2 of B21a and pin B of P14 (PPL-WHT)
B4	CHECK VOLTAGE	OK	Replace switch B21a
		OK	Carry out step B5
B5	CHECK GROUND	OK	Carry out step B6
		OK	Restore wiring between pin 4 of B21a and ground G148b, across pin B4 of connector G21 (RED)
B6	CHECK VOLTAGE	OK	Restore wiring between: • pin 1 of B21b and pin 3 of B21a, across pin 4 of connector G23 and pin B1 of connector G21 (PPL-BLK) • pin 2 of B21b and pin 5 of B21a, across pin 2 of connector G23 and pin B2 of connector G21 (RED)
		OK	Carry out step B7
B7	CHECK VOLTAGE	OK	Replace switch B21b
		OK	Carry out step B8
B8	CHECK GROUND	OK	Restore wiring between: • pin 3 of B21b and fuse G310, across pin 3 of connector G23 (RED)
		OK	Restore wiring between pin 4 of B21b and ground G148b, across pin C4 of connector G23 (BLK)

# FRONT POWER WINDOWS


(Operation without Automatic Raising Device\*)

## INDEX

WIRING DIAGRAM . . . . .	22A-2
GENERAL DESCRIPTION . . . . .	22A-3
FUNCTIONAL DESCRIPTION . . . . .	22A-3
FAULT DIAGNOSIS TABLE . . . . .	22A-3
COMPONENTS AND CONNECTORS . . . . .	22A-4
LOCATION OF COMPONENTS . . . . .	22A-6
TROUBLESHOOTING . . . . .	22A-7

(\*) If the off-side window is equipped with an automatic raising device see preceeding Section 22

## WIRING DIAGRAM





## GENERAL DESCRIPTION

An electrical mechanism permits operation of the front windows when the buttons located on the relative doors are pressed.

The door on the driver's side is also fitted with a button which operates the window on the passenger's side.

**N.B.** The power windows are "key-activated" and cannot be opened if the ignition key is not engaged.

### FUNCTIONAL DESCRIPTION

The operation of the left-hand power window is controlled by switch **B22**.

The key-activated power supply is delivered through fuse **G311** (25A) and the negative earth signal through **G148b**.

The double switch delivers power and earth to the motor **P15** according to the part in which the contact was closed thus determining the direction of rotation of the motor itself and raising or lowering the window.


The operation of the right-hand power window is controlled by one of two switches **B21** (**B21a** located on the right-hand door, **B21b** on the left) which are connected in series.


The "Key activated" power supply is delivered via fuse G310 (25A) and the negative earth signal from earth G148b. The motor of the right-hand window P14 is thus activated by a double switch B21 in one direction or another depending on the closing of the contact.

### FAULT DIAGNOSIS TABLE


Malfunction	Component							Test
	F13	G310	G311	B21	B22	P14	P15	
Front LH power window	•		•		•		•	A
Front RH power window		•		•		•		B

## COMPONENTS AND CONNECTORS





## LOCATION OF COMPONENTS





## TROUBLESHOOTING

FRONT LEFT-HAND POWER WINDOW NOT WORKING		TEST A
TEST PROCEDURE	RESULT	CORRECTIVE ACTION
<b>A1</b> CHECK FUSE	OK	Carry out step A2
– Check for damage of wander fuse G311	OK	Replace fuse (25A)
<b>A2</b> CHECK VOLTAGE	OK	Carry out step A3
– With ignition key engaged check for 12V on fuse G311	OK	Restore wiring between fuse G311 and fusebox G1, pin H6 across solder (RED and ORN). Also check fuse F13 and relay I35 of fusebox G1
<b>A3</b> CHECK VOLTAGE	OK	Carry out step A4
– With ignition key engaged and activating switch B22 in one of the two directions, verify 12 V between pins 1 and 2 of switch itself	OK	Carry out step A5
<b>A4</b> CHECK MOTOR	OK	Replace motor P15
– With ignition key engaged and activating switch B22 in one of the two directions, verify 12 V between pins A and B of motor P15	OK	Restore wiring between: • pin 1 of B22 and pin B of P15 (ORN) • pin 2 of B21b and pin A of P15 (ORN-BLK)
<b>A5</b> CHECK VOLTAGE	OK	Replace switch B22
– With ignition key engaged, verify 12 V between pin 3 and 4 of switch B22, and between pin 5 and 4 of the same switch	OK	Carry out step A6
<b>A6</b> CHECK GROUND	OK	Restore wiring between: • pin 5 of B22 and fuse G311, across pin A1 of connector G23 (RED) • pin 3 of B22 and pin 5 of B22 (RED)
– Check that pin 4 of B22 is grounded (0V)	OK	Restore wiring between pin 4 of B22 and ground G148b, across pin A3 of connector G23 (BLK)

FRONT RIGHT-HAND POWER WINDOW NOT WORKING		TEST B
TEST PROCEDURE	RESULT	CORRECTIVE ACTION
<b>B1</b> CHECK FUSE	OK	Carry out step B2
– Check for damage of wander fuse G310	OK	Replace fuse (25A)
<b>B2</b> CHECK VOLTAGE	OK	Carry out step B3
– With ignition key engaged and activating switch B21a in one of the two directions, verify 12 V between pins 1 and 2 of switch B21a	OK	Carry out step B4
<b>B3</b> CHECK MOTOR	OK	Replace motor P14
– With ignition key engaged and activating switch B21a in one of the two directions, verify 12 V between pins A and B of motor P14	OK	Restore wiring between: • pin 1 of B21a and pin A of P14 (WHI-RED) • pin 2 of B21a and pin B of P14 (PPL-WHT)
<b>B4</b> CHECK VOLTAGE	OK	Replace switch B21a
– With ignition key engaged, verify 12 V between pin 3 and 4 of switch B21a, and between pin 5 and 4 of the same switch	OK	Carry out step B5
<b>B5</b> CHECK GROUND	OK	Carry out step B6
– Check that pin 4 of B21a is grounded (0V)	OK	Restore wiring between pin 4 of B21a and ground G148b, across pin B4 of connector G21 (BLK)
<b>B6</b> CHECK VOLTAGE	OK	Restore wiring between: • pin 1 of B21b and pin 3 of B21a, across pin G1 of connector G23 and pin B1 of connector G21 (GRN-BLK) • pin 2 of B21b and pin 5 of B21a, across pin G2 of connector G23 and pin B2 of connector G21 (LFB)
– With ignition key engaged and activating switch B21b in one of the two directions, verify 12 V between pins 1 and 2 of switch B21b	OK	Carry out step B7
<b>B7</b> CHECK VOLTAGE	OK	Replace switch B21b
– With ignition key engaged, verify 12 V between pin 3 and 4 of switch B21b, and between pin 5 and 4 of the same switch	OK	Carry out step B8
<b>B8</b> CHECK GROUND	OK	Restore wiring between: • pin 3 of B21b and fuse G310, across pin G1 of connector G23 (RED) • pin 5 of B21b and pin 3 of B21b (RED)
– Check that pin 4 of B21b is grounded (0V)	OK	Restore wiring between pin 4 of B21b and ground G148b, across pin G4 of connector G23 (BLK)