

RELAYS IN ENGINE BAY

The relays in the engine bay are housed on brackets at the side of the battery, protected by special covers and their number varies according to the version of vehicle.

WARNING The arrangement of the fuses and relays may vary depending on the versions and markets. In the event of a suspected anomaly, contact Alfa Romeo Authorized Services.

Remove the cover (**A-fig. 53**) to gain access to the following relays (**fig. 54**):

- A.** Engine radiator cooling fan 2nd speed relay (only for T.SPARK versions with climate control system).
- B.** Engine radiator cooling fan 1st speed relay.
- C.** Fuel pump relay.
- D.** Electronic injection relay.
- E.** Climate control compressor relay.
- F.** Timing variator relay (1.6 T.SPARK only) or engine radiator fan 2nd speed relay (only 2.5 V6 24V and JTD).
- G.** Fuel oil heater relay (only JTD versions).




fig. 53




fig. 54