

Contents

Product range	A2	Motor-vehicle sensors from Bosch for the aftermarket and workshops	
	A3	Important information	
	A4	Motor-vehicle sensors	
Applications	B1	Notes for users	
	B2	Passenger vehicles, Transporters	
Cross-reference	C1	Part numbers	
	C2	Non-Bosch → Bosch	

The most comprehensive automotive aftermarket range:
Motor-vehicle sensors from Bosch for the aftermarket and workshops



The number of different sensors used in motor vehicles has increased dramatically in recent years. Bosch supplies replacement parts and diagnosis systems.

Even compact vehicle models are currently fitted with more than 50 individual sensors and sensor-based systems including the electronic stability program ESP for example.

The majority are not subject to wear, but accidents or other influences may cause damage. Of particular relevance to everyday workshop practice are hot-film air-mass meters, wheel-speed sensors, engine-speed sensors, pressure sensors and temperature sensors.

As the leading supplier of original-equipment automotive sensors, Bosch can also offer the most comprehensive aftermarket range in this sector. Suitable replacement parts can be found for nearly all repair applications. In addition, Bosch provides workshops with the essential electronic diagnosis techniques for the identification of defective sensors.

The Bosch sensor range comprises several hundred different types. The types of sensor based on ultra-modern micro electromechanical systems (MEMS) span a field of applications including pressure, acceleration and yaw-rate detection. The wide range of conventional measuring elements available extends from speed sensors and hot-film air-mass meters right through to sensors for automatic air-conditioning systems.

Counterfeit/imitation products: **Important information**



Warning about air-mass meters

Only genuine Bosch air-mass meters ensure compliance with the legally prescribed emission values.

The vehicle homologation will be invalidated if use is made of air-mass meters from other manufacturers. In addition, this can result in a considerable loss of engine power and thus higher fuel consumption.

Bosch products guarantee Bosch quality

This means:

- ▶ Satisfaction of customer requirements and expectations
- ▶ Bosch engineers pursue ambitious quality targets
- ▶ Innovation thanks to constant technological progress
- ▶ Broad Bosch range → High degree of market coverage
- ▶ Top performance, optimum operation
- ▶ Long service life
- ▶ Maximum reliability
- ▶ Compliance with all legal requirements and safety standards
- ▶ Excellent workmanship
- ▶ Environmental compatibility

Motor-vehicle sensors



Engine-speed and reference-mark sensors

System:
Motronic

Operation:

A ferromagnetic gear wheel with reference mark (tooth gap) is attached to the crankshaft. The speed sensor scans the tooth sequence. The electronic control unit uses the signal to calculate the crankshaft position and speed. Some systems are equipped with 2 sensors. Crankshaft position and speed are then measured separately.

Part number: **0 261 210 ...**

Yaw-rate sensor with acceleration sensor employing micromechanical technology

System:
ESP

Operation:

The measuring element of the yaw-rate sensor is produced using surface micromechanical technology and operates on the Coriolis principle. It makes use of the force of inertia of an oscillating mass in a rotating system. Thanks to its high operating frequency, fully digital evaluation electronics and closed control loop, the yaw-rate sensor element is extremely resistant to mechanical interference and vibration. The measuring element for the linear lateral and longitudinal acceleration determines vehicle acceleration on the basis of the capacitive change in the micromechanical structures. The high signal-detection and processing resolution in conjunction with the excellent noise characteristics of the sensor ensure a broad measuring range even with only slight lateral acceleration.

Part number:
0 265 005 2.., 0 265 005 6.., 0 265 005 7..

Active (Hall or AMR) speed sensor

System:
ABS/ASR/ESP

Operation:

The sensor ring of the active speed sensor takes the form of a multi-pole ring attached to the wheel hub. The alternately magnetized plastic elements are arranged in annular formation on a non-magnetic metallic carrier. These North and South poles assume the function of the sensor-ring teeth. A typical feature of the active speed sensor is the integration of the measuring element ("Hall" or magnetoresistive), the signal amplifier and the signal conditioning unit into one so-called IC (integrated circuit). There is a constant change in the magnetic flux through the IC as the multi-pole ring rotates. The speed information is transmitted as load-independent current in the form of square-wave pulses.

The frequency of the current pulses is proportional to the wheel speed. Detection is highly sensitive. So-called "intelligent" sensors are even capable of detecting whether the vehicle is moving forwards or backwards or is stationary.

Part number: **0 265 007 ..., 0 265 008 ...**



Passive (inductive) speed sensor

System:
ABS/ASR/ESP

Operation:

A constant magnetic field is generated in the sensor without a power supply. The sensor is located directly above a sensor ring attached to the wheel hub. As the sensor ring turns, the constantly alternating sequence of teeth and gaps causes interference in the magnetic field. This produces a change in the magnetic flux through the sensor components, thus inducing an AC voltage. Both the frequency and the amplitude of the AC voltage are proportional to the wheel speed, thus supplying the electronic control unit with information on the rate of rotation of the wheel.

Part number: **0 265 001 ...**, **0 265 006 ...**

Camshaft speed sensor

System:
Motronic

Operation:

The camshaft position indicates whether an engine piston moving towards top dead center is in the compression or exhaust stroke. The speed sensor at the camshaft (also referred to as phase sensor) passes this information to the electronic control unit. Such sensors are used where high accuracy is required. Further advantages include a comparatively large air-gap range and good temperature compensation.

Part number: **0 232 10. ...**

Throttle-valve potentiometer, throttle-valve sensor

Systems:
Mono-Jetronic, Motronic, Mono-Motronic

Operation:

Throttle-valve sensors are attached to the throttle-valve assembly or to the central injection unit. These sensors detect the position of the throttle valve and the angular velocity on opening and closing. The angular velocity is an important signal for the electronic control unit to provide compensation for load-change jolts and to prevent part-load bucking.

Note:

Throttle-valve sensors at central injection units cannot be replaced. The entire bottom section of the injection unit has to be renewed. The appropriate bottom section can be found in the replacement-parts program.

Part number: **0 261 211 ...**, **0 280 122 ...**

Motor-vehicle sensors



Air-mass meter

Systems:
LH-Jetronic, Motronic

Operation:

The air-mass meter is installed between the air cleaner and throttle valve and measures the intake-air mass. Use is made in practice of hot-wire and hot-film air-mass meters. Both sensors operate on the same principle: An electrically heated thin platinum wire or platinum film resistor is positioned in the intake-air flow together with a temperature sensor as temperature-sensitive resistor. The electronic control unit is supplied with a voltage signal proportional to the air-mass flow and uses this signal to calculate the quantity of fuel required.

Part number:

0 280 21. ..., **BX: 0 986 280 1.. (HLM)** and **0 986 280 2.. (HFM)**

Air-flow sensor

Systems:
L-Jetronic, Motronic

Operation:

The air flowing into the engine deflects a sensor plate in opposition to the restoring force of a spring. A potentiometer converts the deflection of the sensor plate into a voltage. The electronic control unit uses this signal to calculate the quantity of fuel required.

Part number:

0 280 200 ..., **0 280 201 ...**, **0 280 202 ...**,
0 280 203 ...,
BX: 0 986 280 0..

Air-flow sensor

Systems:
K- and KE-Jetronic, KE-Motronic

Operation:

The air-flow sensor and the fuel distributor together form the mixture-control unit. The two components are available separately and must be replaced separately. The air flowing through the air funnel moves the sensor plate by a certain amount. The sensor-plate deflection is transmitted by way of a lever system to the fuel distributor.

Part number:

0 438 120 ..., **0 438 121 ...**, **F 026 TX2 ...**,
BX: 0 986 439 ...



Pressure sensors (Motronic)

System:
Motronic

Operation:

Pressure sensors can be used for a variety of applications. Intake-manifold pressure sensors measure the absolute pressure in the intake manifold. These sensors are either integrated into the electronic control unit or fitted in the vicinity of the intake manifold in the form of externally mounted sensors. Modern systems featuring on-board diagnosis are additionally fitted with tank-pressure sensors. Modern DUO sensors combine pressure and temperature measurement.

Part number: **0 261 230 ...**

High-pressure sensor (DS-HD-KV)

Operation:

The sensor installed in the high-pressure fuel rail (KVS-HD) is designed to detect the fuel pressure level in the rail. The pressure measured is used as actual quantity for rail-pressure regulation.

Part number: **0 261 545 ...**

Knock sensors

System:
Motronic

Operation:

The knock sensor converts vibration into electric signals. This enables the electronic control unit to detect knocking combustion and to retard the ignition point to prevent engine damage. In some cases several sensors are attached to the engine block for knock-control purposes.

Part number: **0 261 231 ...**

Motor-vehicle sensors



Steering-angle sensor

System:
ESP/EHB

Operation:

The steering angle is output as an absolute value over the full angle range (turning range) of the steering column. The steering column drives two measurement gears by way of a gear wheel. All the gear wheels are located in the housing. The measurement gears are fitted with magnets. The angular position of the magnets is detected by measuring elements, the resistance of which changes depending on the direction of the magnetic field. The measurement gears have different numbers of teeth and their rotational position thus changes at different rates. The total angle can be calculated from the sum of the two current angles by way of a mathematical function and also checked for plausibility. This measurement principle can thus cover a measuring range of several steering wheel turns without a revolution counter.

Part number: **0 265 005 4.., 0 265 005 5..**

Pedal-travel sensor/accelerator-pedal module

System:
Motronic with EGAS

Operation:

In contrast to conventional engine-management systems, in the case of the Motronic with EGAS the driver's acceleration input is no longer relayed to the throttle valve via a cable. Instead, the input is detected using a pedal-travel sensor (also referred to as "electronic throttle control" or ETC) and transmitted to the electronic control unit. The accelerator-pedal module is a pre-assembled unit containing a vehicle-specific foot plate alongside the pedal-travel sensor. The Motronic control unit evaluates the sensor signal and adjusts the electric motor-driven throttle valve (throttle device or EMS positioner) taking into account other vehicle and engine data.

Part number:
0 205 001 ..., 0 280 752 ..., 0 280 755 ...


Temperature sensor (engine)

Systems:
D-, L- and LH-Jetronic,
K-Jetronic (with Lambda sensor),
KE-Jetronic, KE-Motronic, Motronic

Operation:

The coolant-temperature sensor measures the temperature in the coolant circuit and provides the electronic control unit with an electric signal. The sensor consists of an NTC thermistor embedded in a threaded sleeve or a plastic casing. The "coolant temperature" signal is particularly important for the starting and warm-up phase.

Part number: **0 261 220 ..., 0 280 130 ...**



Thermo-time switch

Systems:

D-, L, LH-, K- and KE-Jetronic, Motronic

Operation:

The thermo-time switch limits the injection period of the cold-start valve as a function of time and temperature. The switch consists of an electrically heated bimetallic element, which breaks or makes a contact. Triggering is by way of the ignition/starter switch.

Part number: **0 280 130 2..**

Lambda sensors

Further information can be found in the **Lambda sensors catalog**.

Catalog order number: **1 987 720 017**

How to use this catalogue

JAGUAR | B181

Product    

1 JAGUAR

Daimler

3.6	3.6l 136/165 kW ; AJ6.4 6 Zyl.
Raddrehzahlfühler, vorn	10.86-08.89 LAB 0 265 001 095
	RAB 0 265 001 094
Raddrehzahlfühler, hinten	10.86-08.89 0 265 001 096

2 Sovereign

2.9	2.9l 104 kW AJ 6 6 Zyl.
Geber, Drosselklappe	10.86-08.90 0 280 120 301
Luftmassenmesser, Benzineinspritzung	10.86-08.90 0 280 213 001
Impulsgeber, Zündung/Jetronic	10.86-08.90 0 261 210 041
Temperaturfühler, Kühlwasser Einspritzsystem	10.86-08.90 0 280 130 032
Raddrehzahlfühler, vorn	10.86-08.90 LAB 0 265 001 095
	RAB 0 265 001 094
Raddrehzahlfühler, hinten	10.86-08.90 0 265 001 096
2.9	2.9l 123 kW AJ 6 6 Zyl.
Geber, Drosselklappe	10.86-08.90 0 280 120 301
Luftmassenmesser, Benzineinspritzung	10.86-08.90 0 280 213 001
Temperaturfühler, Kühlwasser Einspritzsystem	10.86-08.90 0 280 130 032
Raddrehzahlfühler, vorn	10.86-08.90 LAB 0 265 001 095
	RAB 0 265 001 094
Raddrehzahlfühler, hinten	10.86-08.90 0 265 001 096
3.6	3.6l 135/170 kW AJ6.4 6 Zyl.
Raddrehzahlfühler, vorn	10.86-08.89 LAB 0 265 001 095
	RAB 0 265 001 094
Raddrehzahlfühler, hinten	10.86-08.89 0 265 001 096

3 XJ S Coupé

5.3	5.3l 183 kW 12 Zyl.
Relais, Jetronic	07.81-12.89 0 332 014 113
	DID 0 332 014 112
5.3	5.3l 183 kW HEV12 12 Zyl.
Relais, Jetronic	07.81-12.87 0 332 014 411
5.3 V12	5.3l 222-227 kW 12 Zyl.
Relais, Jetronic	03.90-12.97 0 332 014 113
	DID 0 332 014 112

4 XJ 6

2.9	2.9l 110 kW AJ6 6 Zyl.
Geber, Drosselklappe	10.86-12.88 0 280 120 301
Luftmassenmesser, Benzineinspritzung	10.86-12.88 0 280 213 001
Impulsgeber, Zündung/Jetronic	10.86-12.88 0 261 210 041
Temperaturfühler, Kühlwasser Einspritzsystem	10.86-12.88 0 280 130 032
Raddrehzahlfühler, vorn	10.86-12.88 LAB 0 265 001 095
	RAB 0 265 001 094
Fg.Nr. →594575	
Raddrehzahlfühler, hinten	10.86-12.88 0 265 001 096
Fg.Nr. →594575	
2.9	2.9l 123 kW AJ 6 6 Zyl.
Geber, Drosselklappe	10.86-08.90 0 280 120 301
Luftmassenmesser, Benzineinspritzung	10.86-08.90 0 280 213 001
Temperaturfühler, Kühlwasser Einspritzsystem	10.86-08.90 0 280 130 032
Raddrehzahlfühler, vorn	10.86-08.90 LAB 0 265 001 095
	RAB 0 265 001 094
Fg.Nr. →594575	

5

Product    

6

7

8

9

10

11

XJ 12

5.3 HE	5.3l 183 kW 12 Zyl.
Relais, Jetronic	07.81-09.94 DID 0 332 014 112
Raddrehzahlfühler, vorn	01.90-09.94 LAB 0 265 001 270
	RAB 0 265 001 269
Raddrehzahlfühler, hinten	01.90-09.94 LAB 0 265 001 272
	RAB 0 265 001 271
5.3 HE	5.3l 194 kW 12 Zyl.
Relais, Jetronic	07.81-09.94 0 332 014 411
Raddrehzahlfühler, vorn	01.90-09.94 LAB 0 265 001 270
	RAB 0 265 001 269
Raddrehzahlfühler, hinten	01.90-09.94 LAB 0 265 001 272
	RAB 0 265 001 271
5.3 HE	5.3l 197-198 kW 12 Zyl.
Raddrehzahlfühler, vorn	01.90-09.94 LAB 0 265 001 270
	RAB 0 265 001 269
Raddrehzahlfühler, hinten	01.90-09.94 LAB 0 265 001 272
	RAB 0 265 001 271

X-Type

2.0 [CF1]	2.1l 115 kW 2.1iV6 6 Zyl.
Raddrehzahlfühler, vorn	03.02→ 0 265 007 879
Raddrehzahlfühler, hinten	03.02→ AA 0 265 007 879
	LAB, NAA 0 265 007 417
	NAA, RAB 0 265 007 404
2.0 D [CF1]	2.0l 96 kW R4-X404 4 Zyl.
Raddrehzahlfühler, vorn	09.03→ 0 265 007 879
Raddrehzahlfühler, hinten	09.03→ AA 0 265 007 879
	LAB, NAA 0 265 007 417
	NAA, RAB 0 265 007 404
2.5 [CF1]	2.5l 145 kW 6 Zyl.
Raddrehzahlfühler, vorn	03.01→ 0 265 007 879
Raddrehzahlfühler, hinten	03.01→ AA 0 265 007 879
	LAB, NAA 0 265 007 417
	NAA, RAB 0 265 007 404

10

11

Bosch Automotive Aftermarket 2008 | 2009

X-Type ▶

1 Vehicle brand
Manufacturer indicated

2 Vehicle models
in alphabetical order

3 Model specifics
special vehicle information

4 Production period

5 Export country
Indicates the country for which
the product is intended

6 Icon explanations
See end of catalogue

7 Engine details
Displacement in liters (Ltr.)
Power output in kW
Engine designation
Number of cylinders

8 Order number
10-digit aftermarket
order number

9 Special notes
For explanations see end
of catalogue

10 Product name

11 Note
Continues on next page

de

Verwendungsteil

en

Applications

fr

Affectations

it

Impiego

es

Aplicación

Benutzerhinweise

In diesem Katalog sind die Daten von Fahrzeugen, Motoren und Geräten für den europäischen Markt von Baujahr 1986 bis einschließlich 2007 erfasst. Diese wurden aus Hersteller- und Importeurgaben, aus Fahrzeuguntersuchungen sowie aus Unterlagen von Bosch nach bestem Wissen sorgfältig zusammengestellt und geben den Stand zum Zeitpunkt der Drucklegung wieder.

Zwangsläufige Abweichungen durch länderspezifische technische Änderungen können nie ganz ausgeschlossen werden. Bosch kann daher insoweit nicht für die Vollständigkeit und Fehlerfreiheit der Daten haften. Für Irrtümer und Druckfehler, die zu Schäden am Eigentum oder Vermögen führen, haftet Bosch nur bei grob fahrlässiger Pflichtverletzung und bei Vorsatz für unmittlere Schäden. Bei Personenschäden haftet Bosch auch bei leichter Fahrlässigkeit.

Bitte beachten Sie: Durch die Umstellung auf die neueste Ausführung aus der Erstausrüstung können bei manchen Verwendungen zwischen den Bestellnummern für Neuware und Austausch unterschiedliche Leistungsangaben auftreten.

Notes for users

This catalog contains the data from the vehicles, engines, and equipment for the European market from year of manufacture 1986 up to and including the year 2007. This data has been assembled from information provided by manufacturers and importers, and taken from Bosch documentation, as well as from investigations made on vehicles. It has been compiled to the best of our knowledge and belief, and reflects the status at the date of going to print.

It is impossible to avoid deviations caused by technical changes resulting from the conditions and regulations applying in a particular country. Bosch can therefore accept no liability for the completeness and faultlessness of the data. In case of mistakes and misprints which result in damage to property or assets, Bosch is only liable for immediate damages insofar as a gross breach of duty or wrongful intent apply. If personal injury is involved, Bosch is liable also in case of ordinary negligence.

Please note: For some applications, the performance data given with the part numbers for exchange and new products can differ due to the change over to the latest OE version.

A l'attention de l'utilisateur

Le présent catalogue mentionne les données spécifiques de véhicules, moteurs et appareils pour le marché européen depuis l'année de fabrication 1986 jusqu'au millésime 2007 inclus. Ces informations ont été rassemblées soigneusement et en toute impartialité à partir des indications des constructeurs et importateurs, des contrôles techniques des véhicules et de la documentation Bosch, et matérialisent le stade des connaissances au moment de la mise sous presse.

Il n'est jamais possible d'exclure totalement les divergences éventuelles dues aux modifications techniques, spécifiques des différents pays considérés. En aucun cas, Bosch n'engage sa responsabilité en ce qui concerne l'intégralité et l'exactitude des données. En ce qui concerne les erreurs et les fautes d'impression, qui peuvent entraîner des dommages à la propriété ou à la fortune, Bosch n'engage sa responsabilité pour les dommages directs qu'en cas d'atteinte et de négligence graves et intentionnelles envers ses obligations. En cas de dommages causés aux personnes, Bosch engage sa responsabilité aussi en cas de légère négligence.

Veuillez faire attention, pour certaines applications, la puissance donnée pour l'échange standard peut être différente de celle du produit neuf car nous donnons la puissance de la dernière version d'origine.

Avvertenze per la consultazione

Nella seguente parte di catalogo sono contemplati veicoli, motori ed apparecchi a partire dall'anno di costruzione 1986 fino all'anno 2007. Tali informazioni sono state rilevate dalle documentazioni di Case Auto, Importatori, da verifiche eseguite sui veicoli, così come da documentazione Bosch.

Eventuali discordanze dovute a specifiche esigenze del Paese e variazioni tecniche non possono essere previste. Per questo Bosch non si assume alcuna responsabilità per mancanze ed eventuali errori riferite ai dati. Per danni a cose o danni patrimoniali, dovuti ad errori o refusi di stampa, Bosch è responsabile solo in caso di dolo o colpa grave. Per danni alla persona, Bosch è responsabile anche in caso di colpa meno grave.

Prego prestare attenzione: dopo gli ultimi cambiamenti intervenuti potranno verificarsi delle differenze tra il numero d'ordine per prodotto nuovo ed il rigenerato del primo equipaggiamento.

Avertencia al usuario

Los datos recogidos en este catálogo para vehículos, motores y maquinaria del mercado europeo abarcan los años de fabricación entre 1986 y 2007, inclusive. Estos datos han sido recogidos del fondo documental de Bosch, así como de las inspecciones de vehículos, datos de fabricantes e importadores.

No obstante, y debido al cuantioso material de información, no se puede excluir la posibilidad de modificaciones, diferencias propias de aplicaciones específicas de los países, fallos, equivocaciones o errores. En caso de inexactitudes y errores de imprenta, la responsabilidad de Bosch se limita al daño inmediato, con posibles perjuicios patrimoniales, a no ser que el daño previsible y típico del contrato sea de mayor cuantía o se deba a dolo o culpa intencionada o a negligencia grave.

Atención: Con la introducción de nuevas versiones en los primeros equipos algunas aplicaciones pueden contener tanto para las referencias de gama original como para las de intercambio distintas equivalencias.

Product



ALFA ROMEO			
Brera			
2.2 JTS [939]2,2l 136 kW 939A5000 4 Zyl.			
Air mass meter, gasoline injection	01.06→		0 280 218 164
Phase sensor	01.06→		0 232 103 052
Wheel speed sensor, front	01.06→		0 265 008 055
Wheel speed sensor, rear	01.06→		0 265 008 056
2.4 JTDM 20V [939]2,4l 147 kW 939A3000 5 Zyl.			
Air mass meter, diesel	04.06→		0 281 002 763
Boost pressure sensor, Diesel	04.06→		0 281 002 437
Wheel speed sensor, front	04.06→		0 265 008 055
Wheel speed sensor, rear	04.06→		0 265 008 056
2.4 JTDM 20V [939]2,4l 154 kW 939A9000 5 Zyl.			
Air mass meter, diesel	05.07→		0 281 002 764
Boost pressure sensor, Diesel	05.07→		0 281 002 437
Wheel speed sensor, front	05.07→		0 265 008 055
Wheel speed sensor, rear	05.07→		0 265 008 056
3.2 JTS 24V Q4 [939]3,2l 191 kW 939A000 6 Zyl.			
Air mass meter, gasoline injection	01.06→		0 280 218 182
Wheel speed sensor, front	01.06→		0 265 008 055
Wheel speed sensor, rear	01.06→		0 265 008 056

Coupé SZ			
3.0V6 [139]3,0l 154 kW AR 61501 6 Zyl.			
Air flow sensor, gasoline injection	03.89-12.91		0 280 202 205
Speed sensor, ignition/injection	03.89-12.91		0 261 210 036


GT			
1.8 TS [937]1,8l 106 kW AR32205 4 Zyl.			
Throttle valve assembly			
Mot.no. →3649574	10.03-04.04		0 280 750 102
Mot.no. 3649575→	05.04→		1 287 213 612
Air mass meter, gasoline injection	10.03-03.06		0 281 002 309
Phase sensor	10.03→		0 232 101 035
Speed sensor, ignition/injection	10.03→		0 261 210 227
Knock sensor	10.03→		0 261 231 131
Yaw rate sensor, brake system	10.03→		0 265 005 241
Pressure sensor, ESP, (electronic stability program)			
Ricam.no →0045014	10.03-11.05		0 265 005 303
Wheel speed sensor, front	10.03→	LAB	0 265 007 486
		RAB	0 265 007 487
Wheel speed sensor, rear	10.03→		0 265 007 488
1.9 JTD 16V [937]1,9l 103 kW 937A5000 4 Zyl.			
Air mass meter, diesel	10.03→		0 280 218 120
High-pressure sensor (CR system)	10.03→		0 281 002 534
Yaw rate sensor, brake system	10.03→		0 265 005 241
Pressure sensor, ESP, (electronic stability program)			
Ricam.no →0045014	10.03-11.05		0 265 005 303
Wheel speed sensor, front	10.03→	LAB	0 265 007 486
		RAB	0 265 007 487
Wheel speed sensor, rear	10.03→		0 265 007 488
1.9 JTD 16V [937]1,9l 110 kW 937A5000 4 Zyl.			
Air mass meter, diesel	01.04→		0 281 002 792
High-pressure sensor (CR system)	01.04→		0 281 002 706
Yaw rate sensor, brake system	01.04→		0 265 005 241
Pressure sensor, ESP, (electronic stability program)			
Ricam.no →0045014	01.04-11.05		0 265 005 303

Product



Wheel speed sensor, front	01.04→	LAB	0 265 007 486
		RAB	0 265 007 487
Wheel speed sensor, rear	01.04→		0 265 007 488
2.0 JTS [937]2,0l 120/121 kW 932A2000; 937A1000 4 Zyl.			
Throttle valve assembly			
Mot.no. →3649574	10.03-04.04		0 280 750 102
Mot.no. 3649575→	05.04→		1 287 213 612
Air mass meter, gasoline injection	10.03→		0 280 218 120
Phase sensor	10.03→		0 232 101 035
Speed sensor, ignition/injection	10.03→		0 261 210 227
Knock sensor	10.03-12.05		0 261 231 148
			0 261 231 173
Yaw rate sensor, brake system	10.03→		0 265 005 241
Pressure sensor, ESP, (electronic stability program)			
Ricam.no →0045014	10.03-11.05		0 265 005 303
Wheel speed sensor, front	10.03→	LAB	0 265 007 486
		RAB	0 265 007 487
Wheel speed sensor, rear	10.03→		0 265 007 488
3.2 V6 [937]3,2l 176 kW 936A000 6 Zyl.			
Throttle valve assembly			
Air mass meter, gasoline injection	10.03→		0 280 750 014
Phase sensor	10.03→		0 281 002 533
Speed sensor, ignition/injection	10.03→		0 261 210 203
Knock sensor	10.03→	LAB	0 261 231 152
		RAB	0 261 231 153
Yaw rate sensor, brake system	10.03→		0 265 005 241
Pressure sensor, ESP, (electronic stability program)			
Ricam.no →0045014	10.03-11.05		0 265 005 303
Wheel speed sensor, front	10.03→	LAB	0 265 007 486
		RAB	0 265 007 487
Wheel speed sensor, rear	10.03→		0 265 007 488

GTV			
1.8 T.S. 16V [916]		1,8l	106 kW AR 32201 4 Zyl.
Throttle valve assembly	05.98-12.00		3 437 010 460
Air mass meter, gasoline injection	04.99-12.00		0 280 218 019
	05.98-03.99		0 281 002 199
Phase sensor	05.98-12.00		0 232 101 035
Speed sensor, ignition/injection	05.98-12.00		0 261 210 160
Knock sensor	05.98-12.00		0 261 231 131
Vacuum pickup, ignition/injection	05.98-12.00		0 928 400 327
Wheel speed sensor, front			
Ricam.no →6063041	05.98-12.00		0 265 006 212
Ricam.no 6063042→	05.98-12.00	LAB	0 265 007 073
		RAB	0 265 007 074
Wheel speed sensor, rear	05.98-11.99	LAB	0 265 006 260
	12.99-12.00	LAB	0 265 007 098
	05.98-11.99	RAB	0 265 006 261
	12.99-12.00	RAB	0 265 007 099
2.0 JTS [916]		2,0l	121 kW 937A1.000 4 Zyl.
Throttle valve assembly	04.03-12.05		0 280 750 102
Air mass meter, gasoline injection	04.03-12.05		0 280 218 113
Phase sensor	04.03-12.05		0 232 101 035
Speed sensor, ignition/injection	04.03-12.05		0 261 210 227
Knock sensor	04.03-12.05		0 261 231 148
Wheel speed sensor, front	04.03-12.05	LAB	0 265 007 073
		RAB	0 265 007 074
Wheel speed sensor, rear	04.03-12.05	LAB	0 265 007 098
		RAB	0 265 007 099
2.0 T.S. 16V [916]		2,0l	110 kW AR 16201 4 Zyl.
Throttle valve sensor	04.95-04.98		0 280 122 001
Air mass meter, gasoline injection	04.95-04.98		0 280 217 111



Phase sensor	04.95-04.98		0 232 101 026
Speed sensor, ignition/injection	04.95-04.98		0 261 210 129
Knock sensor	04.95-04.98		0 261 231 007
Temperature sensor, intake air, injection system	04.95-04.98		0 280 130 073
Temperature sensor, coolant, injection system	04.95-04.98		0 280 130 026
Wheel speed sensor, front	04.95-04.98		0 265 006 212
Wheel speed sensor, rear	04.95-04.98	LAB	0 265 006 260
		RAB	0 265 006 261
2.0 T.S. 16V [916] 2,0l 110 kW AR 32310 4 Zyl.			
Throttle valve assembly			
Mot.no. →3649574	08.00-04.04		0 280 750 102
Mot.no. 3649575→	05.04-12.05		1 287 213 612
Throttle valve sensor	08.00-12.05		0 280 122 001
Air mass meter, gasoline injection	08.00-12.05		0 281 002 309
Phase sensor	08.00-12.05		0 232 101 035
Speed sensor, ignition/injection			
Mot.no. →3649574	08.00-12.05		0 261 210 160
Mot.no. 3649575→	08.00-12.05		0 261 210 227
Knock sensor	08.00-12.05		0 261 231 131
Vacuum pickup, ignition/injection	08.00-12.05		0 928 400 327
Temperature sensor, intake air, injection system	08.00-12.05		0 280 130 073
Temperature sensor, coolant, injection system	08.00-12.05		0 280 130 026
Wheel speed sensor, front	08.00-12.05	LAB	0 265 007 073
		RAB	0 265 007 074
Wheel speed sensor, rear	08.00-12.05	LAB	0 265 007 098
		RAB	0 265 007 099
2.0 T.S. 16V [916] 2,0l 114 kW AR 32301 4 Zyl.			
Throttle valve sensor	05.98-07.00		3 437 010 455
Phase sensor	05.98-07.00		0 232 101 035
Speed sensor, ignition/injection	05.98-07.00		0 261 210 160
Knock sensor	05.98-07.00		0 261 231 131
Temperature sensor, intake air, injection system	05.98-07.00		0 280 130 073
Temperature sensor, coolant, injection system	05.98-07.00		0 280 130 026
Wheel speed sensor, front			
Ricam.no →6063041	05.98-07.00		0 265 006 212
Ricam.no 6063042→	05.98-07.00	LAB	0 265 007 073
		RAB	0 265 007 074
Wheel speed sensor, rear	05.98-11.99	LAB	0 265 006 260
		RAB	0 265 006 261
2.0 V6 Turbo [916] 2,0l 148 kW AR 16202 6 Zyl.			
Throttle valve sensor	04.95-07.00		0 280 120 435
Air flow sensor, gasoline injection	04.95-07.00		0 280 203 034
Phase sensor	04.95-07.00		0 356 914 224
Pulse generator, ignition/Jetronic	04.95-07.00		0 261 210 036
Knock sensor	04.95-07.00		0 261 231 007
Pressure sensor, intake manifold, gasoline	04.95-07.00	HL	0 280 101 001
Wheel speed sensor, front	04.95-11.99		0 265 006 162
	12.99-07.00	LAB	0 265 007 073
		RAB	0 265 007 074
Wheel speed sensor, rear	04.95-11.99	LAB	0 265 006 260
	12.99-07.00	LAB	0 265 007 098
	04.95-11.99	RAB	0 265 006 261
	12.99-07.00	RAB	0 265 007 099
3.0 V6 24V [916] 3,0l 160 kW AR 16105 6 Zyl.			
Throttle valve assembly	08.00-12.05		0 280 750 014
Throttle valve sensor	08.00-12.05		0 280 122 001
Air mass meter, gasoline injection	08.00-12.05		0 280 218 054
Phase sensor	08.00-12.05		0 232 103 024
Speed sensor, ignition/injection	08.00-12.05		0 261 210 203
Temperature sensor, intake air, injection system	08.00-12.05		0 280 130 073
Temperature sensor, coolant, injection system	08.00-12.05		0 280 130 055
Wheel speed sensor, front	08.00-12.05	LAB	0 265 007 073
		RAB	0 265 007 074



Wheel speed sensor, rear	08.00-12.05	LAB	0 265 007 098
		RAB	0 265 007 099
3.0 V6 24V [916] 3,0l 162 kW AR 16102 6 Zyl.			
Throttle valve sensor	11.96-07.00		0 280 122 001
Air mass meter, gasoline injection	11.96-03.98		0 280 217 514
	04.98-07.00		0 280 217 531
Phase sensor	11.96-03.98		0 232 103 009
Speed sensor, ignition/injection	11.96-02.98		0 261 210 113
	03.98-07.00		0 261 210 163
Knock sensor	11.96-07.00		0 261 231 007
Temperature sensor, intake air, injection system	11.96-07.00		0 280 130 073
Temperature sensor, coolant, injection system	11.96-07.00		0 280 130 055
Wheel speed sensor, front	11.96-11.99		0 265 006 162
	12.99-07.00	LAB	0 265 007 073
		RAB	0 265 007 074
Wheel speed sensor, rear	11.96-11.99	LAB	0 265 006 260
	12.99-07.00	LAB	0 265 007 098
	11.96-11.99	RAB	0 265 006 261
	12.99-07.00	RAB	0 265 007 099
3.2 V6 24V [916] 3,2l 176 kW 936A6.000 6 Zyl.			
Throttle valve assembly	04.03-12.05		0 280 750 014
Air mass meter, gasoline injection	04.03-12.05		0 281 002 533
Phase sensor	04.03-12.05		0 232 103 009
Speed sensor, ignition/injection	04.03-12.05		0 261 210 203
Wheel speed sensor, front	04.03-12.05	LAB	0 265 007 073
		RAB	0 265 007 074
Wheel speed sensor, rear	04.03-12.05	LAB	0 265 007 098
		RAB	0 265 007 099

GTV 6

2.5 i.e. 2,5l 110 kW 019.11 Kat. 6 Zyl.			
Throttle valve sensor	09.82-02.87		0 280 120 302
Air flow sensor, gasoline injection	01.81-02.87		0 280 202 010
Pressure sensor, intake manifold, gasoline	09.84-02.87	HL	0 280 101 001
Temperature sensor, coolant, injection system	01.81-02.87		0 280 130 023
Relay, Jetronic	09.82-02.87	WEI	0 332 514 127
2.5 i.e. 2,5l 116-118 kW 016.46 6 Zyl.			
Throttle valve sensor	11.80-02.87		0 280 120 302
Air flow sensor, gasoline injection	11.80-02.87		0 280 202 013
Temperature sensor, coolant, injection system	11.80-02.87		0 280 130 023
Relay, Jetronic	11.80-02.87	15A	0 332 514 121

Roadster RZ

3.0 V6 Zagato [139] 3,0l 154 kW AR 61501 6 Zyl.			
Air flow sensor, gasoline injection	01.92-12.93		0 280 202 205
Speed sensor, ignition/injection	01.92-12.93		0 261 210 036

Spider

1.8 T.S. 16V [916] 1,8l 106 kW AR 32201 4 Zyl.			
Throttle valve assembly	05.98-07.00		3 437 010 460
Phase sensor	05.98-07.00		0 232 101 035
Speed sensor, ignition/injection	05.98-07.00		0 261 210 160
Knock sensor	05.98-07.00		0 261 231 131
Wheel speed sensor, front	09.99-11.99		0 265 006 212
	12.99-07.00	LAB	0 265 007 073
		RAB	0 265 007 074
Wheel speed sensor, rear	05.98-11.99	LAB	0 265 006 260
	12.99-07.00	LAB	0 265 007 098
	05.98-11.99	RAB	0 265 006 261
	12.99-07.00	RAB	0 265 007 099



Product



◀ Spider

2.0 i.e. [105]		2,0l 86 kW 015.44 4 Zyl.	
Throttle valve sensor	10.81-12.89	0 280 120 304	
Speed sensor, ignition/injection	03.86-12.89	0 261 210 002	
Pulse generator, ignition/Jetronic	10.81-02.86	0 261 210 001	
Pressure sensor, intake manifold, gasoline	09.84-12.89	HL	0 280 101 001
Temperature sensor, coolant, injection system	10.81-12.89	0 280 130 023	
Relay, Jetronic	10.81-12.89	0 280 230 001	
		LAH	0 332 014 125
2.0 i.e. [115]		2,0l 88/93 kW AR 01588; AR 01590 4 Zyl.	
Throttle valve sensor	01.90-12.94	0 280 120 300	
Speed sensor, ignition/injection	01.90-12.94	0 261 210 036	
Temperature sensor, coolant, injection system	01.90-12.94	0 280 130 026	
2.0 JTS [916]		2,0l 121 kW 937A1.000 4 Zyl.	
Throttle valve assembly	04.03-04.04	0 280 750 102	
	05.04-02.06	1 287 213 612	
Air mass meter, gasoline injection	04.03-02.06	0 280 218 113	
Phase sensor	04.03-02.06	0 232 101 035	
Speed sensor, ignition/injection	04.03-02.06	0 261 210 227	
Knock sensor	04.03-12.05	0 261 231 148	
	01.06-02.06	0 261 231 173	
Wheel speed sensor, front	04.03-02.06	LAB	0 265 007 073
		RAB	0 265 007 074
Wheel speed sensor, rear	04.03-02.06	LAB	0 265 007 098
		RAB	0 265 007 099
2.0 T.S. 16V [916]		2,0l 110 kW AR 16201 4 Zyl.	
Throttle valve assembly	04.95-04.98	3 437 010 460	
Throttle valve sensor	04.95-04.98	0 280 122 001	
Air mass meter, gasoline injection	04.95-02.98	0 280 217 111	
Phase sensor	04.95-02.98	0 232 101 026	
Speed sensor, ignition/injection	04.95-02.98	0 261 210 129	
Knock sensor	04.95-02.98	0 261 231 095	
Temperature sensor, intake air, injection system	04.95-04.98	0 280 130 073	
Temperature sensor, coolant, injection system	04.95-04.98	0 280 130 026	
Wheel speed sensor, front			
Ricam.no →6063041	04.95-04.98	0 265 006 212	
Ricam.no 6063042→	04.95-04.98	LAB	0 265 007 073
		RAB	0 265 007 074
Wheel speed sensor, rear	04.95-02.98	0 265 006 197	
2.0 T.S. 16V [916]		2,0l 110 kW AR 32310 CF3 4 Zyl.	
Throttle valve assembly			
	Mot.no. →3649574	08.00-04.04	0 280 750 102
Mot.no. 3649575→	05.04-02.06	1 287 213 612	
Throttle valve sensor	08.00-02.06	0 280 122 001	
Air mass meter, gasoline injection	08.00-02.06	0 281 002 309	
Phase sensor	08.00-02.06	0 232 101 035	
Speed sensor, ignition/injection			
Mot.no. →3649574	08.00-02.06	0 261 210 160	
Mot.no. 3649575→	08.00-02.06	0 261 210 227	
Knock sensor	08.00-02.06	0 261 231 131	
Vacuum pickup, ignition/injection	08.00-02.06	0 928 400 327	
Temperature sensor, intake air, injection system	08.00-02.06	0 280 130 073	
Temperature sensor, coolant, injection system	08.00-02.06	0 280 130 026	
Wheel speed sensor, front	08.00-02.06	LAB	0 265 007 073
		RAB	0 265 007 074
Wheel speed sensor, rear	08.00-02.06	LAB	0 265 007 098
		RAB	0 265 007 099
2.0 T.S. 16V [916]		2,0l 114 kW AR 32301 4 Zyl.	
Throttle valve sensor	05.98-07.00	3 437 010 455	
Air mass meter, gasoline injection	04.99-07.00	0 280 218 019	
	05.98-03.99	0 281 002 199	
Phase sensor	05.98-07.00	0 232 101 035	
Speed sensor, ignition/injection	05.98-07.00	0 261 210 160	
Knock sensor	05.98-07.00	0 261 231 131	

Product



Temperature sensor, intake air, injection system	05.98-07.00		0 280 130 073
Temperature sensor, coolant, injection system	05.98-07.00		0 280 130 026
Wheel speed sensor, front			
Ricam.no →6063041	05.98-07.00		0 265 006 212
Ricam.no 6063042→	05.98-07.00	LAB	0 265 007 073
		RAB	0 265 007 074
Wheel speed sensor, rear	05.98-11.99	LAB	0 265 006 260
		RAB	0 265 006 261
2.0 V6 Turbo [916]	2,0l	147 kW	AR 16202 4 Zyl.
Throttle valve sensor	04.98-12.00		0 280 120 435
Air flow sensor, gasoline injection	04.98-12.00		0 280 203 034
Phase sensor	04.98-12.00		0 356 914 224
Pulse generator, ignition/Jetronic	04.98-12.00		0 261 210 036
Knock sensor	04.98-12.00		0 261 231 007
Pressure sensor, intake manifold, gasoline	04.98-12.00	HL	0 280 101 001
Wheel speed sensor, front	04.98-11.99		0 265 006 162
	12.99-12.00	LAB	0 265 007 073
		RAB	0 265 007 074
Wheel speed sensor, rear	12.99-12.00	LAB	0 265 007 098
		RAB	0 265 007 099
2.2 JTS [939]	2,2l	140 kW	939A5000 4 Zyl.
Air mass meter, gasoline injection	03.06→		0 280 218 164
Phase sensor	03.06→		0 232 103 052
Wheel speed sensor, front	03.06→		0 265 008 055
Wheel speed sensor, rear	03.06→		0 265 008 056
2.4 JTDM 20V [939]	2,4l	147 kW	939A3000 5 Zyl.
Air mass meter, diesel	03.07→		0 281 002 763
Boost pressure sensor, Diesel	03.07→		0 281 002 437
Wheel speed sensor, front	03.07→		0 265 008 055
Wheel speed sensor, rear	03.07→		0 265 008 056
3.0 V6 12V [916]	3,0l	141 kW	AR 16101; AR 16199 6 Zyl.
Throttle valve sensor	04.95-02.06		0 280 122 001
Air mass meter, gasoline injection	04.95-02.06		0 280 217 514
Phase sensor	04.95-02.06		0 232 103 009
Pulse generator, ignition/Jetronic	04.95-02.06		0 261 210 113
Knock sensor	04.95-02.98		0 261 231 007
	03.98-02.06		0 261 231 131
Temperature sensor, intake air, injection system	04.95-02.06		0 280 130 073
Temperature sensor, coolant, injection system	04.95-02.06		0 280 130 026
Wheel speed sensor, front	04.95-11.99		0 265 006 162
	12.99-02.06	LAB	0 265 007 073
		RAB	0 265 007 074
Wheel speed sensor, rear	04.95-02.98		0 265 006 197
	03.98-11.99	LAB	0 265 006 260
	12.99-02.06	LAB	0 265 007 098
	03.98-11.99	RAB	0 265 006 261
	12.99-02.06	RAB	0 265 007 099
3.0 V6 24V [916]	3,0l	162 kW	AR 16105 CF3 6 Zyl.
Throttle valve assembly	08.00-03.03		0 280 750 014
Throttle valve sensor	08.00-03.03		0 280 122 001
Air mass meter, gasoline injection	08.00-03.03		0 280 218 054
Phase sensor	08.00-03.03		0 232 103 024
Speed sensor, ignition/injection	08.00-03.03		0 261 210 203
Temperature sensor, intake air, injection system	08.00-03.03		0 280 130 073
Temperature sensor, coolant, injection system	08.00-03.03		0 280 130 055
Wheel speed sensor, front	08.00-03.03	LAB	0 265 007 073
		RAB	0 265 007 074
Wheel speed sensor, rear	08.00-03.03	LAB	0 265 007 098
		RAB	0 265 007 099
3.2 JTS 24V Q4 [939]	3,2l	195 kW	939A000 6 Zyl.
Air mass meter, gasoline injection	09.06→		0 280 218 182
Wheel speed sensor, front	09.06→		0 265 008 055
Wheel speed sensor, rear	09.06→		0 265 008 056



3.2 V6 24V [916]		3,2l 176 kW 936A6.000 6 Zyl.
Throttle valve assembly	04.03-02.06	0 280 750 014
Air mass meter, gasoline injection	04.03-02.06	0 281 002 533
Phase sensor	04.03-02.06	0 232 103 009
Speed sensor, ignition/injection	04.03-02.06	0 261 210 203
Wheel speed sensor, front	04.03-02.06	LAB 0 265 007 073
		RAB 0 265 007 074
Wheel speed sensor, rear	04.03-02.06	LAB 0 265 007 098
		RAB 0 265 007 099

Sprint

1.7 i.e.		1,7l 77 kW 305.58 Kat. 4 Zyl.
Throttle valve sensor	10.87-12.89	0 280 120 315
Air flow sensor, gasoline injection	10.87-12.89	0 280 200 601
Temperature sensor, coolant, injection system	10.87-12.89	0 280 130 026
Relay, Jetronic	10.87-12.89	0 332 014 113

6

2.5 i.e.		2,5l 110 kW 019.28 Kat. 6 Zyl.
Throttle valve sensor	09.79-12.86	0 280 120 302
Air flow sensor, gasoline injection	09.79-12.86	0 280 202 010
Pressure sensor, intake manifold, gasoline	09.84-12.86	HL 0 280 101 001
Temperature sensor, coolant, injection system	09.79-12.86	0 280 130 023
Relay, Jetronic	09.82-12.86	WEI 0 332 514 127
2.5 i.e.		2,5l 117 kW 019.28 6 Zyl.
Throttle valve sensor	09.83-12.86	0 280 120 302
Air flow sensor, gasoline injection	09.83-12.86	0 280 202 013
Temperature sensor, coolant, injection system	09.83-12.86	0 280 130 023
Relay, Jetronic	09.83-12.86	WEI 0 332 514 127
		15A 0 332 514 121

33 Berlina

1.3 I.E. [907]		1,3l 65 kW AR30753 MPI-Weber 4 Zyl.	
Wheel speed sensor, front	09.91-10.94	0 265 003 061	
Wheel speed sensor, rear	09.91-10.94	LAB	0 265 003 066
		RAB	0 265 003 062
1.4 I.E. [907]		1,4l 64 kW AR30755 KAT 4 Zyl.	
Throttle valve sensor	09.91-09.94	0 280 120 315	
Air flow sensor, gasoline injection	09.91-09.94	0 280 200 601	
Temperature sensor, coolant, injection system	09.91-09.94	0 280 130 026	
Wheel speed sensor, front	09.91-09.94	0 265 003 061	
Wheel speed sensor, rear	09.91-09.94	LAB	0 265 003 066
		RAB	0 265 003 062
1.5 I.E. [907]		1,5l 70 kW AR30738; AR30751 4 Zyl.	
Throttle valve sensor	04.92-10.94	0 280 122 001	
Speed sensor, ignition/injection	04.92-10.94	0 261 210 036	
Temperature sensor, coolant, injection system	04.92-10.94	0 280 130 026	
Wheel speed sensor, front	04.92-10.94	0 265 003 061	
Wheel speed sensor, rear	04.92-10.94	LAB	0 265 003 066
		RAB	0 265 003 062
1.5 I.E. [907]		1,5l 70-72/74 kW AR30750; AR30751 KAT 4 Zyl.	
Throttle valve sensor	06.90-10.94	0 280 120 315	
Air flow sensor, gasoline injection	06.90-10.94	0 280 200 601	
Temperature sensor, coolant, injection system	06.90-10.94	0 280 130 026	
Wheel speed sensor, front	06.90-10.94	0 265 003 061	
Wheel speed sensor, rear	06.90-10.94	LAB	0 265 003 066
		RAB	0 265 003 062
1.5 I.E. 4x4 [907]		1,5l 70 kW AR30751 4 Zyl.	
Throttle valve sensor	04.92-10.94	0 280 122 001	
Speed sensor, ignition/injection	04.92-10.94	0 261 210 036	



Temperature sensor, coolant, injection system	04.92-10.94		0 280 130 026
Wheel speed sensor, front	04.92-10.94		0 265 003 061
Wheel speed sensor, rear	04.92-10.94	LAB	0 265 001 267
		RAB	0 265 001 268
1.7 I.E. [905]	1,7 l	77 kW	AR30558 4 Zyl.
Throttle valve sensor	10.87-12.89		0 280 120 315
Air flow sensor, gasoline injection	10.87-12.89		0 280 200 601
Temperature sensor, coolant, injection system	10.87-12.89		0 280 130 026
Relay, Jetronic	10.87-12.89		0 332 014 113
1.7 I.E. [907]	1,7 l	77 kW	AR30740 4 Zyl.
Throttle valve sensor	04.92-10.94		0 280 122 001
Speed sensor, ignition/injection	04.92-10.94		0 261 210 036
Temperature sensor, coolant, injection system	04.92-10.94		0 280 130 039
Wheel speed sensor, front	04.92-10.94		0 265 003 061
Wheel speed sensor, rear	04.92-10.94	LAB	0 265 003 066
		RAB	0 265 003 062
1.7 I.E. [907]	1,7 l	79 kW	AR30736; AR30737 4 Zyl.
Throttle valve sensor	01.90-03.92		0 280 120 315
Air flow sensor, gasoline injection	01.90-03.92		0 280 200 601
Temperature sensor, coolant, injection system	01.90-03.92		0 280 130 026
Wheel speed sensor, front	01.90-03.92		0 265 003 061
Wheel speed sensor, rear	01.90-03.92	LAB	0 265 003 066
		RAB	0 265 003 062
1.7 I.E. 4x4 [907]	1,7 l	77 kW	AR30737 4 Zyl.
Throttle valve sensor	04.92-10.94		0 280 122 001
Speed sensor, ignition/injection	04.92-10.94		0 261 210 036
Temperature sensor, coolant, injection system	04.92-10.94		0 280 130 039
Wheel speed sensor, front	04.92-10.94		0 265 003 061
Wheel speed sensor, rear	04.92-10.94	LAB	0 265 001 267
		RAB	0 265 001 268
1.7 I.E. 4x4 [907]	1,7 l	79 kW	AR30736; AR30737 KAT 4 Zyl.
Throttle valve sensor	07.90-03.92		0 280 120 315
Air flow sensor, gasoline injection	07.90-03.92		0 280 200 601
Temperature sensor, coolant, injection system	07.90-03.92		0 280 130 026
Wheel speed sensor, front	07.90-03.92		0 265 003 061
Wheel speed sensor, rear	07.90-03.92	LAB	0 265 001 267
		RAB	0 265 001 268
1.7 I.E. 16V [907]	1,7 l	95/98 kW	AR30746; AR30747 4 Zyl.
Throttle valve sensor	01.90-10.94		0 280 120 304
Air flow sensor, gasoline injection	01.90-10.94		0 280 202 206
		🌀	0 986 280 065
Speed sensor, ignition/injection	01.90-10.94		0 261 210 036
Temperature sensor, coolant, injection system	01.90-10.94		0 280 130 026
Wheel speed sensor, front	01.90-10.94		0 265 003 061
Wheel speed sensor, rear	01.90-10.94	LAB	0 265 003 066
		RAB	0 265 003 062
1.7 I.E. 16V 4x4 [907]	1,7 l	95-97 kW	AR30747 4 Zyl.
Throttle valve sensor	01.90-10.94		0 280 120 304
Air flow sensor, gasoline injection	01.90-10.94		0 280 202 206
		🌀	0 986 280 065
Speed sensor, ignition/injection	01.90-10.94		0 261 210 036
Temperature sensor, coolant, injection system	01.90-10.94		0 280 130 026
Wheel speed sensor, front	01.90-10.94		0 265 003 061
Wheel speed sensor, rear	01.90-10.94	LAB	0 265 001 267
		RAB	0 265 001 268

33 Sport Wagon

1.5 i.e. [907]		1,5l 70-72 kW AR30751 4 Zyl.
Throttle valve sensor	06.90-03.92	0 280 120 315
Air flow sensor, gasoline injection	06.90-03.92	0 280 200 601
Temperature sensor, coolant, injection system	06.90-03.92	0 280 130 026

Product				


◀ 33 Sport Wagon

Wheel speed sensor, front	06.90-03.92		0 265 003 061
Wheel speed sensor, rear	06.90-03.92	LAB	0 265 003 066
		RAB	0 265 003 062
1.5 I.E. 4x4 [907]	1,5 l 70-72 kW AR30751 4 Zyl.		
Throttle valve sensor	06.90-03.92		0 280 120 315
Air flow sensor, gasoline injection	06.90-03.92		0 280 200 601
Temperature sensor, coolant, injection system	06.90-03.92		0 280 130 026
Wheel speed sensor, front	06.90-03.92		0 265 003 061
Wheel speed sensor, rear	06.90-03.92	LAB	0 265 001 267
		RAB	0 265 001 268
1.7 I.E. [905]	1,7 l 77 kW AR30558; AR30558 KAT 4 Zyl.		
Throttle valve sensor	09.88-12.89		0 280 120 315
Air flow sensor, gasoline injection	09.88-12.89		0 280 200 601
Temperature sensor, coolant, injection system	09.88-12.89		0 280 130 026
Relay, Jetronic	09.88-12.89		0 332 014 113
1.7 I.E. [907]	1,7 l 79 kW AR30736; AR30737 4 Zyl.		
Throttle valve sensor	07.90-03.92		0 280 120 315
Air flow sensor, gasoline injection	07.90-03.92		0 280 200 601
Temperature sensor, coolant, injection system	07.90-03.92		0 280 130 026
Wheel speed sensor, front	07.90-03.92		0 265 003 061
Wheel speed sensor, rear	07.90-03.92	LAB	0 265 003 066
		RAB	0 265 003 062
1.7 I.E. 4x4 [905]	1,7 l 77 kW AR30558; AR30558 KAT 4 Zyl.		
Throttle valve sensor	09.88-12.89		0 280 120 315
Air flow sensor, gasoline injection	09.88-12.89		0 280 200 601
Temperature sensor, coolant, injection system	09.88-12.89		0 280 130 026
Relay, Jetronic	09.88-12.89		0 332 014 113
1.7 I.E. 4x4 [907]	1,7 l 77 kW AR30737 4 Zyl.		
Throttle valve sensor	03.92-10.94		0 280 122 001
Speed sensor, ignition/injection	03.92-10.94		0 261 210 036
Temperature sensor, coolant, injection system	03.92-10.94		0 280 130 039
Wheel speed sensor, front	03.92-10.94		0 265 003 061
Wheel speed sensor, rear	03.92-10.94	LAB	0 265 001 267
		RAB	0 265 001 268
1.7 I.E. 4x4 [907]	1,7 l 79 kW AR30736; AR30737 4 Zyl.		
Throttle valve sensor	07.90-03.92		0 280 120 315
Air flow sensor, gasoline injection	07.90-03.92		0 280 200 601
Temperature sensor, coolant, injection system	07.90-03.92		0 280 130 026
Wheel speed sensor, front	07.90-03.92		0 265 003 061
Wheel speed sensor, rear	07.90-03.92	LAB	0 265 001 267
		RAB	0 265 001 268
1.7 I.E. 16V [907]	1,7 l 95 kW AR30747 4 Zyl.		
Throttle valve sensor	01.90-03.92		0 280 120 304
Air flow sensor, gasoline injection	01.90-03.92		0 280 202 206
			0 986 280 065
Speed sensor, ignition/injection	01.90-03.92		0 261 210 036
Temperature sensor, coolant, injection system	01.90-03.92		0 280 130 026
Wheel speed sensor, front	01.90-03.92		0 265 003 061
Wheel speed sensor, rear	01.90-03.92	LAB	0 265 003 066
		RAB	0 265 003 062
1.7 I.E. 16V 4x4 [907]	1,7 l 95/98 kW AR30746; AR30747 4 Zyl.		
Throttle valve sensor	01.90-10.94		0 280 120 304
Air flow sensor, gasoline injection	01.90-10.94		0 280 202 206
			0 986 280 065
Speed sensor, ignition/injection	01.90-10.94		0 261 210 036
Temperature sensor, coolant, injection system	01.90-10.94		0 280 130 026
Wheel speed sensor, front	01.90-10.94		0 265 003 061
Wheel speed sensor, rear	01.90-10.94	LAB	0 265 001 267
		RAB	0 265 001 268

Product				

75

1.6	1,6 l 81 kW AR 06100 4 Zyl.		
Throttle valve sensor	05.85-09.89		0 261 211 003
1.6 I.E.	1,6 l 77-79 kW AR 61101 4 Zyl.		
Throttle valve sensor	08.89-02.92		0 280 120 300
Speed sensor, ignition/injection	08.89-02.92		0 261 210 036
Temperature sensor, coolant, injection system	08.89-02.92		0 280 130 026
1.8	1,8 l 89 kW AR 06202 4 Zyl.		
Throttle valve sensor	05.85-09.89		0 261 211 003
1.8 I.E.	1,8 l 88 kW AR 06168 4 Zyl.		
Throttle valve sensor	09.88-02.92		0 280 120 300
Air flow sensor, gasoline injection	09.88-02.92		0 280 202 078
Speed sensor, ignition/injection	09.88-02.92		0 261 210 002
Temperature sensor, coolant, injection system	09.88-02.92		0 280 130 023
Relay, Jetronic	09.88-02.92	DID	0 332 014 112
1.8 I.E.	1,8 l 88 kW AR 61201 4 Zyl.		
Throttle valve sensor	08.89-02.92		0 280 120 300
Speed sensor, ignition/injection	08.89-02.92		0 261 210 036
Temperature sensor, coolant, injection system	08.89-02.92		0 280 130 026
1.8 Turbo Essence	1,8 l 121 kW AR 06158 4 Zyl.		
Air flow sensor, gasoline injection	12.86-12.87		0 280 202 113
Temperature sensor, coolant, injection system	12.86-12.87		0 280 130 032
1.8 Turbo I.E.	1,8 l 118 kW AR 06134 4 Zyl.		
Air flow sensor, gasoline injection	02.86-01.90		0 280 202 058
Knock sensor	02.86-01.90		0 261 231 006
Temperature sensor, coolant, injection system	02.86-01.90		0 280 130 032
Relay, Jetronic	02.86-01.90		0 280 230 009
2.0 Twin Spark	2,0 l 106 kW AR 06166 KAT 4 Zyl.		
Throttle valve sensor	09.87-02.92		0 280 120 315
Speed sensor, ignition/injection	09.87-02.92		0 261 210 036
Temperature sensor, coolant, injection system	09.87-02.92		0 280 130 026
2.0 Twin Spark	2,0 l 109 kW AR 06224 4 Zyl.		
Throttle valve sensor	01.87-02.92		0 280 120 315
Speed sensor, ignition/injection	01.87-02.92		0 261 210 036
Temperature sensor, coolant, injection system	01.87-02.92		0 280 130 026
Relay, Jetronic	01.87-02.92		0 332 014 113
2.5 V6	2,5 l 110-113 kW AR 01911 KAT 6 Zyl.		
Throttle valve sensor	02.86-02.92		0 280 120 304
Air flow sensor, gasoline injection	02.86-02.92		0 280 202 010
Pressure sensor, intake manifold, gasoline	02.86-02.92	HL	0 280 101 001
Temperature sensor, coolant, injection system	02.86-02.92		0 280 130 023
Relay, Jetronic	02.86-02.92	WEI	0 332 514 127
2.5 V6	2,5 l 115 kW AR 01646 6 Zyl.		
Throttle valve sensor	09.85-02.87		0 280 120 304
Air flow sensor, gasoline injection	09.85-02.87		0 280 202 013
Pressure sensor, intake manifold, gasoline	02.86-02.87	HL	0 280 101 001
Temperature sensor, coolant, injection system	09.85-02.87		0 280 130 023
Relay, Jetronic	09.85-02.87	WEI	0 332 514 127
3.0 ES Coupé Zagato	3,0 l 152 kW AR 61501 6 Zyl.		
Throttle valve sensor	03.89-02.92		0 280 120 300
Air flow sensor, gasoline injection	03.89-02.92		0 280 202 205
Speed sensor, ignition/injection	03.89-02.92		0 261 210 036
Temperature sensor, coolant, injection system	03.89-02.92		0 280 130 026
3.0 V6	3,0 l 133-136 kW AR 06120 6 Zyl.		
Throttle valve sensor	01.87-02.92		0 280 120 304
Air flow sensor, gasoline injection	01.87-02.92		0 280 202 105
Pressure sensor, intake manifold, gasoline	01.87-02.92	HL	0 280 101 001
Temperature sensor, coolant, injection system	01.87-02.92		0 280 130 023
Relay, Jetronic	01.87-02.92	WEI	0 332 514 127




3.0 V6	3,0l 133-136 kW AR 06124 KAT 6 Zyl.
Throttle valve sensor	02.87-01.90 0 280 120 304
Air flow sensor, gasoline injection	02.87-01.90 0 280 202 108
	0 986 280 067
Pressure sensor, intake manifold, gasoline	02.87-01.90 HL 0 280 101 001
Temperature sensor, coolant, injection system	02.87-01.90 0 280 130 023
Relay, Jetronic	02.87-01.90 WEI 0 332 514 127
3.0 V6	3,0l 139-141 kW AR 61503 6 Zyl.
Throttle valve sensor	02.90-02.92 0 280 120 300
Air flow sensor, gasoline injection	02.90-02.92 0 280 202 205
Speed sensor, ignition/injection	02.90-02.92 0 261 210 036
Temperature sensor, coolant, injection system	02.90-02.92 0 280 130 026

90

2.0 i.e.	2,0l 94 kW AR 01713 MPI-Bosch 4 Zyl.
Throttle valve sensor	10.84-01.87 0 280 120 300
Air flow sensor, gasoline injection	04.85-01.87 0 280 202 078
Pulse generator, ignition/Jetronic	10.84-01.87 0 261 210 001
Temperature sensor, coolant, injection system	10.84-01.87 0 280 130 023
Relay, Jetronic	10.84-01.87 0 332 014 113
	DID 0 332 014 112
2.5 i.e. V6	2,5l 110-113 kW AR 01911 6 Zyl.
Throttle valve sensor	02.86-12.90 0 280 120 304
Air flow sensor, gasoline injection	02.86-12.90 0 280 202 010
Pressure sensor, intake manifold, gasoline	02.86-12.90 HL 0 280 101 001
Temperature sensor, coolant, injection system	02.86-12.90 0 280 130 023
Relay, Jetronic	02.86-12.90 WEI 0 332 514 127
2.5 i.e. V6	2,5l 115 kW AR 01646 MPI-Bosch 6 Zyl.
Throttle valve sensor	10.84-01.87 0 280 120 304
Air flow sensor, gasoline injection	10.84-01.87 0 280 202 013
Temperature sensor, coolant, injection system	10.84-01.87 0 280 130 023
Relay, Jetronic	09.85-01.87 WEI 0 332 514 127

145

1.3 i.e. [930 MY95]	1,4l 68 kW AR 33501 MPI-Weber 4 Zyl.
Wheel speed sensor, front	04.94-11.96 0 265 006 162
Wheel speed sensor, rear	
Ricam.no →3076158	04.94-11.96 0 265 006 197
Ricam.no 3076159→	04.94-11.96 LAB 0 265 006 325
	RAB 0 265 006 326
1.4 i.e. 16V T.S. [930 MY97]	1,4l 76 kW AR 33503 4 Zyl.
Throttle valve sensor	11.96-02.99 0 280 122 001
Air mass meter, gasoline injection	11.96-01.98 0 280 217 102
	02.98-02.99 0 280 218 001
Phase sensor	11.96-02.99 0 232 101 026
Speed sensor, ignition/injection	05.98-02.99 0 261 210 160
Pulse generator, ignition/Jetronic	11.96-04.98 0 261 210 129
Knock sensor	11.96-02.99 0 261 231 095
Temperature sensor, intake air, injection system	11.96-02.99 0 280 130 073
Temperature sensor, coolant, injection system	11.96-02.99 0 280 130 026
Wheel speed sensor, front	11.96-02.99 0 265 006 162
Wheel speed sensor, rear	11.96-02.99 LAB 0 265 006 325
	RAB 0 265 006 326
1.4 i.e. 16V T.S. [930 MY99]	1,4l 76 kW AR 33503 4 Zyl.
Air mass meter, gasoline injection	02.99-12.00 0 280 218 001
Phase sensor	02.99-12.00 0 232 101 035
Speed sensor, ignition/injection	02.99-12.00 0 261 210 160
Knock sensor	02.99-12.00 0 261 231 131
Wheel speed sensor, front	02.99-12.00 LAB 0 265 007 063
	RAB 0 265 007 064



Wheel speed sensor, rear	02.99-12.00 LAB 0 265 007 065
	RAB 0 265 007 066
1.6 i.e. [930 MY95]	1,6l 78 kW AR 33201 MPI-Bosch 4 Zyl.
Throttle valve sensor	04.94-12.94 0 280 122 001
Pulse generator, ignition/Jetronic	04.94-12.94 0 261 210 036
Temperature sensor, intake air, injection system	04.94-12.94 0 280 130 073
Temperature sensor, coolant, injection system	04.94-12.94 0 280 130 026
Wheel speed sensor, front	04.94-12.94 0 265 006 162
Wheel speed sensor, rear	
Ricam.no →3076158	04.94-12.94 0 265 006 197
Ricam.no 3076159→	04.94-12.94 LAB 0 265 006 325
	RAB 0 265 006 326
1.6 i.e. [930 MY95]	1,6l 78 kW AR 33201 MPI-Roch. 4 Zyl.
Wheel speed sensor, front	01.95-11.96 0 265 006 162
Wheel speed sensor, rear	
Ricam.no →3076158	01.95-11.96 0 265 006 197
Ricam.no 3076159→	01.95-11.96 LAB 0 265 006 325
	RAB 0 265 006 326
1.6 i.e. 16V T.S. [930 MY97]	1,6l 88 kW AR 67601 4 Zyl.
Throttle valve sensor	11.96-02.99 0 280 122 001
Air mass meter, gasoline injection	11.96-02.99 0 280 217 111
Phase sensor	11.96-02.99 0 232 101 026
Speed sensor, ignition/injection	05.98-02.99 0 261 210 160
Pulse generator, ignition/Jetronic	11.96-04.98 0 261 210 129
Knock sensor	11.96-02.99 0 261 231 095
Temperature sensor, intake air, injection system	11.96-02.99 0 280 130 073
Temperature sensor, coolant, injection system	11.96-02.99 0 280 130 026
Wheel speed sensor, front	11.96-02.99 0 265 006 162
Wheel speed sensor, rear	11.96-02.99 LAB 0 265 006 325
	RAB 0 265 006 326
1.6 i.e. 16V T.S. [930 MY99]	1,6l 88 kW AR 32102; AR 67601 4 Zyl.
Air mass meter, gasoline injection	02.99-12.00 0 280 218 019
Phase sensor	02.99-12.00 0 232 101 035
Speed sensor, ignition/injection	02.99-12.00 0 261 210 160
Knock sensor	02.99-12.00 0 261 231 131
Wheel speed sensor, front	02.99-12.00 LAB 0 265 007 063
	RAB 0 265 007 064
Wheel speed sensor, rear	02.99-12.00 LAB 0 265 007 065
	RAB 0 265 007 066
1.7 i.e. 16V [930 MY95]	1,7l 96 kW AR 33401 4 Zyl.
Throttle valve sensor	04.94-11.96 0 280 122 001
Air mass meter, gasoline injection	04.94-11.96 0 280 217 111
Phase sensor	04.94-11.96 0 232 103 010
Pulse generator, ignition/Jetronic	04.94-11.96 0 261 210 113
Temperature sensor, intake air, injection system	04.94-11.96 0 280 130 073
Temperature sensor, coolant, injection system	04.94-11.96 0 280 130 026
Wheel speed sensor, front	04.94-11.96 0 265 006 162
Wheel speed sensor, rear	
Ricam.no →3076158	04.94-11.96 0 265 006 197
Ricam.no 3076159→	04.94-11.96 LAB 0 265 006 325
	RAB 0 265 006 326
1.8 i.e. 16V T.S. [930 MY97]	1,8l 103 kW AR 32201 4 Zyl.
Throttle valve assembly	05.98-02.99 3 437 010 460
Air mass meter, gasoline injection	05.98-02.99 0 280 217 111
Phase sensor	05.98-02.99 0 232 101 035
Speed sensor, ignition/injection	05.98-02.99 0 261 210 160
Knock sensor	05.98-02.99 0 261 231 131
Wheel speed sensor, rear	05.98-02.99 LAB 0 265 006 325
	RAB 0 265 006 326
1.8 i.e. 16V T.S. [930 MY97]	1,8l 103 kW AR 67106; AR 67199 4 Zyl.
Throttle valve sensor	11.96-04.98 0 280 122 001
Air mass meter, gasoline injection	11.96-04.98 0 280 217 111
Phase sensor	11.96-04.98 0 232 101 026



Product

◀ 145

Pulse generator, ignition/Jetronic	11.96-04.98		0 261 210 129
Knock sensor	11.96-04.98		0 261 231 095
Temperature sensor, intake air, injection system	11.96-04.98		0 280 130 073
Temperature sensor, coolant, injection system	11.96-04.98		0 280 130 026
Wheel speed sensor, front	11.96-04.98		0 265 006 162
Wheel speed sensor, rear	11.96-04.98	LAB	0 265 006 325
		RAB	0 265 006 326

1.8 i.e. 16V T.S. [930 MY99]		1,8 l	103 kW AR 32201 4 Zyl.
Throttle valve assembly	02.99-12.00		3 437 010 460
Air mass meter, gasoline injection	02.99-12.00		0 280 218 019
Phase sensor	02.99-12.00		0 232 101 035
Speed sensor, ignition/injection	02.99-12.00		0 261 210 160
Knock sensor	02.99-12.00		0 261 231 131
Vacuum pickup, ignition/injection	02.99-12.00		0 928 400 327
Wheel speed sensor, front	02.99-12.00	LAB	0 265 007 063
		RAB	0 265 007 064
Wheel speed sensor, rear	02.99-12.00	LAB	0 265 007 065
		RAB	0 265 007 066

1.9 JTD [930 MY97]		1,9 l	76 kW AR 32302 4 Zyl.
Air mass meter, diesel	05.98-02.99		0 280 218 019
Speed sensor, diesel	05.98-02.99		0 281 002 214
Phase sensor	05.98-02.99		0 281 002 213
High-pressure sensor (CR system)	05.98-02.99		0 281 002 210
Boost pressure sensor, Diesel	05.98-02.99		0 281 002 215
Temperature sensor, fuel	05.98-02.99	2PO	0 281 002 209
Pedal position sensor, diesel	05.98-02.99		0 281 002 203
Wheel speed sensor, front	05.98-02.99	LAB	0 265 007 063
		RAB	0 265 007 064
Wheel speed sensor, rear	05.98-02.99	LAB	0 265 007 065
		RAB	0 265 007 066

1.9 JTD [930 MY99]		1,9 l	76 kW AR 32302 4 Zyl.
Air mass meter, diesel	02.99-12.00		0 280 218 019
Speed sensor, diesel	02.99-12.00		0 281 002 214
Phase sensor	02.99-12.00		0 281 002 213
High-pressure sensor (CR system)	02.99-12.00		0 281 002 210
Boost pressure sensor, Diesel	02.99-12.00		0 281 002 215
Temperature sensor, fuel	02.99-12.00	2PO	0 281 002 209
Pedal position sensor, diesel	02.99-12.00		0 281 002 203
Wheel speed sensor, front	02.99-12.00	LAB	0 265 007 063
		RAB	0 265 007 064
Wheel speed sensor, rear	02.99-12.00	LAB	0 265 007 065
		RAB	0 265 007 066

1.9 TD [930 MY95]		1,9l 66 kW AR 33601; AR 67501 4 Zyl.	
Wheel speed sensor, front	04.94-11.96		0 265 006 162
Wheel speed sensor, rear			
Ricam.no →3076158	04.94-11.96		0 265 006 197
Ricam.no 3076159→	04.94-11.96	LAB	0 265 006 325
		RAB	0 265 006 326
1.9 TD [930 MY97]		1,9l 66 kW AR 33601; AR 67501 4 Zyl.	
Wheel speed sensor, front	11.96-05.98		0 265 006 162
Wheel speed sensor, rear	11.96-05.98	LAB	0 265 006 325
		RAB	0 265 006 326

2.0 i.e. 16V T.S. [930 MY95]		2,0 l	110 kW AR 67204 4 Zyl.
Throttle valve sensor	10.95-11.96		0 280 122 001
Air mass meter, gasoline injection	10.95-11.96		0 280 217 111
Phase sensor	10.95-11.96		0 232 101 026
Pulse generator, ignition/Jetronic	10.95-11.96		0 261 210 129
Knock sensor	10.95-11.96		0 261 231 095
Temperature sensor, intake air, injection system	10.95-11.96		0 280 130 073
Temperature sensor, coolant, injection system	10.95-11.96		0 280 130 055
Wheel speed sensor, front	10.95-11.96		0 265 006 162

Product

Wheel speed sensor, rear			
Ricam.no →3076158	10.95-11.96		0 265 006 197
Ricam.no 3076159→	10.95-11.96	LAB	0 265 006 325
		RAB	0 265 006 326

2.0 i.e. 16V T.S. [930 MY95]		2,0 l	110 kW AR 67299 4 Zyl.
Throttle valve sensor	10.94-11.96		0 280 122 001
Air mass meter, gasoline injection	10.94-11.96		0 280 217 111
Phase sensor	10.94-11.96		0 232 101 026
Pulse generator, ignition/Jetronic	10.94-11.96		0 261 210 129
Knock sensor	10.94-11.96		0 261 231 095
Temperature sensor, intake air, injection system	10.94-11.96		0 280 130 073
Temperature sensor, coolant, injection system	10.94-11.96		0 280 130 055

2.0 i.e. 16V T.S. [930 MY97]		2,0 l	110 kW AR 32301 Step A 4 Zyl.
Throttle valve assembly	05.98-02.99		3 437 010 460
Air mass meter, gasoline injection	05.98-02.99		0 280 217 111
Phase sensor	05.98-02.99		0 232 101 035
Speed sensor, ignition/injection	05.98-02.99		0 261 210 160
Knock sensor	05.98-02.99		0 261 231 131
Wheel speed sensor, rear	05.98-02.99	LAB	0 265 006 325
		RAB	0 265 006 326

2.0 i.e. 16V T.S. [930 MY97]		2,0 l	110 kW AR 67204; AR 67299 4 Zyl.
Throttle valve sensor	11.96-02.99		0 280 122 001
Air mass meter, gasoline injection	11.96-02.99		0 280 217 111
Phase sensor	11.96-02.99		0 232 101 026
Pulse generator, ignition/Jetronic	11.96-02.99		0 261 210 129
Knock sensor	11.96-02.99		0 261 231 095
Temperature sensor, intake air, injection system	11.96-02.99		0 280 130 073
Temperature sensor, coolant, injection system	11.96-02.99		0 280 130 055
Wheel speed sensor, front	11.96-02.99		0 265 006 212
Wheel speed sensor, rear	11.96-02.99	LAB	0 265 006 325
		RAB	0 265 006 326

2.0 i.e. 16V T.S. [930 MY99]		2,0 l	110 kW AR 32301 4 Zyl.
Throttle valve assembly	02.99-12.00		3 437 010 460
Air mass meter, gasoline injection	02.99-12.00		0 280 218 019
Phase sensor	02.99-12.00		0 232 101 035
Speed sensor, ignition/injection	02.99-12.00		0 261 210 160
Knock sensor	02.99-12.00		0 261 231 131
Vacuum pickup, ignition/injection	02.99-12.00		0 928 400 327
Wheel speed sensor, front	02.99-12.00	LAB	0 265 007 063
		RAB	0 265 007 064
Wheel speed sensor, rear	02.99-12.00	LAB	0 265 007 065
		RAB	0 265 007 066

146

1.3 i.e. [930 MY95]		1,3 l	68 kW AR 33501 MPI-Weber 4 Zyl.
Wheel speed sensor, front	12.94-11.96		0 265 006 212
Wheel speed sensor, rear	12.94-11.96		0 265 006 197

1.4 i.e. 16V T.S. [930 MY97]		1,4 l	76 kW AR 33503 4 Zyl.
Throttle valve sensor	11.96-02.99		0 280 122 001
Air mass meter, gasoline injection	11.96-02.99		0 280 217 102
Phase sensor	11.96-02.99		0 232 101 026
Pulse generator, ignition/Jetronic	11.96-02.99		0 261 210 129
Knock sensor	11.96-02.99		0 261 231 095
Temperature sensor, intake air, injection system	11.96-02.99		0 280 130 073
Temperature sensor, coolant, injection system	11.96-02.99		0 280 130 026
Wheel speed sensor, front	11.96-02.99		0 265 006 162
Wheel speed sensor, rear	11.96-02.99	LAB	0 265 006 325
		RAB	0 265 006 326

1.4 i.e. 16V T.S. [930MY99]		1,4 l	76 kW AR 33503 4 Zyl.
Air mass meter, gasoline injection	02.99-12.00		0 280 218 001
Phase sensor	02.99-12.00		0 232 101 035
Speed sensor, ignition/injection	02.99-12.00		0 261 210 160



Knock sensor	02.99-12.00		0 261 231 131
Wheel speed sensor, front	02.99-12.00	LAB	0 265 007 063
		RAB	0 265 007 064
Wheel speed sensor, rear	02.99-12.00	LAB	0 265 007 065
		RAB	0 265 007 066
1.6 i.e. [930 MY95]	1,6 l 78 kW AR 33201 MPI-Roch. 4 Zyl.		
Wheel speed sensor, front	05.95-11.96		0 265 006 212
Wheel speed sensor, rear	05.95-11.96		0 265 006 197
1.6 i.e. 16V T.S. [930 MY97]	1,6 l 88 kW AR 67601 4 Zyl.		
Throttle valve sensor	11.96-02.99		0 280 122 001
Air mass meter, gasoline injection	11.96-02.99		0 280 217 111
Phase sensor	11.96-02.99		0 232 101 026
Pulse generator, ignition/Jetronic	11.96-02.99		0 261 210 129
Knock sensor	11.96-02.99		0 261 231 095
Temperature sensor, intake air, injection system	11.96-02.99		0 280 130 073
Temperature sensor, coolant, injection system	11.96-02.99		0 280 130 026
Wheel speed sensor, front	11.96-02.99		0 265 006 162
Wheel speed sensor, rear	11.96-02.99	LAB	0 265 006 325
		RAB	0 265 006 326
1.6 i.e. 16V T.S. [930MY99]	1,6 l 88 kW AR 32102; AR 67601 4 Zyl.		
Air mass meter, gasoline injection	02.99-12.00		0 280 218 019
Phase sensor	02.99-12.00		0 232 101 035
Speed sensor, ignition/injection	02.99-12.00		0 261 210 160
Knock sensor	02.99-12.00		0 261 231 131
Wheel speed sensor, front	02.99-12.00	LAB	0 265 007 063
		RAB	0 265 007 064
Wheel speed sensor, rear	02.99-12.00	LAB	0 265 007 065
		RAB	0 265 007 066
1.7 i.e. 16V [930 MY95]	1,7 l 96 kW AR 33401 4 Zyl.		
Throttle valve sensor	12.94-11.96		0 280 122 001
Air mass meter, gasoline injection	12.94-11.96		0 280 217 111
Phase sensor	12.94-11.96		0 232 103 010
Pulse generator, ignition/Jetronic	12.94-11.96		0 261 210 113
Temperature sensor, intake air, injection system	12.94-11.96		0 280 130 073
Temperature sensor, coolant, injection system	12.94-11.96		0 280 130 026
Wheel speed sensor, front	12.94-11.96		0 265 006 212
Wheel speed sensor, rear	12.94-11.96		0 265 006 197
1.8 i.e. 16V T.S. [930 MY97]	1,8 l 103 kW AR 32201 4 Zyl.		
Throttle valve assembly	05.98-02.99		3 437 010 460
Air mass meter, gasoline injection	05.98-02.99		0 280 217 111
Phase sensor	05.98-02.99		0 232 101 035
Speed sensor, ignition/injection	05.98-02.99		0 261 210 160
Knock sensor	05.98-02.99		0 261 231 131
Wheel speed sensor, front	05.98-02.99		0 265 006 162
Wheel speed sensor, rear	05.98-02.99	LAB	0 265 006 325
		RAB	0 265 006 326
1.8 i.e. 16V T.S. [930 MY97]	1,8 l 103 kW AR 67106 4 Zyl.		
Throttle valve sensor	11.96-04.98		0 280 122 001
Air mass meter, gasoline injection	11.96-04.98		0 280 217 111
Phase sensor	11.96-04.98		0 232 101 026
Pulse generator, ignition/Jetronic	11.96-04.98		0 261 210 129
Knock sensor	11.96-04.98		0 261 231 095
Temperature sensor, intake air, injection system	11.96-04.98		0 280 130 073
Temperature sensor, coolant, injection system	11.96-04.98		0 280 130 026
Wheel speed sensor, front	11.96-04.98		0 265 006 162
Wheel speed sensor, rear	11.96-04.98	LAB	0 265 006 325
		RAB	0 265 006 326
1.8 i.e. 16V T.S. [930MY99]	1,8 l 103 kW AR 32201 4 Zyl.		
Throttle valve assembly	02.99-12.00		3 437 010 460
Air mass meter, gasoline injection	02.99-12.00		0 280 218 019
Phase sensor	02.99-12.00		0 232 101 035
Speed sensor, ignition/injection	02.99-12.00		0 261 210 160
Knock sensor	02.99-12.00		0 261 231 131



Vacuum pickup, ignition/injection	02.99-12.00		0 928 400 327
Wheel speed sensor, front	02.99-12.00	LAB	0 265 007 063
		RAB	0 265 007 064
Wheel speed sensor, rear	02.99-12.00	LAB	0 265 007 065
		RAB	0 265 007 066
1.9 JTD [930 MY97]	1,9 l 76 kW AR 32302 4 Zyl.		
Air mass meter, diesel	05.98-02.99		0 280 218 019
Speed sensor, diesel	05.98-02.99		0 281 002 214
Phase sensor	05.98-02.99		0 281 002 213
High-pressure sensor (CR system)	05.98-02.99		0 281 002 210
Boost pressure sensor, Diesel	05.98-02.99		0 281 002 215
Temperature sensor, fuel	05.98-02.99	2PO	0 281 002 209
Pedal position sensor, diesel	05.98-02.99		0 281 002 203
Wheel speed sensor, front	05.98-02.99	LAB	0 265 007 063
		RAB	0 265 007 064
Wheel speed sensor, rear	05.98-02.99	LAB	0 265 007 065
		RAB	0 265 007 066
1.9 JTD [930MY99]	1,9 l 76 kW AR 32302 4 Zyl.		
Air mass meter, diesel	02.99-12.00		0 280 218 019
Speed sensor, diesel	02.99-12.00		0 281 002 214
Phase sensor	02.99-12.00		0 281 002 213
High-pressure sensor (CR system)	02.99-12.00		0 281 002 210
Boost pressure sensor, Diesel	02.99-12.00		0 281 002 215
Temperature sensor, fuel	02.99-12.00	2PO	0 281 002 209
Pedal position sensor, diesel	02.99-12.00		0 281 002 203
Wheel speed sensor, front	02.99-12.00	LAB	0 265 007 063
		RAB	0 265 007 064
Wheel speed sensor, rear	02.99-12.00	LAB	0 265 007 065
		RAB	0 265 007 066
1.9 TD [930 MY95]	1,9 l 66 kW AR 33601; AR 67501 4 Zyl.		
Wheel speed sensor, front	12.94-11.96		0 265 006 212
Wheel speed sensor, rear	12.94-11.96		0 265 006 197
1.9 TD [930 MY97]	1,9 l 66 kW AR 33601; AR 67501 4 Zyl.		
Wheel speed sensor, front	11.96-05.98		0 265 006 162
Wheel speed sensor, rear	11.96-05.98	LAB	0 265 006 325
		RAB	0 265 006 326
2.0 ti 16V T.S. [930 MY95]	2,0 l 110 kW AR 67204 4 Zyl.		
Throttle valve sensor	10.95-11.96		0 280 122 001
Air mass meter, gasoline injection	10.95-11.96		0 280 217 111
Phase sensor	10.95-11.96		0 232 101 026
Pulse generator, ignition/Jetronic	10.95-11.96		0 261 210 129
Knock sensor	10.95-11.96		0 261 231 095
Temperature sensor, intake air, injection system	10.95-11.96		0 280 130 073
Temperature sensor, coolant, injection system	10.95-11.96		0 280 130 055
Wheel speed sensor, front	10.95-11.96		0 265 006 212
Wheel speed sensor, rear	10.95-11.96	LAB	0 265 006 325
		RAB	0 265 006 326
2.0 ti 16V T.S. [930 MY97]	2,0 l 110 kW AR 32301 4 Zyl.		
Throttle valve assembly	05.98-02.99		3 437 010 460
Air mass meter, gasoline injection	05.98-02.99		0 280 217 111
Phase sensor	05.98-02.99		0 232 101 035
Speed sensor, ignition/injection	05.98-02.99		0 261 210 160
Knock sensor	05.98-02.99		0 261 231 131
Wheel speed sensor, front	05.98-02.99		0 265 006 162
Wheel speed sensor, rear	05.98-02.99	LAB	0 265 006 325
		RAB	0 265 006 326
2.0 ti 16V T.S. [930 MY97]	2,0 l 110 kW AR 67204 4 Zyl.		
Throttle valve sensor	11.96-04.98		0 280 122 001
Air mass meter, gasoline injection	11.96-04.98		0 280 217 111
Phase sensor	11.96-04.98		0 232 101 026
Pulse generator, ignition/Jetronic	11.96-04.98		0 261 210 129
Knock sensor	11.96-04.98		0 261 231 095
Temperature sensor, intake air, injection system	11.96-04.98		0 280 130 073

Product				

◀ 146

Temperature sensor, coolant, injection system	11.96-04.98		0 280 130 055
Wheel speed sensor, front	11.96-04.98		0 265 006 212
Wheel speed sensor, rear	11.96-04.98	LAB	0 265 006 325
		RAB	0 265 006 326
2.0 ti 16V T.S. [930MY99]	2,0 l	110 kW	AR 32301 4 Zyl.
Throttle valve assembly	02.99-12.00		3 437 010 460
Air mass meter, gasoline injection	02.99-12.00		0 280 218 019
Phase sensor	02.99-12.00		0 232 101 035
Speed sensor, ignition/injection	02.99-12.00		0 261 210 160
Knock sensor	02.99-12.00		0 261 231 131
Vacuum pickup, ignition/injection	02.99-12.00		0 928 400 327
Wheel speed sensor, front	02.99-12.00	LAB	0 265 007 063
		RAB	0 265 007 064
Wheel speed sensor, rear	02.99-12.00	LAB	0 265 007 065
		RAB	0 265 007 066

147

1.6 TS 16V [937]	1,6 l	88 kW	AR 32104 4 Zyl.
Air mass meter, gasoline injection	11.00→		0 281 002 309
Phase sensor	11.00→		0 232 101 035
Speed sensor, ignition/injection			
Mot.no. →3636739	11.00→		0 261 210 160
Mot.no. 3636740→	11.00→		0 261 210 227
Knock sensor	11.00→		0 261 231 131
Yaw rate sensor, brake system	11.00→		0 265 005 241
Wheel speed sensor, front			
Ricam.no →03222100	11.00-10.02	LAB	0 265 007 086
		RAB	0 265 007 085
Ricam.no 03222101→	11.02→	LAB	0 265 007 542
		RAB	0 265 007 543
Wheel speed sensor, rear			
Ricam.no →03222100	11.00-10.02		0 265 007 089
Ricam.no 03222101→	11.02→		0 265 007 544
1.6 TS 16V ECO [937]	1,6 l	77 kW	AR 37203 4 Zyl.
Air mass meter, gasoline injection	11.00→		0 281 002 309
Phase sensor	11.00→		0 232 101 035
Speed sensor, ignition/injection			
Mot.no. →3613607	11.00→		0 261 210 160
Mot.no. 3613608→	11.00→		0 261 210 227
Knock sensor	11.00→		0 261 231 131
Yaw rate sensor, brake system	11.00→		0 265 005 241
Wheel speed sensor, front			
Ricam.no →03222100	11.00-10.02	LAB	0 265 007 086
		RAB	0 265 007 085
Ricam.no 03222101→	11.02→	LAB	0 265 007 542
		RAB	0 265 007 543
Wheel speed sensor, rear			
Ricam.no →03222100	11.00-10.02		0 265 007 089
Ricam.no 03222101→	11.02→		0 265 007 544
1.9 JTD [937]	1,9 l	74 kW	182B9000 4 Zyl.
Air mass meter, diesel	06.03-10.06		0 280 218 120
Speed sensor, diesel	06.03-09.03		0 281 002 474
	10.03-10.06		0 281 002 603
Phase sensor	06.03-10.06		0 281 002 213
High-pressure sensor (CR system)			
Ricam.no →03944567	06.03-10.06		0 281 002 405
Ricam.no 03944568→	06.03-10.06		0 281 002 734
Boost pressure sensor, Diesel	06.03-08.06		0 281 002 510
	09.06-10.06		0 281 002 844
Yaw rate sensor, brake system	06.03-10.06		0 265 005 241

Product				

Wheel speed sensor, front	06.03-10.06	LAB	0 265 007 542
		RAB	0 265 007 543
Wheel speed sensor, rear	06.03-10.06		0 265 007 089
1.9 JTD [937]	1,9 l	81-85 kW	937A2000 4 Zyl.
Air mass meter, diesel	11.00-03.05		0 280 218 120
Speed sensor, diesel	11.00-09.03		0 281 002 474
	10.03-03.05		0 281 002 603
Phase sensor	11.00-03.05		0 281 002 213
High-pressure sensor (CR system)			
Ricam.no →03944567	11.00-03.05		0 281 002 405
Ricam.no 03944568→	11.00-03.05		0 281 002 734
Boost pressure sensor, Diesel			
Mot.no. →2705193	11.00-07.01		0 281 002 215
Mot.no. 2705194→	08.01-03.05		0 281 002 510
Yaw rate sensor, brake system	11.00-03.05		0 265 005 241
Wheel speed sensor, front			
Ricam.no →03222100	11.00-10.02	LAB	0 265 007 086
		RAB	0 265 007 085
Ricam.no 03222101→	11.02-03.05	LAB	0 265 007 542
		RAB	0 265 007 543
Wheel speed sensor, rear			
Ricam.no →03222100	11.00-10.02		0 265 007 089
Ricam.no 03222101→	11.02-03.05		0 265 007 544
1.9 JTDm [937]	1,9 l	85/92 kW	937A3000; 939A7000 4 Zyl.
Air mass meter, diesel	04.05→		0 281 002 792
Speed sensor, diesel	04.05→		0 281 002 603
Phase sensor	04.05→		0 281 002 213
High-pressure sensor (CR system)	04.05→		0 281 002 706
Boost pressure sensor, Diesel	04.05-02.07		0 281 002 437
	03.07→		0 281 002 845
Yaw rate sensor, brake system	04.05→		0 265 005 241
Wheel speed sensor, front	04.05→	LAB	0 265 007 542
		RAB	0 265 007 543
Wheel speed sensor, rear	04.05→		0 265 007 089
1.9 JTDm 16V [937]	1,9 l	93 kW	937A4000 4 Zyl.
Air mass meter, diesel	06.03-09.06		0 280 218 120
High-pressure sensor (CR system)	06.03-09.06		0 281 002 534
Boost pressure sensor, Diesel	06.03-09.06		0 281 002 437
Yaw rate sensor, brake system	06.03-09.06		0 265 005 241
Wheel speed sensor, front	06.03-09.06	LAB	0 265 007 542
		RAB	0 265 007 543
Wheel speed sensor, rear	06.03-09.06		0 265 007 089
1.9 JTDm 16V [937]	1,9 l	100 kW	192B1000 4 Zyl.
Throttle valve assembly	01.06→		0 280 750 102
Air mass meter, diesel	02.04-12.05		0 280 218 120
	01.06→		0 281 002 792
High-pressure sensor (CR system)	02.04-12.05		0 281 002 534
	01.06→		0 281 002 706
Boost pressure sensor, Diesel	02.04→		0 281 002 437
Yaw rate sensor, brake system	02.04→		0 265 005 241
Pressure sensor, ESP, (electronic stability program)			
Ricam.no →3489988	01.06-02.06		0 265 005 303
Wheel speed sensor, front	02.04→	LAB	0 265 007 542
		RAB	0 265 007 543
Wheel speed sensor, rear	02.04→		0 265 007 089
1.9 JTDm 16V [937]	1,9 l	103 kW	192A5000 4 Zyl.
Air mass meter, diesel	10.02-09.03		0 280 218 120
High-pressure sensor (CR system)	10.02-09.03		0 281 002 534
Boost pressure sensor, Diesel	10.02-09.03		0 281 002 437
Yaw rate sensor, brake system	10.02-09.03		0 265 005 241
Wheel speed sensor, front	11.02-09.03	LAB	0 265 007 542
		RAB	0 265 007 543
Wheel speed sensor, rear	10.02-09.03		0 265 007 089



Product			
1.9 JTDM 16V [937]			
		1,9l 110 kW 937A5000 4 Zyl.	
Throttle valve assembly	06.05→	NPF	0 280 750 102
Air mass meter, diesel	10.04-03.05		0 280 218 120
	06.05→		0 281 002 792
High-pressure sensor (CR system)	10.04-03.05		0 281 002 534
	06.05→		0 281 002 706
Boost pressure sensor, Diesel	10.04-03.05		0 281 002 437
	06.05→		0 281 002 437
Yaw rate sensor, brake system	06.05→		0 265 005 241
	10.04-03.05		0 265 005 241
Pressure sensor, ESP, (electronic stability program)			
Ricam.no →3489988	06.05-02.06		0 265 005 303
Wheel speed sensor, front	06.05→	LAB	0 265 007 542
	10.04-03.05	LAB	0 265 007 542
	06.05→	RAB	0 265 007 543
	10.04-03.05	RAB	0 265 007 543
Wheel speed sensor, rear	06.05→		0 265 007 089
	10.04-03.05		0 265 007 089
2.0 TS 16V [937]		2,0l 110 kW AR 32310 4 Zyl.	
Throttle valve assembly			
Mot.no. →3649574	11.00-04.04		0 280 750 102
Mot.no. 3649575→	05.04→		1 287 213 612
Air mass meter, gasoline injection	11.00→		0 281 002 309
Phase sensor	11.00→		0 232 101 035
Speed sensor, ignition/injection			
Mot.no. →3649574	11.00→		0 261 210 160
Mot.no. 3649575→	11.00→		0 261 210 227
Knock sensor	11.00→		0 261 231 131
Yaw rate sensor, brake system	11.00→		0 265 005 241
Pressure sensor, ESP, (electronic stability program)			
Ricam.no →3486881	11.00-01.06		0 265 005 303
Wheel speed sensor, front			
Ricam.no →03222100	11.00-10.02	LAB	0 265 007 086
		RAB	0 265 007 085
	11.02→	LAB	0 265 007 542
		RAB	0 265 007 543
Wheel speed sensor, rear			
Ricam.no →03222100	11.00-10.02		0 265 007 089
Ricam.no 03222101→	11.02→		0 265 007 544
3.2 GTA [937]		3,2l 184 kW 932A000 6 Zyl.	
Throttle valve assembly	01.03→		0 280 750 014
Air mass meter, gasoline injection	01.03→		0 281 002 533
Phase sensor	01.03→		0 232 103 024
Speed sensor, ignition/injection	01.03→		0 261 210 203
Yaw rate sensor, brake system	01.03→		0 265 005 241
Pressure sensor, ESP, (electronic stability program)			
Ricam.no →3486881	01.03-01.06		0 265 005 303
Wheel speed sensor, front	01.03→	LAB	0 265 007 486
		RAB	0 265 007 487
Wheel speed sensor, rear	01.03→		0 265 007 089

155

1.6 i 16V T.S. [167 MY96]		1,6l 85 kW AR 67601 4 Zyl.	
Throttle valve sensor	05.96-10.97		0 280 122 001
Air mass meter, gasoline injection	05.96-10.97		0 280 217 111
Phase sensor	05.96-10.97		0 232 101 026
Speed sensor, ignition/injection	05.96-10.97		0 261 210 129
Knock sensor	05.96-10.97		0 261 231 095
Temperature sensor, intake air, injection system	05.96-10.97		0 280 130 073
Temperature sensor, coolant, injection system	05.96-10.97		0 280 130 026
Wheel speed sensor, front	05.96-10.97		0 265 006 212
Wheel speed sensor, rear	05.96-10.97		0 265 006 197



1.7 T.S. [167 MY92]		1,7l 85/95 kW AR 67103; AR 67105 4 Zyl.	
Throttle valve sensor	02.92-04.96		0 280 122 001
Speed sensor, ignition/injection	02.92-04.96		0 261 210 090
Temperature sensor, coolant, injection system	02.92-04.96		0 280 130 026
Wheel speed sensor, front			
Ricam.no →0159167	02.92-04.96		0 265 006 212
Ricam.no 0159168→	02.92-04.96		0 265 006 162
Wheel speed sensor, rear	02.92-04.96		0 265 006 197
1.8 i 16V T.S. [167 MY96]		1,8l 100 kW AR 67106 4 Zyl.	
Throttle valve sensor	05.96-10.97		0 280 122 001
Air mass meter, gasoline injection	05.96-10.97		0 280 217 111
Phase sensor	05.96-10.97		0 232 101 026
Speed sensor, ignition/injection	05.96-10.97		0 261 210 129
Knock sensor	05.96-10.97		0 261 231 095
Temperature sensor, intake air, injection system	05.96-10.97		0 280 130 073
Temperature sensor, coolant, injection system	05.96-10.97		0 280 130 026
Wheel speed sensor, front	05.96-10.97		0 265 006 212
Wheel speed sensor, rear	05.96-10.97		0 265 006 197
1.8 T.S. [167 MY92]		1,8l 93 kW AR 67101/67102 4 Zyl.	
Throttle valve sensor	02.92-04.96		0 280 122 001
Speed sensor, ignition/injection	02.92-04.96		0 261 210 090
Temperature sensor, coolant, injection system	02.92-04.96		0 280 130 026
Wheel speed sensor, front			
Ricam.no →0159167	02.92-04.96		0 265 006 212
Ricam.no 0159168→	02.92-04.96		0 265 006 162
Wheel speed sensor, rear	02.92-04.96		0 265 006 197
1.9 TD [167]		1,9l 66 kW AR 67501 4 Zyl.	
Wheel speed sensor, front			
Ricam.no →0159167	04.93-04.96		0 265 006 212
Ricam.no 0159168→	04.93-04.96		0 265 006 162
Wheel speed sensor, rear			
Ricam.no →0159167	04.93-04.96		0 265 006 197
1.9 TD [167 MY96]		1,9l 66 kW AR 33601 4 Zyl.	
Wheel speed sensor, front	05.96-10.97		0 265 006 212
Wheel speed sensor, rear	05.96-10.97		0 265 006 197
2.0 i 16V T.S. [167 MY96]		2,0l 110 kW AR 67204 4 Zyl.	
Throttle valve sensor	05.96-10.97		0 280 122 001
Air mass meter, gasoline injection	05.96-10.97		0 280 217 111
Phase sensor	05.96-10.97		0 232 101 026
Speed sensor, ignition/injection	05.96-10.97		0 261 210 129
Knock sensor	05.96-10.97		0 261 231 095
Temperature sensor, intake air, injection system	05.96-10.97		0 280 130 073
Temperature sensor, coolant, injection system	05.96-10.97		0 280 130 055
Wheel speed sensor, front	05.96-10.97		0 265 006 212
Wheel speed sensor, rear	05.96-10.97		0 265 006 197
2.0 i 16V T.S. [167 MY96]		2,0l 110 kW AR 67299 4 Zyl.	
Throttle valve sensor	05.96-10.97		0 280 122 001
Air mass meter, gasoline injection	05.96-10.97		0 280 217 111
Phase sensor	05.96-10.97		0 232 101 026
Speed sensor, ignition/injection	05.96-10.97		0 261 210 129
Knock sensor	05.96-10.97		0 261 231 095
Temperature sensor, intake air, injection system	05.96-10.97		0 280 130 073
Temperature sensor, coolant, injection system	05.96-10.97		0 280 130 026
Wheel speed sensor, front	05.96-10.97		0 265 006 212
Wheel speed sensor, rear	05.96-10.97		0 265 006 197
2.0 T.S. [167 MY92]		2,0l 104/106 kW AR 67201; AR 67202 4 Zyl.	
Throttle valve sensor	02.92-02.95		0 280 122 001
Speed sensor, ignition/injection	02.92-02.95		0 261 210 090
Temperature sensor, coolant, injection system	02.92-02.95		0 280 130 026
Wheel speed sensor, front			
Ricam.no →0159167	02.92-02.95		0 265 006 212
Ricam.no 0159168→	02.92-02.95		0 265 006 162
Wheel speed sensor, rear	02.92-02.95		0 265 006 197

Product				
◀ 155				
2.0T.S. 16V [167 MY92]	2,0l	110 kW	AR 67204	4 Zyl.
Throttle valve sensor	03.95-04.96	0 280 122 001		
Air mass meter, gasoline injection	03.95-04.96	0 280 217 111		
Phase sensor	03.95-04.96	0 232 101 026		
Speed sensor, ignition/injection	03.95-04.96	0 261 210 129		
Knock sensor	03.95-04.96	0 261 231 095		
Temperature sensor, intake air, injection system	03.95-04.96	0 280 130 073		
Temperature sensor, coolant, injection system	03.95-04.96	0 280 130 026		
Wheel speed sensor, front				
Ricam.no →0159167	03.95-04.96	0 265 006 212		
Ricam.no 0159168→	03.95-04.96	0 265 006 162		
Wheel speed sensor, rear	03.95-04.96	0 265 006 197		
2.0 Turbo 4x4 [167 MY92]	2,0l	140 kW	AR 67203	4 Zyl.
Acceleration sensor, ABS	02.92-04.96	0 265 005 030		
Lateral acceleration sensor, brake system	02.92-04.96	0 265 005 031		
Wheel speed sensor, front				
Fg.no. VET0160725→	02.92-04.96	0 265 006 162		
Fg.no. →VET0160724	02.92-04.96	0 265 001 355		
Wheel speed sensor, rear	02.92-04.96	0 265 001 304		
2.5i V6 [167 MY96]	2,5l	121 kW	AR 67303	6 Zyl.
Throttle valve sensor	05.96-10.97	0 280 122 001		
Air flow sensor, gasoline injection	05.96-10.97	0 280 202 211		
		0 986 280 091		
Speed sensor, ignition/injection	05.96-10.97	0 261 210 090		
Temperature sensor, coolant, injection system	05.96-10.97	0 280 130 026		
Wheel speed sensor, front	05.96-10.97	0 265 006 212		
Wheel speed sensor, rear	05.96-10.97	0 265 006 197		
2.5 TD [167]	2,5l	92 kW	VM07B / VM31B	4 Zyl.
Air flow sensor, diesel	04.93-04.96	0 280 202 205		
Pulse generator, diesel	04.93-04.96	0 281 002 096		
Temperature sensor, coolant, diesel	04.93-04.96	0 280 130 055		
Pedal position sensor, diesel	04.93-05.95	0 205 001 009		
	06.95-04.96	0 205 001 016		
Wheel speed sensor, front				
Ricam.no →0159167	04.93-04.96	0 265 006 212		
Ricam.no 0159168→	04.93-04.96	0 265 006 162		
Wheel speed sensor, rear				
Ricam.no →0159167	04.93-04.96	0 265 006 197		
2.5 TD [167 MY96]	2,5l	92 kW	VM31B EDC-Bosch	4 Zyl.
Air flow sensor, diesel	05.96-10.97	0 280 202 205		
Pedal position sensor, diesel	05.96-10.97	0 204 120 802		
Wheel speed sensor, front	05.96-10.97	0 265 006 212		
Wheel speed sensor, rear	05.96-10.97	0 265 006 197		
2.5 V6 [167 MY92]	2,5l	120 kW	AR 67301	6 Zyl.
Throttle valve sensor	02.92-04.96	0 280 122 001		
Air flow sensor, gasoline injection	02.92-04.96	0 280 202 204		
		0 986 280 055		
Speed sensor, ignition/injection	02.92-04.96	0 261 210 090		
Temperature sensor, coolant, injection system	02.92-04.96	0 280 130 026		
Wheel speed sensor, front				
Ricam.no →0159167	02.92-04.96	0 265 006 212		
Ricam.no 0159168→	02.92-04.96	0 265 006 162		
Wheel speed sensor, rear	02.92-04.96	0 265 006 197		
156 Berlina				
1.6 TS 16V [932]	1,6l	88 kW	AR32102	4 Zyl.
Throttle valve assembly	04.98-09.00	3 437 010 452		
Air mass meter, gasoline injection	04.98-06.98	0 280 217 111		
	07.98-09.00	0 280 218 019		
Phase sensor	04.98-09.00	0 232 101 026		
Speed sensor, ignition/injection	04.98-09.00	0 261 210 160		

Product				
Knock sensor	04.98-09.00	0 261 231 131		
Temperature sensor, intake air, injection system	04.98-09.00	0 280 130 073		
Temperature sensor, coolant, injection system	04.98-09.00	0 280 130 026		
Wheel speed sensor, front				
Ricam.no →0062418	04.98-09.00	LAB	0 265 007 016	
		RAB	0 265 007 017	
Ricam.no 0062419→	04.98-09.00	LAB	0 265 007 046	
		RAB	0 265 007 047	
Wheel speed sensor, rear				
Ricam.no →0062418	04.98-09.00	0 265 007 018		
Ricam.no 0062419→	04.98-09.00	0 265 007 048		
1.6 TS 16V [932]	1,6l	88 kW	AR32103	4 Zyl.
Throttle valve assembly	09.00-12.01	0 280 750 073		
Mot.no. →3636739	01.02-10.05	0 280 750 073		
Air mass meter, gasoline injection	09.00-10.05	0 281 002 309		
Phase sensor	09.00-12.01	0 232 101 026		
	01.02-10.05	0 232 101 035		
Speed sensor, ignition/injection	09.00-12.01	0 261 210 160		
Mot.no. →3636739	01.02-10.05	0 261 210 160		
Mot.no. 3636740→	01.02-10.05	0 261 210 227		
Knock sensor	09.00-10.05	0 261 231 131		
Temperature sensor, intake air, injection system	09.00-12.01	0 280 130 073		
Temperature sensor, coolant, injection system	09.00-12.01	0 280 130 026		
Yaw rate sensor, brake system	01.02-10.05	0 265 005 241		
Pressure sensor, ESP, (electronic stability program)	01.02-10.05	0 265 005 303		
Wheel speed sensor, front	10.02-10.05	LAB,MFD	0 265 007 486	
		MFD,RAB	0 265 007 487	
Ricam.no →0062418	09.00-12.01	LAB	0 265 007 016	
		RAB	0 265 007 017	
Ricam.no →00526907	01.02-10.02	LAB	0 265 007 046	
		RAB	0 265 007 047	
Ricam.no 0062419→	09.00-12.01	LAB	0 265 007 046	
		RAB	0 265 007 047	
Wheel speed sensor, rear	10.02-10.05	MFD	0 265 007 488	
		OFD	0 265 007 113	
Ricam.no →0062418	09.00-12.01	0 265 007 018		
Ricam.no →00526907	01.02-10.02	0 265 007 048		
Ricam.no 0062419→	09.00-12.01	0 265 007 048		
1.6 TS 16V [932]	1,6l	88 kW	AR32104	4 Zyl.
Throttle valve assembly	09.00-12.01	0 280 750 073		
Mot.no. →3636739	01.02-10.05	0 280 750 073		
Air mass meter, gasoline injection	01.02-10.05	0 281 002 309		
	09.00-12.01	LLE	0 281 002 309	
Phase sensor	09.00-12.01	0 232 101 026		
	01.02-10.05	0 232 101 035		
Speed sensor, ignition/injection	09.00-12.01	0 261 210 160		
Mot.no. →3636739	01.02-10.05	0 261 210 160		
Mot.no. 3636740→	01.02-10.05	0 261 210 227		
Knock sensor	09.00-10.05	0 261 231 131		
Temperature sensor, intake air, injection system	09.00-12.01	0 280 130 073		
Temperature sensor, coolant, injection system	09.00-12.01	0 280 130 026		
Yaw rate sensor, brake system	01.02-10.05	0 265 005 241		
Pressure sensor, ESP, (electronic stability program)	01.02-10.05	0 265 005 303		
Wheel speed sensor, front	10.02-10.05	LAB,MFD	0 265 007 486	
		MFD,RAB	0 265 007 487	
Ricam.no →0062418	09.00-12.01	LAB	0 265 007 016	
		RAB	0 265 007 017	
Ricam.no →00526907	01.02-10.02	LAB	0 265 007 046	
		RAB	0 265 007 047	
Ricam.no 0062419→	09.00-12.01	LAB	0 265 007 046	
		RAB	0 265 007 047	





Wheel speed sensor, rear	10.02-10.05	MFD	0 265 007 488
		OFD	0 265 007 113
Ricam.no →0062418	09.00-12.01		0 265 007 018
Ricam.no →00526907	01.02-10.02		0 265 007 048
Ricam.no 0062419→	09.00-12.01		0 265 007 048
1.6 TS 16V [932]	1,6l 88 kW AR67601 4 Zyl.		
Throttle valve assembly			
Ricam.no 00084340→	10.97-09.00		3 437 010 452
Air mass meter, gasoline injection	10.97-06.98		0 280 217 111
	07.98-09.00		0 280 218 019
Phase sensor	10.97-09.00		0 232 101 026
Speed sensor, ignition/injection	10.97-09.00		0 261 210 160
Knock sensor	10.97-09.00		0 261 231 131
Temperature sensor, intake air, injection system	10.97-09.00		0 280 130 073
Temperature sensor, coolant, injection system	10.97-09.00		0 280 130 026
Wheel speed sensor, front	10.97-03.98	LAB	0 265 007 016
		RAB	0 265 007 017
Ricam.no →0062418	10.97-09.00	LAB	0 265 007 016
		RAB	0 265 007 017
Ricam.no 0062419→	10.97-09.00	LAB	0 265 007 046
		RAB	0 265 007 047
Wheel speed sensor, rear	10.97-03.98		0 265 007 018
Ricam.no →0062418	10.97-09.00		0 265 007 018
Ricam.no 0062419→	10.97-09.00		0 265 007 048
1.8 TS 16V [932]	1,8l 106 kW AR32201 4 Zyl.		
Throttle valve assembly	10.97-09.00		3 437 010 460
Air mass meter, gasoline injection	10.97-09.00		0 280 218 019
Phase sensor	10.97-09.00		0 232 101 035
Speed sensor, ignition/injection	10.97-09.00		0 261 210 160
Knock sensor	10.97-09.00		0 261 231 131
Temperature sensor, coolant, injection system	10.97-09.00	2PO	0 281 002 209
Wheel speed sensor, front	10.97-03.98	LAB	0 265 007 016
		RAB	0 265 007 017
Ricam.no →0062418	10.97-09.00	LAB	0 265 007 016
		RAB	0 265 007 017
Ricam.no 0062419→	10.97-09.00	LAB	0 265 007 046
		RAB	0 265 007 047
Wheel speed sensor, rear	10.97-03.98		0 265 007 018
Ricam.no →0062418	10.97-09.00		0 265 007 018
Ricam.no 0062419→	10.97-09.00		0 265 007 048
1.8 TS 16V [932]	1,8l 106 kW AR32205 4 Zyl.		
Throttle valve assembly	09.00-12.01		0 280 750 102
Mot.no. →3649574	01.02-04.04		0 280 750 102
Mot.no. 3649575→	05.04-10.05		1 287 213 612
Air mass meter, gasoline injection	01.02-10.05		0 281 002 309
	09.00-12.01	LLE	0 281 002 309
Phase sensor	09.00-10.05		0 232 101 035
Speed sensor, ignition/injection	09.00-12.01		0 261 210 160
Mot.no. →3649574	01.02-10.05		0 261 210 160
Mot.no. 3649575→	01.02-10.05		0 261 210 227
Knock sensor	09.00-10.05		0 261 231 131
Temperature sensor, coolant, injection system	09.00-12.01	2PO	0 281 002 209
Yaw rate sensor, brake system	01.02-10.05		0 265 005 241
Pressure sensor, ESP, (electronic stability program)	01.02-10.05		0 265 005 303
Wheel speed sensor, front	10.02-10.05	LAB,MFD	0 265 007 486
		MFD,RAB	0 265 007 487
Ricam.no →0062418	09.00-12.01	LAB	0 265 007 016
		RAB	0 265 007 017
Ricam.no →00526907	01.02-10.02	LAB	0 265 007 046
		RAB	0 265 007 047
Ricam.no 0062419→	09.00-12.01	LAB	0 265 007 046
		RAB	0 265 007 047



Wheel speed sensor, rear	10.02-10.05	MFD	0 265 007 488
		OFD	0 265 007 113
Ricam.no →0062418	09.00-12.01		0 265 007 018
Ricam.no →00526907	01.02-10.02		0 265 007 048
Ricam.no 0062419→	09.00-12.01		0 265 007 048
1.9 JTD [932]	1,9l 74 kW 182B9.000 4 Zyl.		
Air mass meter, diesel	06.03-12.04		0 281 002 309
Speed sensor, diesel	06.03-12.04		0 281 002 214
Phase sensor	06.03-12.04		0 281 002 213
High-pressure sensor (CR system)	06.03-12.04		0 281 002 260
Yaw rate sensor, brake system	06.03-12.04		0 265 005 241
Pressure sensor, ESP, (electronic stability program)	06.03-12.04		0 265 005 303
Wheel speed sensor, front	06.03-12.04	LAB,MFD	0 265 007 486
		MFD,RAB	0 265 007 487
Wheel speed sensor, rear	06.03-12.04	MFD	0 265 007 488
		OFD	0 265 007 113
1.9 JTD [932]	1,9l 76 kW AR32302 4 Zyl.		
Air mass meter, diesel	05.98-09.00		0 280 218 019
	10.97-04.98		0 281 002 199
Speed sensor, diesel	10.97-09.00		0 281 002 214
Phase sensor	10.97-09.00		0 281 002 213
High-pressure sensor (CR system)	10.97-09.00		0 281 002 210
Boost pressure sensor, Diesel	10.97-09.00		0 281 002 215
Temperature sensor, coolant, diesel	10.97-09.00	2PO	0 281 002 209
Temperature sensor, fuel	10.97-09.00	2PO	0 281 002 209
Pedal position sensor, diesel	10.97-09.00		0 281 002 203
Wheel speed sensor, front	10.97-03.98	LAB	0 265 007 016
		RAB	0 265 007 017
Ricam.no →0062418	10.97-09.00	LAB	0 265 007 016
		RAB	0 265 007 017
Ricam.no 0062419→	10.97-09.00	LAB	0 265 007 046
		RAB	0 265 007 047
Wheel speed sensor, rear	10.97-03.98		0 265 007 018
Ricam.no →0062418	10.97-09.00		0 265 007 018
Ricam.no 0062419→	10.97-09.00		0 265 007 048
1.9 JTD [932]	1,9l 81-85 kW AR37101 / 937A2.000 4 Zyl.		
Air mass meter, diesel	09.00-12.01		0 281 002 309
Speed sensor, diesel	09.00-12.01		0 281 002 214
Phase sensor	09.00-12.01		0 281 002 213
High-pressure sensor (CR system)	09.00-12.01		0 281 002 260
Boost pressure sensor, Diesel	09.00-12.01		0 281 002 215
Temperature sensor, coolant, diesel	09.00-12.01	2PO	0 281 002 209
Temperature sensor, fuel	09.00-12.01	2PO	0 281 002 209
Wheel speed sensor, front			
Ricam.no →0062418	09.00-12.01	LAB	0 265 007 016
		RAB	0 265 007 017
Ricam.no 0062419→	09.00-12.01	LAB	0 265 007 046
		RAB	0 265 007 047
Wheel speed sensor, rear			
Ricam.no →0062418	09.00-12.01		0 265 007 018
Ricam.no 0062419→	09.00-12.01		0 265 007 048
1.9 JTD [932]	1,9l 85 kW 937A2.000 4 Zyl.		
Air mass meter, diesel	01.02-10.05		0 281 002 309
Speed sensor, diesel	01.02-01.04		0 281 002 474
	02.04-10.05		0 281 002 603
Phase sensor	01.02-10.05		0 281 002 213
High-pressure sensor (CR system)			
Mot.no. →3928481	01.02-01.04	LLE	0 281 002 405
Mot.no. →3940874	01.02-01.04	RLE	0 281 002 405
Mot.no. 3928482→	02.04-10.05	LLE	0 281 002 734
Mot.no. 3940875→	02.04-10.05	RLE	0 281 002 734
Boost pressure sensor, Diesel	01.02-10.05		0 281 002 844
Yaw rate sensor, brake system	01.02-10.05		0 265 005 241


Product				

◀ 156 Berlina

Pressure sensor, ESP, (electronic stability program)	01.02-10.05		0 265 005 303
Wheel speed sensor, front	10.02-10.05	LAB,MFD	0 265 007 486
		MFD,RAB	0 265 007 487
Ricam.no →00526907	01.02-10.02	LAB	0 265 007 046
		RAB	0 265 007 047
Wheel speed sensor, rear	10.02-10.05	MFD	0 265 007 488
		OFD	0 265 007 113
Ricam.no →00526907	01.02-10.02		0 265 007 048
1.9 JTD 16V [932]	1,9l 93/100/103 kW 192A5.000; 192B1000; 937A4.000 4 Zyl.		
Throttle valve assembly	10.02-10.05		0 280 750 102
Air mass meter, diesel	10.02-10.05		0 280 218 113
High-pressure sensor (CR system)	10.02-10.05		0 281 002 534
Boost pressure sensor, Diesel	10.02-10.05		0 281 002 437
Yaw rate sensor, brake system	10.02-10.05		0 265 005 241
Pressure sensor, ESP, (electronic stability program)	10.02-10.05		0 265 005 303
Wheel speed sensor, front	10.02-10.05	LAB,MFD	0 265 007 486
		MFD,RAB	0 265 007 487
Wheel speed sensor, rear	10.02-10.05	MFD	0 265 007 488
		OFD	0 265 007 113
2.0 JTS 16V [932]	2,0l 119/121 kW 932A2.000; 937A1.000 4 Zyl.		
Throttle valve assembly	01.02-12.05		0 280 750 102
Air mass meter, gasoline injection	01.02-12.05		0 280 218 113
Phase sensor	01.02-12.05		0 232 101 035
Speed sensor, ignition/injection	01.02-12.05		0 261 210 227
Knock sensor	01.02-12.05		0 261 231 148
Yaw rate sensor, brake system	01.02-12.05		0 265 005 241
Pressure sensor, ESP, (electronic stability program)	01.02-12.05		0 265 005 303
Wheel speed sensor, front	10.02-12.05	LAB,MFD	0 265 007 486
		MFD,RAB	0 265 007 487
Ricam.no →00526907	01.02-10.02	LAB	0 265 007 046
		RAB	0 265 007 047
Wheel speed sensor, rear	10.02-12.05	MFD	0 265 007 488
		OFD	0 265 007 113
Ricam.no →00526907	01.02-10.02		0 265 007 048
2.0 TS 16V [932]	2,0l 114 kW AR32301 4 Zyl.		
Throttle valve assembly	10.97-09.00	GS	3 437 010 460
Air mass meter, gasoline injection	10.97-09.00		0 280 218 019
Phase sensor	10.97-09.00		0 232 101 035
Speed sensor, ignition/injection	10.97-09.00		0 261 210 160
Knock sensor	10.97-09.00		0 261 231 131
Vacuum pickup, ignition/injection	10.97-09.00		0 928 400 327
Wheel speed sensor, front	10.97-03.98	LAB	0 265 007 016
		RAB	0 265 007 017
Ricam.no →0062418	10.97-09.00	LAB	0 265 007 016
		RAB	0 265 007 017
Ricam.no 0062419→	10.97-09.00	LAB	0 265 007 046
		RAB	0 265 007 047
Wheel speed sensor, rear	10.97-03.98		0 265 007 018
Ricam.no →0062418	10.97-09.00		0 265 007 018
Ricam.no 0062419→	10.97-09.00		0 265 007 048
2.0 TS 16V [932]	2,0l 114 kW AR32303 4 Zyl.		
Throttle valve assembly	10.97-12.01		3 437 010 460
Air mass meter, gasoline injection	10.97-12.01		0 280 218 019
Phase sensor	10.97-12.01		0 232 101 035
Speed sensor, ignition/injection	10.97-12.01		0 261 210 160
Knock sensor	10.97-12.01		0 261 231 131
Vacuum pickup, ignition/injection	10.97-12.01		0 928 400 327
Wheel speed sensor, front	10.97-03.98	LAB	0 265 007 016
		RAB	0 265 007 017
Ricam.no →0062418	10.97-12.01	LAB	0 265 007 016
		RAB	0 265 007 017
Ricam.no 0062419→	10.97-12.01	LAB	0 265 007 046
		RAB	0 265 007 047

Product				

Wheel speed sensor, rear	10.97-03.98		0 265 007 018
Ricam.no →0062418	10.97-12.01		0 265 007 018
Ricam.no 0062419→	10.97-12.01		0 265 007 048
2.0 TS 16V [932]	2,0l 114 kW AR32310 4 Zyl.		
Throttle valve assembly	09.00-12.01		0 280 750 102
Air mass meter, gasoline injection	09.00-12.01	LLE	0 281 002 309
Phase sensor	09.00-12.01		0 232 101 035
Speed sensor, ignition/injection	09.00-12.01		0 261 210 160
Knock sensor	09.00-12.01		0 261 231 131
Vacuum pickup, ignition/injection	09.00-12.01		0 928 400 327
Wheel speed sensor, front			
Ricam.no →0062418	09.00-12.01	LAB	0 265 007 016
		RAB	0 265 007 017
Ricam.no 0062419→	09.00-12.01	LAB	0 265 007 046
		RAB	0 265 007 047
Wheel speed sensor, rear			
Ricam.no →0062418	09.00-12.01		0 265 007 018
Ricam.no 0062419→	09.00-12.01		0 265 007 048
2.0 TS 16V [932]	2,0l 121 kW AR32310 4 Zyl.		
Throttle valve assembly	01.02-10.05		0 280 750 102
Air mass meter, gasoline injection	01.02-10.05		0 281 002 309
Phase sensor	01.02-10.05		0 232 101 035
Speed sensor, ignition/injection			
Mot.no. →3649574	01.02-10.05		0 261 210 160
Mot.no. 3649575→	01.02-10.05		0 261 210 227
Knock sensor	01.02-10.05		0 261 231 131
Vacuum pickup, ignition/injection	01.02-10.05		0 928 400 327
Yaw rate sensor, brake system	01.02-10.05		0 265 005 241
Pressure sensor, ESP, (electronic stability program)	01.02-10.05		0 265 005 303
Wheel speed sensor, front	01.02-10.05	LAB,MFD	0 265 007 486
		MFD,RAB	0 265 007 487
Wheel speed sensor, rear	01.02-10.05	MFD	0 265 007 488
		OFD	0 265 007 113
2.4 JTD [932]	2,4l 100 kW AR32501 5 Zyl.		
Air mass meter, diesel	05.98-09.00		0 280 218 019
	10.97-04.98		0 281 002 199
Speed sensor, diesel	10.97-09.00		0 281 002 474
Phase sensor	10.97-09.00		0 281 002 213
High-pressure sensor (CR system)	10.97-09.00		0 281 002 210
Boost pressure sensor, Diesel	10.97-09.00		0 281 002 215
Temperature sensor, coolant, diesel	10.97-09.00	2PO	0 281 002 209
Temperature sensor, fuel	10.97-09.00	2PO	0 281 002 209
Pedal position sensor, diesel	10.97-09.00		0 281 002 203
Wheel speed sensor, front	10.97-03.98	LAB	0 265 007 016
		RAB	0 265 007 017
Ricam.no →0062418	10.97-09.00	LAB	0 265 007 016
		RAB	0 265 007 017
Ricam.no 0062419→	10.97-09.00	LAB	0 265 007 046
		RAB	0 265 007 047
Wheel speed sensor, rear	10.97-03.98		0 265 007 018
Ricam.no →0062418	10.97-09.00		0 265 007 018
Ricam.no 0062419→	10.97-09.00		0 265 007 048
2.4 JTD [932]	2,4l 100 kW 839A6.000 5 Zyl.		
Air mass meter, diesel	09.00-12.01		0 281 002 309
Speed sensor, diesel	09.00-12.01		0 281 002 474
Phase sensor	09.00-12.01		0 281 002 213
High-pressure sensor (CR system)	09.00-12.01		0 281 002 405
Boost pressure sensor, Diesel	09.00-12.01		0 281 002 215
Temperature sensor, coolant, diesel	09.00-12.01	2PO	0 281 002 209
Temperature sensor, fuel	09.00-12.01	2PO	0 281 002 209
Pedal position sensor, diesel	09.00-12.01		0 281 002 203



Wheel speed sensor, front			
Ricam.no →0062418	09.00-12.01	LAB	0 265 007 016
		RAB	0 265 007 017
Ricam.no 0062419→	09.00-12.01	LAB	0 265 007 046
		RAB	0 265 007 047
Wheel speed sensor, rear			
Ricam.no →0062418	09.00-12.01		0 265 007 018
Ricam.no 0062419→	09.00-12.01		0 265 007 048
2.4 JTD [932]	2,4l 110 kW 841C000 5 Zyl.		
Air mass meter, diesel	01.02-10.05		0 281 002 309
Speed sensor, diesel	01.02-10.05		0 281 002 474
Phase sensor	01.02-10.05		0 281 002 213
High-pressure sensor (CR system)	01.02-10.05		0 281 002 405
Boost pressure sensor, Diesel	01.02-10.05		0 281 002 844
Yaw rate sensor, brake system	01.02-10.05		0 265 005 241
Pressure sensor, ESP, (electronic stability program)	01.02-10.05		0 265 005 303
Wheel speed sensor, front	10.02-10.05	LAB,MFD	0 265 007 486
		MFD,RAB	0 265 007 487
Ricam.no →00526907	01.02-10.02	LAB	0 265 007 046
		RAB	0 265 007 047
Wheel speed sensor, rear	10.02-10.05	MFD	0 265 007 488
		OFD	0 265 007 113
Ricam.no →00526907	01.02-10.02		0 265 007 048
2.4 JTD [932]	2,4l 129 kW 841G.000 5 Zyl.		
Throttle valve assembly	06.03-10.05		0 280 750 102
Air mass meter, diesel	06.03-10.05		0 281 002 598
Boost pressure sensor, Diesel	06.03-10.05		0 281 002 437
Yaw rate sensor, brake system	06.03-10.05		0 265 005 241
Pressure sensor, ESP, (electronic stability program)	06.03-10.05		0 265 005 303
Wheel speed sensor, front	06.03-10.05	LAB,MFD	0 265 007 486
		MFD,RAB	0 265 007 487
Wheel speed sensor, rear	06.03-10.05	MFD	0 265 007 488
		OFD	0 265 007 113
2.4 JTD 20V [932]	2,4l 120 kW 841M000 5 Zyl.		
Throttle valve assembly	10.04-10.05		0 280 750 102
Air mass meter, diesel	10.04-10.05		0 281 002 598
Boost pressure sensor, Diesel	10.04-10.05		0 281 002 437
Yaw rate sensor, brake system	10.04-10.05		0 265 005 241
Pressure sensor, ESP, (electronic stability program)	10.04-10.05		0 265 005 303
Wheel speed sensor, front	10.04-10.05	LAB,MFD	0 265 007 486
		MFD,RAB	0 265 007 487
Wheel speed sensor, rear	10.04-10.05	MFD	0 265 007 488
		OFD	0 265 007 113
2.5 24V [932]	2,5l 140 kW AR32401; AR32402 6 Zyl.		
Throttle valve assembly	10.97-12.01		0 280 750 014
Air mass meter, gasoline injection	10.97-12.01		0 280 217 531
Speed sensor, ignition/injection	10.97-12.01		0 261 210 163
Knock sensor	10.97-12.01	L43	0 261 231 095
Temperature sensor, coolant, injection system	10.97-12.01		0 280 130 055
Wheel speed sensor, front	10.97-03.98	LAB	0 265 007 016
		RAB	0 265 007 017
Ricam.no →0062418	10.97-12.01	LAB	0 265 007 016
		RAB	0 265 007 017
Ricam.no 0062419→	10.97-12.01	LAB	0 265 007 046
		RAB	0 265 007 047
Wheel speed sensor, rear	10.97-03.98		0 265 007 018
Ricam.no →0062418	10.97-12.01		0 265 007 018
Ricam.no 0062419→	10.97-12.01		0 265 007 048
2.5 24V [932]	2,5l 140 kW AR32405 6 Zyl.		
Throttle valve assembly	09.00-12.01		0 280 750 014
Air mass meter, gasoline injection	09.00-12.01		0 280 218 054
Speed sensor, ignition/injection	09.00-12.01		0 261 210 163
Knock sensor	09.00-12.01	L43	0 261 231 095



Temperature sensor, coolant, injection system	09.00-12.01		0 280 130 055
Wheel speed sensor, front			
Ricam.no →0062418	09.00-12.01	LAB	0 265 007 016
		RAB	0 265 007 017
Ricam.no 0062419→	09.00-12.01	LAB	0 265 007 046
		RAB	0 265 007 047
Wheel speed sensor, rear			
Ricam.no →0062418	09.00-12.01		0 265 007 018
Ricam.no 0062419→	09.00-12.01		0 265 007 048
2.5 24V [932]	2,5l 141 kW AR32405 6 Zyl.		
Throttle valve assembly	01.02-10.05		0 280 750 014
Air mass meter, gasoline injection	01.02-10.05		0 280 218 054
Phase sensor	01.02-10.05		0 232 103 024
Speed sensor, ignition/injection	01.02-10.05		0 261 210 203
Yaw rate sensor, brake system	01.02-10.05		0 265 005 241
Pressure sensor, ESP, (electronic stability program)	01.02-10.05		0 265 005 303
Wheel speed sensor, front	10.02-10.05	LAB,MFD	0 265 007 486
		MFD,RAB	0 265 007 487
Ricam.no →00526907	01.02-10.02	LAB	0 265 007 046
		RAB	0 265 007 047
Wheel speed sensor, rear	10.02-10.05	MFD	0 265 007 488
		OFD	0 265 007 113
Ricam.no →00526907	01.02-10.02		0 265 007 048
3.2 GTA [932]	3,2l 184 kW 932A000 6 Zyl.		
Throttle valve assembly	03.02-10.05		0 280 750 014
Air mass meter, gasoline injection	03.02-10.05		0 281 002 533
Phase sensor	03.02-10.05		0 232 103 024
Speed sensor, ignition/injection	03.02-10.05		0 261 210 203
Yaw rate sensor, brake system	03.02-10.05		0 265 005 241
Pressure sensor, ESP, (electronic stability program)	03.02-10.05		0 265 005 303
Wheel speed sensor, front	10.02-10.05	LAB,MFD	0 265 007 486
		MFD,RAB	0 265 007 487
Ricam.no →00526907	03.02-10.02	LAB	0 265 007 046
		RAB	0 265 007 047
Wheel speed sensor, rear	10.02-10.05	MFD	0 265 007 488
		OFD	0 265 007 113
Ricam.no →00526907	03.02-10.02		0 265 007 048

156 Cross Wagon Q4

1.9 JTD 4x4 [932]	1,9l 110 kW 937A5000 4 Zyl.	
Throttle valve assembly	10.04→	0 280 750 102
Air mass meter, diesel	10.04-05.05 EU3	0 280 218 113
High-pressure sensor (CR system)	10.04-05.05	0 281 002 534
	06.05→	0 281 002 706
Boost pressure sensor, Diesel	10.04→	0 281 002 437
Yaw rate sensor, brake system	10.04→	0 265 005 241
Pressure sensor, ESP, (electronic stability program)	10.04→	0 265 005 303
Wheel speed sensor, rear	10.04→	0 265 007 691

156 Sport Wagon

1.6 TS 16V [932]	1,6l 88 kW AR32104 4 Zyl.	
Throttle valve assembly		
Mot.no. →3636739	01.02-12.05	0 280 750 073
Air mass meter, gasoline injection	01.02-12.05	0 281 002 309
Phase sensor	01.02-12.05	0 232 101 035
Speed sensor, ignition/injection		
Mot.no. →3636739	01.02-12.05	0 261 210 160
Mot.no. 3636740→	01.02-12.05	0 261 210 227
Knock sensor	01.02-12.05	0 261 231 131
Yaw rate sensor, brake system	01.02-12.05	0 265 005 241
Pressure sensor, ESP, (electronic stability program)	01.02-12.05	0 265 005 303



Product				

◀ 156 Sport Wagon

Wheel speed sensor, front	10.02-12.05	LAB,MFD	0 265 007 486
		MFD,RAB	0 265 007 487
Ricam.no →00526907	01.02-10.02	LAB	0 265 007 046
		RAB	0 265 007 047
Wheel speed sensor, rear	10.02-12.05	MFD	0 265 007 488
		OFD	0 265 007 113
Ricam.no →00526907	01.02-10.02		0 265 007 048
1.6 TS 16V [932]	1,6l 88 kW AR32104 CF3 4 Zyl.		
Throttle valve assembly	09.00-12.01		0 280 750 073
Air mass meter, gasoline injection	09.00-12.01	LLE	0 281 002 309
Phase sensor	09.00-12.01		0 232 101 026
Speed sensor, ignition/injection	09.00-12.01		0 261 210 160
Knock sensor	09.00-12.01		0 261 231 131
Temperature sensor, intake air, injection system	09.00-12.01		0 280 130 073
Temperature sensor, coolant, injection system	09.00-12.01		0 280 130 026
Wheel speed sensor, front			
Ricam.no →0062418	09.00-12.01	LAB	0 265 007 016
		RAB	0 265 007 017
Ricam.no 0062419→	09.00-12.01	LAB	0 265 007 046
		RAB	0 265 007 047
Wheel speed sensor, rear			
Ricam.no →0062418	09.00-12.01		0 265 007 018
Ricam.no 0062419→	09.00-12.01		0 265 007 048
1.6 TS 16V [932]	1,6l 88 kW AR67601 CF2 4 Zyl.		
Throttle valve assembly	06.00-09.00		3 437 010 452
Air mass meter, gasoline injection	06.00-09.00		0 280 218 019
Phase sensor	06.00-09.00		0 232 101 026
Speed sensor, ignition/injection	06.00-09.00		0 261 210 160
Knock sensor	06.00-09.00		0 261 231 131
Temperature sensor, intake air, injection system	06.00-09.00		0 280 130 073
Temperature sensor, coolant, injection system	06.00-09.00		0 280 130 026
Wheel speed sensor, front			
Ricam.no →0062418	06.00-09.00	LAB	0 265 007 016
		RAB	0 265 007 017
Ricam.no 0062419→	06.00-09.00	LAB	0 265 007 046
		RAB	0 265 007 047
Wheel speed sensor, rear			
Ricam.no →0062418	06.00-09.00		0 265 007 018
Ricam.no 0062419→	06.00-09.00		0 265 007 048
1.8 TS 16V [932]	1,8l 106 kW AR32201 CF2 4 Zyl.		
Throttle valve assembly	06.00-09.00		3 437 010 460
Air mass meter, gasoline injection	06.00-09.00		0 280 218 019
Phase sensor	06.00-09.00		0 232 101 035
Speed sensor, ignition/injection	06.00-09.00		0 261 210 160
Knock sensor	06.00-09.00		0 261 231 131
Temperature sensor, coolant, injection system	06.00-09.00	2PO	0 281 002 209
Wheel speed sensor, front			
Ricam.no →0062418	06.00-09.00	LAB	0 265 007 016
		RAB	0 265 007 017
Ricam.no 0062419→	06.00-09.00	LAB	0 265 007 046
		RAB	0 265 007 047
Wheel speed sensor, rear			
Ricam.no →0062418	06.00-09.00		0 265 007 018
Ricam.no 0062419→	06.00-09.00		0 265 007 048
1.8 TS 16V [932]	1,8l 106 kW AR32205 4 Zyl.		
Throttle valve assembly			
Mot.no. →3649574	01.02-04.04		0 280 750 102
Mot.no. 3649575→	05.04-12.05		1 287 213 612
Air mass meter, gasoline injection	01.02-12.05		0 281 002 309
Phase sensor	01.02-12.05		0 232 101 035
Speed sensor, ignition/injection			
Mot.no. →3649574	01.02-12.05		0 261 210 160
Mot.no. 3649575→	01.02-12.05		0 261 210 227

Product				

Knock sensor	01.02-12.05		0 261 231 131
Yaw rate sensor, brake system	01.02-12.05		0 265 005 241
Pressure sensor, ESP, (electronic stability program)	01.02-12.05		0 265 005 303
Wheel speed sensor, front	10.02-12.05	LAB,MFD	0 265 007 486
		MFD,RAB	0 265 007 487
Ricam.no →00526907	01.02-10.02	LAB	0 265 007 046
		RAB	0 265 007 047
Wheel speed sensor, rear	10.02-12.05	MFD	0 265 007 488
		OFD	0 265 007 113
Ricam.no →00526907	01.02-10.02		0 265 007 048
1.8 TS 16V [932]	1,8l 106 kW AR32205 CF3 4 Zyl.		
Throttle valve assembly	09.00-12.01		0 280 750 102
Air mass meter, gasoline injection	09.00-12.01	LLE	0 281 002 309
Phase sensor	09.00-12.01		0 232 101 035
Speed sensor, ignition/injection	09.00-12.01		0 261 210 160
Knock sensor	09.00-12.01		0 261 231 131
Temperature sensor, coolant, injection system	09.00-12.01	2PO	0 281 002 209
Wheel speed sensor, front			
Ricam.no →0062418	09.00-12.01	LAB	0 265 007 016
		RAB	0 265 007 017
Ricam.no 0062419→	09.00-12.01	LAB	0 265 007 046
		RAB	0 265 007 047
Wheel speed sensor, rear			
Ricam.no →0062418	09.00-12.01		0 265 007 018
Ricam.no 0062419→	09.00-12.01		0 265 007 048
1.9 JTD [932]	1,9l 74 kW 18289.000 4 Zyl.		
Air mass meter, diesel	06.03-12.04		0 281 002 309
Speed sensor, diesel	06.03-12.04		0 281 002 214
Phase sensor	06.03-12.04		0 281 002 213
High-pressure sensor (CR system)	06.03-12.04		0 281 002 260
Yaw rate sensor, brake system	06.03-12.04		0 265 005 241
Pressure sensor, ESP, (electronic stability program)	06.03-12.04		0 265 005 303
Wheel speed sensor, front	06.03-12.04	LAB,MFD	0 265 007 486
		MFD,RAB	0 265 007 487
Wheel speed sensor, rear	06.03-12.04	MFD	0 265 007 488
		OFD	0 265 007 113
1.9 JTD [932]	1,9l 76 kW AR32302 CF2 4 Zyl.		
Air mass meter, diesel	06.00-09.00		0 280 218 019
Speed sensor, diesel	06.00-09.00		0 281 002 214
Phase sensor	06.00-09.00		0 281 002 213
High-pressure sensor (CR system)	06.00-09.00		0 281 002 210
Boost pressure sensor, Diesel	06.00-09.00		0 281 002 215
Temperature sensor, coolant, diesel	06.00-09.00	2PO	0 281 002 209
Temperature sensor, fuel	06.00-09.00	2PO	0 281 002 209
Pedal position sensor, diesel	06.00-09.00		0 281 002 203
Wheel speed sensor, front			
Ricam.no →0062418	06.00-09.00	LAB	0 265 007 016
		RAB	0 265 007 017
Ricam.no 0062419→	06.00-09.00	LAB	0 265 007 046
		RAB	0 265 007 047
Wheel speed sensor, rear			
Ricam.no →0062418	06.00-09.00		0 265 007 018
Ricam.no 0062419→	06.00-09.00		0 265 007 048
1.9 JTD [932]	1,9l 80-85 kW AR37101 / 937A2.000 4 Zyl.		
Air mass meter, diesel	09.00-12.01		0 281 002 309
Speed sensor, diesel	09.00-12.01		0 281 002 214
Phase sensor	09.00-12.01		0 281 002 213
High-pressure sensor (CR system)	09.00-12.01		0 281 002 260
Boost pressure sensor, Diesel	09.00-12.01		0 281 002 215
Temperature sensor, coolant, diesel	09.00-12.01	2PO	0 281 002 209
Temperature sensor, fuel	09.00-12.01	2PO	0 281 002 209



Product				
Wheel speed sensor, front				
Ricam.no →0062418	09.00-12.01	LAB	0 265 007 016	
		RAB	0 265 007 017	
Ricam.no 0062419→	09.00-12.01	LAB	0 265 007 046	
		RAB	0 265 007 047	
Wheel speed sensor, rear				
Ricam.no →0062418	09.00-12.01		0 265 007 018	
Ricam.no 0062419→	09.00-12.01		0 265 007 048	
1.9 JTD [932]	1,9l 85 kW 937A2.000 4 Zyl.			
Air mass meter, diesel	01.02-12.05		0 281 002 309	
Speed sensor, diesel	01.02-01.04		0 281 002 474	
	02.04-12.05		0 281 002 603	
Phase sensor	01.02-12.05		0 281 002 213	
High-pressure sensor (CR system)				
Mot.no. →3928481	01.02-01.04	LLE	0 281 002 405	
Mot.no. 3928482→	02.04-12.05	LLE	0 281 002 734	
Yaw rate sensor, brake system	01.02-12.05		0 265 005 241	
Pressure sensor, ESP, (electronic stability program)	01.02-12.05		0 265 005 303	
Wheel speed sensor, front	10.02-12.05	LAB,MFD	0 265 007 486	
		MFD,RAB	0 265 007 487	
Ricam.no →00526907	01.02-10.02	LAB	0 265 007 046	
		RAB	0 265 007 047	
Wheel speed sensor, rear	10.02-12.05	MFD	0 265 007 488	
		OFD	0 265 007 113	
Ricam.no →00526907	01.02-10.02		0 265 007 048	
1.9 JTD 16V [932]	1,9l 93 kW 937A4.000 4 Zyl.			
Throttle valve assembly	06.03-10.05		0 280 750 102	
Air mass meter, diesel	06.03-10.05		0 280 218 113	
High-pressure sensor (CR system)	06.03-10.05		0 281 002 534	
Boost pressure sensor, Diesel	06.03-10.05		0 281 002 437	
Yaw rate sensor, brake system	06.03-10.05		0 265 005 241	
Pressure sensor, ESP, (electronic stability program)	06.03-10.05		0 265 005 303	
Wheel speed sensor, front	06.03-10.05	LAB,MFD	0 265 007 486	
		MFD,RAB	0 265 007 487	
Wheel speed sensor, rear	06.03-10.05	MFD	0 265 007 488	
		OFD	0 265 007 113	
1.9 JTD 16V [932]	1,9l 93 kW 937A4000 4 Zyl.			
Throttle valve assembly	10.03-12.05		0 280 750 102	
Boost pressure sensor, Diesel	10.03-12.05		0 281 002 437	
Yaw rate sensor, brake system	10.03-12.05		0 265 005 241	
Pressure sensor, ESP, (electronic stability program)	10.03-12.05		0 265 005 303	
Wheel speed sensor, rear	10.03-12.05		0 265 007 691	
1.9 JTD 16V [932]	1,9l 100/103 kW 192A5.000; 192B1000 4 Zyl.			
Throttle valve assembly	10.02-12.05		0 280 750 102	
Air mass meter, diesel	10.02-12.05		0 280 218 113	
High-pressure sensor (CR system)	10.02-12.05		0 281 002 534	
Boost pressure sensor, Diesel	10.02-12.05		0 281 002 437	
Yaw rate sensor, brake system	10.02-12.05		0 265 005 241	
Pressure sensor, ESP, (electronic stability program)	10.02-12.05		0 265 005 303	
Wheel speed sensor, front	10.02-12.05	LAB,MFD	0 265 007 486	
		MFD,RAB	0 265 007 487	
Wheel speed sensor, rear	10.02-12.05	MFD	0 265 007 488	
		OFD	0 265 007 113	
1.9 JTD 16V [932]	1,9l 110 kW 937A5000 4 Zyl.			
Throttle valve assembly	10.03-12.05		0 280 750 102	
Boost pressure sensor, Diesel	10.03-12.05		0 281 002 437	
Yaw rate sensor, brake system	10.03-12.05		0 265 005 241	
Pressure sensor, ESP, (electronic stability program)	10.03-12.05		0 265 005 303	
Wheel speed sensor, rear	10.03-12.05		0 265 007 691	
2.0 JTD 16V [932]	2,0l 119/121 kW 932A2.000; 937A1.000 4 Zyl.			
Throttle valve assembly	01.02-12.05		0 280 750 102	
Air mass meter, gasoline injection	01.02-12.05		0 280 218 113	
Phase sensor	01.02-12.05		0 232 101 035	

Product				
Speed sensor, ignition/injection	01.02-12.05		0 261 210 227	
Knock sensor	01.02-12.05		0 261 231 148	
Yaw rate sensor, brake system	01.02-12.05		0 265 005 241	
Pressure sensor, ESP, (electronic stability program)	01.02-12.05		0 265 005 303	
Wheel speed sensor, front	10.02-12.05	LAB,MFD	0 265 007 486	
		MFD,RAB	0 265 007 487	
Ricam.no →00526907	01.02-10.02	LAB	0 265 007 046	
		RAB	0 265 007 047	
Wheel speed sensor, rear	10.02-12.05	MFD	0 265 007 488	
		OFD	0 265 007 113	
Ricam.no →00526907	01.02-10.02		0 265 007 048	
2.0 TS 16V [932]	2,0l 114 kW AR32301 CF2 4 Zyl.			
Throttle valve assembly	06.00-09.00	GS	3 437 010 460	
Air mass meter, gasoline injection	06.00-09.00		0 280 218 019	
Phase sensor	06.00-09.00		0 232 101 035	
Speed sensor, ignition/injection	06.00-09.00		0 261 210 160	
Knock sensor	06.00-09.00		0 261 231 131	
Vacuum pickup, ignition/injection	06.00-09.00		0 928 400 327	
Wheel speed sensor, front				
Ricam.no →0062418	06.00-09.00	LAB	0 265 007 016	
		RAB	0 265 007 017	
Ricam.no 0062419→	06.00-09.00	LAB	0 265 007 046	
		RAB	0 265 007 047	
Wheel speed sensor, rear				
Ricam.no →0062418	06.00-09.00		0 265 007 018	
Ricam.no 0062419→	06.00-09.00		0 265 007 048	
2.0 TS 16V [932]	2,0l 114 kW AR32310 CF3 4 Zyl.			
Throttle valve assembly	09.00-12.01		0 280 750 102	
Air mass meter, gasoline injection	09.00-12.01	LLE	0 281 002 309	
Phase sensor	09.00-12.01		0 232 101 035	
Speed sensor, ignition/injection	09.00-12.01		0 261 210 160	
Knock sensor	09.00-12.01		0 261 231 131	
Vacuum pickup, ignition/injection	09.00-12.01		0 928 400 327	
Wheel speed sensor, front				
Ricam.no →0062418	09.00-12.01	LAB	0 265 007 016	
		RAB	0 265 007 017	
Ricam.no 0062419→	09.00-12.01	LAB	0 265 007 046	
		RAB	0 265 007 047	
Wheel speed sensor, rear				
Ricam.no →0062418	09.00-12.01		0 265 007 018	
Ricam.no 0062419→	09.00-12.01		0 265 007 048	
2.0 TS 16V [932]	2,0l 121 kW AR32310 CF3 4 Zyl.			
Throttle valve assembly	01.02-10.05		0 280 750 102	
Air mass meter, gasoline injection	01.02-10.05	LLE	0 281 002 309	
Phase sensor	01.02-10.05		0 232 101 035	
Speed sensor, ignition/injection				
Mot.no. →3649574	01.02-10.05		0 261 210 160	
Mot.no. 3649575→	01.02-10.05		0 261 210 227	
Knock sensor	01.02-10.05		0 261 231 131	
Vacuum pickup, ignition/injection	01.02-10.05		0 928 400 327	
Yaw rate sensor, brake system	01.02-10.05		0 265 005 241	
Pressure sensor, ESP, (electronic stability program)	01.02-10.05		0 265 005 303	
Wheel speed sensor, front	01.02-10.05	LAB,MFD	0 265 007 486	
		MFD,RAB	0 265 007 487	
Wheel speed sensor, rear	01.02-10.05	MFD	0 265 007 488	
		OFD	0 265 007 113	
2.4 JTD [932]	2,4l 100 kW AR32501 CF2 5 Zyl.			
Air mass meter, diesel	06.00-09.00		0 280 218 019	
Speed sensor, diesel	06.00-09.00		0 281 002 474	
Phase sensor	06.00-09.00		0 281 002 213	
High-pressure sensor (CR system)	06.00-09.00		0 281 002 210	
Boost pressure sensor, Diesel	06.00-09.00		0 281 002 215	
Temperature sensor, coolant, diesel	06.00-09.00	2PO	0 281 002 209	



Product				

◀ 156 Sport Wagon

Temperature sensor, fuel	06.00-09.00	2PO	0 281 002 209
Pedal position sensor, diesel	06.00-09.00		0 281 002 203
Wheel speed sensor, front			
Ricam.no →0062418	06.00-09.00	LAB	0 265 007 016
		RAB	0 265 007 017
Ricam.no 0062419→	06.00-09.00	LAB	0 265 007 046
		RAB	0 265 007 047
Wheel speed sensor, rear			
Ricam.no →0062418	06.00-09.00		0 265 007 018
Ricam.no 0062419→	06.00-09.00		0 265 007 048
2.4 JTD [932] 2,4l 100 kW 839A6.000 CF3 5 Zyl.			
Air mass meter, diesel	09.00-12.01		0 281 002 309
Speed sensor, diesel	09.00-12.01		0 281 002 474
Phase sensor	09.00-12.01		0 281 002 213
High-pressure sensor (CR system)	09.00-12.01		0 281 002 405
Boost pressure sensor, Diesel	09.00-12.01		0 281 002 215
Temperature sensor, coolant, diesel	09.00-12.01	2PO	0 281 002 209
Temperature sensor, fuel	09.00-12.01	2PO	0 281 002 209
Pedal position sensor, diesel	09.00-12.01		0 281 002 203
Wheel speed sensor, front			
Ricam.no →0062418	09.00-12.01	LAB	0 265 007 016
		RAB	0 265 007 017
Ricam.no 0062419→	09.00-12.01	LAB	0 265 007 046
		RAB	0 265 007 047
Wheel speed sensor, rear			
Ricam.no →0062418	09.00-12.01		0 265 007 018
Ricam.no 0062419→	09.00-12.01		0 265 007 048
2.4 JTD [932] 2,4l 110 kW 841C000 5 Zyl.			
Air mass meter, diesel	01.02-10.05		0 281 002 309
Speed sensor, diesel	01.02-10.05		0 281 002 474
Phase sensor	01.02-10.05		0 281 002 213
High-pressure sensor (CR system)	01.02-10.05		0 281 002 405
Boost pressure sensor, Diesel	01.02-10.05		0 281 002 844
Yaw rate sensor, brake system	01.02-10.05		0 265 005 241
Pressure sensor, ESP, (electronic stability program)	01.02-10.05		0 265 005 303
Wheel speed sensor, front	10.02-10.05	LAB,MFD	0 265 007 486
		MFD,RAB	0 265 007 487
Ricam.no →00526907	01.02-10.02	LAB	0 265 007 046
		RAB	0 265 007 047
Wheel speed sensor, rear	10.02-10.05	MFD	0 265 007 488
		OFD	0 265 007 113
Ricam.no →00526907	01.02-10.02		0 265 007 048
2.4 JTD [932] 2,4l 129 kW 841G000 5 Zyl.			
Throttle valve assembly	06.03-12.05		0 280 750 102
Air mass meter, diesel	06.03-12.05		0 281 002 598
Yaw rate sensor, brake system	06.03-12.05		0 265 005 241
Pressure sensor, ESP, (electronic stability program)	06.03-12.05		0 265 005 303
Wheel speed sensor, front	06.03-12.05	LAB,MFD	0 265 007 486
		MFD,RAB	0 265 007 487
Wheel speed sensor, rear	06.03-12.05	MFD	0 265 007 488
		OFD	0 265 007 113
2.4 JTD 20V [932] 2,4l 120 kW 841M000 5 Zyl.			
Throttle valve assembly	10.04-10.05		0 280 750 102
Air mass meter, diesel	10.04-10.05		0 281 002 598
Yaw rate sensor, brake system	10.04-10.05		0 265 005 241
Pressure sensor, ESP, (electronic stability program)	10.04-10.05		0 265 005 303
Wheel speed sensor, front	10.04-10.05	LAB,MFD	0 265 007 486
		MFD,RAB	0 265 007 487
Wheel speed sensor, rear	10.04-10.05	MFD	0 265 007 488
		OFD	0 265 007 113
2.5 24V [932] 2,5l 140 kW AR32401 CF2 6 Zyl.			
Throttle valve assembly	06.00-09.00		0 280 750 014
Air mass meter, gasoline injection	06.00-09.00		0 280 217 531

Product				

Speed sensor, ignition/injection	06.00-09.00		0 261 210 163
Knock sensor	06.00-09.00	L43	0 261 231 095
Temperature sensor, coolant, injection system	06.00-09.00		0 280 130 055
Wheel speed sensor, front			
Ricam.no →0062418	06.00-09.00	LAB	0 265 007 016
		RAB	0 265 007 017
Ricam.no 0062419→	06.00-09.00	LAB	0 265 007 046
		RAB	0 265 007 047
Wheel speed sensor, rear			
Ricam.no →0062418	06.00-09.00		0 265 007 018
Ricam.no 0062419→	06.00-09.00		0 265 007 048
2.5 24V [932] 2,5l 140 kW AR32405 CF3 6 Zyl.			
Throttle valve assembly	09.00-12.01		0 280 750 014
Air mass meter, gasoline injection	09.00-12.01		0 280 218 054
Speed sensor, ignition/injection	09.00-12.01		0 261 210 163
Knock sensor	09.00-12.01	L43	0 261 231 095
Temperature sensor, coolant, injection system	09.00-12.01		0 280 130 055
Wheel speed sensor, front			
Ricam.no →0062418	09.00-12.01	LAB	0 265 007 016
		RAB	0 265 007 017
Ricam.no 0062419→	09.00-12.01	LAB	0 265 007 046
		RAB	0 265 007 047
Wheel speed sensor, rear			
Ricam.no →0062418	09.00-12.01		0 265 007 018
Ricam.no 0062419→	09.00-12.01		0 265 007 048
2.5 24V [932] 2,5l 141 kW AR32405 6 Zyl.			
Throttle valve assembly	01.02-10.05		0 280 750 014
Air mass meter, gasoline injection	01.02-10.05		0 280 218 054
Phase sensor	01.02-10.05		0 232 103 024
Speed sensor, ignition/injection	01.02-10.05		0 261 210 203
Yaw rate sensor, brake system	01.02-10.05		0 265 005 241
Pressure sensor, ESP, (electronic stability program)	01.02-10.05		0 265 005 303
Wheel speed sensor, front	10.02-10.05	LAB,MFD	0 265 007 486
		MFD,RAB	0 265 007 487
Ricam.no →00526907	01.02-10.02	LAB	0 265 007 046
		RAB	0 265 007 047
Wheel speed sensor, rear	10.02-10.05	MFD	0 265 007 488
		OFD	0 265 007 113
Ricam.no →00526907	01.02-10.02		0 265 007 048
3.2 GTA [932] 3,2l 184 kW 932A000 6 Zyl.			
Throttle valve assembly	03.02-10.05		0 280 750 014
Air mass meter, gasoline injection	03.02-10.05		0 281 002 533
Phase sensor	03.02-10.05		0 232 103 024
Speed sensor, ignition/injection	03.02-10.05		0 261 210 203
Yaw rate sensor, brake system	03.02-10.05		0 265 005 241
Pressure sensor, ESP, (electronic stability program)	03.02-10.05		0 265 005 303
Wheel speed sensor, front	10.02-10.05	LAB,MFD	0 265 007 486
		MFD,RAB	0 265 007 487
Ricam.no →00526907	03.02-10.02	LAB	0 265 007 046
		RAB	0 265 007 047
Wheel speed sensor, rear	10.02-10.05	MFD	0 265 007 488
		OFD	0 265 007 113
Ricam.no →00526907	03.02-10.02		0 265 007 048

156 Sport Wagon Q4

1.9 JTD 16V 4x4 [932] 1,9l 110 kW 937A5000 4 Zyl.			
Throttle valve assembly	10.04→		0 280 750 102
Air mass meter, diesel	10.04-05.05	EU3	0 280 218 113
High-pressure sensor (CR system)	10.04-05.05		0 281 002 534
	06.05→		0 281 002 706
Boost pressure sensor, Diesel	10.04→		0 281 002 437
Yaw rate sensor, brake system	10.04→		0 265 005 241

Product



Pressure sensor, ESP, (electronic stability program)	10.04→	0 265 005 303
Wheel speed sensor, rear	10.04→	0 265 007 691

159 Berlina

1.8 i [939]	1,8 l 96 kW 939A4000 4 Zyl.
Wheel speed sensor, front	03.06→ 0 265 008 055
Wheel speed sensor, rear	03.06→ 0 265 008 056
1.9 JTDM 8V [939]	1,9 l 85/88 kW 937A7000; 939A1000 4 Zyl.
Speed sensor, diesel	06.05→ 0 281 002 603
Phase sensor	06.05→ 0 281 002 213
High-pressure sensor (CR system)	06.05→ 0 281 002 706
Boost pressure sensor, Diesel	06.05-02.07 0 281 002 437
	03.07→ 0 281 002 845
Wheel speed sensor, front	06.05→ 0 265 008 055
Wheel speed sensor, rear	06.05→ 0 265 008 056
1.9 JTDM 16V [939]	1,9 l 100/110 kW 937A8000; 939A2000 4 Zyl.
High-pressure sensor (CR system)	06.05→ 0 281 002 706
Boost pressure sensor, Diesel	06.05→ 0 281 002 845
Wheel speed sensor, front	06.05→ 0 265 008 055
Wheel speed sensor, rear	06.05→ 0 265 008 056
1.9 JTS [939]	1,9 l 118 kW 939A6000 4 Zyl.
Air mass meter, gasoline injection	06.05→ 0 280 218 164
Phase sensor	06.05→ 0 232 103 052
Wheel speed sensor, front	06.05→ 0 265 008 055
Wheel speed sensor, rear	06.05→ 0 265 008 056
2.2 JTS [939]	2,2 l 136 kW 939A5000 4 Zyl.
Air mass meter, gasoline injection	06.05→ 0 280 218 164
Phase sensor	06.05→ 0 232 103 052
Wheel speed sensor, front	06.05→ 0 265 008 055
Wheel speed sensor, rear	06.05→ 0 265 008 056
2.4 JTD 20V [939]	2,4 l 154 kW 939A9000 5 Zyl.
Air mass meter, diesel	02.07→ 0 281 002 764
High-pressure sensor (CR system)	02.07→ 0 281 002 706
Boost pressure sensor, Diesel	02.07-02.07 0 281 002 437
	03.07→ 0 281 002 845
Wheel speed sensor, front	02.07→ 0 265 008 055
Wheel speed sensor, rear	02.07→ 0 265 008 056
2.4 JTDM 20V [939]	2,4 l 147 kW 939A3000 5 Zyl.
Air mass meter, diesel	06.05→ 0 281 002 764
High-pressure sensor (CR system)	06.05→ 0 281 002 706
Boost pressure sensor, Diesel	06.05-02.07 0 281 002 437
	03.07→ 0 281 002 845
Wheel speed sensor, front	06.05→ 0 265 008 055
Wheel speed sensor, rear	06.05→ 0 265 008 056

159 Berlina Q4

2.4 JTD 20V [939]	2,4 l 154 kW 939A9000 5 Zyl.
Air mass meter, diesel	09.06→ 0 281 002 764
High-pressure sensor (CR system)	09.06→ 0 281 002 706
Boost pressure sensor, Diesel	09.06-02.07 0 281 002 437
	03.07→ 0 281 002 845
Wheel speed sensor, front	09.06→ 0 265 008 055
Wheel speed sensor, rear	09.06→ 0 265 008 056
3.2 JTS [939]	3,2 l 191 kW 939A000 6 Zyl.
Air mass meter, gasoline injection	01.06→ 0 280 218 182
Wheel speed sensor, front	01.06→ 0 265 008 055
Wheel speed sensor, rear	01.06→ 0 265 008 056

Product



159 Sport Wagon

1.8 i [939]	1,8 l 96 kW 939A4000 4 Zyl.
Wheel speed sensor, front	03.06→ 0 265 008 055
Wheel speed sensor, rear	03.06→ 0 265 008 056
1.9 JTDM 8V [939]	1,9 l 85/88 kW 937A7000; 939A1000 4 Zyl.
Speed sensor, diesel	03.06→ 0 281 002 603
Phase sensor	03.06→ 0 281 002 213
High-pressure sensor (CR system)	03.06→ 0 281 002 706
Boost pressure sensor, Diesel	03.06-02.07 0 281 002 437
	03.07→ 0 281 002 845
Wheel speed sensor, front	03.06→ 0 265 008 055
Wheel speed sensor, rear	03.06→ 0 265 008 056
1.9 JTDM 16V [939]	1,9 l 100/110 kW 937A8000; 939A2000 4 Zyl.
High-pressure sensor (CR system)	03.06→ 0 281 002 706
Boost pressure sensor, Diesel	03.06→ 0 281 002 845
Wheel speed sensor, front	03.06→ 0 265 008 055
Wheel speed sensor, rear	03.06→ 0 265 008 056
1.9 JTS [939]	1,9 l 118 kW 939A6000 4 Zyl.
Air mass meter, gasoline injection	03.06→ 0 280 218 164
Phase sensor	03.06→ 0 232 103 052
Wheel speed sensor, front	03.06→ 0 265 008 055
Wheel speed sensor, rear	03.06→ 0 265 008 056
2.2 JTS [939]	2,2 l 136 kW 939A5000 4 Zyl.
Air mass meter, gasoline injection	03.06→ 0 280 218 164
Phase sensor	03.06→ 0 232 103 052
Wheel speed sensor, front	03.06→ 0 265 008 055
Wheel speed sensor, rear	03.06→ 0 265 008 056
2.4 JTD 20V [939]	2,4 l 154 kW 939A9000 5 Zyl.
Air mass meter, diesel	02.07→ 0 281 002 764
High-pressure sensor (CR system)	02.07→ 0 281 002 706
Boost pressure sensor, Diesel	02.07-02.07 0 281 002 437
	03.07→ 0 281 002 845
Wheel speed sensor, front	02.07→ 0 265 008 055
Wheel speed sensor, rear	02.07→ 0 265 008 056
2.4 JTDM 20V [939]	2,4 l 147 kW 939A3000 5 Zyl.
Air mass meter, diesel	03.06→ 0 281 002 764
High-pressure sensor (CR system)	03.06→ 0 281 002 706
Boost pressure sensor, Diesel	03.06-02.07 0 281 002 437
	03.07→ 0 281 002 845
Wheel speed sensor, front	03.06→ 0 265 008 055
Wheel speed sensor, rear	03.06→ 0 265 008 056

159 Sport Wagon Q4

2.4 JTD 20V [939]	2,4 l 154 kW 939A9000 5 Zyl.
Air mass meter, diesel	09.06→ 0 281 002 764
High-pressure sensor (CR system)	09.06→ 0 281 002 706
Boost pressure sensor, Diesel	09.06-02.07 0 281 002 437
	03.07→ 0 281 002 845
Wheel speed sensor, front	09.06→ 0 265 008 055
Wheel speed sensor, rear	09.06→ 0 265 008 056
3.2 JTS [939]	3,2 l 191 kW 939A000 6 Zyl.
Air mass meter, gasoline injection	03.06→ 0 280 218 182
Wheel speed sensor, front	03.06→ 0 265 008 055
Wheel speed sensor, rear	03.06→ 0 265 008 056

164

2.0 T.S. [164]	2,0 l 106 kW AR 64103 4 Zyl.
Throttle valve sensor	09.92-10.98 0 280 122 001
Speed sensor, ignition/injection	09.92-10.98 0 261 210 036
Temperature sensor, coolant, injection system	09.92-10.98 0 280 130 026



◀ 164

Wheel speed sensor, front	09.92-10.98	LAB	0 265 006 118
		RAB	0 265 006 119
Wheel speed sensor, rear			
Fg.no. →6302794	09.92-10.98		0 265 003 075
2.0 Turbo i.e. [164]	2,0l	126 kW AR 06476	4 Zyl.
Throttle valve sensor	01.88-09.92		0 280 120 313
Air flow sensor, gasoline injection	01.88-09.92		0 280 202 060
			0 986 280 046
Temperature sensor, coolant, injection system	01.88-09.92		0 280 130 026
Relay, Jetronic	01.88-09.92		0 280 230 006
Wheel speed sensor, front	01.88-02.89		0 265 001 156
	03.89-09.92	LAB	0 265 001 251
		RAB	0 265 001 250
Wheel speed sensor, rear	01.88-09.92	LAB	0 265 001 074
		RAB	0 265 001 073
2.0 Twin Spark [164]	2,0l	102/107 kW AR 06416; AR 06420	4 Zyl.
Throttle valve sensor	06.87-09.92		0 280 120 315
Air flow sensor, gasoline injection	06.87-09.92		0 280 202 210
			0 986 280 063
Speed sensor, ignition/injection	06.87-09.92		0 261 210 036
Temperature sensor, coolant, injection system	06.87-09.92		0 280 130 026
Wheel speed sensor, front	06.87-02.89		0 265 001 156
	03.89-09.92	LAB	0 265 001 251
		RAB	0 265 001 250
Wheel speed sensor, rear	06.87-09.92	LAB	0 265 001 074
		RAB	0 265 001 073
2.0 V6 Turbo [164]	2,0l	148 kW AR 64102	6 Zyl.
Throttle valve sensor	09.92-10.98		0 280 120 435
Air flow sensor, gasoline injection	09.92-10.98		0 280 203 034
Speed sensor, ignition/injection	09.92-10.98		0 261 210 036
Knock sensor	09.92-10.98		0 261 231 007
Pressure sensor, intake manifold, gasoline	09.92-10.98	HL	0 280 101 001
Temperature sensor, coolant, injection system	09.92-10.98		0 280 130 032
Wheel speed sensor, front	09.92-09.92	LAB	0 265 001 251
		RAB	0 265 001 250
Wheel speed sensor, rear	09.92-10.98	LAB	0 265 001 074
		RAB	0 265 001 073
2.0 V6 Turbo i.e. [164]	2,0l	148 kW AR 64102	6 Zyl.
Throttle valve sensor	03.91-09.92		0 280 120 435
Air flow sensor, gasoline injection	03.91-09.92		0 280 203 034
Speed sensor, ignition/injection	03.91-09.92		0 261 210 036
Pulse generator, ignition/Jetronic	03.91-09.92		0 356 914 224
Knock sensor	03.91-09.92		0 261 231 007
Pressure sensor, intake manifold, gasoline	03.91-09.92	HL	0 280 101 001
Temperature sensor, coolant, injection system	03.91-09.92		0 280 130 032
Wheel speed sensor, front	03.91-09.92	LAB	0 265 001 251
		RAB	0 265 001 250
Wheel speed sensor, rear	03.91-09.92	LAB	0 265 001 074
		RAB	0 265 001 073
2.5 D Turbo [164]	2,5l	85 kW VM84A	4 Zyl.
Wheel speed sensor, front	06.87-02.89		0 265 001 156
	03.89-09.92	LAB	0 265 001 251
		RAB	0 265 001 250
Wheel speed sensor, rear	06.87-09.92	LAB	0 265 001 074
		RAB	0 265 001 073
2.5 D Turbo [164]	2,5l	92 kW VM08B / VM32B	4 Zyl.
Air flow sensor, diesel	09.92-10.98		0 281 002 085
Pulse generator, diesel	09.92-10.98		0 281 002 096
Temperature sensor, coolant, diesel	09.92-10.98		0 280 130 055
Pedal position sensor, diesel	09.92-10.98		0 205 001 009
Wheel speed sensor, front	09.92-10.98	LAB	0 265 006 118
		RAB	0 265 006 119



Wheel speed sensor, rear			
Fg.no. →6302794	09.92-10.98		0 265 003 075
3.0 i.e. [164]	3,0l	132/136-140 kW AR 06410; AR 06412; AR 64303	6 Zyl.
Throttle valve sensor	06.87-09.92		0 280 120 300
Air flow sensor, gasoline injection	06.87-09.92		0 280 202 201
Speed sensor, ignition/injection	06.87-09.92		0 261 210 036
Temperature sensor, coolant, injection system	06.87-09.92		0 280 130 026
Relay, Jetronic	06.87-09.92		0 332 014 113
Wheel speed sensor, front	06.87-02.89		0 265 001 156
	03.89-09.92	LAB	0 265 001 251
		RAB	0 265 001 250
Wheel speed sensor, rear	06.87-09.92	LAB	0 265 001 074
		RAB	0 265 001 073
3.0 i.e.Q.V. [164]	3,0l	147 kW AR 64301	6 Zyl.
Throttle valve sensor	09.90-09.92		0 280 120 300
Air flow sensor, gasoline injection	09.90-09.92		0 280 203 035
Speed sensor, ignition/injection	09.90-09.92		0 261 210 036
Temperature sensor, coolant, injection system	09.90-09.92		0 280 130 026
Wheel speed sensor, front	09.90-09.92	LAB	0 265 001 251
		RAB	0 265 001 250
Wheel speed sensor, rear	09.90-09.92	LAB	0 265 001 074
		RAB	0 265 001 073
3.0 Q4 4x4 [164]	3,0l	171 kW AR 64307 / 66304	6 Zyl.
Throttle valve sensor	12.93-10.98		0 280 122 001
Air mass meter, gasoline injection	12.93-10.98	OWE	0 280 217 503
Phase sensor	12.93-10.98		0 232 103 009
Speed sensor, ignition/injection	12.93-10.98		0 261 210 113
Knock sensor	12.93-10.98	L43	0 261 231 095
Temperature sensor, intake air, injection system	12.93-10.98		0 280 130 073
Temperature sensor, coolant, injection system	12.93-10.98		0 280 130 026
Wheel speed sensor, front	12.93-10.98	LAB	0 265 006 118
		RAB	0 265 006 119
Wheel speed sensor, rear	12.93-10.98		0 265 006 120
3.0 V6 12V [164]	3,0l	132 kW AR 64305; AR 64399	6 Zyl.
Throttle valve sensor	09.92-10.98		0 280 122 001
Speed sensor, ignition/injection	09.92-10.98		0 261 210 036
Knock sensor	09.92-10.98		0 261 231 007
Temperature sensor, coolant, injection system	09.92-10.98		0 280 130 026
Wheel speed sensor, front	09.92-10.98	LAB	0 265 006 118
		RAB	0 265 006 119
Wheel speed sensor, rear			
Fg.no. →6302794	09.92-10.98		0 265 003 075
3.0 V6 24V [164]	3,0l	155 kW AR 64306; AR 66301 / 66302	6 Zyl.
Throttle valve sensor	09.92-10.98		0 280 122 001
Air flow sensor, gasoline injection	09.92-10.98		0 280 203 026
			0 986 280 042
Phase sensor	09.92-10.98		0 261 210 090
Speed sensor, ignition/injection	09.92-10.98		0 261 210 047
Knock sensor	09.92-10.98		0 261 231 007
Temperature sensor, coolant, injection system	09.92-10.98		0 280 130 026
Wheel speed sensor, front	09.92-10.98	LAB	0 265 006 118
		RAB	0 265 006 119
Wheel speed sensor, rear			
Fg.no. →6299489	09.92-10.98		0 265 003 075
3.0 V6 24V Q.V. [164]	3,0l	169-171 kW AR 64304	6 Zyl.
Throttle valve sensor	09.92-10.98		0 280 122 001
Air flow sensor, gasoline injection	09.92-10.98		0 280 203 026
			0 986 280 042
Phase sensor	09.92-10.98		0 232 103 009
Speed sensor, ignition/injection	09.92-10.98		0 261 210 047
Knock sensor	09.92-10.98	L43	0 261 231 095
Wheel speed sensor, front	09.92-10.98	LAB	0 265 006 118
		RAB	0 265 006 119



Wheel speed sensor, rear		
Fg.no. →6302794	09.92-10.98	0 265 003 075
3.0 V6 24V Q.V. G.D. [164]	3,0l 170 kW AR 64308 6 Zyl.	
Throttle valve sensor	09.92-10.98	0 280 122 001
Air flow sensor, gasoline injection	09.92-10.98	0 280 203 026
		0 986 280 042
Phase sensor	09.92-10.98	0 232 103 009
Speed sensor, ignition/injection	09.92-10.98	0 261 210 047
Knock sensor	09.92-10.98 L43	0 261 231 095
Wheel speed sensor, front	09.92-10.98 LAB	0 265 006 118
	RAB	0 265 006 119
Wheel speed sensor, rear		
Fg.no. →6302794	09.92-10.98	0 265 003 075

166

2.0 T.S. 16V [936]	2,0l 114 kW AR 34103 4 Zyl.	
Throttle valve assembly	10.98-09.00	3 437 010 457
Air mass meter, gasoline injection	10.98-09.00	0 280 218 019
Phase sensor	10.98-09.00	0 232 101 035
Speed sensor, ignition/injection	10.98-09.00	0 261 210 160
Knock sensor	10.98-09.00	0 261 231 131
Vacuum pickup, ignition/injection	10.98-09.00	0 928 400 327
Pressure sensor, ESP, (electronic stability program)	10.98-09.00	0 265 005 303
Wheel speed sensor, front	10.98-09.00 LAB	0 265 007 021
	RAB	0 265 007 020
Wheel speed sensor, rear	10.98-09.00	0 265 007 022
2.0 T.S. 16V [936]	2,0l 114 kW AR 36301 4 Zyl.	
Throttle valve assembly		
Mot.no. →3649574	09.00-04.04	0 280 750 102
Mot.no. 3649575→	05.04→	1 287 213 612
Air mass meter, gasoline injection	09.00→	0 281 002 309
Phase sensor	09.00→	0 232 101 035
Speed sensor, ignition/injection		
Mot.no. →3649574	09.00→	0 261 210 160
Mot.no. 3649575→	09.00→	0 261 210 227
Knock sensor	09.00→	0 261 231 131
Vacuum pickup, ignition/injection	09.00→	0 928 400 327
Yaw rate sensor, brake system		
Fg.no. →94869	09.00-08.04	0 265 005 277
Fg.no. 94870→	09.04→	0 265 005 241
Pressure sensor, ESP, (electronic stability program)	09.00→	0 265 005 303
Wheel speed sensor, front	09.00→ LAB	0 265 007 021
	RAB	0 265 007 020
Wheel speed sensor, rear	09.00→	0 265 007 022
2.0 Turbo V6 [936]	2,0l 151 kW AR 34102 6 Zyl.	
Throttle valve assembly	10.98-12.04	0 280 750 053
Air mass meter, gasoline injection	10.98-05.03	0 280 218 036
	06.03-12.04	0 280 218 054
Phase sensor	10.98-12.04	0 232 103 024
Speed sensor, ignition/injection	10.98-12.04	0 261 210 167
Knock sensor	10.98-12.04 L37	0 261 231 007
	L43	0 261 231 095
Pressure sensor, intake manifold, gasoline	10.98-12.04 HL	0 280 101 001
Temperature sensor, coolant, injection system	10.98-12.04	0 280 130 039
Yaw rate sensor, brake system		
Fg.no. →94869	10.98-08.04	0 265 005 277
Fg.no. 94870→	09.04-12.04	0 265 005 241
Pressure sensor, ESP, (electronic stability program)	10.98-12.04	0 265 005 303
Wheel speed sensor, front	10.98-12.04 LAB	0 265 007 021
	RAB	0 265 007 020
Wheel speed sensor, rear	10.98-12.04	0 265 007 022



2.4 JTD [936]	2,4l 100 kW AR 34202 5 Zyl.	
Air mass meter, diesel	10.98-09.00	0 280 218 019
Speed sensor, diesel	10.98-09.00	0 281 002 474
Phase sensor	10.98-09.00	0 281 002 213
High-pressure sensor (CR system)	10.98-09.00	0 281 002 210
Boost pressure sensor, Diesel	10.98-09.00	0 281 002 215
Temperature sensor, fuel	10.98-09.00 2PO	0 281 002 209
Pedal position sensor, diesel	10.98-09.00	0 281 002 202
Pressure sensor, ESP, (electronic stability program)	10.98-09.00	0 265 005 303
Wheel speed sensor, front	10.98-09.00 LAB	0 265 007 021
	RAB	0 265 007 020
Wheel speed sensor, rear	10.98-09.00	0 265 007 022
2.4 JTD [936]	2,4l 100-110 kW 839A6000 / 841C000 5 Zyl.	
Air mass meter, diesel	09.00→	0 281 002 309
Speed sensor, diesel		
Mot.no. →4036104	09.00→	0 281 002 474
Mot.no. 4036105→	09.00→	0 281 002 603
Phase sensor	09.00→	0 281 002 213
High-pressure sensor (CR system)	09.00→	0 281 002 210
Boost pressure sensor, Diesel	09.00→	0 281 002 844
Temperature sensor, fuel	09.00→ 2PO	0 281 002 209
Pedal position sensor, diesel	09.00→	0 281 002 202
Yaw rate sensor, brake system		
Fg.no. →94869	09.00-08.04	0 265 005 277
Fg.no. 94870→	09.04→	0 265 005 241
Pressure sensor, ESP, (electronic stability program)	09.00→	0 265 005 303
Wheel speed sensor, front	09.00→ LAB	0 265 007 021
	RAB	0 265 007 020
Wheel speed sensor, rear	09.00→	0 265 007 022
2.4 JTD 20V [936]	2,4l 120/128 kW 841M000; 841N000 5 Zyl.	
Throttle valve assembly	10.04→	0 280 750 102
Air mass meter, diesel	10.04→	0 281 002 598
Boost pressure sensor, Diesel	10.04→	0 281 002 845
Yaw rate sensor, brake system		
Fg.no. 94870→	10.04→	0 265 005 241
Pressure sensor, ESP, (electronic stability program)	10.04→	0 265 005 303
Wheel speed sensor, front	10.04→ LAB	0 265 007 021
	RAB	0 265 007 020
Wheel speed sensor, rear	10.04→	0 265 007 022
2.4 JTD 20V [936]	2,4l 129 kW 841G000 / 841H000 5 Zyl.	
Throttle valve assembly	06.03→	0 280 750 102
Air mass meter, diesel	06.03→	0 281 002 598
Boost pressure sensor, Diesel	06.03→	0 281 002 845
Yaw rate sensor, brake system		
Fg.no. →94869	06.03-08.04	0 265 005 277
Fg.no. 94870→	09.04→	0 265 005 241
Pressure sensor, ESP, (electronic stability program)	06.03→	0 265 005 303
Wheel speed sensor, front	06.03→ LAB	0 265 007 021
	RAB	0 265 007 020
Wheel speed sensor, rear	06.03→	0 265 007 022
2.4 JTDM 20V [936]	2,4l 132-136 kW 936B000 5 Zyl.	
Throttle valve assembly	10.05→	0 280 750 102
Air mass meter, diesel	10.05→	0 281 002 763
Boost pressure sensor, Diesel	10.05→	0 281 002 845
Yaw rate sensor, brake system		
Fg.no. 94870→	10.05→	0 265 005 241
Pressure sensor, ESP, (electronic stability program)	10.05→	0 265 005 303
Wheel speed sensor, front	10.05→ LAB	0 265 007 021
	RAB	0 265 007 020
Wheel speed sensor, rear	10.05→	0 265 007 022
2.5 V6 24V [936]	2,5l 140 kW AR 34201 6 Zyl.	
Throttle valve assembly	10.98-09.00	0 280 750 014
Air mass meter, gasoline injection	10.98-09.00	0 280 217 531

Product



◀ 166

Phase sensor	10.98-09.00		0 232 103 009
Speed sensor, ignition/injection	10.98-09.00		0 261 210 163
Knock sensor	10.98-09.00	L37	0 261 231 007
		L43	0 261 231 095
Pressure sensor, ESP, (electronic stability program)	10.98-09.00		0 265 005 303
Wheel speed sensor, front	10.98-09.00	LAB	0 265 007 021
		RAB	0 265 007 020
Wheel speed sensor, rear	10.98-09.00		0 265 007 022
2.5 V6 24V [936]	2,5 l	140 kW	AR 36201 6 Zyl.
Throttle valve assembly	09.00→		0 280 750 014
Air mass meter, gasoline injection	09.00→		0 280 218 054
Phase sensor	09.00→		0 232 103 024
Speed sensor, ignition/injection	09.00→		0 261 210 203
Knock sensor	09.00→	L37	0 261 231 007
		L43	0 261 231 095
Yaw rate sensor, brake system			
Fg.no. →94869	09.00-08.04		0 265 005 277
Fg.no. 94870→	09.04→		0 265 005 241
Pressure sensor, ESP, (electronic stability program)	09.00→		0 265 005 303
Wheel speed sensor, front	09.00→	LAB	0 265 007 021
		RAB	0 265 007 020
Wheel speed sensor, rear	09.00→		0 265 007 022
3.0 V6 24V [936]	3,0 l	166 kW	AR 34301; AR 34302 6 Zyl.
Throttle valve assembly	10.98-09.00		0 280 750 014
Air mass meter, gasoline injection	10.98-09.00		0 280 217 531
Phase sensor	10.98-09.00		0 232 103 009
Speed sensor, ignition/injection	10.98-09.00		0 261 210 163
Knock sensor	10.98-09.00	L37	0 261 231 007
		L43	0 261 231 095
Pressure sensor, ESP, (electronic stability program)	10.98-09.00		0 265 005 303
Wheel speed sensor, front	10.98-09.00	LAB	0 265 007 021
		RAB	0 265 007 020
Wheel speed sensor, rear	10.98-09.00		0 265 007 022
3.0 V6 24V [936]	3,0 l	166 kW	AR 36101 6 Zyl.
Throttle valve assembly	09.00→		0 280 750 014
Air mass meter, gasoline injection	09.00→		0 280 218 054
Phase sensor	09.00→		0 232 103 024
Speed sensor, ignition/injection	09.00→		0 261 210 203
Knock sensor	09.00→	L37	0 261 231 007
		L43	0 261 231 095
Yaw rate sensor, brake system			
Fg.no. →94869	09.00-08.04		0 265 005 277
Fg.no. 94870→	09.04→		0 265 005 241
Pressure sensor, ESP, (electronic stability program)	09.00→		0 265 005 303
Wheel speed sensor, front	09.00→	LAB	0 265 007 021
		RAB	0 265 007 020
Wheel speed sensor, rear	09.00→		0 265 007 022
3.2 V6 24V [936]	3,2 l	166 kW	936A000 6 Zyl.
Throttle valve assembly	06.03→		0 280 750 014
Air mass meter, gasoline injection	06.03→		0 280 218 054
Phase sensor	06.03→		0 232 103 024
Speed sensor, ignition/injection	06.03→		0 261 210 203
Yaw rate sensor, brake system			
Fg.no. →94869	06.03-08.04		0 265 005 277
Fg.no. 94870→	09.04→		0 265 005 241
Pressure sensor, ESP, (electronic stability program)	06.03→		0 265 005 303
Wheel speed sensor, front	06.03→	LAB	0 265 007 021
		RAB	0 265 007 020
Wheel speed sensor, rear	06.03→		0 265 007 022



A



Product				
ALPINA (B. BOVENSIEPEN KG)				
B 7				
4.4 [E 65/66]	4,4l 368 kW N62 B44A19 8 Zyl.			
Knock sensor	03.04→	0 261 231 200		
Duo sensor, acceleration and yaw rate, brake system	03.04→	0 265 005 285		
Pressure sensor, ESP, (electronic stability program)	03.04→	0 265 005 303		
Wheel speed sensor, front	03.04-09.05	0 265 007 592		
Wheel speed sensor, rear	03.04-09.05	0 265 007 593		
	10.05→	0 265 007 845		
Roadster				
V8 [Z8]	4,8l 280 kW F 5/1 8 Zyl.			
Air mass meter, gasoline injection	06.02-10.03	0 280 217 814		
Knock sensor	06.02-10.03	0 261 231 200		
Yaw rate sensor, brake system	06.02-10.03	0 265 005 248		
Pressure sensor, ESP, (electronic stability program)	06.02-10.03	0 265 005 303		
ASTON MARTIN				
Vantage				
5.3 Zagato	5,3l 318 kW V8 8 Zyl.			
Wheel speed sensor, front	01.86-12.89	0 265 006 216		
5.3 32V Kompressor	5,3l 410 kW V8 8 Zyl.			
Wheel speed sensor, front	10.92-12.99	0 265 006 216		
Virage Coupé				
5.3 V8/32V	5,3l 246 kW 8 Zyl.			
Wheel speed sensor, front	10.88-12.95	LAB	0 265 001 323	
Wheel speed sensor, rear	10.88-12.95	0 265 001 324		
AUDI				
A2				
1.2 TDI 3L [8Z0]	1,2l 45 kW ANY 3 Zyl.			
Boost pressure sensor, Diesel				
Fg.no. →8Z...2..027 000	09.99-01.02	0 281 002 177		
Fg.no. 8Z...2..027 001→	02.02-08.05	0 281 002 399		
1.4 [8Z0]	1,4l 55 kW AUA; BBY 4 Zyl.			
Knock sensor	09.99-08.05	0 261 231 146		
1.4 TDI [8Z0]	1,4l 55 kW AMF 3 Zyl.			
Boost pressure sensor, Diesel				
Fg.no. →8Z...2..027 000	09.99-01.02	0 281 002 177		
Fg.no. 8Z...2..027 001→	02.02-08.03	0 281 002 399		
1.4 TDI [8Z0]	1,4l 55 kW BHC 3 Zyl.			
Air mass meter, diesel	05.03-08.05	0 281 002 610		
Boost pressure sensor, Diesel	05.03-08.05	0 281 002 399		
1.4 TDI [8Z0]	1,4l 66 kW ATL 3 Zyl.			
Air mass meter, diesel	11.03-08.05	0 281 002 610		
Boost pressure sensor, Diesel	11.03-08.05	0 281 002 401		
1.6 FSI [8Z0]	1,6l 81 kW BAD 4 Zyl.			
Throttle valve assembly	01.02-08.05	0 280 750 059		
Knock sensor	01.02-08.05	0 261 231 146		
Pressure sensor, intake manifold, gasoline	01.02-08.05	0 261 230 079		

Product



A3

1.4 TFSI [8P1]	1,4l 92 kW CAXC 4 Zyl.
Knock sensor	09.07→ 0 261 231 146
Boost pressure sensor, gasoline	09.07→ 0 281 002 399
1.6	1,6l 74 kW AKL 4 Zyl.
Phase sensor	05.99-09.06 NOC 0 232 101 031
Speed sensor, ignition/injection	05.99-09.06 FKW 0 261 210 147
1.6	1,6l 74 kW BAH 4 Zyl.
Speed sensor, ignition/injection	09.00-09.06 FKW 0 261 210 147
Knock sensor	09.00-09.06 OHL 0 261 231 146
1.6 [8L1]	1,6l 74 kW AEH 4 Zyl.
Phase sensor	09.96-06.01 NOC 0 232 101 031
Speed sensor, ignition/injection	09.96-06.01 FKW 0 261 210 147
Temperature sensor, intake air, injection system	09.96-06.01 0 280 130 085
Accelerator pedal module	
Fg.no. 8L..X..001 072→	08.98-06.01 GS,LLE 0 280 752 214
Fg.no. 8L..Y..000 001→	05.99-06.01 AG,RLE 0 280 752 213
	GS,RLE 0 280 752 210
Pedal position sensor, EMS (electronic engine management)	
Fg.no. →8L..X..090 000	09.96-04.99 GS,RLE 0 280 752 016
Fg.no. 8L..V..155 001→8L..X..001 071	07.97-08.98 GS,LLE 0 281 002 269
1.6 [8L1]	1,6l 74 kW AKL 4 Zyl.
Phase sensor	08.97-06.01 NOC 0 232 101 031
Speed sensor, ignition/injection	08.97-06.01 FKW 0 261 210 147
Temperature sensor, intake air, injection system	08.97-06.01 0 280 130 085
Accelerator pedal module	
Fg.no. 8L..X..001 072→	08.98-06.01 GS,LLE 0 280 752 214
Fg.no. 8L..Y..000 001→	05.99-06.01 AG,RLE 0 280 752 213
	GS,RLE 0 280 752 210
Pedal position sensor, EMS (electronic engine management)	
Fg.no. →8L..X..001 071	08.97-08.98 GS,LLE 0 281 002 269
Fg.no. →8L..X..090 000	08.97-04.99 GS,RLE 0 280 752 016
1.6 [8L1]	1,6l 74 kW APF 4 Zyl.
Phase sensor	08.98-08.00 NOC 0 232 101 031
Speed sensor, ignition/injection	08.98-08.00 FKW 0 261 210 199
Accelerator pedal module	08.98-08.00 GS,LLE 0 280 752 214
Fg.no. 8L..Y..000 001→	05.99-08.00 AG,RLE 0 280 752 213
	GS,RLE 0 280 752 210
Pedal position sensor, EMS (electronic engine management)	
Fg.no. →8L..X..090 000	08.98-04.99 GS,RLE 0 280 752 016
1.6 [8L1]	1,6l 75 kW AVU 4 Zyl.
Phase sensor	05.00-04.02 NOC 0 232 101 038
Speed sensor, ignition/injection	05.00-04.02 FKW 0 261 210 199
Accelerator pedal module	05.00-04.02 AG,RLE 0 280 752 213
	GS,LLE 0 280 752 214
	GS,RLE 0 280 752 210
1.6 [8L1]	1,6l 75 kW BFQ 4 Zyl.
Speed sensor, ignition/injection	05.02-06.03 0 261 210 199
Accelerator pedal module	05.02-06.03 AG,RLE 0 280 752 213
	GS,LLE 0 280 752 214
	GS,RLE 0 280 752 210
1.6 [8P1]	1,6l 75 kW BGU; BSE; BSF 4 Zyl.
Speed sensor, ignition/injection	05.03→ 0 261 210 199
Knock sensor	05.03→ 0 261 231 146
Pressure sensor, intake manifold, gasoline	05.03→ 0 261 230 031
1.6 FSI [8P1]	1,6l 85 kW BAG 4 Zyl.
Speed sensor, ignition/injection	
Fg.no. 8P..4..103 001→	11.03-05.04 0 261 210 250

Product



Knock sensor	08.03-05.04		0 261 231 146
Pressure sensor, intake manifold, gasoline	08.03-05.04		0 261 230 095
1.6 FSI [8P1]		1,6 l 85 kW BLF; BLP 4 Zyl.	
Knock sensor	06.04-09.07		0 261 231 146
Pressure sensor, intake manifold, gasoline	06.04-09.07		0 261 230 095
1.8		1,8 l 92 kW AGN 4 Zyl.	
Air mass meter, gasoline injection	05.99-09.06		0 280 218 002
		0 986 280 205	
Phase sensor	05.99-09.06	NOC	0 232 101 024
Speed sensor, ignition/injection	05.99-09.06	FKW	0 261 210 147
Temperature sensor, intake air, injection system	05.99-09.06		0 280 130 085
1.8 [8L1]		1,8 l 92 kW AGN 4 Zyl.	
Air mass meter, gasoline injection			
Fg.no. 8L..W..000 001→	08.97-06.01		0 280 218 002
		0 986 280 205	
Phase sensor	09.96-06.01	NOC	0 232 101 024
Speed sensor, ignition/injection	09.96-06.01	FKW	0 261 210 147
Temperature sensor, intake air, injection system	09.96-06.01		0 280 130 085
Accelerator pedal module			
Fg.no. 8L..X..001 072→	08.98-06.01	GS,LLE	0 280 752 214
Fg.no. 8L..Y..000 001→	05.99-06.01	AG,RLE	0 280 752 213
		GS,RLE	0 280 752 210
Pedal position sensor, EMS (electronic engine management)			
Fg.no. →8L..X..090 000	09.96-04.99	GS,RLE	0 280 752 016
Fg.no. 8L..V..155 001→8L..X..001 071	07.97-08.98	GS,LLE	0 281 002 269
1.8 [8L1]		1,8 l 92 kW APG 4 Zyl.	
Throttle valve assembly	08.98-04.03		0 280 750 026
Air mass meter, gasoline injection	08.98-04.03		0 280 218 060
		0 986 280 216	
Phase sensor	08.98-04.03	NOC	0 232 101 024
Speed sensor, ignition/injection	08.98-04.03	FKW	0 261 210 147
Accelerator pedal module	08.98-04.03	GS,LLE	0 280 752 214
Fg.no. 8L..Y..000 001→	05.99-04.03	AG,RLE	0 280 752 213
		GS,RLE	0 280 752 210
Pedal position sensor, EMS (electronic engine management)			
Fg.no. →8L..X..090 000	08.98-04.99	GS,RLE	0 280 752 016
1.8 FSI [8P1]		1,8 l 118 kW BYT 4 Zyl.	
Boost pressure sensor, gasoline	11.06-06.07		0 261 230 073
1.8 quattro [8L1]		1,8 l 92 kW AGN 4 Zyl.	
Air mass meter, gasoline injection	08.98-06.99		0 280 218 002
		0 986 280 205	
Phase sensor	08.98-06.99	NOC	0 232 101 024
Speed sensor, ignition/injection	08.98-06.99	FKW	0 261 210 147
Temperature sensor, intake air, injection system	08.98-06.99		0 280 130 085
Accelerator pedal module	08.98-06.99	GS,LLE	0 280 752 214
Fg.no. 8L..Y..000 001→	05.99-06.99	AG,RLE	0 280 752 213
		GS,RLE	0 280 752 210
Pedal position sensor, EMS (electronic engine management)			
Fg.no. →8L..X..090 000	08.98-04.99	GS,RLE	0 280 752 016
1.8 T		1,8 l 110 kW AGU 4 Zyl.	
Air mass meter, gasoline injection	05.99-09.06		0 280 217 117
		0 986 280 201	
Phase sensor	05.99-09.06	NOC	0 232 101 024
Speed sensor, ignition/injection	05.99-09.06	FKW	0 261 210 147
Temperature sensor, intake air, injection system	05.99-09.06		0 280 130 085
1.8 T		1,8 l 132 kW APP 4 Zyl.	
Throttle valve assembly	03.00-09.06		0 280 750 036
Air mass meter, gasoline injection	03.00-09.06		0 280 218 032
		0 986 280 210	
Speed sensor, ignition/injection	03.00-09.06	FKW	0 261 210 147




A

Product				
◀ A3				
1.8 T	1,8l 132 kW AUQ 4 Zyl.			
Throttle valve assembly	10.00-09.06			0 280 750 036
Phase sensor	10.00-09.06	NOC		0 232 101 024
Knock sensor	10.00-09.06	OHL		0 261 231 146
1.8 T [8L1]	1,8l 110 kW AGU 4 Zyl.			
Air mass meter, gasoline injection				
Fg.no. →8L..V..200 000	12.96-07.97			0 280 217 112
Fg.no. 8L..W..000 001→	08.97-06.03			0 280 217 117
				0 986 280 201
Phase sensor	12.96-06.03	NOC		0 232 101 024
Speed sensor, ignition/injection	12.96-06.03	FKW		0 261 210 199
Boost pressure sensor, gasoline	12.96-06.03			0 281 002 177
Temperature sensor, intake air, injection system	12.96-06.03			0 280 130 085
Accelerator pedal module				
Fg.no. 8L..X..001 072→	08.98-06.03	GS,LLE		0 280 752 214
Fg.no. 8L..Y..000 001→	05.99-06.03	AG,RLE		0 280 752 213
		GS,RLE		0 280 752 210
Pedal position sensor, EMS (electronic engine management)				
Fg.no. →8L..X..090 000	12.96-04.99	GS,RLE		0 280 752 016
Fg.no. 8L..V..155 001→8L..X..001 071	07.97-08.98	GS,LLE		0 281 002 269
1.8 T [8L1]	1,8l 110 kW AQA 4 Zyl.			
Throttle valve assembly	08.98-06.99			0 280 750 036
Air mass meter, gasoline injection	08.98-06.99			0 280 218 023
				0 986 280 209
Temperature sensor, intake air, injection system	08.98-06.99			0 280 130 085
Accelerator pedal module	08.98-06.99	GS,LLE		0 280 752 214
Fg.no. 8L..Y..000 001→	05.99-06.99	AG,RLE		0 280 752 213
		GS,RLE		0 280 752 210
Pedal position sensor, EMS (electronic engine management)				
Fg.no. →8L..X..090 000	08.98-04.99	GS,RLE		0 280 752 016
1.8 T [8L1]	1,8l 110 kW ARZ 4 Zyl.			
Throttle valve assembly	07.99-04.00			0 280 750 036
Air mass meter, gasoline injection				
Fg.no. →8L..Y..050 000	07.99-10.99			0 280 218 023
				0 986 280 209
Fg.no. 8L..Y..050 001→	10.99-04.00			0 280 218 032
				0 986 280 210
Phase sensor	07.99-04.00	NOC		0 232 101 024
Speed sensor, ignition/injection	07.99-04.00	FKW		0 261 210 147
Temperature sensor, intake air, injection system	07.99-04.00			0 280 130 085
Accelerator pedal module	07.99-04.00	GS,LLE		0 280 752 214
		GS,RLE		0 280 752 210
1.8 T [8L1]	1,8l 110 kW AUM 4 Zyl.			
Throttle valve assembly	05.00-06.03			0 280 750 036
Air mass meter, gasoline injection	05.00-08.00			0 280 218 032
				0 986 280 210
	09.00-06.03			0 280 218 063
				0 986 280 217
Phase sensor	05.00-06.03	NOC		0 232 101 024
Speed sensor, ignition/injection	05.00-06.03	FKW		0 261 210 147
Knock sensor	05.00-06.03			0 261 231 146
Boost pressure sensor, gasoline	05.00-06.03			0 281 002 177
Temperature sensor, intake air, injection system	05.00-06.03			0 280 130 085
Accelerator pedal module	05.00-06.03	AG,RLE		0 280 752 213
		GS,LLE		0 280 752 214
		GS,RLE		0 280 752 210
1.8 T [8L1]	1,8l 132 kW AJQ 4 Zyl.			
Throttle valve assembly	08.98-08.00			0 280 750 036
Air mass meter, gasoline injection				
Fg.no. →8L..Y..050 000	08.98-10.99			0 280 218 023
				0 986 280 209



Product				
Air mass meter, gasoline injection				
Fg.no. 8L..Y..050 001→	10.99-08.00			0 280 218 032
				0 986 280 210
Speed sensor, ignition/injection	08.98-08.00	FKW		0 261 210 147
Temperature sensor, intake air, injection system	08.98-08.00			0 280 130 085
Accelerator pedal module	08.98-08.00	GS,LLE		0 280 752 214
Fg.no. 8L..Y..000 001→	05.99-08.00	AG,RLE		0 280 752 213
		GS,RLE		0 280 752 210
Pedal position sensor, EMS (electronic engine management)				
Fg.no. →8L..X..090 000	08.98-04.99	GS,RLE		0 280 752 016
1.8 T [8L1]	1,8l 132 kW APP 4 Zyl.			
Throttle valve assembly	08.98-05.00			0 280 750 036
Air mass meter, gasoline injection				
Fg.no. →8L..Y..050 000	08.98-10.99			0 280 218 023
				0 986 280 209
Fg.no. 8L..Y..050 001→	10.99-05.00			0 280 218 032
				0 986 280 210
Speed sensor, ignition/injection	08.98-05.00	FKW		0 261 210 147
Temperature sensor, intake air, injection system	08.98-05.00			0 280 130 085
Accelerator pedal module	08.98-05.00	GS,LLE		0 280 752 214
Fg.no. 8L..Y..000 001→	05.99-05.00	AG,RLE		0 280 752 213
		GS,RLE		0 280 752 210
1.8 T [8L1]	1,8l 132 kW ARY 4 Zyl.			
Throttle valve assembly	09.00-06.01			0 280 750 036
Air mass meter, gasoline injection	09.00-06.01			0 280 218 063
				0 986 280 217
Phase sensor	09.00-06.01	NOC		0 232 101 024
Speed sensor, ignition/injection	09.00-06.01	FKW		0 261 210 147
Knock sensor	09.00-06.01			0 261 231 146
Boost pressure sensor, gasoline	09.00-06.01			0 281 002 177
Temperature sensor, intake air, injection system	09.00-06.01			0 280 130 085
Accelerator pedal module	09.00-06.01	AG,RLE		0 280 752 213
		GS,LLE		0 280 752 214
		GS,RLE		0 280 752 210
1.8 T [8L1]	1,8l 132 kW AUQ 4 Zyl.			
Throttle valve assembly	05.00-06.03			0 280 750 036
Air mass meter, gasoline injection	05.00-08.00			0 280 218 032
				0 986 280 210
	09.00-06.03			0 280 218 063
				0 986 280 217
Phase sensor	05.00-06.03	NOC		0 232 101 024
Speed sensor, ignition/injection	05.00-06.03	FKW		0 261 210 199
Knock sensor	05.00-06.03			0 261 231 146
Boost pressure sensor, gasoline	05.00-06.03			0 281 002 177
Temperature sensor, intake air, injection system	05.00-06.03			0 280 130 085
Accelerator pedal module	05.00-06.03	AG,RLE		0 280 752 213
		GS,LLE		0 280 752 214
		GS,RLE		0 280 752 210
1.8 T quattro [8L1]	1,8l 110 kW AGU 4 Zyl.			
Air mass meter, gasoline injection	08.97-08.00			0 280 217 117
				0 986 280 201
Phase sensor	08.97-08.00	NOC		0 232 101 024
Speed sensor, ignition/injection	08.97-08.00	NOC		0 261 210 199
Boost pressure sensor, gasoline	08.97-08.00			0 281 002 177
Temperature sensor, intake air, injection system	08.97-08.00			0 280 130 085
Accelerator pedal module				
Fg.no. 8L..X..001 072→	08.98-08.00	GS,LLE		0 280 752 214
Fg.no. 8L..Y..000 001→	05.99-08.00	AG,RLE		0 280 752 213
		GS,RLE		0 280 752 210



Pedal position sensor, EMS (electronic engine management)			
Fg.no. →8L..X..001 071	08.97-08.98	GS,LLE	0 281 002 269
Fg.no. →8L..X..090 000	08.97-04.99	GS,RLE	0 280 752 016
1.8 T quattro [8L1]		1,8l 110 kW AQA 4 Zyl.	
Throttle valve assembly	08.98-04.01		0 280 750 036
Air mass meter, gasoline injection			
Fg.no. →8L..Y..050 000	08.98-10.99		0 280 218 023
			0 986 280 209
Fg.no. 8L..Y..050 001→	10.99-04.01		0 280 218 032
			0 986 280 210
Speed sensor, ignition/injection	08.98-04.01	FKW	0 261 210 147
Temperature sensor, intake air, injection system	08.98-04.01		0 280 130 085
Accelerator pedal module	08.98-04.01	GS,LLE	0 280 752 214
Fg.no. 8L..Y..000 001→	05.99-04.01	AG,RLE	0 280 752 213
		GS,RLE	0 280 752 210
Pedal position sensor, EMS (electronic engine management)			
Fg.no. →8L..X..090 000	08.98-04.99	GS,RLE	0 280 752 016
1.8 T quattro [8L1]		1,8l 110 kW ARX 4 Zyl.	
Throttle valve assembly	10.99-06.03		0 280 750 036
Air mass meter, gasoline injection	10.99-06.03		0 280 218 063
			0 986 280 217
Speed sensor, ignition/injection	10.99-06.03	FKW	0 261 210 147
Knock sensor	10.99-06.03		0 261 231 146
Boost pressure sensor, gasoline	10.99-06.03		0 281 002 177
Temperature sensor, intake air, injection system	10.99-06.03		0 280 130 085
Accelerator pedal module	10.99-06.03	AG,RLE	0 280 752 213
		GS,LLE	0 280 752 214
		GS,RLE	0 280 752 210
1.8 T quattro [8L1]		1,8l 132 kW AJQ 4 Zyl.	
Throttle valve assembly	08.98-08.00		0 280 750 036
Air mass meter, gasoline injection			
Fg.no. →8L..Y..050 000	08.98-10.99		0 280 218 023
			0 986 280 209
Fg.no. 8L..Y..050 001→	10.99-08.00		0 280 218 032
			0 986 280 210
Speed sensor, ignition/injection	08.98-08.00	FKW	0 261 210 147
Temperature sensor, intake air, injection system	08.98-08.00		0 280 130 085
Accelerator pedal module	08.98-08.00	GS,LLE	0 280 752 214
Fg.no. 8L..Y..000 001→	05.99-08.00	AG,RLE	0 280 752 213
		GS,RLE	0 280 752 210
Pedal position sensor, EMS (electronic engine management)			
Fg.no. →8L..X..090 000	08.98-04.99	GS,RLE	0 280 752 016
1.8 T quattro [8L1]		1,8l 132 kW ARY 4 Zyl.	
Throttle valve assembly	09.00-06.03		0 280 750 036
Air mass meter, gasoline injection	09.00-06.03		0 280 218 063
			0 986 280 217
Phase sensor	09.00-06.03	NOC	0 232 101 024
Speed sensor, ignition/injection	09.00-06.03	FKW	0 261 210 147
Knock sensor	09.00-06.03		0 261 231 146
Boost pressure sensor, gasoline	09.00-06.03		0 281 002 177
Temperature sensor, intake air, injection system	09.00-06.03		0 280 130 085
Accelerator pedal module	09.00-06.03	AG,RLE	0 280 752 213
		GS,LLE	0 280 752 214
		GS,RLE	0 280 752 210
1.8 TFSI [8P1]		1,8l 118 kW BZB 4 Zyl.	
Boost pressure sensor, gasoline	06.07-05.08		0 261 230 073



1.9 TDI [8L1]				1,9l 66 kW AGR 4 Zyl.
Air mass meter, diesel				
Fg.no. 8L..X..000 001→	08.98-08.00			0 281 002 757
		WW		0 280 217 121
				0 986 280 202
Boost pressure sensor, Diesel	09.96-08.00			0 281 002 177
Accelerator pedal module				
Fg.no. 8L..Y..000 001→	05.99-08.00	AG,RLE		0 281 002 347
	04.99-08.00	GS,RLE		0 281 002 345
Pedal position sensor, diesel				
Fg.no. →8L..V..150 000	09.96-07.97	AG,LLE		0 205 001 045
Fg.no. 8L..V..155 001→8L..X..001 071	07.97-08.98	GS,LLE		0 281 002 269
1.9 TDI [8L1]				1,9l 66 kW ALH 4 Zyl.
Air mass meter, diesel				
Fg.no. 8L..Y..000 001→	08.97-06.01			0 281 002 757
		WW		0 280 217 121
				0 986 280 202
Boost pressure sensor, Diesel	08.97-06.01			0 281 002 177
Accelerator pedal module				
Fg.no. 8L..Y..000 001→	04.99-08.00	GS,RLE		0 281 002 345
Fg.no. 8L..Y..000 001→8L..1..080 600	05.99-02.01	AG,RLE		0 281 002 347
Pedal position sensor, diesel				
Fg.no. →8L..X..001 071	08.97-08.98	GS,LLE		0 281 002 269
1.9 TDI [8L1]				1,9l 74 kW ATD 4 Zyl.
Air mass meter, diesel				
Fg.no. →8L..2..040 000	09.00-10.01			0 281 002 757
		WW		0 280 217 121
				0 986 280 202
Fg.no. 8L..2..040 001→	10.01-06.03			0 281 002 531
				0 986 284 009
Boost pressure sensor, Diesel	09.00-06.03			0 281 002 177
Accelerator pedal module				
Fg.no. →8L..1..080 600	09.00-02.01	AG,RLE		0 281 002 347
1.9 TDI [8L1]				1,9l 74 kW AXR 4 Zyl.
Air mass meter, diesel				
Fg.no. 8L..Y..000 001→	11.01-06.03			0 281 002 531
				0 986 284 009
Boost pressure sensor, Diesel	11.01-06.03			0 281 002 399
1.9 TDI [8L1]				1,9l 81 kW AHF 4 Zyl.
Air mass meter, diesel				
Fg.no. 8L..X..000 001→	08.98-08.00			0 281 002 757
		WW		0 280 217 121
				0 986 280 202
Boost pressure sensor, Diesel	01.97-08.00			0 281 002 177
Accelerator pedal module				
Fg.no. 8L..Y..000 001→	05.99-08.00	AG,RLE		0 281 002 347
	04.99-08.00	GS,RLE		0 281 002 345
Pedal position sensor, diesel				
Fg.no. →8L..V..150 000	01.97-07.97	AG,LLE		0 205 001 045
Fg.no. 8L..V..155 001→8L..X..001 071	07.97-08.98	GS,LLE		0 281 002 269
1.9 TDI [8L1]				1,9l 81 kW ASV 4 Zyl.
Air mass meter, diesel				
Fg.no. 8L..Y..000 001→	09.99-06.01			0 281 002 757
		WW		0 280 217 121
				0 986 280 202
Boost pressure sensor, Diesel	09.99-06.01			0 281 002 177
Accelerator pedal module				
Fg.no. →8L..1..080 600	09.99-02.01	AG,RLE		0 281 002 347
1.9 TDI [8L1]				1,9l 96 kW ASZ 4 Zyl.
Air mass meter, diesel				
Fg.no. →8L..2..105 000	05.00-04.02			0 280 217 529
				0 986 280 204
Fg.no. 8L..2..105 001→	04.02-06.03			0 281 002 461
				0 986 284 007

Product				
◀ A3				
Boost pressure sensor, Diesel	05.00-06.03			0 281 002 401
Accelerator pedal module	05.00-08.00	GS,RLE		0 281 002 345
Fg.no. →8L..1..080 600	05.00-02.01	AG,RLE		0 281 002 347
1.9 TDI [8P1]			1,9l 77 kW BKC	4 Zyl.
Air mass meter, diesel	06.03-05.06			0 281 002 531
				0 986 284 009
Speed sensor, diesel	06.03-05.06	FKW,TW		0 261 210 233
1.9 TDI [8P1]			1,9l 77 kW BLS; BXE	4 Zyl.
Air mass meter, diesel	11.05→			0 281 002 531
				0 986 284 009
Speed sensor, diesel	11.05→	FKW,TW		0 261 210 233
Boost pressure sensor, Diesel	11.05→			0 281 002 399
1.9 TDI quattro [8L1]			1,9l 96 kW ASZ	4 Zyl.
Air mass meter, diesel				
Fg.no. →8L..2..105 000	05.00-04.02			0 280 217 529
				0 986 280 204
Fg.no. 8L..2..105 001→	04.02-06.03			0 281 002 461
				0 986 284 007
Boost pressure sensor, Diesel	05.00-06.03			0 281 002 401
Accelerator pedal module	05.00-08.00	GS,RLE		0 281 002 345
Fg.no. →8L..1..080 600	05.00-02.01	AG,RLE		0 281 002 347
2.0 FSI [8P1]			2,0l 110 kW AXW	4 Zyl.
Knock sensor	05.03-05.04	OHL		0 261 231 146
Pressure sensor, intake manifold, gasoline	05.03-05.04			0 261 230 031
Boost pressure sensor, gasoline	05.03-05.04			0 261 230 073
2.0 FSI [8P1]			2,0l 110 kW BHD	4 Zyl.
Boost pressure sensor, gasoline	10.03-01.04			0 261 230 073
2.0 FSI [8P1]			2,0l 110 kW BLR; BLX; BLY; BMB	4 Zyl.
Knock sensor	01.04-10.05	OHL		0 261 231 146
Pressure sensor, intake manifold, gasoline	01.04-10.05			0 261 230 031
Boost pressure sensor, gasoline	01.04-10.05			0 261 230 073
2.0 FSI [8P1]			2,0l 110 kW BVY; BVZ	4 Zyl.
Knock sensor	11.05→	OHL		0 261 231 146
Pressure sensor, intake manifold, gasoline	11.05→			0 261 230 031
2.0 TDI [8P1]			2,0l 100/103/120/125 kW AZV; BKD; BMM; BMN; BUY	4 Zyl.
Air mass meter, diesel	05.03→			0 281 002 461
				0 986 284 007
Speed sensor, diesel	05.03→	FKW,TW		0 261 210 233
Boost pressure sensor, Diesel	05.03→			0 281 002 401
2.0 TDI quattro [8P1]			2,0l 100/103/125 kW AZV; BKD; BMM; BMN	4 Zyl.
Air mass meter, diesel	05.03→			0 281 002 461
				0 986 284 007
Speed sensor, diesel	05.03→	FKW,TW		0 261 210 233
Boost pressure sensor, Diesel	05.03→			0 281 002 401
2.0 TFSI [8P1]			2,0l 147 kW AXX; BWA	4 Zyl.
Speed sensor, ignition/injection	09.04→			0 261 210 199
Boost pressure sensor, gasoline	09.04→			0 261 230 073
2.0 TFSI [8P1]			2,0l 147 kW CAWB	4 Zyl.
Boost pressure sensor, gasoline	10.07→			0 261 230 073
2.0 TFSI quattro [8P1]			2,0l 147 kW AXX; BWA	4 Zyl.
Speed sensor, ignition/injection	09.04→			0 261 210 199
Boost pressure sensor, gasoline	09.04→			0 261 230 073
3.2 quattro [8P1]			3,2l 184 kW BDB	6 Zyl.
Air mass meter, gasoline injection	07.03-08.04			0 280 218 073
				0 986 280 222
Phase sensor	07.03-08.04			0 232 103 019
Knock sensor	07.03-08.04	OHL		0 261 231 146
3.2 quattro [8P1]			3,2l 184 kW BMJ	6 Zyl.
Air mass meter, gasoline injection	09.04-10.05			0 280 218 073
				0 986 280 222
Phase sensor				
Fg.no. →8P..6A066 000,→8P..6B005 500	09.04-08.05			0 232 103 019
Knock sensor	09.04-10.05	OHL		0 261 231 146

Product				
3.2 quattro [8P1]			3,2l 184 kW BUB	6 Zyl.
Air mass meter, gasoline injection	11.05→			0 280 218 073
				0 986 280 222
Knock sensor	11.05→	OHL		0 261 231 146
A3 Sportback				
1.4 TFSI [8PA]			1,4l 92 kW CAXC	4 Zyl.
Knock sensor	06.07→			0 261 231 146
Boost pressure sensor, gasoline	06.07→			0 281 002 399
1.6 [8PA]			1,6l 75 kW BGU	4 Zyl.
Speed sensor, ignition/injection	09.04-05.05			0 261 210 199
Pressure sensor, intake manifold, gasoline	09.04-05.05			0 261 230 031
1.6 [8PA]			1,6l 75 kW BSE; BSF	4 Zyl.
Speed sensor, ignition/injection	06.05→			0 261 210 199
Knock sensor	06.05→			0 261 231 146
Pressure sensor, intake manifold, gasoline	06.05→			0 261 230 031
1.6 FSI [8PA]			1,6l 85 kW BLF; BLP	4 Zyl.
Knock sensor	09.04-05.07			0 261 231 146
Pressure sensor, intake manifold, gasoline	09.04-05.07			0 261 230 095
1.8 FSI [8PA]			1,8l 118 kW BYT	4 Zyl.
Boost pressure sensor, gasoline	11.06-05.07			0 261 230 073
1.8 TFSI [8PA]			1,8l 118 kW BZB	4 Zyl.
Boost pressure sensor, gasoline	06.07-05.08			0 261 230 073
1.9 TDI [8PA]			1,9l 77 kW BKC	4 Zyl.
Air mass meter, diesel	09.04-05.06			0 281 002 531
				0 986 284 009
1.9 TDI [8PA]			1,9l 77 kW BLS; BXE	4 Zyl.
Air mass meter, diesel	11.05→			0 281 002 531
				0 986 284 009
Speed sensor, diesel	11.05→	FKW,TW		0 261 210 233
Boost pressure sensor, Diesel	11.05→			0 281 002 399
2.0 FSI [8PA]			2,0l 110 kW BLR; BLX; BLY; BMB	4 Zyl.
Knock sensor	09.04-10.05	OHL		0 261 231 146
Pressure sensor, intake manifold, gasoline	09.04-10.05			0 261 230 031
Boost pressure sensor, gasoline	09.04-10.05			0 261 230 073
2.0 FSI [8PA]			2,0l 110 kW BVY; BVZ	4 Zyl.
Knock sensor	11.05→	OHL		0 261 231 146
Pressure sensor, intake manifold, gasoline	11.05→			0 261 230 031
2.0 TDI [8PA]			2,0l 100/103/120/125 kW AZV; BKD; BMM; BMN; BUY	4 Zyl.
Air mass meter, diesel	09.04→			0 281 002 461
				0 986 284 007
Speed sensor, diesel	09.04→	FKW,TW		0 261 210 233
Boost pressure sensor, Diesel	09.04→			0 281 002 401
2.0 TDI quattro [8PA]			2,0l 103 kW BKD	4 Zyl.
Boost pressure sensor, Diesel	09.04-05.07			0 281 002 401
2.0 TDI quattro [8PA]			2,0l 103/125 kW BMM; BMN	4 Zyl.
Air mass meter, diesel	11.05→			0 281 002 461
				0 986 284 007
Speed sensor, diesel	11.05→	FKW,TW		0 261 210 233
Boost pressure sensor, Diesel	11.05→			0 281 002 401
2.0 TFSI [8PA]			2,0l 147 kW AXX; BWA	4 Zyl.
Speed sensor, ignition/injection	09.04→			0 261 210 199
Boost pressure sensor, gasoline	09.04→			0 261 230 073
2.0 TFSI [8PA]			2,0l 147 kW CAWB	4 Zyl.
Boost pressure sensor, gasoline	06.07→			0 261 230 073
2.0 TFSI quattro [8PA]			2,0l 147 kW AXX; BWA	4 Zyl.
Speed sensor, ignition/injection	09.04→			0 261 210 199
Boost pressure sensor, gasoline	09.04→			0 261 230 073
3.2 quattro [8PA]			3,2l 184 kW BMJ	6 Zyl.
Air mass meter, gasoline injection	09.04-10.05			0 280 218 073
				0 986 280 222





Phase sensor			
Fg.no. →8P..6A066 000,→8P..6B005 500	09.04-08.05		0 232 103 019
Knock sensor	09.04-10.05	OHL	0 261 231 146
3.2 quattro [8PA]		3,2l 184 kW BUB 6 Zyl.	
Air mass meter, gasoline injection	11.05-05.07		0 280 218 073
			0 986 280 222
Knock sensor	11.05-05.07	OHL	0 261 231 146

A4

1.6 [8D2; B5]			1,6l 74 kW ADP 4 Zyl.
Knock sensor	11.94-10.96		0 261 231 038
Temperature sensor, intake air, injection system	11.94-10.96		0 280 130 085
Lateral acceleration sensor, brake system	11.94-10.96		0 265 005 127
Duo sensor, acceleration and yaw rate, brake system	11.94-10.96		0 265 005 214
Yaw rate sensor, brake system	11.94-10.96		0 265 005 207
1.6 [8D2; B5]			1,6l 74 kW AHL 4 Zyl.
Phase sensor	10.96-07.99		0 232 101 031
Speed sensor, ignition/injection	10.96-07.99		0 261 210 147
Knock sensor	10.96-07.99		0 261 231 038
Temperature sensor, intake air, injection system	10.96-07.99		0 280 130 085
Lateral acceleration sensor, brake system	10.96-07.99		0 265 005 127
Duo sensor, acceleration and yaw rate, brake system	10.96-07.99		0 265 005 214
Yaw rate sensor, brake system	10.96-07.99		0 265 005 207
1.6 [8D2; B5]			1,6l 74 kW ANA; ARM 4 Zyl.
Phase sensor	08.98-06.00		0 232 101 031
Speed sensor, ignition/injection	08.98-06.00		0 261 210 147
Knock sensor	08.98-06.00		0 261 231 038
Lateral acceleration sensor, brake system	08.98-06.00		0 265 005 127
Duo sensor, acceleration and yaw rate, brake system	08.98-06.00		0 265 005 214
Yaw rate sensor, brake system	08.98-06.00		0 265 005 207
1.6 [8D2; B5]			1,6l 75 kW ALZ 4 Zyl.
Phase sensor	06.00-10.00		0 232 101 038
Lateral acceleration sensor, brake system	06.00-10.00		0 265 005 127
Duo sensor, acceleration and yaw rate, brake system	06.00-10.00		0 265 005 214
Yaw rate sensor, brake system	06.00-10.00		0 265 005 207
1.6 [8EC; B7]			1,6l 75 kW ALZ 4 Zyl.
Speed sensor, ignition/injection	11.04→		0 281 002 222
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →8E..5..600 000	11.04-05.05		0 265 005 601
Fg.no. 8E..6..000 001→	06.05→		0 265 005 621
Wheel speed sensor, front	11.04→		0 265 006 809
Wheel speed sensor, rear	11.04→	ALR,RAB	0 265 006 824
		OLW	0 265 006 824
1.6 [8E2; B6]			1,6l 75 kW ALZ 4 Zyl.
Speed sensor, ignition/injection	10.00-12.04		0 281 002 222
Duo sensor, acceleration and yaw rate, brake system	10.00-12.04		0 265 005 252
Pressure sensor, ESP, (electronic stability program)	10.00-12.04		0 265 005 303
Wheel speed sensor, front			
Fg.no. →8E..3..500 000	10.00-05.03		0 265 006 683
Fg.no. 8E..4..000 001→	06.03-12.04		0 265 006 809
Wheel speed sensor, rear			
Fg.no. →8E..4..050 000	10.00-05.04	ALR,LAB	0 265 006 707
Fg.no. →8E..4..400 000	10.00-05.04	ALR,RAB	0 265 006 681
		OLW	0 265 006 681



Wheel speed sensor, rear			
Fg.no. 8E..5..000 001→	06.04-12.04	ALR,LAB	0 265 006 826
		ALR,RAB	0 265 006 824
		OLW	0 265 006 824
1.8 [8D2; B5]			1,8l 85 kW AFY 4 Zyl.
Phase sensor	04.95-06.00		0 232 101 024
Knock sensor	04.95-06.00	KZB	0 261 231 036
		KZG	0 261 231 038
Temperature sensor, intake air, injection system	04.95-06.00		0 280 130 085
Lateral acceleration sensor, brake system	04.95-06.00		0 265 005 127
Duo sensor, acceleration and yaw rate, brake system	04.95-06.00		0 265 005 214
Yaw rate sensor, brake system	04.95-06.00		0 265 005 207
1.8 [8D2; B5]			1,8l 92 kW ADR 4 Zyl.
Throttle valve assembly			
Fg.no. 8D-X 250 001→	03.99-04.99		0 280 750 080
Air mass meter, gasoline injection			
Fg.no. 8D..X..200 001→	02.99-04.99		0 280 218 013
			0 986 280 206
Phase sensor	11.94-04.99		0 232 101 024
Knock sensor	11.94-04.99	KZB	0 261 231 036
		KZG	0 261 231 038
Temperature sensor, intake air, injection system	11.94-04.99		0 280 130 085
Lateral acceleration sensor, brake system	11.94-04.99		0 265 005 127
Duo sensor, acceleration and yaw rate, brake system	11.94-04.99		0 265 005 214
Yaw rate sensor, brake system	11.94-04.99		0 265 005 207
1.8 [8D2; B5]			1,8l 92 kW APT 4 Zyl.
Throttle valve assembly	04.99-10.00		0 280 750 080
Air mass meter, gasoline injection	04.99-10.00		0 280 218 013
			0 986 280 206
Phase sensor	04.99-10.00		0 232 101 024
Knock sensor	04.99-10.00	KZB	0 261 231 036
		KZG	0 261 231 038
Temperature sensor, intake air, injection system	04.99-10.00		0 280 130 085
Lateral acceleration sensor, brake system	04.99-10.00		0 265 005 127
Duo sensor, acceleration and yaw rate, brake system	04.99-10.00		0 265 005 214
Yaw rate sensor, brake system	04.99-10.00		0 265 005 207
1.8 [8D2; B5]			1,8l 92 kW ARG 4 Zyl.
Throttle valve assembly			
Fg.no. 8D-X 250 001→	03.99-10.00		0 280 750 080
Air mass meter, gasoline injection	08.98-10.00		0 280 218 013
			0 986 280 206
Phase sensor	08.98-10.00		0 232 101 024
Knock sensor	08.98-10.00	KZB	0 261 231 036
		KZG	0 261 231 038
Temperature sensor, intake air, injection system	08.98-10.00		0 280 130 085
Lateral acceleration sensor, brake system	08.98-10.00		0 265 005 127
Duo sensor, acceleration and yaw rate, brake system	08.98-10.00		0 265 005 214
Yaw rate sensor, brake system	08.98-10.00		0 265 005 207
1.8 [8D2; B5]			1,8l 92 kW AVV 4 Zyl.
Throttle valve assembly	06.00-10.00		0 280 750 080
Air mass meter, gasoline injection	06.00-10.00		0 280 218 013
			0 986 280 206
Temperature sensor, intake air, injection system	06.00-10.00		0 280 130 085
Lateral acceleration sensor, brake system	06.00-10.00		0 265 005 127
Duo sensor, acceleration and yaw rate, brake system	06.00-10.00		0 265 005 214
Yaw rate sensor, brake system	06.00-10.00		0 265 005 207

Product				

◀ A4

1.8 quattro [8D2; B5]		1,8l 85 kW AFY 4 Zyl.	
Phase sensor	07.95-10.01		0 232 101 024
Knock sensor	07.95-10.01	KZB	0 261 231 036
		KZG	0 261 231 038
Temperature sensor, intake air, injection system	07.95-10.01		0 280 130 085
Lateral acceleration sensor, brake system	07.95-10.01		0 265 005 127
Duo sensor, acceleration and yaw rate, brake system	07.95-10.01		0 265 005 214
Yaw rate sensor, brake system	07.95-10.01		0 265 005 207
Wheel speed sensor, rear			
Fg.no. 8D..W..280 001→	06.98-10.01	ALR,LAB	0 265 006 571
		ALR,RAB	0 265 006 569
		OLW	0 265 006 569
1.8 quattro [8D2; B5]		1,8l 92 kW ADR 4 Zyl.	
Throttle valve assembly			
Fg.no. 8D-X 250 001→	03.99-04.99		0 280 750 080
Air mass meter, gasoline injection			
Fg.no. 8D..X..200 001→	02.99-04.99		0 280 218 013
			0 986 280 206
Phase sensor	11.94-04.99		0 232 101 024
Knock sensor	11.94-04.99	KZB	0 261 231 036
		KZG	0 261 231 038
Temperature sensor, intake air, injection system	11.94-04.99		0 280 130 085
Lateral acceleration sensor, brake system	11.94-04.99		0 265 005 127
Duo sensor, acceleration and yaw rate, brake system	11.94-04.99		0 265 005 214
Yaw rate sensor, brake system	11.94-04.99		0 265 005 207
Wheel speed sensor, rear			
Fg.no. 8D..W..280 001→	06.98-04.99	ALR,LAB	0 265 006 571
		ALR,RAB	0 265 006 569
		OLW	0 265 006 569
1.8 quattro [8D2; B5]		1,8l 92 kW APT 4 Zyl.	
Throttle valve assembly	02.99-10.00		0 280 750 080
Air mass meter, gasoline injection	02.99-10.00		0 280 218 013
			 0 986 280 206
Phase sensor	02.99-10.00		0 232 101 024
Knock sensor	02.99-10.00	KZB	0 261 231 036
		KZG	0 261 231 038
Temperature sensor, intake air, injection system	02.99-10.00		0 280 130 085
Lateral acceleration sensor, brake system	02.99-10.00		0 265 005 127
Duo sensor, acceleration and yaw rate, brake system	02.99-10.00		0 265 005 214
Yaw rate sensor, brake system	02.99-10.00		0 265 005 207
Wheel speed sensor, rear	02.99-10.00	ALR,LAB	0 265 006 571
		ALR,RAB	0 265 006 569
		OLW	0 265 006 569
1.8 quattro [8D2; B5]		1,8l 92 kW ARG 4 Zyl.	
Throttle valve assembly			
Fg.no. 8D-X 250 001→	03.99-06.00		0 280 750 080
Air mass meter, gasoline injection	02.99-06.00		0 280 218 013
			 0 986 280 206
Phase sensor	02.99-06.00		0 232 101 024
Knock sensor	02.99-06.00	KZB	0 261 231 036
		KZG	0 261 231 038
Temperature sensor, intake air, injection system	02.99-06.00		0 280 130 085
Lateral acceleration sensor, brake system	02.99-06.00		0 265 005 127
Duo sensor, acceleration and yaw rate, brake system	02.99-06.00		0 265 005 214
Yaw rate sensor, brake system	02.99-06.00		0 265 005 207
Wheel speed sensor, rear	02.99-06.00	ALR,LAB	0 265 006 571
		ALR,RAB	0 265 006 569
		OLW	0 265 006 569

Product				

1.8 T [8D2; B5]		1,8l 110 kW AEB 4 Zyl.	
Air mass meter, gasoline injection	11.94-07.98	0 280 217 112	
Phase sensor	11.94-07.98	0 232 101 024	
Knock sensor	11.94-07.98	KZB	0 261 231 036
		KZG	0 261 231 038
Temperature sensor, intake air, injection system	11.94-07.98	0 280 130 085	
Lateral acceleration sensor, brake system	11.94-07.98	0 265 005 127	
Duo sensor, acceleration and yaw rate, brake system	11.94-07.98	0 265 005 214	
Yaw rate sensor, brake system	11.94-07.98	0 265 005 207	
1.8 T [8D2; B5]		1,8l 110 kW ANB; APU 4 Zyl.	
Air mass meter, gasoline injection	08.98-06.00	0 280 218 032	
		🚗 0 986 280 210	
Phase sensor	08.98-06.00	0 232 101 024	
Knock sensor	08.98-06.00	KZB	0 261 231 036
		KZG	0 261 231 038
Boost pressure sensor, gasoline	08.98-06.00	0 281 002 177	
Temperature sensor, intake air, injection system	08.98-06.00	0 280 130 085	
Lateral acceleration sensor, brake system	08.98-06.00	0 265 005 127	
Duo sensor, acceleration and yaw rate, brake system	08.98-06.00	0 265 005 214	
Yaw rate sensor, brake system	08.98-06.00	0 265 005 207	
1.8 T [8D2; B5]		1,8l 110 kW ARK 4 Zyl.	
Air mass meter, gasoline injection	08.98-07.99	0 280 218 032	
		🚗 0 986 280 210	
Phase sensor	08.98-07.99	0 232 101 024	
Lateral acceleration sensor, brake system	08.98-07.99	0 265 005 127	
Duo sensor, acceleration and yaw rate, brake system	08.98-07.99	0 265 005 214	
Yaw rate sensor, brake system	08.98-07.99	0 265 005 207	
1.8 T [8D2; B5]		1,8l 110 kW ATW 4 Zyl.	
Throttle valve assembly	08.99-05.00	0 280 750 009	
Air mass meter, gasoline injection	08.99-05.00	0 280 218 002	
		🚗 0 986 280 205	
Knock sensor	08.99-05.00	KZB	0 261 231 036
		KZG	0 261 231 038
Boost pressure sensor, gasoline	08.99-05.00	0 281 002 177	
Temperature sensor, intake air, injection system	08.99-05.00	0 280 130 085	
1.8 T [8D2; B5]		1,8l 110 kW AWT 4 Zyl.	
Air mass meter, gasoline injection	06.00-10.00	0 280 218 063	
		🚗 0 986 280 217	
Phase sensor	06.00-10.00	0 232 101 024	
Speed sensor, ignition/injection	06.00-10.00	0 281 002 222	
Boost pressure sensor, gasoline	06.00-10.00	0 281 002 177	
Temperature sensor, intake air, injection system	06.00-10.00	0 280 130 085	
Lateral acceleration sensor, brake system	06.00-10.00	0 265 005 127	
Duo sensor, acceleration and yaw rate, brake system	06.00-10.00	0 265 005 214	
Yaw rate sensor, brake system	06.00-10.00	0 265 005 207	
1.8 T [8D2; B5]		1,8l 125 kW AWM 4 Zyl.	
Throttle valve assembly	05.00-10.00	0 280 750 009	
Air mass meter, gasoline injection	05.00-10.00	0 280 218 063	
		🚗 0 986 280 217	
Phase sensor	05.00-10.00	0 232 101 024	
Speed sensor, ignition/injection	05.00-10.00	0 281 002 222	
Boost pressure sensor, gasoline	05.00-10.00	0 281 002 177	
Temperature sensor, intake air, injection system	05.00-10.00	0 280 130 085	
1.8 T [8D2; B5]		1,8l 132 kW AJL 4 Zyl.	
Air mass meter, gasoline injection	08.97-12.98	0 280 217 117	
		🚗 0 986 280 201	
Phase sensor	08.97-12.98	0 232 101 024	
Knock sensor	08.97-12.98	KZB	0 261 231 036
		KZG	0 261 231 038



Temperature sensor, intake air, injection system	08.97-12.98		0 280 130 085
Lateral acceleration sensor, brake system	08.97-12.98		0 265 005 127
Duo sensor, acceleration and yaw rate, brake system	08.97-12.98		0 265 005 214
Yaw rate sensor, brake system	08.97-12.98		0 265 005 207
1.8 T [8EC; B7]		1,8l 120 kW BFB 4 Zyl.	
Throttle valve assembly	11.04→		0 280 750 009
Air mass meter, gasoline injection	11.04→		0 280 218 063
			0 986 280 217
Phase sensor	11.04→		0 232 101 024
Speed sensor, ignition/injection	11.04→		0 281 002 222
Boost pressure sensor, gasoline	11.04→		0 261 230 073
Temperature sensor, intake air, injection system	11.04→		0 280 130 085
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →8E..5..600 000	11.04-05.05		0 265 005 601
Fg.no. 8E..6..000 001→	06.05→		0 265 005 621
Wheel speed sensor, front	11.04→		0 265 006 809
Wheel speed sensor, rear	11.04→	ALR,RAB	0 265 006 824
		OLW	0 265 006 824
1.8 T [8E2; B6]		1,8l 110 kW AVJ 4 Zyl.	
Throttle valve assembly	12.00-06.02		0 280 750 009
Air mass meter, gasoline injection	12.00-06.02		0 280 218 063
			0 986 280 217
Phase sensor	12.00-06.02		0 232 101 024
Speed sensor, ignition/injection	12.00-06.02		0 281 002 222
Boost pressure sensor, gasoline	12.00-06.02		0 261 230 073
Temperature sensor, intake air, injection system			
Fg.no. →8E..1..080 000	12.00-04.01		0 280 130 085
Fg.no. 8E..2..000 001→	04.01-06.02		0 280 130 116
Duo sensor, acceleration and yaw rate, brake system	12.00-06.02		0 265 005 252
Pressure sensor, ESP, (electronic stability program)	12.00-06.02		0 265 005 303
Wheel speed sensor, front	12.00-06.02		0 265 006 683
Wheel speed sensor, rear	12.00-06.02	ALR,LAB	0 265 006 707
		ALR,RAB	0 265 006 681
		OLW	0 265 006 681
1.8 T [8E2; B6]		1,8l 120 kW BFB 4 Zyl.	
Throttle valve assembly	07.02-12.04		0 280 750 009
Air mass meter, gasoline injection	07.02-12.04		0 280 218 063
			0 986 280 217
Phase sensor	07.02-12.04		0 232 101 024
Speed sensor, ignition/injection	07.02-12.04		0 281 002 222
Boost pressure sensor, gasoline	07.02-12.04		0 261 230 073
Temperature sensor, intake air, injection system	07.02-12.04		0 280 130 085
Duo sensor, acceleration and yaw rate, brake system	07.02-12.04		0 265 005 252
Pressure sensor, ESP, (electronic stability program)	07.02-12.04		0 265 005 303
Wheel speed sensor, front			
Fg.no. →8E..3..500 000	07.02-05.03		0 265 006 683
Fg.no. 8E..4..000 001→	06.03-12.04		0 265 006 809
Wheel speed sensor, rear			
Fg.no. →8E..4..050 000	07.02-05.04	ALR,LAB	0 265 006 707
Fg.no. →8E..4..400 000	07.02-05.04	ALR,RAB	0 265 006 681
		OLW	0 265 006 681
Fg.no. 8E..5..000 001→	06.04-12.04	ALR,LAB	0 265 006 826
		ALR,RAB	0 265 006 824
		OLW	0 265 006 824
1.8 T [8E2; B6]		1,8l 125 kW AMB 4 Zyl.	
Throttle valve assembly	07.01-06.02		0 280 750 009
Air mass meter, gasoline injection	07.01-06.02		0 280 218 063
			0 986 280 217
Phase sensor	07.01-06.02		0 232 101 024



Speed sensor, ignition/injection	07.01-06.02		0 281 002 222
Boost pressure sensor, gasoline	07.01-06.02		0 261 230 073
Temperature sensor, intake air, injection system	07.01-06.02		0 280 130 116
Duo sensor, acceleration and yaw rate, brake system	07.01-06.02		0 265 005 252
Pressure sensor, ESP, (electronic stability program)	07.01-06.02		0 265 005 303
Wheel speed sensor, front	07.01-06.02		0 265 006 683
Wheel speed sensor, rear	07.01-06.02	ALR,LAB	0 265 006 707
		ALR,RAB	0 265 006 681
		OLW	0 265 006 681
1.8 T [8E2; B6]		1,8l 140 kW BEX 4 Zyl.	
Throttle valve assembly	11.02-12.04		0 280 750 009
Air mass meter, gasoline injection	11.02-12.04		0 280 218 063
			0 986 280 217
Phase sensor	11.02-12.04		0 232 101 024
Speed sensor, ignition/injection	11.02-12.04		0 281 002 222
Boost pressure sensor, gasoline	11.02-12.04		0 261 230 073
Temperature sensor, intake air, injection system	11.02-12.04		0 280 130 085
Duo sensor, acceleration and yaw rate, brake system	11.02-12.04		0 265 005 252
Pressure sensor, ESP, (electronic stability program)	11.02-12.04		0 265 005 303
Wheel speed sensor, front			
Fg.no. →8E..3..500 000	11.02-05.03		0 265 006 683
Fg.no. 8E..4..000 001→	06.03-12.04		0 265 006 809
Wheel speed sensor, rear			
Fg.no. →8E..4..050 000	11.02-05.04	ALR,LAB	0 265 006 707
Fg.no. →8E..4..400 000	11.02-05.04	ALR,RAB	0 265 006 681
		OLW	0 265 006 681
Fg.no. 8E..5..000 001→	06.04-12.04	ALR,LAB	0 265 006 826
		ALR,RAB	0 265 006 824
		OLW	0 265 006 824
1.8 T quattro [8D2; B5]		1,8l 110 kW AEB 4 Zyl.	
Air mass meter, gasoline injection	11.94-12.98		0 280 217 112
Phase sensor	11.94-12.98		0 232 101 024
Knock sensor	11.94-12.98	KZB	0 261 231 036
		KZG	0 261 231 038
Temperature sensor, intake air, injection system	11.94-12.98		0 280 130 085
Lateral acceleration sensor, brake system	11.94-12.98		0 265 005 127
Yaw rate sensor, brake system	11.94-12.98		0 265 005 207
Wheel speed sensor, rear			
Fg.no. 8D..W..280 001→	06.98-12.98	ALR,LAB	0 265 006 571
		ALR,RAB	0 265 006 569
		OLW	0 265 006 569
1.8 T quattro [8D2; B5]		1,8l 110 kW ANB;APU 4 Zyl.	
Air mass meter, gasoline injection	02.99-10.00		0 280 218 032
			0 986 280 210
Phase sensor	02.99-10.00		0 232 101 024
Knock sensor	02.99-10.00	KZB	0 261 231 036
		KZG	0 261 231 038
Boost pressure sensor, gasoline	02.99-10.00		0 281 002 177
Temperature sensor, intake air, injection system	02.99-10.00		0 280 130 085
Lateral acceleration sensor, brake system	02.99-10.00		0 265 005 127
Duo sensor, acceleration and yaw rate, brake system	02.99-10.00		0 265 005 214
Yaw rate sensor, brake system	02.99-10.00		0 265 005 207
Wheel speed sensor, rear	02.99-10.00	ALR,LAB	0 265 006 571
		ALR,RAB	0 265 006 569
		OLW	0 265 006 569
1.8 T quattro [8D2; B5]		1,8l 110 kW ARK 4 Zyl.	
Air mass meter, gasoline injection	07.98-07.99		0 280 218 032
			0 986 280 210
Phase sensor	07.98-07.99		0 232 101 024
Lateral acceleration sensor, brake system	07.98-07.99		0 265 005 127

Product				

◀ A4

Duo sensor, acceleration and yaw rate, brake system	07.98-07.99			0 265 005 214
Yaw rate sensor, brake system	07.98-07.99			0 265 005 207
Wheel speed sensor, rear	07.98-07.99	ALR,LAB		0 265 006 571
		ALR,RAB		0 265 006 569
		OLW		0 265 006 569
1.8 T quattro [8D2; B5]		1,8 l 110 kW AWT 4 Zyl.		
Air mass meter, gasoline injection	06.00-10.00			0 280 218 063
				0 986 280 217
Phase sensor	06.00-10.00			0 232 101 024
Speed sensor, ignition/injection	06.00-10.00			0 281 002 222
Boost pressure sensor, gasoline	06.00-10.00			0 281 002 177
Temperature sensor, intake air, injection system	06.00-10.00			0 280 130 085
Lateral acceleration sensor, brake system	06.00-10.00			0 265 005 127
Duo sensor, acceleration and yaw rate, brake system	06.00-10.00			0 265 005 214
Yaw rate sensor, brake system	06.00-10.00			0 265 005 207
Wheel speed sensor, rear	06.00-10.00	ALR,LAB		0 265 006 571
		ALR,RAB		0 265 006 569
		OLW		0 265 006 569
1.8 T quattro [8D2; B5]		1,8 l 132 kW AJL 4 Zyl.		
Air mass meter, gasoline injection	08.97-10.00			0 280 217 117
				0 986 280 201
Phase sensor	08.97-10.00			0 232 101 024
Knock sensor	08.97-10.00	KZB		0 261 231 036
		KZG		0 261 231 038
Temperature sensor, intake air, injection system	08.97-10.00			0 280 130 085
Lateral acceleration sensor, brake system	08.97-10.00			0 265 005 127
Duo sensor, acceleration and yaw rate, brake system	08.97-10.00			0 265 005 214
Yaw rate sensor, brake system	08.97-10.00			0 265 005 207
Wheel speed sensor, rear				
Fg.no. 8D..W..280 001→	06.98-10.00	ALR,LAB		0 265 006 571
		ALR,RAB		0 265 006 569
		OLW		0 265 006 569
1.8 T quattro [8EC; B7]		1,8 l 120 kW BFB 4 Zyl.		
Throttle valve assembly	11.04→			0 280 750 009
Air mass meter, gasoline injection	11.04→			0 280 218 063
				0 986 280 217
Phase sensor	11.04→			0 232 101 024
Speed sensor, ignition/injection	11.04→			0 281 002 222
Boost pressure sensor, gasoline	11.04→			0 261 230 073
Temperature sensor, intake air, injection system	11.04→			0 280 130 085
Duo sensor, acceleration and yaw rate, brake system				
Fg.no. →8E..5..600 000	11.04-05.05			0 265 005 601
Fg.no. 8E..6..000 001→	06.05→			0 265 005 621
Wheel speed sensor, front	11.04→			0 265 006 809
Wheel speed sensor, rear	11.04→	ALR,RAB		0 265 006 824
		OLW		0 265 006 824
1.8 T quattro [8E2; B6]		1,8 l 110 kW AVJ 4 Zyl.		
Throttle valve assembly	12.00-06.02			0 280 750 009
Air mass meter, gasoline injection	12.00-06.02			0 280 218 063
				0 986 280 217
Phase sensor	12.00-06.02			0 232 101 024
Speed sensor, ignition/injection	12.00-06.02			0 281 002 222
Boost pressure sensor, gasoline	12.00-06.02			0 261 230 073
Temperature sensor, intake air, injection system				
Fg.no. →8E..1..080 000	12.00-04.01			0 280 130 085
Fg.no. 8E..2..000 001→	04.01-06.02			0 280 130 116
Duo sensor, acceleration and yaw rate, brake system	12.00-06.02			0 265 005 252
Pressure sensor, ESP, (electronic stability program)	12.00-06.02			0 265 005 303

Product				

Wheel speed sensor, front	12.00-06.02			0 265 006 683
Wheel speed sensor, rear	12.00-06.02	ALR,LAB		0 265 006 707
		ALR,RAB		0 265 006 681
		OLW		0 265 006 681
1.8 T quattro [8E2; B6]		1,8 l 120 kW BFB 4 Zyl.		
Throttle valve assembly	07.02-12.04			0 280 750 009
Air mass meter, gasoline injection	07.02-12.04			0 280 218 063
				0 986 280 217
Phase sensor	07.02-12.04			0 232 101 024
Speed sensor, ignition/injection	07.02-12.04			0 281 002 222
Boost pressure sensor, gasoline	07.02-12.04			0 261 230 073
Temperature sensor, intake air, injection system	07.02-12.04			0 280 130 085
Duo sensor, acceleration and yaw rate, brake system	07.02-12.04			0 265 005 252
Pressure sensor, ESP, (electronic stability program)	07.02-12.04			0 265 005 303
Wheel speed sensor, front				
Fg.no. →8E..3..500 000	07.02-05.03			0 265 006 683
Fg.no. 8E..4..000 001→	06.03-12.04			0 265 006 809
Wheel speed sensor, rear				
Fg.no. →8E..4..050 000	07.02-05.04	ALR,LAB		0 265 006 707
Fg.no. →8E..4..400 000	07.02-05.04	ALR,RAB		0 265 006 681
		OLW		0 265 006 681
Fg.no. 8E..5..000 001→	06.04-12.04	ALR,LAB		0 265 006 826
		ALR,RAB		0 265 006 824
		OLW		0 265 006 824
1.8 T quattro [8E2; B6]		1,8 l 125 kW AMB 4 Zyl.		
Throttle valve assembly	07.01-06.02			0 280 750 009
Air mass meter, gasoline injection	07.01-06.02			0 280 218 063
				0 986 280 217
Phase sensor	07.01-06.02			0 232 101 024
Speed sensor, ignition/injection	07.01-06.02			0 281 002 222
Boost pressure sensor, gasoline	07.01-06.02			0 261 230 073
Temperature sensor, intake air, injection system	07.01-06.02			0 280 130 116
Duo sensor, acceleration and yaw rate, brake system	07.01-06.02			0 265 005 252
Pressure sensor, ESP, (electronic stability program)	07.01-06.02			0 265 005 303
Wheel speed sensor, front	07.01-06.02			0 265 006 683
Wheel speed sensor, rear	07.01-06.02	ALR,LAB		0 265 006 707
		ALR,RAB		0 265 006 681
		OLW		0 265 006 681
1.8 T quattro [8E2; B6]		1,8 l 140 kW BEX 4 Zyl.		
Throttle valve assembly	11.02-12.04			0 280 750 009
Air mass meter, gasoline injection	11.02-12.04			0 280 218 063
				0 986 280 217
Phase sensor	11.02-12.04			0 232 101 024
Speed sensor, ignition/injection	11.02-12.04			0 281 002 222
Boost pressure sensor, gasoline	11.02-12.04			0 261 230 073
Temperature sensor, intake air, injection system	11.02-12.04			0 280 130 085
Duo sensor, acceleration and yaw rate, brake system	11.02-12.04			0 265 005 252
Pressure sensor, ESP, (electronic stability program)	11.02-12.04			0 265 005 303
Wheel speed sensor, front				
Fg.no. →8E..3..500 000	11.02-05.03			0 265 006 683
Fg.no. 8E..4..000 001→	06.03-12.04			0 265 006 809
Wheel speed sensor, rear				
Fg.no. →8E..4..050 000	11.02-05.04	ALR,LAB		0 265 006 707
Fg.no. →8E..4..400 000	11.02-05.04	ALR,RAB		0 265 006 681
		OLW		0 265 006 681
Fg.no. 8E..5..000 001→	06.04-12.04	ALR,LAB		0 265 006 826
		ALR,RAB		0 265 006 824
		OLW		0 265 006 824

Product



1.8 Turbo		1,8l 120 kW BFB/BKB 4 Zyl.	
Throttle valve assembly	04.03-02.07		0 280 750 009
Air mass meter, gasoline injection	04.03-02.07		0 280 218 063
			0 986 280 217
Phase sensor	04.03-02.07		0 232 101 091
Speed sensor, ignition/injection	04.03-02.07		0 281 002 222
Boost pressure sensor, gasoline	04.03-02.07		0 261 230 073
Temperature sensor, intake air, injection system	04.03-02.07		0 280 130 085
Duo sensor, acceleration and yaw rate, brake system	04.03-02.07		0 265 005 252
Pressure sensor, ESP, (electronic stability program)	04.03-02.07		0 265 005 303
Wheel speed sensor, front			
Fg.no. →8E..3..500 000	04.03-05.03		0 265 006 683
Fg.no. 8E..4..000 001→	06.03-02.07		0 265 006 809
Wheel speed sensor, rear	04.03-02.07		0 265 006 681
1.9 TDI [8D2; B5]		1,9l 55 kW AFF 4 Zyl.	
Air mass meter, diesel	08.97-06.00		0 281 002 216
			0 986 284 001
Boost pressure sensor, Diesel	08.97-06.00		0 281 002 177
Pedal position sensor, diesel			
Fg.no. →8D..W..028 000	03.96-09.97	AG	0 205 001 031
		GS	0 205 001 032
Fg.no. 8D..W..028 001→	09.97-06.00	AG	0 281 002 289
Fg.no. 8D..W..028 001→8D..W..080 000	09.97-11.97	GS	0 281 002 229
Fg.no. 8D..W..080 001→	11.97-06.00	GS	0 281 002 286
Lateral acceleration sensor, brake system	03.96-06.00		0 265 005 127
Duo sensor, acceleration and yaw rate, brake system	03.96-06.00		0 265 005 214
Yaw rate sensor, brake system	03.96-06.00		0 265 005 207
1.9 TDI [8D2; B5]		1,9l 66 kW AHH 4 Zyl.	
Boost pressure sensor, Diesel	04.97-10.00		0 281 002 177
Pedal position sensor, diesel	04.97-10.00	AG	0 205 001 031
		GS	0 205 001 032
Lateral acceleration sensor, brake system	04.97-10.00		0 265 005 127
Duo sensor, acceleration and yaw rate, brake system	04.97-10.00		0 265 005 214
Yaw rate sensor, brake system	04.97-10.00		0 265 005 207
1.9 TDI [8D2; B5]		1,9l 66 kW AHU 4 Zyl.	
Air mass meter, diesel	08.97-07.98		0 281 002 216
			0 986 284 001
Boost pressure sensor, Diesel	08.97-07.98		0 281 002 177
Pedal position sensor, diesel			
Fg.no. →8D..W..028 000	08.96-09.97	AG	0 205 001 031
		GS	0 205 001 032
Fg.no. 8D..W..028 001→	09.97-07.98	AG	0 281 002 289
Fg.no. 8D..W..028 001→8D..W..080 000	09.97-11.97	GS	0 281 002 229
Fg.no. 8D..W..080 001→	11.97-07.98	GS	0 281 002 286
Lateral acceleration sensor, brake system	08.96-07.98		0 265 005 127
Duo sensor, acceleration and yaw rate, brake system	08.96-07.98		0 265 005 214
Yaw rate sensor, brake system	08.96-07.98		0 265 005 207
1.9 TDI [8D2; B5]		1,9l 66 kW 1Z 4 Zyl.	
Pedal position sensor, diesel	11.94-07.96	AG	0 205 001 031
		GS	0 205 001 032
Lateral acceleration sensor, brake system	11.94-07.96		0 265 005 127
Duo sensor, acceleration and yaw rate, brake system	11.94-07.96		0 265 005 214
Yaw rate sensor, brake system	11.94-07.96		0 265 005 207
1.9 TDI [8D2; B5]		1,9l 81 kW AFN 4 Zyl.	
Air mass meter, diesel	08.97-07.99		0 281 002 216
			0 986 284 001
Boost pressure sensor, Diesel	08.97-07.99		0 281 002 177

Product



Pedal position sensor, diesel			
Fg.no. →8D..W..028 000	02.96-09.97	AG	0 205 001 031
		GS	0 205 001 032
Fg.no. 8D..W..028 001→	09.97-07.99	AG	0 281 002 289
Fg.no. 8D..W..028 001→8D..W..080 000	09.97-11.97	GS	0 281 002 229
Fg.no. 8D..W..080 001→	11.97-07.99	GS	0 281 002 286
Lateral acceleration sensor, brake system	02.96-07.99		0 265 005 127
Duo sensor, acceleration and yaw rate, brake system	02.96-07.99		0 265 005 214
Yaw rate sensor, brake system	02.96-07.99		0 265 005 207
1.9 TDI [8D2; B5]		1,9l 81/85 kW AJM; AVG 4 Zyl.	
Air mass meter, diesel	08.98-11.00		0 281 002 216
			0 986 284 001
Boost pressure sensor, Diesel	08.98-11.00		0 281 002 177
Pedal position sensor, diesel	08.98-11.00	AG	0 281 002 289
		GS	0 281 002 286
Lateral acceleration sensor, brake system	08.98-11.00		0 265 005 127
Duo sensor, acceleration and yaw rate, brake system	08.98-11.00		0 265 005 214
Yaw rate sensor, brake system	08.98-11.00		0 265 005 207
1.9 TDI [8EC; B7]		1,9l 85 kW BKE 4 Zyl.	
Air mass meter, diesel	11.04-11.05		0 281 002 461
			0 986 284 007
Boost pressure sensor, Diesel	11.04-11.05		0 281 002 399
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →8E..5..600 000	11.04-05.05		0 265 005 601
Fg.no. 8E..6..000 001→	06.05-11.05		0 265 005 621
Wheel speed sensor, front	11.04-11.05		0 265 006 809
Wheel speed sensor, rear	11.04-11.05	ALR,RAB	0 265 006 824
		OLW	0 265 006 824
1.9 TDI [8EC; B7]		1,9l 85 kW BRB 4 Zyl.	
Air mass meter, diesel	01.06→		0 281 002 461
			0 986 284 007
Boost pressure sensor, Diesel	01.06→		0 281 002 399
Duo sensor, acceleration and yaw rate, brake system	01.06→		0 265 005 621
Wheel speed sensor, front	01.06→		0 265 006 809
Wheel speed sensor, rear	01.06→	ALR,RAB	0 265 006 824
		OLW	0 265 006 824
1.9 TDI [8E2; B6]		1,9l 74 kW AVB 4 Zyl.	
Air mass meter, diesel			
Fg.no. →8E..2..120 000	04.01-09.01		0 281 002 757
		WW	0 280 217 121
			0 986 280 202
Fg.no. 8E..2..120 001→	09.01-05.04		0 281 002 531
			0 986 284 009
Boost pressure sensor, Diesel	04.01-05.04		0 281 002 399
Duo sensor, acceleration and yaw rate, brake system	04.01-05.04		0 265 005 252
Pressure sensor, ESP, (electronic stability program)	04.01-05.04		0 265 005 303
Wheel speed sensor, front			
Fg.no. →8E..3..500 000	04.01-05.03		0 265 006 683
Fg.no. 8E..4..000 001→	06.03-05.04		0 265 006 809
Wheel speed sensor, rear	04.01-05.04	ALR,LAB	0 265 006 707
		ALR,RAB	0 265 006 681
		OLW	0 265 006 681
1.9 TDI [8E2; B6]		1,9l 85 kW BKE 4 Zyl.	
Air mass meter, diesel	06.04-12.04		0 281 002 461
			0 986 284 007
Boost pressure sensor, Diesel	06.04-12.04		0 281 002 399
Duo sensor, acceleration and yaw rate, brake system	06.04-12.04		0 265 005 252



A

Product				

◀ A4

Pressure sensor, ESP, (electronic stability program)	06.04-12.04		0 265 005 303
Wheel speed sensor, front	06.04-12.04		0 265 006 809
Wheel speed sensor, rear	06.04-12.04	ALR,LAB	0 265 006 826
		ALR,RAB	0 265 006 824
		OLW	0 265 006 824
1.9 TDI [8E2; B6]	1,9l 96 kW AVF 4 Zyl.		
Air mass meter, diesel	04.01-12.04		0 281 002 461
			0 986 284 007
Boost pressure sensor, Diesel	04.01-12.04		0 281 002 401
Duo sensor, acceleration and yaw rate, brake system	04.01-12.04		0 265 005 252
Pressure sensor, ESP, (electronic stability program)	04.01-12.04		0 265 005 303
Wheel speed sensor, front			
Fg.no. →8E..3..500 000	04.01-05.03		0 265 006 683
Fg.no. 8E..4..000 001→	06.03-12.04		0 265 006 809
Wheel speed sensor, rear			
Fg.no. →8E..4..050 000	04.01-05.04	ALR,LAB	0 265 006 707
Fg.no. →8E..4..400 000	04.01-05.04	ALR,RAB	0 265 006 681
		OLW	0 265 006 681
Fg.no. 8E..5..000 001→	06.04-12.04	ALR,LAB	0 265 006 826
		ALR,RAB	0 265 006 824
		OLW	0 265 006 824
1.9 TDI [8E2; B6]	1,9l 96 kW AWX 4 Zyl.		
Air mass meter, diesel			
Fg.no. →8E..1..080 000	12.00-04.01		0 280 217 529
			0 986 280 204
Fg.no. 8E..2..000 001→	04.01-06.03		0 281 002 461
			0 986 284 007
Boost pressure sensor, Diesel	12.00-06.03		0 281 002 401
Duo sensor, acceleration and yaw rate, brake system	12.00-06.03		0 265 005 252
Pressure sensor, ESP, (electronic stability program)	12.00-06.03		0 265 005 303
Wheel speed sensor, front	12.00-06.03		0 265 006 683
Wheel speed sensor, rear	12.00-06.03	ALR,LAB	0 265 006 707
		ALR,RAB	0 265 006 681
		OLW	0 265 006 681
1.9 TDI quattro [8D2; B5]	1,9l 81 kW AFN 4 Zyl.		
Air mass meter, diesel	08.97-12.98		0 281 002 216
			0 986 284 001
Boost pressure sensor, Diesel	08.97-12.98		0 281 002 177
Pedal position sensor, diesel			
Fg.no. →8D..W..028 000	07.96-09.97	AG	0 205 001 031
		GS	0 205 001 032
Fg.no. 8D..W..028 001→	09.97-12.98	AG	0 281 002 289
Fg.no. 8D..W..028 001→8D..W..080 000	09.97-11.97	GS	0 281 002 229
Fg.no. 8D..W..080 001→	11.97-12.98	GS	0 281 002 286
Lateral acceleration sensor, brake system	07.96-12.98		0 265 005 127
Yaw rate sensor, brake system	07.96-12.98		0 265 005 207
Wheel speed sensor, rear			
Fg.no. 8D..W..280 001→	06.98-12.98	ALR,LAB	0 265 006 571
		ALR,RAB	0 265 006 569
		OLW	0 265 006 569
1.9 TDI quattro [8D2; B5]	1,9l 81 kW AVG 4 Zyl.		
Air mass meter, diesel	08.99-01.00		0 281 002 216
			0 986 284 001
Boost pressure sensor, Diesel	08.99-01.00		0 281 002 177
Lateral acceleration sensor, brake system	08.99-01.00		0 265 005 127
Duo sensor, acceleration and yaw rate, brake system	08.99-01.00		0 265 005 214
Yaw rate sensor, brake system	08.99-01.00		0 265 005 207
Wheel speed sensor, rear	08.99-01.00	ALR,LAB	0 265 006 571
		ALR,RAB	0 265 006 569
		OLW	0 265 006 569

Product				

1.9 TDI quattro [8D2; B5]	1,9l 85 kW AJM 4 Zyl.		
Air mass meter, diesel	12.98-12.98		0 281 002 216
			0 986 284 001
Boost pressure sensor, Diesel	12.98-12.98		0 281 002 177
Pedal position sensor, diesel	12.98-12.98	AG	0 281 002 289
		GS	0 281 002 286
Lateral acceleration sensor, brake system	12.98-12.98		0 265 005 127
Yaw rate sensor, brake system	12.98-12.98		0 265 005 207
Wheel speed sensor, rear	12.98-12.98	ALR,LAB	0 265 006 571
		ALR,RAB	0 265 006 569
		OLW	0 265 006 569
1.9 TDI quattro [8D2; B5]	1,9l 85 kW ATJ 4 Zyl.		
Air mass meter, diesel	01.00-10.00		0 281 002 216
			0 986 284 001
Boost pressure sensor, Diesel	01.00-10.00		0 281 002 177
Lateral acceleration sensor, brake system	01.00-10.00		0 265 005 127
Duo sensor, acceleration and yaw rate, brake system	01.00-10.00		0 265 005 214
Yaw rate sensor, brake system	01.00-10.00		0 265 005 207
Wheel speed sensor, rear	01.00-10.00	ALR,LAB	0 265 006 571
		ALR,RAB	0 265 006 569
		OLW	0 265 006 569
1.9 TDI quattro [8E2; B6]	1,9l 96 kW AVF 4 Zyl.		
Air mass meter, diesel	04.01-12.04		0 281 002 461
			0 986 284 007
Boost pressure sensor, Diesel	04.01-12.04		0 281 002 401
Duo sensor, acceleration and yaw rate, brake system	04.01-12.04		0 265 005 252
Pressure sensor, ESP, (electronic stability program)	04.01-12.04		0 265 005 303
Wheel speed sensor, front			
Fg.no. →8E..3..500 000	04.01-05.03		0 265 006 683
Fg.no. 8E..4..000 001→	06.03-12.04		0 265 006 809
Wheel speed sensor, rear			
Fg.no. →8E..4..050 000	04.01-05.04	ALR,LAB	0 265 006 707
Fg.no. →8E..4..400 000	04.01-05.04	ALR,RAB	0 265 006 681
		OLW	0 265 006 681
Fg.no. 8E..5..000 001→	06.04-12.04	ALR,LAB	0 265 006 826
		ALR,RAB	0 265 006 824
		OLW	0 265 006 824
2.0 [8EC; B7]	2,0l 96 kW ALT 4 Zyl.		
Throttle valve assembly	11.04→		0 280 750 088
Air mass meter, gasoline injection	11.04→		0 280 218 058
			0 986 280 215
Phase sensor	11.04→		0 232 101 024
Speed sensor, ignition/injection	11.04→		0 281 002 222
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →8E..5..600 000	11.04-05.05		0 265 005 601
Fg.no. 8E..6..000 001→	06.05→		0 265 005 621
Wheel speed sensor, front	11.04→		0 265 006 809
Wheel speed sensor, rear	11.04→	ALR,RAB	0 265 006 824
		OLW	0 265 006 824
2.0 [8E2; B6]	2,0l 96 kW ALT 4 Zyl.		
Throttle valve assembly	12.00-12.04		0 280 750 088
Air mass meter, gasoline injection	12.00-12.04		0 280 218 058
			0 986 280 215
Phase sensor	12.00-12.04		0 232 101 024
Speed sensor, ignition/injection	12.00-12.04		0 281 002 222
Temperature sensor, intake air, injection system	12.00-12.04		0 280 130 116
Duo sensor, acceleration and yaw rate, brake system	12.00-12.04		0 265 005 252
Pressure sensor, ESP, (electronic stability program)	12.00-12.04		0 265 005 303

Product



Wheel speed sensor, front			
Fg.no. →8E..3..500 000	12.00-05.03		0 265 006 683
Fg.no. 8E..4..000 001→	06.03-12.04		0 265 006 809
Wheel speed sensor, rear			
Fg.no. →8E..4..050 000	12.00-05.04	ALR,LAB	0 265 006 707
Fg.no. →8E..4..400 000	12.00-05.04	ALR,RAB	0 265 006 681
		OLW	0 265 006 681
Fg.no. 8E..5..000 001→	06.04-12.04	ALR,LAB	0 265 006 826
		ALR,RAB	0 265 006 824
		OLW	0 265 006 824
2.0 FSI [8E2; B6]		2,0l 105 kW AWA 4 Zyl.	
Throttle valve assembly	11.01-12.04		0 280 750 134
Air mass meter, gasoline injection	11.01-12.04		0 280 218 058
			0 986 280 215
Speed sensor, ignition/injection	11.01-12.04		0 261 210 145
Duo sensor, acceleration and yaw rate, brake system	11.01-12.04		0 265 005 252
Pressure sensor, ESP, (electronic stability program)	11.01-12.04		0 265 005 303
Wheel speed sensor, front			
Fg.no. →8E..3..500 000	11.01-05.03		0 265 006 683
Fg.no. 8E..4..000 001→	06.03-12.04		0 265 006 809
Wheel speed sensor, rear			
Fg.no. →8E..4..050 000	11.01-05.04	ALR,LAB	0 265 006 707
Fg.no. →8E..4..400 000	11.01-05.04	ALR,RAB	0 265 006 681
		OLW	0 265 006 681
Fg.no. 8E..5..000 001→	06.04-12.04	ALR,LAB	0 265 006 826
		ALR,RAB	0 265 006 824
		OLW	0 265 006 824
2.0 TDI [8EC; B7]		2,0l 89/93 kW BVF; BVG 4 Zyl.	
Air mass meter, diesel	11.05-11.06		0 281 002 461
			0 986 284 007
Boost pressure sensor, Diesel	11.05-11.06		0 281 002 401
Duo sensor, acceleration and yaw rate, brake system	11.05-11.06		0 265 005 621
Wheel speed sensor, front	11.05-11.06		0 265 006 809
Wheel speed sensor, rear	11.05-11.06	ALR,RAB	0 265 006 824
		OLW	0 265 006 824
2.0 TDI [8EC; B7]		2,0l 100 kW BNA 4 Zyl.	
Air mass meter, diesel	11.04-10.05		0 281 002 461
			0 986 284 007
Boost pressure sensor, Diesel	11.04-10.05		0 281 002 401
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →8E..5..600 000	11.04-05.05		0 265 005 601
Fg.no. 8E..6..000 001→	06.05-10.05		0 265 005 621
Wheel speed sensor, front	11.04-10.05		0 265 006 809
Wheel speed sensor, rear	11.04-10.05	ALR,RAB	0 265 006 824
		OLW	0 265 006 824
2.0 TDI [8EC; B7]		2,0l 100 kW BRF 4 Zyl.	
Air mass meter, diesel	11.05→		0 281 002 461
			0 986 284 007
Boost pressure sensor, Diesel	11.05→		0 281 002 401
Duo sensor, acceleration and yaw rate, brake system	11.05→		0 265 005 621
Wheel speed sensor, front	11.05→		0 265 006 809
Wheel speed sensor, rear	11.05→	ALR,RAB	0 265 006 824
		OLW	0 265 006 824
2.0 TDI [8EC; B7]		2,0l 103 kW BLB 4 Zyl.	
Air mass meter, diesel	11.04-05.05		0 281 002 461
			0 986 284 007
Boost pressure sensor, Diesel	11.04-05.05		0 281 002 401
Duo sensor, acceleration and yaw rate, brake system	11.04-05.05		0 265 005 601

Product



Wheel speed sensor, front	11.04-05.05		0 265 006 809
Wheel speed sensor, rear	11.04-05.05	ALR,RAB	0 265 006 824
		OLW	0 265 006 824
2.0 TDI [8EC; B7]		2,0l 103 kW BPW 4 Zyl.	
Air mass meter, diesel	11.04→		0 281 002 461
			0 986 284 007
Boost pressure sensor, Diesel	11.04→		0 281 002 401
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →8E..5..600 000	11.04-05.05		0 265 005 601
Fg.no. 8E..6..000 001→	06.05→		0 265 005 621
Wheel speed sensor, front	11.04→		0 265 006 809
Wheel speed sensor, rear	11.04→	ALR,RAB	0 265 006 824
		OLW	0 265 006 824
2.0 TDI [8EC; B7]		2,0l 103/120/125 kW BRD; BRE; BVA 4 Zyl.	
Air mass meter, diesel	06.05→		0 281 002 461
			0 986 284 007
Boost pressure sensor, Diesel	06.05→		0 281 002 401
Duo sensor, acceleration and yaw rate, brake system	06.05→		0 265 005 621
Wheel speed sensor, front	06.05→		0 265 006 809
Wheel speed sensor, rear	06.05→	ALR,RAB	0 265 006 824
		OLW	0 265 006 824
2.0 TDI quattro [8EC; B7]		2,0l 103/120/125 kW BPW; BRD; BVA 4 Zyl.	
Air mass meter, diesel	01.06→		0 281 002 461
			0 986 284 007
Boost pressure sensor, Diesel	01.06→		0 281 002 401
Duo sensor, acceleration and yaw rate, brake system	01.06→		0 265 005 621
Wheel speed sensor, front	01.06→		0 265 006 809
Wheel speed sensor, rear	01.06→	ALR,RAB	0 265 006 824
		OLW	0 265 006 824
2.0 TFSI [8EC; B7]		2,0l 125 kW BPJ; BYK 4 Zyl.	
Speed sensor, ignition/injection	10.06→		0 261 210 199
Knock sensor	10.06→		0 261 231 146
Boost pressure sensor, gasoline	10.06→		0 261 230 073
Duo sensor, acceleration and yaw rate, brake system	10.06→		0 265 005 621
Wheel speed sensor, front	10.06→		0 265 006 809
Wheel speed sensor, rear	10.06→	ALR,RAB	0 265 006 824
		OLW	0 265 006 824
2.0 TFSI [8EC; B7]		2,0l 147 kW BGB 4 Zyl.	
Speed sensor, ignition/injection	11.04-08.05		0 261 210 199
Knock sensor	11.04-08.05		0 261 231 146
Boost pressure sensor, gasoline	11.04-08.05		0 261 230 073
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →8E..5..600 000	11.04-05.05		0 265 005 601
Fg.no. 8E..6..000 001→	06.05-08.05		0 265 005 621
Wheel speed sensor, front	11.04-08.05		0 265 006 809
Wheel speed sensor, rear	11.04-08.05	ALR,RAB	0 265 006 824
		OLW	0 265 006 824
2.0 TFSI [8EC; B7]		2,0l 147/162 kW BUL; BWE 4 Zyl.	
Speed sensor, ignition/injection	06.05→		0 261 210 199
Knock sensor	06.05→		0 261 231 146
Boost pressure sensor, gasoline	06.05→		0 261 230 073
Duo sensor, acceleration and yaw rate, brake system	06.05→		0 265 005 621
Wheel speed sensor, front	06.05→		0 265 006 809
Wheel speed sensor, rear	06.05→	ALR,RAB	0 265 006 824
		OLW	0 265 006 824



A

Product				
◀ A4				
2.0 TFSI quattro [8EC; B7] 2,0l 147 kW BGB 4 Zyl.				
Speed sensor, ignition/injection	11.04-08.05			0 261 210 199
Knock sensor	11.04-08.05			0 261 231 146
Boost pressure sensor, gasoline	11.04-08.05			0 261 230 073
Duo sensor, acceleration and yaw rate, brake system				
Fg.no. →8E..5..600 000	11.04-05.05			0 265 005 601
Fg.no. 8E..6..000 001→	06.05-08.05			0 265 005 621
Wheel speed sensor, front	11.04-08.05			0 265 006 809
Wheel speed sensor, rear	11.04-08.05	ALR,RAB		0 265 006 824
		OLW		0 265 006 824
2.0 TFSI quattro [8EC; B7] 2,0l 147/162 kW BUL; BWE; BWT 4 Zyl.				
Speed sensor, ignition/injection	06.05→			0 261 210 199
Knock sensor	06.05→			0 261 231 146
Boost pressure sensor, gasoline	06.05→			0 261 230 073
Duo sensor, acceleration and yaw rate, brake system	06.05→			0 265 005 621
Wheel speed sensor, front	06.05→			0 265 006 809
Wheel speed sensor, rear	06.05→	ALR,RAB		0 265 006 824
		OLW		0 265 006 824
2.4 2,4l 125 kW BDV 6 Zyl.				
Throttle valve assembly	04.03-02.07			0 280 750 030
Phase sensor	04.03-02.07			0 232 101 024
Speed sensor, ignition/injection	04.03-02.07			0 261 210 178
Duo sensor, acceleration and yaw rate, brake system	04.03-02.07			0 265 005 252
Pressure sensor, ESP, (electronic stability program)	04.03-02.07			0 265 005 303
Wheel speed sensor, front				
Fg.no. →8E..3..500 000	04.03-05.03			0 265 006 683
Fg.no. 8E..4..000 001→	06.03-02.07			0 265 006 809
Wheel speed sensor, rear				
Fg.no. →8E..4..050 000	04.03-05.04	ALR,LAB		0 265 006 707
2.4 [8D2; B5] 2,4l 120 kW AJG 6 Zyl.				
Throttle valve assembly	08.97-07.98			0 280 750 030
Phase sensor	08.97-07.98			0 232 101 024
Speed sensor, ignition/injection	08.97-07.98			0 261 210 147
Knock sensor	08.97-07.98			0 261 231 036
Temperature sensor, intake air, injection system	08.97-07.98			0 280 130 085
Lateral acceleration sensor, brake system	08.97-07.98			0 265 005 127
Duo sensor, acceleration and yaw rate, brake system	08.97-07.98			0 265 005 214
Yaw rate sensor, brake system	08.97-07.98			0 265 005 207
2.4 [8D2; B5] 2,4l 120 kW AMM 6 Zyl.				
Temperature sensor, intake air, injection system	06.00-10.00			0 280 130 085
Lateral acceleration sensor, brake system	06.00-10.00			0 265 005 127
Duo sensor, acceleration and yaw rate, brake system	06.00-10.00			0 265 005 214
Yaw rate sensor, brake system	06.00-10.00			0 265 005 207
2.4 [8D2; B5] 2,4l 120 kW APZ 6 Zyl.				
Phase sensor	08.98-06.00			0 232 101 024
Speed sensor, ignition/injection	08.98-06.00	AG		0 261 210 147
		GS		0 261 210 178
Knock sensor				
Fg.no. →8D..X..260 000	08.98-04.99			0 261 231 036
Temperature sensor, intake air, injection system	08.98-06.00			0 280 130 085
Lateral acceleration sensor, brake system	08.98-06.00			0 265 005 127
Duo sensor, acceleration and yaw rate, brake system	08.98-06.00			0 265 005 214
Yaw rate sensor, brake system	08.98-06.00			0 265 005 207
2.4 [8D2; B5] 2,4l 121 kW AGA 6 Zyl.				
Phase sensor	08.97-07.98			0 232 101 024
Speed sensor, ignition/injection	08.97-07.98			0 261 210 147
Knock sensor	08.97-07.98			0 261 231 036

Product				
Temperature sensor, intake air, injection system	08.97-07.98			0 280 130 085
Lateral acceleration sensor, brake system	08.97-07.98			0 265 005 127
Duo sensor, acceleration and yaw rate, brake system	08.97-07.98			0 265 005 214
Yaw rate sensor, brake system	08.97-07.98			0 265 005 207
2.4 [8D2; B5] 2,4l 121 kW ALF 6 Zyl.				
Throttle valve assembly	08.97-07.98			0 280 750 030
Phase sensor	08.97-07.98			0 232 101 024
Speed sensor, ignition/injection	08.97-07.98			0 261 210 147
Knock sensor	08.97-07.98			0 261 231 036
Temperature sensor, intake air, injection system	08.97-07.98			0 280 130 085
Lateral acceleration sensor, brake system	08.97-07.98			0 265 005 127
Duo sensor, acceleration and yaw rate, brake system	08.97-07.98			0 265 005 214
Yaw rate sensor, brake system	08.97-07.98			0 265 005 207
2.4 [8D2; B5] 2,4l 121 kW AML 6 Zyl.				
Phase sensor	08.98-10.00			0 232 101 024
Temperature sensor, intake air, injection system	08.98-10.00			0 280 130 085
Lateral acceleration sensor, brake system	08.98-10.00			0 265 005 127
Duo sensor, acceleration and yaw rate, brake system	08.98-10.00			0 265 005 214
Yaw rate sensor, brake system	08.98-10.00			0 265 005 207
2.4 [8D2; B5] 2,4l 121 kW APS; ARJ 6 Zyl.				
Phase sensor	08.98-06.00			0 232 101 024
Speed sensor, ignition/injection	08.98-06.00	AG		0 261 210 147
		GS		0 261 210 178
Knock sensor				
Fg.no. →8D..X..260 000	08.98-04.99			0 261 231 036
Temperature sensor, intake air, injection system	08.98-06.00			0 280 130 085
Lateral acceleration sensor, brake system	08.98-06.00			0 265 005 127
Duo sensor, acceleration and yaw rate, brake system	08.98-06.00			0 265 005 214
Yaw rate sensor, brake system	08.98-06.00			0 265 005 207
2.4 [8E2; B6] 2,4l 120/125 kW AMM; BDV 6 Zyl.				
Throttle valve assembly	04.01-12.04			0 280 750 030
Phase sensor	04.01-12.04			0 232 101 024
Speed sensor, ignition/injection	04.01-12.04			0 261 210 178
Temperature sensor, intake air, injection system	04.01-12.04			0 280 130 116
Duo sensor, acceleration and yaw rate, brake system	04.01-12.04			0 265 005 252
Pressure sensor, ESP, (electronic stability program)	04.01-12.04			0 265 005 303
Wheel speed sensor, front				
Fg.no. →8E..3..500 000	04.01-05.03			0 265 006 683
Fg.no. 8E..4..000 001→	06.03-12.04			0 265 006 809
Wheel speed sensor, rear				
Fg.no. →8E..4..050 000	04.01-05.04	ALR,LAB		0 265 006 707
Fg.no. →8E..4..400 000	04.01-05.04	ALR,RAB		0 265 006 681
		OLW		0 265 006 681
Fg.no. 8E..5..000 001→	06.04-12.04	ALR,LAB		0 265 006 826
		ALR,RAB		0 265 006 824
		OLW		0 265 006 824
2.4 quattro [8D2; B5] 2,4l 120 kW AJG 6 Zyl.				
Throttle valve assembly	08.97-07.98			0 280 750 030
Phase sensor	08.97-07.98			0 232 101 024
Speed sensor, ignition/injection	08.97-07.98			0 261 210 147
Knock sensor	08.97-07.98			0 261 231 036
Temperature sensor, intake air, injection system	08.97-07.98			0 280 130 085
Lateral acceleration sensor, brake system	08.97-07.98			0 265 005 127
Yaw rate sensor, brake system	08.97-07.98			0 265 005 207
Wheel speed sensor, rear				
Fg.no. 8D..W..280 001→	06.98-07.98	ALR,LAB		0 265 006 571
		ALR,RAB		0 265 006 569
		OLW		0 265 006 569





A



Product			
2.4 quattro [8D2; B5]			
Speed sensor, ignition/injection		02.99-06.00	AG 0 261 210 147
			GS 0 261 210 178
Knock sensor			
Fg.no. →8D..X..260 000		02.99-04.99	0 261 231 036
Temperature sensor, intake air, injection system		02.99-06.00	0 280 130 085
Lateral acceleration sensor, brake system		02.99-06.00	0 265 005 127
Duo sensor, acceleration and yaw rate, brake system		02.99-06.00	0 265 005 214
Yaw rate sensor, brake system		02.99-06.00	0 265 005 207
Wheel speed sensor, rear		02.99-06.00	ALR,LAB 0 265 006 571
			ALR,RAB 0 265 006 569
			OLW 0 265 006 569
2.4 quattro [8D2; B5]			
Phase sensor		08.97-07.98	0 232 101 024
Speed sensor, ignition/injection		08.97-07.98	0 261 210 147
Knock sensor		08.97-07.98	0 261 231 036
Temperature sensor, intake air, injection system		08.97-07.98	0 280 130 085
Lateral acceleration sensor, brake system		08.97-07.98	0 265 005 127
Yaw rate sensor, brake system		08.97-07.98	0 265 005 207
Wheel speed sensor, rear		06.98-07.98	ALR,LAB 0 265 006 571
			ALR,RAB 0 265 006 569
			OLW 0 265 006 569
2.4 quattro [8D2; B5]			
Phase sensor		08.98-12.98	0 232 101 024
Temperature sensor, intake air, injection system		08.98-12.98	0 280 130 085
Lateral acceleration sensor, brake system		08.98-12.98	0 265 005 127
Yaw rate sensor, brake system		08.98-12.98	0 265 005 207
Wheel speed sensor, rear		08.98-12.98	ALR,LAB 0 265 006 571
			ALR,RAB 0 265 006 569
			OLW 0 265 006 569
2.4 quattro [8D2; B5]			
Speed sensor, ignition/injection		02.99-10.00	AG 0 261 210 147
			GS 0 261 210 178
Knock sensor			
Fg.no. →8D..X..260 000		02.99-04.99	0 261 231 036
Temperature sensor, intake air, injection system		02.99-10.00	0 280 130 085
Lateral acceleration sensor, brake system		02.99-10.00	0 265 005 127
Duo sensor, acceleration and yaw rate, brake system		02.99-10.00	0 265 005 214
Yaw rate sensor, brake system		02.99-10.00	0 265 005 207
Wheel speed sensor, rear		02.99-10.00	ALR,LAB 0 265 006 571
			ALR,RAB 0 265 006 569
			OLW 0 265 006 569
2.4 quattro [8D2; B5]			
Phase sensor		02.99-06.00	0 232 101 024
Speed sensor, ignition/injection		02.99-06.00	AG 0 261 210 147
			GS 0 261 210 178
Knock sensor			
Fg.no. →8D..X..260 000		02.99-04.99	0 261 231 036
Temperature sensor, intake air, injection system		02.99-06.00	0 280 130 085
Lateral acceleration sensor, brake system		02.99-06.00	0 265 005 127
Duo sensor, acceleration and yaw rate, brake system		02.99-06.00	0 265 005 214
Yaw rate sensor, brake system		02.99-06.00	0 265 005 207
Wheel speed sensor, rear		02.99-06.00	ALR,LAB 0 265 006 571
			ALR,RAB 0 265 006 569
			OLW 0 265 006 569
2.5 TDI [8D2; B5]			
Air mass meter, diesel		08.97-06.00	0 281 002 429
			0 986 284 005
Speed sensor, diesel		08.97-06.00	KZU 0 281 002 222



Boost pressure sensor, Diesel		08.97-06.00	0 281 002 177
Pedal position sensor, diesel			
Fg.no. →8D..W..028 000		08.97-09.97	AG 0 205 001 031
			GS 0 205 001 032
Fg.no. 8D..W..028 001→		09.97-06.00	AG 0 281 002 289
Fg.no. 8D..W..028 001→8D..W..080 000		09.97-11.97	GS 0 281 002 229
Fg.no. 8D..W..080 001→		11.97-06.00	GS 0 281 002 286
Lateral acceleration sensor, brake system		08.97-06.00	0 265 005 127
Duo sensor, acceleration and yaw rate, brake system		08.97-06.00	0 265 005 214
Yaw rate sensor, brake system		08.97-06.00	0 265 005 207
2.5 TDI [8D2; B5]			
Air mass meter, diesel		07.98-06.99	0 281 002 429
			0 986 284 005
Fg.no. 8D..Y..000 001→		07.99-10.00	0 281 002 403
			0 986 284 004
Speed sensor, diesel		07.98-10.00	KZU 0 281 002 222
Boost pressure sensor, Diesel		07.98-10.00	0 281 002 177
Pedal position sensor, diesel		07.98-10.00	AG 0 281 002 289
			GS 0 281 002 286
Lateral acceleration sensor, brake system		07.98-10.00	0 265 005 127
Duo sensor, acceleration and yaw rate, brake system		07.98-10.00	0 265 005 214
Yaw rate sensor, brake system		07.98-10.00	0 265 005 207
2.5 TDI [8EC; B7]			
Speed sensor, diesel		11.04-05.06	0 281 002 222
Boost pressure sensor, Diesel		11.04-05.06	0 281 002 399
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →8E..5..600 000		11.04-05.05	0 265 005 601
Fg.no. 8E..6..000 001→		06.05-05.06	0 265 005 621
Wheel speed sensor, front		11.04-05.06	0 265 006 809
Wheel speed sensor, rear		11.04-05.06	ALR,RAB 0 265 006 824
			OLW 0 265 006 824
2.5 TDI [8E2; B6]			
Speed sensor, diesel		04.01-06.02	0 281 002 222
Boost pressure sensor, Diesel		04.01-06.02	0 281 002 399
Duo sensor, acceleration and yaw rate, brake system		04.01-06.02	0 265 005 252
Pressure sensor, ESP, (electronic stability program)		04.01-06.02	0 265 005 303
Wheel speed sensor, front		04.01-06.02	0 265 006 683
Wheel speed sensor, rear		04.01-06.02	ALR,LAB 0 265 006 707
			ALR,RAB 0 265 006 681
			OLW 0 265 006 681
2.5 TDI [8E2; B6]			
Speed sensor, diesel		06.03-12.04	0 281 002 222
Boost pressure sensor, Diesel		06.03-12.04	0 281 002 399
Duo sensor, acceleration and yaw rate, brake system		06.03-12.04	0 265 005 252
Pressure sensor, ESP, (electronic stability program)		06.03-12.04	0 265 005 303
Wheel speed sensor, front		06.03-12.04	0 265 006 809
Wheel speed sensor, rear			
Fg.no. →8E..4..050 000		06.03-05.04	ALR,LAB 0 265 006 707
Fg.no. →8E..4..400 000		06.03-05.04	ALR,RAB 0 265 006 681
			OLW 0 265 006 681
Fg.no. 8E..5..000 001→		06.04-12.04	ALR,LAB 0 265 006 826
			ALR,RAB 0 265 006 824
			OLW 0 265 006 824
2.5 TDI [8E2; B6]			
Speed sensor, diesel		07.02-05.03	0 281 002 222
Boost pressure sensor, Diesel		07.02-05.03	0 281 002 399

Product				

◀ A4

Duo sensor, acceleration and yaw rate, brake system	07.02-05.03		0 265 005 252
Pressure sensor, ESP, (electronic stability program)	07.02-05.03		0 265 005 303
Wheel speed sensor, front	07.02-05.03		0 265 006 683
Wheel speed sensor, rear	07.02-05.03	ALR,LAB	0 265 006 707
		ALR,RAB	0 265 006 681
		OLW	0 265 006 681

2.5 TDI quattro [8D2; B5]	2,5 l 110 kW AFB 6 Zyl.
Air mass meter, diesel	11.97-06.00
	0 281 002 429
	 0 986 284 005

Speed sensor, diesel	11.97-06.00	KZU	0 281 002 222
Boost pressure sensor, Diesel	11.97-06.00		0 281 002 177
Pedal position sensor, diesel	11.97-06.00	AG	0 281 002 289
		GS	0 281 002 286

Lateral acceleration sensor, brake system	11.97-06.00		0 265 005 127
Duo sensor, acceleration and yaw rate, brake system	11.97-06.00		0 265 005 214
Yaw rate sensor, brake system	11.97-06.00		0 265 005 207

Wheel speed sensor, rear			
Fg.no. 8D..W..280 001→	06.98-06.00	ALR,LAB	0 265 006 571
		ALR,RAB	0 265 006 569
		OLW	0 265 006 569

2.5 TDI quattro [8D2; B5]		2,5 l 110 kW AKN 6 Zyl.
Air mass meter, diesel		
Fg.no. →8D..X..400 000	02.99-06.99	0 281 002 429
		 0 986 284 005
Fg.no. 8D..Y..000 001→	07.99-10.00	0 281 002 403
		 0 986 284 004

Speed sensor, diesel	02.99-10.00	KZU	0 281 002 222
Boost pressure sensor, Diesel	02.99-10.00		0 281 002 177
Pedal position sensor, diesel	02.99-10.00	AG	0 281 002 289
		GS	0 281 002 286

Lateral acceleration sensor, brake system	02.99-10.00		0 265 005 127
Duo sensor, acceleration and yaw rate, brake system	02.99-10.00		0 265 005 214
Yaw rate sensor, brake system	02.99-10.00		0 265 005 207

Wheel speed sensor, rear	02.99-10.00	ALR,LAB	0 265 006 571
		ALR,RAB	0 265 006 569
		OLW	0 265 006 569

2.5 TDI quattro [8E2; B6]		2,5 l 132 kW AKE 6 Zyl.
Speed sensor, diesel	12.00-05.03	0 281 002 222
Boost pressure sensor, Diesel	12.00-05.03	0 281 002 399
Duo sensor, acceleration and yaw rate, brake system	12.00-05.03	0 265 005 252
Pressure sensor, ESP, (electronic stability program)	12.00-05.03	0 265 005 303
Wheel speed sensor, front	12.00-05.03	0 265 006 683
Wheel speed sensor, rear	12.00-05.03	ALR,LAB 0 265 006 707
		ALR,RAB 0 265 006 681
		OLW 0 265 006 681

2.5 TDI quattro [8E2; B6]	2,5 l 132 kW BAU; BDH 6 Zyl.		
Speed sensor, diesel	11.02-12.04		0 281 002 222
Boost pressure sensor, Diesel	11.02-12.04		0 281 002 399
Duo sensor, acceleration and yaw rate, brake system	11.02-12.04		0 265 005 252
Pressure sensor, ESP, (electronic stability program)	11.02-12.04		0 265 005 303
Wheel speed sensor, front			
Fg.no. →8E..3..500 000	11.02-05.03		0 265 006 683
Fg.no. 8E..4..000 001→	06.03-12.04		0 265 006 809
Wheel speed sensor, rear			
Fg.no. →8E..4..050 000	11.02-05.04	ALR,LAB	0 265 006 707
Fg.no. →8E..4..400 000	11.02-05.04	ALR,RAB	0 265 006 681
		OLW	0 265 006 681

Product				

Wheel speed sensor, rear			
Fg.no. 8E..5..000 001→	06.04-12.04	ALR,LAB	0 265 006 826
		ALR,RAB	0 265 006 824
		OLW	0 265 006 824

2.6 [8D2; B5]	2,6l 102/110 kW	ABC; ACZ	6 Zyl.
Throttle valve sensor	11.94-07.98	0 280 120 431	
Phase sensor	11.94-07.98	0 232 101 027	
Knock sensor	11.94-07.98	0 261 231 036	
Lateral acceleration sensor, brake system	11.94-07.98	0 265 005 127	
Duo sensor, acceleration and yaw rate, brake system	11.94-07.98	0 265 005 214	

Yaw rate sensor, brake system	11.94-07.98	0 265 005 207
2.6 quattro [8D2; B5]	2,6 l 102 kW ACZ 6 Zyl.	
Throttle valve sensor	04.95-07.97	0 280 120 431
Phase sensor	04.95-07.97	0 232 101 027
Knock sensor	04.95-07.97	0 261 231 036
Lateral acceleration sensor, brake system	04.95-07.97	0 265 005 127
Yaw rate sensor, brake system	04.95-07.97	0 265 005 207

2.6 quattro [8D2; B5]		2,6l 110 kW ABC 6 Zyl.	
Throttle valve sensor	11.94-07.98	0 280 120 431	
Phase sensor	11.94-07.98	0 232 101 027	
Knock sensor	11.94-07.98	0 261 231 036	
Lateral acceleration sensor, brake system	11.94-07.98	0 265 005 127	
Yaw rate sensor, brake system	11.94-07.98	0 265 005 207	
Wheel speed sensor, rear			
Fg.no. 8D..W..280 001→	06.98-07.98	ALR,LAB	0 265 006 571
		ALR,RAB	0 265 006 569
		OLW	0 265 006 569

2.7 T quattro [8D2; B5]		2,7 l 195 kW AGB 6 Zyl.
Throttle valve assembly	02.99-10.00	0 280 750 003

Air mass meter, gasoline injection			
Fg.no. →8D..Y..300 000	02.99-06.00		0 280 218 038
			0 986 280 212
Phase sensor	02.99-10.00		0 232 101 024
Speed sensor, ignition/injection	02.99-10.00		0 261 210 147

Knock sensor			
Fg.no. →8D..X..260 000	02.99-04.99		0 261 231 036
Pedal position sensor, EMS (electronic engine management)	02.99-10.00		0 280 752 020

Lateral acceleration sensor, brake system	02.99-10.00		0 265 005 127
Duo sensor, acceleration and yaw rate, brake system	02.99-10.00		0 265 005 214

Yaw rate sensor, brake system	02.99-10.00		0 265 005 207
Wheel speed sensor, rear	02.99-10.00	ALR,LAB	0 265 006 571
		ALR,RAB	0 265 006 569
		OLW	0 265 006 569

2.7 TDI [8EC; B7]	2,7 l 120/132 kW BPP; BSG 6 Zyl.		
Speed sensor, diesel	11.05→	FKW	0 261 210 145

High-pressure sensor (CR system)			
Fg.no. →8E..6..111 000, →8E..6..802 000	11.05-08.06		0 281 002 504
Boost pressure sensor, Diesel	11.05→		0 281 002 401
Duo sensor, acceleration and yaw rate, brake system	11.05→		0 265 005 621

Wheel speed sensor, front	11.05→		0 265 006 809
Wheel speed sensor, rear	11.05→	ALR,RAB	0 265 006 824
		OLW	0 265 006 824

2.8 [8D2; B5]	2,8 l 120 kW AFC 6 Zyl.
Phase sensor	11.94-06.95 0 232 101 024
Knock sensor	11.94-06.95 0 261 231 036
Lateral acceleration sensor, brake system	11.94-06.95 0 265 005 127
Duo sensor, acceleration and yaw rate, brake system	11.94-06.95 0 265 005 214
Yaw rate sensor, brake system	11.94-06.95 0 265 005 207



2.8 [8D2; B5]			2,8l 128 kW AAH 6 Zyl.
Throttle valve sensor	11.94-07.97		0 280 120 431
Phase sensor	11.94-07.97		0 232 101 027
Knock sensor	11.94-07.97		0 261 231 036
Lateral acceleration sensor, brake system	11.94-07.97		0 265 005 127
Duo sensor, acceleration and yaw rate, brake system	11.94-07.97		0 265 005 214
Yaw rate sensor, brake system	11.94-07.97		0 265 005 207
2.8 [8D2; B5]			2,8l 140 kW ATX 6 Zyl.
Temperature sensor, intake air, injection system	03.99-10.00		0 280 130 085
Lateral acceleration sensor, brake system	03.99-10.00		0 265 005 127
Duo sensor, acceleration and yaw rate, brake system	03.99-10.00		0 265 005 214
Yaw rate sensor, brake system	03.99-10.00		0 265 005 207
2.8 [8D2; B5]			2,8l 142 kW ACK 6 Zyl.
Throttle valve assembly	03.96-12.98		0 280 750 030
Speed sensor, ignition/injection	03.96-07.97		0 261 210 134
	08.97-12.98		0 261 210 147
Knock sensor	03.96-12.98		0 261 231 036
Temperature sensor, intake air, injection system	03.96-12.98		0 280 130 085
Lateral acceleration sensor, brake system	03.96-12.98		0 265 005 127
Duo sensor, acceleration and yaw rate, brake system	03.96-12.98		0 265 005 214
Yaw rate sensor, brake system	03.96-12.98		0 265 005 207
2.8 [8D2; B5]			2,8l 142 kW AHA 6 Zyl.
Phase sensor	10.96-08.99		0 232 101 024
Speed sensor, ignition/injection	10.96-08.99	AG	0 261 210 147
		GS	0 261 210 134
Knock sensor			
Fg.no. →8D..X..260 000	10.96-04.99		0 261 231 036
Temperature sensor, intake air, injection system	10.96-08.99		0 280 130 085
2.8 [8D2; B5]			2,8l 142 kW ALG 6 Zyl.
Phase sensor	08.97-07.98		0 232 101 024
Speed sensor, ignition/injection	08.97-07.98		0 261 210 147
Knock sensor	08.97-07.98		0 261 231 036
Temperature sensor, intake air, injection system	08.97-07.98		0 280 130 085
Lateral acceleration sensor, brake system	08.97-07.98		0 265 005 127
Duo sensor, acceleration and yaw rate, brake system	08.97-07.98		0 265 005 214
Yaw rate sensor, brake system	08.97-07.98		0 265 005 207
2.8 [8D2; B5]			2,8l 142 kW AMX 6 Zyl.
Phase sensor	08.98-12.98		0 232 101 024
Speed sensor, ignition/injection	08.98-12.98	AG	0 261 210 147
		GS	0 261 210 178
Lateral acceleration sensor, brake system	08.98-12.98		0 265 005 127
Duo sensor, acceleration and yaw rate, brake system	08.98-12.98		0 265 005 214
Yaw rate sensor, brake system	08.98-12.98		0 265 005 207
2.8 [8D2; B5]			2,8l 142 kW APR; AQD 6 Zyl.
Phase sensor	08.98-06.00		0 232 101 024
Speed sensor, ignition/injection	08.98-06.00	AG	0 261 210 147
		GS	0 261 210 178
Knock sensor			
Fg.no. →8D..X..260 000	08.98-04.99		0 261 231 036
Temperature sensor, intake air, injection system	08.98-06.00		0 280 130 085
Lateral acceleration sensor, brake system	08.98-06.00		0 265 005 127
Duo sensor, acceleration and yaw rate, brake system	08.98-06.00		0 265 005 214
Yaw rate sensor, brake system	08.98-06.00		0 265 005 207
2.8 quattro [8D2; B5]			2,8l 128 kW AAH 6 Zyl.
Throttle valve sensor	11.94-12.96		0 280 120 431
Phase sensor	11.94-12.96		0 232 101 027
Knock sensor	11.94-12.96		0 261 231 036



Lateral acceleration sensor, brake system	11.94-12.96		0 265 005 127
Yaw rate sensor, brake system	11.94-12.96		0 265 005 207
2.8 quattro [8D2; B5]			2,8l 128 kW AFC 6 Zyl.
Phase sensor	08.95-04.97		0 232 101 027
Knock sensor	08.95-04.97		0 261 231 036
2.8 quattro [8D2; B5]			2,8l 140 kW ATX 6 Zyl.
Temperature sensor, intake air, injection system	09.99-10.00		0 280 130 085
Lateral acceleration sensor, brake system	09.99-10.00		0 265 005 127
Duo sensor, acceleration and yaw rate, brake system	09.99-10.00		0 265 005 214
Yaw rate sensor, brake system	09.99-10.00		0 265 005 207
Wheel speed sensor, rear	09.99-10.00	ALR,LAB	0 265 006 571
		ALR,RAB	0 265 006 569
		OLW	0 265 006 569
2.8 quattro [8D2; B5]			2,8l 142 kW ACK 6 Zyl.
Throttle valve assembly	03.96-07.98		0 280 750 030
Phase sensor	03.96-07.98		0 232 101 024
Speed sensor, ignition/injection	03.96-07.97		0 261 210 134
	08.97-07.98		0 261 210 147
Knock sensor	03.96-07.98		0 261 231 036
Temperature sensor, intake air, injection system	03.96-07.98		0 280 130 085
Lateral acceleration sensor, brake system	03.96-07.98		0 265 005 127
Yaw rate sensor, brake system	03.96-07.98		0 265 005 207
Wheel speed sensor, rear			
Fg.no. 8D..W..280 001→	06.98-07.98	ALR,LAB	0 265 006 571
		ALR,RAB	0 265 006 569
		OLW	0 265 006 569
2.8 quattro [8D2; B5]			2,8l 142 kW ALG 6 Zyl.
Phase sensor	05.97-07.98		0 232 101 024
Speed sensor, ignition/injection	05.97-07.98		0 261 210 147
Temperature sensor, intake air, injection system	05.97-07.98		0 280 130 085
Lateral acceleration sensor, brake system	05.97-07.98		0 265 005 127
Yaw rate sensor, brake system	05.97-07.98		0 265 005 207
Wheel speed sensor, rear			
Fg.no. 8D..W..280 001→	06.98-07.98	ALR,LAB	0 265 006 571
		ALR,RAB	0 265 006 569
		OLW	0 265 006 569
2.8 quattro [8D2; B5]			2,8l 142 kW AMX 6 Zyl.
Phase sensor	07.99-10.00		0 232 101 024
Speed sensor, ignition/injection	07.99-10.00	AG	0 261 210 147
		GS	0 261 210 178
Lateral acceleration sensor, brake system	07.99-10.00		0 265 005 127
Duo sensor, acceleration and yaw rate, brake system	07.99-10.00		0 265 005 214
Yaw rate sensor, brake system	07.99-10.00		0 265 005 207
Wheel speed sensor, rear	07.99-10.00	ALR,LAB	0 265 006 571
		ALR,RAB	0 265 006 569
		OLW	0 265 006 569
2.8 quattro [8D2; B5]			2,8l 142 kW APR; AQD 6 Zyl.
Phase sensor	02.99-06.00		0 232 101 024
Speed sensor, ignition/injection	02.99-06.00	AG	0 261 210 147
		GS	0 261 210 178
Knock sensor			
Fg.no. →8D..X..260 000	02.99-04.99		0 261 231 036
Temperature sensor, intake air, injection system	02.99-06.00		0 280 130 085
Lateral acceleration sensor, brake system	02.99-06.00		0 265 005 127
Duo sensor, acceleration and yaw rate, brake system	02.99-06.00		0 265 005 214
Yaw rate sensor, brake system	02.99-06.00		0 265 005 207
Wheel speed sensor, rear	02.99-06.00	ALR,LAB	0 265 006 571
		ALR,RAB	0 265 006 569
		OLW	0 265 006 569



A



Product

◀ A4

3.0 [8EC; B7]		3,0l 160 kW BBJ 6 Zyl.	
Throttle valve assembly	11.04-05.06		0 280 750 030
Speed sensor, ignition/injection	11.04-05.06	AG	0 261 210 147
		GS	0 261 210 178
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →8E..5..600 000	11.04-05.05		0 265 005 601
Fg.no. 8E..6..000 001→	06.05-05.06		0 265 005 621
Wheel speed sensor, front	11.04-05.06		0 265 006 809
Wheel speed sensor, rear	11.04-05.06	ALR,RAB	0 265 006 824
		OLW	0 265 006 824
3.0 [8E2; B6]		3,0l 160/162 kW ASN; BBJ 6 Zyl.	
Throttle valve assembly	12.00-12.04		0 280 750 030
Speed sensor, ignition/injection	12.00-12.04	AG	0 261 210 147
		GS	0 261 210 178
Duo sensor, acceleration and yaw rate, brake system	12.00-12.04		0 265 005 252
Pressure sensor, ESP, (electronic stability program)	12.00-12.04		0 265 005 303
Wheel speed sensor, front			
Fg.no. →8E..3..500 000	12.00-05.03		0 265 006 683
Fg.no. 8E..4..000 001→	06.03-12.04		0 265 006 809
Wheel speed sensor, rear			
Fg.no. →8E..4..050 000	12.00-05.04	ALR,LAB	0 265 006 707
Fg.no. →8E..4..400 000	12.00-05.04	ALR,RAB	0 265 006 681
		OLW	0 265 006 681
Fg.no. 8E..5..000 001→	06.04-12.04	ALR,LAB	0 265 006 826
		ALR,RAB	0 265 006 824
		OLW	0 265 006 824
3.0 [8E2; B6]		3,0l 162 kW AVK 6 Zyl.	
Throttle valve assembly	09.01-06.02		0 280 750 030
Speed sensor, ignition/injection	09.01-06.02	AG	0 261 210 147
		GS	0 261 210 178
Duo sensor, acceleration and yaw rate, brake system	09.01-06.02		0 265 005 252
Pressure sensor, ESP, (electronic stability program)	09.01-06.02		0 265 005 303
Wheel speed sensor, front	09.01-06.02		0 265 006 683
Wheel speed sensor, rear	09.01-06.02	ALR,LAB	0 265 006 707
		ALR,RAB	0 265 006 681
		OLW	0 265 006 681
3.0 quattro		3,0l 160 kW BBJ 6 Zyl.	
Speed sensor, ignition/injection	04.03→		0 261 210 147
Duo sensor, acceleration and yaw rate, brake system	04.03→		0 265 005 252
Pressure sensor, ESP, (electronic stability program)	04.03→		0 265 005 303
Wheel speed sensor, front			
Fg.no. →8E..3..500 000	04.03-05.03		0 265 006 683
Fg.no. 8E..4..000 001→	06.03→		0 265 006 809
Wheel speed sensor, rear	04.03→		0 265 006 681
3.0 quattro [8EC; B7]		3,0l 160 kW BBJ 6 Zyl.	
Throttle valve assembly	11.04-05.06		0 280 750 030
Speed sensor, ignition/injection	11.04-05.06	AG	0 261 210 147
		GS	0 261 210 178
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →8E..5..600 000	11.04-05.05		0 265 005 601
Fg.no. 8E..6..000 001→	06.05-05.06		0 265 005 621
Wheel speed sensor, front	11.04-05.06		0 265 006 809
Wheel speed sensor, rear	11.04-05.06	ALR,RAB	0 265 006 824
		OLW	0 265 006 824
3.0 quattro [8E2; B6]		3,0l 160/162 kW ASN; BBJ 6 Zyl.	
Throttle valve assembly	12.00-12.04		0 280 750 030
Speed sensor, ignition/injection	12.00-12.04	AG	0 261 210 147
		GS	0 261 210 178

Product

Duo sensor, acceleration and yaw rate, brake system	12.00-12.04		0 265 005 252
Pressure sensor, ESP, (electronic stability program)	12.00-12.04		0 265 005 303
Wheel speed sensor, front			
Fg.no. →8E..3..500 000	12.00-05.03		0 265 006 683
Fg.no. 8E..4..000 001→	06.03-12.04		0 265 006 809
Wheel speed sensor, rear			
Fg.no. →8E..4..050 000	12.00-05.04	ALR,LAB	0 265 006 707
Fg.no. →8E..4..400 000	12.00-05.04	ALR,RAB	0 265 006 681
		OLW	0 265 006 681
Fg.no. 8E..5..000 001→	06.04-12.04	ALR,LAB	0 265 006 826
		ALR,RAB	0 265 006 824
		OLW	0 265 006 824
3.0 quattro [8E2; B6]		3,0l 162 kW	AVK 6 Zyl.
Throttle valve assembly	09.01-06.02		0 280 750 030
Speed sensor, ignition/injection	09.01-06.02	AG	0 261 210 147
		GS	0 261 210 178
Duo sensor, acceleration and yaw rate, brake system	09.01-06.02		0 265 005 252
Pressure sensor, ESP, (electronic stability program)	09.01-06.02		0 265 005 303
Wheel speed sensor, front	09.01-06.02		0 265 006 683
Wheel speed sensor, rear	09.01-06.02	ALR,LAB	0 265 006 707
		ALR,RAB	0 265 006 681
		OLW	0 265 006 681
3.0 TDI quattro [8EC; B7]		3,0l 150 kW	BKN 6 Zyl.
Speed sensor, diesel	01.05-05.06	FKW	0 261 210 145
High-pressure sensor (CR system)			
Fg.no. →8E..6..184 000,→8E..6..800 880	01.05-07.05		0 281 002 504
Boost pressure sensor, Diesel	01.05-05.06		0 281 002 401
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →8E..5..600 000	01.05-05.05		0 265 005 601
Fg.no. 8E..6..000 001→	06.05-05.06		0 265 005 621
Wheel speed sensor, front	01.05-05.06		0 265 006 809
Wheel speed sensor, rear	01.05-05.06	ALR,RAB	0 265 006 824
		OLW	0 265 006 824
3.0 TDI quattro [8EC; B7]		3,0l 171 kW	ASB 6 Zyl.
Speed sensor, diesel	01.06→	FKW	0 261 210 145
Boost pressure sensor, Diesel	01.06→		0 281 002 401
Duo sensor, acceleration and yaw rate, brake system	01.06→		0 265 005 621
Wheel speed sensor, front	01.06→		0 265 006 809
Wheel speed sensor, rear	01.06→	ALR,RAB	0 265 006 824
		OLW	0 265 006 824
3.2 FSI, FSI quattro [8EC; B7]		3,2l 188 kW	AUK 6 Zyl.
Throttle valve assembly	01.05→		0 280 750 003
Pressure sensor, intake manifold, gasoline	01.05→		0 261 230 095
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →8E..5..600 000	01.05-05.05		0 265 005 601
Fg.no. 8E..6..000 001→	06.05→		0 265 005 621
Wheel speed sensor, front	01.05→		0 265 006 809
Wheel speed sensor, rear	01.05→	ALR,RAB	0 265 006 824
		OLW	0 265 006 824
A4 Avant			
1.6 [8D5; B5]		1,6l 74 kW	ADP 4 Zyl.
Knock sensor	11.94-10.96		0 261 231 038
Temperature sensor, intake air, injection system	11.94-10.96		0 280 130 085
Lateral acceleration sensor, brake system	11.94-10.96		0 265 005 127
Duo sensor, acceleration and yaw rate, brake system	11.94-10.96		0 265 005 214
Yaw rate sensor, brake system	11.94-10.96		0 265 005 207

Product



1.6 [8D5; B5]	1,6l 74 kW AHL 4 Zyl.
Phase sensor	10.96-07.99 0 232 101 031
Speed sensor, ignition/injection	10.96-07.99 0 261 210 147
Knock sensor	10.96-07.99 0 261 231 038
Temperature sensor, intake air, injection system	10.96-07.99 0 280 130 085
Lateral acceleration sensor, brake system	10.96-07.99 0 265 005 127
Duo sensor, acceleration and yaw rate, brake system	10.96-07.99 0 265 005 214
Yaw rate sensor, brake system	10.96-07.99 0 265 005 207
1.6 [8D5; B5]	1,6l 74 kW ANA; ARM 4 Zyl.
Phase sensor	08.98-10.00 0 232 101 031
Speed sensor, ignition/injection	08.98-10.00 0 261 210 147
Knock sensor	08.98-10.00 0 261 231 038
Lateral acceleration sensor, brake system	08.98-10.00 0 265 005 127
Duo sensor, acceleration and yaw rate, brake system	08.98-10.00 0 265 005 214
Yaw rate sensor, brake system	08.98-10.00 0 265 005 207
1.6 [8D5; B5]	1,6l 75 kW ALZ 4 Zyl.
Phase sensor	06.00-09.01 0 232 101 038
Lateral acceleration sensor, brake system	06.00-09.01 0 265 005 127
Duo sensor, acceleration and yaw rate, brake system	06.00-09.01 0 265 005 214
Yaw rate sensor, brake system	06.00-09.01 0 265 005 207
Pressure sensor, ESP, (electronic stability program)	06.00-09.01 0 265 005 303
1.6 [8ED; B7]	1,6l 75 kW ALZ 4 Zyl.
Speed sensor, ignition/injection	11.04→ 0 281 002 222
Duo sensor, acceleration and yaw rate, brake system	
Fg.no. →8E..5..600 000	11.04-05.05 0 265 005 601
Fg.no. 8E..6..000 001→	06.05→ 0 265 005 621
Wheel speed sensor, front	11.04→ 0 265 006 809
Wheel speed sensor, rear	11.04→ ALR,RAB 0 265 006 824
	OLW 0 265 006 824
1.6 [8E5; B6]	1,6l 75 kW ALZ 4 Zyl.
Speed sensor, ignition/injection	09.01-12.04 0 281 002 222
Duo sensor, acceleration and yaw rate, brake system	09.01-12.04 0 265 005 252
Pressure sensor, ESP, (electronic stability program)	09.01-12.04 0 265 005 303
Wheel speed sensor, front	
Fg.no. →8E..3..500 000	09.01-05.03 0 265 006 683
Fg.no. 8E..4..000 001→	06.03-12.04 0 265 006 809
Wheel speed sensor, rear	
Fg.no. →8E..4..050 000	09.01-05.04 ALR,LAB 0 265 006 707
Fg.no. →8E..4..400 000	09.01-05.04 ALR,RAB 0 265 006 681
	OLW 0 265 006 681
Fg.no. 8E..5..000 001→	06.04-12.04 ALR,LAB 0 265 006 826
	ALR,RAB 0 265 006 824
	OLW 0 265 006 824
1.8 [8D5; B5]	1,8l 85 kW AFY 4 Zyl.
Phase sensor	07.95-12.98 0 232 101 024
Knock sensor	07.95-12.98 KZB 0 261 231 036
	KZG 0 261 231 038
Temperature sensor, intake air, injection system	07.95-12.98 0 280 130 085
Lateral acceleration sensor, brake system	07.95-12.98 0 265 005 127
Duo sensor, acceleration and yaw rate, brake system	07.95-12.98 0 265 005 214
Yaw rate sensor, brake system	07.95-12.98 0 265 005 207
1.8 [8D5; B5]	1,8l 92 kW ADR 4 Zyl.
Air mass meter, gasoline injection	
Fg.no. 8D-X 200 001→	01.99-04.99 0 280 218 013
	☛ 0 986 280 206
Phase sensor	11.94-04.99 0 232 101 024

Product



Knock sensor	11.94-04.99 KZB 0 261 231 036
	KZG 0 261 231 038
Temperature sensor, intake air, injection system	11.94-04.99 0 280 130 085
Lateral acceleration sensor, brake system	11.94-04.99 0 265 005 127
Duo sensor, acceleration and yaw rate, brake system	11.94-04.99 0 265 005 214
Yaw rate sensor, brake system	11.94-04.99 0 265 005 207
1.8 [8D5; B5]	1,8l 92 kW APT 4 Zyl.
Throttle valve assembly	04.99-07.99 0 280 750 080
Air mass meter, gasoline injection	04.99-07.99 0 280 218 013
	☛ 0 986 280 206
Phase sensor	04.99-07.99 0 232 101 024
Knock sensor	04.99-07.99 KZB 0 261 231 036
	KZG 0 261 231 038
Temperature sensor, intake air, injection system	04.99-07.99 0 280 130 085
Lateral acceleration sensor, brake system	04.99-07.99 0 265 005 127
Duo sensor, acceleration and yaw rate, brake system	04.99-07.99 0 265 005 214
Yaw rate sensor, brake system	04.99-07.99 0 265 005 207
1.8 [8D5; B5]	1,8l 92 kW ARG 4 Zyl.
Throttle valve assembly	
Fg.no. 8D-X 250 001→	03.99-07.99 0 280 750 080
Air mass meter, gasoline injection	08.98-07.99 0 280 218 013
	☛ 0 986 280 206
Phase sensor	08.98-07.99 0 232 101 024
Knock sensor	08.98-07.99 KZB 0 261 231 036
	KZG 0 261 231 038
Temperature sensor, intake air, injection system	08.98-07.99 0 280 130 085
Lateral acceleration sensor, brake system	08.98-07.99 0 265 005 127
Duo sensor, acceleration and yaw rate, brake system	08.98-07.99 0 265 005 214
Yaw rate sensor, brake system	08.98-07.99 0 265 005 207
1.8 [8D5; B5]	1,8l 92 kW AVV 4 Zyl.
Throttle valve assembly	06.00-09.01 0 280 750 080
Air mass meter, gasoline injection	06.00-09.01 0 280 218 013
	☛ 0 986 280 206
Temperature sensor, intake air, injection system	06.00-09.01 0 280 130 085
Lateral acceleration sensor, brake system	06.00-09.01 0 265 005 127
Duo sensor, acceleration and yaw rate, brake system	06.00-09.01 0 265 005 214
Yaw rate sensor, brake system	06.00-09.01 0 265 005 207
Pressure sensor, ESP, (electronic stability program)	06.00-09.01 0 265 005 303
1.8 quattro [8D5; B5]	1,8l 85 kW AFY 4 Zyl.
Phase sensor	07.95-09.01 0 232 101 024
Knock sensor	07.95-09.01 KZB 0 261 231 036
	KZG 0 261 231 038
Temperature sensor, intake air, injection system	07.95-09.01 0 280 130 085
Lateral acceleration sensor, brake system	07.95-09.01 0 265 005 127
Duo sensor, acceleration and yaw rate, brake system	07.95-09.01 0 265 005 214
Yaw rate sensor, brake system	07.95-09.01 0 265 005 207
Pressure sensor, ESP, (electronic stability program)	07.95-09.01 0 265 005 303
Wheel speed sensor, rear	
Fg.no. 8D..W..280 001→	06.98-09.01 ALR,LAB 0 265 006 571
	ALR,RAB 0 265 006 569
	OLW 0 265 006 569
1.8 quattro [8D5; B5]	1,8l 92 kW ADR 4 Zyl.
Air mass meter, gasoline injection	
Fg.no. 8D..X..200 001→	02.99-04.99 0 280 218 013
	☛ 0 986 280 206
Phase sensor	11.94-04.99 0 232 101 024
Knock sensor	11.94-04.99 KZB 0 261 231 036
	KZG 0 261 231 038



A

Product				

◀ A4 Avant

Temperature sensor, intake air, injection system	11.94-04.99		0 280 130 085
Lateral acceleration sensor, brake system	11.94-04.99		0 265 005 127
Duo sensor, acceleration and yaw rate, brake system	11.94-04.99		0 265 005 214
Yaw rate sensor, brake system	11.94-04.99		0 265 005 207
Wheel speed sensor, rear			
Fg.no. 8D..W..280 001→	06.98-04.99	ALR,LAB	0 265 006 571
		ALR,RAB	0 265 006 569
		OLW	0 265 006 569
1.8 quattro [8D5; B5]		1,8l 92 kW APT 4 Zyl.	
Air mass meter, gasoline injection	04.99-09.01		0 280 218 013
			0 986 280 206
Phase sensor	04.99-09.01		0 232 101 024
Knock sensor	04.99-09.01	KZB	0 261 231 036
		KZG	0 261 231 038
Temperature sensor, intake air, injection system	04.99-09.01		0 280 130 085
Lateral acceleration sensor, brake system	04.99-09.01		0 265 005 127
Duo sensor, acceleration and yaw rate, brake system	04.99-09.01		0 265 005 214
Yaw rate sensor, brake system	04.99-09.01		0 265 005 207
Pressure sensor, ESP, (electronic stability program)	04.99-09.01		0 265 005 303
Wheel speed sensor, rear	04.99-09.01	ALR,LAB	0 265 006 571
		ALR,RAB	0 265 006 569
		OLW	0 265 006 569
1.8 quattro [8D5; B5]		1,8l 92 kW ARG 4 Zyl.	
Air mass meter, gasoline injection	08.98-06.00		0 280 218 013
			0 986 280 206
Phase sensor	08.98-06.00		0 232 101 024
Knock sensor	08.98-06.00	KZB	0 261 231 036
		KZG	0 261 231 038
Temperature sensor, intake air, injection system	08.98-06.00		0 280 130 085
Lateral acceleration sensor, brake system	08.98-06.00		0 265 005 127
Duo sensor, acceleration and yaw rate, brake system	08.98-06.00		0 265 005 214
Yaw rate sensor, brake system	08.98-06.00		0 265 005 207
Wheel speed sensor, rear	08.98-06.00	ALR,LAB	0 265 006 571
		ALR,RAB	0 265 006 569
		OLW	0 265 006 569
1.8 T [8D5; B5]		1,8l 110 kW AEB 4 Zyl.	
Air mass meter, gasoline injection	10.95-07.98		0 280 217 112
Phase sensor	10.95-07.98		0 232 101 024
Knock sensor	10.95-07.98	KZB	0 261 231 036
		KZG	0 261 231 038
Temperature sensor, intake air, injection system	10.95-07.98		0 280 130 085
Lateral acceleration sensor, brake system	10.95-07.98		0 265 005 127
Duo sensor, acceleration and yaw rate, brake system	10.95-07.98		0 265 005 214
Yaw rate sensor, brake system	10.95-07.98		0 265 005 207
1.8 T [8D5; B5]		1,8l 110 kW ANB 4 Zyl.	
Air mass meter, gasoline injection	05.99-07.99		0 280 218 032
			0 986 280 210
Phase sensor	05.99-07.99		0 232 101 024
Knock sensor	05.99-07.99	KZB	0 261 231 036
		KZG	0 261 231 038
Boost pressure sensor, gasoline	05.99-07.99		0 281 002 177
Temperature sensor, intake air, injection system	05.99-07.99		0 280 130 085
Lateral acceleration sensor, brake system	05.99-07.99		0 265 005 127
Duo sensor, acceleration and yaw rate, brake system	05.99-07.99		0 265 005 214
Yaw rate sensor, brake system	05.99-07.99		0 265 005 207
1.8 T [8D5; B5]		1,8l 110 kW APU 4 Zyl.	
Air mass meter, gasoline injection	08.98-09.01		0 280 218 032
			0 986 280 210

Product				

Phase sensor	08.98-09.01		0 232 101 024
Knock sensor	08.98-09.01	KZB	0 261 231 036
		KZG	0 261 231 038
Boost pressure sensor, gasoline	08.98-09.01		0 281 002 177
Temperature sensor, intake air, injection system	08.98-09.01		0 280 130 085
Lateral acceleration sensor, brake system	08.98-09.01		0 265 005 127
Duo sensor, acceleration and yaw rate, brake system	08.98-09.01		0 265 005 214
Yaw rate sensor, brake system	08.98-09.01		0 265 005 207
Pressure sensor, ESP, (electronic stability program)	08.98-09.01		0 265 005 303
1.8 T [8D5; B5]		1,8l 110 kW ATW 4 Zyl.	
Throttle valve assembly	08.99-05.00		0 280 750 009
Air mass meter, gasoline injection	08.99-05.00		0 280 218 002
			0 986 280 205
Knock sensor	08.99-05.00	KZB	0 261 231 036
		KZG	0 261 231 038
Boost pressure sensor, gasoline	08.99-05.00		0 281 002 177
Temperature sensor, intake air, injection system	08.99-05.00		0 280 130 085
1.8 T [8D5; B5]		1,8l 110 kW AWT 4 Zyl.	
Air mass meter, gasoline injection	06.00-09.01		0 280 218 063
			0 986 280 217
Phase sensor	06.00-09.01		0 232 101 024
Speed sensor, ignition/injection	06.00-09.01		0 281 002 222
Boost pressure sensor, gasoline	06.00-09.01		0 281 002 177
Temperature sensor, intake air, injection system	06.00-09.01		0 280 130 085
Lateral acceleration sensor, brake system	06.00-09.01		0 265 005 127
Duo sensor, acceleration and yaw rate, brake system	06.00-09.01		0 265 005 214
Yaw rate sensor, brake system	06.00-09.01		0 265 005 207
Pressure sensor, ESP, (electronic stability program)	06.00-09.01		0 265 005 303
1.8 T [8D5; B5]		1,8l 132 kW AJL 4 Zyl.	
Air mass meter, gasoline injection	08.97-09.01		0 280 217 117
			0 986 280 201
Phase sensor	08.97-09.01		0 232 101 024
Knock sensor	08.97-09.01	KZB	0 261 231 036
		KZG	0 261 231 038
Temperature sensor, intake air, injection system	08.97-09.01		0 280 130 085
Lateral acceleration sensor, brake system	08.97-09.01		0 265 005 127
Duo sensor, acceleration and yaw rate, brake system	08.97-09.01		0 265 005 214
Yaw rate sensor, brake system	08.97-09.01		0 265 005 207
Pressure sensor, ESP, (electronic stability program)	08.97-09.01		0 265 005 303
1.8 T [8ED; B7]		1,8l 120 kW BFB 4 Zyl.	
Throttle valve assembly	11.04→		0 280 750 009
Air mass meter, gasoline injection	11.04→		0 280 218 063
			0 986 280 217
Phase sensor	11.04→		0 232 101 024
Speed sensor, ignition/injection	11.04→		0 281 002 222
Boost pressure sensor, gasoline	11.04→		0 261 230 073
Temperature sensor, intake air, injection system	11.04→		0 280 130 085
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →8E..5..600 000	11.04-05.05		0 265 005 601
Fg.no. 8E..6..000 001→	06.05→		0 265 005 621
Wheel speed sensor, front	11.04→		0 265 006 809
Wheel speed sensor, rear	11.04→	ALR,RAB	0 265 006 824
		OLW	0 265 006 824
1.8 T [8E5; B6]		1,8l 110 kW AVJ 4 Zyl.	
Air mass meter, gasoline injection	09.01-06.02		0 280 218 063
			0 986 280 217
Phase sensor	09.01-06.02		0 232 101 024
Speed sensor, ignition/injection	09.01-06.02		0 281 002 222
Boost pressure sensor, gasoline	09.01-06.02		0 261 230 073

Product



Temperature sensor, intake air, injection system	09.01-06.02		0 280 130 116
Duo sensor, acceleration and yaw rate, brake system	09.01-06.02		0 265 005 252
Pressure sensor, ESP, (electronic stability program)	09.01-06.02		0 265 005 303
Wheel speed sensor, front	09.01-06.02		0 265 006 683
Wheel speed sensor, rear	09.01-06.02	ALR, LAB	0 265 006 707
		ALR, RAB	0 265 006 681
		OLW	0 265 006 681
1.8 T [8E5; B6] 1,8l 120/140 kW BEX; BFB 4 Zyl.			
Throttle valve assembly	07.02-12.04		0 280 750 009
Air mass meter, gasoline injection	07.02-12.04		0 280 218 063
			0 986 280 217
Phase sensor	07.02-12.04		0 232 101 024
Speed sensor, ignition/injection	07.02-12.04		0 281 002 222
Boost pressure sensor, gasoline	07.02-12.04		0 261 230 073
Temperature sensor, intake air, injection system	07.02-12.04		0 280 130 085
Duo sensor, acceleration and yaw rate, brake system	07.02-12.04		0 265 005 252
Pressure sensor, ESP, (electronic stability program)	07.02-12.04		0 265 005 303
Wheel speed sensor, front			
Fg.no. →8E..3..500 000	07.02-05.03		0 265 006 683
Fg.no. 8E..4..000 001→	06.03-12.04		0 265 006 809
Wheel speed sensor, rear			
Fg.no. →8E..4..050 000	07.02-05.04	ALR, LAB	0 265 006 707
Fg.no. →8E..4..400 000	07.02-05.04	ALR, RAB	0 265 006 681
		OLW	0 265 006 681
Fg.no. 8E..5..000 001→	06.04-12.04	ALR, LAB	0 265 006 826
		ALR, RAB	0 265 006 824
		OLW	0 265 006 824
1.8 T quattro [8D5; B5] 1,8l 110 kW AEB 4 Zyl.			
Air mass meter, gasoline injection	02.96-12.98		0 280 217 112
Phase sensor	02.96-12.98		0 232 101 024
Knock sensor	02.96-12.98	KZB	0 261 231 036
		KZG	0 261 231 038
Temperature sensor, intake air, injection system	02.96-12.98		0 280 130 085
Lateral acceleration sensor, brake system	02.96-12.98		0 265 005 127
Yaw rate sensor, brake system	02.96-12.98		0 265 005 207
Wheel speed sensor, rear			
Fg.no. 8D..W..280 001→	06.98-12.98	ALR, LAB	0 265 006 571
		ALR, RAB	0 265 006 569
		OLW	0 265 006 569
1.8 T quattro [8D5; B5] 1,8l 110 kW ANB 4 Zyl.			
Air mass meter, gasoline injection	07.99-06.00		0 280 218 032
			0 986 280 210
Phase sensor	07.99-06.00		0 232 101 024
Knock sensor	07.99-06.00	KZB	0 261 231 036
		KZG	0 261 231 038
Boost pressure sensor, gasoline	07.99-06.00		0 281 002 177
Temperature sensor, intake air, injection system	07.99-06.00		0 280 130 085
Lateral acceleration sensor, brake system	07.99-06.00		0 265 005 127
Duo sensor, acceleration and yaw rate, brake system	07.99-06.00		0 265 005 214
Yaw rate sensor, brake system	07.99-06.00		0 265 005 207
Wheel speed sensor, rear	07.99-06.00	ALR, LAB	0 265 006 571
		ALR, RAB	0 265 006 569
		OLW	0 265 006 569
1.8 T quattro [8D5; B5] 1,8l 110 kW APU 4 Zyl.			
Air mass meter, gasoline injection	02.99-09.01		0 280 218 032
			0 986 280 210
Phase sensor	02.99-09.01		0 232 101 024
Knock sensor	02.99-09.01	KZB	0 261 231 036
		KZG	0 261 231 038
Boost pressure sensor, gasoline	02.99-09.01		0 281 002 177

Product



Temperature sensor, intake air, injection system	02.99-09.01		0 280 130 085
Lateral acceleration sensor, brake system	02.99-09.01		0 265 005 127
Duo sensor, acceleration and yaw rate, brake system	02.99-09.01		0 265 005 214
Yaw rate sensor, brake system	02.99-09.01		0 265 005 207
Pressure sensor, ESP, (electronic stability program)	02.99-09.01		0 265 005 303
Wheel speed sensor, rear	02.99-09.01	ALR, LAB	0 265 006 571
		ALR, RAB	0 265 006 569
		OLW	0 265 006 569
1.8 T quattro [8D5; B5] 1,8l 110 kW ARK 4 Zyl.			
Air mass meter, gasoline injection	08.98-12.98		0 280 218 032
			0 986 280 210
Lateral acceleration sensor, brake system	08.98-12.98		0 265 005 127
Duo sensor, acceleration and yaw rate, brake system	08.98-12.98		0 265 005 214
Yaw rate sensor, brake system	08.98-12.98		0 265 005 207
Wheel speed sensor, rear	08.98-12.98	ALR, LAB	0 265 006 571
		ALR, RAB	0 265 006 569
		OLW	0 265 006 569
1.8 T quattro [8D5; B5] 1,8l 110 kW AWT 4 Zyl.			
Air mass meter, gasoline injection	06.00-09.01		0 280 218 063
			0 986 280 217
Phase sensor	06.00-09.01		0 232 101 024
Speed sensor, ignition/injection	06.00-09.01		0 281 002 222
Boost pressure sensor, gasoline	06.00-09.01		0 281 002 177
Temperature sensor, intake air, injection system	06.00-09.01		0 280 130 085
Lateral acceleration sensor, brake system	06.00-09.01		0 265 005 127
Duo sensor, acceleration and yaw rate, brake system	06.00-09.01		0 265 005 214
Yaw rate sensor, brake system	06.00-09.01		0 265 005 207
Pressure sensor, ESP, (electronic stability program)	06.00-09.01		0 265 005 303
Wheel speed sensor, rear	06.00-09.01	ALR, LAB	0 265 006 571
		ALR, RAB	0 265 006 569
		OLW	0 265 006 569
1.8 T quattro [8D5; B5] 1,8l 132 kW AJL 4 Zyl.			
Air mass meter, gasoline injection	08.97-09.01		0 280 217 117
			0 986 280 201
Phase sensor	08.97-09.01		0 232 101 024
Knock sensor	08.97-09.01	KZB	0 261 231 036
		KZG	0 261 231 038
Temperature sensor, intake air, injection system	08.97-09.01		0 280 130 085
Lateral acceleration sensor, brake system	08.97-09.01		0 265 005 127
Duo sensor, acceleration and yaw rate, brake system	08.97-09.01		0 265 005 214
Yaw rate sensor, brake system	08.97-09.01		0 265 005 207
Pressure sensor, ESP, (electronic stability program)	08.97-09.01		0 265 005 303
Wheel speed sensor, rear			
Fg.no. 8D..W..280 001→	06.98-09.01	ALR, LAB	0 265 006 571
		ALR, RAB	0 265 006 569
		OLW	0 265 006 569
1.8 T quattro [8ED; B7] 1,8l 120 kW BFB 4 Zyl.			
Throttle valve assembly	11.04→		0 280 750 009
Air mass meter, gasoline injection	11.04→		0 280 218 063
			0 986 280 217
Phase sensor	11.04→		0 232 101 024
Speed sensor, ignition/injection	11.04→		0 281 002 222
Boost pressure sensor, gasoline	11.04→		0 261 230 073
Temperature sensor, intake air, injection system	11.04→		0 280 130 085
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →8E..5..600 000	11.04-05.05		0 265 005 601
Fg.no. 8E..6..000 001→	06.05→		0 265 005 621
Wheel speed sensor, front	11.04→		0 265 006 809



A

Product				
◀ A4 Avant				
Wheel speed sensor, rear	11.04→	ALR,RAB	0 265 006 824	
		OLW	0 265 006 824	
1.8 T quattro [8E5; B6]		1,8l 110 kW AVJ 4 Zyl.		
Throttle valve assembly	09.01-06.02		0 280 750 009	
Phase sensor	09.01-06.02		0 232 101 024	
Speed sensor, ignition/injection	09.01-06.02		0 281 002 222	
Boost pressure sensor, gasoline	09.01-06.02		0 261 230 073	
Temperature sensor, intake air, injection system	09.01-06.02		0 280 130 116	
Duo sensor, acceleration and yaw rate, brake system	09.01-06.02		0 265 005 252	
Pressure sensor, ESP, (electronic stability program)	09.01-06.02		0 265 005 303	
Wheel speed sensor, front	09.01-06.02		0 265 006 683	
Wheel speed sensor, rear	09.01-06.02	ALR,LAB	0 265 006 707	
		ALR,RAB	0 265 006 681	
		OLW	0 265 006 681	
1.8 T quattro [8E5; B6]		1,8l 120 kW BFB 4 Zyl.		
Throttle valve assembly	07.02-12.04		0 280 750 009	
Air mass meter, gasoline injection	07.02-12.04		0 280 218 063	
			0 986 280 217	
Phase sensor	07.02-12.04		0 232 101 024	
Speed sensor, ignition/injection	07.02-12.04		0 281 002 222	
Boost pressure sensor, gasoline	07.02-12.04		0 261 230 073	
Temperature sensor, intake air, injection system	07.02-12.04		0 280 130 085	
Duo sensor, acceleration and yaw rate, brake system	07.02-12.04		0 265 005 252	
Pressure sensor, ESP, (electronic stability program)	07.02-12.04		0 265 005 303	
Wheel speed sensor, front				
Fg.no. →8E...3..500 000	07.02-05.03		0 265 006 683	
Fg.no. 8E...4..000 001→	06.03-12.04		0 265 006 809	
Wheel speed sensor, rear				
Fg.no. →8E...4..050 000	07.02-05.04	ALR,LAB	0 265 006 707	
Fg.no. →8E...4..400 000	07.02-05.04	ALR,RAB	0 265 006 681	
		OLW	0 265 006 681	
Fg.no. 8E...5..000 001→	06.04-12.04	ALR,LAB	0 265 006 826	
		ALR,RAB	0 265 006 824	
		OLW	0 265 006 824	
1.8 T quattro [8E5; B6]		1,8l 125 kW AMB 4 Zyl.		
Throttle valve assembly	09.01-06.02		0 280 750 009	
Air mass meter, gasoline injection	09.01-06.02		0 280 218 063	
			0 986 280 217	
Phase sensor	09.01-06.02		0 232 101 024	
Speed sensor, ignition/injection	09.01-06.02		0 281 002 222	
Boost pressure sensor, gasoline	09.01-06.02		0 261 230 073	
Temperature sensor, intake air, injection system	09.01-06.02		0 280 130 116	
Duo sensor, acceleration and yaw rate, brake system	09.01-06.02		0 265 005 252	
Pressure sensor, ESP, (electronic stability program)	09.01-06.02		0 265 005 303	
Wheel speed sensor, front	09.01-06.02		0 265 006 683	
Wheel speed sensor, rear	09.01-06.02	ALR,LAB	0 265 006 707	
		ALR,RAB	0 265 006 681	
		OLW	0 265 006 681	
1.8 T quattro [8E5; B6]		1,8l 140 kW BEX 4 Zyl.		
Throttle valve assembly	11.02-12.04		0 280 750 009	
Air mass meter, gasoline injection	11.02-12.04		0 280 218 063	
			0 986 280 217	
Phase sensor	11.02-12.04		0 232 101 024	
Speed sensor, ignition/injection	11.02-12.04		0 281 002 222	
Boost pressure sensor, gasoline	11.02-12.04		0 261 230 073	
Temperature sensor, intake air, injection system	11.02-12.04		0 280 130 085	
Duo sensor, acceleration and yaw rate, brake system	11.02-12.04		0 265 005 252	
Pressure sensor, ESP, (electronic stability program)	11.02-12.04		0 265 005 303	

Product				
Wheel speed sensor, front				
Fg.no. →8E...3..500 000	11.02-05.03		0 265 006 683	
Fg.no. 8E...4..000 001→	06.03-12.04		0 265 006 809	
Wheel speed sensor, rear				
Fg.no. →8E...4..050 000	11.02-05.04	ALR,LAB	0 265 006 707	
Fg.no. →8E...4..400 000	11.02-05.04	ALR,RAB	0 265 006 681	
		OLW	0 265 006 681	
Fg.no. 8E...5..000 001→	06.04-12.04	ALR,LAB	0 265 006 826	
		ALR,RAB	0 265 006 824	
		OLW	0 265 006 824	
1.9 TDI [8D5; B5]		1,9l 66 kW AHH 4 Zyl.		
Air mass meter, diesel	04.97-09.01		0 281 002 216	
			0 986 284 001	
Boost pressure sensor, Diesel	08.97-09.01		0 281 002 177	
Pedal position sensor, diesel	04.97-09.01	AG	0 205 001 031	
		GS	0 205 001 032	
Lateral acceleration sensor, brake system	04.97-09.01		0 265 005 127	
Duo sensor, acceleration and yaw rate, brake system	04.97-09.01		0 265 005 214	
Yaw rate sensor, brake system	04.97-09.01		0 265 005 207	
1.9 TDI [8D5; B5]		1,9l 66 kW AHU 4 Zyl.		
Air mass meter, diesel	08.97-07.98		0 281 002 216	
			0 986 284 001	
Boost pressure sensor, Diesel	08.97-07.98		0 281 002 177	
Pedal position sensor, diesel				
Fg.no. →8D...W..028 000	08.96-09.97	AG	0 205 001 031	
		GS	0 205 001 032	
Fg.no. 8D...W..028 001→	09.97-07.98	AG	0 281 002 289	
Fg.no. 8D...W..028 001→8D...W..080 000	09.97-11.97	GS	0 281 002 229	
Fg.no. 8D...W..080 001→	11.97-07.98	GS	0 281 002 286	
Lateral acceleration sensor, brake system	08.96-07.98		0 265 005 127	
Duo sensor, acceleration and yaw rate, brake system	08.96-07.98		0 265 005 214	
Yaw rate sensor, brake system	08.96-07.98		0 265 005 207	
1.9 TDI [8D5; B5]		1,9l 66 kW 1Z 4 Zyl.		
Pedal position sensor, diesel	01.95-07.96	AG	0 205 001 031	
		GS	0 205 001 032	
Lateral acceleration sensor, brake system	01.95-07.96		0 265 005 127	
Duo sensor, acceleration and yaw rate, brake system	01.95-07.96		0 265 005 214	
Yaw rate sensor, brake system	01.95-07.96		0 265 005 207	
1.9 TDI [8D5; B5]		1,9l 81 kW AFN 4 Zyl.		
Air mass meter, diesel	08.97-12.98		0 281 002 216	
			0 986 284 001	
Boost pressure sensor, Diesel	08.97-12.98		0 281 002 177	
Pedal position sensor, diesel				
Fg.no. →8D...W..028 000	02.96-09.97	AG	0 205 001 031	
		GS	0 205 001 032	
Fg.no. 8D...W..028 001→	09.97-12.98	AG	0 281 002 289	
Fg.no. 8D...W..028 001→8D...W..080 000	09.97-11.97	GS	0 281 002 229	
Fg.no. 8D...W..080 001→	11.97-12.98	GS	0 281 002 286	
Lateral acceleration sensor, brake system	02.96-12.98		0 265 005 127	
Duo sensor, acceleration and yaw rate, brake system	02.96-12.98		0 265 005 214	
Yaw rate sensor, brake system	02.96-12.98		0 265 005 207	
1.9 TDI [8D5; B5]		1,9l 81 kW AVG 4 Zyl.		
Air mass meter, diesel	08.99-06.00		0 281 002 216	
			0 986 284 001	
Boost pressure sensor, Diesel	08.99-06.00		0 281 002 177	
Pedal position sensor, diesel	08.99-06.00	AG	0 281 002 289	
		GS	0 281 002 286	
Lateral acceleration sensor, brake system	08.99-06.00		0 265 005 127	





Duo sensor, acceleration and yaw rate, brake system	08.99-06.00		0 265 005 214
Yaw rate sensor, brake system	08.99-06.00		0 265 005 207
1.9 TDI [8D5; B5]		1,9l 85 kW AJM 4 Zyl.	
Air mass meter, diesel	08.98-09.01		0 281 002 216
			0 986 284 001
Boost pressure sensor, Diesel	08.98-09.01		0 281 002 177
Pedal position sensor, diesel	08.98-09.01	AG	0 281 002 289
		GS	0 281 002 286
Lateral acceleration sensor, brake system	08.98-09.01		0 265 005 127
Duo sensor, acceleration and yaw rate, brake system	08.98-09.01		0 265 005 214
Yaw rate sensor, brake system	08.98-09.01		0 265 005 207
Pressure sensor, ESP, (electronic stability program)	08.98-09.01		0 265 005 303
1.9 TDI [8ED; B7]		1,9l 85 kW BKE 4 Zyl.	
Air mass meter, diesel	11.04-12.05		0 281 002 461
			0 986 284 007
Boost pressure sensor, Diesel	11.04-12.05		0 281 002 399
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →8E..5..600 000	11.04-05.05		0 265 005 601
Fg.no. 8E..6..000 001→	06.05-12.05		0 265 005 621
Wheel speed sensor, front	11.04-12.05		0 265 006 809
Wheel speed sensor, rear	11.04-12.05	ALR,RAB	0 265 006 824
		OLW	0 265 006 824
1.9 TDI [8ED; B7]		1,9l 85 kW BRB 4 Zyl.	
Air mass meter, diesel	01.06→		0 281 002 461
			0 986 284 007
Boost pressure sensor, Diesel	01.06→		0 281 002 399
Duo sensor, acceleration and yaw rate, brake system	01.06→		0 265 005 621
Wheel speed sensor, front	01.06→		0 265 006 809
Wheel speed sensor, rear	01.06→	ALR,RAB	0 265 006 824
		OLW	0 265 006 824
1.9 TDI [8E5; B6]		1,9l 74 kW AVB 4 Zyl.	
Air mass meter, diesel	09.01-05.04		0 281 002 531
			0 986 284 009
Boost pressure sensor, Diesel	09.01-05.04		0 281 002 399
Duo sensor, acceleration and yaw rate, brake system	09.01-05.04		0 265 005 252
Pressure sensor, ESP, (electronic stability program)	09.01-05.04		0 265 005 303
Wheel speed sensor, front			
Fg.no. →8E..3..500 000	09.01-05.03		0 265 006 683
Fg.no. 8E..4..000 001→	06.03-05.04		0 265 006 809
Wheel speed sensor, rear	09.01-05.04	ALR,LAB	0 265 006 707
		ALR,RAB	0 265 006 681
		OLW	0 265 006 681
1.9 TDI [8E5; B6]		1,9l 85 kW BKE 4 Zyl.	
Air mass meter, diesel	06.04-12.04		0 281 002 461
			0 986 284 007
Boost pressure sensor, Diesel	06.04-12.04		0 281 002 399
Duo sensor, acceleration and yaw rate, brake system	06.04-12.04		0 265 005 252
Pressure sensor, ESP, (electronic stability program)	06.04-12.04		0 265 005 303
Wheel speed sensor, front	06.04-12.04		0 265 006 809
Wheel speed sensor, rear	06.04-12.04	ALR,LAB	0 265 006 826
		ALR,RAB	0 265 006 824
		OLW	0 265 006 824
1.9 TDI [8E5; B6]		1,9l 96 kW AVF 4 Zyl.	
Air mass meter, diesel	09.01-12.04		0 281 002 461
			0 986 284 007
Boost pressure sensor, Diesel	09.01-12.04		0 281 002 401



Duo sensor, acceleration and yaw rate, brake system	09.01-12.04		0 265 005 252
Pressure sensor, ESP, (electronic stability program)	09.01-12.04		0 265 005 303
Wheel speed sensor, front			
Fg.no. →8E..3..500 000	09.01-05.03		0 265 006 683
Fg.no. 8E..4..000 001→	06.03-12.04		0 265 006 809
Wheel speed sensor, rear			
Fg.no. →8E..4..050 000	09.01-05.04	ALR,LAB	0 265 006 707
Fg.no. →8E..4..400 000	09.01-05.04	ALR,RAB	0 265 006 681
		OLW	0 265 006 681
Fg.no. 8E..5..000 001→	06.04-12.04	ALR,LAB	0 265 006 826
		ALR,RAB	0 265 006 824
		OLW	0 265 006 824
1.9 TDI [8E5; B6]		1,9l 96 kW AWX 4 Zyl.	
Air mass meter, diesel	09.01-06.03		0 281 002 461
			0 986 284 007
Boost pressure sensor, Diesel	09.01-06.03		0 281 002 401
Duo sensor, acceleration and yaw rate, brake system	09.01-06.03		0 265 005 252
Pressure sensor, ESP, (electronic stability program)	09.01-06.03		0 265 005 303
Wheel speed sensor, front	09.01-06.03		0 265 006 683
Wheel speed sensor, rear	09.01-06.03	ALR,LAB	0 265 006 707
		ALR,RAB	0 265 006 681
		OLW	0 265 006 681
1.9 TDI quattro [8D5; B5]		1,9l 81 kW AFN 4 Zyl.	
Air mass meter, diesel	08.97-07.99		0 281 002 216
			0 986 284 001
Boost pressure sensor, Diesel	08.97-07.99		0 281 002 177
Pedal position sensor, diesel			
Fg.no. →8D..W..028 000	07.96-09.97	AG	0 205 001 031
		GS	0 205 001 032
Fg.no. 8D..W..028 001→	09.97-07.99	AG	0 281 002 289
Fg.no. 8D..W..028 001→8D..W..080 000	09.97-11.97	GS	0 281 002 229
Fg.no. 8D..W..080 001→	11.97-07.99	GS	0 281 002 286
Lateral acceleration sensor, brake system	07.96-07.99		0 265 005 127
Duo sensor, acceleration and yaw rate, brake system	07.96-07.99		0 265 005 214
Yaw rate sensor, brake system	07.96-07.99		0 265 005 207
Wheel speed sensor, rear			
Fg.no. 8D..W..280 001→	06.98-07.99	ALR,LAB	0 265 006 571
		ALR,RAB	0 265 006 569
		OLW	0 265 006 569
1.9 TDI quattro [8D5; B5]		1,9l 81 kW AVG 4 Zyl.	
Air mass meter, diesel	08.99-01.00		0 281 002 216
			0 986 284 001
Boost pressure sensor, Diesel	08.99-01.00		0 281 002 177
Lateral acceleration sensor, brake system	08.99-01.00		0 265 005 127
Duo sensor, acceleration and yaw rate, brake system	08.99-01.00		0 265 005 214
Yaw rate sensor, brake system	08.99-01.00		0 265 005 207
Wheel speed sensor, rear	08.99-01.00	ALR,LAB	0 265 006 571
		ALR,RAB	0 265 006 569
		OLW	0 265 006 569
1.9 TDI quattro [8D5; B5]		1,9l 85 kW AJM 4 Zyl.	
Air mass meter, diesel	12.98-12.98		0 281 002 216
			0 986 284 001
Boost pressure sensor, Diesel	12.98-12.98		0 281 002 177
Pedal position sensor, diesel	12.98-12.98	AG	0 281 002 289
		GS	0 281 002 286
Lateral acceleration sensor, brake system	12.98-12.98		0 265 005 127
Yaw rate sensor, brake system	12.98-12.98		0 265 005 207

Product				

◀ A4 Avant

Wheel speed sensor, rear	12.98-12.98	ALR,LAB	0 265 006 571
		ALR,RAB	0 265 006 569
		OLW	0 265 006 569
1.9 TDI quattro [8D5; B5]	1,9l 85 kW ATJ 4 Zyl.		
Air mass meter, diesel	01.00-09.01		0 281 002 216
			0 986 284 001
Boost pressure sensor, Diesel	01.00-09.01		0 281 002 177
Lateral acceleration sensor, brake system	01.00-09.01		0 265 005 127
Duo sensor, acceleration and yaw rate, brake system	01.00-09.01		0 265 005 214
Yaw rate sensor, brake system	01.00-09.01		0 265 005 207
Pressure sensor, ESP, (electronic stability program)	01.00-09.01		0 265 005 303
Wheel speed sensor, rear	01.00-09.01	ALR,LAB	0 265 006 571
		ALR,RAB	0 265 006 569
		OLW	0 265 006 569
1.9 TDI quattro [8E5; B6]	1,9l 96 kW AVF 4 Zyl.		
Air mass meter, diesel	09.01-12.04		0 281 002 461
			0 986 284 007
Boost pressure sensor, Diesel	09.01-12.04		0 281 002 401
Duo sensor, acceleration and yaw rate, brake system	09.01-12.04		0 265 005 252
Pressure sensor, ESP, (electronic stability program)	09.01-12.04		0 265 005 303
Wheel speed sensor, front			
Fg.no. →8E...3..500 000	09.01-05.03		0 265 006 683
Fg.no. 8E...4..000 001→	06.03-12.04		0 265 006 809
Wheel speed sensor, rear			
Fg.no. →8E...4..050 000	09.01-05.04	ALR,LAB	0 265 006 707
Fg.no. →8E...4..400 000	09.01-05.04	ALR,RAB	0 265 006 681
		OLW	0 265 006 681
Fg.no. 8E...5..000 001→	06.04-12.04	ALR,LAB	0 265 006 826
		ALR,RAB	0 265 006 824
		OLW	0 265 006 824
2.0 [8ED; B7]	2,0l 96 kW ALT 4 Zyl.		
Throttle valve assembly	11.04→		0 280 750 088
Air mass meter, gasoline injection	11.04→		0 280 218 058
			0 986 280 215
Phase sensor	11.04→		0 232 101 024
Speed sensor, ignition/injection	11.04→		0 281 002 222
Temperature sensor, intake air, injection system	11.04→		0 280 130 116
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →8E...5..600 000	11.04-05.05		0 265 005 601
Fg.no. 8E...6..000 001→	06.05→		0 265 005 621
Wheel speed sensor, front	11.04→		0 265 006 809
Wheel speed sensor, rear	11.04→	ALR,RAB	0 265 006 824
		OLW	0 265 006 824
2.0 [8E5; B6]	2,0l 96 kW ALT 4 Zyl.		
Throttle valve assembly	09.01-12.04		0 280 750 088
Air mass meter, gasoline injection	09.01-12.04		0 280 218 058
			0 986 280 215
Phase sensor	09.01-12.04		0 232 101 024
Speed sensor, ignition/injection	09.01-12.04		0 281 002 222
Temperature sensor, intake air, injection system	09.01-12.04		0 280 130 116
Duo sensor, acceleration and yaw rate, brake system	09.01-12.04		0 265 005 252
Pressure sensor, ESP, (electronic stability program)	09.01-12.04		0 265 005 303
Wheel speed sensor, front			
Fg.no. →8E...3..500 000	09.01-05.03		0 265 006 683
Fg.no. 8E...4..000 001→	06.03-12.04		0 265 006 809
Wheel speed sensor, rear			
Fg.no. →8E...4..050 000	09.01-05.04	ALR,LAB	0 265 006 707
Fg.no. →8E...4..400 000	09.01-05.04	ALR,RAB	0 265 006 681
		OLW	0 265 006 681

Product				

Wheel speed sensor, rear			
Fg.no. 8E..5..000 001→	06.04-12.04	ALR,LAB	0 265 006 826
		ALR,RAB	0 265 006 824
		OLW	0 265 006 824
2.0 FSI [8E5; B6]		2,0l 110 kW AWA	4 Zyl.
Throttle valve assembly	09.01-12.04		0 280 750 134
Air mass meter, gasoline injection	09.01-12.04		0 280 218 058
			0 986 280 215
Speed sensor, ignition/injection	09.01-12.04		0 261 210 145
Duo sensor, acceleration and yaw rate, brake system	09.01-12.04		0 265 005 252
Pressure sensor, ESP, (electronic stability program)	09.01-12.04		0 265 005 303
Wheel speed sensor, front			
Fg.no. →8E..3..500 000	09.01-05.03		0 265 006 683
Fg.no. 8E..4..000 001→	06.03-12.04		0 265 006 809
Wheel speed sensor, rear			
Fg.no. →8E..4..050 000	09.01-05.04	ALR,LAB	0 265 006 707
Fg.no. →8E..4..400 000	09.01-05.04	ALR,RAB	0 265 006 681
		OLW	0 265 006 681
Fg.no. 8E..5..000 001→	06.04-12.04	ALR,LAB	0 265 006 826
		ALR,RAB	0 265 006 824
		OLW	0 265 006 824
2.0 TDI [8ED; B7]		2,0l 89/93 kW BVF; BVG	4 Zyl.
Air mass meter, diesel	11.05-11.06		0 281 002 461
			0 986 284 007
Boost pressure sensor, Diesel	11.05-11.06		0 281 002 401
Duo sensor, acceleration and yaw rate, brake system	11.05-11.06		0 265 005 621
Wheel speed sensor, front	11.05-11.06		0 265 006 809
Wheel speed sensor, rear	11.05-11.06	ALR,RAB	0 265 006 824
		OLW	0 265 006 824
2.0 TDI [8ED; B7]		2,0l 100 kW BNA	4 Zyl.
Air mass meter, diesel	11.04-10.05		0 281 002 461
			0 986 284 007
Boost pressure sensor, Diesel	11.04-10.05		0 281 002 401
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →8E..5..600 000	11.04-05.05		0 265 005 601
Fg.no. 8E..6..000 001→	06.05-10.05		0 265 005 621
Wheel speed sensor, front	11.04-10.05		0 265 006 809
Wheel speed sensor, rear	11.04-10.05	ALR,RAB	0 265 006 824
		OLW	0 265 006 824
2.0 TDI [8ED; B7]		2,0l 100 kW BRF	4 Zyl.
Air mass meter, diesel	11.05→		0 281 002 461
			0 986 284 007
Boost pressure sensor, Diesel	11.05→		0 281 002 401
Duo sensor, acceleration and yaw rate, brake system	11.05→		0 265 005 621
Wheel speed sensor, front	11.05→		0 265 006 809
Wheel speed sensor, rear	11.05→	ALR,RAB	0 265 006 824
		OLW	0 265 006 824
2.0 TDI [8ED; B7]		2,0l 103 kW BLB	4 Zyl.
Air mass meter, diesel	11.04-11.05		0 281 002 461
			0 986 284 007
Boost pressure sensor, Diesel	11.04-11.05		0 281 002 401
Duo sensor, acceleration and yaw rate, brake system	11.04-11.05		0 265 005 601
Wheel speed sensor, front	11.04-11.05		0 265 006 809
Wheel speed sensor, rear	11.04-11.05	ALR,RAB	0 265 006 824
		OLW	0 265 006 824
2.0 TDI [8ED; B7]		2,0l 103 kW BPW	4 Zyl.
Air mass meter, diesel	11.04→		0 281 002 461
			0 986 284 007



Boost pressure sensor, Diesel	11.04→	0 281 002 401
Duo sensor, acceleration and yaw rate, brake system		
Fg.no. →8E...5..600 000	11.04-05.05	0 265 005 601
Fg.no. 8E...6..000 001→	06.05→	0 265 005 621
Wheel speed sensor, front	11.04→	0 265 006 809
Wheel speed sensor, rear	11.04→	ALR,RAB 0 265 006 824 OLW 0 265 006 824
2.0 TDI [8ED; B7]	2,0l 103/120/125 kW BRD; BRE; BVA 4 Zyl.	
Air mass meter, diesel	06.05→	0 281 002 461 🔧 0 986 284 007
Boost pressure sensor, Diesel	06.05→	0 281 002 401
Duo sensor, acceleration and yaw rate, brake system	06.05→	0 265 005 621
Wheel speed sensor, front	06.05→	0 265 006 809
Wheel speed sensor, rear	06.05→	ALR,RAB 0 265 006 824 OLW 0 265 006 824
2.0 TDI quattro [8ED; B7]	2,0l 103/120/125 kW BPW; BRD; BVA 4 Zyl.	
Air mass meter, diesel	01.06→	0 281 002 461 🔧 0 986 284 007
Boost pressure sensor, Diesel	01.06→	0 281 002 401
Duo sensor, acceleration and yaw rate, brake system	01.06→	0 265 005 621
Wheel speed sensor, front	01.06→	0 265 006 809
Wheel speed sensor, rear	01.06→	ALR,RAB 0 265 006 824 OLW 0 265 006 824
2.0 TFSI [8ED; B7]	2,0l 125 kW BPJ 4 Zyl.	
Speed sensor, ignition/injection	03.07→	0 261 210 199
Knock sensor	03.07→	0 261 231 146
Boost pressure sensor, gasoline	03.07→	0 261 230 073
Duo sensor, acceleration and yaw rate, brake system	03.07→	0 265 005 621
Wheel speed sensor, front	03.07→	0 265 006 809
Wheel speed sensor, rear	03.07→	ALR,RAB 0 265 006 824 OLW 0 265 006 824
2.0 TFSI [8ED; B7]	2,0l 147 kW BGB; BPG 4 Zyl.	
Speed sensor, ignition/injection	11.04→	0 261 210 199
Knock sensor	11.04→	0 261 231 146
Boost pressure sensor, gasoline	11.04→	0 261 230 073
Duo sensor, acceleration and yaw rate, brake system		
Fg.no. →8E...5..600 000	11.04-05.05	0 265 005 601
Fg.no. 8E...6..000 001→	06.05→	0 265 005 621
Wheel speed sensor, front	11.04→	0 265 006 809
Wheel speed sensor, rear	11.04→	ALR,RAB 0 265 006 824 OLW 0 265 006 824
2.0 TFSI [8ED; B7]	2,0l 147/162 kW BUL; BWE 4 Zyl.	
Speed sensor, ignition/injection	06.05→	0 261 210 199
Knock sensor	06.05→	0 261 231 146
Boost pressure sensor, gasoline	06.05→	0 261 230 073
Duo sensor, acceleration and yaw rate, brake system	06.05→	0 265 005 621
Wheel speed sensor, front	06.05→	0 265 006 809
Wheel speed sensor, rear	06.05→	ALR,RAB 0 265 006 824 OLW 0 265 006 824
2.0 TFSI quattro [8ED; B7]	2,0l 147 kW BGB 4 Zyl.	
Speed sensor, ignition/injection	11.04-08.05	0 261 210 199
Knock sensor	11.04-08.05	0 261 231 146
Boost pressure sensor, gasoline	11.04-08.05	0 261 230 073
Duo sensor, acceleration and yaw rate, brake system		
Fg.no. →8E...5..600 000	11.04-05.05	0 265 005 601
Fg.no. 8E...6..000 001→	06.05-08.05	0 265 005 621



Wheel speed sensor, front	11.04-08.05	0 265 006 809
Wheel speed sensor, rear	11.04-08.05	ALR,RAB 0 265 006 824 OLW 0 265 006 824
2.0 TFSI quattro [8ED; B7]	2,0l 147/162 kW BUL; BWE 4 Zyl.	
Speed sensor, ignition/injection	06.05→	0 261 210 199
Knock sensor	06.05→	0 261 231 146
Boost pressure sensor, gasoline	06.05→	0 261 230 073
Duo sensor, acceleration and yaw rate, brake system	06.05→	0 265 005 621
Wheel speed sensor, front	06.05→	0 265 006 809
Wheel speed sensor, rear	06.05→	ALR,RAB 0 265 006 824 OLW 0 265 006 824
2.4 [8D5; B5]	2,4l 120 kW AMM 6 Zyl.	
Temperature sensor, intake air, injection system	06.00-09.01	0 280 130 085
Lateral acceleration sensor, brake system	06.00-09.01	0 265 005 127
Duo sensor, acceleration and yaw rate, brake system	06.00-09.01	0 265 005 214
Yaw rate sensor, brake system	06.00-09.01	0 265 005 207
Pressure sensor, ESP, (electronic stability program)	06.00-09.01	0 265 005 303
2.4 [8D5; B5]	2,4l 120 kW APZ 6 Zyl.	
Phase sensor	08.98-06.00	0 232 101 024
Speed sensor, ignition/injection	08.98-06.00	AG 0 261 210 147 GS 0 261 210 178
Knock sensor		
Fg.no. →8D...X..260 000	08.98-04.99	0 261 231 036
Temperature sensor, intake air, injection system	08.98-06.00	0 280 130 085
Lateral acceleration sensor, brake system	08.98-06.00	0 265 005 127
Duo sensor, acceleration and yaw rate, brake system	08.98-06.00	0 265 005 214
Yaw rate sensor, brake system	08.98-06.00	0 265 005 207
2.4 [8D5; B5]	2,4l 121 kW AGA 6 Zyl.	
Phase sensor	08.97-07.98	0 232 101 024
Speed sensor, ignition/injection	08.97-07.98	0 261 210 147
Knock sensor	08.97-07.98	0 261 231 036
Temperature sensor, intake air, injection system	08.97-07.98	0 280 130 085
Lateral acceleration sensor, brake system	08.97-07.98	0 265 005 127
Duo sensor, acceleration and yaw rate, brake system	08.97-07.98	0 265 005 214
Yaw rate sensor, brake system	08.97-07.98	0 265 005 207
2.4 [8D5; B5]	2,4l 121 kW ALF 6 Zyl.	
Throttle valve assembly	08.97-07.98	0 280 750 030
Phase sensor	08.97-07.98	0 232 101 024
Speed sensor, ignition/injection	08.97-07.98	0 261 210 147
Knock sensor	08.97-07.98	0 261 231 036
Temperature sensor, intake air, injection system	08.97-07.98	0 280 130 085
Lateral acceleration sensor, brake system	08.97-07.98	0 265 005 127
Duo sensor, acceleration and yaw rate, brake system	08.97-07.98	0 265 005 214
Yaw rate sensor, brake system	08.97-07.98	0 265 005 207
2.4 [8D5; B5]	2,4l 121 kW AML 6 Zyl.	
Phase sensor	08.98-09.01	0 232 101 024
Temperature sensor, intake air, injection system	08.98-09.01	0 280 130 085
Lateral acceleration sensor, brake system	08.98-09.01	0 265 005 127
Duo sensor, acceleration and yaw rate, brake system	08.98-09.01	0 265 005 214
Yaw rate sensor, brake system	08.98-09.01	0 265 005 207
Pressure sensor, ESP, (electronic stability program)	08.98-09.01	0 265 005 303
2.4 [8D5; B5]	2,4l 121 kW APS; ARJ 6 Zyl.	
Phase sensor	08.98-06.00	0 232 101 024
Speed sensor, ignition/injection	08.98-06.00	AG 0 261 210 147 GS 0 261 210 178
Knock sensor		
Fg.no. →8D...X..260 000	08.98-04.99	0 261 231 036



A

Product				

◀ A4 Avant

Temperature sensor, intake air, injection system	08.98-06.00			0 280 130 085
Lateral acceleration sensor, brake system	08.98-06.00			0 265 005 127
Duo sensor, acceleration and yaw rate, brake system	08.98-06.00			0 265 005 214
Yaw rate sensor, brake system	08.98-06.00			0 265 005 207
2.4 [8E5; B6]	2,4l 120/125 kW	AMM; BDV	6 Zyl.	
Throttle valve assembly	09.01-12.04			0 280 750 030
Phase sensor	09.01-12.04			0 232 101 024
Speed sensor, ignition/injection	09.01-12.04			0 261 210 178
Temperature sensor, intake air, injection system	09.01-12.04			0 280 130 116
Duo sensor, acceleration and yaw rate, brake system	09.01-12.04			0 265 005 252
Pressure sensor, ESP, (electronic stability program)	09.01-12.04			0 265 005 303
Wheel speed sensor, front				
Fg.no. →8E..3..500 000	09.01-05.03			0 265 006 683
Fg.no. 8E..4..000 001→	06.03-12.04			0 265 006 809
Wheel speed sensor, rear				
Fg.no. →8E..4..050 000	09.01-05.04	ALR,LAB		0 265 006 707
Fg.no. →8E..4..400 000	09.01-05.04	ALR,RAB		0 265 006 681
		OLW		0 265 006 681
Fg.no. 8E..5..000 001→	06.04-12.04	ALR,LAB		0 265 006 826
		ALR,RAB		0 265 006 824
		OLW		0 265 006 824
2.4 quattro [8D5; B5]	2,4l 120 kW	AJG	6 Zyl.	
Phase sensor	08.97-07.98			0 232 101 024
Speed sensor, ignition/injection	08.97-07.98			0 261 210 147
Knock sensor	08.97-07.98			0 261 231 036
Temperature sensor, intake air, injection system	08.97-07.98			0 280 130 085
Lateral acceleration sensor, brake system	08.97-07.98			0 265 005 127
Yaw rate sensor, brake system	08.97-07.98			0 265 005 207
Wheel speed sensor, rear				
Fg.no. 8D..W..280 001→	06.98-07.98	ALR,LAB		0 265 006 571
		ALR,RAB		0 265 006 569
		OLW		0 265 006 569
2.4 quattro [8D5; B5]	2,4l 120 kW	APZ	6 Zyl.	
Phase sensor	08.98-06.00			0 232 101 024
Speed sensor, ignition/injection	08.98-06.00	AG		0 261 210 147
		GS		0 261 210 178
Knock sensor				
Fg.no. →8D..X..260 000	08.98-04.99			0 261 231 036
Temperature sensor, intake air, injection system	08.98-06.00			0 280 130 085
Lateral acceleration sensor, brake system	08.98-06.00			0 265 005 127
Duo sensor, acceleration and yaw rate, brake system	08.98-06.00			0 265 005 214
Yaw rate sensor, brake system	08.98-06.00			0 265 005 207
Wheel speed sensor, rear	08.98-06.00	ALR,LAB		0 265 006 571
		ALR,RAB		0 265 006 569
		OLW		0 265 006 569
2.4 quattro [8D5; B5]	2,4l 121 kW	AGA; ALF	6 Zyl.	
Phase sensor	08.97-07.98			0 232 101 024
Speed sensor, ignition/injection	08.97-07.98			0 261 210 147
Knock sensor	08.97-07.98			0 261 231 036
Temperature sensor, intake air, injection system	08.97-07.98			0 280 130 085
Lateral acceleration sensor, brake system	08.97-07.98			0 265 005 127
Yaw rate sensor, brake system	08.97-07.98			0 265 005 207
Wheel speed sensor, rear				
Fg.no. 8D..W..280 001→	06.98-07.98	ALR,LAB		0 265 006 571
		ALR,RAB		0 265 006 569
		OLW		0 265 006 569
2.4 quattro [8D5; B5]	2,4l 121 kW	AML	6 Zyl.	
Phase sensor	08.98-12.98			0 232 101 024
Temperature sensor, intake air, injection system	08.98-12.98			0 280 130 085
Lateral acceleration sensor, brake system	08.98-12.98			0 265 005 127

Product				

Yaw rate sensor, brake system	08.98-12.98			0 265 005 207
Wheel speed sensor, rear	08.98-12.98	ALR,LAB		0 265 006 571
		ALR,RAB		0 265 006 569
		OLW		0 265 006 569
2.4 quattro [8D5; B5]	2,4l 121 kW	APS	6 Zyl.	
Phase sensor	08.98-09.01			0 232 101 024
Speed sensor, ignition/injection	08.98-09.01	AG		0 261 210 147
		GS		0 261 210 178
Knock sensor				
Fg.no. →8D..X..260 000	08.98-04.99			0 261 231 036
Temperature sensor, intake air, injection system	08.98-09.01			0 280 130 085
Lateral acceleration sensor, brake system	08.98-09.01			0 265 005 127
Duo sensor, acceleration and yaw rate, brake system	08.98-09.01			0 265 005 214
Yaw rate sensor, brake system	08.98-09.01			0 265 005 207
Pressure sensor, ESP, (electronic stability program)	08.98-09.01			0 265 005 303
Wheel speed sensor, rear	08.98-09.01	ALR,LAB		0 265 006 571
		ALR,RAB		0 265 006 569
		OLW		0 265 006 569
2.4 quattro [8D5; B5]	2,4l 121 kW	ARJ	6 Zyl.	
Phase sensor	02.99-07.99			0 232 101 024
Speed sensor, ignition/injection	02.99-07.99	AG		0 261 210 147
		GS		0 261 210 178
Knock sensor				
Fg.no. →8D..X..260 000	02.99-04.99			0 261 231 036
Temperature sensor, intake air, injection system	02.99-07.99			0 280 130 085
Lateral acceleration sensor, brake system	02.99-07.99			0 265 005 127
Duo sensor, acceleration and yaw rate, brake system	02.99-07.99			0 265 005 214
Yaw rate sensor, brake system	02.99-07.99			0 265 005 207
Wheel speed sensor, rear	02.99-07.99	ALR,LAB		0 265 006 571
		ALR,RAB		0 265 006 569
		OLW		0 265 006 569
2.5 TDI [8D5; B5]	2,5l 110 kW	AFB	6 Zyl.	
Air mass meter, diesel	11.97-06.00			0 281 002 429
				0 986 284 005
Speed sensor, diesel	11.97-06.00	KZU		0 281 002 222
Boost pressure sensor, Diesel	11.97-06.00			0 281 002 177
Pedal position sensor, diesel	11.97-06.00	AG		0 281 002 289
		GS		0 281 002 286
Lateral acceleration sensor, brake system	11.97-06.00			0 265 005 127
Duo sensor, acceleration and yaw rate, brake system	11.97-06.00			0 265 005 214
Yaw rate sensor, brake system	11.97-06.00			0 265 005 207
2.5 TDI [8D5; B5]	2,5l 110 kW	AKN	6 Zyl.	
Air mass meter, diesel				
Fg.no. →8D..X..400 000	08.98-06.99			0 281 002 429
				0 986 284 005
Fg.no. 8D..Y..000 001→	07.99-09.01			0 281 002 403
				0 986 284 004
Speed sensor, diesel	08.98-09.01	KZU		0 281 002 222
Boost pressure sensor, Diesel	08.98-09.01			0 281 002 177
Pedal position sensor, diesel	08.98-09.01	AG		0 281 002 289
		GS		0 281 002 286
Lateral acceleration sensor, brake system	08.98-09.01			0 265 005 127
Duo sensor, acceleration and yaw rate, brake system	08.98-09.01			0 265 005 214
Yaw rate sensor, brake system	08.98-09.01			0 265 005 207
Pressure sensor, ESP, (electronic stability program)	08.98-09.01			0 265 005 303
2.5 TDI [8ED; B7]	2,5l 120 kW	BDG	6 Zyl.	
Speed sensor, diesel	11.04-05.06			0 281 002 222
Boost pressure sensor, Diesel	11.04-05.06			0 281 002 399



Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →8E..5..600 000	11.04-05.05		0 265 005 601
Fg.no. 8E..6..000 001→	06.05-05.06		0 265 005 621
Wheel speed sensor, front	11.04-05.06		0 265 006 809
Wheel speed sensor, rear	11.04-05.06	ALR,RAB	0 265 006 824
		OLW	0 265 006 824
2.5 TDI [8E5; B6]	2,5 l 114 kW AYM 6 Zyl.		
Speed sensor, diesel	09.01-06.02		0 281 002 222
Boost pressure sensor, Diesel	09.01-06.02		0 281 002 399
Duo sensor, acceleration and yaw rate, brake system	09.01-06.02		0 265 005 252
Pressure sensor, ESP, (electronic stability program)	09.01-06.02		0 265 005 303
Wheel speed sensor, front	09.01-06.02		0 265 006 683
Wheel speed sensor, rear	09.01-06.02	ALR,LAB	0 265 006 707
		ALR,RAB	0 265 006 681
		OLW	0 265 006 681
2.5 TDI [8E5; B6]	2,5 l 120 kW BCZ; BDG 6 Zyl.		
Speed sensor, diesel	06.03-12.04		0 281 002 222
Boost pressure sensor, Diesel	06.03-12.04		0 281 002 399
Duo sensor, acceleration and yaw rate, brake system	06.03-12.04		0 265 005 252
Pressure sensor, ESP, (electronic stability program)	06.03-12.04		0 265 005 303
Wheel speed sensor, front	06.03-12.04		0 265 006 809
Wheel speed sensor, rear			
Fg.no. →8E..4..050 000	06.03-05.04	ALR,LAB	0 265 006 707
Fg.no. →8E..4..400 000	06.03-05.04	ALR,RAB	0 265 006 681
		OLW	0 265 006 681
Fg.no. 8E..5..000 001→	06.04-12.04	ALR,LAB	0 265 006 826
		ALR,RAB	0 265 006 824
		OLW	0 265 006 824
2.5 TDI [8E5; B6]	2,5 l 120 kW BFC 6 Zyl.		
Speed sensor, diesel	07.02-05.03		0 281 002 222
Boost pressure sensor, Diesel	07.02-05.03		0 281 002 399
Duo sensor, acceleration and yaw rate, brake system	07.02-05.03		0 265 005 252
Pressure sensor, ESP, (electronic stability program)	07.02-05.03		0 265 005 303
Wheel speed sensor, front	07.02-05.03		0 265 006 683
Wheel speed sensor, rear	07.02-05.03	ALR,LAB	0 265 006 707
		ALR,RAB	0 265 006 681
		OLW	0 265 006 681
2.5 TDI quattro [8D5; B5]	2,5 l 110 kW AFB 6 Zyl.		
Air mass meter, diesel	11.97-06.00		0 281 002 429
			0 986 284 005
Speed sensor, diesel	11.97-06.00	KZU	0 281 002 222
Boost pressure sensor, Diesel	11.97-06.00		0 281 002 177
Pedal position sensor, diesel	11.97-06.00	AG	0 281 002 289
		GS	0 281 002 286
Lateral acceleration sensor, brake system	11.97-06.00		0 265 005 127
Duo sensor, acceleration and yaw rate, brake system	11.97-06.00		0 265 005 214
Yaw rate sensor, brake system	11.97-06.00		0 265 005 207
Wheel speed sensor, rear			
Fg.no. 8D..W..280 001→	06.98-06.00	ALR,LAB	0 265 006 571
		ALR,RAB	0 265 006 569
		OLW	0 265 006 569
2.5 TDI quattro [8D5; B5]	2,5 l 110 kW AKN 6 Zyl.		
Air mass meter, diesel			
Fg.no. →8D..X..400 000	07.98-06.99		0 281 002 429
			0 986 284 005
Fg.no. 8D..Y..000 001→	07.99-07.99		0 281 002 403
			0 986 284 004
Speed sensor, diesel	07.98-07.99	KZU	0 281 002 222



Boost pressure sensor, Diesel	07.98-07.99		0 281 002 177
Pedal position sensor, diesel	07.98-07.99	AG	0 281 002 289
		GS	0 281 002 286
Lateral acceleration sensor, brake system	07.98-07.99		0 265 005 127
Duo sensor, acceleration and yaw rate, brake system	07.98-07.99		0 265 005 214
Yaw rate sensor, brake system	07.98-07.99		0 265 005 207
Wheel speed sensor, rear	07.98-07.99	ALR,LAB	0 265 006 571
		ALR,RAB	0 265 006 569
		OLW	0 265 006 569
2.5 TDI quattro [8E5; B6]	2,5 l 132 kW AKE 6 Zyl.		
Speed sensor, diesel	09.01-05.03		0 281 002 222
Boost pressure sensor, Diesel	09.01-05.03		0 281 002 399
Duo sensor, acceleration and yaw rate, brake system	09.01-05.03		0 265 005 252
Pressure sensor, ESP, (electronic stability program)	09.01-05.03		0 265 005 303
Wheel speed sensor, front	09.01-05.03		0 265 006 683
Wheel speed sensor, rear	09.01-05.03	ALR,LAB	0 265 006 707
		ALR,RAB	0 265 006 681
		OLW	0 265 006 681
2.5 TDI quattro [8E5; B6]	2,5 l 132 kW BAU; BDH 6 Zyl.		
Speed sensor, diesel	11.02-12.04		0 281 002 222
Boost pressure sensor, Diesel	11.02-12.04		0 281 002 399
Duo sensor, acceleration and yaw rate, brake system	11.02-12.04		0 265 005 252
Pressure sensor, ESP, (electronic stability program)	11.02-12.04		0 265 005 303
Wheel speed sensor, front			
Fg.no. →8E..3..500 000	11.02-05.03		0 265 006 683
Fg.no. 8E..4..000 001→	06.03-12.04		0 265 006 809
Wheel speed sensor, rear			
Fg.no. →8E..4..050 000	11.02-05.04	ALR,LAB	0 265 006 707
Fg.no. →8E..4..400 000	11.02-05.04	ALR,RAB	0 265 006 681
		OLW	0 265 006 681
Fg.no. 8E..5..000 001→	06.04-12.04	ALR,LAB	0 265 006 826
		ALR,RAB	0 265 006 824
		OLW	0 265 006 824
2.6 [8D2; B5]	2,6 l 110 kW ABC 6 Zyl.		
Throttle valve sensor	11.94-07.98		0 280 120 431
Phase sensor	11.94-07.98		0 232 101 027
Knock sensor	11.94-07.98		0 261 231 036
Lateral acceleration sensor, brake system	11.94-07.98		0 265 005 127
Duo sensor, acceleration and yaw rate, brake system	11.94-07.98		0 265 005 214
Yaw rate sensor, brake system	11.94-07.98		0 265 005 207
2.6 [8D5; B5]	2,6 l 102/110 kW ABC; ACZ 6 Zyl.		
Throttle valve sensor	11.94-07.98		0 280 120 431
Phase sensor	11.94-07.98		0 232 101 027
Knock sensor	11.94-07.98		0 261 231 036
Lateral acceleration sensor, brake system	11.94-07.98		0 265 005 127
Duo sensor, acceleration and yaw rate, brake system	11.94-07.98		0 265 005 214
Yaw rate sensor, brake system	11.94-07.98		0 265 005 207
2.6 quattro [8D5; B5]	2,6 l 102 kW ACZ 6 Zyl.		
Throttle valve sensor	01.96-07.97		0 280 120 431
Phase sensor	01.96-07.97		0 232 101 027
Knock sensor	01.96-07.97		0 261 231 036
Lateral acceleration sensor, brake system	01.96-07.97		0 265 005 127
Yaw rate sensor, brake system	01.96-07.97		0 265 005 207
2.6 quattro [8D5; B5]	2,6 l 110 kW ABC 6 Zyl.		
Throttle valve sensor	11.94-07.98		0 280 120 431
Phase sensor	11.94-07.98		0 232 101 027
Knock sensor	11.94-07.98		0 261 231 036
Lateral acceleration sensor, brake system	11.94-07.98		0 265 005 127



A

Product				

◀ A4 Avant

Yaw rate sensor, brake system	11.94-07.98		0 265 005 207
Wheel speed sensor, rear			
Fg.no. 8D..W..280 001→	06.98-07.98	ALR,LAB	0 265 006 571
		ALR,RAB	0 265 006 569
		OLW	0 265 006 569
2.7 TDI [8ED; B7]	2,7 l 120/132 kW BPP; BSG 6 Zyl.		
Speed sensor, diesel	11.05→	FKW	0 261 210 145
High-pressure sensor (CR system)			
Fg.no. →8E..6..111 000,→8E..6..802 000	11.05-08.06		0 281 002 504
Boost pressure sensor, Diesel	11.05→		0 281 002 401
Duo sensor, acceleration and yaw rate, brake system	11.05→		0 265 005 621
Wheel speed sensor, front	11.05→		0 265 006 809
Wheel speed sensor, rear	11.05→	ALR,RAB	0 265 006 824
		OLW	0 265 006 824
2.8 [8D5; B5]	2,8 l 140 kW ATX 6 Zyl.		
Temperature sensor, intake air, injection system	03.99-09.01		0 280 130 085
Lateral acceleration sensor, brake system	03.99-09.01		0 265 005 127
Duo sensor, acceleration and yaw rate, brake system	03.99-09.01		0 265 005 214
Yaw rate sensor, brake system	03.99-09.01		0 265 005 207
Pressure sensor, ESP, (electronic stability program)	03.99-09.01		0 265 005 303
2.8 [8D5; B5]	2,8 l 142 kW ACK 6 Zyl.		
Throttle valve assembly	03.96-07.98		0 280 750 030
Phase sensor	03.96-07.98		0 232 101 024
Speed sensor, ignition/injection	03.96-07.97		0 261 210 134
	08.97-07.98		0 261 210 147
Knock sensor	03.96-07.98		0 261 231 036
Temperature sensor, intake air, injection system	03.96-07.98		0 280 130 085
Lateral acceleration sensor, brake system	03.96-07.98		0 265 005 127
Duo sensor, acceleration and yaw rate, brake system	03.96-07.98		0 265 005 214
Yaw rate sensor, brake system	03.96-07.98		0 265 005 207
2.8 [8D5; B5]	2,8 l 142 kW AHA 6 Zyl.		
Phase sensor	08.97-08.99		0 232 101 024
Speed sensor, ignition/injection	08.97-08.99		0 261 210 147
		AG	0 261 210 147
		GS	0 261 210 134
Knock sensor			
Fg.no. →8D..X..260 000	08.97-04.99		0 261 231 036
Temperature sensor, intake air, injection system	08.97-08.99		0 280 130 085
2.8 [8D5; B5]	2,8 l 142 kW ALG 6 Zyl.		
Phase sensor	08.97-07.98		0 232 101 024
Speed sensor, ignition/injection	08.97-07.98		0 261 210 147
Knock sensor	08.97-07.98		0 261 231 036
Temperature sensor, intake air, injection system	08.97-07.98		0 280 130 085
Lateral acceleration sensor, brake system	08.97-07.98		0 265 005 127
Duo sensor, acceleration and yaw rate, brake system	08.97-07.98		0 265 005 214
Yaw rate sensor, brake system	08.97-07.98		0 265 005 207
2.8 [8D5; B5]	2,8 l 142 kW APR; AQD 6 Zyl.		
Phase sensor	08.98-07.99		0 232 101 024
Speed sensor, ignition/injection	08.98-07.99	AG	0 261 210 147
		GS	0 261 210 178
Knock sensor			
Fg.no. →8D..X..260 000	08.98-04.99		0 261 231 036
Temperature sensor, intake air, injection system	08.98-07.99		0 280 130 085
Lateral acceleration sensor, brake system	08.98-07.99		0 265 005 127
Duo sensor, acceleration and yaw rate, brake system	08.98-07.99		0 265 005 214
Yaw rate sensor, brake system	08.98-07.99		0 265 005 207

Product				

2.8 [8D5; B5]	2,8 l 142 kW ATQ 6 Zyl.		
Phase sensor	08.99-09.01		0 232 101 024
Speed sensor, ignition/injection	08.99-09.01	AG	0 261 210 147
		GS	0 261 210 134
Temperature sensor, intake air, injection system	08.99-09.01		0 280 130 085
2.8 quattro [8D5; B5]	2,8 l 140 kW ATX 6 Zyl.		
Temperature sensor, intake air, injection system	09.99-09.01		0 280 130 085
Lateral acceleration sensor, brake system	09.99-09.01		0 265 005 127
Duo sensor, acceleration and yaw rate, brake system	09.99-09.01		0 265 005 214
Yaw rate sensor, brake system	09.99-09.01		0 265 005 207
Pressure sensor, ESP, (electronic stability program)	09.99-09.01		0 265 005 303
Wheel speed sensor, rear	09.99-09.01	ALR,LAB	0 265 006 571
		ALR,RAB	0 265 006 569
		OLW	0 265 006 569
2.8 quattro [8D5; B5]	2,8 l 142 kW ACK 6 Zyl.		
Phase sensor	03.96-07.98		0 232 101 024
Speed sensor, ignition/injection	03.96-07.97		0 261 210 134
	08.97-07.98		0 261 210 147
Knock sensor	03.96-07.98		0 261 231 036
Temperature sensor, intake air, injection system	03.96-07.98		0 280 130 085
Lateral acceleration sensor, brake system	03.96-07.98		0 265 005 127
Yaw rate sensor, brake system	03.96-07.98		0 265 005 207
Wheel speed sensor, rear			
Fg.no. 8D..W..280 001→	06.98-07.98	ALR,LAB	0 265 006 571
		ALR,RAB	0 265 006 569
		OLW	0 265 006 569
2.8 quattro [8D5; B5]	2,8 l 142 kW ALG 6 Zyl.		
Phase sensor	08.97-07.98		0 232 101 024
Speed sensor, ignition/injection	08.97-07.98		0 261 210 147
Knock sensor	08.97-07.98		0 261 231 036
Temperature sensor, intake air, injection system	08.97-07.98		0 280 130 085
Lateral acceleration sensor, brake system	08.97-07.98		0 265 005 127
Yaw rate sensor, brake system	08.97-07.98		0 265 005 207
Wheel speed sensor, rear			
Fg.no. 8D..W..280 001→	06.98-07.98	ALR,LAB	0 265 006 571
		ALR,RAB	0 265 006 569
		OLW	0 265 006 569
2.8 quattro [8D5; B5]	2,8 l 142 kW AMX 6 Zyl.		
Phase sensor	06.00-09.01		0 232 101 024
Speed sensor, ignition/injection	06.00-09.01	AG	0 261 210 147
		GS	0 261 210 178
Lateral acceleration sensor, brake system	06.00-09.01		0 265 005 127
Duo sensor, acceleration and yaw rate, brake system	06.00-09.01		0 265 005 214
Yaw rate sensor, brake system	06.00-09.01		0 265 005 207
Pressure sensor, ESP, (electronic stability program)	06.00-09.01		0 265 005 303
Wheel speed sensor, rear	06.00-09.01	ALR,LAB	0 265 006 571
		ALR,RAB	0 265 006 569
		OLW	0 265 006 569
2.8 quattro [8D5; B5]	2,8 l 142 kW APR; AQD 6 Zyl.		
Phase sensor	08.98-06.00		0 232 101 024
Speed sensor, ignition/injection	08.98-06.00	AG	0 261 210 147
		GS	0 261 210 178
Knock sensor			
Fg.no. →8D..X..260 000	08.98-04.99		0 261 231 036
Temperature sensor, intake air, injection system	08.98-06.00		0 280 130 085
Lateral acceleration sensor, brake system	08.98-06.00		0 265 005 127
Duo sensor, acceleration and yaw rate, brake system	08.98-06.00		0 265 005 214
Yaw rate sensor, brake system	08.98-06.00		0 265 005 207



Wheel speed sensor, rear	08.98-06.00	ALR,LAB	0 265 006 571
		ALR,RAB	0 265 006 569
		OLW	0 265 006 569
2.8 quattro [8D5; B5]		2,8l 142 kW	ATQ 6 Zyl.
Phase sensor	08.99-09.01		0 232 101 024
Speed sensor, ignition/injection	08.99-09.01	AG	0 261 210 147
		GS	0 261 210 134
Temperature sensor, intake air, injection system	08.99-09.01		0 280 130 085
3.0 [8ED; B7]		3,0l 160 kW	BBJ 6 Zyl.
Throttle valve assembly	11.04-05.06		0 280 750 030
Speed sensor, ignition/injection	11.04-05.06	AG	0 261 210 147
		GS	0 261 210 178
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →8E..5..600 000	11.04-05.05		0 265 005 601
Fg.no. 8E..6..000 001→	06.05-05.06		0 265 005 621
Wheel speed sensor, front	11.04-05.06		0 265 006 809
Wheel speed sensor, rear	11.04-05.06	ALR,RAB	0 265 006 824
		OLW	0 265 006 824
3.0 [8E5; B6]		3,0l 160/162 kW	ASN; BBJ 6 Zyl.
Throttle valve assembly	09.01-12.04		0 280 750 030
Speed sensor, ignition/injection	09.01-12.04	AG	0 261 210 147
		GS	0 261 210 178
Duo sensor, acceleration and yaw rate, brake system	09.01-12.04		0 265 005 252
Pressure sensor, ESP, (electronic stability program)	09.01-12.04		0 265 005 303
Wheel speed sensor, front			
Fg.no. →8E..3..500 000	09.01-05.03		0 265 006 683
Fg.no. 8E..4..000 001→	06.03-12.04		0 265 006 809
Wheel speed sensor, rear			
Fg.no. →8E..4..050 000	09.01-05.04	ALR,LAB	0 265 006 707
Fg.no. →8E..4..400 000	09.01-05.04	ALR,RAB	0 265 006 681
		OLW	0 265 006 681
Fg.no. 8E..5..000 001→	06.04-12.04	ALR,LAB	0 265 006 826
		ALR,RAB	0 265 006 824
		OLW	0 265 006 824
3.0 quattro [8ED; B7]		3,0l 160 kW	BBJ 6 Zyl.
Throttle valve assembly	11.04-05.06		0 280 750 030
Speed sensor, ignition/injection	11.04-05.06	AG	0 261 210 147
		GS	0 261 210 178
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →8E..5..600 000	11.04-05.05		0 265 005 601
Fg.no. 8E..6..000 001→	06.05-05.06		0 265 005 621
Wheel speed sensor, front	11.04-05.06		0 265 006 809
Wheel speed sensor, rear	11.04-05.06	ALR,RAB	0 265 006 824
		OLW	0 265 006 824
3.0 quattro [8E5; B6]		3,0l 160/162 kW	ASN; BBJ 6 Zyl.
Throttle valve assembly	09.01-12.04		0 280 750 030
Speed sensor, ignition/injection	09.01-12.04	AG	0 261 210 147
		GS	0 261 210 178
Duo sensor, acceleration and yaw rate, brake system	09.01-12.04		0 265 005 252
Pressure sensor, ESP, (electronic stability program)	09.01-12.04		0 265 005 303
Wheel speed sensor, front			
Fg.no. →8E..3..500 000	09.01-05.03		0 265 006 683
Fg.no. 8E..4..000 001→	06.03-12.04		0 265 006 809
Wheel speed sensor, rear			
Fg.no. →8E..4..050 000	09.01-05.04	ALR,LAB	0 265 006 707
Fg.no. →8E..4..400 000	09.01-05.04	ALR,RAB	0 265 006 681
		OLW	0 265 006 681



Wheel speed sensor, rear			
Fg.no. 8E..5..000 001→	06.04-12.04	ALR,LAB	0 265 006 826
		ALR,RAB	0 265 006 824
		OLW	0 265 006 824
3.0 quattro [8E5; B6]		3,0l 162 kW	AVK 6 Zyl.
Throttle valve assembly	09.01-06.02		0 280 750 030
Speed sensor, ignition/injection	09.01-06.02	AG	0 261 210 147
		GS	0 261 210 178
Duo sensor, acceleration and yaw rate, brake system	09.01-06.02		0 265 005 252
Pressure sensor, ESP, (electronic stability program)	09.01-06.02		0 265 005 303
Wheel speed sensor, front	09.01-06.02		0 265 006 683
Wheel speed sensor, rear	09.01-06.02	ALR,LAB	0 265 006 707
		ALR,RAB	0 265 006 681
		OLW	0 265 006 681
3.0 TDI quattro [8ED; B7]		3,0l 150 kW	BKN 6 Zyl.
Speed sensor, diesel	01.05-05.06	FKW	0 261 210 145
High-pressure sensor (CR system)			
Fg.no. →8E..6..184 000, →8E..6..800 880	01.05-07.05		0 281 002 504
Boost pressure sensor, Diesel	01.05-05.06		0 281 002 401
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →8E..5..600 000	01.05-05.05		0 265 005 601
Fg.no. 8E..6..000 001→	06.05-05.06		0 265 005 621
Wheel speed sensor, front	01.05-05.06		0 265 006 809
Wheel speed sensor, rear	01.05-05.06	ALR,RAB	0 265 006 824
		OLW	0 265 006 824
3.0 TDI quattro [8ED; B7]		3,0l 171 kW	ASB 6 Zyl.
Speed sensor, diesel	01.06→	FKW	0 261 210 145
Boost pressure sensor, Diesel	01.06→		0 281 002 401
Duo sensor, acceleration and yaw rate, brake system	01.06→		0 265 005 621
Wheel speed sensor, front	01.06→		0 265 006 809
Wheel speed sensor, rear	01.06→	ALR,RAB	0 265 006 824
		OLW	0 265 006 824
3.2, FSI quattro [8ED; B7]		3,2l 188 kW	AUK 6 Zyl.
Throttle valve assembly	01.05→		0 280 750 003
Pressure sensor, intake manifold, gasoline	01.05→		0 261 230 095
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →8E..5..600 000	01.05-05.05		0 265 005 601
Fg.no. 8E..6..000 001→	06.05→		0 265 005 621
Wheel speed sensor, front	01.05→		0 265 006 809
Wheel speed sensor, rear	01.05→	ALR,RAB	0 265 006 824
		OLW	0 265 006 824

A4 Cabriolet

1.8 T [8HE; B7]		1,8l 120 kW	BFB 4 Zyl.
Throttle valve assembly	01.06→		0 280 750 009
Air mass meter, gasoline injection	01.06→		0 280 218 063
			0 986 280 217
Phase sensor	01.06→		0 232 101 024
Speed sensor, ignition/injection	01.06→		0 281 002 222
Boost pressure sensor, gasoline	01.06→		0 261 230 073
Temperature sensor, intake air, injection system	01.06→		0 280 130 085
Duo sensor, acceleration and yaw rate, brake system	01.06→		0 265 005 621
Wheel speed sensor, front	01.06→		0 265 006 809
Wheel speed sensor, rear	01.06→	ALR,RAB	0 265 006 824
		OLW	0 265 006 824

Product				
◀ A4 Cabriolet				
1.8 T [8H7; B6]		1,8l 120 kW BFB 4 Zyl.		
Throttle valve assembly	04.02-12.05			0 280 750 009
Air mass meter, gasoline injection	04.02-12.05			0 280 218 063 🔧 0 986 280 217
Phase sensor	04.02-12.05			0 232 101 024
Speed sensor, ignition/injection	04.02-12.05			0 281 002 222
Boost pressure sensor, gasoline	04.02-12.05			0 261 230 073
Temperature sensor, intake air, injection system	04.02-12.05			0 280 130 085
Duo sensor, acceleration and yaw rate, brake system	04.02-12.05			0 265 005 252
Pressure sensor, ESP, (electronic stability program)	04.02-12.05			0 265 005 303
Wheel speed sensor, front				
Fg.no. →8E..3..500 000	04.02-05.03			0 265 006 683
Fg.no. 8E..4..000 001→	06.03-12.05			0 265 006 809
Wheel speed sensor, rear				
Fg.no. →8E..4..050 000	04.02-05.04	ALR,LAB		0 265 006 707
Fg.no. →8E..4..400 000	04.02-05.04	ALR,RAB		0 265 006 681
		OLW		0 265 006 681
Fg.no. 8E..5..000 001→	06.04-12.05	ALR,LAB		0 265 006 826
		ALR,RAB		0 265 006 824
		OLW		0 265 006 824
1.8 T [8H7; B6]		1,8l 125 kW AMB 4 Zyl.		
Throttle valve assembly	10.02-06.06			0 280 750 009
Air mass meter, gasoline injection	10.02-06.06			0 280 218 063 🔧 0 986 280 217
Phase sensor	10.02-06.06			0 232 101 024
Speed sensor, ignition/injection	10.02-06.06			0 281 002 222
Boost pressure sensor, gasoline	10.02-06.06			0 261 230 073
Temperature sensor, intake air, injection system	10.02-06.06			0 280 130 085
Wheel speed sensor, front				
Fg.no. →8H..3..050 000	10.02-05.03			0 265 006 683
Fg.no. 8H..4..000 001→	06.03-06.06			0 265 006 809
Wheel speed sensor, rear				
Fg.no. →8H..4..050 000,→8H..4..902 000, PR no. 8Q3	10.02-05.04	LAB		0 265 006 707
Fg.no. →8H..6..007 938,→8H..6..900 601, PR no. 8Q0,PR no. 8Q1	10.02-04.06	LAB,RAB		0 265 006 681
Fg.no. →8H..6..007 938,→8H..6..900 601, PR no. 8Q3	10.02-04.06	RAB		0 265 006 681
Fg.no. 8H..5..000 001→,8H..5..900 001→, PR no. 8Q3	06.04-06.06	LAB		0 265 006 826
Fg.no. 8H..6..007 939→,8H..6..900 602→, PR no. 8Q0,PR no. 8Q1	05.06-06.06	LAB,RAB		0 265 006 824
Fg.no. 8H..6..007 939→,8H..6..900 602→, PR no. 8Q3	05.06-06.06	RAB		0 265 006 824
1.8 T quattro [8H7; B6]		1,8l 120 kW BFB 4 Zyl.		
Throttle valve assembly	07.02-12.05			0 280 750 009
Air mass meter, gasoline injection	07.02-12.05			0 280 218 063 🔧 0 986 280 217
Phase sensor	07.02-12.05			0 232 101 024
Speed sensor, ignition/injection	07.02-12.05			0 281 002 222
Boost pressure sensor, gasoline	07.02-12.05			0 261 230 073
Temperature sensor, intake air, injection system	07.02-12.05			0 280 130 085
Duo sensor, acceleration and yaw rate, brake system	07.02-12.05			0 265 005 252
Pressure sensor, ESP, (electronic stability program)	07.02-12.05			0 265 005 303
Wheel speed sensor, front				
Fg.no. →8E..3..500 000	07.02-05.03			0 265 006 683
Fg.no. 8E..4..000 001→	06.03-12.05			0 265 006 809
Wheel speed sensor, rear				
Fg.no. →8E..4..050 000	07.02-05.04	ALR,LAB		0 265 006 707
Fg.no. →8E..4..400 000	07.02-05.04	ALR,RAB		0 265 006 681
		OLW		0 265 006 681

Product				
Wheel speed sensor, rear				
Fg.no. 8E..5..000 001→	06.04-12.05	ALR,LAB		0 265 006 826
		ALR,RAB		0 265 006 824
		OLW		0 265 006 824
2.0 [8H7; B6]		2,0l 96 kW ALT 4 Zyl.		
Throttle valve assembly	05.04-12.05			0 280 750 088
Air mass meter, gasoline injection	05.04-12.05			0 280 218 058 🔧 0 986 280 215
Phase sensor	05.04-12.05			0 232 101 024
Speed sensor, ignition/injection	05.04-12.05			0 281 002 222
Temperature sensor, intake air, injection system	05.04-12.05			0 280 130 116
Duo sensor, acceleration and yaw rate, brake system	05.04-12.05			0 265 005 252
Pressure sensor, ESP, (electronic stability program)	05.04-12.05			0 265 005 303
Wheel speed sensor, front	05.04-12.05			0 265 006 809
Wheel speed sensor, rear	05.04-12.05	ALR,LAB		0 265 006 826
		ALR,RAB		0 265 006 824
		OLW		0 265 006 824
2.0 TDI [8HE; B7]		2,0l 100/103 kW BPW; BRC 4 Zyl.		
Air mass meter, diesel	01.06→			0 281 002 461 🔧 0 986 284 007
Boost pressure sensor, Diesel	01.06→			0 281 002 401
Duo sensor, acceleration and yaw rate, brake system	01.06→			0 265 005 621
Wheel speed sensor, front	01.06→			0 265 006 809
Wheel speed sensor, rear	01.06→	ALR,RAB		0 265 006 824
		OLW		0 265 006 824
2.0 TFSI [8HE; B7]		2,0l 147 kW BWE 4 Zyl.		
Speed sensor, ignition/injection	01.06→			0 261 210 199
Knock sensor	01.06→			0 261 231 146
Boost pressure sensor, gasoline	01.06→			0 261 230 073
Duo sensor, acceleration and yaw rate, brake system	01.06→			0 265 005 621
Wheel speed sensor, front	01.06→			0 265 006 809
Wheel speed sensor, rear	01.06→	ALR,RAB		0 265 006 824
		OLW		0 265 006 824
2.4 [8H7; B6]		2,4l 120 kW AMM 6 Zyl.		
Throttle valve assembly	04.02-12.05			0 280 750 030
Phase sensor	04.02-12.05			0 232 101 024
Speed sensor, ignition/injection	04.02-12.05			0 261 210 178
Temperature sensor, intake air, injection system	04.02-12.05			0 280 130 116
Duo sensor, acceleration and yaw rate, brake system	04.02-12.05			0 265 005 252
Pressure sensor, ESP, (electronic stability program)	04.02-12.05			0 265 005 303
Wheel speed sensor, front				
Fg.no. →8E..3..500 000	04.02-05.03			0 265 006 683
Fg.no. 8E..4..000 001→	06.03-12.05			0 265 006 809
Wheel speed sensor, rear				
Fg.no. →8E..4..050 000	04.02-05.04	ALR,LAB		0 265 006 707
Fg.no. →8E..4..400 000	04.02-05.04	ALR,RAB		0 265 006 681
		OLW		0 265 006 681
Fg.no. 8E..5..000 001→	06.04-12.05	ALR,LAB		0 265 006 826
		ALR,RAB		0 265 006 824
		OLW		0 265 006 824
2.4 [8H7; B6]		2,4l 125 kW BDV 6 Zyl.		
Phase sensor	04.02-12.05			0 232 101 024
Speed sensor, ignition/injection	04.02-12.05			0 261 210 178
Duo sensor, acceleration and yaw rate, brake system	04.02-12.05			0 265 005 252
Pressure sensor, ESP, (electronic stability program)	04.02-12.05			0 265 005 303
Wheel speed sensor, front				
Fg.no. →8E..3..500 000	04.02-05.03			0 265 006 683
Fg.no. 8E..4..000 001→	06.03-12.05			0 265 006 809





Wheel speed sensor, rear			
Fg.no. →8E..4..050 000	04.02-05.04	ALR,LAB	0 265 006 707
Fg.no. →8E..4..400 000	04.02-05.04	ALR,RAB	0 265 006 681
		OLW	0 265 006 681
Fg.no. 8E..5..000 001→	06.04-12.05	ALR,LAB	0 265 006 826
		ALR,RAB	0 265 006 824
		OLW	0 265 006 824
2.5 TDI [8H7; B6]	2,5 l	120 kW BCZ; BDG	6 Zyl.
Speed sensor, diesel	06.03-12.05		0 281 002 222
Boost pressure sensor, Diesel	06.03-12.05		0 281 002 399
Duo sensor, acceleration and yaw rate, brake system	06.03-12.05		0 265 005 252
Pressure sensor, ESP, (electronic stability program)	06.03-12.05		0 265 005 303
Wheel speed sensor, front	06.03-12.05		0 265 006 809
Wheel speed sensor, rear			
Fg.no. →8E..4..050 000	06.03-05.04	ALR,LAB	0 265 006 707
Fg.no. →8E..4..400 000	06.03-05.04	ALR,RAB	0 265 006 681
		OLW	0 265 006 681
Fg.no. 8E..5..000 001→	06.04-12.05	ALR,LAB	0 265 006 826
		ALR,RAB	0 265 006 824
		OLW	0 265 006 824
2.5 TDI [8H7; B6]	2,5 l	120 kW BFC	6 Zyl.
Speed sensor, diesel	08.02-05.03		0 281 002 222
Boost pressure sensor, Diesel	08.02-05.03		0 281 002 399
Duo sensor, acceleration and yaw rate, brake system	08.02-05.03		0 265 005 252
Pressure sensor, ESP, (electronic stability program)	08.02-05.03		0 265 005 303
Wheel speed sensor, front	08.02-05.03		0 265 006 683
Wheel speed sensor, rear	08.02-05.03	ALR,LAB	0 265 006 707
		ALR,RAB	0 265 006 681
		OLW	0 265 006 681
2.7 TDI [8HE; B7]	2,7 l	132 kW BPP	6 Zyl.
Speed sensor, diesel	11.05→	FKW	0 261 210 145
Boost pressure sensor, Diesel	11.05→		0 281 002 401
Duo sensor, acceleration and yaw rate, brake system	11.05→		0 265 005 621
Wheel speed sensor, front	11.05→		0 265 006 809
Wheel speed sensor, rear	11.05→	ALR,RAB	0 265 006 824
		OLW	0 265 006 824
3.0 [8H7; B6]	3,0 l	160/162 kW ASN; BBJ	6 Zyl.
Throttle valve assembly	04.02-12.05		0 280 750 030
Speed sensor, ignition/injection	04.02-12.05	AG	0 261 210 147
		GS	0 261 210 178
Duo sensor, acceleration and yaw rate, brake system	04.02-12.05		0 265 005 252
Pressure sensor, ESP, (electronic stability program)	04.02-12.05		0 265 005 303
Wheel speed sensor, front			
Fg.no. →8E..3..500 000	04.02-05.03		0 265 006 683
Fg.no. 8E..4..000 001→	06.03-12.05		0 265 006 809
Wheel speed sensor, rear			
Fg.no. →8E..4..050 000	04.02-05.04	ALR,LAB	0 265 006 707
Fg.no. →8E..4..400 000	04.02-05.04	ALR,RAB	0 265 006 681
		OLW	0 265 006 681
Fg.no. 8E..5..000 001→	06.04-12.05	ALR,LAB	0 265 006 826
		ALR,RAB	0 265 006 824
		OLW	0 265 006 824
3.0 quattro [8H7; B6]	3,0 l	162 kW ASN	6 Zyl.
Throttle valve assembly	06.03-12.05		0 280 750 030
Speed sensor, ignition/injection	06.03-12.05	AG	0 261 210 147
		GS	0 261 210 178
Duo sensor, acceleration and yaw rate, brake system	06.03-12.05		0 265 005 252



Pressure sensor, ESP, (electronic stability program)	06.03-12.05		0 265 005 303
Wheel speed sensor, front	06.03-12.05		0 265 006 809
Wheel speed sensor, rear			
Fg.no. →8E..4..050 000	06.03-05.04	ALR,LAB	0 265 006 707
Fg.no. →8E..4..400 000	06.03-05.04	ALR,RAB	0 265 006 681
		OLW	0 265 006 681
Fg.no. 8E..5..000 001→	06.04-12.05	ALR,LAB	0 265 006 826
		ALR,RAB	0 265 006 824
		OLW	0 265 006 824
3.0 quattro [8H7; B6]	3,0 l	162 kW BGN	6 Zyl.
Throttle valve assembly	06.04-06.06		0 280 750 030
Speed sensor, ignition/injection	06.04-06.06	AG	0 261 210 147
		GS	0 261 210 178
Duo sensor, acceleration and yaw rate, brake system	06.04-06.06		0 265 005 252
Pressure sensor, ESP, (electronic stability program)	06.04-06.06		0 265 005 303
Wheel speed sensor, front	06.04-06.06		0 265 006 809
Wheel speed sensor, rear			
Fg.no. →8H..6..007 938, →8H..6..900 601, PR no. 8Q3	06.04-04.06	RAB	0 265 006 681
Fg.no. 8H..6..007 939→, 8H..6..900 602→, PR no. 8Q0, PR no. 8Q1	05.06-06.06	LAB,RAB	0 265 006 824
Fg.no. 8H..6..007 939→, 8H..6..900 602→, PR no. 8Q3	05.06-06.06	RAB	0 265 006 824
PR no. 8Q3	06.04-06.06	LAB	0 265 006 826
3.0 TDI quattro [8HE; B7]	3,0 l	150/171 kW ASB; BKN	6 Zyl.
Speed sensor, diesel	01.06→	FKW	0 261 210 145
Boost pressure sensor, Diesel	01.06→		0 281 002 401
Duo sensor, acceleration and yaw rate, brake system	01.06→		0 265 005 621
Pressure sensor, ESP, (electronic stability program)	01.06→		0 265 005 303
Wheel speed sensor, front	01.06→		0 265 006 809
Wheel speed sensor, rear	01.06→	ALR,RAB	0 265 006 824
		OLW	0 265 006 824
3.2 FSI, FSI quattro [8HE; B7]	3,2 l	188 kW AUK	6 Zyl.
Throttle valve assembly	01.06→		0 280 750 003
Pressure sensor, intake manifold, gasoline	01.06→		0 261 230 095
Duo sensor, acceleration and yaw rate, brake system	01.06→		0 265 005 621
Pressure sensor, ESP, (electronic stability program)	01.06→		0 265 005 303
Wheel speed sensor, front	01.06→		0 265 006 809
Wheel speed sensor, rear	01.06→	ALR,RAB	0 265 006 824
		OLW	0 265 006 824
4.2 quattro [8HE; B7]	4,2 l	253 kW BHF	8 Zyl.
Throttle valve assembly	08.06→		0 280 750 003
Air mass meter, gasoline injection	08.06→		0 280 218 067
			0 986 280 219
Speed sensor, ignition/injection	08.06→		0 261 210 190
Duo sensor, acceleration and yaw rate, brake system	08.06→		0 265 005 621
Pressure sensor, ESP, (electronic stability program)	08.06→		0 265 005 303
Wheel speed sensor, front	08.06→		0 265 006 809
Wheel speed sensor, rear	08.06→	RAB	0 265 006 824
4.2 quattro [8H7; B6]	4,2 l	253 kW BBK	8 Zyl.
Throttle valve assembly	02.04-12.05		0 280 750 003
Air mass meter, gasoline injection	02.04-12.05		0 280 218 067
			0 986 280 219
Speed sensor, ignition/injection	02.04-12.05		0 261 210 190
Pressure sensor, ESP, (electronic stability program)	02.04-12.05		0 265 005 303





Product

A5 Coupé				
1.8 TFSI [8T3]		1,8l 125 kW CABD 4 Zyl.		
Duo sensor, acceleration and yaw rate, brake system	10.07→			0 265 005 668
Wheel speed sensor	10.07→	LAB		0 265 007 930
		RAB		0 265 007 928
2.7 TDI [8T3]		2,7l 140 kW CAMA 6 Zyl.		
Boost pressure sensor, Diesel	07.07→			0 281 002 401
Duo sensor, acceleration and yaw rate, brake system	07.07→			0 265 005 668
Wheel speed sensor	07.07→	LAB		0 265 007 930
		RAB		0 265 007 928
3.0 TDI quattro [8T3]		3,0l 176 kW CAPA 6 Zyl.		
Boost pressure sensor, Diesel	06.07→			0 281 002 401
Duo sensor, acceleration and yaw rate, brake system	06.07→			0 265 005 668
Wheel speed sensor	06.07→	LAB		0 265 007 930
		RAB		0 265 007 928
3.2 FSI [8T3]		3,2l 195 kW CALA 6 Zyl.		
Pressure sensor, intake manifold, gasoline	06.07→			0 261 230 095
Duo sensor, acceleration and yaw rate, brake system	06.07→			0 265 005 668
Wheel speed sensor	06.07→	LAB		0 265 007 930
		RAB		0 265 007 928
3.2 FSI quattro [8T3]		3,2l 195 kW CALA 6 Zyl.		
Pressure sensor, intake manifold, gasoline	11.07→			0 261 230 095
Duo sensor, acceleration and yaw rate, brake system	11.07→			0 265 005 668
Wheel speed sensor	11.07→	LAB		0 265 007 930
		RAB		0 265 007 928
A6				
1.8 [C5]		1,8l 92 kW ANQ 4 Zyl.		
Air mass meter, gasoline injection	09.99-10.05			0 280 218 013
				0 986 280 206
Phase sensor	09.99-10.05			0 232 101 024
Speed sensor, ignition/injection	09.99-10.05	FKW		0 261 210 147
Knock sensor	09.99-10.05	HI,KZB		0 261 231 036
		KZG,VO		0 261 231 038
1.8 [4A2; C4]		1,8l 92 kW ADR 4 Zyl.		
Phase sensor	06.94-10.97			0 232 101 024
Knock sensor	06.94-10.97	LLE		0 261 231 038
		RLE		0 261 231 036
Temperature sensor, intake air, injection system	06.94-10.97			0 280 130 085
1.8 [4B2; C5]		1,8l 85 kW AFY 4 Zyl.		
Phase sensor	05.97-05.00			0 232 101 024
Knock sensor	05.97-05.00	HI		0 261 231 036
		VO		0 261 231 038
Temperature sensor, intake air, injection system	05.97-05.00			0 280 130 085
Duo sensor, acceleration and yaw rate, brake system	05.97-05.00			0 265 005 214
1.8 [4B2; C5]		1,8l 92 kW AJP 4 Zyl.		
Phase sensor	12.97-07.99			0 232 101 024
Speed sensor, ignition/injection	12.97-07.99			0 261 210 147
Knock sensor	12.97-07.99	HI		0 261 231 036
		VO		0 261 231 038
Temperature sensor, intake air, injection system	12.97-07.99			0 280 130 085
Duo sensor, acceleration and yaw rate, brake system	12.97-07.99			0 265 005 214

Product

1.8 [4B2; C5]		1,8l 92 kW AQE; ARH 4 Zyl.	
Throttle valve assembly			
Fg.no. 4B..X..124 001→	05.99-04.01	0 280 750 080	
Air mass meter, gasoline injection	01.99-04.01	0 280 218 013	
		0 986 280 206	
Phase sensor	01.99-04.01	0 232 101 024	
Speed sensor, ignition/injection	01.99-04.01	0 261 210 147	
Knock sensor	01.99-04.01	HI	0 261 231 036
		VO	0 261 231 038
Temperature sensor, intake air, injection system	01.99-04.01	0 280 130 085	
Duo sensor, acceleration and yaw rate, brake system	01.99-04.01	0 265 005 214	
Pressure sensor, ESP, (electronic stability program)	01.99-04.01	0 265 005 303	
1.8 quattro [4A2; C4]		1,8l 92 kW ADR 4 Zyl.	
Phase sensor	10.95-10.97	0 232 101 024	
Knock sensor	10.95-10.97	KZB	0 261 231 036
		KZG	0 261 231 038
1.8 T [4B2; C5]		1,8l 110 kW AEB 4 Zyl.	
Air mass meter, gasoline injection			
Fg.no. →4B..W..080 000	04.97-11.97	0 280 217 112	
Fg.no. 4B..W..080 000→	11.97-01.99	0 280 217 117	
		0 986 280 201	
Phase sensor	04.97-01.99	0 232 101 024	
Knock sensor	04.97-01.99	HI	0 261 231 036
		VO	0 261 231 038
Pressure sensor, intake manifold, gasoline	04.97-01.99	0 280 101 001	
Boost pressure sensor, gasoline	04.97-01.99	0 281 002 177	
Temperature sensor, intake air, injection system	04.97-01.99	0 280 130 085	
Duo sensor, acceleration and yaw rate, brake system	04.97-01.99	0 265 005 214	
1.8 T [4B2; C5]		1,8l 110 kW ANB 4 Zyl.	
Throttle valve assembly			
	01.99-09.00	0 280 750 009	
Air mass meter, gasoline injection	01.99-09.00	0 280 218 032	
		0 986 280 210	
Phase sensor	01.99-09.00	0 232 101 024	
Knock sensor	01.99-09.00	HI	0 261 231 036
		VO	0 261 231 038
Boost pressure sensor, gasoline	01.99-09.00	0 281 002 177	
Temperature sensor, intake air, injection system	01.99-09.00	0 280 130 085	
Duo sensor, acceleration and yaw rate, brake system	01.99-09.00	0 265 005 214	
1.8 T [4B2; C5]		1,8l 110 kW APU 4 Zyl.	
Throttle valve assembly			
	11.98-04.01	0 280 750 009	
Air mass meter, gasoline injection	11.98-04.01	0 280 218 032	
		0 986 280 210	
Phase sensor	11.98-04.01	0 232 101 024	
Knock sensor	11.98-04.01	HI	0 261 231 036
		VO	0 261 231 038
Boost pressure sensor, gasoline	11.98-04.01	0 281 002 177	
Temperature sensor, intake air, injection system	11.98-04.01	0 280 130 085	
Duo sensor, acceleration and yaw rate, brake system	11.98-04.01	0 265 005 214	
Pressure sensor, ESP, (electronic stability program)	11.98-04.01	0 265 005 303	
1.8 T [4B2; C5]		1,8l 110 kW ARK 4 Zyl.	
Throttle valve assembly			
	01.99-05.99	0 280 750 009	
Air mass meter, gasoline injection	01.99-05.99	0 280 218 032	
		0 986 280 210	
Phase sensor	01.99-05.99	0 232 101 024	
Knock sensor	01.99-05.99	HI	0 261 231 036
		VO	0 261 231 038
Boost pressure sensor, gasoline	01.99-05.99	0 281 002 177	
Temperature sensor, intake air, injection system	01.99-05.99	0 280 130 085	



Duo sensor, acceleration and yaw rate, brake system	01.99-05.99		0 265 005 214
1.8 T [4B2; C5]		1,8l 110 kW AWT 4 Zyl.	
Throttle valve assembly	05.00-04.01		0 280 750 009
Air mass meter, gasoline injection	05.00-04.01		0 280 218 063 0 986 280 217
Phase sensor	05.00-04.01		0 232 101 024
Speed sensor, ignition/injection	05.00-04.01		0 281 002 222
Knock sensor	05.00-04.01	HI	0 261 231 036
		VO	0 261 231 038
Boost pressure sensor, gasoline	05.00-04.01		0 281 002 177
Temperature sensor, intake air, injection system	05.00-04.01		0 280 130 085
Duo sensor, acceleration and yaw rate, brake system	05.00-04.01		0 265 005 214
Pressure sensor, ESP, (electronic stability program)	05.00-04.01		0 265 005 303
1.8 T [4B2; C5]		1,8l 132 kW AJL 4 Zyl.	
Air mass meter, gasoline injection	11.97-10.00		0 280 217 117 0 986 280 201
Phase sensor	11.97-10.00		0 232 101 024
Knock sensor	11.97-10.00	HI	0 261 231 036
		VO	0 261 231 038
Pressure sensor, intake manifold, gasoline	11.97-10.00		0 280 101 001
Boost pressure sensor, gasoline	11.97-10.00		0 281 002 177
Temperature sensor, intake air, injection system	11.97-10.00		0 280 130 085
Duo sensor, acceleration and yaw rate, brake system	11.97-10.00		0 265 005 214
1.8 T quattro [4B2; C5]		1,8l 110 kW AEB 4 Zyl.	
Air mass meter, gasoline injection			
Fg.no. →4B..W..080 000	04.97-11.97		0 280 217 112
Fg.no. 4B..W..080 000→	11.97-01.99		0 280 217 117 0 986 280 201
Phase sensor	04.97-01.99		0 232 101 024
Knock sensor	04.97-01.99	HI	0 261 231 036
		VO	0 261 231 038
Pressure sensor, intake manifold, gasoline	04.97-01.99		0 280 101 001
Boost pressure sensor, gasoline	04.97-01.99		0 281 002 177
Temperature sensor, intake air, injection system	04.97-01.99		0 280 130 085
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. 4B..X..026 001→	10.98-01.99		0 265 005 214
Yaw rate sensor, brake system			
Fg.no. →4B..X..026 000	04.97-10.98		0 265 005 207
Wheel speed sensor, rear			
Fg.no. 4B..X..062 732→	12.98-01.99	ALR,LAB	0 265 006 586
		ALR,RAB	0 265 006 584
		OLW	0 265 006 584
1.8 T quattro [4B2; C5]		1,8l 110 kW ANB 4 Zyl.	
Throttle valve assembly	01.99-09.00		0 280 750 009
Air mass meter, gasoline injection	01.99-09.00		0 280 218 032 0 986 280 210
Phase sensor	01.99-09.00		0 232 101 024
Knock sensor	01.99-09.00	HI	0 261 231 036
		VO	0 261 231 038
Boost pressure sensor, gasoline	01.99-09.00		0 281 002 177
Temperature sensor, intake air, injection system	01.99-09.00		0 280 130 085
Duo sensor, acceleration and yaw rate, brake system	01.99-09.00		0 265 005 214
Wheel speed sensor, rear	01.99-09.00	ALR,LAB	0 265 006 586
		ALR,RAB	0 265 006 584
		OLW	0 265 006 584



1.8 T quattro [4B2; C5]		1,8l 110 kW APU 4 Zyl.	
Throttle valve assembly	11.98-05.01		0 280 750 009
Air mass meter, gasoline injection	11.98-05.01		0 280 218 032 0 986 280 210
Phase sensor	11.98-05.01		0 232 101 024
Knock sensor	11.98-05.01	HI	0 261 231 036
		VO	0 261 231 038
Boost pressure sensor, gasoline	11.98-05.01		0 281 002 177
Temperature sensor, intake air, injection system	11.98-05.01		0 280 130 085
Duo sensor, acceleration and yaw rate, brake system	11.98-05.01		0 265 005 214
Pressure sensor, ESP, (electronic stability program)	11.98-05.01		0 265 005 303
Wheel speed sensor, rear			
Fg.no. 4B..X..062 732→	12.98-05.01	ALR,LAB	0 265 006 586
		ALR,RAB	0 265 006 584
		OLW	0 265 006 584
1.8 T quattro [4B2; C5]		1,8l 110 kW ARK 4 Zyl.	
Throttle valve assembly	01.99-05.99		0 280 750 009
Air mass meter, gasoline injection	01.99-05.99		0 280 218 032 0 986 280 210
Phase sensor	01.99-05.99		0 232 101 024
Knock sensor	01.99-05.99	HI	0 261 231 036
		VO	0 261 231 038
Boost pressure sensor, gasoline	01.99-05.99		0 281 002 177
Temperature sensor, intake air, injection system	01.99-05.99		0 280 130 085
Duo sensor, acceleration and yaw rate, brake system	01.99-05.99		0 265 005 214
Wheel speed sensor, rear	01.99-05.99	ALR,LAB	0 265 006 586
		ALR,RAB	0 265 006 584
1.8 T quattro [4B2; C5]		1,8l 110 kW AWT 4 Zyl.	
Throttle valve assembly	05.00-05.04		0 280 750 009
Air mass meter, gasoline injection	05.00-05.04		0 280 218 063 0 986 280 217
Phase sensor	05.00-05.04		0 232 101 024
Speed sensor, ignition/injection	05.00-05.04		0 281 002 222
Knock sensor	05.00-05.04	HI	0 261 231 036
		VO	0 261 231 038
Boost pressure sensor, gasoline	05.00-05.04		0 281 002 177
Temperature sensor, intake air, injection system	05.00-05.04		0 280 130 085
Duo sensor, acceleration and yaw rate, brake system	05.00-05.01		0 265 005 214
Pressure sensor, ESP, (electronic stability program)	06.01-05.04		0 265 005 252
Wheel speed sensor, front			
Fg.no. 4B..2..031 501→4B..2..200 000	09.01-06.02		0 265 006 578
Fg.no. 4B..3..000 001→	07.02-05.04		0 265 006 765
Wheel speed sensor, rear	05.00-05.04	OLW	0 265 006 761
Fg.no. →4B..2..079 500	05.00-12.01	ALR,LAB	0 265 006 586
		ALR,RAB	0 265 006 584
		OLW	0 265 006 584
Fg.no. 4B..2..079 501→	12.01-05.04	ALR,LAB	0 265 006 763
		ALR,RAB	0 265 006 761
		OLW	0 265 006 761
1.8 T quattro [4B2; C5]		1,8l 132 kW AJL 4 Zyl.	
Air mass meter, gasoline injection	06.97-10.00		0 280 217 117 0 986 280 201
Phase sensor	06.97-10.00		0 232 101 024
Knock sensor	06.97-10.00	HI	0 261 231 036
		VO	0 261 231 038
Pressure sensor, intake manifold, gasoline	06.97-10.00		0 280 101 001
Boost pressure sensor, gasoline	06.97-10.00		0 281 002 177
Temperature sensor, intake air, injection system	06.97-10.00		0 280 130 085



Product				
◀ A6				
Duo sensor, acceleration and yaw rate, brake system				
Fg.no. 4B..X..026 001→	10.98-10.00			0 265 005 214
Yaw rate sensor, brake system				
Fg.no. →4B..X..026 000	06.97-10.98			0 265 005 207
Wheel speed sensor, rear				
Fg.no. 4B..X..062 732→	12.98-10.00	ALR,LAB	0 265 006 586	
		ALR,RAB	0 265 006 584	
		OLW	0 265 006 584	
1.8 Turbo [C5]		1,8l	110 kW	AWL 4 Zyl.
Throttle valve assembly	07.00-09.06			0 280 750 009
Air mass meter, gasoline injection	07.00-09.06			0 280 218 063
				0 986 280 217
Phase sensor	07.00-09.06			0 232 101 024
Speed sensor, ignition/injection	07.00-09.06	FKW	0 261 210 147	
Knock sensor	07.00-09.06	HI,KZB	0 261 231 036	
		KZG,VO	0 261 231 038	
Temperature sensor, intake air, injection system	07.00-09.06			0 280 130 116
1.9 TDI [4A2; C4]		1,9l	66 kW	1Z 4 Zyl.
Pedal position sensor, diesel				
Fg.no. →4A..S..082 000	06.94-02.95	AG	0 205 001 018	
		GS	0 205 001 017	
Fg.no. 4A..S..082 001→	02.95-09.96	AG	0 205 001 031	
		GS	0 205 001 032	
1.9 TDI [4B2; C5]		1,9l	81 kW	AFN 4 Zyl.
Air mass meter, diesel	04.97-08.99			0 281 002 216
				0 986 284 001
Boost pressure sensor, Diesel	04.97-08.99			0 281 002 177
Pedal position sensor, diesel				
Fg.no. →4B..X..200 000	04.97-06.99	AG	0 281 002 289	
		GS	0 281 002 286	
Duo sensor, acceleration and yaw rate, brake system	04.97-08.99			0 265 005 214
1.9 TDI [4B2; C5]		1,9l	81 kW	AVG 4 Zyl.
Air mass meter, diesel	08.99-10.00			0 281 002 216
				0 986 284 001
Boost pressure sensor, Diesel	08.99-10.00			0 281 002 177
Duo sensor, acceleration and yaw rate, brake system	08.99-10.00			0 265 005 214
1.9 TDI [4B2; C5]		1,9l	85 kW	AJM 4 Zyl.
Air mass meter, diesel	05.99-04.01			0 281 002 216
				0 986 284 001
Boost pressure sensor, Diesel	05.99-04.01			0 281 002 177
Pedal position sensor, diesel				
Fg.no. →4B..X..200 000	05.99-06.99	AG	0 281 002 289	
		GS	0 281 002 286	
Duo sensor, acceleration and yaw rate, brake system	05.99-04.01			0 265 005 214
Pressure sensor, ESP, (electronic stability program)	05.99-04.01			0 265 005 303
1.9 TDI [4B2; C5]		1,9l	96 kW	AVF; AWX 4 Zyl.
Air mass meter, diesel	06.01-05.04			0 281 002 461
				0 986 284 007
Boost pressure sensor, Diesel	06.01-05.04			0 281 002 401
Duo sensor, acceleration and yaw rate, brake system	06.01-05.04			0 265 005 252
Pressure sensor, ESP, (electronic stability program)	06.01-05.04			0 265 005 303
Wheel speed sensor, front				
Fg.no. 4B..2..031 501→4B..2..200 000	09.01-06.02			0 265 006 578
Fg.no. 4B..3..000 001→	07.02-05.04			0 265 006 765
2.0 [4A2; C4]		2,0l	85 kW	ABK 4 Zyl.
Knock sensor	06.94-08.96	LLE	0 261 231 038	
		RLE	0 261 231 036	

Product				
2.0 [4A2; C4]		2,0l	103 kW	ACE 4 Zyl.
Throttle valve sensor	06.94-10.97			0 280 120 426
Air flow sensor, gasoline injection	06.94-10.97			0 986 439 389
				F 026 TX2 059
				0 986 439 389
Knock sensor	06.94-10.97	LLE	0 261 231 038	
		RLE	0 261 231 036	
2.0 [4B2; C5]		2,0l	96 kW	ALT 4 Zyl.
Throttle valve assembly	06.01-05.04			0 280 750 088
Air mass meter, gasoline injection	06.01-05.04			0 280 218 058
				0 986 280 215
Phase sensor	06.01-05.04			0 232 101 024
Speed sensor, ignition/injection	06.01-05.04			0 281 002 222
Temperature sensor, intake air, injection system	06.01-05.04			0 280 130 116
Duo sensor, acceleration and yaw rate, brake system	06.01-05.04			0 265 005 252
Pressure sensor, ESP, (electronic stability program)	06.01-05.04			0 265 005 303
Wheel speed sensor, front				
Fg.no. 4B..2..031 501→4B..2..200 000	09.01-06.02			0 265 006 578
Fg.no. 4B..3..000 001→	07.02-05.04			0 265 006 765
2.0 quattro [4A2; C4]		2,0l	103 kW	ACE 4 Zyl.
Throttle valve sensor	06.94-10.97			0 280 120 426
Air flow sensor, gasoline injection	06.94-10.97			0 986 439 389
				F 026 TX2 059
				0 986 439 389
Phase sensor	06.94-10.97			0 232 101 024
Knock sensor	06.94-10.97	KZB	0 261 231 036	
		KZG	0 261 231 038	
2.0 TDI [4F2; C6]		2,0l	89 kW	BVG 4 Zyl.
Air mass meter, diesel	09.05-06.06			0 281 002 461
				0 986 284 007
Boost pressure sensor, Diesel	09.05-06.06			0 281 002 401
Duo sensor, acceleration and yaw rate, brake system	09.05-06.06			0 265 005 692
Wheel speed sensor				
Fg.no. 4F..6..140 001→	02.06-06.06	LAB	0 265 007 930	
		RAB	0 265 007 928	
2.0 TDI [4F2; C6]		2,0l	100 kW	BNA 4 Zyl.
Air mass meter, diesel	07.04-11.05			0 281 002 461
				0 986 284 007
Boost pressure sensor, Diesel	07.04-11.05			0 281 002 401
Duo sensor, acceleration and yaw rate, brake system	07.04-11.05			0 265 005 692
Wheel speed sensor				
Fg.no. →4F..5..085 230	07.04-12.04	LAB	0 265 007 728	
2.0 TDI [4F2; C6]		2,0l	100 kW	BRF 4 Zyl.
Air mass meter, diesel	06.05→			0 281 002 461
				0 986 284 007
Boost pressure sensor, Diesel	06.05→			0 281 002 401
Duo sensor, acceleration and yaw rate, brake system				
Fg.no. →4F..6..250 000	06.05-05.06			0 265 005 692
Fg.no. 4F..7..000 001→	06.06→			0 265 005 619
Wheel speed sensor				
Fg.no. 4F..6..140 001→	02.06→	LAB	0 265 007 930	
		RAB	0 265 007 928	
2.0 TDI [4F2; C6]		2,0l	103 kW	BLB 4 Zyl.
Air mass meter, diesel	07.04-11.05			0 281 002 461
				0 986 284 007
Boost pressure sensor, Diesel	07.04-11.05			0 281 002 401
Duo sensor, acceleration and yaw rate, brake system	07.04-11.05			0 265 005 692



Wheel speed sensor			
Fg.no. →4F..5..085 230	07.04-12.04	LAB	0 265 007 728
2.0 TDI [4F2; C6]		2,0 l 103 kW BRE 4 Zyl.	
Air mass meter, diesel	06.05→		0 281 002 461
			0 986 284 007
Boost pressure sensor, Diesel	06.05→		0 281 002 401
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →4F..6..250 000	06.05-05.06		0 265 005 692
Fg.no. 4F..7..000 001→	06.06→		0 265 005 619
Wheel speed sensor			
Fg.no. 4F..6..140 001→	02.06→	LAB	0 265 007 930
		RAB	0 265 007 928
2.0 TFSI [4F2; C6]		2,0 l 125 kW BPJ 4 Zyl.	
Speed sensor, ignition/injection	06.05→		0 261 210 199
Knock sensor	06.05→		0 261 231 146
Boost pressure sensor, gasoline	06.05→		0 261 230 073
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →4F..6..250 000	06.05-05.06		0 265 005 692
Fg.no. 4F..7..000 001→	06.06→		0 265 005 619
Wheel speed sensor			
Fg.no. 4F..6..140 001→	02.06→	LAB	0 265 007 930
		RAB	0 265 007 928
2.3 [4A2; C4]		2,3 l 98 kW AAR 5 Zyl.	
Throttle valve sensor	06.94-10.97	AG	0 280 120 433
Air flow sensor, gasoline injection	06.94-10.97		F 026 TX2 054
			0 266 TX2 054
Knock sensor	06.94-10.97		0 261 231 038
2.3 quattro [4A2; C4]		2,3 l 98 kW AAR 5 Zyl.	
Throttle valve sensor	08.94-07.95	AG	0 280 120 433
Air flow sensor, gasoline injection	08.94-07.95		F 026 TX2 054
			0 266 TX2 054
Knock sensor	08.94-07.95	KZB	0 261 231 036
		KZG	0 261 231 038
2.4 [C5]		2,4 l 121 kW APS 6 Zyl.	
Throttle valve assembly	09.99-09.05		0 280 750 030
Phase sensor	09.99-09.05		0 232 101 024
Speed sensor, ignition/injection	09.99-09.05	AG,FKW	0 261 210 147
		FKW,GS	0 261 210 178
Temperature sensor, intake air, injection system	09.99-09.05		0 280 130 085
2.4 [4A2; C4]		2,4 l 110 kW AFM 6 Zyl.	
Throttle valve sensor	07.95-10.97		0 280 120 431
Knock sensor	07.95-10.97		0 261 231 036
2.4 [4B2; C5]		2,4 l 100 kW ALW 6 Zyl.	
Phase sensor	08.97-01.99		0 232 101 024
Speed sensor, ignition/injection	08.97-01.99	AG	0 261 210 147
		GS	0 261 210 178
Temperature sensor, intake air, injection system	08.97-01.99		0 280 130 085
Duo sensor, acceleration and yaw rate, brake system	08.97-01.99		0 265 005 214
2.4 [4B2; C5]		2,4 l 100 kW ARN 6 Zyl.	
Throttle valve assembly	02.99-05.00		0 280 750 030
Phase sensor	02.99-05.00		0 232 101 024
Speed sensor, ignition/injection	02.99-05.00	AG	0 261 210 147
		GS	0 261 210 178
Knock sensor			
Fg.no. →4B..X..200 000	02.99-06.99		0 261 231 036
Temperature sensor, intake air, injection system	02.99-05.00		0 280 130 085
Duo sensor, acceleration and yaw rate, brake system	02.99-05.00		0 265 005 214



2.4 [4B2; C5]		2,4 l 100 kW ASM 6 Zyl.	
Throttle valve assembly	06.01-05.04		0 280 750 030
Phase sensor	06.01-05.04		0 232 101 024
Speed sensor, ignition/injection	06.01-05.04	AG	0 261 210 147
		GS	0 261 210 178
Temperature sensor, intake air, injection system	06.01-05.04		0 280 130 085
Duo sensor, acceleration and yaw rate, brake system	06.01-05.04		0 265 005 252
Pressure sensor, ESP, (electronic stability program)	06.01-05.04		0 265 005 303
Wheel speed sensor, front			
Fg.no. 4B..2..031 501→4B..2..200 000	09.01-06.02		0 265 006 578
Fg.no. 4B..3..000 001→	07.02-05.04		0 265 006 765
2.4 [4B2; C5]		2,4 l 115 kW APC 6 Zyl.	
Phase sensor	04.98-04.01		0 232 101 024
Speed sensor, ignition/injection	04.98-04.01	AG	0 261 210 147
		GS	0 261 210 178
Knock sensor			
Fg.no. →4B..X..200 000	04.98-06.99		0 261 231 036
Temperature sensor, intake air, injection system	04.98-04.01		0 280 130 085
Duo sensor, acceleration and yaw rate, brake system	04.98-04.01		0 265 005 214
Pressure sensor, ESP, (electronic stability program)	04.98-04.01		0 265 005 303
2.4 [4B2; C5]		2,4 l 120 kW AJG; ALF 6 Zyl.	
Phase sensor	04.97-01.99		0 232 101 024
Speed sensor, ignition/injection	04.97-01.99	AG	0 261 210 147
		GS	0 261 210 178
Knock sensor	04.97-01.99		0 261 231 036
Temperature sensor, intake air, injection system	04.97-01.99		0 280 130 085
Duo sensor, acceleration and yaw rate, brake system	04.97-01.99		0 265 005 214
2.4 [4B2; C5]		2,4 l 120 kW AMM 6 Zyl.	
Throttle valve assembly	06.01-05.04		0 280 750 030
Phase sensor	06.01-05.04		0 232 101 024
Speed sensor, ignition/injection	06.01-05.04	AG	0 261 210 147
		GS	0 261 210 178
Temperature sensor, intake air, injection system	06.01-05.04		0 280 130 085
Duo sensor, acceleration and yaw rate, brake system	06.01-05.04		0 265 005 252
Pressure sensor, ESP, (electronic stability program)	06.01-05.04		0 265 005 303
Wheel speed sensor, front			
Fg.no. 4B..2..031 501→4B..2..200 000	09.01-06.02		0 265 006 578
Fg.no. 4B..3..000 001→	07.02-05.04		0 265 006 765
2.4 [4B2; C5]		2,4 l 120 kW APZ 6 Zyl.	
Throttle valve assembly	11.98-05.00		0 280 750 030
Phase sensor	11.98-05.00		0 232 101 024
Speed sensor, ignition/injection	11.98-05.00	AG	0 261 210 147
		GS	0 261 210 178
Knock sensor			
Fg.no. →4B..X..200 000	11.98-06.99		0 261 231 036
Temperature sensor, intake air, injection system	11.98-05.00		0 280 130 085
Duo sensor, acceleration and yaw rate, brake system	11.98-05.00		0 265 005 214
2.4 [4B2; C5]		2,4 l 121 kW AGA 6 Zyl.	
Phase sensor	04.97-01.99		0 232 101 024
Speed sensor, ignition/injection	04.97-01.99	AG	0 261 210 147
		GS	0 261 210 178
Knock sensor	04.97-01.99		0 261 231 036
Temperature sensor, intake air, injection system	04.97-01.99		0 280 130 085
Duo sensor, acceleration and yaw rate, brake system	04.97-01.99		0 265 005 214
2.4 [4B2; C5]		2,4 l 121 kW AML 6 Zyl.	
Throttle valve assembly	06.00-04.01		0 280 750 030
Phase sensor	06.00-04.01		0 232 101 024



◀ A6

Speed sensor, ignition/injection	06.00-04.01	AG	0 261 210 147
		GS	0 261 210 178
Temperature sensor, intake air, injection system	06.00-04.01		0 280 130 085
Duo sensor, acceleration and yaw rate, brake system	06.00-04.01		0 265 005 252
Pressure sensor, ESP, (electronic stability program)	06.00-04.01		0 265 005 303
2.4 [4B2; C5]	2,4l	121 kW APS; ARJ 6 Zyl.	
Throttle valve assembly	11.98-04.01		0 280 750 030
Phase sensor	11.98-04.01		0 232 101 024
Speed sensor, ignition/injection	11.98-04.01	AG	0 261 210 147
		GS	0 261 210 178
Knock sensor			
Fg.no. →4B..X..200 000	11.98-06.99		0 261 231 036
Temperature sensor, intake air, injection system	11.98-04.01		0 280 130 085
Duo sensor, acceleration and yaw rate, brake system	11.98-04.01		0 265 005 214
Pressure sensor, ESP, (electronic stability program)	11.98-04.01		0 265 005 303
2.4 [4B2; C5]	2,4l	125 kW BDV 6 Zyl.	
Throttle valve assembly	06.01-05.04		0 280 750 030
Phase sensor	06.01-05.04		0 232 101 024
Speed sensor, ignition/injection	06.01-05.04	AG	0 261 210 147
		GS	0 261 210 178
Temperature sensor, intake air, injection system	06.01-05.04		0 280 130 085
Duo sensor, acceleration and yaw rate, brake system	06.01-05.04		0 265 005 252
Pressure sensor, ESP, (electronic stability program)	06.01-05.04		0 265 005 303
Wheel speed sensor, front			
Fg.no. 4B..2..031 501→4B..2..200 000	09.01-06.02		0 265 006 578
Fg.no. 4B..3..000 001→	07.02-05.04		0 265 006 765
2.4 [4F2; C6]	2,4l	130 kW BDW 6 Zyl.	
Throttle valve assembly	04.04→		0 280 750 003
Pressure sensor, intake manifold, gasoline	04.04→		0 261 230 095
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →4F..6..250 000	04.04-05.06		0 265 005 692
Fg.no. 4F..7..000 001→	06.06→		0 265 005 619
Wheel speed sensor			
Fg.no. →4F..5..085 230	04.04-12.04	LAB	0 265 007 728
Fg.no. 4F..6..140 001→	02.06→	LAB	0 265 007 930
		RAB	0 265 007 928
2.4 quattro [4B2; C5]	2,4l	115 kW APC 6 Zyl.	
Phase sensor	08.98-07.99		0 232 101 024
Speed sensor, ignition/injection	08.98-07.99	AG	0 261 210 147
		GS	0 261 210 178
Knock sensor			
Fg.no. →4B..X..200 000	08.98-06.99		0 261 231 036
Temperature sensor, intake air, injection system	08.98-07.99		0 280 130 085
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. 4B..X..026 001→	10.98-07.99		0 265 005 214
Yaw rate sensor, brake system			
Fg.no. →4B..X..026 000	08.98-10.98		0 265 005 207
Wheel speed sensor, rear			
Fg.no. 4B..X..062 732→	12.98-07.99	ALR,LAB	0 265 006 586
		ALR,RAB	0 265 006 584
		OLW	0 265 006 584
2.4 quattro [4B2; C5]	2,4l	120 kW AJG 6 Zyl.	
Phase sensor	06.97-01.99		0 232 101 024
Speed sensor, ignition/injection	06.97-01.99	AG	0 261 210 147
		GS	0 261 210 178
Knock sensor			
Temperature sensor, intake air, injection system	06.97-01.99		0 261 231 036
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →4B..X..200 000	11.98-06.99		0 261 231 036



Duo sensor, acceleration and yaw rate, brake system			
Fg.no. 4B..X..026 001→	10.98-01.99		0 265 005 214
Yaw rate sensor, brake system			
Fg.no. →4B..X..026 000	06.97-10.98		0 265 005 207
Wheel speed sensor, rear			
Fg.no. 4B..X..062 732→	12.98-01.99	ALR,LAB	0 265 006 586
		ALR,RAB	0 265 006 584
		OLW	0 265 006 584
2.4 quattro [4B2; C5]	2,4l	120 kW APZ 6 Zyl.	
Throttle valve assembly	11.98-05.00		0 280 750 030
Phase sensor	11.98-05.00		0 232 101 024
Speed sensor, ignition/injection	11.98-05.00	AG	0 261 210 147
		GS	0 261 210 178
Knock sensor			
Fg.no. →4B..X..200 000	11.98-06.99		0 261 231 036
Temperature sensor, intake air, injection system	11.98-05.00		0 280 130 085
Duo sensor, acceleration and yaw rate, brake system	11.98-05.00		0 265 005 214
Wheel speed sensor, rear			
Fg.no. 4B..X..062 732→	12.98-05.00	ALR,LAB	0 265 006 586
		ALR,RAB	0 265 006 584
		OLW	0 265 006 584
2.4 quattro [4B2; C5]	2,4l	121 kW AGA; ALF 6 Zyl.	
Phase sensor	04.97-01.99		0 232 101 024
Speed sensor, ignition/injection	04.97-01.99	AG	0 261 210 147
		GS	0 261 210 178
Knock sensor			
Temperature sensor, intake air, injection system	04.97-01.99		0 280 130 085
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. 4B..X..026 001→	10.98-01.99		0 265 005 214
Yaw rate sensor, brake system			
Fg.no. →4B..X..026 000	04.97-10.98		0 265 005 207
Wheel speed sensor, rear			
Fg.no. 4B..X..062 732→	12.98-01.99	ALR,LAB	0 265 006 586
		ALR,RAB	0 265 006 584
		OLW	0 265 006 584
2.4 quattro [4B2; C5]	2,4l	121 kW AML 6 Zyl.	
Throttle valve assembly	06.00-05.01		0 280 750 030
Phase sensor	06.00-05.01		0 232 101 024
Speed sensor, ignition/injection	06.00-05.01	AG	0 261 210 147
		GS	0 261 210 178
Temperature sensor, intake air, injection system	06.00-05.01		0 280 130 085
Duo sensor, acceleration and yaw rate, brake system	06.00-05.01		0 265 005 214
Pressure sensor, ESP, (electronic stability program)	06.00-05.01		0 265 005 303
Wheel speed sensor, rear	06.00-05.01	ALR,LAB	0 265 006 586
		ALR,RAB	0 265 006 584
		OLW	0 265 006 584
2.4 quattro [4B2; C5]	2,4l	121 kW APS 6 Zyl.	
Phase sensor	11.98-06.99		0 232 101 024
Speed sensor, ignition/injection	11.98-06.99	AG	0 261 210 147
		GS	0 261 210 178
Knock sensor			
Temperature sensor, intake air, injection system	11.98-06.99		0 280 130 085
Duo sensor, acceleration and yaw rate, brake system	11.98-06.99		0 265 005 214
Wheel speed sensor, rear			
Fg.no. 4B..X..062 732→	12.98-06.99	ALR,LAB	0 265 006 586
		ALR,RAB	0 265 006 584
		OLW	0 265 006 584



2.4 quattro [4B2; C5]		2,4l 121 kW ARJ 6 Zyl.	
Throttle valve assembly	11.98-05.01		0 280 750 030
Phase sensor	11.98-05.01		0 232 101 024
Speed sensor, ignition/injection	11.98-05.01	AG	0 261 210 147
		GS	0 261 210 178
Knock sensor			
Fg.no. →4B..X..200 000	11.98-06.99		0 261 231 036
Temperature sensor, intake air, injection system	11.98-05.01		0 280 130 085
Duo sensor, acceleration and yaw rate, brake system	11.98-05.01		0 265 005 214
Pressure sensor, ESP, (electronic stability program)	11.98-05.01		0 265 005 303
Wheel speed sensor, rear			
Fg.no. 4B..X..062 732→	12.98-05.01	ALR,LAB	0 265 006 586
		ALR,RAB	0 265 006 584
		OLW	0 265 006 584
2.4 quattro [4B2; C5]		2,4l 125 kW BDV 6 Zyl.	
Throttle valve assembly	06.01-05.04		0 280 750 030
Phase sensor	06.01-05.04		0 232 101 024
Speed sensor, ignition/injection	06.01-05.04	AG	0 261 210 147
		GS	0 261 210 178
Temperature sensor, intake air, injection system	06.01-05.04		0 280 130 085
Duo sensor, acceleration and yaw rate, brake system	06.01-05.04		0 265 005 252
Pressure sensor, ESP, (electronic stability program)	06.01-05.04		0 265 005 303
Wheel speed sensor, front			
Fg.no. 4B..2..031 501→4B..2..200 000	09.01-06.02		0 265 006 578
Fg.no. 4B..3..000 001→	07.02-05.04		0 265 006 765
Wheel speed sensor, rear			
Fg.no. →4B..2..079 500	06.01-12.01	ALR,LAB	0 265 006 586
		ALR,RAB	0 265 006 584
		OLW	0 265 006 584
Fg.no. 4B..2..079 501→	12.01-05.04	ALR,LAB	0 265 006 763
		ALR,RAB	0 265 006 761
		OLW	0 265 006 761
2.4 quattro [4F2; C6]		2,4l 130 kW BDW 6 Zyl.	
Throttle valve assembly	01.05→		0 280 750 003
Pressure sensor, intake manifold, gasoline	01.05→		0 261 230 095
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →4F..6..250 000	01.05-05.06		0 265 005 692
Fg.no. 4F..7..000 001→	06.06→		0 265 005 619
Wheel speed sensor			
Fg.no. 4F..6..140 001→	02.06→	LAB	0 265 007 930
		RAB	0 265 007 928
2.5 TDI [4A2; C4]		2,5l 85/103 kW AAT; AEL 5 Zyl.	
Air mass meter, diesel	06.94-10.97		0 281 002 074
Pedal position sensor, diesel			
Fg.no. →4A..S..082 000	06.94-02.95	AG	0 205 001 018
		GS	0 205 001 017
Fg.no. 4A..S..082 001→	02.95-10.97	AG	0 205 001 031
		GS	0 205 001 032
2.5 TDI [4B2; C5]		2,5l 110 kW AFB 6 Zyl.	
Air mass meter, diesel	04.97-05.00		0 281 002 429
			0 986 284 005
Speed sensor, diesel	04.97-05.00		0 281 002 222
Pressure sensor, intake manifold, diesel	04.97-05.00		0 281 002 326
Pedal position sensor, diesel			
Fg.no. →4B..X..200 000	04.97-06.99	AG	0 281 002 289
		GS	0 281 002 286
Duo sensor, acceleration and yaw rate, brake system	04.97-05.00		0 265 005 214



2.5 TDI [4B2; C5]		2,5l 110 kW AKN 6 Zyl.	
Air mass meter, diesel	11.98-06.99		0 281 002 429 0 986 284 005
Speed sensor, diesel	11.98-06.99		0 281 002 222
Pressure sensor, intake manifold, diesel	11.98-06.99		0 281 002 326
Pedal position sensor, diesel	11.98-06.99	AG	0 281 002 289
		GS	0 281 002 286
Duo sensor, acceleration and yaw rate, brake system	11.98-06.99		0 265 005 214
2.5 TDI [4B2; C5]		2,5l 114 kW AYM 6 Zyl.	
Speed sensor, diesel	06.01-06.02		0 281 002 222
Pressure sensor, intake manifold, diesel	06.01-06.02		0 281 002 326
Duo sensor, acceleration and yaw rate, brake system	06.01-06.02		0 265 005 252
Pressure sensor, ESP, (electronic stability program)	06.01-06.02		0 265 005 303
Wheel speed sensor, front			
Fg.no. 4B..2..031 501→	09.01-06.02		0 265 006 578
2.5 TDI [4B2; C5]		2,5l 120 kW BCZ; BDG; BFC 6 Zyl.	
Speed sensor, diesel	07.02-05.04		0 281 002 222
Pressure sensor, intake manifold, diesel	07.02-05.04		0 281 002 326
Duo sensor, acceleration and yaw rate, brake system	07.02-05.04		0 265 005 252
Pressure sensor, ESP, (electronic stability program)	07.02-05.04		0 265 005 303
Wheel speed sensor, front	07.02-05.04		0 265 006 765
2.5 TDI [4B2; C5]		2,5l 132 kW AKE 6 Zyl.	
Speed sensor, diesel	10.99-08.03		0 281 002 222
Pressure sensor, intake manifold, diesel	10.99-08.03		0 281 002 326
Duo sensor, acceleration and yaw rate, brake system	10.99-05.01		0 265 005 214
Pressure sensor, ESP, (electronic stability program)	10.99-08.03		0 265 005 303
Wheel speed sensor, front			
Fg.no. 4B..2..031 501→4B..2..200 000	09.01-06.02		0 265 006 578
Fg.no. 4B..3..000 001→	07.02-08.03		0 265 006 765
2.5 TDI [4B2; C5]		2,5l 132 kW BAU; BDH 6 Zyl.	
Speed sensor, diesel	11.02-05.04		0 281 002 222
Pressure sensor, intake manifold, diesel	11.02-05.04		0 281 002 326
Duo sensor, acceleration and yaw rate, brake system	11.02-05.04		0 265 005 252
Pressure sensor, ESP, (electronic stability program)	11.02-05.04		0 265 005 303
Wheel speed sensor, front	11.02-05.04		0 265 006 765
2.5 TDI quattro [4A2; C4]		2,5l 103 kW AEL 5 Zyl.	
Air mass meter, diesel	07.95-10.97		0 281 002 074
Pedal position sensor, diesel	07.95-10.97		0 205 001 032
2.5 TDI quattro [4B2; C5]		2,5l 110 kW AFB 6 Zyl.	
Air mass meter, diesel	07.97-05.00		0 281 002 429 0 986 284 005
Speed sensor, diesel	07.97-05.00		0 281 002 222
Pressure sensor, intake manifold, diesel	07.97-05.00		0 281 002 326
Pedal position sensor, diesel			
Fg.no. →4B..X..200 000	07.97-06.99	AG	0 281 002 289
		GS	0 281 002 286
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. 4B..X..026 001→	10.98-05.00		0 265 005 214
Yaw rate sensor, brake system			
Fg.no. →4B..X..026 000	07.97-10.98		0 265 005 207
Wheel speed sensor, rear			
Fg.no. 4B..X..062 732→	12.98-05.00	ALR,LAB	0 265 006 586
		ALR,RAB	0 265 006 584
		OLW	0 265 006 584





Product

◀ A6

2.5 TDI quattro [4B2; C5]		2,5 l 110 kW AKN 6 Zyl.	
Air mass meter, diesel	11.98-06.99	0 281 002 429	
		0 986 284 005	
Speed sensor, diesel	11.98-06.99	0 281 002 222	
Pressure sensor, intake manifold, diesel	11.98-06.99	0 281 002 326	
Pedal position sensor, diesel	11.98-06.99	AG	0 281 002 289
		GS	0 281 002 286
Duo sensor, acceleration and yaw rate, brake system	11.98-06.99	0 265 005 214	
Wheel speed sensor, rear			
Fg.no. 4B..X..062 732→	12.98-06.99	ALR,LAB	0 265 006 586
		ALR,RAB	0 265 006 584
		OLW	0 265 006 584
2.5 TDI quattro [4B2; C5]		2,5 l 132 kW AKE 6 Zyl.	
Speed sensor, diesel	10.99-08.03	0 281 002 222	
Pressure sensor, intake manifold, diesel	10.99-08.03	0 281 002 326	
Duo sensor, acceleration and yaw rate, brake system	10.99-05.01	0 265 005 214	
	06.01-08.03	0 265 005 252	
Pressure sensor, ESP, (electronic stability program)	10.99-08.03	0 265 005 303	
Wheel speed sensor, front			
Fg.no. 4B..2..031 501→4B..2..200 000	09.01-06.02	0 265 006 578	
Fg.no. 4B..3..000 001→	07.02-08.03	0 265 006 765	
Wheel speed sensor, rear			
Fg.no. →4B..2..079 500	10.99-12.01	ALR,LAB	0 265 006 586
		ALR,RAB	0 265 006 584
		OLW	0 265 006 584
Fg.no. 4B..2..079 501→	12.01-08.03	ALR,LAB	0 265 006 763
		ALR,RAB	0 265 006 761
		OLW	0 265 006 761
2.5 TDI quattro [4B2; C5]		2,5 l 132 kW BAU; BDH 6 Zyl.	
Speed sensor, diesel	02.03-05.04	0 281 002 222	
Pressure sensor, intake manifold, diesel	02.03-05.04	0 281 002 326	
Duo sensor, acceleration and yaw rate, brake system	02.03-05.04	0 265 005 252	
Pressure sensor, ESP, (electronic stability program)	02.03-05.04	0 265 005 303	
Wheel speed sensor, front	02.03-05.04	0 265 006 765	
Wheel speed sensor, rear	02.03-05.04	ALR,LAB	0 265 006 763
		ALR,RAB	0 265 006 761
		OLW	0 265 006 761
2.6 [4A2; C4]		2,6 l 102 kW ACZ 6 Zyl.	
Throttle valve sensor	06.94-10.97	0 280 120 431	
Phase sensor	06.94-10.97	0 232 101 027	
Temperature sensor, intake air, injection system	06.94-10.97	KZS	0 280 130 060
2.6 [4A2; C4]		2,6 l 110 kW ABC 6 Zyl.	
Throttle valve sensor	06.94-10.97	0 280 120 431	
Phase sensor	06.94-10.97	0 232 101 027	
Knock sensor	06.94-10.97	0 261 231 036	
Temperature sensor, intake air, injection system	06.94-10.97	KZS	0 280 130 060
2.6 i [4A2; C4]		2,6 l 110 kW ABC 6 Zyl.	
Throttle valve sensor	06.94-12.97	0 280 120 431	
Knock sensor	06.94-12.97	0 261 231 036	
Temperature sensor, coolant, injection system	06.94-12.97	ABM	0 280 130 040
2.6 quattro [4A2; C4]		2,6 l 102/110 kW ABC; ACZ 6 Zyl.	
Throttle valve sensor	06.94-10.97	0 280 120 431	
Phase sensor	06.94-10.97	0 232 101 027	
Knock sensor	06.94-10.97	0 261 231 036	
Temperature sensor, intake air, injection system	06.94-10.97	KZS	0 280 130 060
2.7 Biturbo [4B2; C5]		2,7 l 169 kW AJK 6 Zyl.	
Throttle valve assembly	02.99-05.01	0 280 750 003	
Air mass meter, gasoline injection	02.99-05.01	0 280 218 038	
		0 986 280 212	
Phase sensor	02.99-05.01	0 232 101 024	

Product				
Speed sensor, ignition/injection	02.99-05.01	GS	0 261 210 147	
Fg.no. →4B..1..006 637	02.99-05.00	AG	0 281 002 222	
Fg.no. 4B..1..006 638→	06.00-05.01	AG	0 261 210 217	
Knock sensor				
Fg.no. →4B..X..200 000	02.99-06.99		0 261 231 036	
Temperature sensor, intake air, injection system	02.99-05.01		0 280 130 085	
Duo sensor, acceleration and yaw rate, brake system	02.99-05.01		0 265 005 214	
Pressure sensor, ESP, (electronic stability program)	02.99-05.01		0 265 005 303	
2.7 Biturbo quattro [4B2; C5]		2,7 l 169 kW AJK 6 Zyl.		
Air mass meter, gasoline injection	10.97-08.00		0 280 218 038	
			0 986 280 212	
Phase sensor	10.97-08.00		0 232 101 024	
Speed sensor, ignition/injection	10.97-08.00	GS	0 261 210 147	
Fg.no. →4B..1..006 637	10.97-05.00	AG	0 281 002 222	
Fg.no. 4B..1..006 638→	06.00-08.00	AG	0 261 210 217	
Knock sensor				
Fg.no. →4B..X..200 000	10.97-06.99		0 261 231 036	
Temperature sensor, intake air, injection system	10.97-08.00		0 280 130 085	
Duo sensor, acceleration and yaw rate, brake system				
Fg.no. 4B..X..026 001→	10.98-08.00		0 265 005 214	
Yaw rate sensor, brake system				
Fg.no. →4B..X..026 000	10.97-10.98		0 265 005 207	
Wheel speed sensor, rear				
Fg.no. 4B..X..062 732→	12.98-08.00	ALR,LAB	0 265 006 586	
		ALR,RAB	0 265 006 584	
		OLW	0 265 006 584	
2.7 Biturbo quattro [4B2; C5]		2,7 l 169 kW AZA 6 Zyl.		
Throttle valve assembly	09.00-05.01		0 280 750 003	
Speed sensor, ignition/injection	09.00-05.01	AG	0 261 210 217	
		GS	0 261 210 147	
Temperature sensor, intake air, injection system	09.00-05.01		0 280 130 085	
Duo sensor, acceleration and yaw rate, brake system	09.00-05.01		0 265 005 214	
Pressure sensor, ESP, (electronic stability program)	09.00-05.01		0 265 005 303	
Wheel speed sensor, rear	09.00-05.01	ALR,LAB	0 265 006 586	
		ALR,RAB	0 265 006 584	
		OLW	0 265 006 584	
2.7 Biturbo quattro [4B2; C5]		2,7 l 184 kW ARE 6 Zyl.		
Throttle valve assembly	06.01-06.02		0 280 750 003	
Phase sensor	06.01-06.02		0 232 101 024	
Speed sensor, ignition/injection	06.01-06.02	AG	0 261 210 217	
		GS	0 261 210 147	
Temperature sensor, intake air, injection system	06.01-06.02		0 280 130 085	
Duo sensor, acceleration and yaw rate, brake system	06.01-06.02		0 265 005 252	
Pressure sensor, ESP, (electronic stability program)	06.01-06.02		0 265 005 303	
Wheel speed sensor, front				
Fg.no. 4B..2..031 501→	09.01-06.02		0 265 006 578	
Wheel speed sensor, rear				
Fg.no. →4B..2..079 500	06.01-12.01	ALR,LAB	0 265 006 586	
		ALR,RAB	0 265 006 584	
		OLW	0 265 006 584	
Fg.no. 4B..2..079 501→	12.01-06.02	ALR,LAB	0 265 006 763	
		ALR,RAB	0 265 006 761	
		OLW	0 265 006 761	
2.7 Biturbo quattro [4B2; C5]		2,7 l 184 kW BES 6 Zyl.		
Throttle valve assembly	07.02-05.04		0 280 750 003	
Phase sensor	07.02-05.04		0 232 101 024	
Speed sensor, ignition/injection	07.02-05.04	AG	0 261 210 217	
		GS	0 261 210 147	
Temperature sensor, intake air, injection system	07.02-05.04		0 280 130 085	



Duo sensor, acceleration and yaw rate, brake system	07.02-05.04		0 265 005 252
Pressure sensor, ESP, (electronic stability program)	07.02-05.04		0 265 005 303
Wheel speed sensor, front	07.02-05.04		0 265 006 765
Wheel speed sensor, rear	07.02-05.04	ALR, LAB	0 265 006 763
		ALR, RAB	0 265 006 761
		OLW	0 265 006 761
2.7 Biturbo quattro [4B2; C5]		2,7 l 187 kW BEL 6 Zyl.	
Throttle valve assembly	07.02-07.04		0 280 750 003
Phase sensor	07.02-07.04		0 232 101 024
Speed sensor, ignition/injection	07.02-07.04	AG	0 261 210 217
		GS	0 261 210 147
Temperature sensor, intake air, injection system	07.02-07.04		0 280 130 116
Duo sensor, acceleration and yaw rate, brake system	07.02-07.04		0 265 005 252
Wheel speed sensor, front	07.02-07.04		0 265 006 765
Wheel speed sensor, rear	07.02-07.04	ALR, LAB	0 265 006 763
		ALR, RAB	0 265 006 761
		OLW	0 265 006 761
2.7 quattro [4B2; C5]		2,7 l 187 kW APB 6 Zyl.	
Throttle valve assembly	06.01-06.02		0 280 750 003
Phase sensor	06.01-06.02		0 232 101 024
Speed sensor, ignition/injection	06.01-06.02	AG	0 261 210 217
		GS	0 261 210 147
Temperature sensor, intake air, injection system	06.01-06.02		0 280 130 085
Duo sensor, acceleration and yaw rate, brake system	06.01-06.02		0 265 005 252
Wheel speed sensor, front	06.01-06.02	B17, B18	0 265 006 578
Wheel speed sensor, rear	06.01-06.02	OLW	0 265 006 761
Fg.no. →4B..2..079 500	06.01-12.01	ALR, LAB	0 265 006 586
		ALR, RAB	0 265 006 584
		OLW	0 265 006 584
Fg.no. 4B..2..079 501→	12.01-06.02	ALR, LAB	0 265 006 763
		ALR, RAB	0 265 006 761
		OLW	0 265 006 761
2.7 TDI [4F2; C6]		2,7 l 120/132 kW BPP; BSG 6 Zyl.	
Speed sensor, diesel	11.04→	FKW	0 261 210 145
High-pressure sensor (CR system)			
Fg.no. →4F..6..132 000	11.04-12.05		0 281 002 504
Boost pressure sensor, Diesel	11.04→		0 281 002 399
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →4F..6..250 000	11.04-05.06		0 265 005 692
Fg.no. 4F..7..000 001→	06.06→		0 265 005 619
Wheel speed sensor			
Fg.no. →4F..5..085 230	11.04-12.04	LAB	0 265 007 728
Fg.no. 4F..6..140 001→	02.06→	LAB	0 265 007 930
		RAB	0 265 007 928
2.7 TDI quattro [4F2; C6]		2,7 l 120/132 kW BPP; BSG 6 Zyl.	
Speed sensor, diesel	06.05→	FKW	0 261 210 145
High-pressure sensor (CR system)			
Fg.no. →4F..6..132 000	06.05-12.05		0 281 002 504
Boost pressure sensor, Diesel	06.05→		0 281 002 399
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →4F..6..250 000	06.05-05.06		0 265 005 692
Fg.no. 4F..7..000 001→	06.06→		0 265 005 619
Wheel speed sensor			
Fg.no. 4F..6..140 001→	02.06→	LAB	0 265 007 930
		RAB	0 265 007 928



2.8 [C5]		2,8 l 140 kW ATX 6 Zyl.	
Throttle valve assembly	09.99-09.05		0 280 750 030
Speed sensor, ignition/injection	09.99-09.05	AG, FKW	0 261 210 147
		FKW, GS	0 261 210 178
Temperature sensor, intake air, injection system	09.99-09.05		0 280 130 085
2.8 [4A2; C4]		2,8 l 120 kW AEJ 6 Zyl.	
Throttle valve sensor	09.94-10.97		0 280 120 431
2.8 [4A2; C4]		2,8 l 128 kW AAH 6 Zyl.	
Throttle valve sensor	06.94-10.97		0 280 120 431
Phase sensor	06.94-10.97		0 232 101 027
Knock sensor	06.94-10.97		0 261 231 036
2.8 [4A2; C4]		2,8 l 142 kW ACK 6 Zyl.	
Throttle valve sensor	10.95-10.97		0 280 120 431
Phase sensor	10.95-10.97		0 232 101 024
Speed sensor, ignition/injection	10.95-10.97		0 261 210 139
Knock sensor	10.95-10.97		0 261 231 036
Temperature sensor, intake air, injection system	10.95-10.97	KZS	0 280 130 060
2.8 [4B2; C5]		2,8 l 132 kW AGE 6 Zyl.	
Phase sensor	10.97-05.00		0 232 101 024
Speed sensor, ignition/injection	10.97-05.00	AG	0 261 210 147
		GS	0 261 210 178
Knock sensor			
Fg.no. →4B..X..200 000	10.97-06.99		0 261 231 036
Temperature sensor, intake air, injection system	10.97-05.00		0 280 130 085
Duo sensor, acceleration and yaw rate, brake system	10.97-05.00		0 265 005 214
2.8 [4B2; C5]		2,8 l 140 kW ATX 6 Zyl.	
Throttle valve assembly	07.99-04.01		0 280 750 030
Phase sensor	07.99-04.01		0 232 101 024
Speed sensor, ignition/injection	07.99-04.01	AG	0 261 210 147
		GS	0 261 210 178
Temperature sensor, intake air, injection system	07.99-04.01		0 280 130 085
Duo sensor, acceleration and yaw rate, brake system	07.99-04.01		0 265 005 214
Pressure sensor, ESP, (electronic stability program)	07.99-04.01		0 265 005 303
2.8 [4B2; C5]		2,8 l 142 kW ACK 6 Zyl.	
Phase sensor	04.97-07.98		0 232 101 024
Speed sensor, ignition/injection	04.97-07.98	AG	0 261 210 147
		GS	0 261 210 178
Knock sensor	04.97-07.98		0 261 231 036
Temperature sensor, intake air, injection system	04.97-07.98		0 280 130 085
Duo sensor, acceleration and yaw rate, brake system	04.97-07.98		0 265 005 214
2.8 [4B2; C5]		2,8 l 142 kW AHA 6 Zyl.	
Phase sensor	08.97-07.98		0 232 101 024
Speed sensor, ignition/injection	08.97-07.98	AG	0 261 210 147
		GS	0 261 210 178
Knock sensor	08.97-07.98		0 261 231 036
Duo sensor, acceleration and yaw rate, brake system	08.97-07.98		0 265 005 214
2.8 [4B2; C5]		2,8 l 142 kW ALG 6 Zyl.	
Phase sensor	06.97-01.99		0 232 101 024
Speed sensor, ignition/injection	06.97-01.99	AG	0 261 210 147
		GS	0 261 210 178
Knock sensor	06.97-01.99		0 261 231 036
Temperature sensor, intake air, injection system	06.97-01.99		0 280 130 085
Duo sensor, acceleration and yaw rate, brake system	06.97-01.99		0 265 005 214
2.8 [4B2; C5]		2,8 l 142 kW AMX 6 Zyl.	
Throttle valve assembly	06.00-04.01		0 280 750 030
Phase sensor	06.00-04.01		0 232 101 024
Speed sensor, ignition/injection	06.00-04.01	AG	0 261 210 147
		GS	0 261 210 178

Product				

◀ A6

Temperature sensor, intake air, injection system	06.00-04.01		0 280 130 085
Duo sensor, acceleration and yaw rate, brake system	06.00-04.01		0 265 005 214
Pressure sensor, ESP, (electronic stability program)	06.00-04.01		0 265 005 303
2.8 [4B2; C5]	2,8 l	142 kW	APR; AQD 6 Zyl.
Throttle valve assembly	11.98-04.01		0 280 750 030
Phase sensor	11.98-04.01		0 232 101 024
Speed sensor, ignition/injection	11.98-04.01	AG	0 261 210 147
		GS	0 261 210 178
Knock sensor			
Fg.no. →4B..X..200 000	11.98-06.99		0 261 231 036
Temperature sensor, intake air, injection system	11.98-04.01		0 280 130 085
Duo sensor, acceleration and yaw rate, brake system	11.98-04.01		0 265 005 214
Pressure sensor, ESP, (electronic stability program)	11.98-04.01		0 265 005 303
2.8 [4B2; C5]	2,8 l	142 kW	ATQ 6 Zyl.
Phase sensor	08.99-04.01		0 232 101 024
Speed sensor, ignition/injection	08.99-04.01	AG	0 261 210 147
		GS	0 261 210 178
Knock sensor	08.99-04.01		0 261 231 036
Duo sensor, acceleration and yaw rate, brake system	08.99-04.01		0 265 005 214
2.8 FSI [4F2; C6]	2,8 l	154 kW	BDX 6 Zyl.
Pressure sensor, intake manifold, gasoline	11.06→		0 261 230 095
Duo sensor, acceleration and yaw rate, brake system	11.06→		0 265 005 619
Wheel speed sensor	11.06→	LAB	0 265 007 930
		RAB	0 265 007 928
2.8 FSI quattro [4F2, C6]	2,8 l	154 kW	BDX 6 Zyl.
Pressure sensor, intake manifold, gasoline	11.06→		0 261 230 095
Duo sensor, acceleration and yaw rate, brake system	11.06→		0 265 005 619
Wheel speed sensor	11.06→	LAB	0 265 007 930
		RAB	0 265 007 928
2.8 i [4A2; C4]	2,8 l	128 kW	AAH 6 Zyl.
Knock sensor	06.94-12.97		0 261 231 036
Temperature sensor, coolant, injection system	06.94-12.97	ABM	0 280 130 040
2.8 quattro [4A2; C4]	2,8 l	120 kW	AEJ 6 Zyl.
Throttle valve sensor	07.95-10.97		0 280 120 431
Knock sensor	07.95-10.97		0 261 231 036
2.8 quattro [4A2; C4]	2,8 l	128 kW	AAH 6 Zyl.
Throttle valve sensor	06.94-10.97		0 280 120 431
Phase sensor	06.94-10.97		0 232 101 027
Knock sensor	06.94-10.97		0 261 231 036
2.8 quattro [4A2; C4]	2,8 l	142 kW	ACK 6 Zyl.
Throttle valve sensor	10.95-10.97		0 280 120 431
Phase sensor	10.95-10.97		0 232 101 024
Speed sensor, ignition/injection	10.95-10.97		0 261 210 139
Knock sensor	10.95-10.97		0 261 231 036
Temperature sensor, intake air, injection system	10.95-10.97	KZS	0 280 130 060
2.8 quattro [4B2; C5]	2,8 l	132 kW	AGE 6 Zyl.
Phase sensor	04.98-05.00		0 232 101 024
Speed sensor, ignition/injection	04.98-05.00	AG	0 261 210 147
		GS	0 261 210 178
Knock sensor			
Fg.no. →4B..X..200 000	04.98-06.99		0 261 231 036
Temperature sensor, intake air, injection system	04.98-05.00		0 280 130 085
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. 4B..X..026 001→	10.98-05.00		0 265 005 214
Yaw rate sensor, brake system			
Fg.no. →4B..X..026 000	04.98-10.98		0 265 005 207

Product				

Wheel speed sensor, rear Fg.no. 4B..X..062 732→	12.98-05.00	ALR,LAB	0 265 006 586
		ALR,RAB	0 265 006 584
		OLW	0 265 006 584
2.8 quattro [4B2; C5]	2,8 l	140 kW	ATX 6 Zyl.
Throttle valve assembly	07.99-05.01		0 280 750 030
Phase sensor	07.99-05.01		0 232 101 024
Speed sensor, ignition/injection	07.99-05.01	AG	0 261 210 147
		GS	0 261 210 178
Temperature sensor, intake air, injection system	07.99-05.01		0 280 130 085
Duo sensor, acceleration and yaw rate, brake system	07.99-05.01		0 265 005 214
Pressure sensor, ESP, (electronic stability program)	07.99-05.01		0 265 005 303
Wheel speed sensor, rear	07.99-05.01	ALR,LAB	0 265 006 586
		ALR,RAB	0 265 006 584
		OLW	0 265 006 584
2.8 quattro [4B2; C5]	2,8 l	142 kW	ACK 6 Zyl.
Phase sensor	04.97-12.98		0 232 101 024
Speed sensor, ignition/injection	04.97-12.98	AG	0 261 210 147
		GS	0 261 210 178
Knock sensor	04.97-12.98		0 261 231 036
Temperature sensor, intake air, injection system	04.97-12.98		0 280 130 085
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. 4B..X..026 001→	10.98-12.98		0 265 005 214
Yaw rate sensor, brake system			
Fg.no. →4B..X..026 000	04.97-10.98		0 265 005 207
2.8 quattro [4B2; C5]	2,8 l	142 kW	ALG 6 Zyl.
Phase sensor	06.97-01.99		0 232 101 024
Speed sensor, ignition/injection	06.97-01.99	AG	0 261 210 147
		GS	0 261 210 178
Knock sensor	06.97-01.99		0 261 231 036
Temperature sensor, intake air, injection system	06.97-01.99		0 280 130 085
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. 4B..X..026 001→	10.98-01.99		0 265 005 214
Yaw rate sensor, brake system			
Fg.no. →4B..X..026 000	06.97-10.98		0 265 005 207
Wheel speed sensor, rear Fg.no. 4B..X..062 732→	12.98-01.99	ALR,LAB	0 265 006 586
		ALR,RAB	0 265 006 584
		OLW	0 265 006 584
2.8 quattro [4B2; C5]	2,8 l	142 kW	AMX 6 Zyl.
Throttle valve assembly	06.00-05.01		0 280 750 030
Phase sensor	06.00-05.01		0 232 101 024
Speed sensor, ignition/injection	06.00-05.01	AG	0 261 210 147
		GS	0 261 210 178
Knock sensor	06.00-05.01		0 261 231 036
Temperature sensor, intake air, injection system	06.00-05.01		0 280 130 085
Duo sensor, acceleration and yaw rate, brake system	06.00-05.01		0 265 005 252
Pressure sensor, ESP, (electronic stability program)	06.00-05.01		0 265 005 303
Wheel speed sensor, rear	06.00-05.01	ALR,LAB	0 265 006 586
		ALR,RAB	0 265 006 584
		OLW	0 265 006 584
2.8 quattro [4B2; C5]	2,8 l	142 kW	APR 6 Zyl.
Throttle valve assembly	01.99-05.01		0 280 750 030
Phase sensor	01.99-05.01		0 232 101 024
Speed sensor, ignition/injection	01.99-05.01	AG	0 261 210 147
		GS	0 261 210 178
Knock sensor			
Fg.no. →4B..X..200 000	01.99-06.99		0 261 231 036
Temperature sensor, intake air, injection system	01.99-05.01		0 280 130 085



Duo sensor, acceleration and yaw rate, brake system	01.99-05.01		0 265 005 214
Pressure sensor, ESP, (electronic stability program)	01.99-05.01		0 265 005 303
Wheel speed sensor, rear	01.99-05.01	ALR,LAB	0 265 006 586
		ALR,RAB	0 265 006 584
		OLW	0 265 006 584
2.8 quattro [4B2; C5]		2,8l 142 kW AQD 6 Zyl.	
Throttle valve assembly	11.98-05.01		0 280 750 030
Phase sensor	11.98-05.01		0 232 101 024
Speed sensor, ignition/injection	11.98-05.01	AG	0 261 210 147
		GS	0 261 210 178
Knock sensor			
Fg.no. →4B..X..200 000	11.98-06.99		0 261 231 036
Temperature sensor, intake air, injection system	11.98-05.01		0 280 130 085
Duo sensor, acceleration and yaw rate, brake system	11.98-05.01		0 265 005 214
Pressure sensor, ESP, (electronic stability program)	11.98-05.01		0 265 005 303
Wheel speed sensor, rear			
Fg.no. 4B..X..062 732→	12.98-05.01	ALR,LAB	0 265 006 586
		ALR,RAB	0 265 006 584
		OLW	0 265 006 584
3.0 [4B2; C5]		3,0l 160 kW BBJ 6 Zyl.	
Throttle valve assembly	06.01-05.04		0 280 750 030
Phase sensor	06.01-05.04		0 232 101 024
Speed sensor, ignition/injection	06.01-05.04	AG	0 261 210 147
		GS	0 261 210 178
Duo sensor, acceleration and yaw rate, brake system	06.01-05.04		0 265 005 252
Pressure sensor, ESP, (electronic stability program)	06.01-05.04		0 265 005 303
Wheel speed sensor, front			
Fg.no. 4B..2..031 501→4B..2..200 000	09.01-06.02		0 265 006 578
Fg.no. 4B..3..000 001→	07.02-05.04		0 265 006 765
3.0 [4B2; C5]		3,0l 162 kW ASN 6 Zyl.	
Throttle valve assembly	06.01-05.04		0 280 750 030
Speed sensor, ignition/injection	06.01-05.04	AG	0 261 210 147
		GS	0 261 210 178
Duo sensor, acceleration and yaw rate, brake system	06.01-05.04		0 265 005 252
Pressure sensor, ESP, (electronic stability program)	06.01-05.04		0 265 005 303
Wheel speed sensor, front			
Fg.no. 4B..2..031 501→4B..2..200 000	09.01-06.02		0 265 006 578
Fg.no. 4B..3..000 001→	07.02-05.04		0 265 006 765
3.0 [4B2; C5]		3,0l 162 kW AVK 6 Zyl.	
Throttle valve assembly	06.01-07.04		0 280 750 030
Speed sensor, ignition/injection	06.01-07.04		0 261 210 178
Duo sensor, acceleration and yaw rate, brake system	06.01-07.04		0 265 005 252
Wheel speed sensor, front			
Fg.no. →4B..2..031 500	06.01-06.02	B17,B18	0 265 006 578
Fg.no. 4B..3..000 001→	07.02-07.04		0 265 006 765
3.0 [4F2; C6]		3,0l 160 kW BBJ 6 Zyl.	
Throttle valve assembly	04.04-05.06		0 280 750 030
Duo sensor, acceleration and yaw rate, brake system	04.04-05.06		0 265 005 692
Wheel speed sensor			
Fg.no. →4F..5..085 230	04.04-12.04	LAB	0 265 007 728
Fg.no. 4F..6..140 001→	02.06-05.06	LAB	0 265 007 930
		RAB	0 265 007 928
3.0 quattro [4B2; C5]		3,0l 160 kW BBJ 6 Zyl.	
Throttle valve assembly	06.01-05.04		0 280 750 030
Phase sensor	06.01-05.04		0 232 101 024
Speed sensor, ignition/injection	06.01-05.04	AG	0 261 210 147
		GS	0 261 210 178



Duo sensor, acceleration and yaw rate, brake system	06.01-05.04		0 265 005 252
Pressure sensor, ESP, (electronic stability program)	06.01-05.04		0 265 005 303
Wheel speed sensor, front			
Fg.no. 4B..2..031 501→4B..2..200 000	09.01-06.02		0 265 006 578
Fg.no. 4B..3..000 001→	07.02-05.04		0 265 006 765
Wheel speed sensor, rear			
Fg.no. →4B..2..079 500	06.01-12.01	ALR,LAB	0 265 006 586
		ALR,RAB	0 265 006 584
		OLW	0 265 006 584
Fg.no. 4B..2..079 501→	12.01-05.04	ALR,LAB	0 265 006 763
		ALR,RAB	0 265 006 761
		OLW	0 265 006 761
3.0 quattro [4B2; C5]		3,0l 162 kW ASN 6 Zyl.	
Throttle valve assembly	06.01-05.04		0 280 750 030
Speed sensor, ignition/injection	06.01-05.04	AG	0 261 210 147
		GS	0 261 210 178
Duo sensor, acceleration and yaw rate, brake system	06.01-05.04		0 265 005 252
Pressure sensor, ESP, (electronic stability program)	06.01-05.04		0 265 005 303
Wheel speed sensor, front			
Fg.no. 4B..2..031 501→4B..2..200 000	09.01-06.02		0 265 006 578
Fg.no. 4B..3..000 001→	07.02-05.04		0 265 006 765
Wheel speed sensor, rear			
Fg.no. →4B..2..079 500	06.01-12.01	ALR,LAB	0 265 006 586
		ALR,RAB	0 265 006 584
		OLW	0 265 006 584
Fg.no. 4B..2..079 501→	12.01-05.04	ALR,LAB	0 265 006 763
		ALR,RAB	0 265 006 761
		OLW	0 265 006 761
3.0 quattro [4F2; C6]		3,0l 160 kW BBJ 6 Zyl.	
Throttle valve assembly	04.04-05.06		0 280 750 030
Duo sensor, acceleration and yaw rate, brake system	04.04-05.06		0 265 005 692
Wheel speed sensor			
Fg.no. →4F..5..085 230	04.04-12.04	LAB	0 265 007 728
Fg.no. 4F..6..140 001→	02.06-05.06	LAB	0 265 007 930
		RAB	0 265 007 928
3.0 TDI quattro [4F2; C6]		3,0l 155 kW BNG 6 Zyl.	
Speed sensor, diesel	04.04→	FKW	0 261 210 145
High-pressure sensor (CR system)			
Fg.no. →4F..6..132 000	04.04-12.05		0 281 002 504
Boost pressure sensor, Diesel	04.04→		0 281 002 399
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →4F..6..250 000	04.04-05.06		0 265 005 692
Fg.no. 4F..7..000 001→	06.06→		0 265 005 619
Wheel speed sensor			
Fg.no. →4F..5..085 230	04.04-12.04	LAB	0 265 007 728
Fg.no. 4F..6..140 001→	02.06→	LAB	0 265 007 930
		RAB	0 265 007 928
3.0 TDI quattro [4F2; C6]		3,0l 165 kW BMK 6 Zyl.	
Speed sensor, diesel	04.04-05.06	FKW	0 261 210 145
High-pressure sensor (CR system)			
Fg.no. →4F..6..132 000	04.04-12.05		0 281 002 504
Boost pressure sensor, Diesel	04.04-05.06		0 281 002 399
Duo sensor, acceleration and yaw rate, brake system	04.04-05.06		0 265 005 692
Wheel speed sensor			
Fg.no. →4F..5..085 230	04.04-12.04	LAB	0 265 007 728
Fg.no. 4F..6..140 001→	02.06-05.06	LAB	0 265 007 930
		RAB	0 265 007 928

Product



◀ A6

3.0 TDI quattro [4F2; C6]		3,0l	171 kW	ASB	6 Zyl.
Speed sensor, diesel	06.06→	FKW	0 261 210 145		
Boost pressure sensor, Diesel	06.06→		0 281 002 399		
Duo sensor, acceleration and yaw rate, brake system	06.06→		0 265 005 619		
Wheel speed sensor	06.06→	LAB	0 265 007 930		
		RAB	0 265 007 928		
3.2 FSI [4F2; C6]		3,2l	188 kW	AUK	6 Zyl.
Throttle valve assembly	04.04-05.07		0 280 750 003		
Pressure sensor, intake manifold, gasoline	04.04-05.07		0 261 230 095		
Duo sensor, acceleration and yaw rate, brake system					
Fg.no. →4F..6..250 000	04.04-05.06		0 265 005 692		
Fg.no. 4F..7..000 001→	06.06-05.07		0 265 005 619		
Wheel speed sensor					
Fg.no. →4F..5..085 230	04.04-12.04	LAB	0 265 007 728		
Fg.no. 4F..6..140 001→	02.06-05.07	LAB	0 265 007 930		
		RAB	0 265 007 928		
3.2 FSI quattro [4F2; C6]		3,2l	188 kW	AUK	6 Zyl.
Throttle valve assembly	04.04→		0 280 750 003		
Pressure sensor, intake manifold, gasoline	04.04→		0 261 230 095		
Duo sensor, acceleration and yaw rate, brake system					
Fg.no. →4F..6..250 000	04.04-05.06		0 265 005 692		
Fg.no. 4F..7..000 001→	06.06→		0 265 005 619		
Wheel speed sensor					
Fg.no. →4F..5..085 230	04.04-12.04	LAB	0 265 007 728		
Fg.no. 4F..6..140 001→	02.06→	LAB	0 265 007 930		
		RAB	0 265 007 928		
3.2 FSI quattro [4F2; C6]		3,2l	188 kW	BKH	6 Zyl.
Throttle valve assembly	07.05→		0 280 750 003		
Pressure sensor, intake manifold, gasoline	07.05→		0 261 230 095		
Duo sensor, acceleration and yaw rate, brake system					
Fg.no. →4F..6..250 000	07.05-05.06		0 265 005 692		
Fg.no. 4F..7..000 001→	06.06→		0 265 005 619		
Wheel speed sensor	07.05→	LAB	0 265 007 930		
		RAB	0 265 007 928		
3.2 FSI quattro [4F2; C6]		3,2l	249 kW	BYU	6 Zyl.
Throttle valve assembly	09.06→		0 280 750 003		
Pressure sensor, intake manifold, gasoline	09.06→		0 261 230 095		
Duo sensor, acceleration and yaw rate, brake system	09.06→		0 265 005 619		
Wheel speed sensor	09.06→	LAB	0 265 007 930		
		RAB	0 265 007 928		
4.2 FSI quattro [4F2; C6]		4,2l	257 kW	BVJ	8 Zyl.
Throttle valve assembly	06.06→		0 280 750 003		
Air mass meter, gasoline injection	06.06→		0 280 218 069		
			🚗 0 986 280 220		
Duo sensor, acceleration and yaw rate, brake system	06.06→		0 265 005 619		
Wheel speed sensor	06.06→	LAB	0 265 007 930		
		RAB	0 265 007 928		
4.2 quattro [4B4; C5]		4,2l	220 kW	ARS	8 Zyl.
Throttle valve assembly	04.99-05.01		0 280 750 032		
Air mass meter, gasoline injection	04.99-05.01		0 280 218 015		
			🚗 0 986 280 207		
Phase sensor	04.99-05.01		0 232 101 024		
Speed sensor, ignition/injection	04.99-05.01	AG	0 261 210 190		
		GS	0 261 210 192		
Knock sensor	04.99-05.01		0 261 231 038		
Duo sensor, acceleration and yaw rate, brake system	04.99-05.01		0 265 005 214		



A

Product				
Pressure sensor, ESP, (electronic stability program)	04.99-05.01			0 265 005 303
Wheel speed sensor, front	04.99-05.01			0 265 006 578
Wheel speed sensor, rear	04.99-05.01	LAB		0 265 006 567
		RAB		0 265 006 565
4.2 quattro [4B4; C5]		4,2l	220 kW ASG	8 Zyl.
Throttle valve assembly	06.00-05.04			0 280 750 003
Air mass meter, gasoline injection	06.00-05.04			0 280 218 069
				0 986 280 220
Phase sensor	06.00-05.04			0 232 101 024
Speed sensor, ignition/injection	06.00-05.04	AG		0 261 210 190
		GS		0 261 210 192
Knock sensor	06.00-05.04			0 261 231 038
Duo sensor, acceleration and yaw rate, brake system	06.00-05.01			0 265 005 214
	06.01-05.04			0 265 005 252
Pressure sensor, ESP, (electronic stability program)	06.00-05.04			0 265 005 303
Wheel speed sensor, front				
Fg.no. →4B..2..200 000	06.00-06.02			0 265 006 578
Fg.no. 4B..3..000 001→	07.02-05.04			0 265 006 765
Wheel speed sensor, rear				
Fg.no. →4B..2..079 500	06.00-12.01	LAB		0 265 006 567
		RAB		0 265 006 565
Fg.no. 4B..2..079 501→	12.01-05.04	LAB		0 265 006 769
	01.02-05.04	RAB		0 265 006 767
4.2 quattro [4B4; C5]		4,2l	220 kW AWN	8 Zyl.
Throttle valve assembly	06.01-07.04			0 280 750 003
Air mass meter, gasoline injection	06.01-07.04			0 280 218 069
				0 986 280 220
Phase sensor	06.01-07.04			0 232 101 024
Speed sensor, ignition/injection	06.01-07.04			0 261 210 190
Knock sensor	06.01-07.04			0 261 231 038
Duo sensor, acceleration and yaw rate, brake system	06.01-07.04			0 265 005 252
Wheel speed sensor, front				
Fg.no. →4B..2..031 500	06.01-08.01			0 265 006 578
Fg.no. 4B..3..000 001→	07.02-07.04			0 265 006 765
Wheel speed sensor, rear				
Fg.no. →4B..2..079 500	06.01-12.01	LAB		0 265 006 567
		RAB		0 265 006 565
Fg.no. 4B..2..079 501→	12.01-07.04	LAB		0 265 006 769
	01.02-07.04	RAB		0 265 006 767
4.2 quattro [4F2; C6]		4,2l	246 kW BAT	8 Zyl.
Throttle valve assembly	04.04-05.06			0 280 750 003
Air mass meter, gasoline injection	04.04-05.06			0 280 218 069
				0 986 280 220
Speed sensor, ignition/injection	04.04-05.06			0 261 210 190
Duo sensor, acceleration and yaw rate, brake system	04.04-05.06			0 265 005 692
Wheel speed sensor				
Fg.no. →4F..5..085 230	04.04-12.04	LAB		0 265 007 728
Fg.no. 4F..6..140 001→	02.06-05.06	LAB		0 265 007 930
		RAB		0 265 007 928
A6 Avant				
1.8 [4A5; C4]		1,8l	92 kW ADR	4 Zyl.
Phase sensor	10.95-10.97			0 232 101 024
Knock sensor	10.95-10.97	LLE		0 261 231 038
		RLE		0 261 231 036
Temperature sensor, intake air, injection system	10.95-10.97			0 280 130 085
1.8 [4B5; C5]		1,8l	85 kW AFY	4 Zyl.
Phase sensor	02.98-05.00			0 232 101 024
Knock sensor	02.98-05.00	HI		0 261 231 036
		VO		0 261 231 038





Temperature sensor, intake air, injection system	02.98-05.00	0 280 130 085
Duo sensor, acceleration and yaw rate, brake system	02.98-05.00	0 265 005 214
1.8 [4B5; C5] 1,8l 92 kW AJP 4 Zyl.		
Phase sensor	02.98-04.99	0 232 101 024
Speed sensor, ignition/injection	02.98-04.99	0 261 210 147
Knock sensor	02.98-04.99 HI	0 261 231 036
	VO	0 261 231 038
Temperature sensor, intake air, injection system	02.98-04.99	0 280 130 085
Duo sensor, acceleration and yaw rate, brake system	02.98-04.99	0 265 005 214
1.8 [4B5; C5] 1,8l 92 kW AQE; ARH 4 Zyl.		
Throttle valve assembly		
Fg.no. 4B..X..124 001→	05.99-04.01	0 280 750 080
Air mass meter, gasoline injection	01.99-04.01	0 280 218 013
		0 986 280 206
Phase sensor	01.99-04.01	0 232 101 024
Speed sensor, ignition/injection	01.99-04.01	0 261 210 147
Knock sensor	01.99-04.01 HI	0 261 231 036
	VO	0 261 231 038
Temperature sensor, intake air, injection system	01.99-04.01	0 280 130 085
Duo sensor, acceleration and yaw rate, brake system	01.99-04.01	0 265 005 214
Pressure sensor, ESP, (electronic stability program)	01.99-04.01	0 265 005 303
1.8 quattro [4A5; C4] 1,8l 92 kW ADR 4 Zyl.		
Phase sensor	07.96-10.97	0 232 101 024
Knock sensor	07.96-10.97 KZB	0 261 231 036
	KZG	0 261 231 038
1.8 T [4B5; C5] 1,8l 110 kW AEB 4 Zyl.		
Air mass meter, gasoline injection	02.98-01.99	0 280 217 117
		0 986 280 201
Phase sensor	02.98-01.99	0 232 101 024
Knock sensor	02.98-01.99 HI	0 261 231 036
	VO	0 261 231 038
Pressure sensor, intake manifold, gasoline	02.98-01.99	0 280 101 001
Boost pressure sensor, gasoline	02.98-01.99	0 281 002 177
Temperature sensor, intake air, injection system	02.98-01.99	0 280 130 085
Duo sensor, acceleration and yaw rate, brake system	02.98-01.99	0 265 005 214
1.8 T [4B5; C5] 1,8l 110 kW ANB 4 Zyl.		
Throttle valve assembly	01.99-09.00	0 280 750 009
Air mass meter, gasoline injection	01.99-09.00	0 280 218 032
		0 986 280 210
Phase sensor	01.99-09.00	0 232 101 024
Knock sensor	01.99-09.00 HI	0 261 231 036
	VO	0 261 231 038
Boost pressure sensor, gasoline	01.99-09.00	0 281 002 177
Temperature sensor, intake air, injection system	01.99-09.00	0 280 130 085
Duo sensor, acceleration and yaw rate, brake system	01.99-09.00	0 265 005 214
1.8 T [4B5; C5] 1,8l 110 kW APU 4 Zyl.		
Throttle valve assembly	11.98-04.01	0 280 750 009
Air mass meter, gasoline injection	11.98-04.01	0 280 218 032
		0 986 280 210
Phase sensor	11.98-04.01	0 232 101 024
Knock sensor	11.98-04.01 HI	0 261 231 036
	VO	0 261 231 038
Boost pressure sensor, gasoline	11.98-04.01	0 281 002 177
Temperature sensor, intake air, injection system	11.98-04.01	0 280 130 085
Duo sensor, acceleration and yaw rate, brake system	11.98-04.01	0 265 005 214
Pressure sensor, ESP, (electronic stability program)	11.98-04.01	0 265 005 303



1.8 T [4B5; C5] 1,8l 110 kW ARK 4 Zyl.	
Throttle valve assembly	01.99-05.99 0 280 750 009
Air mass meter, gasoline injection	01.99-05.99 0 280 218 032
	0 986 280 210
Phase sensor	01.99-05.99 0 232 101 024
Knock sensor	01.99-05.99 HI 0 261 231 036
	VO 0 261 231 038
Boost pressure sensor, gasoline	01.99-05.99 0 281 002 177
Temperature sensor, intake air, injection system	01.99-05.99 0 280 130 085
Duo sensor, acceleration and yaw rate, brake system	01.99-05.99 0 265 005 214
1.8 T [4B5; C5] 1,8l 110 kW AWT 4 Zyl.	
Throttle valve assembly	05.00-04.01 0 280 750 009
Air mass meter, gasoline injection	05.00-04.01 0 280 218 063
	0 986 280 217
Phase sensor	05.00-04.01 0 232 101 024
Speed sensor, ignition/injection	05.00-04.01 0 281 002 222
Knock sensor	05.00-04.01 HI 0 261 231 036
	VO 0 261 231 038
Boost pressure sensor, gasoline	05.00-04.01 0 281 002 177
Temperature sensor, intake air, injection system	05.00-04.01 0 280 130 085
Duo sensor, acceleration and yaw rate, brake system	05.00-04.01 0 265 005 214
Pressure sensor, ESP, (electronic stability program)	05.00-04.01 0 265 005 303
1.8 T [4B5; C5] 1,8l 132 kW AJL 4 Zyl.	
Air mass meter, gasoline injection	02.98-10.00 0 280 217 117
	0 986 280 201
Phase sensor	02.98-10.00 0 232 101 024
Knock sensor	02.98-10.00 HI 0 261 231 036
	VO 0 261 231 038
Pressure sensor, intake manifold, gasoline	02.98-10.00 0 280 101 001
Boost pressure sensor, gasoline	02.98-10.00 0 281 002 177
Temperature sensor, intake air, injection system	02.98-10.00 0 280 130 085
Duo sensor, acceleration and yaw rate, brake system	02.98-10.00 0 265 005 214
1.8 T quattro [4B5; C5] 1,8l 110 kW AEB 4 Zyl.	
Air mass meter, gasoline injection	02.98-01.99 0 280 217 117
	0 986 280 201
Phase sensor	02.98-01.99 0 232 101 024
Knock sensor	02.98-01.99 HI 0 261 231 036
	VO 0 261 231 038
Pressure sensor, intake manifold, gasoline	02.98-01.99 0 280 101 001
Boost pressure sensor, gasoline	02.98-01.99 0 281 002 177
Temperature sensor, intake air, injection system	02.98-01.99 0 280 130 085
Duo sensor, acceleration and yaw rate, brake system	
Fg.no. 4B..X..026 001→	10.98-01.99 0 265 005 214
Yaw rate sensor, brake system	
Fg.no. →4B..X..026 000	02.98-10.98 0 265 005 207
Wheel speed sensor, rear	
Fg.no. 4B..X..062 732→	12.98-01.99 ALR,LAB 0 265 006 586
	ALR,RAB 0 265 006 584
	OLW 0 265 006 584
1.8 T quattro [4B5; C5] 1,8l 110 kW ANB 4 Zyl.	
Throttle valve assembly	01.99-09.00 0 280 750 009
Air mass meter, gasoline injection	01.99-09.00 0 280 218 032
	0 986 280 210
Phase sensor	01.99-09.00 0 232 101 024
Knock sensor	01.99-09.00 HI 0 261 231 036
	VO 0 261 231 038
Boost pressure sensor, gasoline	01.99-09.00 0 281 002 177
Temperature sensor, intake air, injection system	01.99-09.00 0 280 130 085





Product				
◀ A6 Avant				
Duo sensor, acceleration and yaw rate, brake system	01.99-09.00			0 265 005 214
Wheel speed sensor, rear	01.99-09.00	ALR,LAB	0 265 006 586	
		ALR,RAB	0 265 006 584	
		OLW	0 265 006 584	
1.8 T quattro [4B5; C5]		1,8l 110 kW APU 4 Zyl.		
Throttle valve assembly	11.98-05.01			0 280 750 009
Air mass meter, gasoline injection	11.98-05.01			0 280 218 032
				0 986 280 210
Phase sensor	11.98-05.01			0 232 101 024
Knock sensor	11.98-05.01	HI	0 261 231 036	
		VO	0 261 231 038	
Boost pressure sensor, gasoline	11.98-05.01			0 281 002 177
Temperature sensor, intake air, injection system	11.98-05.01			0 280 130 085
Duo sensor, acceleration and yaw rate, brake system	11.98-05.01			0 265 005 214
Pressure sensor, ESP, (electronic stability program)	11.98-05.01			0 265 005 303
Wheel speed sensor, rear				
Fg.no. 4B..X..062 732→	12.98-05.01	ALR,LAB	0 265 006 586	
		ALR,RAB	0 265 006 584	
		OLW	0 265 006 584	
1.8 T quattro [4B5; C5]		1,8l 110 kW ARK 4 Zyl.		
Throttle valve assembly	01.99-05.99			0 280 750 009
Air mass meter, gasoline injection	01.99-05.99			0 280 218 032
				0 986 280 210
Phase sensor	01.99-05.99			0 232 101 024
Knock sensor	01.99-05.99	HI	0 261 231 036	
		VO	0 261 231 038	
Boost pressure sensor, gasoline	01.99-05.99			0 281 002 177
Temperature sensor, intake air, injection system	01.99-05.99			0 280 130 085
Duo sensor, acceleration and yaw rate, brake system	01.99-05.99			0 265 005 214
Wheel speed sensor, rear	01.99-05.99	ALR,LAB	0 265 006 586	
		ALR,RAB	0 265 006 584	
1.8 T quattro [4B5; C5]		1,8l 110 kW AWT 4 Zyl.		
Throttle valve assembly	05.00-01.05			0 280 750 009
Air mass meter, gasoline injection	05.00-01.05			0 280 218 063
				0 986 280 217
Phase sensor	05.00-01.05			0 232 101 024
Speed sensor, ignition/injection	05.00-01.05			0 281 002 222
Knock sensor	05.00-01.05	HI	0 261 231 036	
		VO	0 261 231 038	
Boost pressure sensor, gasoline	05.00-01.05			0 281 002 177
Temperature sensor, intake air, injection system	05.00-01.05			0 280 130 085
Duo sensor, acceleration and yaw rate, brake system	05.00-05.01			0 265 005 214
	06.01-01.05			0 265 005 252
Pressure sensor, ESP, (electronic stability program)	05.00-01.05			0 265 005 303
Wheel speed sensor, front				
Fg.no. 4B..2..031 501→4B..2..200 000	09.01-06.02			0 265 006 578
Fg.no. 4B..3..000 001→	07.02-01.05			0 265 006 765
Wheel speed sensor, rear				
Fg.no. →4B..2..079 500	05.00-12.01	ALR,LAB	0 265 006 586	
		ALR,RAB	0 265 006 584	
		OLW	0 265 006 584	
Fg.no. 4B..2..079 501→	12.01-01.05	ALR,LAB	0 265 006 763	
		ALR,RAB	0 265 006 761	
		OLW	0 265 006 761	
1.8 T quattro [4B5; C5]		1,8l 132 kW AJL 4 Zyl.		
Air mass meter, gasoline injection	02.98-10.00			0 280 217 117
				0 986 280 201
Phase sensor	02.98-10.00			0 232 101 024
Knock sensor	02.98-10.00	HI	0 261 231 036	
		VO	0 261 231 038	

Product				
Pressure sensor, intake manifold, gasoline	02.98-10.00			0 280 101 001
Boost pressure sensor, gasoline	02.98-10.00			0 281 002 177
Temperature sensor, intake air, injection system	02.98-10.00			0 280 130 085
Duo sensor, acceleration and yaw rate, brake system				
Fg.no. 4B..X..026 001→	10.98-10.00			0 265 005 214
Yaw rate sensor, brake system				
Fg.no. →4B..X..026 000	02.98-10.98			0 265 005 207
Wheel speed sensor, rear				
Fg.no. 4B..X..062 732→	12.98-10.00	ALR,LAB	0 265 006 586	
		ALR,RAB	0 265 006 584	
		OLW	0 265 006 584	
1.9 TDI [4A5; C4]		1,9l 66 kW 1Z 4 Zyl.		
Pedal position sensor, diesel				
Fg.no. →4A..S..082 000	07.94-02.95	AG	0 205 001 018	
		GS	0 205 001 017	
Fg.no. 4A..S..082 001→	02.95-06.96	AG	0 205 001 031	
		GS	0 205 001 032	
1.9 TDI [4B5; C5]		1,9l 81/85 kW AFN; AJM 4 Zyl.		
Air mass meter, diesel	02.98-04.01			0 281 002 216
				0 986 284 001
Boost pressure sensor, Diesel	02.98-04.01			0 281 002 177
Pedal position sensor, diesel				
Fg.no. →4B..X..200 000	02.98-06.99	AG	0 281 002 289	
		GS	0 281 002 286	
Duo sensor, acceleration and yaw rate, brake system	02.98-04.01			0 265 005 214
Pressure sensor, ESP, (electronic stability program)	02.98-04.01			0 265 005 303
1.9 TDI [4B5; C5]		1,9l 96 kW AVF; AWW 4 Zyl.		
Air mass meter, diesel	06.01-01.05			0 281 002 461
				0 986 284 007
Boost pressure sensor, Diesel	06.01-01.05			0 281 002 401
Duo sensor, acceleration and yaw rate, brake system	06.01-01.05			0 265 005 252
Pressure sensor, ESP, (electronic stability program)	06.01-01.05			0 265 005 303
Wheel speed sensor, front				
Fg.no. 4B..2..031 501→4B..2..200 000	09.01-06.02			0 265 006 578
Fg.no. 4B..3..000 001→	07.02-01.05			0 265 006 765
2.0 [4A5; C4]		2,0l 85 kW ABK 4 Zyl.		
Knock sensor	06.94-06.96	LLE	0 261 231 038	
		RLE	0 261 231 036	
2.0 [4A5; C4]		2,0l 103 kW ACE 4 Zyl.		
Throttle valve sensor	07.96-10.97			0 280 120 426
Air flow sensor, gasoline injection	07.96-10.97			0 986 439 389
				F 026 TX2 059
				0 986 439 389
Phase sensor	07.96-10.97			0 232 101 024
Knock sensor	07.96-10.97	LLE	0 261 231 038	
		RLE	0 261 231 036	
2.0 [4B5; C5]		2,0l 96 kW ALT 4 Zyl.		
Throttle valve assembly	06.01-01.05			0 280 750 088
Air mass meter, gasoline injection	06.01-01.05			0 280 218 058
				0 986 280 215
Phase sensor	06.01-01.05			0 232 101 024
Speed sensor, ignition/injection	06.01-01.05			0 281 002 222
Temperature sensor, intake air, injection system	06.01-01.05			0 280 130 116
Duo sensor, acceleration and yaw rate, brake system	06.01-01.05			0 265 005 252
Pressure sensor, ESP, (electronic stability program)	06.01-01.05			0 265 005 303
Wheel speed sensor, front				
Fg.no. 4B..2..031 501→4B..2..200 000	09.01-06.02			0 265 006 578
Fg.no. 4B..3..000 001→	07.02-01.05			0 265 006 765



Product			
2.0 quattro [4A5; C4]			
Throttle valve sensor	06.94-10.97		0 280 120 426
Air flow sensor, gasoline injection	06.94-10.97		0 986 439 389
			F 026 TX2 059
			0 986 439 389
Phase sensor	06.94-10.97		0 232 101 024
Knock sensor	06.94-10.97	KZB	0 261 231 036
		KZG	0 261 231 038
2.0 TDI [4F5; C6]			
Air mass meter, diesel	09.05-06.06		0 281 002 461
			0 986 284 007
Boost pressure sensor, Diesel	09.05-06.06		0 281 002 401
Duo sensor, acceleration and yaw rate, brake system	09.05-06.06		0 265 005 601
Wheel speed sensor			
Fg.no. 4F..6..140 001→	02.06-06.06	LAB	0 265 007 930
		RAB	0 265 007 928
2.0 TDI [4F5; C6]			
Air mass meter, diesel	06.05-11.05		0 281 002 461
			0 986 284 007
Boost pressure sensor, Diesel	06.05-11.05		0 281 002 401
Duo sensor, acceleration and yaw rate, brake system	06.05-11.05		0 265 005 601
2.0 TDI [4F5; C6]			
Air mass meter, diesel	06.05→		0 281 002 461
			0 986 284 007
Boost pressure sensor, Diesel	06.05→		0 281 002 401
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →4F..6..250 000	06.05-05.06		0 265 005 601
Fg.no. 4F..7..000 001→	06.06→		0 265 005 619
Wheel speed sensor			
Fg.no. 4F..6..140 001→	02.06→	LAB	0 265 007 930
		RAB	0 265 007 928
2.0 TDI [4F5; C6]			
Air mass meter, diesel	06.05-11.05		0 281 002 461
			0 986 284 007
Boost pressure sensor, Diesel	06.05-11.05		0 281 002 401
Duo sensor, acceleration and yaw rate, brake system	06.05-11.05		0 265 005 601
2.0 TDI [4F5; C6]			
Air mass meter, diesel	06.05→		0 281 002 461
			0 986 284 007
Boost pressure sensor, Diesel	06.05→		0 281 002 401
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →4F..6..250 000	06.05-05.06		0 265 005 601
Fg.no. 4F..7..000 001→	06.06→		0 265 005 619
Wheel speed sensor			
Fg.no. 4F..6..140 001→	02.06→	LAB	0 265 007 930
		RAB	0 265 007 928
2.0 TFSI [4F5; C6]			
Speed sensor, ignition/injection	06.05→		0 261 210 199
Knock sensor	06.05→		0 261 231 146
Boost pressure sensor, gasoline	06.05→		0 261 230 073
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →4F..6..250 000	06.05-05.06		0 265 005 601
Fg.no. 4F..7..000 001→	06.06→		0 265 005 619
Wheel speed sensor			
Fg.no. 4F..6..140 001→	02.06→	LAB	0 265 007 930
		RAB	0 265 007 928



2.3 [4A5; C4]			
Throttle valve sensor	06.94-06.96	AG	0 280 120 433
Air flow sensor, gasoline injection	06.94-06.96		F 026 TX2 054
			F 026 TX2 054
Knock sensor	06.94-06.96		0 261 231 038
2.3 quattro [4A5; C4]			
Throttle valve sensor	07.96-07.97	AG	0 280 120 433
Air flow sensor, gasoline injection	07.96-07.97		F 026 TX2 054
			F 026 TX2 054
Knock sensor	07.96-07.97	KZB	0 261 231 036
		KZG	0 261 231 038
2.4 [4A5; C4]			
Throttle valve sensor	07.96-10.97		0 280 120 431
Knock sensor	07.96-10.97		0 261 231 036
2.4 [4B5; C5]			
Phase sensor	02.98-01.99		0 232 101 024
Speed sensor, ignition/injection	02.98-01.99	AG	0 261 210 147
		GS	0 261 210 178
Temperature sensor, intake air, injection system	02.98-01.99		0 280 130 085
Duo sensor, acceleration and yaw rate, brake system	02.98-01.99		0 265 005 214
2.4 [4B5; C5]			
Throttle valve assembly	02.99-05.00		0 280 750 030
Phase sensor	02.99-05.00		0 232 101 024
Speed sensor, ignition/injection	02.99-05.00	AG	0 261 210 147
		GS	0 261 210 178
Knock sensor			
Fg.no. →4B..X..200 000	02.99-06.99		0 261 231 036
Temperature sensor, intake air, injection system	02.99-05.00		0 280 130 085
Duo sensor, acceleration and yaw rate, brake system	02.99-05.00		0 265 005 214
2.4 [4B5; C5]			
Throttle valve assembly	06.01-01.05		0 280 750 030
Phase sensor	06.01-01.05		0 232 101 024
Speed sensor, ignition/injection	06.01-01.05	AG	0 261 210 147
		GS	0 261 210 178
Temperature sensor, intake air, injection system	06.01-01.05		0 280 130 085
Duo sensor, acceleration and yaw rate, brake system	06.01-01.05		0 265 005 252
Pressure sensor, ESP, (electronic stability program)	06.01-01.05		0 265 005 303
Wheel speed sensor, front			
Fg.no. 4B..2..031 501→4B..2..200 000	09.01-06.02		0 265 006 578
Fg.no. 4B..3..000 001→	07.02-01.05		0 265 006 765
2.4 [4B5; C5]			
Phase sensor	04.98-07.98		0 232 101 024
Speed sensor, ignition/injection	04.98-07.98	AG	0 261 210 147
		GS	0 261 210 178
Knock sensor	04.98-07.98		0 261 231 036
Temperature sensor, intake air, injection system	04.98-07.98		0 280 130 085
Duo sensor, acceleration and yaw rate, brake system	04.98-07.98		0 265 005 214
Pressure sensor, ESP, (electronic stability program)	04.98-07.98		0 265 005 303
2.4 [4B5; C5]			
Phase sensor	02.98-07.98		0 232 101 024
Speed sensor, ignition/injection	02.98-07.98	AG	0 261 210 147
		GS	0 261 210 178
Knock sensor	02.98-07.98		0 261 231 036
Temperature sensor, intake air, injection system	02.98-07.98		0 280 130 085
Duo sensor, acceleration and yaw rate, brake system	02.98-07.98		0 265 005 214
2.4 [4B5; C5]			
Throttle valve assembly	06.00-04.01		0 280 750 030
Phase sensor	06.00-04.01		0 232 101 024



Product



◀ A6 Avant

Speed sensor, ignition/injection	06.00-04.01	AG	0 261 210 147
		GS	0 261 210 178
Temperature sensor, intake air, injection system	06.00-04.01		0 280 130 085
Duo sensor, acceleration and yaw rate, brake system	06.00-04.01		0 265 005 252
Pressure sensor, ESP, (electronic stability program)	06.00-04.01		0 265 005 303
2.4 [4B5; C5]	2,4l 120 kW APZ 6 Zyl.		
Throttle valve assembly	11.98-05.00		0 280 750 030
Phase sensor	11.98-05.00		0 232 101 024
Speed sensor, ignition/injection	11.98-05.00	AG	0 261 210 147
		GS	0 261 210 178
Knock sensor			
Fg.no. →4B..X..200 000	11.98-06.99		0 261 231 036
Temperature sensor, intake air, injection system	11.98-05.00		0 280 130 085
Duo sensor, acceleration and yaw rate, brake system	11.98-05.00		0 265 005 214
2.4 [4B5; C5]	2,4l 121 kW AGA; ALF 6 Zyl.		
Phase sensor	04.97-01.99		0 232 101 024
Speed sensor, ignition/injection	04.97-01.99	AG	0 261 210 147
		GS	0 261 210 178
Knock sensor	04.97-01.99		0 261 231 036
Temperature sensor, intake air, injection system	04.97-01.99		0 280 130 085
Duo sensor, acceleration and yaw rate, brake system	04.97-01.99		0 265 005 214
2.4 [4B5; C5]	2,4l 121 kW APS; ARJ 6 Zyl.		
Throttle valve assembly	11.98-04.01		0 280 750 030
Phase sensor	11.98-04.01		0 232 101 024
Speed sensor, ignition/injection	11.98-04.01	AG	0 261 210 147
		GS	0 261 210 178
Knock sensor			
Fg.no. →4B..X..200 000	11.98-06.99		0 261 231 036
Temperature sensor, intake air, injection system	11.98-04.01		0 280 130 085
Duo sensor, acceleration and yaw rate, brake system	11.98-04.01		0 265 005 214
Pressure sensor, ESP, (electronic stability program)	11.98-04.01		0 265 005 303
2.4 [4B5; C5]	2,4l 125 kW BDV 6 Zyl.		
Throttle valve assembly	06.01-01.05		0 280 750 030
Phase sensor	06.01-01.05		0 232 101 024
Speed sensor, ignition/injection	06.01-01.05	AG	0 261 210 147
		GS	0 261 210 178
Temperature sensor, intake air, injection system	06.01-01.05		0 280 130 085
Duo sensor, acceleration and yaw rate, brake system	06.01-01.05		0 265 005 252
Pressure sensor, ESP, (electronic stability program)	06.01-01.05		0 265 005 303
Wheel speed sensor, front			
Fg.no. 4B..2..031 501→4B..2..200 000	09.01-06.02		0 265 006 578
Fg.no. 4B..3..000 001→	07.02-01.05		0 265 006 765
2.4 [4F5; C6]	2,4l 130 kW BDW 6 Zyl.		
Throttle valve assembly	03.05→		0 280 750 003
Pressure sensor, intake manifold, gasoline	03.05→		0 261 230 095
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →4F..6..250 000	03.05-05.06		0 265 005 601
Fg.no. 4F..7..000 001→	06.06→		0 265 005 619
Wheel speed sensor			
Fg.no. 4F..6..140 001→	02.06→	LAB	0 265 007 930
		RAB	0 265 007 928
2.4 quattro [4B5; C5]	2,4l 115 kW APC 6 Zyl.		
Phase sensor	08.98-05.01		0 232 101 024
Speed sensor, ignition/injection	08.98-05.01	AG	0 261 210 147
		GS	0 261 210 178
Knock sensor			
Fg.no. →4B..X..200 000	08.98-06.99		0 261 231 036

Product



Temperature sensor, intake air, injection system	08.98-05.01		0 280 130 085
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. 4B..X..026 001→	10.98-05.01		0 265 005 214
Yaw rate sensor, brake system			
Fg.no. →4B..X..026 000	08.98-10.98		0 265 005 207
Wheel speed sensor, rear			
Fg.no. 4B..X..062 732→	12.98-05.01	ALR,LAB	0 265 006 586
		ALR,RAB	0 265 006 584
		OLW	0 265 006 584
2.4 quattro [4B5; C5]	2,4l 120 kW AJG 6 Zyl.		
Phase sensor	02.98-01.99		0 232 101 024
Speed sensor, ignition/injection	02.98-01.99	AG	0 261 210 147
		GS	0 261 210 178
Knock sensor	02.98-01.99		0 261 231 036
Temperature sensor, intake air, injection system	02.98-01.99		0 280 130 085
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. 4B..X..026 001→	10.98-01.99		0 265 005 214
Yaw rate sensor, brake system			
Fg.no. →4B..X..026 000	02.98-10.98		0 265 005 207
Wheel speed sensor, rear			
Fg.no. 4B..X..062 732→	12.98-01.99	ALR,LAB	0 265 006 586
		ALR,RAB	0 265 006 584
		OLW	0 265 006 584
2.4 quattro [4B5; C5]	2,4l 120 kW APZ 6 Zyl.		
Throttle valve assembly	11.98-05.01		0 280 750 030
Phase sensor	11.98-05.01		0 232 101 024
Speed sensor, ignition/injection	11.98-05.01	AG	0 261 210 147
		GS	0 261 210 178
Knock sensor			
Fg.no. →4B..X..200 000	11.98-06.99		0 261 231 036
Temperature sensor, intake air, injection system	11.98-05.01		0 280 130 085
Duo sensor, acceleration and yaw rate, brake system	11.98-05.01		0 265 005 214
Wheel speed sensor, rear			
Fg.no. 4B..X..062 732→	12.98-05.01	ALR,LAB	0 265 006 586
		ALR,RAB	0 265 006 584
		OLW	0 265 006 584
2.4 quattro [4B5; C5]	2,4l 121 kW AGA; ALF 6 Zyl.		
Phase sensor	04.97-01.99		0 232 101 024
Speed sensor, ignition/injection	04.97-01.99	AG	0 261 210 147
		GS	0 261 210 178
Knock sensor	04.97-01.99		0 261 231 036
Temperature sensor, intake air, injection system	04.97-01.99		0 280 130 085
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. 4B..X..026 001→	10.98-01.99		0 265 005 214
Yaw rate sensor, brake system			
Fg.no. →4B..X..026 000	04.97-10.98		0 265 005 207
Wheel speed sensor, rear			
Fg.no. 4B..X..062 732→	12.98-01.99	ALR,LAB	0 265 006 586
		ALR,RAB	0 265 006 584
		OLW	0 265 006 584
2.4 quattro [4B5; C5]	2,4l 121 kW AML 6 Zyl.		
Throttle valve assembly	06.00-05.01		0 280 750 030
Phase sensor	06.00-05.01		0 232 101 024
Speed sensor, ignition/injection	06.00-05.01	AG	0 261 210 147
		GS	0 261 210 178
Temperature sensor, intake air, injection system	06.00-05.01		0 280 130 085
Duo sensor, acceleration and yaw rate, brake system	06.00-05.01		0 265 005 214



Pressure sensor, ESP, (electronic stability program)	06.00-05.01		0 265 005 303
Wheel speed sensor, rear	06.00-05.01	ALR,LAB	0 265 006 586
		ALR,RAB	0 265 006 584
		OLW	0 265 006 584
2.4 quattro [4B5; C5] 2,4l 121 kW APS 6 Zyl.			
Phase sensor	11.98-06.99		0 232 101 024
Speed sensor, ignition/injection	11.98-06.99	AG	0 261 210 147
		GS	0 261 210 178
Knock sensor	11.98-06.99		0 261 231 036
Temperature sensor, intake air, injection system	11.98-06.99		0 280 130 085
Duo sensor, acceleration and yaw rate, brake system	11.98-06.99		0 265 005 214
Wheel speed sensor, rear			
Fg.no. 4B..X..062 732→	12.98-06.99	ALR,LAB	0 265 006 586
		ALR,RAB	0 265 006 584
		OLW	0 265 006 584
2.4 quattro [4B5; C5] 2,4l 121 kW ARJ 6 Zyl.			
Throttle valve assembly	11.98-05.01		0 280 750 030
Phase sensor	11.98-05.01		0 232 101 024
Speed sensor, ignition/injection	11.98-05.01	AG	0 261 210 147
		GS	0 261 210 178
Knock sensor			
Fg.no. →4B..X..200 000	11.98-06.99		0 261 231 036
Temperature sensor, intake air, injection system	11.98-05.01		0 280 130 085
Duo sensor, acceleration and yaw rate, brake system	11.98-05.01		0 265 005 214
Pressure sensor, ESP, (electronic stability program)	11.98-05.01		0 265 005 303
Wheel speed sensor, rear			
Fg.no. 4B..X..062 732→	12.98-05.01	ALR,LAB	0 265 006 586
		ALR,RAB	0 265 006 584
		OLW	0 265 006 584
2.4 quattro [4B5; C5] 2,4l 125 kW BDV 6 Zyl.			
Throttle valve assembly	06.01-01.05		0 280 750 030
Phase sensor	06.01-01.05		0 232 101 024
Speed sensor, ignition/injection	06.01-01.05	AG	0 261 210 147
		GS	0 261 210 178
Temperature sensor, intake air, injection system	06.01-01.05		0 280 130 085
Duo sensor, acceleration and yaw rate, brake system	06.01-01.05		0 265 005 252
Pressure sensor, ESP, (electronic stability program)	06.01-01.05		0 265 005 303
Wheel speed sensor, front			
Fg.no. 4B..2..031 501→4B..2..200 000	09.01-06.02		0 265 006 578
Fg.no. 4B..3..000 001→	07.02-01.05		0 265 006 765
Wheel speed sensor, rear			
Fg.no. →4B..2..079 500	06.01-12.01	ALR,LAB	0 265 006 586
		ALR,RAB	0 265 006 584
		OLW	0 265 006 584
Fg.no. 4B..2..079 501→	12.01-01.05	ALR,LAB	0 265 006 763
		ALR,RAB	0 265 006 761
		OLW	0 265 006 761
2.4 quattro [4F5; C6] 2,4l 130 kW BDW 6 Zyl.			
Throttle valve assembly	03.05→		0 280 750 003
Pressure sensor, intake manifold, gasoline	03.05→		0 261 230 095
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →4F..6..250 000	03.05-05.06		0 265 005 601
Fg.no. 4F..7..000 001→	06.06→		0 265 005 619
Wheel speed sensor			
Fg.no. 4F..6..140 001→	02.06→	LAB	0 265 007 930
		RAB	0 265 007 928



2.5 TDI [4A5; C4]		2,5l 85/103 kW AAT; AEL 5 Zyl.	
Air mass meter, diesel	06.94-10.97		0 281 002 074
Pedal position sensor, diesel			
Fg.no. →4A..S..082 000	06.94-02.95	AG	0 205 001 018
		GS	0 205 001 017
Fg.no. 4A..S..082 001→	02.95-10.97	AG	0 205 001 031
		GS	0 205 001 032
2.5 TDI [4B5; C5]		2,5l 110 kW AFB 6 Zyl.	
Air mass meter, diesel	02.98-05.00		0 281 002 429
			0 986 284 005
Speed sensor, diesel	02.98-05.00		0 281 002 222
Pressure sensor, intake manifold, diesel	02.98-05.00		0 281 002 326
Pedal position sensor, diesel			
Fg.no. →4B..X..200 000	02.98-06.99	AG	0 281 002 289
		GS	0 281 002 286
Duo sensor, acceleration and yaw rate, brake system	02.98-05.00		0 265 005 214
2.5 TDI [4B5; C5]		2,5l 110 kW AKN 6 Zyl.	
Air mass meter, diesel			
Fg.no. →8D..X..400 000	11.98-06.99		0 281 002 429
			0 986 284 005
Fg.no. 8D..Y..000 001→	07.99-04.01		0 281 002 403
			0 986 284 004
Speed sensor, diesel	11.98-04.01		0 281 002 222
Pressure sensor, intake manifold, diesel	11.98-04.01		0 281 002 326
Pedal position sensor, diesel	11.98-04.01	AG	0 281 002 289
		GS	0 281 002 286
Duo sensor, acceleration and yaw rate, brake system	11.98-04.01		0 265 005 214
2.5 TDI [4B5; C5]		2,5l 114 kW AYM 6 Zyl.	
Speed sensor, diesel	06.01-06.02		0 281 002 222
Pressure sensor, intake manifold, diesel	06.01-06.02		0 281 002 326
Duo sensor, acceleration and yaw rate, brake system	06.01-06.02		0 265 005 252
Pressure sensor, ESP, (electronic stability program)	06.01-06.02		0 265 005 303
Wheel speed sensor, front			
Fg.no. 4B..2..031 501→	09.01-06.02		0 265 006 578
2.5 TDI [4B5; C5]		2,5l 120 kW BFC 6 Zyl.	
Speed sensor, diesel	07.02-08.03		0 281 002 222
Pressure sensor, intake manifold, diesel	07.02-08.03		0 281 002 326
Duo sensor, acceleration and yaw rate, brake system	07.02-08.03		0 265 005 252
Pressure sensor, ESP, (electronic stability program)	07.02-08.03		0 265 005 303
Wheel speed sensor, front	07.02-08.03		0 265 006 765
2.5 TDI [4B5; C5]		2,5l 132 kW AKE 6 Zyl.	
Speed sensor, diesel	10.99-08.03		0 281 002 222
Pressure sensor, intake manifold, diesel	10.99-08.03		0 281 002 326
Duo sensor, acceleration and yaw rate, brake system	10.99-05.01		0 265 005 214
Pressure sensor, ESP, (electronic stability program)	10.99-08.03		0 265 005 303
Wheel speed sensor, front			
Fg.no. 4B..2..031 501→4B..2..200 000	09.01-06.02		0 265 006 578
Fg.no. 4B..3..000 001→	07.02-08.03		0 265 006 765
2.5 TDI [4B5; C5]		2,5l 132 kW BAU; BCZ; BDG; BDH 6 Zyl.	
Speed sensor, diesel	11.02-01.05		0 281 002 222
Pressure sensor, intake manifold, diesel	11.02-01.05		0 281 002 326
Duo sensor, acceleration and yaw rate, brake system	11.02-01.05		0 265 005 252
Pressure sensor, ESP, (electronic stability program)	11.02-01.05		0 265 005 303
Wheel speed sensor, front	11.02-01.05		0 265 006 765
2.5 TDI quattro [4A5; C4]		2,5l 103 kW AEL 5 Zyl.	
Air mass meter, diesel	07.96-10.97		0 281 002 074
Pedal position sensor, diesel	07.96-10.97		0 205 001 032

Product				

◀ A6 Avant

2.5 TDI quattro [4B5; C5]		2,5l 110 kW AFB 6 Zyl.		
Air mass meter, diesel	02.98-05.00		0 281 002 429	0 986 284 005
Speed sensor, diesel	02.98-05.00		0 281 002 222	
Pressure sensor, intake manifold, diesel	02.98-05.00		0 281 002 326	
Pedal position sensor, diesel				
Fg.no. →4B..X..200 000	02.98-06.99	AG	0 281 002 289	
		GS	0 281 002 286	
Duo sensor, acceleration and yaw rate, brake system				
Fg.no. 4B..X..026 001→	10.98-05.00		0 265 005 214	
Yaw rate sensor, brake system				
Fg.no. →4B..X..026 000	02.98-10.98		0 265 005 207	
Wheel speed sensor, rear				
Fg.no. 4B..X..062 732→	12.98-05.00	ALR,LAB	0 265 006 586	
		ALR,RAB	0 265 006 584	
		OLW	0 265 006 584	
2.5 TDI quattro [4B5; C5]		2,5l 110 kW AKN 6 Zyl.		
Air mass meter, diesel	11.98-06.99		0 281 002 429	0 986 284 005
Speed sensor, diesel	11.98-06.99		0 281 002 222	
Pressure sensor, intake manifold, diesel	11.98-06.99		0 281 002 326	
Pedal position sensor, diesel	11.98-06.99	AG	0 281 002 289	
		GS	0 281 002 286	
Duo sensor, acceleration and yaw rate, brake system	11.98-06.99		0 265 005 214	
Wheel speed sensor, rear				
Fg.no. 4B..X..062 732→	12.98-06.99	ALR,LAB	0 265 006 586	
		ALR,RAB	0 265 006 584	
		OLW	0 265 006 584	
2.5 TDI quattro [4B5; C5]		2,5l 132 kW AKE 6 Zyl.		
Speed sensor, diesel	10.99-08.03		0 281 002 222	
Pressure sensor, intake manifold, diesel	10.99-08.03		0 281 002 326	
Duo sensor, acceleration and yaw rate, brake system	10.99-05.01		0 265 005 214	
	06.01-08.03		0 265 005 252	
Pressure sensor, ESP, (electronic stability program)	10.99-08.03		0 265 005 303	
Wheel speed sensor, front				
Fg.no. 4B..2..031 501→4B..2..200 000	09.01-06.02		0 265 006 578	
Fg.no. 4B..3..000 001→	07.02-08.03		0 265 006 765	
Wheel speed sensor, rear				
Fg.no. →4B..2..079 500	10.99-12.01	ALR,LAB	0 265 006 586	
		ALR,RAB	0 265 006 584	
		OLW	0 265 006 584	
Fg.no. 4B..2..079 501→	12.01-08.03	ALR,LAB	0 265 006 763	
		ALR,RAB	0 265 006 761	
		OLW	0 265 006 761	
2.5 TDI quattro [4B5; C5]		2,5l 132 kW BAU; BDH 6 Zyl.		
Speed sensor, diesel	02.03-01.05		0 281 002 222	
Pressure sensor, intake manifold, diesel	02.03-01.05		0 281 002 326	
Duo sensor, acceleration and yaw rate, brake system	02.03-01.05		0 265 005 252	
Pressure sensor, ESP, (electronic stability program)	02.03-01.05		0 265 005 303	
Wheel speed sensor, front	02.03-01.05		0 265 006 765	
Wheel speed sensor, rear	02.03-01.05	ALR,LAB	0 265 006 763	
		ALR,RAB	0 265 006 761	
		OLW	0 265 006 761	
2.6 [4A5; C4]		2,6l 102 kW ACZ 6 Zyl.		
Throttle valve sensor	06.94-07.96		0 280 120 431	
Phase sensor	06.94-07.96		0 232 101 027	
Temperature sensor, intake air, injection system	06.94-07.96	KZS	0 280 130 060	

Product				

2.6 [4A5; C4]		2,6l 110 kW ABC 6 Zyl.		
Throttle valve sensor	06.94-06.96		0 280 120 431	
Phase sensor	06.94-06.96		0 232 101 027	
Knock sensor	06.94-06.96		0 261 231 036	
Temperature sensor, intake air, injection system	06.94-06.96	KZS	0 280 130 060	
2.6 quattro [4A5; C4]		2,6l 102/110 kW ABC; ACZ 6 Zyl.		
Throttle valve sensor	06.94-10.97		0 280 120 431	
Phase sensor	06.94-10.97		0 232 101 027	
Knock sensor	06.94-10.97		0 261 231 036	
Temperature sensor, intake air, injection system	06.94-10.97	KZS	0 280 130 060	
2.7 Biturbo [4B5; C5]		2,7l 169 kW AJK 6 Zyl.		
Air mass meter, gasoline injection	02.99-05.01		0 280 218 038	0 986 280 212
Phase sensor	02.99-05.01		0 232 101 024	
Speed sensor, ignition/injection	02.99-05.01	GS	0 261 210 147	
Fg.no. →4B..1..006 637	02.99-05.00	AG	0 281 002 222	
Fg.no. 4B..1..006 638→	06.00-05.01	AG	0 261 210 217	
Knock sensor				
Fg.no. →4B..X..200 000	02.99-06.99		0 261 231 036	
Temperature sensor, intake air, injection system	02.99-05.01		0 280 130 085	
Duo sensor, acceleration and yaw rate, brake system	02.99-05.01		0 265 005 214	
Pressure sensor, ESP, (electronic stability program)	02.99-05.01		0 265 005 303	
2.7 Biturbo quattro [4B5; C5]		2,7l 169 kW AJK 6 Zyl.		
Air mass meter, gasoline injection	02.99-08.00		0 280 218 038	0 986 280 212
Phase sensor	02.99-08.00		0 232 101 024	
Speed sensor, ignition/injection	02.99-08.00	GS	0 261 210 147	
Fg.no. →4B..1..006 637	02.99-05.00	AG	0 281 002 222	
Fg.no. 4B..1..006 638→	06.00-08.00	AG	0 261 210 217	
Knock sensor				
Fg.no. →4B..X..200 000	02.99-06.99		0 261 231 036	
Temperature sensor, intake air, injection system	02.99-08.00		0 280 130 085	
Duo sensor, acceleration and yaw rate, brake system				
Fg.no. 4B..X..026 001→	02.99-08.00		0 265 005 214	
Wheel speed sensor, rear	02.99-08.00	ALR,LAB	0 265 006 586	
		ALR,RAB	0 265 006 584	
		OLW	0 265 006 584	
2.7 Biturbo quattro [4B5; C5]		2,7l 169 kW AZA 6 Zyl.		
Throttle valve assembly	09.00-05.01		0 280 750 003	
Speed sensor, ignition/injection	09.00-05.01	AG	0 261 210 217	
		GS	0 261 210 147	
Temperature sensor, intake air, injection system	09.00-05.01		0 280 130 085	
Duo sensor, acceleration and yaw rate, brake system	09.00-05.01		0 265 005 214	
Pressure sensor, ESP, (electronic stability program)	09.00-05.01		0 265 005 303	
Wheel speed sensor, rear	09.00-05.01	ALR,LAB	0 265 006 586	
		ALR,RAB	0 265 006 584	
		OLW	0 265 006 584	
2.7 Biturbo quattro [4B5; C5]		2,7l 184 kW ARE 6 Zyl.		
Throttle valve assembly	06.01-06.02		0 280 750 003	
Phase sensor	06.01-06.02		0 232 101 024	
Speed sensor, ignition/injection	06.01-06.02	AG	0 261 210 217	
		GS	0 261 210 147	
Temperature sensor, intake air, injection system	06.01-06.02		0 280 130 085	
Duo sensor, acceleration and yaw rate, brake system	06.01-06.02		0 265 005 252	
Pressure sensor, ESP, (electronic stability program)	06.01-06.02		0 265 005 303	
Wheel speed sensor, front				
Fg.no. 4B..2..031 501→	09.01-06.02		0 265 006 578	



Wheel speed sensor, rear			
Fg.no. →4B..2..079 500	06.01-12.01	ALR,LAB	0 265 006 586
		ALR,RAB	0 265 006 584
		OLW	0 265 006 584
Fg.no. 4B..2..079 501→	12.01-06.02	ALR,LAB	0 265 006 763
		ALR,RAB	0 265 006 761
		OLW	0 265 006 761
2.7 Biturbo quattro [4B5; C5]	2,7 l 184 kW BES 6 Zyl.		
Throttle valve assembly	07.02-01.05		0 280 750 003
Phase sensor	07.02-01.05		0 232 101 024
Speed sensor, ignition/injection	07.02-01.05	AG	0 261 210 217
		GS	0 261 210 147
Temperature sensor, intake air, injection system	07.02-01.05		0 280 130 085
Duo sensor, acceleration and yaw rate, brake system	07.02-01.05		0 265 005 252
Pressure sensor, ESP, (electronic stability program)	07.02-01.05		0 265 005 303
Wheel speed sensor, front	07.02-01.05		0 265 006 765
Wheel speed sensor, rear	07.02-01.05	ALR,LAB	0 265 006 763
		ALR,RAB	0 265 006 761
		OLW	0 265 006 761
2.7 TDI [4F5; C6]	2,7 l 120/132 kW BPP; BSG 6 Zyl.		
Speed sensor, diesel	03.05→	FKW	0 261 210 145
High-pressure sensor (CR system)			
Fg.no. →4F..6..132 000	03.05-12.05		0 281 002 504
Boost pressure sensor, Diesel	03.05→		0 281 002 399
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →4F..6..250 000	03.05-05.06		0 265 005 601
Fg.no. 4F..7..000 001→	06.06→		0 265 005 619
Wheel speed sensor			
Fg.no. 4F..6..140 001→	02.06→	LAB	0 265 007 930
		RAB	0 265 007 928
2.7 TDI quattro [4F5; C6]	2,7 l 120/132 kW BPP; BSG 6 Zyl.		
Speed sensor, diesel	06.05→	FKW	0 261 210 145
High-pressure sensor (CR system)			
Fg.no. →4F..6..132 000	06.05-12.05		0 281 002 504
Boost pressure sensor, Diesel	06.05→		0 281 002 399
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →4F..6..250 000	06.05-05.06		0 265 005 601
Fg.no. 4F..7..000 001→	06.06→		0 265 005 619
Wheel speed sensor			
Fg.no. 4F..6..140 001→	02.06→	LAB	0 265 007 930
		RAB	0 265 007 928
2.8 [4A5; C4]	2,8 l 120 kW AEJ 6 Zyl.		
Throttle valve sensor	06.94-07.96		0 280 120 431
2.8 [4A5; C4]	2,8 l 128 kW AAH 6 Zyl.		
Throttle valve sensor	09.94-07.96		0 280 120 431
Phase sensor	09.94-07.96		0 232 101 027
Knock sensor	09.94-07.96		0 261 231 036
2.8 [4A5; C4]	2,8 l 142 kW ACK 6 Zyl.		
Throttle valve sensor	10.95-10.97		0 280 120 431
Phase sensor	10.95-10.97		0 232 101 024
Speed sensor, ignition/injection	10.95-10.97		0 261 210 139
Knock sensor	10.95-10.97		0 261 231 036
Temperature sensor, intake air, injection system	10.95-10.97	KZS	0 280 130 060
2.8 [4B5; C5]	2,8 l 132 kW AGE 6 Zyl.		
Phase sensor	02.98-05.00		0 232 101 024
Speed sensor, ignition/injection	02.98-05.00	AG	0 261 210 147
		GS	0 261 210 178
Knock sensor			
Fg.no. →4B..X..200 000	02.98-06.99		0 261 231 036



Temperature sensor, intake air, injection system	02.98-05.00		0 280 130 085
Duo sensor, acceleration and yaw rate, brake system	02.98-05.00		0 265 005 214
2.8 [4B5; C5]	2,8 l 140 kW ATX 6 Zyl.		
Throttle valve assembly	07.99-04.01		0 280 750 030
Phase sensor	07.99-04.01		0 232 101 024
Speed sensor, ignition/injection	07.99-04.01	AG	0 261 210 147
		GS	0 261 210 178
Temperature sensor, intake air, injection system	07.99-04.01		0 280 130 085
Duo sensor, acceleration and yaw rate, brake system	07.99-04.01		0 265 005 214
Pressure sensor, ESP, (electronic stability program)	07.99-04.01		0 265 005 303
2.8 [4B5; C5]	2,8 l 142 kW ACK; ALG 6 Zyl.		
Phase sensor	02.98-01.99		0 232 101 024
Speed sensor, ignition/injection	02.98-01.99	AG	0 261 210 147
		GS	0 261 210 178
Knock sensor	02.98-01.99		0 261 231 036
Temperature sensor, intake air, injection system	02.98-01.99		0 280 130 085
Duo sensor, acceleration and yaw rate, brake system	02.98-01.99		0 265 005 214
2.8 [4B5; C5]	2,8 l 142 kW APR; AQD 6 Zyl.		
Throttle valve assembly	11.98-04.01		0 280 750 030
Phase sensor	11.98-04.01		0 232 101 024
Speed sensor, ignition/injection	11.98-04.01	AG	0 261 210 147
		GS	0 261 210 178
Knock sensor			
Fg.no. →4B..X..200 000	11.98-06.99		0 261 231 036
Temperature sensor, intake air, injection system	11.98-04.01		0 280 130 085
Duo sensor, acceleration and yaw rate, brake system	11.98-04.01		0 265 005 214
Pressure sensor, ESP, (electronic stability program)	11.98-04.01		0 265 005 303
2.8 FSI [4F5; C6]	2,8 l 154 kW BDX 6 Zyl.		
Pressure sensor, intake manifold, gasoline	11.06→		0 261 230 095
2.8 FSI quattro [4F5; C6]	2,8 l 154 kW BDX 6 Zyl.		
Pressure sensor, intake manifold, gasoline	11.06→		0 261 230 095
2.8 quattro [4A5; C4]	2,8 l 120 kW AEJ 6 Zyl.		
Throttle valve sensor	07.96-10.97		0 280 120 431
2.8 quattro [4A5; C4]	2,8 l 128 kW AAH 6 Zyl.		
Throttle valve sensor	06.94-10.97		0 280 120 431
Phase sensor	06.94-10.97		0 232 101 027
Knock sensor	06.94-10.97		0 261 231 036
2.8 quattro [4A5; C4]	2,8 l 142 kW ACK 6 Zyl.		
Throttle valve sensor	07.96-10.97		0 280 120 431
Phase sensor	07.96-10.97		0 232 101 024
Speed sensor, ignition/injection	07.96-10.97		0 261 210 139
Knock sensor	07.96-10.97		0 261 231 036
Temperature sensor, intake air, injection system	07.96-10.97	KZS	0 280 130 060
2.8 quattro [4B5; C5]	2,8 l 132 kW AGE 6 Zyl.		
Phase sensor	04.98-05.01		0 232 101 024
Speed sensor, ignition/injection	04.98-05.01	AG	0 261 210 147
		GS	0 261 210 178
Knock sensor			
Fg.no. →4B..X..200 000	04.98-06.99		0 261 231 036
Temperature sensor, intake air, injection system	04.98-05.01		0 280 130 085
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. 4B..X..026 001→	10.98-05.01		0 265 005 214
Yaw rate sensor, brake system			
Fg.no. →4B..X..026 000	04.98-10.98		0 265 005 207
Wheel speed sensor, rear			
Fg.no. 4B..X..062 732→	12.98-05.01	ALR,LAB	0 265 006 586
		ALR,RAB	0 265 006 584
		OLW	0 265 006 584



Product

◀ A6 Avant

2.8 quattro [4B5; C5]		2,8l 140 kW ATX 6 Zyl.
Throttle valve assembly	07.99-05.01	0 280 750 030
Phase sensor	07.99-05.01	0 232 101 024
Speed sensor, ignition/injection	07.99-05.01	AG 0 261 210 147
		GS 0 261 210 178
Temperature sensor, intake air, injection system	07.99-05.01	0 280 130 085
Duo sensor, acceleration and yaw rate, brake system	07.99-05.01	0 265 005 214
Pressure sensor, ESP, (electronic stability program)	07.99-05.01	0 265 005 303
Wheel speed sensor, rear	07.99-05.01	ALR,LAB 0 265 006 586
		ALR,RAB 0 265 006 584
		OLW 0 265 006 584

2.8 quattro [4B5; C5]		2,8l 142 kW ACK 6 Zyl.
Phase sensor	02.98-12.98	0 232 101 024
Speed sensor, ignition/injection	02.98-12.98	AG 0 261 210 147
		GS 0 261 210 178
Knock sensor	02.98-12.98	0 261 231 036
Temperature sensor, intake air, injection system	02.98-12.98	0 280 130 085
Duo sensor, acceleration and yaw rate, brake system		
Fg.no. 4B..X..026 001→	10.98-12.98	0 265 005 214
Yaw rate sensor, brake system		
Fg.no. →4B..X..026 000	02.98-10.98	0 265 005 207

2.8 quattro [4B5; C5]		2,8l 142 kW ALG 6 Zyl.
Phase sensor	02.98-01.99	0 232 101 024
Speed sensor, ignition/injection	02.98-01.99	AG 0 261 210 147
		GS 0 261 210 178
Knock sensor	02.98-01.99	0 261 231 036
Temperature sensor, intake air, injection system	02.98-01.99	0 280 130 085
Duo sensor, acceleration and yaw rate, brake system		
Fg.no. 4B..X..026 001→	10.98-01.99	0 265 005 214
Yaw rate sensor, brake system		
Fg.no. →4B..X..026 000	02.98-10.98	0 265 005 207

Wheel speed sensor, rear		
Fg.no. 4B..X..062 732→	12.98-01.99	ALR,LAB 0 265 006 586
		ALR,RAB 0 265 006 584
		OLW 0 265 006 584

2.8 quattro [4B5; C5]		2,8l 142 kW AMX 6 Zyl.
Throttle valve assembly	06.00-05.01	0 280 750 030
Phase sensor	06.00-05.01	0 232 101 024
Speed sensor, ignition/injection	06.00-05.01	AG 0 261 210 147
		GS 0 261 210 178
Knock sensor	06.00-05.01	0 261 231 036
Temperature sensor, intake air, injection system	06.00-05.01	0 280 130 085
Duo sensor, acceleration and yaw rate, brake system	06.00-05.01	0 265 005 252
Pressure sensor, ESP, (electronic stability program)	06.00-05.01	0 265 005 303
Wheel speed sensor, rear	06.00-05.01	ALR,LAB 0 265 006 586
		ALR,RAB 0 265 006 584
		OLW 0 265 006 584

2.8 quattro [4B5; C5]		2,8l 142 kW APR 6 Zyl.
Throttle valve assembly	01.99-05.01	0 280 750 030
Phase sensor	01.99-05.01	0 232 101 024
Speed sensor, ignition/injection	01.99-05.01	AG 0 261 210 147
		GS 0 261 210 178
Knock sensor		
Fg.no. →4B..X..200 000	01.99-06.99	0 261 231 036
Temperature sensor, intake air, injection system	01.99-05.01	0 280 130 085
Duo sensor, acceleration and yaw rate, brake system	01.99-05.01	0 265 005 214
Pressure sensor, ESP, (electronic stability program)	01.99-05.01	0 265 005 303

Product

Wheel speed sensor, rear	01.99-05.01	ALR,LAB 0 265 006 586
		ALR,RAB 0 265 006 584
		OLW 0 265 006 584

2.8 quattro [4B5; C5]		2,8l 142 kW AQD 6 Zyl.
Throttle valve assembly	11.98-07.99	0 280 750 030
Phase sensor	11.98-07.99	0 232 101 024
Speed sensor, ignition/injection	11.98-07.99	AG 0 261 210 147
		GS 0 261 210 178

Knock sensor		
Fg.no. →4B..X..200 000	11.98-06.99	0 261 231 036
Temperature sensor, intake air, injection system	11.98-07.99	0 280 130 085
Duo sensor, acceleration and yaw rate, brake system	11.98-07.99	0 265 005 214

Wheel speed sensor, rear		
Fg.no. 4B..X..062 732→	12.98-07.99	ALR,LAB 0 265 006 586
		ALR,RAB 0 265 006 584
		OLW 0 265 006 584

3.0 [4B5; C5]		3,0l 160/162 kW ASN; BBJ 6 Zyl.
Throttle valve assembly	06.01-01.05	0 280 750 030
Speed sensor, ignition/injection	06.01-01.05	AG 0 261 210 147
		GS 0 261 210 178

Duo sensor, acceleration and yaw rate, brake system	06.01-01.05	0 265 005 252
Pressure sensor, ESP, (electronic stability program)	06.01-01.05	0 265 005 303

Wheel speed sensor, front		
Fg.no. 4B..2..031 501→4B..2..200 000	09.01-06.02	0 265 006 578
Fg.no. 4B..3..000 001→	07.02-01.05	0 265 006 765

3.0 [4F5; C6]		3,0l 160 kW BBJ 6 Zyl.
Throttle valve assembly	03.05-05.06	0 280 750 030
Duo sensor, acceleration and yaw rate, brake system	03.05-05.06	0 265 005 601

Wheel speed sensor		
Fg.no. 4F..6..140 001→	02.06-05.06	LAB 0 265 007 930
		RAB 0 265 007 928

3.0 quattro [4B5; C5]		3,0l 160 kW BBJ 6 Zyl.
Throttle valve assembly	06.01-01.05	0 280 750 030
Phase sensor	06.01-01.05	0 232 101 024
Speed sensor, ignition/injection	06.01-01.05	AG 0 261 210 147
		GS 0 261 210 178

Duo sensor, acceleration and yaw rate, brake system	06.01-01.05	0 265 005 252
Pressure sensor, ESP, (electronic stability program)	06.01-01.05	0 265 005 303

Wheel speed sensor, front		
Fg.no. 4B..2..031 501→4B..2..200 000	09.01-06.02	0 265 006 578
Fg.no. 4B..3..000 001→	07.02-01.05	0 265 006 765

Wheel speed sensor, rear		
Fg.no. →4B..2..079 500	06.01-12.01	ALR,LAB 0 265 006 586
		ALR,RAB 0 265 006 584
		OLW 0 265 006 584
Fg.no. 4B..2..079 501→	12.01-01.05	ALR,LAB 0 265 006 763
		ALR,RAB 0 265 006 761
		OLW 0 265 006 761
		OLW 0 265 006 761

3.0 quattro [4B5; C5]		3,0l 162 kW ASN 6 Zyl.
Throttle valve assembly	06.01-01.05	0 280 750 030
Speed sensor, ignition/injection	06.01-01.05	AG 0 261 210 147
		GS 0 261 210 178

Duo sensor, acceleration and yaw rate, brake system	06.01-01.05	0 265 005 252
Pressure sensor, ESP, (electronic stability program)	06.01-01.05	0 265 005 303

Wheel speed sensor, front		
Fg.no. 4B..2..031 501→4B..2..200 000	09.01-06.02	0 265 006 578
Fg.no. 4B..3..000 001→	07.02-01.05	0 265 006 765



Wheel speed sensor, rear			
Fg.no. →4B..2..079 500	06.01-12.01	ALR, LAB	0 265 006 586
		ALR, RAB	0 265 006 584
		OLW	0 265 006 584
Fg.no. 4B..2..079 501→	12.01-01.05	ALR, LAB	0 265 006 763
		ALR, RAB	0 265 006 761
		OLW	0 265 006 761
3.0 quattro [4F5; C6]		3,0 l 160 kW BBJ 6 Zyl.	
Throttle valve assembly	03.05-05.06		0 280 750 030
Duo sensor, acceleration and yaw rate, brake system	03.05-05.06		0 265 005 601
Wheel speed sensor			
Fg.no. 4F..6..140 001→	02.06-05.06	LAB	0 265 007 930
		RAB	0 265 007 928
3.0 TDI quattro [4F5; C6]		3,0 l 155 kW BNG 6 Zyl.	
Speed sensor, diesel	03.05→	FKW	0 261 210 145
Boost pressure sensor, Diesel	03.05→		0 281 002 399
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →4F..6..250 000	03.05-05.06		0 265 005 601
Fg.no. 4F..7..000 001→	06.06→		0 265 005 619
Wheel speed sensor			
Fg.no. 4F..6..140 001→	02.06→	LAB	0 265 007 930
		RAB	0 265 007 928
3.0 TDI quattro [4F5; C6]		3,0 l 165 kW BMK 6 Zyl.	
Speed sensor, diesel	03.05-05.06	FKW	0 261 210 145
High-pressure sensor (CR system)			
Fg.no. →4F..6..132 000	03.05-12.05		0 281 002 504
Boost pressure sensor, Diesel	03.05-05.06		0 281 002 399
Duo sensor, acceleration and yaw rate, brake system	03.05-05.06		0 265 005 601
Wheel speed sensor			
Fg.no. 4F..6..140 001→	02.06-05.06	LAB	0 265 007 930
		RAB	0 265 007 928
3.0 TDI quattro [4F5; C6]		3,0 l 171 kW ASB 6 Zyl.	
Speed sensor, diesel	06.06→	FKW	0 261 210 145
Boost pressure sensor, Diesel	06.06→		0 281 002 399
Duo sensor, acceleration and yaw rate, brake system	06.06→		0 265 005 619
Wheel speed sensor	06.06→	LAB	0 265 007 930
		RAB	0 265 007 928
3.2 FSI [4F5; C6]		3,2 l 188 kW AUK 6 Zyl.	
Throttle valve assembly	03.05-05.07		0 280 750 003
Pressure sensor, intake manifold, gasoline	03.05-05.07		0 261 230 095
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →4F..6..250 000	03.05-05.06		0 265 005 601
Fg.no. 4F..7..000 001→	06.06-05.07		0 265 005 619
Wheel speed sensor			
Fg.no. 4F..6..140 001→	02.06-05.07	LAB	0 265 007 930
		RAB	0 265 007 928
3.2 FSI quattro [4F5; C6]		3,2 l 188 kW AUK 6 Zyl.	
Throttle valve assembly	03.05→		0 280 750 003
Pressure sensor, intake manifold, gasoline	03.05→		0 261 230 095
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →4F..6..250 000	03.05-05.06		0 265 005 601
Fg.no. 4F..7..000 001→	06.06→		0 265 005 619
Wheel speed sensor			
Fg.no. 4F..6..140 001→	02.06→	LAB	0 265 007 930
		RAB	0 265 007 928



4.2 FSI quattro [4F5; C6]		4,2 l 257 kW BVJ 8 Zyl.	
Throttle valve assembly	06.06→		0 280 750 003
Air mass meter, gasoline injection	06.06→		0 280 218 069
			0 986 280 220
Duo sensor, acceleration and yaw rate, brake system	06.06→		0 265 005 619
Wheel speed sensor	06.06→	LAB	0 265 007 930
		RAB	0 265 007 928
4.2 quattro [4B6; C5]		4,2 l 220 kW ARS 8 Zyl.	
Throttle valve assembly	04.99-05.01		0 280 750 032
Air mass meter, gasoline injection	04.99-05.01		0 280 218 015
			0 986 280 207
Phase sensor	04.99-05.01		0 232 101 024
Speed sensor, ignition/injection	04.99-05.01	AG	0 261 210 190
		GS	0 261 210 192
Knock sensor	04.99-05.01		0 261 231 038
Duo sensor, acceleration and yaw rate, brake system	04.99-05.01		0 265 005 214
Pressure sensor, ESP, (electronic stability program)	04.99-05.01		0 265 005 303
Wheel speed sensor, front	04.99-05.01		0 265 006 578
Wheel speed sensor, rear	04.99-05.01	LAB	0 265 006 567
		RAB	0 265 006 565
4.2 quattro [4B6; C5]		4,2 l 220 kW ASG 8 Zyl.	
Throttle valve assembly	06.01-01.05		0 280 750 003
Air mass meter, gasoline injection	06.01-01.05		0 280 218 069
			0 986 280 220
Phase sensor	06.01-01.05		0 232 101 024
Speed sensor, ignition/injection	06.01-01.05	AG	0 261 210 190
		GS	0 261 210 192
Knock sensor	06.01-01.05		0 261 231 038
Duo sensor, acceleration and yaw rate, brake system	06.01-01.05		0 265 005 252
Pressure sensor, ESP, (electronic stability program)	06.01-01.05		0 265 005 303
Wheel speed sensor, front			
Fg.no. →4B..2..200 000	06.01-06.02		0 265 006 578
Fg.no. 4B..3..000 001→	07.02-01.05		0 265 006 765
Wheel speed sensor, rear			
Fg.no. →4B..2..079 500	06.01-12.01	LAB	0 265 006 567
		RAB	0 265 006 565
Fg.no. 4B..2..079 501→	12.01-01.05	LAB	0 265 006 769
	01.02-01.05	RAB	0 265 006 767
4.2 quattro [4F5; C6]		4,2 l 246 kW BAT 8 Zyl.	
Throttle valve assembly	03.05-05.06		0 280 750 003
Air mass meter, gasoline injection	03.05-05.06		0 280 218 069
			0 986 280 220
Speed sensor, ignition/injection	03.05-05.06		0 261 210 190
Duo sensor, acceleration and yaw rate, brake system	03.05-05.06		0 265 005 601
Wheel speed sensor			
Fg.no. 4F..6..140 001→	02.06-05.06	LAB	0 265 007 930
		RAB	0 265 007 928

A6 Avant Allroad

2.5 TDI [4BH; C5]		2,5 l 120 kW BCZ 6 Zyl.	
Speed sensor, diesel	06.03-08.05		0 281 002 222
Pressure sensor, intake manifold, diesel	06.03-08.05		0 281 002 326
Duo sensor, acceleration and yaw rate, brake system	06.03-08.05		0 265 005 214
Wheel speed sensor, rear	06.03-08.05	LAB	0 265 006 781
		RAB	0 265 006 783

Product				
◀ A6 Avant Allroad				
2.5 TDI [4BH; C5]		2,5l 132 kW AKE 6 Zyl.		
Speed sensor, diesel	05.00-05.03			0 281 002 222
Pressure sensor, intake manifold, diesel	05.00-05.03			0 281 002 326
Duo sensor, acceleration and yaw rate, brake system	05.00-05.03			0 265 005 214
Wheel speed sensor, rear				
Fg.no. →4B..2..079 500	05.00-11.01	LAB		0 265 006 655
		RAB		0 265 006 657
Fg.no. 4B..2..079 501→	12.01-05.03	LAB		0 265 006 781
		RAB		0 265 006 783
2.5 TDI [4BH; C5]		2,5l 132 kW BAU 6 Zyl.		
Speed sensor, diesel	06.03-08.05			0 281 002 222
Pressure sensor, intake manifold, diesel	06.03-08.05			0 281 002 326
Duo sensor, acceleration and yaw rate, brake system	06.03-08.05			0 265 005 214
Wheel speed sensor, rear	06.03-08.05	LAB		0 265 006 781
		RAB		0 265 006 783
2.7 T [4BH; C5]		2,7l 184 kW ARE 6 Zyl.		
Throttle valve assembly	05.00-06.02			0 280 750 003
Phase sensor	05.00-06.02			0 232 101 024
Speed sensor, ignition/injection	05.00-06.02	AG		0 261 210 217
		GS		0 261 210 147
Temperature sensor, intake air, injection system	05.00-06.02			0 280 130 085
Duo sensor, acceleration and yaw rate, brake system	05.00-06.02			0 265 005 214
Wheel speed sensor, rear				
Fg.no. →4B..2..079 500	05.00-11.01	LAB		0 265 006 655
		RAB		0 265 006 657
Fg.no. 4B..2..079 501→	12.01-06.02	LAB		0 265 006 781
		RAB		0 265 006 783
2.7 T [4BH; C5]		2,7l 184 kW BES 6 Zyl.		
Throttle valve assembly	07.02-08.05			0 280 750 003
Phase sensor	07.02-08.05			0 232 101 024
Speed sensor, ignition/injection	07.02-08.05	AG		0 261 210 217
		GS		0 261 210 147
Temperature sensor, intake air, injection system	07.02-08.05			0 280 130 116
Duo sensor, acceleration and yaw rate, brake system	07.02-08.05			0 265 005 214
Wheel speed sensor, rear	07.02-08.05	LAB		0 265 006 781
		RAB		0 265 006 783
2.7 T [4BH; C5]		2,7l 187 kW APB 6 Zyl.		
Throttle valve assembly	09.00-06.02			0 280 750 003
Phase sensor	09.00-06.02			0 232 101 024
Speed sensor, ignition/injection	09.00-06.02	AG		0 261 210 217
		GS		0 261 210 147
Temperature sensor, intake air, injection system	09.00-06.02			0 280 130 085
Duo sensor, acceleration and yaw rate, brake system	09.00-06.02			0 265 005 214
Wheel speed sensor, front	09.00-06.02	B17,B18		0 265 006 578
2.7 T [4BH; C5]		2,7l 187 kW BEL 6 Zyl.		
Throttle valve assembly	07.02-08.05			0 280 750 003
Phase sensor	07.02-08.05			0 232 101 024
Speed sensor, ignition/injection	07.02-08.05	AG		0 261 210 217
		GS		0 261 210 147
Temperature sensor, intake air, injection system	07.02-08.05			0 280 130 116
Duo sensor, acceleration and yaw rate, brake system	07.02-08.05			0 265 005 214
Wheel speed sensor, rear	07.02-08.05	LAB		0 265 006 781
		RAB		0 265 006 783



Product				
2.7 TDI [4FH; C6]				
2,7l 120/132 kW BPP; BSG 6 Zyl.				
Speed sensor, diesel	05.06→	FKW		0 261 210 178
Duo sensor, acceleration and yaw rate, brake system				
Fg.no. →4F..7..075 000	05.06-10.06			0 265 005 601
Fg.no. 4F..7..075 001→	11.06→			0 265 005 692
Wheel speed sensor	05.06→	LAB		0 265 007 930
		RAB		0 265 007 928
3.0 TDI [4FH; C6]		3,0l 155/171 kW ASB; BNG 6 Zyl.		
Speed sensor, diesel	05.06→	FKW		0 261 210 178
Boost pressure sensor, Diesel	05.06→			0 281 002 399
Duo sensor, acceleration and yaw rate, brake system				
Fg.no. →4F..7..075 000	05.06-10.06			0 265 005 601
Fg.no. 4F..7..075 001→	11.06→			0 265 005 692
Wheel speed sensor	05.06→	LAB		0 265 007 930
		RAB		0 265 007 928
3.2 FSI [4FH; C6]		3,2l 188 kW AUK 6 Zyl.		
Throttle valve assembly	05.06→			0 280 750 003
Pressure sensor, intake manifold, gasoline	05.06→			0 261 230 095
Duo sensor, acceleration and yaw rate, brake system				
Fg.no. →4F..7..075 000	05.06-10.06			0 265 005 601
Fg.no. 4F..7..075 001→	11.06→			0 265 005 692
Wheel speed sensor	05.06→	LAB		0 265 007 930
		RAB		0 265 007 928
4.2 [4BH; C5]		4,2l 220 kW BAS 8 Zyl.		
Throttle valve assembly	07.02-08.05			0 280 750 003
Air mass meter, gasoline injection	07.02-08.05			0 280 218 069
				0 986 280 220
Speed sensor, ignition/injection	07.02-08.05			0 261 210 190
Duo sensor, acceleration and yaw rate, brake system	07.02-08.05			0 265 005 214
Wheel speed sensor, rear	07.02-08.05	LAB		0 265 006 781
		RAB		0 265 006 783
4.2 FSI [4FH; C6]		4,2l 257 kW BVJ 8 Zyl.		
Throttle valve assembly	05.06→			0 280 750 003
Air mass meter, gasoline injection	05.06→			0 280 218 069
				0 986 280 220
Pressure sensor, intake manifold, gasoline	05.06→			0 261 230 095
Duo sensor, acceleration and yaw rate, brake system				
Fg.no. →4F..7..075 000	05.06-10.06			0 265 005 601
Fg.no. 4F..7..075 001→	11.06→			0 265 005 692
Wheel speed sensor	05.06→	LAB		0 265 007 930
		RAB		0 265 007 928
A8				
2.5 TDI [4D2; D2]		2,5l 110 kW AFB 6 Zyl.		
Air mass meter, diesel	06.97-04.00			0 281 002 429
				0 986 284 005
Speed sensor, diesel	06.97-04.00	KZU		0 281 002 222
Pressure sensor, intake manifold, diesel	06.97-04.00			0 281 002 326
Pedal position sensor, diesel	08.98-04.00			0 281 002 331
	06.97-07.98	AG		0 281 002 253
		GS		0 281 002 229
Lateral acceleration sensor, brake system	06.97-04.00			0 265 005 127
Yaw rate sensor, brake system	06.97-04.00			0 265 005 207
Wheel speed sensor, front				
Fg.no. 4D..X..005 001→	10.98-04.00	16R		0 265 006 580
		20R		0 265 006 662



Wheel speed sensor, rear			
Fg.no. 4D..X..005 001→	10.98-04.00		0 265 006 588
2.5 TDI [4D2; D2]		2,5 l 110 kW AKN 6 Zyl.	
Air mass meter, diesel	11.97-09.02		0 281 002 429
			0 986 284 005
Speed sensor, diesel	11.97-09.02	KZU	0 281 002 222
Pressure sensor, intake manifold, diesel	11.97-09.02		0 281 002 326
Pedal position sensor, diesel	08.98-09.02		0 281 002 331
	11.97-07.98	AG	0 281 002 253
		GS	0 281 002 229
Lateral acceleration sensor, brake system	11.97-09.02		0 265 005 127
Yaw rate sensor, brake system	11.97-09.02		0 265 005 207
Pressure sensor, ESP, (electronic stability program)	11.97-09.02		0 265 005 303
Wheel speed sensor, front			
Fg.no. 4D..X..005 001→	10.98-09.02	16R	0 265 006 580
		20R	0 265 006 662
Wheel speed sensor, rear			
Fg.no. 4D..X..005 001→	10.98-09.02		0 265 006 588
2.5 TDI [4D2; D2]		2,5 l 132 kW AKE 6 Zyl.	
Speed sensor, diesel	05.00-09.02	KZU	0 281 002 222
Pressure sensor, intake manifold, diesel	05.00-09.02		0 281 002 326
Pedal position sensor, diesel	05.00-09.02		0 281 002 331
Lateral acceleration sensor, brake system	05.00-09.02		0 265 005 127
Yaw rate sensor, brake system	05.00-09.02		0 265 005 207
Pressure sensor, ESP, (electronic stability program)	05.00-09.02		0 265 005 303
Wheel speed sensor, front	05.00-09.02	16R	0 265 006 580
		20R	0 265 006 662
Wheel speed sensor, rear	05.00-09.02		0 265 006 588
2.5 TDI quattro [4D2; D2]		2,5 l 110 kW AFB; AKN 6 Zyl.	
Air mass meter, diesel	06.97-06.00		0 281 002 429
			0 986 284 005
Speed sensor, diesel	06.97-06.00	KZU	0 281 002 222
Pressure sensor, intake manifold, diesel	06.97-06.00		0 281 002 326
Pedal position sensor, diesel	08.98-06.00		0 281 002 331
	06.97-07.98	AG	0 281 002 253
		GS	0 281 002 229
Lateral acceleration sensor, brake system	06.97-06.00		0 265 005 127
Yaw rate sensor, brake system	06.97-06.00		0 265 005 207
Wheel speed sensor, front			
Fg.no. 4D..X..005 001→	10.98-06.00	16R,FKR	0 265 006 580
		20R,FKR	0 265 006 662
Wheel speed sensor, rear	06.97-06.00	FKR	0 265 006 588
2.5 TDI quattro [4D2; D2]		2,5 l 132 kW AKE 6 Zyl.	
Speed sensor, diesel	11.99-09.02	KZU	0 281 002 222
Pressure sensor, intake manifold, diesel	11.99-09.02		0 281 002 326
Pedal position sensor, diesel	11.99-09.02		0 281 002 331
Lateral acceleration sensor, brake system	11.99-09.02		0 265 005 127
Yaw rate sensor, brake system	11.99-09.02		0 265 005 207
Pressure sensor, ESP, (electronic stability program)	11.99-09.02		0 265 005 303
Wheel speed sensor, front	11.99-09.02	16R,FKR	0 265 006 580
		20R,FKR	0 265 006 662
Wheel speed sensor, rear	11.99-09.02	FKR	0 265 006 588
2.8 [4D2; D2]		2,8 l 120/128 kW AAH; AEJ 6 Zyl.	
Throttle valve sensor	06.94-03.96		0 280 120 431
Phase sensor	06.94-03.96		0 232 101 027
Knock sensor	06.94-03.96		0 261 231 036
Pedal position sensor, EMS (electronic engine management)	06.94-03.96		0 280 752 022
2.8 [4D2; D2]		2,8 l 142 kW ACK 6 Zyl.	
Throttle valve sensor	03.96-12.98		0 280 120 431
Phase sensor	03.96-12.98		0 232 101 024



Speed sensor, ignition/injection			
Fg.no. →4D..V..010 965	03.96-04.97	AG	0 261 210 139
		GS	0 261 210 134
Fg.no. 4D..V..010 966→	04.97-12.98	AG	0 281 002 222
		GS	0 261 210 147
Knock sensor	03.96-12.98		0 261 231 036
Pedal position sensor, EMS (electronic engine management)	03.96-12.98		0 280 752 022
Lateral acceleration sensor, brake system	03.96-12.98		0 265 005 127
Yaw rate sensor, brake system	03.96-12.98		0 265 005 207
Wheel speed sensor, front			
Fg.no. 4D..X..005 001→	10.98-12.98	16R	0 265 006 580
		20R	0 265 006 662
Wheel speed sensor, rear			
Fg.no. 4D..X..005 001→	10.98-12.98		0 265 006 588
2.8 [4D2; D2]		2,8 l 142 kW ALG 6 Zyl.	
Phase sensor	10.97-12.98		0 232 101 024
Speed sensor, ignition/injection	10.97-12.98	AG	0 281 002 222
		GS	0 261 210 147
Temperature sensor, intake air, injection system	10.97-12.98		0 280 130 085
Pedal position sensor, EMS (electronic engine management)	10.97-12.98		0 280 752 022
Lateral acceleration sensor, brake system	10.97-12.98		0 265 005 127
Yaw rate sensor, brake system	10.97-12.98		0 265 005 207
Wheel speed sensor, front			
Fg.no. 4D..X..005 001→	10.98-12.98	16R	0 265 006 580
		20R	0 265 006 662
Wheel speed sensor, rear			
Fg.no. 4D..X..005 001→	10.98-12.98		0 265 006 588
2.8 [4D2; D2]		2,8 l 142 kW AMX 6 Zyl.	
Throttle valve assembly	05.00-09.02		0 280 750 030
Phase sensor	05.00-09.02		0 232 101 024
Speed sensor, ignition/injection	05.00-09.02	AG	0 281 002 222
		GS	0 261 210 147
Temperature sensor, intake air, injection system	05.00-09.02		0 280 130 085
Pedal position sensor, EMS (electronic engine management)	05.00-09.02		0 280 752 022
Lateral acceleration sensor, brake system	05.00-09.02		0 265 005 127
Yaw rate sensor, brake system	05.00-09.02		0 265 005 207
Pressure sensor, ESP, (electronic stability program)	05.00-09.02		0 265 005 303
Wheel speed sensor, front	05.00-09.02	16R	0 265 006 580
		20R	0 265 006 662
Wheel speed sensor, rear	05.00-09.02		0 265 006 588
2.8 [4D2; D2]		2,8 l 142 kW APR 6 Zyl.	
Throttle valve assembly	01.99-04.99		0 280 750 030
Phase sensor	01.99-04.99		0 232 101 024
Speed sensor, ignition/injection	01.99-04.99	AG	0 281 002 222
		GS	0 261 210 147
Temperature sensor, intake air, injection system	01.99-04.99		0 280 130 085
Pedal position sensor, EMS (electronic engine management)	01.99-04.99		0 280 752 022
Lateral acceleration sensor, brake system	01.99-04.99		0 265 005 127
Yaw rate sensor, brake system	01.99-04.99		0 265 005 207
Wheel speed sensor, front	01.99-04.99	16R	0 265 006 580
		20R	0 265 006 662
Wheel speed sensor, rear	01.99-04.99		0 265 006 588
2.8 [4D2; D2]		2,8 l 142 kW AQD 6 Zyl.	
Throttle valve assembly	01.99-02.01		0 280 750 030
Phase sensor	01.99-02.01		0 232 101 024
Speed sensor, ignition/injection	01.99-02.01	AG	0 281 002 222
		GS	0 261 210 147
Temperature sensor, intake air, injection system	01.99-02.01		0 280 130 085



A



Product				
◀ A8				
Pedal position sensor, EMS (electronic engine management)	01.99-02.01			0 280 752 022
Lateral acceleration sensor, brake system	01.99-02.01			0 265 005 127
Yaw rate sensor, brake system	01.99-02.01			0 265 005 207
Pressure sensor, ESP, (electronic stability program)	01.99-02.01			0 265 005 303
Wheel speed sensor, front	01.99-02.01	16R		0 265 006 580
		20R		0 265 006 662
Wheel speed sensor, rear	01.99-02.01			0 265 006 588
2.8 FSI [4E; D3]		2,8 l	154 kW	BDX 6 Zyl.
Pressure sensor, intake manifold, gasoline	09.07→			0 261 230 095
Duo sensor, acceleration and yaw rate, brake system	09.07→			0 265 005 252
Pressure sensor, ESP, (electronic stability program)	09.07→			0 265 005 303
Wheel speed sensor	09.07→	LAB		0 265 007 930
		RAB		0 265 007 928
2.8 quattro [4D2; D2]	2,8 l	120/128 kW	AAH; AEJ	6 Zyl.
Throttle valve sensor	09.94-03.96			0 280 120 431
Phase sensor	09.94-03.96			0 232 101 027
Knock sensor	09.94-03.96			0 261 231 036
Pedal position sensor, EMS (electronic engine management)	09.94-03.96			0 280 752 022
2.8 quattro [4D2; D2]		2,8 l	142 kW	ACK 6 Zyl.
Throttle valve sensor	03.96-12.98			0 280 120 431
Phase sensor	03.96-12.98			0 232 101 024
Speed sensor, ignition/injection Fg.no. →4D..V..010 965	03.96-04.97	AG		0 261 210 139
		GS		0 261 210 134
Fg.no. 4D..V..010 966→	04.97-12.98	AG		0 281 002 222
		GS		0 261 210 147
Knock sensor	03.96-12.98			0 261 231 036
Pedal position sensor, EMS (electronic engine management)	03.96-12.98			0 280 752 022
Lateral acceleration sensor, brake system	03.96-12.98			0 265 005 127
Yaw rate sensor, brake system	03.96-12.98			0 265 005 207
Wheel speed sensor, front Fg.no. 4D..X..005 001→	10.98-12.98	16R,FKR		0 265 006 580
		20R,FKR		0 265 006 662
Wheel speed sensor, rear	03.96-12.98	FKR		0 265 006 588
2.8 quattro [4D2; D2]		2,8 l	142 kW	ALG 6 Zyl.
Phase sensor	10.97-12.98			0 232 101 024
Speed sensor, ignition/injection	10.97-12.98	AG		0 281 002 222
		GS		0 261 210 147
Knock sensor	10.97-12.98			0 261 231 036
Temperature sensor, intake air, injection system	10.97-12.98			0 280 130 085
Pedal position sensor, EMS (electronic engine management)	10.97-12.98			0 280 752 022
Lateral acceleration sensor, brake system	10.97-12.98			0 265 005 127
Yaw rate sensor, brake system	10.97-12.98			0 265 005 207
Wheel speed sensor, front Fg.no. 4D..X..005 001→	10.98-12.98	16R,FKR		0 265 006 580
		20R,FKR		0 265 006 662
Wheel speed sensor, rear	10.97-12.98	FKR		0 265 006 588
2.8 quattro [4D2; D2]		2,8 l	142 kW	AMX 6 Zyl.
Throttle valve assembly	05.00-09.02			0 280 750 030
Phase sensor	05.00-09.02			0 232 101 024
Speed sensor, ignition/injection	05.00-09.02	AG		0 281 002 222
		GS		0 261 210 147
Temperature sensor, intake air, injection system	05.00-09.02			0 280 130 085
Pedal position sensor, EMS (electronic engine management)	05.00-09.02			0 280 752 022
Lateral acceleration sensor, brake system	05.00-09.02			0 265 005 127
Yaw rate sensor, brake system	05.00-09.02			0 265 005 207
Pressure sensor, ESP, (electronic stability program)	05.00-09.02			0 265 005 303

Product				
Wheel speed sensor, front	05.00-09.02	16R,FKR	0 265 006 580	
		20R,FKR	0 265 006 662	
Wheel speed sensor, rear	05.00-09.02	FKR	0 265 006 588	
2.8 quattro [4D2; D2]	2,8l	142 kW	APR; AQD	6 Zyl.
Throttle valve assembly	01.99-04.99		0 280 750 030	
Phase sensor	01.99-04.99		0 232 101 024	
Speed sensor, ignition/injection	01.99-04.99	AG	0 281 002 222	
		GS	0 261 210 147	
Temperature sensor, intake air, injection system	01.99-04.99		0 280 130 085	
Pedal position sensor, EMS (electronic engine management)	01.99-04.99		0 280 752 022	
Lateral acceleration sensor, brake system	01.99-04.99		0 265 005 127	
Yaw rate sensor, brake system	01.99-04.99		0 265 005 207	
Wheel speed sensor, front	01.99-04.99	16R,FKR	0 265 006 580	
		20R,FKR	0 265 006 662	
Wheel speed sensor, rear	01.99-04.99	FKR	0 265 006 588	
3.0 [4E; D3]	3,0l	160/162 kW	ASN; BBJ	6 Zyl.
Throttle valve assembly	07.03-05.06		0 280 750 030	
Speed sensor, ignition/injection	07.03-05.06		0 261 210 178	
Duo sensor, acceleration and yaw rate, brake system	07.03-05.06		0 265 005 252	
Pressure sensor, ESP, (electronic stability program)	07.03-05.06		0 265 005 303	
Wheel speed sensor	07.03-05.06	LAB	0 265 007 930	
		RAB	0 265 007 928	
3.0 quattro [4E; D3]	3,0l	160 kW	BBJ	6 Zyl.
Throttle valve assembly	11.03-05.06		0 280 750 030	
Speed sensor, ignition/injection	11.03-05.06		0 261 210 178	
Duo sensor, acceleration and yaw rate, brake system	11.03-05.06		0 265 005 252	
Pressure sensor, ESP, (electronic stability program)	11.03-05.06		0 265 005 303	
Wheel speed sensor	11.03-05.06	LAB	0 265 007 930	
		RAB	0 265 007 928	
3.0 TDI quattro [4E; D3]	3,0l	155/171 kW	ASB; BNG	6 Zyl.
Speed sensor, diesel	11.03→	FKW	0 261 210 145	
High-pressure sensor (CR system)				
Fg.no. →4E..6..011 250	11.03-09.05		0 281 002 504	
Boost pressure sensor, Diesel	11.03→		0 281 002 399	
Duo sensor, acceleration and yaw rate, brake system	11.03→		0 265 005 252	
Pressure sensor, ESP, (electronic stability program)	11.03→		0 265 005 303	
Wheel speed sensor	11.03→	LAB	0 265 007 930	
		RAB	0 265 007 928	
3.2 FSI, FSI quattro [4E; D3]	3,2l	191 kW	BPK	6 Zyl.
Throttle valve assembly	06.05→		0 280 750 003	
Pressure sensor, intake manifold, gasoline	06.05→		0 261 230 095	
Duo sensor, acceleration and yaw rate, brake system	06.05→		0 265 005 252	
Pressure sensor, ESP, (electronic stability program)	06.05→		0 265 005 303	
Wheel speed sensor	06.05→	LAB	0 265 007 930	
		RAB	0 265 007 928	
3.3 TDI quattro [4D2; D2]	3,3l	165 kW	AKF	8 Zyl.
Air mass meter, diesel	12.99-08.02		0 281 002 435	
			 0 986 284 006	
Speed sensor, diesel	12.99-08.02		0 261 210 192	
Pressure sensor, intake manifold, diesel	12.99-08.02		0 281 002 326	
Pedal position sensor, diesel	12.99-08.02		0 281 002 331	
Lateral acceleration sensor, brake system	12.99-08.02		0 265 005 127	
Yaw rate sensor, brake system	12.99-08.02		0 265 005 207	
Pressure sensor, ESP, (electronic stability program)	12.99-08.02		0 265 005 303	
Wheel speed sensor, front	12.99-08.02	FKR	0 265 006 662	
Wheel speed sensor, rear	12.99-08.02	FKR	0 265 006 588	

Product



3.7 [4D2; D2]	3,7l 169 kW AEW; AKJ 8 Zyl.
Throttle valve sensor	07.95-12.98 0 280 120 431
Air mass meter, gasoline injection	07.95-12.98 0 280 217 804
Phase sensor	07.95-12.98 0 232 101 024
Speed sensor, ignition/injection	
Fg.no. →4B..X..004 999	07.95-10.98 0 261 210 143
Fg.no. 4D..X..005 001→	11.98-12.98 0 261 210 190
Knock sensor	07.95-12.98 LAB 0 261 231 040
	RAB 0 261 231 038
Temperature sensor, intake air, injection system	07.95-12.98 KZS 0 280 130 060
Pedal position sensor, EMS (electronic engine management)	07.95-12.98 0 280 752 022
Lateral acceleration sensor, brake system	07.95-12.98 0 265 005 127
Yaw rate sensor, brake system	07.95-12.98 0 265 005 207
Wheel speed sensor, front	
Fg.no. 4D..X..005 001→	10.98-12.98 16R 0 265 006 580
	20R 0 265 006 662
Wheel speed sensor, rear	
Fg.no. 4D..X..005 001→	10.98-12.98 0 265 006 588
3.7 [4D2; D2]	3,7l 191 kW AKC 8 Zyl.
Throttle valve assembly	05.00-09.02 0 280 750 003
Air mass meter, gasoline injection	05.00-09.02 0 280 218 069
	0 986 280 220
Phase sensor	05.00-09.02 0 232 101 024
Speed sensor, ignition/injection	05.00-09.02 0 261 210 190
Knock sensor	05.00-09.02 0 261 231 038
Pedal position sensor, EMS (electronic engine management)	05.00-09.02 0 280 752 022
Lateral acceleration sensor, brake system	05.00-09.02 0 265 005 127
Yaw rate sensor, brake system	05.00-09.02 0 265 005 207
Pressure sensor, ESP, (electronic stability program)	05.00-09.02 0 265 005 303
Wheel speed sensor, front	05.00-09.02 16R 0 265 006 580
	20R 0 265 006 662
Wheel speed sensor, rear	05.00-09.02 0 265 006 588
3.7 [4D2; D2]	3,7l 191 kW AQG 8 Zyl.
Throttle valve assembly	10.98-02.01 0 280 750 032
Air mass meter, gasoline injection	10.98-02.01 0 280 218 015
	0 986 280 207
Phase sensor	10.98-02.01 0 232 101 024
Speed sensor, ignition/injection	10.98-02.01 0 261 210 190
Knock sensor	10.98-02.01 0 261 231 038
Pedal position sensor, EMS (electronic engine management)	10.98-02.01 0 280 752 022
Lateral acceleration sensor, brake system	10.98-02.01 0 265 005 127
Yaw rate sensor, brake system	10.98-02.01 0 265 005 207
Pressure sensor, ESP, (electronic stability program)	10.98-02.01 0 265 005 303
Wheel speed sensor, front	10.98-02.01 16R 0 265 006 580
	20R 0 265 006 662
Wheel speed sensor, rear	10.98-02.01 0 265 006 588
3.7 quattro [4D2; D2]	3,7l 169 kW AEW; AKJ 8 Zyl.
Throttle valve sensor	10.95-12.98 0 280 120 431
Air mass meter, gasoline injection	10.95-12.98 0 280 217 804
Phase sensor	10.95-12.98 0 232 101 024
Speed sensor, ignition/injection	
Fg.no. →4B..X..004 999	10.95-10.98 0 261 210 143
Fg.no. 4D..X..005 001→	11.98-12.98 AG 0 261 210 190
	GS 0 261 210 192
Knock sensor	
Fg.no. →4D..X..004 999	10.95-10.98 LAB 0 261 231 040
	RAB 0 261 231 038
Fg.no. 4D..X..005 001→	10.98-12.98 0 261 231 038

Product



Temperature sensor, intake air, injection system	10.95-12.98 KZS 0 280 130 060
Pedal position sensor, EMS (electronic engine management)	10.95-12.98 0 280 752 022
Lateral acceleration sensor, brake system	10.95-12.98 0 265 005 127
Yaw rate sensor, brake system	10.95-12.98 0 265 005 207
Wheel speed sensor, front	
Fg.no. 4D..X..005 001→	10.98-12.98 16R,FKR 0 265 006 580
	20R,FKR 0 265 006 662
Wheel speed sensor, rear	10.95-12.98 FKR 0 265 006 588
3.7 quattro [4D2; D2]	3,7l 191 kW AKC 8 Zyl.
Throttle valve assembly	05.00-09.02 0 280 750 003
Air mass meter, gasoline injection	05.00-09.02 0 280 218 069
	0 986 280 220
Phase sensor	05.00-09.02 0 232 101 024
Speed sensor, ignition/injection	05.00-09.02 AG 0 261 210 190
	GS 0 261 210 192
Knock sensor	05.00-09.02 0 261 231 038
Pedal position sensor, EMS (electronic engine management)	05.00-09.02 0 280 752 022
Lateral acceleration sensor, brake system	05.00-09.02 0 265 005 127
Yaw rate sensor, brake system	05.00-09.02 0 265 005 207
Pressure sensor, ESP, (electronic stability program)	05.00-09.02 0 265 005 303
Wheel speed sensor, front	05.00-09.02 16R,FKR 0 265 006 580
	20R,FKR 0 265 006 662
Wheel speed sensor, rear	05.00-09.02 FKR 0 265 006 588
3.7 quattro [4D2; D2]	3,7l 191 kW AQG 8 Zyl.
Throttle valve assembly	10.98-02.01 0 280 750 032
Air mass meter, gasoline injection	10.98-02.01 0 280 218 015
	0 986 280 207
Phase sensor	10.98-02.01 0 232 101 024
Speed sensor, ignition/injection	10.98-02.01 AG 0 261 210 190
	GS 0 261 210 192
Knock sensor	10.98-02.01 0 261 231 038
Pedal position sensor, EMS (electronic engine management)	10.98-02.01 0 280 752 022
Lateral acceleration sensor, brake system	10.98-02.01 0 265 005 127
Yaw rate sensor, brake system	10.98-02.01 0 265 005 207
Pressure sensor, ESP, (electronic stability program)	10.98-02.01 0 265 005 303
Wheel speed sensor, front	10.98-02.01 16R,FKR 0 265 006 580
	20R,FKR 0 265 006 662
Wheel speed sensor, rear	10.98-02.01 FKR 0 265 006 588
3.7 quattro [4E; D3]	3,7l 206 kW BFL 8 Zyl.
Throttle valve assembly	11.02-05.06 0 280 750 003
Air mass meter, gasoline injection	11.02-05.06 0 280 218 069
	0 986 280 220
Phase sensor	11.02-05.06 0 232 101 024
Speed sensor, ignition/injection	11.02-05.06 0 261 210 245
Duo sensor, acceleration and yaw rate, brake system	11.02-05.06 0 265 005 252
Pressure sensor, ESP, (electronic stability program)	11.02-05.06 0 265 005 303
Wheel speed sensor	11.02-05.06 LAB 0 265 007 930
	RAB 0 265 007 928
4.0 TDI quattro [4E; D3]	4,0l 202 kW ASE 8 Zyl.
Speed sensor, diesel	05.03-07.05 FKW 0 261 210 192
High-pressure sensor (CR system)	05.03-07.05 0 281 002 606
Boost pressure sensor, Diesel	05.03-07.05 0 281 002 399
Duo sensor, acceleration and yaw rate, brake system	05.03-07.05 0 265 005 252
Pressure sensor, ESP, (electronic stability program)	05.03-07.05 0 265 005 303
Wheel speed sensor	05.03-07.05 LAB 0 265 007 930
	RAB 0 265 007 928



A



Product				

◀ A8

4.2 FSI quattro [4E; D3]				4,2l 257 kW BVJ 8 Zyl.
Throttle valve assembly	06.06→			0 280 750 003
Air mass meter, gasoline injection	06.06→			0 280 218 069
				0 986 280 220
Duo sensor, acceleration and yaw rate, brake system	06.06→			0 265 005 252
Pressure sensor, ESP, (electronic stability program)	06.06→			0 265 005 303
Wheel speed sensor	06.06→	LAB		0 265 007 930
		RAB		0 265 007 928
4.2 quattro [4D2; D2]				4,2l 175 kW ARU 8 Zyl.
Air mass meter, gasoline injection	02.99-04.00			0 280 218 015
				0 986 280 207
Speed sensor, ignition/injection	02.99-04.00	AG		0 261 210 190
		GS		0 261 210 192
Knock sensor	02.99-04.00			0 261 231 038
Pedal position sensor, EMS (electronic engine management)	02.99-04.00			0 280 752 022
Lateral acceleration sensor, brake system	02.99-04.00			0 265 005 127
Yaw rate sensor, brake system	02.99-04.00			0 265 005 207
Wheel speed sensor, front	02.99-04.00	16R,FKR		0 265 006 580
		20R,FKR		0 265 006 662
Wheel speed sensor, rear	02.99-04.00	FKR		0 265 006 588
4.2 quattro [4D2; D2]				4,2l 180 kW AEM 8 Zyl.
Throttle valve sensor	06.94-07.96			0 280 120 431
Air mass meter, gasoline injection	06.94-07.96			0 280 217 804
Phase sensor	06.94-07.96			0 232 101 024
Speed sensor, ignition/injection	06.94-07.96			0 261 210 111
Knock sensor	06.94-07.96	LAB		0 261 231 040
		RAB		0 261 231 038
Temperature sensor, intake air, injection system	06.94-07.96	KZS		0 280 130 060
Pedal position sensor, EMS (electronic engine management)	06.94-07.96			0 280 752 022
4.2 quattro [4D2; D2]				4,2l 210/220 kW ABZ; AGH 8 Zyl.
Throttle valve sensor	06.94-12.98			0 280 120 431
Air mass meter, gasoline injection	06.94-12.98			0 280 217 804
Phase sensor	06.94-12.98			0 232 101 024
Speed sensor, ignition/injection				
Fg.no. →4D..T..015 000	06.94-07.96			0 261 210 111
Fg.no. 4D..V..000 001→4D..X..004 999	07.96-10.98			0 261 210 143
Fg.no. 4D..X..005 001→	11.98-12.98	AG		0 261 210 190
		GS		0 261 210 192
Knock sensor				
Fg.no. →4D..X..004 999	06.94-10.98	LAB		0 261 231 040
		RAB		0 261 231 038
Fg.no. 4D..X..005 001→	10.98-12.98			0 261 231 038
Temperature sensor, intake air, injection system	06.94-12.98	KZS		0 280 130 060
Pedal position sensor, EMS (electronic engine management)	06.94-12.98			0 280 752 022
Lateral acceleration sensor, brake system	06.94-12.98			0 265 005 127
Yaw rate sensor, brake system	06.94-12.98			0 265 005 207
Wheel speed sensor, front				
Fg.no. 4D..X..005 001→	10.98-12.98	16R,FKR		0 265 006 580
		20R,FKR		0 265 006 662
Wheel speed sensor, rear	06.94-12.98	FKR		0 265 006 588
4.2 quattro [4D2; D2]				4,2l 220 kW AKG 8 Zyl.
Throttle valve sensor	04.97-12.98			0 280 120 431
Air mass meter, gasoline injection	04.97-12.98			0 280 217 804
Phase sensor	04.97-12.98			0 232 101 024
Speed sensor, ignition/injection				
Fg.no. →4D..X..004 999	04.97-10.98			0 261 210 143
Fg.no. 4D..X..005 001→	11.98-12.98	AG		0 261 210 190
		GS		0 261 210 192

Product				

Knock sensor				
Fg.no. →4D..X..004 999	04.97-10.98	LAB		0 261 231 040
		RAB		0 261 231 038
Fg.no. 4D..X..005 001→	10.98-12.98			0 261 231 038
Temperature sensor, intake air, injection system	04.97-12.98	KZS		0 280 130 060
Pedal position sensor, EMS (electronic engine management)	04.97-12.98			0 280 752 022
Lateral acceleration sensor, brake system	04.97-12.98			0 265 005 127
Yaw rate sensor, brake system	04.97-12.98			0 265 005 207
Wheel speed sensor, front				
Fg.no. 4D..X..005 001→	10.98-12.98	16R,FKR		0 265 006 580
		20R,FKR		0 265 006 662
Wheel speed sensor, rear	04.97-12.98	FKR		0 265 006 588
4.2 quattro [4D2; D2]				4,2l 228 kW AKB 8 Zyl.
Speed sensor, ignition/injection	05.99-05.00	AG		0 261 210 190
		GS		0 261 210 192
Pedal position sensor, EMS (electronic engine management)	05.99-05.00			0 280 752 022
4.2 quattro [4D2; D2]				4,2l 228 kW AQF 8 Zyl.
Air mass meter, gasoline injection	10.98-02.01			0 280 218 015
				0 986 280 207
Speed sensor, ignition/injection	10.98-02.01	AG		0 261 210 190
		GS		0 261 210 192
Pedal position sensor, EMS (electronic engine management)	10.98-02.01			0 280 752 022
Lateral acceleration sensor, brake system	10.98-02.01			0 265 005 127
Yaw rate sensor, brake system	10.98-02.01			0 265 005 207
Pressure sensor, ESP, (electronic stability program)	10.98-02.01			0 265 005 303
Wheel speed sensor, front	10.98-02.01	16R,FKR		0 265 006 580
		20R,FKR		0 265 006 662
Wheel speed sensor, rear	10.98-02.01	FKR		0 265 006 588
4.2 quattro [4D2; D2]				4,2l 228 kW AUW 8 Zyl.
Air mass meter, gasoline injection	05.00-09.02			0 280 218 069
				0 986 280 220
Speed sensor, ignition/injection	05.00-09.02	AG		0 261 210 190
		GS		0 261 210 192
Knock sensor	05.00-09.02			0 261 231 038
Pedal position sensor, EMS (electronic engine management)	05.00-09.02			0 280 752 022
Lateral acceleration sensor, brake system	05.00-09.02			0 265 005 127
Yaw rate sensor, brake system	05.00-09.02			0 265 005 207
Pressure sensor, ESP, (electronic stability program)	05.00-09.02			0 265 005 303
Wheel speed sensor, front	05.00-09.02	16R,FKR		0 265 006 580
		20R,FKR		0 265 006 662
Wheel speed sensor, rear	05.00-09.02	FKR		0 265 006 588
4.2 quattro [4E; D3]				4,2l 246 kW BFM 8 Zyl.
Throttle valve assembly	11.02-05.06			0 280 750 003
Air mass meter, gasoline injection	11.02-05.06			0 280 218 069
				0 986 280 220
Phase sensor	11.02-05.06			0 232 101 024
Speed sensor, ignition/injection	11.02-05.06			0 261 210 245
Duo sensor, acceleration and yaw rate, brake system	11.02-05.06			0 265 005 252
Pressure sensor, ESP, (electronic stability program)	11.02-05.06			0 265 005 303
Wheel speed sensor	11.02-05.06	LAB		0 265 007 930
		RAB		0 265 007 928
4.2 TDI quattro [4E; D3]				4,2l 235/240 kW BMC; BVN 8 Zyl.
Speed sensor, diesel	01.05→	FKW		0 261 210 192
Boost pressure sensor, Diesel	01.05→			0 281 002 401
Duo sensor, acceleration and yaw rate, brake system	01.05→			0 265 005 252
Pressure sensor, ESP, (electronic stability program)	01.05→			0 265 005 303



Wheel speed sensor	01.05→	LAB	0 265 007 930
		RAB	0 265 007 928
6.0 quattro [4D2; D2]	6,0l 309 kW AZC 12 Zyl.		
Air mass meter, gasoline injection	03.01-08.02		0 280 218 071
			0 986 280 221
Phase sensor	03.01-08.02		0 232 103 019
Pedal position sensor, EMS (electronic engine management)	03.01-08.02		0 280 752 022
Lateral acceleration sensor, brake system	03.01-08.02		0 265 005 127
Yaw rate sensor, brake system	03.01-08.02		0 265 005 207
Pressure sensor, ESP, (electronic stability program)	03.01-08.02		0 265 005 303
Wheel speed sensor, front	03.01-08.02	FKR	0 265 006 662
Wheel speed sensor, rear	03.01-08.02	FKR	0 265 006 588
6.0 quattro [4E; D3]	6,0l 331 kW BHT 12 Zyl.		
Air mass meter, gasoline injection	02.04→		0 280 218 143
Phase sensor	02.04→		0 232 103 019
Duo sensor, acceleration and yaw rate, brake system	02.04→		0 265 005 252
Pressure sensor, ESP, (electronic stability program)	02.04→		0 265 005 303
Wheel speed sensor	02.04→	LAB,OSS	0 265 007 930
		OSS,RAB	0 265 007 928
6.0 quattro [4E; D3]	6,0l 331 kW BSB 12 Zyl.		
Phase sensor	10.04→		0 232 103 019
Duo sensor, acceleration and yaw rate, brake system	10.04→		0 265 005 252
Pressure sensor, ESP, (electronic stability program)	10.04→		0 265 005 303
Wheel speed sensor	10.04→	LAB,OSS	0 265 007 930
		OSS,RAB	0 265 007 928
6.0 quattro [4E; D3]	6,0l 331 kW BTE 12 Zyl.		
Air mass meter, gasoline injection	02.05→		0 280 218 143
Phase sensor	02.05→		0 232 103 019
Duo sensor, acceleration and yaw rate, brake system	02.05→		0 265 005 252
Pressure sensor, ESP, (electronic stability program)	02.05→		0 265 005 303
Wheel speed sensor	02.05→	LAB,OSS	0 265 007 930
		OSS,RAB	0 265 007 928

Cabriolet

1.8 [8G7; B4]	1,8l 92 kW ADR 4 Zyl.		
Phase sensor	01.97-08.00		0 232 101 024
Knock sensor	01.97-08.00	KZB	0 261 231 036
		KZG	0 261 231 038
Temperature sensor, intake air, injection system	01.97-08.00		0 280 130 085
1.9 TDI [8G7; B4]	1,9l 66 kW AHU 4 Zyl.		
Pedal position sensor, diesel	07.96-08.00		0 205 001 032
2.0 [8G7; B4]	2,0l 85 kW ABK 4 Zyl.		
Phase sensor	01.93-09.98		0 232 101 027
Knock sensor	01.93-09.98	KZB	0 261 231 036
		KZG	0 261 231 038
2.0 [8G7; B4]	2,0l 103 kW ACE 4 Zyl.		
Throttle valve sensor	05.95-07.96		0 280 120 426
Air flow sensor, gasoline injection	05.95-07.96		0 986 439 389
			0 026 TX2 059
			0 986 439 389
2.3 [8G7; B4]	2,3l 98 kW NG 5 Zyl.		
Throttle valve sensor	06.91-07.94		0 280 120 433
Air flow sensor, gasoline injection	06.91-07.94		F 026 TX2 054
			0 026 TX2 054
Knock sensor	06.91-07.94	LLE	0 261 231 036
		RLE	0 261 231 038
Pressure sensor, intake manifold, gasoline	06.91-07.94		0 280 101 001
Temperature sensor, coolant, injection system	06.91-07.94		0 280 130 053



2.6 [8G7; B4]	2,6l 102 kW ACZ 6 Zyl.		
Throttle valve sensor	05.95-12.99		0 280 120 431
Phase sensor	05.95-12.99		0 232 101 027
Knock sensor	05.95-12.99		0 261 231 038
Temperature sensor, intake air, injection system	05.95-12.99	KZS	0 280 130 060
Temperature sensor, coolant, injection system	05.95-12.99	KZW	0 280 130 040
2.6 [8G7; B4]	2,6l 110 kW ABC 6 Zyl.		
Throttle valve sensor	01.94-08.00		0 280 120 431
Phase sensor	01.94-08.00		0 232 101 027
Knock sensor	01.94-08.00	KZB	0 261 231 036
		KZG	0 261 231 038
Temperature sensor, intake air, injection system	01.94-08.00	KZS	0 280 130 060
Temperature sensor, coolant, injection system	01.94-08.00	KZW	0 280 130 040
2.8 [8G7; B4]	2,8l 128 kW AAH 6 Zyl.		
Throttle valve sensor	11.92-08.00		0 280 120 431
Phase sensor	11.92-08.00		0 232 101 027
Knock sensor	11.92-08.00	KZB	0 261 231 036
		KZG	0 261 231 038
Temperature sensor, coolant, injection system	11.92-08.00	KZW	0 280 130 040

Coupé

1.8 [89; B3]	1,8l 82 kW DZ 4 Zyl.		
Air flow sensor, gasoline injection	08.89-07.91	FOB	F 026 TX2 051
			0 026 TX2 051
1.8 GT [85; B2]	1,8l 66 kW JN 4 Zyl.		
Air flow sensor, gasoline injection	01.85-07.88		F 026 TX2 063
			0 026 TX2 063
Temperature sensor, coolant, injection system	01.85-07.88		0 280 130 040
1.8 GT [85; B2]	1,8l 81 kW PV 4 Zyl.		
Air flow sensor, gasoline injection	08.86-07.88		F 026 TX2 063
			0 026 TX2 063
Knock sensor	08.86-07.88		0 261 231 038
Temperature sensor, coolant, injection system	08.86-07.88		0 280 130 040
1.8 GT [85; B2]	1,8l 82 kW DZ 4 Zyl.		
Air flow sensor, gasoline injection	08.86-07.88	FOB	F 026 TX2 051
			0 026 TX2 051
2.0 [89; B3]	2,0l 83 kW 3A 4 Zyl.		
Air flow sensor, gasoline injection	05.89-07.90		0 438 121 087
			0 986 439 387
Knock sensor	05.89-07.90	KZB,LLE	0 261 231 036
		KZG,RLE	0 261 231 038
Temperature sensor, coolant, injection system	05.89-07.90	KZW	0 280 130 040
2.0 [89; B3]	2,0l 85 kW AAD 4 Zyl.		
Throttle valve sensor	08.90-07.91		0 280 120 426
Air flow sensor, gasoline injection	08.90-07.91		0 438 121 087
			0 986 439 387
Knock sensor	08.90-07.91	KZB	0 261 231 036
Temperature sensor, coolant, injection system	08.90-07.91	KZW	0 280 130 040
2.0 [89; B3]	2,0l 85 kW ABK 4 Zyl.		
Knock sensor	09.91-12.95	KZB	0 261 231 036
2.0 [89; B3]	2,0l 101 kW 6A 4 Zyl.		
Air flow sensor, gasoline injection	01.92-07.92		0 986 439 389
			0 026 TX2 059
			0 986 439 389
Knock sensor	01.92-07.92	KZG	0 261 231 038
Temperature sensor, coolant, injection system	01.92-07.92	KZW	0 280 130 040
2.0 [89; B3]	2,0l 103 kW ACE 4 Zyl.		
Throttle valve sensor	08.92-12.95		0 280 120 426
Air flow sensor, gasoline injection	08.92-12.95		0 986 439 389
			0 026 TX2 059
			0 986 439 389

Product					
◀ Coupé					
Knock sensor	08.92-12.95	KZG	0 261 231 038		
Temperature sensor, coolant, injection system	08.92-12.95	KZW	0 280 130 040		
2.0 GT [85; B2]		2,0l	83 kW	SK	5 Zyl.
Knock sensor	02.86-07.86		0 261 231 038		
Wheel speed sensor, rear	02.86-07.86		0 265 001 099		
2.0 GT [85; B2]		2,0l	85 kW	HP	5 Zyl.
Air flow sensor, gasoline injection					
Fg.no. →85..G..140 638	08.83-02.86	FMB	0 438 121 005		
Wheel speed sensor, rear	08.83-07.86		0 265 001 099		
2.0 GT 5E [85; B2]		2,0l	81 kW	JL	5 Zyl.
Air flow sensor, gasoline injection	09.83-07.88		0 438 120 181		
Wheel speed sensor, rear	09.83-07.88		0 265 001 099		
2.0 GT 5E [85; B2]		2,0l	85 kW	JS	5 Zyl.
Air flow sensor, gasoline injection					
Fg.no. →85..G..140 638	09.83-02.86	FMB	0 438 121 005		
Wheel speed sensor, rear	09.83-07.86		0 265 001 099		
2.2 [89; B3]		2,2l	98 kW	KV	5 Zyl.
Air flow sensor, gasoline injection	11.88-07.91	FOB	0 438 120 211		
2.2 GT [85; B2]		2,2l	88 kW	KX	5 Zyl.
Air flow sensor, gasoline injection	01.84-07.88		F 026 TX2 064		
			F 026 TX2 064		
Pressure sensor, intake manifold, gasoline	01.84-07.88		0 280 101 001		
Temperature sensor, coolant, injection system	01.84-07.88		0 280 130 037		
Wheel speed sensor, rear	01.84-07.88		0 265 001 099		
2.2 GT [85; B2]		2,2l	98/100 kW	HY; KV	5 Zyl.
Air flow sensor, gasoline injection					
Fg.no. →85..G..140 638	09.84-02.86	FMB	0 438 121 005		
Wheel speed sensor, rear	09.84-07.88		0 265 001 099		
2.2 quattro [85; B2]		2,2l	89 kW	JT	5 Zyl.
Air flow sensor, gasoline injection	12.84-12.87	FOB	F 026 TX2 064		
			F 026 TX2 064		
Pressure sensor, intake manifold, gasoline	12.84-12.87		0 280 101 001		
Temperature sensor, coolant, injection system	12.84-12.87		0 280 130 037		
2.2 quattro [85; B2]		2,2l	98/100 kW	HY; KV	5 Zyl.
Air flow sensor, gasoline injection					
Fg.no. →85..G..140 638	12.84-02.86	FMB	0 438 121 005		
2.2 quattro [89; B3]		2,2l	98 kW	KV	5 Zyl.
Air flow sensor, gasoline injection	11.88-07.91	FOB	0 438 120 211		
2.2 S2 T quattro [89; B3]		2,2l	162 kW	3B	5 Zyl.
Air mass meter, gasoline injection	09.90-09.92		0 280 213 007		
			0 986 280 137		
Knock sensor	09.90-09.92	KZA	0 261 231 040		
		KZG	0 261 231 038		
Pressure sensor, intake manifold, gasoline	09.90-09.92		0 280 101 001		
Temperature sensor, coolant, injection system	09.90-09.92		0 280 130 037		
2.2 S2 T quattro [89; B3]		2,2l	169 kW	ABY	5 Zyl.
Throttle valve sensor	10.92-12.95		0 280 120 431		
Air mass meter, gasoline injection	10.92-12.95		0 280 213 007		
			0 986 280 137		
Knock sensor					
Fg.no. →8B..P..003 310	10.92-11.92	KZA	0 261 231 040		
Fg.no. 8B..P..003 311→	11.92-12.95	KZB	0 261 231 036		
Pressure sensor, intake manifold, gasoline	10.92-12.95		0 280 101 001		
2.3 [89; B3]		2,3l	98 kW	NG	5 Zyl.
Air flow sensor, gasoline injection	11.88-07.94		F 026 TX2 054		
			F 026 TX2 054		
Knock sensor	11.88-07.94	KZB,LLE	0 261 231 036		
		KZG,RLE	0 261 231 038		
Pressure sensor, intake manifold, gasoline	11.88-07.94		0 280 101 001		
Temperature sensor, coolant, injection system	11.88-07.94	2PO	0 280 130 053		



Product				
2.3 [89; B3]		2,3l 125 kW 7A 5 Zyl.		
Throttle valve sensor				
Fg.no. 8B..L..008 001→	11.89-07.91	0 280 120 422		
Temperature sensor, coolant, injection system	08.89-07.91	0 280 130 037		
2.3 GT [85; B2]		2,3l 98 kW NG 5 Zyl.		
Air flow sensor, gasoline injection	08.86-07.88	F 026 TX2 054		
		 F 026 TX2 054		
Knock sensor	08.86-07.88	0 261 231 038		
Pressure sensor, intake manifold, gasoline	08.86-07.88	0 280 101 001		
Temperature sensor, coolant, injection system	02.87-07.88	0 280 130 053		
Wheel speed sensor, rear	08.86-07.88	0 265 001 099		
2.3 quattro [85; B2]		2,3l 98 kW NG 5 Zyl.		
Air flow sensor, gasoline injection	01.87-12.87	F 026 TX2 054		
		 F 026 TX2 054		
Knock sensor	01.87-12.87	KZG	0 261 231 038	
Pressure sensor, intake manifold, gasoline	01.87-12.87	0 280 101 001		
Temperature sensor, coolant, injection system	01.87-12.87	2PO	0 280 130 053	
2.3 quattro [89; B3]		2,3l 98 kW NG 5 Zyl.		
Air flow sensor, gasoline injection	11.88-07.94	F 026 TX2 054		
		 F 026 TX2 054		
Knock sensor	11.88-07.94	KZB,LLE	0 261 231 036	
		KZG,RLE	0 261 231 038	
Pressure sensor, intake manifold, gasoline	11.88-07.94	0 280 101 001		
Temperature sensor, coolant, injection system	11.88-07.94	2PO	0 280 130 053	
2.3 quattro [89; B3]		2,3l 125 kW 7A 5 Zyl.		
Throttle valve sensor				
Fg.no. 8B..L..008 001→	11.89-07.91	0 280 120 422		
Temperature sensor, coolant, injection system	11.88-07.91	0 280 130 037		
2.6 [89; B3]		2,6l 110 kW ABC 6 Zyl.		
Phase sensor	08.92-12.95	0 232 101 027		
Knock sensor	08.92-12.95	KZB	0 261 231 036	
Temperature sensor, intake air, injection system	08.92-12.95	KZS	0 280 130 060	
Temperature sensor, coolant, injection system	08.92-12.95	KZW	0 280 130 040	
2.6 quattro [89; B3]		2,6l 110 kW ABC 6 Zyl.		
Throttle valve sensor	08.92-12.95	0 280 120 431		
Phase sensor	08.92-12.95	0 232 101 027		
Knock sensor	08.92-12.95	KZB	0 261 231 036	
Temperature sensor, intake air, injection system	08.92-12.95	KZS	0 280 130 060	
Temperature sensor, coolant, injection system	08.92-12.95	KZW	0 280 130 040	
2.8 [89; B3]		2,8l 128 kW AAH 6 Zyl.		
Throttle valve sensor	09.91-12.95	0 280 120 431		
Phase sensor	09.91-12.95	0 232 101 027		
Knock sensor	09.91-12.95	KZB	0 261 231 036	
Temperature sensor, coolant, injection system	09.91-12.95	KZW	0 280 130 040	
2.8 quattro [89; B3]		2,8l 128 kW AAH 6 Zyl.		
Throttle valve sensor	08.91-12.95	0 280 120 431		
Phase sensor	08.91-12.95	0 232 101 027		
Knock sensor	08.91-12.95	KZB	0 261 231 036	
Temperature sensor, coolant, injection system	08.91-12.95	KZW	0 280 130 040	
Quattro				
2.2 Turbo [85; B2]		2,2l 162 kW RR 5 Zyl.		
Air mass meter, gasoline injection	08.89-07.91	0 280 213 007		
		 0 986 280 137		
Knock sensor	08.89-07.91	KZB	0 261 231 036	
		KZG	0 261 231 038	
Temperature sensor, coolant, injection system	08.89-07.91	0 280 130 037		
2.2 Turbo Sport [85; B2]		2,2l 225 kW KW 5 Zyl.		
Air mass meter, gasoline injection	05.84-07.87	0 280 214 001		
		 0 986 280 124		
Acceleration sensor, ABS	05.84-07.87	0 265 005 002		



A



Q7			
3.0 TDI [4LB]	3,0l 155/171 kW	BUG; BUN 6 Zyl.	
Boost pressure sensor, Diesel	03.06-11.07	0 281 002 401	
3.6 FSI [4LB]	3,6l 206 kW	BHK 6 Zyl.	
Air mass meter, gasoline injection	03.07→	0 280 218 175	
4.2 FSI [4LB]	4,2l 257 kW	BAR 8 Zyl.	
Throttle valve assembly	03.06-05.08	0 280 750 003	
Air mass meter, gasoline injection	03.06-05.08	0 280 218 060	
		0 986 280 216	

RS4			
4.2 quattro [8EC; B7]	4,2l 309 kW	BNS 8 Zyl.	
Duo sensor, acceleration and yaw rate, brake system	11.05→	0 265 005 621	
Wheel speed sensor, front	11.05→	0 265 006 809	
Wheel speed sensor, rear	11.05→	0 265 006 824	RAB

RS4 Avant			
2.7 quattro [8D5; B5]	2,7l 280 kW	ASJ; AZR 6 Zyl.	
Air mass meter, gasoline injection	05.00-09.01	0 280 218 067	
		0 986 280 219	
Phase sensor	05.00-09.01	0 232 101 024	
Speed sensor, ignition/injection	05.00-09.01	0 261 210 147	
Boost pressure sensor, gasoline	05.00-09.01	0 281 002 177	
Temperature sensor, intake air, injection system	05.00-09.01	0 280 130 085	
Lateral acceleration sensor, brake system	05.00-09.01	0 265 005 127	
Duo sensor, acceleration and yaw rate, brake system	05.00-09.01	0 265 005 214	
Yaw rate sensor, brake system	05.00-09.01	0 265 005 207	
Wheel speed sensor, front	05.00-09.01	0 265 006 578	
Wheel speed sensor, rear	05.00-09.01	0 265 006 695	LAB
		0 265 006 693	RAB
4.2 quattro [8ED; B7]	4,2l 309 kW	BNS 8 Zyl.	
Duo sensor, acceleration and yaw rate, brake system	05.06→	0 265 005 621	
Wheel speed sensor, front	05.06→	0 265 006 809	
Wheel speed sensor, rear	05.06→	0 265 006 824	RAB

RS4 Cabriolet			
4.2 quattro [8HE; B7]	4,2l 309 kW	BNS 8 Zyl.	
Duo sensor, acceleration and yaw rate, brake system	05.06→	0 265 005 621	
Wheel speed sensor, front	05.06→	0 265 006 809	
Wheel speed sensor, rear	05.06→	0 265 006 824	RAB

RS6			
4.2 quattro [4B4]	4,2l 331 kW	BCY 8 Zyl.	
Throttle valve assembly	07.02-04.04	0 280 750 127	
Air mass meter, gasoline injection	07.02-04.04	0 280 218 065	
		0 986 280 218	
Phase sensor	07.02-04.04	0 232 101 024	
Speed sensor, ignition/injection	07.02-04.04	0 261 210 192	
Knock sensor	07.02-04.04	0 261 231 038	
Boost pressure sensor, gasoline	07.02-04.04	0 281 002 177	
Temperature sensor, intake air, injection system	07.02-04.04	0 280 130 060	
Duo sensor, acceleration and yaw rate, brake system	07.02-04.04	0 265 005 252	
Pressure sensor, ESP, (electronic stability program)	07.02-04.04	0 265 005 303	



Wheel speed sensor, front	07.02-04.04	0 265 006 765	
Wheel speed sensor, rear	07.02-04.04	0 265 006 767	RAB
Fg.no. →4B..4..900 476	07.02-08.03	0 265 006 771	LAB
Fg.no. 4B..4..900 477→	09.03-04.04	0 265 006 769	LAB

RS6 Avant			
4.2 quattro [4B6]	4,2l 331 kW	BCY 8 Zyl.	
Throttle valve assembly	05.02-04.04	0 280 750 127	
Air mass meter, gasoline injection	05.02-04.04	0 280 218 065	
		0 986 280 218	
Phase sensor	05.02-04.04	0 232 101 024	
Speed sensor, ignition/injection	05.02-04.04	0 261 210 192	
Knock sensor	05.02-04.04	0 261 231 038	
Boost pressure sensor, gasoline	05.02-04.04	0 281 002 177	
Temperature sensor, intake air, injection system	05.02-04.04	0 280 130 060	
Duo sensor, acceleration and yaw rate, brake system	05.02-04.04	0 265 005 252	
Pressure sensor, ESP, (electronic stability program)	05.02-04.04	0 265 005 303	
Wheel speed sensor, front	05.02-04.04	0 265 006 765	
Wheel speed sensor, rear	05.02-04.04	0 265 006 767	RAB
Fg.no. →4B..4..900 476	05.02-08.03	0 265 006 771	LAB
Fg.no. 4B..4..900 477→	09.03-04.04	0 265 006 769	LAB
4.2 quattro [4B6]	4,2l 353 kW	BRV 8 Zyl.	
Throttle valve assembly	04.04-09.04	0 280 750 127	
Air mass meter, gasoline injection	04.04-09.04	0 280 218 065	
		0 986 280 218	
Phase sensor	04.04-09.04	0 232 101 024	
Speed sensor, ignition/injection	04.04-09.04	0 261 210 192	
Knock sensor	04.04-09.04	0 261 231 038	
Boost pressure sensor, gasoline	04.04-09.04	0 281 002 177	
Temperature sensor, intake air, injection system	04.04-09.04	0 280 130 060	
Duo sensor, acceleration and yaw rate, brake system	04.04-09.04	0 265 005 252	
Pressure sensor, ESP, (electronic stability program)	04.04-09.04	0 265 005 303	
Wheel speed sensor, front	04.04-09.04	0 265 006 765	
Wheel speed sensor, rear	04.04-09.04	0 265 006 769	LAB
		0 265 006 767	RAB

R8			
4.2 quattro [423]	4,2l 309 kW	BYH 8 Zyl.	
Throttle valve assembly			
Fg.no. →42..8..000 500	04.07-05.07	0 280 750 003	
Air mass meter, gasoline injection	04.07→	0 280 218 143	
Duo sensor, acceleration and yaw rate, brake system	04.07→	0 265 005 621	MBH
		0 265 005 619	NBA
Wheel speed sensor	04.07→	0 265 007 928	LAB
		0 265 007 930	RAB

S3			
1.8 quattro [8L1]	1,8l 154 kW	AMK 4 Zyl.	
Throttle valve assembly	09.00-04.02	0 280 750 036	
Air mass meter, gasoline injection	09.00-04.02	0 280 218 065	
		0 986 280 218	
Phase sensor	09.00-04.02	0 232 101 024	NOC
Speed sensor, ignition/injection	09.00-04.02	0 261 210 199	FKW
Knock sensor	09.00-04.02	0 261 231 146	
Boost pressure sensor, gasoline			
Fg.no. →8L..1..080 000	09.00-02.01	0 281 002 177	
Fg.no. 8L..1..080 001→	02.01-04.02	0 261 230 073	
Temperature sensor, intake air, injection system	09.00-04.02	0 280 130 085	

Product



◀ S3

Accelerator pedal module	09.00-04.02	AG,RLE	0 280 752 213
		GS,LL	0 280 752 214
		GS,RLE	0 280 752 210
1.8 quattro [8L1]		1,8 l 154 kW APY 4 Zyl.	
Throttle valve assembly	08.98-08.00		0 280 750 036
Air mass meter, gasoline injection	08.98-08.00		0 280 218 034
			0 986 280 211
Phase sensor	08.98-08.00	NOC	0 232 101 024
Speed sensor, ignition/injection	08.98-08.00	FKW	0 261 210 147
Boost pressure sensor, gasoline	08.98-08.00		0 281 002 177
Temperature sensor, intake air, injection system	08.98-08.00		0 280 130 085
Accelerator pedal module	08.98-08.00	GS,LL	0 280 752 214
Fg.no. 8L..Y..000 001→	05.99-08.00	AG,RLE	0 280 752 213
		GS,RLE	0 280 752 210
Pedal position sensor, EMS (electronic engine management)			
Fg.no. →8L..X..090 000	08.98-04.99	GS,RLE	0 280 752 016
1.8 quattro [8L1]		1,8 l 154 kW AUL 4 Zyl.	
Air mass meter, gasoline injection	09.99-04.01		0 280 218 034
			0 986 280 211
Phase sensor	09.99-04.01	NOC	0 232 101 024
Speed sensor, ignition/injection	09.99-04.01	FKW	0 261 210 199
Boost pressure sensor, gasoline	09.99-04.01		0 281 002 177
1.8 quattro [8L1]		1,8 l 165 kW BAM 4 Zyl.	
Throttle valve assembly	08.01-06.03		0 280 750 036
Air mass meter, gasoline injection	08.01-06.03		0 280 218 065
			0 986 280 218
Phase sensor	08.01-06.03	NOC	0 232 101 024
Speed sensor, ignition/injection	08.01-06.03	FKW	0 261 210 199
Knock sensor	08.01-06.03		0 261 231 146
Boost pressure sensor, gasoline	08.01-06.03		0 261 230 073
Temperature sensor, intake air, injection system	08.01-06.03		0 280 130 085
Accelerator pedal module	08.01-06.03	AG,RLE	0 280 752 213
		GS,LL	0 280 752 214
		GS,RLE	0 280 752 210
2.0 TFSI quattro [8P1]		2,0 l 188/195 kW BHZ; BZC 4 Zyl.	
Speed sensor, ignition/injection	11.06→		0 261 210 199
Boost pressure sensor, gasoline	11.06→		0 281 002 401



A

S4

2.2 quattro [4A2; C4]		2,2 l 169 kW AAN 5 Zyl.	
Air mass meter, gasoline injection	07.92-07.94		0 280 213 007
			0 986 280 137
Knock sensor	07.92-07.94	KZB	0 261 231 036
		KZG	0 261 231 038
2.7 Biturbo quattro [8D2; B5]		2,7 l 187 kW APB 6 Zyl.	
Pedal position sensor, EMS (electronic engine management)	10.97-12.98		0 280 752 020
Lateral acceleration sensor, brake system	10.97-12.98		0 265 005 127
Duo sensor, acceleration and yaw rate, brake system	10.97-12.98		0 265 005 214
Yaw rate sensor, brake system	10.97-12.98		0 265 005 207
Wheel speed sensor, rear			
Fg.no. 8D..W..280 001→	06.98-12.98	ALR,LAB	0 265 006 571
		ALR,RAB	0 265 006 569
		OLW	0 265 006 569
2.7 Biturbo quattro [8D2; B5]		2,7 l 195 kW AGB 6 Zyl.	
Air mass meter, gasoline injection			
Fg.no. →8D..Y..300 000	10.97-06.00		0 280 218 038
			0 986 280 212
Phase sensor	10.97-10.00		0 232 101 024

Product				
Knock sensor				
Fg.no. →8D..X..260 000	10.97-04.99		0 261 231 036	
Temperature sensor, intake air, injection system	10.97-10.00		0 280 130 085	
Pedal position sensor, EMS (electronic engine management)	10.97-10.00		0 280 752 020	
Lateral acceleration sensor, brake system	10.97-10.00		0 265 005 127	
Duo sensor, acceleration and yaw rate, brake system	10.97-10.00		0 265 005 214	
Yaw rate sensor, brake system	10.97-10.00		0 265 005 207	
Wheel speed sensor, rear				
Fg.no. 8D..W..280 001→	06.98-10.00	ALR,LAB	0 265 006 571	
		ALR,RAB	0 265 006 569	
		OLW	0 265 006 569	
2.7 Biturbo quattro [8D2; B5]		2,7 l 195 kW AZB 6 Zyl.		
Phase sensor	11.00-09.01		0 232 101 024	
Temperature sensor, intake air, injection system	11.00-09.01		0 280 130 085	
Pedal position sensor, EMS (electronic engine management)	11.00-09.01		0 280 752 020	
Lateral acceleration sensor, brake system	11.00-09.01		0 265 005 127	
Duo sensor, acceleration and yaw rate, brake system	11.00-09.01		0 265 005 214	
Yaw rate sensor, brake system	11.00-09.01		0 265 005 207	
Wheel speed sensor, rear	11.00-09.01	ALR,LAB	0 265 006 571	
		ALR,RAB	0 265 006 569	
4.2 quattro [4A2; C4]		4,2 l 206 kW ABH 8 Zyl.		
Air mass meter, gasoline injection	07.92-07.94		0 280 216 001	
Knock sensor	07.92-07.94	KZA	0 261 231 040	
		KZG	0 261 231 038	
Temperature sensor, coolant, injection system	07.92-07.94		0 280 130 037	
4.2 quattro [8EC; B7]		4,2 l 253 kW BBK 8 Zyl.		
Throttle valve assembly	11.04→		0 280 750 003	
Air mass meter, gasoline injection	11.04→		0 280 218 067	
			0 986 280 219	
Speed sensor, ignition/injection	11.04→		0 261 210 190	
Duo sensor, acceleration and yaw rate, brake system				
Fg.no. →8E..5..600 000	11.04-05.05		0 265 005 601	
Fg.no. 8E..6..000 001→	06.05→		0 265 005 621	
Wheel speed sensor, front	11.04→		0 265 006 809	
Wheel speed sensor, rear	11.04→	ALR,RAB	0 265 006 824	
		OLW	0 265 006 824	
4.2 quattro [8E2; B6]		4,2 l 253 kW BBK 8 Zyl.		
Throttle valve assembly	03.03-12.04		0 280 750 003	
Air mass meter, gasoline injection	03.03-12.04		0 280 218 067	
			0 986 280 219	
Speed sensor, ignition/injection	03.03-12.04		0 261 210 190	
Duo sensor, acceleration and yaw rate, brake system	03.03-12.04		0 265 005 252	
Pressure sensor, ESP, (electronic stability program)	03.03-12.04		0 265 005 303	
Wheel speed sensor, front				
Fg.no. →8E..3..500 000	03.03-05.03		0 265 006 683	
Fg.no. 8E..4..000 001→	06.03-12.04		0 265 006 809	
Wheel speed sensor, rear				
Fg.no. →8E..4..050 000	03.03-05.04	ALR,LAB	0 265 006 707	
Fg.no. →8E..4..400 000	03.03-05.04	ALR,RAB	0 265 006 681	
		OLW	0 265 006 681	
Fg.no. 8E..5..000 001→	06.04-12.04	ALR,LAB	0 265 006 826	
		ALR,RAB	0 265 006 824	
		OLW	0 265 006 824	





S4 Avant

2.7 Biturbo quattro [8D5; B5]		2,7 l 195 kW AGB 6 Zyl.
Air mass meter, gasoline injection		
Fg.no. →8D..Y..300 000	10.97-06.00	0 280 218 038 0 986 280 212
Phase sensor	10.97-09.01	0 232 101 024
Knock sensor		
Fg.no. →8D..X..260 000	10.97-04.99	0 261 231 036
Temperature sensor, intake air, injection system	10.97-09.01	0 280 130 085
Pedal position sensor, EMS (electronic engine management)	10.97-09.01	0 280 752 020
Lateral acceleration sensor, brake system	10.97-09.01	0 265 005 127
Duo sensor, acceleration and yaw rate, brake system	10.97-09.01	0 265 005 214
Yaw rate sensor, brake system	10.97-09.01	0 265 005 207
Wheel speed sensor, rear		
Fg.no. 8D..W..280 001→	06.98-09.01	ALR,LAB 0 265 006 571 ALR,RAB 0 265 006 569 OLW 0 265 006 569
2.7 Biturbo quattro [8D5; B5]		2,7 l 195 kW AZB 6 Zyl.
Phase sensor	11.00-09.01	0 232 101 024
Temperature sensor, intake air, injection system	11.00-09.01	0 280 130 085
Pedal position sensor, EMS (electronic engine management)	11.00-09.01	0 280 752 020
Lateral acceleration sensor, brake system	11.00-09.01	0 265 005 127
Duo sensor, acceleration and yaw rate, brake system	11.00-09.01	0 265 005 214
Yaw rate sensor, brake system	11.00-09.01	0 265 005 207
Wheel speed sensor, rear	11.00-09.01	ALR,LAB 0 265 006 571 ALR,RAB 0 265 006 569
4.2 quattro [8E; B7]		4,2 l 253 kW BBK; BHF 8 Zyl.
Throttle valve assembly	11.04→	0 280 750 003
Air mass meter, gasoline injection	11.04→	0 280 218 067 0 986 280 219
Speed sensor, ignition/injection	11.04→	0 261 210 190
Duo sensor, acceleration and yaw rate, brake system		
Fg.no. →8E..5..600 000	11.04-05.05	0 265 005 601
Fg.no. 8E..6..000 001→	06.05→	0 265 005 621
Wheel speed sensor, front	11.04→	0 265 006 809
Wheel speed sensor, rear	11.04→	ALR,RAB 0 265 006 824 OLW 0 265 006 824
4.2 quattro [8E5; B6]		4,2 l 253 kW BBK 8 Zyl.
Throttle valve assembly	03.03-12.04	0 280 750 003
Air mass meter, gasoline injection	03.03-12.04	0 280 218 067 0 986 280 219
Speed sensor, ignition/injection	03.03-12.04	0 261 210 190
Duo sensor, acceleration and yaw rate, brake system	03.03-12.04	0 265 005 252
Pressure sensor, ESP, (electronic stability program)	03.03-12.04	0 265 005 303
Wheel speed sensor, front		
Fg.no. →8E..3..500 000	03.03-05.03	0 265 006 683
Fg.no. 8E..4..000 001→	06.03-12.04	0 265 006 809
Wheel speed sensor, rear		
Fg.no. →8E..4..050 000	03.03-05.04	ALR,LAB 0 265 006 707
Fg.no. →8E..4..400 000	03.03-05.04	ALR,RAB 0 265 006 681 OLW 0 265 006 681
Fg.no. 8E..5..000 001→	06.04-12.04	ALR,LAB 0 265 006 826 ALR,RAB 0 265 006 824 OLW 0 265 006 824



S4 Cabriolet

4.2 quattro [8HE; B7]		4,2 l 253 kW BBK 8 Zyl.
Throttle valve assembly	01.06→	0 280 750 003
Air mass meter, gasoline injection	01.06→	0 280 218 067 0 986 280 219
Speed sensor, ignition/injection	01.06→	0 261 210 190
Duo sensor, acceleration and yaw rate, brake system	01.06→	0 265 005 621
Pressure sensor, ESP, (electronic stability program)	01.06→	0 265 005 303
Wheel speed sensor, front	01.06→	0 265 006 809
Wheel speed sensor, rear	01.06→	RAB 0 265 006 824
4.2 quattro [8H7; B7]		4,2 l 253 kW BBK; BHF 8 Zyl.
Throttle valve assembly	02.04-06.06	0 280 750 003
Air mass meter, gasoline injection	02.04-06.06	0 280 218 067 0 986 280 219
Speed sensor, ignition/injection	02.04-06.06	0 261 210 190
Duo sensor, acceleration and yaw rate, brake system	02.04-06.06	0 265 005 252
Pressure sensor, ESP, (electronic stability program)	02.04-06.06	0 265 005 303
Wheel speed sensor, front	02.04-06.06	0 265 006 809
Wheel speed sensor, rear		
Fg.no. →8H..4..050 000, →8H..4..902 000,	02.04-05.04	LAB 0 265 006 707
PR no. 8Q3		
Fg.no. 8H..5..000 001→, 8H..5..900 001→,	06.04-06.06	LAB 0 265 006 826
PR no. 8Q3		
PR no. 8Q0, PR no. 8Q1	02.04-06.06	0 265 006 681
PR no. 8Q3	02.04-06.06	RAB 0 265 006 681

S5 Coupé

4.2 quattro [8T3]		4,2 l 260 kW CAUA 8 Zyl.
Throttle valve assembly	06.07→	0 280 750 003
Air mass meter, gasoline injection	06.07→	0 280 218 214
Duo sensor, acceleration and yaw rate, brake system	06.07→	0 265 005 668
Wheel speed sensor	06.07→	LAB 0 265 007 930 RAB 0 265 007 928

S6

2.2 T quattro [4A2; C4]		2,2 l 169 kW AAN 5 Zyl.
Throttle valve sensor	06.94-07.97	0 280 120 431
Air mass meter, gasoline injection	06.94-07.97	0 280 213 007 0 986 280 137
Phase sensor	06.94-07.97	0 232 101 020
Knock sensor	06.94-07.97	KZB 0 261 231 036 KZG 0 261 231 038
4.2 Plus quattro [4A2; C4]		4,2 l 240 kW AHK 8 Zyl.
Throttle valve sensor	06.96-10.97	0 280 120 431
Air mass meter, gasoline injection	06.96-10.97	0 280 217 817
Phase sensor	06.96-10.97	NOC 0 232 101 024
Speed sensor, ignition/injection	06.96-10.97	0 261 210 111
Knock sensor	06.96-10.97	KZA 0 261 231 040 KZG 0 261 231 038
Temperature sensor, intake air, injection system	06.96-10.97	KZS 0 280 130 060
4.2 quattro [4A2; C4]		4,2 l 213 kW AEC 8 Zyl.
Air mass meter, gasoline injection	09.94-07.97	0 280 216 001
Knock sensor	09.94-07.97	KZA 0 261 231 040 KZG 0 261 231 038
4.2 quattro [4B4; C5]		4,2 l 250 kW ANK 8 Zyl.
Air mass meter, gasoline injection	06.01-05.04	0 280 218 069 0 986 280 220



A

Product

◀ S6

Phase sensor	06.01-05.04		0 232 101 024
Speed sensor, ignition/injection	06.01-05.04	AG	0 261 210 190
		GS	0 261 210 192
Knock sensor	06.01-05.04		0 261 231 038
Duo sensor, acceleration and yaw rate, brake system	06.01-05.04		0 265 005 252
Wheel speed sensor, front			
Fg.no. 4B..3..000 001→	07.02-05.04		0 265 006 765
Wheel speed sensor, rear			
Fg.no. →4B..2..079 500	06.01-12.01	RAB	0 265 006 565
Fg.no. 4B..2..079 501→	01.02-05.04	LAB	0 265 006 771
		RAB	0 265 006 767
4.2 quattro [4B4; C5]		4,2l 250 kW AQJ 8 Zyl.	
Phase sensor	09.99-05.01		0 232 101 024
Speed sensor, ignition/injection	09.99-05.01	AG	0 261 210 190
		GS	0 261 210 192
Knock sensor	09.99-05.01		0 261 231 038
Duo sensor, acceleration and yaw rate, brake system	09.99-05.01		0 265 005 214
Wheel speed sensor, front	09.99-05.01		0 265 006 578
Wheel speed sensor, rear	09.99-05.01	RAB	0 265 006 565
5.2 FSI quattro [4F2; C6]		5,2l 320 kW BXA 10 Zyl.	
Throttle valve assembly	06.06→		0 280 750 003
Air mass meter, gasoline injection	06.06→		0 280 218 143
Duo sensor, acceleration and yaw rate, brake system	06.06→		0 265 005 692
Wheel speed sensor	06.06→	LAB	0 265 007 930
		RAB	0 265 007 928

A



S6 Avant

2.2 T quattro [4A5; C4]		2,2l 169 kW AAN 5 Zyl.	
Throttle valve sensor	06.94-07.97	0 280 120 431	
Air mass meter, gasoline injection	06.94-07.97	0 280 213 007	
		0 986 280 137	
Phase sensor	06.94-07.97	0 232 101 020	
Knock sensor	06.94-07.97	KZB	0 261 231 036
		KZG	0 261 231 038
4.2 Plus quattro [4A5; C4]		4,2l 240 kW AHK 8 Zyl.	
Throttle valve sensor	06.96-10.97	0 280 120 431	
Air mass meter, gasoline injection	06.96-10.97	0 280 217 817	
Phase sensor	06.96-10.97	NOC	0 232 101 024
Speed sensor, ignition/injection	06.96-10.97	0 261 210 111	
Knock sensor	06.96-10.97	KZA	0 261 231 040
		KZG	0 261 231 038
Temperature sensor, intake air, injection system	06.96-10.97	KZS	0 280 130 060
4.2 quattro [4A5; C4]		4,2l 213 kW AEC 8 Zyl.	
Air mass meter, gasoline injection	09.94-07.97	0 280 216 001	
Knock sensor	09.94-07.97	KZA	0 261 231 040
		KZG	0 261 231 038
4.2 quattro [4B6; C5]		4,2l 250 kW ANK 8 Zyl.	
Air mass meter, gasoline injection	06.01-01.05	0 280 218 069	
		0 986 280 220	
Phase sensor	06.01-01.05	0 232 101 024	
Speed sensor, ignition/injection	06.01-01.05	AG	0 261 210 190
		GS	0 261 210 192
Knock sensor	06.01-01.05	0 261 231 038	
Duo sensor, acceleration and yaw rate, brake system	06.01-01.05	0 265 005 252	
Wheel speed sensor, front			
Fg.no. 4B..3..000 001→	07.02-01.05	0 265 006 765	

Product				
Wheel speed sensor, rear				
Fg.no. →4B..2..079 500	06.01-12.01	RAB	0 265 006 565	
Fg.no. 4B..2..079 501→	01.02-01.05	LAB	0 265 006 771	
		RAB	0 265 006 767	
4.2 quattro [4B6; C5]		4,2l	250 kW	AQJ 8 Zyl.
Phase sensor	09.99-05.01		0 232 101 024	
Speed sensor, ignition/injection	09.99-05.01	AG	0 261 210 190	
		GS	0 261 210 192	
Knock sensor	09.99-05.01		0 261 231 038	
Duo sensor, acceleration and yaw rate, brake system	09.99-05.01		0 265 005 214	
Wheel speed sensor, front	09.99-05.01		0 265 006 578	
Wheel speed sensor, rear	09.99-05.01	RAB	0 265 006 565	
4.2 quattro [4B6; C5]		4,2l	250 kW	BBD 8 Zyl.
Throttle valve assembly	06.01-07.04		0 280 750 003	
Air mass meter, gasoline injection	06.01-07.04		0 280 218 067	
			0 986 280 219	
Phase sensor	06.01-07.04		0 232 101 024	
Speed sensor, ignition/injection	06.01-07.04		0 261 210 190	
Knock sensor	06.01-07.04		0 261 231 038	
Duo sensor, acceleration and yaw rate, brake system	06.01-07.04		0 265 005 252	
Wheel speed sensor, front				
Fg.no. →4B..2..031 500	06.01-08.01		0 265 006 578	
Fg.no. 4B..3..000 001→	07.02-07.04		0 265 006 765	
Wheel speed sensor, rear				
Fg.no. 4B..2..079 501→4B..4..027 600	01.02-08.03	LAB	0 265 006 771	
Fg.no. 4B..4..900 477→	09.03-07.04	LAB	0 265 006 769	
5.2 FSI quattro [4F5; C6]		5,2l	320 kW	BXA 10 Zyl.
Throttle valve assembly	06.06→		0 280 750 003	
Air mass meter, gasoline injection	06.06→		0 280 218 143	
Duo sensor, acceleration and yaw rate, brake system	06.06→		0 265 005 601	
Wheel speed sensor	06.06→	LAB	0 265 007 930	
		RAB	0 265 007 928	
S8				
4.2 quattro [4D2]		4,2l	250 kW	AHC; AKH 8 Zyl.
Throttle valve sensor	09.96-12.98		0 280 120 431	
Air mass meter, gasoline injection	09.96-12.98		0 280 217 817	
Phase sensor	09.96-12.98		0 232 101 024	
Speed sensor, ignition/injection	09.96-12.98	AG	0 261 210 143	
		GS	0 261 210 111	
Knock sensor	09.96-12.98	LAB	0 261 231 040	
		RAB	0 261 231 038	
Temperature sensor, intake air, injection system	09.96-12.98	KZS	0 280 130 060	
Pedal position sensor, EMS (electronic engine management)	09.96-12.98		0 280 752 022	
Lateral acceleration sensor, brake system	09.96-12.98		0 265 005 127	
Yaw rate sensor, brake system	09.96-12.98		0 265 005 207	
Wheel speed sensor, front				
Fg.no. 4D..X..005 001→	10.98-12.98	16R,FKR	0 265 006 580	
		20R,FKR	0 265 006 662	
Wheel speed sensor, rear	09.96-12.98	FKR	0 265 006 588	
4.2 quattro [4D2]		4,2l	265 kW	AQH 8 Zyl.
Phase sensor	05.99-02.01		0 232 101 024	
Speed sensor, ignition/injection	05.99-02.01	AG	0 261 210 190	
		GS	0 261 210 192	
Knock sensor	05.99-02.01	KZG	0 261 231 038	
Pedal position sensor, EMS (electronic engine management)	05.99-02.01		0 280 752 022	
Lateral acceleration sensor, brake system	05.99-02.01		0 265 005 127	



Yaw rate sensor, brake system	05.99-02.01		0 265 005 207
Pressure sensor, ESP, (electronic stability program)	05.99-02.01		0 265 005 303
Wheel speed sensor, front	05.99-02.01	16R,FKR	0 265 006 580
		20R,FKR	0 265 006 662
Wheel speed sensor, rear	05.99-02.01	FKR	0 265 006 588
4.2 quattro [4D2]		4,2l 265 kW AVP 8 Zyl.	
Air mass meter, gasoline injection	09.00-09.02		0 280 218 067
			0 986 280 219
Phase sensor	09.00-09.02		0 232 101 024
Speed sensor, ignition/injection	09.00-09.02	AG	0 261 210 190
		GS	0 261 210 192
Knock sensor	09.00-09.02	KZG	0 261 231 038
Pedal position sensor, EMS (electronic engine management)	09.00-09.02		0 280 752 022
Lateral acceleration sensor, brake system	09.00-09.02		0 265 005 127
Yaw rate sensor, brake system	09.00-09.02		0 265 005 207
Pressure sensor, ESP, (electronic stability program)	09.00-09.02		0 265 005 303
Wheel speed sensor, front	09.00-09.02	16R,FKR	0 265 006 580
		20R,FKR	0 265 006 662
Wheel speed sensor, rear	09.00-09.02	FKR	0 265 006 588
4.2 quattro [4D2]		4,2l 265 kW AYS;BCS 8 Zyl.	
Air mass meter, gasoline injection	09.00-09.02		0 280 218 067
			0 986 280 219
Phase sensor	09.00-09.02		0 232 101 024
Speed sensor, ignition/injection	09.00-09.02	AG	0 261 210 190
		GS	0 261 210 192
Knock sensor	09.00-09.02	KZG	0 261 231 038
Lateral acceleration sensor, brake system	09.00-09.02		0 265 005 127
Yaw rate sensor, brake system	09.00-09.02		0 265 005 207
Pressure sensor, ESP, (electronic stability program)	09.00-09.02		0 265 005 303
Wheel speed sensor, front	09.00-09.02	16R,FKR	0 265 006 580
		20R,FKR	0 265 006 662
Wheel speed sensor, rear	09.00-09.02	FKR	0 265 006 588
5.2 FSI quattro [4E2]		5,2l 331 kW BSM 10 Zyl.	
Throttle valve assembly	06.06→		0 280 750 003
Air mass meter, gasoline injection	06.06→		0 280 218 143
Duo sensor, acceleration and yaw rate, brake system	06.06→		0 265 005 252
Pressure sensor, ESP, (electronic stability program)	06.06→		0 265 005 303
Wheel speed sensor	06.06→	LAB,OSS	0 265 007 930
		OSS,RAB	0 265 007 928

TT Coupé

1.8 T [8N3]		1,8l 110 kW AUM 4 Zyl.	
Throttle valve assembly	01.01-06.06		0 280 750 036
Air mass meter, gasoline injection	01.01-06.06		0 280 218 063
			0 986 280 217
Phase sensor	01.01-06.06		0 232 101 024
Speed sensor, ignition/injection	01.01-06.06		0 261 210 199
Knock sensor	01.01-06.06		0 261 231 146
Boost pressure sensor, gasoline			
Fg.no. →8N..3..050 000	01.01-05.03		0 281 002 177
Fg.no. 8N..4..000 001→	06.03-06.06		0 261 230 073
Temperature sensor, intake air, injection system	01.01-06.06		0 280 130 085
Accelerator pedal module	01.01-06.06	GS,LLE	0 280 752 214
	01.01-08.02	RLE	0 280 752 210
1.8 T [8N3]		1,8l 120 kW BVP 4 Zyl.	
Throttle valve assembly	09.05-06.06		0 280 750 036
Air mass meter, gasoline injection	09.05-06.06		0 280 218 063
			0 986 280 217
Phase sensor	09.05-06.06		0 232 101 024
Speed sensor, ignition/injection	09.05-06.06		0 261 210 199



Knock sensor	09.05-06.06		0 261 231 146
Boost pressure sensor, gasoline	09.05-06.06		0 261 230 073
Temperature sensor, intake air, injection system	09.05-06.06		0 280 130 085
Accelerator pedal module	09.05-06.06	GS,LLE	0 280 752 214
1.8 T [8N3]		1,8l 132 kW AJQ 4 Zyl.	
Throttle valve assembly	07.98-08.00		0 280 750 036
Air mass meter, gasoline injection			
Fg.no. →8N..Y..050 000	07.98-11.99		0 280 218 023
			0 986 280 209
Fg.no. 8N..Y..050 001→	12.99-08.00		0 280 218 032
			0 986 280 210
Phase sensor	07.98-08.00		0 232 101 024
Speed sensor, ignition/injection	07.98-08.00		0 261 210 147
Pressure sensor, intake manifold, gasoline	07.98-08.00		0 280 101 001
Boost pressure sensor, gasoline	07.98-08.00		0 281 002 177
Temperature sensor, intake air, injection system	07.98-08.00		0 280 130 085
Accelerator pedal module	07.98-08.00	LLE	0 280 752 214
Fg.no. 8N..Y..080 001→	04.00-08.00	RLE	0 280 752 210
Pedal position sensor, EMS (electronic engine management)			
Fg.no. →8N..Y..080 000	07.98-03.00	RLE	0 280 752 016
1.8 T [8N3]		1,8l 132 kW APP 4 Zyl.	
Throttle valve assembly	11.99-09.00		0 280 750 036
Air mass meter, gasoline injection	11.99-09.00		0 280 218 032
			0 986 280 210
Phase sensor	11.99-09.00		0 232 101 024
Speed sensor, ignition/injection	11.99-09.00		0 261 210 147
Pressure sensor, intake manifold, gasoline	11.99-09.00		0 280 101 001
Boost pressure sensor, gasoline	11.99-09.00		0 281 002 177
Temperature sensor, intake air, injection system	11.99-09.00		0 280 130 085
Accelerator pedal module	11.99-09.00	LLE	0 280 752 214
Fg.no. 8N..Y..080 001→	04.00-09.00	RLE	0 280 752 210
Pedal position sensor, EMS (electronic engine management)			
Fg.no. →8N..Y..080 000	11.99-03.00	RLE	0 280 752 016
1.8 T [8N3]		1,8l 132 kW ATC 4 Zyl.	
Throttle valve assembly	03.99-08.00		0 280 750 036
Air mass meter, gasoline injection	03.99-08.00		0 280 218 032
			0 986 280 210
Phase sensor	03.99-08.00		0 232 101 024
Temperature sensor, intake air, injection system	03.99-08.00		0 280 130 085
Accelerator pedal module	03.99-08.00	GS	0 280 752 214
1.8 T [8N3]		1,8l 132 kW AUQ 4 Zyl.	
Throttle valve assembly	09.00-06.06		0 280 750 036
Air mass meter, gasoline injection	09.00-06.06		0 280 218 063
			0 986 280 217
Phase sensor	09.00-06.06		0 232 101 024
Speed sensor, ignition/injection	09.00-06.06		0 261 210 199
Knock sensor	09.00-06.06		0 261 231 146
Boost pressure sensor, gasoline			
Fg.no. →8N..3..050 000	09.00-05.03		0 281 002 177
Fg.no. 8N..4..000 001→	06.03-06.06		0 261 230 073
Temperature sensor, intake air, injection system	09.00-06.06		0 280 130 085
Accelerator pedal module	09.00-06.06	GS,LLE	0 280 752 214
	09.00-08.02	RLE	0 280 752 210
1.8 T [8N3]		1,8l 132 kW AWP 4 Zyl.	
Throttle valve assembly	09.02-06.06		0 280 750 036
Air mass meter, gasoline injection	09.00-06.06		0 280 218 063
			0 986 280 217
Phase sensor	09.00-06.06		0 232 101 024
Speed sensor, ignition/injection	09.00-06.06		0 261 210 199
Knock sensor	09.00-06.06		0 261 231 146



Product				
◀ TT Coupé				
Boost pressure sensor, gasoline				
Fg.no. →8N..3..050 000	09.00-05.03			0 281 002 177
Fg.no. 8N..4..000 001→	06.03-06.06			0 261 230 073
Temperature sensor, intake air, injection system	09.00-06.06			0 280 130 085
Accelerator pedal module	09.00-06.06	GS		0 280 752 214
1.8 T [8N3]			1,8 l 140 kW BVR 4 Zyl.	
Throttle valve assembly	09.05-06.06			0 280 750 036
Air mass meter, gasoline injection	09.05-06.06			0 280 218 063
				0 986 280 217
Phase sensor	09.05-06.06			0 232 101 024
Speed sensor, ignition/injection	09.05-06.06			0 261 210 199
Knock sensor	09.05-06.06			0 261 231 146
Boost pressure sensor, gasoline	09.05-06.06			0 261 230 073
Temperature sensor, intake air, injection system	09.05-06.06			0 280 130 085
Accelerator pedal module	09.05-06.06	GS,LLE		0 280 752 214
1.8 T quattro [8N3]			1,8 l 132 kW AJQ 4 Zyl.	
Throttle valve assembly	07.98-08.00			0 280 750 036
Air mass meter, gasoline injection				
Fg.no. →8N..Y..050 000	07.98-11.99			0 280 218 023
				0 986 280 209
Fg.no. 8N..Y..050 001→	12.99-08.00			0 280 218 032
				0 986 280 210
Phase sensor	07.98-08.00			0 232 101 024
Speed sensor, ignition/injection	07.98-08.00			0 261 210 147
Pressure sensor, intake manifold, gasoline	07.98-08.00			0 280 101 001
Boost pressure sensor, gasoline	07.98-08.00			0 281 002 177
Temperature sensor, intake air, injection system	07.98-08.00			0 280 130 085
Accelerator pedal module	07.98-08.00	LLE		0 280 752 214
Fg.no. 8N..Y..080 001→	04.00-08.00	RLE		0 280 752 210
Pedal position sensor, EMS (electronic engine management)				
Fg.no. →8N..Y..080 000	07.98-03.00	RLE		0 280 752 016
1.8 T quattro [8N3]			1,8 l 132 kW ARY 4 Zyl.	
Throttle valve assembly	09.00-05.05			0 280 750 036
Air mass meter, gasoline injection	09.00-05.05			0 280 218 063
				0 986 280 217
Phase sensor	09.00-05.05			0 232 101 024
Speed sensor, ignition/injection	09.00-05.05			0 261 210 199
Knock sensor	09.00-05.05			0 261 231 146
Boost pressure sensor, gasoline				
Fg.no. →8N..3..050 000	09.00-05.03			0 281 002 177
Fg.no. 8N..4..000 001→	06.03-05.05			0 261 230 073
Temperature sensor, intake air, injection system	09.00-05.05			0 280 130 085
Accelerator pedal module	09.00-05.05	GS,LLE		0 280 752 214
	09.00-08.02	RLE		0 280 752 210
1.8 T quattro [8N3]			1,8 l 132 kW ATC 4 Zyl.	
Throttle valve assembly	11.99-08.00			0 280 750 036
Air mass meter, gasoline injection	11.99-08.00			0 280 218 032
				0 986 280 210
Phase sensor	11.99-08.00			0 232 101 024
Temperature sensor, intake air, injection system	11.99-08.00			0 280 130 085
Accelerator pedal module	11.99-08.00	GS		0 280 752 214
1.8 T quattro [8N3]			1,8 l 132 kW AUQ 4 Zyl.	
Throttle valve assembly	06.05-06.06			0 280 750 036
Air mass meter, gasoline injection	06.05-06.06			0 280 218 063
				0 986 280 217
Phase sensor	06.05-06.06			0 232 101 024
Speed sensor, ignition/injection	06.05-06.06			0 261 210 199
Knock sensor	06.05-06.06			0 261 231 146
Boost pressure sensor, gasoline	06.05-06.06			0 261 230 073
Temperature sensor, intake air, injection system	06.05-06.06			0 280 130 085
Accelerator pedal module	06.05-06.06	GS,LLE		0 280 752 214

Product				
1.8 T quattro [8N3]				
1,8 l 132 kW AWP 4 Zyl.				
Air mass meter, gasoline injection	09.00-08.02			0 280 218 063
				0 986 280 217
Phase sensor	09.00-08.02			0 232 101 024
Speed sensor, ignition/injection	09.00-08.02			0 261 210 199
Knock sensor	09.00-08.02			0 261 231 146
Boost pressure sensor, gasoline	09.00-08.02			0 281 002 177
Temperature sensor, intake air, injection system	09.00-08.02			0 280 130 085
Accelerator pedal module	09.00-08.02	GS		0 280 752 214
1.8 T quattro [8N3]			1,8 l 140 kW BVR 4 Zyl.	
Throttle valve assembly	09.05-06.06			0 280 750 036
Air mass meter, gasoline injection	09.05-06.06			0 280 218 063
				0 986 280 217
Phase sensor	09.05-06.06			0 232 101 024
Speed sensor, ignition/injection	09.05-06.06			0 261 210 199
Knock sensor	09.05-06.06			0 261 231 146
Boost pressure sensor, gasoline	09.05-06.06			0 261 230 073
Temperature sensor, intake air, injection system	09.05-06.06			0 280 130 085
Accelerator pedal module	09.05-06.06	GS,LLE		0 280 752 214
1.8 T quattro [8N3]			1,8 l 165 kW AMU 4 Zyl.	
Throttle valve assembly	03.00-08.02			0 280 750 036
Air mass meter, gasoline injection	03.00-08.02			0 280 218 034
				0 986 280 211
Phase sensor	03.00-08.02			0 232 101 024
Temperature sensor, intake air, injection system	03.00-08.02			0 280 130 085
Accelerator pedal module	03.00-08.02	GS		0 280 752 214
1.8 T quattro [8N3]			1,8 l 165 kW APX 4 Zyl.	
Throttle valve assembly	07.98-08.01			0 280 750 036
Air mass meter, gasoline injection	07.98-08.01			0 280 218 034
				0 986 280 211
Phase sensor	07.98-08.01			0 232 101 024
Speed sensor, ignition/injection	07.98-08.01			0 261 210 147
Boost pressure sensor, gasoline				
Fg.no. →8N..1..031 000	07.98-01.01			0 281 002 177
Fg.no. 8N..1..031 001→	02.01-08.01			0 261 230 073
Temperature sensor, intake air, injection system	07.98-08.01			0 280 130 085
Accelerator pedal module	07.98-08.01	LLE		0 280 752 214
Fg.no. 8N..Y..080 001→	04.00-08.01	RLE		0 280 752 210
Pedal position sensor, EMS (electronic engine management)				
Fg.no. →8N..Y..080 000	07.98-03.00	RLE		0 280 752 016
1.8 T quattro [8N3]			1,8 l 165 kW BAM 4 Zyl.	
Throttle valve assembly	09.00-06.06			0 280 750 036
Air mass meter, gasoline injection	09.00-06.06			0 280 218 065
				0 986 280 218
Phase sensor	09.00-06.06			0 232 101 024
Speed sensor, ignition/injection	09.02-06.06			0 261 210 178
	09.00-08.02			0 261 210 199
Knock sensor	09.00-06.06			0 261 231 146
Boost pressure sensor, gasoline				
Fg.no. →8N..1..031 000	09.00-01.01			0 281 002 177
Fg.no. 8N..1..031 001→	02.01-06.06			0 261 230 073
Temperature sensor, intake air, injection system	09.00-06.06			0 280 130 085
Accelerator pedal module	09.00-06.06	GS,LLE		0 280 752 214
	09.00-08.02	RLE		0 280 752 210
2.0 TFSI [8J3]			2,0 l 147 kW BWA 4 Zyl.	
Speed sensor, ignition/injection	07.06→			0 261 210 199
Boost pressure sensor, gasoline	07.06→			0 261 230 073
3.2 quattro [8J3]			3,2 l 184 kW BUB 6 Zyl.	
Air mass meter, gasoline injection	07.06→			0 280 218 073
				0 986 280 222
Phase sensor	07.06→			0 232 103 019
Knock sensor	07.06→	OHL		0 261 231 146





3.2 quattro [8N3]		3,2l 184 kW BHE 6 Zyl.
Air mass meter, gasoline injection	07.03-06.06	0 280 218 073 🔍 0 986 280 222
Phase sensor	07.03-06.06	0 232 103 019
Knock sensor	07.03-06.06 OHL	0 261 231 146
Accelerator pedal module	07.03-06.06 GS,LLE	0 280 752 214

TT Roadster

1.8 T [8N9]		1,8l 110 kW AUM 4 Zyl.
Throttle valve assembly	01.01-06.06	0 280 750 036
Air mass meter, gasoline injection	01.01-06.06	0 280 218 063 🔍 0 986 280 217
Phase sensor	01.01-06.06	0 232 101 024
Speed sensor, ignition/injection	01.01-06.06	0 261 210 199
Knock sensor	01.01-06.06	0 261 231 146
Boost pressure sensor, gasoline	01.01-06.06	0 281 002 177
Fg.no. →8N..3..050 000	01.01-05.03	0 281 002 177
Fg.no. 8N..4..000 001→	06.03-06.06	0 261 230 073
Temperature sensor, intake air, injection system	01.01-06.06	0 280 130 085
Accelerator pedal module	01.01-06.06 GS,LLE	0 280 752 214
	01.01-08.02 RLE	0 280 752 210

1.8 T [8N9]		1,8l 120 kW BVP 4 Zyl.
Throttle valve assembly	09.05-06.06	0 280 750 036
Air mass meter, gasoline injection	09.05-06.06	0 280 218 063 🔍 0 986 280 217
Phase sensor	09.05-06.06	0 232 101 024
Speed sensor, ignition/injection	09.05-06.06	0 261 210 199
Knock sensor	09.05-06.06	0 261 231 146
Boost pressure sensor, gasoline	09.05-06.06	0 261 230 073
Temperature sensor, intake air, injection system	09.05-06.06	0 280 130 085
Accelerator pedal module	09.05-06.06 GS,LLE	0 280 752 214

1.8 T [8N9]		1,8l 132 kW AJQ 4 Zyl.
Throttle valve assembly	04.99-08.00	0 280 750 036
Air mass meter, gasoline injection		
Fg.no. →8N..Y..050 000	04.99-11.99	0 280 218 023 🔍 0 986 280 209
Fg.no. 8N..Y..050 001→	12.99-08.00	0 280 218 032 🔍 0 986 280 210
Phase sensor	04.99-08.00	0 232 101 024
Speed sensor, ignition/injection	04.99-08.00	0 261 210 147
Pressure sensor, intake manifold, gasoline	04.99-08.00	0 280 101 001
Boost pressure sensor, gasoline	04.99-08.00	0 281 002 177
Temperature sensor, intake air, injection system	04.99-08.00	0 280 130 085
Accelerator pedal module	04.99-08.00 LLE	0 280 752 214
Fg.no. 8N..Y..080 001→	04.00-08.00 RLE	0 280 752 210

Pedal position sensor, EMS (electronic engine management)		
Fg.no. →8N..Y..080 000	04.99-03.00 RLE	0 280 752 016

1.8 T [8N9]		1,8l 132 kW APP 4 Zyl.
Throttle valve assembly	09.99-10.01	0 280 750 036
Air mass meter, gasoline injection	09.99-10.01	0 280 218 032 🔍 0 986 280 210
Phase sensor	09.99-10.01	0 232 101 024
Speed sensor, ignition/injection	09.99-10.01	0 261 210 147
Pressure sensor, intake manifold, gasoline	09.99-10.01	0 280 101 001
Boost pressure sensor, gasoline	09.99-10.01	0 281 002 177
Temperature sensor, intake air, injection system	09.99-10.01	0 280 130 085
Accelerator pedal module	09.99-10.01 LLE	0 280 752 214
Fg.no. 8N..Y..080 001→	04.00-10.01 RLE	0 280 752 210

Pedal position sensor, EMS (electronic engine management)		
Fg.no. →8N..Y..080 000	09.99-03.00 RLE	0 280 752 016



1.8 T [8N9]		1,8l 132 kW ATC 4 Zyl.
Throttle valve assembly	11.99-08.00	0 280 750 036
Air mass meter, gasoline injection	11.99-08.00	0 280 218 032 🔍 0 986 280 210
Phase sensor	11.99-08.00	0 232 101 024
Temperature sensor, intake air, injection system	11.99-08.00	0 280 130 085
Accelerator pedal module	11.99-08.00 GS	0 280 752 214

1.8 T [8N9]		1,8l 132 kW AUQ 4 Zyl.
Throttle valve assembly	08.00-06.06	0 280 750 036
Air mass meter, gasoline injection	08.00-06.06	0 280 218 063 🔍 0 986 280 217
Phase sensor	08.00-06.06	0 232 101 024
Speed sensor, ignition/injection	08.00-06.06	0 261 210 199
Knock sensor	08.00-06.06	0 261 231 146
Boost pressure sensor, gasoline	08.00-06.06	0 281 002 177
Fg.no. →8N..3..050 000	08.00-05.03	0 281 002 177
Fg.no. 8N..4..000 001→	06.03-06.06	0 261 230 073
Temperature sensor, intake air, injection system	08.00-06.06	0 280 130 085
Accelerator pedal module	08.00-06.06 GS,LLE	0 280 752 214
	08.00-08.02 RLE	0 280 752 210

1.8 T [8N9]		1,8l 132 kW AWP 4 Zyl.
Air mass meter, gasoline injection	09.00-08.02	0 280 218 063 🔍 0 986 280 217

Phase sensor	09.00-08.02	0 232 101 024
Speed sensor, ignition/injection	09.00-08.02	0 261 210 199
Knock sensor	09.00-08.02	0 261 231 146
Boost pressure sensor, gasoline	09.00-08.02	0 281 002 177
Temperature sensor, intake air, injection system	09.00-08.02	0 280 130 085
Accelerator pedal module	09.00-08.02 GS	0 280 752 214

1.8 T [8N9]		1,8l 140 kW BVR 4 Zyl.
Throttle valve assembly	09.05-06.06	0 280 750 036
Air mass meter, gasoline injection	09.05-06.06	0 280 218 063 🔍 0 986 280 217
Phase sensor	09.05-06.06	0 232 101 024
Speed sensor, ignition/injection	09.05-06.06	0 261 210 199
Knock sensor	09.05-06.06	0 261 231 146
Boost pressure sensor, gasoline	09.05-06.06	0 261 230 073
Temperature sensor, intake air, injection system	09.05-06.06	0 280 130 085
Accelerator pedal module	09.05-06.06 GS,LLE	0 280 752 214

1.8 T quattro [8N9]		1,8l 132 kW AJQ 4 Zyl.
Throttle valve assembly	07.99-08.00	0 280 750 036
Air mass meter, gasoline injection		
Fg.no. →8N..Y..050 000	07.99-11.99	0 280 218 023 🔍 0 986 280 209
Fg.no. 8N..Y..050 001→	12.99-08.00	0 280 218 032 🔍 0 986 280 210

Phase sensor	07.99-08.00	0 232 101 024
Speed sensor, ignition/injection	07.99-08.00	0 261 210 147
Pressure sensor, intake manifold, gasoline	07.99-08.00	0 280 101 001
Boost pressure sensor, gasoline	07.99-08.00	0 281 002 177
Temperature sensor, intake air, injection system	07.99-08.00	0 280 130 085
Accelerator pedal module	07.99-08.00 LLE	0 280 752 214
Fg.no. 8N..Y..080 001→	04.00-08.00 RLE	0 280 752 210

Pedal position sensor, EMS (electronic engine management)		
Fg.no. →8N..Y..080 000	07.99-03.00 RLE	0 280 752 016

1.8 T quattro [8N9]		1,8l 132 kW ARY 4 Zyl.
Throttle valve assembly	09.00-05.05	0 280 750 036
Air mass meter, gasoline injection	09.00-05.05	0 280 218 063 🔍 0 986 280 217
Phase sensor	09.00-05.05	0 232 101 024
Speed sensor, ignition/injection	09.00-05.05	0 261 210 199
Knock sensor	09.00-05.05	0 261 231 146



Product				
◀ TT Roadster				
Boost pressure sensor, gasoline	09.00-05.05			0 281 002 177
Fg.no. →8N..3..050 000	09.00-05.03			0 281 002 177
Fg.no. 8N..4..000 001→	06.03-05.05			0 261 230 073
Temperature sensor, intake air, injection system	09.00-05.05			0 280 130 085
Accelerator pedal module	09.00-05.05	GS,LLE		0 280 752 214
	09.00-08.02	RLE		0 280 752 210
1.8 T quattro [8N9]			1,8 l	132 kW ATC 4 Zyl.
Throttle valve assembly	11.99-08.00			0 280 750 036
Air mass meter, gasoline injection	11.99-08.00			0 280 218 032
				0 986 280 210
Phase sensor	11.99-08.00			0 232 101 024
Temperature sensor, intake air, injection system	11.99-08.00			0 280 130 085
Accelerator pedal module	11.99-08.00	GS		0 280 752 214
1.8 T quattro [8N9]			1,8 l	132 kW AUQ 4 Zyl.
Throttle valve assembly	06.05-06.06			0 280 750 036
Air mass meter, gasoline injection	06.05-06.06			0 280 218 063
				0 986 280 217
Phase sensor	06.05-06.06			0 232 101 024
Speed sensor, ignition/injection	06.05-06.06			0 261 210 199
Knock sensor	06.05-06.06			0 261 231 146
Boost pressure sensor, gasoline	06.05-06.06			0 261 230 073
Temperature sensor, intake air, injection system	06.05-06.06			0 280 130 085
Accelerator pedal module	06.05-06.06	GS,LLE		0 280 752 214
				0 280 752 214
1.8 T quattro [8N9]			1,8 l	132 kW AWP 4 Zyl.
Air mass meter, gasoline injection	09.00-08.02			0 280 218 063
				0 986 280 217
Phase sensor	09.00-08.02			0 232 101 024
Speed sensor, ignition/injection	09.00-08.02			0 261 210 199
Knock sensor	09.00-08.02			0 261 231 146
Boost pressure sensor, gasoline	09.00-08.02			0 281 002 177
Temperature sensor, intake air, injection system	09.00-08.02			0 280 130 085
Accelerator pedal module	09.00-08.02	GS		0 280 752 214
				0 280 752 214
1.8 T quattro [8N9]			1,8 l	140 kW BVR 4 Zyl.
Throttle valve assembly	09.05-06.06			0 280 750 036
Air mass meter, gasoline injection	09.05-06.06			0 280 218 063
				0 986 280 217
Phase sensor	09.05-06.06			0 232 101 024
Speed sensor, ignition/injection	09.05-06.06			0 261 210 199
Knock sensor	09.05-06.06			0 261 231 146
Temperature sensor, intake air, injection system	09.05-06.06			0 280 130 085
Accelerator pedal module	09.05-06.06	GS,LLE		0 280 752 214
				0 280 752 214
1.8 T quattro [8N9]			1,8 l	165 kW AMU 4 Zyl.
Throttle valve assembly	03.00-08.02			0 280 750 036
Air mass meter, gasoline injection	03.00-08.02			0 280 218 034
				0 986 280 211
Phase sensor	03.00-08.02			0 232 101 024
Temperature sensor, intake air, injection system	03.00-08.02			0 280 130 085
Accelerator pedal module	03.00-08.02	GS		0 280 752 214
				0 280 752 214
1.8 T quattro [8N9]			1,8 l	165 kW APX 4 Zyl.
Throttle valve assembly	03.99-08.01			0 280 750 036
Air mass meter, gasoline injection	03.99-08.01			0 280 218 034
				0 986 280 211
Phase sensor	03.99-08.01			0 232 101 024
Speed sensor, ignition/injection	03.99-08.01			0 261 210 147
Boost pressure sensor, gasoline				
Fg.no. →8N..1..031 000	03.99-01.01			0 281 002 177
Fg.no. 8N..1..031 001→	02.01-08.01			0 261 230 073
Temperature sensor, intake air, injection system	03.99-08.01			0 280 130 085
Accelerator pedal module	03.99-08.01	LLE		0 280 752 214
	Fg.no. 8N..Y..080 001→	RLE		0 280 752 210
Pedal position sensor, EMS (electronic engine management)				
Fg.no. →8N..Y..080 000	03.99-03.00	RLE		0 280 752 016

Product				
1.8 T quattro [8N9]				
			1,8 l	165 kW BAM 4 Zyl.
Throttle valve assembly	09.00-06.06			0 280 750 036
Air mass meter, gasoline injection	09.00-06.06			0 280 218 065
				0 986 280 218
Phase sensor	09.00-06.06			0 232 101 024
Speed sensor, ignition/injection	09.02-06.06			0 261 210 178
	09.00-08.02			0 261 210 199
Knock sensor	09.00-06.06			0 261 231 146
Boost pressure sensor, gasoline				
Fg.no. →8N..1..031 000	09.00-01.01			0 281 002 177
Fg.no. 8N..1..031 001→	02.01-06.06			0 261 230 073
Temperature sensor, intake air, injection system	09.00-06.06			0 280 130 085
Accelerator pedal module	09.00-06.06	GS,LLE		0 280 752 214
	09.00-08.02	RLE		0 280 752 210
2.0 TFSI [8J9]			2,0 l	147 kW BWA 4 Zyl.
Speed sensor, ignition/injection	02.07→			0 261 210 199
Boost pressure sensor, gasoline	02.07→			0 261 230 073
3.2 quattro [8J9]			3,2 l	184 kW BUB 6 Zyl.
Air mass meter, gasoline injection	02.07→			0 280 218 073
				0 986 280 222
Phase sensor	02.07→			0 232 103 019
Knock sensor	02.07→	OHL		0 261 231 146
3.2 quattro [8N9]			3,2 l	184 kW BHE 6 Zyl.
Air mass meter, gasoline injection	07.03-06.06			0 280 218 073
				0 986 280 222
Phase sensor	07.03-06.06			0 232 103 019
Knock sensor	07.03-06.06	OHL		0 261 231 146
Accelerator pedal module	07.03-06.06	GS,LLE		0 280 752 214
V8				
3.6 quattro [44; 4C; D11]				
			3,6 l	184 kW PT 8 Zyl.
Throttle valve sensor				
Fg.no. →4C..M..020 000	10.88-07.91			0 280 120 424
Fg.no. 4C..N..000 001→	07.91-11.93			0 280 120 428
Air mass meter, gasoline injection	10.88-11.93			0 280 216 001
Knock sensor	10.88-11.93	KZA		0 261 231 040
		KZG		0 261 231 038
Temperature sensor, coolant, injection system	10.88-11.93			0 280 130 037
4.2 quattro [44; 4C; D11]			4,2 l	206 kW ABH 8 Zyl.
Throttle valve sensor	10.91-11.93			0 280 120 428
Air mass meter, gasoline injection	10.91-11.93			0 280 216 001
Knock sensor	10.91-11.93	KZA		0 261 231 040
		KZG		0 261 231 038
Temperature sensor, coolant, injection system	10.91-11.93			0 280 130 037
80				
1.4 [89; 8A2; B3]				
			1,4 l	48 kW SE 4 Zyl.
Wheel speed sensor, rear				
Fg.no. →89..J..373 598	08.86-04.88			0 265 001 181
1.6 [8C2; B4]			1,6 l	74 kW ADA 4 Zyl.
Throttle valve sensor	06.93-05.95			0 280 120 431
Knock sensor	06.93-05.95			0 261 231 036
1.6 [8C2; B4]			1,6 l	75 kW ABB 4 Zyl.
Air flow sensor, gasoline injection	03.92-08.93			F 026 TX2 051
				F 026 TX2 051
Pressure sensor, intake manifold, gasoline	03.92-08.93			0 280 101 001
1.6 [81; 85; B2]			1,6 l	55 kW DT 4 Zyl.
Temperature sensor, coolant, injection system	08.83-03.87			0 280 130 040





1.6 [89; 8A2; B3]				1,6 l 51 kW PP 4 Zyl.
Temperature sensor, coolant, injection system	03.87-12.91	KZW		0 280 130 040
Wheel speed sensor, rear				
Fg.no. →89..J..373 598	03.87-04.88			0 265 001 181
1.6 [89; 8A2; B3]				1,6 l 55 kW RN 4 Zyl.
Wheel speed sensor, rear				
Fg.no. →89..J..373 598	09.86-04.88			0 265 001 181
1.6 [89; 8A2; B3]				1,6 l 75 kW ABB 4 Zyl.
Air flow sensor, gasoline injection	08.90-12.91	FOB		F 026 TX2 051
				☛ F 026 TX2 051
Temperature sensor, coolant, injection system	08.90-12.91	KAT		0 280 130 040
		KZW		0 280 130 040
1.6 D [89; 8A2; B3]				1,6 l 40 kW JK 4 Zyl.
Wheel speed sensor, rear				
Fg.no. →89..J..373 598	09.86-04.88			0 265 001 181
1.8 [81; 85; B2]				1,8 l 64/66 kW DS; SF 4 Zyl.
Temperature sensor, coolant, injection system	01.83-03.87			0 280 130 040
1.8 [81; 85; B2]				1,8 l 66 kW JN 4 Zyl.
Air flow sensor, gasoline injection	08.83-03.87			F 026 TX2 063
				☛ F 026 TX2 063
Temperature sensor, coolant, injection system	08.83-03.87			0 280 130 040
1.8 [81; 85; B2]				1,8 l 81 kW PV 4 Zyl.
Air flow sensor, gasoline injection	08.85-03.87			F 026 TX2 063
				☛ F 026 TX2 063
Knock sensor	08.85-03.87			0 261 231 038
1.8 [81; 85; B2]				1,8 l 82 kW DZ; MU 4 Zyl.
Air flow sensor, gasoline injection				
Fg.no. →81..G..140 000	01.83-02.86			0 438 120 189
Fg.no. 81..G..140 001→	02.86-03.87	FOB		F 026 TX2 051
				☛ F 026 TX2 051
1.8 [89; 8A2; B3]				1,8 l 55 kW RU 4 Zyl.
Wheel speed sensor, rear				
Fg.no. →89..J..373 598	10.86-04.88			0 265 001 181
1.8 E [89; 8A2; B3]				1,8 l 82 kW DZ 4 Zyl.
Air flow sensor, gasoline injection	09.86-12.91	FOB		F 026 TX2 051
				☛ F 026 TX2 051
Temperature sensor, coolant, injection system	09.86-12.91	KZW		0 280 130 040
Wheel speed sensor, rear				
Fg.no. →89..J..373 598	09.86-04.88			0 265 001 181
1.8 quattro [81; 85; B2]				1,8 l 66 kW JN 4 Zyl.
Air flow sensor, gasoline injection	08.85-08.86			F 026 TX2 063
				☛ F 026 TX2 063
Temperature sensor, coolant, injection system	08.85-08.86			0 280 130 040
1.8 quattro [81; 85; B2]				1,8 l 81 kW PV 4 Zyl.
Air flow sensor, gasoline injection	03.85-08.86			F 026 TX2 063
				☛ F 026 TX2 063
Knock sensor	03.85-08.86			0 261 231 038
Temperature sensor, coolant, injection system	03.85-08.86			0 280 130 040
1.8 quattro [81; 85; B2]				1,8 l 82 kW DZ; MU 4 Zyl.
Air flow sensor, gasoline injection	03.85-08.86	MZF		0 438 121 027
		NOR		0 438 120 189
1.8 quattro [89; 8A2; B3]				1,8 l 64 kW SF 4 Zyl.
Wheel speed sensor, rear				
Fg.no. →89..J..373 595	09.86-04.88			0 265 001 183
1.8 quattro [89; 8A2; B3]				1,8 l 66 kW JN 4 Zyl.
Air flow sensor, gasoline injection	09.86-07.90			F 026 TX2 063
				☛ F 026 TX2 063
Temperature sensor, coolant, injection system	09.86-07.90			0 280 130 040
Wheel speed sensor, rear				
Fg.no. →89..J..373 595	09.86-04.88			0 265 001 183
1.8 quattro [89; 8A2; B3]				1,8 l 82 kW DZ 4 Zyl.
Air flow sensor, gasoline injection	09.86-09.91	FOB		F 026 TX2 051
				☛ F 026 TX2 051



Wheel speed sensor, rear				
Fg.no. →89..J..373 595	09.86-04.88			0 265 001 183
1.8 S [89; 8A2; B3]				1,8 l 64 kW SF 4 Zyl.
Temperature sensor, coolant, injection system	09.86-01.90	KZW		0 280 130 040
Wheel speed sensor, rear				
Fg.no. →89..J..373 598	09.86-04.88			0 265 001 181
1.8 S [89; 8A2; B3]				1,8 l 66 kW JN 4 Zyl.
Air flow sensor, gasoline injection	09.86-12.91			F 026 TX2 063
				☛ F 026 TX2 063
Temperature sensor, coolant, injection system	09.86-12.91	KZW		0 280 130 040
Wheel speed sensor, rear				
Fg.no. →89..J..373 598	09.86-04.88			0 265 001 181
1.8 S [89; 8A2; B3]				1,8 l 66 kW JV; NE; PM 4 Zyl.
Temperature sensor, coolant, injection system	08.86-12.91	KZW		0 280 130 040
Wheel speed sensor, rear				
Fg.no. →89..J..373 598	08.86-04.88			0 265 001 181
1.9 E [89; 8A2; B3]				1,9 l 83 kW SD 4 Zyl.
Air flow sensor, gasoline injection	09.87-07.88			F 026 TX2 063
				☛ F 026 TX2 063
Knock sensor	09.87-07.88			0 261 231 038
Temperature sensor, coolant, injection system	09.87-07.88	KZW		0 280 130 040
Wheel speed sensor, rear				
Fg.no. →89..J..373 598	09.87-04.88			0 265 001 181
1.9 quattro [89; 8A2; B3]				1,9 l 83 kW SD 4 Zyl.
Air flow sensor, gasoline injection	09.86-07.88			F 026 TX2 063
				☛ F 026 TX2 063
Knock sensor	09.86-07.88			0 261 231 036
Temperature sensor, coolant, injection system	09.86-07.88			0 280 130 040
Wheel speed sensor, rear				
Fg.no. →89..J..373 595	09.86-04.88			0 265 001 183
1.9 TDI [8C2; B4]				1,9 l 66 kW 1Z 4 Zyl.
Air flow sensor, diesel				
Fg.no. →8C..R..128 401	09.91-01.94	GS		0 281 002 072
Boost pressure sensor, Diesel	09.91-05.95			0 281 002 018
Pressure sensor, intake manifold, diesel	09.91-05.95			0 261 230 037
Pedal position sensor, diesel				
Fg.no. →8C..R..300 000	09.91-07.94			0 205 001 001
Fg.no. 8C..S..000 001→	08.94-05.95	AG		0 205 001 018
		GS		0 205 001 017
2.0 [8C2; B4]				2,0 l 101 kW 6A 4 Zyl.
Throttle valve sensor	09.91-07.92			0 280 120 426
Air flow sensor, gasoline injection	09.91-07.92			0 986 439 389
				☛ F 026 TX2 059
				☛ 0 986 439 389
Temperature sensor, coolant, injection system	09.91-07.92	ABM		0 280 130 040
2.0 [8C2; B4]				2,0 l 103 kW ACE 4 Zyl.
Throttle valve sensor	08.92-05.95			0 280 120 426
Air flow sensor, gasoline injection	08.92-05.95			0 986 439 389
				☛ F 026 TX2 059
				☛ 0 986 439 389
Knock sensor	08.92-05.95	LLE		0 261 231 036
		RLE		0 261 231 038
Temperature sensor, coolant, injection system	08.92-05.95	ABM		0 280 130 040
2.0 [89; 8A2; B3]				2,0 l 85 kW AAD 4 Zyl.
Throttle valve sensor	08.90-12.91			0 280 120 426
Air flow sensor, gasoline injection	08.90-12.91			0 438 121 087
				☛ 0 986 439 387
Knock sensor	08.90-12.91			0 261 231 036
Temperature sensor, coolant, injection system	08.90-12.91	KAT		0 280 130 040
		KZW		0 280 130 040



Product				
◀ 80				
2.0 [89; 8A2; B3]	2,0l 101 kW 6A 4 Zyl.			
Air flow sensor, gasoline injection	03.90-12.91		0 986 439 389	F 026 TX2 059
			0 986 439 389	
Knock sensor	03.90-12.91	KZB	0 261 231 036	
		KZG	0 261 231 038	
Temperature sensor, coolant, injection system	03.90-12.91	KAT	0 280 130 040	
2.0 E [8C2; B4]	2,0l 85 kW ABK 4 Zyl.			
Knock sensor	09.91-05.95		0 261 231 036	
2.0 E [89; 8A2; B3]	2,0l 83 kW 3A 4 Zyl.			
Air flow sensor, gasoline injection	08.88-10.90		0 438 121 087	0 986 439 387
			0 986 439 387	
Knock sensor	08.88-10.90		0 261 231 038	
Temperature sensor, coolant, injection system	08.88-10.90	KAT	0 280 130 040	
		KZW	0 280 130 040	
2.0 quattro [8C2; B4]	2,0l 79/85 kW ABK; ADW 4 Zyl.			
Knock sensor	09.91-05.95	KZB	0 261 231 036	
		KZG	0 261 231 038	
2.0 quattro [8C2; B4]	2,0l 101/103 kW ACE; 6A 4 Zyl.			
Throttle valve sensor	09.91-05.95		0 280 120 426	
Air flow sensor, gasoline injection	09.91-05.95		0 986 439 389	F 026 TX2 059
			0 986 439 389	
Knock sensor	09.91-05.95	LLE	0 261 231 036	
		RLE	0 261 231 038	
Temperature sensor, coolant, injection system	09.91-05.95	ABM	0 280 130 040	
2.0 quattro [89; 8A2; B3]	2,0l 83 kW 3A 4 Zyl.			
Air flow sensor, gasoline injection	08.88-09.90		0 438 121 087	0 986 439 387
			0 986 439 387	
Knock sensor	08.88-09.90	LLE	0 261 231 036	
		RLE	0 261 231 038	
Temperature sensor, coolant, injection system	08.88-09.90		0 280 130 040	
2.0 quattro [89; 8A2; B3]	2,0l 85 kW AAD 4 Zyl.			
Throttle valve sensor	09.90-09.91		0 280 120 426	
Air flow sensor, gasoline injection	09.90-09.91		0 438 121 087	0 986 439 387
			0 986 439 387	
Knock sensor	09.90-09.91	LLE	0 261 231 036	
		RLE	0 261 231 038	
Temperature sensor, coolant, injection system	09.90-09.91	KZW	0 280 130 040	
2.0 16V quattro [89; 8A2; B3]	2,0l 101 kW 6A 4 Zyl.			
Air flow sensor, gasoline injection	03.90-08.91		0 986 439 389	F 026 TX2 059
			0 986 439 389	
Knock sensor	03.90-08.91	KZB	0 261 231 036	
		KZG	0 261 231 038	
Temperature sensor, coolant, injection system	03.90-08.91	KZW	0 280 130 040	
2.2 S2 quattro [8C2; B4]	2,2l 169 kW ABY 5 Zyl.			
Throttle valve sensor	02.93-05.95		0 280 120 431	
Air mass meter, gasoline injection	02.93-05.95		0 280 213 007	0 986 280 137
			0 986 280 137	
Phase sensor	02.93-05.95		0 232 101 020	
Knock sensor	02.93-05.95	KZB	0 261 231 036	
		KZG	0 261 231 038	
Pressure sensor, intake manifold, gasoline	02.93-05.95		0 280 101 001	
Temperature sensor, coolant, injection system	02.93-05.95	KZW	0 280 130 037	
2.3 [8C2; B4]	2,3l 98 kW NG 5 Zyl.			
Throttle valve sensor	09.91-11.94		0 280 120 433	
Air flow sensor, gasoline injection	09.91-11.94		F 026 TX2 054	F 026 TX2 054
			F 026 TX2 054	
Knock sensor	09.91-11.94	LLE	0 261 231 036	
		RLE	0 261 231 038	
Pressure sensor, intake manifold, gasoline	09.91-11.94		0 280 101 001	
Temperature sensor, coolant, injection system	09.91-11.94		0 280 130 053	



Product				
80 Avant				
2.3 quattro [8C2; B4]	2,3l 98 kW NG 5 Zyl.			
Air flow sensor, gasoline injection	09.91-11.94		F 026 TX2 054	F 026 TX2 054
			F 026 TX2 054	
Knock sensor	09.91-11.94	LLE	0 261 231 036	
		RLE	0 261 231 038	
Pressure sensor, intake manifold, gasoline	09.91-11.94		0 280 101 001	
Temperature sensor, coolant, injection system	09.91-11.94	ABM	0 280 130 053	
2.3 quattro [89; 8A2; B3]	2,3l 98 kW NG 5 Zyl.			
Air flow sensor, gasoline injection	04.87-08.91		F 026 TX2 054	F 026 TX2 054
			F 026 TX2 054	
Knock sensor	04.87-08.91	LLE	0 261 231 036	
		RLE	0 261 231 038	
Pressure sensor, intake manifold, gasoline	04.87-08.91		0 280 101 001	
Temperature sensor, coolant, injection system	04.87-08.91	KZS	0 280 130 053	
Wheel speed sensor, rear				
Fg.no. →89..J..373 595	04.87-04.88		0 265 001 183	
2.6 E [8C2; B4]	2,6l 102 kW ACZ 6 Zyl.			
Temperature sensor, coolant, injection system	05.93-05.95	ABM	0 280 130 040	
2.6 E [8C2; B4]	2,6l 110 kW ABC 6 Zyl.			
Throttle valve sensor	07.92-05.95		0 280 120 431	
Knock sensor	07.92-05.95	KZB	0 261 231 036	
		KZG	0 261 231 038	
Temperature sensor, coolant, injection system	07.92-05.95	ABM	0 280 130 040	
2.6 quattro [8C2; B4]	2,6l 102/110 kW ABC; ACZ 6 Zyl.			
Throttle valve sensor	07.92-05.95		0 280 120 431	
Knock sensor	07.92-05.95	KZB	0 261 231 036	
		KZG	0 261 231 038	
Temperature sensor, intake air, injection system	07.92-05.95		0 280 130 060	
Temperature sensor, coolant, injection system	07.92-05.95	ABM	0 280 130 040	
2.8 E, quattro [8C2; B4]	2,8l 128 kW AAH 6 Zyl.			
Throttle valve sensor	09.91-05.95		0 280 120 431	
Knock sensor	09.91-05.95	KZB	0 261 231 036	
		KZG	0 261 231 038	
Temperature sensor, coolant, injection system	09.91-05.95	ABM	0 280 130 040	



A



Product		
2.0 E [8C5; B4]	2,0l 85 kW ABK 4 Zyl.	
Knock sensor	08.92-07.95	0 261 231 036
2.0 quattro [8C5; B4]	2,0l 79 kW ADW 4 Zyl.	
Knock sensor	11.93-07.95	KZB 0 261 231 036
		KZG 0 261 231 038
2.0 quattro [8C5; B4]	2,0l 103 kW ACE 4 Zyl.	
Throttle valve sensor	07.94-07.95	0 280 120 426
Air flow sensor, gasoline injection	07.94-07.95	0 986 439 389
		F 026 TX2 059
		0 986 439 389
Knock sensor	07.94-07.95	LLE 0 261 231 036
		RLE 0 261 231 038
Temperature sensor, coolant, injection system	07.94-07.95	ABM 0 280 130 040
2.2 RS2 quattro [8C5; B4]	2,2l 232 kW ADU 5 Zyl.	
Throttle valve sensor	03.94-07.95	0 280 120 431
Air mass meter, gasoline injection	03.94-07.95	0 280 213 017
		0 986 280 139
Knock sensor	03.94-07.95	KZB 0 261 231 036
		KZG 0 261 231 038
2.2 S2 quattro [8C5; B4]	2,2l 169 kW ABY 5 Zyl.	
Throttle valve sensor	07.94-07.95	0 280 120 431
Air mass meter, gasoline injection	07.94-07.95	0 280 213 007
		0 986 280 137
Phase sensor	07.94-07.95	0 232 101 020
Knock sensor	07.94-07.95	KZB 0 261 231 036
		KZG 0 261 231 038
Pressure sensor, intake manifold, gasoline	07.94-07.95	0 280 101 001
Temperature sensor, coolant, injection system	07.94-07.95	KZW 0 280 130 037
2.3 E [8C5; B4]	2,3l 98 kW NG 5 Zyl.	
Throttle valve sensor	08.92-11.94	0 280 120 433
Air flow sensor, gasoline injection	08.92-11.94	F 026 TX2 054
		F 026 TX2 054
Knock sensor	08.92-11.94	LLE 0 261 231 036
		RLE 0 261 231 038
Pressure sensor, intake manifold, gasoline	08.92-11.94	0 280 101 001
Temperature sensor, coolant, injection system	08.92-11.94	0 280 130 053
2.3 quattro [8C5; B4]	2,3l 98 kW NG 5 Zyl.	
Air flow sensor, gasoline injection	08.92-11.94	F 026 TX2 054
		F 026 TX2 054
Knock sensor	08.92-11.94	LLE 0 261 231 036
		RLE 0 261 231 038
Pressure sensor, intake manifold, gasoline	08.92-11.94	0 280 101 001
Temperature sensor, coolant, injection system	08.92-11.94	ABM 0 280 130 053
2.6 E [8C5; B4]	2,6l 102 kW ACZ 6 Zyl.	
Temperature sensor, coolant, injection system	05.93-05.95	ABM 0 280 130 040
2.6 E [8C5; B4]	2,6l 110 kW ABC 6 Zyl.	
Throttle valve sensor	08.92-05.95	0 280 120 431
Knock sensor	08.92-05.95	KZB 0 261 231 036
		KZG 0 261 231 038
Temperature sensor, coolant, injection system	08.92-05.95	ABM 0 280 130 040
2.6 quattro [8C5; B4]	2,6l 102/110 kW ABC; ACZ 6 Zyl.	
Throttle valve sensor	08.92-07.95	0 280 120 431
Knock sensor	08.92-07.95	KZB 0 261 231 036
		KZG 0 261 231 038
Temperature sensor, intake air, injection system	08.92-07.95	0 280 130 060
Temperature sensor, coolant, injection system	08.92-07.95	ABM 0 280 130 040
2.8 E [8C5; B4]	2,8l 128 kW AAH 6 Zyl.	
Throttle valve sensor	08.92-05.95	0 280 120 431
Knock sensor	08.92-05.95	KZB 0 261 231 036
		KZG 0 261 231 038
Temperature sensor, coolant, injection system	08.92-05.95	ABM 0 280 130 040



2.8 quattro [8C5; B4]	2,8l 128 kW AAH 6 Zyl.	
Throttle valve sensor	08.92-07.95	0 280 120 431
Knock sensor	08.92-07.95	KZB 0 261 231 036
		KZG 0 261 231 038
Temperature sensor, coolant, injection system	08.92-07.95	ABM 0 280 130 040
90		
1.6 TD [89; 8A2; B3]	1,6l 59 kW RA 4 Zyl.	
Wheel speed sensor, rear		
Fg.no. →89..J..373 598	07.87-04.88	0 265 001 181
1.8 [81; 85; B2]	1,8l 66 kW JN 4 Zyl.	
Air flow sensor, gasoline injection	06.84-03.87	F 026 TX2 063
		F 026 TX2 063
Temperature sensor, coolant, injection system	06.84-03.87	0 280 130 040
1.8 E [89; 8A2; B3]	1,8l 82 kW DZ 4 Zyl.	
Air flow sensor, gasoline injection	08.89-12.91	FOB F 026 TX2 051
		F 026 TX2 051
Temperature sensor, coolant, injection system	08.89-12.91	FGK,KZW 0 280 130 040
2.0 [81; 85; B2]	2,0l 81 kW JL 5 Zyl.	
Air flow sensor, gasoline injection	10.84-03.87	0 438 120 181
Wheel speed sensor, rear	10.84-03.87	0 265 001 099
2.0 [81; 85; B2]	2,0l 83 kW SK 5 Zyl.	
Knock sensor	02.86-03.87	0 261 231 038
Wheel speed sensor, rear	02.86-03.87	0 265 001 099
2.0 [81; 85; B2]	2,0l 85 kW HP; JS 5 Zyl.	
Air flow sensor, gasoline injection		
Fg.no. 81..G..144 746→	02.86-03.87	FOB 0 438 120 211
Wheel speed sensor, rear	10.84-03.87	0 265 001 099
2.0 [89; 8A2; B3]	2,0l 83 kW 3A 4 Zyl.	
Air flow sensor, gasoline injection	09.87-10.90	0 438 121 070
		0 986 439 370
Knock sensor	09.87-10.90	KZB 0 261 231 036
		KZG 0 261 231 038
Temperature sensor, coolant, injection system	09.87-10.90	0 280 130 040
2.0 [89; 8A2; B3]	2,0l 85 kW PS 5 Zyl.	
Throttle valve sensor	05.87-12.91	0 280 120 433
Air flow sensor, gasoline injection	05.87-12.91	FGK,FOB 0 438 121 073
		FOB,OKA 0 438 120 211
Knock sensor	05.87-12.91	KZB 0 261 231 036
		KZG 0 261 231 038
Temperature sensor, coolant, injection system	05.87-12.91	KAT,KZS 0 280 130 053
		KZW,OKA 0 280 130 040
Wheel speed sensor, rear		
Fg.no. →89..J..373 598	05.87-04.88	0 265 001 181
2.0 quattro [89; 8A2; B3]	2,0l 118 kW NM 5 Zyl.	
Temperature sensor, coolant, injection system	01.88-09.91	0 280 130 037
Wheel speed sensor, rear		
Fg.no. →89..J..373 595	01.88-04.88	0 265 001 183
2.2 [81; 85; B2]	2,2l 85 kW KX 5 Zyl.	
Air flow sensor, gasoline injection	01.85-03.87	F 026 TX2 064
		F 026 TX2 064
Pressure sensor, intake manifold, gasoline	01.85-03.87	0 280 101 001
Wheel speed sensor, rear	01.85-03.87	0 265 001 099
2.2 [81; 85; B2]	2,2l 98/100 kW HY; KV 5 Zyl.	
Air flow sensor, gasoline injection		
Fg.no. 81..G..144 746→	02.86-03.87	FOB 0 438 120 211
Wheel speed sensor, rear	10.84-03.87	0 265 001 099
2.2 E [89; 8A2; B3]	2,2l 98 kW KV 5 Zyl.	
Air flow sensor, gasoline injection	04.87-12.91	FOB 0 438 120 211
Wheel speed sensor, rear		
Fg.no. →89..J..373 598	04.87-04.88	0 265 001 181



Product				

◀ 90

2.2 quattro [81; 85; B2]		2,2l 89 kW JT 5 Zyl.	
Air flow sensor, gasoline injection	12.84-03.87	F 026 TX2 064 🔌 F 026 TX2 064	
Pressure sensor, intake manifold, gasoline	12.84-03.87	0 280 101 001	
Temperature sensor, coolant, injection system	12.84-03.87	0 280 130 037	
2.2 quattro [81; 85; B2]		2,2l 100 kW HY 5 Zyl.	
Air flow sensor, gasoline injection			
Fg.no. 85..G..144 746→	03.86-03.87	FOB	0 438 120 211
2.2 quattro [89; 8A2; B3]		2,2l 98 kW KV 5 Zyl.	
Air flow sensor, gasoline injection	04.87-09.91	FOB	0 438 120 211
Wheel speed sensor, rear			
Fg.no. →89..J..373 595	04.87-04.88	0 265 001 183	
2.3 [89; 8A2; B3]		2,3l 125 kW 7A 5 Zyl.	
Throttle valve sensor			
Fg.no. 8A..L..070 001→	10.89-12.91	0 280 120 422	
Temperature sensor, coolant, injection system	08.88-12.91	0 280 130 037	
2.3 E [89; 8A2; B3]		2,3l 98 kW NG 5 Zyl.	
Throttle valve sensor	04.87-12.91	0 280 120 433	
Air flow sensor, gasoline injection	04.87-12.91	F 026 TX2 054 🔌 F 026 TX2 054	
Knock sensor	04.87-12.91	KZB	0 261 231 036
		KZG	0 261 231 038
Pressure sensor, intake manifold, gasoline	04.87-12.91	0 280 101 001	
Temperature sensor, coolant, injection system	04.87-12.91	0 280 130 053	
Wheel speed sensor, rear			
Fg.no. →89..J..373 598	04.87-04.88	0 265 001 181	
2.3 quattro [89; 8A2; B3]		2,3l 98 kW NG 5 Zyl.	
Throttle valve sensor	04.87-09.91	0 280 120 426	
Air flow sensor, gasoline injection	04.87-09.91	F 026 TX2 054 🔌 F 026 TX2 054	
Knock sensor	04.87-09.91	LLE	0 261 231 036
		RLE	0 261 231 004
Pressure sensor, intake manifold, gasoline	04.87-09.91	0 280 101 001	
Temperature sensor, coolant, injection system	04.87-09.91	0 280 130 053	
Wheel speed sensor, rear			
Fg.no. →89..J..373 595	04.87-04.88	0 265 001 183	
2.3 quattro [89; 8A2; B3]		2,3l 125 kW 7A 5 Zyl.	
Throttle valve sensor			
Fg.no. 8A..L..203 051→	03.90-09.91	0 280 120 422	
Temperature sensor, coolant, injection system	07.88-09.91	0 280 130 037	
2.8 quattro [89; 8A2; B3]		2,8l 128 kW AAH 6 Zyl.	
Knock sensor	03.92-06.95	LLE	0 261 231 036

100

1.6 [4A2; C4]		1,6l 75 kW ABB 4 Zyl.	
Air flow sensor, gasoline injection	03.92-01.94	F 026 TX2 051 🔌 F 026 TX2 051	
1.8 [44; 44Q; C3]		1,8l 55 kW DR; RS 4 Zyl.	
Wheel speed sensor, rear	08.82-12.87	0 265 001 060	
1.8 [44; 44Q; C3]		1,8l 65/66 kW DS; JW; SH 4 Zyl.	
Wheel speed sensor, rear			
Fg.no. →44..J..200 099	03.83-12.87	0 265 001 060	
1.8 [44; 44Q; C3]		1,8l 66 kW PH 4 Zyl.	
Air flow sensor, gasoline injection	04.85-12.90	F 026 TX2 063 🔌 F 026 TX2 063	
Temperature sensor, coolant, injection system	04.85-12.90	0 280 130 040	
Wheel speed sensor, rear			
Fg.no. →44..J..200 099	04.85-12.87	0 265 001 060	
1.8 [44; 44Q; C3]		1,8l 66 kW 4B 4 Zyl.	
Temperature sensor, coolant, injection system	01.88-12.90	0 280 130 040	

Product				

1.8 quattro [44; 44Q; C3]		1,8l 66 kW PH 4 Zyl.	
Air flow sensor, gasoline injection	08.85-07.88	F 026 TX2 063 🔌 F 026 TX2 063	
Temperature sensor, coolant, injection system	08.85-07.88	0 280 130 040	
2.0 [4A2; C4]		2,0l 85 kW AAD 4 Zyl.	
Throttle valve sensor	01.91-12.92	AG	0 280 120 433
		GS	0 280 120 426
Air flow sensor, gasoline injection	08.91-12.92	0 438 121 087 🔌 0 986 439 387	
Knock sensor	01.91-12.92	LLE	0 261 231 038
		RLE	0 261 231 036
2.0 [4A2; C4]		2,0l 85 kW ABK 4 Zyl.	
Knock sensor	01.93-07.94	LLE	0 261 231 038
		RLE	0 261 231 036
2.0 [4A2; C4]		2,0l 103 kW ACE 4 Zyl.	
Air flow sensor, gasoline injection	01.92-07.94	0 986 439 389 🔌 F 026 TX2 059 🔌 0 986 439 389	
Knock sensor	01.92-07.94	0 261 231 038	
2.0 [44; 44Q; C3]		2,0l 83 kW SL 5 Zyl.	
Air flow sensor, gasoline injection	08.86-12.87	FOB	0 438 120 211
Knock sensor	08.86-12.87	0 261 231 038	
Wheel speed sensor, rear	08.86-12.87	0 265 001 060	
2.0 [44; 44Q; C3]		2,0l 85 kW KP 5 Zyl.	
Air flow sensor, gasoline injection			
Fg.no. →44..G..300000	08.84-07.86	FMB	0 438 121 005
Fg.no. 44..H..025439→	08.86-12.87	FOB	0 438 120 211
Wheel speed sensor, rear	08.84-12.87	0 265 001 060	
2.0 [44; 44Q; C3]		2,0l 85 kW RT 5 Zyl.	
Air flow sensor, gasoline injection	01.88-12.90	0 438 121 073 FOB 0 438 120 211	
Knock sensor	01.88-12.90	0 261 231 038	
2.0 D [44; 44Q; C3]		2,0l 51 kW CN 5 Zyl.	
Wheel speed sensor, rear			
Fg.no. →44..J..200 099	08.80-12.87	0 265 001 060	
2.0 quattro [4A2; C4]		2,0l 85 kW AAD 4 Zyl.	
Throttle valve sensor	12.90-07.92	0 280 120 426	
Air flow sensor, gasoline injection	08.91-07.92	0 438 121 087 🔌 0 986 439 387	
Knock sensor	12.90-07.92	KZB	0 261 231 036
		KZG	0 261 231 038
2.0 quattro [4A2; C4]		2,0l 103 kW ACE 4 Zyl.	
Throttle valve sensor	01.92-07.94	0 280 120 426	
Air flow sensor, gasoline injection	01.92-07.94	0 986 439 389 🔌 F 026 TX2 059 🔌 0 986 439 389	
Knock sensor	01.92-07.94	KZB	0 261 231 036
		KZG	0 261 231 038
2.0 TD [44; 44Q; C3]		2,0l 66 kW DE 5 Zyl.	
Wheel speed sensor, rear	08.82-12.87	0 265 001 060	
2.0 TD [44; 44Q; C3]		2,0l 75 kW NC 5 Zyl.	
Wheel speed sensor, rear			
Fg.no. →44..J..200 099	08.87-12.87	0 265 001 060	
2.2 [44; 44Q; C3]		2,2l 85 kW KZ 5 Zyl.	
Air flow sensor, gasoline injection	08.84-07.87	F 026 TX2 064 🔌 F 026 TX2 064	
Pressure sensor, intake manifold, gasoline	08.84-07.87	0 280 101 001	
Wheel speed sensor, rear	08.84-07.87	0 265 001 060	
2.2 [44; 44Q; C3]		2,2l 101 kW HX; KU 5 Zyl.	
Air flow sensor, gasoline injection			
Fg.no. →44..G..300000	08.84-07.86	FMB	0 438 121 005
Fg.no. 44..H..025439→	08.86-12.90	FOB	0 438 120 211



Wheel speed sensor, rear		
Fg.no. →44..J..200 099	08.84-12.87	0 265 001 060
2.2 E	2,2l 96 kW PR 5 Zyl.	
Air flow sensor, gasoline injection	01.92-12.98	0 438 120 211
Knock sensor	01.92-12.98	0 261 231 004
2.2 quattro [44; 44Q; C3]	2,2l 88 kW PX 5 Zyl.	
Air flow sensor, gasoline injection	08.85-07.86	F 026 TX2 064
		☛ F 026 TX2 064
Pressure sensor, intake manifold, gasoline	08.85-07.86	0 280 101 001
2.2 quattro [44; 44Q; C3]	2,2l 101 kW HX; KU 5 Zyl.	
Air phase sensor, gasoline injection		
Fg.no. 44..H..000 001→	08.86-11.90 FOB	0 438 120 211
2.2 quattro Turbo [44; 44Q; C3]	2,2l 121 kW MC 5 Zyl.	
Air flow sensor, gasoline injection		
Fg.no. →44..K..038 261	03.86-10.88	0 438 121 053
2.2 turbo [44; 44Q; C3]	2,2l 121 kW MC 5 Zyl.	
Air flow sensor, gasoline injection		
Fg.no. →44..K..038 261	05.86-10.88	0 438 121 053
Wheel speed sensor, rear		
Fg.no. →44..J..200 099	05.86-12.87	0 265 001 060
2.3 [4A2; C4]	2,3l 98 kW AAR 5 Zyl.	
Throttle valve sensor	12.90-07.94	0 280 120 433
Air flow sensor, gasoline injection	12.90-07.94	F 026 TX2 054
		☛ F 026 TX2 054
Knock sensor	12.90-07.94	0 261 231 038
Pressure sensor, intake manifold, gasoline	12.90-07.94	0 280 101 001
2.3 [44; 44Q; C3]	2,3l 100 kW NF 5 Zyl.	
Throttle valve sensor	10.86-12.90	0 280 120 433
Air flow sensor, gasoline injection	10.86-12.90	F 026 TX2 054
		☛ F 026 TX2 054
Knock sensor	10.86-12.90	0 261 231 038
Pressure sensor, intake manifold, gasoline	10.86-12.90	0 280 101 001
Temperature sensor, coolant, injection system	10.86-12.90	0 280 130 053
Wheel speed sensor, rear		
Fg.no. →44..J..200 099	10.86-12.87	0 265 001 060
2.3 quattro [4A2; C4]	2,3l 98 kW AAR 5 Zyl.	
Air flow sensor, gasoline injection	12.90-07.94	F 026 TX2 054
		☛ F 026 TX2 054
Knock sensor	12.90-07.94	0 261 231 038
Pressure sensor, intake manifold, gasoline	12.90-07.94	0 280 101 001
2.3 quattro [44; 44Q; C3]	2,3l 100 kW NF 5 Zyl.	
Air flow sensor, gasoline injection	08.86-11.90	F 026 TX2 054
		☛ F 026 TX2 054
Knock sensor	08.86-11.90	0 261 231 038
Pressure sensor, intake manifold, gasoline	08.86-11.90	0 280 101 001
Temperature sensor, coolant, injection system	08.86-11.90 2PO	0 280 130 053
2.5 TDI [4A2; C4]	2,5l 85 kW AAT 5 Zyl.	
Air mass meter, diesel	08.91-07.94	0 281 002 074
Pressure sensor, intake manifold, diesel	08.91-07.94	0 281 002 018
Temperature sensor, coolant, diesel	08.91-07.94	0 280 130 037
Temperature sensor, charge air cooling, diesel	08.91-07.94	0 280 130 039
Pedal position sensor, diesel		
Fg.no. →4A..P..064 812	08.91-01.93	0 205 001 001
Fg.no. 4A..P..064 813→	02.93-07.94 AG	0 205 001 013
	GS	0 205 001 007
2.5 TDI [4A2; C4]	2,5l 85 kW ABP 5 Zyl.	
Pressure sensor, intake manifold, diesel	06.91-07.92	0 281 002 018
Temperature sensor, coolant, diesel	06.91-07.92	0 280 130 037
Temperature sensor, charge air cooling, diesel	06.91-07.92	0 280 130 039
Pedal position sensor, diesel	06.91-07.92	0 205 001 001
2.5 TDI [44; 44Q; C3]	2,5l 88 kW 1T 5 Zyl.	
Pressure sensor, intake manifold, diesel	01.90-12.90	0 281 002 018
Temperature sensor, coolant, diesel	01.90-12.90	0 280 130 037



Temperature sensor, intake air, diesel	01.90-12.90	0 280 130 039
Pedal position sensor, diesel	01.90-12.90	0 205 001 001
2.6 [4A2; C4]	2,6l 102 kW ACZ 6 Zyl.	
Throttle valve sensor	01.93-07.94	0 280 120 431
Temperature sensor, coolant, injection system	01.93-07.94	0 280 130 040
2.6 [4A2; C4]	2,6l 110 kW ABC 6 Zyl.	
Throttle valve sensor	04.92-07.94	0 280 120 431
Knock sensor	04.92-07.94	0 261 231 036
Temperature sensor, coolant, injection system	04.92-07.94	0 280 130 040
2.6 E	2,6l 102 kW ACZ 6 Zyl.	
Phase sensor	01.92-01.98	0 232 101 024
Knock sensor	01.92-01.98	0 261 231 004
2.6 quattro [4A2; C4]	2,6l 110 kW ABC 6 Zyl.	
Throttle valve sensor	03.92-07.94	0 280 120 431
Phase sensor	03.92-07.94	0 232 101 027
Knock sensor	03.92-07.94	0 261 231 036
Temperature sensor, coolant, injection system	03.92-07.94	0 280 130 040
2.8 [4A2; C4]	2,8l 128 kW AAH 6 Zyl.	
Throttle valve sensor	12.90-07.94	0 280 120 431
Knock sensor	12.90-07.94	0 261 231 036
Temperature sensor, coolant, injection system	12.90-07.94	0 280 130 040
2.8 quattro [4A2; C4]	2,8l 128 kW AAH 6 Zyl.	
Throttle valve sensor	12.90-07.94	0 280 120 431
Phase sensor	12.90-07.94	0 232 101 027
Knock sensor	12.90-07.94	0 261 231 036
Temperature sensor, coolant, injection system	12.90-07.94	0 280 130 040

100 Avant

1.6 [4A5; C4]	1,6l 75 kW ABB 4 Zyl.	
Air flow sensor, gasoline injection	03.92-07.93	F 026 TX2 051
		☛ F 026 TX2 051
1.8 [44; 44Q; C3]	1,8l 55 kW DR; RS 4 Zyl.	
Wheel speed sensor, rear	05.83-12.87	0 265 001 060
1.8 [44; 44Q; C3]	1,8l 66 kW DS; JW 4 Zyl.	
Wheel speed sensor, rear		
Fg.no. →44..J..200 099	05.83-12.87	0 265 001 060
1.8 [44; 44Q; C3]	1,8l 66 kW PH 4 Zyl.	
Air flow sensor, gasoline injection	08.86-12.87	F 026 TX2 063
		☛ F 026 TX2 063
Temperature sensor, coolant, injection system	08.86-12.87	0 280 130 040
Wheel speed sensor, rear	08.86-12.87	0 265 001 060
1.8 [44; 44Q; C3]	1,8l 66 kW 4B 4 Zyl.	
Temperature sensor, coolant, injection system	01.88-07.89	0 280 130 040
1.8 quattro [44; 44Q; C3]	1,8l 66 kW PH 4 Zyl.	
Air flow sensor, gasoline injection	08.85-07.88	F 026 TX2 063
		☛ F 026 TX2 063
Temperature sensor, coolant, injection system	08.85-07.88	0 280 130 040
2.0 [4A5; C4]	2,0l 85 kW AAD 4 Zyl.	
Throttle valve sensor	08.91-12.92 AG	0 280 120 433
	GS	0 280 120 426
Air flow sensor, gasoline injection	08.91-12.92	0 438 121 087
		☛ 0 986 439 387
Knock sensor	08.91-12.92 LLE	0 261 231 038
	RLE	0 261 231 036
2.0 [4A5; C4]	2,0l 85 kW ABK 4 Zyl.	
Knock sensor	01.93-07.94 LLE	0 261 231 038
	RLE	0 261 231 036
2.0 [4A5; C4]	2,0l 103 kW ACE 4 Zyl.	
Air flow sensor, gasoline injection	07.92-07.94	0 986 439 389
		☛ F 026 TX2 059
		☛ 0 986 439 389
Knock sensor	07.92-07.94	0 261 231 038





Product



◀ 100 Avant

2.0 [44; 44Q; C3]		2,0l 83 kW SL 5 Zyl.
Air flow sensor, gasoline injection	08.86-12.87	FOB 0 438 120 211
Knock sensor	08.86-12.87	0 261 231 038
Wheel speed sensor, rear	08.86-12.87	0 265 001 060
2.0 [44; 44Q; C3]		2,0l 85 kW KP 5 Zyl.
Air flow sensor, gasoline injection	08.86-12.87	FOB 0 438 120 211
Wheel speed sensor, rear	08.86-12.87	0 265 001 060
2.0 [44; 44Q; C3]		2,0l 85 kW RT 5 Zyl.
Air flow sensor, gasoline injection	01.88-12.90	FOB,OKA 0 438 120 211
		KAT 0 438 121 073
Knock sensor	01.88-12.90	0 261 231 038
2.0 D [44; 44Q; C3]		2,0l 51 kW CN 5 Zyl.
Wheel speed sensor, rear		
Fg.no. →44..J..200 099	05.83-12.87	0 265 001 060
2.0 quattro [4A5; C4]		2,0l 85 kW AAD 4 Zyl.
Throttle valve sensor	12.90-07.92	0 280 120 426
Air flow sensor, gasoline injection	08.91-07.92	0 438 121 087
		 0 986 439 387
Knock sensor	12.90-07.92	KZB 0 261 231 036
		KZG 0 261 231 038
2.0 TD [44; 44Q; C3]		2,0l 66 kW DE 5 Zyl.
Wheel speed sensor, rear	05.83-12.87	0 265 001 060
2.2 [44; 44Q; C3]		2,2l 85 kW KZ 5 Zyl.
Air flow sensor, gasoline injection	08.86-07.87	F 026 TX2 064
		 F 026 TX2 064
Pressure sensor, intake manifold, gasoline	08.86-07.87	0 280 101 001
Wheel speed sensor, rear	08.86-07.87	0 265 001 060
2.2 [44; 44Q; C3]		2,2l 101 kW HX 5 Zyl.
Air flow sensor, gasoline injection	09.86-12.87	FOB 0 438 120 211
Wheel speed sensor, rear	09.86-12.87	0 265 001 060
2.2 [44; 44Q; C3]		2,2l 101 kW KU 5 Zyl.
Air flow sensor, gasoline injection	01.88-07.89	FOB 0 438 120 211
2.2 quattro [44; 44Q; C3]		2,2l 88 kW PX 5 Zyl.
Air flow sensor, gasoline injection	08.85-07.86	F 026 TX2 064
		 F 026 TX2 064
Pressure sensor, intake manifold, gasoline	08.85-07.86	0 280 101 001
2.2 quattro [44; 44Q; C3]		2,2l 101 kW HX 5 Zyl.
Air flow sensor, gasoline injection		
Fg.no. 44..H..000 001→	08.86-12.87	FOB 0 438 120 211
2.2 quattro [44; 44Q; C3]		2,2l 101 kW KU 5 Zyl.
Air flow sensor, gasoline injection	08.86-11.90	FOB 0 438 120 211
2.2 quattro Turbo [44; 44Q; C3]		2,2l 121 kW MC 5 Zyl.
Air flow sensor, gasoline injection		
Fg.no. →44..K..038 261	03.86-10.88	0 438 121 053
2.2 Turbo [44; 44Q; C3]		2,2l 121 kW MC 5 Zyl.
Air flow sensor, gasoline injection		
Fg.no. →44..K..038 261	08.88-10.88	0 438 121 053
2.3 [4A5; C4]		2,3l 98 kW AAR 5 Zyl.
Throttle valve sensor	08.91-07.94	0 280 120 433
Air flow sensor, gasoline injection	08.91-07.94	F 026 TX2 054
		 F 026 TX2 054
Knock sensor	08.91-07.94	0 261 231 038
Pressure sensor, intake manifold, gasoline	08.91-07.94	0 280 101 001
2.3 [44; 44Q; C3]		2,3l 100 kW NF 5 Zyl.
Throttle valve sensor	01.88-07.89	0 280 120 433
Air flow sensor, gasoline injection	01.88-07.89	F 026 TX2 054
		 F 026 TX2 054
Knock sensor	01.88-07.89	0 261 231 038
Pressure sensor, intake manifold, gasoline	01.88-07.89	0 280 101 001
Temperature sensor, coolant, injection system	01.88-07.89	0 280 130 053
2.3 quattro [4A5; C4]		2,3l 98 kW AAR 5 Zyl.
Air flow sensor, gasoline injection	12.90-07.94	F 026 TX2 054
		 F 026 TX2 054

Product



Knock sensor	12.90-07.94	0 261 231 038
Pressure sensor, intake manifold, gasoline	12.90-07.94	0 280 101 001
2.3 quattro [44; 44Q; C3]		2,3l 100 kW NF 5 Zyl.
Air flow sensor, gasoline injection	08.86-11.90	F 026 TX2 054
		 F 026 TX2 054
Knock sensor	08.86-11.90	0 261 231 038
Pressure sensor, intake manifold, gasoline	08.86-11.90	0 280 101 001
Temperature sensor, coolant, injection system	08.86-11.90	2PO 0 280 130 053
2.5 TDI [4A5; C4]		2,5l 85 kW AAT 5 Zyl.
Air mass meter, diesel	08.91-07.94	0 281 002 074
Pressure sensor, intake manifold, diesel	08.91-07.94	0 281 002 018
Temperature sensor, coolant, diesel	08.91-07.94	0 280 130 037
Temperature sensor, charge air cooling, diesel	08.91-07.94	0 280 130 039
Pedal position sensor, diesel		
Fg.no. →4A..P..064 812	08.91-01.93	0 205 001 001
Fg.no. 4A..P..064 813→	02.93-07.94	AG 0 205 001 013
		GS 0 205 001 007
2.5 TDI [4A5; C4]		2,5l 85 kW ABP 5 Zyl.
Pressure sensor, intake manifold, diesel	08.91-07.92	0 281 002 018
Temperature sensor, coolant, diesel	08.91-07.92	0 280 130 037
Temperature sensor, charge air cooling, diesel	08.91-07.92	0 280 130 039
Pedal position sensor, diesel	08.91-07.92	0 205 001 001
2.5 TDI [44; 44Q; C3]		2,5l 88 kW 1T 5 Zyl.
Pressure sensor, intake manifold, diesel	01.90-12.90	0 281 002 018
Temperature sensor, coolant, diesel	01.90-12.90	0 280 130 037
Temperature sensor, intake air, diesel	01.90-12.90	0 280 130 039
Pedal position sensor, diesel	01.90-12.90	0 205 001 001
2.6 [4A5; C4]		2,6l 102 kW ACZ 6 Zyl.
Throttle valve sensor	07.93-07.94	0 280 120 431
Temperature sensor, coolant, injection system	07.93-07.94	0 280 130 040
2.6 [4A5; C4]		2,6l 110 kW ABC 6 Zyl.
Throttle valve sensor	07.92-07.94	0 280 120 431
Knock sensor	07.92-07.94	0 261 231 036
Temperature sensor, coolant, injection system	07.92-07.94	0 280 130 040
2.6 quattro [4A5; C4]		2,6l 110 kW ABC 6 Zyl.
Throttle valve sensor	03.92-07.94	0 280 120 431
Phase sensor	03.92-07.94	0 232 101 027
Knock sensor	03.92-07.94	0 261 231 036
Temperature sensor, coolant, injection system	03.92-07.94	0 280 130 040
2.8 [4A5; C4]		2,8l 128 kW AAH 6 Zyl.
Throttle valve sensor	08.91-07.94	0 280 120 431
Knock sensor	08.91-07.94	0 261 231 036
Temperature sensor, coolant, injection system	08.91-07.94	0 280 130 040
2.8 quattro [4A5; C4]		2,8l 128 kW AAH 6 Zyl.
Throttle valve sensor	12.90-07.94	0 280 120 431
Phase sensor	12.90-07.94	0 232 101 027
Knock sensor	12.90-07.94	0 261 231 036
Temperature sensor, coolant, injection system	12.90-07.94	0 280 130 040

200		
2.2 Turbo [44, C3]		2,2l 121 kW MC 5 Zyl.
Air flow sensor, gasoline injection		
Fg.no. →44..K..038 261	08.85-10.88	0 438 121 053
Pressure sensor, intake manifold, gasoline	08.85-12.91	0 280 101 001
Wheel speed sensor, rear		
Fg.no. →44..J..200 099	08.85-01.88	0 265 001 060
2.2 Turbo [44, C3]		2,2l 134 kW JY; KG 5 Zyl.
Pressure sensor, intake manifold, gasoline	08.83-01.88	0 280 101 001
Wheel speed sensor, rear	08.83-01.88	0 265 001 060
2.2 Turbo [44, C3]		2,2l 140/147 kW 1B; 2B 5 Zyl.
Pressure sensor, intake manifold, gasoline	02.88-12.91	0 280 101 001



Product		
2.2 Turbo quattro [44, C3]	2,2l 121 kW MC 5 Zyl.	
Air flow sensor, gasoline injection		
Fg.no. →44..K..038 261	01.85-10.88	0 438 121 053
Pressure sensor, intake manifold, gasoline	01.85-12.90	0 280 101 001
2.2 Turbo quattro [44, C3]	2,2l 134 kW JY; KG 5 Zyl.	
Pressure sensor, intake manifold, gasoline	11.84-12.87	0 280 101 001
2.2 Turbo quattro [44, C3]	2,2l 147 kW 1B 5 Zyl.	
Pressure sensor, intake manifold, gasoline	02.88-11.90	0 280 101 001
2.2 Turbo quattro [44, C3]	2,2l 162 kW 3B 5 Zyl.	
Air mass meter, gasoline injection	03.89-12.90	0 280 213 007 0 986 280 137
Knock sensor	03.89-12.90	KZA 0 261 231 040 KZB 0 261 231 036
Pressure sensor, intake manifold, gasoline	03.89-12.90	0 280 101 001
Temperature sensor, coolant, injection system	03.89-12.90	0 280 130 037
2.6	2,6l 102 kW ACZ 6 Zyl.	
Phase sensor	11.95-09.99	0 232 101 027
Knock sensor	11.95-09.99	KZB 0 261 231 036
Temperature sensor, intake air, injection system	11.95-09.99	KZS 0 280 130 060
Temperature sensor, coolant, injection system	11.95-09.99	LAB 0 280 130 040

200 Avant

2.2 Turbo quattro [44, C3]	2,2l 121 kW MC 5 Zyl.	
Air flow sensor, gasoline injection		
Fg.no. →44..K..038 261	01.85-10.88	0 438 121 053
Pressure sensor, intake manifold, gasoline	01.85-11.90	0 280 101 001
2.2 Turbo quattro [44, C3]	2,2l 134 kW JY; KG 5 Zyl.	
Pressure sensor, intake manifold, gasoline	11.84-12.87	0 280 101 001
2.2 Turbo quattro [44, C3]	2,2l 147 kW 1B 5 Zyl.	
Pressure sensor, intake manifold, gasoline	02.88-11.90	0 280 101 001
2.2 Turbo quattro [44, C3]	2,2l 162 kW 3B 5 Zyl.	
Air mass meter, gasoline injection	03.89-11.90	0 280 213 007 0 986 280 137
Knock sensor	03.89-11.90	KZA 0 261 231 040 KZB 0 261 231 036
Pressure sensor, intake manifold, gasoline	03.89-11.90	0 280 101 001
Temperature sensor, coolant, injection system	03.89-11.90	0 280 130 037

4000

1.8 [81]	1,8l 79 kW MG 4 Zyl.	
Air flow sensor, gasoline injection	10.84-12.87	F 026 TX2 063 0 986 280 137
Knock sensor	10.84-12.87	0 261 231 002
2.2 quattro [81]	2,2l 88 kW JT 5 Zyl.	
Air flow sensor, gasoline injection	12.83-03.87	F 026 TX2 064 0 986 280 137
Pressure sensor, intake manifold, gasoline	12.83-03.87	0 280 101 001
Temperature sensor, coolant, injection system	12.83-03.87	0 280 130 037

5000

2.2 [44]	2,2l 85 kW KZ 5 Zyl.	
Air flow sensor, gasoline injection	08.84-09.86	F 026 TX2 064 0 986 280 137
Pressure sensor, intake manifold, gasoline	08.84-09.86	0 280 101 001
Temperature sensor, coolant, injection system	08.84-09.86	0 280 130 037
2.2 Turbo [44]	2,2l 118 kW MC 5 Zyl.	
Air flow sensor, gasoline injection	08.85-05.88	0 438 121 053
Wheel speed sensor, rear	08.85-05.88	0 265 001 060



2.3 [44]	2,3l 100 kW NF 5 Zyl.	
Air flow sensor, gasoline injection	10.86-01.88	F 026 TX2 054 0 986 280 137
Pressure sensor, intake manifold, gasoline	10.86-01.88	0 280 101 010
Temperature sensor, coolant, injection system	10.86-01.88	0 280 130 053

AUSTIN

Maestro

2.0i	2,0l 83 kW EFI O Series 4 Zyl.	
Relay, Jetronic	10.84-08.88	DID 0 332 014 112

Montego

2.0i	2,0l 83 kW O Series 4 Zyl.	
Relay, Jetronic	04.84-08.88	DID 0 332 014 112

Montego Estate

2.0i	2,0l 83 kW O Series EFI 4 Zyl.	
Relay, Jetronic	10.84-08.88	DID 0 332 014 112

AUTOBIANCHI

Y 10

1.0 fire i.e.	1,0l 33 kW 156 A 2.146 KAT; 156 A 2.246; 156 A 2.256 KAT 4 Zyl.	
Temperature sensor, coolant, injection system	10.87-09.92	0 280 130 026
1.0 fire i.e. 4x4	1,0l 33 kW 156 A 2.146 KAT 4 Zyl.	
Temperature sensor, coolant, injection system	10.87-07.89	0 280 130 026
1.1 fire i.e.	1,1l 37/41 kW 156 C.000; 156 C.046 KAT 4 Zyl.	
Temperature sensor, coolant, injection system	01.89-09.92	0 280 130 026
1.1 fire i.e. 4x4	1,1l 41 kW 156 C.000 KAT 4 Zyl.	
Temperature sensor, coolant, injection system	01.89-09.92	0 280 130 026
1.1 i.e. [R.92]	1,1l 37 kW 156 C 046 4 Zyl.	
Speed sensor, ignition/injection	09.92-01.95	0 261 210 098
Temperature sensor, coolant, injection system	09.92-01.95	0 280 130 026
1.1 i.e. [R.92]	1,1l 43 kW 176 B 2.000 4 Zyl.	
Speed sensor, ignition/injection	02.95-12.95	0 261 210 117
Temperature sensor, coolant, injection system	02.95-12.95	0 280 130 026
1.1 i.e. ECVT [R.92]	1,1l 40 kW 176 B 2.000 4 Zyl.	
Speed sensor, ignition/injection	02.95-12.95	0 261 210 117
Temperature sensor, coolant, injection system	02.95-12.95	0 280 130 026
1.1 i.e. Selectronic, i.e. 4x4 [R.92]	1,1l 37 kW 156 C 046 4 Zyl.	
Speed sensor, ignition/injection	09.92-01.95	0 261 210 098
Temperature sensor, coolant, injection system	09.92-01.95	0 280 130 026
1.3 GT i.e.	1,3l 53/54/57 kW 146 A 5.046 KAT; 146 B.000 4 Zyl.	
Throttle valve sensor	11.87-09.92	0 280 120 328
Air flow sensor, gasoline injection	11.87-09.92	0 280 200 602
Temperature sensor, coolant, injection system	11.87-09.92	0 280 130 026
Relay, Jetronic	11.87-09.92	0 332 014 113
1.3 i.e. [R.92]	1,3l 53 kW 146 A 5.046 MPI 4 Zyl.	
Air flow sensor, gasoline injection	09.92-12.95	0 280 200 602
Temperature sensor, coolant, injection system	09.92-12.95	0 280 130 026
Relay, Jetronic	09.92-12.95	0 332 014 113



Product



BENTLEY

Brooklands

6.8 V8	6,8l 182 kW L 410 MN 1T 8 Zyl.	
Throttle valve sensor	07.93-07.98	0 280 122 007
Air mass meter, gasoline injection	07.93-07.98	0 280 217 801
Phase sensor	07.93-07.98	0 232 103 010
Pulse generator, ignition/Jetronic	07.93-07.98	0 261 210 047
Pressure sensor, intake manifold, gasoline	07.93-07.98	0 261 230 004
Temperature sensor, intake air, injection system	07.93-07.98	0 280 130 039
Temperature sensor, coolant, injection system	07.93-07.98	0 280 130 026

Continental Cabrio

R 6.8 V8 Turbo	6,8l 286 kW L 410 MT 1T 8 Zyl.	
Throttle valve sensor	08.95-12.95	0 280 122 007
Air mass meter, gasoline injection	08.95-12.95	0 280 217 801
Phase sensor	08.95-12.95	0 232 103 010
Pulse generator, ignition/Jetronic	08.95-12.95	0 261 210 047
Pressure sensor, intake manifold, gasoline	08.95-12.95	0 261 230 004
Temperature sensor, intake air, injection system	08.95-12.95	0 280 130 039
Temperature sensor, coolant, injection system	08.95-12.95	0 280 130 026

Mulsanne

6.8	6,8l V8 8 Zyl.	
Air flow sensor, gasoline injection	01.81-12.86	0 438 120 157
6.8 Turbo	6,8l 232 kW V8 8 Zyl.	
Throttle valve sensor	10.86-05.90	0 280 120 300
Air flow sensor, gasoline injection	10.86-05.90	0 438 121 063
Speed sensor, ignition/injection	10.86-05.90	0 261 210 003
Pressure sensor, intake manifold, gasoline	10.86-05.90	0 281 002 018
Temperature sensor, coolant, injection system	10.86-05.90	0 280 130 032

Turbo R, S

R 6.8	6,8l 232/240 kW V8 8 Zyl.	
Throttle valve sensor	11.91-03.93	0 280 120 300
Air flow sensor, gasoline injection	11.91-03.93	F 026 TX2 056
		0 261 210 047
Speed sensor, ignition/injection	11.91-03.93	0 261 210 047
Pressure sensor, intake manifold, gasoline	11.91-03.93	0 281 002 018
Temperature sensor, coolant, injection system	11.91-03.93	0 280 130 026
R 6.8 V8	6,8l 265 kW L 410 MT 8 Zyl.	
Throttle valve sensor	04.93-07.95	0 280 122 007
Air mass meter, gasoline injection	04.93-07.95	0 280 217 801
Temperature sensor, intake air, injection system	04.93-07.95	0 280 130 039
Temperature sensor, coolant, injection system	04.93-07.95	0 280 130 026
R 6.8 V8	6,8l 286 kW L 410 MT 1T 8 Zyl.	
Throttle valve sensor	07.95-07.99	0 280 122 007
Air mass meter, gasoline injection	07.95-07.99	0 280 217 801
Phase sensor	07.95-07.99	0 232 103 010
Speed sensor, ignition/injection	07.95-07.99	0 261 210 047
Pressure sensor, intake manifold, gasoline	07.95-07.99	0 261 230 004
Temperature sensor, intake air, injection system	07.95-07.99	0 280 130 039
Temperature sensor, coolant, injection system	07.95-07.99	0 280 130 026

Product



BERTONE

Freeclimber

1.6 i	1,6l 74 kW M 40 B 16 4 Zyl.	
Air flow sensor, gasoline injection	02.92→	KAT 0 280 200 204
		0 986 280 029
		OKA 0 280 200 205
		0 986 280 040
Temperature sensor, coolant, injection system	02.92→	0 280 130 026

BMW

Serie M

M 3 [E 30]	2,3l 143-158 kW 23 4E A/S 2 4 Zyl.	
Throttle valve sensor	07.86-12.90	0 280 120 301
Air flow sensor, gasoline injection	07.86-12.90	0 280 203 028
		0 986 280 049
Speed sensor, ignition/injection	07.86-12.90	0 261 210 002
Pressure sensor, intake manifold, gasoline	07.86-11.86	0 280 101 001
Temperature sensor, coolant, injection system	07.86-12.90	0 280 130 026
Wheel speed sensor	07.86-12.90	HI 0 265 001 059
		LAB, VO 0 265 001 058
		RAB, VO 0 265 001 057
M 3 [E 36]	3,0l 210 kW 30 6S 1 6 Zyl.	
Air mass meter, gasoline injection	01.94-09.95	0 280 217 806
Knock sensor	01.94-09.95	MI 0 261 231 092
M 3 Evolution I [E 30]	2,3l 147 kW 23 4E A 4 Zyl.	
Throttle valve sensor	02.87-05.87	0 280 120 301
Air flow sensor, gasoline injection	02.87-05.87	0 280 203 028
		0 986 280 049
Speed sensor, ignition/injection	02.87-05.87	0 261 210 002
Pressure sensor, intake manifold, gasoline	02.87-05.87	0 280 101 001
Temperature sensor, coolant, injection system	02.87-05.87	0 280 130 026
Wheel speed sensor	02.87-05.87	HI 0 265 001 059
		LAB, VO 0 265 001 058
		RAB, VO 0 265 001 057
M 3 Evolution II [E 30]	2,3l 162 kW 23 4S 1 4 Zyl.	
Throttle valve sensor	03.88-08.88	0 280 120 301
Air flow sensor, gasoline injection	03.88-08.88	0 280 203 028
		0 986 280 049
Speed sensor, ignition/injection	03.88-08.88	0 261 210 002
Pressure sensor, intake manifold, gasoline	03.88-08.88	0 280 101 001
Temperature sensor, coolant, injection system	03.88-08.88	0 280 130 026
Wheel speed sensor	03.88-08.88	HI 0 265 001 059
		LAB, VO 0 265 001 058
		RAB, VO 0 265 001 057
M 3 Evolution III [E 30]	2,5l 175 kW 25 4S 1 4 Zyl.	
Throttle valve sensor	12.89-04.90	0 280 120 301
Air flow sensor, gasoline injection	12.89-04.90	0 280 203 027
		0 986 280 002
Speed sensor, ignition/injection	12.89-04.90	0 261 210 002
Pressure sensor, intake manifold, gasoline	12.89-04.90	0 280 101 001
Temperature sensor, coolant, injection system	12.89-04.90	0 280 130 026
Wheel speed sensor	12.89-04.90	HI 0 265 001 059
		LAB, VO 0 265 001 058
		RAB, VO 0 265 001 057
M 3 3.2 [E 36]	3,2l 236 kW 32 6S 1 6 Zyl.	
Air mass meter, gasoline injection	10.95-12.97	0 280 217 806
Knock sensor	10.95-12.97	MI 0 261 231 092



Pedal position sensor, EMS (electronic engine management)	10.95-12.97	0 280 752 001
M 5 [E 28]	3,5l 191-210 kW 35 6ED 6 Zyl.	
Throttle valve sensor	01.85-12.87	0 280 120 301
Air flow sensor, gasoline injection	01.85-12.87	0 280 203 025 0 986 280 043
Speed sensor, ignition/injection	01.85-12.87	0 261 210 002
Pressure sensor, intake manifold, gasoline	09.86-12.87 KAT	0 280 101 001
Temperature sensor, coolant, injection system	01.85-12.87	0 280 130 023
Wheel speed sensor	01.85-08.86 HI	0 265 001 027
	09.86-12.87 HI,LAB	0 265 001 168
	HI,RAB	0 265 001 167
	01.85-12.87 VO	0 265 001 029
M 5 [E 39]	5,0l 294 kW 50 8S 1 8 Zyl.	
Air mass meter, gasoline injection	10.98→	0 280 217 533
Knock sensor	10.98→	0 261 231 200
Pedal position sensor, EMS (electronic engine management)	10.98→	0 280 752 023
Duo sensor, acceleration and yaw rate, brake system	10.98→	0 265 005 248
Pressure sensor, ESP, (electronic stability program)	10.98-07.03	0 265 005 303
M 5 3.6 [E 34]	3,5l 232 kW 36 6S 1 6 Zyl.	
Throttle valve sensor	10.88-12.93 AG	0 280 120 404
	GS	0 280 120 301
Air mass meter, gasoline injection	10.88-12.94	0 280 214 001 0 986 280 124
Temperature sensor, coolant, injection system	11.90-12.94	0 280 130 026
Wheel speed sensor, front	10.88-12.93	0 265 001 339
M 5 3.8 [E 34]	3,8l 240-250 kW 38 6S 1 6 Zyl.	
Air mass meter, gasoline injection	03.92-12.95	0 280 214 006
Wheel speed sensor, front	03.92-12.95	0 265 001 339
M 6 [E 24]	3,4l 191 kW 35 6EE 6 Zyl.	
Throttle valve sensor	09.86-12.88	0 280 120 301
Air flow sensor, gasoline injection	09.86-12.88	0 280 203 025 0 986 280 043
Pressure sensor, intake manifold, gasoline	09.86-12.88	0 280 101 001
Temperature sensor, coolant, injection system	09.86-12.88	0 280 130 026
Wheel speed sensor, front	09.86-12.88	0 265 001 038
Wheel speed sensor, rear	10.86-12.88 LAB	0 265 001 168
	RAB	0 265 001 167
M 535i [E 28]	3,4l 136-141/150-160 kW 34 6EA; 34 6KA 6 Zyl.	
Throttle valve sensor	01.86-12.87	0 280 120 320
	09.86-12.87 AG	0 280 120 406
Air flow sensor, gasoline injection	09.84-12.87	0 280 203 027 0 986 280 002
Speed sensor, ignition/injection	09.84-08.86	0 261 210 002
	09.86-12.87	0 261 210 035
Pulse generator, ignition/Jetronic	09.86-12.87	0 356 914 212
Temperature sensor, coolant, injection system	09.84-12.87	0 280 130 026
Wheel speed sensor	09.84-08.86 HI	0 265 001 027
	09.86-12.87 HI,LAB	0 265 001 168
	HI,RAB	0 265 001 167
	09.84-12.87 VO	0 265 001 029
M 635CSi [E 24]	3,5l 191-210 kW 35 6ED 6 Zyl.	
Throttle valve sensor	03.84-04.89	0 280 120 301
Air flow sensor, gasoline injection	03.84-04.89	0 280 203 025 0 986 280 043
Speed sensor, ignition/injection	03.84-04.89	0 261 210 002
Pressure sensor, intake manifold, gasoline	09.86-04.89	0 280 101 001
Temperature sensor, coolant, injection system	03.84-04.89	0 280 130 026
Wheel speed sensor, front	03.84-04.89	0 265 001 038



Wheel speed sensor, rear	03.84-09.86	0 265 001 027
	10.86-04.89 LAB	0 265 001 168
	RAB	0 265 001 167

Serie M Cabrio

M 3 [E 30]	2,3l 143-158 kW 23 4E A/S 2 4 Zyl.	
Throttle valve sensor	03.88-09.91	0 280 120 301
Air flow sensor, gasoline injection	03.88-09.91	0 280 203 028 0 986 280 049
Speed sensor, ignition/injection	03.88-09.91	0 261 210 002
Temperature sensor, coolant, injection system	03.88-09.91	0 280 130 026
Wheel speed sensor	03.88-09.91 HI	0 265 001 059
	LAB,VO	0 265 001 058
	RAB,VO	0 265 001 057
M 3 [E 36]	3,0l 210 kW 30 6S 1 6 Zyl.	
Air mass meter, gasoline injection	01.94-12.95	0 280 217 806
Knock sensor	01.94-12.95 MI	0 261 231 092
M 3 3.2 [E 36]	3,2l 236 kW 32 6S 1 6 Zyl.	
Air mass meter, gasoline injection	01.96-12.99	0 280 217 806
Knock sensor	01.96-12.99 MI	0 261 231 092
Pedal position sensor, EMS (electronic engine management)	01.96-12.99	0 280 752 001

Serie M Coupé

M 3 [E 36]	3,0l 179 kW 30 6S 2 6 Zyl.	
Air mass meter, gasoline injection	09.93-12.96	0 280 217 502
Phase sensor	09.93-12.96 NOC	0 232 103 003
Temperature sensor, coolant, injection system	09.93-09.95	0 280 130 026
M 3 [E 36]	3,0l 210 kW 30 6S 1 6 Zyl.	
Air mass meter, gasoline injection	09.92-09.95	0 280 217 806
Knock sensor	09.92-09.95 MI	0 261 231 092
Temperature sensor, intake air, injection system	09.92-09.95	0 280 130 060
M 3 3.2 [E 36]	3,2l 236 kW 32 6S 1/3 6 Zyl.	
Air mass meter, gasoline injection	10.95-12.98	0 280 217 806
Knock sensor	10.95-12.98 MI	0 261 231 092

Serie M Touring

M 5 [E 34]	3,8l 240-250 kW 38 6S 1 6 Zyl.	
Air mass meter, gasoline injection	04.92-12.95	0 280 214 006
Wheel speed sensor, front	04.92-12.95	0 265 001 339


Serie X

X 3 2.0d [E 83]	2,0l 110 kW 20 4D 4 4 Zyl.	
Air mass meter, diesel	10.04-09.07	0 928 400 529
Duo sensor, acceleration and yaw rate, brake system	10.04-09.06	0 265 005 285
Wheel speed sensor, front	10.04-09.05	0 265 007 621
Wheel speed sensor, rear	10.04-09.05	0 265 007 622
X 3 2.0i [E 83]	2,0l 110 kW N46 B20B 4 Zyl.	
Air mass meter, gasoline injection	09.05→ BFK	0 280 218 165
	BHK	0 280 218 159
Duo sensor, acceleration and yaw rate, brake system	09.05-09.06	0 265 005 285
X 3 2.5i [E 83]	2,5l 141 kW 25 6S 5 6 Zyl.	
Duo sensor, acceleration and yaw rate, brake system	03.04-09.06	0 265 005 285
Wheel speed sensor, front	03.04-09.05	0 265 007 621
Wheel speed sensor, rear	03.04-09.05	0 265 007 622

Product				
◀ Serie X				
X 3 3.0 d [E 83]	3,0l	150 kW	30 6D 2	6 Zyl.
Air mass meter, diesel	01.04-09.05		0 928 400 529	
Duo sensor, acceleration and yaw rate, brake system	01.04-09.05		0 265 005 285	
Wheel speed sensor, front	01.04-09.05		0 265 007 621	
Wheel speed sensor, rear	01.04-09.05		0 265 007 622	
X 3 3.0 d [E 83]	3,0l	160 kW	30 6D 3	6 Zyl.
Air mass meter, diesel	10.06-02.07		0 281 002 849	
	09.05-09.06		0 928 400 529	
Duo sensor, acceleration and yaw rate, brake system	09.05-09.06		0 265 005 285	
X 3 3.0 sd [E 83]	3,0l	210 kW	30 6D 5	6 Zyl.
Air mass meter, diesel	09.06-02.07		0 281 002 849	
X 3 3.0 i [E 83]	3,0l	170 kW	30 6S 3	6 Zyl.
Duo sensor, acceleration and yaw rate, brake system	01.04-09.06		0 265 005 285	
Wheel speed sensor, front	01.04-09.05		0 265 007 621	
Wheel speed sensor, rear	01.04-09.05		0 265 007 622	
X 5 3.0 d [E 53]	3,0l	135 kW	30 6D 1	6 Zyl.
Air mass meter, diesel	03.01-09.03	UPE	0 928 400 527	
High-pressure sensor (CR system)	03.01-09.03		0 281 002 475	
Duo sensor, acceleration and yaw rate, brake system	03.01-09.03		0 265 005 248	
Pressure sensor, ESP, (electronic stability program)	03.01-09.03		0 265 005 303	
X 5 3.0 d [E 53]	3,0l	160 kW	30 6D 2	6 Zyl.
Air mass meter, diesel	10.03-10.06		0 928 400 529	
High-pressure sensor (CR system)	10.03-10.06		0 281 002 497	
Duo sensor, acceleration and yaw rate, brake system	10.03-10.06		0 265 005 285	
Wheel speed sensor, rear	10.03-10.06		0 265 007 853	
X 5 3.0 d [E 70]	3,0l	173 kW	30 6D 3	6 Zyl.
Air mass meter, diesel	03.07→		0 928 400 529	
Duo sensor, acceleration and yaw rate, brake system	03.07→	EAO	0 265 005 678	
X 5 3.0 si [E 70]	3,0l	200 kW	N52 B30A	6 Zyl.
Duo sensor, acceleration and yaw rate, brake system	11.06→	EAO	0 265 005 678	
X 5 3.0 i [E 53]	3,0l	170 kW	30 6S 3	6 Zyl.
Duo sensor, acceleration and yaw rate, brake system	10.99-09.03		0 265 005 248	
	10.03-10.06		0 265 005 285	
Pressure sensor, ESP, (electronic stability program)	10.99-09.03		0 265 005 303	
Wheel speed sensor, rear	10.03-10.06		0 265 007 853	
X 5 4.4 i [E 53]	4,4l	210 kW	44 8S 2	8 Zyl.
Air mass meter, gasoline injection	03.99-09.03		0 280 217 814	
Knock sensor	03.99-09.03		0 261 231 200	
Duo sensor, acceleration and yaw rate, brake system	03.99-09.03		0 265 005 248	
Pressure sensor, ESP, (electronic stability program)	03.99-09.03		0 265 005 303	
X 5 4.4 i [E 53]	4,4l	235 kW	N62 B44A	8 Zyl.
Air mass meter, gasoline injection	10.03-10.06		0 280 218 135	
Knock sensor	10.03-10.06		0 261 231 200	
Duo sensor, acceleration and yaw rate, brake system	10.03-10.06		0 265 005 285	
Wheel speed sensor, rear	10.03-10.06		0 265 007 853	
X 5 4.6 is [E 53]	4,6l	255 kW	46 8S 1	8 Zyl.
Air mass meter, gasoline injection	02.02-09.03		0 280 217 814	
Knock sensor	02.02-09.03		0 261 231 200	
Duo sensor, acceleration and yaw rate, brake system	02.02-09.03		0 265 005 248	
Pressure sensor, ESP, (electronic stability program)	02.02-09.03		0 265 005 303	
X 5 4.8 is [E 53]	4,8l	265 kW	N62 B48A	8 Zyl.
Air mass meter, gasoline injection	03.04-10.06		0 280 218 135	
Knock sensor	03.04-10.06		0 261 231 200	

Product				
Duo sensor, acceleration and yaw rate, brake system	03.04-10.06		0 265 005 285	
Wheel speed sensor, rear	03.04-10.06		0 265 007 853	
X 5 4.8i [E 70]	4,8l	261 kW	N62 B48B	8 Zyl.
Knock sensor	11.06→		0 261 231 200	
Duo sensor, acceleration and yaw rate, brake system	11.06→	EAO	0 265 005 678	
Serie Z				
Z 1 [E30]	2,5l	125 kW	25 6K 1	6 Zyl.
Throttle valve sensor	07.88-06.91		0 280 120 310	
Air flow sensor, gasoline injection	07.88-06.91		0 280 202 082	
			0 986 280 003	
Pulse generator, ignition/Jetronic	07.88-06.91		0 356 914 212	
Temperature sensor, coolant, injection system	07.88-06.91		0 280 130 026	
Wheel speed sensor, front	07.88-06.91	LAB	0 265 001 038	
		RAB	0 265 001 057	
Wheel speed sensor, rear	07.88-09.90		0 265 001 244	
Z 3 M 3.2 [E 36/7]	3,2l	236 kW	32 6S 1	6 Zyl.
Air mass meter, gasoline injection	11.96-12.00		0 280 217 806	
Knock sensor	11.96-12.00	MI	0 261 231 092	
Z 3 M 3.2 [E 36/7]	3,2l	239 kW	32 6S 4	6 Zyl.
Pedal position sensor, EMS (electronic engine management)	03.01-12.02		0 280 752 023	
Z 3 1.8 [E 36/7]	1,8l	85 kW	18 4E 2	4 Zyl.
Air flow sensor, gasoline injection	09.94-12.98	OKA	0 280 202 135	
Z 3 1.9 [E 36/7]	1,9l	87 kW	19 4E 1	4 Zyl.
Air mass meter, gasoline injection	09.98-12.02		0 280 217 124	
Z 3 1.9 [E 36/7]	1,9l	103 kW	19 4S 1	4 Zyl.
Air mass meter, gasoline injection	09.95-12.99		0 280 217 110	
Z 3 2.2i [E 36/7]	2,2l	125 kW	22 6S 1	6 Zyl.
Pedal position sensor, EMS (electronic engine management)	09.00-12.02		0 281 002 291	
Z 3 2.5i [E 36/7]	2,5l	141 kW	25 6S 5	6 Zyl.
Pedal position sensor, EMS (electronic engine management)	09.00-12.02		0 281 002 291	
Z 3 3.0i [E 36/7]	3,0l	170 kW	30 6S 3	6 Zyl.
Pedal position sensor, EMS (electronic engine management)	05.00-12.02		0 281 002 291	
Z 4 2.0i [E 85]	2,0l	110 kW	N46 B20...	4 Zyl.
Air mass meter, gasoline injection	03.05→	BFK	0 280 218 165	
		BHK	0 280 218 159	
Z 8 [E 52]	5,0l	294 kW	50 8S 1	8 Zyl.
Air mass meter, gasoline injection	03.00-07.03		0 280 217 533	
Knock sensor	03.00-07.03		0 261 231 200	
Duo sensor, acceleration and yaw rate, brake system	03.00-07.03		0 265 005 248	
Pressure sensor, ESP, (electronic stability program)	03.00-07.03		0 265 005 303	
Serie Z Coupé				
Z 3 M 3.2 [E 36/8]	3,2l	236 kW	32 6S 1/3	6 Zyl.
Air mass meter, gasoline injection	09.97-12.00		0 280 217 806	
Knock sensor	09.97-12.00	MI	0 261 231 092	
Z 3 M 3.2 [E 36/8]	3,2l	239 kW	32 6S 4	6 Zyl.
Pedal position sensor, EMS (electronic engine management)	03.01-12.02		0 280 752 023	
Z 3 3.0i [E 36/8]	3,0l	170 kW	30 6S 3	6 Zyl.
Pedal position sensor, EMS (electronic engine management)	05.00-12.02		0 281 002 291	





Serie 1			
116i [E 87]	1,6l 85 kW N45 B16A 4 Zyl.		
Air mass meter, gasoline injection	09.04-03.07		0 280 218 075
118d [E 81]	2,0l 100-105 kW N47 D20A 4 Zyl.		
Air mass meter, diesel	05.07→		0 281 002 567
118d [E 87]	2,0l 90 kW 20 4D 4 4 Zyl.		
Air mass meter, diesel	09.04-03.07		0 928 400 529
High-pressure sensor (CR system)	09.04-03.07		0 281 002 497
118d [E 87]	2,0l 100-105 kW N47 D20A 4 Zyl.		
Air mass meter, diesel	03.07→		0 281 002 567
118i [E 81]	2,0l 105 kW N43 B20A 4 Zyl.		
Air mass meter, gasoline injection	05.07→		0 280 218 159
118i [E 87]	2,0l 95 kW N46 B20B 4 Zyl.		
Air mass meter, gasoline injection	11.04-03.07	BFK	0 280 218 165
		BHK	0 280 218 159
118i [E 87]	2,0l 105 kW N43 B20A 4 Zyl.		
Air mass meter, gasoline injection	03.07→		0 280 218 159
120d [E 81]	2,0l 120-130 kW N47 D20A 4 Zyl.		
Air mass meter, diesel	05.07→		0 281 002 567
120d [E 87]	2,0l 120 kW 20 4D 4 4 Zyl.		
Air mass meter, diesel	09.04-03.07		0 928 400 529
High-pressure sensor (CR system)	09.04-03.07		0 281 002 497
120d [E 87]	2,0l 120-130 kW N47 D20A 4 Zyl.		
Air mass meter, diesel	03.07→		0 281 002 567
120i [E 81]	2,0l 115 kW N46 B20... 4 Zyl.		
Air mass meter, gasoline injection	05.07→	BHK	0 280 218 159
120i [E 81]	2,0l 120-125 kW N43 B20A 4 Zyl.		
Air mass meter, gasoline injection	05.07→		0 280 218 159
120i [E 87]	2,0l 110 kW N46 B20... 4 Zyl.		
Air mass meter, gasoline injection	09.04-03.07	BFK	0 280 218 165
		BHK	0 280 218 159
120i [E 87]	2,0l 115 kW N46 B20... 4 Zyl.		
Air mass meter, gasoline injection	03.07→	BHK	0 280 218 159
120i [E 87]	2,0l 120-125 kW N43 B20A 4 Zyl.		
Air mass meter, gasoline injection	03.07→		0 280 218 159
123d [E 81]	2,0l 150 kW N47 D20B 4 Zyl.		
Air mass meter, diesel	09.07→		0 281 002 567
123d [E 87]	2,0l 150 kW N47 D20B 4 Zyl.		
Air mass meter, diesel	09.07→		0 281 002 567

Serie 1 Coupé			
120d [E 82]	2,0l 130 kW N47 D20A 4 Zyl.		
Air mass meter, diesel	10.07→		0 281 002 567
123d [E 82]	2,0l 150 kW N47 D20B 4 Zyl.		
Air mass meter, diesel	10.07→		0 281 002 567

Serie 3			
316 [E 30]	1,8l 66 kW 18 4V D 4 Zyl.		
Temperature sensor, coolant, injection system	09.83-12.88		0 280 130 026
Wheel speed sensor	09.82-12.88	HI	0 265 001 059
		LAB,VO	0 265 001 058
		RAB,VO	0 265 001 057
316i [E 30]	1,6l 73-75 kW 16 4E 1 4 Zyl.		
Throttle valve sensor	09.88-12.91		0 280 120 316
Air flow sensor, gasoline injection	09.88-12.91	KAT	0 280 200 204
			0 986 280 029
		LLP,OKA	0 280 200 205
			0 986 280 040
Speed sensor, ignition/injection	09.88-03.89		0 261 210 035



Pulse generator, ignition/Jetronic	09.88-08.90		0 356 914 212
	09.90-12.91		0 356 914 220
Temperature sensor, coolant, injection system	09.88-12.91		0 280 130 026
Wheel speed sensor	09.88-12.91	HI	0 265 001 059
		LAB,VO	0 265 001 058
		RAB,VO	0 265 001 057
316i [E 30]	1,8l 75 kW 18 4K A 4 Zyl.		
Throttle valve sensor	09.87-12.88		0 280 120 320
Air flow sensor, gasoline injection	09.87-12.88		0 280 202 039
			0 986 280 001
Pressure sensor, intake manifold, gasoline	09.87-12.88	AG	0 280 101 001
		VFA	0 280 101 005
Temperature sensor, coolant, injection system	09.87-12.88		0 280 130 023
Wheel speed sensor	09.87-12.88	HI	0 265 001 059
		LAB,VO	0 265 001 058
		RAB,VO	0 265 001 057
316i [E 36]	1,6l 73-75 kW 16 4E 1 4 Zyl.		
Air flow sensor, gasoline injection	09.90-02.94	KAT	0 280 200 204
			0 986 280 029
		LLP,OKA	0 280 200 205
			0 986 280 040
Temperature sensor, coolant, injection system	09.90-02.94		0 280 130 026
316i [E 36]	1,6l 75 kW 16 4E 2 4 Zyl.		
Air flow sensor, gasoline injection	09.93-12.98	KAT	0 280 200 204
			0 986 280 029
		LLP,OKA	0 280 200 205
			0 986 280 040
Knock sensor	09.93-09.95		0 261 231 097
Temperature sensor, coolant, injection system	09.93-09.95		0 280 130 026
316i [E 36]	1,8l 85 kW 18 4E 1 4 Zyl.		
Air flow sensor, gasoline injection	10.91-10.94	OKA	0 280 202 135
Temperature sensor, coolant, injection system	10.91-10.94		0 280 130 026
316i [E 46]	1,6l 75 kW 16 4E 3 4 Zyl.		
Air mass meter, gasoline injection	04.98-09.02		0 280 217 124
316i [E 46]	1,6l 85 kW N40 B16A; N45 B16A 4 Zyl.		
Air mass meter, gasoline injection	03.02-03.05		0 280 218 075
316i [E 46]	1,8l 85 kW N42 B18A; N46 B18A 4 Zyl.		
Air mass meter, gasoline injection	02.02-03.05		0 280 218 075
316i [E 46]	1,9l 77 kW 19 4E 1 4 Zyl.		
Air mass meter, gasoline injection	04.98-09.02		0 280 217 124
316i [E 90]	1,6l 85 kW N45 B16A 4 Zyl.		
Air mass meter, gasoline injection	09.05→		0 280 218 075
318d [E 46]	2,0l 85 kW 20 4D 1 4 Zyl.		
Air mass meter, diesel	09.01-03.03	UPE	0 928 400 527
318d [E 46]	2,0l 85 kW 20 4D 4 4 Zyl.		
Air mass meter, diesel	03.03-03.05	EU3,UPE	0 928 400 527
		EU4	0 928 400 529
High-pressure sensor (CR system)	03.03-03.05		0 281 002 497
318d [E 90]	2,0l 90 kW 20 4D 4 4 Zyl.		
Air mass meter, diesel	09.05→		0 928 400 529
High-pressure sensor (CR system)	09.05→		0 281 002 497
318i [E 30]	1,8l 75-77 kW 18 4K A 4 Zyl.		
Throttle valve sensor	01.86-12.87		0 280 120 320
Air flow sensor, gasoline injection	10.84-12.87		0 280 202 039
			0 986 280 001
Pressure sensor, intake manifold, gasoline	10.84-12.87	AG	0 280 101 001
	12.84-12.87	VFA	0 280 101 005
Temperature sensor, coolant, injection system	10.84-12.87		0 280 130 023
Relay, pump	10.84-12.87	TW	0 280 230 001
Wheel speed sensor	10.84-12.87	HI	0 265 001 059
		LAB,VO	0 265 001 058
		RAB,VO	0 265 001 057



Product

◀ Serie 3

318 i [E 30]		1,8l 77 kW	18 4E B 4 Zyl.
Throttle valve sensor	07.82-12.87		0 280 120 320
	01.86-12.87		0 280 120 320
Air flow sensor, gasoline injection	07.82-12.87		0 280 202 050
			0 986 280 005
Temperature sensor, coolant, injection system	09.83-12.87		0 280 130 023
Relay, pump	07.82-12.87	TW	0 280 230 001
Wheel speed sensor	09.83-12.87	HI	0 265 001 059
		LAB,VO	0 265 001 058
		RAB,VO	0 265 001 057
318 i [E 30]		1,8l 83-85 kW	18 4E 1 4 Zyl.
Throttle valve sensor	09.87-12.91		0 280 120 316
Air flow sensor, gasoline injection	09.87-12.91	OKA	0 280 202 135
Speed sensor, ignition/injection	09.87-03.89		0 261 210 035
Pulse generator, ignition/Jetronic	09.87-08.90		0 356 914 212
	09.90-12.91		0 356 914 220
Temperature sensor, coolant, injection system	09.87-12.91		0 280 130 026
Wheel speed sensor	09.87-12.91	HI	0 265 001 059
		LAB,VO	0 265 001 058
		RAB,VO	0 265 001 057
318 i [E 36]		1,8l 83-85 kW	18 4E 1 4 Zyl.
Air flow sensor, gasoline injection	12.90-02.94	LLP,OKA	0 280 202 135
Temperature sensor, coolant, injection system	12.90-02.94		0 280 130 026
318 i [E 36]		1,8l 85 kW	18 4E 2 4 Zyl.
Air flow sensor, gasoline injection	09.93-12.98	LLP,OKA	0 280 202 135
	11.92-10.98	OKA	0 280 202 135
Knock sensor	11.92-09.95		0 261 231 097
Temperature sensor, coolant, injection system	09.93-09.95		0 280 130 026
Relay, Jetronic	11.92-10.98		0 332 019 456
318 i [E 36]		1,8l 103 kW	18 4S 1 4 Zyl.
Air flow sensor, gasoline injection	03.92-10.96	LLP,OKA	0 280 202 135
	11.92-10.96	OKA	0 280 202 135
Knock sensor	03.92-10.96		0 261 231 072
Temperature sensor, coolant, injection system	03.92-09.95		0 280 130 026
	11.92-10.96		0 280 130 026
318 i [E 36]		1,9l 103 kW	19 4S 1 4 Zyl.
Air mass meter, gasoline injection	09.95-12.98		0 280 217 110
318 i [E 46]		1,9l 87 kW	19 4E 1 4 Zyl.
Air mass meter, gasoline injection	04.98-09.01		0 280 217 124
318 i [E 46]		2,0l 105 kW N42 B20A; N46 B20...	4 Zyl.
Air mass meter, gasoline injection	09.01-03.05		0 280 218 075
318 i [E 90]		2,0l 95 kW N46 B20B	4 Zyl.
Air mass meter, gasoline injection	09.05→	BFK	0 280 218 165
		BHK	0 280 218 159
318 is [E 30]		1,8l 100 kW	18 4S 1 4 Zyl.
Air flow sensor, gasoline injection	09.89-12.91	OKA	0 280 202 135
Phase sensor	09.89-12.91	NOC	0 261 210 058
Speed sensor, ignition/injection	09.89-12.91	FKW	0 261 210 057
Temperature sensor, coolant, injection system	09.89-12.91		0 280 130 026
Wheel speed sensor	09.89-12.91	HI	0 265 001 059
		LAB,VO	0 265 001 058
		RAB,VO	0 265 001 057
318 is [E 36]		1,8l 103 kW	18 4S 1 4 Zyl.
Air flow sensor, gasoline injection	03.93-12.96	LLP,OKA	0 280 202 135
Knock sensor	03.93-12.96		0 261 231 072
Temperature sensor, coolant, injection system	03.93-09.95		0 280 130 026
318 is [E 36]		1,9l 103 kW	19 4S 1 4 Zyl.
Air mass meter, gasoline injection	03.95-12.98		0 280 217 110
318 tds [E 36]		1,7l 66 kW	17 4T 1 4 Zyl.
Pedal position sensor, diesel	10.94-03.98		0 205 001 040
320 d [E 46]		2,0l 100 kW	20 4D 1 4 Zyl.
Air mass meter, diesel	11.00-09.01	UPE	0 928 400 527
Pedal position sensor, diesel	04.98-09.01		0 205 001 040

Product


320 d [E 46]		2,0l 110 kW 20 4D 4 4 Zyl.	
Air mass meter, diesel	09.01-03.05	EU3,UPE	0 928 400 527
		EU4	0 928 400 529
High-pressure sensor (CR system)	09.01-03.05		0 281 002 497
320 d [E 90]		2,0l 110/120 kW 20 4D 4 4 Zyl.	
Air mass meter, diesel	03.05→		0 928 400 529
High-pressure sensor (CR system)	03.05→		0 281 002 497
320 i [E 30]		2,0l 90-95 kW 20 6E E/K A 6 Zyl.	
Throttle valve sensor	12.85-12.91	AG	0 280 120 402
		GS	0 280 120 321
Air flow sensor, gasoline injection	09.86-12.91		0 280 202 083
			0 986 280 009
Speed sensor, ignition/injection	12.85-09.87		0 261 210 028
	12.86-03.89		0 261 210 035
Pulse generator, ignition/Jetronic	12.86-08.90		0 356 914 212
	09.90-12.91		0 356 914 220
Temperature sensor, coolant, injection system	12.85-12.91		0 280 130 026
Relay, pump	12.85-12.91	TW	0 280 230 001
Wheel speed sensor	12.85-12.91	HI	0 265 001 059
		LAB,VO	0 265 001 058
		RAB,VO	0 265 001 057
320 i [E 30]		2,0l 92-95 kW 20 6E B/Z 6 Zyl.	
Throttle valve sensor	01.86-09.87		0 280 120 319
Air flow sensor, gasoline injection	10.85-09.87		0 280 202 090
			0 986 280 068
Speed sensor, ignition/injection	09.82-09.87		0 261 210 028
Temperature sensor, coolant, injection system	10.84-09.87		0 280 130 026
Relay, pump	09.82-09.87	TW	0 280 230 001
Wheel speed sensor	09.82-09.87	HI	0 265 001 059
		LAB,VO	0 265 001 058
		RAB,VO	0 265 001 057
320 i [E 36]		2,0l 95 kW 20 6S 1/2 6 Zyl.	
Temperature sensor, coolant, injection system	10.91-01.93		0 280 130 026
320 i [E 36]		2,0l 110 kW 20 6S 1/2 6 Zyl.	
Air mass meter, gasoline injection	09.90-09.92	BO	0 280 212 025
			0 986 280 111
			0 986 280 130
Phase sensor	09.90-09.92	BOM,NOC	0 261 210 053
Temperature sensor, intake air, injection system	09.90-12.95		0 280 130 039
Temperature sensor, coolant, injection system	09.90-09.92		0 280 130 026
320 i [E 90]		2,0l 110 kW N46 B20... 4 Zyl.	
Air mass meter, gasoline injection	03.05-03.07	BFK	0 280 218 165
	03.05→	BHK	0 280 218 159
320 is [E 30]		2,0l 141 kW 20 4E A 4 Zyl.	
Throttle valve sensor	01.88-12.90		0 280 120 301
Air flow sensor, gasoline injection	01.88-12.90		0 280 203 028
			0 986 280 049
Speed sensor, ignition/injection	01.88-12.90		0 261 210 002
Pressure sensor, intake manifold, gasoline	01.88-12.90		0 280 101 001
Temperature sensor, coolant, injection system	01.88-12.90		0 280 130 026
Wheel speed sensor	01.88-12.90	HI	0 265 001 059
		LAB,VO	0 265 001 058
		RAB,VO	0 265 001 057
320 si [E 90]		2,0l 127 kW N45 B20A 4 Zyl.	
Air mass meter, gasoline injection	03.06-09.06	BFK	0 280 218 165
		BHK	0 280 218 159
323 i [E 30]		2,3l 102-110 kW 23 6E B/C/W 6 Zyl.	
Throttle valve sensor	09.82-12.86		0 280 120 301
Air flow sensor, gasoline injection	10.85-12.86		0 280 202 090
			0 986 280 068
Temperature sensor, coolant, injection system	09.84-12.86		0 280 130 026
Relay, pump	09.82-12.86	TW	0 280 230 001



Wheel speed sensor	09.82-12.86	HI	0 265 001 059
		LAB,VO	0 265 001 058
		RAB,VO	0 265 001 057
324 d [E 30]	2,4l 63 kW 24 6D A/B 6 Zyl.		
Pressure sensor, intake manifold, diesel	09.88-12.90		0 281 002 018
Temperature sensor, coolant, diesel	09.88-12.90		0 280 130 055
Temperature sensor, intake air, diesel	09.88-12.90		0 280 130 039
Pedal position sensor, diesel	09.88-12.90		0 132 009 316
Wheel speed sensor	09.85-12.90	HI	0 265 001 059
		LAB,VO	0 265 001 058
		RAB,VO	0 265 001 057
324 td [E 30]	2,4l 85 kW 24 6T B 6 Zyl.		
Pressure sensor, intake manifold, diesel	09.87-12.90		0 281 002 018
Temperature sensor, coolant, diesel	09.87-12.90		0 280 130 055
Temperature sensor, intake air, diesel	09.87-12.90		0 280 130 039
Pedal position sensor, diesel	09.87-12.90		0 132 009 315
Wheel speed sensor	09.87-12.90	HI	0 265 001 059
		LAB,VO	0 265 001 058
		RAB,VO	0 265 001 057
325 d [E 90]	3,0l 145 kW 30 6D 3 6 Zyl.		
Air mass meter, diesel	09.06→		0 928 400 529
325 e [E 30]	2,7l 90 kW 6 Zyl.		
Throttle valve sensor	01.86-12.88		0 280 120 319
	12.86-12.88	AG	0 280 120 404
Air flow sensor, gasoline injection	12.86-12.88		0 280 202 083
			0 986 280 009
	09.84-11.86		0 280 202 091
			0 986 280 006
Speed sensor, ignition/injection	01.86-11.86		0 261 210 002
	12.86-12.88		0 261 210 035
Pulse generator, ignition/Jetronic	12.86-12.88		0 356 914 212
Pressure sensor, intake manifold, gasoline	10.83-12.88		0 280 101 001
Temperature sensor, coolant, injection system	09.84-12.88		0 280 130 026
Wheel speed sensor	10.83-12.88	HI	0 265 001 059
		LAB,VO	0 265 001 058
		RAB,VO	0 265 001 057
325 e [E 30]	2,7l 90-95 kW 27 6K A/B 6 Zyl.		
Throttle valve sensor	01.85-11.86		0 280 120 301
	12.86-12.87		0 280 120 319
		AG	0 280 120 404
Air flow sensor, gasoline injection	09.86-12.87		0 280 202 083
			0 986 280 009
	09.85-08.86		0 280 202 091
			0 986 280 006
Speed sensor, ignition/injection	01.85-11.86		0 261 210 001
Pulse generator, ignition/Jetronic	12.86-12.87		0 356 914 212
Pressure sensor, intake manifold, gasoline	01.85-11.86		0 280 101 001
Temperature sensor, coolant, injection system	01.85-12.87		0 280 130 026
Wheel speed sensor	01.85-12.87	HI	0 265 001 059
		LAB,VO	0 265 001 058
		RAB,VO	0 265 001 057
325 i [E 30]	2,5l 125 kW 25 6K 1 6 Zyl.		
Throttle valve sensor	12.86-12.91	AG	0 280 120 402
		GS	0 280 120 321
Air flow sensor, gasoline injection	12.86-12.91		0 280 202 082
			0 986 280 003
		TRO	0 280 202 092
Speed sensor, ignition/injection	12.86-09.87		0 261 210 028
Pulse generator, ignition/Jetronic	12.86-12.91		0 356 914 212
Temperature sensor, coolant, injection system	12.86-12.91		0 280 130 026
Wheel speed sensor	12.86-12.91	HI	0 265 001 059
		LAB,VO	0 265 001 058
		RAB,VO	0 265 001 057



325 i [E 30]	2,5l 126 kW 25 6E 1/2 6 Zyl.		
Throttle valve sensor	01.86-12.91		0 280 120 321
	09.85-12.91	AG	0 280 120 402
Air flow sensor, gasoline injection	09.85-12.91		0 280 202 082
			0 986 280 003
		TRO	0 280 202 092
Speed sensor, ignition/injection	09.85-09.87		0 261 210 028
Temperature sensor, coolant, injection system	09.85-12.91		0 280 130 026
Wheel speed sensor	09.85-12.91	HI	0 265 001 059
		LAB,VO	0 265 001 058
		RAB,VO	0 265 001 057
325 i [E 36]	2,5l 138 kW 25 6S 1/2 6 Zyl.		
Air mass meter, gasoline injection	04.91-02.93		0 280 213 011
			0 986 280 116
Phase sensor	07.93-08.95		0 261 210 053
Temperature sensor, coolant, injection system	04.91-08.95		0 280 130 026
325 i [E 36]	2,5l 141 kW 25 6S 1/2 6 Zyl.		
Air mass meter, gasoline injection	09.90-09.92		0 280 213 011
			0 986 280 116
	10.92-12.95		0 280 217 502
Phase sensor	09.90-09.92	BOM,NOC	0 261 210 053
	10.92-12.95	NOC	0 232 103 003
Temperature sensor, intake air, injection system	09.90-12.95		0 280 130 039
Temperature sensor, coolant, injection system	09.90-09.95		0 280 130 026
325 ix [E 30]	2,5l 125 kW 25 6K 1 6 Zyl.		
Throttle valve sensor	12.86-12.91	AG	0 280 120 402
		GS	0 280 120 321
Air flow sensor, gasoline injection	12.86-12.91		0 280 202 082
			0 986 280 003
Pulse generator, ignition/Jetronic	12.86-12.91		0 356 914 212
Temperature sensor, coolant, injection system	12.86-12.91		0 280 130 026
Acceleration sensor, ABS	12.86-12.91		0 265 005 003
Wheel speed sensor	12.86-12.91	HI	0 265 001 059
		VO	0 265 001 113
325 ix [E 30]	2,5l 126 kW 25 6E 1/2 6 Zyl.		
Throttle valve sensor	03.86-12.91		0 280 120 321
		AG	0 280 120 402
Air flow sensor, gasoline injection	03.86-12.91		0 280 202 082
			0 986 280 003
		TRO	0 280 202 092
Speed sensor, ignition/injection	03.86-09.87		0 261 210 028
Temperature sensor, coolant, injection system	03.86-12.91		0 280 130 026
Acceleration sensor, ABS	03.86-12.91		0 265 005 003
Wheel speed sensor	03.86-12.91	HI	0 265 001 059
		VO	0 265 001 113
325 td [E 36]	2,5l 85 kW 25 6T 1 6 Zyl.		
Pressure sensor, intake manifold, diesel	09.91-09.92		0 281 002 063
Temperature sensor, coolant, diesel	09.91-01.96		0 280 130 055
Pedal position sensor, diesel	09.91-12.98		0 205 001 040
325 tds [E 36]	2,5l 105 kW 25 6T 1 6 Zyl.		
Temperature sensor, coolant, diesel	05.93-01.96		0 280 130 055
Pedal position sensor, diesel	05.93-12.98		0 205 001 040
325 xi [E 46]	2,5l 141 kW 25 6S 5 6 Zyl.		
Duo sensor, acceleration and yaw rate, brake system	09.00-03.05		0 265 005 248
325 xi [E 90]	2,5l 160 kW N52 B25A 6 Zyl.		
Duo sensor, acceleration and yaw rate, brake system	09.05→		0 265 005 678
Wheel speed sensor, front	09.05→		0 265 007 669
Wheel speed sensor, rear	09.05→		0 265 007 670
330 d [E 46]	3,0l 135 kW 30 6D 1 6 Zyl.		
Air mass meter, diesel	02.01-03.03	UPE	0 928 400 527
High-pressure sensor (CR system)	10.99-03.03		0 281 002 475



Product				
◀ Serie 3				
330 d [E 46]	3,0l	150 kW	30 6D 2	6 Zyl.
Air mass meter, diesel	03.03-03.05		0 928 400 529	
High-pressure sensor (CR system)	03.03-03.05		0 281 002 497	
330 d [E 90]	3,0l	170 kW	30 6D 3	6 Zyl.
Air mass meter, diesel	09.05→		0 928 400 529	
High-pressure sensor (CR system)	09.05→		0 281 002 497	
330 xd [E 46]	3,0l	135 kW	30 6D 1	6 Zyl.
Air mass meter, diesel	02.01-03.03	UPE	0 928 400 527	
High-pressure sensor (CR system)	07.00-03.03		0 281 002 475	
Duo sensor, acceleration and yaw rate, brake system	07.00-03.03		0 265 005 248	
330 xd [E 46]	3,0l	150 kW	30 6D 2	6 Zyl.
Air mass meter, diesel	03.03-03.05		0 928 400 529	
High-pressure sensor (CR system)	03.03-03.05		0 281 002 497	
Duo sensor, acceleration and yaw rate, brake system	03.03-03.05		0 265 005 248	
330 xd [E 90]	3,0l	170 kW	30 6D 3	6 Zyl.
Air mass meter, diesel	09.05→		0 928 400 529	
High-pressure sensor (CR system)	09.05→		0 281 002 497	
Duo sensor, acceleration and yaw rate, brake system	09.05→		0 265 005 678	
Wheel speed sensor, front	09.05→		0 265 007 669	
Wheel speed sensor, rear	09.05→		0 265 007 670	
330 xi [E 46]	3,0l	170 kW	30 6S 3	6 Zyl.
Duo sensor, acceleration and yaw rate, brake system	07.00-03.05		0 265 005 248	
330 xi [E 90]	3,0l	190 kW	N52 B30A	6 Zyl.
Duo sensor, acceleration and yaw rate, brake system	09.05→		0 265 005 678	
Wheel speed sensor, front	09.05→		0 265 007 669	
Wheel speed sensor, rear	09.05→		0 265 007 670	
335 d [E 90]	3,0l	210 kW	30 6D 5	6 Zyl.
Air mass meter, diesel	09.06-02.07		0 281 002 849	
335 xi [E 90]	3,0l	225 kW	N54 B30A	6 Zyl.
Duo sensor, acceleration and yaw rate, brake system	03.07→		0 265 005 678	
Wheel speed sensor, front	03.07→		0 265 007 669	
Wheel speed sensor, rear	03.07→		0 265 007 670	
Serie 3 Cabrio				
318 Ci [E 46]	2,0l	105-110 kW	N42 B20A; N46 B20...	4 Zyl.
Air mass meter, gasoline injection	09.01-03.07		0 280 218 075	
318 i [E 30]	1,8l	83 kW	18 4E 1	4 Zyl.
Throttle valve sensor	09.90-12.93		0 280 120 316	
Air flow sensor, gasoline injection	09.90-12.93	OKA	0 280 202 135	
Pulse generator, ignition/Jetronic	09.90-12.93		0 356 914 220	
Temperature sensor, coolant, injection system	09.90-12.93		0 280 130 026	
Wheel speed sensor	09.90-12.93	HI	0 265 001 059	
		LAB,VO	0 265 001 058	
		RAB,VO	0 265 001 057	
318 i [E 30]	1,8l	103 kW	18 4S 1	4 Zyl.
Phase sensor	07.90-12.92	NOC	0 261 210 058	
Speed sensor, ignition/injection	07.90-12.92	FKW	0 261 210 057	
Temperature sensor, coolant, injection system	07.90-12.92		0 280 130 026	
Wheel speed sensor	07.90-12.92	HI	0 265 001 059	
		LAB,VO	0 265 001 058	
		RAB,VO	0 265 001 057	
318 i [E 36]	1,8l	83-85 kW	18 4E 2	4 Zyl.
Air flow sensor, gasoline injection	01.94-12.99	LLP,OKA	0 280 202 135	
Knock sensor	01.94-09.95		0 261 231 097	
Temperature sensor, coolant, injection system	01.94-09.95		0 280 130 026	

Product				
318 i [E 36]	1,8l	103 kW	18 4S 1	4 Zyl.
Knock sensor	09.93-09.96		0 261 231 072	
Temperature sensor, coolant, injection system	09.93-09.95		0 280 130 026	
318 i [E 36]	1,9l	103 kW	19 4S 1	4 Zyl.
Air mass meter, gasoline injection	09.95-12.98		0 280 217 110	
320 Cd [E 46]	2,0l	110 kW	20 4D 4	4 Zyl.
Air mass meter, diesel	01.05-03.07	EU3,UPE	0 928 400 527	
		EU4	0 928 400 529	
High-pressure sensor (CR system)	01.05-03.07		0 281 002 497	
320 i [E 30]	2,0l	92-95 kW	20 6E B	6 Zyl.
Throttle valve sensor	04.86-09.87		0 280 120 319	
Air flow sensor, gasoline injection	04.86-09.87		0 280 202 090	
			0 986 280 068	
Speed sensor, ignition/injection	04.86-09.87		0 261 210 028	
Temperature sensor, coolant, injection system	04.86-09.87		0 280 130 026	
Relay, pump	04.86-09.87	TW	0 280 230 001	
Wheel speed sensor	04.86-09.87	HI	0 265 001 059	
		LAB,VO	0 265 001 058	
		RAB,VO	0 265 001 057	
320 i [E 30]	2,0l	95 kW	20 6E E/K A	6 Zyl.
Throttle valve sensor	04.86-12.93	AG	0 280 120 402	
		GS	0 280 120 321	
Air flow sensor, gasoline injection	09.86-12.93		0 280 202 083	
			0 986 280 009	
Speed sensor, ignition/injection	04.86-09.87		0 261 210 028	
	12.86-03.89		0 261 210 035	
Pulse generator, ignition/Jetronic	12.86-08.90		0 356 914 212	
	09.90-12.93		0 356 914 220	
Temperature sensor, coolant, injection system	04.86-12.93		0 280 130 026	
Relay, pump	04.86-12.93	TW	0 280 230 001	
Wheel speed sensor	04.86-12.93	HI	0 265 001 059	
		LAB,VO	0 265 001 058	
		RAB,VO	0 265 001 057	
320 i [E 93]	2,0l	115 kW	N46 B20B	4 Zyl.
Air mass meter, gasoline injection	03.07→	BHK	0 280 218 159	
320 i [E 93]	2,0l	120-125 kW	N43 B20A	4 Zyl.
Air mass meter, gasoline injection	03.07→		0 280 218 159	
325 i [E 30]	2,5l	125 kW	25 6K 1	6 Zyl.
Throttle valve sensor	12.86-12.92	AG	0 280 120 402	
		GS	0 280 120 321	
Air flow sensor, gasoline injection	12.86-12.92		0 280 202 082	
			0 986 280 003	
Speed sensor, ignition/injection	12.86-09.87		0 261 210 028	
Pulse generator, ignition/Jetronic	12.86-12.92		0 356 914 212	
Temperature sensor, coolant, injection system	12.86-12.92		0 280 130 026	
Wheel speed sensor	12.86-12.92	HI	0 265 001 059	
		LAB,VO	0 265 001 058	
		RAB,VO	0 265 001 057	
325 i [E 30]	2,5l	126 kW	25 6E 1/2	6 Zyl.
Throttle valve sensor	01.86-12.92		0 280 120 321	
	09.85-12.92	AG	0 280 120 402	
Air flow sensor, gasoline injection	09.85-12.92		0 280 202 082	
			0 986 280 003	
		TRO	0 280 202 092	
Speed sensor, ignition/injection	09.85-09.87		0 261 210 028	
Temperature sensor, coolant, injection system	09.85-12.92		0 280 130 026	
Wheel speed sensor	09.85-12.92	HI	0 265 001 059	
		LAB,VO	0 265 001 058	
		RAB,VO	0 265 001 057	
325 i [E 36]	2,5l	141 kW	25 6S 2	6 Zyl.
Air mass meter, gasoline injection	03.93-12.95		0 280 217 502	
Phase sensor	03.93-12.95	NOC	0 232 103 003	
Temperature sensor, coolant, injection system	03.93-09.95		0 280 130 026	





330 Cd [E 46]	3,0l 150 kW 30 6D 2 6 Zyl.
Air mass meter, diesel	04.05-03.07 0 928 400 529
High-pressure sensor (CR system)	04.05-03.07 0 281 002 497
330 d [E 93]	3,0l 170 kW 30 6D 3 6 Zyl.
Air mass meter, diesel	03.07→ 0 928 400 529
High-pressure sensor (CR system)	03.07→ 0 281 002 497

Serie 3 Compact


316 g [E 36]	1,6l 64-75 kW 16 4E 2 4 Zyl.
Air flow sensor, gasoline injection	11.95-09.00 KAT 0 280 200 204 0 986 280 029 LLP,OKA 0 280 200 205 0 986 280 040
316 i [E 36]	1,6l 75 kW 16 4E 2 4 Zyl.
Air flow sensor, gasoline injection	03.94-09.00 KAT 0 280 200 204 0 986 280 029 LLP,OKA 0 280 200 205 0 986 280 040
Knock sensor	03.94-09.95 0 261 231 097
Temperature sensor, coolant, injection system	03.94-09.95 0 280 130 026
316 i [E 36]	1,9l 77 kW 19 4E 1 4 Zyl.
Air mass meter, gasoline injection	12.98-09.00 0 280 217 124
316 ti [E 46]	1,6l 85 kW N40 B16A; N45 B16A 4 Zyl.
Air mass meter, gasoline injection	03.02-12.04 0 280 218 075
316 ti [E 46]	1,8l 85 kW N42 B18A; N46 B18A 4 Zyl.
Air mass meter, gasoline injection	06.01-12.04 0 280 218 075
318 td [E 46]	2,0l 85 kW 20 4D 4 4 Zyl.
Air mass meter, diesel	03.03-12.04 EU3,UPE 0 928 400 527 EU4 0 928 400 529
High-pressure sensor (CR system)	03.03-12.04 0 281 002 497
318 tds [E 36]	1,7l 66 kW 17 4T 1 4 Zyl.
Pedal position sensor, diesel	01.95-09.00 0 205 001 040
318 ti [E 36]	1,8l 103 kW 18 4S 1 4 Zyl.
Air flow sensor, gasoline injection	10.94-09.96 LLP,OKA 0 280 202 135
Knock sensor	10.94-09.96 0 261 231 072
Temperature sensor, coolant, injection system	10.94-09.95 0 280 130 026
318 ti [E 36]	1,9l 103 kW 19 4S 1 4 Zyl.
Air mass meter, gasoline injection	12.95-09.00 0 280 217 110
Temperature sensor, intake air, injection system	12.95-09.00 0 280 130 039
318 ti [E 46]	2,0l 105 kW N42 B20A; N46 B20... 4 Zyl.
Air mass meter, gasoline injection	09.01-12.04 0 280 218 075
320 td [E 46]	2,0l 110 kW 20 4D 4 4 Zyl.
Air mass meter, diesel	09.01-12.04 EU3,UPE 0 928 400 527 EU4 0 928 400 529
High-pressure sensor (CR system)	09.01-12.04 0 281 002 497

Serie 3 Coupé

316 Ci [E 46]	1,6l 75 kW 16 4E 3 4 Zyl.
Air mass meter, gasoline injection	10.99-09.02 0 280 217 124
316 Ci [E 46]	1,6l 85 kW N40 B16A; N45 B16A 4 Zyl.
Air mass meter, gasoline injection	03.02-09.06 0 280 218 075
316 i [E 36]	1,6l 75 kW 16 4E 2 4 Zyl.
Air flow sensor, gasoline injection	09.93-12.99 KAT 0 280 200 204 0 986 280 029 LLP,OKA 0 280 200 205 0 986 280 040
Knock sensor	09.93-09.95 0 261 231 097
Temperature sensor, coolant, injection system	09.93-09.95 0 280 130 026
318 Ci [E 46]	1,9l 87 kW 19 4E 1 4 Zyl.
Air mass meter, gasoline injection	04.99-09.01 0 280 217 124




318 Ci [E 46]	2,0l 105-110 kW N42 B20A; N46 B20... 4 Zyl.
Air mass meter, gasoline injection	09.01-09.06 0 280 218 075
318 is [E 36]	1,8l 103 kW 18 4S 1 4 Zyl.
Air flow sensor, gasoline injection	03.92-09.96 LLP,OKA 0 280 202 135
Knock sensor	03.92-09.96 0 261 231 072
Temperature sensor, coolant, injection system	03.92-09.95 0 280 130 026
318 is [E 36]	1,9l 103 kW 19 4S 1 4 Zyl.
Air mass meter, gasoline injection	12.95-12.99 0 280 217 110
320 Cd [E 46]	2,0l 110 kW 20 4D 4 4 Zyl.
Air mass meter, diesel	09.03-09.06 EU3,UPE 0 928 400 527 EU4 0 928 400 529
High-pressure sensor (CR system)	09.03-09.06 0 281 002 497
320 d [E 92]	2,0l 130 kW N47 D20A 4 Zyl.
Air mass meter, diesel	03.07→ 0 281 002 567
320 i [E 36]	2,0l 110 kW 20 6S 1/2 6 Zyl.
Air mass meter, gasoline injection	03.92-09.92 BO 0 280 212 025 0 986 280 111 0 986 280 130
Phase sensor	03.92-09.92 BOM,NOC 0 261 210 053
Temperature sensor, intake air, injection system	03.92-12.95 0 280 130 039
320 i [E 92]	2,0l 115 kW N46 B20B 4 Zyl.
Air mass meter, gasoline injection	03.07→ BHK 0 280 218 159
320 i [E 92]	2,0l 125 kW N43 B20A 4 Zyl.
Air mass meter, gasoline injection	03.07→ 0 280 218 159
325 d [E 92]	3,0l 145 kW 30 6D 3 6 Zyl.
Air mass meter, diesel	03.07→ 0 928 400 529
325 i [E 36]	2,5l 141 kW 25 6S 1/2 6 Zyl.
Air mass meter, gasoline injection	03.92-09.92 0 280 213 011 0 986 280 116
	10.92-12.95 0 280 217 502
Phase sensor	03.92-09.92 BOM,NOC 0 261 210 053 10.92-12.95 NOC 0 232 103 003
Temperature sensor, intake air, injection system	03.92-12.95 0 280 130 039
Temperature sensor, coolant, injection system	03.92-09.95 0 280 130 026
325 is [E 36]	2,5l 141 kW 25 6S 1/2 6 Zyl.
Air mass meter, gasoline injection	03.91-09.92 0 280 213 011 0 986 280 116
	10.92-12.95 0 280 217 502
Phase sensor	03.91-09.92 BOM,NOC 0 261 210 053 10.92-12.95 NOC 0 232 103 003
Temperature sensor, coolant, injection system	03.91-09.95 0 280 130 026
325 xi [E 92]	2,5l 160 kW N52 B25A 6 Zyl.
Duo sensor, acceleration and yaw rate, brake system	09.06→ 0 265 005 678
Wheel speed sensor, front	09.06→ 0 265 007 669
Wheel speed sensor, rear	09.06→ 0 265 007 670
330 Cd [E 46]	3,0l 150 kW 30 6D 2 6 Zyl.
Air mass meter, diesel	03.03-09.06 0 928 400 529
High-pressure sensor (CR system)	03.03-09.06 0 281 002 497
330 d [E 92]	3,0l 170 kW 30 6D 3 6 Zyl.
Air mass meter, diesel	09.06→ 0 928 400 529
330 xd [E 92]	3,0l 170 kW 30 6D 3 6 Zyl.
Air mass meter, diesel	09.06→ 0 928 400 529
Duo sensor, acceleration and yaw rate, brake system	09.06→ 0 265 005 678
Wheel speed sensor, front	09.06→ 0 265 007 669
Wheel speed sensor, rear	09.06→ 0 265 007 670
330 xi [E 92]	3,0l 200 kW N52 B30A 6 Zyl.
Duo sensor, acceleration and yaw rate, brake system	09.06→ 0 265 005 678
Wheel speed sensor, front	09.06→ 0 265 007 669
Wheel speed sensor, rear	09.06→ 0 265 007 670



Product				
◀ Serie 3 Coupé				
335 d [E 92]	3,0l	210 kW	30 6D 5	6 Zyl.
Air mass meter, diesel	09.06-02.07		0 281 002 849	
Serie 3 Touring				
316 i [E 30]	1,6l	73-75 kW	16 4E 1	4 Zyl.
Air flow sensor, gasoline injection	09.91-06.94	KAT	0 280 200 204	
			0 986 280 029	
		LLP,OKA	0 280 200 205	
			0 986 280 040	
Wheel speed sensor	09.91-06.94	HI	0 265 001 059	
		LAB,VO	0 265 001 058	
		RAB,VO	0 265 001 057	
316 i [E 36]	1,6l	75 kW	16 4E 2	4 Zyl.
Air flow sensor, gasoline injection	01.96-12.99	KAT	0 280 200 204	
			0 986 280 029	
		LLP,OKA	0 280 200 205	
			0 986 280 040	
316 i [E 46]	1,8l	85 kW	N42 B18A; N46 B18A	4 Zyl.
Air mass meter, gasoline injection	03.02-09.05		0 280 218 075	
318 d [E 46]	2,0l	85 kW	20 4D 1	4 Zyl.
Air mass meter, diesel	03.02-03.03	UPE	0 928 400 527	
318 d [E 46]	2,0l	85 kW	20 4D 4	4 Zyl.
Air mass meter, diesel	03.03-09.05	EU3,UPE	0 928 400 527	
		EU4	0 928 400 529	
High-pressure sensor (CR system)	03.03-09.05		0 281 002 497	
318 d [E 91]	2,0l	90 kW	20 4D 4	4 Zyl.
Air mass meter, diesel	03.06→		0 928 400 529	
High-pressure sensor (CR system)	03.06→		0 281 002 497	
318 i [E 30]	1,8l	83-85 kW	18 4E 1	4 Zyl.
Throttle valve sensor	04.89-06.94		0 280 120 316	
Air flow sensor, gasoline injection	04.89-06.94	OKA	0 280 202 135	
Pulse generator, ignition/Jetronic	04.89-08.90		0 356 914 212	
	09.90-12.93		0 356 914 220	
Temperature sensor, coolant, injection system	04.89-12.93		0 280 130 026	
Wheel speed sensor	04.89-06.94	HI	0 265 001 059	
		LAB,VO	0 265 001 058	
		RAB,VO	0 265 001 057	
318 i [E 36]	1,8l	85 kW	18 4E 2	4 Zyl.
Air flow sensor, gasoline injection	07.95-12.99	LLP,OKA	0 280 202 135	
318 i [E 46]	1,9l	87 kW	19 4E 1	4 Zyl.
Air mass meter, gasoline injection	10.99-09.01		0 280 217 124	
318 i [E 46]	2,0l	105 kW	N42 B20A; N46 B20...	4 Zyl.
Air mass meter, gasoline injection	09.01-03.05		0 280 218 075	
318 i [E 91]	2,0l	95 kW	N46 B20B	4 Zyl.
Air mass meter, gasoline injection	03.06→	BFK	0 280 218 165	
		BHK	0 280 218 159	
318 tds [E 36]	1,7l	66 kW	17 4T 1	4 Zyl.
Pedal position sensor, diesel	03.95-12.99		0 205 001 040	
320 d [E 46]	2,0l	100 kW	20 4D 1	4 Zyl.
Air mass meter, diesel	11.00-09.01	UPE	0 928 400 527	
320 d [E 46]	2,0l	110 kW	20 4D 4	4 Zyl.
Air mass meter, diesel	09.01-09.05	EU3,UPE	0 928 400 527	
		EU4	0 928 400 529	
High-pressure sensor (CR system)	09.01-09.05		0 281 002 497	
320 d [E 91]	2,0l	110/120 kW	20 4D 4	4 Zyl.
Air mass meter, diesel	09.05→		0 928 400 529	
High-pressure sensor (CR system)	09.05→		0 281 002 497	
320 i [E 30]	2,0l	90-95 kW	20 6E E/K A	6 Zyl.
Throttle valve sensor	01.88-12.91		0 280 120 321	
		AG	0 280 120 402	
Air flow sensor, gasoline injection	01.88-12.91		0 280 202 083	
			0 986 280 009	



Product				
Speed sensor, ignition/injection	01.88-03.89		0 261 210 035	
Pulse generator, ignition/Jetronic	01.88-08.90		0 356 914 212	
	09.90-12.91		0 356 914 220	
Temperature sensor, coolant, injection system	01.88-12.91		0 280 130 026	
Wheel speed sensor	04.89-12.91	HI	0 265 001 059	
	01.88-03.89	HI	0 265 001 199	
	01.88-12.91	LAB,VO	0 265 001 058	
		RAB,VO	0 265 001 057	
320 i [E 91]	2,0l	110 kW	N46 B20...	4 Zyl.
Air mass meter, gasoline injection	09.05→	BFK	0 280 218 165	
		BHK	0 280 218 159	
324 td [E 30]	2,4l	85 kW	24 6T B	6 Zyl.
Pressure sensor, intake manifold, diesel	01.88-12.93		0 281 002 018	
Temperature sensor, coolant, diesel	01.88-12.93		0 280 130 055	
Temperature sensor, intake air, diesel	01.88-12.93		0 280 130 039	
Pedal position sensor, diesel	01.88-12.93		0 132 009 315	
Wheel speed sensor	04.89-12.93	HI	0 265 001 059	
	01.88-03.89	HI	0 265 001 199	
	01.88-12.93	LAB,VO	0 265 001 058	
		RAB,VO	0 265 001 057	
325 d [E 91]	3,0l	145 kW	30 6D 3	6 Zyl.
Air mass meter, diesel	09.06→		0 928 400 529	
325 i [E 30]	2,5l	125 kW	25 6K 1	6 Zyl.
Throttle valve sensor	07.87-12.93	AG	0 280 120 402	
		GS	0 280 120 321	
Air flow sensor, gasoline injection	07.87-12.93		0 280 202 082	
			0 986 280 003	
Pulse generator, ignition/Jetronic	07.87-12.93		0 356 914 212	
Temperature sensor, coolant, injection system	07.87-12.93		0 280 130 026	
Wheel speed sensor	04.89-12.93	HI	0 265 001 059	
	07.87-03.89	HI	0 265 001 199	
	07.87-12.93	LAB,VO	0 265 001 058	
		RAB,VO	0 265 001 057	
325 ix [E 30]	2,5l	125 kW	25 6K 1	6 Zyl.
Throttle valve sensor	06.88-03.93		0 280 120 321	
		AG	0 280 120 402	
Air flow sensor, gasoline injection	06.88-03.93		0 280 202 082	
			0 986 280 003	
Pulse generator, ignition/Jetronic	06.88-03.93		0 356 914 212	
Temperature sensor, coolant, injection system	06.88-03.93		0 280 130 026	
Acceleration sensor, ABS	06.88-03.93		0 265 005 003	
Wheel speed sensor	04.89-03.93	HI	0 265 001 059	
	06.88-03.89	HI	0 265 001 199	
	06.88-03.93	VO	0 265 001 113	
325 tds [E 36]	2,5l	105 kW	25 6T 1	6 Zyl.
Temperature sensor, coolant, diesel	09.95-01.96		0 280 130 055	
Pedal position sensor, diesel	09.95-12.99		0 205 001 040	
325 xi [E 46]	2,5l	141 kW	25 6S 5	6 Zyl.
Duo sensor, acceleration and yaw rate, brake system	09.00-09.05		0 265 005 248	
325 xi [E 91]	2,5l	160 kW	N52 B25A	6 Zyl.
Duo sensor, acceleration and yaw rate, brake system	09.05→		0 265 005 678	
Wheel speed sensor, front	09.05→		0 265 007 669	
Wheel speed sensor, rear	09.05→		0 265 007 670	
330 d [E 46]	3,0l	135 kW	30 6D 1	6 Zyl.
Air mass meter, diesel	02.01-03.03	UPE	0 928 400 527	
High-pressure sensor (CR system)	10.99-03.03		0 281 002 475	
330 d [E 46]	3,0l	150 kW	30 6D 2	6 Zyl.
Air mass meter, diesel	03.03-09.05		0 928 400 529	
High-pressure sensor (CR system)	03.03-09.05		0 281 002 497	
330 d [E 91]	3,0l	170 kW	30 6D 3	6 Zyl.
Air mass meter, diesel	09.05→		0 928 400 529	



330 xd [E 46]	3,0l 135 kW 30 6D 1 6 Zyl.
Air mass meter, diesel	02.01-03.03 UPE 0 928 400 527
High-pressure sensor (CR system)	07.00-03.03 0 281 002 475
Duo sensor, acceleration and yaw rate, brake system	07.00-03.03 0 265 005 248
330 xd [E 46]	3,0l 150 kW 30 6D 2 6 Zyl.
Air mass meter, diesel	03.03-09.05 0 928 400 529
High-pressure sensor (CR system)	03.03-09.05 0 281 002 497
Duo sensor, acceleration and yaw rate, brake system	03.03-09.05 0 265 005 248
330 xd [E 91]	3,0l 170 kW 30 6D 3 6 Zyl.
Air mass meter, diesel	09.05→ 0 928 400 529
Duo sensor, acceleration and yaw rate, brake system	09.05→ 0 265 005 678
Wheel speed sensor, front	09.05→ 0 265 007 669
Wheel speed sensor, rear	09.05→ 0 265 007 670
330 xi [E 46]	3,0l 170 kW 30 6S 3 6 Zyl.
Duo sensor, acceleration and yaw rate, brake system	07.00-09.05 0 265 005 248
330 xi [E 91]	3,0l 190 kW N52 B30A 6 Zyl.
Duo sensor, acceleration and yaw rate, brake system	09.05→ 0 265 005 678
Wheel speed sensor, front	09.05→ 0 265 007 669
Wheel speed sensor, rear	09.05→ 0 265 007 670
335 d [E 91]	3,0l 210 kW 30 6D 5 6 Zyl.
Air mass meter, diesel	09.06-02.07 0 281 002 849
335 xi [E 91]	3,0l 225 kW N54 B30A 6 Zyl.
Duo sensor, acceleration and yaw rate, brake system	03.07→ 0 265 005 678
Wheel speed sensor, front	03.07→ 0 265 007 669
Wheel speed sensor, rear	03.07→ 0 265 007 670

Serie 5

518 i [E 28]	1,8l 77 kW 18 4E B/Y 4 Zyl.
Throttle valve sensor	01.86-12.87 0 280 120 320
Air flow sensor, gasoline injection	09.84-12.87 0 280 202 050 0 986 280 005
Temperature sensor, coolant, injection system	09.84-12.87 0 280 130 023
Wheel speed sensor, front	09.84-12.87 0 265 001 029
Wheel speed sensor, rear	05.86-09.86 0 265 001 027 10.86-12.87 LAB 0 265 001 168 RAB 0 265 001 167
518 i [E 28]	1,8l 77 kW 18 4E W 4 Zyl.
Throttle valve sensor	01.84-12.87 0 280 120 302
Air flow sensor, gasoline injection	01.84-12.87 0 280 202 050 0 986 280 005
Temperature sensor, coolant, injection system	01.84-12.87 0 280 130 023
Wheel speed sensor, front	01.84-12.87 0 265 001 029
Wheel speed sensor, rear	05.86-09.86 0 265 001 027 10.86-12.87 LAB 0 265 001 168 RAB 0 265 001 167
518 i [E 34]	1,8l 83 kW 18 4E 1 4 Zyl.
Throttle valve sensor	09.89-09.91 0 280 120 316
Air flow sensor, gasoline injection	09.89-12.94 OKA 0 280 202 135
Pulse generator, ignition/Jetronic	09.89-08.90 0 356 914 212 09.90-08.91 0 356 914 220
Temperature sensor, coolant, injection system	09.89-12.94 0 280 130 026
Wheel speed sensor, front	09.89-12.94 0 265 001 339
518 i [E 34]	1,8l 85 kW 18 4E 2 4 Zyl.
Air flow sensor, gasoline injection	09.90-12.95 OKA 0 280 202 135
Knock sensor	09.90-12.95 0 261 231 097



Temperature sensor, coolant, injection system	09.90-12.95 0 280 130 026
Wheel speed sensor, front	09.90-12.95 0 265 001 339
520 d [E 39]	2,0l 100 kW 20 4D 1 4 Zyl.
Air mass meter, diesel	11.00-07.03 UPE 0 928 400 527
520 d [E 60]	2,0l 110/120 kW 20 4D 4 4 Zyl.
Air mass meter, diesel	09.05-09.07 0 928 400 529
High-pressure sensor (CR system)	09.05-09.07 0 281 002 497
Duo sensor, acceleration and yaw rate, brake system	09.05-09.07 0 265 005 678
520 d [E 60]	2,0l 130 kW N47 D20A 4 Zyl.
Duo sensor, acceleration and yaw rate, brake system	09.07→ EAO 0 265 005 678
520 i [E 28]	2,0l 90-95 kW 20 6K A 6 Zyl.
Throttle valve sensor	12.86-12.87 0 280 120 321 AG 0 280 120 402
Air flow sensor, gasoline injection	12.86-12.87 0 280 202 083 0 986 280 009
Pulse generator, ignition/Jetronic	12.86-12.87 0 356 914 212
Temperature sensor, coolant, injection system	12.86-12.87 0 280 130 026
Wheel speed sensor	12.86-12.87 HI 0 265 001 027 VO 0 265 001 029
520 i [E 28]	2,0l 92 kW 20 6E B 6 Zyl.
Air flow sensor, gasoline injection	04.80-01.86 0 280 202 031 02.86-12.88 0 280 202 090 0 986 280 068
520 i [E 28]	2,0l 92-95 kW 20 6E B/C/Z 6 Zyl.
Throttle valve sensor	01.86-12.87 0 280 120 319
Air flow sensor, gasoline injection	09.82-12.87 0 280 202 031
Temperature sensor, coolant, injection system	09.84-12.87 0 280 130 026
Wheel speed sensor	04.86-12.87 HI 0 265 001 027 09.82-12.87 VO 0 265 001 029
520 i [E 34]	2,0l 95 kW 20 6E J/K A 6 Zyl.
Throttle valve sensor	01.88-12.90 AG 0 280 120 402 GS 0 280 120 310
Air flow sensor, gasoline injection	01.88-12.90 0 280 202 083 0 986 280 009
Pulse generator, ignition/Jetronic	01.88-08.90 0 356 914 212 09.90-12.90 0 356 914 220
Temperature sensor, coolant, injection system	01.88-12.90 0 280 130 026
Wheel speed sensor, front	01.88-12.90 0 265 001 339
520 i [E 34]	2,0l 100 kW 20 6S 1/2 6 Zyl.
Air mass meter, gasoline injection	10.90-09.92 BO 0 280 212 025 0 986 280 111 0 986 280 130
Wheel speed sensor, front	10.90-12.94 0 265 001 339
520 i [E 34]	2,0l 110 kW 20 6S 1/2 6 Zyl.
Air mass meter, gasoline injection	09.89-09.92 BO 0 280 212 025 0 986 280 111 0 986 280 130
Phase sensor	09.89-09.92 BOM,NOC 0 261 210 053
Wheel speed sensor, front	09.89-12.95 0 265 001 339
520 i [E 39]	2,0l 100-110 kW 20 6S 3/4 6 Zyl.
Duo sensor, acceleration and yaw rate, brake system	10.98-06.03 0 265 005 248
Pressure sensor, ESP, (electronic stability program)	10.98-06.03 0 265 005 303
520 i [E 39]	2,2l 120-125 kW 22 6S 1 6 Zyl.
Duo sensor, acceleration and yaw rate, brake system	09.00-07.03 0 265 005 248
Pressure sensor, ESP, (electronic stability program)	09.00-07.03 0 265 005 303
520 i [E 60]	2,0l 115 kW N46 B20B 4 Zyl.
Duo sensor, acceleration and yaw rate, brake system	09.07→ 0 265 005 678



Product

◀ Serie 5

520 i [E 60]	2,0l	125 kW	N43 B20A	4 Zyl.
Duo sensor, acceleration and yaw rate, brake system	09.07→	EAO	0 265 005 678	
520 i [E 60]	2,2l	125 kW	22 6S 1	6 Zyl.
Duo sensor, acceleration and yaw rate, brake system	07.03-09.05		0 265 005 266	
	07.03-03.05	AFP,EAL	0 265 005 285	
523 i [E 39]	2,4l	135 kW	24 6S 3	6 Zyl.
Duo sensor, acceleration and yaw rate, brake system	03.99-12.02		0 265 005 248	
Pressure sensor, ESP, (electronic stability program)	03.99-12.02		0 265 005 303	
523 i [E 39]	2,5l	125 kW	25 6S 3/4	6 Zyl.
Duo sensor, acceleration and yaw rate, brake system	10.98-09.00		0 265 005 248	
Pressure sensor, ESP, (electronic stability program)	10.98-09.00		0 265 005 303	
523 i [E 60]	2,5l	130 kW	N52 B25...	6 Zyl.
Duo sensor, acceleration and yaw rate, brake system	03.05-09.05		0 265 005 266	
		AFP,EAL	0 265 005 285	
	10.05→	EAO	0 265 005 678	
523 i [E 60]	2,5l	140 kW	N53 B25A	6 Zyl.
Duo sensor, acceleration and yaw rate, brake system	03.07→	EAO	0 265 005 678	
523 Li [E 60]	2,5l	130 kW	N52 B25...	6 Zyl.
Duo sensor, acceleration and yaw rate, brake system	11.06→	EAO	0 265 005 678	
524 d [E 28]	2,4l	63 kW	24 6D A	6 Zyl.
Wheel speed sensor	03.86-12.87	VO	0 265 001 029	
524 td [E 28]	2,4l	85 kW	24 6T A	6 Zyl.
Speed sensor, diesel	01.87-12.87		0 261 210 001	
Pressure sensor, intake manifold, diesel	01.87-12.87		0 281 002 018	
Temperature sensor, coolant, diesel	01.87-12.87		0 280 130 037	
Temperature sensor, intake air, diesel	01.87-12.87		0 280 130 039	
Pedal position sensor, diesel	01.87-12.87		0 132 009 308	
Wheel speed sensor	04.86-12.87	HI	0 265 001 027	
	09.83-12.87	VO	0 265 001 029	
524 td [E 34]	2,4l	85 kW	24 6T B	6 Zyl.
Pressure sensor, intake manifold, diesel	03.88-12.91		0 281 002 018	
Temperature sensor, coolant, diesel	03.88-12.91		0 280 130 055	
Temperature sensor, intake air, diesel	03.88-12.91		0 280 130 039	
Pedal position sensor, diesel	03.88-12.91		0 132 009 315	
Wheel speed sensor, front	03.88-12.91		0 265 001 339	
525 d [E 39]	2,5l	120 kW	25 6D 1	6 Zyl.
Air mass meter, diesel	02.01-07.03	UPE	0 928 400 527	
High-pressure sensor (CR system)	04.00-07.03		0 281 002 475	
Duo sensor, acceleration and yaw rate, brake system	04.00-07.03		0 265 005 248	
Pressure sensor, ESP, (electronic stability program)	04.00-07.03		0 265 005 303	
525 d [E 60]	2,5l	120/130 kW	25 6D 2	6 Zyl.
Air mass meter, diesel	05.04-03.07		0 928 400 529	
High-pressure sensor (CR system)	05.04-03.07		0 281 002 497	
Duo sensor, acceleration and yaw rate, brake system	05.04-09.05		0 265 005 266	
		AFP,EAL	0 265 005 285	
	10.05-03.07	EAO	0 265 005 678	
525 d [E 60]	3,0l	145 kW	30 6D 3	6 Zyl.
Air mass meter, diesel	03.07→		0 928 400 529	
Duo sensor, acceleration and yaw rate, brake system	03.07→	EAO	0 265 005 678	
525 e [E 28]	2,7l	90-95 kW	27 6K A/B	6 Zyl.
Throttle valve sensor	12.84-11.86		0 280 120 301	
	12.86-12.87		0 280 120 319	
		AG	0 280 120 404	

Product

Air flow sensor, gasoline injection	12.86-12.87		0 280 202 083	
				0 986 280 009
	12.84-11.86		0 280 202 091	
				0 986 280 006
Speed sensor, ignition/injection	12.84-11.86		0 261 210 001	
Pulse generator, ignition/Jetronic	12.86-12.87		0 356 914 212	
Pressure sensor, intake manifold, gasoline	12.84-11.86		0 280 101 001	
Temperature sensor, coolant, injection system	12.84-12.87		0 280 130 026	
Wheel speed sensor	04.86-12.87	HI	0 265 001 027	
	12.84-12.87	VO	0 265 001 029	
525 e [E 28]	2,7l	92 kW	27 6E A/B	6 Zyl.
Throttle valve sensor	01.86-12.87		0 280 120 319	
	09.85-12.87	AG	0 280 120 404	
Air flow sensor, gasoline injection	09.85-12.87		0 280 202 083	
				0 986 280 009
		TRO	0 280 202 093	
Speed sensor, ignition/injection	09.85-12.87		0 261 210 028	
Temperature sensor, coolant, injection system	05.83-12.87		0 280 130 026	
Wheel speed sensor	04.86-12.87	HI	0 265 001 027	
	05.83-12.87	VO	0 265 001 029	
525 i [E 28]	2,5l	110 kW	25 6E A	6 Zyl.
Throttle valve sensor	01.86-12.87		0 280 120 320	
Air flow sensor, gasoline injection	06.81-12.87		0 280 202 025	
				0 986 280 018
Temperature sensor, coolant, injection system	06.81-12.87		0 280 130 023	
Relay, Jetronic	06.81-12.87		0 280 230 001	
Wheel speed sensor	04.86-12.87	HI	0 265 001 027	
	10.81-12.87	VO	0 265 001 029	
525 i [E 34]	2,5l	125 kW	25 6K 1	6 Zyl.
Throttle valve sensor	01.88-12.90	AG	0 280 120 402	
		GS	0 280 120 310	
Air flow sensor, gasoline injection	01.88-12.90		0 280 202 082	
				0 986 280 003
Temperature sensor, coolant, injection system	01.88-12.90		0 280 130 026	
Wheel speed sensor, front	01.88-12.90		0 265 001 339	
525 i [E 34]	2,5l	141 kW	25 6S 1	6 Zyl.
Air mass meter, gasoline injection	10.90-09.92		0 280 213 011	
				0 986 280 116
525 i [E 34]	2,5l	141 kW	25 6S 1/2	6 Zyl.
Air mass meter, gasoline injection	09.89-09.92		0 280 213 011	
				0 986 280 116
	10.92-12.95		0 280 217 502	
Phase sensor	10.92-12.95	NOC	0 232 103 003	
	09.89-09.92	NOC	0 261 210 053	
Temperature sensor, intake air, injection system	09.89-12.95		0 280 130 039	
Temperature sensor, coolant, injection system	09.89-12.95		0 280 130 026	
Wheel speed sensor, front	09.89-12.95		0 265 001 339	
525 i [E 34]	2,5l	141 kW	25 6S 2	6 Zyl.
Air mass meter, gasoline injection	01.93-12.96		0 280 217 502	
Phase sensor	07.93-12.96		0 261 210 053	
	01.93-12.96	NOC	0 232 103 003	
Temperature sensor, coolant, injection system	01.93-12.96		0 280 130 026	
525 i [E 39]	2,5l	141 kW	25 6S 5	6 Zyl.
Duo sensor, acceleration and yaw rate, brake system	09.00-07.03		0 265 005 248	
Pressure sensor, ESP, (electronic stability program)	09.00-07.03		0 265 005 303	
525 i [E 60]	2,5l	141 kW	25 6S 5	6 Zyl.
Duo sensor, acceleration and yaw rate, brake system	09.03-09.05		0 265 005 266	
	09.03-03.05	AFP,EAL	0 265 005 285	
525 i [E 60]	2,5l	160 kW	N52 B25...	6 Zyl.
Duo sensor, acceleration and yaw rate, brake system	03.05-09.05		0 265 005 266	
		AFP,EAL	0 265 005 285	
	10.05→	EAO	0 265 005 678	



525i [E 60]	3,0l 160 kW N53 B30A 6 Zyl.
Duo sensor, acceleration and yaw rate, brake system	03.07→ EAO 0 265 005 678
525ix [E 34]	2,5l 141 kW 25 6S 1/2 6 Zyl.
Air mass meter, gasoline injection	09.91-09.92 0 280 213 011 0 986 280 116
	10.92-12.95 0 280 217 502
Phase sensor	10.92-12.95 NOC 0 232 103 003 09.91-09.92 NOC 0 261 210 053
Temperature sensor, intake air, injection system	09.91-12.95 0 280 130 039
Temperature sensor, coolant, injection system	09.91-12.95 0 280 130 026
525td [E 34]	2,5l 85 kW 25 6T 1 6 Zyl.
Temperature sensor, coolant, diesel	03.93-12.95 0 280 130 055
Pedal position sensor, diesel	03.93-12.95 0 205 001 040
Wheel speed sensor, front	03.93-12.95 0 265 001 339
525td [E 39]	2,5l 85 kW 25 6T 1 6 Zyl.
Pedal position sensor, diesel	01.97-09.00 0 205 001 040
525tds [E 34]	2,5l 105 kW 25 6T 1 6 Zyl.
Pressure sensor, intake manifold, diesel	09.91-09.92 0 281 002 063
Temperature sensor, coolant, diesel	09.91-12.95 0 280 130 055
Pedal position sensor, diesel	09.94-12.95 0 205 001 040
Wheel speed sensor, front	09.91-12.95 0 265 001 339
525tds [E 39]	2,5l 105 kW 25 6T 1 6 Zyl.
Pedal position sensor, diesel	01.96-09.00 0 205 001 040
525xd [E 60]	3,0l 145 kW 30 6D 3 6 Zyl.
Air mass meter, diesel	09.07→ 0 928 400 529
Duo sensor, acceleration and yaw rate, brake system	09.07→ 0 265 005 678
Wheel speed sensor, front	09.07→ 0 265 007 850
525xi [E 60]	2,5l 160 kW N52 B25A 6 Zyl.
Duo sensor, acceleration and yaw rate, brake system	03.05-09.05 0 265 005 610 10.05-03.07 0 265 005 678
Wheel speed sensor, front	03.05-03.07 0 265 007 850
525xi [E 60]	3,0l 160 kW N53 B30A 6 Zyl.
Duo sensor, acceleration and yaw rate, brake system	03.07→ 0 265 005 678
Wheel speed sensor, front	03.07→ 0 265 007 850
528e [E 28]	2,7l 90 kW 27 6K A/B 6 Zyl.
Throttle valve sensor	01.86-12.87 0 280 120 319 12.86-12.87 AG 0 280 120 404
Air flow sensor, gasoline injection	12.86-12.87 0 280 202 083 0 986 280 009 09.84-11.86 0 280 202 091 0 986 280 006
Speed sensor, ignition/injection	09.85-08.86 0 261 210 002 09.86-12.87 0 261 210 035
Pulse generator, ignition/Jetronic	12.86-12.87 0 356 914 212
Pressure sensor, intake manifold, gasoline	10.84-12.87 0 280 101 001
Temperature sensor, coolant, injection system	09.84-12.87 0 280 130 026
Wheel speed sensor	04.86-12.87 HI 0 265 001 027 01.85-12.87 VO 0 265 001 029
528i [E 28]	2,8l 135 kW 6 Zyl.
Throttle valve sensor	01.86-12.87 0 280 120 320
Air flow sensor, gasoline injection	06.81-12.87 0 280 202 025 0 986 280 018
Temperature sensor, coolant, injection system	06.81-12.87 0 280 130 023
Relay, Jetronic	06.81-12.87 0 280 230 001
Wheel speed sensor	10.81-08.86 HI 0 265 001 027 09.86-12.87 HI,LAB 0 265 001 168 HI,RAB 0 265 001 167 10.81-12.87 VO 0 265 001 029



528i [E 39]	2,8l 142 kW 28 6S 1/2 6 Zyl.
Duo sensor, acceleration and yaw rate, brake system	10.98-09.00 0 265 005 248
Pressure sensor, ESP, (electronic stability program)	10.98-09.00 0 265 005 303
530d [E 39]	3,0l 135-142 kW 30 6D 1 6 Zyl.
Air mass meter, diesel	02.01-07.03 UPE 0 928 400 527
High-pressure sensor (CR system)	08.98-07.03 0 281 002 475
Pedal position sensor, diesel	08.98-09.99 0 281 002 291
Duo sensor, acceleration and yaw rate, brake system	10.98-07.03 0 265 005 248
Pressure sensor, ESP, (electronic stability program)	10.98-07.03 0 265 005 303
530d [E 60]	3,0l 160 kW 30 6D 2 6 Zyl.
Air mass meter, diesel	07.03-09.05 0 928 400 529
High-pressure sensor (CR system)	07.03-09.05 0 281 002 497
Duo sensor, acceleration and yaw rate, brake system	07.03-09.05 0 265 005 266 AFP,EAL 0 265 005 285
530d [E 60]	3,0l 170 kW 30 6D 3 6 Zyl.
Air mass meter, diesel	09.05-03.07 0 928 400 529
High-pressure sensor (CR system)	09.05-03.07 0 281 002 497
Duo sensor, acceleration and yaw rate, brake system	09.05-03.07 EAO 0 265 005 678
530d [E 60]	3,0l 173 kW 30 6D 3 6 Zyl.
Air mass meter, diesel	03.07→ 0 928 400 529
Duo sensor, acceleration and yaw rate, brake system	03.07→ EAO 0 265 005 678
530i [E 34]	3,0l 138 kW 30 6K A 6 Zyl.
Throttle valve sensor	01.88-12.90 AG 0 280 120 406 GS 0 280 120 320
Air flow sensor, gasoline injection	01.88-12.90 0 280 203 027 0 986 280 002
Temperature sensor, coolant, injection system	01.88-12.90 0 280 130 026
Wheel speed sensor, front	01.88-12.90 0 265 001 339
530i [E 34]	3,0l 160 kW 30 8S 1 8 Zyl.
Air mass meter, gasoline injection	09.92-12.96 0 280 217 502
Knock sensor	09.92-04.93 0 261 231 074 05.93-12.96 0 261 231 096
Temperature sensor, coolant, injection system	09.92-09.95 XJD 0 280 130 089
Wheel speed sensor, front	09.92-09.95 0 265 001 339
530i [E 39]	3,0l 170 kW 30 6S 3 6 Zyl.
Duo sensor, acceleration and yaw rate, brake system	09.00-07.03 0 265 005 248
Pressure sensor, ESP, (electronic stability program)	09.00-07.03 0 265 005 303
530i [E 60]	3,0l 170 kW 30 6S 3 6 Zyl.
Duo sensor, acceleration and yaw rate, brake system	07.03-09.05 0 265 005 266 07.03-03.05 AFP,EAL 0 265 005 285
530i [E 60]	3,0l 190 kW N52 B30... 6 Zyl.
Duo sensor, acceleration and yaw rate, brake system	03.05-09.05 0 265 005 266 AFP,EAL 0 265 005 285 10.05→ EAO 0 265 005 678
530i [E 60]	3,0l 200 kW N53 B30A 6 Zyl.
Duo sensor, acceleration and yaw rate, brake system	03.07→ EAO 0 265 005 678
530xd [E 60]	3,0l 170 kW 30 6D 3 6 Zyl.
Air mass meter, diesel	09.05-03.07 0 928 400 529
High-pressure sensor (CR system)	09.05-03.07 0 281 002 497
Duo sensor, acceleration and yaw rate, brake system	09.05-03.07 0 265 005 678 10.05-03.07 0 265 005 678
Wheel speed sensor, front	09.05-03.07 0 265 007 850
530xd [E 60]	3,0l 173 kW 30 6D 3 6 Zyl.
Air mass meter, diesel	03.07→ 0 928 400 529
Duo sensor, acceleration and yaw rate, brake system	03.07→ 0 265 005 678
Wheel speed sensor, front	03.07→ 0 265 007 850

Product				
◀ Serie 5				
530 xi [E 60]	3,0l	190 kW	N52 B30A	6 Zyl.
Duo sensor, acceleration and yaw rate, brake system	03.05-09.05			0 265 005 610
	10.05→			0 265 005 678
Wheel speed sensor, front	03.05→			0 265 007 850
530 xi [E 60]	3,0l	200 kW	N53 B30A	6 Zyl.
Duo sensor, acceleration and yaw rate, brake system	03.07→			0 265 005 678
Wheel speed sensor, front	03.07→			0 265 007 850
535 d [E 60]	3,0l	200 kW	30 6D 4	6 Zyl.
Air mass meter, diesel	09.04-03.07			0 281 002 713
High-pressure sensor (CR system)	09.04-03.07			0 281 002 497
Duo sensor, acceleration and yaw rate, brake system	09.04-09.05			0 265 005 266
		AFP,EAL		0 265 005 285
	10.05-03.07	EAO		0 265 005 678
535 d [E 60]	3,0l	210 kW	30 6D 5	6 Zyl.
Duo sensor, acceleration and yaw rate, brake system	03.07→		EAO	0 265 005 678
535 i [E 28]	3,4l	134 kW	34 6K A	6 Zyl.
Throttle valve sensor	01.86-12.87			0 280 120 320
Air flow sensor, gasoline injection	09.84-12.87			0 280 203 027
				0 986 280 002
Speed sensor, ignition/injection	09.84-12.87			0 261 210 002
Temperature sensor, coolant, injection system	09.84-12.87			0 280 130 026
Wheel speed sensor	01.85-08.86	HI		0 265 001 027
	01.85-12.87	VO		0 265 001 029
535 i [E 28]	3,4l	136-141 kW	34 6K A	6 Zyl.
Throttle valve sensor	01.86-12.87			0 280 120 320
	09.86-12.87	AG		0 280 120 406
Air flow sensor, gasoline injection	01.85-12.87			0 280 203 027
				0 986 280 002
Speed sensor, ignition/injection	01.85-08.86			0 261 210 002
	09.86-12.87			0 261 210 035
Pulse generator, ignition/Jetronic	09.86-12.87			0 356 914 212
Temperature sensor, coolant, injection system	01.85-12.87			0 280 130 026
Wheel speed sensor	01.85-08.86	HI		0 265 001 027
	09.86-12.87	HI,LAB		0 265 001 168
		HI,RAB		0 265 001 167
	01.85-12.87	VO		0 265 001 029
535 i [E 28]	3,4l	160 kW	34 6E C	6 Zyl.
Throttle valve sensor	01.86-12.87			0 280 120 320
	09.86-12.87	AG		0 280 120 406
Air flow sensor, gasoline injection	09.84-12.87			0 280 203 027
				0 986 280 002
Speed sensor, ignition/injection	09.84-08.86			0 261 210 002
	09.86-12.87			0 261 210 035
Pulse generator, ignition/Jetronic	09.86-12.87			0 356 914 212
Temperature sensor, coolant, injection system	09.84-12.87			0 280 130 026
Wheel speed sensor	09.84-08.86	HI		0 265 001 027
	09.86-12.87	HI,LAB		0 265 001 168
		HI,RAB		0 265 001 167
	09.84-12.87	VO		0 265 001 029
535 i [E 34]	3,5l	155 kW	34 6K B	6 Zyl.
Throttle valve assembly	01.88-12.93			0 132 010 453
Throttle valve sensor	01.88-12.93		AG	0 280 120 406
			GS	0 280 120 320
Air flow sensor, gasoline injection	01.88-12.94			0 280 203 027
				0 986 280 002
Temperature sensor, coolant, injection system	01.88-12.94			0 280 130 026
	01.89-12.94	XJD		0 280 130 089
Wheel speed sensor, front	01.88-12.93			0 265 001 339
535 i [E 39]	3,5l	173-180 kW	35 8S 1/2	8 Zyl.
Air mass meter, gasoline injection	01.96-09.98			0 280 217 502
	10.98-07.03			0 280 217 533



Product				
Knock sensor	01.96-09.97			0 261 231 113
	10.97-07.03			0 261 231 200
Pedal position sensor, EMS (electronic engine management)	09.98-09.99			0 281 002 291
Duo sensor, acceleration and yaw rate, brake system	10.98-07.03			0 265 005 248
Pressure sensor, ESP, (electronic stability program)	10.98-07.03			0 265 005 303
540 i [E 34]	4,0l	210 kW	40 8S 1	8 Zyl.
Air mass meter, gasoline injection	09.92-12.96			0 280 217 800
Knock sensor	09.92-05.93			0 261 231 074
	06.93-09.95			0 261 231 096
Temperature sensor, coolant, injection system	09.92-09.95	XJD		0 280 130 089
Wheel speed sensor, front	09.92-09.95			0 265 001 339
540 i [E 39]	4,4l	210 kW	44 8S 1/2	8 Zyl.
Air mass meter, gasoline injection	01.96-09.98			0 280 217 800
	10.98-07.03			0 280 217 814
Knock sensor	01.96-09.97			0 261 231 113
	10.97-07.03			0 261 231 200
Pedal position sensor, EMS (electronic engine management)	09.98-09.99			0 281 002 291
Duo sensor, acceleration and yaw rate, brake system	10.98-07.03			0 265 005 248
Pressure sensor, ESP, (electronic stability program)	10.98-07.03			0 265 005 303
540 i [E 60]	4,0l	225 kW	N62 B40A	8 Zyl.
Knock sensor	09.05→			0 261 231 200
Duo sensor, acceleration and yaw rate, brake system	09.05→	EAO		0 265 005 678
545 i [E 60]	4,4l	245 kW	N62 B44A	8 Zyl.
Air mass meter, gasoline injection	09.03-09.05			0 280 218 135
Knock sensor	09.03-09.05			0 261 231 200
Duo sensor, acceleration and yaw rate, brake system	09.03-09.05			0 265 005 266
		AFP,EAL		0 265 005 285
550 i [E 60]	4,8l	270 kW	N62 B48 B	8 Zyl.
Knock sensor	09.05→			0 261 231 200
Duo sensor, acceleration and yaw rate, brake system	09.05→	EAO		0 265 005 678
Serie 5 Touring				
518 g [E 34]	1,8l	75-85 kW	18 4E 2	4 Zyl.
Air flow sensor, gasoline injection	11.95-06.96	OKA		0 280 202 135
Knock sensor	11.95-06.96			0 261 231 097
Wheel speed sensor, front	11.95-06.96			0 265 001 339
518 i [E 34]	1,8l	83-85 kW	18 4E 1	4 Zyl.
Air flow sensor, gasoline injection	03.93-12.94	OKA		0 280 202 135
Temperature sensor, coolant, injection system	03.93-12.94			0 280 130 026
Wheel speed sensor, front	03.93-12.94			0 265 001 339
518 i [E 34]	1,8l	85 kW	18 4E 2	4 Zyl.
Air flow sensor, gasoline injection	09.94-12.96	OKA		0 280 202 135
Knock sensor	09.94-12.96			0 261 231 097
Temperature sensor, coolant, injection system	09.94-12.96			0 280 130 026
Wheel speed sensor, front	09.94-12.96			0 265 001 339
520 d [E 39]	2,0l	100 kW	20 4D 1	4 Zyl.
Air mass meter, diesel	11.00-07.03	UPE		0 928 400 527
520 d [E 61]	2,0l	110/120 kW	20 4D 4	4 Zyl.
Air mass meter, diesel	09.05-09.07			0 928 400 529
High-pressure sensor (CR system)	09.05-09.07			0 281 002 497
Duo sensor, acceleration and yaw rate, brake system	09.05-09.07			0 265 005 678
520 d [E 61]	2,0l	130 kW	N47 D20A	4 Zyl.
Duo sensor, acceleration and yaw rate, brake system	09.07→		EAO	0 265 005 678



Product			
520i [E 34]	2,0l 110 kW 20 6S 1/2 6 Zyl.		
Air mass meter, gasoline injection	11.91-09.92 BO	0 280 212 025	0 986 280 111
			0 986 280 130
Phase sensor	11.91-09.92 BOM,NOC	0 261 210 053	
Wheel speed sensor, front	11.91-12.96	0 265 001 339	
520i [E 39]	2,0l 100-110 kW 20 6S 3/4 6 Zyl.		
Duo sensor, acceleration and yaw rate, brake system	10.98-12.01	0 265 005 248	
Pressure sensor, ESP, (electronic stability program)	10.98-12.01	0 265 005 303	
520i [E 39]	2,2l 120-125 kW 22 6S 1 6 Zyl.		
Duo sensor, acceleration and yaw rate, brake system	09.00-05.04	0 265 005 248	
Pressure sensor, ESP, (electronic stability program)	09.00-05.04	0 265 005 303	
520i [E 61]	2,0l 125 kW N43 B20A 4 Zyl.		
Duo sensor, acceleration and yaw rate, brake system	09.07→ EAO	0 265 005 678	
523i [E 39]	2,5l 125 kW 25 6S 3/4 6 Zyl.		
Duo sensor, acceleration and yaw rate, brake system	10.98-09.00	0 265 005 248	
Pressure sensor, ESP, (electronic stability program)	10.98-09.00	0 265 005 303	
523i [E 61]	2,5l 130 kW N52 B25... 6 Zyl.		
Duo sensor, acceleration and yaw rate, brake system	03.05-09.05 AFP,EAL	0 265 005 266	0 265 005 285
	10.05→ EAO	0 265 005 678	
Wheel speed sensor, rear	03.05-09.05	0 265 007 623	
523i [E 61]	2,5l 140 kW N53 B25A 6 Zyl.		
Duo sensor, acceleration and yaw rate, brake system	03.07→ EAO	0 265 005 678	
525d [E 39]	2,5l 120 kW 25 6D 1 6 Zyl.		
Air mass meter, diesel	02.01-05.04 UPE	0 928 400 527	
High-pressure sensor (CR system)	04.00-05.04	0 281 002 475	
Duo sensor, acceleration and yaw rate, brake system	04.00-05.04	0 265 005 248	
Pressure sensor, ESP, (electronic stability program)	04.00-05.04	0 265 005 303	
525d [E 61]	2,5l 120/130 kW 25 6D 2 6 Zyl.		
Air mass meter, diesel	05.04-03.07	0 928 400 529	
High-pressure sensor (CR system)	05.04-03.07	0 281 002 497	
Duo sensor, acceleration and yaw rate, brake system	05.04-09.05 AFP,EAL	0 265 005 266	0 265 005 285
	10.05-03.07 EAO	0 265 005 678	
Wheel speed sensor, rear	05.04-09.05	0 265 007 623	
525d [E 61]	3,0l 145 kW 30 6D 3 6 Zyl.		
Air mass meter, diesel	03.07→	0 928 400 529	
Duo sensor, acceleration and yaw rate, brake system	03.07→ EAO	0 265 005 678	
525i [E 34]	2,5l 141 kW 25 6S 1/2 6 Zyl.		
Air mass meter, gasoline injection	11.91-09.92	0 280 213 011	0 986 280 116
	10.92-12.96	0 280 217 502	
Phase sensor	10.92-12.96 NOC	0 232 103 003	
	11.91-09.92 NOC	0 261 210 053	
Temperature sensor, intake air, injection system	11.91-12.96	0 280 130 039	
Temperature sensor, coolant, injection system	11.91-12.96	0 280 130 026	
Wheel speed sensor, front	11.91-12.96	0 265 001 339	
525i [E 39]	2,5l 141 kW 25 6S 5 6 Zyl.		
Duo sensor, acceleration and yaw rate, brake system	09.00-05.04	0 265 005 248	
Pressure sensor, ESP, (electronic stability program)	09.00-05.04	0 265 005 303	
525i [E 61]	2,5l 141 kW 25 6S 5 6 Zyl.		
Duo sensor, acceleration and yaw rate, brake system	05.04-03.05 AFP,EAL	0 265 005 266	0 265 005 285
Wheel speed sensor, rear	05.04-03.05	0 265 007 623	



525i [E 61]	2,5l 160 kW N52 B25... 6 Zyl.		
Duo sensor, acceleration and yaw rate, brake system	03.05-09.05	0 265 005 266	0 265 005 285
	10.05→ EAO	0 265 005 678	
Wheel speed sensor, rear	03.05-09.05	0 265 007 623	
525i [E 61]	3,0l 160 kW N53 B30A 6 Zyl.		
Duo sensor, acceleration and yaw rate, brake system	03.07→ EAO	0 265 005 678	
525ix [E 34]	2,5l 141 kW 25 6S 1/2 6 Zyl.		
Air mass meter, gasoline injection	02.92-09.92	0 280 213 011	0 986 280 116
	10.92-12.96	0 280 217 502	
Phase sensor	10.92-12.96 NOC	0 232 103 003	
	02.92-09.92 NOC	0 261 210 053	
Temperature sensor, intake air, injection system	02.92-12.96	0 280 130 039	
Temperature sensor, coolant, injection system	02.92-12.96	0 280 130 026	
525td [E 34]	2,5l 85 kW 25 6T 1 6 Zyl.		
Temperature sensor, coolant, diesel	03.93-12.96	0 280 130 055	
Pedal position sensor, diesel	03.93-12.96	0 205 001 040	
Wheel speed sensor, front	03.93-12.96	0 265 001 339	
525tds [E 34]	2,5l 105 kW 25 6T 1 6 Zyl.		
Pressure sensor, intake manifold, diesel	12.91-09.92	0 281 002 063	
Temperature sensor, coolant, diesel	12.91-12.96	0 280 130 055	
Pedal position sensor, diesel	09.94-12.96	0 205 001 040	
Wheel speed sensor, front	12.91-12.96	0 265 001 339	
525tds [E 39]	2,5l 105 kW 25 6T 1 6 Zyl.		
Pedal position sensor, diesel	03.97-09.00	0 205 001 040	
525xd [E 61]	3,0l 145 kW 30 6D 3 6 Zyl.		
Air mass meter, diesel	09.07→	0 928 400 529	
Duo sensor, acceleration and yaw rate, brake system	09.07→	0 265 005 678	
Wheel speed sensor, front	09.07→	0 265 007 850	
525xi [E 61]	2,5l 160 kW N52 B25A 6 Zyl.		
Duo sensor, acceleration and yaw rate, brake system	03.05-09.05	0 265 005 610	
	10.05-03.07	0 265 005 678	
Wheel speed sensor, front	03.05-03.07	0 265 007 850	
Wheel speed sensor, rear	03.05-09.05	0 265 007 623	
525xi [E 61]	3,0l 160 kW N53 B30A 6 Zyl.		
Duo sensor, acceleration and yaw rate, brake system	03.07→	0 265 005 678	
Wheel speed sensor, front	03.07→	0 265 007 850	
528i [E 39]	2,8l 142 kW 28 6S 1/2 6 Zyl.		
Duo sensor, acceleration and yaw rate, brake system	10.98-09.00	0 265 005 248	
Pressure sensor, ESP, (electronic stability program)	10.98-09.00	0 265 005 303	
530d [E 39]	3,0l 135-142 kW 30 6D 1 6 Zyl.		
Air mass meter, diesel	02.01-05.04 UPE	0 928 400 527	
High-pressure sensor (CR system)	08.98-05.04	0 281 002 475	
Pedal position sensor, diesel	08.98-09.99	0 281 002 291	
Duo sensor, acceleration and yaw rate, brake system	10.98-05.04	0 265 005 248	
Pressure sensor, ESP, (electronic stability program)	10.98-05.04	0 265 005 303	
530d [E 61]	3,0l 160 kW 30 6D 2 6 Zyl.		
Air mass meter, diesel	05.04-09.05	0 928 400 529	
High-pressure sensor (CR system)	05.04-09.05	0 281 002 497	
Duo sensor, acceleration and yaw rate, brake system	05.04-09.05 AFP,EAL	0 265 005 266	0 265 005 285
Wheel speed sensor, rear	05.04-09.05	0 265 007 623	
530d [E 61]	3,0l 170 kW 30 6D 3 6 Zyl.		
Air mass meter, diesel	09.05-03.07	0 928 400 529	
High-pressure sensor (CR system)	09.05-03.07	0 281 002 497	
Duo sensor, acceleration and yaw rate, brake system	09.05-03.07 EAO	0 265 005 678	



B

Product				
◀ Serie 5 Touring				
530 d [E 61]	3,0l	173 kW	30 6D 3	6 Zyl.
Air mass meter, diesel	03.07→			0 928 400 529
Duo sensor, acceleration and yaw rate, brake system	03.07→	EAO		0 265 005 678
530 i [E 34]	3,0l	160 kW	30 8S 1	8 Zyl.
Air mass meter, gasoline injection	09.92-12.96			0 280 217 502
Knock sensor	09.92-04.93			0 261 231 074
	05.93-12.96			0 261 231 096
Temperature sensor, coolant, injection system	09.92-12.96	XJD		0 280 130 089
Wheel speed sensor, front	09.92-12.96			0 265 001 339
530 i [E 39]	3,0l	170 kW	30 6S 3	6 Zyl.
Duo sensor, acceleration and yaw rate, brake system	09.00-05.04			0 265 005 248
Pressure sensor, ESP, (electronic stability program)	09.00-05.04			0 265 005 303
530 i [E 61]	3,0l	190 kW	N52 B30...	6 Zyl.
Duo sensor, acceleration and yaw rate, brake system	03.05-09.05			0 265 005 266
		AFP,EAL		0 265 005 285
	10.05→	EAO		0 265 005 678
Wheel speed sensor, rear	03.05-09.05			0 265 007 623
530 i [E 61]	3,0l	200 kW	N53 B30A	6 Zyl.
Duo sensor, acceleration and yaw rate, brake system	03.07→	EAO		0 265 005 678
530 xd [E 61]	3,0l	170 kW	30 6D 3	6 Zyl.
Air mass meter, diesel	09.05-03.07			0 928 400 529
High-pressure sensor (CR system)	09.05-03.07			0 281 002 497
Duo sensor, acceleration and yaw rate, brake system	09.05-03.07			0 265 005 678
	10.05-03.07			0 265 005 678
Wheel speed sensor, front	09.05-03.07			0 265 007 850
530 xd [E 61]	3,0l	173 kW	30 6D 3	6 Zyl.
Air mass meter, diesel	03.07→			0 928 400 529
Duo sensor, acceleration and yaw rate, brake system	03.07→			0 265 005 678
Wheel speed sensor, front	03.07→			0 265 007 850
530 xi [E 61]	3,0l	190 kW	N52 B30A	6 Zyl.
Duo sensor, acceleration and yaw rate, brake system	03.05-09.05			0 265 005 610
	10.05→			0 265 005 678
Wheel speed sensor, front	03.05→			0 265 007 850
Wheel speed sensor, rear	03.05-09.05			0 265 007 623
530 xi [E 61]	3,0l	200 kW	N53 B30A	6 Zyl.
Duo sensor, acceleration and yaw rate, brake system	03.07→			0 265 005 678
Wheel speed sensor, front	03.07→			0 265 007 850
535 d [E 61]	3,0l	200 kW	30 6D 4	6 Zyl.
Air mass meter, diesel	09.04-03.07			0 281 002 713
High-pressure sensor (CR system)	09.04-03.07			0 281 002 497
Duo sensor, acceleration and yaw rate, brake system	09.04-09.05			0 265 005 266
		AFP,EAL		0 265 005 285
	10.05-03.07	EAO		0 265 005 678
Wheel speed sensor, rear	09.04-09.05			0 265 007 623
535 d [E 61]	3,0l	210 kW	30 6D 5	6 Zyl.
Duo sensor, acceleration and yaw rate, brake system	03.07→	EAO		0 265 005 678
540 i [E 34]	4,0l	210 kW	40 8S 1	8 Zyl.
Air mass meter, gasoline injection	10.93-12.96			0 280 217 800
Knock sensor	10.93-12.96			0 261 231 096
Temperature sensor, coolant, injection system	10.93-12.96	XJD		0 280 130 089
Wheel speed sensor, front	10.93-12.96			0 265 001 339
540 i [E 39]	4,4l	210 kW	44 8S 1/2	8 Zyl.
Air mass meter, gasoline injection	03.97-09.98			0 280 217 800
	10.98-05.04			0 280 217 814
Knock sensor	03.97-09.97			0 261 231 113
	10.97-05.04			0 261 231 200



Product				
Pedal position sensor, EMS (electronic engine management)	09.98-09.99			0 281 002 291
Duo sensor, acceleration and yaw rate, brake system	10.98-05.04			0 265 005 248
Pressure sensor, ESP, (electronic stability program)	10.98-05.04			0 265 005 303
545 i [E 61]	4,4l	245 kW	N62 B44A	8 Zyl.
Air mass meter, gasoline injection	05.04-09.05			0 280 218 135
Knock sensor	05.04-09.05			0 261 231 200
Duo sensor, acceleration and yaw rate, brake system	05.04-09.05			0 265 005 266
		AFP,EAL		0 265 005 285
Wheel speed sensor, rear	05.04-09.05			0 265 007 623
550 i [E 61]	4,8l	270 kW	N62 B48B	8 Zyl.
Knock sensor	09.05→			0 261 231 200
Duo sensor, acceleration and yaw rate, brake system	09.05→	EAO		0 265 005 678
Serie 6				
628 CSI [E 24]	2,8l	135 kW	28 6EA	6 Zyl.
Throttle valve sensor	01.86-12.87			0 280 120 320
Air flow sensor, gasoline injection	09.84-12.87			0 280 202 025
				0 986 280 018
Temperature sensor, coolant, injection system	09.84-12.87			0 280 130 023
Relay, Jetronic	09.84-12.87			0 280 230 001
Wheel speed sensor, front	09.84-12.87			0 265 001 038
Wheel speed sensor, rear	09.84-09.86			0 265 001 027
	10.86-12.87	LAB		0 265 001 168
		RAB		0 265 001 167
630 i [E 63]	3,0l	190 kW	N52 B30...	6 Zyl.
Duo sensor, acceleration and yaw rate, brake system	09.04-09.05			0 265 005 266
		AFP,EAL		0 265 005 285
	10.05→	EAO		0 265 005 678
630 i [E 63]	3,0l	200 kW	N53 B30A	6 Zyl.
Duo sensor, acceleration and yaw rate, brake system	09.07→	EAO		0 265 005 678
635 CSI [E 24]	3,4l	135 kW	6 Zyl.	
Throttle valve sensor	01.86-04.89			0 280 120 320
Air flow sensor, gasoline injection	09.84-04.89			0 280 203 027
				0 986 280 002
Speed sensor, ignition/injection	09.84-08.86			0 261 210 002
Temperature sensor, coolant, injection system	09.84-04.89			0 280 130 026
Wheel speed sensor, front	09.84-04.89			0 265 001 038
Wheel speed sensor, rear	09.84-09.86			0 265 001 027
	10.86-04.89	LAB		0 265 001 168
		RAB		0 265 001 167
635 CSI [E 24]	3,4l	136-155 kW	6 Zyl.	
Throttle valve sensor	01.86-04.89			0 280 120 320
	09.86-04.89	AG		0 280 120 406
Air flow sensor, gasoline injection	01.85-04.89			0 280 203 027
				0 986 280 002
Speed sensor, ignition/injection	01.85-08.86			0 261 210 002
	09.86-03.89			0 261 210 035
Pulse generator, ignition/Jetronic	09.86-04.89			0 356 914 212
Temperature sensor, coolant, injection system	01.85-04.89			0 280 130 026
Wheel speed sensor, front	01.85-04.89			0 265 001 038
Wheel speed sensor, rear	01.85-09.86			0 265 001 027
	10.86-04.89	LAB		0 265 001 168
		RAB		0 265 001 167
635 CSI [E 24]	3,4l	150-162 kW	6 Zyl.	
Throttle valve sensor	05.82-06.87			0 280 120 320
	07.87-04.89	AG		0 280 120 406
		GS		0 280 120 320



Air flow sensor, gasoline injection	05.82-04.89	KAT	0 280 203 027 🔌 0 986 280 002
CH,S	12.82-04.89	OKA	0 280 203 014
CH,S	10.84-06.87	OKA	0 280 203 027 🔌 0 986 280 002
Speed sensor, ignition/injection	07.87-04.89	AG	0 261 210 002
		GS	0 261 210 035
Pulse generator, ignition/Jetronic	09.86-04.89		0 356 914 212
Temperature sensor, coolant, injection system	05.82-04.89		0 280 130 026
Wheel speed sensor, front	05.82-04.89		0 265 001 038
Wheel speed sensor, rear	05.82-09.86		0 265 001 027
	10.86-04.89	LAB	0 265 001 168
		RAB	0 265 001 167

635 d [E 63]	3,0l	210 kW	30 6D 5	6 Zyl.
Duo sensor, acceleration and yaw rate, brake system	09.07→	EAO	0 265 005 678	
645 Ci [E 63]	4,4l	245 kW	N62 B44A	8 Zyl.
Air mass meter, gasoline injection	01.04-09.05		0 280 218 135	
Knock sensor	01.04-09.05		0 261 231 200	
Duo sensor, acceleration and yaw rate, brake system	01.04-09.05		0 265 005 266	
		AFP,EAL	0 265 005 285	
650 i [E 63]	4,8l	270 kW	N62 B48B	8 Zyl.
Knock sensor	09.05→		0 261 231 200	
Duo sensor, acceleration and yaw rate, brake system	09.05→	EAO	0 265 005 678	

Serie 6 Cabrio


630 i [E 64]	3,0l	190 kW	N52 B30...	6 Zyl.
Duo sensor, acceleration and yaw rate, brake system	09.04-09.05		0 265 005 266	
		AFP,EAL	0 265 005 285	
	10.05→	EAO	0 265 005 678	
630 i [E 64]	3,0l	200 kW	N53 B30A	6 Zyl.
Duo sensor, acceleration and yaw rate, brake system	09.07→	EAO	0 265 005 678	
635 d [E 64]	3,0l	210 kW	30 6D 5	6 Zyl.
Duo sensor, acceleration and yaw rate, brake system	09.07→	EAO	0 265 005 678	
645 Ci [E 64]	4,4l	245 kW	N62 B44A	8 Zyl.
Air mass meter, gasoline injection	04.04-09.05		0 280 218 135	
Knock sensor	04.04-09.05		0 261 231 200	
Duo sensor, acceleration and yaw rate, brake system	04.04-09.05		0 265 005 266	
		AFP,EAL	0 265 005 285	
650 i [E 64]	4,8l	270 kW	N62 B48B	8 Zyl.
Knock sensor	09.05→		0 261 231 200	
Duo sensor, acceleration and yaw rate, brake system	09.05→	EAO	0 265 005 678	

Serie 7

725 tds [E 38]	2,5l	105 kW	25 6T 1	6 Zyl.
Pedal position sensor, diesel	01.96-12.00		0 205 001 040	
728 i [E 23]	2,8l	135 kW	28 6E A	6 Zyl.
Throttle valve sensor	07.78-06.86		0 280 120 206	
	01.86-06.86		0 280 120 320	
Air flow sensor, gasoline injection	06.81-06.86		0 280 202 025 🔌 0 986 280 018	
	S 07.78-06.86		0 280 203 008	
Temperature sensor, coolant, injection system	06.81-06.86		0 280 130 023	
Speed relay	S 07.78-06.86		0 335 530 018	
Relay, Jetronic	06.81-06.86		0 280 230 001	
	S 07.78-06.86		0 332 514 105	



Wheel speed sensor	09.81-06.86	HI	0 265 001 023	
	01.79-06.86	VO	0 265 001 005	
Wheel speed sensor, rear	10.81-06.86		0 265 001 023	
728 i, iL [E 38]	2,8l	142 kW	28 6S 1/2	6 Zyl.
Duo sensor, acceleration and yaw rate, brake system	10.98-12.01		0 265 005 248	
Pressure sensor, ESP, (electronic stability program)	10.98-12.01		0 265 005 303	
730 d [E 38]	3,0l	135-142 kW	30 6D 1	6 Zyl.
Air mass meter, diesel	02.01-12.01	UPE	0 928 400 527	
High-pressure sensor (CR system)	08.98-12.01		0 281 002 475	
Pedal position sensor, diesel	08.98-09.99		0 281 002 291	
Duo sensor, acceleration and yaw rate, brake system	10.98-12.01		0 265 005 248	
Pressure sensor, ESP, (electronic stability program)	10.98-12.01		0 265 005 303	
730 d [E 65]	3,0l	160 kW	30 6D 2	6 Zyl.
Air mass meter, diesel	10.02-03.05		0 928 400 529	
High-pressure sensor (CR system)	10.02-03.05		0 281 002 497	
Duo sensor, acceleration and yaw rate, brake system	10.02-03.05		0 265 005 285	
Pressure sensor, ESP, (electronic stability program)	10.02-03.05		0 265 005 303	
Wheel speed sensor, front	10.02-03.03		0 265 007 461	
	04.03-03.05		0 265 007 592	
Wheel speed sensor, rear	10.02-03.03		0 265 007 462	
	04.03-03.05		0 265 007 593	
730 d [E 65]	3,0l	170 kW	30 6D 3	6 Zyl.
Air mass meter, diesel	04.05→		0 928 400 529	
High-pressure sensor (CR system)	04.05→		0 281 002 497	
Duo sensor, acceleration and yaw rate, brake system	04.05→		0 265 005 285	
Pressure sensor, ESP, (electronic stability program)	04.05→		0 265 005 303	
Wheel speed sensor, front	04.05-09.05		0 265 007 592	
Wheel speed sensor, rear	04.05-09.05		0 265 007 593	
	10.05→		0 265 007 845	
730 i [E 65]	3,0l	170 kW	30 6S 3	6 Zyl.
Duo sensor, acceleration and yaw rate, brake system	03.03-03.05		0 265 005 285	
Pressure sensor, ESP, (electronic stability program)	03.03-03.05		0 265 005 303	
Wheel speed sensor, front	03.03-03.05		0 265 007 592	
Wheel speed sensor, rear	03.03-03.05		0 265 007 593	
730 i [E 65]	3,0l	190 kW	N52 B30...	6 Zyl.
Duo sensor, acceleration and yaw rate, brake system	04.05→		0 265 005 285	
Pressure sensor, ESP, (electronic stability program)	04.05→		0 265 005 303	
Wheel speed sensor, front	04.05-09.05		0 265 007 592	
Wheel speed sensor, rear	04.05-09.05		0 265 007 593	
	10.05→		0 265 007 845	
730 i, iL [E 32]	3,0l	136-145 kW	30 6K A	6 Zyl.
Throttle valve assembly	09.87-06.94		0 132 010 453	
Throttle valve sensor	09.86-06.94	AG	0 280 120 406	
		GS	0 280 120 320	
Air flow sensor, gasoline injection	09.86-06.94		0 280 203 027 🔌 0 986 280 002	
Temperature sensor, coolant, injection system	09.86-06.94		0 280 130 026	
Wheel speed sensor, front	09.86-06.94		0 265 001 339	
730 i, iL [E 32]	3,0l	160 kW	30 8S 1	8 Zyl.
Air mass meter, gasoline injection	09.91-10.94		0 280 217 502	
Knock sensor	09.91-04.93		0 261 231 074	
	05.93-10.94		0 261 231 096	
Temperature sensor, intake air, injection system	09.91-10.94		0 280 130 039	
Temperature sensor, coolant, injection system	09.91-10.94		0 280 130 026	
Wheel speed sensor, front	09.91-10.94		0 265 001 339	



Product				
◀ Serie 7				
730 i, iL [E 38]	3,0l	155-160 kW	30 8S 1	8 Zyl.
Air mass meter, gasoline injection	06.94-12.96		0 280 217 502	
Knock sensor	06.94-12.96		0 261 231 096	
Temperature sensor, coolant, injection system	06.94-12.96	XJD	0 280 130 089	
730 Ld [E 66]	3,0l	170 kW	30 6D 3	6 Zyl.
Air mass meter, diesel	09.05→		0 928 400 529	
High-pressure sensor (CR system)	09.05→		0 281 002 497	
Duo sensor, acceleration and yaw rate, brake system	09.05→		0 265 005 285	
Pressure sensor, ESP, (electronic stability program)	09.05→		0 265 005 303	
Wheel speed sensor, rear	09.05→		0 265 007 845	
730 Li [E 66]	3,0l	170 kW	30 6S 3	6 Zyl.
Duo sensor, acceleration and yaw rate, brake system	03.03-03.05		0 265 005 285	
Pressure sensor, ESP, (electronic stability program)	03.03-03.05		0 265 005 303	
Wheel speed sensor, front	03.03-03.05		0 265 007 592	
Wheel speed sensor, rear	03.03-03.05		0 265 007 593	
730 Li [E 66]	3,0l	190 kW	N52 B30...	6 Zyl.
Duo sensor, acceleration and yaw rate, brake system	04.05→		0 265 005 285	
Pressure sensor, ESP, (electronic stability program)	04.05→		0 265 005 303	
Wheel speed sensor, front	04.05-09.05		0 265 007 592	
Wheel speed sensor, rear	04.05-09.05		0 265 007 593	
	10.05→		0 265 007 845	
732 i [E 23]	3,2l	145 kW	32 6E A	6 Zyl.
Throttle valve sensor	01.86-06.86		0 280 120 320	
Air flow sensor, gasoline injection	09.82-06.86		0 280 203 018	
			0 986 280 072	
	CH,S	09.80-06.86	0 280 203 014	
Speed sensor, ignition/injection	09.80-06.86		0 261 210 002	
Temperature sensor, coolant, injection system	09.83-06.86		0 280 130 023	
Wheel speed sensor	09.81-06.86	HI	0 265 001 023	
	09.79-06.86	VO	0 265 001 005	
Wheel speed sensor, rear	10.81-06.86		0 265 001 023	
735 i [E 23]	3,4l	135/136-141 kW	; 34 6K A	6 Zyl.
Throttle valve sensor	01.86-08.86		0 280 120 320	
Air flow sensor, gasoline injection	09.84-08.86		0 280 203 027	
			0 986 280 002	
Speed sensor, ignition/injection	09.84-08.86		0 261 210 002	
Temperature sensor, coolant, injection system	09.84-08.86		0 280 130 026	
Wheel speed sensor	01.85-08.86	HI	0 265 001 023	
		VO	0 265 001 005	
Wheel speed sensor, rear	09.84-08.86		0 265 001 023	
735 i [E 23]	3,4l	160 kW	34 6E A/C	6 Zyl.
Throttle valve sensor	01.86-06.86		0 280 120 320	
Air flow sensor, gasoline injection	CH	09.82-06.86	0 280 203 014	
	EH	10.84-06.86	0 280 203 027	
			0 986 280 002	
Speed sensor, ignition/injection	09.82-06.86		0 261 210 002	
Temperature sensor, coolant, injection system	09.82-06.86		0 280 130 026	
Wheel speed sensor	09.82-06.86	HI	0 265 001 023	
		VO	0 265 001 005	
Wheel speed sensor, rear	09.82-06.86		0 265 001 023	
735 i [E 65]	3,6l	200 kW	N62 B36A	8 Zyl.
Air mass meter, gasoline injection	11.01-09.03		0 280 218 077	
	10.03-03.05		0 280 218 135	
Knock sensor	11.01-03.05		0 261 231 200	
Duo sensor, acceleration and yaw rate, brake system	11.01-03.05		0 265 005 285	
Pressure sensor, ESP, (electronic stability program)	11.01-03.05		0 265 005 303	
Wheel speed sensor, front	11.01-03.03		0 265 007 461	
	04.03-03.05		0 265 007 592	



Product				
Wheel speed sensor, rear	11.01-03.03		0 265 007 462	
	04.03-03.05		0 265 007 593	
735 i, iL [E 32]	3,4l	155-162 kW	34 6E C/K B	6 Zyl.
Throttle valve assembly	09.87-12.92		0 132 010 453	
Throttle valve sensor	09.86-12.92	AG	0 280 120 406	
		GS	0 280 120 320	
Air flow sensor, gasoline injection	09.86-12.92		0 280 203 027	
			0 986 280 002	
Temperature sensor, coolant, injection system	09.86-12.92		0 280 130 026	
Wheel speed sensor, front	09.86-12.92		0 265 001 339	
735 i, iL [E 38]	3,5l	173-175 kW	35 8S 1/2	8 Zyl.
Air mass meter, gasoline injection	09.94-09.98		0 280 217 502	
	10.98-12.01		0 280 217 533	
Knock sensor	09.94-09.97		0 261 231 113	
	10.97-12.01		0 261 231 200	
Pedal position sensor, EMS (electronic engine management)	09.98-09.99		0 281 002 291	
Duo sensor, acceleration and yaw rate, brake system	10.98-12.01		0 265 005 248	
Pressure sensor, ESP, (electronic stability program)	10.98-12.01		0 265 005 303	
735 Li [E 66]	3,6l	200 kW	N62 B36A	8 Zyl.
Air mass meter, gasoline injection	03.02-09.03		0 280 218 077	
	10.03-03.05		0 280 218 135	
Knock sensor	03.02-03.05		0 261 231 200	
Duo sensor, acceleration and yaw rate, brake system	03.02-03.05		0 265 005 285	
Pressure sensor, ESP, (electronic stability program)	03.02-03.05		0 265 005 303	
Wheel speed sensor, front	03.02-03.03		0 265 007 461	
	04.03-03.05		0 265 007 592	
Wheel speed sensor, rear	03.02-03.03		0 265 007 462	
	04.03-03.05		0 265 007 593	
740 d [E 38]	3,9l	180 kW	39 8D 1	8 Zyl.
Air mass meter, diesel	10.98-12.01		0 280 217 124	
High-pressure sensor (CR system)	10.98-12.01		0 281 002 475	
Pedal position sensor, diesel	10.98-12.01		0 281 002 291	
Duo sensor, acceleration and yaw rate, brake system	10.98-12.01		0 265 005 248	
Pressure sensor, ESP, (electronic stability program)	10.98-12.01		0 265 005 303	
740 d [E 65]	3,9l	190 kW	39 8D 1	8 Zyl.
Air mass meter, diesel	10.02-03.05		0 281 002 567	
High-pressure sensor (CR system)	10.02-03.05		0 281 002 497	
Duo sensor, acceleration and yaw rate, brake system	10.02-03.05		0 265 005 285	
Pressure sensor, ESP, (electronic stability program)	10.02-03.05		0 265 005 303	
Wheel speed sensor, front	10.02-03.03		0 265 007 461	
	04.03-03.05		0 265 007 592	
Wheel speed sensor, rear	10.02-03.03		0 265 007 462	
	04.03-03.05		0 265 007 593	
740 i [E 65]	4,0l	225 kW	N62 B40A	8 Zyl.
Knock sensor	04.05→		0 261 231 200	
Duo sensor, acceleration and yaw rate, brake system	04.05→		0 265 005 285	
Pressure sensor, ESP, (electronic stability program)	04.05→		0 265 005 303	
Wheel speed sensor, front	04.05-09.05		0 265 007 592	
Wheel speed sensor, rear	04.05-09.05		0 265 007 593	
	10.05→		0 265 007 845	
740 i, iL [E 32]	4,0l	210 kW	40 8S 1	8 Zyl.
Air mass meter, gasoline injection	09.91-10.94		0 280 217 800	
Knock sensor	09.91-05.93		0 261 231 074	
	06.93-10.94		0 261 231 096	
Temperature sensor, intake air, injection system	09.91-10.94		0 280 130 039	
Temperature sensor, coolant, injection system	09.91-10.94		0 280 130 026	
Wheel speed sensor, front	09.91-10.94		0 265 001 339	




740 i, iL [E 38]		4,0l 210 kW 40 8S 1 8 Zyl.
Air mass meter, gasoline injection	06.94-06.96	0 280 217 800
Knock sensor	06.94-06.96	0 261 231 096
Temperature sensor, coolant, injection system	06.94-06.96 XJD	0 280 130 089
740 i, iL [E 38]		4,4l 210 kW 44 8S 1/2 8 Zyl.
Air mass meter, gasoline injection	01.96-09.98	0 280 217 800
	10.98-12.01	0 280 217 814
Knock sensor	01.96-09.97	0 261 231 113
	10.97-12.01	0 261 231 200
Pedal position sensor, EMS (electronic engine management)	09.98-09.99	0 281 002 291
Duo sensor, acceleration and yaw rate, brake system	10.98-12.01	0 265 005 248
Pressure sensor, ESP, (electronic stability program)	10.98-12.01	0 265 005 303
740 Li [E 66]		4,0l 225 kW N62 B40A 8 Zyl.
Knock sensor	04.05→	0 261 231 200
Duo sensor, acceleration and yaw rate, brake system	04.05→	0 265 005 285
Pressure sensor, ESP, (electronic stability program)	04.05→	0 265 005 303
Wheel speed sensor, front	04.05-09.05	0 265 007 592
Wheel speed sensor, rear	04.05-09.05	0 265 007 593
	10.05→	0 265 007 845
745 d [E 65]		4,4l 220 kW 44 8D 1 8 Zyl.
Air mass meter, diesel	03.05-08.05	0 281 002 567
Duo sensor, acceleration and yaw rate, brake system	03.05-08.05	0 265 005 285
Pressure sensor, ESP, (electronic stability program)	03.05-08.05	0 265 005 303
Wheel speed sensor, front	03.05-08.05	0 265 007 592
Wheel speed sensor, rear	03.05-08.05	0 265 007 593
745 d [E 65]		4,4l 242 kW 44 8D 1 8 Zyl.
Air mass meter, diesel	09.05→	0 281 002 567
Duo sensor, acceleration and yaw rate, brake system	09.05→	0 265 005 285
Pressure sensor, ESP, (electronic stability program)	09.05→	0 265 005 303
Wheel speed sensor, rear	09.05→	0 265 007 845
745 i [E 23]		3,4l 185 kW 34 6T A 6 Zyl.
Speed sensor, ignition/injection	05.83-06.86	0 261 210 002
Knock sensor	05.83-06.86	0 261 231 001
Pressure sensor, intake manifold, gasoline	05.83-06.86 AG	0 280 101 001
Temperature sensor, coolant, injection system	05.83-06.86	0 280 130 026
Wheel speed sensor	05.83-06.86 HI	0 265 001 023
	VO	0 265 001 005
Wheel speed sensor, rear	05.83-06.86	0 265 001 023
745 i [E 65]		4,4l 245 kW N62 B44A 8 Zyl.
Air mass meter, gasoline injection	11.01-09.03	0 280 218 077
	10.03-03.05	0 280 218 135
Knock sensor	11.01-03.05	0 261 231 200
Duo sensor, acceleration and yaw rate, brake system	11.01-03.05	0 265 005 285
Pressure sensor, ESP, (electronic stability program)	11.01-03.05	0 265 005 303
Wheel speed sensor, front	11.01-03.03	0 265 007 461
	04.03-03.05	0 265 007 592
Wheel speed sensor, rear	11.01-03.03	0 265 007 462
	04.03-03.05	0 265 007 593
745 Li [E 66]		4,4l 245 kW N62 B44A 8 Zyl.
Air mass meter, gasoline injection	03.02-09.03	0 280 218 077
	10.03-03.05	0 280 218 135
Knock sensor	03.02-03.05	0 261 231 200
Duo sensor, acceleration and yaw rate, brake system	03.02-03.05	0 265 005 285
Pressure sensor, ESP, (electronic stability program)	03.02-03.05	0 265 005 303
Wheel speed sensor, front	03.02-03.03	0 265 007 461
	04.03-03.05	0 265 007 592




Wheel speed sensor, rear	03.02-03.03	0 265 007 462
	04.03-03.05	0 265 007 593
750 i [E 65]		4,8l 270 kW N62 B48B 8 Zyl.
Knock sensor	04.05→	0 261 231 200
Duo sensor, acceleration and yaw rate, brake system	04.05→	0 265 005 285
Pressure sensor, ESP, (electronic stability program)	04.05→	0 265 005 303
Wheel speed sensor, front	04.05-09.05	0 265 007 592
Wheel speed sensor, rear	04.05-09.05	0 265 007 593
	10.05→	0 265 007 845
750 i, iL [E 32]		5,0l 220 kW 50 12 A 12 Zyl.
Throttle valve assembly	09.87-10.94	0 205 003 001
Air mass meter, gasoline injection	09.87-10.94	0 280 212 025
		0 986 280 111
		0 986 280 130
Temperature sensor, intake air, injection system	09.87-10.94	0 280 130 060
Temperature sensor, coolant, injection system	09.87-10.94	0 280 130 056
Wheel speed sensor, front	09.87-10.94	0 265 001 339
750 i, iL [E 38]		5,4l 240 kW 54 12 1/2 12 Zyl.
Air mass meter, gasoline injection	06.94-12.01	0 280 217 110
Knock sensor	06.94-09.97	0 261 231 107
Duo sensor, acceleration and yaw rate, brake system	10.98-12.01	0 265 005 248
Pressure sensor, ESP, (electronic stability program)	10.98-12.01	0 265 005 303
750 Li [E 66]		4,8l 270 kW N62 B48B 8 Zyl.
Knock sensor	04.05→	0 261 231 200
Duo sensor, acceleration and yaw rate, brake system	04.05→	0 265 005 285
Pressure sensor, ESP, (electronic stability program)	04.05→	0 265 005 303
Wheel speed sensor, front	04.05-09.05	0 265 007 592
Wheel speed sensor, rear	04.05-09.05	0 265 007 593
	10.05→	0 265 007 845
760 i [E 65]		6,0l 327 kW N73 B60... 12 Zyl.
Air mass meter, gasoline injection	12.02→	0 280 218 076
Duo sensor, acceleration and yaw rate, brake system	12.02→	0 265 005 285
Pressure sensor, ESP, (electronic stability program)	12.02→	0 265 005 303
Wheel speed sensor, front	12.02-03.03	0 265 007 461
	04.03-09.05	0 265 007 592
Wheel speed sensor, rear	12.02-03.03	0 265 007 462
	04.03-09.05	0 265 007 593
	10.05→	0 265 007 845
760 Li [E 66]		6,0l 327 kW N73 B60... 12 Zyl.
Air mass meter, gasoline injection	12.02→	0 280 218 076
Duo sensor, acceleration and yaw rate, brake system	12.02→	0 265 005 285
Pressure sensor, ESP, (electronic stability program)	12.02→	0 265 005 303
Wheel speed sensor, front	12.02-03.03	0 265 007 461
	04.03-09.05	0 265 007 592
Wheel speed sensor, rear	12.02-03.03	0 265 007 462
	04.03-09.05	0 265 007 593
	10.05→	0 265 007 845

Serie 8

840 Ci [E 31]		4,4l 210 kW 44 8S 1 8 Zyl.
Air mass meter, gasoline injection	09.94-12.99	0 280 217 800
Knock sensor	09.94-12.99	0 261 231 113
840 i [E 31]		4,0l 210 kW 40 8S 1 8 Zyl.
Air mass meter, gasoline injection	04.93-03.96	0 280 217 800
Knock sensor	04.93-03.96	0 261 231 096
Temperature sensor, coolant, injection system	04.93-03.96 XJD	0 280 130 089



Product				
◀ Serie 8				
850 Ci [E 31]	5,4l	240 kW	54 12 1	12 Zyl.
Air mass meter, gasoline injection	03.94-12.99		0 280 217 110	
Knock sensor	03.94-12.99		0 261 231 107	
850 CSI [E 31]	5,6l	279-280 kW	56 12 1	12 Zyl.
Throttle valve assembly	08.92-10.96		0 205 003 001	
Air mass meter, gasoline injection	08.92-10.96		0 280 212 026	
Temperature sensor, coolant, injection system	08.92-10.96	AS3	0 280 130 056	
		XJD	0 280 130 089	
850 i, Ci [E 31]	5,0l	220 kW	50 12 A	12 Zyl.
Throttle valve assembly	07.89-12.94		0 205 003 001	
Air mass meter, gasoline injection	07.89-12.94		0 280 212 025	
			0 986 280 111	
			0 986 280 130	
Temperature sensor, coolant, injection system	07.89-12.94	AS3	0 280 130 056	
		XJD	0 280 130 089	
Wheel speed sensor, front	07.89-09.91	BO	0 265 001 301	
Wheel speed sensor, rear	07.89-09.91	BO,LAB	0 265 001 303	
		BO,RAB	0 265 001 302	



BUICK

Regal				
2.0 i	2,0l	91 kW	L34	4 Zyl.
Phase sensor	02.03→		0 232 103 015	
Speed sensor, ignition/injection	02.03→		0 261 210 150	
Knock sensor	02.03→		0 261 231 163	
Pressure sensor, intake manifold, gasoline	02.03→		0 261 230 116	
Temperature sensor, coolant, injection system	02.03→		0 280 130 121	

CADILLAC

Allante Convertible				
4.5 i	4,5l	147 kW	8 Zyl.	
Wheel speed sensor, front	09.89-12.92		0 265 001 258	

Catera				
3.0	3,0l	149 kW	X30...	6 Zyl.
Throttle valve sensor	10.96-12.01		0 280 122 014	
Air mass meter, gasoline injection	10.96-12.01		0 280 217 519	
Speed sensor, ignition/injection	10.96-12.01		0 261 210 131	
Knock sensor	10.96-12.01		0 261 231 116	
Pressure sensor, intake manifold, gasoline	10.96-12.01	FTA	0 261 230 015	
Temperature sensor, intake air, injection system	10.96-12.01		0 280 130 092	
Temperature sensor, coolant, injection system	10.96-12.01		0 280 130 093	

CHERY

QQ				
1.1 i [SQR7110]	1,1l	38 kW	DA465Q-1A2	4 Zyl.
Throttle valve sensor	05.04-08.06		0 280 122 019	
Knock sensor	05.04-08.06		0 261 231 036	
Pressure sensor, intake manifold, gasoline	05.04-08.06		0 261 230 011	
Temperature sensor, coolant, injection system	05.04-08.06		0 280 130 037	

Product				

CHEVROLET

Blazer				
2.4 MPFI	2,4l	94 kW	C24NE	4 Zyl.
Throttle valve assembly	05.00-01.07		F 000 DV0 100	
Throttle valve sensor	05.00-01.07		0 280 122 001	
Speed sensor, ignition/injection	05.00-01.07		0 261 210 030	
Knock sensor	05.00-01.07		0 261 231 046	
Pressure sensor, intake manifold, gasoline	05.00-01.07		0 261 230 022	
Temperature sensor, coolant, injection system	05.00-01.07		0 280 130 107	
4.3 V6 MPFI	4,3l	132 kW	C43NE	6 Zyl.
Pressure sensor, intake manifold, gasoline	10.01-10.03		0 261 230 030	

C

20	4,1l	165 kW	C41GE	6 Zyl.
Throttle valve sensor	01.96-12.96		0 280 122 001	
Air mass meter, gasoline injection	01.96-12.96		0 280 217 525	
Phase sensor	01.96-12.96		0 232 103 006	
Speed sensor, ignition/injection	01.96-12.96		0 261 210 083	
Temperature sensor, intake air, injection system	01.96-12.96		0 280 130 073	
Temperature sensor, coolant, injection system	01.96-12.96		0 280 130 068	

Calibra

2.0 16V	2,0l	110,3 kW	C20XE	4 Zyl.
Throttle valve sensor	10.93-03.96		0 280 122 001	
Air mass meter, gasoline injection				
Fg.no. →14002934	10.93-03.96		0 280 212 015	
			0 986 280 113	
Fg.no. 14002935→	10.93-03.96		0 280 217 106	
Phase sensor				
Fg.no. →1035178	10.93-03.95		0 232 103 002	
Speed sensor, ignition/injection	10.93-03.96		0 261 210 030	
Knock sensor	10.93-03.96		0 261 231 006	
Temperature sensor, intake air, injection system	10.93-03.96		0 280 130 073	
Temperature sensor, coolant, injection system	10.93-03.96		0 280 130 107	
Wheel speed sensor, rear	10.93-03.96	HLI	0 265 003 094	
		HRE	0 265 003 093	

Camaro Coupé

5.0 i	5,0l	164 kW	8 Zyl.	
Air mass meter, gasoline injection	09.87-07.89		0 280 213 009	
			0 986 280 105	

Captiva

2.0 CDRI, CDRI 4x4 [KL1C]	2,0l	110 kW	Z20S	4 Zyl.
Air flow sensor, diesel	10.06→		0 281 002 683	

Corvette Cabrio

5.7	5,7l	225 kW	PTPI	8 Zyl.
Throttle valve assembly	09.91-09.01		0 205 005 002	
Acceleration sensor, ABS	09.91-08.92		0 265 005 004	
	09.92-09.01		0 265 005 041	
Wheel speed sensor, rear	09.91-09.01	LAB	0 265 001 166	
		RAB	0 265 001 165	



Corvette Coupé			
5.7	5,7 l	179-183 kW	L98 8 Zyl.
Air mass meter, gasoline injection	08.85-07.87	0 280 213 004	0 986 280 103
	08.87-07.89	0 280 213 009	0 986 280 105
Acceleration sensor, ABS	08.86-08.91	0 265 005 004	
Wheel speed sensor, front	08.87-07.89	0 265 001 164	0 265 001 163
Wheel speed sensor, rear	08.87-07.91	0 265 001 166	0 265 001 165
5.7 ZR-1	5,7 l	279 kW	LT5 8 Zyl.
Acceleration sensor, ABS	06.89-08.91	0 265 005 004	
Wheel speed sensor, rear	06.89-07.91	0 265 001 166	0 265 001 165
5.7 ZR-1	5,7 l	279-302 kW	LT5 8 Zyl.
Throttle valve assembly	09.91-08.95	0 205 005 002	
Acceleration sensor, ABS	09.91-08.92	0 265 005 004	
	09.92-08.95	0 265 005 041	
Wheel speed sensor, rear	09.91-08.95	0 265 001 166	0 265 001 165

Lacetti			
2.0 D [KL1N, J200]	2,0 l	89 kW	4 Zyl.
Air flow sensor, diesel	09.06→	0 281 002 683	

Nubira			
2.0 D [KL1N, J200]	2,0 l	89 kW	4 Zyl.
Air mass meter, diesel	09.06→	0 281 002 683	

Nubira Station Wagon			
2.0 D [KL1N, J200]	2,0 l	89 kW	4 Zyl.
Air mass meter, diesel	09.06→	0 281 002 683	

Silverado			
4.1 MPFI	4,1 l	102 kW	C41GE 6 Zyl.
Throttle valve assembly	11.96-12.01	9 280 082 000	
Air mass meter, gasoline injection	11.96-12.01	0 280 217 525	
Phase sensor	11.96-12.01	0 232 103 006	
Speed sensor, ignition/injection	11.96-09.97	0 261 210 083	
Temperature sensor, intake air, injection system	11.96-12.01	0 280 130 073	
Temperature sensor, coolant, injection system	11.96-12.01	0 280 130 032	

S10			
2.2 EFI	2,2 l	83 kW	B22NZ 4 Zyl.
Temperature sensor, coolant, injection system	03.95-10.98	0 280 130 026	
2.2 MPFI	2,2 l	100 kW	C22SE 4 Zyl.
Throttle valve assembly	08.97-04.00	F 000 DVO 100	
Speed sensor, ignition/injection	08.97-04.00	0 261 210 030	
Knock sensor	08.97-04.00	0 261 231 046	
Pressure sensor, intake manifold, gasoline	08.97-04.00	0 261 230 022	
Temperature sensor, coolant, injection system	08.97-04.00	0 280 130 107	
4.3 V6 MPFI	4,3 l	132 kW	6 Zyl.
Pressure sensor, intake manifold, gasoline	10.01-10.03	0 261 230 030	



CHRYSLER

New Yorker			
2.2 i	2,2 l	72 kW	EDF 4 Zyl.
Temperature sensor, coolant, injection system	10.86-09.87	0 280 130 063	

Voyager			
2.5 TD [ES]	2,5 l	85-87 kW	VM HR 425 CLIEE 4 Zyl.
Air mass meter, diesel	04.95-12.95	0 281 002 132	
2.5 TD [GS]	2,5 l	85 kW	VM HR 425 CLIEE 4 Zyl.
Air mass meter, diesel	01.95-12.00	0 281 002 132	
Pressure sensor, intake manifold, diesel	08.97-12.00	0 281 002 205	

CITROEN

AX			
1.0 i	1,0 l	31-33/37 kW	CDY Kat. <TU9M>; CDZ Kat. <TU9M> 4 Zyl.
Temperature sensor, coolant, injection system	07.92-12.98	KLO 0 280 130 026	
1.4 i	1,4 l	55-58 kW	KDX, KDY Kat. (Gußmot.) <TU3FM>; KDY, KDZ Kat. <TU3M> 4 Zyl.
Temperature sensor, coolant, injection system	06.88-12.96	0 280 130 026	
1.4 i	1,4 l	66/69-74 kW	KFY Kat. <TU3FJ>; KFZ Kat. <TU3FJ>; K6B <TU3FJ2> 4 Zyl.
Throttle valve sensor	05.91-12.96	0 280 122 001	

Berlingo			
Electricque [M49]	24 kW	SA18 0 Zyl.	
Wheel speed sensor, front	10.98-11.02	0 265 006 200	
Wheel speed sensor, rear			
Org.no. →8938	10.98-05.01	0 265 006 209	
Org.no. 8939→	06.01-11.02	0 265 006 659	
Electricque [M59]	28 kW	SA18 0 Zyl.	
Wheel speed sensor, front			
Org.no. →10220	11.02-11.04	0 265 006 200	
Org.no. 10221→	12.04→	0 265 007 666	
Wheel speed sensor, rear			
Org.no. →9582	11.02-02.03	0 265 006 659	
Org.no. 9583→10220	03.03-11.04	0 265 006 793	
Org.no. 10221→	12.04→	LAB 0 265 007 668	
Org.no. 10221→10478	12.04-07.05	RAB 0 265 007 667	
Org.no. 10479→	08.05→	RAB 0 265 007 883	
1.1 i [M49]	1,1 l	44 kW	HDY; HDZ 4 Zyl.
Temperature sensor, coolant, injection system	07.96-11.02	0 280 130 084	
Wheel speed sensor, front	07.96-11.02	0 265 006 200	
Wheel speed sensor, rear			
Org.no. →8938	07.96-05.01	0 265 006 209	
Org.no. 8939→	06.01-11.02	0 265 006 659	
1.1 i [M49]	1,1 l	44 kW	HFX 4 Zyl.
Pressure sensor, intake manifold, gasoline	06.00-11.02	0 261 230 043	
Wheel speed sensor, front	06.00-11.02	0 265 006 200	
Wheel speed sensor, rear			
Org.no. →8938	06.00-05.01	0 265 006 209	
Org.no. 8939→	06.01-11.02	0 265 006 659	
1.1 i [M59]	1,1 l	44 kW	HFX 4 Zyl.
Knock sensor	11.02→	0 261 231 128	
Pressure sensor, intake manifold, gasoline	11.02→	0 261 230 043	
Wheel speed sensor, front			
Org.no. →10220	11.02-11.04	0 265 006 200	
Org.no. 10221→	12.04→	0 265 007 666	

Product				

◀ Berlingo

Wheel speed sensor, rear			
Org.no. →9582	11.02-02.03		0 265 006 659
Org.no. 9583→10220	03.03-11.04		0 265 006 793
Org.no. 10221→	12.04→	LAB	0 265 007 668
Org.no. 10221→10478	12.04-07.05	RAB	0 265 007 667
Org.no. 10479→	08.05→	RAB	0 265 007 883
1.4 [M49]		1,4l 51 kW K5A 4 Zyl.	
Wheel speed sensor, front	10.96-11.02		0 265 006 200
Wheel speed sensor, rear			
Org.no. →8938	10.96-05.01		0 265 006 209
Org.no. 8939→	06.01-11.02		0 265 006 659
1.4 i [M49]		1,4l 55 kW KFW 4 Zyl.	
Pressure sensor, intake manifold, gasoline	06.00-11.02		0 261 230 043
Wheel speed sensor, front	06.00-11.02		0 265 006 200
Wheel speed sensor, rear			
Org.no. →8938	06.00-05.01		0 265 006 209
Org.no. 8939→	06.01-11.02		0 265 006 659
1.4 i [M49]		1,4l 55 kW KFX 4 Zyl.	
Knock sensor	07.96-11.02	N14	0 261 231 128
Pressure sensor, intake manifold, gasoline			
Org.no. →8056	07.96-12.98		0 261 230 012
Org.no. 8057→	01.99-11.02		0 261 230 057
Wheel speed sensor, front	07.96-11.02		0 265 006 200
Wheel speed sensor, rear			
Org.no. →8938	07.96-05.01		0 265 006 209
Org.no. 8939→	06.01-11.02		0 265 006 659
1.4 i [M59]		1,4l 55 kW KFW 4 Zyl.	
Knock sensor	11.02→		0 261 231 128
Pressure sensor, intake manifold, gasoline	11.02→		0 261 230 043
Accelerator pedal module	11.02→	LLE	0 280 752 251
Wheel speed sensor, front			
Org.no. →10220	11.02-11.04		0 265 006 200
Org.no. 10221→	12.04→		0 265 007 666
Wheel speed sensor, rear			
Org.no. →9582	11.02-02.03		0 265 006 659
Org.no. 9583→10220	03.03-11.04		0 265 006 793
Org.no. 10221→	12.04→	LAB	0 265 007 668
Org.no. 10221→10478	12.04-07.05	RAB	0 265 007 667
Org.no. 10479→	08.05→	RAB	0 265 007 883
1.6 HDi [M59]		1,6l 55 kW 9HW 4 Zyl.	
Wheel speed sensor, front	09.05→		0 265 007 666
Wheel speed sensor, rear	09.05→	LAB	0 265 007 668
		RAB	0 265 007 883
1.6 HDi [M59]		1,6l 66 kW 9HX 4 Zyl.	
Yaw rate sensor, brake system	09.05→		0 265 005 290
Wheel speed sensor, front	09.05→		0 265 007 666
Wheel speed sensor, rear	09.05→	LAB	0 265 007 668
		RAB	0 265 007 883
1.6 i 16V [M49]		1,6l 80 kW NFU 4 Zyl.	
Throttle valve assembly	06.00-11.02		0 280 750 085
Knock sensor	06.00-11.02		0 261 231 128
Pressure sensor, intake manifold, gasoline	06.00-11.02		0 261 230 043
Wheel speed sensor, front	06.00-11.02		0 265 006 200
Wheel speed sensor, rear			
Org.no. →8938	06.00-05.01		0 265 006 209
Org.no. 8939→	06.01-11.02		0 265 006 659
1.6 i 16V [M59]		1,6l 80 kW NFU 4 Zyl.	
Throttle valve assembly	11.02→		0 280 750 085
Knock sensor	11.02→		0 261 231 128
			0 261 231 168
Pressure sensor, intake manifold, gasoline	11.02→		0 261 230 043
Accelerator pedal module	11.02→	LLE	0 280 752 251
Yaw rate sensor, brake system	11.02→		0 265 005 290

Product				

Wheel speed sensor, front			
Org.no. →10220	11.02-11.04		0 265 006 200
Org.no. 10221→	12.04→		0 265 007 666
Wheel speed sensor, rear			
Org.no. →9582	11.02-02.03	TBR	0 265 006 659
Org.no. →10220	11.02-11.04	SBR	0 265 006 732
Org.no. 9583→10220	03.03-11.04	TBR	0 265 006 793
Org.no. 10221→	12.04→	LAB	0 265 007 668
Org.no. 10221→10478	12.04-07.05	RAB	0 265 007 667
Org.no. 10479→	08.05→	RAB	0 265 007 883
1.8 D [M49]		1,8l 43-44 kW A9A-161A 4 Zyl.	
Wheel speed sensor, front	07.96-11.02		0 265 006 200
Wheel speed sensor, rear			
Org.no. →8938	07.96-05.01		0 265 006 209
Org.no. 8939→	06.01-11.02		0 265 006 659
1.8 i		1,8l 74 kW XU7JB 4 Zyl.	
Temperature sensor, coolant, injection system	10.99-12.03		0 280 130 084
1.8 i [M49]		1,8l 66 kW LFX 4 Zyl.	
Pressure sensor, intake manifold, gasoline			
Org.no. →8056	03.97-12.98		0 261 230 012
Org.no. 8057→	01.99-11.02		0 261 230 057
Wheel speed sensor, front	03.97-11.02		0 265 006 200
Wheel speed sensor, rear			
Org.no. →8938	03.97-05.01		0 265 006 209
Org.no. 8939→	06.01-11.02		0 265 006 659
1.9 D [M49]		1,9l 50-51/52 kW DJY; D9B; WJC/WJZ; WJY 4 Zyl.	
Wheel speed sensor, front	07.96-11.02		0 265 006 200
Wheel speed sensor, rear			
Org.no. →8938	07.96-05.01		0 265 006 209
Org.no. 8939→	06.01-11.02		0 265 006 659
1.9 D [M59]		1,9l 52 kW WJY 4 Zyl.	
Wheel speed sensor, front			
Org.no. →10220	11.02-11.04		0 265 006 200
Org.no. 10221→	12.04→		0 265 007 666
Wheel speed sensor, rear			
Org.no. →9582	11.02-02.03		0 265 006 659
Org.no. 9583→10220	03.03-11.04		0 265 006 793
Org.no. 10221→	12.04→	LAB	0 265 007 668
Org.no. 10221→10478	12.04-07.05	RAB	0 265 007 667
Org.no. 10479→	08.05→	RAB	0 265 007 883
2.0 HDi [M49]		2,0l 66 kW RHY 4 Zyl.	
High-pressure sensor (CR system)	12.99-11.02		0 281 002 283
Wheel speed sensor, front	12.99-11.02		0 265 006 200
Wheel speed sensor, rear			
Org.no. →8938	12.99-05.01		0 265 006 209
Org.no. 8939→	06.01-11.02		0 265 006 659
2.0 HDi [M59]		2,0l 66 kW RHY 4 Zyl.	
Yaw rate sensor, brake system	11.02→		0 265 005 290
Wheel speed sensor, front			
Org.no. →10220	11.02-11.04		0 265 006 200
Org.no. 10221→	12.04→		0 265 007 666
Wheel speed sensor, rear			
Org.no. →9582	11.02-02.03	TBR	0 265 006 659
Org.no. →10220	11.02-11.04	SBR	0 265 006 732
Org.no. 9583→10220	03.03-11.04	TBR	0 265 006 793
Org.no. 10221→	12.04→	LAB	0 265 007 668
Org.no. 10221→10478	12.04-07.05	RAB	0 265 007 667
Org.no. 10479→	08.05→	RAB	0 265 007 883
2.0 HDi		2,0l 66 kW DW10TD 4 Zyl.	
High-pressure sensor (CR system)	10.00→		0 281 002 283



Product



BX

14 i [X56]	1,4l 55 kW KDY Kat. <TU3M/Z>; KDZ Kat. <TU3M/Z> 4 Zyl.
Temperature sensor, coolant, injection system	09.88-09.93 0 280 130 026
16 i [X56]	1,6l 76 kW 180Z <XU5J> 4 Zyl.
Throttle valve sensor	
Fg.no. 4132→	02.88-12.94 0 280 120 327
Org.no. →4131	03.86-02.88 0 280 120 310
Air flow sensor, gasoline injection	06.86-12.94 0 280 202 056
	0 986 280 028
Temperature sensor, coolant, injection system	03.86-12.94 0 280 130 026
Relay, Jetronic	03.86-12.94 0 280 230 006
16 i [X56]	1,6l 83-85 kW B6D,B6E 4 Zyl.
Throttle valve sensor	
Fg.no. 4132→	02.88-02.93 0 280 120 327
Org.no. →4131	09.87-02.88 0 280 120 310
Air flow sensor, gasoline injection	09.87-02.93 0 280 202 056
	0 986 280 028
Temperature sensor, coolant, injection system	09.87-02.93 0 280 130 026
19 i [X56]	1,9l 75-77 kW DFZ Kat. <XU9J1/Z> 4 Zyl.
Throttle valve sensor	
Fg.no. 4132→	02.88-12.94 0 280 120 327
Org.no. →4131	03.86-02.88 0 280 120 310
Air flow sensor, gasoline injection	
Org.no. →4227	A,CH,D,NL,S 06.86-05.88 0 280 202 097
	0 986 280 070
Temperature sensor, coolant, injection system	03.86-12.94 0 280 130 026
Relay, Jetronic	03.86-12.94 0 280 230 006
19 i [X56]	1,9l 80 kW DDZ Kat. <XU9M/Z> 4 Zyl.
Temperature sensor, coolant, injection system	06.88-12.94 0 280 130 026
19 i [X56]	1,9l 88 kW DKZ Kat. <XU9JAZ> 4 Zyl.
Throttle valve sensor	06.88-03.93 0 280 120 327
Speed sensor, ignition/injection	06.88-03.93 0 261 210 043
Temperature sensor, coolant, injection system	06.88-03.93 0 280 130 026
19 i [X56]	1,9l 90 kW D6A <XU9J2/K> 4 Zyl.
Throttle valve sensor	
Fg.no. 4132→4923	02.88-05.90 0 280 120 327
Org.no. →4131	07.86-02.88 0 280 120 310
Org.no. 4924→	05.90-07.90 0 280 122 001
Air flow sensor, gasoline injection	
Org.no. →4923	07.86-04.90 0 280 202 602
	0 986 280 019
Temperature sensor, coolant, injection system	07.86-07.90 0 280 130 026
Relay, Jetronic	07.86-07.90 0 332 019 151
19 i [X56]	1,9l 90 kW D6D <XU9J2/K> 4 Zyl.
Throttle valve sensor	07.90-09.93 0 280 122 001
Speed sensor, ignition/injection	07.90-09.93 0 261 210 043
Temperature sensor, coolant, injection system	07.90-09.93 0 280 130 026
19 i 16S [X56]	1,9l 108 kW DFW Kat. <XU9J4/Z> 4 Zyl.
Throttle valve sensor	03.88-03.93 0 280 120 327
Speed sensor, ignition/injection	03.88-03.93 0 261 210 043
Knock sensor	03.88-03.93 0 261 231 006
Temperature sensor, coolant, injection system	03.88-03.93 0 280 130 026
19 i 16S [X56]	1,9l 116 kW D6C <XU9J4/K> 4 Zyl.
Throttle valve sensor	
Fg.no. 4132→	02.88-12.92 0 280 120 327
Org.no. →4131	07.87-02.88 0 280 120 310
Speed sensor, ignition/injection	07.87-12.92 0 261 210 043
Knock sensor	03.88-12.92 0 261 231 006
Temperature sensor, coolant, injection system	07.87-12.92 0 280 130 026

Product



C 15

E 1.1 i	1,1l 44 kW HDZ Kat. 4 Zyl.
Temperature sensor, coolant, injection system	06.89-12.96 0 280 130 026
E 1.4 i	1,4l 55-58 kW KDY Kat. (Gußmot.) 4 Zyl.
Temperature sensor, coolant, injection system	01.92-12.96 0 280 130 026

20	2,0l 74-78 kW 829 A5, J6RA500 4 Zyl.
Wheel speed sensor	07.82-03.86 0 265 001 098
Wheel speed sensor, front	04.86-12.92 0 265 001 157
Wheel speed sensor, rear	07.82-12.92 0 265 001 158
22	2,2l 83-85 kW J6T A500 4 Zyl.
Wheel speed sensor	07.85-03.86 0 265 001 098
Wheel speed sensor, front	04.86-12.92 0 265 001 157
Wheel speed sensor, rear	07.85-12.92 0 265 001 158
25 D	2,5l 54 kW M25-660 4 Zyl.
Wheel speed sensor	07.82-03.86 0 265 001 098
Wheel speed sensor, front	04.86-12.92 0 265 001 157
Wheel speed sensor, rear	07.82-12.92 0 265 001 158
25 D Turbo	2,5l 70 kW M25-648 <CRD93T> 4 Zyl.
Wheel speed sensor	04.83-03.86 0 265 001 098
Wheel speed sensor, front	04.86-12.86 0 265 001 157
Wheel speed sensor, rear	04.83-12.86 0 265 001 158
25 D Turbo 2	2,5l 78 kW M25-671 4 Zyl.
Air flow sensor, diesel	01.87-12.92 0 281 002 037
Pulse generator, diesel	01.87-12.92 0 281 002 030
Pressure sensor, intake manifold, diesel	01.87-12.92 0 281 002 018
Temperature sensor, coolant, diesel	01.87-12.92 0 280 130 026
Pedal position sensor, diesel	01.87-12.92 0 132 009 305
Wheel speed sensor, front	01.87-12.92 0 265 001 157
Wheel speed sensor, rear	01.87-12.92 0 265 001 158
25 D Turbo 2	2,5l 88 kW M25-669 4 Zyl.
Wheel speed sensor, front	01.87-12.92 0 265 001 157
Wheel speed sensor, rear	01.87-12.92 0 265 001 158
25 Injection	2,5l 89-98 kW M25-663 Kat. 4 Zyl.
Throttle valve sensor	02.84-05.86 0 280 120 301
Wheel speed sensor	02.84-03.86 0 265 001 098
Wheel speed sensor, front	04.86-05.86 0 265 001 157
Wheel speed sensor, rear	02.84-05.86 0 265 001 158
25 Injection	2,5l 89-98 kW M25-668 Kat. <EN5L> 4 Zyl.
Throttle valve sensor	05.86-12.92 0 280 120 301
Air flow sensor, gasoline injection	05.86-12.92 0 280 202 100
Temperature sensor, coolant, injection system	05.86-12.92 0 280 130 026
Relay, Jetronic	05.86-12.92 0 280 230 009
Wheel speed sensor, front	05.86-12.92 0 265 001 157
Wheel speed sensor, rear	05.86-12.92 0 265 001 158
25 Injection	2,5l 96-100 kW M25-659 <EN5L> 4 Zyl.
Throttle valve sensor	07.83-12.92 0 280 120 301
Air flow sensor, gasoline injection	07.83-12.92 0 280 202 021
Temperature sensor, coolant, injection system	07.83-12.92 0 280 130 026
Relay, Jetronic	07.83-12.92 0 280 230 009
Wheel speed sensor	07.83-03.86 0 265 001 098
Wheel speed sensor, front	04.86-12.92 0 265 001 157
Wheel speed sensor, rear	07.83-12.92 0 265 001 158
25 Injection Turbo	2,5l 122-125 kW M25-662 <EN5T> 4 Zyl.
Throttle valve sensor	06.84-06.86 0 280 120 313
Air flow sensor, gasoline injection	06.84-06.86 0 280 202 061
Temperature sensor, coolant, injection system	06.84-06.86 0 280 130 026
Relay, Jetronic	06.84-06.86 0 332 019 151
Relay, pump	06.84-06.86 0 280 230 009

Product				

◀ CX

Wheel speed sensor	06.84-03.86	0 265 001 098
Wheel speed sensor, front	04.86-06.86	0 265 001 157
Wheel speed sensor, rear	06.84-06.86	0 265 001 158
25 Injection Turbo 2	2,5 l 116 kW M25-667 Kat. <EN5TE> 4 Zyl.	
Throttle valve sensor	09.86-12.92	0 280 120 318
Temperature sensor, coolant, injection system	09.86-12.92	0 280 130 026
Relay, Jetronic	09.86-12.92	0 280 230 009
Wheel speed sensor, front	09.86-12.92	0 265 001 157
Wheel speed sensor, rear	09.86-12.92	0 265 001 158
25 Injection Turbo 2	2,5 l 122 kW M25-662 <EN5TE> 4 Zyl.	
Wheel speed sensor, front	05.86-12.87	0 265 001 157
Wheel speed sensor, rear	05.86-12.87	0 265 001 158
25 Injection Turbo 2	2,5 l 122 kW M25-666 <EN5TE> 4 Zyl.	
Throttle valve sensor	05.86-12.92	0 280 120 317
Air flow sensor, gasoline injection	05.86-12.92	0 280 202 099
Temperature sensor, coolant, injection system	05.86-12.92	0 280 130 026
Relay, Jetronic	05.86-12.92	0 280 230 009
Wheel speed sensor, front	05.86-12.92	0 265 001 157
Wheel speed sensor, rear	05.86-12.92	0 265 001 158



C1

1.0 i [B0]	1,0 l 50 kW CFA 3 Zyl.	
Wheel speed sensor, rear	06.05→	0 265 007 688
1.4 HDi [B0]	1,4 l 40 kW 8HT 4 Zyl.	
Wheel speed sensor, rear	06.05→	0 265 007 688

C2

1.1 i [A6]	1,1 l 44 kW HFX 4 Zyl.	
Knock sensor		
Org.no. →9820	09.03-10.03	0 261 231 128
Org.no. 9821→	11.03→	0 261 231 168
Pressure sensor, intake manifold, gasoline	09.03→	0 261 230 043
1.4 HDi [A6]	1,4 l 50 kW 8HX/8HZ 4 Zyl.	
High-pressure sensor (CR system)	09.03→	0 281 002 283
Accelerator pedal module	09.03→ LLE	0 280 752 251
1.4 i [A6]	1,4 l 55 kW KVF 4 Zyl.	
Knock sensor		
Org.no. →9820	09.03-10.03	0 261 231 128
Org.no. 9821→	11.03→	0 261 231 168
Pressure sensor, intake manifold, gasoline	09.03→	0 261 230 043
Accelerator pedal module	09.03→ LLE	0 280 752 251
1.4 i 16V [A6]	1,4 l 66 kW KFU 4 Zyl.	
Knock sensor	12.05→	0 261 231 168
Pressure sensor, intake manifold, gasoline	12.05→	0 261 230 043
1.6 i [A6]	1,6 l 80 kW NFU 4 Zyl.	
Throttle valve assembly	09.03→	0 280 750 085
Knock sensor	09.03→	0 261 231 168
Pressure sensor, intake manifold, gasoline	09.03→	0 261 230 043
Accelerator pedal module	09.03→ LLE	0 280 752 251
1.6 i VTS [A6]	1,6 l 90 kW NFS 4 Zyl.	
Throttle valve assembly	10.04→	0 280 750 085
Knock sensor	10.04→	0 261 231 168
Pressure sensor, intake manifold, gasoline	10.04→	0 261 230 043
Accelerator pedal module	10.04→ LLE	0 280 752 251

C3

1.1 i [A8]	1,1 l 44 kW HFX 4 Zyl.	
Knock sensor	01.02-08.05	0 261 231 128
Pressure sensor, intake manifold, gasoline	01.02-08.05	0 261 230 043

Product				

1.1 i [A31]	1,1 l 44 kW HFX 4 Zyl.	
Knock sensor	09.05→	0 261 231 168
Pressure sensor, intake manifold, gasoline	09.05→	0 261 230 043
1.4 HDi [A8]	1,4 l 50 kW 8HX 4 Zyl.	
High-pressure sensor (CR system)	01.02-08.05	0 281 002 283
1.4 HDi 16V [A8]	1,4 l 66 kW 8HY 4 Zyl.	
Accelerator pedal module	01.02-08.05 LLE	0 280 752 251
1.4 i [A8]	1,4 l 55 kW KVF 4 Zyl.	
Knock sensor	01.02-08.05	0 261 231 128
Pressure sensor, intake manifold, gasoline	01.02-08.05	0 261 230 043
Accelerator pedal module	01.02-08.05 LLE	0 280 752 251
1.4 i [A31]	1,4 l 54 kW KVF 4 Zyl.	
Knock sensor	09.05→	0 261 231 168
Pressure sensor, intake manifold, gasoline	09.05→	0 261 230 043
1.4 i 16V [A8]	1,4 l 66 kW KFU 4 Zyl.	
Knock sensor	10.03-08.05	0 261 231 168
Pressure sensor, intake manifold, gasoline	10.03-08.05	0 261 230 043
Accelerator pedal module	10.03-08.05 LLE	0 280 752 251
1.4 i 16V [A31]	1,4 l 66 kW KFU 4 Zyl.	
Knock sensor	09.05→	0 261 231 168
Pressure sensor, intake manifold, gasoline	09.05→	0 261 230 043
1.6 i [A8]	1,6 l 80 kW NFU 4 Zyl.	
Throttle valve assembly	01.02-08.05	0 280 750 085
Knock sensor		
Org.no. →9428	01.02-09.02	0 261 231 128
Org.no. 9429→	10.02-08.05	0 261 231 168
Pressure sensor, intake manifold, gasoline	01.02-08.05	0 261 230 043
Accelerator pedal module	01.02-08.05 LLE	0 280 752 251
1.6 i [A31]	1,6 l 80 kW NFU 4 Zyl.	
Knock sensor	09.05→	0 261 231 168
Pressure sensor, intake manifold, gasoline	09.05→	0 261 230 043
1.6 16V	1,6 l 81 kW TU5JP4 4 Zyl.	
Throttle valve assembly	05.03-09.05	0 280 750 085
Pressure sensor, intake manifold, gasoline	05.03-09.05	0 261 230 043
Accelerator pedal module	05.03-09.05	0 280 752 251

C3-Pluriel

1.4 HDi [A42]	1,4 l 50 kW 8HX/8HZ 4 Zyl.	
High-pressure sensor (CR system)	10.03→	0 281 002 283
1.4 i [A42]	1,4 l 55 kW KVF 4 Zyl.	
Knock sensor		
Org.no. →9820	05.03-10.03	0 261 231 128
Org.no. 9821→	11.03→	0 261 231 168
Pressure sensor, intake manifold, gasoline	05.03→	0 261 230 043
Accelerator pedal module	05.03→ LLE	0 280 752 251
1.6 i 16V [A42]	1,6 l 80 kW NFU 4 Zyl.	
Throttle valve assembly	05.03→	0 280 750 085
Knock sensor	05.03→	0 261 231 168
Pressure sensor, intake manifold, gasoline	05.03→	0 261 230 043
Accelerator pedal module	05.03→ LLE	0 280 752 251

C4

1.4 i [B5]	1,4 l 66 kW KFU 4 Zyl.	
Knock sensor	11.04→	0 261 231 168
Pressure sensor, intake manifold, gasoline	11.04→	0 261 230 043
Yaw rate sensor, brake system	11.04→	0 265 005 606
Steering angle sensor, ESP (electronic stability program)	11.04→	0 265 005 486
Wheel speed sensor, rear	11.04→	0 265 007 779



1.6 HDi [B5]	1,6l 66/80 kW 9HX; 9HY/9HZ 4 Zyl.
Yaw rate sensor, brake system	11.04→ 0 265 005 606
Steering angle sensor, ESP (electronic stability program)	11.04→ 0 265 005 486
Wheel speed sensor, rear	11.04→ 0 265 007 779
1.6 i [B5]	1,6l 80 kW NFU 4 Zyl.
Knock sensor	11.04→ 0 261 231 168
Pressure sensor, intake manifold, gasoline	11.04→ 0 261 230 043
Yaw rate sensor, brake system	11.04→ 0 265 005 606
Steering angle sensor, ESP (electronic stability program)	11.04→ 0 265 005 486
Wheel speed sensor, rear	11.04→ 0 265 007 779
2.0 HDi [B5]	2,0l 100 kW RHR 4 Zyl.
Yaw rate sensor, brake system	11.04→ 0 265 005 606
Steering angle sensor, ESP (electronic stability program)	11.04→ 0 265 005 486
Wheel speed sensor, rear	11.04→ 0 265 007 779
2.0 i [B5]	2,0l 100 kW RFN 4 Zyl.
Pressure sensor, intake manifold, gasoline	11.04→ 0 261 230 058
Yaw rate sensor, brake system	11.04→ 0 265 005 606
Steering angle sensor, ESP (electronic stability program)	11.04→ 0 265 005 486
Wheel speed sensor, rear	11.04→ 0 265 007 779
2.0 i [B5]	2,0l 103 kW RFJ 4 Zyl.
Pressure sensor, intake manifold, gasoline	11.04→ 0 261 230 043
Yaw rate sensor, brake system	11.04→ 0 265 005 606
Steering angle sensor, ESP (electronic stability program)	11.04→ 0 265 005 486
Wheel speed sensor, rear	11.04→ 0 265 007 779

C4 Coupé

1.4 i [B5]	1,4l 66 kW KFU 4 Zyl.
Knock sensor	11.04→ 0 261 231 168
Pressure sensor, intake manifold, gasoline	11.04→ 0 261 230 043
Yaw rate sensor, brake system	11.04→ 0 265 005 606
Steering angle sensor, ESP (electronic stability program)	11.04→ 0 265 005 486
Wheel speed sensor, rear	11.04→ 0 265 007 779
1.6 HDi [B5]	1,6l 66/80 kW 9HX; 9HY/9HZ 4 Zyl.
Yaw rate sensor, brake system	11.04→ 0 265 005 606
Steering angle sensor, ESP (electronic stability program)	11.04→ 0 265 005 486
Wheel speed sensor, rear	11.04→ 0 265 007 779
1.6 i [B5]	1,6l 80 kW NFU 4 Zyl.
Knock sensor	11.04→ 0 261 231 168
Pressure sensor, intake manifold, gasoline	11.04→ 0 261 230 043
Yaw rate sensor, brake system	11.04→ 0 265 005 606
Steering angle sensor, ESP (electronic stability program)	11.04→ 0 265 005 486
Wheel speed sensor, rear	11.04→ 0 265 007 779
2.0 HDi [B5]	2,0l 100 kW RHR 4 Zyl.
Yaw rate sensor, brake system	11.04→ 0 265 005 606
Steering angle sensor, ESP (electronic stability program)	11.04→ 0 265 005 486
Wheel speed sensor, rear	11.04→ 0 265 007 779
2.0 i [B5]	2,0l 100 kW RFN 4 Zyl.
Pressure sensor, intake manifold, gasoline	11.04→ 0 261 230 058
Yaw rate sensor, brake system	11.04→ 0 265 005 606
Steering angle sensor, ESP (electronic stability program)	11.04→ 0 265 005 486
Wheel speed sensor, rear	11.04→ 0 265 007 779




2.0 i [B5]	2,0l 103/130 kW RFJ; RFK 4 Zyl.
Pressure sensor, intake manifold, gasoline	11.04→ 0 261 230 043
Yaw rate sensor, brake system	11.04→ 0 265 005 606
Steering angle sensor, ESP (electronic stability program)	11.04→ 0 265 005 486
Wheel speed sensor, rear	11.04→ 0 265 007 779

C4 Grand Picasso

1.6 HDi [B58]	1,6l 80 kW 9HZ 4 Zyl.
Yaw rate sensor, brake system	10.06→ 0 265 005 715
Steering angle sensor, ESP (electronic stability program)	10.06→ 0 265 005 486
Wheel speed sensor, front	10.06→ 0 265 007 788
Wheel speed sensor, rear	10.06→ 0 265 007 789
1.8 i [B58]	1,8l 92 kW 6FY 4 Zyl.
Pressure sensor, intake manifold, gasoline	10.06→ 0 261 230 043
Yaw rate sensor, brake system	10.06→ 0 265 005 715
Steering angle sensor, ESP (electronic stability program)	10.06→ 0 265 005 486
Wheel speed sensor, front	10.06→ 0 265 007 788
Wheel speed sensor, rear	10.06→ 0 265 007 789
2.0 HDi [B58]	2,0l 100 kW RHR 4 Zyl.
Yaw rate sensor, brake system	10.06→ 0 265 005 715
Steering angle sensor, ESP (electronic stability program)	10.06→ 0 265 005 486
Wheel speed sensor, front	10.06→ 0 265 007 788
Wheel speed sensor, rear	10.06→ 0 265 007 789
2.0 i [B58]	2,0l 103 kW RFJ 4 Zyl.
Pressure sensor, intake manifold, gasoline	10.06→ 0 261 230 043
Yaw rate sensor, brake system	10.06→ 0 265 005 715
Steering angle sensor, ESP (electronic stability program)	10.06→ 0 265 005 486
Wheel speed sensor, front	10.06→ 0 265 007 788
Wheel speed sensor, rear	10.06→ 0 265 007 789

C4 Picasso

1.6 HDi [B58]	1,6l 80 kW 9HZ 4 Zyl.
Yaw rate sensor, brake system	02.07→ 0 265 005 715
Steering angle sensor, ESP (electronic stability program)	02.07→ 0 265 005 486
Wheel speed sensor, front	02.07→ 0 265 007 788
Wheel speed sensor, rear	02.07→ 0 265 007 789
1.8 i [B58]	1,8l 92 kW 6FY 4 Zyl.
Pressure sensor, intake manifold, gasoline	02.07→ 0 261 230 043
Yaw rate sensor, brake system	02.07→ 0 265 005 715
Steering angle sensor, ESP (electronic stability program)	02.07→ 0 265 005 486
Wheel speed sensor, front	02.07→ 0 265 007 788
Wheel speed sensor, rear	02.07→ 0 265 007 789
2.0 HDi [B58]	2,0l 100 kW RHR 4 Zyl.
Yaw rate sensor, brake system	02.07→ 0 265 005 715
Steering angle sensor, ESP (electronic stability program)	02.07→ 0 265 005 486
Wheel speed sensor, front	02.07→ 0 265 007 788
Wheel speed sensor, rear	02.07→ 0 265 007 789
2.0 i [B58]	2,0l 103 kW RFJ 4 Zyl.
Pressure sensor, intake manifold, gasoline	02.07→ 0 261 230 043
Yaw rate sensor, brake system	02.07→ 0 265 005 715
Steering angle sensor, ESP (electronic stability program)	02.07→ 0 265 005 486





Product				

◀ C4 Picasso

Wheel speed sensor, front	02.07→	0 265 007 788
Wheel speed sensor, rear	02.07→	0 265 007 789

C5

1.6 HDi [X7]		1,6 l 80 kW 9HY/9HZ 4 Zyl.	
Accelerator pedal module	10.04→	LLE,OTT	0 280 752 241
		OTT,RLE	0 280 752 242
1.8 i [X7]		1,8 l 85/92 kW 6FY; 6FZ 4 Zyl.	
Pressure sensor, intake manifold, gasoline	10.04→		0 261 230 043
Accelerator pedal module	10.04→	LLE,OTT	0 280 752 241
		OTT,RLE	0 280 752 242
1.8 i 16V [X4]		1,8 l 85 kW 6FZ 4 Zyl.	
Pressure sensor, intake manifold, gasoline	03.01-09.04		0 261 230 057
2.0 HDi [X4]		2,0 l 66/79/80 kW RHS; RHY; RHZ 4 Zyl.	
High-pressure sensor (CR system)	03.01-09.04		0 281 002 283
2.0 HDi [X7]		2,0 l 100 kW RHR/ RHL 4 Zyl.	
Accelerator pedal module	10.04→	LLE,OTT	0 280 752 241
		OTT,RLE	0 280 752 242
2.0 HPi [X4]		2,0 l 103 kW RLZ 4 Zyl.	
Pressure sensor, intake manifold, gasoline	03.01-09.04		0 261 230 058
2.0 i [X7]		2,0 l 103 kW RFJ 4 Zyl.	
Pressure sensor, intake manifold, gasoline	10.04→		0 261 230 043
		LLE,OTT	0 280 752 241
Accelerator pedal module	10.04→	OTT,RLE	0 280 752 242
			0 280 752 242
2.0 i 16V [X4]		2,0 l 100 kW RFN 4 Zyl.	
Pressure sensor, intake manifold, gasoline	03.01-09.04		0 261 230 057
2.2 HDi [X4]		2,2 l 98 kW 4HX 4 Zyl.	
High-pressure sensor (CR system)	03.01-09.04		0 281 002 283
2.2 HDi [X7]		2,2 l 98/125 kW 4H ...; 4HX 4 Zyl.	
Accelerator pedal module	10.04→	LLE,OTT	0 280 752 241
		OTT,RLE	0 280 752 242
3.0 i [X4]		3,0 l 150 kW XFX 6 Zyl.	
Throttle valve assembly	03.01-09.04		0 280 750 041
Knock sensor	03.01-09.04	KZB	0 261 231 130
		KZG	0 261 231 071
Pressure sensor, intake manifold, gasoline	03.01-09.04		0 261 230 058
3.0 i [X7]		3,0 l 155 kW XFU 6 Zyl.	
Throttle valve assembly	10.04→		0 280 750 041
Pressure sensor, intake manifold, gasoline	10.04→		0 261 230 058
Accelerator pedal module	10.04→	LLE,OTT	0 280 752 241
		OTT,RLE	0 280 752 242

C5 Break

1.6 HDi [X7]		1,6 l 80 kW 9HY/9HZ 4 Zyl.	
Accelerator pedal module	10.04→	LLE,OTT	0 280 752 241
		OTT,RLE	0 280 752 242
1.8 i [X7]		1,8 l 85/92 kW 6FY; 6FZ 4 Zyl.	
Pressure sensor, intake manifold, gasoline	10.04→		0 261 230 043
Accelerator pedal module	10.04→	LLE,OTT	0 280 752 241
		OTT,RLE	0 280 752 242
1.8 i 16V [X4]		1,8 l 85 kW 6FZ 4 Zyl.	
Pressure sensor, intake manifold, gasoline	06.01-09.04		0 261 230 057
2.0 HDi [X4]		2,0 l 66/79/80 kW RHS; RHY; RHZ 4 Zyl.	
High-pressure sensor (CR system)	06.01-09.04		0 281 002 283
2.0 HDi [X7]		2,0 l 100 kW RHR/ RHL 4 Zyl.	
Accelerator pedal module	10.04→	LLE,OTT	0 280 752 241
		OTT,RLE	0 280 752 242
2.0 HPi [X4]		2,0 l 103 kW RLZ 4 Zyl.	
Pressure sensor, intake manifold, gasoline	06.01-09.04		0 261 230 058
2.0 i [X7]		2,0 l 103 kW RFJ 4 Zyl.	
Pressure sensor, intake manifold, gasoline	10.04→		0 261 230 043

Product				

Accelerator pedal module	10.04→	LLE,OTT 0 280 752 241
		OTT,RLE 0 280 752 242
2.0 i 16V [X4]		2,0 l 100 kW RFN 4 Zyl.
Pressure sensor, intake manifold, gasoline	06.01-09.04	0 261 230 057
2.2 HDi [X4]		2,2 l 98 kW 4HX 4 Zyl.
High-pressure sensor (CR system)	06.01-09.04	0 281 002 283
2.2 HDi [X7]		2,2 l 98/125 kW 4H ...; 4HX 4 Zyl.
Accelerator pedal module	10.04→	LLE,OTT 0 280 752 241
		OTT,RLE 0 280 752 242
3.0 i [X4]		3,0 l 150 kW XFX 6 Zyl.
Throttle valve assembly	06.01-09.04	0 280 750 041
Knock sensor	06.01-09.04	KZB 0 261 231 130
		KZG 0 261 231 071
Pressure sensor, intake manifold, gasoline	06.01-09.04	0 261 230 058
3.0 i [X7]		3,0 l 155 kW XFU 6 Zyl.
Throttle valve assembly	10.04→	0 280 750 041
Pressure sensor, intake manifold, gasoline	10.04→	0 261 230 058
Accelerator pedal module	10.04→	LLE,OTT 0 280 752 241
		OTT,RLE 0 280 752 242

C6

2.2 HDi [X6]		2,2l 125 kW 4HT 4 Zyl.
Accelerator pedal module	06.06→	LLE,OTT 0 280 752 241
		OTT,RLE 0 280 752 242
2.7 HDi [X6]		2,7l 150 kW UHZ 6 Zyl.
Accelerator pedal module	11.05→	LLE,OTT 0 280 752 241
		OTT,RLE 0 280 752 242
3.0 i [X6]		3,0l 155 kW XFX 6 Zyl.
Throttle valve assembly	11.05→	0 280 750 041
Knock sensor	11.05→	KZB 0 261 231 130
		KZG 0 261 231 071
Pressure sensor, intake manifold, gasoline	11.05→	0 261 230 058
Accelerator pedal module	11.05→	LLE,OTT 0 280 752 241
		OTT,RLE 0 280 752 242

C8

2.0 HDi [V3]		2,0l 81 kW RHT/RHM; RHW 4 Zyl.	
High-pressure sensor (CR system)	06.02→		0 281 002 283
Yaw rate sensor, brake system	06.02→		0 265 005 290
Wheel speed sensor, front	06.02→	LAB	0 265 007 083
		RAB	0 265 007 084
2.0 HDi [V3]		2,0l 88/100 kW RHK; RHR 4 Zyl.	
Yaw rate sensor, brake system	03.06→		0 265 005 606
Wheel speed sensor, front	03.06→	LAB	0 265 007 083
		RAB	0 265 007 084
2.0 i 16V [V3]		2,0l 100 kW RFN 4 Zyl.	
Pressure sensor, intake manifold, gasoline	06.02→		0 261 230 058
Yaw rate sensor, brake system	06.02→		0 265 005 290
Wheel speed sensor, front	06.02→	LAB	0 265 007 083
		RAB	0 265 007 084
2.0 i 16V [V3]		2,0l 103 kW RFJ 4 Zyl.	
Pressure sensor, intake manifold, gasoline	10.05→		0 261 230 043
Yaw rate sensor, brake system	10.05→		0 265 005 606
Wheel speed sensor, front	10.05→	LAB	0 265 007 083
		RAB	0 265 007 084
2.2 HDi [V3]		2,2l 94 kW 4HW 4 Zyl.	
High-pressure sensor (CR system)	06.02→		0 281 002 283
Yaw rate sensor, brake system	06.02→		0 265 005 290
Wheel speed sensor, front	06.02→	LAB	0 265 007 083
		RAB	0 265 007 084

Product



2.2 i 16V [V3]		2,2l 116 kW 3FZ 4 Zyl.	
Pressure sensor, intake manifold, gasoline	06.02→		0 261 230 057
Yaw rate sensor, brake system	06.02→		0 265 005 290
Wheel speed sensor, front	06.02→	LAB	0 265 007 083
		RAB	0 265 007 084
3.0 i [V3]		2,9l 150 kW XFW 6 Zyl.	
Throttle valve assembly	10.02→		0 280 750 041
Pressure sensor, intake manifold, gasoline	10.02→		0 261 230 058
Yaw rate sensor, brake system	10.02→		0 265 005 290
Wheel speed sensor, front	10.02→	LAB	0 265 007 083
		RAB	0 265 007 084

Evasion

1.8 i [U60]		1,8l 72-74 kW LFW 4 Zyl.	
Wheel speed sensor, front			
Org.no. 7481→	06.97-07.02		0 265 006 388
Wheel speed sensor, rear			
Org.no. 7481→7601	06.97-09.97		0 265 006 426
Org.no. 7602→	10.97-07.02		0 265 006 504
1.9 D Turbo [U60]		1,9l 66/67-68 kW DHX; D8B 4 Zyl.	
Wheel speed sensor, front			
Org.no. 7481→	06.97-07.02		0 265 006 388
Wheel speed sensor, rear			
Org.no. 7481→7601	06.97-09.97		0 265 006 426
Org.no. 7602→	10.97-07.02		0 265 006 504
2.0 HDi [U60]		2,0l 80/81 kW RHW; RHZ 4 Zyl.	
High-pressure sensor (CR system)	01.99-07.02		0 281 002 283
Wheel speed sensor, front	01.99-07.02		0 265 006 388
Wheel speed sensor, rear	01.99-07.02		0 265 006 504
2.0 i [U60]		2,0l 89-90 kW RFU 4 Zyl.	
Knock sensor			
Org.no. →8133	06.94-02.99		0 261 231 071
Org.no. 8134→	03.99-07.02		0 261 231 130
Wheel speed sensor, front			
Org.no. 7481→	06.97-07.02		0 265 006 388
Wheel speed sensor, rear			
Org.no. 7481→7601	06.97-09.97		0 265 006 426
Org.no. 7602→	10.97-07.02		0 265 006 504
2.0 i Turbo [U60]		2,0l 108-110 kW RGX 4 Zyl.	
Throttle valve sensor			
Org.no. →6778	06.94-06.95		0 280 122 001
Org.no. 6779→	07.95-07.02		0 280 122 003
Knock sensor			
Org.no. →8133	06.94-02.99		0 261 231 071
Org.no. 8134→	03.99-07.02		0 261 231 130
Wheel speed sensor, front			
Org.no. 7481→	06.97-07.02		0 265 006 388
Wheel speed sensor, rear			
Org.no. 7481→7601	06.97-09.97		0 265 006 426
Org.no. 7602→	10.97-07.02		0 265 006 504
2.0 i 16V [U60]		2,0l 97-99 kW RFV 4 Zyl.	
Throttle valve sensor	05.98-04.00		0 280 122 003
Knock sensor			
Org.no. →8133	05.98-02.99		0 261 231 109
Org.no. 8134→	03.99-04.00	EFV	0 261 231 130
Pressure sensor, intake manifold, gasoline			
Org.no. →8056	05.98-12.98		0 261 230 012
Org.no. 8057→	01.99-04.00		0 261 230 034
Wheel speed sensor, front	05.98-04.00		0 265 006 388
Wheel speed sensor, rear	05.98-04.00		0 265 006 504


Product



2.0 i 16V [U60]		2,0l 100 kW RFN 4 Zyl.	
Pressure sensor, intake manifold, gasoline	04.00-07.02		0 261 230 057
Wheel speed sensor, front	04.00-07.02		0 265 006 388
Wheel speed sensor, rear	04.00-07.02		0 265 006 504
2.1 D Turbo [U60]		2,1l 80-81 kW P8C 4 Zyl.	
Temperature sensor, intake air, diesel	04.96-07.02		0 280 130 039
Wheel speed sensor, front	Org.no. 7481→	06.97-07.02	0 265 006 388
Wheel speed sensor, rear	Org.no. 7481→7601	06.97-09.97	0 265 006 426
Org.no. 7602→	10.97-07.02		0 265 006 504

Jumper

1.9 D [23]		1,9l 51 kW DJY; D9B 4 Zyl.	
Wheel speed sensor, front			
Fg.no. 15445358→	02.94-04.00		0 265 006 427
Wheel speed sensor, rear			
Fg.no. 15445358→	02.94-02.02	LAB	0 265 006 405
		RAB	0 265 006 406
1.9 D Turbo [23]		1,9l 66-68 kW DHX; D8C 4 Zyl.	
Wheel speed sensor, front			
Fg.no. 15445358→	02.94-04.00		0 265 006 427
Wheel speed sensor, rear			
Fg.no. 15445358→	02.94-02.02	LAB	0 265 006 405
		RAB	0 265 006 406
2.0 [23]		2,0l 79 kW R5B 4 Zyl.	
Wheel speed sensor, front			
Fg.no. 15445358→	02.94-04.00		0 265 006 427
Wheel speed sensor, rear			
Fg.no. 15445358→	02.94-02.02	LAB	0 265 006 405
		RAB	0 265 006 406
2.0 HDi [U5]		2,0l 62 kW RHV 4 Zyl.	
High-pressure sensor (CR system)	02.02→		0 281 002 283
2.0 HDi [23]		2,0l 62 kW RHV 4 Zyl.	
High-pressure sensor (CR system)	03.01-02.02		0 281 002 283
Wheel speed sensor, rear			
Fg.no. 15445358→	03.01-02.02	LAB	0 265 006 405
		RAB	0 265 006 406
2.0 i [23]		2,0l 80 kW RFW 4 Zyl.	
Wheel speed sensor, front			
Fg.no. 15445358→	02.94-04.00		0 265 006 427
Wheel speed sensor, rear			
Fg.no. 15445358→	02.94-02.02	LAB	0 265 006 405
		RAB	0 265 006 406
2.2 HDi [U5]		2,2l 77 kW 4HY 4 Zyl.	
High-pressure sensor (CR system)	02.02→		0 281 002 283
2.5 D [23]		2,5l 63 kW T9A 4 Zyl.	
Wheel speed sensor, front			
Fg.no. 15445358→	02.94-04.00		0 265 006 427
Wheel speed sensor, rear			
Fg.no. 15445358→	02.94-02.02	LAB	0 265 006 405
		RAB	0 265 006 406
2.5 D Turbo [23]		2,5l 76 kW THZ; T8A 4 Zyl.	
Wheel speed sensor, front			
Fg.no. 15445358→	02.94-04.00		0 265 006 427
Wheel speed sensor, rear			
Fg.no. 15445358→	02.94-02.02	LAB	0 265 006 405
		RAB	0 265 006 406
2.5 TDi [23]		2,5l 79 kW THX 4 Zyl.	
Wheel speed sensor, front			
Fg.no. 15445358→	10.96-04.00		0 265 006 427



C



Product				

◀ Jumper

Wheel speed sensor, rear				
Fg.no. 15445358→	10.96-02.02	LAB	0 265 006 405	
		RAB	0 265 006 406	
2.8 D [23]	2,8 l	64 kW	8140 63	4 Zyl.
Wheel speed sensor, front				
Fg.no. 15445358→	01.99-04.00		0 265 006 427	
Wheel speed sensor, rear				
Fg.no. 15445358→	01.99-02.02	LAB	0 265 006 405	
		RAB	0 265 006 406	
2.8 D Turbo [23]	2,8 l	90 kW	8140 43	4 Zyl.
Wheel speed sensor, front				
Fg.no. 15445358→	10.99-04.00		0 265 006 427	
Wheel speed sensor, rear				
Fg.no. 15445358→	10.99-02.02	LAB	0 265 006 405	
		RAB	0 265 006 406	
2.8 HDi [U5]	2,8 l	94/107 kW	8140 43s	4 Zyl.
Air flow sensor, diesel	02.02→		0 281 002 184	
2.8 HDi [23]	2,8 l	94 kW	8140 43s	4 Zyl.
Air flow sensor, diesel	09.00-02.02		0 281 002 184	
Wheel speed sensor, rear				
Fg.no. 15445358→	09.00-02.02	LAB	0 265 006 405	
		RAB	0 265 006 406	
2.8 HDi	2,8 l	93 kW	8140 43s	4 Zyl.
Speed sensor, diesel	09.05→		0 281 002 332	
Boost pressure sensor, Diesel	09.05→		0 281 002 514	
Temperature sensor, coolant, diesel	09.05→		0 281 002 170	

Jumpy

1.6 HDi [G9]	1,6 l	66 kW	9HU	4 Zyl.
Yaw rate sensor, brake system	02.07→		0 265 005 606	
Wheel speed sensor, front	02.07→		0 265 007 790	
Wheel speed sensor, rear	02.07→		0 265 007 791	
1.6 i [U64]	1,6 l	58 kW	220 A2.000	4 Zyl.
Temperature sensor, coolant, injection system	10.95→		0 280 130 026	
Wheel speed sensor, front				
Org.no. 7481→9050	06.97-08.01		0 265 006 388	
Org.no. 9051→	09.01→		0 265 006 730	
Wheel speed sensor, rear				
Org.no. 7481→7601	06.97-09.97		0 265 006 426	
Org.no. 7602→9050	10.97-08.01		0 265 006 504	
Org.no. 9051→	09.01→		0 265 006 731	
1.9 D [U64]	1,9 l	50-52 kW	D9B	4 Zyl.
Wheel speed sensor, front				
Org.no. 7481→9050	06.97-08.01		0 265 006 388	
Org.no. 9051→	09.01→		0 265 006 730	
Wheel speed sensor, rear				
Org.no. 7481→7601	06.97-09.97		0 265 006 426	
Org.no. 7602→9050	10.97-08.01		0 265 006 504	
Org.no. 9051→	09.01→		0 265 006 731	
1.9 D [U64]	1,9 l	51 kW	WJZ	4 Zyl.
Wheel speed sensor, front	10.98-08.01		0 265 006 388	
Wheel speed sensor, rear	10.98-08.01		0 265 006 504	
1.9 D [U64]	1,9 l	52 kW	WJY	4 Zyl.
Wheel speed sensor, front	09.01→		0 265 006 730	
Wheel speed sensor, rear	09.01→		0 265 006 731	
1.9 D Turbo [U64]	1,9 l	66/67-68 kW	DHX; D8B	4 Zyl.
Wheel speed sensor, front				
Org.no. 7481→9050	06.97-08.01		0 265 006 388	
Org.no. 9051→	09.01→		0 265 006 730	

Product				

Wheel speed sensor, rear				
Org.no. 7481→7601	06.97-09.97		0 265 006 426	
Org.no. 7602→9050	10.97-08.01		0 265 006 504	
Org.no. 9051→	09.01→		0 265 006 731	
2.0 HDi [G9]	2,0 l	88/100 kW	RHK; RHR	4 Zyl.
Yaw rate sensor, brake system	02.07→		0 265 005 606	
Wheel speed sensor, front	02.07→		0 265 007 790	
Wheel speed sensor, rear	02.07→		0 265 007 791	
2.0 HDi [U64]	2,0 l	70/80/81 kW	RHW; RHX; RHZ	4 Zyl.
High-pressure sensor (CR system)	10.99→		0 281 002 283	
Wheel speed sensor, front				
Org.no. →9050	10.99-08.01		0 265 006 388	
Org.no. 9051→	09.01→		0 265 006 730	
Wheel speed sensor, rear				
Org.no. →9050	10.99-08.01		0 265 006 504	
Org.no. 9051→	09.01→		0 265 006 731	
2.0 i [U64]	2,0 l	100 kW	RFN	4 Zyl.
Pressure sensor, intake manifold, gasoline	04.00→		0 261 230 057	
Wheel speed sensor, front				
Org.no. →9050	04.00-08.01		0 265 006 388	
Org.no. 9051→	09.01→		0 265 006 730	
Wheel speed sensor, rear				
Org.no. →9050	04.00-08.01		0 265 006 504	
Org.no. 9051→	09.01→		0 265 006 731	
2.0 i 16V [G9]	2,0 l	103 kW	RFJ	4 Zyl.
Pressure sensor, intake manifold, gasoline	02.07→		0 261 230 043	
Yaw rate sensor, brake system	02.07→		0 265 005 606	
Wheel speed sensor, front	02.07→		0 265 007 790	
Wheel speed sensor, rear	02.07→		0 265 007 791	

Saxo

1.1 i [S8]	1,1 l	44 kW	HFX	4 Zyl.
Pressure sensor, intake manifold, gasoline	03.00-09.03		0 261 230 043	
1.4 i [S8]	1,4 l	55 kW	KFW	4 Zyl.
Pressure sensor, intake manifold, gasoline	06.00-09.03		0 261 230 043	
1.4 i [S8]	1,4 l	55 kW	KFX	4 Zyl.
Knock sensor				
Org.no. 7756→	02.98-09.03	GS,IF4	0 261 231 128	
Pressure sensor, intake manifold, gasoline				
Org.no. →8056	02.96-12.98		0 261 230 012	
Org.no. 8057→	01.99-09.03		0 261 230 057	
1.6 i [S8]	1,6 l	65-66 kW	NFZ	4 Zyl.
Throttle valve sensor	02.96-09.03	AG	0 280 122 011	
Org.no. →7874	02.96-06.98	GS	0 280 122 003	
Knock sensor				
Org.no. 7875→	06.98-09.03	GS	0 261 231 128	
Pressure sensor, intake manifold, gasoline	02.96-09.03	AG	0 261 230 004	
Org.no. →7874	02.96-06.98	GS	0 261 230 004	
Org.no. 7875→8056	07.98-12.98	GS	0 261 230 012	
Org.no. 8057→	01.99-09.03	GS	0 261 230 057	
Temperature sensor, intake air, injection system	02.96-09.03	AG	0 280 130 039	
Org.no. →7874	02.96-06.98	GS	0 280 130 039	
1.6 i [S8]	1,6 l	74 kW	NFT	4 Zyl.
Knock sensor				
Org.no. →9456	06.00-10.02		0 261 231 128	
Org.no. 9457→	11.02-09.03		0 261 231 168	
Pressure sensor, intake manifold, gasoline	06.00-09.03		0 261 230 043	
1.6 i 16V [S8]	1,6 l	87-88 kW	NFX	4 Zyl.
Pressure sensor, intake manifold, gasoline				
Org.no. →8056	07.96-12.98		0 261 230 012	
Org.no. 8057→	01.99-09.03		0 261 230 057	



Visa		
1.6i [VD]	1,6l 76/83 kW B6D; 180A 4 Zyl.	
Throttle valve sensor	01.85-03.91	0 280 120 327
Air flow sensor, gasoline injection	01.85-03.91	0 280 202 056 0 986 280 028
Temperature sensor, coolant, injection system	01.85-03.91	0 280 130 026
Relay, Jetronic	01.85-03.91	0 280 230 006

Xantia		
1.8i [X1]	1,8l 66 kW LFX 4 Zyl.	
Pressure sensor, intake manifold, gasoline	04.97-01.98	0 261 230 012
1.8i [X1]	1,8l 70-71/74-76 kW LFZ Kat.; L6A 4 Zyl.	
Pressure sensor, intake manifold, gasoline	03.93-01.98 BO	0 261 230 004
1.8i [X2]	1,8l 66 kW LFX 4 Zyl.	
Pressure sensor, intake manifold, gasoline		
Org.no. →8056	10.97-12.98	0 261 230 012
Org.no. 8057→	01.99-12.01	0 261 230 057
1.8i 16V [X1]	1,8l 81 kW LFY Kat. 4 Zyl.	
Knock sensor	05.95-01.98 BO	0 261 231 109
Pressure sensor, intake manifold, gasoline	05.95-01.98	0 261 230 012
1.8i 16V [X2]	1,8l 81 kW LFY 4 Zyl.	
Throttle valve sensor	12.97-12.01	0 280 122 003
Knock sensor	12.97-12.01 BO	0 261 231 109
Pressure sensor, intake manifold, gasoline		
Org.no. →8056	12.97-12.98	0 261 230 012
Org.no. 8057→	01.99-12.01	0 261 230 057
2.0 HDi [X2]	2,0l 66 kW RHY 4 Zyl.	
High-pressure sensor (CR system)	03.99-12.01	0 281 002 283
2.0i [X1]	2,0l 89-90/91-92 kW RFX Kat.; R6D 4 Zyl.	
Knock sensor	03.93-01.98	0 261 231 071
2.0i [X2]	2,0l 89-90 kW RFX 4 Zyl.	
Knock sensor	12.97-12.01 KZG	0 261 231 071
2.0i Turbo [X1]	2,0l 108-110 kW RGX 4 Zyl.	
Throttle valve sensor	05.95-01.98	0 280 122 003
Knock sensor	05.95-01.98	0 261 231 071
2.0i Turbo [X2]	2,0l 108-110 kW RGX 4 Zyl.	
Throttle valve sensor	12.97-12.01	0 280 122 003
Knock sensor		
Org.no. →8133	12.97-02.99	0 261 231 071
Org.no. 8134→	03.99-12.01	0 261 231 130
2.0i 16V [X1]	2,0l 97 kW RFV 4 Zyl.	
Throttle valve sensor	12.94-01.98	0 280 122 003
Knock sensor	12.94-01.98	0 261 231 109
2.0i 16V [X1]	2,0l 110-114 kW RFY, RFT 4 Zyl.	
Throttle valve sensor	03.93-12.98	0 280 122 001
Knock sensor	03.93-12.98	0 261 231 071
2.0i 16V [X2]	2,0l 97 kW RFV 4 Zyl.	
Throttle valve sensor	12.97-12.01 AG	0 280 122 005
	GS	0 280 122 003
Knock sensor	12.97-12.01	0 261 231 045
Pressure sensor, intake manifold, gasoline		
Org.no. →8056	12.97-12.98	0 261 230 012
Org.no. 8057→	01.99-12.01	0 261 230 034
2.1 D Turbo [X1]	2,1l 80-81 kW P8C 4 Zyl.	
Temperature sensor, intake air, diesel	05.95-01.98	0 280 130 039
Pedal position sensor, diesel		
Org.no. →6992	05.95-01.96	0 205 001 015
2.1 D Turbo [X2]	2,1l 80-81 kW P8C 4 Zyl.	
Temperature sensor, intake air, injection system	12.97-12.01	0 280 130 039



3.0i [X1]	3,0l 140 kW XZF 6 Zyl.	
Throttle valve sensor	10.96-01.98	0 280 122 009
Knock sensor	10.96-01.98	0 261 231 125
Pressure sensor, intake manifold, gasoline	10.96-01.98	0 261 230 012
3.0i [X2]	3,0l 140 kW XZF 6 Zyl.	
Throttle valve sensor	12.97-12.01	0 280 122 009
Knock sensor	12.97-12.01	0 261 231 125
Pressure sensor, intake manifold, gasoline		
Org.no. →8077	12.97-01.99	0 261 230 012
Org.no. 8078→	02.99-12.01	0 261 230 034

Xantia Break		
1.8i [X1]	1,8l 66 kW LFX 4 Zyl.	
Pressure sensor, intake manifold, gasoline	04.97-01.98	0 261 230 012
1.8i [X1]	1,8l 70-71/74-76 kW LFZ Kat.; L6A 4 Zyl.	
Pressure sensor, intake manifold, gasoline	09.95-01.98 BO	0 261 230 004
1.8i [X2]	1,8l 66 kW LFX 4 Zyl.	
Pressure sensor, intake manifold, gasoline		
Org.no. →8056	12.97-12.98	0 261 230 012
Org.no. 8057→	01.99-12.01	0 261 230 057
1.8i 16V [X1]	1,8l 81 kW LFY Kat. 4 Zyl.	
Knock sensor	04.97-01.98 BO	0 261 231 109
Pressure sensor, intake manifold, gasoline	04.97-01.98	0 261 230 012
1.8i 16V [X2]	1,8l 81 kW LFY 4 Zyl.	
Throttle valve sensor	12.97-12.01	0 280 122 003
Knock sensor	12.97-12.01 BO	0 261 231 109
Pressure sensor, intake manifold, gasoline		
Org.no. →8056	12.97-12.98	0 261 230 012
Org.no. 8057→	01.99-12.01	0 261 230 057
2.0 HDi [X2]	2,0l 66 kW RHY 4 Zyl.	
High-pressure sensor (CR system)	03.99-12.01	0 281 002 283
2.0i [X1]	2,0l 89-90/91-92 kW RFX Kat.; R6D 4 Zyl.	
Knock sensor	09.95-01.98	0 261 231 071
2.0i Turbo [X1]	2,0l 108-110 kW RGX 4 Zyl.	
Throttle valve sensor	09.95-01.98	0 280 122 003
Knock sensor	09.95-01.98	0 261 231 071
2.0i Turbo [X2]	2,0l 108-110 kW RGX 4 Zyl.	
Throttle valve sensor	12.97-12.01	0 280 122 003
Knock sensor		
Org.no. →8133	12.97-02.99	0 261 231 071
Org.no. 8134→	03.99-12.01	0 261 231 130
2.0i 16V [X1]	2,0l 97 kW RFV 4 Zyl.	
Throttle valve sensor	09.95-01.98	0 280 122 003
Knock sensor	09.95-01.98	0 261 231 109
2.0i 16V [X2]	2,0l 97 kW RFV 4 Zyl.	
Throttle valve sensor	12.97-12.01 AG	0 280 122 005
	GS	0 280 122 003
Knock sensor	12.97-12.01	0 261 231 045
Pressure sensor, intake manifold, gasoline		
Org.no. →8056	12.97-12.98	0 261 230 012
Org.no. 8057→	01.99-12.01	0 261 230 034
2.1 D Turbo [X1]	2,1l 80-81 kW P8C 4 Zyl.	
Temperature sensor, intake air, diesel	06.96-01.98	0 280 130 039
2.1 D Turbo [X2]	2,1l 80-81 kW P8C 4 Zyl.	
Temperature sensor, intake air, injection system	12.97-12.01	0 280 130 039
3.0i [X2]	3,0l 140 kW XZF 6 Zyl.	
Throttle valve sensor	01.98-12.01	0 280 122 009
Knock sensor	01.98-12.01	0 261 231 125
Pressure sensor, intake manifold, gasoline		
Org.no. →8077	01.98-01.99	0 261 230 012
Org.no. 8078→	02.99-12.01	0 261 230 034



Product				

XM				
2.0i [Y3]	2,0l 79-81 kW RDZ Kat. 4 Zyl.			
Temperature sensor, intake air, injection system	05.89-06.94			0 280 130 039
2.0i [Y3]	2,0l 89-90 kW RFZ Kat. <XU10J2Z> 4 Zyl.			
Throttle valve sensor	05.89-06.94			0 280 122 001
Pressure sensor, intake manifold, gasoline				
Org.no. 6020→	04.93-06.94	BO		0 261 230 004
Temperature sensor, intake air, injection system	05.89-06.94			0 280 130 039
Temperature sensor, coolant, injection system				
Org.no. 5714→	07.92-06.94	BO		0 280 130 026
2.0i [Y3]	2,0l 90-96 kW R6A <XU10J2K> 4 Zyl.			
Throttle valve sensor	05.89-06.94	AG		0 280 120 323
Org.no. →4935	05.89-05.90	GS		0 280 120 323
Air flow sensor, gasoline injection	05.89-06.94			0 280 202 118
				0 986 280 057
Pressure sensor, intake manifold, gasoline				
Org.no. 6020→	04.93-06.94	BO		0 261 230 004
Temperature sensor, intake air, injection system	05.89-06.94			0 280 130 039
Temperature sensor, coolant, injection system				
Org.no. 5714→	07.92-06.94	BO		0 280 130 026
2.0i [Y4]	2,0l 90-96 kW R6A <XU10J2> 4 Zyl.			
Air flow sensor, gasoline injection	07.94-10.00			0 280 202 118
				0 986 280 057
Temperature sensor, intake air, injection system	07.94-10.00			0 280 130 039
2.0i Turbo [Y3]	2,0l 104-107 kW RGY <XU10J2TE/Z> 4 Zyl.			
Throttle valve sensor	09.92-06.94			0 280 122 001
Knock sensor	09.92-06.94			0 261 231 109
2.0i Turbo [Y4]	2,0l 108 kW RGX <XU10J2TE> 4 Zyl.			
Throttle valve sensor				
Org.no. →6778	04.95-11.97			0 280 122 001
Org.no. 6779→	12.97-10.00			0 280 122 003
Knock sensor				
Org.no. →8133	04.95-02.99			0 261 231 109
Org.no. 8134→	03.99-10.00			0 261 231 130
2.0i Turbo [Y4]	2,0l 108-110 kW RGY <XU10J2TE> 4 Zyl.			
Throttle valve sensor	07.94-09.95			0 280 122 001
Knock sensor	07.94-09.95			0 261 231 109
2.0i 16V [Y4]	2,0l 97-99 kW RFV <XU10J4R> 4 Zyl.			
Throttle valve sensor	07.94-10.00			0 280 122 003
Knock sensor				
Org.no. →8133	07.94-02.99			0 261 231 109
Org.no. 8134→	03.99-10.00	EFV		0 261 231 130
Pressure sensor, intake manifold, gasoline				
Org.no. 7329→8056	02.97-12.98			0 261 230 012
Org.no. 8057→	01.99-10.00			0 261 230 057
2.1 D Turbo [Y4]	2,1l 80-81 kW P8C <XUD11BTE> 4 Zyl.			
Temperature sensor, intake air, diesel	07.94-10.00			0 280 130 039
Pedal position sensor, diesel				
Org.no. →6992	07.94-12.95	GS		0 205 001 015
2.5 D Turbo [Y4]	2,5l 94-96 kW THY <DK5ATE> 4 Zyl.			
Air flow sensor, diesel	07.94-10.00	N05		0 281 002 128
Pressure sensor, intake manifold, diesel	07.94-10.00	N03,N07		0 281 002 063
		N05		0 281 002 122
Temperature sensor, intake air, injection system	07.94-10.00			0 280 130 039
Pedal position sensor, diesel	07.94-10.00			0 205 001 015
3.0i [Y3]	3,0l 123-125 kW SFZ,S6A <ZPJ> 6 Zyl.			
Knock sensor				
Org.no. →5168	06.89-02.91	HI,KZB		0 261 231 033
		KZG,VO		0 261 231 034
Org.no. 5169→	02.91-06.93	HI,KZB		0 261 231 070
		KZG,VO		0 261 231 071
Temperature sensor, intake air, injection system	05.89-06.93			0 280 130 039

Product				

3.0i [Y3]	3,0l 123-125 kW UFZ <ZPJ> 6 Zyl.			
Knock sensor				
Org.no. 5169→	06.93-06.94	HI,KZB		0 261 231 070
		KZG,VO		0 261 231 071
Temperature sensor, intake air, injection system	06.93-06.94			0 280 130 039
3.0i [Y4]	3,0l 123-125 kW UFY <ZPJ>; UFZ <ZPJ> 6 Zyl.			
Throttle valve sensor	07.94-12.97			0 280 122 003
Knock sensor	07.94-12.97	KZG		0 261 231 071
Temperature sensor, intake air, injection system	07.94-12.97			0 280 130 039
3.0i [Y4]	3,0l 140-143 kW XFZ <ES9J4> 6 Zyl.			
Throttle valve sensor	09.97-10.00			0 280 122 009
Knock sensor	09.97-10.00			0 261 231 125
Pressure sensor, intake manifold, gasoline				
Org.no. →8077	09.97-12.98			0 261 230 012
Org.no. 8078→	01.99-10.00			0 261 230 057
3.0i 24V [Y3]	3,0l 147 kW SKZ <ZPJ4> 6 Zyl.			
Knock sensor				
Org.no. →5168	06.89-02.91	HI,KZB		0 261 231 033
		KZG,VO		0 261 231 034
Org.no. 5169→	02.91-06.93	HI,KZB		0 261 231 070
		KZG,VO		0 261 231 071
3.0i 24V [Y3]	3,0l 147 kW UKZ <ZPJ4> 6 Zyl.			
Knock sensor				
Org.no. 5169→	06.93-06.94	HI,KZB		0 261 231 070
		KZG,VO		0 261 231 071
3.0i 24V [Y4]	3,0l 147 kW UKZ <ZPJ4> 6 Zyl.			
Throttle valve sensor	07.94-12.97			0 280 122 003
Knock sensor	07.94-12.97	KZG		0 261 231 071
Temperature sensor, intake air, injection system	07.94-12.97			0 280 130 039

Xsara				
1.4 HDi [N7]	1,4l 50 kW 8HZ 4 Zyl.			
Yaw rate sensor, brake system	01.03→			0 265 005 290
Wheel speed sensor, front	01.03→			0 265 006 389
Wheel speed sensor, rear	01.03→			0 265 006 203
1.4i [N6]	1,4l 55 kW KFX 4 Zyl.			
Knock sensor	07.97-08.00	N14		0 261 231 128
Pressure sensor, intake manifold, gasoline				
Org.no. →8056	07.97-12.98			0 261 230 012
Org.no. 8057→	01.99-08.00			0 261 230 057
Wheel speed sensor, front	07.97-08.00	SBR		0 265 006 389
Wheel speed sensor, rear	07.97-08.00	STB		0 265 006 203
1.4i [N7]	1,4l 55 kW KFW 4 Zyl.			
Knock sensor	09.00→			0 261 231 128
Pressure sensor, intake manifold, gasoline	09.00→			0 261 230 043
Yaw rate sensor, brake system	09.00→			0 265 005 290
Wheel speed sensor, front	09.00→			0 265 006 389
Wheel speed sensor, rear	09.00→			0 265 006 203
1.5 D [N6]	1,5l 42 kW VJY; VJZ 4 Zyl.			
Wheel speed sensor, front	07.97-08.00	SBR		0 265 006 389
Wheel speed sensor, rear	07.97-08.00	STB		0 265 006 203
1.6i [N6]	1,6l 65-66 kW NFZ 4 Zyl.			
Throttle valve sensor				
Org.no. →7874	07.97-06.98			0 280 122 003
Knock sensor				
Org.no. 7875→	07.98-08.00			0 261 231 128
Pressure sensor, intake manifold, gasoline				
Org.no. →7874	07.97-06.98			0 261 230 004
Org.no. 7875→8056	07.98-12.98			0 261 230 012
Temperature sensor, intake air, injection system				
Org.no. →7874	07.97-06.98			0 280 130 039



Wheel speed sensor, front	07.97-08.00	SBR	0 265 006 389
Wheel speed sensor, rear	07.97-08.00	STB	0 265 006 203
1.6 i 16V [N7]		1,6 l 80 kW NFU 4 Zyl.	
Throttle valve assembly	09.00→		0 280 750 085
Knock sensor			
Org.no. →9456	09.00-10.02		0 261 231 128
Org.no. 9457→	11.02→		0 261 231 168
Pressure sensor, intake manifold, gasoline	09.00→		0 261 230 043
Accelerator pedal module	09.00→		0 280 752 243
Yaw rate sensor, brake system	09.00→		0 265 005 290
Wheel speed sensor, front	09.00→		0 265 006 389
Wheel speed sensor, rear	09.00→		0 265 006 202
1.8 D [N6]		1,8 l 44 kW A9A,161A 4 Zyl.	
Wheel speed sensor, front	07.97-08.00	SBR	0 265 006 389
Wheel speed sensor, rear	07.97-08.00	STB	0 265 006 203
1.8 i [N6]		1,8 l 66 kW LFX 4 Zyl.	
Pressure sensor, intake manifold, gasoline	07.97-08.00		0 261 230 012
Wheel speed sensor, front	07.97-08.00	SBR	0 265 006 389
Wheel speed sensor, rear	07.97-08.00	STB	0 265 006 203
1.8 i [N6]		1,8 l 74-75 kW LFZ; L6A 4 Zyl.	
Wheel speed sensor, front	07.97-08.00	SBR	0 265 006 389
Wheel speed sensor, rear	07.97-08.00	STB	0 265 006 203
1.8 i 16V [N6]		1,8 l 81-82 kW LFY 4 Zyl.	
Throttle valve sensor	07.97-08.00		0 280 122 003
Pressure sensor, intake manifold, gasoline	07.97-08.00		0 261 230 012
Wheel speed sensor, front	07.97-08.00	SBR	0 265 006 389
Wheel speed sensor, rear	07.97-08.00	SBR	0 265 006 202
1.9 D [N6]		1,9 l 50/51 kW DJY; WJZ 4 Zyl.	
Wheel speed sensor, front	07.97-08.00	SBR	0 265 006 389
Wheel speed sensor, rear	07.97-08.00	STB	0 265 006 203
1.9 D [N7]		1,9 l 52 kW WJY 4 Zyl.	
Yaw rate sensor, brake system	09.00→		0 265 005 290
Wheel speed sensor, front	09.00→		0 265 006 389
Wheel speed sensor, rear	09.00→		0 265 006 203
1.9 D Turbo [N6]		1,9 l 55/66 kW DHV; DHY; D8A 4 Zyl.	
Wheel speed sensor, front	07.97-08.00	SBR	0 265 006 389
Wheel speed sensor, rear	07.97-08.00	STB	0 265 006 203
2.0 HDi [N6]		2,0 l 66 kW RHY 4 Zyl.	
Wheel speed sensor, front	02.99-08.00	SBR	0 265 006 389
Wheel speed sensor, rear	02.99-08.00	SBR	0 265 006 202
2.0 HDi [N7]		2,0 l 66 kW RHY 4 Zyl.	
High-pressure sensor (CR system)	09.00→	BO	0 281 002 283
Accelerator pedal module	09.00→		0 280 752 243
Yaw rate sensor, brake system	09.00→		0 265 005 290
Wheel speed sensor, front	09.00→		0 265 006 389
Wheel speed sensor, rear	09.00→		0 265 006 202
2.0 HDi [N7]		2,0 l 80 kW RHZ 4 Zyl.	
High-pressure sensor (CR system)	09.00→		0 281 002 283
Accelerator pedal module	09.00→		0 280 752 243
Yaw rate sensor, brake system	09.00→		0 265 005 290
Wheel speed sensor, front	09.00→		0 265 006 389
Wheel speed sensor, rear	09.00→		0 265 006 202
2.0 i 16V [N6]		2,0 l 97 kW RFV 4 Zyl.	
Throttle valve sensor	07.97-08.00		0 280 122 003
Knock sensor	07.97-08.00		0 261 231 045
Pressure sensor, intake manifold, gasoline	07.97-08.00		0 261 230 012
Wheel speed sensor, front	07.97-08.00	SBR	0 265 006 389
Wheel speed sensor, rear	07.97-08.00	SBR	0 265 006 202
2.0 i 16V [N6]		2,0 l 120-123 kW RFS 4 Zyl.	
Throttle valve sensor	07.97-08.00		0 280 122 009
Pressure sensor, intake manifold, gasoline	07.97-08.00		0 261 230 012
Wheel speed sensor, front	07.97-08.00	SBR	0 265 006 389
Wheel speed sensor, rear	07.97-08.00	SBR	0 265 006 202



2.0 i 16V [N7]		2,0 l 100 kW RFN 4 Zyl.
Pressure sensor, intake manifold, gasoline	09.00→	0 261 230 057
Yaw rate sensor, brake system	09.00→	0 265 005 290
Wheel speed sensor, front	09.00→	0 265 006 389
Wheel speed sensor, rear	09.00→	0 265 006 202

Xsara Break

1.4 HDi [N7]		1,4 l 50 kW 8HZ 4 Zyl.
Yaw rate sensor, brake system	01.03→	0 265 005 290
Wheel speed sensor, front	01.03→	0 265 006 389
Wheel speed sensor, rear	01.03→	0 265 006 441
1.4 i [N6]		1,4 l 55 kW KFX 4 Zyl.
Knock sensor	04.98-08.00	N14 0 261 231 128
Pressure sensor, intake manifold, gasoline		
Org.no. →8056	04.98-12.98	0 261 230 012
Org.no. 8057→	01.99-08.00	0 261 230 057
Wheel speed sensor, front	04.98-08.00	SBR 0 265 006 389
Wheel speed sensor, rear	04.98-08.00	STB 0 265 006 441
1.4 i [N7]		1,4 l 55 kW KFW 4 Zyl.
Knock sensor	09.00→	0 261 231 128
Pressure sensor, intake manifold, gasoline	09.00→	0 261 230 043
Yaw rate sensor, brake system	09.00→	0 265 005 290
Wheel speed sensor, front	09.00→	0 265 006 389
Wheel speed sensor, rear	09.00→	0 265 006 441
1.5 D [N6]		1,5 l 42 kW VJY; VJZ 4 Zyl.
Wheel speed sensor, front	10.97-08.00	SBR 0 265 006 389
Wheel speed sensor, rear	10.97-08.00	STB 0 265 006 441
1.6 i [N6]		1,6 l 65-66 kW NFZ 4 Zyl.
Throttle valve sensor		
Org.no. →7874	10.97-06.98	0 280 122 003
Knock sensor		
Org.no. 7875→	07.98-08.00	0 261 231 128
Pressure sensor, intake manifold, gasoline		
Org.no. →7874	10.97-06.98	0 261 230 004
Org.no. 7875→8056	07.98-12.98	0 261 230 012
Temperature sensor, intake air, injection system		
Org.no. →7874	10.97-06.98	0 280 130 039
Wheel speed sensor, front	10.97-08.00	SBR 0 265 006 389
Wheel speed sensor, rear	10.97-08.00	STB 0 265 006 441
1.6 i 16V [N7]		1,6 l 80 kW NFU 4 Zyl.
Throttle valve assembly	09.00→	0 280 750 085
Knock sensor		
Org.no. →9456	09.00-10.02	0 261 231 128
Org.no. 9457→	11.02→	0 261 231 168
Pressure sensor, intake manifold, gasoline	09.00→	0 261 230 043
Accelerator pedal module	09.00→	0 280 752 243
Yaw rate sensor, brake system	09.00→	0 265 005 290
Wheel speed sensor, front	09.00→	0 265 006 389
Wheel speed sensor, rear	09.00→	0 265 006 202
1.8 D [N6]		1,8 l 44 kW A9A,161A 4 Zyl.
Wheel speed sensor, front	04.98-08.00	SBR 0 265 006 389
Wheel speed sensor, rear	04.98-08.00	STB 0 265 006 441
1.8 i [N6]		1,8 l 66 kW LFX 4 Zyl.
Pressure sensor, intake manifold, gasoline	04.98-08.00	0 261 230 012
Wheel speed sensor, front	04.98-08.00	SBR 0 265 006 389
Wheel speed sensor, rear	04.98-08.00	STB 0 265 006 441
1.8 i [N6]		1,8 l 74-75 kW LFZ; L6A 4 Zyl.
Wheel speed sensor, front	04.98-08.00	SBR 0 265 006 389
Wheel speed sensor, rear	04.98-08.00	SBR 0 265 006 202
		STB 0 265 006 441



◀ Xsara Break

1.8 i 16V [N6]		1,8l 81-82 kW LFY 4 Zyl.
Throttle valve sensor	04.98-08.00	0 280 122 003
Pressure sensor, intake manifold, gasoline	04.98-08.00	0 261 230 012
Wheel speed sensor, front	04.98-08.00 SBR	0 265 006 389
Wheel speed sensor, rear	04.98-08.00 SBR	0 265 006 202
1.9 D [N6]		1,9l 50/51 kW DJY; WJZ 4 Zyl.
Wheel speed sensor, front	04.98-08.00 SBR	0 265 006 389
Wheel speed sensor, rear	04.98-08.00 STB	0 265 006 441
1.9 D [N7]		1,9l 52 kW WJY 4 Zyl.
Yaw rate sensor, brake system	09.00→	0 265 005 290
Wheel speed sensor, front	09.00→	0 265 006 389
Wheel speed sensor, rear	09.00→	0 265 006 441
1.9 D Turbo [N6]		1,9l 55/66 kW DHV; DHY 4 Zyl.
Wheel speed sensor, front	04.98-08.00 SBR	0 265 006 389
Wheel speed sensor, rear	04.98-08.00 STB	0 265 006 441
2.0 HDi [N6]		2,0l 66 kW RHY 4 Zyl.
Wheel speed sensor, front	02.99-08.00 SBR	0 265 006 389
Wheel speed sensor, rear	02.99-08.00 SBR	0 265 006 202
2.0 HDi [N7]		2,0l 66 kW RHY 4 Zyl.
High-pressure sensor (CR system)	09.00→ BO	0 281 002 283
Accelerator pedal module	09.00→	0 280 752 243
Yaw rate sensor, brake system	09.00→	0 265 005 290
Wheel speed sensor, front	09.00→	0 265 006 389
Wheel speed sensor, rear	09.00→	0 265 006 202
2.0 HDi [N7]		2,0l 80 kW RHZ 4 Zyl.
High-pressure sensor (CR system)	09.00→	0 281 002 283
Accelerator pedal module	09.00→	0 280 752 243
Yaw rate sensor, brake system	09.00→	0 265 005 290
Wheel speed sensor, front	09.00→	0 265 006 389
Wheel speed sensor, rear	09.00→	0 265 006 202
2.0 i 16V [N6]		2,0l 97 kW RFV 4 Zyl.
Throttle valve sensor	07.98-08.00	0 280 122 003
Knock sensor	07.98-08.00	0 261 231 045
Pressure sensor, intake manifold, gasoline	07.98-08.00	0 261 230 012
Wheel speed sensor, front	07.98-08.00 SBR	0 265 006 389
Wheel speed sensor, rear	07.98-08.00 SBR	0 265 006 202
2.0 i 16V [N7]		2,0l 100 kW RFN 4 Zyl.
Pressure sensor, intake manifold, gasoline	09.00→	0 261 230 057
Yaw rate sensor, brake system	09.00→	0 265 005 290
Wheel speed sensor, front	09.00→	0 265 006 389
Wheel speed sensor, rear	09.00→	0 265 006 202



Xsara Coupé			
1.4 i [N6]		1,4l 55 kW KFX 4 Zyl.	
Knock sensor	07.97-08.00 N14	0 261 231 128	
Pressure sensor, intake manifold, gasoline			
Org.no. →8056	07.97-12.98	0 261 230 012	
Org.no. 8057→	01.99-08.00	0 261 230 057	
Wheel speed sensor, front	07.97-08.00 SBR	0 265 006 389	
Wheel speed sensor, rear	07.97-08.00 STB	0 265 006 203	
1.4 i [N7]		1,4l 55 kW KFW 4 Zyl.	
Knock sensor	09.00→	0 261 231 128	
Pressure sensor, intake manifold, gasoline	09.00→	0 261 230 043	
Yaw rate sensor, brake system	09.00→	0 265 005 290	
Wheel speed sensor, front	09.00→	0 265 006 389	
Wheel speed sensor, rear	09.00→	0 265 006 203	
1.6 i 16V [N7]		1,6l 80 kW NFU 4 Zyl.	
Throttle valve assembly	09.00→	0 280 750 085	
Knock sensor			
Org.no. →9456	09.00-10.02	0 261 231 128	
Org.no. 9457→	11.02→	0 261 231 168	
Pressure sensor, intake manifold, gasoline	09.00→	0 261 230 043	



Accelerator pedal module	09.00→	0 280 752 243
Yaw rate sensor, brake system	09.00→	0 265 005 290
Wheel speed sensor, front	09.00→	0 265 006 389
Wheel speed sensor, rear	09.00→	0 265 006 202
1.8 D [N6]		1,8l 44 kW A9A,161A 4 Zyl.
Wheel speed sensor, front	07.97-08.00 SBR	0 265 006 389
Wheel speed sensor, rear	07.97-08.00 STB	0 265 006 203
1.8 i [N6]		1,8l 66 kW LFX 4 Zyl.
Pressure sensor, intake manifold, gasoline	07.97-08.00	0 261 230 012
Wheel speed sensor, front	07.97-08.00 SBR	0 265 006 389
Wheel speed sensor, rear	07.97-08.00 STB	0 265 006 203
1.8 i [N6]		1,8l 74 kW LFZ 4 Zyl.
Wheel speed sensor, front	07.97-08.00 SBR	0 265 006 389
Wheel speed sensor, rear	07.97-08.00 STB	0 265 006 203
1.8 i 16V [N6]		1,8l 81-82 kW LFY 4 Zyl.
Throttle valve sensor	07.97-08.00	0 280 122 003
Pressure sensor, intake manifold, gasoline	07.97-08.00	0 261 230 012
Wheel speed sensor, front	07.97-08.00 SBR	0 265 006 389
Wheel speed sensor, rear	07.97-08.00 SBR	0 265 006 202
1.9 D [N6]		1,9l 50/51 kW DJY; WJZ 4 Zyl.
Wheel speed sensor, front	07.97-08.00 SBR	0 265 006 389
Wheel speed sensor, rear	07.97-08.00 STB	0 265 006 203
1.9 D [N7]		1,9l 52 kW WJY 4 Zyl.
Yaw rate sensor, brake system	09.00→	0 265 005 290
Wheel speed sensor, front	09.00→	0 265 006 389
Wheel speed sensor, rear	09.00→	0 265 006 203
1.9 D Turbo [N6]		1,9l 55/66 kW DHV; DHY 4 Zyl.
Wheel speed sensor, front	07.97-08.00 SBR	0 265 006 389
Wheel speed sensor, rear	07.97-08.00 STB	0 265 006 203
2.0 HDi [N6]		2,0l 66 kW RHY 4 Zyl.
Wheel speed sensor, front	02.99-08.00 SBR	0 265 006 389
Wheel speed sensor, rear	02.99-08.00 SBR	0 265 006 202
2.0 HDi [N7]		2,0l 66 kW RHY 4 Zyl.
High-pressure sensor (CR system)	09.00→ BO	0 281 002 283
Accelerator pedal module	09.00→	0 280 752 243
Yaw rate sensor, brake system	09.00→	0 265 005 290
Wheel speed sensor, front	09.00→	0 265 006 389
Wheel speed sensor, rear	09.00→	0 265 006 202
2.0 HDi [N7]		2,0l 80 kW RHZ 4 Zyl.
High-pressure sensor (CR system)	09.00→	0 281 002 283
Accelerator pedal module	09.00→	0 280 752 243
Yaw rate sensor, brake system	09.00→	0 265 005 290
Wheel speed sensor, front	09.00→	0 265 006 389
Wheel speed sensor, rear	09.00→	0 265 006 202
2.0 i 16V [N6]		2,0l 97 kW RFV 4 Zyl.
Throttle valve sensor	07.97-08.00	0 280 122 003
Knock sensor	07.97-08.00	0 261 231 045
Pressure sensor, intake manifold, gasoline	07.97-08.00	0 261 230 012
Wheel speed sensor, front	07.97-08.00 SBR	0 265 006 389
Wheel speed sensor, rear	07.97-08.00 SBR	0 265 006 202
2.0 i 16V [N6]		2,0l 120-123 kW RFS 4 Zyl.
Throttle valve sensor	07.97-08.00	0 280 122 009
Pressure sensor, intake manifold, gasoline	07.97-08.00	0 261 230 012
Wheel speed sensor, front	07.97-08.00 SBR	0 265 006 389
Wheel speed sensor, rear	07.97-08.00 SBR	0 265 006 202
2.0 i 16V [N7]		2,0l 100 kW RFN 4 Zyl.
Pressure sensor, intake manifold, gasoline	09.00→	0 261 230 057
Yaw rate sensor, brake system	09.00→	0 265 005 290
Wheel speed sensor, front	09.00→	0 265 006 389
Wheel speed sensor, rear	09.00→	0 265 006 202
2.0 i 16V [N7]		2,0l 120 kW RFS 4 Zyl.
Throttle valve sensor	09.00→	0 280 122 009
Pressure sensor, intake manifold, gasoline	09.00→	0 261 230 057



Yaw rate sensor, brake system	09.00→	0 265 005 290
Wheel speed sensor, front	09.00→	0 265 006 389
Wheel speed sensor, rear	09.00→	0 265 006 202

Xsara Picasso

1.6 HDi [N68] 1,6l 66 kW 9HX 4 Zyl.		
Yaw rate sensor, brake system	09.05→	0 265 005 290
Wheel speed sensor, front	09.05→	0 265 007 665
1.6 HDi [N68] 1,6l 80 kW 9HY/9HZ 4 Zyl.		
Yaw rate sensor, brake system	05.04→	0 265 005 290
Wheel speed sensor, front		
Org.no. →10220FV,→10312UW,→1031278	05.04→	0 265 006 389
Org.no. 10221FV→,10313UW→,1031378→	05.04→	0 265 007 665
1.6 i 1,6l 67 kW 4 Zyl.		
Knock sensor	06.02-02.07	0 261 231 128
Pressure sensor, intake manifold, gasoline	06.02-02.07	0 261 230 043
Wheel speed sensor, front	06.02-02.07	0 265 006 389
Wheel speed sensor, rear	06.02-02.07	0 265 006 659
1.6 i [N68] 1,6l 66 kW NFZ 4 Zyl.		
Knock sensor	01.00→	0 261 231 128
Pressure sensor, intake manifold, gasoline	01.00→	0 261 230 057
Wheel speed sensor, front		
Org.no. →10220FV,→10312UW,→1031278	01.00→	0 265 006 389
Org.no. 10221FV→,10313UW→,1031378→	01.00→	0 265 007 665
Wheel speed sensor, rear	01.00→	0 265 006 659
1.6 i [N68] 1,6l 74 kW NFV 4 Zyl.		
Knock sensor		
Org.no. →9491	01.00-11.02	0 261 231 128
Org.no. 9492→	12.02→	0 261 231 168
Pressure sensor, intake manifold, gasoline	01.00→	0 261 230 043
Wheel speed sensor, front		
Org.no. →10220FV,→10312UW,→1031278	01.00→	0 265 006 389
Org.no. 10221FV→,10313UW→,1031378→	01.00→	0 265 007 665
Wheel speed sensor, rear	01.00→	0 265 006 659
1.6 i 16V [N68] 1,6l 80 kW NFU;N6A 4 Zyl.		
Knock sensor	03.05→	0 261 231 168
Pressure sensor, intake manifold, gasoline	03.05→	0 261 230 043
Yaw rate sensor, brake system	03.05→	0 265 005 290
Wheel speed sensor, front	03.05→	0 265 007 665
1.6 i 16V Flex 1,6l 81-83 kW TU5JP4 4 Zyl.		
Throttle valve assembly	10.06→	0 280 750 085
Pressure sensor, intake manifold, gasoline	10.06→	0 261 230 043
Accelerator pedal module	10.06→	0 280 752 251
1.8 i [N68] 1,8l 85 kW 6FZ 4 Zyl.		
Pressure sensor, intake manifold, gasoline	01.00→	0 261 230 057
Yaw rate sensor, brake system	01.00→	0 265 005 290
Wheel speed sensor, front		
Org.no. →10220FV,→10312UW,→1031278	01.00→	0 265 006 389
Org.no. 10221FV→,10313UW→,1031378→	01.00→	0 265 007 665
Wheel speed sensor, rear	01.00→	0 265 006 659
2.0 HDi [N68] 2,0l 66 kW RHY 4 Zyl.		
High-pressure sensor (CR system)	01.00→	0 281 002 283
Yaw rate sensor, brake system	01.00→	0 265 005 290
Wheel speed sensor, front		
Org.no. →10220FV,→10312UW,→1031278	01.00→	0 265 006 389
Org.no. 10221FV→,10313UW→,1031378→	01.00→	0 265 007 665
Wheel speed sensor, rear	01.00→	0 265 006 659
2.0 i 2,0l 97 kW 4 Zyl.		
Pressure sensor, intake manifold, gasoline	06.02-02.07	EML 0 261 230 058
		MGS 0 261 230 057
Wheel speed sensor, front	06.02-02.07	0 265 006 389
Wheel speed sensor, rear	06.02-02.07	0 265 006 659



2.0 i 16V 2,0l 100 kW 4 Zyl.		
Wheel speed sensor, front	10.00→	0 265 006 389
Wheel speed sensor, rear	10.00→	0 265 006 659
2.0 i 16V [N68] 2,0l 100 kW RFM/RFN 4 Zyl.		
Pressure sensor, intake manifold, gasoline	03.01→	EML 0 261 230 058
		MGS 0 261 230 057
Yaw rate sensor, brake system	03.01→	0 265 005 290
Wheel speed sensor, front		
Org.no. →10220FV,→10312UW,→1031278	03.01→	0 265 006 389
Org.no. 10221FV→,10313UW→,1031378→	03.01→	0 265 007 665
Wheel speed sensor, rear	03.01→	0 265 006 659

ZX

1.1 [N20/N21] 1,1l 40-44 kW H1A,H1B 4 Zyl.		
Wheel speed sensor, front	03.91-08.96	0 265 006 199
Wheel speed sensor, rear	03.91-08.96	KOB 0 265 006 204
Org.no. →6748	03.91-04.95	LIM,SBR 0 265 006 204
Org.no. 6749→	05.95-08.96	LIM,TBR 0 265 006 203
1.1 i [N20/N21] 1,1l 44 kW HDY 4 Zyl.		
Wheel speed sensor, front	09.96-06.97	0 265 006 199
Wheel speed sensor, rear	09.96-06.97	KOB 0 265 006 204
Org.no. 6749→	09.96-06.97	LIM,TBR 0 265 006 203
1.1 i [N20/N21] 1,1l 44 kW HDY Kat. 4 Zyl.		
Temperature sensor, coolant, injection system	04.94-08.96	0 280 130 026
Wheel speed sensor, front	04.94-08.96	0 265 006 199
Wheel speed sensor, rear	04.94-08.96	KOB 0 265 006 204
Org.no. →6748	04.94-04.95	LIM,SBR 0 265 006 204
Org.no. 6749→	05.95-08.96	LIM,TBR 0 265 006 203
1.1 i [N20/N21] 1,1l 44 kW HDZ 4 Zyl.		
Wheel speed sensor, front	09.96-06.97	0 265 006 199
Wheel speed sensor, rear	09.96-06.97	KOB 0 265 006 204
Org.no. 6749→	09.96-06.97	LIM,TBR 0 265 006 203
1.1 i [N20/N21] 1,1l 44 kW HDZ Kat. 4 Zyl.		
Wheel speed sensor, front	10.91-03.94	0 265 006 199
Wheel speed sensor, rear	10.91-03.94	0 265 006 204
1.4 1,4l 49 kW K5A 4 Zyl.		
Wheel speed sensor, front	02.92-12.99	0 265 006 199
Wheel speed sensor, rear	02.92-12.99	0 265 006 203
1.4 [N20/N21] 1,4l 55 kW K2D 4 Zyl.		
Wheel speed sensor, front	03.91-08.93	0 265 006 199
Wheel speed sensor, rear	03.91-08.93	0 265 006 204
1.4 [N20/N21] 1,4l 55 kW K5A 4 Zyl.		
Wheel speed sensor, front	09.93-12.95	0 265 006 199
Wheel speed sensor, rear	09.93-12.95	KOB 0 265 006 204
Org.no. →6748	09.93-04.95	LIM,SBR 0 265 006 204
Org.no. 6749→	05.95-12.95	LIM,TBR 0 265 006 203
1.4 D [N20/N21] 1,4l 37-39 kW K9Y 4 Zyl.		
Wheel speed sensor, front	06.94-06.97	0 265 006 199
Wheel speed sensor, rear	06.94-06.97	KOB 0 265 006 204
Org.no. →6748	06.94-04.95	LIM,SBR 0 265 006 204
Org.no. 6749→	05.95-06.97	LIM,TBR 0 265 006 203
1.4 i [N20/N21] 1,4l 55 kW KDX Kat. 4 Zyl.		
Temperature sensor, coolant, injection system		
Org.no. 5783→	08.92-08.96	BO 0 280 130 026
Wheel speed sensor, front	08.92-08.96	0 265 006 199
Wheel speed sensor, rear	08.92-08.96	KOB 0 265 006 204
Org.no. →6748	08.92-04.95	LIM,SBR 0 265 006 204
Org.no. 6749→	05.95-08.96	LIM,TBR 0 265 006 203
1.4 i [N20/N21] 1,4l 55 kW KDY,HDY Kat. 4 Zyl.		
Wheel speed sensor, front	03.91-08.92	0 265 006 199
Wheel speed sensor, rear	03.91-08.92	0 265 006 204



Product				

◀ ZX

1.4 i [N20/N21]		1,4l 55 kW KFX 4 Zyl.
Pressure sensor, intake manifold, gasoline	05.96-10.97	0 261 230 012
Wheel speed sensor, front	05.96-10.97	0 265 006 199
Wheel speed sensor, rear	05.96-10.97 KOB	0 265 006 204
Org.no. 6749→	05.96-10.97 LIM,TBR	0 265 006 203
1.4 i 8V		1,4l 55 kW KFX 4 Zyl.
Throttle valve sensor	01.97→	0 280 122 003
Pressure sensor, intake manifold, gasoline	01.97→	0 261 230 004
		0 261 230 024
Temperature sensor, intake air, injection system	01.97→	0 280 130 039
Temperature sensor, coolant, injection system	01.97→	0 280 130 026
Wheel speed sensor, front	01.97→	0 265 006 199
Wheel speed sensor, rear	01.97→	0 265 006 203
1.5 D [N20/N21]		1,5l 42 kW VJY;VJZ 4 Zyl.
Wheel speed sensor, front	09.96-10.97	0 265 006 199
Wheel speed sensor, rear	09.96-10.97 KOB	0 265 006 204
Org.no. 6749→	09.96-10.97 LIM,TBR	0 265 006 203
1.6 i [N20/N21]		1,6l 65 kW BFZ Kat. 4 Zyl.
Wheel speed sensor, front	07.93-10.97	0 265 006 199
Wheel speed sensor, rear	07.93-10.97 KOB	0 265 006 204
Org.no. →6748	07.93-04.95 LIM,SBR	0 265 006 204
Org.no. 6749→	05.95-10.97 LIM,TBR	0 265 006 203
1.6 i [N20/N21]		1,6l 65-66 kW BDY Kat.; B4A 4 Zyl.
Temperature sensor, intake air, injection system	03.91-12.94	0 280 130 039
Wheel speed sensor, front	03.91-12.94	0 265 006 199
Wheel speed sensor, rear	03.91-12.94	0 265 006 204
1.6 i [N20/N21]		1,6l 65-66 kW NFZ 4 Zyl.
Throttle valve sensor	02.96-10.97	0 280 122 003
Pressure sensor, intake manifold, gasoline	02.96-10.97 BO	0 261 230 004
Temperature sensor, intake air, injection system	02.96-10.97	0 280 130 039
Wheel speed sensor, front	02.96-10.97	0 265 006 199
Wheel speed sensor, rear	02.96-10.97 KOB	0 265 006 204
Org.no. 6749→	02.96-10.97 LIM,TBR	0 265 006 203
1.6 i 8V		1,6l 65 kW NFZ 4 Zyl.
Throttle valve sensor	10.96→	AG 0 280 122 011
		GS 0 280 122 003
Pressure sensor, intake manifold, gasoline	10.96→	0 261 230 024
Temperature sensor, intake air, injection system	10.96→	0 280 130 039
Temperature sensor, coolant, injection system	10.96→	0 280 130 026
Wheel speed sensor, front	10.96→	0 265 006 199
Wheel speed sensor, rear	10.96→	0 265 006 203
1.6 8V		1,6l 55 kW K2D 4 Zyl.
Wheel speed sensor, front	04.92-12.99	0 265 006 199
Wheel speed sensor, rear	04.92-12.99	0 265 006 203
1.8 D [N20/N21]		1,8l 44 kW A9A,161A 4 Zyl.
Wheel speed sensor, front	03.91-10.97	0 265 006 199
Wheel speed sensor, rear	03.91-10.97 KOB	0 265 006 204
Org.no. →6748	03.91-04.95 LIM,SBR	0 265 006 204
Org.no. 6749→	05.95-10.97 LIM,TBR	0 265 006 203
1.8 i [N20/N21]		1,8l 74-76 kW LFZ Kat.; L6A 4 Zyl.
Pressure sensor, intake manifold, gasoline	07.92-10.97 BO	0 261 230 004
Wheel speed sensor, front	07.92-10.97	0 265 006 199
Wheel speed sensor, rear	07.92-10.97 KOB	0 265 006 204
Org.no. →6748	07.92-04.95 LIM,SBR	0 265 006 204
Org.no. 6749→	05.95-10.97 LIM,TBR	0 265 006 203
1.8 i 16V [N20/N21]		1,8l 81 kW LFY 4 Zyl.
Throttle valve sensor	01.96-02.98	0 280 122 003
Knock sensor	01.96-02.98	0 261 231 109
Pressure sensor, intake manifold, gasoline	01.96-02.98	0 261 230 012
Wheel speed sensor, front	01.96-02.98	0 265 006 199
Wheel speed sensor, rear	01.96-02.98 KOB	0 265 006 204
		LIM,SBR 0 265 006 202
Org.no. 6749→	01.96-02.98 LIM,TBR	0 265 006 203

Product				

1.9 D [N20/N21]		1,9l 47-48 kW DJZ 4 Zyl.
Wheel speed sensor, front	03.91-04.94	0 265 006 199
Wheel speed sensor, rear	03.91-04.94	0 265 006 204
1.9 D [N20/N21]		1,9l 50/51-52 kW DJY; D9B 4 Zyl.
Wheel speed sensor, front	03.91-10.97	0 265 006 199
Wheel speed sensor, rear	03.91-10.97 KOB	0 265 006 204
Org.no. →6748	03.91-04.95 LIM,SBR	0 265 006 204
Org.no. 6749→	05.95-10.97 LIM,TBR	0 265 006 203
1.9 D Turbo [N20/N21]		1,9l 66/68 kW DHY; D8A 4 Zyl.
Wheel speed sensor, front	07.92-10.97	0 265 006 199
Wheel speed sensor, rear	07.92-10.97 KOB	0 265 006 204
		LIM,SBR 0 265 006 202
Org.no. 6749→	05.95-10.97 LIM,TBR	0 265 006 203
1.9 i [N20/N21]		1,9l 88-90 kW DKZ,DFY Kat. 4 Zyl.
Throttle valve sensor	03.91-10.97	0 280 120 327
Speed sensor, ignition/injection	03.91-10.97	0 261 210 043
Temperature sensor, coolant, injection system	03.91-10.97	0 280 130 026
Wheel speed sensor, front	03.91-10.97	0 265 006 199
Wheel speed sensor, rear	03.91-10.97 KOB	0 265 006 204
		LIM 0 265 006 202
1.9 i [N20/N21]		1,9l 93-96 kW D6E 4 Zyl.
Speed sensor, ignition/injection	03.91-10.97	0 261 210 043
Temperature sensor, intake air, injection system	03.91-10.97	0 280 130 039
Temperature sensor, coolant, injection system	03.91-10.97	0 280 130 026
Wheel speed sensor, front	03.91-10.97	0 265 006 199
Wheel speed sensor, rear	03.91-10.97 KOB	0 265 006 204
		LIM 0 265 006 202
2.0 i [N20/N21]		2,0l 89-90 kW RFX Kat.; R6D 4 Zyl.
Knock sensor	07.92-10.97 KZG	0 261 231 071
Wheel speed sensor, front	07.92-10.97	0 265 006 199
Wheel speed sensor, rear	07.92-10.97 KOB	0 265 006 204
		LIM 0 265 006 202
2.0 i 16V [N20/N21]		2,0l 110-114 kW RFY,RFT Kat. 4 Zyl.
Throttle valve sensor		
Org.no. →6778	07.92-05.95	0 280 122 001
Knock sensor	07.92-10.97 KZG	0 261 231 071
Wheel speed sensor, front	07.92-10.97	0 265 006 199
Wheel speed sensor, rear	07.92-10.97 KOB	0 265 006 204
		LIM 0 265 006 202
2.0 i 16V [N20/N21]		2,0l 120-122 kW RFS 4 Zyl.
Throttle valve sensor	09.96-10.97	0 280 122 009
Pressure sensor, intake manifold, gasoline	09.96-10.97	0 261 230 012
Wheel speed sensor, front	09.96-10.97	0 265 006 199
Wheel speed sensor, rear	09.96-10.97 KOB	0 265 006 204

DACIA

Logan

1.4 MPI [KS./LS.]		1,4l 55 kW K7J 710 4 Zyl.
Wheel speed sensor, front	07.04→	0 265 007 596
Wheel speed sensor, rear	07.04→	LAB 0 265 007 583
		RAB 0 265 007 582
1.5 dCi [KS./LS.]		1,5l 48/50 kW K9K 790; K9K 792 4 Zyl.
Boost pressure sensor, Diesel	06.05→	0 281 002 593
Wheel speed sensor, front	06.05→	0 265 007 596
Wheel speed sensor, rear	06.05→	LAB 0 265 007 583
		RAB 0 265 007 582
1.6 MPI [KS./LS.]		1,6l 64 kW K7M 710 4 Zyl.
Wheel speed sensor, front	07.04→	0 265 007 596
Wheel speed sensor, rear	07.04→	LAB 0 265 007 583
		RAB 0 265 007 582

Product



1.6 16V [KS./LS.]		1,6l 77 kW K4M 690 4 Zyl.
Wheel speed sensor, front	12.05→	0 265 007 596
Wheel speed sensor, rear	12.05→	LAB 0 265 007 583
		RAB 0 265 007 582

DAEWOO

Korando

2.0 i 16V [KJ]		2,0l 100 kW M161 E20 4 Zyl.
Wheel speed sensor, front	07.96-12.00	0 265 006 134
Wheel speed sensor, rear	07.96-12.00	0 265 006 343
2.3 D [KJ]		2,3l 57 kW OM661 D23 4 Zyl.
Wheel speed sensor, front	07.96-12.00	0 265 006 134
Wheel speed sensor, rear	07.96-12.00	0 265 006 343
2.3 i 16V [KJ]		2,3l 103 kW M161 E23 4 Zyl.
Wheel speed sensor, front	07.96-12.00	0 265 006 134
Wheel speed sensor, rear	07.96-12.00	0 265 006 343
2.9 D [KJ]		2,9l 70-73 kW OM662 D29 5 Zyl.
Wheel speed sensor, front	07.96-12.00	0 265 006 134
Wheel speed sensor, rear	07.96-12.00	0 265 006 343
2.9 TD Intercooler [KJ]		2,9l 95 kW OM662 D29 5 Zyl.
Wheel speed sensor, front	07.96-12.00	0 265 006 134
Wheel speed sensor, rear	07.96-12.00	0 265 006 343
3.2 i 24V [KJ]		3,2l 162 kW M162 E32 6 Zyl.
Wheel speed sensor, front	07.96-12.00	0 265 006 134
Wheel speed sensor, rear	07.96-12.00	0 265 006 343

Leganza

1.8 i [KLAV, V100]		1,8l 66-70/100 kW D-TEC; E-TEC 4 Zyl.
Wheel speed sensor, front	03.97-12.02	0 265 006 414
Wheel speed sensor, rear	03.97-12.02	0 265 006 415
2.0 i [KLAV, V100]		2,0l 93/98-107 kW T20SED; X20SED 4 Zyl.
Wheel speed sensor, front	03.97-12.02	0 265 006 414
Wheel speed sensor, rear	03.97-12.02	0 265 006 415
2.2 i [KLAV, V100]		2,2l 100 kW T22SED 4 Zyl.
Wheel speed sensor, front	09.98-12.02	0 265 006 414
Wheel speed sensor, rear	09.98-12.02	0 265 006 415

Musso

2.0 i 16V [MJ]		2,0l 100 kW M161 E20 4 Zyl.
Wheel speed sensor, front	05.96-12.00	0 265 006 134
Wheel speed sensor, rear	05.96-12.00	0 265 006 135
2.3 D [MJ]		2,3l 57 kW OM661 D23 4 Zyl.
Wheel speed sensor, front	07.93-12.00	0 265 006 134
Wheel speed sensor, rear	07.93-12.00	0 265 006 135
2.3 i 16V [MJ]		2,3l 103 kW M161 E23 4 Zyl.
Wheel speed sensor, front	05.96-12.00	0 265 006 134
Wheel speed sensor, rear	05.96-12.00	0 265 006 135
2.9 D [MJ]		2,9l 72 kW OM 662 D29 5 Zyl.
Wheel speed sensor, front	07.93-12.00	0 265 006 134
Wheel speed sensor, rear	07.93-12.00	0 265 006 135
2.9 TD Intercooler [MJ]		2,9l 88 kW OM662 D29 5 Zyl.
Wheel speed sensor, front	05.97-12.00	0 265 006 134
Wheel speed sensor, rear	05.97-12.00	0 265 006 135
3.2 i 24V [MJ]		3,2l 162 kW M162 E32 6 Zyl.
Speed sensor, ignition/injection	01.96-12.00	0 281 002 123
Wheel speed sensor, front	01.96-12.00	0 265 006 134
Wheel speed sensor, rear	01.96-12.00	0 265 006 135

Product



Nubira

1.6 i [KALJ, J100]		1,6l 78 kW A16DMS 4 Zyl.	
Wheel speed sensor, front	09.97-09.99	LAB	0 265 006 593
		RAB	0 265 006 594
1.6 i [KALJ, 150, 190]		1,6l 78 kW 4 Zyl.	
Wheel speed sensor, front	10.99-06.03	LAB	0 265 006 593
		RAB	0 265 006 594
Wheel speed sensor, rear	10.99-06.03	LAB	0 265 006 595
		RAB	0 265 006 596
2.0 i [KALJ, J100]		2,0l 98 kW X20SED 4 Zyl.	
Wheel speed sensor, front	09.97-09.99	LAB	0 265 006 593
		RAB	0 265 006 594
2.0 i [KALJ, 150, 190]		2,0l 79/98 kW ; X20SED 4 Zyl.	
Wheel speed sensor, front	10.99-06.03	LAB	0 265 006 593
		RAB	0 265 006 594
Wheel speed sensor, rear	10.99-06.03	LAB	0 265 006 595
		RAB	0 265 006 596

Nubira Hatchback

1.6 i [KALJ, J100]		1,6l 78 kW A16DMS 4 Zyl.	
Wheel speed sensor, front	09.97-09.99	LAB	0 265 006 593
		RAB	0 265 006 594
2.0 i [KALJ, J100]		2,0l 98 kW X20SED 4 Zyl.	
Wheel speed sensor, front	09.97-09.99	LAB	0 265 006 593
		RAB	0 265 006 594

Nubira Station Wagon

1.6 i [KALJ, J100]		1,6l 78 kW A16DMS 4 Zyl.	
Wheel speed sensor, front	09.97-09.99	LAB	0 265 006 593
		RAB	0 265 006 594
1.6 i [KALJ, 150, 190]		1,6l 78 kW 4 Zyl.	
Wheel speed sensor, front	10.99-06.03	LAB	0 265 006 593
		RAB	0 265 006 594
Wheel speed sensor, rear	10.99-06.03	LAB	0 265 006 595
		RAB	0 265 006 596
2.0 i [KALJ, J100]		2,0l 98 kW X20SED 4 Zyl.	
Wheel speed sensor, front	09.97-09.99	LAB	0 265 006 593
		RAB	0 265 006 594
2.0 i [KALJ, 150, 190]		2,0l 98 kW X20SED 4 Zyl.	
Wheel speed sensor, front	10.99-06.03	LAB	0 265 006 593
		RAB	0 265 006 594
Wheel speed sensor, rear	10.99-06.03	LAB	0 265 006 595
		RAB	0 265 006 596

Prince

2.0 LPG		2,0l 83-85 kW Holden-C 20 LE 4 Zyl.
Wheel speed sensor, front	01.91-03.96	0 265 006 136
Wheel speed sensor, rear	01.91-03.96	0 265 006 137

DAIMLER LTD.

Sovereign

4.2		4,2l 150 kW 6 Zyl.
Air flow sensor, gasoline injection	03.79-12.89	0 280 203 006
		0 986 280 022





Product

DODGE			
Caravan			
2.5 TD [NS]	2,5 l	85 kW	VM HR 425 CLIEE 4 Zyl.
Air mass meter, diesel	01.95-08.03		0 281 002 132
Pressure sensor, intake manifold, diesel	08.97-08.03		0 281 002 205
Dakota			
3.9 [AN]	3,9 l	131-134 kW	EHC 6 Zyl.
Speed sensor, ignition/injection	01.97-12.03	GS	0 258 005 704
5.2 [AN]	5,2 l	164-172 kW	ELF, ELG 8 Zyl.
Speed sensor, ignition/injection	01.97-12.00	GS	0 258 005 704
Shadow			
2.2	2,2 l	69 kW	EDF 4 Zyl.
Temperature sensor, intake air, injection system	01.87-12.94		0 280 130 046
Spirit			
2.5 iLE	2,5 l	74 kW	4 TBI 4 Zyl.
Temperature sensor, intake air, injection system	10.88-08.93		0 280 130 046
			0 280 130 063
600			
2.2 i	2,2 l	72 kW	EDF 4 Zyl.
Temperature sensor, coolant, injection system	09.85-08.88		0 280 130 046
			0 280 130 063
FERRARI			
F50			
V12	4,7 l	383 kW	12 Zyl.
Throttle valve sensor	07.95→		0 280 122 011
Air mass meter, gasoline injection	07.95→		0 280 213 012
			0 986 280 110
Phase sensor	07.95→		0 232 103 006
Pulse generator, ignition/Jetronic	07.95→		0 261 210 104
Temperature sensor, coolant, injection system	07.95→		0 280 130 026
F355			
3.5	3,5 l	280 kW	F129B/40 8 Zyl.
Throttle valve sensor	05.94-10.95		0 280 122 001
Air mass meter, gasoline injection	05.94-10.95		0 280 213 023
Phase sensor	05.94-10.95		0 232 103 006
Pulse generator, ignition/Jetronic	05.94-10.95		0 261 210 126
Temperature sensor, coolant, injection system	05.94-10.95		0 280 130 026
Spider	3,5 l	280 kW	F129C/40 8 Zyl.
Throttle valve sensor	10.95→		0 280 122 004
Air mass meter, gasoline injection	10.95→		0 280 217 800
Phase sensor	10.95→		0 232 103 006
Pulse generator, ignition/Jetronic	10.95→		0 261 210 126
Knock sensor	10.95→		0 261 231 007
Temperature sensor, intake air, injection system	10.95→		0 280 130 039
Temperature sensor, coolant, injection system	10.95→		0 280 130 026

Product

F360			
Modena		3,5l	298 kW F131 8 Zyl.
Throttle valve assembly	03.99-12.04	0 280 750 038	
Air mass meter, gasoline injection	03.99-12.04	0 280 218 012	
Phase sensor	03.99-12.04	0 232 103 026	
Speed sensor, ignition/injection	03.99-12.04	0 261 210 198	
Knock sensor	03.99-12.04	0 261 231 145	
Pressure sensor, intake manifold, gasoline	03.99-12.04	0 261 230 015	
Temperature sensor, coolant, injection system	03.99-12.04	0 281 002 170	
Spider		3,5l	294 kW F131B 8 Zyl.
Throttle valve assembly	06.00→	0 280 750 038	
Air mass meter, gasoline injection	06.00→	0 280 218 012	
Phase sensor	06.00→	0 232 103 026	
Speed sensor, ignition/injection	06.00→	0 261 210 198	
Knock sensor	06.00→	0 261 231 145	
Pressure sensor, intake manifold, gasoline	06.00→	0 261 230 015	
Temperature sensor, coolant, injection system	06.00→	0 281 002 170	
Mondial			
T		3,4l	221 kW F 119 D 8 Zyl.
Air mass meter, gasoline injection	10.89-02.94	0 280 212 018	
Speed sensor, ignition/injection	10.89-02.94	0 261 210 029	
Temperature sensor, coolant, injection system	10.89-02.94	0 280 130 026	
T		3,4l	221 kW F 119 DL 8 Zyl.
Throttle valve sensor	11.88-02.94	0 280 120 311	
Air mass meter, gasoline injection	11.88-02.94	0 280 212 018	
Speed sensor, ignition/injection	11.88-02.94	0 261 210 029	
Temperature sensor, coolant, injection system	11.88-02.94	0 280 130 026	
Relay, pump	11.88-02.94	0 332 014 140	
8		3,2l	199 kW F 105 NS.. 8 Zyl.
Throttle valve sensor	01.88-12.88	0 280 120 310	
Air flow sensor, gasoline injection	01.88-12.88	0 438 120 207	
Relay, Jetronic	01.88-12.88	0 332 204 001	
8		3,2l	199 kW F 105 P..Kat. 4 Zyl.
Air flow sensor, gasoline injection	01.88-12.88	0 438 121 066	
Pressure sensor, intake manifold, gasoline	01.88-12.88	0 280 101 003	
Relay, Jetronic	01.88-12.88	0 280 230 009	
8 Quattrovalvole		2,9l	169 kW F 105 E..Kat. 8 Zyl.
Throttle valve sensor	10.83-07.87	0 280 120 310	
Air flow sensor, gasoline injection	10.83-07.87	0 438 120 164	
Pressure sensor, intake manifold, gasoline	10.83-07.87	0 280 101 003	
Relay, Jetronic	10.83-07.87	12S	0 332 204 101
8 Quattrovalvole		3,2l	191 kW F 105 C..Kat. 8 Zyl.
Throttle valve sensor	01.86-12.87	0 280 120 310	
Air flow sensor, gasoline injection	01.86-12.87	0 438 120 164	
Pressure sensor, intake manifold, gasoline	01.86-12.87	0 280 101 003	
8 Quattrovalvole		3,2l	195/199 kW F 105 C.. 8 Zyl.
Throttle valve sensor	09.85-12.87	0 280 120 310	
Air flow sensor, gasoline injection	09.85-12.87	0 438 120 207	
Relay, Jetronic	09.85-12.87	0 332 204 001	
Testarossa			
4.9		4,9l	272 kW F 113 B..Kat. 12 Zyl.
Throttle valve sensor	08.86-10.91	0 280 120 310	
Air flow sensor, gasoline injection	08.86-10.91	F 026 TX2 065	
		🏎️ F 026 TX2 065	
Pressure sensor, intake manifold, gasoline	08.86-10.91	0 280 101 001	
Temperature sensor, coolant, injection system	08.86-10.91	0 280 130 032	

Product



4.9			4,9l 287 kW F 113 A../B.. 12 Zyl.
Throttle valve sensor	01.86-10.91		0 280 120 310
Air flow sensor, gasoline injection	01.86-10.91		F 026 TX2 065 F 026 TX2 065
Pressure sensor, intake manifold, gasoline	01.86-10.91		0 280 101 001
Temperature sensor, coolant, injection system	01.86-10.91		0 280 130 032
Relay, Jetronic	01.86-10.91		0 280 230 012

208

GTB Turbo			2,0l 162 kW F 106 D.. 8 Zyl.
Air flow sensor, gasoline injection	06.82-10.89		0 438 120 191
Speed relay	06.82-10.89		0 280 230 008
Relay, pump	06.82-10.89		0 280 230 007
GTB Turbo			2,0l 187 kW F 106 N.. 8 Zyl.
Throttle valve sensor	04.86-10.90		0 280 120 314
Air flow sensor, gasoline injection	04.86-10.90		0 438 120 212
GTS Turbo			2,0l 187 kW F 106 N.. 8 Zyl.
Throttle valve sensor	04.86-10.90		0 280 120 314
Air flow sensor, gasoline injection	04.86-10.90		0 438 120 212

328

GTB			3,2l 188 kW F 105 C.. 8 Zyl.
Throttle valve sensor	09.85-09.89		0 280 120 310
Air flow sensor, gasoline injection	09.85-09.89		0 438 120 164
Relay, Jetronic	09.85-09.89		0 332 204 001
GTB			3,2l 195/199 kW F 105 C.. 8 Zyl.
Throttle valve sensor	09.85-12.88		0 280 120 310
Air flow sensor, gasoline injection	09.85-12.88		0 438 120 207
Relay, Jetronic	09.85-12.88		0 332 204 001
GTB			3,2l 199 kW F 105 CB.. 8 Zyl.
Throttle valve sensor	01.88-09.89		0 280 120 310
Air flow sensor, gasoline injection	01.88-09.89		0 438 120 207
Relay, Jetronic	01.88-09.89		0 332 204 001
GTS			3,2l 195/199 kW F 105 C..; F 105 CB.. 8 Zyl.
Throttle valve sensor	09.85-09.89		0 280 120 310
Air flow sensor, gasoline injection	09.85-09.89		0 438 120 207
Relay, Jetronic	09.85-09.89		0 332 204 001

348

TB			3,4l 217-221 kW F 119 F 000 8 Zyl.
Air mass meter, gasoline injection	02.90-04.94		0 280 212 018
Temperature sensor, coolant, injection system	02.90-04.94		0 280 130 026
TS			3,4l 217-221 kW F 119 F 000 8 Zyl.
Air mass meter, gasoline injection	08.90-04.94		0 280 212 018
Temperature sensor, coolant, injection system	08.90-04.94		0 280 130 026

412

4.9 i			4,9l 245/250 kW F 101 E.. 12 Zyl.
Throttle valve sensor	06.85-12.88		0 280 120 314
Air flow sensor, gasoline injection	06.85-12.88		0 438 120 206
Relay, Jetronic	06.85-12.88		0 332 014 113 12S 0 332 204 101
Wheel speed sensor, front	06.85-12.88	LAB	0 265 001 091 RAB 0 265 001 090
Wheel speed sensor, rear	06.85-12.88	LAB	0 265 001 093 RAB 0 265 001 092
4.9 i			4,9l 250 kW F 101 C.. 12 Zyl.
Relay, Jetronic	07.86-12.88		0 332 014 113 12S 0 332 204 101

Product



Wheel speed sensor, front	07.86-12.88	LAB	0 265 001 091 RAB 0 265 001 090
Wheel speed sensor, rear	07.86-12.88	LAB	0 265 001 093 RAB 0 265 001 092

456

GT 2+2			5,5l 325 kW F 116 B 00 12 Zyl.
Throttle valve sensor	01.93-03.96		0 280 122 001
Air mass meter, gasoline injection	01.93-03.96		0 280 213 012 0 986 280 110
Phase sensor	01.93-03.96		0 232 103 006
Temperature sensor, coolant, injection system	01.93-03.96		0 280 130 026
GT/GTR 48V			5,5l 325 kW F 116 V12 12 Zyl.
Throttle valve sensor	03.96-12.04		0 280 122 004
Air mass meter, gasoline injection	03.96-12.04		0 280 217 521
Phase sensor	03.96-12.04		0 232 103 006
Speed sensor, ignition/injection	03.96-12.04		0 261 210 152
Temperature sensor, intake air, injection system	03.96-12.04		0 280 130 039
Temperature sensor, coolant, injection system	03.96-12.04		0 280 130 026
Wheel speed sensor, front	03.96-12.04		0 265 006 252
Wheel speed sensor, rear	03.96-12.04		0 265 006 253

512

TR			5,0l 315 kW F 113 D 00/40 12 Zyl.
Throttle valve sensor	01.92-10.94		0 280 122 001
Air mass meter, gasoline injection	01.92-10.94		0 280 213 023
Phase sensor	01.92-10.94		0 232 101 016
Speed sensor, ignition/injection	01.92-10.94		0 261 210 029
Temperature sensor, coolant, injection system	01.92-10.94		0 280 130 026
Wheel speed sensor, front	01.92-10.92		0 265 001 361 11.92-10.94 0 265 006 116
Wheel speed sensor, rear	01.92-10.92		0 265 001 363 11.92-10.94 0 265 006 117

550

Maranello			5,5l 357 kW F 133 12 Zyl.
Throttle valve sensor	10.96→		0 280 122 004
Air mass meter, gasoline injection	10.96→		0 280 217 521
Temperature sensor, intake air, injection system	10.96→		0 280 130 039
Temperature sensor, coolant, injection system	10.96→		0 280 130 026

FIAT

Albea

1.2 i.e. 8V [172..]			1,2l 44 kW 188 A 4.000 4 Zyl.
Speed sensor, ignition/injection	01.02→		0 261 210 114
1.2 i.e. 16V [172..]			1,2l 59 kW 188 A 5.000 4 Zyl.
Throttle valve assembly	01.02→		F 01C 600 023
Speed sensor, ignition/injection	01.02→		0 261 210 219
Knock sensor	01.02→		0 261 231 173
Pressure sensor, intake manifold, gasoline	01.02→		0 261 230 030
Accelerator pedal module	01.02→		0 281 002 379
Wheel speed sensor, front	01.02→	LAB	0 265 007 103 RAB 0 265 007 102
Wheel speed sensor, rear	01.02→		0 265 007 126
1.2 i.e. 16V LPG [172..]			1,2l 57-59 kW 188 A 5.000 4 Zyl.
Throttle valve assembly	07.05→		F 01C 600 023
Speed sensor, ignition/injection	07.05→		0 261 210 219



Product				

◀ Albea

Knock sensor	07.05→		0 261 231 173
Pressure sensor, intake manifold, gasoline	07.05→		0 261 230 030
Accelerator pedal module	07.05→		0 281 002 379
Wheel speed sensor, front	07.05→	LAB	0 265 007 103
		RAB	0 265 007 102
Wheel speed sensor, rear	07.05→		0 265 007 126
1.3 JTD 16V [172..]		1,2l 52 kW 188 A 9.000 4 Zyl.	
Air mass meter, diesel	07.03→		0 281 002 613
High-pressure sensor (CR system)	07.03→		0 281 002 534
Boost pressure sensor, Diesel	07.03-05.06		0 281 002 510
			0 281 002 844
Accelerator pedal module	07.03→		0 281 002 379
Wheel speed sensor, front	07.03→	LAB	0 265 007 103
		RAB	0 265 007 102
Wheel speed sensor, rear	07.03→		0 265 007 126
1.4 i.e. 8V [172..]		1,4l 57 kW 350 A 1.000 4 Zyl.	
Phase sensor	07.06→		0 232 103 048
Pressure sensor, intake manifold, gasoline	07.06→		0 261 230 030
Accelerator pedal module	07.06→		0 281 002 379
Wheel speed sensor, front	07.06→	LAB	0 265 007 103
		RAB	0 265 007 102
Wheel speed sensor, rear	07.06→		0 265 007 126
1.6 i.e. 16V [172..]		1,6l 76 kW 182 B 6.000 4 Zyl.	
Wheel speed sensor, front	01.02→	LAB	0 265 007 103
		RAB	0 265 007 102
Wheel speed sensor, rear	01.02→		0 265 007 126

Barchetta

1.8 i.e. 16V [183..]		1,8l 96 kW 183 A 1.000 4 Zyl.	
Phase sensor			
Ricam.no →0037640	01.95-05.98	0 232 101 026	
Ricam.no 0037641→	06.98-09.00	0 232 101 037	
Temperature sensor, coolant, injection system			
Ricam.no →37640	01.95-05.98	0 280 130 026	
Wheel speed sensor, front			
Ricam.no →43319	01.95-05.99	0 265 006 138	
Ricam.no 43320→	06.99-09.00	LAB	0 265 007 024
		RAB	0 265 007 025
Wheel speed sensor, rear			
Ricam.no →43319	01.95-05.99	LAB	0 265 006 210
Ricam.no →0043319	01.95-05.99	RAB	0 265 006 211
Ricam.no 43320→	06.99-09.00	LAB	0 265 007 026
		RAB	0 265 007 027
1.8 i.e. 16V [183..]		1,8l 96 kW 188 A 6.000 4 Zyl.	
Phase sensor		10.00-02.05	0 232 101 037
Wheel speed sensor, front	10.00-02.05	LAB	0 265 007 024
		RAB	0 265 007 025
Wheel speed sensor, rear	10.00-02.05	LAB	0 265 007 026
		RAB	0 265 007 027

Brava

1.2 16V [182..]		1,2l 60 kW 182 B 2.000 4 Zyl.	
Throttle valve assembly	11.98-09.01		0 280 750 013
Speed sensor, ignition/injection	11.98-09.01		0 261 210 124
Knock sensor	11.98-09.01		0 261 231 007
Pressure sensor, intake manifold, gasoline	11.98-09.01		0 261 230 035
1.2 16V [182..]		1,2l 60 kW 188 A 5.000 4 Zyl.	
Throttle valve assembly	08.00-09.01		F 01C 600 023
Speed sensor, ignition/injection	08.00-09.01		0 261 210 220
Knock sensor	08.00-09.01		0 261 231 173
Pressure sensor, intake manifold, gasoline	08.00-09.01		0 261 230 030

Product				

1.4 12V [182..]		1,4l 55/59 kW 182 A 3.000; 182 A 5.000 4 Zyl.	
Speed sensor, ignition/injection	10.95-10.98		0 281 002 102
Knock sensor	10.95-10.98		0 261 231 007
Temperature sensor, coolant, injection system	10.95-10.98		0 280 130 026
1.6 MPI 16V		1,6l 78 kW 178 A 8.011; 182 B 6.000 4 Zyl.	
Wheel speed sensor, front	08.99-06.03	VLI	0 265 007 034
		VRE	0 265 007 035
Wheel speed sensor, rear	08.99-06.03	HLI	0 265 007 032
		HRE	0 265 007 033
1.8 MPI 16V		1,8l 97 kW 183 A 1.000 4 Zyl.	
Phase sensor	02.00-06.03		0 232 101 037
Wheel speed sensor, front	02.00-06.03	VLI	0 265 007 034
		VRE	0 265 007 035
Wheel speed sensor, rear	02.00-06.03	HLI	0 265 007 032
		HRE	0 265 007 033
1.8 16V [182..]		1,8l 83 kW 182 A 2.000 4 Zyl.	
Phase sensor			
Ricam.no →4873621	11.98-07.99		0 232 101 026
Ricam.no 4873622→	08.99-09.01		0 232 101 037
Temperature sensor, coolant, injection system	10.95-07.99		0 280 130 055
1.9 JTD [182..]		1,9l 76 kW 182 B 4.000 4 Zyl.	
Air mass meter, diesel	11.98-09.01		0 280 218 019
Speed sensor, diesel	11.98-09.01		0 281 002 214
Phase sensor	11.98-09.01		0 281 002 213
High-pressure sensor (CR system)	11.98-09.01		0 281 002 210
Boost pressure sensor, Diesel	11.98-09.01		0 281 002 215
Temperature sensor, fuel	11.98-09.01		0 281 002 209
1.9 JTD [182..]		1,9l 76 kW 182 B 9.000 4 Zyl.	
Air mass meter, diesel	08.00-09.01		0 281 002 309
Speed sensor, diesel	08.00-09.01		0 281 002 214
Phase sensor	08.00-09.01		0 281 002 213
High-pressure sensor (CR system)	08.00-09.01		0 281 002 260
Boost pressure sensor, Diesel	08.00-09.01		0 281 002 215
Temperature sensor, fuel	08.00-09.01		0 281 002 209
1.9 TD [182..]		1,9l 55 kW 182 A 8.000 4 Zyl.	
Speed sensor, diesel	03.96-09.01		0 281 002 102
1.9 TD [182..]		1,9l 73/73,6 kW 182 A 7.000 4 Zyl.	
Air mass meter, diesel	03.96-09.01		0 281 002 144
Speed sensor, diesel	03.96-09.01		0 281 002 102
Temperature sensor, intake air, diesel	03.96-09.01		0 280 130 073

Bravo

1.2 16V [182..]		1,2l 60 kW 182 B 2.000 4 Zyl.	
Throttle valve assembly	11.98-09.01		0 280 750 013
Speed sensor, ignition/injection	11.98-09.01		0 261 210 124
Knock sensor	11.98-09.01		0 261 231 007
Pressure sensor, intake manifold, gasoline	11.98-09.01		0 261 230 035
1.2 16V [182..]		1,2l 60 kW 188 A 5.000 4 Zyl.	
Throttle valve assembly	08.00-09.01		F 01C 600 023
Speed sensor, ignition/injection	08.00-09.01		0 261 210 220
Knock sensor	08.00-09.01		0 261 231 173
Pressure sensor, intake manifold, gasoline	08.00-09.01		0 261 230 030
1.4 Turbo 16V [198]		1,4l 110 kW 198 A 1.000 4 Zyl.	
Speed sensor, ignition/injection	07.07→		0 261 210 238
Knock sensor	07.07→		0 261 231 173
Pressure sensor, ESP, (electronic stability program)	07.07→		0 265 005 303
Wheel speed sensor, front	07.07→		0 265 008 002
Wheel speed sensor, rear	07.07→		0 265 008 003
1.4 12V [182..]		1,4l 55/59 kW 182 A 3.000; 182 A 5.000 4 Zyl.	
Speed sensor, ignition/injection	10.95-10.98		0 281 002 102
Knock sensor	10.95-10.98		0 261 231 007
Temperature sensor, coolant, injection system	10.95-10.98		0 280 130 026



Product		
1.4 16V [198]	1,4l 66 kW 192 B 2.000 4 Zyl.	
Throttle valve assembly	03.07→	F 01C 600 027
Phase sensor	03.07→	0 232 103 048
Speed sensor, ignition/injection	03.07→	0 261 210 238
Knock sensor	03.07→	0 261 231 173
Pressure sensor, intake manifold, gasoline	03.07→	F 01C 600 070
Pressure sensor, ESP, (electronic stability program)	03.07→	0 265 005 303
Wheel speed sensor, front	03.07→	0 265 008 002
Wheel speed sensor, rear	03.07→	0 265 008 003
1.8 16V [182..]	1,8l 83 kW 182 A 2.000 4 Zyl.	
Phase sensor	10.95-10.98	0 232 101 026
Ricam.no →4873621	11.98-07.99	0 232 101 026
Ricam.no 4873622→	08.99-09.01	0 232 101 037
Temperature sensor, coolant, injection system	11.98-07.99	0 280 130 055
Relay, Jetronic	10.95-10.98 DID	0 332 014 112
1.9 JTD [182..]	1,9l 76 kW 182 B 4.000 4 Zyl.	
Air mass meter, diesel	11.98-09.01	0 280 218 019
Speed sensor, diesel	11.98-09.01	0 281 002 214
Phase sensor	11.98-09.01	0 281 002 213
High-pressure sensor (CR system)	11.98-09.01	0 281 002 210
Boost pressure sensor, Diesel	11.98-09.01	0 281 002 215
Temperature sensor, fuel	11.98-09.01	0 281 002 209
1.9 JTD [182..]	1,9l 76 kW 182 B 9.000 4 Zyl.	
Air mass meter, diesel	08.00-09.01	0 281 002 309
Speed sensor, diesel	08.00-09.01	0 281 002 214
Phase sensor	08.00-09.01	0 281 002 213
High-pressure sensor (CR system)	08.00-09.01	0 281 002 260
Boost pressure sensor, Diesel	08.00-09.01	0 281 002 215
Temperature sensor, fuel	08.00-09.01	0 281 002 209
1.9 JTD 8V [198]	1,9l 66 kW 192 B 5.000 4 Zyl.	
Air mass meter, diesel	03.07-06.07	0 281 002 792
Speed sensor, diesel	03.07→	0 281 002 603
Phase sensor	03.07→	0 281 002 213
Boost pressure sensor, Diesel	03.07→	0 281 002 845
Pressure sensor, ESP, (electronic stability program)	03.07→	0 265 005 303
Wheel speed sensor, front	03.07→	0 265 008 002
Wheel speed sensor, rear	03.07→	0 265 008 003
1.9 JTD 8V [198]	1,9l 66 kW 198 A 1.000 4 Zyl.	
Boost pressure sensor, Diesel	10.07→	0 281 002 845
Pressure sensor, ESP, (electronic stability program)	10.07→	0 265 005 303
Wheel speed sensor, front	10.07→	0 265 008 002
Wheel speed sensor, rear	10.07→	0 265 008 003
1.9 JTD 8V [198]	1,9l 85/88 kW 192 A 1.000; 192 A 8.000 4 Zyl.	
Air mass meter, diesel	03.07-06.07	0 281 002 792
Speed sensor, diesel	03.07→	0 281 002 603
Phase sensor	03.07→	0 281 002 213
Boost pressure sensor, Diesel	03.07→	0 281 002 845
Pressure sensor, ESP, (electronic stability program)	03.07→	0 265 005 303
Wheel speed sensor, front	03.07→	0 265 008 002
Wheel speed sensor, rear	03.07→	0 265 008 003
1.9 JTD 16V [198]	1,9l 110 kW 937 A 5.000 4 Zyl.	
Boost pressure sensor, Diesel	07.07→	0 281 002 845
Pressure sensor, ESP, (electronic stability program)	07.07→	0 265 005 303
Wheel speed sensor, front	07.07→	0 265 008 002
Wheel speed sensor, rear	07.07→	0 265 008 003
1.9 TD [182..]	1,9l 55 kW 182 A 8.000 4 Zyl.	
Speed sensor, diesel	03.96-09.01	0 281 002 102
1.9 TD [182..]	1,9l 73/73,6 kW 182 A 7.000 4 Zyl.	
Air mass meter, diesel	03.96-09.01	0 281 002 144
Speed sensor, diesel	03.96-09.01	0 281 002 102
Temperature sensor, intake air, diesel	03.96-09.01	0 280 130 073



Product		
2.0 20V [182..]	2,0l 108 kW 182 A 1.000 5 Zyl.	
Throttle valve sensor	10.95-10.98	0 280 122 001
Air mass meter, gasoline injection	10.95-10.98	0 280 217 111
Phase sensor	10.95-10.98	0 232 101 026
Speed sensor, ignition/injection	10.95-10.98	0 281 002 102
Knock sensor	10.95-10.98	0 261 231 095
Temperature sensor, intake air, injection system	10.95-10.98	0 280 130 073
Temperature sensor, coolant, injection system	10.95-10.98	0 280 130 026
Relay, Jetronic	10.95-10.98	0 332 014 140
2.0 20V [182..]	2,0l 113 kW 182 B 7.000 5 Zyl.	
Throttle valve assembly	11.98-09.01	0 205 003 052
Air mass meter, gasoline injection	11.98-09.01	0 280 218 019
Phase sensor	11.98-09.01	0 232 101 036
Speed sensor, ignition/injection	11.98-09.01	0 261 210 160
Knock sensor	11.98-09.01	0 261 231 144

Coupé

1.8 i 16V [175..]	1,8l 96 kW 183 A 1.000 4 Zyl.	
Air mass meter, gasoline injection	03.96-09.96	0 280 217 514
Phase sensor	03.96-09.96	0 232 101 026
Temperature sensor, coolant, injection system	03.96-09.96	0 280 130 026
Wheel speed sensor, front	03.96-09.96	0 265 006 212
Wheel speed sensor, rear	03.96-09.96	0 265 006 197
1.8 16V [175..]	1,8l 96 kW 183 A 1.000 4 Zyl.	
Phase sensor		
Mot.no. →1070426	10.96-04.98	0 232 101 026
Mot.no. 1070427→	05.98-09.00	0 232 101 037
Temperature sensor, coolant, injection system	10.96-05.98	0 280 130 026
Wheel speed sensor, front	10.96-09.00	0 265 006 124
Wheel speed sensor, rear	10.96-09.00	0 265 006 197
2.0 i 16V [175..]	2,0l 104 kW 836 A 3.000; 836 A 3.011 4 Zyl.	
Wheel speed sensor, front	04.94-09.96	0 265 006 212
Wheel speed sensor, rear	04.94-09.96	0 265 006 197
2.0 i 16V Turbo [175..]	2,0l 143 kW 175 A 1.000 4 Zyl.	
Knock sensor	04.94-09.96	0 261 231 095
Wheel speed sensor, front	02.94-09.96	0 265 006 162
Wheel speed sensor, rear	02.94-09.96	0 265 006 197
2.0 20V [175..]	2,0l 108 kW 182 A 1.000 5 Zyl.	
Throttle valve sensor	10.96-03.98	0 280 122 001
Air mass meter, gasoline injection	10.96-03.98	0 280 217 111
Phase sensor	10.96-03.98	0 232 101 026
Speed sensor, ignition/injection	10.96-03.98	0 281 002 102
Knock sensor	10.96-03.98	0 261 231 095
Temperature sensor, intake air, injection system	10.96-03.98	0 280 130 073
Temperature sensor, coolant, injection system	10.96-03.98	0 280 130 055
Relay, Jetronic	10.96-03.98	0 332 014 140
Wheel speed sensor, front	10.96-03.98	0 265 006 124
Wheel speed sensor, rear	10.96-03.98	0 265 006 197
2.0 20V [175..]	2,0l 113 kW 182 B 3.000 5 Zyl.	
Throttle valve assembly	04.98-09.00	0 205 003 052
Air mass meter, gasoline injection	04.98-09.00	0 280 218 019
Phase sensor	04.98-09.00	0 232 101 036
Speed sensor, ignition/injection	04.98-09.00	0 261 210 160
Knock sensor	04.98-09.00	0 261 231 144
Temperature sensor, intake air, injection system	04.98-09.00	0 280 130 073
Wheel speed sensor, front	04.98-09.00	0 265 006 124
Wheel speed sensor, rear	04.98-09.00	0 265 006 197
2.0 20V Turbo [175..]	2,0l 162 kW 175 A 3.000 5 Zyl.	
Throttle valve sensor	10.96-09.00	0 280 122 001
Air mass meter, gasoline injection	10.96-09.00	0 280 217 514
Phase sensor	10.96-09.00	0 232 101 026



Product				
Speed sensor, ignition/injection	10.96-09.00			0 281 002 102
Knock sensor	10.96-09.00			0 261 231 007
Pressure sensor, intake manifold, gasoline	10.96-09.00			0 280 101 001
Temperature sensor, intake air, injection system	10.96-09.00			0 280 130 060
Temperature sensor, coolant, injection system				
Mot.no. →1368080	10.96-09.00	LLE		0 280 130 055
Mot.no. →1373288	10.96-09.00	RLE		0 280 130 055
Relay, Jetronic	10.96-09.00			0 332 014 140
Relay, pump	10.96-09.00			0 332 014 140
Wheel speed sensor, front	10.96-09.00			0 265 006 124
Wheel speed sensor, rear	10.96-09.00			0 265 006 197

Croma				
1.9 TD i.d. [154..]	1,9l	69 kW	154 C	6.000 4 Zyl.
Wheel speed sensor, front	07.90-10.92			0 265 006 262
Wheel speed sensor, rear				
Ricam.no →0001448	07.90-10.92			0 265 003 075
1.9 TD i.d. [154..]	1,9l	69 kW	154 D	1.000 4 Zyl.
Wheel speed sensor, front	11.92-12.96			0 265 006 262
Wheel speed sensor, rear				
Ricam.no →0001448	11.92-01.94			0 265 003 075
Ricam.no 0001449→	02.94-12.96			0 265 006 238
2.0 [154..]	2,0l	66 kW	154 A	1.000 4 Zyl.
Wheel speed sensor, front	12.85-02.89			0 265 001 072
Wheel speed sensor, rear	12.85-02.89	LAB		0 265 001 074
		RAB		0 265 001 073
2.0 [154..]	2,0l	72 kW	154 C	2.000 CHT 4 Zyl.
Wheel speed sensor, front	03.89-06.90			0 265 006 262
Wheel speed sensor, rear	03.89-06.90			0 265 003 075
2.0 [154..]	2,0l	74 kW	154 C	5.000 CHT 4 Zyl.
Wheel speed sensor, front	07.90-11.92			0 265 006 262
Wheel speed sensor, rear	07.90-11.92			0 265 003 075
Ricam.no →0001448	07.90-11.92			0 265 003 075
2.0 i.e. [154..]	2,0l	83 kW	834 B	0.048 4 Zyl.
Throttle valve sensor	03.86-09.90			0 280 120 311
Air flow sensor, gasoline injection	03.86-09.90			0 280 202 102
				0 986 280 054
Temperature sensor, coolant, injection system	03.86-09.90			0 280 130 026
Relay, Jetronic	03.86-09.90			0 280 230 006
Wheel speed sensor, front	03.86-09.90			0 265 001 072
Wheel speed sensor, rear	03.86-09.90	LAB		0 265 001 074
		RAB		0 265 001 073
2.0 i.e. [154..]	2,0l	85 kW	154 C	3.046 4 Zyl.
Throttle valve sensor	10.90-12.96			0 280 120 311
Air flow sensor, gasoline injection	10.90-12.96			0 280 202 102
				0 986 280 054
Temperature sensor, coolant, injection system	10.90-12.96			0 280 130 026
Relay, Jetronic	10.90-12.96			0 280 230 006
Wheel speed sensor, front	10.90-12.96			0 265 006 262
Wheel speed sensor, rear				
Ricam.no →0001448	10.90-01.94			0 265 003 075
Ricam.no 0001449→	02.94-12.96			0 265 006 238
2.0 i.e. [154..]	2,0l	85 kW	834 B	0.146 4 Zyl.
Air flow sensor, gasoline injection	11.92-12.96			0 280 202 102
				0 986 280 054
Temperature sensor, coolant, injection system	11.92-12.96			0 280 130 026
Relay, Jetronic	11.92-12.96			0 280 230 006
Wheel speed sensor, front	11.92-12.96			0 265 006 262
Wheel speed sensor, rear				
Ricam.no →0001448	11.92-01.94			0 265 003 075
Ricam.no 0001449→	02.94-12.96			0 265 006 238

Product				
2.0 i.e. [154..]	2,0l	86 kW	154 C	3.000 4 Zyl.
Air flow sensor, gasoline injection	05.91-12.96			0 280 202 059
				0 986 280 044
Temperature sensor, coolant, injection system	05.91-12.96			0 280 130 026
Wheel speed sensor, front	07.90-12.96			0 265 006 262
Wheel speed sensor, rear				
Ricam.no →0001448	07.90-01.94			0 265 003 075
Ricam.no 0001449→	02.94-12.96			0 265 006 238
2.0 i.e. [154..]	2,0l	86 kW	834 B	0.146 4 Zyl.
Air flow sensor, gasoline injection	11.92-12.96			0 280 202 102
				0 986 280 054
Temperature sensor, coolant, injection system	11.92-12.96			0 280 130 026
Wheel speed sensor, front	11.92-12.96			0 265 006 262
Wheel speed sensor, rear				
Ricam.no →0001448	11.92-01.94			0 265 003 075
Ricam.no 0001449→	02.94-12.96			0 265 006 238
2.0 i.e. [154..]	2,0l	89 kW	834 AB	0.000 MPI-Bosch 4 Zyl.
Throttle valve sensor	12.85-06.90			0 280 120 311
Air flow sensor, gasoline injection	12.85-06.90			0 280 202 059
				0 986 280 044
Temperature sensor, coolant, injection system	12.85-06.90			0 280 130 026
Relay, Jetronic	12.85-06.90			0 280 230 006
Wheel speed sensor, front	12.85-06.90			0 265 001 072
Wheel speed sensor, rear	12.85-06.90	LAB		0 265 001 074
		RAB		0 265 001 073
2.0 i.e. Turbo [154..]	2,0l	110 kW	154 C	4.046 4 Zyl.
Air flow sensor, gasoline injection	10.90-12.96			0 280 202 103
Temperature sensor, coolant, injection system	10.90-12.96			0 280 130 026
Relay, Jetronic	10.90-11.92			0 280 230 009
Wheel speed sensor, front	10.90-12.96			0 265 006 262
Wheel speed sensor, rear				
Ricam.no →0001448	10.90-01.94			0 265 003 075
Ricam.no 0001449→	02.94-12.96			0 265 006 238
2.0 i.e. Turbo [154..]	2,0l	110 kW	834 C	0.146 MPI-Bosch 4 Zyl.
Throttle valve sensor	07.86-09.90			0 280 120 323
Air flow sensor, gasoline injection	07.86-09.90			0 280 202 103
Temperature sensor, coolant, injection system	07.86-09.90			0 280 130 026
Relay, Jetronic				
Ricam.no →0281951	07.86-09.90			0 280 230 006
Ricam.no 0281952→	07.86-09.90			0 280 230 009
Wheel speed sensor, front	07.86-09.90			0 265 001 072
Wheel speed sensor, rear	07.86-09.90	LAB		0 265 001 074
		RAB		0 265 001 073
2.0 i.e. Turbo [154..]	2,0l	114 kW	154 A	2.000 4 Zyl.
Throttle valve sensor	12.85-06.90			0 280 120 312
Air flow sensor, gasoline injection	12.85-04.90			0 280 202 060
				0 986 280 046
	05.90-06.90			0 280 202 128
Temperature sensor, coolant, injection system	12.85-06.90			0 280 130 026
Relay, Jetronic				
Ricam.no →0281951	12.85-06.90			0 280 230 006
Ricam.no 0281952→	12.85-06.90			0 280 230 009
Wheel speed sensor, front	12.85-06.90			0 265 001 072
Wheel speed sensor, rear	12.85-06.90	LAB		0 265 001 074
		RAB		0 265 001 073
2.0 i.e. Turbo [154..]	2,0l	116 kW	154 C	4.000 4 Zyl.
Throttle valve sensor	07.90-11.92			0 280 120 312
Air flow sensor, gasoline injection	07.90-11.92			0 280 202 128
Temperature sensor, coolant, injection system	07.90-11.92			0 280 130 026
Relay, Jetronic	07.90-11.92			0 280 230 009
Wheel speed sensor, front	07.90-11.92			0 265 006 262
Wheel speed sensor, rear				
Ricam.no →0001448	07.90-11.92			0 265 003 075



2.0 i.e. 16V [154..]	2,0l 101 kW 154 E 1.000 4 Zyl.
Throttle valve sensor	11.92-12.96 0 280 122 001
Air flow sensor, gasoline injection	11.92-12.96 0 280 202 211
	0 986 280 091
Speed sensor, ignition/injection	11.92-12.96 0 261 210 093
Knock sensor	11.92-12.96 0 261 231 095
Temperature sensor, coolant, injection system	11.92-12.96 0 280 130 026
Relay, Jetronic	11.92-12.96 0 280 230 018
	DID 0 332 014 112
Wheel speed sensor, front	11.92-12.96 0 265 006 262
Wheel speed sensor, rear	
Ricam.no →0001448	11.92-01.94 0 265 003 075
Ricam.no 0001449→	02.94-12.96 0 265 006 238
2.0 i.e. 16V [154..]	2,0l 101 kW 154 E 1.027 4 Zyl.
Throttle valve sensor	03.95-12.96 0 280 122 001
Air flow sensor, gasoline injection	03.95-12.96 0 280 202 211
	0 986 280 091
Speed sensor, ignition/injection	03.95-12.96 0 261 210 093
Knock sensor	03.95-12.96 0 261 231 095
Temperature sensor, coolant, injection system	03.95-12.96 0 280 130 026
Wheel speed sensor, front	03.95-12.96 0 265 006 262
Wheel speed sensor, rear	
Ricam.no 0001449→	03.95-12.96 0 265 006 238
2.5 D [154..]	2,5l 55 kW 8144.67 4 Zyl.
Wheel speed sensor, front	12.85-12.89 0 265 001 072
Wheel speed sensor, rear	12.85-12.89 LAB 0 265 001 074
	RAB 0 265 001 073
2.5 i.e. [154..]	2,5l 117 kW 834 G.000 6 Zyl.
Air flow sensor, gasoline injection	06.93-12.96 0 280 202 211
	0 986 280 091
Speed sensor, ignition/injection	06.93-12.96 0 261 210 090
Temperature sensor, coolant, injection system	06.93-12.96 0 280 130 026
Wheel speed sensor, front	06.93-12.96 0 265 006 262
Wheel speed sensor, rear	
Ricam.no →0001448	06.93-01.94 0 265 003 075
Ricam.no 0001449→	02.94-12.96 0 265 006 238
2.5 TD [154..]	2,5l 74 kW 8144.91.2200 4 Zyl.
Wheel speed sensor, front	12.85-02.89 0 265 001 072
Wheel speed sensor, rear	12.85-02.89 LAB 0 265 001 074
	RAB 0 265 001 073
2.5 TD [154..]	2,5l 77 kW 8144.97 S 4 Zyl.
Wheel speed sensor, front	12.91-11.92 0 265 006 262
Wheel speed sensor, rear	
Ricam.no →0001448	12.91-11.92 0 265 003 075
2.5 TD [154..]	2,5l 85 kW 8144.97Y (EM.04) 4 Zyl.
Wheel speed sensor, front	11.92-12.96 0 265 006 262
Wheel speed sensor, rear	
Ricam.no →0001448	11.92-01.94 0 265 003 075
Ricam.no 0001449→	02.94-12.96 0 265 006 238
2.5 TD [154..]	2,5l 85 kW 8144.97.2200 4 Zyl.
Wheel speed sensor, front	03.89-06.90 0 265 006 262
Wheel speed sensor, rear	03.89-06.90 0 265 003 075
2.5 TD [154..]	2,5l 86 kW 8144.97 4 Zyl.
Wheel speed sensor, front	07.90-10.92 0 265 006 262
Wheel speed sensor, rear	
Ricam.no →0001448	07.90-10.92 0 265 003 075
2.5 TDI [154..]	2,5l 85 kW 8144.97Y (US87) 4 Zyl.
Air flow sensor, diesel	09.93-11.96 0 281 002 088
Speed sensor, ignition/injection	09.93-11.96 0 261 210 093
Temperature sensor, coolant, diesel	09.93-11.96 0 280 130 026
Pedal position sensor, diesel	09.93-11.96 0 205 001 010
Wheel speed sensor, front	09.93-11.96 0 265 006 262



Wheel speed sensor, rear	
Ricam.no →0001448	09.93-01.94 0 265 003 075
Ricam.no 0001449→	02.94-11.96 0 265 006 238

Doblo

1.2 i.e. 8V [119..]	1,2l 48 kW 223 A 5.000 4 Zyl.
Phase sensor	07.00-09.05 0 232 103 039
Speed sensor, ignition/injection	
Mot.no. →2533528	07.00-09.05 OLH 0 261 210 114
1.3 JTD [119..]	1,2l 54 kW 199 A 2.000 4 Zyl.
Air mass meter, diesel	10.05→ 0 281 002 792
High-pressure sensor (CR system)	10.05→ 0 281 002 534
Boost pressure sensor, Diesel	
Mot.no. →1376014	10.05→ 0 281 002 510
Mot.no. 1376015→	10.05→ 0 281 002 844
Accelerator pedal module	10.05→ LLE 0 281 002 415
1.3 JTD [119..]	1,2l 62 kW 223 A 9.000 4 Zyl.
Air mass meter, diesel	10.05→ 0 281 002 792
High-pressure sensor (CR system)	10.05→ 0 281 002 534
Boost pressure sensor, Diesel	10.05-11.06 0 281 002 437
	12.06→ 0 281 002 845
Accelerator pedal module	10.05→ LLE 0 281 002 415
1.3 JTD 16V [119..]	1,2l 51 kW 188 A 9.000 4 Zyl.
Air mass meter, diesel	02.04-09.05 0 281 002 613
High-pressure sensor (CR system)	02.04-09.05 0 281 002 534
Boost pressure sensor, Diesel	02.04-09.05 0 281 002 510
Accelerator pedal module	02.04-09.05 LLE 0 281 002 415
1.3 MPI 16V	1,3l 59 kW 178 D 6.011 4 Zyl.
Throttle valve assembly	11.01-01.06 F 01C 600 023
Speed sensor, ignition/injection	11.01-01.06 0 261 210 161
Knock sensor	11.01-01.06 0 261 231 173
Pressure sensor, intake manifold, gasoline	11.01-01.06 0 261 230 030
Accelerator pedal module	11.01-01.06 LLE 0 281 002 415
1.4 i.e. [119..]	1,4l 55 kW 350 A 1.000 4 Zyl.
Phase sensor	10.05→ 0 232 103 048
Pressure sensor, intake manifold, gasoline	10.05→ 0 261 230 030
Accelerator pedal module	10.05→ LLE 0 281 002 415
1.6 i.e. 16V [119..]	1,6l 76 kW 182 B 6.000 4 Zyl.
Accelerator pedal module	10.01-09.05 LLE 0 281 002 415
1.9 D	1,9l 46 kW 4 Zyl.
Speed sensor, diesel	11.03-01.06 0 281 002 474
1.9 D [119..]	1,9l 46 kW 223 A 6.000 4 Zyl.
Speed sensor, diesel	07.00-09.05 0 281 002 474
Accelerator pedal module	07.00-09.05 LLE 0 281 002 415
1.9 JTD [119..]	1,9l 74 kW 182 B 9.000 4 Zyl.
Air mass meter, diesel	10.01-01.04 0 280 218 113
Speed sensor, diesel	10.01-01.04 0 281 002 474
Phase sensor	10.01-01.04 0 281 002 213
High-pressure sensor (CR system)	10.01-01.04 0 281 002 260
Boost pressure sensor, Diesel	10.01-01.04 0 281 002 510
Accelerator pedal module	10.01-01.04 LLE 0 281 002 415
1.9 JTD [119..]	1,9l 74 kW 223 B 2.000 4 Zyl.
Speed sensor, diesel	10.05→ KW 0 281 002 603
Phase sensor	10.05→ NOC 0 281 002 213
High-pressure sensor (CR system)	10.05→ 0 281 002 534
Boost pressure sensor, Diesel	10.05-03.07 0 281 002 437
	04.07→ 0 281 002 845
Accelerator pedal module	10.05→ LLE 0 281 002 415
1.9 JTD [119..]	1,9l 77 kW 223 A 7.000 4 Zyl.
Air mass meter, diesel	11.02-09.05 0 280 218 113
Speed sensor, diesel	11.02-01.04 0 281 002 474
	02.04-09.05 0 281 002 603



Product				
◀ Doblo				
Phase sensor	11.02-09.05			0 281 002 213
High-pressure sensor (CR system)				
Mot.no. →3920857	11.02-09.05	LLE		0 281 002 260
Mot.no. →3963472	11.02-09.05	RLE		0 281 002 260
Boost pressure sensor, Diesel	11.02-09.05			0 281 002 510
Accelerator pedal module	11.02-09.05	LLE		0 281 002 415
1.9 JTD [119..]	1,9l 77/88 kW 186 A 9.000; 223 B 1.000			4 Zyl.
Speed sensor, diesel	10.05→	KW		0 281 002 603
Phase sensor	10.05→	NOC		0 281 002 213
High-pressure sensor (CR system)	10.05→			0 281 002 534
Boost pressure sensor, Diesel	10.05-03.07			0 281 002 437
	04.07→			0 281 002 845
Accelerator pedal module	10.05→	LLE		0 281 002 415



Doblo Cargo

1.2 i.e. 8V [223..]	1,2l 47 kW 223 A 5.000			4 Zyl.
Phase sensor	07.00-09.05			0 232 103 039
Speed sensor, ignition/injection				
Mot.no. →2533528	07.00-09.05	OLH		0 261 210 114
1.3 JTD [223..]	1,2l 55 kW 199 A 2.000			4 Zyl.
Air mass meter, diesel	10.05→			0 281 002 792
High-pressure sensor (CR system)	10.05→			0 281 002 534
Boost pressure sensor, Diesel				
Mot.no. →1376014	10.05→			0 281 002 510
Mot.no. 1376015→	10.05→			0 281 002 844
Accelerator pedal module	10.05→	LLE		0 281 002 415
1.3 JTD [223..]	1,2l 62 kW 223 A 9.000			4 Zyl.
Air mass meter, diesel	10.05→			0 281 002 792
High-pressure sensor (CR system)	10.05→			0 281 002 534
Boost pressure sensor, Diesel	10.05-11.06			0 281 002 437
	12.06→			0 281 002 845
Accelerator pedal module	10.05→	LLE		0 281 002 415
1.3 JTD 16V [223..]	1,2l 51 kW 188 A 9.000			4 Zyl.
Air mass meter, diesel	02.04-09.05			0 281 002 613
High-pressure sensor (CR system)	02.04-09.05			0 281 002 534
Boost pressure sensor, Diesel	02.04-09.05			0 281 002 510
Accelerator pedal module	02.04-09.05	LLE		0 281 002 415
1.4 i.e. [223..]	1,4l 57 kW 350 A 1.000			4 Zyl.
Phase sensor	10.05→			0 232 103 048
Pressure sensor, intake manifold, gasoline	10.05→			0 261 230 030
Accelerator pedal module	10.05→	LLE		0 281 002 415
1.6 i.e. 16V [223..]	1,6l 76 kW 182 B 6.000			4 Zyl.
Accelerator pedal module	10.01-09.05	LLE		0 281 002 415
1.9 D [223..]	1,9l 46 kW 223 A 6.000			4 Zyl.
Speed sensor, diesel	07.00-09.05			0 281 002 474
Accelerator pedal module	07.00-09.05	LLE		0 281 002 415
1.9 JTD [223..]	1,9l 74 kW 182 B 9.000			4 Zyl.
Air mass meter, diesel	10.01-01.04			0 280 218 113
Speed sensor, diesel	10.01-01.04			0 281 002 474
Phase sensor	10.01-01.04			0 281 002 213
High-pressure sensor (CR system)	10.01-01.04			0 281 002 260
Boost pressure sensor, Diesel	10.01-01.04			0 281 002 510
Accelerator pedal module	10.01-01.04	LLE		0 281 002 415
1.9 JTD [223..]	1,9l 74 kW 223 B 2.000			4 Zyl.
Speed sensor, diesel	10.05→	KW		0 281 002 603
Phase sensor	10.05→	NOC		0 281 002 213
High-pressure sensor (CR system)	10.05→			0 281 002 534
Boost pressure sensor, Diesel	10.05-03.07			0 281 002 437
	04.07→			0 281 002 845
Accelerator pedal module	10.05→	LLE		0 281 002 415

Product				
1.9 JTD [223..]	1,9l 77 kW 223 A 7.000			4 Zyl.
Air mass meter, diesel	11.02-09.05			0 280 218 113
Speed sensor, diesel	11.02-01.04			0 281 002 474
	02.04-09.05			0 281 002 603
Phase sensor	11.02-09.05			0 281 002 213
High-pressure sensor (CR system)				
Mot.no. →3920857	11.02-09.05	LLE		0 281 002 260
Mot.no. →3963472	11.02-09.05	RLE		0 281 002 260
Boost pressure sensor, Diesel	11.02-09.05			0 281 002 510
Accelerator pedal module	11.02-09.05	LLE		0 281 002 415
1.9 JTD [223..]	1,9l 77/88 kW 186 A 9.000; 223 B 1000			4 Zyl.
Speed sensor, diesel	10.05→	KW		0 281 002 603
Phase sensor	10.05→	NOC		0 281 002 213
High-pressure sensor (CR system)	10.05→			0 281 002 534
Boost pressure sensor, Diesel	10.05-03.07			0 281 002 437
	04.07→			0 281 002 845
Accelerator pedal module	10.05→	LLE		0 281 002 415

Ducato

2.8 JTD Combinato, Maxi Cargo, Minibus, Multi T.A./T.B.	2,8l 93 kW 8140.43S			4 Zyl.
Pulse generator, diesel	06.05→			0 281 002 667
Speed sensor, diesel	06.05→			0 281 002 332
High-pressure sensor (CR system)	06.05→			0 281 002 405
Boost pressure sensor, Diesel	06.05→			0 281 002 514
Temperature sensor, coolant, diesel	06.05→			0 281 002 170
Wheel speed sensor, front	06.05→			0 265 006 673
Wheel speed sensor, rear	06.05→	LAB		0 265 006 688
		RAB		0 265 006 689

Ducato Cargo

2.8 D	2,8l 63 kW 8140.63.22.60			4 Zyl.
Wheel speed sensor, front	01.04-05.05			0 265 006 673
Wheel speed sensor, rear	01.04-05.05	LAB		0 265 006 688
		RAB		0 265 006 689
2.8 D Turbo	2,8l 90 kW 8140.43.22.00			4 Zyl.
Wheel speed sensor, front	01.04-05.05			0 265 006 673
Wheel speed sensor, rear	01.04-05.05	LAB		0 265 006 688
		RAB		0 265 006 689
2.8 JTD	2,8l 93 kW 8140.43S			4 Zyl.
Pulse generator, diesel	06.05→			0 281 002 667
Speed sensor, diesel	06.05→			0 281 002 332
High-pressure sensor (CR system)	06.05→			0 281 002 405
Boost pressure sensor, Diesel	06.05→			0 281 002 514
Temperature sensor, coolant, diesel	06.05→			0 281 002 170
Wheel speed sensor, front	06.05→			0 265 006 673
Wheel speed sensor, rear	06.05→	LAB		0 265 006 688
		RAB		0 265 006 689

Ducato Maxi 17

2.3 JTD [251..]	2,3l 88 kW F1AE0481D			4 Zyl.
Air mass meter, diesel	06.06→			0 281 002 763
Boost pressure sensor, Diesel	06.06-05.07			0 281 002 437
	06.07→			0 281 002 845
Wheel speed sensor, rear	06.06→	FKR,FMR		0 265 007 686
		FLR		0 265 007 833
3.0 JTD [251..]	3,0l 116 kW F1CE0481D			4 Zyl.
Air mass meter, diesel	06.06→			0 281 002 763
Phase sensor	06.06→			0 281 002 667
Boost pressure sensor, Diesel	06.06→			0 281 002 437



Wheel speed sensor, rear	06.06→	FKR,FMR	0 265 007 686
		FLR	0 265 007 833

Ducato Maxi 20

2.3 JTD [251..]	2,3l 88 kW F1AE0481D 4 Zyl.
Air mass meter, diesel	06.06→ 0 281 002 763
Boost pressure sensor, Diesel	06.06-05.07 0 281 002 437
	06.07→ 0 281 002 845

Wheel speed sensor, rear	06.06→	FKR,FMR	0 265 007 686
		FLR	0 265 007 833

3.0 JTD [251..]	3,0l 116 kW F1CE0481D 4 Zyl.		
Air mass meter, diesel	06.06→	0 281 002 763	
Phase sensor	06.06→	0 281 002 667	
Boost pressure sensor, Diesel	06.06→	0 281 002 437	
Wheel speed sensor, rear	06.06→	FKR,FMR	0 265 007 686
		FLR	0 265 007 833

Ducato 10

1.9 D [230..]	1,9l 50 kW DJY 4 Zyl.
Wheel speed sensor, front	
Fg.no. 5445359→5946342	04.98-10.01 BO 0 265 006 427
Fg.no. 5946343→	04.98-10.01 BSY 0 265 006 673

Wheel speed sensor, rear	
Fg.no. 5445359→	04.98-10.01 BO,LAB 0 265 006 405
	BO,RAB 0 265 006 406

1.9 D [230..]	1,9l 51 kW 230 A 2.000 4 Zyl.
Wheel speed sensor, front	
Fg.no. 5445359→5946342	08.97-03.98 BO 0 265 006 427

Wheel speed sensor, rear	
Fg.no. 5445359→	08.97-03.98 BO,LAB 0 265 006 405
	BO,RAB 0 265 006 406

1.9 TD [230..]	1,9l 60 kW 230 A 3.000 4 Zyl.
Wheel speed sensor, front	
Fg.no. 5445359→5946342	08.97-03.98 BO 0 265 006 427

Wheel speed sensor, rear	
Fg.no. 5445359→	08.97-03.98 BO,LAB 0 265 006 405
	BO,RAB 0 265 006 406

1.9 TD [230..]	1,9l 66 kW DHX 4 Zyl.
Altitude sensor	04.98-10.01 9 456 160 006

Wheel speed sensor, front	
Fg.no. 5445359→5946342	04.98-10.01 BO 0 265 006 427
Fg.no. 5946343→	04.98-10.01 BSY 0 265 006 673

Wheel speed sensor, rear	
Fg.no. 5445359→	04.98-10.01 BO,LAB 0 265 006 405
	BO,RAB 0 265 006 406

1.9 TD CAT [230..]	1,9l 59 kW 230 A 4.000 4 Zyl.
Wheel speed sensor, front	
Fg.no. 5445359→5946342	08.97-03.98 BO 0 265 006 427

Wheel speed sensor, rear	
Fg.no. 5445359→	08.97-03.98 BO,LAB 0 265 006 405
	BO,RAB 0 265 006 406

2.0 [230..]	2,0l 79 kW R5B 4 Zyl.

Wheel speed sensor, front	
Fg.no. 5445359→5946342	08.97-03.02 BO 0 265 006 427
Fg.no. 5946343→	03.94-03.02 BSY 0 265 006 673

Wheel speed sensor, rear	12.01-03.02	LAB	0 265 006 688
		RAB	0 265 006 689
Fg.no. 5445359→	08.97-11.01	BO,LAB	0 265 006 405
		BO,RAB	0 265 006 406



2.0 i.e. [230..]	2,0l 80 kW RFW 4 Zyl.

Wheel speed sensor, front	
Fg.no. 5445359→5946342	08.97-03.02 BO 0 265 006 427
Fg.no. 5946343→	03.94-03.02 BSY 0 265 006 673

Wheel speed sensor, rear	12.01-03.02	LAB	0 265 006 688
		RAB	0 265 006 689
Fg.no. 5445359→	08.97-11.01	BO,LAB	0 265 006 405
		BO,RAB	0 265 006 406

2.0 i.e. 4x4 [234..]	2,0l 80 kW RFW 4 Zyl.

Wheel speed sensor, front	
Fg.no. 5445359→5946342	08.97-03.02 BO 0 265 006 427
Fg.no. 5946343→	03.94-03.02 BSY 0 265 006 673

Wheel speed sensor, rear	12.01-03.02	LAB	0 265 006 688
		RAB	0 265 006 689
Fg.no. 5445359→	08.97-11.01	BO,LAB	0 265 006 405
		BO,RAB	0 265 006 406

2.0 JTD [230..]	2,0l 63 kW RHV 4 Zyl.

High-pressure sensor (CR system)	10.01-03.02 0 281 002 283

Wheel speed sensor, front			
Fg.no. 5946343→	10.01-03.02	BSY	0 265 006 673
Wheel speed sensor, rear	12.01-03.02	LAB	0 265 006 688

Fg.no. 5445359→	10.01-11.01	BO,LAB	0 265 006 405
		BO,RAB	0 265 006 406

2.5 D [230..]	2,5l 62 kW 8140.67 4 Zyl.

Wheel speed sensor, front	
Fg.no. 5445359→5946342	08.97-03.98 BO 0 265 006 427

Wheel speed sensor, rear	
Fg.no. 5445359→	08.97-03.98 BO,LAB 0 265 006 405
	BO,RAB 0 265 006 406

2.5 TD ECO [230..]	2,5l 80 kW 8140.47R 4 Zyl.

Air flow sensor, diesel	03.94-03.98		0 281 002 087
Speed sensor, diesel	03.94-03.98	MDR	0 281 002 108
Temperature sensor, coolant, diesel	03.94-03.98		0 280 130 026
Pedal position sensor, diesel	03.94-03.98		0 205 001 010

Wheel speed sensor, front	
Fg.no. 5445359→5946342	08.97-03.98 BO 0 265 006 427

Wheel speed sensor, rear	
Fg.no. 5445359→	08.97-03.98 BO,LAB 0 265 006 405
	BO,RAB 0 265 006 406

2.5 TD EGR [230..]	2,5l 85 kW 8140.47 4 Zyl.

Speed sensor, diesel	03.94-03.98	MDR	0 281 002 108

Wheel speed sensor, front	
Fg.no. 5445359→5946342	08.97-03.98 BO 0 265 006 427

Wheel speed sensor, rear	
Fg.no. 5445359→	08.97-03.98 BO,LAB 0 265 006 405
	BO,RAB 0 265 006 406

2.5 TD EGR 4x4 [234..]	2,5l 85 kW 8140.47 4 Zyl.

Speed sensor, diesel	03.94-03.98	MDR	0 281 002 108

Wheel speed sensor, front	
Fg.no. 5445359→5946342	08.97-03.98 BO 0 265 006 427

Wheel speed sensor, rear	
Fg.no. 5445359→	08.97-03.98 BO,LAB 0 265 006 405
	BO,RAB 0 265 006 406

2.8 D [230..]	2,8l 64 kW 8140.63 4 Zyl.

Wheel speed sensor, front	
Fg.no. 5445359→5946342	04.98-03.02 BO 0 265 006 427
Fg.no. 5946343→	04.98-03.02 BSY 0 265 006 673

Wheel speed sensor, rear	12.01-03.02	LAB	0 265 006 688
		RAB	0 265 006 689
Fg.no. 5445359→	04.98-11.01	BO,LAB	0 265 006 405
		BO,RAB	0 265 006 406





Product

◀ Ducato 10

2.8 JTD [230..]				2,8l 94 kW 8140.43S 4 Zyl.
Speed sensor, diesel	08.00-03.02			0 281 002 332
High-pressure sensor (CR system)	08.00-03.02			0 281 002 405
Wheel speed sensor, front				
Fg.no. 5946343→	08.00-03.02	BSY		0 265 006 673
Wheel speed sensor, rear	12.01-03.02	LAB		0 265 006 688
		RAB		0 265 006 689
Fg.no. 5445359→	08.00-11.01	BO,LAB		0 265 006 405
		BO,RAB		0 265 006 406
2.8 JTD EGR [230..]				2,8l 94 kW 8140.43S 4 Zyl.
Air mass meter, diesel	08.00-03.02			0 281 002 184
Speed sensor, diesel	08.00-03.02			0 281 002 332
High-pressure sensor (CR system)	08.00-03.02			0 281 002 405
Wheel speed sensor, front				
Fg.no. 5946343→	08.00-03.02	BSY		0 265 006 673
Wheel speed sensor, rear	12.01-03.02	LAB		0 265 006 688
		RAB		0 265 006 689
Fg.no. 5445359→	08.00-11.01	BO,LAB		0 265 006 405
		BO,RAB		0 265 006 406
2.8 JTD EGR 4x4 [234..]				2,8l 94 kW 8140.43S 4 Zyl.
Air mass meter, diesel	08.00-03.02			0 281 002 184
Speed sensor, diesel	08.00-03.02			0 281 002 332
High-pressure sensor (CR system)	08.00-03.02			0 281 002 405
Wheel speed sensor, front				
Fg.no. 5445359→5946342	08.00-03.02	BO		0 265 006 427
Fg.no. 5946343→	08.00-03.02	BSY		0 265 006 673
Wheel speed sensor, rear	12.01-03.02	LAB		0 265 006 688
		RAB		0 265 006 689
Fg.no. 5445359→	08.00-11.01	BO,LAB		0 265 006 405
		BO,RAB		0 265 006 406
2.8 JTD 4x4 [234..]				2,8l 94 kW 8140.43S 4 Zyl.
Speed sensor, diesel	08.00-03.02			0 281 002 332
High-pressure sensor (CR system)	08.00-03.02			0 281 002 405
Wheel speed sensor, front				
Fg.no. 5445359→5946342	08.00-03.02	BO		0 265 006 427
Fg.no. 5946343→	08.00-03.02	BSY		0 265 006 673
Wheel speed sensor, rear	12.01-03.02	LAB		0 265 006 688
		RAB		0 265 006 689
Fg.no. 5445359→	08.00-11.01	BO,LAB		0 265 006 405
		BO,RAB		0 265 006 406
2.8 TD EGR [230..]				2,8l 90 kW 8140.43 4 Zyl.
Speed sensor, diesel	10.97-03.02	MDR		0 281 002 108
Wheel speed sensor, front				
Fg.no. 5445359→5946342	10.97-03.02	BO		0 265 006 427
Fg.no. 5946343→	10.97-03.02	BSY		0 265 006 673
Wheel speed sensor, rear	12.01-03.02	LAB		0 265 006 688
		RAB		0 265 006 689
Fg.no. 5445359→	10.97-11.01	BO,LAB		0 265 006 405
		BO,RAB		0 265 006 406
2.8 TD EGR 4x4, TD 4x4 [234..]				2,8l 90 kW 8140.43 4 Zyl.
Wheel speed sensor, front				
Fg.no. 5445359→5946342	10.97-03.02	BO		0 265 006 427
Fg.no. 5946343→	10.97-03.02	BSY		0 265 006 673
Wheel speed sensor, rear	12.01-03.02	LAB		0 265 006 688
		RAB		0 265 006 689
Fg.no. 5445359→	10.97-11.01	BO,LAB		0 265 006 405
		BO,RAB		0 265 006 406

Product

Ducato 11

2.0 i.e. [243..]				2,0l 81 kW RFL 4 Zyl.
Wheel speed sensor, front	04.02-08.06			0 265 006 673
Wheel speed sensor, rear	04.02-08.06	LAB		0 265 006 688
		RAB		0 265 006 689
2.0 i.e. Bipower [243..]				2,0l 71-81 kW RFL 4 Zyl.
Wheel speed sensor, front	04.02-08.06			0 265 006 673
Wheel speed sensor, rear	04.02-08.06	LAB		0 265 006 688
		RAB		0 265 006 689
2.0 i.e. Bipower 4x4 [247..]				2,0l 71-81 kW RFL 4 Zyl.
Wheel speed sensor, front	04.02-08.06			0 265 006 673
2.0 i.e. 4x4 [247..]				2,0l 81 kW RFL 4 Zyl.
Wheel speed sensor, front	04.02-08.06			0 265 006 673
2.0 JTD [243..]				2,0l 62 kW RHV 4 Zyl.
High-pressure sensor (CR system)	04.02-08.06			0 281 002 283
Wheel speed sensor, front	04.02-08.06			0 265 006 673
Wheel speed sensor, rear	04.02-08.06	LAB		0 265 006 688
		RAB		0 265 006 689
2.2 JTD [250..]				2,2l 74 kW 4HV 4 Zyl.
Wheel speed sensor, rear	06.06→	FKR,FMR		0 265 007 686
		FLR		0 265 007 833
2.3 JTD [243..]				2,3l 81 kW F1AE0481C 4 Zyl.
Boost pressure sensor, Diesel	04.02-08.06			0 281 002 514
Wheel speed sensor, front	04.02-08.06			0 265 006 673
Wheel speed sensor, rear	04.02-08.06	LAB		0 265 006 688
		RAB		0 265 006 689
2.3 JTD [250..]				2,3l 88 kW F1AE0481D 4 Zyl.
Air mass meter, diesel	06.06→			0 281 002 763
Boost pressure sensor, Diesel	06.06-05.07			0 281 002 437
	06.07→			0 281 002 845
Wheel speed sensor, rear	06.06→	FKR,FMR		0 265 007 686
		FLR		0 265 007 833
2.3 JTD EGR [243..]				2,3l 81 kW F1AE0481C 4 Zyl.
Wheel speed sensor, front	04.02-08.06			0 265 006 673
Wheel speed sensor, rear	04.02-08.06	LAB		0 265 006 688
		RAB		0 265 006 689
2.8 JTD [243..]				2,8l 94 kW 8140.43S 4 Zyl.
Boost pressure sensor, Diesel	04.02-08.06			0 281 002 514
Wheel speed sensor, front	04.02-08.06			0 265 006 673
Wheel speed sensor, rear	04.02-08.06	LAB		0 265 006 688
		RAB		0 265 006 689
2.8 JTD EGR [243..]				2,8l 94 kW 8140.43S 4 Zyl.
Air mass meter, diesel	04.02-08.06			0 281 002 184
Boost pressure sensor, Diesel	04.02-08.06			0 281 002 514
Wheel speed sensor, front	04.02-08.06			0 265 006 673
Wheel speed sensor, rear	04.02-08.06	LAB		0 265 006 688
		RAB		0 265 006 689
2.8 JTD EGR 4x4 [247..]				2,8l 94 kW 8140.43S 4 Zyl.
Air mass meter, diesel	04.02-08.06			0 281 002 184
Boost pressure sensor, Diesel	04.02-08.06			0 281 002 514
Wheel speed sensor, front	04.02-08.06			0 265 006 673
2.8 TD EGR 4x4 [247..]				2,8l 90 kW 8140.43 4 Zyl.
Wheel speed sensor, front	10.02-08.06			0 265 006 673
2.8 TD, TD EGR [243..]				2,8l 90 kW 8140.43 4 Zyl.
Wheel speed sensor, front	10.02-08.06			0 265 006 673
Wheel speed sensor, rear	10.02-08.06	LAB		0 265 006 688
		RAB		0 265 006 689
3.0 JTD [250..]				3,0l 116 kW F1CE0481D 4 Zyl.
Air mass meter, diesel	06.06→			0 281 002 763
Phase sensor	06.06→			0 281 002 667
Boost pressure sensor, Diesel	06.06→			0 281 002 437



Wheel speed sensor, rear	06.06→	FKR,FMR	0 265 007 686
		FLR	0 265 007 833

Ducato 14

1.9 TD [231..]				1,9l 60 kW 230 A 3.000 4 Zyl.
Wheel speed sensor, front				
Fg.no. 5445359→5946342	08.97-03.98	BO		0 265 006 427
Wheel speed sensor, rear				
Fg.no. 5445359→	08.97-03.98	BO,LAB		0 265 006 405
		BO,RAB		0 265 006 406
1.9 TD [231..]				1,9l 66 kW DHX 4 Zyl.
Altitude sensor	04.98-10.01			9 456 160 006
Wheel speed sensor, front				
Fg.no. 5445359→5946342	04.98-10.01	BO		0 265 006 427
Fg.no. 5946343→	04.98-10.01	BSY		0 265 006 673
Wheel speed sensor, rear				
Fg.no. 5445359→	04.98-10.01	BO,LAB		0 265 006 405
		BO,RAB		0 265 006 406
1.9 TD CAT [231..]				1,9l 59 kW 230 A 4.000 4 Zyl.
Wheel speed sensor, front				
Fg.no. 5445359→5946342	08.97-03.98	BO		0 265 006 427
Wheel speed sensor, rear				
Fg.no. 5445359→	08.97-03.98	BO,LAB		0 265 006 405
		BO,RAB		0 265 006 406
2.0 [231..]				2,0l 79 kW R5B 4 Zyl.
Wheel speed sensor, front				
Fg.no. 5445359→5946342	08.97-03.02	BO		0 265 006 427
Fg.no. 5946343→	03.94-03.02	BSY		0 265 006 673
Wheel speed sensor, rear				
	12.01-03.02	LAB		0 265 006 688
		RAB		0 265 006 689
Fg.no. 5445359→	08.97-11.01	BO,LAB		0 265 006 405
		BO,RAB		0 265 006 406
2.0 i.e. [231..]				2,0l 80 kW RFW 4 Zyl.
Wheel speed sensor, front				
Fg.no. 5445359→5946342	08.97-03.02	BO		0 265 006 427
Fg.no. 5946343→	03.94-03.02	BSY		0 265 006 673
Wheel speed sensor, rear				
	12.01-03.02	LAB		0 265 006 688
		RAB		0 265 006 689
Fg.no. 5445359→	08.97-11.01	BO,LAB		0 265 006 405
		BO,RAB		0 265 006 406
2.0 i.e. 4x4 [234..]				2,0l 80 kW RFW 4 Zyl.
Wheel speed sensor, front				
Fg.no. 5445359→5946342	08.97-03.02	BO		0 265 006 427
Fg.no. 5946343→	03.94-03.02	BSY		0 265 006 673
Wheel speed sensor, rear				
	12.01-03.02	LAB		0 265 006 688
		RAB		0 265 006 689
Fg.no. 5445359→	08.97-11.01	BO,LAB		0 265 006 405
		BO,RAB		0 265 006 406
2.0 JTD [231..]				2,0l 63 kW RHV 4 Zyl.
High-pressure sensor (CR system)	10.01-03.02			0 281 002 283
Wheel speed sensor, front				
Fg.no. 5946343→	10.01-03.02	BSY		0 265 006 673
Wheel speed sensor, rear				
	12.01-03.02	LAB		0 265 006 688
		RAB		0 265 006 689
Fg.no. 5445359→	10.01-11.01	BO,LAB		0 265 006 405
		BO,RAB		0 265 006 406
2.5 D [231..]				2,5l 62 kW 8140.67 4 Zyl.
Wheel speed sensor, front				
Fg.no. 5445359→5946342	08.97-03.98	BO		0 265 006 427
Wheel speed sensor, rear				
Fg.no. 5445359→	08.97-03.98	BO,LAB		0 265 006 405
		BO,RAB		0 265 006 406



2.5 TD [231..]				2,5l 85 kW 8140.47 4 Zyl.
Wheel speed sensor, front				
Fg.no. 5445359→5946342	08.97-03.98	BO		0 265 006 427
Wheel speed sensor, rear				
Fg.no. 5445359→	08.97-03.98	BO,LAB		0 265 006 405
		BO,RAB		0 265 006 406
2.5 TD ECO [231..]				2,5l 80 kW 8140.47R 4 Zyl.
Air flow sensor, diesel	03.94-03.98			0 281 002 087
Speed sensor, diesel	03.94-03.98	MDR		0 281 002 108
Temperature sensor, coolant, diesel	03.94-03.98			0 280 130 026
Pedal position sensor, diesel	03.94-03.98			0 205 001 010
Wheel speed sensor, front				
Fg.no. 5445359→5946342	08.97-03.98	BO		0 265 006 427
Wheel speed sensor, rear				
Fg.no. 5445359→	08.97-03.98	BO,LAB		0 265 006 405
		BO,RAB		0 265 006 406
2.5 TD ECO 4x4 [234..]				2,5l 80 kW 8140.47R 4 Zyl.
Air flow sensor, diesel	03.94-03.98			0 281 002 087
Speed sensor, diesel	03.94-03.98	MDR		0 281 002 108
Temperature sensor, coolant, diesel	03.94-03.98			0 280 130 026
Pedal position sensor, diesel	03.94-03.98			0 205 001 010
Wheel speed sensor, front				
Fg.no. 5445359→5946342	08.97-03.98	BO		0 265 006 427
Wheel speed sensor, rear				
Fg.no. 5445359→	08.97-03.98	BO,LAB		0 265 006 405
		BO,RAB		0 265 006 406
2.5 TD EGR [231..]				2,5l 85 kW 8140.47 4 Zyl.
Speed sensor, diesel	03.94-03.98	MDR		0 281 002 108
Wheel speed sensor, front				
Fg.no. 5445359→5946342	08.97-03.98	BO		0 265 006 427
Wheel speed sensor, rear				
Fg.no. 5445359→	08.97-03.98	BO,LAB		0 265 006 405
		BO,RAB		0 265 006 406
2.5 TD EGR 4x4 [234..]				2,5l 85 kW 8140.47 4 Zyl.
Speed sensor, diesel	03.94-03.98	MDR		0 281 002 108
Wheel speed sensor, front				
Fg.no. 5445359→5946342	08.97-03.98	BO		0 265 006 427
Wheel speed sensor, rear				
Fg.no. 5445359→	08.97-03.98	BO,LAB		0 265 006 405
		BO,RAB		0 265 006 406
2.8 D [231..]				2,8l 64 kW 8140.63 4 Zyl.
Wheel speed sensor, front				
Fg.no. 5445359→5946342	04.98-03.02	BO		0 265 006 427
Fg.no. 5946343→	04.98-03.02	BSY		0 265 006 673
Wheel speed sensor, rear				
	12.01-03.02	LAB		0 265 006 688
		RAB		0 265 006 689
Fg.no. 5445359→	04.98-11.01	BO,LAB		0 265 006 405
		BO,RAB		0 265 006 406
2.8 JTD [231..]				2,8l 94 kW 8140.43S 4 Zyl.
Speed sensor, diesel	08.00-03.02			0 281 002 332
High-pressure sensor (CR system)	08.00-03.02			0 281 002 405
Wheel speed sensor, front				
Fg.no. 5946343→	08.00-03.02	BSY		0 265 006 673
Wheel speed sensor, rear				
	12.01-03.02	LAB		0 265 006 688
		RAB		0 265 006 689
Fg.no. 5445359→	08.00-11.01	BO,LAB		0 265 006 405
		BO,RAB		0 265 006 406
2.8 JTD EGR [231..]				2,8l 94 kW 8140.43S 4 Zyl.
Air mass meter, diesel	08.00-03.02			0 281 002 184
Speed sensor, diesel	08.00-03.02			0 281 002 332
High-pressure sensor (CR system)	08.00-03.02			0 281 002 405
Wheel speed sensor, front				
Fg.no. 5946343→	08.00-03.02	BSY		0 265 006 673



Product



◀ Ducato 14

Wheel speed sensor, rear	12.01-03.02	LAB	0 265 006 688
		RAB	0 265 006 689
Fg.no. 5445359→	08.00-11.01	BO,LAB	0 265 006 405
		BO,RAB	0 265 006 406
2.8 JTD EGR 4x4 [234..]		2,8l 94 kW 8140.43S 4 Zyl.	
Air mass meter, diesel	08.00-03.02		0 281 002 184
Speed sensor, diesel	08.00-03.02		0 281 002 332
High-pressure sensor (CR system)	08.00-03.02		0 281 002 405
Wheel speed sensor, front			
Fg.no. 5445359→5946342	08.00-03.02	BO	0 265 006 427
Fg.no. 5946343→	08.00-03.02	BSY	0 265 006 673
Wheel speed sensor, rear	12.01-03.02	LAB	0 265 006 688
		RAB	0 265 006 689
Fg.no. 5445359→	08.00-11.01	BO,LAB	0 265 006 405
		BO,RAB	0 265 006 406
2.8 JTD 4x4 [234..]		2,8l 94 kW 8140.43S 4 Zyl.	
Speed sensor, diesel	08.00-03.02		0 281 002 332
High-pressure sensor (CR system)	08.00-03.02		0 281 002 405
Wheel speed sensor, front			
Fg.no. 5445359→5946342	08.00-03.02	BO	0 265 006 427
Fg.no. 5946343→	08.00-03.02	BSY	0 265 006 673
Wheel speed sensor, rear	12.01-03.02	LAB	0 265 006 688
		RAB	0 265 006 689
Fg.no. 5445359→	08.00-11.01	BO,LAB	0 265 006 405
		BO,RAB	0 265 006 406
2.8 TD [231..]		2,8l 90 kW 8140.43 4 Zyl.	
Wheel speed sensor, front			
Fg.no. 5445359→5946342	10.97-03.02	BO	0 265 006 427
Fg.no. 5946343→	10.97-03.02	BSY	0 265 006 673
Wheel speed sensor, rear	12.01-03.02	LAB	0 265 006 688
		RAB	0 265 006 689
Fg.no. 5445359→	10.97-11.01	BO,LAB	0 265 006 405
		BO,RAB	0 265 006 406
2.8 TD EGR [231..]		2,8l 90 kW 8140.43 4 Zyl.	
Speed sensor, diesel	10.97-03.02	MDR	0 281 002 108
Wheel speed sensor, front			
Fg.no. 5445359→5946342	10.97-03.02	BO	0 265 006 427
Fg.no. 5946343→	10.97-03.02	BSY	0 265 006 673
Wheel speed sensor, rear	12.01-03.02	LAB	0 265 006 688
		RAB	0 265 006 689
Fg.no. 5445359→	10.97-11.01	BO,LAB	0 265 006 405
		BO,RAB	0 265 006 406
2.8 TD EGR 4x4, TD 4x4 [234..]		2,8l 90 kW 8140.43 4 Zyl.	
Wheel speed sensor, front			
Fg.no. 5445359→5946342	10.97-03.02	BO	0 265 006 427
Fg.no. 5946343→	10.97-03.02	BSY	0 265 006 673
Wheel speed sensor, rear	12.01-03.02	LAB	0 265 006 688
		RAB	0 265 006 689
Fg.no. 5445359→	10.97-11.01	BO,LAB	0 265 006 405
		BO,RAB	0 265 006 406



F

Ducato 15

2.0 i.e. [244..]		2,0l 81 kW RFL 4 Zyl.	
Wheel speed sensor, front	04.02-08.06		0 265 006 673
Wheel speed sensor, rear	04.02-08.06	LAB	0 265 006 688
		RAB	0 265 006 689
2.0 i.e. Bipower [244..]		2,0l 71-81 kW RFL 4 Zyl.	
Wheel speed sensor, front	04.02-08.06		0 265 006 673
Wheel speed sensor, rear	04.02-08.06	LAB	0 265 006 688
		RAB	0 265 006 689

Product				
2.0 i.e. Bipower 4x4 [247..]				
Wheel speed sensor, front	04.02-08.06	2,0l 71-81 kW RFL 4 Zyl. 0 265 006 673		
2.0 i.e. 4x4 [247..]				
Wheel speed sensor, front	04.02-08.06	2,0l 81 kW RFL 4 Zyl. 0 265 006 673		
2.0 JTD [244..]				
High-pressure sensor (CR system)	04.02-08.06	2,0l 62 kW RHV 4 Zyl. 0 281 002 283		
Wheel speed sensor, front	04.02-08.06	0 265 006 673		
Wheel speed sensor, rear	04.02-08.06	LAB	0 265 006 688	
		RAB	0 265 006 689	
2.2 JTD [250..]				
Air mass meter, diesel	06.06→	2,2l 74 kW 4HV 4 Zyl. 0 281 002 763		
Wheel speed sensor, rear	06.06→	FKR,FMR	0 265 007 686	
		FLR	0 265 007 833	
2.3 JTD [244..]				
Boost pressure sensor, Diesel	04.02-08.06	2,3l 81 kW F1AE0481C 4 Zyl. 0 281 002 514		
Wheel speed sensor, front	04.02-08.06	0 265 006 673		
Wheel speed sensor, rear	04.02-08.06	LAB	0 265 006 688	
		RAB	0 265 006 689	
2.3 JTD [250..]				
Air mass meter, diesel	06.06→	2,3l 88 kW F1AE0481D 4 Zyl. 0 281 002 763		
Boost pressure sensor, Diesel	06.06-05.07	0 281 002 437		
	06.07→	0 281 002 845		
Wheel speed sensor, rear	06.06→	FKR,FMR	0 265 007 686	
		FLR	0 265 007 833	
2.3 JTD EGR [244..]				
Wheel speed sensor, front	04.02-08.06	2,3l 81 kW F1AE0481C 4 Zyl. 0 265 006 673		
Wheel speed sensor, rear	04.02-08.06	LAB	0 265 006 688	
		RAB	0 265 006 689	
2.8 JTD [244..]				
Boost pressure sensor, Diesel	04.02-08.06	2,8l 94 kW 8140.43S 4 Zyl. 0 281 002 514		
Wheel speed sensor, front	04.02-08.06	0 265 006 673		
Wheel speed sensor, rear	04.02-08.06	LAB	0 265 006 688	
		RAB	0 265 006 689	
2.8 JTD CGV [244..]				
Boost pressure sensor, Diesel	04.04-08.06	2,8l 107 kW 8140.43S 4 Zyl. 0 281 002 514		
Wheel speed sensor, front	04.04-08.06	0 265 006 673		
Wheel speed sensor, rear	04.04-08.06	LAB	0 265 006 688	
		RAB	0 265 006 689	
2.8 JTD EGR [244..]				
Air mass meter, diesel	04.02-08.06	2,8l 94 kW 8140.43S 4 Zyl. 0 281 002 184		
Boost pressure sensor, Diesel	04.02-08.06	0 281 002 514		
Wheel speed sensor, front	04.02-08.06	0 265 006 673		
Wheel speed sensor, rear	04.02-08.06	LAB	0 265 006 688	
		RAB	0 265 006 689	
2.8 JTD EGR 4x4 [247..]				
Air mass meter, diesel	04.02-08.06	2,8l 94 kW 8140.43S 4 Zyl. 0 281 002 184		
Boost pressure sensor, Diesel	04.02-08.06	0 281 002 514		
Wheel speed sensor, front	04.02-08.06	0 265 006 673		
2.8 JTD 4x4 [247..]				
Boost pressure sensor, Diesel	04.02-08.06	2,8l 94 kW 8140.43S 4 Zyl. 0 281 002 514		
Wheel speed sensor, front	04.02-08.06	0 265 006 673		
2.8 TD EGR 4x4, TD 4x4 [247..]				
Wheel speed sensor, front	10.02-08.06	2,8l 90 kW 8140.43 4 Zyl. 0 265 006 673		
2.8 TD, TD EGR [244..]				
Wheel speed sensor, front	10.02-08.06	2,8l 90 kW 8140.43 4 Zyl. 0 265 006 673		
Wheel speed sensor, rear	10.02-08.06	LAB	0 265 006 688	
		RAB	0 265 006 689	
3.0 JTD [250..]				
Air mass meter, diesel	06.06→	3,0l 116 kW F1CE0481D 4 Zyl. 0 281 002 763		
Phase sensor	06.06→	0 281 002 667		
Boost pressure sensor, Diesel	06.06→	0 281 002 437		
Wheel speed sensor, rear	06.06→	FKR,FMR	0 265 007 686	
		FLR	0 265 007 833	





Ducato 17				
2.2 JTD [250..]		2,2l 74 kW 4HV 4 Zyl.		
Air mass meter, diesel	06.06→			0 281 002 763
Wheel speed sensor, rear	06.06→	FKR,FMR		0 265 007 686
		FLR		0 265 007 833
2.3 JTD [250..]		2,3l 88 kW F1AE0481D 4 Zyl.		
Air mass meter, diesel	06.06→			0 281 002 763
Boost pressure sensor, Diesel	06.06-05.07			0 281 002 437
	06.07→			0 281 002 845
Wheel speed sensor, rear	06.06→	FKR,FMR		0 265 007 686
		FLR		0 265 007 833
3.0 JTD [250..]		3,0l 116 kW F1CE0481D 4 Zyl.		
Air mass meter, diesel	06.06→			0 281 002 763
Phase sensor	06.06→			0 281 002 667
Boost pressure sensor, Diesel	06.06→			0 281 002 437
Wheel speed sensor, rear	06.06→	FKR,FMR		0 265 007 686
		FLR		0 265 007 833

Ducato 18				
2.0 i.e. [232..]		2,0l 80 kW RFW 4 Zyl.		
Wheel speed sensor, front				
Fg.no. 5445359→5946342	08.97-03.02	BO	0 265 006 427	
Fg.no. 5946343→	03.94-03.02	BSY	0 265 006 673	
Wheel speed sensor, rear	12.01-03.02	LAB	0 265 006 688	
		RAB	0 265 006 689	
Fg.no. 5445359→	08.97-11.01	BO,LAB	0 265 006 405	
		BO,RAB	0 265 006 406	
2.0 i.e. [245..]		2,0l 81 kW RFL 4 Zyl.		
Wheel speed sensor, front	04.02-08.06		0 265 006 673	
Wheel speed sensor, rear	04.02-08.06	LAB	0 265 006 688	
		RAB	0 265 006 689	
2.0 i.e. Bipower [245..]		2,0l 71-81 kW RFL 4 Zyl.		
Wheel speed sensor, front	04.02-08.06		0 265 006 673	
Wheel speed sensor, rear	04.02-08.06	LAB	0 265 006 688	
		RAB	0 265 006 689	
2.0 i.e. Bipower 4x4 [247..]		2,0l 71-81 kW RFL 4 Zyl.		
Wheel speed sensor, front	04.02-08.06		0 265 006 673	
2.0 i.e. 4x4 [247..]		2,0l 81 kW RFL 4 Zyl.		
Wheel speed sensor, front	04.02-08.06		0 265 006 673	
2.3 JTD [245..]		2,3l 81 kW F1AE0481C 4 Zyl.		
Boost pressure sensor, Diesel	04.02-08.06		0 281 002 514	
Wheel speed sensor, front	04.02-08.06		0 265 006 673	
Wheel speed sensor, rear	04.02-08.06	LAB	0 265 006 688	
		RAB	0 265 006 689	
2.5 D [232..]		2,5l 62 kW 8140.67 4 Zyl.		
Wheel speed sensor, front				
Fg.no. 5445359→	08.97-03.98	BO	0 265 006 427	
Wheel speed sensor, rear				
Fg.no. 5445359→	08.97-03.98	BO,LAB	0 265 006 405	
		BO,RAB	0 265 006 406	
2.5 D 4x4 [234..]		2,5l 62 kW 8140.67 4 Zyl.		
Wheel speed sensor, front				
Fg.no. 5445359→5946342	08.97-03.98	BO	0 265 006 427	
Wheel speed sensor, rear				
Fg.no. 5445359→	08.97-03.98	BO,LAB	0 265 006 405	
		BO,RAB	0 265 006 406	
2.5 TD [232..]		2,5l 85 kW 8140.47 4 Zyl.		
Wheel speed sensor, front				
Fg.no. 5445359→	08.97-03.98	BO	0 265 006 427	

Product				
Wheel speed sensor, rear Fg.no. 5445359→	08.97-03.98	BO,LAB	0 265 006 405	
		BO,RAB	0 265 006 406	
2.5 TD ECO [232..]	2,5l 80 kW	8140.47R	4 Zyl.	
Air flow sensor, diesel	03.94-03.98		0 281 002 087	
Speed sensor, diesel	03.94-03.98	MDR	0 281 002 108	
Temperature sensor, coolant, diesel	03.94-03.98		0 280 130 026	
Pedal position sensor, diesel	03.94-03.98		0 205 001 010	
Wheel speed sensor, front Fg.no. 5445359→	08.97-03.98	BO	0 265 006 427	
Wheel speed sensor, rear Fg.no. 5445359→	08.97-03.98	BO,LAB	0 265 006 405	
		BO,RAB	0 265 006 406	
2.5 TD 4x4 [234..]	2,5l 85 kW	8140.47	4 Zyl.	
Wheel speed sensor, front Fg.no. 5445359→5946342	08.97-03.98	BO	0 265 006 427	
Wheel speed sensor, rear Fg.no. 5445359→	08.97-03.98	BO,LAB	0 265 006 405	
		BO,RAB	0 265 006 406	
2.8 D [232..]	2,8l 64 kW	8140.63	4 Zyl.	
Wheel speed sensor, front Fg.no. 5445359→5946342	04.98-03.02	BO	0 265 006 427	
Fg.no. 5946343→	04.98-03.02	BSY	0 265 006 673	
Wheel speed sensor, rear	12.01-03.02	LAB	0 265 006 688	
		RAB	0 265 006 689	
Fg.no. 5445359→	04.98-11.01	BO,LAB	0 265 006 405	
		BO,RAB	0 265 006 406	
2.8 D 4x4 [234..]	2,8l 64 kW	8140.63	4 Zyl.	
Wheel speed sensor, front Fg.no. 5445359→5946342	04.98-03.02	BO	0 265 006 427	
Fg.no. 5946343→	04.98-03.02	BSY	0 265 006 673	
Wheel speed sensor, rear	12.01-03.02	LAB	0 265 006 688	
		RAB	0 265 006 689	
Fg.no. 5445359→	04.98-11.01	BO,LAB	0 265 006 405	
		BO,RAB	0 265 006 406	
2.8 JTD [232..]	2,8l 94 kW	8140.43S	4 Zyl.	
Speed sensor, diesel	08.00-03.02		0 281 002 332	
High-pressure sensor (CR system)	08.00-03.02		0 281 002 405	
Wheel speed sensor, front Fg.no. 5946343→	08.00-03.02	BSY	0 265 006 673	
Wheel speed sensor, rear	12.01-03.02	LAB	0 265 006 688	
		RAB	0 265 006 689	
Fg.no. 5445359→	08.00-11.01	BO,LAB	0 265 006 405	
		BO,RAB	0 265 006 406	
2.8 JTD [245..]	2,8l 94 kW	8140.43S	4 Zyl.	
Boost pressure sensor, Diesel	04.02-08.06		0 281 002 514	
Wheel speed sensor, front	04.02-08.06		0 265 006 673	
Wheel speed sensor, rear	04.02-08.06	LAB	0 265 006 688	
		RAB	0 265 006 689	
2.8 JTD CGV [245..]	2,8l 107 kW	8140.43S	4 Zyl.	
Boost pressure sensor, Diesel	04.04-08.06		0 281 002 514	
Wheel speed sensor, front	04.04-08.06		0 265 006 673	
Wheel speed sensor, rear	04.04-08.06	LAB	0 265 006 688	
		RAB	0 265 006 689	
2.8 JTD EGR [232..]	2,8l 94 kW	8140.43S	4 Zyl.	
Air mass meter, diesel	08.00-03.02		0 281 002 184	
Speed sensor, diesel	08.00-03.02		0 281 002 332	
High-pressure sensor (CR system)	08.00-03.02		0 281 002 405	
Wheel speed sensor, front Fg.no. 5946343→	08.00-03.02	BSY	0 265 006 673	



Product				
◀ Ducato 18				
Wheel speed sensor, rear	12.01-03.02	LAB	0 265 006 688	
		RAB	0 265 006 689	
Fg.no. 5445359→	08.00-11.01	BO,LAB	0 265 006 405	
		BO,RAB	0 265 006 406	
2.8 JTD EGR [245..]	2,8l	94 kW	8140.43S	4 Zyl.
Air mass meter, diesel	04.02-08.06		0 281 002 184	
Boost pressure sensor, Diesel	04.02-08.06		0 281 002 514	
Wheel speed sensor, front	04.02-08.06		0 265 006 673	
Wheel speed sensor, rear	04.02-08.06	LAB	0 265 006 688	
		RAB	0 265 006 689	
2.8 JTD EGR 4x4 [234..]	2,8l	94 kW	8140.43S	4 Zyl.
Air mass meter, diesel	08.00-03.02		0 281 002 184	
Speed sensor, diesel	08.00-03.02		0 281 002 332	
High-pressure sensor (CR system)	08.00-03.02		0 281 002 405	
Wheel speed sensor, front				
Fg.no. 5445359→5946342	08.00-03.02	BO	0 265 006 427	
Fg.no. 5946343→	08.00-03.02	BSY	0 265 006 673	
Wheel speed sensor, rear	12.01-03.02	LAB	0 265 006 688	
		RAB	0 265 006 689	
Fg.no. 5445359→	08.00-11.01	BO,LAB	0 265 006 405	
		BO,RAB	0 265 006 406	
2.8 JTD EGR 4x4 [247..]	2,8l	94 kW	8140.43S	4 Zyl.
Air mass meter, diesel	04.02-08.06		0 281 002 184	
Boost pressure sensor, Diesel	04.02-08.06		0 281 002 514	
Wheel speed sensor, front	04.02-08.06		0 265 006 673	
2.8 JTD 4x4 [234..]	2,8l	94 kW	8140.43S	4 Zyl.
Speed sensor, diesel	08.00-03.02		0 281 002 332	
High-pressure sensor (CR system)	08.00-03.02		0 281 002 405	
Wheel speed sensor, front				
Fg.no. 5445359→5946342	08.00-03.02	BO	0 265 006 427	
Fg.no. 5946343→	08.00-03.02	BSY	0 265 006 673	
Wheel speed sensor, rear	12.01-03.02	LAB	0 265 006 688	
		RAB	0 265 006 689	
Fg.no. 5445359→	08.00-11.01	BO,LAB	0 265 006 405	
		BO,RAB	0 265 006 406	
2.8 JTD 4x4 [247..]	2,8l	94 kW	8140.43S	4 Zyl.
Boost pressure sensor, Diesel	04.02-08.06		0 281 002 514	
Wheel speed sensor, front	04.02-08.06		0 265 006 673	
2.8 TD [232..]	2,8l	90 kW	8140.43	4 Zyl.
Wheel speed sensor, front				
Fg.no. 5445359→5946342	10.97-03.02	BO	0 265 006 427	
Fg.no. 5946343→	10.97-03.02	BSY	0 265 006 673	
Wheel speed sensor, rear	12.01-03.02	LAB	0 265 006 688	
		RAB	0 265 006 689	
Fg.no. 5445359→	10.97-11.01	BO,LAB	0 265 006 405	
		BO,RAB	0 265 006 406	
2.8 TD [245..]	2,8l	90 kW	8140.43	4 Zyl.
Wheel speed sensor, front	10.02-08.06		0 265 006 673	
Wheel speed sensor, rear	10.02-08.06	LAB	0 265 006 688	
		RAB	0 265 006 689	
2.8 TD EGR [232..]	2,8l	90 kW	8140.43	4 Zyl.
Speed sensor, diesel	10.97-03.02	MDR	0 281 002 108	
Wheel speed sensor, front				
Fg.no. 5445359→5946342	10.97-03.02	BO	0 265 006 427	
Fg.no. 5946343→	10.97-03.02	BSY	0 265 006 673	
Wheel speed sensor, rear	12.01-03.02	LAB	0 265 006 688	
		RAB	0 265 006 689	
Fg.no. 5445359→	10.97-11.01	BO,LAB	0 265 006 405	
		BO,RAB	0 265 006 406	
2.8 TD EGR 4x4, TD 4x4 [234..]	2,8l	90 kW	8140.43	4 Zyl.
Wheel speed sensor, front				
Fg.no. 5445359→5946342	10.97-03.02	BO	0 265 006 427	
Fg.no. 5946343→	10.97-03.02	BSY	0 265 006 673	

Product				
Wheel speed sensor, rear	12.01-03.02	LAB	0 265 006 688	
		RAB	0 265 006 689	
Fg.no. 5445359→	10.97-11.01	BO,LAB	0 265 006 405	
		BO,RAB	0 265 006 406	
2.8 TD 4x4 [247..]	2,8l	90 kW	8140.43	4 Zyl.
Wheel speed sensor, front	10.02-08.06		0 265 006 673	
Fiorino				
1.3 [255..]	1,3l	49 kW	146 A 5.000	4 Zyl.
Wheel speed sensor, front	09.93-12.01	LAB	0 265 006 538	
		RAB	0 265 006 537	
Wheel speed sensor, rear	09.93-12.01	LAB	0 265 006 539	
		RAB	0 265 006 540	
1.4 i.e. [255..]	1,4l	49 kW	146 D 5.000	4 Zyl.
Speed sensor, ignition/injection	06.95-12.01		0 261 210 127	
Temperature sensor, coolant, injection system	06.95-12.01		0 280 130 026	
Wheel speed sensor, front	06.95-12.01	LAB	0 265 006 538	
		RAB	0 265 006 537	
Wheel speed sensor, rear	06.95-12.01	LAB	0 265 006 539	
		RAB	0 265 006 540	
1.4 i.e. [255..]	1,4l	52 kW	146 C 5.000	4 Zyl.
Temperature sensor, coolant, injection system	09.93-06.95		0 280 130 026	
Wheel speed sensor, front	09.93-06.95	LAB	0 265 006 538	
		RAB	0 265 006 537	
Wheel speed sensor, rear	09.93-06.95	LAB	0 265 006 539	
		RAB	0 265 006 540	
1.5 i.e. [255..]	1,5l	55 kW	149 C 1.000	4 Zyl.
Temperature sensor, coolant, injection system	01.88-08.93		0 280 130 026	
1.6 i.e. [255..]	1,6l	59 kW	146 C 6.000	4 Zyl.
Temperature sensor, coolant, injection system	09.93-06.95		0 280 130 026	
Wheel speed sensor, front	09.93-06.95	LAB	0 265 006 538	
		RAB	0 265 006 537	
Wheel speed sensor, rear	09.93-06.95	LAB	0 265 006 539	
		RAB	0 265 006 540	
1.6 i.e. [255..]	1,6l	59 kW	146 D 6.000	4 Zyl.
Speed sensor, ignition/injection	06.95-12.01		0 261 210 127	
Temperature sensor, coolant, injection system	06.95-12.01		0 280 130 026	
Wheel speed sensor, front	06.95-12.01	LAB	0 265 006 538	
		RAB	0 265 006 537	
Wheel speed sensor, rear	06.95-12.01	LAB	0 265 006 539	
		RAB	0 265 006 540	
1.7 D [255..]	1,7l	43 kW	146 B 2.000	4 Zyl.
Wheel speed sensor, front	09.93-12.01	LAB	0 265 006 538	
		RAB	0 265 006 537	
Wheel speed sensor, rear	09.93-12.01	LAB	0 265 006 539	
		RAB	0 265 006 540	
1.7 TDS [255..]	1,7l	46 kW	146 D 7.000	4 Zyl.
Wheel speed sensor, front	02.97-12.01	LAB	0 265 006 538	
		RAB	0 265 006 537	
Wheel speed sensor, rear	02.97-12.01	LAB	0 265 006 539	
		RAB	0 265 006 540	





Fiorino Pick-up			
1.5 MPI	1,5l	56 kW	160 E 1.011 4 Zyl.
Wheel speed sensor, front	09.97-06.02	LAB	0 265 006 538
		RAB	0 265 006 537
Wheel speed sensor, rear	09.97-06.02	LAB	0 265 006 539
		RAB	0 265 006 540
1.6 MPI	1,6l	66 kW	146 B 7.011 4 Zyl.
Throttle valve sensor	10.95-10.96		0 280 122 001
Speed sensor, ignition/injection	10.95-10.96		0 261 210 118
Knock sensor	10.95-10.96		0 261 231 007
Pressure sensor, intake manifold, gasoline	10.95-10.96		0 261 230 004
Temperature sensor, intake air, injection system	10.95-10.96		0 280 130 060

Idea			
1.3 JTD 16V [135..]	1,3l	52 kW	188 A 9.000 4 Zyl.
Air mass meter, diesel	01.04→		0 281 002 613
High-pressure sensor (CR system)	01.04→		0 281 002 534
Boost pressure sensor, Diesel			
Mot.no. →1376014	01.04→		0 281 002 510
Mot.no. 1376015→	01.04→		0 281 002 844
Accelerator pedal module	01.04→	RLE	0 281 002 369
Acceleration sensor, ABS	01.04-04.06		0 265 005 127
Yaw rate sensor, brake system	01.04-04.06		0 265 005 241
Wheel speed sensor, rear	01.04-03.07		0 265 007 503
1.3 JTD 16V [135..]	1,3l	66 kW	199 A 3.000 4 Zyl.
Air mass meter, diesel	11.04→		0 281 002 792
Boost pressure sensor, Diesel	11.04-11.06		0 281 002 437
	12.06→		0 281 002 845
Accelerator pedal module	11.04→	RLE	0 281 002 369
Acceleration sensor, ABS	11.04-04.06		0 265 005 127
Yaw rate sensor, brake system	11.04-04.06		0 265 005 241
Wheel speed sensor, rear	11.04-03.07		0 265 007 503
1.4 i.e. 8V [135..]	1,4l	55 kW	350 A 1.000 4 Zyl.
Phase sensor	11.04→		0 232 103 048
Pressure sensor, intake manifold, gasoline	11.04→		0 261 230 030
Accelerator pedal module	11.04→	RLE	0 281 002 369
Acceleration sensor, ABS	11.04-04.06		0 265 005 127
Yaw rate sensor, brake system	11.04-04.06		0 265 005 241
Wheel speed sensor, rear	11.04-03.07		0 265 007 503
1.4 i.e. 8V [135..]	1,4l	59 kW	188 A 5.000 4 Zyl.
Throttle valve assembly			
Mot.no. →992720	01.04→		F 01C 600 023
Mot.no. 992721→	01.04→		0 280 750 042
Speed sensor, ignition/injection	01.04→		0 261 210 238
Knock sensor	01.04→		0 261 231 173
Pressure sensor, intake manifold, gasoline	01.04→		0 261 230 030
Temperature sensor, coolant, injection system	01.04→		F 01C 050 016
Accelerator pedal module	01.04→	RLE	0 281 002 369
Acceleration sensor, ABS	01.04-04.06		0 265 005 127
Yaw rate sensor, brake system	01.04-04.06		0 265 005 241
Wheel speed sensor, rear	01.04-03.07		0 265 007 503
1.4 i.e. 16V [135..]	1,4l	66/70 kW	192 B 2.000; 843 A 1.000 4 Zyl.
Throttle valve assembly	01.04→		F 01C 600 027
Speed sensor, ignition/injection	01.04→		0 261 210 238
Knock sensor	01.04→		0 261 231 173
Pressure sensor, intake manifold, gasoline	01.04→		0 261 230 030
Accelerator pedal module	01.04→	RLE	0 281 002 369
Acceleration sensor, ABS	01.04-04.06		0 265 005 127
Yaw rate sensor, brake system	01.04-04.06		0 265 005 241
Wheel speed sensor, rear	01.04-03.07		0 265 007 503



1.9 JTD 8V [135..]	1,9l	74 kW	188 B 2.000 4 Zyl.
Speed sensor, diesel	01.04→	KW	0 281 002 603
Phase sensor	01.04→	NOC	0 281 002 213
High-pressure sensor (CR system)	01.04-10.04		0 281 002 534
Boost pressure sensor, Diesel	01.04-03.07		0 281 002 437
	04.07→		0 281 002 845
Accelerator pedal module	01.04→	RLE	0 281 002 369
Acceleration sensor, ABS	01.04-04.06		0 265 005 127
Yaw rate sensor, brake system	01.04-04.06		0 265 005 241
Wheel speed sensor, rear	01.04-03.07		0 265 007 503

Linea			
1.3 JTD [110]	1,3l	66 kW	199 A 3.000 4 Zyl.
Air mass meter, diesel	03.07→		0 281 002 792
Boost pressure sensor, Diesel	03.07→		0 281 002 845
1.4 Turbo 16V [110]	1,4l	88 kW	198 A 4.000 4 Zyl.
Phase sensor	03.07→		0 232 103 048
Speed sensor, ignition/injection	03.07→		0 261 210 238
Knock sensor	03.07→		0 261 231 173
Boost pressure sensor, gasoline	03.07→		0 281 002 844
1.4 8V [110]	1,4l	57 kW	350 A 1.000 4 Zyl.
Phase sensor	03.07→		0 232 103 048
Pressure sensor, intake manifold, gasoline	03.07→		0 261 230 030

Marea			
1.2 i 16V [185..]	1,2l	60 kW	182 B 2.000 4 Zyl.
Throttle valve assembly	03.99-09.02		0 280 750 013
Speed sensor, ignition/injection	03.99-09.02		0 261 210 124
Knock sensor	03.99-09.02		0 261 231 007
Pressure sensor, intake manifold, gasoline	03.99-09.02		0 261 230 035
Wheel speed sensor, front	03.99-09.02	LAB	0 265 007 073
	03.99-03.01	RAB	0 265 007 035
	04.01-09.02	RAB	0 265 007 074
Wheel speed sensor, rear	03.99-09.02	LAB	0 265 007 032
		RAB	0 265 007 033
1.4 i 12V [185..]	1,4l	59 kW	182 A 3.000 4 Zyl.
Speed sensor, ignition/injection	10.96-02.99		0 281 002 102
Knock sensor	10.96-02.99		0 261 231 007
Temperature sensor, coolant, injection system	10.96-02.99		0 280 130 026
Wheel speed sensor, front			
Ricam.no 0172273→,5054835→	10.96-02.99	LAB,LLE	0 265 007 034
Ricam.no 0176273→,5054835→	10.96-02.99	LLE,RAB	0 265 007 035
Wheel speed sensor, rear			
Ricam.no 0176273→,5054835→	10.96-02.99	LAB,LLE	0 265 007 032
		LLE,RAB	0 265 007 033
1.6 i 16V [185..]	1,6l	76 kW	182 A 4.000 4 Zyl.
Wheel speed sensor, front	03.99→	LAB	0 265 007 073
	03.99-03.01	RAB	0 265 007 035
	04.01→	RAB	0 265 007 074
Ricam.no 0172273→,5054835→	10.96-02.99	LAB,LLE	0 265 007 034
Ricam.no 0176273→,5054835→	10.96-02.99	LLE,RAB	0 265 007 035
Ricam.no 0180748→	10.96-02.99	LAB,RLE	0 265 007 034
		RAB,RLE	0 265 007 035
Wheel speed sensor, rear	03.99→	LAB	0 265 007 032
		RAB	0 265 007 033
Ricam.no 0176273→,5054835→	10.96-02.99	LAB,LLE	0 265 007 032
		LLE,RAB	0 265 007 033
Ricam.no 0180748→	10.96-02.99	LAB,RLE	0 265 007 032
		RAB,RLE	0 265 007 033





Product



◀ Marea

1.6i 16V [185..]		1,6l 76 kW 182 B 5.098 4 Zyl.	
Wheel speed sensor, front	03.99-09.02	LAB	0 265 007 073
	03.99-03.01	RAB	0 265 007 035
	04.01-09.02	RAB	0 265 007 074
Ricam.no 0172273→,5054835→	10.98-02.99	LAB,LLE	0 265 007 034
Ricam.no 0176273→,5054835→	10.98-02.99	LLE,RAB	0 265 007 035
Wheel speed sensor, rear	03.99-09.02	LAB	0 265 007 032
		RAB	0 265 007 033
Ricam.no 0176273→,5054835→	10.98-02.99	LAB,LLE	0 265 007 032
		LLE,RAB	0 265 007 033

1.6i 16V [185..]		1,6l 76 kW 182 B 6.000 4 Zyl.	
Wheel speed sensor, front	08.00→	LAB	0 265 007 073
	08.00-03.01	RAB	0 265 007 035
	04.01→	RAB	0 265 007 074
Wheel speed sensor, rear	08.00→	LAB	0 265 007 032
		RAB	0 265 007 033

1.6i 16V Bi-Power [185..]		1,6l 68-76 kW 185 A 3.000 4 Zyl.	
Wheel speed sensor, front	03.99-09.02	LAB	0 265 007 073
	03.99-03.01	RAB	0 265 007 035
	04.01-09.02	RAB	0 265 007 074
Ricam.no 0172273→,5054835→	10.97-02.99	LAB,LLE	0 265 007 034
Ricam.no 0176273→,5054835→	10.97-02.99	LLE,RAB	0 265 007 035
Wheel speed sensor, rear	03.99-09.02	LAB	0 265 007 032
		RAB	0 265 007 033
Ricam.no 0176273→,5054835→	10.97-02.99	LAB,LLE	0 265 007 032
		LLE,RAB	0 265 007 033

1.8i 16V [185..]		1,8l 83 kW 182 A 2.000 4 Zyl.	
Phase sensor			
Ricam.no →2018321,→0270958	10.96-09.02		0 232 101 026
Ricam.no 2018322→,0270958→	03.99-09.02		0 232 101 037
Temperature sensor, coolant, injection system	10.96-02.99		0 280 130 055
Ricam.no →2018321,→0270957	03.99-09.02		0 280 130 055
Wheel speed sensor, front	03.99-09.02	LAB	0 265 007 073
	03.99-03.01	RAB	0 265 007 035
	04.01-09.02	RAB	0 265 007 074
Ricam.no 0172273→,5054835→	10.96-02.99	LAB,LLE	0 265 007 034
Ricam.no 0176273→,5054835→	10.96-02.99	LLE,RAB	0 265 007 035
Ricam.no 0180748→	10.96-02.99	LAB,RLE	0 265 007 034
		RAB,RLE	0 265 007 035
Wheel speed sensor, rear	03.99-09.02	LAB	0 265 007 032
		RAB	0 265 007 033
Ricam.no 0176273→,5054835→	10.96-02.99	LAB,LLE	0 265 007 032
		LLE,RAB	0 265 007 033
Ricam.no 0180748→	10.96-02.99	LAB,RLE	0 265 007 032
		RAB,RLE	0 265 007 033

1.8 MPI 16V		1,8l 97 kW 183 A 1.000 4 Zyl.	
Phase sensor	08.99→		0 232 101 037
Wheel speed sensor, front	08.99→	VLI	0 265 007 034
		VRE	0 265 007 035
Wheel speed sensor, rear	08.99→	HLI	0 265 007 032
		HRE	0 265 007 033

1.9 JTD [185..]		1,9l 74 kW 182 B 9.000 4 Zyl.	
Air mass meter, diesel	10.01-09.02		0 281 002 309
Speed sensor, diesel			
Mot.no. →2151823	10.01-09.02		0 281 002 214
Mot.no. 2151824→	10.01-09.02		0 281 002 474
Phase sensor	10.01-09.02		0 281 002 213
High-pressure sensor (CR system)	10.01-09.02		0 281 002 260
		EFV	0 281 002 405
Boost pressure sensor, Diesel	10.01-09.02		0 281 002 510
Wheel speed sensor, front	10.01-09.02	LAB	0 265 007 073
		RAB	0 265 007 074

Product



Wheel speed sensor, rear	10.01-09.02	LAB	0 265 007 032
		RAB	0 265 007 033

1.9 JTD [185..]		1,9l 77 kW 182 B 4.000 4 Zyl.	
Air mass meter, diesel	03.99-09.02		0 280 218 019
Speed sensor, diesel			
Mot.no. →2151823	03.99-09.02		0 281 002 214
Mot.no. 2151824→	03.99-09.02		0 281 002 474
Phase sensor	03.99-09.02		0 281 002 213
High-pressure sensor (CR system)	03.99-09.02		0 281 002 210
		EFV	0 281 002 405

Boost pressure sensor, Diesel	03.99-09.02		0 281 002 215
Temperature sensor, fuel	03.99-09.02		0 281 002 209
Wheel speed sensor, front	03.99-09.02	LAB	0 265 007 073
	03.99-03.01	RAB	0 265 007 035
	04.01-09.02	RAB	0 265 007 074
Wheel speed sensor, rear	03.99-09.02	LAB	0 265 007 032
		RAB	0 265 007 033

1.9 JTD [185..]		1,9l 81 kW 186 A 6.000 4 Zyl.	
Air mass meter, diesel	08.00-09.02		0 281 002 308
Speed sensor, diesel			
Mot.no. →2151823	08.00-09.02		0 281 002 214
Mot.no. 2151824→	08.00-09.02		0 281 002 474
Phase sensor	08.00-09.02		0 281 002 213
High-pressure sensor (CR system)	08.00-09.02		0 281 002 260
		EFV	0 281 002 405

Boost pressure sensor, Diesel			
Mot.no. →2705194	08.00-07.01		0 281 002 215
Mot.no. 2705195→	08.01-09.02		0 281 002 510
Wheel speed sensor, front	08.00-09.02	LAB	0 265 007 073
	08.00-03.01	RAB	0 265 007 035
	04.01-09.02	RAB	0 265 007 074
Wheel speed sensor, rear	08.00-09.02	LAB	0 265 007 032
		RAB	0 265 007 033

1.9 TD [185..]		1,9l 55,1 kW 182 A 8.000 4 Zyl.	
Speed sensor, diesel	10.96-09.02		0 281 002 102
Wheel speed sensor, front	03.99-09.02	LAB	0 265 007 073
	03.99-03.01	RAB	0 265 007 035
	04.01-09.02	RAB	0 265 007 074
Ricam.no 0172273→,5054835→	10.96-02.99	LAB,LLE	0 265 007 034
Ricam.no 0176273→,5054835→	10.96-02.99	LLE,RAB	0 265 007 035
Ricam.no 0180748→	10.96-02.99	LAB,RLE	0 265 007 034
		RAB,RLE	0 265 007 035
Wheel speed sensor, rear	03.99-09.02	LAB	0 265 007 032
		RAB	0 265 007 033

1.9 TD [185..]		1,9l 73,6 kW 182 A 7.000 4 Zyl.	
Air mass meter, diesel	10.96-02.99		0 281 002 144
Speed sensor, diesel	10.96-02.99		0 281 002 102
Temperature sensor, coolant, diesel	10.96-02.99		0 280 130 055
Temperature sensor, intake air, diesel	10.96-02.99		0 280 130 073

Wheel speed sensor, front			
Ricam.no 0172273→,5054835→	10.96-02.99	LAB,LLE	0 265 007 034
Ricam.no 0176273→,5054835→	10.96-02.99	LLE,RAB	0 265 007 035
Ricam.no 0180748→	10.96-02.99	LAB,RLE	0 265 007 034
		RAB,RLE	0 265 007 035

2.0i 20V [185..]		2,0l 108 kW 182 A 1.000 5 Zyl.	
Throttle valve sensor	10.96-02.99		0 280 122 001
Air mass meter, gasoline injection	10.96-02.99		0 280 217 111
Phase sensor			
Ricam.no →2018321,→0270958	10.96-02.99		0 232 101 026
Speed sensor, ignition/injection	10.96-02.99		0 281 002 102
Knock sensor	10.96-02.99		0 261 231 095
Temperature sensor, intake air, injection system	10.96-02.99		0 280 130 073
Temperature sensor, coolant, injection system	10.96-02.99		0 280 130 026

Product				
Relay, Jetronic	10.96-02.99			0 332 014 140
Wheel speed sensor, front				
Ricam.no 0172273→,5054835→	10.96-02.99	LAB,LLE		0 265 007 034
Ricam.no 0176273→,5054835→	10.96-02.99	LLE,RAB		0 265 007 035
Wheel speed sensor, rear				
Ricam.no 0176273→,5054835→	10.96-02.99	LAB,LLE		0 265 007 032
		LLE,RAB		0 265 007 033
2.0 i 20V [185..]	2,0l	110 kW	185 A	8.000 5 Zyl.
Throttle valve assembly	08.00→			0 205 003 052
Air mass meter, gasoline injection	08.00→			0 281 002 309
Phase sensor	08.00→			0 232 101 036
Speed sensor, ignition/injection	08.00→			0 261 210 160
Knock sensor	08.00→			0 261 231 144
Temperature sensor, intake air, injection system	08.00-09.02			0 280 130 073
Wheel speed sensor, front	08.00→	LAB		0 265 007 073
	08.00-03.01	RAB		0 265 007 035
	04.01→	RAB		0 265 007 074
Wheel speed sensor, rear	08.00→	LAB		0 265 007 032
		RAB		0 265 007 033
2.0 i 20V [185..]	2,0l	113 kW	182 B	7.000 5 Zyl.
Throttle valve assembly	03.99→			0 205 003 052
Air mass meter, gasoline injection	03.99→			0 280 218 019
Phase sensor	03.99→			0 232 101 036
Speed sensor, ignition/injection	03.99→			0 261 210 160
Knock sensor	03.99→			0 261 231 144
Temperature sensor, intake air, injection system	03.99→			0 280 130 073
Wheel speed sensor, front	03.99→	LAB		0 265 007 073
	03.99-03.01	RAB		0 265 007 035
	04.01→	RAB		0 265 007 074
Wheel speed sensor, rear	03.99→	LAB		0 265 007 032
		RAB		0 265 007 033
2.4 JTD [185..]	2,4l	100 kW	185 A	6.000 5 Zyl.
Air mass meter, diesel	03.99-09.02			0 280 218 004
Speed sensor, diesel				
Mot.no. →2151823	03.99-09.02			0 281 002 214
Mot.no. 2151824→	03.99-09.02			0 281 002 474
Phase sensor	03.99-09.02			0 281 002 213
High-pressure sensor (CR system)	03.99-09.02			0 281 002 210
		EFV		0 281 002 405
Boost pressure sensor, Diesel	03.99-09.02			0 281 002 215
Temperature sensor, intake air, diesel	03.99-09.02			0 280 130 073
Temperature sensor, fuel	03.99-09.02			0 281 002 209
Wheel speed sensor, front	03.99-09.02	LAB		0 265 007 073
	03.99-03.01	RAB		0 265 007 035
	04.01-09.02	RAB		0 265 007 074
Wheel speed sensor, rear	03.99-09.02	LAB		0 265 007 032
		RAB		0 265 007 033
2.4 MPI 20V	2,4l	118 kW	185 A	7.011 5 Zyl.
Throttle valve assembly	08.00→			1 287 213 608
Air mass meter, gasoline injection	08.00→			0 280 218 019
Phase sensor	08.00→			0 232 101 036
Speed sensor, ignition/injection	08.00→			0 261 210 160
Knock sensor	08.00→			0 261 231 144
Wheel speed sensor, front	08.00→	VLI		0 265 007 034
		VRE		0 265 007 035
Wheel speed sensor, rear	08.00→	HLI		0 265 007 032
		HRE		0 265 007 033
2.4 TD [185..]	2,4l	91 kW	185 A	2.000 5 Zyl.
Air flow sensor, diesel				
Mot.no. →0918279	10.96-02.99			0 281 002 185
Air mass meter, diesel				
Mot.no. 0918280→	10.96-02.99			0 281 002 144

Product				
Speed sensor, diesel	10.96-02.99			0 281 002 102
Temperature sensor, coolant, diesel	10.96-02.99			0 280 130 055
Temperature sensor, intake air, diesel	10.96-02.99			0 280 130 073
Wheel speed sensor, front				
Ricam.no 0172273→,5054835→	10.96-02.99	LAB,LLE		0 265 007 034
Ricam.no 0176273→,5054835→	10.96-02.99	LLE,RAB		0 265 007 035
Ricam.no 0180748→	10.96-02.99	LAB,RLE		0 265 007 034
		RAB,RLE		0 265 007 035
Marea Weekend				
1.8 MPI 16V	1,8l	97 kW	183 A	1.000 4 Zyl.
Phase sensor	08.99→			0 232 101 037
Wheel speed sensor, front	08.99→	VLI		0 265 007 034
		VRE		0 265 007 035
Wheel speed sensor, rear	08.99→	HLI		0 265 007 032
		HRE		0 265 007 033
Marengo				
1.9 D [259..]	1,9l	48 kW	160 A	7.000 4 Zyl.
Wheel speed sensor, front	04.93-12.96	WW		0 265 001 215
Wheel speed sensor, rear	04.93-12.96	LAB		0 265 001 216
		RAB		0 265 001 217
1.9 D Turbo [259..]	1,9l	66 kW	160 A	6.000 4 Zyl.
Wheel speed sensor, front	02.90-03.93			0 265 001 215
Wheel speed sensor, rear	02.90-12.96	LAB		0 265 001 216
	04.93-12.96	RAB		0 265 001 217
	02.90-03.93	RAB		0 265 006 197
1.9 JTD [285..]	1,9l	77 kW	182 B	4.000 4 Zyl.
Air mass meter, diesel	03.99-09.02			0 280 218 019
Speed sensor, diesel				
Mot.no. →2151823	03.99-09.02			0 281 002 214
Mot.no. 2151824→	03.99-09.02			0 281 002 474
Phase sensor	03.99-09.02			0 281 002 213
High-pressure sensor (CR system)	03.99-09.02			0 281 002 210
		EFV		0 281 002 405
Boost pressure sensor, Diesel	03.99-09.02			0 281 002 215
Temperature sensor, fuel	03.99-09.02			0 281 002 209
Wheel speed sensor, front	03.99-09.02	LAB		0 265 007 073
	03.99-03.01	RAB		0 265 007 035
	04.01-09.02	RAB		0 265 007 074
Wheel speed sensor, rear	03.99-09.02	LAB		0 265 007 032
		RAB		0 265 007 033
1.9 JTD [285..]	1,9l	81 kW	186 A	6.000 4 Zyl.
Air mass meter, diesel	08.00-09.02			0 281 002 308
Speed sensor, diesel				
Mot.no. →2151823	08.00-09.02			0 281 002 214
Mot.no. 2151824→	08.00-09.02			0 281 002 474
Phase sensor	08.00-09.02			0 281 002 213
High-pressure sensor (CR system)	08.00-09.02			0 281 002 260
		EFV		0 281 002 405
Boost pressure sensor, Diesel				
Mot.no. →2705194	08.00-07.01			0 281 002 215
Mot.no. 2705195→	08.01-09.02			0 281 002 510
Wheel speed sensor, front	08.00-09.02	LAB		0 265 007 073
	08.00-03.01	RAB		0 265 007 035
	04.01-09.02	RAB		0 265 007 074
Wheel speed sensor, rear	08.00-09.02	LAB		0 265 007 032
		RAB		0 265 007 033





Product				

◀ Marengo

1.9 TD [285..]	1,9l	55 kW	182 A	8.000	4 Zyl.
Speed sensor, diesel	03.99-09.02			0 281 002 102	
Wheel speed sensor, front	03.99-09.02	LAB		0 265 007 073	
	03.99-03.01	RAB		0 265 007 035	
	04.01-09.02	RAB		0 265 007 074	
Wheel speed sensor, rear	03.99-09.02	LAB		0 265 007 032	
		RAB		0 265 007 033	
1.9 TD [285..]	1,9l	55,1 kW	182 A	8.000	4 Zyl.
Speed sensor, diesel	01.97-09.02			0 281 002 102	
Wheel speed sensor, front	03.99-09.02	LAB,LLE		0 265 007 073	
Ricam.no 0172273→,5054835→	01.97-02.99	LAB,LLE		0 265 007 034	
Ricam.no 0176273→,5054835→	01.97-09.02	LLE,RAB		0 265 007 035	
Wheel speed sensor, rear					
Ricam.no 0176273→,5054835→	01.97-09.02	LAB,LLE		0 265 007 032	
		LLE,RAB		0 265 007 033	
1.9 TD [285..]	1,9l	73,6 kW	182 A	7.000	4 Zyl.
Air mass meter, diesel	01.97-02.99			0 281 002 144	
Speed sensor, diesel	01.97-02.99			0 281 002 102	
Temperature sensor, coolant, diesel	01.97-02.99			0 280 130 055	
Temperature sensor, intake air, diesel	01.97-02.99			0 280 130 073	
Wheel speed sensor, front					
Ricam.no 0172273→,5054835→	01.97-02.99	LAB,LLE		0 265 007 034	
Ricam.no 0176273→,5054835→	01.97-02.99	LLE,RAB		0 265 007 035	
Wheel speed sensor, rear					
Ricam.no 0176273→,5054835→	01.97-02.99	LAB,LLE		0 265 007 032	
		LLE,RAB		0 265 007 033	

Multipla

1.6 Blupower [186..]	1,6l	70 kW	186 A	3.000	4 Zyl.
Wheel speed sensor, front	01.99-03.02	LAB		0 265 007 038	
		RAB		0 265 007 039	
Ricam.no →2152664	04.02→	LAB		0 265 007 038	
		RAB		0 265 007 039	
Ricam.no 2152665→	04.02→	LAB		0 265 007 561	
		RAB		0 265 007 560	
Wheel speed sensor, rear	01.99-03.02	LAB		0 265 007 036	
		RAB		0 265 007 037	
Ricam.no →2152664	04.02→	LAB		0 265 007 551	
		RAB		0 265 007 550	
Ricam.no 2152665→	04.02→	LAB		0 265 007 563	
		RAB		0 265 007 562	
1.6 16V [186..]	1,6l	76 kW	182 A	4.000	4 Zyl.
Wheel speed sensor, front	01.99-03.02	LAB		0 265 007 038	
		RAB		0 265 007 039	
Wheel speed sensor, rear	01.99-03.02	LAB		0 265 007 036	
		RAB		0 265 007 037	
1.6 16V [186..]	1,6l	76 kW	182 B	6.000	4 Zyl.
Yaw rate sensor, brake system	04.02→			0 265 005 241	
Wheel speed sensor, front					
Ricam.no →2152664	09.00→	LAB		0 265 007 038	
		RAB		0 265 007 039	
Ricam.no 2152665→	09.00→	LAB		0 265 007 561	
		RAB		0 265 007 560	
Wheel speed sensor, rear	09.00-03.02	LAB		0 265 007 036	
		RAB		0 265 007 037	
Ricam.no →2152664	04.02→	LAB		0 265 007 551	
		RAB		0 265 007 550	
Ricam.no 2152665→	09.00→	LAB		0 265 007 563	
		RAB		0 265 007 562	

Product				

1.6 16V Bipower [186..]	1,6l	68-76 kW	182 B	6.000	4 Zyl.
Yaw rate sensor, brake system	04.02→			0 265 005 241	
Wheel speed sensor, front					
Ricam.no →2152664	01.01→	LAB		0 265 007 038	
		RAB		0 265 007 039	
Ricam.no 2152665→	01.01→	LAB		0 265 007 561	
		RAB		0 265 007 560	
Wheel speed sensor, rear	01.01-03.02	LAB		0 265 007 036	
		RAB		0 265 007 037	
Ricam.no →2152664	04.02→	LAB		0 265 007 551	
		RAB		0 265 007 550	
Ricam.no 2152665→	01.01→	LAB		0 265 007 563	
		RAB		0 265 007 562	
1.6 16V Bipower [186..]	1,6l	68-76 kW	186 A	4.000	4 Zyl.
Wheel speed sensor, front	01.99-03.02	LAB		0 265 007 038	
		RAB		0 265 007 039	
Wheel speed sensor, rear	01.99-03.02	LAB		0 265 007 036	
		RAB		0 265 007 037	
1.6 16V GPL [186..]	1,6l	68-76 kW	182 B	6.000	4 Zyl.
Wheel speed sensor, front					
Ricam.no →2152664	01.01→	LAB		0 265 007 038	
		RAB		0 265 007 039	
Ricam.no 2152665→	01.01→	LAB		0 265 007 561	
		RAB		0 265 007 560	
Wheel speed sensor, rear	01.01-03.02	LAB		0 265 007 036	
		RAB		0 265 007 037	
Ricam.no →2152664	04.02→	LAB		0 265 007 551	
		RAB		0 265 007 550	
Ricam.no 2152665→	01.01→	LAB		0 265 007 563	
		RAB		0 265 007 562	
1.9 JTD [186..]	1,9l	77 kW	182 B	4.000	4 Zyl.
Air mass meter, diesel	01.99-12.00			0 280 218 004	
Speed sensor, diesel					
Mot.no. →2151823	01.99-12.00			0 281 002 214	
Mot.no. 2151824→	01.99-12.00			0 281 002 474	
Phase sensor	01.99-12.00			0 281 002 213	
High-pressure sensor (CR system)	01.99-07.99			0 281 002 210	
	08.99-12.00			0 281 002 405	
Boost pressure sensor, Diesel	01.99-12.00			0 281 002 510	
Temperature sensor, fuel	01.99-12.00			0 281 002 209	
Wheel speed sensor, front	01.99-12.00	LAB		0 265 007 038	
		RAB		0 265 007 039	
Wheel speed sensor, rear	01.99-12.00	LAB		0 265 007 036	
		RAB		0 265 007 037	
1.9 JTD [186..]	1,9l	81 kW	186 A	6.000	4 Zyl.
Air mass meter, diesel	08.00-03.02			0 281 002 308	
Speed sensor, diesel					
Mot.no. →2151823	08.00-03.02			0 281 002 214	
Mot.no. 2151824→	08.00-03.02			0 281 002 474	
Phase sensor	08.00-03.02			0 281 002 213	
High-pressure sensor (CR system)	08.00-03.02			0 281 002 405	
Boost pressure sensor, Diesel					
Mot.no. →2705194	08.00-07.01			0 281 002 215	
Mot.no. 2705195→	08.01-03.02			0 281 002 510	
Wheel speed sensor, front	08.00-03.02	LAB		0 265 007 038	
		RAB		0 265 007 039	
Wheel speed sensor, rear	08.00-03.02	LAB		0 265 007 036	
		RAB		0 265 007 037	
1.9 JTD [186..]	1,9l	85 kW	186 A	8.000	4 Zyl.
Air mass meter, diesel	11.03→			0 280 218 120	
	04.02-10.03			0 281 002 308	
	10.03→			0 281 002 792	



Speed sensor, diesel	10.03→	KW	0 281 002 603
Mot.no. →3927658	04.02→		0 281 002 474
Mot.no. 3927659→	04.02→		0 281 002 603
Phase sensor	04.02→		0 281 002 213
	10.03→	NOC	0 281 002 213
High-pressure sensor (CR system)	04.02-02.04		0 281 002 405
	10.03→		0 281 002 534
Boost pressure sensor, Diesel	10.03-03.07		0 281 002 437
	04.02-08.06		0 281 002 510
	09.06→		0 281 002 844
	04.07→		0 281 002 845
Pedal position sensor, diesel	04.02→	RLE	0 281 002 386
Yaw rate sensor, brake system	04.02→		0 265 005 241
Wheel speed sensor, front			
Ricam.no →2152664	04.02→	LAB	0 265 007 038
		RAB	0 265 007 039
Ricam.no 2152665→	04.02→	LAB	0 265 007 561
		RAB	0 265 007 560
Wheel speed sensor, rear			
Ricam.no →2152664	04.02→	LAB	0 265 007 551
		RAB	0 265 007 550
Ricam.no 2152665→	04.02→	LAB	0 265 007 563
		RAB	0 265 007 562
1.9 JTD [186..]	1,9l 88 kW 186 A 9.000	4 Zyl.	
Air mass meter, diesel	10.05→		0 281 002 792
Speed sensor, diesel	10.05→	KW	0 281 002 603
Phase sensor	10.05→	NOC	0 281 002 213
High-pressure sensor (CR system)	10.05→		0 281 002 534
Boost pressure sensor, Diesel	10.05-03.07		0 281 002 437
	04.07→		0 281 002 845
Pedal position sensor, diesel	10.05→	RLE	0 281 002 386
Yaw rate sensor, brake system	10.05→		0 265 005 241
Wheel speed sensor, front			
Ricam.no →2152664	10.05→	LAB	0 265 007 038
		RAB	0 265 007 039
Ricam.no 2152665→	10.05→	LAB	0 265 007 561
		RAB	0 265 007 560
Wheel speed sensor, rear			
Ricam.no →2152664	10.05→	LAB	0 265 007 551
		RAB	0 265 007 550
Ricam.no 2152665→	10.05→	LAB	0 265 007 563
		RAB	0 265 007 562

Nuova Croma

1.9 JTD 8V [194..]	1,9l 85/88 kW 939 A 1.000	4 Zyl.	
Speed sensor, diesel	06.05→	KW	0 281 002 603
Phase sensor	06.05→		0 281 002 213
High-pressure sensor (CR system)	06.05→		0 281 002 534
Boost pressure sensor, Diesel	06.05→		0 281 002 437
1.9 JTD 16V [194..]	1,9l 100/110 kW 939 A 1.000; 939 A 2.000	4 Zyl.	
High-pressure sensor (CR system)	06.05→		0 281 002 534
Boost pressure sensor, Diesel	06.05→		0 281 002 437
2.4 JTD [194..]	2,4l 147 kW 939 A 3.000	5 Zyl.	
Air mass meter, diesel	06.05→		0 281 002 763
High-pressure sensor (CR system)	06.05→		0 281 002 534
Boost pressure sensor, Diesel	06.05→		0 281 002 437



Nuova 500

1.2 8V [150..]	1,2l 51 kW 169 A 4.000	4 Zyl.	
Phase sensor	07.07→		0 232 103 048
Pressure sensor, intake manifold, gasoline	07.07→		0 261 230 030
Yaw rate sensor, brake system	07.07→		0 265 005 607
1.3 MJTD [150..]	1,3l 55 kW 169 A 1.000	4 Zyl.	
Boost pressure sensor, Diesel	07.07→		0 281 002 844
Yaw rate sensor, brake system	07.07→		0 265 005 607
1.4 16V [150..]	1,4l 74 kW 169 A 3.000	4 Zyl.	
Throttle valve assembly	07.07→		F 01C 600 027
Phase sensor	07.07→		0 232 103 048
Speed sensor, ignition/injection	07.07→		0 261 210 238
Knock sensor	07.07→		0 261 231 173
Pressure sensor, intake manifold, gasoline	07.07→		F 01C 600 070
Yaw rate sensor, brake system	07.07→		0 265 005 607

Palio

1.0 MPI 8V	1,0l 45 kW 178 A 3.011	4 Zyl.	
Wheel speed sensor, front	06.96-08.01	LAB	0 265 006 163
		RAB	0 265 006 164
Wheel speed sensor, rear	06.96-08.01		0 265 006 249
1.0 MPI 8V 6 Marchas	1,0l 45 kW 178 A 3.011	4 Zyl.	
Wheel speed sensor, front	01.99-10.00	LAB	0 265 006 163
		RAB	0 265 006 164
Wheel speed sensor, rear	01.99-10.00		0 265 006 249
1.0 MPI 16V	1,0l 51,5 kW 178 D 8.011	4 Zyl.	
Throttle valve assembly	08.00-02.03		F 01C 600 023
Speed sensor, ignition/injection	08.00-02.03		0 261 210 161
Knock sensor	08.00-02.03		0 261 231 173
Pressure sensor, intake manifold, gasoline	08.00-02.03		0 261 230 030
Wheel speed sensor, front	08.00-02.03	LAB	0 265 007 103
		RAB	0 265 007 102
Wheel speed sensor, rear	08.00-02.03		0 265 007 051
1.1 [178..]	1,1l 40 kW 178 B 9.033	4 Zyl.	
Wheel speed sensor, front	03.01-07.01	LAB	0 265 006 163
	03.98-07.01	RAB	0 265 006 164
Wheel speed sensor, rear	03.01-07.01		0 265 006 249
1.2 i.e. 8V [171..]	1,2l 44 kW 188 A 4.000	4 Zyl.	
Speed sensor, ignition/injection	10.01→		0 261 210 114
1.2 i.e. 8V [171..]	1,2l 46 kW 178 C 4.066	4 Zyl.	
Phase sensor	07.01→		0 232 103 039
Speed sensor, ignition/injection	07.01-10.03	OLH	0 261 210 114
	11.03→	OLH	0 261 210 114
Wheel speed sensor, front	07.01→	LAB	0 265 007 103
		RAB	0 265 007 102
Wheel speed sensor, rear	07.01→		0 265 007 051
1.2 i.e. 8V [171..]	1,2l 54 kW 178 B 7.045	4 Zyl.	
Phase sensor			
Mot.no. 2935744→	10.01→		0 232 103 048
Speed sensor, ignition/injection	10.01-10.03	OLH	0 261 210 114
	11.03→	OLH	0 261 210 114
1.2 i.e. 8V [178..]	1,2l 44 kW 178 B 5.000	4 Zyl.	
Phase sensor	01.01-09.01		0 232 103 039
Speed sensor, ignition/injection	09.00-08.02		0 261 210 114
Wheel speed sensor, front	01.01-09.01	LAB	0 265 006 163
	03.01-08.02	LAB	0 265 006 163
	09.00-08.02	RAB	0 265 006 164
Wheel speed sensor, rear	01.01-09.01		0 265 006 249
	03.01-08.02		0 265 006 249





Product

◀ Palio

1.2 i.e. 8V [178..]		1,2l 44/54 kW 178 B 7.045; 188 A 4.000 4 Zyl.	
Speed sensor, ignition/injection	03.00-09.01		0 261 210 114
Wheel speed sensor, front	03.00-09.01	LAB	0 265 006 163
		RAB	0 265 006 164
Wheel speed sensor, rear	03.00-09.01		0 265 006 249
1.2 i.e. 8V [178..]		1,2l 54 kW 178 E 2.000 4 Zyl.	
Speed sensor, ignition/injection	11.99-09.01	OLH	0 261 210 114
Wheel speed sensor, front	11.99-09.01	LAB	0 265 006 163
		RAB	0 265 006 164
Wheel speed sensor, rear	11.99-09.01		0 265 006 249
1.2 i.e. 16V [171..]		1,2l 59 kW 188 A 5.000 4 Zyl.	
Throttle valve assembly	10.01→		0 280 750 042
Speed sensor, ignition/injection	10.01→		0 261 210 219
Knock sensor	10.01→		0 261 231 173
Pressure sensor, intake manifold, gasoline	10.01→		0 261 230 030
Temperature sensor, coolant, injection system	10.01→		F 01C 050 016
Accelerator pedal module	10.01→		0 281 002 379
Wheel speed sensor, front	10.01→	LAB	0 265 007 103
		RAB	0 265 007 102
Wheel speed sensor, rear	10.01→		0 265 007 051
1.3 JTD 16V [171..]		1,2l 52 kW 188 A 9.000 4 Zyl.	
Air mass meter, diesel	07.03→		0 281 002 613
High-pressure sensor (CR system)	07.03→		0 281 002 534
Boost pressure sensor, Diesel			
Mot.no. →1376014	07.03→		0 281 002 510
Mot.no. 1376015→	07.03→		0 281 002 844
Accelerator pedal module	07.03→		0 281 002 379
		RLE	0 281 002 369
Wheel speed sensor, front	07.03→	LAB	0 265 007 103
		RAB	0 265 007 102
Wheel speed sensor, rear	07.03→		0 265 007 051
1.3 MPI 16V		1,3l 59 kW 178 D 6.011 4 Zyl.	
Throttle valve assembly	03.00→		F 01C 600 023
Speed sensor, ignition/injection	03.00→		0 261 210 161
Knock sensor	03.00→		0 261 231 173
Pressure sensor, intake manifold, gasoline	03.00→		0 261 230 030
Accelerator pedal module	03.00-02.03		0 281 002 379
Wheel speed sensor, front	03.00-09.00	LAB	0 265 006 163
	10.00→	LAB	0 265 007 103
	03.00-09.00	RAB	0 265 006 164
	10.00→	RAB	0 265 007 102
Wheel speed sensor, rear	03.00-09.00		0 265 006 249
	10.00→		0 265 007 051
1.4 i.e. [171..]		1,4l 57 kW 350 A 1.000 4 Zyl.	
Phase sensor	07.03→		0 232 103 048
Pressure sensor, intake manifold, gasoline	07.03→		0 261 230 030
Accelerator pedal module	07.03→		0 281 002 379
Wheel speed sensor, front	07.03→	LAB	0 265 007 103
		RAB	0 265 007 102
Wheel speed sensor, rear	07.03→		0 265 007 051
1.4 i.e. [178..]		1,4l 51 kW 178 B 2.000; 178 B 2.016 4 Zyl.	
Speed sensor, ignition/injection	03.98-09.01		0 261 210 104
Wheel speed sensor, front	03.98-09.01	LAB	0 265 006 163
		RAB	0 265 006 164
Wheel speed sensor, rear	03.98-09.01		0 265 006 249
1.5 MPI 8V		1,5l 60 kW 178 A 5.011 4 Zyl.	
Wheel speed sensor, front	04.96-11.99	LAB	0 265 006 163
		RAB	0 265 006 164
Wheel speed sensor, rear	04.96-11.99		0 265 006 249
1.6 i.e. 16V [171..]		1,6l 74/76 kW 182 B 6.000 4 Zyl.	
Wheel speed sensor, front	07.01→	LAB	0 265 007 103
		RAB	0 265 007 102
Wheel speed sensor, rear	07.01→		0 265 007 051

Product

1.6 i.e. 16V [178..]				1,6 l 74/76 kW 178 B 3.000; 178 D 2.011; 182 B 6.000 4 Zyl.
Wheel speed sensor, front	03.98-09.01	LAB		0 265 006 163
		RAB		0 265 006 164
Wheel speed sensor, rear	03.98-09.01			0 265 006 249
1.6 i.e. 16V Sport [171..]				1,6 l 76 kW 178 E 7.000 4 Zyl.
Wheel speed sensor, front	10.01→	LAB		0 265 007 103
		RAB		0 265 007 102
Wheel speed sensor, rear	10.01→			0 265 007 051
1.7 D Turbo				1,7 l 52 kW 4 Zyl.
Wheel speed sensor, front	01.04→	LAB		0 265 007 103
		RAB		0 265 007 102
Wheel speed sensor, rear	01.04→			0 265 007 051
1.7 D Turbo [Fase II]				1,7 l 52 kW 4 Zyl.
Wheel speed sensor, front	01.04→	LAB		0 265 007 103
		RAB		0 265 007 102
Wheel speed sensor, rear	01.04→			0 265 007 051
1.9 D [171..]				1,9 l 48 kW 223 A 6.000 4 Zyl.
Speed sensor, diesel	01.03-06.05			0 281 002 474
Wheel speed sensor, front	01.03-06.05	LAB		0 265 007 103
		RAB		0 265 007 102
Wheel speed sensor, rear	01.03-06.05			0 265 007 051

Palio Weekend				
1.0 MPI 16V		1,0l 51 kW 178 D 8.011 4 Zyl.		
Throttle valve assembly	09.00-08.01	F 01C 600 023		
	08.02-02.03	F 01C 600 023		
Speed sensor, ignition/injection	09.00-02.03	0 261 210 161		
Knock sensor	09.00-02.03	0 261 231 173		
Pressure sensor, intake manifold, gasoline	09.00-02.03	0 261 230 030		
Wheel speed sensor, front	09.00-02.03	LAB	0 265 007 103	
		RAB	0 265 007 102	
Wheel speed sensor, rear	09.00-02.03	LAB	0 265 007 052	
		RAB	0 265 007 053	
1.2 i.e. [178..]		1,2l 44 kW 178 C 4.066 4 Zyl.		
Speed sensor, ignition/injection	08.00-02.02	0 261 210 114		
Wheel speed sensor, front	08.00-02.02	LAB	0 265 006 163	
		RAB	0 265 006 164	
Wheel speed sensor, rear	08.00-02.02	LAB	0 265 006 364	
		RAB	0 265 006 365	
1.2 i.e. 8V [173..]		1,2l 44 kW 188 A 4.000 4 Zyl.		
Speed sensor, ignition/injection	10.01-10.03	0 261 210 114		
	11.03→	0 261 210 114		
Wheel speed sensor, front	10.01→	LAB	0 265 007 103	
		RAB	0 265 007 102	
Wheel speed sensor, rear	10.01→	LAB	0 265 007 052	
		RAB	0 265 007 053	
1.2 i.e. 8V [178..]		1,2l 44 kW 178 B 5.000 4 Zyl.		
Phase sensor	01.01-09.01	0 232 103 039		
Speed sensor, ignition/injection	03.99-09.01	0 261 210 114		
Wheel speed sensor, front	03.99-09.01	LAB	0 265 006 163	
		RAB	0 265 006 164	
Wheel speed sensor, rear	03.99-09.01	LAB	0 265 006 364	
		RAB	0 265 006 365	
1.2 i.e. 16V [173..]		1,2l 59 kW 188 A 5.000 4 Zyl.		
Throttle valve assembly	10.01-01.06	F 01C 600 023		
	02.06→	0 280 750 042		
Phase sensor	10.01→	0 232 103 048		
Speed sensor, ignition/injection	10.01→	0 261 210 219		
Knock sensor	10.01→	0 261 231 173		
Pressure sensor, intake manifold, gasoline	10.01→	0 261 230 030		
Temperature sensor, coolant, injection system	10.01→	F 01C 050 016		
Accelerator pedal module	10.01→	0 281 002 379		



F



Wheel speed sensor, front	10.01→	LAB	0 265 007 103
		RAB	0 265 007 102
Wheel speed sensor, rear	10.01→	LAB	0 265 007 052
		RAB	0 265 007 053
1.3 i MPI 16V [173..] 1,2l 59 kW 188 A 5.000 4 Zyl.			
Throttle valve assembly	06.03-01.06		F 01C 600 023
	02.06-02.07		0 280 750 042
Speed sensor, ignition/injection	06.03-02.07		0 261 210 219
Knock sensor	06.03-02.07		0 261 231 173
Pressure sensor, intake manifold, gasoline	06.03-02.07		0 261 230 030
Temperature sensor, coolant, injection system	06.03-02.07		F 01C 050 016
Accelerator pedal module	06.03-02.07		0 281 002 379
Wheel speed sensor, front	06.03-02.07	LAB	0 265 007 103
		RAB	0 265 007 102
Wheel speed sensor, rear	06.03-02.07	LAB	0 265 007 052
		RAB	0 265 007 053
1.3 MPI 16V 1,3l 59 kW 178 D 6.011 4 Zyl.			
Throttle valve assembly	03.00-02.03		F 01C 600 023
Speed sensor, ignition/injection	03.00-02.03		0 261 210 161
Knock sensor	03.00-02.03		0 261 231 173
Pressure sensor, intake manifold, gasoline	03.00-02.03		0 261 230 030
Accelerator pedal module	03.00-02.03		0 281 002 379
Wheel speed sensor, front	03.00-09.00	LAB	0 265 006 163
	10.00-02.03	LAB	0 265 007 103
	03.00-09.00	RAB	0 265 006 164
	10.00-02.03	RAB	0 265 007 102
Wheel speed sensor, rear	03.00-09.00	LAB	0 265 006 364
	10.00-02.03	LAB	0 265 007 052
	03.00-09.00	RAB	0 265 006 365
	10.00-02.03	RAB	0 265 007 053
1.4 i.e. [178..] 1,4l 51 kW 178 B 2.000; 178 B 2.016 4 Zyl.			
Speed sensor, ignition/injection	11.97-06.01		0 261 210 104
Wheel speed sensor, front	11.97-06.01	LAB	0 265 006 163
		RAB	0 265 006 164
Wheel speed sensor, rear	11.97-06.01	LAB	0 265 006 364
		RAB	0 265 006 365
1.6 i.e. 8V [178..] 1,6l 69 kW 178 C 8.098 4 Zyl.			
Speed sensor, ignition/injection	06.01-09.02		0 261 210 104
Wheel speed sensor, front	06.01-09.02	LAB	0 265 006 163
		RAB	0 265 006 164
Wheel speed sensor, rear	06.01-09.02	LAB	0 265 006 364
		RAB	0 265 006 365
1.6 i.e. 16V [173..] 1,6l 76 kW 182 B 6.000 4 Zyl.			
Wheel speed sensor, front	10.01→	LAB	0 265 007 103
		RAB	0 265 007 102
Wheel speed sensor, rear	10.01→	LAB	0 265 007 052
		RAB	0 265 007 053
1.6 i.e. 16V [178..] 1,6l 74/76 kW 176 D 2.011; 178 B 3.000; 178 C 7.098; 182 B 6.000 4 Zyl.			
Wheel speed sensor, front	11.97→	LAB	0 265 006 163
		RAB	0 265 006 164
Wheel speed sensor, rear	11.97→	LAB	0 265 006 364
		RAB	0 265 006 365
1.6 MPI 16V 1,6l 78 kW 178 D 2.011 4 Zyl.			
Wheel speed sensor, front	05.97-09.00	LAB	0 265 006 163
	10.00-02.03	LAB	0 265 007 103
	05.97-09.00	RAB	0 265 006 164
	10.00-02.03	RAB	0 265 007 102
Wheel speed sensor, rear	05.97-09.00	LAB	0 265 006 364
	10.00-02.03	LAB	0 265 007 052
	05.97-09.00	RAB	0 265 006 365
	10.00-02.03	RAB	0 265 007 053



1.7 D Turbo			1,7l 52 kW 4 Zyl.
Wheel speed sensor, front	01.04→	LAB	0 265 007 103
		RAB	0 265 007 102
Wheel speed sensor, rear	01.04→		0 265 007 051
1.7 TD [178..] 1,7l 46/51 kW 176 A 3.000; 176 B 7.000; 178 C 9.066 4 Zyl.			
Wheel speed sensor, front	09.97-02.02	LAB	0 265 006 163
		RAB	0 265 006 164
Wheel speed sensor, rear	09.97-02.02	LAB	0 265 006 364
		RAB	0 265 006 365
1.9 D [173..] 1,9l 48 kW 223 A 6.000 4 Zyl.			
Speed sensor, diesel	01.03-02.04		0 281 002 474
Wheel speed sensor, front	01.03-02.04	LAB	0 265 007 103
		RAB	0 265 007 102
Wheel speed sensor, rear	01.03-02.04	LAB	0 265 007 052
		RAB	0 265 007 053
1.9 D [178..] 1,9l 51 kW 188 A 2.000 4 Zyl.			
Speed sensor, diesel	04.03-09.04		0 281 002 474
Accelerator pedal module	04.03-09.04		0 281 002 379
Wheel speed sensor, front	04.03-09.04	LAB	0 265 007 103
		RAB	0 265 007 102
Wheel speed sensor, rear	04.03-09.04	LAB	0 265 007 052
		RAB	0 265 007 053
1.9 D [178..] 1,9l 46 kW 223 A 6.000 4 Zyl.			
Speed sensor, diesel	11.00-09.01		0 281 002 474
Accelerator pedal module	11.00-09.01		0 281 002 379
Wheel speed sensor, front	11.00-09.01	LAB	0 265 006 163
		RAB	0 265 006 164
Wheel speed sensor, rear	11.00-09.01		0 265 006 249
1.9 JTD [173..] 1,9l 57/80 kW 188 A 2.000 4 Zyl.			
Air mass meter, diesel	10.01→		0 281 002 308
Speed sensor, diesel	10.01-01.04		0 281 002 474
	02.04→		0 281 002 603
Phase sensor	10.01→		0 281 002 213
High-pressure sensor (CR system)	10.01-02.04		0 281 002 405
Boost pressure sensor, Diesel	10.01-09.04		0 281 002 510
Accelerator pedal module	10.01-09.04		0 281 002 379
Wheel speed sensor, front	10.01-09.04	LAB	0 265 007 103
		RAB	0 265 007 102
Wheel speed sensor, rear	10.01-09.04	LAB	0 265 007 052
		RAB	0 265 007 053
1.9 JTD [173..] 1,9l 80 kW 188 A 2.000 4 Zyl.			
High-pressure sensor (CR system)	06.02-01.04		0 281 002 405
Boost pressure sensor, Diesel	06.02→		0 281 002 510
Accelerator pedal module	06.02→		0 281 002 379
Wheel speed sensor, front	06.02→	LAB	0 265 007 103
		RAB	0 265 007 102
Wheel speed sensor, rear	06.02→	LAB	0 265 007 052
		RAB	0 265 007 053
75 1.2 i.e. [178..] 1,2l 54 kW 178 B 5.000 4 Zyl.			
Speed sensor, ignition/injection	09.97-09.01		0 261 210 114
Wheel speed sensor, front	09.97-09.01	LAB	0 265 006 163
		RAB	0 265 006 164
Wheel speed sensor, rear	09.97-09.01	LAB	0 265 006 364
		RAB	0 265 006 365
75 1.2 i.e. [178..] 1,2l 54 kW 188 A 4.000 4 Zyl.			
Wheel speed sensor, front	08.00-09.01	LAB	0 265 006 163
		RAB	0 265 006 164
Wheel speed sensor, rear	08.00-09.01	LAB	0 265 006 364
		RAB	0 265 006 365
75 1.2 i.e. 8V [173..] 1,2l 54 kW 188 A 4.000 4 Zyl.			
Phase sensor	10.01-09.04		0 232 103 039
Speed sensor, ignition/injection	10.01-10.03		0 261 210 114
	11.03-09.04		0 261 210 114

Product

◀ Palio Weekend

Wheel speed sensor, front	10.01-09.04	LAB	0 265 007 103
		RAB	0 265 007 102
Wheel speed sensor, rear	10.01-09.04	LAB	0 265 007 052
		RAB	0 265 007 053
85 1.2 i.e. 16V [173..]		1,2l 63 kW	188 A 5.000 4 Zyl.
Throttle valve assembly	10.01-09.04		F 01C 600 023
Phase sensor	10.01-09.04		0 232 103 048
Speed sensor, ignition/injection	10.01-09.04		0 261 210 219
Knock sensor	10.01-09.04		0 261 231 173
Pressure sensor, intake manifold, gasoline	10.01-09.04		0 261 230 030
Accelerator pedal module	10.01-09.04		0 281 002 379
Wheel speed sensor, front	10.01-09.04	LAB	0 265 007 103
		RAB	0 265 007 102
Wheel speed sensor, rear	10.01-09.04	LAB	0 265 007 052
		RAB	0 265 007 053
100 1.6 i.e. 16V [173..]		1,6l 76 kW	182 B 6.000 4 Zyl.
Wheel speed sensor, front	10.01-09.04	LAB	0 265 007 103
		RAB	0 265 007 102
Wheel speed sensor, rear	10.01-09.04	LAB	0 265 007 052
		RAB	0 265 007 053
100 1.6 i.e. 16V [178..]		1,6l 76 kW	178 B 3.000; 182 B 6.000 4 Zyl.
Wheel speed sensor, front	09.97-09.01	LAB	0 265 006 163
		RAB	0 265 006 164
Wheel speed sensor, rear	09.97-09.01	LAB	0 265 006 364
		RAB	0 265 006 365

F



Panda				
1.1 i.e. [169..]		1,1l	40 kW	187 A 1.000 4 Zyl.
Phase sensor	10.03→	NOC	0 232 103 048	
Pressure sensor, intake manifold, gasoline	10.03→		0 261 230 030	
Wheel speed sensor, front	10.03→		0 265 007 448	
Wheel speed sensor, rear	10.03→		0 265 007 449	
1.2 i.e. [169..]		1,2l	44 kW	188 A 4.000 4 Zyl.
Pressure sensor, intake manifold, gasoline	10.03→		0 261 230 030	
Acceleration sensor, ABS	10.03→		0 265 005 127	
Yaw rate sensor, brake system	10.03→		0 265 005 241	
Wheel speed sensor, front	10.03→		0 265 007 448	
Wheel speed sensor, rear	10.03→		0 265 007 449	
1.2 i.e. Natural Power [169..]		1,2l	38-44 kW	188 A 4.000 4 Zyl.
Phase sensor	12.06→	NOC	0 232 103 048	
Acceleration sensor, ABS	12.06→		0 265 005 127	
Yaw rate sensor, brake system	12.06→		0 265 005 241	
Wheel speed sensor, front	12.06→		0 265 007 639	
1.2 i.e. 4x4 [169..]		1,2l	44 kW	188 A 4.000 4 Zyl.
Pressure sensor, intake manifold, gasoline	10.04→		0 261 230 030	
Wheel speed sensor, front	10.04→		0 265 007 639	
Wheel speed sensor, rear	10.04→		0 265 007 640	
1.3 JTD [169..]		1,3l	52 kW	188 A 9.000 4 Zyl.
Air mass meter, diesel	01.04→		0 281 002 613	
High-pressure sensor (CR system)	01.04→		0 281 002 534	
Boost pressure sensor, Diesel	01.04-08.06		0 281 002 510	
	09.06→		0 281 002 844	
Acceleration sensor, ABS	01.04→		0 265 005 127	
Yaw rate sensor, brake system	01.04→		0 265 005 241	
Wheel speed sensor, front	01.04→		0 265 007 448	
Wheel speed sensor, rear	01.04→		0 265 007 449	
1.3 JTD [169..]		1,3l	55 kW	169 A 1.000 4 Zyl.
Air mass meter, diesel	05.06→		0 281 002 792	
Boost pressure sensor, Diesel	05.06→	→1376014	0 281 002 510	
			0 281 002 844	
			0 265 005 127	
Acceleration sensor, ABS	05.06→		0 265 005 127	

Product				
Yaw rate sensor, brake system	05.06→		0 265 005 241	
Wheel speed sensor, front	05.06→		0 265 007 448	
Wheel speed sensor, rear	05.06→		0 265 007 449	
1.3 JTD 4x4 [169..]		1,3l 52 kW	188 A 9.000	4 Zyl.
Air mass meter, diesel	09.05→		0 281 002 613	
High-pressure sensor (CR system)	09.05→		0 281 002 534	
Boost pressure sensor, Diesel	09.05-08.06		0 281 002 510	
	09.06→		0 281 002 844	
Wheel speed sensor, front	09.05→		0 265 007 639	
Wheel speed sensor, rear	09.05→		0 265 007 640	
1.4 i.e. 16V [169..]		1,4l 74 kW	169 A 3.000	4 Zyl.
Throttle valve assembly	10.06→		F 01C 600 066	
Speed sensor, ignition/injection	10.06→		0 261 210 238	
Knock sensor	10.06→		0 261 231 173	
Pressure sensor, intake manifold, gasoline	10.06→		F 01C 600 070	
Acceleration sensor, ABS	10.06→		0 265 005 127	
Yaw rate sensor, brake system	10.06→		0 265 005 241	
Wheel speed sensor, front	10.06→		0 265 007 448	
Wheel speed sensor, rear	10.06→		0 265 007 449	
1000 i.e. [141..]		1,0l 33 kW	141 C 2.000	4 Zyl.
Speed sensor, ignition/injection				
Mot.no. 4599750→	01.95-09.03		0 261 210 117	
1000 i.e. [141..]		1,0l 33 kW	156 A 2.246	4 Zyl.
Temperature sensor, coolant, injection system	01.86-03.97	MEB	0 280 130 026	
1000 i.e. 4x4 [153..]		1,0l 33 kW	156 A 2.246	4 Zyl.
Speed sensor, ignition/injection	07.90-04.92		0 261 210 117	
Temperature sensor, coolant, injection system	01.86-06.90	MEB	0 280 130 026	
1100 i.e. [141..]		1,1l 37 kW	156 C 0.046	4 Zyl.
Speed sensor, ignition/injection				
Mot.no. 4599750→	01.93-03.97		0 261 210 117	
Temperature sensor, coolant, injection system	04.92-12.92	MEB	0 280 130 026	
1100 i.e. [141..]		1,1l 37 kW	187 A 1.000	4 Zyl.
Phase sensor	12.00-09.03		0 232 103 039	
1100 i.e. [141..]		1,1l 40 kW	176 B 2.000	4 Zyl.
Speed sensor, ignition/injection				
Mot.no. 4599750→	01.95-09.03		0 261 210 117	
1100 i.e. Selecta [141..]		1,1l 37 kW	156 C 0.046	4 Zyl.
Speed sensor, ignition/injection				
Mot.no. 4599750→	01.93-03.97		0 261 210 117	
Temperature sensor, coolant, injection system	01.86-12.92	MEB	0 280 130 026	
1100 i.e. Selecta [141..]		1,1l 40 kW	176 B 2.000	4 Zyl.
Speed sensor, ignition/injection				
Mot.no. 4599750→	01.95-09.03		0 261 210 117	
1100 i.e. 4x4 [153..]		1,1l 37 kW	156 C 0.046	4 Zyl.
Speed sensor, ignition/injection				
Mot.no. 4599750→	01.93-12.94		0 261 210 117	
Temperature sensor, coolant, injection system	03.92-12.92	MEB	0 280 130 026	
1100 i.e. 4x4 [153..]		1,1l 40 kW	176 B 2.000	4 Zyl.
Speed sensor, ignition/injection				
Mot.no. 4599750→	01.95-09.03		0 261 210 117	
Petra				
1.2 i.e. 16V [172..]		1,2l 59 kW	188 A 5.000	4 Zyl.
Throttle valve assembly	03.03→		F 01C 600 023	
Speed sensor, ignition/injection	03.03→		0 261 210 219	
Knock sensor	03.03→		0 261 231 173	
Pressure sensor, intake manifold, gasoline	03.03→		0 261 230 030	
Accelerator pedal module	03.03→		0 281 002 379	
Wheel speed sensor, front	03.03→	LAB	0 265 007 103	
		RAB	0 265 007 102	
Wheel speed sensor, rear	03.03→		0 265 007 126	

Petra				
1.2 i.e. 16V [172..]		1,2l	59 kW	188 A 5.000 4 Zyl.
Throttle valve assembly	03.03→		F 01C 600 023	
Speed sensor, ignition/injection	03.03→		0 261 210 219	
Knock sensor	03.03→		0 261 231 173	
Pressure sensor, intake manifold, gasoline	03.03→		0 261 230 030	
Accelerator pedal module	03.03→		0 281 002 379	
Wheel speed sensor, front	03.03→	LAB	0 265 007 103	
		RAB	0 265 007 102	
Wheel speed sensor, rear	03.03→		0 265 007 126	



Punto				
1.2 i 8V [188..] 1,2l 44 kW 188 A 4.000 4 Zyl.				
Phase sensor	07.99-06.03			0 232 103 039
Speed sensor, ignition/injection	07.99-06.03			0 261 210 114
Wheel speed sensor, front				
Ricam.no →284749,→4546420,→5171879	07.99-05.02	LAB		0 265 007 069
		RAB		0 265 007 070
Ricam.no 284750→,4546421→,5171880→	06.02-06.03	LAB		0 265 007 510
		RAB		0 265 007 511
Wheel speed sensor, rear				
Ricam.no →284749,→4546420,→5171879	07.99-05.02	LAB		0 265 007 072
		RAB		0 265 007 071
Ricam.no 284750→,4546421→,5171880→	06.02-06.03	LAB		0 265 007 512
		RAB		0 265 007 513
1.2 i 8V Bipower [188..] 1,2l 59 kW 188 A 4.000 4 Zyl.				
Speed sensor, ignition/injection	11.02-06.03			0 261 210 114
Wheel speed sensor, front	11.02-06.03	LAB		0 265 007 510
		RAB		0 265 007 511
Wheel speed sensor, rear	11.02-06.03	LAB		0 265 007 512
		RAB		0 265 007 513
1.2 i 16V [188..] 1,2l 59 kW 188 A 5.000 4 Zyl.				
Throttle valve assembly	07.99-06.03			F 01C 600 023
Phase sensor	10.00-11.01			0 232 103 035
	12.01-06.03			0 232 103 048
Speed sensor, ignition/injection	07.99-09.00			0 261 210 161
	10.00-06.03			0 261 210 219
Knock sensor	07.99-06.03			0 261 231 173
Pressure sensor, intake manifold, gasoline	07.99-06.03			0 261 230 030
Accelerator pedal module	07.99-06.03	RLE		0 281 002 369
Wheel speed sensor, front				
Ricam.no →284749,→4546420,→5171879	07.99-05.02	LAB		0 265 007 069
		RAB		0 265 007 070
Ricam.no 284750→,4546421→,5171880→	06.02-06.03	LAB		0 265 007 510
		RAB		0 265 007 511
Wheel speed sensor, rear				
Ricam.no →284749,→4546420,→5171879	07.99-05.02	LAB		0 265 007 072
		RAB		0 265 007 071
Ricam.no 284750→,4546421→,5171880→	06.02-06.03	LAB		0 265 007 512
		RAB		0 265 007 513
1.2 i.e. 8V [188..] 1,2l 44 kW 188 A 4.000 4 Zyl.				
Phase sensor	07.03→	NOC		0 232 103 048
Speed sensor, ignition/injection				
Mot.no. →2192182	07.03→			0 261 210 114
Pressure sensor, intake manifold, gasoline	07.03→			0 261 230 030
Wheel speed sensor, front	07.03→	LAB		0 265 007 610
		RAB		0 265 007 518
Wheel speed sensor, rear	07.03→	RAB		0 265 007 519
1.2 i.e. 8V Bipower [188..] 1,2l 44 kW 188 A 4.000 4 Zyl.				
Phase sensor	07.03→	NOC		0 232 103 048
Speed sensor, ignition/injection				
Mot.no. →2192182	07.03→			0 261 210 114
Wheel speed sensor, front	07.03→	LAB		0 265 007 610
		RAB		0 265 007 518
Wheel speed sensor, rear	07.03→	RAB		0 265 007 519
1.2 i.e. 16V [188..] 1,2l 59 kW 188 A 5.000 4 Zyl.				
Throttle valve assembly	07.03→			F 01C 600 023
Phase sensor	07.03→			0 232 103 048
Speed sensor, ignition/injection	07.03→			0 261 210 238
Knock sensor	07.03→			0 261 231 173
Pressure sensor, intake manifold, gasoline	07.03→			0 261 230 030
Temperature sensor, coolant, injection system	07.03→			F 01C 050 016
Accelerator pedal module	07.03→	RLE		0 281 002 369



Wheel speed sensor, front	07.03→	LAB		0 265 007 610
		RAB		0 265 007 518
Wheel speed sensor, rear	07.03→	RAB		0 265 007 519
1.3 MJTD 16V [188..] 1,3l 52 kW 188 A 9.000 4 Zyl.				
Air mass meter, diesel	07.03→			0 281 002 613
High-pressure sensor (CR system)	07.03-10.04			0 281 002 534
Boost pressure sensor, Diesel				
Mot.no. →1376014	07.03→			0 281 002 510
Mot.no. 1376015→	07.03→			0 281 002 844
Accelerator pedal module	07.03→	RLE		0 281 002 369
Acceleration sensor, ABS	07.03→			0 265 005 127
Yaw rate sensor, brake system	07.03→			0 265 005 241
Wheel speed sensor, front	07.03→	LAB		0 265 007 610
		RAB		0 265 007 518
Wheel speed sensor, rear	07.03→	LAB,OFD		0 265 007 831
		RAB		0 265 007 519
Ricam.no 0568434→,4972621→	07.03→	LAB,MFD		0 265 007 831
1.4 i.e. 16V [188..] 1,4l 70 kW 834 A 1.000 4 Zyl.				
Throttle valve assembly	07.03→			F 01C 600 027
Speed sensor, ignition/injection	07.03→			0 261 210 238
Knock sensor	07.03→			0 261 231 173
Pressure sensor, intake manifold, gasoline	07.03→			0 261 230 030
Accelerator pedal module	07.03→	RLE		0 281 002 369
Acceleration sensor, ABS	07.03→			0 265 005 127
Yaw rate sensor, brake system	07.03→			0 265 005 241
Wheel speed sensor, front	07.03→	LAB		0 265 007 610
		RAB		0 265 007 518
Wheel speed sensor, rear	07.03→	LAB,OFD		0 265 007 831
		RAB		0 265 007 519
Ricam.no 0568434→,4972621→	07.03→	LAB,MFD		0 265 007 831
1.7 D [176..] 1,7l 42 kW 176 B 3.000 4 Zyl.				
Wheel speed sensor, front	08.93-04.97	ZE		0 265 001 387
Wheel speed sensor, rear	08.93-04.97	LAB		0 265 006 139
		RAB		0 265 006 140
1.7 TD [176..] 1,7l 46/51-53 kW 176 A 3.000; 176 A 5.000; 176 B 7.000 4 Zyl.				
Wheel speed sensor, front	08.93-08.99	ZE		0 265 001 387
Wheel speed sensor, rear	08.93-08.99	LAB		0 265 006 139
		RAB		0 265 006 140
1.8 i 16V [188..] 1,7l 96 kW 183 A 1.000 4 Zyl.				
Phase sensor	07.99-06.03			0 232 101 037
Wheel speed sensor, front	07.99-06.03	LAB		0 265 007 069
		RAB		0 265 007 070
Wheel speed sensor, rear				
Ricam.no →0134146	07.99-06.00	LAB		0 265 007 072
		RAB		0 265 007 071
Ricam.no 0134147→	07.00-06.03	LAB		0 265 007 100
		RAB		0 265 007 101
1.8 i 16V [188..] 1,7l 96 kW 188 A 6.000 4 Zyl.				
Phase sensor	09.00-06.03			0 232 101 037
Wheel speed sensor, front	09.00-06.03	LAB		0 265 007 069
		RAB		0 265 007 070
Wheel speed sensor, rear				
Ricam.no 0134147→	09.00-06.03	LAB		0 265 007 100
		RAB		0 265 007 101
1.8 i.e. 16V [188..] 1,7l 96 kW 188 A 6.000 4 Zyl.				
Phase sensor	07.03→			0 232 101 037
Acceleration sensor, ABS	07.03→			0 265 005 127
Yaw rate sensor, brake system	07.03→			0 265 005 241
Wheel speed sensor, front	07.03→	LAB		0 265 007 610
		RAB		0 265 007 518
Wheel speed sensor, rear	07.03→	RAB		0 265 007 520
Ricam.no →0568433,→4972620	07.03-11.04	LAB		0 265 007 521



Product				
◀ Punto				
1.9 D [188..]	1,9l	44 kW	188 A	3.000 4 Zyl.
Speed sensor, diesel				
Mot.no. →2151823	07.99-06.03		0 281 002 214	
Mot.no. 2151824→	07.99-06.03		0 281 002 474	
Accelerator pedal module	07.99-06.03	RLE	0 281 002 369	
Wheel speed sensor, front				
Ricam.no →284749,→4546420,→5171879	07.99-05.02	LAB	0 265 007 069	
		RAB	0 265 007 070	
Ricam.no 284750→,4546421→,5171880→	06.02-06.03	LAB	0 265 007 510	
		RAB	0 265 007 511	
Wheel speed sensor, rear				
Ricam.no →284749,→4546420,→5171879	07.99-05.02	LAB	0 265 007 072	
		RAB	0 265 007 071	
Ricam.no 284750→,4546421→,5171880→	06.02-06.03	LAB	0 265 007 512	
		RAB	0 265 007 513	
1.9 JTD [188..]	1,9l	59 kW	188 A	2.000 4 Zyl.
Air mass meter, diesel	07.99-06.03		0 281 002 309	
Speed sensor, diesel				
Mot.no. →2151823	07.99-06.03		0 281 002 214	
Mot.no. 2151824→	07.99-06.03		0 281 002 474	
Phase sensor	07.99-06.03		0 281 002 213	
High-pressure sensor (CR system)	07.99-06.03		0 281 002 260	
		EFV	0 281 002 405	
Boost pressure sensor, Diesel	07.99-06.03		0 281 002 215	
		EFV	0 281 002 510	
Accelerator pedal module	07.99-06.03	RLE	0 281 002 369	
Wheel speed sensor, front				
Ricam.no →284749,→4546420,→5171879	07.99-05.02	LAB	0 265 007 069	
		RAB	0 265 007 070	
Ricam.no 284750→,4546421→,5171880→	06.02-06.03	LAB	0 265 007 510	
		RAB	0 265 007 511	
Wheel speed sensor, rear				
Ricam.no →284749,→4546420,→5171879	07.99-05.02	LAB	0 265 007 072	
		RAB	0 265 007 071	
Ricam.no 284750→,4546421→,5171880→	06.02-06.03	LAB	0 265 007 512	
		RAB	0 265 007 513	
1.9 JTD [188..]	1,9l	62,5 kW	188 A	7.000 4 Zyl.
Air mass meter, diesel	06.01-06.03		0 281 002 309	
Speed sensor, diesel	06.01-06.03		0 281 002 214	
		EFV	0 281 002 474	
Phase sensor	06.01-06.03		0 281 002 213	
High-pressure sensor (CR system)	06.01-06.03		0 281 002 260	
		EFV	0 281 002 405	
Boost pressure sensor, Diesel	06.01-06.03		0 281 002 215	
		EFV	0 281 002 510	
Accelerator pedal module	06.01-06.03	RLE	0 281 002 369	
Wheel speed sensor, front				
Ricam.no →284749,→4546420,→5171879	06.01-05.02	LAB	0 265 007 069	
		RAB	0 265 007 070	
Ricam.no 284750→,4546421→,5171880→	06.02-06.03	LAB	0 265 007 510	
		RAB	0 265 007 511	
Wheel speed sensor, rear				
Ricam.no →284749,→4546420,→5171879	06.01-05.02	LAB	0 265 007 072	
		RAB	0 265 007 071	
Ricam.no 284750→,4546421→,5171880→	06.02-06.03	LAB	0 265 007 512	
		RAB	0 265 007 513	
1.9 JTD 8V [188..]	1,9l	63 kW	188 A	7.000 4 Zyl.
Air mass meter, diesel	07.03→		0 280 218 113	
Speed sensor, diesel				
Mot.no. →3619164	07.03→		0 281 002 474	
Mot.no. 3619165→	07.03→		0 281 002 603	
Phase sensor	07.03→		0 281 002 213	
High-pressure sensor (CR system)	07.03-02.04		0 281 002 405	



Product				
Boost pressure sensor, Diesel	07.03→		0 281 002 510	
Accelerator pedal module	07.03→	RLE	0 281 002 369	
Acceleration sensor, ABS	07.03→		0 265 005 127	
Yaw rate sensor, brake system	07.03→		0 265 005 241	
Wheel speed sensor, front	07.03→	LAB	0 265 007 610	
		RAB	0 265 007 518	
Wheel speed sensor, rear	07.03→	LAB,OFD	0 265 007 831	
		RAB	0 265 007 519	
Ricam.no 0568434→,4972621→	07.03→	LAB,MFD	0 265 007 831	
1.9 JTD 8V [188..]	1,9l	74 kW	188 B	2.000 4 Zyl.
Air mass meter, diesel	07.03→		0 280 218 113	
Speed sensor, diesel	07.03→	KW	0 281 002 603	
Phase sensor	07.03→		0 281 002 213	
High-pressure sensor (CR system)	07.03→		0 281 002 534	
Boost pressure sensor, Diesel	07.03→		0 281 002 437	
Accelerator pedal module	07.03→	NSP,RLE	0 281 002 369	
Acceleration sensor, ABS	07.03→		0 265 005 127	
Yaw rate sensor, brake system	07.03→		0 265 005 241	
Wheel speed sensor, front	07.03→	LAB	0 265 007 610	
		RAB	0 265 007 518	
Wheel speed sensor, rear	07.03→	RAB,SBR	0 265 007 520	
		RAB,TBR	0 265 007 519	
Ricam.no →0568433,→4972620	07.03→	LAB,SBR	0 265 007 521	
Ricam.no 0568434→,4972621→	07.03→	LAB,TBR	0 265 007 831	
55 1.1 i.e. [176..]	1,1l	40 kW	176 A	6.000; 176 B 2.000 4 Zyl.
Speed sensor, ignition/injection	08.93-08.99		0 261 210 114	
Wheel speed sensor, front	08.93-08.99	ZE	0 265 001 387	
Wheel speed sensor, rear	08.93-08.99	LAB	0 265 006 139	
		RAB	0 265 006 140	
60 1.2 i.e. [176..]	1,2l	43 kW	176 A	7.000 4 Zyl.
Speed sensor, ignition/injection	08.93-05.94		0 261 210 114	
Wheel speed sensor, front	08.93-05.94	ZE	0 265 001 387	
Wheel speed sensor, rear	08.93-05.94	LAB	0 265 006 139	
		RAB	0 265 006 140	
60 1.2 i.e. [176..]	1,2l	43 kW	176 B	4.000 4 Zyl.
Speed sensor, ignition/injection	06.95-08.99		0 261 210 114	
Wheel speed sensor, front	06.95-08.99	ZE	0 265 001 387	
Wheel speed sensor, rear	06.95-08.99	LAB	0 265 006 139	
		RAB	0 265 006 140	
60 1.2 i.e. Selecta [176..]	1,2l	43 kW	176 B	1.000 4 Zyl.
Speed sensor, ignition/injection	06.94-04.97		0 261 210 114	
75 1.2 i.e. [176..]	1,2l	54 kW	176 A	8.000 4 Zyl.
Speed sensor, ignition/injection	08.93-08.99		0 261 210 114	
Wheel speed sensor, front	08.93-08.99	ZE	0 265 001 387	
Wheel speed sensor, rear	08.93-08.99	LAB	0 265 006 139	
		RAB	0 265 006 140	
85 1.2 i.e. 16V [176..]	1,2l	63 kW	176 B	9.000 4 Zyl.
Speed sensor, ignition/injection	05.97-08.99		0 261 210 124	
Wheel speed sensor, front	05.97-08.99	ZE	0 265 001 387	
Wheel speed sensor, rear	05.97-08.99	LAB	0 265 006 139	
		RAB	0 265 006 140	
90 1.6 i.e. [176..]	1,6l	65 kW	176 A	9.000 4 Zyl.
Wheel speed sensor, front	01.94-04.97	ZE	0 265 001 387	
Wheel speed sensor, rear	01.94-04.97	LAB	0 265 006 139	
		RAB	0 265 006 140	
Punto Cabrio				
60 1.2 i.e. [176..]	1,2l	43/44 kW	176 A	7.000; 176 B 4.000 4 Zyl.
Speed sensor, ignition/injection	04.94-08.99		0 261 210 114	
Wheel speed sensor, front	04.94-08.99	ZE	0 265 001 387	
Wheel speed sensor, rear	04.94-08.99	LAB	0 265 006 139	
		RAB	0 265 006 140	




F



85 1.2 i.e. 16V [176..]		1,2l 63 kW 176 B 9.000 4 Zyl.
Speed sensor, ignition/injection	05.97-08.99	0 261 210 124
Wheel speed sensor, front	05.97-08.99 ZE	0 265 001 387
Wheel speed sensor, rear	05.97-08.99 LAB	0 265 006 139
	RAB	0 265 006 140
90 1.6 i.e. [176..]		1,6l 65 kW 176 A 9.000 4 Zyl.
Wheel speed sensor, front	04.94-04.97 ZE	0 265 001 387
Wheel speed sensor, rear	04.94-04.97 LAB	0 265 006 139
	RAB	0 265 006 140

Punto Grande

1.2 i.e. [199..]		1,2l 48 kW 199 A 4.000 4 Zyl.
Phase sensor	10.05→	0 232 103 048
Pressure sensor, intake manifold, gasoline	10.05→	0 261 230 030
Yaw rate sensor, brake system	10.05→	0 265 005 607
Wheel speed sensor, front	10.05→	0 265 007 671
Wheel speed sensor, rear	10.05→	0 265 007 768
1.3 MJTD [199..]		1,3l 55 kW 199 A 2.000 4 Zyl.
Air mass meter, diesel	10.05→	0 281 002 792
Boost pressure sensor, Diesel	10.05-05.06	0 281 002 510
	06.06→	0 281 002 844
Yaw rate sensor, brake system	10.05→	0 265 005 607
Wheel speed sensor, front	10.05→	0 265 007 671
Wheel speed sensor, rear	10.05→	0 265 007 768
1.3 MJTD [199..]		1,3l 66 kW 199 A 3.000 4 Zyl.
Air mass meter, diesel	10.05→	0 281 002 792
Boost pressure sensor, Diesel	10.05-11.06	0 281 002 437
	12.06→	0 281 002 845
Yaw rate sensor, brake system	10.05→	0 265 005 607
Wheel speed sensor, front	10.05→	0 265 007 671
Wheel speed sensor, rear	10.05→	0 265 007 768
1.4 i.e. Turbo 16V [199..]		1,4l 88 kW 198 A 4.000 4 Zyl.
Phase sensor	06.07→	0 232 103 048
Speed sensor, ignition/injection	06.07→	0 261 210 238
Knock sensor	06.07→	0 261 231 173
Boost pressure sensor, gasoline	06.07→	0 281 002 844
Yaw rate sensor, brake system	06.07→	0 265 005 607
Wheel speed sensor, front	06.07→	0 265 007 671
Wheel speed sensor, rear	06.07→	0 265 007 769
1.4 i.e. 8V [199..]		1,4l 57 kW 350 A 1.000 4 Zyl.
Phase sensor	10.05→	0 232 103 048
Pressure sensor, intake manifold, gasoline	10.05→	0 261 230 030
Yaw rate sensor, brake system	10.05→	0 265 005 607
Wheel speed sensor, front	10.05→	0 265 007 671
Wheel speed sensor, rear	10.05→	0 265 007 768
1.4 i.e. 16V [199..]		1,4l 70 kW 199 A 6.000 4 Zyl.
Throttle valve assembly	03.06→	F 01C 600 066
Speed sensor, ignition/injection	03.06→	0 261 210 238
Knock sensor	03.06→	0 261 231 173
Pressure sensor, intake manifold, gasoline	03.06→	F 01C 600 070
Temperature sensor, intake air, injection system	03.06→	F 01C 600 071
Yaw rate sensor, brake system	03.06→	0 265 005 607
Wheel speed sensor, front	03.06→	0 265 007 671
Wheel speed sensor, rear	03.06→ NSP	0 265 007 768
	VSP	0 265 007 769
1.9 JTD [199..]		1,9l 88/96 kW 199 A 5.000; 939 A 1.000 4 Zyl.
Speed sensor, diesel	10.05→	KW 0 281 002 603
Phase sensor	10.05→	NOC 0 281 002 213
Boost pressure sensor, Diesel	10.05-03.07	0 281 002 437
	04.07→	0 281 002 845
Yaw rate sensor, brake system	10.05→	0 265 005 607



Wheel speed sensor, front	10.05→	0 265 007 671
Wheel speed sensor, rear	10.05→	0 265 007 769

Punto GT

1.4 i.e. Turbo [176..]		1,4l 96/98 kW 176 A 4.000; 176 B 6.000 4 Zyl.
Throttle valve sensor	08.93-08.99	0 280 122 001
Air mass meter, gasoline injection	08.93-08.99	0 280 212 024
		0 986 280 123
Phase sensor	08.93-08.99	0 232 102 004
Speed sensor, ignition/injection	08.93-08.99	0 261 210 104
Knock sensor	08.93-08.99	0 261 231 007
Pressure sensor, intake manifold, gasoline	08.93-08.99	0 280 101 001
Temperature sensor, intake air, injection system	08.93-08.99	0 280 130 060
Temperature sensor, coolant, injection system	08.93-08.99	0 280 130 026
Relay, Jetronic	04.94-04.97	0 332 014 140
Wheel speed sensor, front	08.93-08.99 ZE	0 265 001 387
Wheel speed sensor, rear	08.93-08.99 LAB	0 265 006 139
	RAB	0 265 006 140

Punto VAN

1.1 i.e. [276..]		1,1l 40 kW 176 B 2.000 4 Zyl.
Speed sensor, ignition/injection	05.97-08.99	0 261 210 114
Wheel speed sensor, front	05.97-08.99 ZE	0 265 001 387
Wheel speed sensor, rear	05.97-08.99 LAB	0 265 006 139
	RAB	0 265 006 140
1.2 i 8V [288..]		1,2l 44 kW 188 A 4.000 4 Zyl.
Phase sensor	07.03→	NOC 0 232 103 048
Speed sensor, ignition/injection	07.99-06.03	0 261 210 114
Mot.no. →2192182	07.03→	0 261 210 114
Pressure sensor, intake manifold, gasoline	07.03→	0 261 230 030
Wheel speed sensor, front	07.03→	LAB 0 265 007 610
		RAB 0 265 007 518
Ricam.no →284749,→4546420,→5171879	07.99-05.02	LAB 0 265 007 069
		RAB 0 265 007 070
Ricam.no 284750→,4546421→,5171880→	06.02-06.03	LAB 0 265 007 510
		RAB 0 265 007 511
Wheel speed sensor, rear	07.03→	RAB 0 265 007 519
Ricam.no →284749,→4546420,→5171879	07.99-05.02	LAB 0 265 007 072
		RAB 0 265 007 071
Ricam.no 284750→,4546421→,5171880→	06.02-06.03	LAB 0 265 007 512
		RAB 0 265 007 513
1.2 i 8V Bipower [288..]		1,2l 44 kW 188 A 4.000 4 Zyl.
Phase sensor	07.03→	NOC 0 232 103 048
Speed sensor, ignition/injection		
Mot.no. →2192182	07.03→	0 261 210 114
Wheel speed sensor, front	07.03→	LAB 0 265 007 610
		RAB 0 265 007 518
Wheel speed sensor, rear	07.03→	RAB 0 265 007 519
1.3 MJTD 16V [288..]		1,3l 52 kW 188 A 9.000 4 Zyl.
Air mass meter, diesel	07.03→	0 281 002 613
High-pressure sensor (CR system)	07.03-10.04	0 281 002 534
Boost pressure sensor, Diesel		
Mot.no. →1376014	07.03→	0 281 002 510
Mot.no. 1376015→	07.03→	0 281 002 844
Accelerator pedal module	07.03→	RLE 0 281 002 369
Acceleration sensor, ABS	07.03→	0 265 005 127
Yaw rate sensor, brake system	07.03→	0 265 005 241
Wheel speed sensor, front	07.03→	LAB 0 265 007 610
		RAB 0 265 007 518

Product				
◀ Punto VAN				
Wheel speed sensor, rear	07.03→	LAB,OFD	0 265 007 831	
		RAB	0 265 007 519	
Ricam.no 0568434→,4972621→	07.03→	LAB,MFD	0 265 007 831	
1.7 D [276..]		1,7l	42 kW	176 B 3.000 4 Zyl.
Wheel speed sensor, front	05.97-08.99	ZE	0 265 001 387	
Wheel speed sensor, rear	05.97-08.99	LAB	0 265 006 139	
		RAB	0 265 006 140	
1.7 TD [276..]		1,7l	51/53 kW	176 A 3.000; 176 A 5.000 4 Zyl.
Wheel speed sensor, front	05.97-08.99	ZE	0 265 001 387	
Wheel speed sensor, rear	05.97-08.99	LAB	0 265 006 139	
		RAB	0 265 006 140	
1.7 TD SOFT [276..]		1,7l	46 kW	176 B 7.000 4 Zyl.
Wheel speed sensor, front	05.97-08.99	ZE	0 265 001 387	
Wheel speed sensor, rear	05.97-08.99	LAB	0 265 006 139	
		RAB	0 265 006 140	
1.9 D [288..]		1,9l	44 kW	188 A 3.000 4 Zyl.
Speed sensor, diesel				
Mot.no. →2151823	05.99-06.03		0 281 002 214	
Mot.no. 2151824→	05.99-06.03		0 281 002 474	
Accelerator pedal module	05.99-06.03	RLE	0 281 002 369	
Wheel speed sensor, front				
Ricam.no →284749,→4546420,→5171879	05.99-05.02	LAB	0 265 007 069	
		RAB	0 265 007 070	
Ricam.no 284750→,4546421→,5171880→	06.02-06.03	LAB	0 265 007 510	
		RAB	0 265 007 511	
Wheel speed sensor, rear				
Ricam.no →284749,→4546420,→5171879	05.99-05.02	LAB	0 265 007 072	
		RAB	0 265 007 071	
Ricam.no 284750→,4546421→,5171880→	06.02-06.03	LAB	0 265 007 512	
		RAB	0 265 007 513	
1.9 JTD [288..]		1,9l	85 kW	188 A 7.000 4 Zyl.
Air mass meter, diesel	05.99-06.03		0 281 002 309	
Speed sensor, diesel	05.99-06.03	EFV	0 281 002 474	
Phase sensor	05.99-06.03		0 281 002 213	
High-pressure sensor (CR system)	05.99-06.03		0 281 002 260	
		EFV	0 281 002 405	
Boost pressure sensor, Diesel	05.99-06.03		0 281 002 215	
		EFV	0 281 002 510	
Accelerator pedal module	05.99-06.03	RLE	0 281 002 369	
Wheel speed sensor, front				
Ricam.no →284749,→4546420,→5171879	05.99-05.02	LAB	0 265 007 069	
		RAB	0 265 007 070	
Ricam.no 284750→,4546421→,5171880→	06.02-06.03	LAB	0 265 007 510	
		RAB	0 265 007 511	
Wheel speed sensor, rear				
Ricam.no →284749,→4546420,→5171879	05.99-05.02	LAB	0 265 007 072	
		RAB	0 265 007 071	
Ricam.no 284750→,4546421→,5171880→	06.02-06.03	LAB	0 265 007 512	
		RAB	0 265 007 513	
1.9 JTD 8V [288..]		1,9l	63 kW	188 A 7.000 4 Zyl.
Air mass meter, diesel	07.03→		0 280 218 113	
Speed sensor, diesel				
Mot.no. →3619164	07.03→		0 281 002 474	
Mot.no. 3619165→	07.03→		0 281 002 603	
Phase sensor	07.03→		0 281 002 213	
High-pressure sensor (CR system)	07.03-02.04		0 281 002 405	
Boost pressure sensor, Diesel	07.03→		0 281 002 510	
Accelerator pedal module	07.03→	RLE	0 281 002 369	
Acceleration sensor, ABS	07.03→		0 265 005 127	
Yaw rate sensor, brake system	07.03→		0 265 005 241	
Wheel speed sensor, front	07.03→	LAB	0 265 007 610	
		RAB	0 265 007 518	



Product				
Wheel speed sensor, rear	07.03→		LAB,OFD	0 265 007 831
			RAB	0 265 007 519
Ricam.no 0568434→,4972621→	07.03→		LAB,MFD	0 265 007 831
Regata				
75 i.e. [138..]		1,5l	55 kW	138 C 2.. 4 Zyl.
Throttle valve sensor	10.85-04.87			0 280 120 300
Air flow sensor, gasoline injection	10.85-04.87			0 280 200 024
				0 986 280 075
Pressure sensor, intake manifold, gasoline	10.85-04.87			0 280 101 001
Temperature sensor, coolant, injection system	10.85-04.87			0 280 130 023
Relay, Jetronic	10.85-04.87	WEI		0 332 514 127
75 i.e. [138..]		1,5l	55 kW	149 C 1.000 4 Zyl.
Temperature sensor, coolant, injection system	05.87-06.90			0 280 130 026
Ritmo				
75 i.e. [138A..]		1,5l	55 kW	138 C 2.. 4 Zyl.
Throttle valve sensor	10.85-10.87			0 280 120 300
Air flow sensor, gasoline injection	10.85-10.87			0 280 200 024
				0 986 280 075
Pressure sensor, intake manifold, gasoline	10.85-10.87			0 280 101 001
Temperature sensor, coolant, injection system	10.85-10.87			0 280 130 023
Relay, Jetronic	10.85-10.87	WEI		0 332 514 127
75 i.e. [138A..]		1,5l	55 kW	149 C 1.. 4 Zyl.
Temperature sensor, coolant, injection system	05.87-12.88			0 280 130 026
90 i.e. [138A..]		1,6l	66 kW	149 C 2.000 4 Zyl.
Temperature sensor, coolant, injection system	05.87-12.87			0 280 130 026
Scudo				
1.6i [222..]		1,6l	58 kW	220 A 2.000 4 Zyl.
Pulse generator, ignition/Jetronic	10.95-05.00			0 261 210 127
Temperature sensor, coolant, injection system	10.95-05.00			0 280 130 084
Wheel speed sensor, front				
Ricam.no 7480→9050	06.97-05.00			0 265 006 388
Wheel speed sensor, rear				
Ricam.no 7480→7608	05.97-09.97			0 265 006 426
Ricam.no 7609→9050	09.97-05.00			0 265 006 504
1.9 D [222..]		1,9l	51 kW	D9B 4 Zyl.
Wheel speed sensor, front				
Ricam.no 7480→9050	06.97-05.00			0 265 006 388
Wheel speed sensor, rear				
Ricam.no 7480→7608	05.97-09.97			0 265 006 426
Ricam.no 7609→9050	09.97-05.00			0 265 006 504
1.9 D [222..]		1,9l	51 kW	WJZ 4 Zyl.
Wheel speed sensor, front				
Ricam.no 7480→9050	06.98-08.01			0 265 006 388
Wheel speed sensor, rear				
Ricam.no 7609→9050	06.98-08.01			0 265 006 504
1.9 TD [222..]		1,9l	66/68 kW	DHX; D8B 4 Zyl.
Wheel speed sensor, front				
Ricam.no 7480→9050	06.97-05.00			0 265 006 388
Wheel speed sensor, rear				
Ricam.no 7480→7608	05.97-09.97			0 265 006 426
Ricam.no 7609→9050	09.97-05.00			0 265 006 504
2.0 8V JTD [222..]		2,0l	70/81 kW	RHX; RHZ 4 Zyl.
High-pressure sensor (CR system)	10.99-01.07			0 281 002 283
Wheel speed sensor, front				
Ricam.no 7480→9050	10.99-08.01			0 265 006 388
Wheel speed sensor, rear				
Ricam.no 7609→9050	10.99-08.01			0 265 006 504



2.0 16V [222..]			2,0l 100 kW RFN 4 Zyl.
Pressure sensor, intake manifold, gasoline	05.00-01.07		0 261 230 057
Wheel speed sensor, front			
Ricam.no 7480→9050	05.00-08.01		0 265 006 388
Wheel speed sensor, rear			
Ricam.no 7609→9050	05.00-08.01		0 265 006 504
2.0 16V JTD [222..]			2,0l 81 kW RHM 4 Zyl.
High-pressure sensor (CR system)	06.04-01.07		0 281 002 283
2.0 16V JTD [222..]			2,0l 81 kW RHW 4 Zyl.
High-pressure sensor (CR system)	09.00-05.04		0 281 002 283
Wheel speed sensor, front			
Ricam.no 7480→9050	09.00-08.01		0 265 006 388
Wheel speed sensor, rear			
Ricam.no 7609→9050	09.00-08.01		0 265 006 504

Sedici			
1.9 JTD 4x4 [189..]			1,9l 88 kW D19AA 4 Zyl.
Speed sensor, diesel	05.06→	KW	0 281 002 603
Phase sensor	05.06→		0 281 002 213
Boost pressure sensor, Diesel	05.06-03.07		0 281 002 437
	04.07→		0 281 002 845

Seicento			
Elettra [187..]0 Zyl.			
Pedal position sensor, EMS (electronic engine management)	10.98-12.03		0 281 002 202
900 [187..]			0,9l 29 kW 1170 A 1.046 4 Zyl.
Wheel speed sensor, front	03.98-12.03	LAB	0 265 007 043
		RAB	0 265 007 044
Wheel speed sensor, rear	03.98-12.03		0 265 007 045
1100 [187..]			1,1l 40 kW 176 B 2.000 4 Zyl.
Wheel speed sensor, front	03.98-12.03	LAB	0 265 007 043
		RAB	0 265 007 044
Wheel speed sensor, rear	03.98-12.03		0 265 007 045
1100 [187..]			1,1l 40 kW 187 A 1.000 4 Zyl.
Phase sensor			
Fg.no. →1219710	09.00→	NOC	0 232 103 039
Fg.no. 1219711→	09.00→	NOC	0 232 103 048
Wheel speed sensor, front	09.00→	LAB	0 265 007 043
		RAB	0 265 007 044
Wheel speed sensor, rear	09.00→		0 265 007 045

Siena			
1.0 MPI 16V			1,0l 51 kW 178 D 8.011 4 Zyl.
Throttle valve assembly	03.00-08.01		F 01C 600 023
	10.02-02.03		F 01C 600 023
Speed sensor, ignition/injection	03.00-02.03		0 261 210 161
Knock sensor	03.00-02.03		0 261 231 173
Pressure sensor, intake manifold, gasoline	03.00-02.03		0 261 230 030
Wheel speed sensor, front	03.00-02.03	LAB	0 265 007 103
		RAB	0 265 007 102
Wheel speed sensor, rear	03.00-02.03		0 265 007 051
1.2 i.e. 8V [172..]			1,2l 44 kW 178 C 4.066 4 Zyl.
Speed sensor, ignition/injection			
Mot.no. →2935743	01.02-03.04	OLH	0 261 210 114
Wheel speed sensor, front	01.02-03.04	LAB	0 265 007 103
		RAB	0 265 007 102
Wheel speed sensor, rear	01.02-03.04		0 265 007 051



1.2 i.e. 8V [178..]			1,2l 44/54 kW 178 B 5.000; 178 B 7.045 4 Zyl.
Speed sensor, ignition/injection	01.98-12.01		0 261 210 114
Wheel speed sensor, front	03.99-12.01	LAB	0 265 006 163
		RAB	0 265 006 164
Wheel speed sensor, rear	03.99-12.01		0 265 006 249
1.3 MPI 16V			1,3l 59 kW 178 D 6.011 4 Zyl.
Throttle valve assembly	03.00-02.03		F 01C 600 023
Speed sensor, ignition/injection	03.00-02.03		0 261 210 161
Knock sensor	03.00-02.03		0 261 231 173
Pressure sensor, intake manifold, gasoline	03.00-02.03		0 261 230 030
Accelerator pedal module	03.00-02.03		0 281 002 379
Wheel speed sensor, front	03.00-09.00	LAB	0 265 006 163
	10.00-02.03	LAB	0 265 007 103
	03.00-09.00	RAB	0 265 006 164
	10.00-02.03	RAB	0 265 007 102
Wheel speed sensor, rear	03.00-09.00		0 265 006 249
	10.00-02.03		0 265 007 051
1.4 i.e. [178..]			1,4l 51 kW 178 B 2.000; 178 B 2.016 4 Zyl.
Speed sensor, ignition/injection	04.97-06.01		0 261 210 104
Wheel speed sensor, front	04.97-06.01	LAB	0 265 006 163
	07.97-06.01	RAB	0 265 006 164
Wheel speed sensor, rear	04.97-06.01		0 265 006 249
1.4 i.e. 8V [178..]			1,4l 51 kW 178 B 2.000 4 Zyl.
Speed sensor, ignition/injection	02.00-06.02		0 261 210 104
Wheel speed sensor, front	03.01-06.02	LAB	0 265 006 163
		RAB	0 265 006 164
Wheel speed sensor, rear	03.01-06.02		0 265 006 249
1.6 i.e. 16V [178..]			1,6l 76 kW 178 B 3.000; 182 B 6.000 4 Zyl.
Wheel speed sensor, front	04.97-12.01	LAB	0 265 006 163
	07.97-12.01	RAB	0 265 006 164
Wheel speed sensor, rear	04.97-12.01		0 265 006 249

Stilo			
1.2 16V [192..]			1,2l 59 kW 188 A 5.000 4 Zyl.
Throttle valve assembly	10.01-12.03		F 01C 600 023
Phase sensor			
Fg.no. →819153	10.01-12.03		0 232 103 035
Fg.no. 819154→	10.01-12.03		0 232 103 048
Speed sensor, ignition/injection	10.01-12.03		0 261 210 219
Knock sensor	10.01-12.03		0 261 231 173
Pressure sensor, intake manifold, gasoline	10.01-12.03		0 261 230 030
Accelerator pedal module	10.01-12.03	LLE,XBN	0 280 752 227
Wheel speed sensor, front	10.01-12.03		0 265 007 401
Wheel speed sensor, rear			
Fg.no. 312323→	10.01-12.03		0 265 007 636
Ricam.no →312322	10.01-12.03		0 265 007 400
1.4 16V [192..]			1,4l 66/70 kW 192 B 2.000; 843 A 1.000 4 Zyl.
Throttle valve assembly	01.04→		F 01C 600 027
Phase sensor	01.04→	NOC	0 232 103 048
Speed sensor, ignition/injection	01.04→		0 261 210 238
Knock sensor	01.04→		0 261 231 173
Pressure sensor, intake manifold, gasoline	01.04→		0 261 230 030
Wheel speed sensor, front	01.04→		0 265 007 401
Wheel speed sensor, rear	01.04→		0 265 007 636
1.6 16V [192..]			1,6l 76 kW 182 B 6.000 4 Zyl.
Accelerator pedal module	10.01-12.03	LLE,XBN	0 280 752 227
Yaw rate sensor, brake system	10.01→		0 265 005 241
Pressure sensor, ESP, (electronic stability program)	10.01→		0 265 005 303
Wheel speed sensor, front	10.01→		0 265 007 401
Wheel speed sensor, rear	01.04→		0 265 007 636
Fg.no. 312323→	10.01-12.03		0 265 007 636
Ricam.no →312322	10.01-12.03		0 265 007 400



Product				
◀ Stilo				
1.6 16V [192..]	1,6l 100 kW 192 B 3.000 4 Zyl.			
Accelerator pedal module	07.05→	LLE,XBN	0 280 752 227	
Yaw rate sensor, brake system	07.05→		0 265 005 241	
Pressure sensor, ESP, (electronic stability program)	07.05→		0 265 005 303	
Wheel speed sensor, front	07.05→		0 265 007 401	
Wheel speed sensor, rear	07.05→		0 265 007 636	
1.8 MPI 8V	1,8l 76 kW 7D 4 Zyl.			
Wheel speed sensor, front	06.02-09.05		0 265 007 401	
Wheel speed sensor, rear	06.02-09.05		0 265 007 400	
1.8 MPI 16V	1,8l 97 kW 4 Zyl.			
Phase sensor	01.04→		0 232 101 037	
Wheel speed sensor, front	01.04→		0 265 007 401	
Wheel speed sensor, rear	01.04→		0 265 007 400	
1.8 16V [192..]	1,8l 98 kW 192 A 4.000 4 Zyl.			
Phase sensor	10.01→		0 232 101 037	
Yaw rate sensor, brake system	10.01→		0 265 005 241	
Pressure sensor, ESP, (electronic stability program)	10.01→		0 265 005 303	
Wheel speed sensor, front	10.01→		0 265 007 401	
Wheel speed sensor, rear	01.04→		0 265 007 636	
Fg.no. 312323→	10.01-12.03		0 265 007 636	
Ricam.no →312322	10.01-12.03		0 265 007 400	
1.9 JTD	1,9l 85 kW 4 Zyl.			
Air mass meter, diesel	06.02→		0 281 002 308	
Pulse generator, diesel	06.02→		0 281 002 213	
Speed sensor, diesel	06.02→		0 281 002 474	
Accelerator pedal module	06.02→		0 280 752 227	
Wheel speed sensor, front	06.02→		0 265 007 401	
Wheel speed sensor, rear	06.02→		0 265 007 400	
1.9 JTD 8V [192..]	1,9l 59 kW 192 A 3.000 4 Zyl.			
Air mass meter, diesel	10.01→		0 281 002 308	
Speed sensor, diesel	10.01-12.03		0 281 002 474	
	01.04→		0 281 002 603	
Phase sensor	10.01→	NOC	0 281 002 213	
High-pressure sensor (CR system)	10.01-06.02		0 281 002 260	
	07.02-12.03		0 281 002 405	
Boost pressure sensor, Diesel	10.01-01.06		0 281 002 510	
	02.06→		0 281 002 844	
Accelerator pedal module	10.01→	LLE,XBN	0 280 752 227	
Pressure sensor, ESP, (electronic stability program)	01.04→		0 265 005 303	
Wheel speed sensor, front	10.01→		0 265 007 401	
Wheel speed sensor, rear	01.04→		0 265 007 636	
Fg.no. 312323→	10.01-12.03		0 265 007 636	
Ricam.no →312322	10.01-12.03		0 265 007 400	
1.9 JTD 8V [192..]	1,9l 66 kW 192 B 5.000 4 Zyl.			
Air mass meter, diesel	10.05-06.07		0 281 002 792	
Speed sensor, diesel	10.05→	KW	0 281 002 603	
Phase sensor	10.05→	NOC	0 281 002 213	
High-pressure sensor (CR system)	10.05→		0 281 002 534	
Boost pressure sensor, Diesel	10.05-03.07		0 281 002 437	
	04.07→		0 281 002 845	
Yaw rate sensor, brake system	10.05→		0 265 005 241	
Pressure sensor, ESP, (electronic stability program)	10.05→		0 265 005 303	
Wheel speed sensor, front	10.05→		0 265 007 401	
Wheel speed sensor, rear	10.05→		0 265 007 636	
1.9 JTD 8V [192..]	1,9l 74 kW 192 A 9.000 4 Zyl.			
Air mass meter, diesel	01.04→		0 281 002 308	
Speed sensor, diesel	01.04→		0 281 002 603	
Phase sensor	01.04→	NOC	0 281 002 213	
Boost pressure sensor, Diesel	01.04-01.06		0 281 002 510	
	02.06→		0 281 002 844	
Accelerator pedal module	01.04→	LLE,XBN	0 280 752 227	
Yaw rate sensor, brake system	01.04→		0 265 005 241	
Pressure sensor, ESP, (electronic stability program)	01.04→		0 265 005 303	

Product				
Wheel speed sensor, front	01.04→		0 265 007 401	
Wheel speed sensor, rear	01.04→		0 265 007 636	
1.9 JTD 8V [192..]	1,9l 85 kW 192 A 1.000 4 Zyl.			
Air mass meter, diesel	10.01→		0 281 002 308	
Speed sensor, diesel	10.01-12.03		0 281 002 474	
	01.04→		0 281 002 603	
Phase sensor	10.01→	NOC	0 281 002 213	
High-pressure sensor (CR system)	10.01-06.02		0 281 002 260	
	07.02-12.03		0 281 002 405	
Boost pressure sensor, Diesel	10.01-01.06		0 281 002 510	
	02.06→		0 281 002 844	
Accelerator pedal module	10.01→	LLE,XBN	0 280 752 227	
Yaw rate sensor, brake system	10.01→		0 265 005 241	
Pressure sensor, ESP, (electronic stability program)	10.01→		0 265 005 303	
Wheel speed sensor, front	10.01→		0 265 007 401	
Wheel speed sensor, rear	01.04→		0 265 007 636	
Fg.no. 312323→	10.01-12.03		0 265 007 636	
Ricam.no →312322	10.01-12.03		0 265 007 400	
1.9 JTD 8V [192..]	1,9l 85/88 kW 192 A 8.000; 937 A 7.000 4 Zyl.			
Air mass meter, diesel	07.05-06.07		0 281 002 792	
Speed sensor, diesel	07.05→	KW	0 281 002 603	
Phase sensor	07.05→	NOC	0 281 002 213	
High-pressure sensor (CR system)	07.05→		0 281 002 534	
Boost pressure sensor, Diesel	07.05-03.07		0 281 002 437	
	04.07→		0 281 002 845	
Yaw rate sensor, brake system	07.05→		0 265 005 241	
Pressure sensor, ESP, (electronic stability program)	07.05→		0 265 005 303	
Wheel speed sensor, front	07.05→		0 265 007 401	
Wheel speed sensor, rear	07.05→		0 265 007 636	
1.9 JTD 16V [192..]	1,9l 93/100/103 kW 192 A 5.000; 192 B 1.000; 937 A 4.000 4 Zyl.			
Air mass meter, diesel	01.04→		0 280 218 120	
High-pressure sensor (CR system)	01.04→		0 281 002 534	
Boost pressure sensor, Diesel	01.04-03.07		0 281 002 437	
	04.07→		0 281 002 845	
Accelerator pedal module	01.04→	LLE,XBN	0 280 752 227	
Yaw rate sensor, brake system	01.04→		0 265 005 241	
Pressure sensor, ESP, (electronic stability program)	01.04→		0 265 005 303	
Wheel speed sensor, front	01.04→		0 265 007 401	
Wheel speed sensor, rear	01.04→		0 265 007 636	
1.9 JTD 16V [192..]	1,9l 110 kW 937 A 5.000 4 Zyl.			
Air mass meter, diesel	07.05-06.07		0 281 002 792	
High-pressure sensor (CR system)	07.05→		0 281 002 534	
Boost pressure sensor, Diesel	07.05-03.07		0 281 002 437	
	04.07→		0 281 002 845	
Yaw rate sensor, brake system	07.05→		0 265 005 241	
Pressure sensor, ESP, (electronic stability program)	07.05→		0 265 005 303	
Wheel speed sensor, front	07.05→		0 265 007 401	
Wheel speed sensor, rear	07.05→		0 265 007 636	
2.4 MPI 20V	2,4l 123 kW 192 A 7.011 5 Zyl.			
Throttle valve assembly	06.02→		0 205 003 052	
Air mass meter, gasoline injection	06.02→		0 281 002 308	
Phase sensor	06.02→		0 232 101 036	
Speed sensor, ignition/injection	06.02→		0 261 210 160	
Knock sensor	06.02→		0 261 231 144	
Accelerator pedal module	06.02→	LLE,XBN	0 280 752 227	
Yaw rate sensor, brake system	06.02→		0 265 005 241	
Wheel speed sensor, front	06.02→		0 265 007 401	
Wheel speed sensor, rear	06.02→		0 265 007 400	
2.4 20V [192..]	2,4l 125 kW 192 A 2.000 5 Zyl.			
Throttle valve assembly	10.01→		0 205 003 052	
Air mass meter, gasoline injection	10.01→		0 281 002 308	
Phase sensor	10.01→		0 232 101 036	



Product



Speed sensor, ignition/injection	10.01→	0 261 210 160
Knock sensor	10.01→	0 261 231 144
Accelerator pedal module	10.01-12.03 LLE,XBN	0 280 752 227
Yaw rate sensor, brake system	10.01→	0 265 005 241
Pressure sensor, ESP, (electronic stability program)	10.01→	0 265 005 303
Wheel speed sensor, front	10.01→	0 265 007 401
Wheel speed sensor, rear	01.04→	0 265 007 636
Fg.no. 312323→	10.01-12.03	0 265 007 636
Ricam.no →312322	10.01-12.03	0 265 007 400

Stilo Multi Wagon

1.4 16V [192..]	1,4l 66/70 kW 192 B 2.000; 843 A 1.000 4 Zyl.
Throttle valve assembly	01.04→ F 01C 600 027
Phase sensor	01.04→ NOC 0 232 103 048
Speed sensor, ignition/injection	01.04→ 0 261 210 238
Knock sensor	01.04→ 0 261 231 173
Pressure sensor, intake manifold, gasoline	01.04→ 0 261 230 030
Wheel speed sensor, front	01.04→ 0 265 007 401
Wheel speed sensor, rear	01.04→ 0 265 007 636
1.6 16V [192..]	1,6l 76 kW 182 B 6.000 4 Zyl.
Yaw rate sensor, brake system	10.02→ 0 265 005 241
Pressure sensor, ESP, (electronic stability program)	10.02→ 0 265 005 303
Wheel speed sensor, front	10.02→ 0 265 007 401
Wheel speed sensor, rear	10.02→ 0 265 007 636
1.6 16V [192..]	1,6l 100 kW 192 B 3.000 4 Zyl.
Accelerator pedal module	07.05→ LLE,XBN 0 280 752 227
Yaw rate sensor, brake system	07.05→ 0 265 005 241
Pressure sensor, ESP, (electronic stability program)	07.05→ 0 265 005 303
Wheel speed sensor, front	07.05→ 0 265 007 401
Wheel speed sensor, rear	07.05→ 0 265 007 636
1.8 16V [192..]	1,8l 98 kW 192 A 4.000 4 Zyl.
Phase sensor	10.02→ 0 232 101 037
Yaw rate sensor, brake system	10.02→ 0 265 005 241
Pressure sensor, ESP, (electronic stability program)	10.02→ 0 265 005 303
Wheel speed sensor, front	10.02→ 0 265 007 401
Wheel speed sensor, rear	10.02→ 0 265 007 636
1.9 JTD 8V [192..]	1,9l 59 kW 192 A 3.000 4 Zyl.
Air mass meter, diesel	10.02→ 0 281 002 308
Speed sensor, diesel	10.02-07.03 0 281 002 474
	08.03→ 0 281 002 603
Phase sensor	10.02→ NOC 0 281 002 213
High-pressure sensor (CR system)	10.02-12.03 0 281 002 405
Boost pressure sensor, Diesel	10.02-01.06 0 281 002 510
	02.06→ 0 281 002 844
Accelerator pedal module	10.02→ LLE,XBN 0 280 752 227
Yaw rate sensor, brake system	10.02→ 0 265 005 241
Pressure sensor, ESP, (electronic stability program)	10.02→ 0 265 005 303
Wheel speed sensor, front	10.02→ 0 265 007 401
Wheel speed sensor, rear	10.02→ 0 265 007 636
1.9 JTD 8V [192..]	1,9l 66 kW 192 B 5.000 4 Zyl.
Air mass meter, diesel	10.05-06.07 0 281 002 792
Speed sensor, diesel	10.05→ KW 0 281 002 603
Phase sensor	10.05→ NOC 0 281 002 213
High-pressure sensor (CR system)	10.05→ 0 281 002 534
Boost pressure sensor, Diesel	10.05-03.07 0 281 002 437
	04.07→ 0 281 002 845
Yaw rate sensor, brake system	10.05→ 0 265 005 241
Pressure sensor, ESP, (electronic stability program)	10.05→ 0 265 005 303
Wheel speed sensor, front	10.05→ 0 265 007 401
Wheel speed sensor, rear	10.05→ 0 265 007 636

Product



1.9 JTD 8V [192..]	1,9l 74 kW 192 A 9.000 4 Zyl.
Air mass meter, diesel	09.04→ 0 281 002 308
Speed sensor, diesel	09.04→ 0 281 002 603
Phase sensor	09.04→ NOC 0 281 002 213
Boost pressure sensor, Diesel	09.04-01.06 0 281 002 510
	02.06→ 0 281 002 844
Accelerator pedal module	09.04→ LLE,XBN 0 280 752 227
Yaw rate sensor, brake system	09.04→ 0 265 005 241
Pressure sensor, ESP, (electronic stability program)	09.04→ 0 265 005 303
Wheel speed sensor, front	09.04→ 0 265 007 401
Wheel speed sensor, rear	09.04→ 0 265 007 636
1.9 JTD 8V [192..]	1,9l 85 kW 192 A 1.000 4 Zyl.
Air mass meter, diesel	10.02→ 0 281 002 308
Speed sensor, diesel	10.02-07.03 0 281 002 474
	08.03→ 0 281 002 603
Phase sensor	10.02→ NOC 0 281 002 213
High-pressure sensor (CR system)	10.02-12.03 0 281 002 405
Boost pressure sensor, Diesel	10.02-01.06 0 281 002 510
	02.06→ 0 281 002 844
Accelerator pedal module	10.02→ LLE,XBN 0 280 752 227
Yaw rate sensor, brake system	10.02→ 0 265 005 241
Pressure sensor, ESP, (electronic stability program)	10.02→ 0 265 005 303
Wheel speed sensor, front	10.02→ 0 265 007 401
Wheel speed sensor, rear	10.02→ 0 265 007 636
1.9 JTD 8V [192..]	1,9l 85/88 kW 192 A 8.000; 937 A 7.000 4 Zyl.
Air mass meter, diesel	07.05-06.07 0 281 002 792
Speed sensor, diesel	07.05→ KW 0 281 002 603
Phase sensor	07.05→ NOC 0 281 002 213
High-pressure sensor (CR system)	07.05→ 0 281 002 534
Boost pressure sensor, Diesel	07.05-03.07 0 281 002 437
	04.07→ 0 281 002 845
Yaw rate sensor, brake system	07.05→ 0 265 005 241
Pressure sensor, ESP, (electronic stability program)	07.05→ 0 265 005 303
Wheel speed sensor, front	07.05→ 0 265 007 401
Wheel speed sensor, rear	07.05→ 0 265 007 636
1.9 JTD 16V [192..]	1,9l 93/100/103 kW 192 A 5.000; 192 B 1.000; 937 A 4.000 4 Zyl.
Air mass meter, diesel	01.04→ 0 280 218 120
High-pressure sensor (CR system)	01.04→ 0 281 002 534
Boost pressure sensor, Diesel	01.04-03.07 0 281 002 437
	04.07→ 0 281 002 845
Accelerator pedal module	01.04→ LLE,XBN 0 280 752 227
Yaw rate sensor, brake system	01.04→ 0 265 005 241
Pressure sensor, ESP, (electronic stability program)	01.04→ 0 265 005 303
Wheel speed sensor, front	01.04→ 0 265 007 401
Wheel speed sensor, rear	01.04→ 0 265 007 636
1.9 JTD 16V [192..]	1,9l 110 kW 937 A 5.000 4 Zyl.
Air mass meter, diesel	07.05-06.07 0 281 002 792
High-pressure sensor (CR system)	07.05→ 0 281 002 534
Boost pressure sensor, Diesel	07.05-03.07 0 281 002 437
	04.07→ 0 281 002 845
Yaw rate sensor, brake system	07.05→ 0 265 005 241
Pressure sensor, ESP, (electronic stability program)	07.05→ 0 265 005 303
Wheel speed sensor, front	07.05→ 0 265 007 401
Wheel speed sensor, rear	07.05→ 0 265 007 636
2.4 20V [192..]	2,4l 125 kW 192 A 2.000 4 Zyl.
Throttle valve assembly	01.04→ 0 205 003 052
Air mass meter, gasoline injection	01.04→ 0 281 002 308
Phase sensor	01.04→ 0 232 101 036
Speed sensor, ignition/injection	01.04→ 0 261 210 160
Knock sensor	01.04→ 0 261 231 144
Yaw rate sensor, brake system	01.04→ 0 265 005 241



F



Product



◀ Stilo Multi Wagon

Pressure sensor, ESP, (electronic stability program)	01.04→	0 265 005 303
Wheel speed sensor, front	01.04→	0 265 007 401
Wheel speed sensor, rear	01.04→	0 265 007 636

Strada

1.2 MPI 8V [278]1,2l 44 kW 178 B 5.000 4 Zyl.		
Speed sensor, ignition/injection	03.99-03.03	0 261 210 114
Wheel speed sensor, front	03.99-03.03	LAB 0 265 007 049
		RAB 0 265 007 050
Wheel speed sensor, rear	03.99-03.03	LAB 0 265 007 054
		RAB 0 265 007 055

1.2 MPI 8V [278]1,2l 54 kW 188 A 4.000 4 Zyl.		
Speed sensor, ignition/injection	05.01-06.05	0 261 210 114
Wheel speed sensor, front	04.03-06.05	ATJ,LAB 0 265 007 103
		ATJ,RAB 0 265 007 102
		ATN,LAB 0 265 007 049
		ATN,RAB 0 265 007 050
Wheel speed sensor, rear	05.01-03.03	LAB 0 265 007 049
		RAB 0 265 007 050
	05.01-06.05	LAB 0 265 007 054
		RAB 0 265 007 055

1.3 JTD [278]1,3l 63 kW 223 A 9.000 4 Zyl.		
Air mass meter, diesel	07.05→	0 281 002 792
Boost pressure sensor, Diesel	07.05-11.06	0 281 002 437
	12.06→	0 281 002 845
Accelerator pedal module	07.05→	0 281 002 379
Wheel speed sensor, front	07.05→	LAB 0 265 007 103
		RAB 0 265 007 102
Wheel speed sensor, rear	07.05→	LAB 0 265 007 054
		RAB 0 265 007 055

1.5 MPI 8V1,5l 56 kW 178 A 5.011 4 Zyl.		
Wheel speed sensor, front	10.98-02.03	LAB 0 265 007 049
		RAB 0 265 007 050
Wheel speed sensor, rear	10.98-02.03	LAB 0 265 007 054
		RAB 0 265 007 055

1.6 MPI 16V1,6l 78 kW 178 D 2.011 4 Zyl.		
Wheel speed sensor, front	02.98-02.03	LAB 0 265 007 049
		RAB 0 265 007 050
Wheel speed sensor, rear	02.98-02.03	LAB 0 265 007 054
		RAB 0 265 007 055

1.7 TDS [278]1,7l 51 kW 176 A 3.000 4 Zyl.		
Wheel speed sensor, front	03.99-03.03	LAB 0 265 007 049
		RAB 0 265 007 050
Wheel speed sensor, rear	03.99-03.03	LAB 0 265 007 054
		RAB 0 265 007 055

1.9 D [278]1,9l 46 kW 223 A 6.000 4 Zyl.		
Speed sensor, diesel	11.00-03.03	0 281 002 214
	04.03-06.05	0 281 002 474
Accelerator pedal module	11.00-06.05	0 281 002 379
Wheel speed sensor, front	11.00-06.05	LAB 0 265 007 049
		RAB 0 265 007 050
Wheel speed sensor, rear	11.00-06.05	LAB 0 265 007 054
		RAB 0 265 007 055

1.9 JTD [278]1,9l 59 kW 188 A 2.000 4 Zyl.		
Air mass meter, diesel	04.03-06.05	0 281 002 308
Speed sensor, diesel	04.03-02.04	0 281 002 474
	03.04-06.05	0 281 002 603
Phase sensor	04.03-06.05	0 281 002 213
High-pressure sensor (CR system)	04.03-02.04	0 281 002 405
Boost pressure sensor, Diesel	04.03-06.05	0 281 002 844
Accelerator pedal module	04.03-06.05	0 281 002 379

Product



Wheel speed sensor, front	04.03-06.05	LAB 0 265 007 049
		RAB 0 265 007 050
Wheel speed sensor, rear	04.03-06.05	LAB 0 265 007 054
		RAB 0 265 007 055

Strada Adventure

1.7 TD [Fase II]1,7l 52 kW 4 Zyl.		
Wheel speed sensor, front	10.06→	LAB 0 265 007 103
		RAB 0 265 007 102
Wheel speed sensor, rear	10.06→	LAB 0 265 007 054
		RAB 0 265 007 055

Temptra

1.4 [159]1,4l 56 kW 159 A 2.000 4 Zyl.		
Wheel speed sensor, front	04.93-03.96	0 265 001 215
	04.96-12.96	0 265 006 212
Wheel speed sensor, rear	04.96-12.96	0 265 006 197
	04.93-03.96	LAB 0 265 001 216
		RAB 0 265 001 217

1.4 i.e. [159]1,4l 51 kW 160 A 1.046 4 Zyl.		
Temperature sensor, coolant, injection system	03.92-03.93	0 280 130 026
Wheel speed sensor, front	04.93-03.96	0 265 001 215
	04.96-12.96	0 265 006 212
Wheel speed sensor, rear	04.96-12.96	0 265 006 197
	04.93-03.96	LAB 0 265 001 216
		RAB 0 265 001 217

1.4 i.e. [159]1,4l 51 kW 836 A 4.000 4 Zyl.		
Speed sensor, ignition/injection	03.95-12.96	KL 0 261 210 118
		KLO 0 261 210 115
Temperature sensor, coolant, injection system	03.95-12.96	0 280 130 026
Wheel speed sensor, front	03.95-03.96	0 265 001 215
	04.96-12.96	0 265 006 212
Wheel speed sensor, rear	04.96-12.96	0 265 006 197
	03.95-03.96	LAB 0 265 001 216
		RAB 0 265 001 217

1.6 [159]1,6l 62 kW 159 A 3.000 4 Zyl.		
Speed sensor, ignition/injection	04.93-12.96	KL 0 261 210 118
Wheel speed sensor, front	04.93-03.96	0 265 001 215
	04.96-12.96	0 265 006 212
Wheel speed sensor, rear	04.96-12.96	0 265 006 197
	04.93-03.96	LAB 0 265 001 216
		RAB 0 265 001 217

1.6 [159]1,6l 62 kW 159 A 3.098 4 Zyl.		
Wheel speed sensor, front	04.93-03.96	0 265 001 215
	04.96-12.96	0 265 006 212
Wheel speed sensor, rear	04.96-12.96	0 265 006 197
	04.93-03.96	LAB 0 265 001 216
		RAB 0 265 001 217

1.6 i.e. [159]1,6l 55 kW 159 A 3.048 4 Zyl.		
Temperature sensor, coolant, injection system	06.92-03.93	0 280 130 026
1.6 i.e. [159]1,6l 55 kW 835 C 1.000 4 Zyl.		
Speed sensor, ignition/injection	04.93-12.96	KL 0 261 210 118
		KLO 0 261 210 102
Temperature sensor, coolant, injection system	04.93-12.96	0 280 130 026
Wheel speed sensor, front	04.93-03.96	0 265 001 215
	04.96-12.96	0 265 006 212
Wheel speed sensor, rear	04.96-12.96	0 265 006 197
	04.93-03.96	LAB 0 265 001 216
		RAB 0 265 001 217

1.6 i.e. [159]1,6l 57 kW 159 A 3.046 4 Zyl.		
Temperature sensor, coolant, injection system	06.90-07.92	0 280 130 026



1.6 i.e. [159]				1,6l 66 kW 159 B 9.000 4 Zyl.
Wheel speed sensor, front	05.94-03.96			0 265 001 215
	04.96-12.96			0 265 006 212
Wheel speed sensor, rear	04.96-12.96			0 265 006 197
	05.94-03.96	LAB		0 265 001 216
		RAB		0 265 001 217
1.6 i.e. Selecta [159]				1,6l 55 kW 159 A 3.048 4 Zyl.
Wheel speed sensor, front	04.93-03.96			0 265 001 215
	04.96-12.96			0 265 006 212
Wheel speed sensor, rear	04.96-12.96			0 265 006 197
	04.93-03.96	LAB		0 265 001 216
		RAB		0 265 001 217
1.8 i.e. [159]				1,8l 66/71/76 kW 159 A 4.046; 835 C 2.000; 835 C 4.000; 836 A 5.000 4 Zyl.
Wheel speed sensor, front	04.93-03.96			0 265 001 215
	04.96-12.96			0 265 006 212
Wheel speed sensor, rear	04.96-12.96			0 265 006 197
	04.93-03.96	LAB		0 265 001 216
		RAB		0 265 001 217
1.8 i.e. [159]				1,8l 77 kW 159 A 4.046; 835 C 2.000; 835 C 4.000; 836 A 5.000 4 Zyl.
Wheel speed sensor, front	04.93-03.96			0 265 001 215
	04.96-12.96			0 265 006 212
Wheel speed sensor, rear	04.96-12.96			0 265 006 197
1.8 i.e. [159]				1,8l 77 kW 835 C 2.000 4 Zyl.
Wheel speed sensor, rear	04.93-12.96	LAB		0 265 001 216
		RAB		0 265 001 217
1.9 D [159]				1,9l 48 kW 160 A 7.000 4 Zyl.
Wheel speed sensor, front	04.93-12.96			0 265 001 215
Wheel speed sensor, rear	04.93-12.96	LAB		0 265 001 216
		RAB		0 265 001 217
1.9 TD [159]				1,9l 60/66/68 kW 160 A 6.000; 160 A 6.046; 160 B 6.046; 160 D 1.000 4 Zyl.
Wheel speed sensor, front	02.90-12.96			0 265 001 215
Wheel speed sensor, rear	02.90-12.96	LAB		0 265 001 216
		RAB		0 265 001 217
2.0 i.e. [159]				2,0l 83-85 kW 159 A 6.046 4 Zyl.
Wheel speed sensor, front	02.90-03.96			0 265 001 215
	04.96-12.96			0 265 006 212
Wheel speed sensor, rear	04.96-12.96			0 265 006 197
	02.90-03.96	LAB		0 265 001 216
	04.93-03.96	RAB		0 265 001 217
	02.90-03.93	RAB		0 265 006 197
2.0 SPI 8V				2,0l 76 kW 159 B 1.011 4 Zyl.
Wheel speed sensor, front	05.94-12.98			0 265 006 402
Wheel speed sensor, rear	05.94-12.98			0 265 006 403

Tempra SW

1.4 [159]				1,4l 56 kW 159 A 2.000 4 Zyl.
Wheel speed sensor, front	04.93-03.96			0 265 001 215
	04.96-12.96			0 265 006 212
Wheel speed sensor, rear	04.96-12.96			0 265 006 197
	04.93-03.96	LAB		0 265 001 216
		RAB		0 265 001 217
1.4 i.e. [159]				1,4l 51 kW 160 A 1.046 4 Zyl.
Temperature sensor, coolant, injection system	03.92-03.93			0 280 130 026
Wheel speed sensor, front	04.94-03.96			0 265 001 215
	04.96-12.96			0 265 006 212
Wheel speed sensor, rear	04.96-12.96			0 265 006 197
	04.94-03.96	LAB		0 265 001 216
		RAB		0 265 001 217



1.4 i.e. [159]				1,4l 51 kW 836 A 4.000 4 Zyl.
Speed sensor, ignition/injection	03.95-12.96	KL		0 261 210 118
		KLO		0 261 210 115
Temperature sensor, coolant, injection system	03.95-12.96			0 280 130 026
Wheel speed sensor, front	03.95-03.96			0 265 001 215
	04.96-12.96			0 265 006 212
Wheel speed sensor, rear	04.96-12.96			0 265 006 197
	03.95-03.96	LAB		0 265 001 216
		RAB		0 265 001 217
1.6 [159]				1,6l 62 kW 159 A 3.000 4 Zyl.
Speed sensor, ignition/injection	04.93-12.96	KL		0 261 210 118
Wheel speed sensor, front	04.93-03.96			0 265 001 215
	04.96-12.96			0 265 006 212
Wheel speed sensor, rear	04.96-12.96			0 265 006 197
	04.93-03.96	LAB		0 265 001 216
		RAB		0 265 001 217
1.6 i.e. [159]				1,6l 55 kW 159 A 3.048 4 Zyl.
Temperature sensor, coolant, injection system	06.92-03.93			0 280 130 026
1.6 i.e. [159]				1,6l 55 kW 835 C 1.000 4 Zyl.
Speed sensor, ignition/injection	04.93-12.96	KL		0 261 210 118
		KLO		0 261 210 102
Temperature sensor, coolant, injection system	04.93-12.96			0 280 130 026
Wheel speed sensor, front	04.93-03.96			0 265 001 215
	04.96-12.96			0 265 006 212
Wheel speed sensor, rear	04.96-12.96			0 265 006 197
	04.93-03.96	LAB		0 265 001 216
		RAB		0 265 001 217
1.6 i.e. [159]				1,6l 57 kW 159 A 3.046 4 Zyl.
Temperature sensor, coolant, injection system	01.91-07.92			0 280 130 026
1.6 i.e. [159]				1,6l 66 kW 159 B 9.000 4 Zyl.
Wheel speed sensor, front	05.94-03.96			0 265 001 215
	04.96-12.96			0 265 006 212
Wheel speed sensor, rear	04.96-12.96			0 265 006 197
	05.94-03.96	LAB		0 265 001 216
		RAB		0 265 001 217
1.6 i.e. Selecta [159]				1,6l 55 kW 159 A 3.048 4 Zyl.
Wheel speed sensor, front	04.93-03.96			0 265 001 215
	04.96-12.96			0 265 006 212
Wheel speed sensor, rear	04.96-12.96			0 265 006 197
	04.93-03.96	LAB		0 265 001 216
		RAB		0 265 001 217
1.8 i.e. [159]				1,8l 66/71/76/77 kW 159 A 4.046; 835 C 2.000/4.000; 836 A 5.000 4 Zyl.
Wheel speed sensor, front	04.93-03.96			0 265 001 215
	04.96-12.96			0 265 006 212
Wheel speed sensor, rear	04.96-12.96			0 265 006 197
	04.93-03.96	LAB		0 265 001 216
		RAB		0 265 001 217
1.9 D [159]				1,9l 48 kW 160 A 7.000 4 Zyl.
Wheel speed sensor, front	04.93-12.96			0 265 001 215
Wheel speed sensor, rear	04.93-12.96	LAB		0 265 001 216
		RAB		0 265 001 217
1.9 TD [159]				1,9l 60/66/68 kW 160 A 6.000; 160 A 6.046; 160 B 6.046; 160 D 1.000 4 Zyl.
Wheel speed sensor, front	02.90-12.96			0 265 001 215
Wheel speed sensor, rear	02.90-12.96	LAB		0 265 001 216
		RAB		0 265 001 217
2.0 i.e. [159]				2,0l 83-85 kW 159 A 6.046 4 Zyl.
Wheel speed sensor, front	03.92-03.96			0 265 001 215
	04.96-12.96			0 265 006 212



Product				
◀ Tempra SW				
Wheel speed sensor, rear	04.96-12.96			0 265 006 197
	03.92-03.96	LAB		0 265 001 216
	04.93-03.96	RAB		0 265 001 217
	03.92-03.93	RAB		0 265 006 197
2.0 i.e. 4x4 [159]	2,0l	83-85 kW	159 A	6.046 4 Zyl.
Lateral acceleration sensor, brake system	03.92-12.96	LAB		0 265 005 031
		RAB		0 265 005 030
Wheel speed sensor, front	03.92-12.96			0 265 001 215
Wheel speed sensor, rear	03.92-12.96			0 265 001 304
2.0 MPI 8V	2,0l	80 kW	159 B	8.011 4 Zyl.
Wheel speed sensor, front	05.94-10.97			0 265 001 355
		WW		0 265 001 215
Wheel speed sensor, rear	05.94-10.97			0 265 006 197



Tipo

1.1 i.e. [160..]	1,1l	37 kW	156 C	0.046 4 Zyl.
Speed sensor, ignition/injection	10.94-05.95			0 261 210 098
	06.95-10.95			0 261 210 117
Temperature sensor, coolant, injection system	10.94-10.95			0 280 130 026
Wheel speed sensor, front	10.94-10.95			0 265 001 215
Wheel speed sensor, rear	10.94-10.95	LAB		0 265 001 216
		RAB		0 265 001 217
1.4 [160..]	1,4l	52 kW	159 A	2.000 4 Zyl.
Temperature sensor, coolant, injection system	03.93-10.95			0 280 130 066
Wheel speed sensor, front	03.93-10.95			0 265 001 215
Wheel speed sensor, rear	03.93-10.95	LAB		0 265 001 216
		RAB		0 265 001 217
1.4 i.e. [160..]	1,4l	51 kW	836 A	4.000 4 Zyl.
Speed sensor, ignition/injection	10.93-10.95	KL		0 261 210 118
		KLO		0 261 210 115
Temperature sensor, coolant, injection system	10.93-10.95			0 280 130 066
Wheel speed sensor, front	10.93-10.95			0 265 001 215
Wheel speed sensor, rear	10.93-10.95	LAB		0 265 001 216
		RAB		0 265 001 217
1.4 i.e. [160..]	1,4l	52 kW	160 A	1.046 4 Zyl.
Temperature sensor, coolant, injection system	03.93-10.95			0 280 130 066
Wheel speed sensor, front	03.93-10.95			0 265 001 215
Wheel speed sensor, rear	03.93-10.95	LAB		0 265 001 216
		RAB		0 265 001 217
1.6 [160..]	1,6l	58 kW	159 A	3.000 4 Zyl.
Speed sensor, ignition/injection	03.93-09.93	KL		0 261 210 103
		KLO		0 261 210 102
Temperature sensor, coolant, injection system	03.93-10.95			0 280 130 066
Wheel speed sensor, front	03.93-10.95			0 265 001 215
Wheel speed sensor, rear	03.93-10.95	LAB		0 265 001 216
		RAB		0 265 001 217
1.6 i.e. [160..]	1,6l	55 kW	159 A	3.048 4 Zyl.
Temperature sensor, coolant, injection system	01.92-03.93			0 280 130 066
1.6 i.e. [160..]	1,6l	56 kW	160 E	2.011; 835 C 1.000 4 Zyl.
Speed sensor, ignition/injection	03.93-09.93	KL		0 261 210 103
	10.93-10.95	KL		0 261 210 118
	03.93-09.93	KLO		0 261 210 102
	10.93-10.95	KLO		0 261 210 115
Temperature sensor, coolant, injection system	03.93-10.95			0 280 130 066
Wheel speed sensor, front	03.93-10.95			0 265 001 215
Wheel speed sensor, rear	03.93-10.95	LAB		0 265 001 216
		RAB		0 265 001 217
1.6 i.e. [160..]	1,6l	57 kW	159 A	3.046 4 Zyl.
Temperature sensor, coolant, injection system	03.90-03.93			0 280 130 066
1.6 i.e. Selecta [160..]	1,6l	56 kW	159 A	3.048 4 Zyl.
Temperature sensor, coolant, injection system	03.93-10.95			0 280 130 066
Wheel speed sensor, front	03.93-10.95			0 265 001 215

Product				
Wheel speed sensor, rear	03.93-10.95	LAB		0 265 001 216
		RAB		0 265 001 217
1.6 MPI 8V	1,6l	66 kW	160 E	1.011 4 Zyl.
Throttle valve sensor	12.95-05.97			0 280 122 001
Speed sensor, ignition/injection	12.95-05.97			0 261 210 118
Knock sensor	12.95-05.97			0 261 231 007
Pressure sensor, intake manifold, gasoline	12.95-05.97			0 261 230 004
Temperature sensor, intake air, injection system	12.95-05.97			0 280 130 060
Temperature sensor, coolant, injection system	12.95-05.97			0 280 130 068
1.7 D [160..]	1,7l	42 kW	149 B	4.000 4 Zyl.
Wheel speed sensor, front	03.93-10.95			0 265 001 215
Wheel speed sensor, rear	03.93-10.95	LAB		0 265 001 216
		RAB		0 265 001 217
1.8 i.e. [160..]	1,8l	66/71/77 kW	835 C 2.000/4.000; 836 A 5.000/6.000	4 Zyl.
Wheel speed sensor, front	03.93-10.95			0 265 001 215
Wheel speed sensor, rear	03.93-10.95	LAB		0 265 001 216
		RAB		0 265 001 217
1.8 i.e. 16V [160..]	1,8l	101 kW	160 A	5.000 4 Zyl.
Wheel speed sensor, front	06.89-09.91			0 265 001 215
Wheel speed sensor, rear	06.89-09.91	LAB		0 265 001 216
		RAB		0 265 001 217
1.9 D [160..]	1,9l	48 kW	160 A	7.000 4 Zyl.
Wheel speed sensor, front	03.93-10.95			0 265 001 215
Wheel speed sensor, rear	03.93-10.95	LAB		0 265 001 216
		RAB		0 265 001 217
1.9 D Turbo [160..]	1,9l	65/68 kW	160 A 6.000; 160 D 1.000	4 Zyl.
Wheel speed sensor, front	03.93-10.95			0 265 001 215
Wheel speed sensor, rear	03.93-10.95	LAB		0 265 001 216
		RAB		0 265 001 217
1.9 TD [160..]	1,9l	59/67,6/68 kW	160 A 6.000; 160 A 6.046; 160 B 6.046	4 Zyl.
Wheel speed sensor, front	07.87-03.93			0 265 001 215
Wheel speed sensor, rear	07.87-03.93	LAB		0 265 001 216
		RAB		0 265 001 217
2.0 i.e. [160..]	2,0l	85 kW	159 A 6.011; 159 A 6.046	4 Zyl.
Wheel speed sensor, front	03.93-10.95			0 265 001 215
Wheel speed sensor, rear	03.93-10.95	LAB		0 265 001 216
		RAB		0 265 001 217
2.0 i.e. 16V [160..]	2,0l	104/107 kW	160 A 8.046; 836 A 3.000; 836 A 3.011	4 Zyl.
Wheel speed sensor, front	12.90-10.95			0 265 001 215
Wheel speed sensor, rear	12.90-10.95	LAB		0 265 001 216
		RAB		0 265 001 217

Ulysse

1.8 i.e. [121..]	1,8l	75 kW	LFW	4 Zyl.
Wheel speed sensor, front	Ricam.no 7480→9050	06.97-05.00		0 265 006 388
Wheel speed sensor, rear	Ricam.no 7480→7609	06.97-09.97	BO	0 265 006 426
	Ricam.no 7610→	10.97-05.00	BO	0 265 006 504
1.9 TD [121..]	1,9l	66 kW	DHX; D8B	4 Zyl.
Wheel speed sensor, front	Ricam.no 7480→9050	06.97-12.99		0 265 006 388
Wheel speed sensor, rear	Ricam.no 7480→7609	06.97-09.97	BO	0 265 006 426
	Ricam.no 7610→	10.97-12.99	BO	0 265 006 504
2.0 i.e. [121..]	2,0l	90 kW	RFU	4 Zyl.
Knock sensor				
Wheel speed sensor, front	Ricam.no 8135→	03.99-05.00		0 261 231 130
Wheel speed sensor, rear	Ricam.no 7480→9050	06.97-05.00		0 265 006 388

Product				
Wheel speed sensor, rear				
Ricam.no 7480→7609	06.97-09.97	BO	0 265 006 426	
Ricam.no 7610→	10.97-05.00	BO	0 265 006 504	
2.0 i.e. Turbo [121..]		2,0l 110 kW RGX 4 Zyl.		
Throttle valve sensor				
Ricam.no →6778	09.94-06.95		0 280 122 001	
Ricam.no 6779→	07.95-05.00		0 280 122 003	
Knock sensor				
Ricam.no 8135→	03.99-05.00		0 261 231 130	
Wheel speed sensor, front				
Ricam.no 7480→9050	06.97-05.00		0 265 006 388	
Wheel speed sensor, rear				
Ricam.no 7480→7609	06.97-09.97	BO	0 265 006 426	
Ricam.no 7610→	10.97-05.00	BO	0 265 006 504	
2.0 i.e. 16V [121..]		2,0l 97 kW RFV 4 Zyl.		
Knock sensor				
Ricam.no →8134	05.98-02.99		0 261 231 109	
Ricam.no 8135→	03.99-05.00		0 261 231 130	
Pressure sensor, intake manifold, gasoline				
Ricam.no →8057	05.98-12.98		0 261 230 012	
Ricam.no 8058→	01.99-05.00		0 261 230 034	
Wheel speed sensor, front				
Ricam.no 7480→9050	05.98-05.00		0 265 006 388	
Wheel speed sensor, rear				
Ricam.no 7610→	05.98-05.00	BO	0 265 006 504	
2.0 i.e. 16V [121..]		2,0l 100 kW RFN 4 Zyl.		
Pressure sensor, intake manifold, gasoline	03.00-09.02		0 261 230 057	
Wheel speed sensor, front				
Ricam.no 7480→9050	03.00-08.01		0 265 006 388	
Wheel speed sensor, rear				
Ricam.no 7610→	03.00-09.02	BO	0 265 006 504	
2.0 JTD 8V [121..]		2,0l 80 kW RHZ 4 Zyl.		
High-pressure sensor (CR system)	07.99-09.02		0 281 002 283	
Wheel speed sensor, front				
Ricam.no 7480→9050	07.99-08.01		0 265 006 388	
Wheel speed sensor, rear				
Ricam.no 7610→	07.99-09.02	BO	0 265 006 504	
2.0 JTD 16V [121..]		2,0l 80 kW RHW 4 Zyl.		
High-pressure sensor (CR system)	11.00-09.02		0 281 002 283	
Wheel speed sensor, front				
Ricam.no 7480→9050	11.00-08.01		0 265 006 388	
Wheel speed sensor, rear				
Ricam.no 7610→	11.00-09.02	BO	0 265 006 504	
2.0 16V [179..]		2,0l 100 kW RFN 4 Zyl.		
Yaw rate sensor, brake system				
Ricam.no →10570	10.02-10.05		0 265 005 290	
Wheel speed sensor, front	10.02-10.05	LAB	0 265 007 083	
		RAB	0 265 007 084	
2.0 16V JTD [179..]		2,0l 79/80 kW RHM; RHW 4 Zyl.		
High-pressure sensor (CR system)	10.02→		0 281 002 283	
Yaw rate sensor, brake system				
Ricam.no →10570	10.02-10.05		0 265 005 290	
Wheel speed sensor, front	10.02→	LAB	0 265 007 083	
		RAB	0 265 007 084	
2.0 16V JTD [179..]		2,0l 88/100 kW RHK; RHR 4 Zyl.		
Wheel speed sensor, front	02.06→	LAB	0 265 007 083	
		RAB	0 265 007 084	
2.1 TD [121..]		2,1l 80 kW P8C 4 Zyl.		
Wheel speed sensor, front				
Ricam.no 7480→9050	06.97-10.99		0 265 006 388	
Wheel speed sensor, rear				
Ricam.no 7480→7609	06.97-09.97	BO	0 265 006 426	
Ricam.no 7610→	10.97-10.99	BO	0 265 006 504	

Product				
2.2 16V JTD [179..]		2,2l 94 kW 4HW 4 Zyl.		
High-pressure sensor (CR system)	10.02→		0 281 002 283	
Yaw rate sensor, brake system				
Ricam.no →10570	10.02-10.05		0 265 005 290	
Wheel speed sensor, front	10.02→	LAB	0 265 007 083	
		RAB	0 265 007 084	
3.0 V6 24V [179..]		3,0l 150 kW XFW 6 Zyl.		
Knock sensor	01.03-10.05	KZB	0 261 231 130	
Yaw rate sensor, brake system				
Ricam.no →10570	01.03-10.05		0 265 005 290	
Wheel speed sensor, front	01.03-10.05	LAB	0 265 007 083	
		RAB	0 265 007 084	
Uno				
1.0 i.e. [158..]		1,0l 33 kW 146 D 8.000 4 Zyl.		
Speed sensor, ignition/injection	01.96-12.02		0 261 210 114	
1.0 i.e. [158..]		1,0l 33 kW 156 A 2.246 4 Zyl.		
Temperature sensor, coolant, injection system	01.96-12.02		0 280 130 026	
1.3 Turbo i.e. [146..]		1,3l 73,5 kW 146 A 2.246 4 Zyl.		
Throttle valve sensor	10.87-08.89		0 280 120 314	
Air flow sensor, gasoline injection	10.87-08.89		0 280 200 051	
Temperature sensor, coolant, injection system	10.87-08.89		0 280 130 026	
Relay, Jetronic	10.87-08.89		0 280 230 009	
1.3 Turbo i.e. [146..]		1,3l 74 kW 146 A 2.246 4 Zyl.		
Throttle valve sensor	09.89-03.91		0 280 120 314	
Air flow sensor, gasoline injection	09.89-03.91		0 280 200 051	
Temperature sensor, coolant, injection system	09.89-03.91		0 280 130 066	
Relay, Jetronic	09.89-03.91		0 280 230 009	
Wheel speed sensor, front	09.89-03.91	LAB	0 265 001 337	
		RAB	0 265 001 336	
Wheel speed sensor, rear	09.89-03.91		0 265 001 338	
1.3 Turbo i.e. [146..]		1,3l 77 kW 146 A 2.000 4 Zyl.		
Throttle valve sensor	04.85-08.89		0 280 120 314	
Air flow sensor, gasoline injection	04.85-08.89		0 280 200 046	
Temperature sensor, coolant, injection system	04.85-08.89		0 280 130 026	
Relay, Jetronic	04.85-08.89		0 280 230 006	
1.4 i [146..]		1,4l 52 kW 146 A 4.045; 146 C 1.000 4 Zyl.		
Temperature sensor, coolant, injection system	05.90-12.98		0 280 130 066	
1.4 MPI Turbo		1,4l 85 kW 146 A 8.011 4 Zyl.		
Throttle valve sensor	03.94-12.95		0 280 120 314	
Temperature sensor, coolant, injection system	03.94-12.95		0 280 130 026	
1.4 Turbo i.e. [146..]		1,4l 84 kW 146 A 8.046 4 Zyl.		
Throttle valve sensor	10.90-12.93		0 280 120 314	
Temperature sensor, coolant, injection system	10.90-12.93		0 280 130 066	
Relay, Jetronic	10.90-12.93		0 332 014 113	
Wheel speed sensor, front	10.90-12.93	LAB	0 265 001 337	
		RAB	0 265 001 336	
Wheel speed sensor, rear	10.90-12.93		0 265 001 338	
1.4 Turbo i.e. [146..]		1,4l 85 kW 146 A 8.000 4 Zyl.		
Throttle valve sensor	05.90-12.98		0 280 120 314	
Temperature sensor, intake air, injection system	05.90-12.98		0 280 130 026	
Relay, Jetronic	05.90-12.98		0 332 014 107	
1.4 Turbo i.e. [146..]		1,4l 87 kW 146 A 8.000 4 Zyl.		
Throttle valve sensor	09.89-09.92		0 280 120 314	
Temperature sensor, coolant, injection system	09.89-09.92		0 280 130 066	
Relay, Jetronic	09.89-09.92		0 332 014 113	
Wheel speed sensor, front	09.89-09.92	LAB	0 265 001 337	
		RAB	0 265 001 336	
Wheel speed sensor, rear	09.89-09.92		0 265 001 338	





Product				

◀ Uno

1.6 RMPI	1,6l 66 kW 146 B 7.011 4 Zyl.
Throttle valve sensor	05.93-09.94 0 280 120 300
Air flow sensor, gasoline injection	05.93-09.94 0 280 200 055
Knock sensor	05.93-09.94 0 261 231 007
Temperature sensor, intake air, injection system	05.93-09.94 0 280 130 060
Temperature sensor, coolant, injection system	05.93-09.94 0 280 130 069
45 fire i.e. [146..]	1,0l 33 kW 156 A 2.246 4 Zyl.
Temperature sensor, coolant, injection system	10.87-08.89 0 280 130 026
45 i.e. [146..]	1,0l 33 kW 156 A 2.246 4 Zyl.
Temperature sensor, coolant, injection system	09.89-03.94 0 280 130 066
70 i.e. [146..]	1,4l 51/52 kW 146 C 1.000; 160 A 1.046 4 Zyl.
Temperature sensor, coolant, injection system	09.89-03.94 0 280 130 066
75 i.e. [146..]	1,5l 55 kW 138 C 2.048 4 Zyl.
Throttle valve sensor	10.85-08.87 0 280 120 300
Air flow sensor, gasoline injection	10.85-08.87 0 280 200 024
	0 986 280 075
Pressure sensor, intake manifold, gasoline	10.85-08.87 0 280 101 001
Temperature sensor, coolant, injection system	10.85-08.87 0 280 130 023
Relay, Jetronic	10.85-08.87 WEI 0 332 514 127
75 i.e. [146..]	1,5l 55 kW 149 C 1.000 4 Zyl.
Temperature sensor, coolant, injection system	09.87-08.89 0 280 130 026
	09.89-03.94 0 280 130 066
75 i.e. Selecta [146..]	1,5l 55 kW 149 C 1.000 4 Zyl.
Temperature sensor, coolant, injection system	05.92-03.94 0 280 130 066

Uno Mille

1.0 MPI	1,0l 40 kW 178 D 9.011 4 Zyl.
Speed sensor, ignition/injection	06.01-06.06 0 261 210 114

Uno Van

45 i.e. [246..]	1,0l 33 kW 156 A 2.246 4 Zyl.
Temperature sensor, coolant, injection system	09.89-03.94 0 280 130 066

X 1/9

1500 i.e.	1,5l 56 kW 138 AE.. 4 Zyl.
Throttle valve sensor	06.80-12.88 0 280 120 300
Air flow sensor, gasoline injection	09.80-12.88 0 280 200 024
	0 986 280 075
Pressure sensor, intake manifold, gasoline	09.83-12.88 0 280 101 001
Temperature sensor, coolant, injection system	06.80-12.88 0 280 130 023
Relay, Jetronic	09.80-12.88 WEI 0 332 514 127

FISSORE

Magnum 4x4

2.5 VIP V6 i.e.	2,5l 118 kW Alfa Romeo 019.11 6 Zyl.
Throttle valve sensor	03.86-03.88 0 280 120 302
Air flow sensor, gasoline injection	03.86-03.88 0 280 202 013
Temperature sensor, intake air, injection system	03.86-03.88 0 280 130 023
Relay, Jetronic	03.86-03.88 WEI 0 332 514 127

Product				

FORD

Capri II

2.8 i [78]	2,8l 118 kW RRN 6 Zyl.
Air flow sensor, gasoline injection	01.81-04.87 0 438 120 069

C-MAX

1.8, FFV	1,8l 92 kW 4 Zyl.
Pressure sensor, intake manifold, gasoline	03.07→ 0 261 230 044
1.8 TDCi	1,8l 85 kW 4 Zyl.
Pressure sensor, intake manifold, diesel	03.07→ 0 261 230 119
2.0, CNG	2,0l 107 kW 4 Zyl.
Pressure sensor, intake manifold, gasoline	03.07→ 0 261 230 044

Escort

1.6 i	1,6l 70 kW L1R 4 Zyl.
Pressure sensor, intake manifold, gasoline	02.00-10.02 0 261 230 027
1.9 i	1,9l 82 kW J 4 Zyl.
Air flow sensor, gasoline injection	08.89-02.92 0 280 202 121
	0 986 280 039

Escort IV

1.4 [86]	1,4l 51/54/55 kW FUA; FUA; FUC 4 Zyl.
Knock sensor	01.86-07.90 0 261 231 006
1.4 i [86]	1,4l 54 kW F6B; F6D 4 Zyl.
Knock sensor	01.87-07.90 0 261 231 006
1.6 [86]	1,6l 58/65/66 kW LP2; LUC; LUG 4 Zyl.
Knock sensor	01.86-07.90 0 261 231 006
1.6 i [86]	1,6l 66 kW L4B 4 Zyl.
Air flow sensor, gasoline injection	01.86-07.90 F 026 TX2 066
	F 026 TX2 066
Knock sensor	01.86-07.90 0 261 231 006
Temperature sensor, coolant, injection system	01.86-07.90 0 280 130 050
1.6 RS Turbo [86]	1,6l 97 kW LNB 4 Zyl.
Throttle valve sensor	01.86-07.90 0 280 120 302
Air flow sensor, gasoline injection	01.86-07.90 0 438 121 056
Knock sensor	01.86-07.90 0 261 231 006
Temperature sensor, coolant, injection system	01.86-07.90 0 280 130 049
1.6 XR3i [86]	1,6l 66/75 kW LJB; L4B 4 Zyl.
Air flow sensor, gasoline injection	01.86-07.90 F 026 TX2 066
	F 026 TX2 066
Knock sensor	01.86-07.90 0 261 231 006
Temperature sensor, coolant, injection system	01.86-07.90 0 280 130 050
1.6 XR3i [86]	1,6l 77 kW LRB; LR2 4 Zyl.
Air flow sensor, gasoline injection	01.86-08.89 0 438 120 199
Knock sensor	01.86-08.89 0 261 231 006
Relay, Jetronic	01.86-08.89 0 280 230 113
	0 280 230 116
1.6 XR3i [86]	1,6l 79 kW LJA 4 Zyl.
Air flow sensor, gasoline injection	08.89-07.90 0 438 120 199
Knock sensor	08.89-07.90 0 261 231 006
Relay, Jetronic	08.89-07.90 0 280 230 116



Escort IV Cabrio		
1.4 [86]	1,4l 51-55 kW FUA...; FUC	4 Zyl.
Knock sensor	01.86-07.90	0 261 231 006
1.4 i [86]	1,4l 54 kW F6...	4 Zyl.
Knock sensor	01.87-07.90	0 261 231 006
1.6 [86]	1,6l 58/65-66 kW LP2; LU...	4 Zyl.
Knock sensor	01.86-07.90	0 261 231 006
1.6 i [86]	1,6l 66 kW L4B	4 Zyl.
Air flow sensor, gasoline injection	01.86-07.90	F 026 TX2 066 🔧 F 026 TX2 066
Knock sensor	01.86-07.90	0 261 231 006
Temperature sensor, coolant, injection system	01.86-07.90	0 280 130 050
1.6 XR3i [86]	1,6l 75 kW LJB	4 Zyl.
Air flow sensor, gasoline injection	08.89-07.90	F 026 TX2 066 🔧 F 026 TX2 066
Knock sensor	08.89-07.90	0 261 231 006
Temperature sensor, coolant, injection system	08.89-07.90	0 280 130 050
1.6 XR3i [86]	1,6l 77 kW LRB; LR2	4 Zyl.
Air flow sensor, gasoline injection	01.86-08.89	0 438 120 199
Knock sensor	01.86-08.89	0 261 231 006
Relay, Jetronic	01.86-08.89	0 280 230 113 0 280 230 116

Escort IV Express		
1.4 [86]	1,4l 54 kW FUC	4 Zyl.
Knock sensor	01.86-07.90	0 261 231 006
1.4 i [86]	1,4l 54 kW F6...	4 Zyl.
Knock sensor	01.86-07.90	0 261 231 006
1.6 [86]	1,6l 65-66 kW LU...	4 Zyl.
Knock sensor	01.86-07.90	0 261 231 006

Escort IV Turnier		
1.4 [86]	1,4l 51-55 kW FUA...; FUC	4 Zyl.
Knock sensor	01.86-07.90	0 261 231 006
1.4 i [86]	1,4l 54 kW F6...	4 Zyl.
Knock sensor	01.87-07.90	0 261 231 006
1.6 [86]	1,6l 58/65-66 kW LP2; LU...	4 Zyl.
Knock sensor	01.86-07.90	0 261 231 006
1.6 i [86]	1,6l 66 kW L4B	4 Zyl.
Air flow sensor, gasoline injection	01.86-07.90	F 026 TX2 066 🔧 F 026 TX2 066
Knock sensor	01.86-07.90	0 261 231 006
Temperature sensor, coolant, injection system	01.86-07.90	0 280 130 050

Escort SW		
1.6 i	1,6l 70 kW L1R	4 Zyl.
Pressure sensor, intake manifold, gasoline	02.00-10.02	0 261 230 027

Explorer		
4.0 i	4,0l 153-157 kW EFI	6 Zyl.
Knock sensor	09.96-08.98	0 261 231 119
	09.98-08.00	0 261 231 138

F		
250	3,9l 149 kW	4 Zyl.
Pulse generator, diesel	04.06→	0 281 002 411
Speed sensor, diesel	04.06→	0 281 002 410



Boost pressure sensor, Diesel	04.06→	0 281 002 316
Temperature sensor, coolant, diesel	04.06→	0 281 002 471

Fairlane		
4.0 i [AU]	4,0l 168 kW Y	6 Zyl.
Speed sensor, ignition/injection	02.99-06.00	0 261 210 168
Pressure sensor, intake manifold, gasoline	02.99-06.00	0 261 230 029
4.0 i [AU II]	4,0l 168 kW Y	6 Zyl.
Speed sensor, ignition/injection	07.00-02.03	0 261 210 168
Pressure sensor, intake manifold, gasoline	07.00-02.03	0 261 230 029
4.0 i [BA]	4,0l 182 kW H	6 Zyl.
Knock sensor	07.03-02.05	0 261 231 045
Pressure sensor, intake manifold, gasoline	07.03-02.05	0 261 230 027 0 261 230 029
4.0 i [NL]	4,0l 162 kW X	6 Zyl.
Wheel speed sensor, front	09.96-02.99	0 265 006 230
4.1 i [ZL]	4,1l 120 kW T	6 Zyl.
Air flow sensor, gasoline injection	09.84-05.88	0 280 202 077 🔧 0 986 280 023
5.0 i [NL]	5,0l 165 kW Z	8 Zyl.
Wheel speed sensor, front	09.96-02.99	0 265 006 230
5.4 i [BA II]	5,4l 220 kW Z	8 Zyl.
Yaw rate sensor, brake system	03.05-09.05	0 265 005 236

Falcon		
4.1 i [XF]	4,1l 120 kW T	6 Zyl.
Air flow sensor, gasoline injection	09.84-10.87	0 280 202 077 🔧 0 986 280 023

Fiesta		
1.0 i	1,0l 48 kW C4E	4 Zyl.
Pressure sensor, intake manifold, gasoline	09.99-06.06	0 261 230 027
1.3 i	1,3l 51 kW JL474QA	4 Zyl.
Knock sensor	05.03-02.07	0 261 231 162
Pressure sensor, intake manifold, gasoline	05.03-02.07	0 261 230 027
1.3 i	1,3l 55 kW	4 Zyl.
Pressure sensor, intake manifold, gasoline	03.03-12.04	0 261 230 027
1.6 i	1,6l 68/70 kW ; JL482QA	4 Zyl.
Knock sensor	03.02→	0 261 231 162
Pressure sensor, intake manifold, gasoline	03.00→	0 261 230 027
1.6 i	1,6l 70 kW L1M	4 Zyl.
Pressure sensor, intake manifold, gasoline	09.99-04.05	0 261 230 027
1.6 i [New]	1,6l 72 kW CCJA	4 Zyl.
Pressure sensor, intake manifold, gasoline	05.02→	0 261 230 027

Fiesta II		
1.4 [84/87]	1,4l 51/54/55 kW FUB; FUBA; FUD	4 Zyl.
Knock sensor	08.83-02.89	0 261 231 006
1.4 i [84/87]	1,4l 52 kW F6...	4 Zyl.
Knock sensor	10.86-02.89	0 261 231 006
1.6 [84/87]	1,6l 58 kW LP3	4 Zyl.
Knock sensor	08.83-02.89	0 261 231 006
1.6 XR2 [84/87]	1,6l 70-71 kW LU...	4 Zyl.
Knock sensor	03.84-02.89	0 261 231 006

Fiesta III		
1.6 Turbo [89]	1,6l 96-98 kW LHA	4 Zyl.
Temperature sensor, coolant, injection system	07.90-12.96	0 280 130 049





Product				

Fiesta IV			
1.25 i 16V [96]	1,2 l	55 kW DH...	4 Zyl.
Pressure sensor, intake manifold, gasoline	08.98-12.99	0 261 230 027	
1.3 i [96]	1,3 l	37/44 kW JJ...; J4...	4 Zyl.
Pressure sensor, intake manifold, gasoline	08.98-12.02	0 261 230 027	

Fiesta IV Courier			
1.3 i [96]	1,3 l	44 kW J4...	4 Zyl.
Pressure sensor, intake manifold, gasoline	08.98-12.02	0 261 230 027	

Fiesta Sedan			
1.6 i	1,6 l	70 kW L1M	4 Zyl.
Pressure sensor, intake manifold, gasoline	10.01-08.04	0 261 230 027	

Fiesta V			
2.0 i ST150 [02]	2,0 l	110 kW N4JB	4 Zyl.
Pressure sensor, intake manifold, gasoline	11.04→	0 261 230 044	

Focus			
1.8 i	1,8 l	91 kW CAF483Q0	4 Zyl.
Pressure sensor, intake manifold, gasoline	09.05→	0 261 230 044	

Focus C-MAX			
1.6 Ti-VCT	1,6 l	85 kW HXDA	4 Zyl.
Phase sensor	07.04-03.07	NOC	0 232 103 052
1.8	1,8 l	88/90-92 kW CSDA; CSDB; Q...	4 Zyl.
Pressure sensor, intake manifold, gasoline	06.03-03.07	0 261 230 044	
1.8 FFV	1,8 l	92 kW Q7DA	4 Zyl.
Pressure sensor, intake manifold, gasoline	05.05-03.07	0 261 230 044	
1.8 TDCi	1,8 l	85 kW KKDA	4 Zyl.
Pressure sensor, intake manifold, diesel	04.05-03.07	0 261 230 119	
2.0	2,0 l	107 kW AOD...	4 Zyl.
Pressure sensor, intake manifold, gasoline	04.04-03.07	0 261 230 044	
2.0 CNG	2,0 l	93-107 kW	4 Zyl.
Pressure sensor, intake manifold, gasoline	11.05-03.07	0 261 230 044	

Focus II			
1.6 Ti-VCT	1,6 l	85 kW HXDA	4 Zyl.
Phase sensor	11.04→	NOC	0 232 103 052
1.8 FFV	1,8 l	92 kW Q...	4 Zyl.
Pressure sensor, intake manifold, gasoline	05.05→	0 261 230 044	
1.8 TDCi	1,8 l	85 kW KKDA	4 Zyl.
Pressure sensor, intake manifold, diesel	04.05→	0 261 230 119	
2.0 i	2,0 l	107 kW AOD...	4 Zyl.
Pressure sensor, intake manifold, gasoline	11.04→	0 261 230 044	
2.5 i ST	2,5 l	166 kW HYDA	5 Zyl.
Air mass meter, gasoline injection	10.05→	0 280 218 134	
Boost pressure sensor, gasoline	10.05→	0 261 230 090	

Focus II Cabriolet			
2.0 i	2,0 l	107 kW AOD...	4 Zyl.
Pressure sensor, intake manifold, gasoline	07.06→	0 261 230 044	

Product				

Focus II Turnier			
1.6 Ti-VCT	1,6 l	85 kW HXDA	4 Zyl.
Phase sensor	11.04→	NOC	0 232 103 052
1.8 FFV	1,8 l	92 kW Q...	4 Zyl.
Pressure sensor, intake manifold, gasoline	05.05→	0 261 230 044	
1.8 TDCi	1,8 l	85 kW KKDA	4 Zyl.
Pressure sensor, intake manifold, diesel	04.05→	0 261 230 119	
2.0 i	2,0 l	107 kW AOD...	4 Zyl.
Pressure sensor, intake manifold, gasoline	11.04→	0 261 230 044	

Galaxy			
1.8 TDCi [06]	1,8 l	74/92 kW FFWA; QYWA	4 Zyl.
Pressure sensor, intake manifold, diesel	03.06→	0 261 230 119	
1.9 TDI [00]	1,9 l	66/85 kW ANU; AUY	4 Zyl.
Air mass meter, diesel	04.00-08.06	0 281 002 757	
	WW	0 280 217 121	
		0 986 280 202	
1.9 TDI [00]	1,9 l	96/110 kW ASZ; BTB	4 Zyl.
Air mass meter, diesel	01.03-08.06	0 281 002 461	
		0 986 284 007	
1.9 TDI [95]	1,9 l	66 kW AHU	4 Zyl.
Air mass meter, diesel	09.97-03.00	0 281 002 757	
	WW	0 280 217 121	
		0 986 280 202	
Pedal position sensor, diesel	09.96-08.97	0 205 001 044	
1.9 TDI [95]	1,9 l	66 kW ANU	4 Zyl.
Air mass meter, diesel	09.99-03.00	0 281 002 757	
	WW	0 280 217 121	
		0 986 280 202	
1.9 TDI [95]	1,9 l	66 kW 1Z	4 Zyl.
Pedal position sensor, diesel	02.95-09.96	0 205 001 044	
1.9 TDI [95]	1,9 l	81 kW AFN; AVG	4 Zyl.
Air mass meter, diesel	11.97-03.00	0 281 002 757	
	WW	0 280 217 121	
		0 986 280 202	
2.0 [06]	2,0 l	107 kW AOWA	4 Zyl.
Pressure sensor, intake manifold, gasoline	03.06→	0 261 230 044	
2.8 i [00]	2,8 l	150 kW AYL	6 Zyl.
Phase sensor	04.00-08.06	NOC	0 232 103 019
2.8 i [95]	2,8 l	128 kW AAA; AMY	6 Zyl.
Air mass meter, gasoline injection	02.95-03.00	0 280 217 512	
		0 986 280 203	
Phase sensor	12.97-03.00	0 232 103 019	
2.8 i 4x4 [95]	2,8 l	128 kW AAA; AMY	6 Zyl.
Air mass meter, gasoline injection	07.96-03.00	0 280 217 512	
		0 986 280 203	
Phase sensor	12.97-03.00	0 232 103 019	

Granada III			
2.0 i [85]	2,0 l	85 kW NR...	4 Zyl.
Air flow sensor, gasoline injection	05.85-01.92	0 280 202 063	
2.4 i [85]	2,4 l	96 kW ARC	6 Zyl.
Air flow sensor, gasoline injection	09.86-08.89	0 280 200 047	
		0 986 280 056	
2.4 i [92]	2,4 l	92 kW ARD	6 Zyl.
Air flow sensor, gasoline injection	02.92-09.94	0 280 200 047	
		0 986 280 056	
2.8 i [85]	2,8 l	110 kW PRE	6 Zyl.
Air flow sensor, gasoline injection	05.85-08.87	0 280 200 044	



2.8 i 4x4 [85]			2,8 l 110 kW PRE 6 Zyl.
Air flow sensor, gasoline injection	08.86-08.87	0 280 200 047	0 986 280 056
Knock sensor	10.85-08.87	0 261 231 006	
2.9 i [85]			2,9 l 110 kW BRC 6 Zyl.
Air flow sensor, gasoline injection	09.86-01.92	0 280 200 047	0 986 280 056
2.9 i [92]			2,9 l 107 kW BRF 6 Zyl.
Air flow sensor, gasoline injection	02.92-09.94	0 280 200 047	0 986 280 056
2.9 i 4x4 [92]			2,9 l 107 kW BR... 6 Zyl.
Air flow sensor, gasoline injection	02.92-09.94	0 280 200 047	0 986 280 056

Granada III Estate			
2.4 i [92]			2,4 l 92 kW ARD 6 Zyl.
Air flow sensor, gasoline injection	02.92-09.94	0 280 200 047	0 986 280 056
2.9 i [92]			2,9 l 107 kW BRF 6 Zyl.
Air flow sensor, gasoline injection	02.92-09.94	0 280 200 047	0 986 280 056
2.9 i 4x4 [92]			2,9 l 107 kW BR... 6 Zyl.
Air flow sensor, gasoline injection	02.92-09.94	0 280 200 047	0 986 280 056

Ka			
1.0 i			1,0 l 48 kW C4C 4 Zyl.
Pressure sensor, intake manifold, gasoline	08.99-12.07	0 261 230 027	
1.3 i			1,3 l 36/37 kW JJB; JJD; JJF; JJG; JJH 4 Zyl.
Pressure sensor, intake manifold, gasoline	09.00-10.02	0 261 230 027	
1.3 i			1,3 l 36/44 kW JLL; J4D; J4K; J4M; J4N 4 Zyl.
Pressure sensor, intake manifold, gasoline	09.00-10.02	0 261 230 027	
1.3 i			1,3 l 44 kW J4P; J4S 4 Zyl.
Pressure sensor, intake manifold, gasoline	09.00-10.02	0 261 230 027	
1.3 i			1,3 l 51 kW 4 Zyl.
Knock sensor	10.05→	0 261 231 162	
1.6 i			1,6 l 70 kW CCA 4 Zyl.
Pressure sensor, intake manifold, gasoline	02.01-12.07	0 261 230 027	

LTD			
4.1 i [FE]			4,1 l 120 kW T 6 Zyl.
Air flow sensor, gasoline injection	09.84-05.88	0 280 202 077	0 986 280 023
5.0 i [DL]			5,0 l 165 kW Z 8 Zyl.
Wheel speed sensor, front	09.96-05.99	0 265 006 230	

Maverick			
2.0 i, i 4x4 [01]			2,0 l 91-95 kW YF 4 Zyl.
Knock sensor	10.00→	0 261 231 124	
2.3 i, i 4x4 [01]			2,3 l 112-116 kW GZ 4 Zyl.
Pressure sensor, intake manifold, gasoline	12.03→	0 261 230 180	

Merkur			
2.9 i			2,9 l 107 kW 6 Zyl.
Air flow sensor, gasoline injection	11.86-02.92	0 280 200 047	0 986 280 056



Mondeo			
2.0 i			2,0 l 105 kW J 4 Zyl.
Pressure sensor, intake manifold, gasoline	02.04→	0 261 230 068	
Yaw rate sensor, brake system	02.04→	0 265 005 236	
Wheel speed sensor, front	02.04→	0 265 007 879	
Wheel speed sensor, rear	02.04→	0 265 007 879	
2.0 i			2,0 l 107 kW CJBB Duratec-HE 4 Zyl.
Pressure sensor, intake manifold, gasoline	08.01→	0 261 230 044	
2.5 i			2,5 l 127 kW Duratec-V6 6 Zyl.
Yaw rate sensor, brake system	06.04→	0 265 005 236	
Wheel speed sensor, front	06.04→	0 265 007 879	
Wheel speed sensor, rear	06.04→	0 265 007 879	

Mondeo III			
1.8 i [01]			1,8 l 81/92 kW CGB...; CGBA; CGBB; CHB... 4 Zyl.
Pressure sensor, intake manifold, gasoline	10.00→	0 261 230 044	
Duo sensor, acceleration and yaw rate, brake system	10.00-08.04	0 265 005 236	
Steering angle sensor, ESP (electronic stability program)	09.04→	0 265 005 639	
Steering angle sensor, ESP (electronic stability program)	10.00→	0 265 005 414	
Pressure sensor, ESP, (electronic stability program)	10.00→	0 265 005 303	
Wheel speed sensor	10.00→	0 265 007 879	
1.8 i [01]			1,8 l 96 kW CFBA 4 Zyl.
Throttle valve assembly	06.03→	0 280 750 110	
Air mass meter, gasoline injection	06.03→	0 280 218 104	
Phase sensor	06.03→	NOC 0 232 103 040	
Knock sensor	06.03→	0 261 231 160	
Pressure sensor, intake manifold, gasoline	06.03→	0 261 230 068	
Duo sensor, acceleration and yaw rate, brake system	06.03-08.04	0 265 005 236	
Steering angle sensor, ESP (electronic stability program)	09.04→	0 265 005 639	
Steering angle sensor, ESP (electronic stability program)	06.03→	0 265 005 414	
Pressure sensor, ESP, (electronic stability program)	06.03→	0 265 005 303	
Wheel speed sensor	06.03→	0 265 007 879	
2.0 i [01]			2,0 l 107 kW CJB... 4 Zyl.
Pressure sensor, intake manifold, gasoline	10.00→	0 261 230 044	
Duo sensor, acceleration and yaw rate, brake system	10.00-08.04	0 265 005 236	
Steering angle sensor, ESP (electronic stability program)	09.04→	0 265 005 639	
Steering angle sensor, ESP (electronic stability program)	10.00→	0 265 005 414	
Pressure sensor, ESP, (electronic stability program)	10.00→	0 265 005 303	
Wheel speed sensor	10.00→	0 265 007 879	
2.0 TDCi [01]			2,0 l 66 kW SDDBA 4 Zyl.
Duo sensor, acceleration and yaw rate, brake system	04.06→	0 265 005 639	
Steering angle sensor, ESP (electronic stability program)	04.06→	0 265 005 414	
Pressure sensor, ESP, (electronic stability program)	04.06→	0 265 005 303	
Wheel speed sensor	04.06→	0 265 007 879	
2.0 TDCi [01]			2,0 l 85/96 kW FMBA; HJB...; HJBA; HJBB; HJBC 4 Zyl.
Duo sensor, acceleration and yaw rate, brake system	10.01-08.04	0 265 005 236	
Steering angle sensor, ESP (electronic stability program)	09.04→	0 265 005 639	
Steering angle sensor, ESP (electronic stability program)	10.01→	0 265 005 414	
Pressure sensor, ESP, (electronic stability program)	10.01→	0 265 005 303	
Wheel speed sensor	10.01→	0 265 007 879	
2.0 TDCi [01]			2,0 l 96 kW N7B... 4 Zyl.
Duo sensor, acceleration and yaw rate, brake system	10.01-08.04	0 265 005 236	
Steering angle sensor, ESP (electronic stability program)	09.04→	0 265 005 639	
Steering angle sensor, ESP (electronic stability program)	10.01→	0 265 005 414	



Product



◀ Mondeo III

Pressure sensor, ESP, (electronic stability program)	10.01→	0 265 005 303
Wheel speed sensor	10.01→	0 265 007 879
2.0 TDDi [01]	2,0l 66 kW D5BA 4 Zyl.	
Duo sensor, acceleration and yaw rate, brake system	10.00-08.04 09.04→	0 265 005 236 0 265 005 639
Steering angle sensor, ESP (electronic stability program)	10.00→	0 265 005 414
Pressure sensor, ESP, (electronic stability program)	10.00→	0 265 005 303
Wheel speed sensor	10.00→	0 265 007 879
2.0 TDDi [01]	2,0l 85 kW D6BA 4 Zyl.	
Duo sensor, acceleration and yaw rate, brake system	10.00-08.02	0 265 005 236
Steering angle sensor, ESP (electronic stability program)	10.00-08.02	0 265 005 414
Pressure sensor, ESP, (electronic stability program)	10.00-08.02	0 265 005 303
Wheel speed sensor	10.00-08.02	0 265 007 879
2.2 TDCi [01]	2,2l 114 kW QJB... 4 Zyl.	
Duo sensor, acceleration and yaw rate, brake system	08.04-08.04 09.04→	0 265 005 236 0 265 005 639
Steering angle sensor, ESP (electronic stability program)	08.04→	0 265 005 414
Pressure sensor, ESP, (electronic stability program)	08.04→	0 265 005 303
Wheel speed sensor	08.04→	0 265 007 879
2.5 i [01]	2,5l 125 kW LCBD 6 Zyl.	
Duo sensor, acceleration and yaw rate, brake system	10.00-08.04 09.04→	0 265 005 236 0 265 005 639
Steering angle sensor, ESP (electronic stability program)	10.00→	0 265 005 414
Pressure sensor, ESP, (electronic stability program)	10.00→	0 265 005 303
Wheel speed sensor	10.00→	0 265 007 879
3.0 i [01]	3,0l 150 kW REBA 6 Zyl.	
Duo sensor, acceleration and yaw rate, brake system	08.04-08.04 09.04→	0 265 005 236 0 265 005 639
Pressure sensor, ESP, (electronic stability program)	08.04→	0 265 005 303
Wheel speed sensor	08.04→	0 265 007 879
3.0 i ST220 [01]	3,0l 166 kW MEBA 6 Zyl.	
Duo sensor, acceleration and yaw rate, brake system	02.02-08.04 09.04→	0 265 005 236 0 265 005 639
Steering angle sensor, ESP (electronic stability program)	02.02→	0 265 005 414
Pressure sensor, ESP, (electronic stability program)	02.02→	0 265 005 303
Wheel speed sensor	02.02→	0 265 007 879

Mondeo III Turnier

1.8 i [01]	1,8l 81/92 kW CGBA; CGBB; CHBA; CHBB 4 Zyl.	
Pressure sensor, intake manifold, gasoline	10.00→	0 261 230 044
Duo sensor, acceleration and yaw rate, brake system	10.00-08.04 09.04→	0 265 005 236 0 265 005 639
Steering angle sensor, ESP (electronic stability program)	10.00→	0 265 005 414
Pressure sensor, ESP, (electronic stability program)	10.00→	0 265 005 303
Wheel speed sensor	10.00→	0 265 007 879
1.8 i [01]	1,8l 96 kW CFBA 4 Zyl.	
Throttle valve assembly	06.03→	0 280 750 110
Air mass meter, gasoline injection	06.03→	0 280 218 104
Phase sensor	06.03→ NOC	0 232 103 040
Knock sensor	06.03→	0 261 231 160
Pressure sensor, intake manifold, gasoline	06.03→	0 261 230 068
Duo sensor, acceleration and yaw rate, brake system	06.03-08.04 09.04→	0 265 005 236 0 265 005 639
Steering angle sensor, ESP (electronic stability program)	06.03→	0 265 005 414

Product



Pressure sensor, ESP, (electronic stability program)	06.03→	0 265 005 303
Wheel speed sensor	06.03→	0 265 007 879
2.0 i [01]	2,0l 107 kW CJBA; CJBB 4 Zyl.	
Pressure sensor, intake manifold, gasoline	10.00→	0 261 230 044
Duo sensor, acceleration and yaw rate, brake system	10.00-08.04 09.04→	0 265 005 236 0 265 005 639
Steering angle sensor, ESP (electronic stability program)	10.00→	0 265 005 414
Pressure sensor, ESP, (electronic stability program)	10.00→	0 265 005 303
Wheel speed sensor	10.00→	0 265 007 879
2.0 TDCi [01]	2,0l 66 kW SDBA 4 Zyl.	
Duo sensor, acceleration and yaw rate, brake system	04.06→	0 265 005 639
Steering angle sensor, ESP (electronic stability program)	04.06→	0 265 005 414
Pressure sensor, ESP, (electronic stability program)	04.06→	0 265 005 303
Wheel speed sensor	04.06→	0 265 007 879
2.0 TDCi [01]	2,0l 85/96 kW FMBA; HJBA; HJBB; HJBC; N7B... 4 Zyl.	
Duo sensor, acceleration and yaw rate, brake system	10.01-08.04 09.04→	0 265 005 236 0 265 005 639
Steering angle sensor, ESP (electronic stability program)	10.01→	0 265 005 414
Pressure sensor, ESP, (electronic stability program)	10.01→	0 265 005 303
Wheel speed sensor	10.01→	0 265 007 879
2.0 TDDi [01]	2,0l 66 kW D5BA 4 Zyl.	
Duo sensor, acceleration and yaw rate, brake system	10.00-08.04 09.04→	0 265 005 236 0 265 005 639
Steering angle sensor, ESP (electronic stability program)	10.00→	0 265 005 414
Pressure sensor, ESP, (electronic stability program)	10.00→	0 265 005 303
Wheel speed sensor	10.00→	0 265 007 879
2.0 TDDi [01]	2,0l 85 kW D6BA 4 Zyl.	
Duo sensor, acceleration and yaw rate, brake system	10.00-08.02	0 265 005 236
Steering angle sensor, ESP (electronic stability program)	10.00-08.02	0 265 005 414
Pressure sensor, ESP, (electronic stability program)	10.00-08.02	0 265 005 303
Wheel speed sensor	10.00-08.02	0 265 007 879
2.2 TDCi [01]	2,2l 114 kW QJB... 4 Zyl.	
Duo sensor, acceleration and yaw rate, brake system	08.04-08.04 09.04→	0 265 005 236 0 265 005 639
Steering angle sensor, ESP (electronic stability program)	08.04→	0 265 005 414
Pressure sensor, ESP, (electronic stability program)	08.04→	0 265 005 303
Wheel speed sensor	08.04→	0 265 007 879
2.5 i [01]	2,5l 125 kW LCBD 6 Zyl.	
Duo sensor, acceleration and yaw rate, brake system	10.00-08.04 09.04→	0 265 005 236 0 265 005 639
Steering angle sensor, ESP (electronic stability program)	10.00→	0 265 005 414
Pressure sensor, ESP, (electronic stability program)	10.00→	0 265 005 303
Wheel speed sensor	10.00→	0 265 007 879
3.0 i [01]	3,0l 150 kW REBA 6 Zyl.	
Duo sensor, acceleration and yaw rate, brake system	08.04-08.04 09.04→	0 265 005 236 0 265 005 639
Pressure sensor, ESP, (electronic stability program)	08.04→	0 265 005 303
Wheel speed sensor	08.04→	0 265 007 879
3.0 i ST220 [01]	3,0l 166 kW MEBA 6 Zyl.	
Duo sensor, acceleration and yaw rate, brake system	02.02-08.04 09.04→	0 265 005 236 0 265 005 639
Steering angle sensor, ESP (electronic stability program)	02.02→	0 265 005 414



Pressure sensor, ESP, (electronic stability program)	02.02→	0 265 005 303
Wheel speed sensor	02.02→	0 265 007 879

Mondeo IV		
1.6 Ti-VCT [07]		
1,6l 81/92 kW 4 Zyl.		
Phase sensor	02.07→	NOC 0 232 103 052
1.8 TDCi [07]		
1,8l 74 kW 4 Zyl.		
Pressure sensor, intake manifold, diesel	02.07→	0 261 230 119
2.0 [07]		
2,0l 107 kW 4 Zyl.		
Pressure sensor, intake manifold, gasoline	02.07→	0 261 230 044
2.5 [07]		
2,5l 162 kW 5 Zyl.		
Air mass meter, gasoline injection	02.07→	0 280 218 134
Temperature sensor, intake air, injection system	02.07→	0 261 230 105

Mondeo IV Turnier		
1.6 Ti-VCT [07]		
1,6l 81/92 kW 4 Zyl.		
Phase sensor	02.07→	NOC 0 232 103 052
1.8 TDCi [07]		
1,8l 74 kW 4 Zyl.		
Pressure sensor, intake manifold, diesel	02.07→	0 261 230 119
2.0 [07]		
2,0l 107 kW 4 Zyl.		
Pressure sensor, intake manifold, gasoline	02.07→	0 261 230 044
2.5 [07]		
2,5l 162 kW 5 Zyl.		
Air mass meter, gasoline injection	02.07→	0 280 218 134
Temperature sensor, intake air, injection system	02.07→	0 261 230 105

Orion II		
1.4 i [86]		
1,4l 54 kW F6... 4 Zyl.		
Knock sensor	10.87-07.90	0 261 231 006
1.6 i [86]		
1,6l 66 kW L4B 4 Zyl.		
Air flow sensor, gasoline injection	04.86-07.90	F 026 TX2 066 F 026 TX2 066
Knock sensor	04.86-07.90	0 261 231 006
Temperature sensor, coolant, injection system	04.86-07.90	0 280 130 050
1.6 i [86]		
1,6l 75 kW LJB 4 Zyl.		
Knock sensor	08.89-07.90	0 261 231 006
1.6 i [86]		
1,6l 77 kW LRB 4 Zyl.		
Air flow sensor, gasoline injection	04.86-07.90	0 438 120 199
Knock sensor	04.86-07.90	0 261 231 006
Relay, Jetronic	04.86-07.90	0 280 230 116
1.6 i [86]		
1,6l 79 kW LJA 4 Zyl.		
Knock sensor	08.89-07.90	0 261 231 006

Scorpio I		
1.8 [85]		
1,8l 66 kW REC 4 Zyl.		
Speed relay	09.87-01.92	0 280 230 117
Relay, Jetronic	02.88-01.92	0 280 230 117
2.0 i [85]		
2,0l 74 kW NRC 4 Zyl.		
Air flow sensor, gasoline injection	10.85-12.90	0 280 202 063
	CH,S 10.85-12.90	0 280 202 094
Knock sensor	10.85-12.90	0 261 231 006
2.0 i [85]		
2,0l 85 kW NRA 4 Zyl.		
Air flow sensor, gasoline injection	05.85-01.92	0 280 202 063
	CH,S 05.85-01.92	0 280 202 094
2.0 i [85]		
2,0l 85 kW NRI 4 Zyl.		
Air flow sensor, gasoline injection	10.85-01.92	0 280 202 063
	CH,S 10.85-01.92	0 280 202 094
Knock sensor	10.85-01.92	0 261 231 006



2.4 i [85]		
2,4l 92/96 kW ARC; ARD 6 Zyl.		
Air flow sensor, gasoline injection	09.86-01.92 ZE	0 280 200 047 0 986 280 056
2.4 i [92]		
2,4l 92 kW ARD 6 Zyl.		
Air flow sensor, gasoline injection	02.92-09.94	0 280 200 047 0 986 280 056
2.8 i [85]		
2,8l 105-107 kW PR... 6 Zyl.		
Air flow sensor, gasoline injection	10.85-12.88	0 280 200 047 0 986 280 056
2.8 i [85]		
2,8l 110 kW PRE 6 Zyl.		
Air flow sensor, gasoline injection	05.85-11.86	0 280 200 044
2.8 i 4x4 [85]		
2,8l 105-107 kW PR... 6 Zyl.		
Air flow sensor, gasoline injection	10.85-12.88	0 280 200 047 0 986 280 056
2.8 i 4x4 [85]		
2,8l 110 kW PRE 6 Zyl.		
Air flow sensor, gasoline injection	10.85-11.86	0 280 200 044
2.9 i [85]		
2,9l 107/110 kW BR...; BRC 6 Zyl.		
Air flow sensor, gasoline injection	09.86-01.92 ZE	0 280 200 047 0 986 280 056
2.9 i [92]		
2,9l 107 kW BRF 6 Zyl.		
Air flow sensor, gasoline injection	02.92-09.94	0 280 200 047 0 986 280 056
2.9 i 4x4 [85]		
2,9l 107/110 kW BRC; BRE 6 Zyl.		
Air flow sensor, gasoline injection	09.86-01.92 ZE	0 280 200 047 0 986 280 056
2.9 i 4x4 [92]		
2,9l 107 kW BRF 6 Zyl.		
Air flow sensor, gasoline injection	02.92-09.94	0 280 200 047 0 986 280 056

Scorpio I Turnier		
2.4 i [92]		
2,4l 92 kW ARD 6 Zyl.		
Air flow sensor, gasoline injection	02.92-09.94	0 280 200 047 0 986 280 056
2.9 i [92]		
2,9l 107 kW BRF 6 Zyl.		
Air flow sensor, gasoline injection	02.92-09.94	0 280 200 047 0 986 280 056

Scorpio II		
2.5 TD [95]		
2,5l 85 kW SCC 4 Zyl.		
Speed sensor, diesel	01.95-12.98	0 281 002 096
2.9 i [95]		
2,9l 110 kW BRG 6 Zyl.		
Air flow sensor, gasoline injection	10.94-08.96	0 280 200 047 0 986 280 056

Scorpio II Turnier		
2.5 TD [95]		
2,5l 85 kW SCC 4 Zyl.		
Speed sensor, diesel	01.95-12.98	0 281 002 096
2.9 i [95]		
2,9l 110 kW BRG 6 Zyl.		
Air flow sensor, gasoline injection	10.94-08.96	0 280 200 047 0 986 280 056

Sierra		
1.6 [87]		
1,6l 53/55 kW LSE; LSF 4 Zyl.		
Speed relay	01.87-02.93	0 280 230 118
1.8 [87]		
1,8l 59-66 kW RE... 4 Zyl.		
Speed relay	10.87-05.88	0 280 230 117
Relay, Jetronic	02.88-05.88	0 280 230 117





Product				

◀ Sierra

2.0i [82]		2,0l 74 kW NRD 4 Zyl.	
Air flow sensor, gasoline injection	CH,S	10.85-12.86	0 280 202 094
	CH,S	10.85-12.86	0 280 202 063
Knock sensor		10.85-12.86	0 261 231 006
2.0i [82]		2,0l 85 kW NRB 4 Zyl.	
Air flow sensor, gasoline injection	CH,S	03.85-12.86	0 280 202 094
	CH,S	03.85-12.86	0 280 202 063
2.0i [82]		2,0l 85 kW NR2 4 Zyl.	
Air flow sensor, gasoline injection	CH,S	10.85-12.86	0 280 202 094
	CH,S	10.85-12.86	0 280 202 063
Knock sensor		10.85-12.86	0 261 231 001
2.0i [87]		2,0l 74 kW N4B 4 Zyl.	
Air flow sensor, gasoline injection		01.87-02.93	0 280 202 063
	S	01.87-05.92	0 280 202 094
Knock sensor		01.87-02.93	0 261 231 001
2.0i [87]		2,0l 85 kW N4A; N4I 4 Zyl.	
Air flow sensor, gasoline injection		01.87-02.93	0 280 202 063
	S	01.87-05.92	0 280 202 094
2.8i [87]		2,8l 105 kW PR8 6 Zyl.	
Air flow sensor, gasoline injection	CH,S	01.87-12.88	0 280 200 047
			0 986 280 056
	CH,S	01.87-12.88	0 280 200 044
2.8i XR4 4x4 [87]		2,8l 105-107 kW PR... 6 Zyl.	
Air flow sensor, gasoline injection	CH,S	01.87-12.88	0 280 200 047
			0 986 280 056
	CH,S	01.87-12.88	0 280 200 044
2.8i XR4 4x4 [87]		2,8l 110 kW PRG 6 Zyl.	
Air flow sensor, gasoline injection		01.87-12.88	0 438 120 069
Relay, Jetronic		01.87-12.88	0 280 230 109
2.8i XR4, i XR4 4x4 [82]		2,8l 105-107/109-111 kW PR, PRI; PR5, PR6 6 Zyl.	
Air flow sensor, gasoline injection	CH,S	08.82-12.86	0 280 200 047
			0 986 280 056
	CH,S	08.82-12.86	0 280 200 044
2.8i XR4 4x4 [82]		2,8l 110 kW PRT 6 Zyl.	
Air flow sensor, gasoline injection		02.85-12.86	0 438 120 069
Relay, Jetronic		02.85-12.86	0 280 230 109
2.9i [87]		2,9l 107 kW B4... 6 Zyl.	
Air flow sensor, gasoline injection		08.88-02.93	0 280 200 047
			0 986 280 056
2.9i XR4 4x4 [87]		2,9l 107/110 kW B4...; B4A 6 Zyl.	
Air flow sensor, gasoline injection		08.88-02.93	0 280 200 047
			0 986 280 056

Sierra Turnier

1.6 [87]		1,6l 53/55 kW LSE; LSF 4 Zyl.	
Speed relay		01.87-02.93	0 280 230 118
1.8 [87]		1,8l 59 kW REF 4 Zyl.	
Speed relay		10.87-05.88	0 280 230 117
2.0i [82]		2,0l 74/85 kW NRB; NRD 4 Zyl.	
Air flow sensor, gasoline injection	CH,S	03.85-12.86	0 280 202 094
	CH,S	03.85-12.86	0 280 202 063
2.0i [82]		2,0l 85 kW NR2 4 Zyl.	
Air flow sensor, gasoline injection	CH,S	10.85-12.86	0 280 202 094
	CH,S	10.85-12.86	0 280 202 063
Knock sensor		10.85-12.86	0 261 231 001
2.0i [87]		2,0l 74 kW N4B 4 Zyl.	
Air flow sensor, gasoline injection		01.87-02.93	0 280 202 063
	S	01.87-02.92	0 280 202 094
Knock sensor		01.87-02.93	0 261 231 001
2.0i [87]		2,0l 85 kW N4A; N4I 4 Zyl.	
Air flow sensor, gasoline injection		01.87-02.93	0 280 202 063
	S	01.87-02.92	0 280 202 094

Product				

2.8i XR4 [82]		2,8l 105-107/109-111 kW PR, PRI; PR5, PR6 6 Zyl.	
Air flow sensor, gasoline injection	CH,S	08.82-12.86	0 280 200 047
			0 986 280 056
	CH,S	08.82-12.86	0 280 200 044
2.8i XR4 4x4 [82]		2,8l 110 kW PRT 6 Zyl.	
Air flow sensor, gasoline injection		03.85-12.86	0 438 120 069
Relay, Jetronic		03.85-12.86	0 280 230 109
2.8i 4x4 [87]		2,8l 105-107 kW PR7 6 Zyl.	
Air flow sensor, gasoline injection	CH,S	01.87-12.88	0 280 200 047
			0 986 280 056
	CH,S	01.87-12.88	0 280 200 044
2.8i 4x4 [87]		2,8l 110 kW PRG 6 Zyl.	
Air flow sensor, gasoline injection		01.87-12.88	0 438 120 069
Relay, Jetronic		01.87-12.88	0 280 230 109
2.9i [87]		2,9l 107 kW B4... 6 Zyl.	
Air flow sensor, gasoline injection		08.88-02.93	0 280 200 047
			0 986 280 056
2.9i 4x4 [87]		2,9l 107/110 kW B4...; B4A 6 Zyl.	
Air flow sensor, gasoline injection		08.88-02.93	0 280 200 047
			0 986 280 056

S-MAX

1.8 TDCi		1,8l 92 kW QYWA 4 Zyl.	
Pressure sensor, intake manifold, diesel		03.06→	0 261 230 119
2.0		2,0l 107 kW AOWA 4 Zyl.	
Pressure sensor, intake manifold, gasoline		03.06→	0 261 230 044
2.5		2,5l 162 kW HUWA 5 Zyl.	
Air mass meter, gasoline injection		03.06→	0 280 218 134
Temperature sensor, intake air, injection system		03.06→	0 261 230 105

Transit

FT 240 K/S 2.0 TD [F...]		2,0l 55 kW D3FA 4 Zyl.	
Wheel speed sensor, front		08.00-07.06	TW 0 265 006 458
		07.03-07.06	TW 0 265 006 784
Wheel speed sensor, rear		08.00-05.04	LAB,TW 0 265 006 542
		07.03-07.06	LAB,TW 0 265 006 784
		05.04-07.06	LAB,TW 0 265 006 816
		08.00-05.04	LAB,TW 0 265 006 818
		11.03-05.04	RAB,TW 0 265 006 460
		05.04-07.06	RAB,TW 0 265 006 811
		08.00-07.06	RAB,TW 0 265 006 815
			0 265 006 817
FT 240 K/S 2.0 TDE [F...]		2,0l 63 kW F3FA 4 Zyl.	
Wheel speed sensor, front		08.00-07.06	TW 0 265 006 458
		07.03-07.06	TW 0 265 006 784
Wheel speed sensor, rear		08.00-05.04	LAB,TW 0 265 006 542
		07.03-07.06	LAB,TW 0 265 006 784
		05.04-07.06	LAB,TW 0 265 006 816
		08.00-05.04	LAB,TW 0 265 006 818
		11.03-05.04	RAB,TW 0 265 006 460
		05.04-07.06	RAB,TW 0 265 006 811
		08.00-07.06	RAB,TW 0 265 006 815
			0 265 006 817
FT 260 K/S 2.0 TD [F...]		2,0l 55 kW D3FA 4 Zyl.	
Wheel speed sensor, front		08.00-07.06	TW 0 265 006 458
		07.03-07.06	TW 0 265 006 784
Wheel speed sensor, rear		08.00-05.04	LAB,TW 0 265 006 542
		07.03-07.06	LAB,TW 0 265 006 784
		05.04-07.06	LAB,TW 0 265 006 816
		08.00-05.04	LAB,TW 0 265 006 818
		11.03-05.04	RAB,TW 0 265 006 460

Product				
Wheel speed sensor, rear	05.04-07.06	RAB,TW	0 265 006 811	
	08.00-07.06	RAB,TW	0 265 006 815	
			0 265 006 817	
FT 260 K/S 2.0 TDCi [F__]		2,0l 92 kW F1FA 4 Zyl.		
Wheel speed sensor, front	05.02-07.06	TW	0 265 006 458	
	07.03-07.06	TW	0 265 006 784	
Wheel speed sensor, rear	05.02-05.04	LAB,TW	0 265 006 542	
	07.03-07.06	LAB,TW	0 265 006 784	
	05.04-07.06	LAB,TW	0 265 006 816	
	05.02-05.04	LAB,TW	0 265 006 818	
	11.03-05.04	RAB,TW	0 265 006 460	
	05.04-07.06	RAB,TW	0 265 006 811	
	05.02-07.06	RAB,TW	0 265 006 815	
			0 265 006 817	
FT 260 K/S 2.0 TDE [F__]		2,0l 63/74 kW ABFA; F3FA 4 Zyl.		
Wheel speed sensor, front	08.00-07.06	TW	0 265 006 458	
	07.03-07.06	TW	0 265 006 784	
Wheel speed sensor, rear	08.00-05.04	LAB,TW	0 265 006 542	
	07.03-07.06	LAB,TW	0 265 006 784	
	05.04-07.06	LAB,TW	0 265 006 816	
	08.00-05.04	LAB,TW	0 265 006 818	
	11.03-05.04	RAB,TW	0 265 006 460	
	05.04-07.06	RAB,TW	0 265 006 811	
	08.00-07.06	RAB,TW	0 265 006 815	
			0 265 006 817	
FT 260 K/S 2.3i [F__]		2,3l 103-107 kW E5FC 4 Zyl.		
Wheel speed sensor, front	08.01-07.06		0 265 006 458	
Wheel speed sensor, rear	08.01-07.06	LAB,TW	0 265 006 461	
	12.02-07.06	LAB,TW	0 265 006 812	
	08.01-07.06	LAB,TW	0 265 006 814	
		RAB,TW	0 265 006 460	
	03.04-07.06	RAB,TW	0 265 006 811	
	08.01-07.06	RAB,TW	0 265 006 813	
FT 260 K/S 2.4 TDE [F__]		2,4l 66 kW D2F... 4 Zyl.		
Wheel speed sensor, front	04.01-07.06		0 265 006 458	
Wheel speed sensor, rear	04.01-07.06	LAB,TW	0 265 006 461	
	12.02-07.06	LAB,TW	0 265 006 812	
	04.01-07.06	LAB,TW	0 265 006 814	
		RAB,TW	0 265 006 460	
	03.04-07.06	RAB,TW	0 265 006 811	
	04.01-07.06	RAB,TW	0 265 006 813	
FT 280 K/S 2.0 TD [F__]		2,0l 55 kW D3FA 4 Zyl.		
Wheel speed sensor, front	08.00-07.06	TW	0 265 006 458	
	07.03-07.06	TW	0 265 006 784	
Wheel speed sensor, rear	08.00-05.04	LAB,TW	0 265 006 542	
	07.03-07.06	LAB,TW	0 265 006 784	
	05.04-07.06	LAB,TW	0 265 006 816	
	08.00-05.04	LAB,TW	0 265 006 818	
	11.03-05.04	RAB,TW	0 265 006 460	
	05.04-07.06	RAB,TW	0 265 006 811	
	08.00-07.06	RAB,TW	0 265 006 815	
			0 265 006 817	
FT 280 K/S 2.0 TDCi [F__]		2,0l 92 kW F1FA 4 Zyl.		
Wheel speed sensor, front	05.02-07.06	TW	0 265 006 458	
	07.03-07.06	TW	0 265 006 784	
Wheel speed sensor, rear	05.02-05.04	LAB,TW	0 265 006 542	
	07.03-07.06	LAB,TW	0 265 006 784	
	05.04-07.06	LAB,TW	0 265 006 816	
	05.02-05.04	LAB,TW	0 265 006 818	
	11.03-05.04	RAB,TW	0 265 006 460	
	05.04-07.06	RAB,TW	0 265 006 811	
	05.02-07.06	RAB,TW	0 265 006 815	
			0 265 006 817	

Product				
FT 280 K/S 2.0 TDE [F__]	2,0l 63/74 kW ABFA; F3FA 4 Zyl.			
Wheel speed sensor, front	08.00-07.06	TW	0 265 006 458	
	07.03-07.06	TW	0 265 006 784	
Wheel speed sensor, rear	08.00-05.04	LAB,TW	0 265 006 542	
	07.03-07.06	LAB,TW	0 265 006 784	
	05.04-07.06	LAB,TW	0 265 006 816	
	08.00-05.04	LAB,TW	0 265 006 818	
	11.03-05.04	RAB,TW	0 265 006 460	
	05.04-07.06	RAB,TW	0 265 006 811	
	08.00-07.06	RAB,TW	0 265 006 815	
			0 265 006 817	
FT 280 K/S 2.3i [F__]	2,3l 103-107 kW E5FC 4 Zyl.			
Wheel speed sensor, front	08.01-07.06		0 265 006 458	
Wheel speed sensor, rear	08.01-07.06	LAB,TW	0 265 006 461	
	12.02-07.06	LAB,TW	0 265 006 812	
	08.01-07.06	LAB,TW	0 265 006 814	
		RAB,TW	0 265 006 460	
	03.04-07.06	RAB,TW	0 265 006 811	
	08.01-07.06	RAB,TW	0 265 006 813	
FT 280 K/S 2.4 TDE [F__]	2,4l 66 kW D2F... 4 Zyl.			
Wheel speed sensor, front	04.01-07.06		0 265 006 458	
Wheel speed sensor, rear	04.01-07.06	LAB,TW	0 265 006 461	
	12.02-07.06	LAB,TW	0 265 006 812	
	04.01-07.06	LAB,TW	0 265 006 814	
		RAB,TW	0 265 006 460	
	03.04-07.06	RAB,TW	0 265 006 811	
	04.01-07.06	RAB,TW	0 265 006 813	
FT 280 L 2.3i [F__]	2,3l 103-107 kW E5FC 4 Zyl.			
Wheel speed sensor, front	08.01-07.06		0 265 006 458	
Wheel speed sensor, rear	08.01-07.06	LAB,TW	0 265 006 461	
	12.02-07.06	LAB,TW	0 265 006 812	
	08.01-07.06	LAB,TW	0 265 006 814	
		RAB,TW	0 265 006 460	
	03.04-07.06	RAB,TW	0 265 006 811	
	08.01-07.06	RAB,TW	0 265 006 813	
FT 280 L 2.4 TDE [F__]	2,4l 55 kW F4FA 4 Zyl.			
Wheel speed sensor, front	01.00-09.03		0 265 006 458	
Wheel speed sensor, rear	01.00-09.03	LAB,TW	0 265 006 461	
	12.02-09.03	LAB,TW	0 265 006 812	
	01.00-09.03	LAB,TW	0 265 006 814	
		RAB,TW	0 265 006 460	
			0 265 006 813	
FT 280 L 2.4 TDE [F__]	2,4l 66/85/92 kW	DOFA; D2F...; FXFA	4 Zyl.	
Wheel speed sensor, front	01.00-07.06		0 265 006 458	
Wheel speed sensor, rear	01.00-07.06	LAB,TW	0 265 006 461	
	12.02-07.06	LAB,TW	0 265 006 812	
	01.00-07.06	LAB,TW	0 265 006 814	
		RAB,TW	0 265 006 460	
	03.04-07.06	RAB,TW	0 265 006 811	
	01.00-07.06	RAB,TW	0 265 006 813	
FT 280 M 2.0 TD [F__]	2,0l 55 kW D3FA 4 Zyl.			
Wheel speed sensor, front	08.00-07.06	TW	0 265 006 458	
	07.03-07.06	TW	0 265 006 784	
Wheel speed sensor, rear	08.00-05.04	LAB,TW	0 265 006 542	
	07.03-07.06	LAB,TW	0 265 006 784	
	05.04-07.06	LAB,TW	0 265 006 816	
	08.00-05.04	LAB,TW	0 265 006 818	
	11.03-05.04	RAB,TW	0 265 006 460	
	05.04-07.06	RAB,TW	0 265 006 811	
	08.00-07.06	RAB,TW	0 265 006 815	
			0 265 006 817	





Product



◀ Transit

FT 280 M 2.0 TDCi [F__]		2,0l 92 kW FIFA 4 Zyl.	
Wheel speed sensor, front	05.02-07.06	TW	0 265 006 458
	07.03-07.06	TW	0 265 006 784
Wheel speed sensor, rear	05.02-05.04	LAB,TW	0 265 006 542
	07.03-07.06	LAB,TW	0 265 006 784
	05.04-07.06	LAB,TW	0 265 006 816
	05.02-05.04	LAB,TW	0 265 006 818
	11.03-05.04	RAB,TW	0 265 006 460
	05.04-07.06	RAB,TW	0 265 006 811
	05.02-07.06	RAB,TW	0 265 006 815
			0 265 006 817

FT 280 M 2.0 TDE [F__]		2,0l 63/74 kW ABFA; F3FA 4 Zyl.	
Wheel speed sensor, front	08.00-07.06	TW	0 265 006 458
	07.03-07.06	TW	0 265 006 784
Wheel speed sensor, rear	08.00-05.04	LAB,TW	0 265 006 542
	07.03-07.06	LAB,TW	0 265 006 784
	05.04-07.06	LAB,TW	0 265 006 816
	08.00-05.04	LAB,TW	0 265 006 818
	11.03-05.04	RAB,TW	0 265 006 460
	05.04-07.06	RAB,TW	0 265 006 811
	08.00-07.06	RAB,TW	0 265 006 815
			0 265 006 817

FT 280 M 2.3i [F__]		2,3l 103-107 kW E5FC 4 Zyl.	
Wheel speed sensor, front	08.01-07.06		0 265 006 458
Wheel speed sensor, rear	08.01-07.06	LAB,TW	0 265 006 461
	12.02-07.06	LAB,TW	0 265 006 812
	08.01-07.06	LAB,TW	0 265 006 814
		RAB,TW	0 265 006 460
	03.04-07.06	RAB,TW	0 265 006 811
	08.01-07.06	RAB,TW	0 265 006 813

FT 280 M 2.4 TDE [F__]		2,4l 66 kW D2F... 4 Zyl.	
Wheel speed sensor, front	04.01-07.06		0 265 006 458
Wheel speed sensor, rear	04.01-07.06	LAB,TW	0 265 006 461
	12.02-07.06	LAB,TW	0 265 006 812
	04.01-07.06	LAB,TW	0 265 006 814
		RAB,TW	0 265 006 460
	03.04-07.06	RAB,TW	0 265 006 811
	04.01-07.06	RAB,TW	0 265 006 813

FT 280 S 2.4 TDI		2,4l 66 kW 4 Zyl.	
Wheel speed sensor, front	01.01-05.06		0 265 006 458
Wheel speed sensor, rear	01.01-09.03	LAB,OZB	0 265 006 461
	10.03-05.06	LAB,OZB	0 265 006 812
	01.01-05.06	LAB,ZWB	0 265 006 814
	01.01-09.03	OZB,RAB	0 265 006 460
	10.03-05.06	OZB,RAB	0 265 006 811
	01.01-05.06	RAB,ZWB	0 265 006 813

FT 300 K/S 2.0 TD [F__]		2,0l 55 kW D3FA 4 Zyl.	
Wheel speed sensor, front	08.00-07.06	TW	0 265 006 458
	07.03-07.06	TW	0 265 006 784
Wheel speed sensor, rear	08.00-05.04	LAB,TW	0 265 006 542
	07.03-07.06	LAB,TW	0 265 006 784
	05.04-07.06	LAB,TW	0 265 006 816
	08.00-05.04	LAB,TW	0 265 006 818
	11.03-05.04	RAB,TW	0 265 006 460
	05.04-07.06	RAB,TW	0 265 006 811
	08.00-07.06	RAB,TW	0 265 006 815
			0 265 006 817

Product



FT 300 K/S 2.0 TDCi [F__]		2,0l 92 kW FIFA 4 Zyl.	
Wheel speed sensor, front	05.02-07.06	TW	0 265 006 458
	07.03-07.06	TW	0 265 006 784
Wheel speed sensor, rear	05.02-05.04	LAB,TW	0 265 006 542
	07.03-07.06	LAB,TW	0 265 006 784
	05.04-07.06	LAB,TW	0 265 006 816
	05.02-05.04	LAB,TW	0 265 006 818
	11.03-05.04	RAB,TW	0 265 006 460
	05.04-07.06	RAB,TW	0 265 006 811
	05.02-07.06	RAB,TW	0 265 006 815
			0 265 006 817

FT 300 K/S 2.0 TDE [F__]		2,0l 63/74 kW ABFA; F3FA 4 Zyl.	
Wheel speed sensor, front	08.00-07.06	TW	0 265 006 458
	07.03-07.06	TW	0 265 006 784
Wheel speed sensor, rear	08.00-05.04	LAB,TW	0 265 006 542
	07.03-07.06	LAB,TW	0 265 006 784
	05.04-07.06	LAB,TW	0 265 006 816
	08.00-05.04	LAB,TW	0 265 006 818
	11.03-05.04	RAB,TW	0 265 006 460
	05.04-07.06	RAB,TW	0 265 006 811
	08.00-07.06	RAB,TW	0 265 006 815
			0 265 006 817

FT 300 K/S 2.3i [F__]		2,3l 107 kW E5FA 4 Zyl.	
Wheel speed sensor, front	08.00-07.06		0 265 006 458
Wheel speed sensor, rear	08.00-07.06	LAB,TW	0 265 006 461
	12.02-07.06	LAB,TW	0 265 006 812
	08.00-07.06	LAB,TW	0 265 006 814
		RAB,TW	0 265 006 460
	03.04-07.06	RAB,TW	0 265 006 811
	08.00-07.06	RAB,TW	0 265 006 813

FT 300 L 2.0 TD [F__]		2,0l 55 kW D3FA 4 Zyl.	
Wheel speed sensor, front	08.00-07.06	TW	0 265 006 458
	07.03-07.06	TW	0 265 006 784
Wheel speed sensor, rear	08.00-05.04	LAB,TW	0 265 006 542
	07.03-07.06	LAB,TW	0 265 006 784
	05.04-07.06	LAB,TW	0 265 006 816
	08.00-05.04	LAB,TW	0 265 006 818
	11.03-05.04	RAB,TW	0 265 006 460
	05.04-07.06	RAB,TW	0 265 006 811
	08.00-07.06	RAB,TW	0 265 006 815
			0 265 006 817

FT 300 L 2.0 TDCi [F__]		2,0l 92 kW FIFA 4 Zyl.	
Wheel speed sensor, front	05.02-07.06	TW	0 265 006 458
	07.03-07.06	TW	0 265 006 784
Wheel speed sensor, rear	05.02-05.04	LAB,TW	0 265 006 542
	07.03-07.06	LAB,TW	0 265 006 784
	05.04-07.06	LAB,TW	0 265 006 816
	05.02-05.04	LAB,TW	0 265 006 818
	11.03-05.04	RAB,TW	0 265 006 460
	05.04-07.06	RAB,TW	0 265 006 811
	05.02-07.06	RAB,TW	0 265 006 815
			0 265 006 817

FT 300 L 2.0 TDE [F__]		2,0l 63/74 kW ABFA; F3FA 4 Zyl.	
Wheel speed sensor, front	08.00-07.06	TW	0 265 006 458
	07.03-07.06	TW	0 265 006 784
Wheel speed sensor, rear	08.00-05.04	LAB,TW	0 265 006 542
	07.03-07.06	LAB,TW	0 265 006 784
	05.04-07.06	LAB,TW	0 265 006 816
	08.00-05.04	LAB,TW	0 265 006 818
	11.03-05.04	RAB,TW	0 265 006 460
	05.04-07.06	RAB,TW	0 265 006 811
	08.00-07.06	RAB,TW	0 265 006 815
			0 265 006 817

Product				
FT 300 L 2.3i [F__] 2,3l 107 kW E5FA 4 Zyl.				
Wheel speed sensor, front	08.00-07.06			0 265 006 458
Wheel speed sensor, rear	08.00-07.06	LAB,TW		0 265 006 461
	12.02-07.06	LAB,TW		0 265 006 812
	08.00-07.06	LAB,TW		0 265 006 814
		RAB,TW		0 265 006 460
	03.04-07.06	RAB,TW		0 265 006 811
	08.00-07.06	RAB,TW		0 265 006 813
FT 300 M 2.0 TD [F__] 2,0l 55 kW D3FA 4 Zyl.				
Wheel speed sensor, front	08.00-07.06	TW		0 265 006 458
	07.03-07.06	TW		0 265 006 784
Wheel speed sensor, rear	08.00-05.04	LAB,TW		0 265 006 542
	07.03-07.06	LAB,TW		0 265 006 784
	05.04-07.06	LAB,TW		0 265 006 816
	08.00-05.04	LAB,TW		0 265 006 818
	11.03-05.04	RAB,TW		0 265 006 460
	05.04-07.06	RAB,TW		0 265 006 811
	08.00-07.06	RAB,TW		0 265 006 815
				0 265 006 817
FT 300 M 2.0 TDCi [F__] 2,0l 92 kW FIFA 4 Zyl.				
Wheel speed sensor, front	05.02-07.06	TW		0 265 006 458
	07.03-07.06	TW		0 265 006 784
Wheel speed sensor, rear	05.02-05.04	LAB,TW		0 265 006 542
	07.03-07.06	LAB,TW		0 265 006 784
	05.04-07.06	LAB,TW		0 265 006 816
	05.02-05.04	LAB,TW		0 265 006 818
	11.03-05.04	RAB,TW		0 265 006 460
	05.04-07.06	RAB,TW		0 265 006 811
	05.02-07.06	RAB,TW		0 265 006 815
				0 265 006 817
FT 300 M 2.0 TDE [F__] 2,0l 63/74 kW ABFA; F3FA 4 Zyl.				
Wheel speed sensor, front	08.00-07.06	TW		0 265 006 458
	07.03-07.06	TW		0 265 006 784
Wheel speed sensor, rear	08.00-05.04	LAB,TW		0 265 006 542
	07.03-07.06	LAB,TW		0 265 006 784
	05.04-07.06	LAB,TW		0 265 006 816
	08.00-05.04	LAB,TW		0 265 006 818
	11.03-05.04	RAB,TW		0 265 006 460
	05.04-07.06	RAB,TW		0 265 006 811
	08.00-07.06	RAB,TW		0 265 006 815
				0 265 006 817
FT 300 M 2.3i [F__] 2,3l 107 kW E5FA 4 Zyl.				
Wheel speed sensor, front	08.00-07.06			0 265 006 458
Wheel speed sensor, rear	08.00-07.06	LAB,TW		0 265 006 461
	12.02-07.06	LAB,TW		0 265 006 812
	08.00-07.06	LAB,TW		0 265 006 814
		RAB,TW		0 265 006 460
	03.04-07.06	RAB,TW		0 265 006 811
	08.00-07.06	RAB,TW		0 265 006 813
FT 300 S 2.0 TDCi 2,0l 92 kW FIFA 4 Zyl.				
Wheel speed sensor, front	05.02-05.06	TW		0 265 006 458
				0 265 006 784
Wheel speed sensor, rear	05.02-05.04	LAB,TW		0 265 006 542
	07.03-05.06	LAB,TW		0 265 006 784
	05.04-05.06	LAB,TW		0 265 006 816
	05.02-05.04	LAB,TW		0 265 006 818
	05.02-05.06	RAB,TW		0 265 006 815
				0 265 006 817

Product				
FT 300 S 2.4 TDI 2,4l 66/74 kW 4 Zyl.				
Wheel speed sensor, front	01.01-05.06			0 265 006 458
Wheel speed sensor, rear	01.01-09.03	LAB,OZB		0 265 006 461
	10.03-05.06	LAB,OZB		0 265 006 812
	01.01-05.06	LAB,ZWB		0 265 006 814
	01.01-09.03	OZB,RAB		0 265 006 460
	10.03-05.06	OZB,RAB		0 265 006 811
	01.01-05.06	RAB,ZWB		0 265 006 813
FT 310 S 2.4 TDI 2,4l 88 kW 4 Zyl.				
Wheel speed sensor, front	01.01-05.06			0 265 006 458
Wheel speed sensor, rear	01.01-09.03	LAB,OZB		0 265 006 461
	10.03-05.06	LAB,OZB		0 265 006 812
	01.01-05.06	LAB,ZWB		0 265 006 814
	01.01-09.03	OZB,RAB		0 265 006 460
	10.03-05.06	OZB,RAB		0 265 006 811
	01.01-05.06	RAB,ZWB		0 265 006 813
FT 330 K/S 2.0 TDCi [F__] 2,0l 92 kW FIFA 4 Zyl.				
Wheel speed sensor, front	05.02-07.06	TW		0 265 006 458
	07.03-07.06	TW		0 265 006 784
Wheel speed sensor, rear	05.02-05.04	LAB,TW		0 265 006 542
	07.03-07.06	LAB,TW		0 265 006 784
	05.04-07.06	LAB,TW		0 265 006 816
	05.02-05.04	LAB,TW		0 265 006 818
	11.03-05.04	RAB,TW		0 265 006 460
	05.04-07.06	RAB,TW		0 265 006 811
	05.02-07.06	RAB,TW		0 265 006 815
				0 265 006 817
FT 330 K/S 2.0 TDE [F__] 2,0l 74 kW ABFA 4 Zyl.				
Wheel speed sensor, front	08.03-07.06	TW		0 265 006 458
				0 265 006 784
Wheel speed sensor, rear	08.03-05.04	LAB,TW		0 265 006 542
	08.03-07.06	LAB,TW		0 265 006 784
	05.04-07.06	LAB,TW		0 265 006 816
	08.03-05.04	LAB,TW		0 265 006 818
	11.03-05.04	RAB,TW		0 265 006 460
	05.04-07.06	RAB,TW		0 265 006 811
	08.03-07.06	RAB,TW		0 265 006 815
				0 265 006 817
FT 330 K/S 2.3i [F__] 2,3l 103-107 kW E5FA; E5FC 4 Zyl.				
Wheel speed sensor, front	12.00-07.06			0 265 006 458
Wheel speed sensor, rear	12.00-07.06	LAB,TW		0 265 006 461
	12.02-07.06	LAB,TW		0 265 006 812
	12.00-07.06	LAB,TW		0 265 006 814
		RAB,TW		0 265 006 460
	03.04-07.06	RAB,TW		0 265 006 811
	12.00-07.06	RAB,TW		0 265 006 813
FT 330 K/S 2.4 TD [F__] 2,4l 55 kW F4FA 4 Zyl.				
Wheel speed sensor, front	01.00-09.03			0 265 006 458
Wheel speed sensor, rear	01.00-09.03	LAB,TW		0 265 006 461
	12.02-09.03	LAB,TW		0 265 006 812
	01.00-09.03	LAB,TW		0 265 006 814
		RAB,TW		0 265 006 460
				0 265 006 813
FT 330 K/S 2.4 TDCi [F__] 2,4l 101 kW H9FA 4 Zyl.				
Wheel speed sensor, front	03.04-07.06			0 265 006 458
Wheel speed sensor, rear	03.04-07.06	LAB,TW		0 265 006 461
				0 265 006 812
				0 265 006 814
		RAB,TW		0 265 006 460
				0 265 006 811
				0 265 006 813





Product



◀ Transit

FT 330 K/S 2.4 TDE [F__]			2,4l 66/85/88/92 kW DOFA; D2F...; D4FA; FXFA 4 Zyl.
Wheel speed sensor, front	01.00-07.06		0 265 006 458
Wheel speed sensor, rear	01.00-07.06	LAB,TW	0 265 006 461
	12.02-07.06	LAB,TW	0 265 006 812
	01.00-07.06	LAB,TW	0 265 006 814
		RAB,TW	0 265 006 460
	03.04-07.06	RAB,TW	0 265 006 811
	01.00-07.06	RAB,TW	0 265 006 813
FT 330 L 2.0 TDCi [F__]			2,0l 92 kW FIFA 4 Zyl.
Wheel speed sensor, front	05.02-07.06	TW	0 265 006 458
	07.03-07.06	TW	0 265 006 784
Wheel speed sensor, rear	05.02-05.04	LAB,TW	0 265 006 542
	07.03-07.06	LAB,TW	0 265 006 784
	05.04-07.06	LAB,TW	0 265 006 816
	05.02-05.04	LAB,TW	0 265 006 818
	11.03-05.04	RAB,TW	0 265 006 460
	05.04-07.06	RAB,TW	0 265 006 811
	05.02-07.06	RAB,TW	0 265 006 815
			0 265 006 817
FT 330 L 2.0 TDE [F__]			2,0l 74 kW ABFA 4 Zyl.
Wheel speed sensor, front	08.03-07.06	TW	0 265 006 458
			0 265 006 784
Wheel speed sensor, rear	08.03-05.04	LAB,TW	0 265 006 542
	08.03-07.06	LAB,TW	0 265 006 784
	05.04-07.06	LAB,TW	0 265 006 816
	08.03-05.04	LAB,TW	0 265 006 818
	11.03-05.04	RAB,TW	0 265 006 460
	05.04-07.06	RAB,TW	0 265 006 811
	08.03-07.06	RAB,TW	0 265 006 815
			0 265 006 817
FT 330 L 2.3i [F__]			2,3l 103-107 kW E5FA; E5FC 4 Zyl.
Wheel speed sensor, front	12.00-07.06		0 265 006 458
Wheel speed sensor, rear	12.00-07.06	LAB,TW	0 265 006 461
	12.02-07.06	LAB,TW	0 265 006 812
	12.00-07.06	LAB,TW	0 265 006 814
		RAB,TW	0 265 006 460
	03.04-07.06	RAB,TW	0 265 006 811
	12.00-07.06	RAB,TW	0 265 006 813
FT 330 L 2.4 TD [F__]			2,4l 55 kW F4FA 4 Zyl.
Wheel speed sensor, front	01.00-09.03		0 265 006 458
Wheel speed sensor, rear	01.00-09.03	LAB,TW	0 265 006 461
	12.02-09.03	LAB,TW	0 265 006 812
	01.00-09.03	LAB,TW	0 265 006 814
		RAB,TW	0 265 006 460
			0 265 006 813
FT 330 L 2.4 TDCi [F__]			2,4l 101 kW H9FA 4 Zyl.
Wheel speed sensor, front	03.04-07.06		0 265 006 458
Wheel speed sensor, rear	03.04-07.06	LAB,TW	0 265 006 461
			0 265 006 812
			0 265 006 814
		RAB,TW	0 265 006 460
			0 265 006 811
			0 265 006 813
FT 330 L 2.4 TDE [F__]			2,4l 66/85/88/92 kW DOFA; D2F...; D4FA; FXFA 4 Zyl.
Wheel speed sensor, front	01.00-07.06		0 265 006 458
Wheel speed sensor, rear	01.00-07.06	LAB,TW	0 265 006 461
	12.02-07.06	LAB,TW	0 265 006 812
	01.00-07.06	LAB,TW	0 265 006 814
		RAB,TW	0 265 006 460
	03.04-07.06	RAB,TW	0 265 006 811
	01.00-07.06	RAB,TW	0 265 006 813

Product



FT 330 L 2.4 TDI		2,4l 66/88 kW 4 Zyl.	
Wheel speed sensor, front	01.01-05.06		0 265 006 458
Wheel speed sensor, rear	01.01-09.03	LAB, OZB	0 265 006 461
	10.03-05.06	LAB, OZB	0 265 006 812
	01.01-05.06	LAB, ZWB	0 265 006 814
	01.01-09.03	OZB, RAB	0 265 006 460
	10.03-05.06	OZB, RAB	0 265 006 811
	01.01-05.06	RAB, ZWB	0 265 006 813
FT 330 M 2.0 TDCi [F__]		2,0l 92 kW FIFA 4 Zyl.	
Wheel speed sensor, front	05.02-07.06	TW	0 265 006 458
	07.03-07.06	TW	0 265 006 784
Wheel speed sensor, rear	05.02-05.04	LAB, TW	0 265 006 542
	07.03-07.06	LAB, TW	0 265 006 784
	05.04-07.06	LAB, TW	0 265 006 816
	05.02-05.04	LAB, TW	0 265 006 818
	11.03-05.04	RAB, TW	0 265 006 460
	05.04-07.06	RAB, TW	0 265 006 811
	05.02-07.06	RAB, TW	0 265 006 815
			0 265 006 817
FT 330 M 2.0 TDE [F__]		2,0l 74 kW ABFA 4 Zyl.	
Wheel speed sensor, front	08.03-07.06	TW	0 265 006 458
			0 265 006 784
Wheel speed sensor, rear	08.03-05.04	LAB, TW	0 265 006 542
	08.03-07.06	LAB, TW	0 265 006 784
	05.04-07.06	LAB, TW	0 265 006 816
	08.03-05.04	LAB, TW	0 265 006 818
	11.03-05.04	RAB, TW	0 265 006 460
	05.04-07.06	RAB, TW	0 265 006 811
	08.03-07.06	RAB, TW	0 265 006 815
			0 265 006 817
FT 330 M 2.3i [F__]		2,3l 103-107 kW E5FA; E5FC 4 Zyl.	
Wheel speed sensor, front	12.00-07.06		0 265 006 458
Wheel speed sensor, rear	12.00-07.06	LAB, TW	0 265 006 461
	12.02-07.06	LAB, TW	0 265 006 812
	12.00-07.06	LAB, TW	0 265 006 814
		RAB, TW	0 265 006 460
	03.04-07.06	RAB, TW	0 265 006 811
	12.00-07.06	RAB, TW	0 265 006 813
FT 330 M 2.4 TD [F__]		2,4l 55 kW F4FA 4 Zyl.	
Wheel speed sensor, front	01.00-09.03		0 265 006 458
Wheel speed sensor, rear	01.00-09.03	LAB, TW	0 265 006 461
	12.02-09.03	LAB, TW	0 265 006 812
	01.00-09.03	LAB, TW	0 265 006 814
		RAB, TW	0 265 006 460
			0 265 006 813
FT 330 M 2.4 TDCi [F__]		2,4l 101 kW H9FA 4 Zyl.	
Wheel speed sensor, front	03.04-07.06		0 265 006 458
Wheel speed sensor, rear	03.04-07.06	LAB, TW	0 265 006 461
			0 265 006 812
			0 265 006 814
		RAB, TW	0 265 006 460
			0 265 006 811
			0 265 006 813
FT 330 M 2.4 TDE [F__]		2,4l 66/85/88/92 kW DOFA; D2F...; D4FA; FXFA 4 Zyl.	
Wheel speed sensor, front	01.00-07.06		0 265 006 458
Wheel speed sensor, rear	01.00-07.06	LAB, TW	0 265 006 461
	12.02-07.06	LAB, TW	0 265 006 812
	01.00-07.06	LAB, TW	0 265 006 814
		RAB, TW	0 265 006 460
	03.04-07.06	RAB, TW	0 265 006 811
	01.00-07.06	RAB, TW	0 265 006 813



FT 330 M 2.4 TDI		2,4l 66/88 kW 4 Zyl.	
Wheel speed sensor, front	01.01-05.06		0 265 006 458
Wheel speed sensor, rear	01.01-09.03	LAB,OZB	0 265 006 461
	10.03-05.06	LAB,OZB	0 265 006 812
	01.01-05.06	LAB,ZWB	0 265 006 814
	01.01-09.03	OZB,RAB	0 265 006 460
	10.03-05.06	OZB,RAB	0 265 006 811
	01.01-05.06	RAB,ZWB	0 265 006 813
FT 330 S 2.4 TDI		2,4l 66/74/88 kW 4 Zyl.	
Wheel speed sensor, front	01.01-05.06		0 265 006 458
Wheel speed sensor, rear	01.01-09.03	LAB,OZB	0 265 006 461
	10.03-05.06	LAB,OZB	0 265 006 812
	01.01-05.06	LAB,ZWB	0 265 006 814
	01.01-09.03	OZB,RAB	0 265 006 460
	10.03-05.06	OZB,RAB	0 265 006 811
	01.01-05.06	RAB,ZWB	0 265 006 813
FT 350 E 2.4 TDI		2,4l 66/88 kW 4 Zyl.	
Wheel speed sensor, front	01.01-05.06		0 265 006 458
Wheel speed sensor, rear	01.01-09.03	LAB,OZB	0 265 006 461
	10.03-05.06	LAB,OZB	0 265 006 812
	01.01-05.06	LAB,ZWB	0 265 006 814
	01.01-09.03	OZB,RAB	0 265 006 460
	10.03-05.06	OZB,RAB	0 265 006 811
	01.01-05.06	RAB,ZWB	0 265 006 813
FT 350 E 2.4 TDI		2,4l 96 kW 4 Zyl.	
Wheel speed sensor, front	06.04-05.06		0 265 006 458
Wheel speed sensor, rear	06.04-05.06	LAB,OZB	0 265 006 812
		LAB,ZWB	0 265 006 814
		OZB,RAB	0 265 006 811
		RAB,ZWB	0 265 006 813
FT 350 EL 2.0 TDCi [F__]		2,0l 92 kW FIFA 4 Zyl.	
Wheel speed sensor, front	05.02-07.06	TW	0 265 006 458
	07.03-07.06	TW	0 265 006 784
Wheel speed sensor, rear	05.02-05.04	LAB,TW	0 265 006 542
	07.03-07.06	LAB,TW	0 265 006 784
	05.04-07.06	LAB,TW	0 265 006 816
	05.02-05.04	LAB,TW	0 265 006 818
	11.03-05.04	RAB,TW	0 265 006 460
	05.04-07.06	RAB,TW	0 265 006 811
	05.02-07.06	RAB,TW	0 265 006 815
			0 265 006 817
FT 350 EL 2.0 TDE [F__]		2,0l 74 kW ABFA 4 Zyl.	
Wheel speed sensor, front	08.03-07.06	TW	0 265 006 458
			0 265 006 784
Wheel speed sensor, rear	08.03-05.04	LAB,TW	0 265 006 542
	08.03-07.06	LAB,TW	0 265 006 784
	05.04-07.06	LAB,TW	0 265 006 816
	08.03-05.04	LAB,TW	0 265 006 818
	11.03-05.04	RAB,TW	0 265 006 460
	05.04-07.06	RAB,TW	0 265 006 811
	08.03-07.06	RAB,TW	0 265 006 815
		0 265 006 817	
FT 350 EL 2.3i [F__]		2,3l 103-107 kW E5FA; E5FC 4 Zyl.	
Wheel speed sensor, front	12.00-07.06		0 265 006 458
Wheel speed sensor, rear	12.00-07.06	LAB,TW	0 265 006 461
	12.02-07.06	LAB,TW	0 265 006 812
	12.00-07.06	LAB,TW	0 265 006 814
		RAB,TW	0 265 006 460
	03.04-07.06	RAB,TW	0 265 006 811
	12.00-07.06	RAB,TW	0 265 006 813



FT 350 EL 2.4 TD [F__]		2,4l 55 kW F4FA 4 Zyl.	
Wheel speed sensor, front	01.00-09.03		0 265 006 458
Wheel speed sensor, rear	01.00-09.03	LAB,TW	0 265 006 461
	12.02-09.03	LAB,TW	0 265 006 812
	01.00-09.03	LAB,TW	0 265 006 814
		RAB,TW	0 265 006 460
			0 265 006 813
FT 350 EL 2.4 TDCi [F__]		2,4l 101 kW H9FA 4 Zyl.	
Wheel speed sensor, front	03.04-07.06		0 265 006 458
Wheel speed sensor, rear	03.04-07.06	LAB,TW	0 265 006 461
			0 265 006 812
			0 265 006 814
		RAB,TW	0 265 006 460
			0 265 006 811
			0 265 006 813
FT 350 EL 2.4 TDE [F__]		2,4l 66/85/92 kW DOFA; D2F...; FXFA 4 Zyl.	
Wheel speed sensor, front	01.00-07.06		0 265 006 458
Wheel speed sensor, rear	01.00-07.06	LAB,TW	0 265 006 461
	12.02-07.06	LAB,TW	0 265 006 812
	01.00-07.06	LAB,TW	0 265 006 814
		RAB,TW	0 265 006 460
	03.04-07.06	RAB,TW	0 265 006 811
	01.00-07.06	RAB,TW	0 265 006 813
			0 265 006 815
			0 265 006 817
FT 350 L 2.0 TDCi [F__]		2,0l 92 kW FIFA 4 Zyl.	
Wheel speed sensor, front	05.02-07.06	TW	0 265 006 458
	07.03-07.06	TW	0 265 006 784
Wheel speed sensor, rear	05.02-05.04	LAB,TW	0 265 006 542
	07.03-07.06	LAB,TW	0 265 006 784
	05.04-07.06	LAB,TW	0 265 006 816
	05.02-05.04	LAB,TW	0 265 006 818
	11.03-05.04	RAB,TW	0 265 006 460
	05.04-07.06	RAB,TW	0 265 006 811
	05.02-07.06	RAB,TW	0 265 006 815
			0 265 006 817
FT 350 L 2.0 TDE [F__]		2,0l 74 kW ABFA 4 Zyl.	
Wheel speed sensor, front	08.03-07.06	TW	0 265 006 458
			0 265 006 784
Wheel speed sensor, rear	08.03-05.04	LAB,TW	0 265 006 542
	08.03-07.06	LAB,TW	0 265 006 784
	05.04-07.06	LAB,TW	0 265 006 816
	08.03-05.04	LAB,TW	0 265 006 818
	11.03-05.04	RAB,TW	0 265 006 460
	05.04-07.06	RAB,TW	0 265 006 811
	08.03-07.06	RAB,TW	0 265 006 815
			0 265 006 817
FT 350 L 2.3i [F__]		2,3l 103-107 kW E5FA; E5FC 4 Zyl.	
Wheel speed sensor, front	12.00-07.06		0 265 006 458
Wheel speed sensor, rear	12.00-07.06	LAB,TW	0 265 006 461
	12.02-07.06	LAB,TW	0 265 006 812
	12.00-07.06	LAB,TW	0 265 006 814
		RAB,TW	0 265 006 460
	03.04-07.06	RAB,TW	0 265 006 811
	12.00-07.06	RAB,TW	0 265 006 813
			0 265 006 815
			0 265 006 817
FT 350 L 2.4 TD [F__]		2,4l 55 kW F4FA 4 Zyl.	
Wheel speed sensor, front	01.00-09.03		0 265 006 458
Wheel speed sensor, rear	01.00-09.03	LAB,TW	0 265 006 461
	12.02-09.03	LAB,TW	0 265 006 812
	01.00-09.03	LAB,TW	0 265 006 814
		RAB,TW	0 265 006 460
			0 265 006 813





◀ Transit

FT 350 L 2.4 TDCi [F__]		2,4l 101 kW H9FA 4 Zyl.	
Wheel speed sensor, front	03.04-07.06		0 265 006 458
Wheel speed sensor, rear	03.04-07.06	LAB,TW	0 265 006 461
			0 265 006 812
			0 265 006 814
		RAB,TW	0 265 006 460
			0 265 006 811
			0 265 006 813
FT 350 L 2.4 TDE [F__]		2,4l 66/85/88/92 kW DOFA; D2F...; D4FA; FXFA 4 Zyl.	
Wheel speed sensor, front	01.00-07.06		0 265 006 458
Wheel speed sensor, rear	01.00-07.06	LAB,TW	0 265 006 461
	12.02-07.06	LAB,TW	0 265 006 812
	01.00-07.06	LAB,TW	0 265 006 814
		RAB,TW	0 265 006 460
	03.04-07.06	RAB,TW	0 265 006 811
	01.00-07.06	RAB,TW	0 265 006 813
FT 350 L 2.4 TDI		2,4l 66/88 kW 4 Zyl.	
Wheel speed sensor, front	01.01-05.06		0 265 006 458
Wheel speed sensor, rear	01.01-09.03	LAB,OZB	0 265 006 461
	10.03-05.06	LAB,OZB	0 265 006 812
	01.01-05.06	LAB,ZWB	0 265 006 814
	01.01-09.03	OZB,RAB	0 265 006 460
	10.03-05.06	OZB,RAB	0 265 006 811
	01.01-05.06	RAB,ZWB	0 265 006 813
FT 350 L 2.4 TDI		2,4l 96 kW 4 Zyl.	
Wheel speed sensor, front	06.04-05.06		0 265 006 458
Wheel speed sensor, rear	06.04-05.06	LAB,OZB	0 265 006 812
		LAB,ZWB	0 265 006 814
		OZB,RAB	0 265 006 811
		RAB,ZWB	0 265 006 813
FT 350 M 2.0 TDCi [F__]		2,0l 92 kW FIFA 4 Zyl.	
Wheel speed sensor, front	05.02-07.06	TW	0 265 006 458
	07.03-07.06	TW	0 265 006 784
Wheel speed sensor, rear	05.02-05.04	LAB,TW	0 265 006 542
	07.03-07.06	LAB,TW	0 265 006 784
	05.04-07.06	LAB,TW	0 265 006 816
	05.02-05.04	LAB,TW	0 265 006 818
	11.03-05.04	RAB,TW	0 265 006 460
	05.04-07.06	RAB,TW	0 265 006 811
	05.02-07.06	RAB,TW	0 265 006 815
			0 265 006 817
FT 350 M 2.0 TDE [F__]		2,0l 74 kW ABFA 4 Zyl.	
Wheel speed sensor, front	08.03-07.06	TW	0 265 006 458
			0 265 006 784
Wheel speed sensor, rear	08.03-05.04	LAB,TW	0 265 006 542
	08.03-07.06	LAB,TW	0 265 006 784
	05.04-07.06	LAB,TW	0 265 006 816
	08.03-05.04	LAB,TW	0 265 006 818
	11.03-05.04	RAB,TW	0 265 006 460
	05.04-07.06	RAB,TW	0 265 006 811
	08.03-07.06	RAB,TW	0 265 006 815
			0 265 006 817
FT 350 M 2.3i [F__]		2,3l 103-107 kW E5FA; E5FC 4 Zyl.	
Wheel speed sensor, front	12.00-07.06		0 265 006 458
Wheel speed sensor, rear	12.00-07.06	LAB,TW	0 265 006 461
	12.02-07.06	LAB,TW	0 265 006 812
	12.00-07.06	LAB,TW	0 265 006 814
		RAB,TW	0 265 006 460
	03.04-07.06	RAB,TW	0 265 006 811
	12.00-07.06	RAB,TW	0 265 006 813



F



FT 350 M 2.4 TD [F__]		2,4l 55 kW F4FA 4 Zyl.	
Wheel speed sensor, front	01.00-09.03		0 265 006 458
Wheel speed sensor, rear	01.00-09.03	LAB,TW	0 265 006 461
	12.02-09.03	LAB,TW	0 265 006 812
	01.00-09.03	LAB,TW	0 265 006 814
		RAB,TW	0 265 006 460
			0 265 006 813
FT 350 M 2.4 TDCi [F__]		2,4l 101 kW H9FA 4 Zyl.	
Wheel speed sensor, front	03.04-07.06		0 265 006 458
Wheel speed sensor, rear	03.04-07.06	LAB,TW	0 265 006 461
			0 265 006 812
			0 265 006 814
		RAB,TW	0 265 006 460
			0 265 006 811
			0 265 006 813
FT 350 M 2.4 TDE [F__]		2,4l 66/85/88/92 kW DOFA; D2F...; D4FA; FXFA 4 Zyl.	
Wheel speed sensor, front	01.00-07.06		0 265 006 458
Wheel speed sensor, rear	01.00-07.06	LAB,TW	0 265 006 461
	12.02-07.06	LAB,TW	0 265 006 812
	01.00-07.06	LAB,TW	0 265 006 814
		RAB,TW	0 265 006 460
	03.04-07.06	RAB,TW	0 265 006 811
	01.00-07.06	RAB,TW	0 265 006 813
FT 350 M 2.4 TDI		2,4l 66/88 kW 4 Zyl.	
Wheel speed sensor, front	01.01-05.06		0 265 006 458
Wheel speed sensor, rear	01.01-09.03	LAB,OZB	0 265 006 461
	10.03-05.06	LAB,OZB	0 265 006 812
	01.01-05.06	LAB,ZWB	0 265 006 814
	01.01-09.03	OZB,RAB	0 265 006 460
	10.03-05.06	OZB,RAB	0 265 006 811
	01.01-05.06	RAB,ZWB	0 265 006 813
FT 350 M 2.4 TDI		2,4l 96 kW 4 Zyl.	
Wheel speed sensor, front	06.04-05.06		0 265 006 458
Wheel speed sensor, rear	06.04-05.06	LAB,OZB	0 265 006 812
		LAB,ZWB	0 265 006 814
		OZB,RAB	0 265 006 811
		RAB,ZWB	0 265 006 813
FT 430 E 2.4 TDI		2,4l 96 kW 4 Zyl.	
Wheel speed sensor, front	06.04-05.06		0 265 006 458
Wheel speed sensor, rear	06.04-05.06	LAB,OZB	0 265 006 812
		LAB,ZWB	0 265 006 814
		OZB,RAB	0 265 006 811
		RAB,ZWB	0 265 006 813
			0 265 006 813
FT 430 EL 2.4 TD [F__]		2,4l 55 kW F4FA 4 Zyl.	
Wheel speed sensor, front	08.02-09.03		0 265 006 458
Wheel speed sensor, rear	08.02-09.03	LAB,TW	0 265 006 461
	12.02-09.03	LAB,TW	0 265 006 812
	08.02-09.03	LAB,TW	0 265 006 814
		RAB,TW	0 265 006 460
			0 265 006 813
FT 430 EL 2.4 TDCi [F__]		2,4l 101 kW H9FA 4 Zyl.	
Wheel speed sensor, front	03.04-07.06		0 265 006 458
Wheel speed sensor, rear	03.04-07.06	LAB,TW	0 265 006 461
			0 265 006 812
			0 265 006 814
		RAB,TW	0 265 006 460
			0 265 006 811
			0 265 006 813

Product



FT 430 EL 2.4 TDE [F__]				2,4l	66/85/92 kW	DOFA; D2F...; FXFA	4 Zyl.
Wheel speed sensor, front	08.02-07.06						0 265 006 458
Wheel speed sensor, rear	08.02-07.06	LAB, TW					0 265 006 461
	12.02-07.06	LAB, TW					0 265 006 812
	08.02-07.06	LAB, TW					0 265 006 814
		RAB, TW					0 265 006 460
	03.04-07.06	RAB, TW					0 265 006 811
	08.02-07.06	RAB, TW					0 265 006 813
FT 430 M 2.4 TD [F__]				2,4l	55 kW	F4FA	4 Zyl.
Wheel speed sensor, front	08.02-09.03						0 265 006 458
Wheel speed sensor, rear	08.02-09.03	LAB, TW					0 265 006 461
	12.02-09.03	LAB, TW					0 265 006 812
	08.02-09.03	LAB, TW					0 265 006 814
		RAB, TW					0 265 006 460
							0 265 006 813
FT 430 M 2.4 TDCi [F__]				2,4l	101 kW	H9FA	4 Zyl.
Wheel speed sensor, front	03.04-07.06						0 265 006 458
Wheel speed sensor, rear	03.04-07.06	LAB, TW					0 265 006 461
							0 265 006 812
							0 265 006 814
		RAB, TW					0 265 006 460
							0 265 006 811
							0 265 006 813
FT 430 M 2.4 TDE [F__]				2,4l	85/92 kW	DOFA; FXFA	4 Zyl.
Wheel speed sensor, front	08.02-07.06						0 265 006 458
Wheel speed sensor, rear	08.02-07.06	LAB, TW					0 265 006 461
	12.02-07.06	LAB, TW					0 265 006 812
	08.02-07.06	LAB, TW					0 265 006 814
		RAB, TW					0 265 006 460
	03.04-07.06	RAB, TW					0 265 006 811
	08.02-07.06	RAB, TW					0 265 006 813
2.0 i LWB 100-190, i SWB 80-150 [E_]				2,0l	72 kW	NCA	4 Zyl.
Air flow sensor, gasoline injection	08.91-07.94						0 280 202 063
2.0 i 80-120, i 100 L, i 130-190 [T_]				2,0l	57 kW	N6T	4 Zyl.
Air flow sensor, gasoline injection	10.88-07.91						0 280 202 063
2.2 TDCi				2,2l	63/81/96 kW	P8FA; QVFA; QWF...	4 Zyl.
Boost pressure sensor, Diesel	04.06→						0 261 230 131
Duo sensor, acceleration and yaw rate, brake system	04.06→	TW					0 265 005 690
2.3i				2,3l	107 kW	GZF...	4 Zyl.
Pressure sensor, intake manifold, gasoline	04.06→						0 261 230 044
Duo sensor, acceleration and yaw rate, brake system	04.06→	TW					0 265 005 690
2.4 TDCi				2,4l	74/85/103 kW	HPFB; JXFA; PHF...	4 Zyl.
Boost pressure sensor, Diesel	07.06→						0 261 230 131
Duo sensor, acceleration and yaw rate, brake system	07.06→	TW					0 265 005 690

Transit Euroline							
2.0 TDCi [F__]				2,0l	92 kW	F1FA	4 Zyl.
Wheel speed sensor, front	05.02-07.06	TW					0 265 006 458
	07.03-07.06	TW					0 265 006 784
Wheel speed sensor, rear	07.03-07.06	LAB, TW					0 265 006 784
	05.02-05.04	LAB, TW					0 265 006 818
	11.03-05.04	RAB, TW					0 265 006 460
	05.04-07.06	RAB, TW					0 265 006 811
	05.02-07.06	RAB, TW					0 265 006 817
2.0 TDE [F__]				2,0l	74 kW	ABFA	4 Zyl.
Wheel speed sensor, front	08.00-07.06	TW					0 265 006 458
	07.03-07.06	TW					0 265 006 784
Wheel speed sensor, rear	07.03-07.06	LAB, TW					0 265 006 784
	08.00-05.04	LAB, TW					0 265 006 818
	11.03-05.04	RAB, TW					0 265 006 460
	05.04-07.06	RAB, TW					0 265 006 811
	08.00-07.06	RAB, TW					0 265 006 817

Product



Wheel speed sensor, rear	07.03-07.06	LAB, TW					0 265 006 784
	08.00-05.04	LAB, TW					0 265 006 818
	11.03-05.04	RAB, TW					0 265 006 460
	05.04-07.06	RAB, TW					0 265 006 811
	08.00-07.06	RAB, TW					0 265 006 817
2.2 TDCi				2,2l	81/96 kW	QVFA; QWF...	4 Zyl.
Boost pressure sensor, Diesel	04.06→						0 261 230 131
Duo sensor, acceleration and yaw rate, brake system	04.06→	TW					0 265 005 690

Transit Nugget							
2.0 TDCi [F__]				2,0l	92 kW	F1FA	4 Zyl.
Wheel speed sensor, front	05.02-07.06	TW					0 265 006 458
	07.03-07.06	TW					0 265 006 784
Wheel speed sensor, rear	07.03-07.06	LAB, TW					0 265 006 784
	05.02-05.04	LAB, TW					0 265 006 818
	11.03-05.04	RAB, TW					0 265 006 460
	05.04-07.06	RAB, TW					0 265 006 811
	05.02-07.06	RAB, TW					0 265 006 817
2.0 TDE [F__]				2,0l	74 kW	ABFA	4 Zyl.
Wheel speed sensor, front	08.00-07.06	TW					0 265 006 458
	07.03-07.06	TW					0 265 006 784
Wheel speed sensor, rear	07.03-07.06	LAB, TW					0 265 006 784
	08.00-05.04	LAB, TW					0 265 006 818
	11.03-05.04	RAB, TW					0 265 006 460
	05.04-07.06	RAB, TW					0 265 006 811
	08.00-07.06	RAB, TW					0 265 006 817
2.2 TDCi				2,2l	81/96 kW	QVFA; QWF...	4 Zyl.
Boost pressure sensor, Diesel	04.06→						0 261 230 131
Duo sensor, acceleration and yaw rate, brake system	04.06→	TW					0 265 005 690

Transit Tourneo							
2.0 TDCi [F__]				2,0l	92 kW	F1FA	4 Zyl.
Wheel speed sensor, front	05.02-07.06	TW					0 265 006 458
	07.03-07.06	TW					0 265 006 784
Wheel speed sensor, rear	07.03-07.06	LAB, TW					0 265 006 784
	05.02-05.04	LAB, TW					0 265 006 818
	11.03-05.04	RAB, TW					0 265 006 460
	05.04-07.06	RAB, TW					0 265 006 811
	05.02-07.06	RAB, TW					0 265 006 817
2.0 TDE [F__]				2,0l	74 kW	ABFA	4 Zyl.
Wheel speed sensor, front	08.00-07.06	TW					0 265 006 458
	07.03-07.06	TW					0 265 006 784
Wheel speed sensor, rear	07.03-07.06	LAB, TW					0 265 006 784
	08.00-05.04	LAB, TW					0 265 006 818
	11.03-05.04	RAB, TW					0 265 006 460
	05.04-07.06	RAB, TW					0 265 006 811
	08.00-07.06	RAB, TW					0 265 006 817
2.2 TDCi				2,2l	81/96 kW	QVFA; QWF...	4 Zyl.
Boost pressure sensor, Diesel	04.06→						0 261 230 131
Duo sensor, acceleration and yaw rate, brake system	04.06→	TW					0 265 005 690

Versailles							
2.0i				2,0l	82 kW	UQC	4 Zyl.
Wheel speed sensor, front	02.95-10.96						0 265 006 218
Wheel speed sensor, rear	02.95-10.96	LAB					0 265 006 220
		RAB					0 265 006 219





Product

GAZ				
Gazel				
2.32,3l 80,9 kW 4063.10 4 Zyl.				
Throttle valve sensor	11.97→			0 280 122 001
Air mass meter, gasoline injection	11.97→	TW		0 280 212 014
				0 986 280 108
				0 280 218 037
				0 986 280 108
				0 986 280 108
Phase sensor	11.97→			0 232 103 006
Speed sensor, ignition/injection	11.97→			0 261 210 113
Knock sensor	11.97→			0 261 231 046
Pressure sensor, intake manifold, gasoline	11.97→	TW		0 261 230 004
				0 261 230 037
2.5i2,5l 111,8 kW 40522.10 4 Zyl.				
Throttle valve sensor	09.01→			0 280 122 001
Air mass meter, gasoline injection	09.01→	TW		0 280 212 014
				0 986 280 108
				0 280 218 037
				0 986 280 108
				0 986 280 108
Phase sensor	09.01→			0 232 103 006
Speed sensor, ignition/injection	09.01→			0 261 210 113
Knock sensor	09.01→			0 261 231 046
Pressure sensor, intake manifold, gasoline	09.01→	TW		0 261 230 004
				0 261 230 037
2.7 TD2,7l 80 kW ADCR110 4 Zyl.				
Speed sensor, diesel	01.07→	FKW		0 281 002 315
Phase sensor	01.07→	NOC		0 281 002 667
Temperature sensor, coolant, diesel	01.07→			0 281 002 209
Temperature sensor, intake air, diesel	01.07→			0 280 130 039
Temperature sensor, fuel	01.07→			0 281 002 209
Accelerator pedal module	01.07→			0 281 002 687
Sobol				
2.32,3l 80,9 kW 4063.10 4 Zyl.				
Throttle valve sensor	09.97→			0 280 122 001
Air mass meter, gasoline injection	09.97→	TW		0 280 212 014
				0 986 280 108
				0 280 218 037
				0 986 280 108
				0 986 280 108
Phase sensor	09.97→			0 232 103 006
Speed sensor, ignition/injection	09.97→			0 261 210 113
Knock sensor	09.97→			0 261 231 046
Pressure sensor, intake manifold, gasoline	09.97→	TW		0 261 230 004
				0 261 230 037
2.5i2,5l 111,8 kW 40522 4 Zyl.				
Throttle valve sensor	09.01→			0 280 122 001
Air mass meter, gasoline injection	09.01→	TW		0 280 212 014
				0 986 280 108
				0 280 218 037
				0 986 280 108
				0 986 280 108
Phase sensor	09.01→			0 232 103 006
Speed sensor, ignition/injection	09.01→			0 261 210 113
Knock sensor	09.01→			0 261 231 046
Pressure sensor, intake manifold, gasoline	09.01→	TW		0 261 230 004
				0 261 230 037

Product

Volga				
2.1 TD2,1l 70 kW 560 4 Zyl.				
Phase sensor	09.97→			0 232 103 006
2.32,3l 73,5 kW 4061.10 4 Zyl.				
Throttle valve sensor	11.02-12.05			0 280 122 001
Air mass meter, gasoline injection	11.02-12.05	TW		0 280 212 014
				0 986 280 108
				0 280 218 037
				0 986 280 108
				0 986 280 108
Phase sensor	11.02-12.05			0 232 103 006
Speed sensor, ignition/injection	11.02-12.05			0 261 210 113
Knock sensor	11.02-12.05			0 261 231 046
Pressure sensor, intake manifold, gasoline	11.02-12.05	TW		0 261 230 004
				0 261 230 037
2.3i2,3l 106,6/110 kW 4062.10 4 Zyl.				
Throttle valve sensor	01.97→			0 280 122 001
Air mass meter, gasoline injection	01.97→	TW		0 280 212 014
				0 986 280 108
				0 280 218 037
				0 986 280 108
				0 986 280 108
Speed sensor, ignition/injection	01.97→			0 261 210 113
Knock sensor	01.97→			0 261 231 046
Pressure sensor, intake manifold, gasoline	01.97→	TW		0 261 230 004
				0 261 230 037
2.3i2,3l 110 kW 4062 4 Zyl.				
Throttle valve sensor	01.89-12.99			0 280 122 001
Air mass meter, gasoline injection	01.89-12.99	TW		0 280 212 014
				0 986 280 108
				0 280 218 037
				0 986 280 108
				0 986 280 108
Phase sensor	01.89-12.99			0 232 103 006
Speed sensor, ignition/injection	01.89-12.99			0 261 210 113
Knock sensor	01.89-12.99			0 261 231 046
Pressure sensor, intake manifold, gasoline	01.89-12.99	TW		0 261 230 004
				0 261 230 037
2.3i16V2,3l 106 kW 4062.10 4 Zyl.				
Throttle valve sensor	01.04→			0 280 122 001
Air mass meter, gasoline injection	01.04→	TW		0 280 212 014
				0 986 280 108
				0 280 218 037
				0 986 280 108
				0 986 280 108
Speed sensor, ignition/injection	01.04→			0 261 210 113
Knock sensor	01.04→			0 261 231 046
Pressure sensor, intake manifold, gasoline	01.04→	TW		0 261 230 004
				0 261 230 037
2.3 16V2,3l 73,5 kW 4061.10 4 Zyl.				
Throttle valve sensor	01.97-12.04			0 280 122 001
Air mass meter, gasoline injection	01.97-12.04	TW		0 280 212 014
				0 986 280 108
				0 280 218 037
				0 986 280 108
				0 986 280 108
Phase sensor	01.97-12.04			0 232 103 006
Speed sensor, ignition/injection	01.97-12.04			0 261 210 113
Knock sensor	01.97-12.04			0 261 231 046
Pressure sensor, intake manifold, gasoline	01.97-12.04	TW		0 261 230 004
				0 261 230 037



2.4	2,4l 66/66,2/73,5 kW 402; 402.10; 4021; 4021.10 4 Zyl.
Phase sensor	01.86→ 0 232 103 006

Volga Kombi

2.3	2,3l 73,5 kW 4061.10 4 Zyl.
Throttle valve sensor	11.02→ 0 280 122 001
Air mass meter, gasoline injection	11.02→ TW 0 280 212 014 0 986 280 108 0 280 218 037 0 986 280 108 0 986 280 108
Speed sensor, ignition/injection	11.02→ 0 261 210 113
Knock sensor	11.02→ 0 261 231 046
Pressure sensor, intake manifold, gasoline	11.02→ TW 0 261 230 004 0 261 230 037
2.3i	2,3l 106,6 kW 4062.10 4 Zyl.
Throttle valve sensor	10.97→ 0 280 122 001
Air mass meter, gasoline injection	10.97→ TW 0 280 212 014 0 986 280 108 0 280 218 037 0 986 280 108 0 986 280 108
Speed sensor, ignition/injection	10.97→ 0 261 210 113
Knock sensor	10.97→ 0 261 231 046
Pressure sensor, intake manifold, gasoline	10.97→ TW 0 261 230 004 0 261 230 037
2.3i 16V	2,3l 96/106 kW 4062.10 4 Zyl.
Throttle valve sensor	01.97→ 0 280 122 001
Air mass meter, gasoline injection	01.97→ TW 0 280 212 014 0 986 280 108 0 280 218 037 0 986 280 108 0 986 280 108
Speed sensor, ignition/injection	01.97→ 0 261 210 113
Knock sensor	01.97→ 0 261 231 046
Pressure sensor, intake manifold, gasoline	01.97→ TW 0 261 230 004 0 261 230 037
2.3 16V	2,3l 106 kW 4062.10 4 Zyl.
Throttle valve sensor	01.97-12.00 0 280 122 001
Air mass meter, gasoline injection	01.97-12.00 TW 0 280 212 014 0 986 280 108 0 280 218 037 0 986 280 108 0 986 280 108
Speed sensor, ignition/injection	01.97-12.00 0 261 210 113
Knock sensor	01.97-12.00 0 261 231 046
Pressure sensor, intake manifold, gasoline	01.97-12.00 TW 0 261 230 004 0 261 230 037

GREATWALL

Deer

2.2i 4WD	2,2l 78 kW GW491QE 4 Zyl.
Throttle valve sensor	06.96→ 0 280 122 019
Phase sensor	06.96→ 0 232 101 024
Speed sensor, ignition/injection	06.96→ 0 261 210 127
Knock sensor	06.96→ 0 261 231 163
Pressure sensor, intake manifold, gasoline	06.96→ 0 261 230 011
Temperature sensor, coolant, injection system	06.96→ 0 280 130 113



HOLDEN

Barina Hatchback

1.4i [SB]	1,4l 44 kW C14NZ 4 Zyl.
Temperature sensor, coolant, injection system	
Fg.no. W3000001→,W4000001→	04.94-07.97 0 280 130 093
Fg.no. →V3999999,→V4999999	04.94-07.97 0 280 130 107

HONDA

Accord Hatchback

2.0 TDi [CG/CH/CL]	2,0l 77 kW 20T2N 4 Zyl.
Air mass meter, diesel	01.99-10.00 0 280 218 012 01.99-12.99 GS,TW 0 281 002 120
Boost pressure sensor, Diesel	01.99-10.00 0 281 002 389
Temperature sensor, coolant, diesel	01.99-10.00 0 280 130 026
Temperature sensor, intake air, diesel	01.99-10.00 0 280 130 039

Accord Sedan

1.6i [CG/CH/CL]	1,6l 85 kW D16B6 4 Zyl.
Temperature sensor, intake air, injection system	10.98-12.99 0 280 130 073 01.00-02.03 GS 0 280 130 092
Temperature sensor, coolant, injection system	10.98-02.03 0 280 130 107
1.8i [CG/CH/CL]	1,8l 100 kW F18B2 4 Zyl.
Temperature sensor, intake air, injection system	10.98-02.03 GS 0 280 130 092
2.0 D Turbo [CE/CF]	2,0l 77 kW 20T2N 4 Zyl.
Air mass meter, diesel	09.95-10.98 0 281 002 120
Speed sensor, diesel	09.95-10.98 0 281 002 121
Temperature sensor, coolant, diesel	09.95-10.98 0 280 130 026
Temperature sensor, intake air, diesel	09.95-10.98 0 280 130 039
2.0i [CG/CH/CL]	2,0l 108 kW F20B6 4 Zyl.
Temperature sensor, intake air, injection system	10.98-02.03 GS 0 280 130 092
2.0 TDi [CG/CH/CL]	2,0l 77 kW 20T2N 4 Zyl.
Air mass meter, diesel	01.99-02.03 0 280 218 012 01.99-12.99 GS,TW 0 281 002 120
Boost pressure sensor, Diesel	01.99-02.03 0 281 002 389
Temperature sensor, coolant, diesel	01.99-02.03 0 280 130 026
Temperature sensor, intake air, diesel	01.99-02.03 0 280 130 039
2.2i Typ R [CG/CH/CL]	2,2l 156 kW H22A7 4 Zyl.
Temperature sensor, intake air, injection system	01.99-02.03 GS 0 280 130 092

Civic Aerodeck

2.0 D Turbo [MB/MC]	2,0l 77 kW 20T2N 4 Zyl.
Air mass meter, diesel	04.98-12.99 0 281 002 120
Temperature sensor, coolant, diesel	04.98-02.01 0 280 130 026
Temperature sensor, intake air, diesel	04.98-02.01 0 280 130 039
Wheel speed sensor, front	04.98-02.01 LAB 0 265 006 258 RAB 0 265 006 259
Wheel speed sensor, rear	04.98-02.01 LAB 0 265 006 267 RAB 0 265 006 268

Civic Fastback

2.0 D [MB/MC]	2,0l 63 kW 20T2N 4 Zyl.
Air mass meter, diesel	03.97-02.01 0 281 002 120
Temperature sensor, coolant, diesel	03.97-02.01 0 280 130 026





Product				

◀ Civic Fastback

Wheel speed sensor, front	03.97-02.01	LAB	0 265 006 258
		RAB	0 265 006 259
Wheel speed sensor, rear	03.97-02.01	LAB	0 265 006 267
		RAB	0 265 006 268

Civic Hatchback

1.7 CTDi [EU/EP]	1,7l	74 kW	4EE2	4 Zyl.
Air mass meter, diesel	01.02-12.05			0 281 002 482

Jazz

1.2 [GD]	1,2l	57 kW	L12A1	4 Zyl.
Knock sensor	03.02→			0 261 231 120
Pressure sensor, intake manifold, gasoline	03.02→			0 261 230 099
1.4 [GD]	1,3l	61 kW	L13A1	4 Zyl.
Pressure sensor, intake manifold, gasoline	03.02→	GS		0 261 230 099

HYUNDAI

Accent

1.3 i [LC]	1,3l	55/61-63 kW	G4E-A	4 Zyl.
Throttle valve sensor	08.99-03.06			0 280 122 014
1.3 i [X3]	1,3l	44/55/62 kW	G4EH	4 Zyl.
Throttle valve sensor	07.94-07.99			0 280 122 001
Air mass meter, gasoline injection	07.94-07.99			0 280 217 102
1.3 i [X3]	1,3l	67 kW	G4EH	4 Zyl.
Throttle valve sensor	04.94-05.99			0 280 122 001
1.5 CRDi [LC]	1,5l	57-60 kW	D3-EA	3 Zyl.
Air mass meter, diesel	01.02-03.06			0 281 002 528
Accelerator pedal module	01.02-06.03	LLE		0 281 002 545
	01.02-02.04	RLE		0 281 002 547
1.5 i [LC]	1,5l	66/75 kW	G4EB; G4EC-G	4 Zyl.
Throttle valve sensor	08.99-03.06			0 280 122 014
1.5 i [X3]	1,5l	63/65-68 kW	G4EK	4 Zyl.
Throttle valve sensor	07.94-07.99			0 280 122 001
Air mass meter, gasoline injection	07.94-07.99			0 280 217 102
1.5 i [X3]	1,5l	71 kW		4 Zyl.
Throttle valve sensor	04.94-05.99			0 280 122 001
1.5 i 12V	1,5l	69 kW	Alpha	4 Zyl.
Throttle valve sensor	11.99→			0 280 122 014
1.5 i 16V [X3]	1,5l	73 kW	G4FK	4 Zyl.
Throttle valve sensor	11.95-07.99			0 280 122 001
Air mass meter, gasoline injection	11.95-07.99			0 280 217 102
Pressure sensor, intake manifold, gasoline	08.97-05.98			0 261 230 013
1.6 i [LC]	1,6l	77 kW	G4ED-G	4 Zyl.
Throttle valve sensor	08.02-03.06			0 280 122 014

Accent Hatchback

1.3 [LC]	1,3l	53 kW	G4E-A	4 Zyl.
Throttle valve sensor	08.99-03.06			0 280 122 014
1.3 i [LC]	1,3l	55/61-63 kW	G4E-A	4 Zyl.
Throttle valve sensor	08.99-03.06			0 280 122 014
1.3 i [X3]	1,3l	44/55/62 kW	G4EH	4 Zyl.
Throttle valve sensor	07.94-07.99			0 280 122 001
Air mass meter, gasoline injection	07.94-07.99			0 280 217 102
1.5 CRDi [LC]	1,5l	57-60 kW	D3-EA	3 Zyl.
Air mass meter, diesel	01.02-03.06			0 281 002 528
Accelerator pedal module	01.02-06.03	LLE		0 281 002 545
	01.02-02.04	RLE		0 281 002 547

Product				

1.5 i [LC]	1,5l	66/75 kW	G4EB; G4EC-G	4 Zyl.
Throttle valve sensor	08.99-03.06			0 280 122 014
1.5 i [X3]	1,5l	63/65-68 kW	G4EK	4 Zyl.
Throttle valve sensor	07.94-07.99			0 280 122 001
Air mass meter, gasoline injection	07.94-07.99			0 280 217 102
1.5 i [X3]	1,5l	73 kW	G4FK	4 Zyl.
Throttle valve sensor	11.95-07.99			0 280 122 001
Air mass meter, gasoline injection	11.95-07.99			0 280 217 102
Pressure sensor, intake manifold, gasoline	08.97-05.98			0 261 230 013
1.6 i [LC]	1,6l	77 kW	G4ED-G	4 Zyl.
Throttle valve sensor	08.02-03.06			0 280 122 014

Coupé

1.6 i 16V [RD]	1,6l	84-85 kW	Beta	4 Zyl.
Throttle valve sensor	05.96-09.01			0 280 122 001
Air mass meter, gasoline injection	05.96-09.01			0 280 217 116
1.6 16V [GK]	1,6l	76-79 kW	G4ED-G	4 Zyl.
Throttle valve sensor	03.02→			0 280 122 014
1.8 i 16V [RD]	1,8l	94 kW	G4GM	4 Zyl.
Air mass meter, gasoline injection	07.97-09.01			0 280 217 116
2.0 i 16V [RD]	2,0l	100-102 kW	G4GF	4 Zyl.
Throttle valve sensor	05.96-09.01			0 280 122 001
Air mass meter, gasoline injection	05.96-09.01			0 280 217 116
2.0 16V [GK]	2,0l	101-105 kW	G4GC-G	4 Zyl.
Throttle valve sensor	10.01→			0 280 122 014

Elantra

1.5 i [J2]	1,5l	65-68 kW	G4EK	4 Zyl.
Throttle valve sensor	07.96-09.00			0 280 122 001
1.6 i	1,6l	82 kW	G4GA	4 Zyl.
Throttle valve sensor	04.04→			0 280 122 014
1.6 i 16V [J2]	1,6l	84 kW	4G61	4 Zyl.
Throttle valve sensor	05.95-09.00			0 280 122 001
1.6 i 16V [XD]	1,6l	77-79 kW	G4ED-G	4 Zyl.
Throttle valve sensor	06.00→			0 280 122 014
1.8 i	1,8l	96 kW	G4GB	4 Zyl.
Throttle valve sensor	12.03→			0 280 122 014
1.8 i 16V [J2]	1,8l	101 kW	G4GM	4 Zyl.
Throttle valve sensor	05.95-09.00			0 280 122 001
Air mass meter, gasoline injection	05.95-01.96			0 280 217 116
1.8 i 16V [XD]	1,8l	97 kW	G4GB	4 Zyl.
Throttle valve sensor	06.00→			0 280 122 014
2.0 i 16V [XD]	2,0l	102-105 kW	G4...	4 Zyl.
Throttle valve sensor	06.00→			0 280 122 014

Elantra Hatchback

1.6 i 16V [XD]	1,6l	77-79 kW	G4ED	4 Zyl.
Throttle valve sensor	06.00→			0 280 122 014
1.8 i 16V [XD]	1,8l	97 kW	G4GB	4 Zyl.
Throttle valve sensor	06.00→			0 280 122 014
2.0 i 16V [XD]	2,0l	102-105 kW	G4...	4 Zyl.
Throttle valve sensor	06.00→			0 280 122 014

Excel

1.3 i [X3]	1,3l	55 kW	G4EH	4 Zyl.
Throttle valve sensor	07.94-07.99			0 280 122 001
Air mass meter, gasoline injection	07.94-07.99			0 280 217 102



1.5 i [X3]			1,5l 65-68 kW G4EK 4 Zyl.
Throttle valve sensor	07.94-07.99	0 280 122 001	
Air mass meter, gasoline injection	07.94-07.99	0 280 217 102	
1.5 i 16V [X3]			1,5l 73 kW G4FK 4 Zyl.
Throttle valve sensor	11.95-07.99	0 280 122 001	
Air mass meter, gasoline injection	11.95-07.99	0 280 217 102	
Pressure sensor, intake manifold, gasoline	08.97-05.98	0 261 230 013	

Excel Hatchback

1.5 i [X3]			1,5l 73 kW G4FK 4 Zyl.
Throttle valve sensor	11.95-07.99	0 280 122 001	
Air mass meter, gasoline injection	11.95-07.99	0 280 217 102	
Pressure sensor, intake manifold, gasoline	08.97-05.98	0 261 230 013	

Getz

1.1 i [TB]			1,1l 46-49 kW G4HD 4 Zyl.
Throttle valve sensor	09.02→	0 280 122 014	
1.3 i [TB]			1,3l 60-63 kW G4E-A 4 Zyl.
Throttle valve sensor	09.02-09.05	0 280 122 014	
1.5 CRDi [TB]			1,5l 60 kW D3-EA 3 Zyl.
Air mass meter, diesel	05.03-08.05	0 281 002 528	
1.6 i [TB]			1,6l 77 kW G4ED-G 4 Zyl.
Throttle valve sensor	09.02→	0 280 122 014	

H 100

2.5 D			2,5l 55 kW D4BX 4 Zyl.
Wheel speed sensor, front	02.93-12.94	LAB	0 265 006 133
		RAB	0 265 006 121
Wheel speed sensor, rear	02.93-12.94	LAB	0 265 006 123
		RAB	0 265 006 122

H-1

2.5 CRDi			2,5l 103 kW D4CB 4 Zyl.
Air flow sensor, diesel	08.03→	0 281 002 554	

Lantra

1.5 i [J2]			1,5l 65-68 kW G4EK 4 Zyl.
Throttle valve sensor	07.96-09.00	0 280 122 001	
1.6 i 16V [J2]			1,6l 66/84 kW G4DJ; G4GR 4 Zyl.
Throttle valve sensor	05.95-09.00	0 280 122 001	
1.8 i 16V [J2]			1,8l 94 kW G4GM 4 Zyl.
Throttle valve sensor	05.95-09.00	0 280 122 001	
Air mass meter, gasoline injection	05.95-01.96	0 280 217 116	
2.0 i 16V [J2]			2,0l 102 kW G4GF 4 Zyl.
Throttle valve sensor	08.96-09.00	0 280 122 001	

Lantra Station Wagon

1.5 i [J2]			1,5l 65 kW G4EK 4 Zyl.
Throttle valve sensor	07.96-09.00	0 280 122 001	
1.6 i [J2]			1,6l 66/84 kW G4GR 4 Zyl.
Throttle valve sensor	05.95-09.00	0 280 122 001	
1.8 i [J2]			1,8l 94 kW G4GM 4 Zyl.
Throttle valve sensor	05.95-09.00	0 280 122 001	
Air mass meter, gasoline injection	05.95-01.96	0 280 217 116	
2.0 i [J2]			2,0l 102 kW G4GF 4 Zyl.
Throttle valve sensor	08.96-09.00	0 280 122 001	



Matrix

1.5 CRDi [FC]			1,5l 60 kW D3-EA 3 Zyl.
Air mass meter, diesel	08.01-01.06	0 281 002 528	
Accelerator pedal module	08.01-01.06	0 281 002 543	
		RLE	0 281 002 547
1.5 CRDi [FC]			1,5l 75 kW D4FA 4 Zyl.
Accelerator pedal module	02.05→	LLE	0 281 002 543
		RLE	0 281 002 547
1.5 CRDi [FC]			1,5l 81 kW 4 Zyl.
Accelerator pedal module	09.06→	LLE	0 281 002 543
1.6 i [FC]			1,6l 76 kW G4ED 4 Zyl.
Throttle valve sensor	08.01→	0 280 122 014	
1.8 i [FC]			1,8l 90 kW G4GB 4 Zyl.
Throttle valve sensor	08.01→	0 280 122 014	

Pony

1.3 i [X3]			1,3l 62 kW G4EH 4 Zyl.
Throttle valve sensor	07.94-07.99	0 280 122 001	
Air mass meter, gasoline injection	07.94-07.99	0 280 217 102	

Santa Fe

2.0 CRDi [SM]			2,0l 83 kW D4EA 4 Zyl.
Accelerator pedal module	04.01-07.02	LLE	0 281 002 446
	08.02-12.05	LLE	0 281 002 556
2.0 CRDi			2,0l 83 kW 4 Zyl.
Air mass meter, diesel	06.00→	0 281 002 447	
Accelerator pedal module	06.00-03.01	0 281 002 446	
	06.00→	0 281 002 556	
2.0 CRDi 4x4 [SM]			2,0l 83 kW D4EA 4 Zyl.
Accelerator pedal module	07.01-07.02	LLE	0 281 002 446
	08.02-12.05	LLE	0 281 002 556
2.0 CRDi-VGT			2,0l 83 kW 4 Zyl.
Accelerator pedal module	08.03→	0 281 002 556	
2.0 CRDi-VGT 4x4 [SM]			2,0l 92 kW D4EA-V 4 Zyl.
Accelerator pedal module	08.03-12.05	LLE	0 281 002 556
2.4 i [SM]			2,4l 100/107 kW G4JS-G; G4JSX 4 Zyl.
Air mass meter, gasoline injection	02.00-07.01	0 280 218 020	
2.4 i 4x4 [SM]			2,4l 100/107 kW G4JS-G; G4JSX 4 Zyl.
Air mass meter, gasoline injection	12.00-07.01	0 280 218 020	

Scoupe

1.5 i			1,5l 65-68 kW G4EK 4 Zyl.
Throttle valve sensor	07.92-04.95	0 280 122 001	
Air mass meter, gasoline injection	07.92-04.95	0 280 217 102	
Speed sensor, ignition/injection	07.92-04.95	0 261 210 083	
Knock sensor	07.92-04.94	0 261 231 091	
1.5 i			1,5l 75 kW G4EK 4 Zyl.
Throttle valve sensor	10.90-04.95	0 280 122 001	
Speed sensor, ignition/injection	10.90-04.95	0 261 210 083	
Temperature sensor, coolant, injection system	10.90-04.95	0 280 130 026	
1.5 i Turbo GT			1,5l 84-85 kW Alpha; G4EK-TC 4 Zyl.
Throttle valve sensor	04.91-04.95	0 280 122 001	
Air mass meter, gasoline injection	04.91-04.95	0 280 212 024	
		0 986 280 123	
Speed sensor, ignition/injection	04.91-04.95	0 261 210 083	
Knock sensor	04.91-04.94	0 261 231 091	





Product				

Starex			
2.5 CRDi	2,5l	103 kW	D4CB 4 Zyl.
Air flow sensor, diesel	10.02→	0 281 002 554	
2.5 CRDi	2,5l	107 kW	4 Zyl.
Air mass meter, diesel	12.02→	0 281 002 554	

Terracan			
2.9 CRDi [HP]	2,9l	110/120 kW	J3 4 Zyl.
Air mass meter, diesel	11.01→	0 281 002 554	

Tiburon			
1.5 i [RD]	1,5l	74-76 kW	G4EK 4 Zyl.
Throttle valve sensor	04.96→	0 280 122 001	
Air mass meter, gasoline injection	04.96→	0 280 217 102	
2.0 i [RD]	2,0l	102-103 kW	G4GF 4 Zyl.
Throttle valve sensor	05.96→	0 280 122 001	
Air mass meter, gasoline injection	05.96→	0 280 217 116	

Trajet			
2.0 [FO]	2,0l	100-103 kW	G4JP 4 Zyl.
Throttle valve sensor	03.04→	0 280 122 014	

Trajet XG			
2.0 CRDi	2,0l	83 kW	D 4 Zyl.
Air mass meter, diesel	10.99→	0 281 002 447	
Accelerator pedal module	10.99-03.01	0 281 002 446	
	10.99→	0 281 002 556	
2.0 i	2,0l	104 kW	4 Zyl.
Throttle valve sensor	03.04→	0 280 122 014	

Tucson			
2.0 i, i 4x4 [JM]	2,0l	104 kW	G4GC 4 Zyl.
Throttle valve sensor	08.04→	0 280 122 014	

XG			
30 3.0i [F]	3,0l	138 kW	G6CT 6 Zyl.
Air mass meter, gasoline injection	12.98-11.02	0 280 218 029	
	12.02-12.05	0 280 218 090	
35 3.5i [F]	3,5l	145 kW	G6CU 6 Zyl.
Air mass meter, gasoline injection	03.03-12.05	0 280 218 090	

INNOCENTI (NUOVA INNOCENTI)

Elba			
1.4 i.e.	1,4l	49 kW	146 C 5.000 SPI-RB 4 Zyl.
Temperature sensor, coolant, injection system	09.93-06.95	0 280 130 026	
1.4 i.e.	1,4l	49 kW	146 D 5.000 SPI-RB 4 Zyl.
Pulse generator, ignition/Jetronic	06.95-12.96	0 261 210 115	
Temperature sensor, coolant, injection system	06.95-12.96	0 280 130 026	
1.5 i.e.	1,5l	55 kW	149 C 1.000 4 Zyl.
Temperature sensor, coolant, injection system	03.92-08.93	0 280 130 026	
1.6 i.e.	1,6l	55 kW	146 C 6.000 SPI-RB 4 Zyl.
Temperature sensor, coolant, injection system	09.93-03.96	0 280 130 026	

Product				

1.6 i.e.	1,6l	55 kW	146 D 6.000 SPI-RB 4 Zyl.
Pulse generator, ignition/Jetronic	03.95-12.96	0 261 210 115	
Temperature sensor, coolant, injection system	03.95-12.96	0 280 130 026	

IVECO

Daily			
C 35 C 9	2,8l	66 kW	8140.43R... 4 Zyl.
Speed sensor, diesel	08.01-09.04	0 281 002 332	
High-pressure sensor (CR system)	08.01-09.04	0 281 002 405	
Boost pressure sensor, Diesel			
Mot.no. →3487098	08.01-09.04	0 281 002 205	
Mot.no. 3487099→	08.01-09.04	0 281 002 514	
C 35 C 10	2,3l	70 kW	F1AE0481A'A... 4 Zyl.
Phase sensor	09.02-03.06	NOC	0 281 002 512
Boost pressure sensor, Diesel	09.02-03.06	0 281 002 514	
Temperature sensor, coolant, diesel	09.02-03.06	0 281 002 209	
C 35 C 11	2,8l	78 kW	8140.43B.43... 4 Zyl.
Speed sensor, diesel	05.01-09.02	0 281 002 332	
High-pressure sensor (CR system)	05.01-09.02	0 281 002 405	
Boost pressure sensor, Diesel			
Mot.no. →3487098	05.01-09.02	0 281 002 205	
Mot.no. 3487099→	05.01-09.02	0 281 002 514	
C 35 C 12	2,3l	85 kW	F1AE0481B... 4 Zyl.
Phase sensor	09.02-03.06	NOC	0 281 002 512
Boost pressure sensor, Diesel	09.02-03.06	0 281 002 514	
Temperature sensor, coolant, diesel	09.02-03.06	0 281 002 209	
C 35 C 13	2,8l	92 kW	8140.43S... 4 Zyl.
Speed sensor, diesel	05.99-09.04	0 281 002 332	
High-pressure sensor (CR system)	05.99-09.04	0 281 002 405	
Boost pressure sensor, Diesel			
Mot.no. →3487098	05.99-09.04	0 281 002 205	
Mot.no. 3487099→	05.99-09.04	0 281 002 514	
C 35 C 14	3,0l	100 kW	F1CE0481A... 4 Zyl.
Phase sensor	09.04-03.06	NOC	0 281 002 667
Boost pressure sensor, Diesel	09.04-03.06	0 281 002 437	
Temperature sensor, coolant, diesel	09.04-03.06	0 281 002 209	
C 35 C 15	2,8l	108 kW	8140.43N.43... 4 Zyl.
Speed sensor, diesel	05.01-09.04	0 281 002 332	
High-pressure sensor (CR system)	05.01-09.04	0 281 002 405	
Boost pressure sensor, Diesel			
Mot.no. →3487098	05.01-09.04	0 281 002 205	
Mot.no. 3487099→	05.01-09.04	0 281 002 514	
C 35 C 17	3,0l	122 kW	F1CE0481B... 4 Zyl.
Phase sensor	09.04-03.06	NOC	0 281 002 667
Boost pressure sensor, Diesel	09.04-03.06	0 281 002 437	
Temperature sensor, coolant, diesel	09.04-03.06	0 281 002 209	
C 40 C 13	2,8l	92 kW	8140.43S... 4 Zyl.
Speed sensor, diesel	01.01-09.04	0 281 002 332	
High-pressure sensor (CR system)	01.01-09.04	0 281 002 405	
Boost pressure sensor, Diesel			
Mot.no. →3487098	01.01-09.04	0 281 002 205	
Mot.no. 3487099→	01.01-09.04	0 281 002 514	
C 40 C 14	3,0l	100 kW	F1CE0481A... 4 Zyl.
Phase sensor	09.04-03.06	NOC	0 281 002 667
Boost pressure sensor, Diesel	09.04-03.06	0 281 002 437	
Temperature sensor, coolant, diesel	09.04-03.06	0 281 002 209	
C 40 C 15	2,8l	108 kW	8140.43N.43... 4 Zyl.
Speed sensor, diesel	04.03-09.04	0 281 002 332	
High-pressure sensor (CR system)	04.03-09.04	0 281 002 405	



Boost pressure sensor, Diesel		
Mot.no. →3487098	04.03-09.04	0 281 002 205
Mot.no. 3487099→	04.03-09.04	0 281 002 514
C 40 C 17	3,0l 122 kW F1CE0481B...	4 Zyl.
Phase sensor	09.04-03.06 NOC	0 281 002 667
Boost pressure sensor, Diesel	09.04-03.06	0 281 002 437
Temperature sensor, coolant, diesel	09.04-03.06	0 281 002 209
C 45 C 13	2,8l 92 kW 8140.43S...	4 Zyl.
Speed sensor, diesel	01.01-09.04	0 281 002 332
High-pressure sensor (CR system)	01.01-09.04	0 281 002 405
Boost pressure sensor, Diesel		
Mot.no. →3487098	01.01-09.04	0 281 002 205
Mot.no. 3487099→	01.01-09.04	0 281 002 514
C 50 C 11	2,8l 78 kW 8140.43B.43...	4 Zyl.
Speed sensor, diesel	05.01-09.04	0 281 002 332
High-pressure sensor (CR system)	05.01-09.04	0 281 002 405
Boost pressure sensor, Diesel		
Mot.no. →3487098	05.01-09.04	0 281 002 205
Mot.no. 3487099→	05.01-09.04	0 281 002 514
C 50 C 13	2,8l 92 kW 8140.43S...	4 Zyl.
Speed sensor, diesel	05.99-09.04	0 281 002 332
High-pressure sensor (CR system)	05.99-09.04	0 281 002 405
Boost pressure sensor, Diesel		
Mot.no. →3487098	05.99-09.04	0 281 002 205
Mot.no. 3487099→	05.99-09.04	0 281 002 514
C 50 C 14	3,0l 100 kW F1CE0481A...	4 Zyl.
Phase sensor	09.04-03.06 NOC	0 281 002 667
Boost pressure sensor, Diesel	09.04-03.06	0 281 002 437
Temperature sensor, coolant, diesel	09.04-03.06	0 281 002 209
C 50 C 15	2,8l 108 kW 8140.43N.43...	4 Zyl.
Speed sensor, diesel	05.01-09.04	0 281 002 332
High-pressure sensor (CR system)	05.01-09.04	0 281 002 405
Boost pressure sensor, Diesel		
Mot.no. →3487098	05.01-09.04	0 281 002 205
Mot.no. 3487099→	05.01-09.04	0 281 002 514
C 50 C 17	3,0l 122 kW F1CE0481B...	4 Zyl.
Phase sensor	09.04-03.06 NOC	0 281 002 667
Boost pressure sensor, Diesel	09.04-03.06	0 281 002 437
Temperature sensor, coolant, diesel	09.04-03.06	0 281 002 209
C 65 C 14	3,0l 100 kW F1CE0481A...	4 Zyl.
Phase sensor	09.04-03.06 NOC	0 281 002 667
Boost pressure sensor, Diesel	09.04-03.06	0 281 002 437
Temperature sensor, coolant, diesel	09.04-03.06	0 281 002 209
C 65 C 15	2,8l 108 kW 8140.43N.43...	4 Zyl.
Speed sensor, diesel	05.00-09.04	0 281 002 332
High-pressure sensor (CR system)	05.00-09.04	0 281 002 405
Boost pressure sensor, Diesel		
Mot.no. →3487098	05.00-09.04	0 281 002 205
Mot.no. 3487099→	05.00-09.04	0 281 002 514
C 65 C 17	3,0l 122 kW F1CE0481B...	4 Zyl.
Phase sensor	09.04-03.06 NOC	0 281 002 667
Boost pressure sensor, Diesel	09.04-03.06	0 281 002 437
Temperature sensor, coolant, diesel	09.04-03.06	0 281 002 209
L 29 L 9	2,8l 66 kW 8140.43R...	4 Zyl.
Speed sensor, diesel	08.01-09.02	0 281 002 332
High-pressure sensor (CR system)	08.01-09.02	0 281 002 405
Boost pressure sensor, Diesel		
Mot.no. →3487098	08.01-09.02	0 281 002 205
Mot.no. 3487099→	08.01-09.02	0 281 002 514
L 29 L 10	2,3l 70 kW F1AE0481A...	4 Zyl.
Phase sensor	09.02-03.06 NOC	0 281 002 512
Boost pressure sensor, Diesel	09.02-03.06	0 281 002 514
Temperature sensor, coolant, diesel	09.02-03.06	0 281 002 209



L 29 L 12	2,3l 85 kW F1AE0481B...	4 Zyl.
Phase sensor	09.02-03.06 NOC	0 281 002 512
Boost pressure sensor, Diesel	09.02-03.06	0 281 002 514
Temperature sensor, coolant, diesel	09.02-03.06	0 281 002 209
L 29 L 13	2,8l 92 kW 8140.43S...	4 Zyl.
Speed sensor, diesel	10.00-03.06	0 281 002 332
High-pressure sensor (CR system)	10.00-03.06	0 281 002 405
Boost pressure sensor, Diesel		
Mot.no. →3487098	10.00-03.06	0 281 002 205
Mot.no. 3487099→	10.00-03.06	0 281 002 514
L 29 L 14	2,3l 100 kW F1AE0481M...	4 Zyl.
Phase sensor	09.04-03.06 NOC	0 281 002 512
Boost pressure sensor, Diesel	09.04-03.06	0 281 002 514
Temperature sensor, coolant, diesel	09.04-03.06	0 281 002 209
S 35 S 9	2,8l 66 kW 8140.43R...	4 Zyl.
Speed sensor, diesel	08.01-03.06	0 281 002 332
High-pressure sensor (CR system)	08.01-03.06	0 281 002 405
Boost pressure sensor, Diesel		
Mot.no. →3487098	08.01-03.06	0 281 002 205
Mot.no. 3487099→	08.01-03.06	0 281 002 514
S 35 S 10	2,3l 70 kW F1AE0481A...	4 Zyl.
Phase sensor	09.02-03.06 NOC	0 281 002 512
Boost pressure sensor, Diesel	09.02-03.06	0 281 002 514
Temperature sensor, coolant, diesel	09.02-03.06	0 281 002 209
S 35 S 11	2,8l 78 kW 8140.43B.43...	4 Zyl.
Speed sensor, diesel	05.01-03.06	0 281 002 332
High-pressure sensor (CR system)	05.01-03.06	0 281 002 405
Boost pressure sensor, Diesel		
Mot.no. →3487098	05.01-03.06	0 281 002 205
Mot.no. 3487099→	05.01-03.06	0 281 002 514
S 35 S 12	2,3l 85 kW F1AE0481B...	4 Zyl.
Phase sensor	09.02-03.06 NOC	0 281 002 512
Boost pressure sensor, Diesel	09.02-03.06	0 281 002 514
Temperature sensor, coolant, diesel	09.02-03.06	0 281 002 209
S 35 S 13	2,8l 92 kW 8140.43S...	4 Zyl.
Speed sensor, diesel	05.99-03.06	0 281 002 332
High-pressure sensor (CR system)	05.99-03.06	0 281 002 405
Boost pressure sensor, Diesel		
Mot.no. →3487098	05.99-03.06	0 281 002 205
Mot.no. 3487099→	05.99-03.06	0 281 002 514
S 35 S 14	2,3l 100 kW F1AE0481M...	4 Zyl.
Phase sensor	09.04-03.06 NOC	0 281 002 512
Boost pressure sensor, Diesel	09.04-03.06	0 281 002 514
Temperature sensor, coolant, diesel	09.04-03.06	0 281 002 209
S 35 S 15	2,8l 108 kW 8140.43N.43...	4 Zyl.
Speed sensor, diesel	05.01-03.06	0 281 002 332
High-pressure sensor (CR system)	05.01-03.06	0 281 002 405
Boost pressure sensor, Diesel		
Mot.no. →3487098	05.01-03.06	0 281 002 205
Mot.no. 3487099→	05.01-03.06	0 281 002 514
S 35 S 17	3,0l 122 kW F1CE0481B...	4 Zyl.
Phase sensor	09.04-03.06 NOC	0 281 002 667
Boost pressure sensor, Diesel	09.04-03.06	0 281 002 437
Temperature sensor, coolant, diesel	09.04-03.06	0 281 002 209

Daily Chassi

35.13	2,8l 92 kW 8140.43S	4 Zyl.
Speed sensor, diesel	10.05→	0 281 002 332
High-pressure sensor (CR system)	10.05→	0 281 002 405
Boost pressure sensor, Diesel	10.05→	0 281 002 514
Temperature sensor, coolant, diesel	10.05→	0 281 002 170



Product				

◀ Daily Chassi

50.13	2,8l 92 kW 8140.43S 4 Zyl.
Speed sensor, diesel	10.05→ 0 281 002 332
High-pressure sensor (CR system)	10.05→ 0 281 002 405
Boost pressure sensor, Diesel	10.05→ 0 281 002 514
Temperature sensor, coolant, diesel	10.05→ 0 281 002 170

Daily, Grinta	
New Daily A45-10 Turbo	2,5l 76 kW 8140.27S.27... 4 Zyl.
Wheel speed sensor, front	07.89-04.96 0 265 050 012
Wheel speed sensor, rear	02.90-02.96 0 265 050 029
New Daily 30-8, 35-8	2,5l 55 kW 8140.07.27... 4 Zyl.
Wheel speed sensor, front	02.91-04.96 0 265 050 012
Wheel speed sensor, rear	02.91-02.96 0 265 050 029
New Daily 35-10 Turbo	2,5l 66,1-68,9 kW 8140.97.27... 4 Zyl.
Wheel speed sensor, front	07.91-04.96 0 265 050 012
Wheel speed sensor, rear	07.91-02.96 0 265 050 029
New Daily 35-10 Turbo I.D.	2,5l 80 kW 8140.47R.2790 4 Zyl.
Air flow sensor, diesel	07.92-04.97 0 281 002 087
Pulse generator, diesel	07.92-04.97 0 281 002 089
Temperature sensor, coolant, diesel	07.92-04.97 0 280 130 026
Pedal position sensor, diesel	07.92-04.97 0 205 001 201
Wheel speed sensor, front	07.92-04.97 0 265 050 012
Wheel speed sensor, rear	07.92-02.96 0 265 050 029
New Daily 40-8	2,5l 55 kW 8140.07.27... 4 Zyl.
Wheel speed sensor, front	07.89-04.96 0 265 050 012
Wheel speed sensor, rear	02.90-02.96 0 265 050 029
New Daily 40-10 Turbo 4x4	2,5l 76 kW 8140.27S.28... 4 Zyl.
Wheel speed sensor, front	09.89-04.96 0 265 050 012
Wheel speed sensor, rear	02.90-02.96 0 265 050 029
Turbo Daily A45-12 Turbo	2,5l 85 kW 8140.47.27... 4 Zyl.
Wheel speed sensor, front	06.90-04.96 0 265 050 012
Wheel speed sensor, rear	06.90-02.96 0 265 050 029
Turbo Daily 35-10 Turbo	2,5l 80 kW 8140.47R... 4 Zyl.
Wheel speed sensor, rear	
Fg.no. →5115972	07.92-04.97 0 265 050 026
Turbo Daily 35-10 Turbo	2,8l 76 kW 8140.23.37...; 8140.23.3713 4 Zyl.
Wheel speed sensor, rear	
Fg.no. →5115972	05.96-05.99 0 265 050 026
Turbo Daily 35-12 Turbo	2,5l 85 kW 8140.47.27... 4 Zyl.
Wheel speed sensor, front	10.90-04.96 0 265 050 012
Wheel speed sensor, rear	10.90-02.96 0 265 050 029
Turbo Daily 49-12 Turbo	2,5l 85 kW 8140.47.27... 4 Zyl.
Wheel speed sensor, front	06.90-04.96 0 265 050 012
Wheel speed sensor, rear	06.90-02.96 0 265 050 029
Turbo Daily 59-12 Turbo	2,5l 85 kW 8140.47.27... 4 Zyl.
Wheel speed sensor, front	05.91-04.96 0 265 050 012
Wheel speed sensor, rear	05.91-02.96 0 265 050 029

Scudato	
60.13	2,8l 92 kW 8140.43S 4 Zyl.
Speed sensor, diesel	10.05→ 0 281 002 332
High-pressure sensor (CR system)	10.05→ 0 281 002 405
Boost pressure sensor, Diesel	10.05→ 0 281 002 514
Temperature sensor, coolant, diesel	10.05→ 0 281 002 170

Product				

JAGUAR

Daimler	
3.6	3,6l 136/165 kW ; AJ6.4 6 Zyl.
Wheel speed sensor, front	10.86-08.89 LAB 0 265 001 095
	RAB 0 265 001 094
Wheel speed sensor, rear	10.86-08.89 0 265 001 096

Sovereign	
2.9	2,9l 104 kW AJ 6 6 Zyl.
Throttle valve sensor	10.86-08.90 0 280 120 301
Air mass meter, gasoline injection	10.86-08.90 0 280 213 001
Pulse generator, ignition/Jetronic	10.86-08.90 0 261 210 041
Temperature sensor, coolant, injection system	10.86-08.90 0 280 130 032
Wheel speed sensor, front	10.86-08.90 LAB 0 265 001 095
	RAB 0 265 001 094
Wheel speed sensor, rear	10.86-08.90 0 265 001 096
2.9	2,9l 123 kW AJ 6 6 Zyl.
Throttle valve sensor	10.86-08.90 0 280 120 301
Air mass meter, gasoline injection	10.86-08.90 0 280 213 001
Temperature sensor, coolant, injection system	10.86-08.90 0 280 130 032
Wheel speed sensor, front	10.86-08.90 LAB 0 265 001 095
	RAB 0 265 001 094
Wheel speed sensor, rear	10.86-08.90 0 265 001 096
3.6	3,6l 135/170 kW AJ6.4 6 Zyl.
Wheel speed sensor, front	10.86-08.89 LAB 0 265 001 095
	RAB 0 265 001 094
Wheel speed sensor, rear	10.86-08.89 0 265 001 096

XJ S Coupé	
5.3	5,3l 183 kW 12 Zyl.
Relay, Jetronic	07.81-12.89 0 332 014 113
	DID 0 332 014 112
5.3	5,3l 183 kW HE V12 12 Zyl.
Relay, Jetronic	07.81-12.87 0 332 014 411
5.3 V12	5,3l 222-227 kW 12 Zyl.
Relay, Jetronic	03.90-12.97 0 332 014 113
	DID 0 332 014 112

XJ 6	
2.9	2,9l 110 kW AJ 6 6 Zyl.
Throttle valve sensor	10.86-12.88 0 280 120 301
Air mass meter, gasoline injection	10.86-12.88 0 280 213 001
Pulse generator, ignition/Jetronic	10.86-12.88 0 261 210 041
Temperature sensor, coolant, injection system	10.86-12.88 0 280 130 032
Wheel speed sensor, front	
Fg.no. →594575	10.86-12.88 LAB 0 265 001 095
	RAB 0 265 001 094
Wheel speed sensor, rear	
Fg.no. →594575	10.86-12.88 0 265 001 096
2.9	2,9l 123 kW AJ 6 6 Zyl.
Throttle valve sensor	10.86-08.90 0 280 120 301
Air mass meter, gasoline injection	10.86-08.90 0 280 213 001
Temperature sensor, coolant, injection system	10.86-08.90 0 280 130 032
Wheel speed sensor, front	
Fg.no. →594575	10.86-08.90 LAB 0 265 001 095
	RAB 0 265 001 094

Product



Wheel speed sensor, rear			
Fg.no. →594575	10.86-08.90		0 265 001 096
3.2 24V	3,2l	146-149 kW	9BPMNA 6 Zyl.
Wheel speed sensor, front	10.90-09.94	LAB	0 265 001 095
		RAB	0 265 001 094
Wheel speed sensor, rear	10.90-09.94		0 265 001 096
3.6	3,6l	136/170 kW	AJ6.4 6 Zyl.
Wheel speed sensor, front	10.86-08.89	LAB	0 265 001 095
		RAB	0 265 001 094
Wheel speed sensor, rear	10.86-08.89		0 265 001 096
4.2	4,2l	147 kW	6 Zyl.
Air flow sensor, gasoline injection	S 03.79-10.86		0 280 203 006
			0 986 280 022
Air mass meter, gasoline injection	03.79-10.86		0 280 203 005
			0 986 280 047
Relay, Jetronic	03.79-10.86		0 332 014 113
4.2	4,2l	147-151 kW	6 Zyl.
Air flow sensor, gasoline injection	03.79-10.86		0 280 203 006
			0 986 280 022
Relay, Jetronic	03.79-10.86		0 332 014 113

XJ 12

5.3 HE	5,3l	183 kW	12 Zyl.
Relay, Jetronic	07.81-09.94	DID	0 332 014 112
Wheel speed sensor, front	01.90-09.94	LAB	0 265 001 270
		RAB	0 265 001 269
Wheel speed sensor, rear	01.90-09.94	LAB	0 265 001 272
		RAB	0 265 001 271
5.3 HE	5,3l	194 kW	12 Zyl.
Relay, Jetronic	07.81-09.94		0 332 014 411
Wheel speed sensor, front	01.90-09.94	LAB	0 265 001 270
		RAB	0 265 001 269
Wheel speed sensor, rear	01.90-09.94	LAB	0 265 001 272
		RAB	0 265 001 271
5.3 HE	5,3l	197-198 kW	12 Zyl.
Wheel speed sensor, front	01.90-09.94	LAB	0 265 001 270
		RAB	0 265 001 269
Wheel speed sensor, rear	01.90-09.94	LAB	0 265 001 272
		RAB	0 265 001 271

X-Type

2.0 [CF1]	2,1l	115 kW	2.1IV6 6 Zyl.
Wheel speed sensor, front	03.02→		0 265 007 879
Wheel speed sensor, rear	03.02→	AA	0 265 007 879
		LAB,NAA	0 265 007 417
		NAA,RAB	0 265 007 404
2.0 D [CF1]	2,0l	96 kW	R4-X404 4 Zyl.
Wheel speed sensor, front	09.03→		0 265 007 879
Wheel speed sensor, rear	09.03→	AA	0 265 007 879
		LAB,NAA	0 265 007 417
		NAA,RAB	0 265 007 404
2.5 [CF1]	2,5l	145 kW	6 Zyl.
Wheel speed sensor, front	03.01→		0 265 007 879
Wheel speed sensor, rear	03.01→	AA	0 265 007 879
		LAB,NAA	0 265 007 417
		NAA,RAB	0 265 007 404
3.0 [CF1]	3,0l	169-172 kW	AJ-V6 6 Zyl.
Wheel speed sensor, front	03.01→		0 265 007 879
Wheel speed sensor, rear	03.01→	AA	0 265 007 879
		LAB,NAA	0 265 007 417
		NAA,RAB	0 265 007 404

Product



X-Type Estate

2.0 [CF1]	2,1l	115 kW	2.1IV6 6 Zyl.
Wheel speed sensor, front	03.03→		0 265 007 879
Wheel speed sensor, rear	03.03→	AA	0 265 007 879
		LAB,NAA	0 265 007 417
		NAA,RAB	0 265 007 404
2.0 D [CF1]	2,0l	96 kW	R4-X404 4 Zyl.
Wheel speed sensor, front	09.03→		0 265 007 879
Wheel speed sensor, rear	09.03→	AA	0 265 007 879
		LAB,NAA	0 265 007 417
		NAA,RAB	0 265 007 404
2.5 [CF1]	2,5l	145 kW	6 Zyl.
Wheel speed sensor, front	09.03→		0 265 007 879
Wheel speed sensor, rear	09.03→	AA	0 265 007 879
		LAB,NAA	0 265 007 417
		NAA,RAB	0 265 007 404
3.0 [CF1]	3,0l	169-172 kW	AJ-V6 6 Zyl.
Wheel speed sensor, front	09.03→		0 265 007 879
Wheel speed sensor, rear	09.03→	AA	0 265 007 879
		LAB,NAA	0 265 007 417
		NAA,RAB	0 265 007 404

JEEP

Cherokee

2.5 D Turbo [XJ]	2,5l	85-89 kW	ENC,ENO 4 Zyl.
Temperature sensor, coolant, diesel	10.95-12.01		0 280 130 055

KIA

Avella

1.3 i	1,3l	54 kW	B3 4 Zyl.
Throttle valve sensor	03.94→		0 280 122 001

Capital

1.5 i	1,5l	85 kW	B5D 4 Zyl.
Throttle valve sensor	05.90-06.95		0 280 120 316
Air flow sensor, gasoline injection	05.90-06.95		0 280 202 125
Position sensor for TDC	05.90-06.95		0 356 914 224
Speed sensor, ignition/injection	05.90-06.95		0 261 210 065
Temperature sensor, coolant, injection system	05.90-06.95		0 280 130 026
Relay, Jetronic	05.90-05.93		0 332 019 150
Relay, pump	05.90-04.93		0 332 019 453

Carens II

2.0 CRDi	2,0l	85 kW	4 Zyl.
Air mass meter, diesel	02.02-04.06		0 281 002 447

Carnival II

2.9 CRDi	2,9l	107 kW	J3 4 Zyl.
Air mass meter, diesel	01.02-03.06		0 281 002 554





Product				

Clarus I		
1.8 16V [GC]	1,8l 85 kW T8D 4 Zyl.	
Air mass meter, gasoline injection	05.96-05.98	0 280 217 116
Speed sensor, ignition/injection	05.96-05.98	0 261 210 104
1.8 16V [GC]	1,8l 92 kW T8D 4 Zyl.	
Air mass meter, gasoline injection	05.96-05.98	0 280 217 116
2.0 16V [GC]	2,0l 98/109 kW FE 4 Zyl.	
Air mass meter, gasoline injection	05.96-05.98	0 280 217 116

Opirus		
3.5 V6 [LD]	3,5l 149 kW G6CU 6 Zyl.	
Air mass meter, gasoline injection	09.03→	0 280 218 090

Sephia I		
1.5 i 16V [FA]	1,5l 74 kW B5D 4 Zyl.	
Air mass meter, gasoline injection	10.97-12.00	0 280 217 105
1.6 i [FA]	1,6l 59 kW B6 4 Zyl.	
Position sensor for TDC	07.93-06.95	0 356 914 213
1.8 i 16V [FA]	1,8l 82 kW T8D 4 Zyl.	
Air mass meter, gasoline injection	09.96-12.97	0 280 217 116

Sephia I Hatchback		
1.8 i 16V [FA]	1,8l 82 kW T8D 4 Zyl.	
Air mass meter, gasoline injection	09.96-12.00	0 280 217 116

Sephia I Leo		
1.8 i 16V [FA]	1,8l 104 kW T8D 4 Zyl.	
Throttle valve sensor	09.96-09.97	0 280 122 001
Air mass meter, gasoline injection	09.96-09.97	0 280 217 116
Speed sensor, ignition/injection	09.96-09.97	0 261 210 104

Sorento		
2.5 CRDi	2,5l 107 kW 4 Zyl.	
Air mass meter, diesel	05.00→	0 281 002 554
2.5 CRDi [JC]	2,5l 103 kW D4CB 4 Zyl.	
Air mass meter, diesel	07.02→	0 281 002 554
3.5 i V6 [JC]	3,5l 144 kW G6CU 6 Zyl.	
Air mass meter, gasoline injection	03.03→	0 280 218 090

Sportage		
2.0 i 4WD [JA]	2,0l 70 kW FED 4 Zyl.	
Throttle valve sensor	07.93-09.98	0 280 122 001
Air mass meter, gasoline injection	07.93-09.98	0 280 217 105
Relay, pump	07.93-09.98	0 332 019 151
2.0 i 4WD [JA]	2,0l 73 kW FED 4 Zyl.	
Throttle valve sensor	07.93-08.04	0 280 122 001
Air mass meter, gasoline injection	07.93-08.04	0 280 217 105
Speed sensor, ignition/injection	07.93-08.04	0 261 210 065
Relay, pump	07.93-08.04	0 332 019 151
2.0 i 4WD [JA]	2,0l 94 kW FED 4 Zyl.	
Throttle valve sensor	04.94-10.98	0 280 122 001
Air mass meter, gasoline injection	04.94-10.98	0 280 217 105
Relay, pump	04.94-10.98	0 332 019 151
2.0 TD 4WD	2,0l 61 kW RF 4 Zyl.	
Speed sensor, diesel	11.96-10.98	0 261 210 104

Product				

LADA		
Kalina		
1.4	1,4l 65,5 kW 11194 4 Zyl.	
Air mass meter, gasoline injection	07.07→	0 280 218 116
1.6	1,6l 59,5/65,5 kW 21114-50; 21114-90; 21124 4 Zyl.	
Air mass meter, gasoline injection	11.04→	0 280 218 116

Kalina Hatchback		
1.4	1,4l 65,5 kW 11194 4 Zyl.	
Air mass meter, gasoline injection	07.07→	0 280 218 116
1.6	1,6l 59,5 kW 21114-50 4 Zyl.	
Air mass meter, gasoline injection	07.06→	0 280 218 116

Kalina Kombi		
1.4	1,4l 65,5 kW 11194 4 Zyl.	
Air mass meter, gasoline injection	07.07→	0 280 218 116
1.6	1,6l 59,5 kW 21114-50 4 Zyl.	
Air mass meter, gasoline injection	07.07→	0 280 218 116

Niva		
1.7 i	1,7l 59-62 kW VAZ 2121.4 4 Zyl.	
Air mass meter, gasoline injection	07.96-12.99 BO,WW	0 280 218 004
1.7 i	1,7l 60/62 kW VAZ; VAZ 2121.3 4 Zyl.	
Air mass meter, gasoline injection	07.99-12.00	0 280 218 004

Priora		
1.6	1,6l 72 kW 21126 4 Zyl.	
Air mass meter, gasoline injection	11.06→	0 280 218 116

Samara		
1.3 i	1,3l 50 kW 2108 4 Zyl.	
Air mass meter, gasoline injection	02.96→	0 280 218 004
1.5 i	1,5l 50/52/60 kW 2111 4 Zyl.	
Air mass meter, gasoline injection	09.91→ BO,WW	0 280 218 004

Samara Hatchback		
1.5 i	1,5l 57 kW 2111 4 Zyl.	
Air mass meter, gasoline injection	01.84→ BO,WW	0 280 218 004

Serie 110		
1.5	1,5l 54 kW 2110 4 Zyl.	
Air mass meter, gasoline injection	01.96-12.00	0 280 218 004
1.5 i 8V	1,5l 56/57 kW 2111-14/16; 2111/2111-12 4 Zyl.	
Air mass meter, gasoline injection	01.96→ BO,WW	0 280 218 004
1.5 i 16V	1,5l 67/69 kW 2112/-10; 2112/-10,-14; 2112-70/76 4 Zyl.	
Air mass meter, gasoline injection	01.96→ BO,WW	0 280 218 004
1.5 16V Premier	1,5l 68 kW 2112 4 Zyl.	
Air mass meter, gasoline injection	06.99-12.00 BO,WW	0 280 218 004
2.0 GTI	2,0l 110 kW C20XE 4 Zyl.	
Wheel speed sensor, front	01.97-12.00	0 265 006 330
Wheel speed sensor, rear	01.97-12.00	0 265 002 276



2.0 16V	2,0l 110 kW C20XE 4 Zyl.
Wheel speed sensor, front	01.96-12.00 0 265 006 330
Wheel speed sensor, rear	01.96-12.00 0 265 002 276

Serie 111

1.5 i	1,5l 57-58 kW 2111 4 Zyl.
Air mass meter, gasoline injection	01.96→ BO,WW 0 280 218 004
1.5 i 8V	1,5l 57 kW 2111-14 4 Zyl.
Air mass meter, gasoline injection	01.96→ BO,WW 0 280 218 004
1.5 i 16V	1,5l 67/69/70 kW 2112; 2112-10; 2112-10/16 4 Zyl.
Air mass meter, gasoline injection	01.96→ BO,WW 0 280 218 004

Serie 112

1.5 i	1,5l 54 kW 4 Zyl.
Air mass meter, gasoline injection	01.96→ BO,WW 0 280 218 004
1.5 i 8V	1,5l 56/57 kW 2111-14; 2111/2111-12 4 Zyl.
Air mass meter, gasoline injection	01.96→ BO,WW 0 280 218 004
1.5 i 16V	1,5l 66/67/69 kW 2112; 2112-10 4 Zyl.
Air mass meter, gasoline injection	01.96→ BO,WW 0 280 218 004

Serie 115

1.3 i	1,3l 47 kW 2114 4 Zyl.
Air mass meter, gasoline injection	01.00→ 0 280 218 004
1.5 i	1,5l 57 kW 2114 4 Zyl.
Air mass meter, gasoline injection	01.00→ 0 280 218 004

LAMBORGHINI (S+L+H)

Countach

Quattrovalvole	5,2l 309 kW L 507 V4l 12 Zyl.
Air flow sensor, gasoline injection	09.85-07.90 0 438 120 098

LANCIA

Dedra Berlina

1.6 i [835]	1,6l 55 kW 835C1.000 Kat 4 Zyl.
Speed sensor, ignition/injection	04.93-10.94 0 261 210 103
	04.93-09.93 KL 0 261 210 102
	10.93-10.94 KL 0 261 210 115
Temperature sensor, coolant, injection system	04.93-10.94 0 280 130 026
Wheel speed sensor, rear	04.93-10.94 LAB 0 265 001 216
	RAB 0 265 001 217
1.6 i [835]	1,6l 57 kW 835A1.046 Kat 4 Zyl.
Temperature sensor, coolant, injection system	08.89-03.93 0 280 130 026
1.6 i [835]	1,6l 66 kW 159B9.000 MPI-GM 4 Zyl.
Wheel speed sensor, front	10.94-08.95 0 265 001 215
	09.95-04.98 0 265 006 212
Wheel speed sensor, rear	09.95-04.98 0 265 006 197
	10.94-08.95 LAB 0 265 001 216
	RAB 0 265 001 217
1.6 i 16V [835]	1,6l 76 kW 182A4.000 MPI-Weber 4 Zyl.
Wheel speed sensor, front	04.98-10.99 0 265 006 212
Wheel speed sensor, rear	04.98-10.99 0 265 006 197
1.8 i [835]	1,8l 74 kW 836A5.000 MPI-Weber 4 Zyl.
Wheel speed sensor, front	10.94-08.95 0 265 001 215
	09.95-12.95 0 265 006 212



Wheel speed sensor, rear	09.95-12.95	0 265 006 197
	10.94-08.95 LAB	0 265 001 216
	RAB	0 265 001 217

1.8 i [835]	1,8l 77 kW 835A2.046 Kat 4 Zyl.
Wheel speed sensor, front	04.93-10.94 0 265 001 215
Wheel speed sensor, rear	04.93-10.94 LAB 0 265 001 216
	RAB 0 265 001 217

1.8 i 16V [835]	1,8l 97 kW 183A1.000 MPI-Hit. 4 Zyl.
Wheel speed sensor, front	01.96-10.99 0 265 006 212
Wheel speed sensor, rear	01.96-10.99 0 265 006 197

1.9 TD [835]	1,9l 66 kW 835A4.000 4 Zyl.
Wheel speed sensor, front	01.89-10.94 0 265 001 215
Wheel speed sensor, rear	01.89-10.94 LAB 0 265 001 216
	RAB 0 265 001 217

1.9 TD [835]	1,9l 66 kW 835A4.000/160D1.000 4 Zyl.
Wheel speed sensor, front	09.95-10.99 0 265 006 212
Wheel speed sensor, rear	10.94-10.99 0 265 006 197

2.0 i [835]	2,0l 83/86 kW 835A5.000 MPI-Weber; 835A5.046 Kat 4 Zyl.
Wheel speed sensor, front	01.89-10.94 0 265 001 215
Wheel speed sensor, rear	01.89-10.94 LAB 0 265 001 216
	RAB 0 265 001 217

2.0 i [835]	2,0l 119/132 kW 835A8.000 MPI-Weber; 835A8.046 Kat 4 Zyl.
Acceleration sensor, ABS	06.90-07.92 0 265 005 030
Lateral acceleration sensor, brake system	06.90-10.94 0 265 005 031
Wheel speed sensor, front	06.90-10.94 0 265 006 212
Wheel speed sensor, rear	06.90-10.94 0 265 006 197

2.0 i Automatic [835]	2,0l 83 kW 835A5.046 Kat 4 Zyl.
Wheel speed sensor, front	10.94-08.95 0 265 001 215
Wheel speed sensor, rear	10.94-08.95 LAB 0 265 001 216
	RAB 0 265 001 217

2.0 i 4x4 Integrale [835]	2,0l 121/124 kW 835A7.000; 835A7.046 Kat 4 Zyl.
Wheel speed sensor, front	06.90-10.94 0 265 001 215
Wheel speed sensor, rear	06.90-10.94 0 265 001 304

2.0 i 16V [835]	2,0l 102 kW 836A3.000 MPI-Weber 4 Zyl.
Wheel speed sensor, front	09.95-10.99 0 265 006 212
Wheel speed sensor, rear	10.94-10.99 0 265 006 197

Dedra Station Wagon

1.6 i [835]	1,6l 66 kW 159B9.000 MPI-GM 4 Zyl.
Wheel speed sensor, front	10.94-08.95 0 265 001 215
	09.95-04.98 0 265 006 212
	0 265 006 197
Wheel speed sensor, rear	09.95-04.98 0 265 006 197
	10.94-08.95 LAB 0 265 001 216
	RAB 0 265 001 217

1.6 i 16V [835]	1,6l 76 kW 182A4.000 MPI-Weber 4 Zyl.
Wheel speed sensor, front	04.98-10.99 0 265 006 212
Wheel speed sensor, rear	04.98-10.99 0 265 006 197


1.8 i [835]	1,8l 74 kW 836A5.000 MPI-Weber 4 Zyl.
Wheel speed sensor, front	10.94-08.95 0 265 001 215
	09.95-12.95 0 265 006 212
	0 265 006 197
Wheel speed sensor, rear	09.95-12.95 0 265 006 197
	10.94-08.95 LAB 0 265 001 216
	RAB 0 265 001 217

1.8 i 16V [835]	1,8l 83/97 kW 182A2.000 MPI-Hit.; 183A1.000 MPI-Hit. 4 Zyl.
Wheel speed sensor, front	01.96-10.99 0 265 006 212
Wheel speed sensor, rear	01.96-10.99 0 265 006 197

1.9 TD [835]	1,9l 66 kW 835A4.000/160D1.000 4 Zyl.
Wheel speed sensor, front	09.95-10.99 0 265 006 212
Wheel speed sensor, rear	10.94-10.99 0 265 006 197

2.0 i 16V, i 16V 4x4 [835]	2,0l 102 kW 836A3.000 MPI-Weber 4 Zyl.
Wheel speed sensor, front	09.95-10.99 0 265 006 212
Wheel speed sensor, rear	10.94-10.99 0 265 006 197





Product

Delta

1.4 i [836 Nuova D.]	1,4l	51 kW	160A1.046 SPI-Bosch	4 Zyl.
Speed sensor, ignition/injection	01.93-04.94			0 261 210 115
Temperature sensor, coolant, injection system	01.93-04.94			0 280 130 026
Wheel speed sensor, front	01.93-04.94			0 265 006 212
Wheel speed sensor, rear	01.93-04.94			0 265 006 197
1.4 i [836 Nuova D.]	1,4l	51 kW	836A4.000 SPI-Bosch	4 Zyl.
Speed sensor, ignition/injection	04.94-12.99			0 261 210 115
			KL	0 261 210 118
Temperature sensor, coolant, injection system	04.94-12.99			0 280 130 026
Wheel speed sensor, front	09.95-12.99			0 265 006 162
	04.94-08.95			0 265 006 212
Wheel speed sensor, rear	04.94-12.99			0 265 006 197
1.6 i [836 Nuova D.]	1,6l	55 kW	835C1.000 SPI-Bosch	4 Zyl.
Speed sensor, ignition/injection	01.93-09.93			0 261 210 103
	10.93-12.99			0 261 210 118
	01.93-09.93		KL	0 261 210 102
	10.93-12.99		KL	0 261 210 115
Temperature sensor, coolant, injection system	01.93-12.99			0 280 130 026
Wheel speed sensor, front	09.95-12.99			0 265 006 162
	01.93-08.95			0 265 006 212
Wheel speed sensor, rear	01.93-12.99			0 265 006 197
1.6 i 16V HPE [836 Nuova D.]	1,6l	66/76 kW	182A4.000, 182A6.000 MPI-Weber	4 Zyl.
Wheel speed sensor, front	01.96-12.99			0 265 006 212
Wheel speed sensor, rear	01.96-12.99			0 265 006 197
1.8 i [836 Nuova D.]	1,8l	66/74/76 kW	835C2.000, 835/836C4.000, 836A5.000, 836A6.000 MPI-Weber	4 Zyl.
Wheel speed sensor, front	09.95-12.99			0 265 006 162
	01.93-08.95			0 265 006 212
Wheel speed sensor, rear	01.93-12.99			0 265 006 197
1.8 i GT 16V [836 Nuova D.]	1,8l	97 kW	183A1.000 MPI-Hit.	4 Zyl.
Wheel speed sensor, front	01.96-12.99			0 265 006 212
Wheel speed sensor, rear	01.96-12.99			0 265 006 197
1.8 i 16V [836 Nuova D.]	1,8l	83 kW	182A2.000 MPI-Hit.	4 Zyl.
Wheel speed sensor, front	01.96-12.99			0 265 006 212
Wheel speed sensor, rear	01.96-12.99			0 265 006 197
1.9 TD [836 Nuova D.]	1,9l	66 kW	160D1.000	4 Zyl.
Wheel speed sensor, front	10.95-12.99			0 265 006 162
Wheel speed sensor, rear	10.95-12.99			0 265 006 197
1.9 TD [836 Nuova D.]	1,9l	66 kW	835A4.000	4 Zyl.
Wheel speed sensor, front	09.95-10.95			0 265 006 162
	07.94-08.95			0 265 006 212
Wheel speed sensor, rear	07.94-10.95			0 265 006 197
2.0 i HF Turbo Int. 4x4 [831]	2,0l	122/126/136 kW	831B5.000/C5.000 MPI-Weber; 831C5.046 Kat	4 Zyl.
Wheel speed sensor, front	05.86-02.89		LAB	0 265 001 246
			RAB	0 265 001 247
Wheel speed sensor, rear	05.86-02.89		LAB	0 265 001 248
			RAB	0 265 001 249
2.0 i Turbo 8V Int. 4x4 [831]	2,0l	126 kW	831C5.046 Kat	4 Zyl.
Wheel speed sensor, front	03.89-12.94		LAB	0 265 001 246
			RAB	0 265 001 247
Wheel speed sensor, rear	03.89-12.94		LAB	0 265 001 248
			RAB	0 265 001 249
2.0 i Turbo 16V Int. 4x4 [831]	2,0l	136 kW	831E5.046 Kat	4 Zyl.
Knock sensor	06.91-12.94			0 261 231 095
Wheel speed sensor, front	06.91-12.94		LAB	0 265 001 246
			RAB	0 265 001 247
Wheel speed sensor, rear	06.91-12.94		LAB	0 265 001 248
			RAB	0 265 001 249



Product

2.0 i Turbo 16V Int. 4x4 [831]	2,0l	144-147 kW	831E5.000 MPI-Weber	4 Zyl.
Wheel speed sensor, front	06.91-12.94		LAB	0 265 001 246
			RAB	0 265 001 247
Wheel speed sensor, rear	06.91-12.94		LAB	0 265 001 248
			RAB	0 265 001 249
2.0 i Turbo 16V Int. 4x4 [831]	2,0l	147 kW	831D5.000 MPI-Weber	4 Zyl.
Acceleration sensor, ABS	03.89-09.91			0 265 005 030
Lateral acceleration sensor, brake system	03.89-09.91			0 265 005 031
Wheel speed sensor, front	03.89-09.91		LAB	0 265 001 246
			RAB	0 265 001 247
Wheel speed sensor, rear	03.89-09.91		LAB	0 265 001 248
			RAB	0 265 001 249
2.0 i 16V [836 Nuova D.]	2,0l	102 kW	836A3.000 MPI-Weber	4 Zyl.
Knock sensor	01.93-12.95			0 261 231 102
Wheel speed sensor, front	09.95-12.95			0 265 006 162
	01.93-08.95			0 265 006 212
Wheel speed sensor, rear	01.93-12.95			0 265 006 197
2.0 i 16V Turbo HPE [836 Nuova D.]	2,0l	137 kW	175A4.000 MPI-Weber	4 Zyl.
Wheel speed sensor, front	09.96-12.99			0 265 006 162
Wheel speed sensor, rear	09.96-12.99			0 265 006 197
2.0 i 16V Turbo HPE [836 Nuova D.]	2,0l	137 kW	836A2.000 MPI-Weber	4 Zyl.
Wheel speed sensor, front	09.95-09.96			0 265 006 162
	01.93-08.95			0 265 006 212
Wheel speed sensor, rear	01.93-09.96			0 265 006 197

Kappa Berlina

2.0 i Turbo 16V [838]	2,0l	151 kW	838A4.000	4 Zyl.
Throttle valve sensor	11.94-06.98			0 280 122 001
Air mass meter, gasoline injection	11.94-06.98			0 280 213 025
				0 986 280 114
Phase sensor	11.94-06.98			0 232 101 018
Pulse generator, ignition/Jetronic	11.94-06.98			0 261 210 130
Knock sensor	11.94-06.98			0 261 231 007
Pressure sensor, intake manifold, gasoline	11.94-06.98			0 280 101 001
Temperature sensor, intake air, injection system	11.94-06.98			0 280 130 060
Temperature sensor, coolant, injection system	11.94-06.98			0 280 130 026
Relay, Jetronic	11.94-06.98			0 332 014 140
Wheel speed sensor, front	11.94-06.98			0 265 006 160
Wheel speed sensor, rear				
Fg.no. 2059704→	11.94-06.98			0 265 007 040
Ricam.no →2059703	11.94-06.98			0 265 006 300
2.0 i Turbo 20V [838]	2,0l	162 kW	175A3.000	5 Zyl.
Throttle valve sensor	06.98-12.00			0 280 122 001
Air mass meter, gasoline injection	06.98-12.00			0 280 217 514
Phase sensor	06.98-12.00			0 232 101 026
Pulse generator, ignition/Jetronic	06.98-12.00			0 261 210 119
Knock sensor	06.98-12.00			0 261 231 095
Pressure sensor, intake manifold, gasoline	06.98-12.00			0 280 101 001
Temperature sensor, intake air, injection system	06.98-12.00			0 280 130 060
Temperature sensor, coolant, injection system	06.98-12.00			0 280 130 026
Relay, Jetronic	06.98-12.00			0 332 014 140
Wheel speed sensor, front	06.98-12.00			0 265 006 160
Wheel speed sensor, rear	06.98-12.00			0 265 007 040
2.0 i 20V [838]	2,0l	110 kW	838A1.000	5 Zyl.
Throttle valve sensor	11.94-06.96			0 280 122 001
			AG	0 280 122 005
Air mass meter, gasoline injection	11.94-06.96			0 280 217 111
Phase sensor	11.94-06.96			0 232 101 026
Pulse generator, ignition/Jetronic	11.94-06.96			0 261 210 119
Knock sensor	11.94-06.96			0 261 231 095
Temperature sensor, intake air, injection system	11.94-06.96			0 280 130 073




Temperature sensor, coolant, injection system	11.94-06.96	0 280 130 026
	AG	0 280 130 032
Relay, Jetronic	11.94-06.96	0 332 014 140
Wheel speed sensor, front	11.94-06.96	0 265 006 160
Wheel speed sensor, rear		
Fg.no. 2059704→	11.94-06.96	0 265 007 040
Ricam.no →2059703	11.94-06.96	0 265 006 300
2.0 i 20V [838]	2,0l 114 kW 838A6.000 5 Zyl.	
Throttle valve sensor	06.96-12.00	0 280 122 001
Air mass meter, gasoline injection	06.96-06.98	0 280 217 111
	06.98-12.00	0 280 218 019
Phase sensor	06.96-06.98	0 232 101 026
	06.98-12.00	0 232 101 036
Speed sensor, ignition/injection	06.98-12.00	0 261 210 160
Pulse generator, ignition/Jetronic	06.96-06.98	0 261 210 119
Knock sensor	06.96-06.98	0 261 231 095
	06.98-12.00	0 261 231 144
Temperature sensor, intake air, injection system	06.96-12.00	0 280 130 073
Temperature sensor, coolant, injection system	06.96-12.00	0 280 130 026
Pedal position sensor, EMS (electronic engine management)	06.98-12.00	0 281 002 202
Relay, Jetronic	06.96-12.00	0 332 014 140
Wheel speed sensor, front	06.96-06.98	0 265 006 160
	06.98-12.00 LAB	0 265 007 041
	RAB	0 265 007 042
Wheel speed sensor, rear	06.96-12.00	0 265 007 040
2.4 i 20V [838]	2,4l 129 kW 838A2.000 5 Zyl.	
Throttle valve sensor	11.94-06.98	0 280 122 001
Air mass meter, gasoline injection	11.94-06.98	0 280 217 111
Phase sensor	11.94-06.98	0 232 101 026
Pulse generator, ignition/Jetronic	11.94-06.98	0 261 210 119
Knock sensor	11.94-06.98	0 261 231 095
Temperature sensor, intake air, injection system	11.94-06.98	0 280 130 073
Temperature sensor, coolant, injection system	11.94-06.98	0 280 130 026
Relay, Jetronic	11.94-06.98	0 332 014 140
Wheel speed sensor, front	11.94-06.98	0 265 006 160
Wheel speed sensor, rear		
Fg.no. 2059704→	11.94-06.98	0 265 007 040
Ricam.no →2059703	11.94-06.98	0 265 006 300
2.4 i 20V [838]	2,4l 129 kW 838B2.000 5 Zyl.	
Throttle valve sensor	06.98-12.00	0 280 122 001
Air mass meter, gasoline injection	06.98-12.00	0 280 218 019
Phase sensor	06.98-12.00	0 232 101 036
Speed sensor, ignition/injection	06.98-12.00	0 261 210 160
Knock sensor	06.98-12.00	0 261 231 144
Temperature sensor, intake air, injection system	06.98-12.00	0 280 130 073
Temperature sensor, coolant, injection system	06.98-12.00	0 280 130 026
Pedal position sensor, EMS (electronic engine management)	06.98-12.00	0 281 002 202
Relay, Jetronic	06.98-12.00	0 332 014 140
Wheel speed sensor, front	06.98-12.00 LAB	0 265 007 041
	RAB	0 265 007 042
Wheel speed sensor, rear	06.98-12.00	0 265 007 040
2.4 JTD [838]	2,4l 100 kW 838A8.000 5 Zyl.	
Air mass meter, diesel	03.98-12.00	0 280 218 019
Speed sensor, diesel	03.98-12.00	0 281 002 214
Phase sensor	03.98-12.00	0 281 002 213
High-pressure sensor (CR system)	03.98-12.00	0 281 002 210
Boost pressure sensor, Diesel	03.98-12.00	0 281 002 215
Temperature sensor, fuel	03.98-12.00 2PO	0 281 002 209
Pedal position sensor, diesel	03.98-12.00	0 281 002 202



Wheel speed sensor, front	03.98-12.00 LAB	0 265 007 041
	RAB	0 265 007 042
Wheel speed sensor, rear	03.98-12.00	0 265 007 040
2.4 TD [838]	2,4l 91 kW 838A3.000; 838A7.000 5 Zyl.	
Air flow sensor, diesel	11.94-03.98	0 281 002 085
Pulse generator, diesel	11.94-03.98	0 261 210 119
Temperature sensor, coolant, diesel	11.94-03.98	0 280 130 026
Pedal position sensor, diesel	11.94-03.98	0 205 001 010
Wheel speed sensor, front	11.94-03.98	0 265 006 160
Wheel speed sensor, rear		
Fg.no. 2059704→	11.94-03.98	0 265 007 040
Ricam.no →2059703	11.94-03.98	0 265 006 300
3.0 i 24V [838]	3,0l 150 kW 838B.000 6 Zyl.	
Throttle valve sensor	11.94-12.00	0 280 122 001
Air mass meter, gasoline injection	11.94-06.98	0 280 217 514
Fg.no. →2088054	06.98-12.99	0 280 217 514
Fg.no. 2088054→	12.99-12.00	0 280 217 531
Phase sensor	11.94-12.00	0 232 103 009
Pulse generator, ignition/Jetronic	11.94-12.00	0 261 210 113
Knock sensor	11.94-12.00	0 261 231 007
Temperature sensor, intake air, injection system	11.94-12.00	0 280 130 073
Temperature sensor, coolant, injection system	11.94-12.00	0 280 130 026
Wheel speed sensor, front	11.94-06.98	0 265 006 160
	06.98-12.00 LAB	0 265 007 041
	RAB	0 265 007 042
Wheel speed sensor, rear		
Fg.no. →2059704	11.94-12.00	0 265 006 300
Fg.no. 2059704→	11.94-12.00	0 265 007 040
3.0 i 24V [838]	3,0l 150 kW 838.000 6 Zyl.	
Throttle valve sensor	06.98-12.00	0 280 122 001
Air mass meter, gasoline injection		
Fg.no. →2092370	06.98-12.00	0 280 217 514
Fg.no. 2092371→	06.98-12.00	0 280 217 531
Pulse generator, ignition/Jetronic	06.98-12.00	0 261 210 113
Knock sensor	06.98-12.00	0 261 231 007
Temperature sensor, intake air, injection system	06.98-12.00	0 280 130 073
Temperature sensor, coolant, injection system	06.98-12.00	0 280 130 026
Wheel speed sensor, front	06.98-12.00	0 265 006 160
Wheel speed sensor, rear		
Fg.no. →2059704	06.98-12.00	0 265 006 300
Fg.no. 2059704→	06.98-12.00	0 265 007 040

Kappa Coupé

2.0 i Turbo 16V [838]	2,0l 151 kW 834A4.000 MPI-Bosch 4 Zyl.	
Throttle valve sensor	04.97-06.98	0 280 122 001
Air mass meter, gasoline injection	04.97-06.98	0 280 213 025
		0 986 280 114
Phase sensor	04.97-06.98	0 261 210 093
Knock sensor	04.97-06.98	0 261 231 095
Temperature sensor, coolant, injection system	04.97-06.98	0 280 130 026
Relay, Jetronic	04.97-06.98	0 332 014 140
Wheel speed sensor, front	04.97-06.98	0 265 006 160
Wheel speed sensor, rear	04.97-06.98	0 265 006 300
2.0 i Turbo 20V [838]	2,0l 162 kW 175A3.000 MPI-Bosch 5 Zyl.	
Throttle valve sensor	06.98-06.00	0 280 122 001
Air mass meter, gasoline injection	06.98-06.00	0 280 217 514
Phase sensor	06.98-06.00	0 232 101 026
Pulse generator, ignition/Jetronic	06.98-06.00	0 261 210 119
Knock sensor	06.98-06.00	0 261 231 095
Pressure sensor, intake manifold, gasoline	06.98-06.00	0 280 101 001
Temperature sensor, intake air, injection system	06.98-06.00	0 280 130 060
Temperature sensor, coolant, injection system	06.98-06.00	0 280 130 026



Product



◀ Kappa Coupé

Relay, Jetronic	06.98-06.00		0 332 014 140
Wheel speed sensor, front	06.98-06.00	LAB	0 265 007 041
		RAB	0 265 007 042
Wheel speed sensor, rear	06.98-06.00		0 265 007 040
2.4 i 20V [838]	2,4l 129 kW 838A2.000 MPI-RB 5 Zyl.		
Throttle valve sensor	04.97-06.98		0 280 122 001
Air mass meter, gasoline injection	04.97-06.98		0 280 217 111
Phase sensor	04.97-06.98		0 232 101 026
Pulse generator, ignition/Jetronic	04.97-06.98		0 261 210 119
Knock sensor	04.97-06.98		0 261 231 095
Temperature sensor, intake air, injection system	04.97-06.98		0 280 130 073
Temperature sensor, coolant, injection system	04.97-06.98		0 280 130 026
Relay, Jetronic	04.97-06.98		0 332 014 140
Wheel speed sensor, front	04.97-06.98		0 265 006 160
Wheel speed sensor, rear	04.97-06.98		0 265 007 040
2.4 i 20V [838]	2,4l 129 kW 838B2.000 MPI-RB 5 Zyl.		
Throttle valve assembly	06.98-06.00		0 205 003 052
Throttle valve sensor	06.98-06.00		0 280 122 001
Air mass meter, gasoline injection	06.98-06.00		0 280 218 019
Phase sensor	06.98-06.00		0 232 101 026
Pulse generator, ignition/Jetronic	06.98-06.00		0 261 210 119
Knock sensor	06.98-06.00		0 261 231 095
Temperature sensor, intake air, injection system	06.98-06.00		0 280 130 073
Temperature sensor, coolant, injection system	06.98-06.00		0 280 130 026
Relay, Jetronic	06.98-06.00		0 332 014 140
Wheel speed sensor, front	06.98-06.00	LAB	0 265 007 041
		RAB	0 265 007 042
Wheel speed sensor, rear	06.98-06.00		0 265 007 040
3.0 i 24V V6 [838]	3,0l 150 kW 838B.000 MPI-RB 6 Zyl.		
Throttle valve sensor	04.97-06.00		0 280 122 001
Air mass meter, gasoline injection	04.97-06.00		0 280 217 514
Phase sensor	04.97-06.00		0 232 103 009
Pulse generator, ignition/Jetronic	04.97-06.00		0 261 210 113
Knock sensor	04.97-06.00		0 261 231 007
Temperature sensor, intake air, injection system	04.97-06.00		0 280 130 073
Temperature sensor, coolant, injection system	04.97-06.00		0 280 130 026
Wheel speed sensor, front	04.97-06.98		0 265 006 160
	06.98-06.00	LAB	0 265 007 041
		RAB	0 265 007 042
Wheel speed sensor, rear	04.97-06.98		0 265 006 300
	07.98-06.00		0 265 007 040


Kappa Station Wagon

2.0 i Turbo 16V [838]	2,0l 151 kW 838A4.000 4 Zyl.		
Throttle valve sensor	11.94-06.98		0 280 122 001
Air mass meter, gasoline injection	11.94-06.98		0 280 213 025
			0 986 280 114
Phase sensor	11.94-06.98		0 232 101 018
Pulse generator, ignition/Jetronic	11.94-06.98		0 261 210 130
Knock sensor	11.94-06.98		0 261 231 007
Pressure sensor, intake manifold, gasoline	11.94-06.98		0 280 101 001
Temperature sensor, intake air, injection system	11.94-06.98		0 280 130 060
Temperature sensor, coolant, injection system	11.94-06.98		0 280 130 026
Relay, Jetronic	11.94-06.98		0 332 014 140
Wheel speed sensor, front	11.94-06.98		0 265 006 160
Wheel speed sensor, rear			
Fg.no. 2059704→	11.94-06.98		0 265 007 040
			0 265 006 300
Ricam.no →2059703	11.94-06.98		0 265 006 300
2.0 i Turbo 20V [838]	2,0l 162 kW 175A3.000 5 Zyl.		
Throttle valve sensor	06.98-12.00		0 280 122 001
Air mass meter, gasoline injection	06.98-12.00		0 280 217 514
Phase sensor	06.98-12.00		0 232 101 026

Product



Pulse generator, ignition/Jetronic	06.98-12.00		0 261 210 119
Knock sensor	06.98-12.00		0 261 231 095
Pressure sensor, intake manifold, gasoline	06.98-12.00		0 280 101 001
Temperature sensor, intake air, injection system	06.98-12.00		0 280 130 060
Temperature sensor, coolant, injection system	06.98-12.00		0 280 130 026
Relay, Jetronic	06.98-12.00		0 332 014 140
Wheel speed sensor, front	06.98-12.00		0 265 006 160
Wheel speed sensor, rear	06.98-12.00		0 265 007 040
			0 265 006 300
2.0 i 20V [838]	2,0l 114 kW 838A6.000 5 Zyl.		
Throttle valve sensor	06.96-12.00		0 280 122 001
Air mass meter, gasoline injection	06.96-06.98		0 280 217 111
	06.98-12.00		0 280 218 019
Phase sensor	06.96-06.98		0 232 101 026
	06.98-12.00		0 232 101 036
Speed sensor, ignition/injection	06.98-12.00		0 261 210 160
Pulse generator, ignition/Jetronic	06.96-06.98		0 261 210 119
Knock sensor	06.96-06.98		0 261 231 095
	06.98-12.00		0 261 231 144
Temperature sensor, intake air, injection system	06.96-12.00		0 280 130 073
Temperature sensor, coolant, injection system	06.96-12.00		0 280 130 026
Pedal position sensor, EMS (electronic engine management)	06.98-12.00		0 281 002 202
Relay, Jetronic	06.96-12.00		0 332 014 140
Wheel speed sensor, front	06.96-06.98		0 265 006 160
	06.98-12.00	LAB	0 265 007 041
		RAB	0 265 007 042
Wheel speed sensor, rear	06.98-12.00		0 265 007 040
Fg.no. 2059704→	06.96-06.98		0 265 007 040
Ricam.no →2059703	06.96-06.98		0 265 006 300
2.4 D Turbo [838]	2,4l 91 kW 838A7.000 5 Zyl.		
Air flow sensor, diesel	06.96-03.98		0 281 002 085
Pulse generator, diesel	06.96-03.98		0 261 210 119
Temperature sensor, coolant, diesel	06.96-03.98		0 280 130 026
Pedal position sensor, diesel	06.96-03.98		0 205 001 010
Wheel speed sensor, front	06.96-03.98		0 265 006 160
Wheel speed sensor, rear	06.96-03.98		0 265 007 040
			0 265 006 300
			0 265 006 300
2.4 i 20V [838]	2,4l 129 kW 838A2.000 5 Zyl.		
Throttle valve sensor	11.94-06.98		0 280 122 001
Air mass meter, gasoline injection	11.94-06.98		0 280 217 111
Phase sensor	11.94-06.98		0 232 101 026
Pulse generator, ignition/Jetronic	11.94-06.98		0 261 210 119
Knock sensor	11.94-06.98		0 261 231 095
Temperature sensor, intake air, injection system	11.94-06.98		0 280 130 073
Temperature sensor, coolant, injection system	11.94-06.98		0 280 130 026
Relay, Jetronic	11.94-06.98		0 332 014 140
Wheel speed sensor, front	11.94-06.98		0 265 006 160
Wheel speed sensor, rear	11.94-06.98		0 265 007 040
			0 265 006 300
			0 265 006 300
2.4 i 20V [838]	2,4l 129 kW 838B2.000 5 Zyl.		
Throttle valve sensor	06.98-12.00		0 280 122 001
Air mass meter, gasoline injection	06.98-12.00		0 280 218 019
Phase sensor	06.98-12.00		0 232 101 036
Speed sensor, ignition/injection	06.98-12.00		0 261 210 160
Knock sensor	06.98-12.00		0 261 231 144
Temperature sensor, intake air, injection system	06.98-12.00		0 280 130 073
Temperature sensor, coolant, injection system	06.98-12.00		0 280 130 026
Pedal position sensor, EMS (electronic engine management)	06.98-12.00		0 281 002 202
Relay, Jetronic	06.98-12.00		0 332 014 140



Wheel speed sensor, front	06.98-12.00	LAB	0 265 007 041
		RAB	0 265 007 042
Wheel speed sensor, rear	06.98-12.00		0 265 007 040
2.4 JTD [838]	2,4 l	100 kW 838A8.000	5 Zyl.
Air mass meter, diesel	03.98-12.00		0 280 218 019
Speed sensor, diesel	03.98-12.00		0 281 002 214
Phase sensor	03.98-12.00		0 281 002 213
High-pressure sensor (CR system)	03.98-12.00		0 281 002 210
Boost pressure sensor, Diesel	03.98-12.00		0 281 002 215
Temperature sensor, fuel	03.98-12.00	2PO	0 281 002 209
Pedal position sensor, diesel	03.98-12.00		0 281 002 202
Wheel speed sensor, front	03.98-12.00	LAB	0 265 007 041
		RAB	0 265 007 042
Wheel speed sensor, rear	03.98-12.00		0 265 007 040
3.0 i 24V [838]	3,0 l	150 kW 838B.000	6 Zyl.
Throttle valve sensor	11.94-12.00		0 280 122 001
Air mass meter, gasoline injection	11.94-06.98		0 280 217 514
Fg.no. →2088054	06.98-12.99		0 280 217 514
Fg.no. 2088054→	12.99-12.00		0 280 217 531
Phase sensor	11.94-12.00		0 232 103 009
Pulse generator, ignition/Jetronic	11.94-12.00		0 261 210 113
Knock sensor	11.94-12.00		0 261 231 007
Temperature sensor, intake air, injection system	11.94-12.00		0 280 130 073
Temperature sensor, coolant, injection system	11.94-12.00		0 280 130 026
Wheel speed sensor, front	11.94-06.98		0 265 006 160
	06.98-12.00	LAB	0 265 007 041
		RAB	0 265 007 042
Wheel speed sensor, rear			
Fg.no. →2059704	11.94-12.00		0 265 006 300
Fg.no. 2059704→	11.94-12.00		0 265 007 040

Lybra Berlina

1.6 i 16V [839]	1,6 l	76 kW 182A4.000	4 Zyl.
Wheel speed sensor, front	10.99-09.00	LAB	0 265 007 073
		RAB	0 265 007 074
Wheel speed sensor, rear	10.99-09.00	LAB	0 265 007 076
		RAB	0 265 007 075
1.6 i 16V [839]	1,6 l	76 kW 182B6.000	4 Zyl.
Wheel speed sensor, front	10.00-08.02	LAB	0 265 007 073
	09.02-09.05	LAB	0 265 007 564
	10.00-08.02	RAB	0 265 007 074
	09.02-09.05	RAB	0 265 007 565
Wheel speed sensor, rear	10.00-08.02	LAB	0 265 007 076
	09.02-09.05	LAB	0 265 007 567
	10.00-08.02	RAB	0 265 007 075
	09.02-09.05	RAB	0 265 007 566
1.8 i 16V [839]	1,8 l	96 kW 839A4.000; 839A7.000	4 Zyl.
Air mass meter, gasoline injection	10.99-02.02		0 280 218 019
Phase sensor	10.99-02.02		0 232 101 037
Wheel speed sensor, front	10.99-02.02	LAB	0 265 007 073
		RAB	0 265 007 074
Wheel speed sensor, rear	10.99-02.02	LAB	0 265 007 076
		RAB	0 265 007 075
1.8 i 16V [839]	1,8 l	96 kW 839A9.000	4 Zyl.
Air mass meter, gasoline injection	03.02-09.05		0 280 218 019
Phase sensor	03.02-09.05		0 232 101 037
Wheel speed sensor, front	03.02-08.02	LAB	0 265 007 073
	09.02-09.05	LAB	0 265 007 564
	03.02-08.02	RAB	0 265 007 074
	09.02-09.05	RAB	0 265 007 565



Wheel speed sensor, rear	03.02-08.02	LAB	0 265 007 076
	09.02-09.05	LAB	0 265 007 567
	03.02-08.02	RAB	0 265 007 075
	09.02-09.05	RAB	0 265 007 566
1.9 JTD [839]	1,9 l	77 kW AR32302	4 Zyl.
Air mass meter, diesel	10.99-09.00		0 280 218 019
Speed sensor, diesel	10.99-09.00		0 281 002 214
Phase sensor	10.99-09.00		0 281 002 213
High-pressure sensor (CR system)	10.99-09.00		0 281 002 210
Boost pressure sensor, Diesel	10.99-09.00		0 281 002 215
Temperature sensor, fuel	10.99-09.00	2PO	0 281 002 209
Pedal position sensor, EMS (electronic engine management)	10.99-09.00		0 281 002 202
Wheel speed sensor, front	10.99-09.00	LAB	0 265 007 073
		RAB	0 265 007 074
Wheel speed sensor, rear	10.99-09.00	LAB	0 265 007 076
		RAB	0 265 007 075
1.9 JTD [839]	1,9 l	80 kW AR37101	4 Zyl.
Air mass meter, diesel	09.00-06.01		0 281 002 309
Speed sensor, diesel	09.00-06.01		0 281 002 474
Phase sensor	09.00-06.01		0 281 002 213
High-pressure sensor (CR system)	09.00-06.01		0 281 002 405
Boost pressure sensor, Diesel	09.00-06.01		0 281 002 215
Temperature sensor, fuel	09.00-06.01	2PO	0 281 002 209
Pedal position sensor, EMS (electronic engine management)	09.00-06.01		0 281 002 202
Wheel speed sensor, front	09.00-06.01	LAB	0 265 007 073
		RAB	0 265 007 074
Wheel speed sensor, rear	09.00-06.01	LAB	0 265 007 076
		RAB	0 265 007 075
1.9 JTD [839]	1,9 l	85 kW 937A2.000	4 Zyl.
Air mass meter, diesel	06.01-09.05		0 281 002 309
Speed sensor, diesel	06.01-06.03		0 281 002 474
	07.03-09.05		0 281 002 603
Phase sensor	06.01-09.05		0 281 002 213
High-pressure sensor (CR system)	06.01-02.04		0 281 002 405
Boost pressure sensor, Diesel	06.01-09.05		0 281 002 215
Temperature sensor, fuel	06.01-09.05	2PO	0 281 002 209
Pedal position sensor, EMS (electronic engine management)	06.01-09.05		0 281 002 202
Wheel speed sensor, front	06.01-08.02	LAB	0 265 007 073
	09.02-09.05	LAB	0 265 007 564
	06.01-08.02	RAB	0 265 007 074
	09.02-09.05	RAB	0 265 007 565
Wheel speed sensor, rear	06.01-08.02	LAB	0 265 007 076
	09.02-09.05	LAB	0 265 007 567
	06.01-08.02	RAB	0 265 007 075
	09.02-09.05	RAB	0 265 007 566
2.0 i 20V [839]	2,0 l	110 kW 185A8.000	5 Zyl.
Throttle valve assembly	10.00-09.05		0 205 003 052
Air mass meter, gasoline injection	10.00-09.05		0 281 002 309
Phase sensor	10.00-09.05		0 232 101 036
Speed sensor, ignition/injection	10.00-09.05		0 261 210 160
Knock sensor	10.00-09.05		0 261 231 144
Pedal position sensor, EMS (electronic engine management)	10.00-09.05		0 281 002 202
Wheel speed sensor, front	10.00-08.02	LAB	0 265 007 073
	09.02-09.05	LAB	0 265 007 564
	10.00-08.02	RAB	0 265 007 074
	09.02-09.05	RAB	0 265 007 565

Product				
◀ Lybra Berlina				
Wheel speed sensor, rear	10.00-08.02	LAB	0 265 007 076	
	09.02-09.05	LAB	0 265 007 567	
	10.00-08.02	RAB	0 265 007 075	
	09.02-09.05	RAB	0 265 007 566	
2.0 i 20V [839]	2,0 l	113 kW	182B7.000	5 Zyl.
Throttle valve assembly	10.99-09.00		0 205 003 052	
Air mass meter, gasoline injection	10.99-09.00		0 280 218 019	
Phase sensor	10.99-09.00		0 232 101 036	
Speed sensor, ignition/injection	10.99-09.00		0 261 210 160	
Knock sensor	10.99-09.00		0 261 231 144	
Pedal position sensor, EMS (electronic engine management)	10.99-09.00		0 281 002 202	
Wheel speed sensor, front	10.99-09.00	LAB	0 265 007 073	
		RAB	0 265 007 074	
Wheel speed sensor, rear	10.99-09.00	LAB	0 265 007 076	
		RAB	0 265 007 075	
2.4 i 20V [839]	2,4 l	129 kW	192A2.000	5 Zyl.
Throttle valve assembly	10.99-05.02		0 205 003 052	
Air mass meter, gasoline injection	10.99-05.02		0 281 002 309	
Phase sensor	10.99-05.02		0 232 101 036	
Speed sensor, ignition/injection	10.99-05.02		0 261 210 160	
Knock sensor	10.99-05.02		0 261 231 144	
Pedal position sensor, EMS (electronic engine management)	10.99-05.02		0 281 002 202	
Wheel speed sensor, front	10.99-05.02	LAB	0 265 007 073	
		RAB	0 265 007 074	
Wheel speed sensor, rear	10.99-05.02	LAB	0 265 007 076	
		RAB	0 265 007 075	
2.4 JTD [839]	2,4 l	98 kW	839A5.000/AR32501	5 Zyl.
Air mass meter, diesel	10.99-09.00		0 280 218 019	
Speed sensor, diesel	10.99-09.00		0 281 002 214	
Phase sensor	10.99-09.00		0 281 002 213	
High-pressure sensor (CR system)	10.99-09.00		0 281 002 210	
Boost pressure sensor, Diesel	10.99-09.00		0 281 002 215	
Temperature sensor, fuel	10.99-09.00	2PO	0 281 002 209	
Pedal position sensor, EMS (electronic engine management)	10.99-09.00		0 281 002 202	
Wheel speed sensor, front	10.99-09.00	LAB	0 265 007 073	
		RAB	0 265 007 074	
Wheel speed sensor, rear	10.99-09.00	LAB	0 265 007 076	
		RAB	0 265 007 075	
2.4 JTD [839]	2,4 l	103 kW	839A6.000	5 Zyl.
Air mass meter, diesel	09.00-05.02		0 281 002 309	
Speed sensor, diesel	09.00-05.02		0 281 002 474	
Phase sensor	09.00-05.02		0 281 002 213	
High-pressure sensor (CR system)	09.00-05.02		0 281 002 405	
Boost pressure sensor, Diesel	09.00-05.02		0 281 002 215	
Temperature sensor, fuel	09.00-05.02	2PO	0 281 002 209	
Pedal position sensor, EMS (electronic engine management)	09.00-05.02		0 281 002 202	
Wheel speed sensor, front	09.00-05.02	LAB	0 265 007 073	
		RAB	0 265 007 074	
Wheel speed sensor, rear	09.00-05.02	LAB	0 265 007 076	
		RAB	0 265 007 075	
2.4 JTD [839]	2,4 l	110 kW	841C000	5 Zyl.
Air mass meter, diesel	10.03-09.05		0 280 218 113	
	06.02-09.03		0 281 002 309	
Speed sensor, diesel	06.02-06.03		0 281 002 474	
	07.03-09.05		0 281 002 603	
Phase sensor	06.02-09.05		0 281 002 213	
High-pressure sensor (CR system)	06.02-09.05		0 281 002 405	
Boost pressure sensor, Diesel	06.02-09.05		0 281 002 215	
Temperature sensor, fuel	06.02-09.05	2PO	0 281 002 209	



Product				
Pedal position sensor, EMS (electronic engine management)	06.02-09.05			0 281 002 202
Wheel speed sensor, front	06.02-08.02	LAB		0 265 007 073
	09.02-09.05	LAB		0 265 007 564
	06.02-08.02	RAB		0 265 007 074
	09.02-09.05	RAB		0 265 007 565
Wheel speed sensor, rear	06.02-08.02	LAB		0 265 007 076
	09.02-09.05	LAB		0 265 007 567
	06.02-08.02	RAB		0 265 007 075
	09.02-09.05	RAB		0 265 007 566
Lybra Station Wagon				
1.6 i 16V [839]	1,6 l	76 kW	182A4.000	4 Zyl.
Air mass meter, gasoline injection	10.99-09.00			0 280 218 019
Wheel speed sensor, front	10.99-09.00	LAB		0 265 007 073
		RAB		0 265 007 074
Wheel speed sensor, rear	10.99-09.00	LAB		0 265 007 076
		RAB		0 265 007 075
1.6 i 16V [839]	1,6 l	76 kW	182B6.000	4 Zyl.
Air mass meter, gasoline injection	10.00-09.05			0 280 218 019
Wheel speed sensor, front	10.00-08.02	LAB		0 265 007 073
	09.02-09.05	LAB		0 265 007 564
	10.00-08.02	RAB		0 265 007 074
	09.02-09.05	RAB		0 265 007 565
Wheel speed sensor, rear	10.00-08.02	LAB		0 265 007 076
	09.02-09.05	LAB		0 265 007 567
	10.00-08.02	RAB		0 265 007 075
	09.02-09.05	RAB		0 265 007 566
1.8 i 16V [839]	1,8 l	96 kW	839A4.000; 839A7.000	4 Zyl.
Air mass meter, gasoline injection	10.99-02.02			0 280 218 019
Phase sensor	10.99-02.02			0 232 101 037
Wheel speed sensor, front	10.99-02.02	LAB		0 265 007 073
		RAB		0 265 007 074
Wheel speed sensor, rear	10.99-02.02	LAB		0 265 007 076
		RAB		0 265 007 075
1.8 i 16V [839]	1,8 l	96 kW	839A9.000	4 Zyl.
Air mass meter, gasoline injection	03.02-09.05			0 280 218 019
Phase sensor	03.02-09.05			0 232 101 037
Wheel speed sensor, front	03.02-08.02	LAB		0 265 007 073
	09.02-09.05	LAB		0 265 007 564
	03.02-08.02	RAB		0 265 007 074
	09.02-09.05	RAB		0 265 007 565
Wheel speed sensor, rear	03.02-08.02	LAB		0 265 007 076
	09.02-09.05	LAB		0 265 007 567
	03.02-08.02	RAB		0 265 007 075
	09.02-09.05	RAB		0 265 007 566
1.9 JTD [839]	1,9 l	77 kW	AR32302	4 Zyl.
Air mass meter, diesel	10.99-09.00			0 280 218 019
Speed sensor, diesel	10.99-09.00			0 281 002 214
Phase sensor	10.99-09.00			0 281 002 213
High-pressure sensor (CR system)	10.99-09.00			0 281 002 210
Boost pressure sensor, Diesel	10.99-09.00			0 281 002 215
Temperature sensor, fuel	10.99-09.00	2PO		0 281 002 209
Pedal position sensor, EMS (electronic engine management)	10.99-09.00			0 281 002 202
Wheel speed sensor, front	10.99-09.00	LAB		0 265 007 073
		RAB		0 265 007 074
Wheel speed sensor, rear	10.99-09.00	LAB		0 265 007 076
		RAB		0 265 007 075
1.9 JTD [839]	1,9 l	80 kW	AR37101	4 Zyl.
Air mass meter, diesel	09.00-06.01			0 281 002 309
Speed sensor, diesel	09.00-06.01			0 281 002 474



Phase sensor	09.00-06.01		0 281 002 213
High-pressure sensor (CR system)	09.00-06.01		0 281 002 405
Boost pressure sensor, Diesel	09.00-06.01		0 281 002 215
Temperature sensor, fuel	09.00-06.01	2PO	0 281 002 209
Pedal position sensor, EMS (electronic engine management)	09.00-06.01		0 281 002 202
Wheel speed sensor, front	09.00-06.01	LAB	0 265 007 073
		RAB	0 265 007 074
Wheel speed sensor, rear	09.00-06.01	LAB	0 265 007 076
		RAB	0 265 007 075
1.9 JTD [839]	1,9l 85 kW 937A2.000 4 Zyl.		
Air mass meter, diesel	06.01-09.05		0 281 002 309
Speed sensor, diesel	06.01-06.03		0 281 002 474
	07.03-09.05		0 281 002 603
Phase sensor	06.01-09.05		0 281 002 213
High-pressure sensor (CR system)	06.01-02.04		0 281 002 405
Boost pressure sensor, Diesel	06.01-09.05		0 281 002 215
Temperature sensor, fuel	06.01-09.05	2PO	0 281 002 209
Pedal position sensor, EMS (electronic engine management)	06.01-09.05		0 281 002 202
Wheel speed sensor, front	06.01-08.02	LAB	0 265 007 073
	09.02-09.05	LAB	0 265 007 564
	06.01-08.02	RAB	0 265 007 074
	09.02-09.05	RAB	0 265 007 565
Wheel speed sensor, rear	06.01-08.02	LAB	0 265 007 076
	09.02-09.05	LAB	0 265 007 567
	06.01-08.02	RAB	0 265 007 075
	09.02-09.05	RAB	0 265 007 566
2.0 i 20V [839]	2,0l 113 kW 182B7.000 4 Zyl.		
Throttle valve assembly	10.99-09.00		0 205 003 052
Air mass meter, gasoline injection	10.99-09.00		0 280 218 019
Phase sensor	10.99-09.00		0 232 101 036
Speed sensor, ignition/injection	10.99-09.00		0 261 210 160
Knock sensor	10.99-09.00		0 261 231 144
Pedal position sensor, EMS (electronic engine management)	10.99-09.00		0 281 002 202
Wheel speed sensor, front	10.99-09.00	LAB	0 265 007 073
		RAB	0 265 007 074
Wheel speed sensor, rear	10.99-09.00	LAB	0 265 007 076
		RAB	0 265 007 075
2.0 i 20V [839]	2,0l 113 kW 185A8.000 4 Zyl.		
Throttle valve assembly	10.00-09.05		0 205 003 052
Air mass meter, gasoline injection	10.00-09.05		0 281 002 309
Phase sensor	10.00-09.05		0 232 101 036
Speed sensor, ignition/injection	10.00-09.05		0 261 210 160
Knock sensor	10.00-09.05		0 261 231 144
Pedal position sensor, EMS (electronic engine management)	10.00-09.05		0 281 002 202
Wheel speed sensor, front	10.00-08.02	LAB	0 265 007 073
	09.02-09.05	LAB	0 265 007 564
	10.00-08.02	RAB	0 265 007 074
	09.02-09.05	RAB	0 265 007 565
Wheel speed sensor, rear	10.00-08.02	LAB	0 265 007 076
	09.02-09.05	LAB	0 265 007 567
	10.00-08.02	RAB	0 265 007 075
	09.02-09.05	RAB	0 265 007 566
2.4 JTD [839]	2,4l 98 kW 839A5.000/AR32501 5 Zyl.		
Air mass meter, diesel	10.99-09.00		0 280 218 019
Speed sensor, diesel	10.99-09.00		0 281 002 214
Phase sensor	10.99-09.00		0 281 002 213
High-pressure sensor (CR system)	10.99-09.00		0 281 002 210
Boost pressure sensor, Diesel	10.99-09.00		0 281 002 215
Temperature sensor, fuel	10.99-09.00	2PO	0 281 002 209



Pedal position sensor, EMS (electronic engine management)	10.99-09.00		0 281 002 202
Wheel speed sensor, front	10.99-09.00	LAB	0 265 007 073
		RAB	0 265 007 074
Wheel speed sensor, rear	10.99-09.00	LAB	0 265 007 076
		RAB	0 265 007 075
2.4 JTD [839]	2,4l	103 kW	839A6.000 5 Zyl.
Air mass meter, diesel	09.00-05.02		0 281 002 309
Speed sensor, diesel	09.00-05.02		0 281 002 474
Phase sensor	09.00-05.02		0 281 002 213
High-pressure sensor (CR system)	09.00-05.02		0 281 002 405
Boost pressure sensor, Diesel	09.00-05.02		0 281 002 215
Temperature sensor, fuel	09.00-05.02	2PO	0 281 002 209
Pedal position sensor, EMS (electronic engine management)	09.00-05.02		0 281 002 202
Wheel speed sensor, front	09.00-05.02	LAB	0 265 007 073
		RAB	0 265 007 074
Wheel speed sensor, rear	09.00-05.02	LAB	0 265 007 076
		RAB	0 265 007 075
2.4 JTD [839]	2,4l	110 kW	841C000 5 Zyl.
Air mass meter, diesel	10.03-09.05		0 280 218 113
	06.02-09.03		0 281 002 309
Speed sensor, diesel	06.02-06.03		0 281 002 474
	07.03-09.05		0 281 002 603
Phase sensor	06.02-09.05		0 281 002 213
High-pressure sensor (CR system)	06.02-09.05		0 281 002 405
Boost pressure sensor, Diesel	06.02-09.05		0 281 002 215
Temperature sensor, fuel	06.02-09.05	2PO	0 281 002 209
Pedal position sensor, EMS (electronic engine management)	06.02-09.05		0 281 002 202
Wheel speed sensor, front	06.02-08.02	LAB	0 265 007 073
	09.02-09.05	LAB	0 265 007 564
	06.02-08.02	RAB	0 265 007 074
	09.02-09.05	RAB	0 265 007 565
Wheel speed sensor, rear	06.02-08.02	LAB	0 265 007 076
	09.02-09.05	LAB	0 265 007 567
	06.02-08.02	RAB	0 265 007 075
	09.02-09.05	RAB	0 265 007 566

Musa

1.3 MJTD [184] 1,3l 51 kW 188A9000 4 Zyl.			
Air mass meter, diesel	10.04→		0 281 002 613
Boost pressure sensor, Diesel	10.04→		0 281 002 510
			0 281 002 844
Acceleration sensor, ABS	10.04→		0 265 005 127
Yaw rate sensor, brake system	10.04-12.05		0 265 005 241
Wheel speed sensor, front	10.04-03.07		0 265 007 830
Wheel speed sensor, rear	10.04-03.07		0 265 007 503
1.3 MJTD 16V [184] 1,3l 66 kW 199A3000 4 Zyl.			
Air mass meter, diesel	01.06→		0 281 002 792
Acceleration sensor, ABS	01.06→		0 265 005 127
Wheel speed sensor, front	01.06-03.07		0 265 007 830
Wheel speed sensor, rear	01.06-03.07		0 265 007 503
1.4 [184] 1,4l 55 kW 350A1000 4 Zyl.			
Air mass meter, gasoline injection	03.05→		0 281 002 613
Pressure sensor, intake manifold, gasoline	03.05→		0 261 230 030
Acceleration sensor, ABS	03.05→		0 265 005 127
Yaw rate sensor, brake system	03.05-12.05		0 265 005 241
Wheel speed sensor, front	03.05-03.07		0 265 007 830
Wheel speed sensor, rear	03.05-03.07		0 265 007 503





Product



◀ Musa

1.4 16V [184]	1,4l 66/70 kW 192B2000; 843A1000 4 Zyl.
Air mass meter, gasoline injection	10.04→ 0 281 002 613
Speed sensor, ignition/injection	10.04→ 0 261 210 238
Knock sensor	10.04→ 0 261 231 173
Pressure sensor, intake manifold, gasoline	10.04→ 0 261 230 030
Acceleration sensor, ABS	10.04→ 0 265 005 127
Yaw rate sensor, brake system	10.04-12.05 0 265 005 241
Wheel speed sensor, front	10.04-03.07 0 265 007 830
Wheel speed sensor, rear	10.04-03.07 0 265 007 503
1.9 JTD [184]	1,9l 74 kW 188B2000 4 Zyl.
Speed sensor, diesel	10.04→ 0 281 002 603
Phase sensor	10.04→ 0 281 002 213
High-pressure sensor (CR system)	10.04→ 0 281 002 534
Boost pressure sensor, Diesel	10.04→ 0 281 002 845
Acceleration sensor, ABS	10.04→ 0 265 005 127
Yaw rate sensor, brake system	10.04-12.05 0 265 005 241
Wheel speed sensor, front	10.04-03.07 0 265 007 830
Wheel speed sensor, rear	10.04-03.07 0 265 007 503

Phedra

2.0 JTD 16V [180]	2,0l 80 kW RHM; RHW 4 Zyl.
High-pressure sensor (CR system)	09.02→ 0 281 002 283
Duo sensor, acceleration and yaw rate, brake system	
Ricam.no→10569	09.02→ 0 265 005 290
Ricam.no 10570→	09.02→ 0 265 005 606
Wheel speed sensor, front	09.02→ LAB 0 265 007 083
	RAB 0 265 007 084
2.0 JTD 16V [180]	2,0l 88/100 kW RHK; RHR 4 Zyl.
Duo sensor, acceleration and yaw rate, brake system	
Ricam.no 10570→	03.06→ 0 265 005 606
Wheel speed sensor, front	03.06→ LAB 0 265 007 083
	RAB 0 265 007 084
2.0 16V [180]	2,0l 100 kW RFN 4 Zyl.
Temperature sensor, intake air, injection system	09.02-09.06 0 261 230 058
Duo sensor, acceleration and yaw rate, brake system	
Ricam.no→10569	09.02-09.06 0 265 005 290
Ricam.no 10570→	09.02-09.06 0 265 005 606
Wheel speed sensor, front	09.02-09.06 LAB 0 265 007 083
	RAB 0 265 007 084
2.2 JTD 16V [180]	2,2l 95 kW 4HW 4 Zyl.
High-pressure sensor (CR system)	09.02→ 0 281 002 283
Duo sensor, acceleration and yaw rate, brake system	
Ricam.no→10569	09.02→ 0 265 005 290
Ricam.no 10570→	09.02→ 0 265 005 606
Wheel speed sensor, front	09.02→ LAB 0 265 007 083
	RAB 0 265 007 084
3.0 24V [180]	3,0l 150 kW XFW 6 Zyl.
Knock sensor	09.02-10.05 KZB 0 261 231 130
Temperature sensor, intake air, injection system	09.02-10.05 0 261 230 058
Duo sensor, acceleration and yaw rate, brake system	
Ricam.no→10569	09.02-10.05 0 265 005 290
Wheel speed sensor, front	09.02-10.05 LAB 0 265 007 083
	RAB 0 265 007 084

Product



Thema Berlina

2.0 i.e. [104]	2,0l 83-85 kW 834 B 0.. Kat. 4 Zyl.
Throttle valve sensor	03.86-09.88 0 280 120 311
Air flow sensor, gasoline injection	03.86-09.88 0 280 202 102
	0 986 280 054
Temperature sensor, coolant, injection system	03.86-09.88 0 280 130 026
Relay, Jetronic	03.86-06.88 0 280 230 006
Wheel speed sensor, front	03.86-09.88 0 265 001 072
Wheel speed sensor, rear	03.86-09.88 LAB 0 265 001 074
	RAB 0 265 001 073
2.0 i.e. [104]	2,0l 84 kW 834 B 146 4 Zyl.
Air flow sensor, gasoline injection	05.92-11.94 0 280 202 102
	0 986 280 054
Temperature sensor, coolant, injection system	05.92-11.94 0 280 130 026
Relay, Jetronic	05.92-11.94 0 280 230 006
Wheel speed sensor, front	05.92-11.94 0 265 006 262
Wheel speed sensor, rear	05.92-09.93 0 265 003 075
	10.93-11.94 0 265 006 238
2.0 i.e. [104]	2,0l 86 kW 834 B 1.000 4 Zyl.
Throttle valve sensor	06.88-05.92 0 280 120 311
Air flow sensor, gasoline injection	CH,S 06.88-05.92 0 280 202 081
	CH,S 06.88-05.92 0 280 202 059
	0 986 280 044
Temperature sensor, coolant, injection system	06.88-05.92 0 280 130 026
Relay, Jetronic	06.88-06.88 0 280 230 006
Wheel speed sensor, front	06.88-05.92 LAB 0 265 001 209
	06.89-05.92 RAB 0 265 001 210
Wheel speed sensor, rear	06.88-05.92 LAB 0 265 001 074
	RAB 0 265 001 073
2.0 i.e. [104]	2,0l 88 kW 834 B.000 4 Zyl.
Throttle valve sensor	11.84-09.88 0 280 120 311
Air flow sensor, gasoline injection	CH,S 11.84-09.88 0 280 202 081
	CH,S 11.84-09.88 0 280 202 059
	0 986 280 044
Temperature sensor, coolant, injection system	11.84-09.88 0 280 130 026
Relay, Jetronic	11.84-06.88 0 280 230 006
Wheel speed sensor, front	11.84-09.88 0 265 001 072
Wheel speed sensor, rear	11.84-09.88 LAB 0 265 001 074
	RAB 0 265 001 073
2.0 i.e. Turbo [104]	2,0l 110 kW 834 C 146 4 Zyl.
Throttle valve sensor	06.88-05.90 0 280 120 312
Air flow sensor, gasoline injection	06.88-05.90 0 280 202 060
	0 986 280 046
Temperature sensor, coolant, injection system	06.88-05.90 0 280 130 026
Relay, Jetronic	06.88-05.90 0 280 230 009
Wheel speed sensor, front	06.88-05.90 LAB 0 265 001 209
	06.89-05.90 RAB 0 265 001 210
Wheel speed sensor, rear	06.88-05.90 LAB 0 265 001 074
	RAB 0 265 001 073
2.0 i.e. Turbo [104]	2,0l 110 kW 834 C 146 Kat. 4 Zyl.
Throttle valve sensor	07.86-05.90 0 280 120 323
Air flow sensor, gasoline injection	07.86-05.90 0 280 202 103
Temperature sensor, coolant, injection system	07.86-05.90 0 280 130 026
Relay, Jetronic	07.86-06.88 0 280 230 006
	07.86-05.90 0 280 230 009
Wheel speed sensor, front	07.86-05.90 LAB 0 265 001 209
	06.89-05.90 RAB 0 265 001 210
Wheel speed sensor, rear	07.86-05.90 LAB 0 265 001 074
	RAB 0 265 001 073

Product




2.0 i.e. Turbo [104]			2,0l 122 kW 834 C 000 4 Zyl.
Throttle valve sensor	11.84-09.88		0 280 120 312
Air flow sensor, gasoline injection	11.84-09.88		0 280 202 060
			0 986 280 046
Temperature sensor, coolant, injection system	11.84-09.88		0 280 130 026
Relay, Jetronic	11.84-06.88		0 280 230 006
	11.84-09.88		0 280 230 009
Wheel speed sensor, front	11.84-09.88		0 265 001 072
Wheel speed sensor, rear	11.84-09.88	LAB	0 265 001 074
		RAB	0 265 001 073
2.0 i.e. Turbo 16V [104]			2,0l 132 kW 834 C 1.246 Kat 4 Zyl.
Throttle valve sensor	04.89-05.92		0 280 120 331
Air mass meter, gasoline injection	04.89-05.92		0 280 202 115
Temperature sensor, coolant, injection system	04.89-05.92		0 280 130 026
Relay, Jetronic	04.89-05.92		0 280 230 009
Wheel speed sensor, front	04.89-05.92	LAB	0 265 001 209
	06.89-05.92	RAB	0 265 001 210
Wheel speed sensor, rear	04.89-05.92	LAB	0 265 001 074
		RAB	0 265 001 073
2.0 i.e. Turbo 16V [104]			2,0l 136 kW 834 C 1.000 4 Zyl.
Throttle valve sensor	06.88-05.92		0 280 120 307
Air mass meter, gasoline injection	06.88-05.92		0 280 202 114
			0 986 280 080
Temperature sensor, coolant, injection system	06.88-05.92		0 280 130 026
Relay, Jetronic	06.88-05.92		0 280 230 009
Wheel speed sensor, front	06.88-05.92	LAB	0 265 001 209
	06.89-05.92	RAB	0 265 001 210
Wheel speed sensor, rear	06.88-05.92	LAB	0 265 001 074
		RAB	0 265 001 073
2.0 i.e. 16V [104]			2,0l 107 kW 834 B 2.246 Kat 4 Zyl.
Throttle valve sensor	02.89-05.92		0 280 120 300
Air flow sensor, gasoline injection	02.89-05.92		0 280 202 602
			0 986 280 019
Pressure sensor, intake manifold, gasoline	02.89-05.92		0 280 101 001
Temperature sensor, coolant, injection system	02.89-05.92		0 280 130 026
Wheel speed sensor, front	02.89-05.92	LAB	0 265 001 209
	06.89-05.92	RAB	0 265 001 210
Wheel speed sensor, rear	02.89-05.92	LAB	0 265 001 074
		RAB	0 265 001 073
2.0 i.e. 16V [104]			2,0l 108 kW 834 B 2.000 4 Zyl.
Throttle valve sensor	06.88-05.92		0 280 120 300
Air flow sensor, gasoline injection	06.88-05.92		0 280 202 602
			0 986 280 019
Temperature sensor, coolant, injection system	06.88-05.92		0 280 130 026
Relay, Jetronic	06.88-05.92		0 332 014 113
Wheel speed sensor, front	06.88-05.92	LAB	0 265 001 209
	06.89-05.92	RAB	0 265 001 210
Wheel speed sensor, rear	06.88-05.92	LAB	0 265 001 074
		RAB	0 265 001 073
2.0 i.e. 16V [104]			2,0l 112 kW 834 F 1.000 4 Zyl.
Throttle valve sensor	05.92-11.94		0 280 122 001
Air flow sensor, gasoline injection	05.92-11.94		0 280 202 204
			0 986 280 055
Speed sensor, ignition/injection	05.92-11.94		0 261 210 093
Knock sensor	05.92-11.94		0 261 231 007
Temperature sensor, coolant, injection system	05.92-11.94		0 280 130 026
Relay, Jetronic	05.92-11.94		0 332 014 140
		DID	0 332 014 112
Wheel speed sensor, front	05.92-11.94		0 265 006 262
Wheel speed sensor, rear	05.92-09.93		0 265 003 075
	10.93-11.94		0 265 006 238

Product



2.0 i.e. 16V Turbo [104]			2,0l 148 kW 834 F 2.000 4 Zyl.
Throttle valve sensor	05.92-11.94		0 280 122 001
Air mass meter, gasoline injection	05.92-11.94		0 280 213 025
			0 986 280 114
Phase sensor	05.92-11.94		0 232 101 018
Speed sensor, ignition/injection	05.92-11.94		0 261 210 093
Knock sensor	05.92-11.94		0 261 231 007
Pressure sensor, intake manifold, gasoline	05.92-11.94		0 280 101 001
Temperature sensor, coolant, injection system	05.92-11.94		0 280 130 026
Relay, Jetronic	05.92-11.94		0 332 014 140
Wheel speed sensor, front	05.92-11.94		0 265 006 262
Wheel speed sensor, rear	05.92-09.93		0 265 003 075
	10.93-11.94		0 265 006 238
2.5 TD [104]			2,5l 74 kW 8144.91.2200 4 Zyl.
Wheel speed sensor, front	11.84-09.88		0 265 001 072
Wheel speed sensor, rear	11.84-09.88	LAB	0 265 001 074
		RAB	0 265 001 073
2.5 TD [104]			2,5l 85 kW 8144.97S.2200 4 Zyl.
Wheel speed sensor, front	06.88-05.92	LAB	0 265 001 209
	06.89-05.92	RAB	0 265 001 210
Wheel speed sensor, rear	06.88-05.92	LAB	0 265 001 074
		RAB	0 265 001 073
2.5 TD [104]			2,5l 85 kW 8144.97Y 4 Zyl.
Air flow sensor, diesel	01.93-11.94		0 281 002 088
Temperature sensor, coolant, diesel	01.93-11.94		0 280 130 026
Pedal position sensor, diesel	01.93-11.94		0 205 001 010
Wheel speed sensor, front	05.92-11.94		0 265 006 262
Wheel speed sensor, rear	05.92-09.93		0 265 003 075
	01.93-11.94		0 265 003 075
	10.93-11.94		0 265 006 238
2.5 TD [104]			2,5l 85 kW 8144.97.2200 4 Zyl.
Wheel speed sensor, front	06.88-05.92	LAB	0 265 001 209
	06.89-05.92	RAB	0 265 001 210
Wheel speed sensor, rear	06.88-05.92	LAB	0 265 001 074
		RAB	0 265 001 073
2.8 6 V PRV [104]			2,8l 110 kW 834 E 000 6 Zyl.
Air flow sensor, gasoline injection	11.84-09.88		0 438 120 200
Relay, Jetronic	11.84-06.88		0 280 230 006
Wheel speed sensor, front	11.84-09.88		0 265 001 072
Wheel speed sensor, rear	11.84-09.88	LAB	0 265 001 074
		RAB	0 265 001 073
2.9 6 V PRV [104]			2,9l 108 kW 834 E 146 6 Zyl.
Throttle valve sensor	06.88-09.91		0 280 120 301
Air mass meter, gasoline injection	06.88-09.91		0 280 213 006
			0 986 280 115
Speed sensor, ignition/injection	06.88-09.91		0 261 210 029
Knock sensor	06.88-09.91		0 261 231 007
Temperature sensor, coolant, injection system	06.88-09.91		0 280 130 032
Relay, Jetronic	06.88-09.91		0 332 014 140
Wheel speed sensor, rear	06.88-09.91	LAB	0 265 001 074
		RAB	0 265 001 073
3.0 i.e. [104]			3,0l 126 kW 834 F.000 6 Zyl.
Throttle valve sensor	05.92-11.94		0 280 122 001
Speed sensor, ignition/injection	05.92-11.94		0 261 210 096
Knock sensor	05.92-11.94		0 261 231 095
Temperature sensor, coolant, injection system	05.92-11.94		0 280 130 026
Wheel speed sensor, front	05.92-11.94		0 265 006 262
Wheel speed sensor, rear	05.92-09.93		0 265 003 075
	10.93-11.94		0 265 006 238
8.32 [104]			2,9l 150 kW F 105 L.046 Kat 8 Zyl.
Throttle valve sensor	12.87-12.90		0 280 120 302
Air flow sensor, gasoline injection	12.87-12.90		0 438 121 066
Pressure sensor, intake manifold, gasoline	12.87-12.90		0 280 101 003



Product				
◀ Thema Berlina				
Temperature sensor, coolant, injection system	12.87-12.90			0 280 130 026
Relay, Jetronic	12.87-12.90			0 280 230 009
Wheel speed sensor, front	12.87-06.89			0 265 001 072
Wheel speed sensor, rear	12.87-12.90	LAB		0 265 001 074
		RAB		0 265 001 073
8.32 [104]	2,9l	158 kW	F 105 L	8 Zyl.
Throttle valve sensor	06.86-12.89			0 280 120 302
Air flow sensor, gasoline injection	06.86-12.89			0 438 121 066
Temperature sensor, coolant, injection system	06.86-12.89			0 280 130 026
Relay, Jetronic	06.86-06.88			0 280 230 006
Wheel speed sensor, front	06.86-06.89			0 265 001 072
Wheel speed sensor, rear	06.86-12.89	LAB		0 265 001 074
		RAB		0 265 001 073



Thema Station Wagon

2.0 i.e. Turbo [104]	2,0l	110 kW	834 C 146	4 Zyl.
Throttle valve sensor	06.88-05.90			0 280 120 312
Air flow sensor, gasoline injection	06.88-05.90			0 280 202 060
				0 986 280 046
Temperature sensor, coolant, injection system	06.88-05.90			0 280 130 026
Relay, Jetronic	06.88-05.90			0 280 230 009
Wheel speed sensor, front	06.88-05.90	LAB		0 265 001 209
		RAB		0 265 001 210
Wheel speed sensor, rear	06.88-05.90	LAB		0 265 001 074
		RAB		0 265 001 073
2.0 i.e. Turbo [104]	2,0l	110 kW	834 C 146 Kat.	4 Zyl.
Throttle valve sensor	07.86-05.90			0 280 120 323
Air flow sensor, gasoline injection	07.86-05.90			0 280 202 103
Temperature sensor, coolant, injection system	07.86-05.90			0 280 130 026
Relay, Jetronic	07.86-06.88			0 280 230 006
				0 280 230 009
Wheel speed sensor, front	07.86-05.90	LAB		0 265 001 209
		RAB		0 265 001 210
Wheel speed sensor, rear	07.86-05.90	LAB		0 265 001 074
		RAB		0 265 001 073
2.0 i.e. Turbo [104]	2,0l	122 kW	834 C 000	4 Zyl.
Throttle valve sensor	11.84-09.88			0 280 120 312
Air flow sensor, gasoline injection	11.84-09.88			0 280 202 060
				0 986 280 046
Temperature sensor, coolant, injection system	11.84-09.88			0 280 130 026
Relay, Jetronic	11.84-06.88			0 280 230 006
				0 280 230 009
Wheel speed sensor, front	11.84-09.88			0 265 001 072
Wheel speed sensor, rear	11.84-09.88	LAB		0 265 001 074
		RAB		0 265 001 073
2.0 i.e. Turbo 16V [104]	2,0l	132 kW	834 C 1.246 Kat	4 Zyl.
Throttle valve sensor	04.89-05.92			0 280 120 331
Air mass meter, gasoline injection	04.89-05.92			0 280 202 115
Temperature sensor, coolant, injection system	04.89-05.92			0 280 130 026
Relay, Jetronic	04.89-05.92			0 280 230 009
Wheel speed sensor, front	04.89-05.92	LAB		0 265 001 209
		RAB		0 265 001 210
Wheel speed sensor, rear	04.89-05.92	LAB		0 265 001 074
		RAB		0 265 001 073
2.0 i.e. Turbo 16V [104]	2,0l	136 kW	834 C 1.000	4 Zyl.
Throttle valve sensor	06.88-05.92			0 280 120 307
Air mass meter, gasoline injection	06.88-05.92			0 280 202 114
				0 986 280 080
Temperature sensor, coolant, injection system	06.88-05.92			0 280 130 026
Relay, Jetronic	06.88-05.92			0 280 230 009
Wheel speed sensor, front	06.88-05.92	LAB		0 265 001 209
		RAB		0 265 001 210

Product				
Wheel speed sensor, rear				
	06.88-05.92	LAB		0 265 001 074
		RAB		0 265 001 073
2.0 i.e. 16V [104]	2,0l	107 kW	834 B 2.246 Kat	4 Zyl.
Throttle valve sensor	02.89-05.92			0 280 120 300
Air flow sensor, gasoline injection	02.89-05.92			0 280 202 602
				0 986 280 019
Pressure sensor, intake manifold, gasoline	02.89-05.92			0 280 101 001
Temperature sensor, coolant, injection system	02.89-05.92			0 280 130 026
Wheel speed sensor, front	02.89-05.92	LAB		0 265 001 209
		RAB		0 265 001 210
Wheel speed sensor, rear	02.89-05.92	LAB		0 265 001 074
		RAB		0 265 001 073
2.0 i.e. 16V [104]	2,0l	108 kW	834 B 2.000	4 Zyl.
Throttle valve sensor	06.88-05.92			0 280 120 300
Air flow sensor, gasoline injection	06.88-05.92			0 280 202 602
				0 986 280 019
Temperature sensor, coolant, injection system	06.88-05.92			0 280 130 026
Relay, Jetronic	06.88-05.92			0 332 014 113
Wheel speed sensor, front	06.88-05.92	LAB		0 265 001 209
		RAB		0 265 001 210
Wheel speed sensor, rear	06.88-05.92	LAB		0 265 001 074
		RAB		0 265 001 073
2.0 i.e. 16V [104]	2,0l	112 kW	834 F 1.000	4 Zyl.
Throttle valve sensor	05.92-11.94			0 280 122 001
Air flow sensor, gasoline injection	05.92-11.94			0 280 202 204
				0 986 280 055
Speed sensor, ignition/injection	05.92-11.94			0 261 210 093
Knock sensor	05.92-11.94			0 261 231 007
Temperature sensor, coolant, injection system	05.92-11.94			0 280 130 026
Relay, Jetronic	05.92-11.94			0 332 014 140
		DID		0 332 014 112
Wheel speed sensor, front	05.92-11.94			0 265 006 262
Wheel speed sensor, rear	05.92-09.93			0 265 003 075
				10.93-11.94 0 265 006 238
2.0 i.e. 16V Turbo [104]	2,0l	148 kW	834 F 2.000	4 Zyl.
Throttle valve sensor	05.92-11.94			0 280 122 001
Air mass meter, gasoline injection	05.92-11.94			0 280 213 025
				0 986 280 114
Phase sensor	05.92-11.94			0 232 101 018
Speed sensor, ignition/injection	05.92-11.94			0 261 210 093
Knock sensor	05.92-11.94			0 261 231 007
Pressure sensor, intake manifold, gasoline	05.92-11.94			0 280 101 001
Temperature sensor, coolant, injection system	05.92-11.94			0 280 130 026
Relay, Jetronic	05.92-11.94			0 332 014 140
Wheel speed sensor, front	05.92-11.94			0 265 006 262
Wheel speed sensor, rear	05.92-09.93			0 265 003 075
				10.93-11.94 0 265 006 238
2.5 TD [104]	2,5l	74 kW	8144.91.2200	4 Zyl.
Wheel speed sensor, front	11.84-09.88			0 265 001 072
Wheel speed sensor, rear	11.84-09.88	LAB		0 265 001 074
		RAB		0 265 001 073
2.5 TD [104]	2,5l	85 kW	8144.97S.2200	4 Zyl.
Wheel speed sensor, front	06.88-05.92	LAB		0 265 001 209
		RAB		0 265 001 210
Wheel speed sensor, rear	06.88-05.92	LAB		0 265 001 074
		RAB		0 265 001 073
2.5 TD [104]	2,5l	85 kW	8144.97Y	4 Zyl.
Wheel speed sensor, front	05.92-11.94			0 265 006 262
Wheel speed sensor, rear	05.92-09.93			0 265 003 075
				10.93-11.94 0 265 006 238
2.5 TD [104]	2,5l	85 kW	8144.97Y EDC-Bosch	4 Zyl.
Air flow sensor, diesel	01.93-11.94			0 281 002 088
Temperature sensor, coolant, diesel	01.93-11.94			0 280 130 026



Pedal position sensor, diesel	01.93-11.94	0 205 001 010
Wheel speed sensor, front	01.93-11.94	0 265 006 262
Wheel speed sensor, rear	01.93-11.94	0 265 003 075
2.5 TD [104]	2,5l 85 kW 8144.97.2200 4 Zyl.	
Wheel speed sensor, front	06.88-05.92 LAB	0 265 001 209
	06.89-05.92 RAB	0 265 001 210
Wheel speed sensor, rear	06.88-05.92 LAB	0 265 001 074
	RAB	0 265 001 073
3.0 i.e. [104]	3,0l 126 kW 834 F.000 6 Zyl.	
Throttle valve sensor	05.92-11.94	0 280 122 001
Speed sensor, ignition/injection	05.92-11.94	0 261 210 096
Knock sensor	05.92-11.94	0 261 231 095
Temperature sensor, coolant, injection system	05.92-11.94	0 280 130 026
Wheel speed sensor, front	05.92-11.94	0 265 006 262
Wheel speed sensor, rear	05.92-09.93	0 265 003 075
	10.93-11.94	0 265 006 238

Thesis		
2.0 Turbo 20V [841]	2,0l 136 kW 841E.000 5 Zyl.	
Throttle valve assembly	04.02→	0 205 003 052
Air mass meter, gasoline injection	04.02→	0 280 218 054
Phase sensor	04.02→	0 232 101 036
Speed sensor, ignition/injection	04.02→	0 261 210 160
Knock sensor	04.02→	0 261 231 173
2.4 JTD 10V [841]	2,4l 110 kW 841C.000 5 Zyl.	
Air mass meter, diesel		
Ricam.no →8957	04.02-09.03	0 281 002 309
Ricam.no 8958→	10.03-02.05	0 280 218 113
Speed sensor, diesel	04.02-06.03	0 281 002 474
	07.03-02.05	0 281 002 603
Phase sensor	04.02-02.05	0 281 002 213
High-pressure sensor (CR system)	04.02-02.05	0 281 002 405
Boost pressure sensor, Diesel	04.02-02.05	0 281 002 844
2.4 JTD 20V [841]	2,4l 120/129 kW 841G.000; 841M.000; 841N.000 5 Zyl.	
Air mass meter, diesel	06.03-02.06	0 281 002 598
Boost pressure sensor, Diesel	06.03-02.06	0 281 002 845
2.4 JTD 20V [841]	2,4l 129 kW 841H.000 5 Zyl.	
Air mass meter, diesel	06.03-02.06	0 281 002 598
Boost pressure sensor, Diesel	06.03-02.06	0 281 002 845
2.4 JTD 20V [841]	2,4l 136 kW 841H.000 5 Zyl.	
Air mass meter, diesel	03.06→	0 281 002 763
High-pressure sensor (CR system)	03.06→	0 281 002 706
Boost pressure sensor, Diesel	03.06→	0 281 002 845
2.4 20V [841]	2,4l 125 kW 841D.000 5 Zyl.	
Throttle valve assembly	04.02→	1 287 213 608
Air mass meter, gasoline injection	04.02→	0 281 002 309
Phase sensor	04.02→	0 232 101 036
Speed sensor, ignition/injection	04.02→	0 261 210 160
Knock sensor	04.02→	0 261 231 144
3.0 V6 24V [841]	3,0l 158 kW 841A.000 6 Zyl.	
Throttle valve assembly	04.02-07.03	0 280 750 014
Air mass meter, gasoline injection	04.02-07.03	0 280 218 054
Phase sensor	04.02-07.03	0 232 103 024
Speed sensor, ignition/injection	04.02-07.03	0 261 210 203
3.2 V6 24V [841]	3,2l 169 kW 841A.000 6 Zyl.	
Throttle valve assembly	08.03→	0 280 750 014
Air mass meter, gasoline injection	08.03→	0 280 218 054
Phase sensor	08.03→	0 232 103 024
Speed sensor, ignition/injection	08.03→	0 261 210 203



Y		
1.1 i.e. [840]	1,1l 40 kW 176B2.000 SPI-Weber 4 Zyl.	
Wheel speed sensor, front	04.97-06.00	0 265 006 138
Wheel speed sensor, rear	04.97-06.00 LAB	0 265 006 139
	RAB	0 265 006 140
1.2 i 8V [840]	1,2l 44 kW 188A4.000 4 Zyl.	
Wheel speed sensor, front	06.00-06.03 LAB	0 265 007 024
	RAB	0 265 007 025
Wheel speed sensor, rear	06.00-06.03 LAB	0 265 007 026
	RAB	0 265 007 027
1.2 i 16V [840]	1,2l 63 kW 188A5.000 4 Zyl.	
Throttle valve assembly	06.00-06.03	0 280 750 042
Speed sensor, ignition/injection	06.00-06.03	0 261 210 220
Knock sensor	06.00-06.03	0 261 231 173
Wheel speed sensor, front	06.00-06.03 LAB	0 265 007 024
	RAB	0 265 007 025
Wheel speed sensor, rear	06.00-06.03 LAB	0 265 007 026
	RAB	0 265 007 027
1.2 i.e. 8V [840]	1,2l 44 kW 840A3.000 SPI-Weber 4 Zyl.	
Pulse generator, ignition/Jetronic	01.96-06.00	0 281 002 102
Wheel speed sensor, front	01.96-06.00	0 265 006 138
Wheel speed sensor, rear	01.96-06.00 LAB	0 265 006 139
	RAB	0 265 006 140
1.2 i.e. 16V [840]	1,2l 63 kW 176B9.000 MPI-Weber 4 Zyl.	
Wheel speed sensor, front	04.97-06.00	0 265 006 138
Wheel speed sensor, rear	04.97-06.00 LAB	0 265 006 139
	RAB	0 265 006 140
1.4 i.e. 12V [840]	1,4l 55-59 kW 840A2.000 SPI-Bosch 4 Zyl.	
Pulse generator, ignition/Jetronic	01.96-06.00	0 281 002 102
Knock sensor	01.96-06.00	0 261 231 007
Temperature sensor, coolant, injection system	01.96-06.00	0 280 130 026
Wheel speed sensor, front	01.96-06.00	0 265 006 138
Wheel speed sensor, rear	01.96-06.00 LAB	0 265 006 139
	RAB	0 265 006 140

Y 10		
1.0 i fire [156]	1,0l 33 kW 156A2.246 SPI-Bosch 4 Zyl.	
Temperature sensor, coolant, injection system	01.89-02.92	0 280 130 026
1.0 i fire 4x4 [156]	1,0l 33 kW 156A2.246 4 Zyl.	
Temperature sensor, coolant, injection system	10.87-07.89	0 280 130 026
1.1 i [156]	1,1l 37 kW 156C.046 SPI-Bosch 4 Zyl.	
Speed sensor, ignition/injection	09.92-12.95	0 261 210 098
Temperature sensor, coolant, injection system	09.92-12.95	0 280 130 026
1.1 i fire LX [156]	1,1l 37/41 kW 156C.000 SPI-Bosch; 156C.046 Kat 4 Zyl.	
Temperature sensor, coolant, injection system	03.89-09.92	0 280 130 026
1.1 i fire 4x4 [156]	1,1l 41 kW 156C.000 SPI-Bosch 4 Zyl.	
Temperature sensor, coolant, injection system	01.89-09.92	0 280 130 026
1.1 i Selectronic, i 4x4 [156]	1,1l 37 kW 156C.046 SPI-Bosch 4 Zyl.	
Temperature sensor, coolant, injection system	09.92-12.95	0 280 130 026
1.3 i [156]	1,3l 53 kW 146A5.046 MPI-Bosch 4 Zyl.	
Air flow sensor, gasoline injection	09.92-12.95	0 280 200 602
Temperature sensor, coolant, injection system	09.92-12.95	0 280 130 026
Relay, Jetronic	09.92-12.95	0 332 014 113
1.3 i GT [156]	1,3l 53/54/56/57 kW 146A5.046 Kat/MPI-Bosch; 156B.000 4 Zyl.	
Throttle valve sensor	11.87-09.92	0 280 120 328
Air flow sensor, gasoline injection	11.87-09.92	0 280 200 602
Temperature sensor, coolant, injection system	11.87-09.92	0 280 130 026
Relay, Jetronic	11.87-09.92	0 332 014 113





Product



Ypsilon			
1.2 8V [843]	1,2l 44 kW 188A4.000	4 Zyl.	
Phase sensor	06.03→	0 232 103 048	
Speed sensor, ignition/injection	11.03-03.04	0 261 210 114	
Pressure sensor, intake manifold, gasoline	06.03→	0 261 230 030	
Wheel speed sensor, front	06.03→	0 265 007 830	
Wheel speed sensor, rear	06.03→	0 265 008 049	0 265 008 188
1.2 16V [843]	1,2l 59 kW 188A5.000	4 Zyl.	
Speed sensor, ignition/injection	06.03-09.06	0 261 210 238	
Knock sensor	06.03-09.06	0 261 231 173	
Wheel speed sensor, front	06.03-09.06	0 265 007 830	
Wheel speed sensor, rear	06.03-09.06	0 265 008 049	0 265 008 188
1.3 JTD 16V [843]	1,3l 51 kW 188A4.000	4 Zyl.	
Air mass meter, diesel	06.03-09.06	0 281 002 613	
Wheel speed sensor, front	06.03-09.06	0 265 007 830	
Wheel speed sensor, rear	06.03-09.06	0 265 008 049	0 265 008 188
1.3 Multijet 16V [843]	1,3l 55 kW 199A2000	4 Zyl.	
Air mass meter, diesel	10.06→	0 281 002 792	
Wheel speed sensor, front	10.06→	0 265 007 830	
Wheel speed sensor, rear	10.06→	0 265 008 049	0 265 008 188
1.3 Multijet 16V [843]	1,3l 66 kW 199A3000	4 Zyl.	
Air mass meter, diesel	10.06→	0 281 002 792	
Boost pressure sensor, Diesel	10.06-11.06	0 281 002 437	12.06→ 0 281 002 845
Wheel speed sensor, front	10.06→	0 265 007 830	
Wheel speed sensor, rear	10.06→	0 265 008 049	0 265 008 188
1.4 8V [843]	1,4l 57 kW 843A1.000	4 Zyl.	
Phase sensor	10.06→	0 232 103 048	
Pressure sensor, intake manifold, gasoline	10.06→	0 261 230 030	
Wheel speed sensor, front	10.06→	0 265 007 830	
Wheel speed sensor, rear	10.06→	0 265 008 049	
1.4 16V [843]	1,4l 70 kW 843A1.000	4 Zyl.	
Throttle valve assembly	06.03-03.04	0 280 750 137	
Speed sensor, ignition/injection	06.03→	0 261 210 238	
Knock sensor	06.03→	0 261 231 173	
Wheel speed sensor, front	06.03→	0 265 007 830	
Wheel speed sensor, rear	06.03→	0 265 008 049	0 265 008 188

ZETA			
2.0 i.e. Turbo [122]	2,0l 110 kW RGX	4 Zyl.	
Throttle valve sensor			
Ricam.no →6779	09.94-06.95	0 280 122 001	
Ricam.no 6780→	07.95-06.99	0 280 122 003	
Knock sensor			
Ricam.no 0008135→	03.99-06.99	0 261 231 130	
Wheel speed sensor, front	09.94-06.99	0 265 006 388	
Wheel speed sensor, rear	09.97-06.99	0 265 006 406	09.94-08.97 0 265 006 426
2.0 JTD [122]	2,0l 80 kW RHW; RHZ	4 Zyl.	
High-pressure sensor (CR system)	06.99-06.02	0 281 002 283	
Wheel speed sensor, front	06.99-06.02	0 265 006 388	
Wheel speed sensor, rear	06.99-06.02	0 265 006 406	

Product



2.0 16V [122]	2,0l 97 kW RFN	4 Zyl.
Pressure sensor, intake manifold, gasoline	10.00-06.02	0 261 230 057
Wheel speed sensor, front	10.00-06.02	0 265 006 388
Wheel speed sensor, rear	10.00-06.02	0 265 006 504
2.0 16V [122]	2,0l 97 kW RFV	4 Zyl.
Throttle valve sensor	06.99-10.00	0 280 122 009
Knock sensor	06.99-10.00	0 261 231 130
Pressure sensor, intake manifold, gasoline	06.99-10.00	0 261 230 012
Wheel speed sensor, front	06.99-10.00	0 265 006 388
Wheel speed sensor, rear	06.99-10.00	0 265 006 406
2.1 TD [122]	2,1l 80 kW P8C	4 Zyl.
Wheel speed sensor, front	05.96-06.99	0 265 006 388
Wheel speed sensor, rear	09.97-06.99	0 265 006 406
	05.96-08.97	0 265 006 426

LAND ROVER GROUP

Defender 90		
2.5 Td5	2,5l 90 kW Td5	5 Zyl.
Boost pressure sensor, Diesel	06.98-07.07	0 281 002 205
Temperature sensor, coolant, diesel	06.98-07.07	0 280 130 026

Defender 110		
2.5 Td5	2,5l 90 kW Td5	5 Zyl.
Boost pressure sensor, Diesel	06.98-07.07	0 281 002 205
Temperature sensor, coolant, diesel	06.98-07.07	0 280 130 026

Defender 130		
2.5 Td5	2,5l 90 kW Td5	5 Zyl.
Boost pressure sensor, Diesel	06.98-07.07	0 281 002 205
Temperature sensor, coolant, diesel	06.98-07.07	0 280 130 026

Discovery			
2.5 TDi	2,5l 82-83 kW 19L 21L	4 Zyl.	
Air flow sensor, diesel	10.93-12.98	0 281 002 092	
Pulse generator, diesel	10.93-12.98 AG	0 281 002 104	
	CH 10.93-12.98	0 281 002 107	
Speed sensor, diesel	10.93-12.98	0 261 210 028	
Pressure sensor, intake manifold, diesel	10.93-12.98	0 281 002 063	
Temperature sensor, coolant, diesel	10.93-12.98	0 280 130 026	
Temperature sensor, intake air, diesel	10.93-12.98	0 280 130 039	
Pedal position sensor, diesel	10.93-12.98	0 205 001 021	
2.5 Td5	2,5l 100-102 kW 5ROHC	5 Zyl.	
Boost pressure sensor, Diesel	10.98-10.04	0 281 002 205	
Temperature sensor, coolant, diesel	10.98-10.04	0 280 130 026	
2.7 TDV6	2,7l 140 kW TDV6	6 Zyl.	
Duo sensor, acceleration and yaw rate, brake system	10.04→	0 265 005 639	
Wheel speed sensor, front			
Fg.no. 6A351057→	10.04→	0 265 007 923	
Wheel speed sensor, rear	10.04→	0 265 007 922	
4.0	4,0l 161 kW 4.0-V6	6 Zyl.	
Duo sensor, acceleration and yaw rate, brake system	10.04→	0 265 005 639	
Wheel speed sensor, front			
Fg.no. 6A351057→	10.04→	0 265 007 923	
Wheel speed sensor, rear	10.04→	0 265 007 922	



4.0i			4,0l 136 kW V8 - EFi 8 Zyl.
Throttle valve sensor	10.98-10.04		0 280 122 016
Air mass meter, gasoline injection	10.98-10.04		0 280 217 532
Speed sensor, ignition/injection	10.98-10.04	AG	0 261 210 158
		GS	0 261 210 155
Knock sensor	10.98-10.04	ZE	0 261 231 140
4.4			4,4l 220 kW AJ-V8 4.4 EFi 8 Zyl.
Duo sensor, acceleration and yaw rate, brake system	10.04→		0 265 005 639
Wheel speed sensor, front			
Fg.no. 6A351057→	10.04→		0 265 007 923
Wheel speed sensor, rear	10.04→		0 265 007 922

Freelander I

2.0D			2,0l 70-72 kW TCie 17N,18N 4 Zyl.
Air mass meter, diesel	09.97-09.03	EDC	0 281 002 182
Temperature sensor, coolant, diesel	09.97-09.03		0 280 130 026
Temperature sensor, intake air, diesel	09.97-09.03		0 280 130 039

Range Rover I

2.5 TDi			2,5l 81-83 kW 300 TDi 4 Zyl.
Temperature sensor, coolant, diesel	01.95-04.96		0 280 130 026
2.5 TDi Classic			2,5l 83 kW 14L 4 Zyl.
Air flow sensor, diesel	10.92-09.94		0 281 002 092
Pulse generator, diesel	10.92-09.94	AG	0 281 002 104
		CH	0 281 002 107
Pressure sensor, intake manifold, diesel	10.92-09.94		0 281 002 063
Temperature sensor, coolant, diesel	10.92-09.94		0 280 130 026
Temperature sensor, intake air, diesel	10.92-09.94		0 280 130 039
Pedal position sensor, diesel	10.92-09.94		0 205 001 021
3.5i			3,5l 110 kW V8F-EFi 8 Zyl.
Relay, Jetronic	01.87-09.90		0 332 014 113
3.5i			3,5l 112 kW 22D 8 Zyl.
Air flow sensor, gasoline injection	06.70-06.86		0 280 202 008
Relay, Jetronic	06.70-06.86		0 332 014 113
3.5i			3,5l 120 kW 24D,25D 8 Zyl.
Air flow sensor, gasoline injection	10.85-09.89		0 280 202 046
			0 986 280 027
Relay, Jetronic	10.85-09.90		0 332 014 113

Range Rover II

2.5D			2,5l 100-102 kW 25 6T 6 Zyl.
Pedal position sensor, diesel			
	Fg.no. WA 376580→	09.94-09.02	0 205 001 040
	Fg.no. →WA 376579	09.94-09.02	0 205 001 006
4.0i V8			4,0l 136-140 kW 42D 8 Zyl.
Air mass meter, gasoline injection			
Fg.no. XA 410482→	09.94-09.02		0 280 218 010
Speed sensor, ignition/injection	09.94-09.02	AG	0 261 210 158
Knock sensor			
Fg.no. XA 410482→	09.94-09.02		0 261 231 140
4.6i V8			4,6l 158-166 kW 46D 8 Zyl.
Air mass meter, gasoline injection			
Fg.no. XA 410482→	09.94-09.02		0 280 218 010
Speed sensor, ignition/injection	09.94-09.02	AG	0 261 210 158
Knock sensor			
Fg.no. XA 410482→	09.94-09.02		0 261 231 140



Range Rover III

3.0 Td6			2,9l 130 kW M57 D30 6 Zyl.
Pressure sensor, ESP, (electronic stability program)	03.02-09.06		0 265 005 303
3.6 TDV8			3,6l 200 kW 3.6 32V Lion 8 Zyl.
Phase sensor	09.06→		0 232 103 052
Duo sensor, acceleration and yaw rate, brake system	09.06→		0 265 005 655
4.2 V8 Supercharged			4,2l 291 kW AJ-V8 8 Zyl.
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. 5A000001→6A999999	03.05→		0 265 005 639
Fg.no. 7A000001→	03.05→		0 265 005 655
4.4 V8			4,4l 210 kW M62B44 V8 8 Zyl.
Air mass meter, gasoline injection	03.02→		0 280 217 814
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →4A999999	03.02→		0 265 005 248
Fg.no. 5A000001→6A999999	03.02→		0 265 005 639
4.4 V8			4,4l 225 kW AJ 4.4 8 Zyl.
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. 5A000001→6A999999	05.05→		0 265 005 639
Fg.no. 7A000001→	05.05→		0 265 005 655

Range Rover IV Sport

2.7 TDV6			2,7l 140 kW Lion 2.7-Liter-V6 6 Zyl.
Duo sensor, acceleration and yaw rate, brake system	03.05→		0 265 005 639
Wheel speed sensor, front	03.05→		0 265 007 924
Wheel speed sensor, rear	03.05→		0 265 007 922
3.6 TDV8			3,6l 200 kW 3.6 32V Lion 8 Zyl.
Phase sensor	01.07→		0 232 103 052
Duo sensor, acceleration and yaw rate, brake system	01.07→		0 265 005 639
Wheel speed sensor, front	01.07→		0 265 007 924
Wheel speed sensor, rear	01.07→		0 265 007 922
4.2 V8 Supercharged			4,2l 286-287 kW AJ-V8 4.2 Kompr. 8 Zyl.
Duo sensor, acceleration and yaw rate, brake system	03.05→		0 265 005 639
Wheel speed sensor, front	03.05→		0 265 007 924
Wheel speed sensor, rear	03.05→		0 265 007 922
4.4 V8			4,4l 220 kW AJ-V8 4.4 EFi-V8 8 Zyl.
Duo sensor, acceleration and yaw rate, brake system	03.05→		0 265 005 639
Wheel speed sensor, front	03.05→		0 265 007 924
Wheel speed sensor, rear	03.05→		0 265 007 922

MAZDA

MPV

2.3i [LW]			2,3l 104 kW L3 4 Zyl.
Pressure sensor, intake manifold, gasoline	03.02-06.04	FAR	0 261 230 180

MX-5

1.8 [NC]			1,8l 93 kW 4 Zyl.
Pressure sensor, intake manifold, gasoline			
Fg.no. →115161	07.05→		0 261 230 180





Product				

◀ MX-5

2.0 [NC]	2,0l 118 kW 4 Zyl.
Pressure sensor, intake manifold, gasoline	
Fg.no. →115161	07.05→ 0 261 230 180

Tribute

2.3 i, i4x4 [EP]	2,3l 110 kW GZ 4 Zyl.
Pressure sensor, intake manifold, gasoline	12.03-05.04 0 261 230 180

3 Hatchback

2.0 [BK]	2,0l 110 kW LF 4 Zyl.
Pressure sensor, intake manifold, gasoline	
Fg.no. 138361→381360	07.03→ FAR 0 261 230 180

3 Sedan

2.0 [BK]	2,0l 110 kW LF 4 Zyl.
Pressure sensor, intake manifold, gasoline	
Fg.no. 138361→381360	07.03→ FAR 0 261 230 180

5

1.8 [CR]	1,8l 85 kW L8 4 Zyl.
Pressure sensor, intake manifold, gasoline	02.05→ 0 261 230 180
2.0 [CR]	2,0l 107 kW LF 4 Zyl.
Pressure sensor, intake manifold, gasoline	02.05→ 0 261 230 180

6 Fastback

1.8 [GG/GY]	1,8l 88 kW L8 4 Zyl.
Pressure sensor, intake manifold, gasoline	
Fg.no. →654518	03.05→ 0 261 230 180
2.0 [GG/GY]	2,0l 104-108 kW LF 4 Zyl.
Pressure sensor, intake manifold, gasoline	
Fg.no. →654518	03.05→ 0 261 230 180
2.3 [GG/GY]	2,3l 122 kW L3 4 Zyl.
Pressure sensor, intake manifold, gasoline	
Fg.no. →654518	03.05→ 0 261 230 180

6 Sedan

1.8 [GG/GY]	1,8l 88 kW L8 4 Zyl.
Pressure sensor, intake manifold, gasoline	
Fg.no. →654518	03.05→ 0 261 230 180
2.0 [GG/GY]	2,0l 104-108 kW LF 4 Zyl.
Pressure sensor, intake manifold, gasoline	
Fg.no. →654518	03.05→ 0 261 230 180
2.3 [GG/GY]	2,3l 122 kW L3 4 Zyl.
Pressure sensor, intake manifold, gasoline	
Fg.no. →654518	03.05→ 0 261 230 180
2.3 MPS 4x4 [GG/GY]	2,3l 191 kW 4 Zyl.
Boost pressure sensor, gasoline	
Fg.no. →655119	07.05→ 0 261 230 128

6 Wagon

1.8 [GG/GY]	1,8l 88 kW L8 4 Zyl.
Pressure sensor, intake manifold, gasoline	
Fg.no. →427967	03.05→ 0 261 230 180
2.0 [GG/GY]	2,0l 104-108 kW LF 4 Zyl.
Pressure sensor, intake manifold, gasoline	
Fg.no. →427967	03.05→ 0 261 230 180

Product				

2.3 [GG/GY]	2,3l 122 kW L3 4 Zyl.
Pressure sensor, intake manifold, gasoline	
Fg.no. →427967	03.05→ 0 261 230 180
2.3 4x4 [GG/GY]	2,3l 119 kW L3 4 Zyl.
Pressure sensor, intake manifold, gasoline	
Fg.no. →427967	03.05→ 0 261 230 180

MERCEDES-BENZ

Classe A

160 [168]	1,6l 75 kW M 166.960 4 Zyl.
Speed sensor, ignition/injection	05.99-08.05 0 261 210 170
Duo sensor, acceleration and yaw rate, brake system	05.99-08.05 0 265 005 258
Pressure sensor, ESP, (electronic stability program)	05.99-08.05 0 265 005 303
Fg.no. A029701→	05.99-08.05 0 265 005 307
Wheel speed sensor, front	05.99-08.05 LAB 0 265 006 370
	RAB 0 265 006 368
Wheel speed sensor, rear	05.99-08.05 0 265 006 372
190 [168]	1,9l 92 kW M 166.990 4 Zyl.
Speed sensor, ignition/injection	09.00-08.05 0 261 210 170
Duo sensor, acceleration and yaw rate, brake system	09.00-08.05 0 265 005 258
Pressure sensor, ESP, (electronic stability program)	09.00-08.05 0 265 005 303
Wheel speed sensor, front	09.00-08.05 LAB 0 265 006 370
	RAB 0 265 006 368
Wheel speed sensor, rear	09.00-08.05 0 265 006 372

MB

100	2,3l 110 kW M 161.971 4 Zyl.
Air mass meter, gasoline injection	11.96→ 0 280 217 100
Speed sensor, ignition/injection	11.96→ 0 281 002 123

Serie A

140 [168]	1,4l 60 kW M 166.940 4 Zyl.
Speed sensor, ignition/injection	01.98-08.04 0 261 210 170
	10.97-12.97 0 281 002 123
Duo sensor, acceleration and yaw rate, brake system	10.97-05.99 0 265 005 201
	06.99-08.04 0 265 005 258
Pressure sensor, ESP, (electronic stability program)	10.97-08.04 0 265 005 303
Wheel speed sensor, front	10.97-08.04 LAB 0 265 006 370
	RAB 0 265 006 368
Wheel speed sensor, rear	10.97-08.04 0 265 006 372
150 [169]	1,5l 70 kW M 266.920 4 Zyl.
Phase sensor	09.04→ 0 232 103 050
Speed sensor, ignition/injection	09.04→ 0 261 210 170
Duo sensor, acceleration and yaw rate, brake system	09.04→ 0 265 005 298
Wheel speed sensor, front	09.04→ 0 265 007 478
Wheel speed sensor, rear	09.04→ 0 265 007 480
160 [168]	1,6l 75 kW M 166.960 4 Zyl.
Speed sensor, ignition/injection	01.98-08.04 0 261 210 170
	10.97-12.97 0 281 002 123
Duo sensor, acceleration and yaw rate, brake system	10.97-05.99 0 265 005 201
	06.99-08.04 0 265 005 258
Pressure sensor, ESP, (electronic stability program)	10.97-08.04 0 265 005 303
Wheel speed sensor, front	10.97-08.04 LAB 0 265 006 370
	RAB 0 265 006 368
Wheel speed sensor, rear	10.97-08.04 0 265 006 372



Product		
160 CDI [168] 1,7l 44 kW OM 668.941 4 Zyl.		
Air mass meter, diesel		
Mot.no. →30210110	09.98-02.01	0 281 002 281
Speed sensor, diesel	09.98-02.01	0 261 210 170
High-pressure sensor (CR system)	09.98-02.01	0 281 002 498
Duo sensor, acceleration and yaw rate, brake system	09.98-05.99 06.99-02.01	0 265 005 201 0 265 005 258
Pressure sensor, ESP, (electronic stability program)	09.98-02.01	0 265 005 303
Wheel speed sensor, front	09.98-02.01 LAB RAB	0 265 006 370 0 265 006 368
Wheel speed sensor, rear	09.98-02.01	0 265 006 372
160 CDI [168] 1,7l 55 kW OM 668.940 4 Zyl.		
Air mass meter, diesel		
Mot.no. →30210110	03.01-08.04	0 281 002 281
Speed sensor, diesel	03.01-08.04	0 261 210 170
High-pressure sensor (CR system)	03.01-08.04	0 281 002 498
Duo sensor, acceleration and yaw rate, brake system	03.01-08.04	0 265 005 258
Pressure sensor, ESP, (electronic stability program)	03.01-08.04	0 265 005 303
Wheel speed sensor, front	03.01-08.04 LAB RAB	0 265 006 370 0 265 006 368
Wheel speed sensor, rear	03.01-08.04	0 265 006 372
160 CDI [169] 2,0l 60 kW OM 640.942 4 Zyl.		
Speed sensor, diesel	09.04→	0 261 210 170
High-pressure sensor (CR system)	09.04→	0 281 002 504
Duo sensor, acceleration and yaw rate, brake system	09.04→	0 265 005 298
Wheel speed sensor, front	09.04→	0 265 007 478
Wheel speed sensor, rear	09.04→	0 265 007 480
170 [169] 1,7l 85 kW M 266.940 4 Zyl.		
Phase sensor	09.04→	0 232 103 050
Speed sensor, ignition/injection	09.04→	0 261 210 170
Duo sensor, acceleration and yaw rate, brake system	09.04→	0 265 005 298
Wheel speed sensor, front	09.04→	0 265 007 478
Wheel speed sensor, rear	09.04→	0 265 007 480
170 CDI [168] 1,7l 66 kW OM 668.940 4 Zyl.		
Air mass meter, diesel		
Mot.no. →30210110	07.98-02.01	0 281 002 281
Speed sensor, diesel	07.98-02.01	0 261 210 170
High-pressure sensor (CR system)	07.98-02.01	0 281 002 498
Duo sensor, acceleration and yaw rate, brake system	07.98-05.99 06.99-02.01	0 265 005 201 0 265 005 258
Pressure sensor, ESP, (electronic stability program)	07.98-02.01	0 265 005 303
Wheel speed sensor, front	07.98-02.01 LAB RAB	0 265 006 370 0 265 006 368
Wheel speed sensor, rear	07.98-02.01	0 265 006 372
170 CDI [168] 1,7l 66/70 kW OM 668.942 4 Zyl.		
Air mass meter, diesel		
Mot.no. →30210110	03.01-08.04	0 281 002 281
Speed sensor, diesel	03.01-08.04	0 261 210 170
High-pressure sensor (CR system)	03.01-08.04	0 281 002 498
Duo sensor, acceleration and yaw rate, brake system	03.01-08.04	0 265 005 258
Pressure sensor, ESP, (electronic stability program)	03.01-08.04	0 265 005 303
Wheel speed sensor, front	03.01-08.04 LAB RAB	0 265 006 370 0 265 006 368
Wheel speed sensor, rear	03.01-08.04	0 265 006 372
180 CDI [169] 2,0l 80 kW OM 640.940 4 Zyl.		
Speed sensor, diesel	09.04→	0 261 210 170
High-pressure sensor (CR system)	09.04→	0 281 002 504
Duo sensor, acceleration and yaw rate, brake system	09.04→	0 265 005 298



Wheel speed sensor, front	09.04→	0 265 007 478
Wheel speed sensor, rear	09.04→	0 265 007 480
190 [168] 1,9l 92 kW M 166.990 4 Zyl.		
Speed sensor, ignition/injection	03.99-08.04	0 261 210 170
Duo sensor, acceleration and yaw rate, brake system	03.99-05.99 06.99-08.04	0 265 005 201 0 265 005 258
Pressure sensor, ESP, (electronic stability program)	03.99-08.04	0 265 005 303
Wheel speed sensor, front	03.99-08.04 LAB RAB	0 265 006 370 0 265 006 368
Wheel speed sensor, rear	03.99-08.04	0 265 006 372
200 [169] 2,0l 100 kW M 266.960 4 Zyl.		
Phase sensor	09.04→	0 232 103 050
Speed sensor, ignition/injection	09.04→	0 261 210 170
Duo sensor, acceleration and yaw rate, brake system	09.04→	0 265 005 298
Wheel speed sensor, front	09.04→	0 265 007 478
Wheel speed sensor, rear	09.04→	0 265 007 480
200 CDI [169] 2,0l 103 kW OM 640.941 4 Zyl.		
Speed sensor, diesel	09.04→	0 261 210 170
High-pressure sensor (CR system)	09.04→	0 281 002 504
Duo sensor, acceleration and yaw rate, brake system	09.04→	0 265 005 298
Wheel speed sensor, front	09.04→	0 265 007 478
Wheel speed sensor, rear	09.04→	0 265 007 480
200 Turbo [169] 2,0l 142 kW M 266.980 4 Zyl.		
Phase sensor	06.05→	0 232 103 050
Speed sensor, ignition/injection	06.05→	0 261 210 170
Duo sensor, acceleration and yaw rate, brake system	06.05→	0 265 005 298
Wheel speed sensor, front	06.05→	0 265 007 478
Wheel speed sensor, rear	06.05→	0 265 007 480
210 Evolution [168] 2,1l 103 kW M 166.995 4 Zyl.		
Speed sensor, ignition/injection	03.02-08.04	0 261 210 170
Duo sensor, acceleration and yaw rate, brake system	03.02-08.04	0 265 005 258
Pressure sensor, ESP, (electronic stability program)	03.02-08.04	0 265 005 303
Wheel speed sensor, front	03.02-08.04 LAB RAB	0 265 006 370 0 265 006 368
Wheel speed sensor, rear	03.02-08.04	0 265 006 372

Serie B

150 [245] 1,5l 70 kW M 266.920 4 Zyl.		
Phase sensor	04.05→	0 232 103 050
Speed sensor, ignition/injection	04.05→	0 261 210 170
Duo sensor, acceleration and yaw rate, brake system	04.05→	0 265 005 298
Wheel speed sensor, front	04.05→	0 265 007 478
Wheel speed sensor, rear	04.05→	0 265 007 480
170 [245] 1,7l 85 kW M 266.940 4 Zyl.		
Phase sensor	04.05→	0 232 103 050
Speed sensor, ignition/injection	04.05→	0 261 210 170
Duo sensor, acceleration and yaw rate, brake system	04.05→	0 265 005 298
Wheel speed sensor, front	04.05→	0 265 007 478
Wheel speed sensor, rear	04.05→	0 265 007 480
180 CDI [245] 2,0l 80 kW OM 640.940 4 Zyl.		
Speed sensor, diesel	04.05→ FKW	0 261 210 170
Phase sensor	04.05→	0 232 103 050
High-pressure sensor (CR system)	04.05→	0 281 002 504
Duo sensor, acceleration and yaw rate, brake system	04.05→	0 265 005 298



◀ Serie B

Wheel speed sensor, front	04.05→	0 265 007 478
Wheel speed sensor, rear	04.05→	0 265 007 480
200 [245]	2,0l 100 kW M 266.960 4 Zyl.	
Phase sensor	04.05→	0 232 103 050
Speed sensor, ignition/injection	04.05→	0 261 210 170
Duo sensor, acceleration and yaw rate, brake system	04.05→	0 265 005 298
Wheel speed sensor, front	04.05→	0 265 007 478
Wheel speed sensor, rear	04.05→	0 265 007 480
200 CDI [245]	2,0l 103 kW OM 640.941 4 Zyl.	
Speed sensor, diesel	04.05→ FKW	0 261 210 170
Phase sensor	04.05→	0 232 103 050
High-pressure sensor (CR system)	04.05→	0 281 002 504
Duo sensor, acceleration and yaw rate, brake system	04.05→	0 265 005 298
Wheel speed sensor, front	04.05→	0 265 007 478
Wheel speed sensor, rear	04.05→	0 265 007 480
200 Turbo [245]	2,0l 142 kW M 266.980 4 Zyl.	
Phase sensor	04.05→	0 232 103 050
Speed sensor, ignition/injection	04.05→	0 261 210 170
Duo sensor, acceleration and yaw rate, brake system	04.05→	0 265 005 298
Wheel speed sensor, front	04.05→	0 265 007 478
Wheel speed sensor, rear	04.05→	0 265 007 480

Serie C

30 AMG CDI [203]	3,0l 170 kW OM 612.990 5 Zyl.	
Air mass meter, diesel	01.03-08.04	0 281 002 535
Speed sensor, diesel	01.03-08.04	0 261 210 170
High-pressure sensor (CR system)		
Mot.no. →30 287865,→40 176145,→50 846433,→60 001942	01.03-08.04	0 281 002 498
Mot.no. 30 287866→,40 176146→,50 846434→,60 001943→	01.03-08.04	0 281 002 700
30 AMG CDI Coupé [203]	3,0l 170 kW OM 612.990 5 Zyl.	
Air mass meter, diesel	09.02-08.04	0 281 002 535
Speed sensor, diesel	09.02-08.04	0 261 210 170
High-pressure sensor (CR system)		
Mot.no. →30 287865,→40 176145,→50 846433,→60 001942	09.02-08.04	0 281 002 498
Mot.no. 30 287866→,40 176146→,50 846434→,60 001943→	09.02-08.04	0 281 002 700
32 AMG KOMPRESSOR [203]	3,2l 260 kW M 112.961 6 Zyl.	
Throttle valve assembly	01.01-01.04	0 280 750 017
Phase sensor	01.01-01.04	0 232 103 050
Speed sensor, ignition/injection	01.01-01.04	0 261 210 170
Knock sensor	01.01-01.04	0 261 231 110
Pressure sensor, ESP, (electronic stability program)		
Fg.no. →A 216361/F 161299	01.01-01.04	0 265 005 307
36 AMG [202]	3,6l 206 kW M 104.941 6 Zyl.	
Throttle valve assembly		
Mot.no. 006909→,Comp. no. Code 807	01.94-05.97 ASR,GS,OTT	0 205 003 042
Mot.no. 084643→,Comp. no. Code 807	01.94-05.97 AG,ASR,OTT	0 205 003 042
Air mass meter, gasoline injection		
Mot.no. →12/52 084642,Comp. no. Code 807	01.94-05.97	0 280 217 500
Mot.no. 006909→,Comp. no. Code 807	01.94-05.97 GS	0 280 217 517
Mot.no. 084643→,Comp. no. Code 807	08.96-05.97	0 280 218 080
Mot.no. 084643→,Comp. no. Code 807	01.94-05.97 AG	0 280 217 517



Speed sensor, ignition/injection			
Mot.no. →004555	01.94-05.97	GS	0 261 210 085
Mot.no. →042151	01.94-05.97	AG	0 261 210 085
Mot.no. 004556→006908	01.94-05.97	GS	0 261 210 122
Mot.no. 006909→	01.94-05.97	GS	0 261 210 141
Mot.no. 042152→084642	01.94-05.97	AG	0 261 210 122
Mot.no. 084643→	01.94-05.97	AG	0 261 210 141
Pedal position sensor, EMS (electronic engine management)			
09.96-05.97 0 205 001 302			
Wheel speed sensor, front			
Fg.no. A334661→A809594, F331441→F894083,202...A/B/C/D/E, Comp. no. Code 806/809, ~~Comp. no. Code 800/805~~	01.94-05.97	BO,LAB	0 265 006 266
Fg.no. A344661→A809594, F331441→F894083,202...A/B/C/D/E, Comp. no. Code 806/809, ~~Comp. no. Code 800/805~~	01.94-05.97	BO,RAB	0 265 006 264
Fg.no. →A344660,→F331440, Comp. no. Code 805, ~~Comp. no. Code 806~~	01.94-05.97	BO,LAB	0 265 006 248
		BO,RAB	0 265 006 242
Wheel speed sensor, rear			
	01.94-05.97	BO,LAB, MET	0 265 006 192
		BO,MET, RAB	0 265 006 172
		BO,OEA	0 265 002 212
43 AMG [202]	4,3l	225 kW M 113.944 8 Zyl.	
Throttle valve assembly	11.97-04.00		0 205 003 048
Air mass meter, gasoline injection	11.97-04.00		0 280 217 810
Phase sensor	11.97-04.00	NOC	0 232 103 050
Speed sensor, ignition/injection	11.97-04.00	FKW	0 261 210 170
Knock sensor	11.97-04.00		0 261 231 110
Pedal position sensor, EMS (electronic engine management)			
Fg.no. →A653728,→F758207, Comp. no. Code 808, ~~Comp. no. Code 809~~	11.97-04.00		0 205 001 302
Duo sensor, acceleration and yaw rate, brake system	11.97-04.00		0 265 005 201
Pressure sensor, ESP, (electronic stability program)			
Fg.no. A 809595→,F 894084→	11.97-04.00		0 265 005 307
Wheel speed sensor, front			
Fg.no. 202...A/B/C/D/E	11.97-04.00	BO,LAB	0 265 006 266
		BO,RAB	0 265 006 264
Wheel speed sensor, rear			
	11.97-04.00	BO,LAB, MET	0 265 006 192
		BO,MET, RAB	0 265 006 172
		BO,OEA	0 265 002 212
55 AMG [203]	5,4l	270 kW M 113.988 8 Zyl.	
Throttle valve assembly	02.04-08.07		0 280 750 017
Air mass meter, gasoline injection	02.04-08.07		0 280 217 810
Phase sensor	02.04-08.07		0 232 103 050
Speed sensor, ignition/injection	02.04-08.07		0 261 210 170
Knock sensor	02.04-08.07		0 261 231 110
160 KOMPRESSOR Coupé [203]	1,8l	90 kW M 271.921 4 Zyl.	
Throttle valve assembly	06.05→		0 280 750 076
Phase sensor	06.05→		0 232 103 050
Speed sensor, ignition/injection	06.05→		0 261 210 170
180 [202]		1,8l 90 kW M 111.920 4 Zyl.	
Air mass meter, gasoline injection	03.93-08.95		0 280 217 100
Speed sensor, ignition/injection	03.93-08.95		0 261 210 085
Pressure sensor, ESP, (electronic stability program)			
Fg.no. A 809595→,F 894084→	03.93-08.95		0 265 005 307



Wheel speed sensor, front			
Fg.no. A334661→,F331441→, 202...A/B/D/E,Comp. no. Code 806/809, ~~Comp. no. Code 800/805~~	03.93-08.95	BO,LAB	0 265 006 266
Fg.no. A344661→,F331441→, 202...A/B/C/D/E,Comp. no. Code 806/809, ~~Comp. no. Code 800/805~~	03.93-08.95	BO,RAB	0 265 006 264
Fg.no. →A344660,→F331440, Comp. no. Code 805, ~~Comp. no. Code 806~~	03.93-08.95	BO,LAB	0 265 006 248
		BO,RAB	0 265 006 242
Wheel speed sensor, rear	03.93-08.95	BO,LAB, MET	0 265 006 192
		BO,MET, RAB	0 265 006 172
		BO,OEA	0 265 002 212
180 [202]	1,8l	90 kW M 111.921 4 Zyl.	
Throttle valve assembly			
Mot.no. 060039→,Comp. no. Code 809, ~~Comp. no. Code 808~~	09.95-04.00	AG,OTT	0 280 750 074
Mot.no. 106154→,Comp. no. Code 809, ~~Comp. no. Code 808~~	09.95-04.00	GS,OTT	0 280 750 074
Air mass meter, gasoline injection	09.95-04.00	FGK KUT	0 280 217 114 0 280 218 081
Speed sensor, ignition/injection			
Mot.no. →060038	09.95-04.00	AG	0 281 002 123
Mot.no. →106153	09.95-04.00	GS	0 281 002 123
Mot.no. 060039→	09.95-04.00	AG	0 261 210 170
Mot.no. 106154→	09.95-04.00	GS	0 261 210 170
Pressure sensor, ESP, (electronic stability program)			
Fg.no. A 809595→,F 894084→	09.95-04.00		0 265 005 307
Wheel speed sensor, front			
Fg.no. A334661→,F331441→, 202...A/B/D/E,Comp. no. Code 806/809, ~~Comp. no. Code 800/805~~	09.95-04.00	BO,LAB	0 265 006 266
Fg.no. A344661→,F331441→, 202...A/B/C/D/E,Comp. no. Code 806/809, ~~Comp. no. Code 800/805~~	09.95-04.00	BO,RAB	0 265 006 264
Fg.no. →A344660,→F331440, Comp. no. Code 805, ~~Comp. no. Code 806~~	09.95-04.00	BO,LAB	0 265 006 248
		BO,RAB	0 265 006 242
Wheel speed sensor, rear	09.95-04.00	BO,LAB, MET	0 265 006 192
		BO,MET, RAB	0 265 006 172
		BO,OEA	0 265 002 212
180 [203]	2,0l	95 kW M 111.951 4 Zyl.	
Throttle valve assembly	10.00-08.02		0 280 750 067
Speed sensor, ignition/injection	10.00-08.02		0 261 210 170
Pressure sensor, ESP, (electronic stability program)			
Fg.no. →A 216361/F 161299	10.00-08.02		0 265 005 307
180 Coupé [203]	2,0l	95 kW M 111.951 4 Zyl.	
Throttle valve assembly	01.01-08.02		0 280 750 067
Speed sensor, ignition/injection	01.01-08.02		0 261 210 170
180 KOMPRESSOR [203]	1,8l	105 kW M 271.946 4 Zyl.	
Throttle valve assembly	09.02-07.07		0 280 750 076
Phase sensor	09.02-07.07		0 232 103 050
Speed sensor, ignition/injection	09.02-07.07		0 261 210 170
180 KOMPRESSOR [204]	1,8l	115 kW M 271.952 4 Zyl.	
Throttle valve assembly	08.07→		0 280 750 076
Phase sensor	08.07→		0 232 103 050
Speed sensor, ignition/injection	08.07→		0 261 210 170
180 KOMPRESSOR Coupé [203]	1,8l	105 kW M 271.946 4 Zyl.	
Throttle valve assembly	09.02→		0 280 750 076
Phase sensor	09.02→		0 232 103 050
Speed sensor, ignition/injection	09.02→		0 261 210 170



200 [202]				2,0l 100 kW M 111.941 4 Zyl.
Air mass meter, gasoline injection	01.94-04.00			0 280 217 100
Speed sensor, ignition/injection	01.94-04.00			0 261 210 085
Pressure sensor, ESP, (electronic stability program)				
Fg.no. A 809595→,F 894084→	01.94-04.00			0 265 005 307
Wheel speed sensor, front				
Fg.no. A334661→,F331441→, 202...A/B/D/E,Comp. no. Code 806/809, ~~Comp. no. Code 800/805~~	01.94-04.00	BO,LAB		0 265 006 266
Fg.no. A344661→,F331441→, 202...A/B/C/D/E,Comp. no. Code 806/809, ~~Comp. no. Code 800/805~~	01.94-04.00	BO,RAB		0 265 006 264
Fg.no. →A344660,→F331440, Comp. no. Code 805, ~~Comp. no. Code 806~~	01.94-04.00	BO,LAB BO,RAB		0 265 006 248 0 265 006 242
Wheel speed sensor, rear	01.94-04.00	BO,LAB, MET BO,MET, RAB BO,OEA		0 265 006 192 0 265 006 172 0 265 002 212
200 [202]	2,0l 100 kW M 111.945 4 Zyl.			
Throttle valve assembly				
Mot.no. 060039→,Comp. no. Code 809, ~~Comp. no. Code 808~~	01.94-04.00	AG,OTT		0 280 750 074
Mot.no. 106154→,Comp. no. Code 809, ~~Comp. no. Code 808~~	01.94-04.00	GS,OTT		0 280 750 074
Air mass meter, gasoline injection	01.94-04.00	FGK KUT		0 280 217 114 0 280 218 081
Speed sensor, ignition/injection				
Mot.no. →060038	01.94-04.00	AG		0 281 002 123
Mot.no. →106153	01.94-04.00	GS		0 281 002 123
Mot.no. 060039→	01.94-04.00	AG		0 261 210 170
Mot.no. 106154→	01.94-04.00	GS		0 261 210 170
Wheel speed sensor, front				
Fg.no. A334661→,F331441→, 202...A/B/D/E,Comp. no. Code 806/809, ~~Comp. no. Code 800/805~~	01.94-04.00	BO,LAB		0 265 006 266
Fg.no. A344661→,F331441→, 202...A/B/C/D/E,Comp. no. Code 806/809, ~~Comp. no. Code 800/805~~	01.94-04.00	BO,RAB		0 265 006 264
Wheel speed sensor, rear	01.94-04.00	BO,LAB, MET BO,MET, RAB BO,OEA		0 265 006 192 0 265 006 172 0 265 002 212
200 CDI [202]	2,2l 75 kW OM 611.960 4 Zyl.			
Air mass meter, diesel				
Mot.no. →30 055905	03.98-04.00			0 280 217 114
Mot.no. 30 055906→	03.98-04.00			0 281 002 384
Pulse generator, diesel	03.98-04.00			0 281 002 123
High-pressure sensor (CR system)	03.98-04.00			0 281 002 498
Pressure sensor, ESP, (electronic stability program)				
Fg.no. A 809595→,F 894084→	03.98-04.00			0 265 005 307
Wheel speed sensor, front				
Fg.no. A334661→,A809594, F331441→F894083,202...A/B/C/D/E, Comp. no. Code 806/809, ~~Comp. no. Code 800/805~~	03.98-04.00	BO,LAB		0 265 006 266
Fg.no. A344661→A809594, F331441→F894083,202...A/B/C/D/E, Comp. no. Code 806/809, ~~Comp. no. Code 800/805~~	03.98-04.00	BO,RAB		0 265 006 264
Fg.no. →A344660,→F331440, Comp. no. Code 805, ~~Comp. no. Code 806~~	03.98-04.00	BO,LAB BO,RAB		0 265 006 248 0 265 006 242



◀ Serie C

Wheel speed sensor, rear	03.98-04.00	BO,LAB, MET	0 265 006 192
		BO,MET, RAB	0 265 006 172
		BO,OEA	0 265 002 212
200 CDI [203]	2,2l 75/90 kW OM 646.962 4 Zyl.		
Air mass meter, diesel	03.03-07.07		0 281 002 535
Speed sensor, diesel	03.03-07.07		0 261 210 170
High-pressure sensor (CR system)	03.03-07.07		0 281 002 504
200 CDI [203]	2,2l 85 kW OM 611.962 4 Zyl.		
Speed sensor, diesel	10.00-02.03		0 261 210 170
High-pressure sensor (CR system)	10.00-02.03		0 281 002 498
Pressure sensor, ESP, (electronic stability program)			
Fg.no. →A 216361/F 161299	10.00-02.03		0 265 005 307
200 CDI [204]	2,2l 100 kW OM 646.811 4 Zyl.		
Air mass meter, diesel	08.07→		0 281 002 535
Speed sensor, diesel	08.07→		0 261 210 170
200 CDI Coupé [203]	2,2l 90 kW OM 646.962 4 Zyl.		
Air mass meter, diesel	03.03→		0 281 002 535
Speed sensor, diesel	03.03→		0 261 210 170
High-pressure sensor (CR system)	03.03→		0 281 002 504
200 CGI KOMPRESSOR, Coupé [203]	1,8l 125 kW M 271.942 4 Zyl.		
Throttle valve assembly	04.03-08.04		0 280 750 076
Phase sensor	04.03-08.04		0 232 103 050
Speed sensor, ignition/injection	04.03-08.04		0 261 210 170
200 D [202]	2,0l 55 kW OM 601.913 4 Zyl.		
Temperature sensor, coolant, diesel	03.93-08.95	KLO	0 280 130 035
Wheel speed sensor, front	03.93-08.95	LAB	0 265 006 248
		RAB	0 265 006 242
Wheel speed sensor, rear	03.93-08.95	BO,LAB, MET	0 265 006 192
		BO,MET, RAB	0 265 006 172
		BO,OEA	0 265 002 212
200 D [202]	2,0l 55-65 kW OM 604.915 4 Zyl.		
Speed sensor, diesel	09.96-06.99		0 281 002 123
Pedal position sensor, diesel			
Fg.no. →A436535,→F483848,	09.96-06.99		0 205 001 029
Comp. no. Code 806,Comp. no. Code 807			
Wheel speed sensor, front			
Fg.no. A334661→,F331441→,	09.96-06.99	BO,LAB	0 265 006 266
202...A/B/D/E,Comp. no. Code 806/809,			
Comp. no. Code 800/805			
Fg.no. A344661→,F331441→,	09.96-06.99	BO,RAB	0 265 006 264
202...A/B/C/D/E,Comp. no. Code 806/809,			
Comp. no. Code 800/805			
Fg.no. →A344660,→F331440,	09.96-06.99	BO,LAB	0 265 006 248
Comp. no. Code 805,Comp. no. Code 806		BO,RAB	0 265 006 242
Wheel speed sensor, rear	09.96-06.99	BO,LAB, MET	0 265 006 192
		BO,MET, RAB	0 265 006 172
		BO,OEA	0 265 002 212
200 KOMPRESSOR [202]	2,0l 132-141 kW M 111.944 4 Zyl.		
Throttle valve assembly			
Mot.no. 002224→,Comp. no. Code 809,	09.95-04.00	AG	0 280 750 074
Comp. no. Code 808			
Mot.no. 015671→,Comp. no. Code 809,	09.95-04.00	GS	0 280 750 074
Comp. no. Code 808			
Air mass meter, gasoline injection	09.95-04.00	FGK	0 280 217 114
		KUT	0 280 218 081



Speed sensor, ignition/injection			
Mot.no. →060038	09.95-04.00	AG	0 281 002 123
Mot.no. →106153	09.95-04.00	GS	0 281 002 123
Mot.no. 060039→	09.95-04.00	AG	0 261 210 170
Mot.no. 106154→	09.95-04.00	GS	0 261 210 170
Pressure sensor, ESP, (electronic stability program)			
Fg.no. A 809595→,F 894084→	09.95-04.00		0 265 005 307
Wheel speed sensor, front			
Fg.no. →A809594,→F894083,	09.95-04.00	BO,LAB	0 265 006 266
202...A/B/C/D/E,		BO,RAB	0 265 006 264
Comp. no. Code 806/809,			
Comp. no. Code 800/805			
Wheel speed sensor, rear	09.95-04.00	BO,LAB, MET	0 265 006 192
		BO,MET, RAB	0 265 006 172
		BO,OEA	0 265 002 212
200 KOMPRESSOR [203]	1,8l 120 kW M 271.940 4 Zyl.		
Throttle valve assembly	09.02-02.07		0 280 750 076
Phase sensor	09.02-02.07		0 232 103 050
Speed sensor, ignition/injection	09.02-02.07		0 261 210 170
200 KOMPRESSOR [203]	2,0l 120 kW M 111.955 4 Zyl.		
Throttle valve assembly	05.00-08.02		0 280 750 074
Speed sensor, ignition/injection	05.00-08.02		0 261 210 170
Pressure sensor, ESP, (electronic stability program)			
Fg.no. →A 216361/F 161299	05.00-08.02		0 265 005 307
200 KOMPRESSOR [204]	1,8l 135 kW M 271.950 4 Zyl.		
Throttle valve assembly	03.07→		0 280 750 076
Phase sensor	03.07→		0 232 103 050
Speed sensor, ignition/injection	03.07→		0 261 210 170
200 KOMPRESSOR Coupé [203]	1,8l 120 kW M 271.940 4 Zyl.		
Throttle valve assembly	09.02→		0 280 750 076
Phase sensor	09.02→		0 232 103 050
Speed sensor, ignition/injection	09.02→		0 261 210 170
200 KOMPRESSOR Coupé [203]	2,0l 120 kW M 111.955 4 Zyl.		
Throttle valve assembly	01.01-08.02		0 280 750 074
Speed sensor, ignition/injection	01.01-08.02		0 261 210 170
220 [202]	2,2l 110 kW M 111.961 4 Zyl.		
Air mass meter, gasoline injection	03.93-09.96		0 280 217 100
Speed sensor, ignition/injection	03.93-09.96	OWE	0 261 210 085
		WEG	0 261 210 122
Knock sensor	03.93-09.96	OWE	0 261 231 098
Wheel speed sensor, front	03.93-09.95	BO,LAB, OAS	0 265 006 248
		BO,OAS, RAB	0 265 006 242
Fg.no. A334661→,F331441→,	03.93-09.96	BO,LAB	0 265 006 266
202...A/B/D/E,Comp. no. Code 806/809,			
Comp. no. Code 800/805			
Fg.no. A344661→,F331441→,	03.93-09.96	BO,RAB	0 265 006 264
202...A/B/C/D/E,Comp. no. Code 806/809,			
Comp. no. Code 800/805			
Fg.no. →A344660,→F331440,	03.93-09.96	BO,LAB	0 265 006 248
Comp. no. Code 805,Comp. no. Code 806		BO,RAB	0 265 006 242
Wheel speed sensor, rear	03.93-09.96	BO,LAB, MET	0 265 006 192
		BO,MET, RAB	0 265 006 172
		BO,OEA	0 265 002 212
220 CDI [202]	2,2l 92 kW OM 611.960 4 Zyl.		
Air mass meter, diesel			
Mot.no. →30 055905	12.97-04.00		0 280 217 114
Mot.no. 30 055906→	12.97-04.00		0 281 002 384



Pulse generator, diesel	12.97-04.00		0 281 002 123
High-pressure sensor (CR system)	12.97-04.00		0 281 002 498
Pressure sensor, ESP, (electronic stability program)			
Fg.no. A 809595→,F 894084→	12.97-04.00		0 265 005 307
Wheel speed sensor, front			
Fg.no. A334661→A809594, F331441→F894083,202...A/B/C/D/E, Comp. no. Code 806/809, Comp.no.Code 800/805	12.97-04.00	BO,LAB	0 265 006 266
Fg.no. A344661→A809594, F331441→F894083,202...A/B/C/D/E, Comp. no. Code 806/809, Comp.no.Code 800/805	12.97-04.00	BO,RAB	0 265 006 264
Fg.no. →A344660,→F331440, Comp. no. Code 805,Comp.no.Code 806	12.97-04.00	BO,LAB	0 265 006 248
		BO,RAB	0 265 006 242
Wheel speed sensor, rear	12.97-04.00	BO,LAB, MET BO,MET, RAB BO,OEA	0 265 006 192 0 265 006 172 0 265 002 212
220 CDI [203]	2,2l 105 kW OM 611.962 4 Zyl.		
Speed sensor, diesel	05.00-02.03		0 261 210 170
High-pressure sensor (CR system)	05.00-02.03		0 281 002 498
Pressure sensor, ESP, (electronic stability program)			
Fg.no. →A 216361/F 161299	05.00-02.03		0 265 005 307
220 CDI [203]	2,2l 110 kW OM 646.963 4 Zyl.		
Air mass meter, diesel	03.03-02.07		0 281 002 535
Speed sensor, diesel	03.03-02.07		0 261 210 170
High-pressure sensor (CR system)	03.03-02.07		0 281 002 504
220 CDI [204]	2,2l 125 kW OM 646.811 4 Zyl.		
Air mass meter, diesel	03.07→		0 281 002 535
Speed sensor, diesel	03.07→		0 261 210 170
220 CDI Coupé [203]	2,2l 105 kW OM 611.962 4 Zyl.		
Speed sensor, diesel	01.01-02.03		0 261 210 170
High-pressure sensor (CR system)	01.01-02.03		0 281 002 498
220 CDI Coupé [203]	2,2l 110 kW OM 646.963 4 Zyl.		
Air mass meter, diesel	03.03→		0 281 002 535
Speed sensor, diesel	03.03→		0 261 210 170
High-pressure sensor (CR system)	03.03→		0 281 002 504
220 D [202]	2,2l 55-70 kW OM 604.910 4 Zyl.		
Speed sensor, diesel			
Mot.no. →018030	08.93-06.99	AG	0 281 002 100
Mot.no. →086383	08.93-06.99	GS	0 281 002 100
Mot.no. 018031→	08.93-06.99	AG	0 281 002 123
Mot.no. 086384→	08.93-06.99	GS	0 281 002 123
Pedal position sensor, diesel			
Fg.no. A 218853→,F 159752→	08.93-06.99		0 205 001 029
Fg.no. →A 218852,→F 159751	08.93-06.99		0 205 001 008
Wheel speed sensor, front			
Fg.no. A334661→,F331441→, 202...A/B/D/E,Comp. no. Code 806/809, Comp.no.Code 800/805	08.93-06.99	BO,LAB	0 265 006 266
Fg.no. A344661→,F331441→, 202...A/B/C/D/E,Comp. no. Code 806/809, Comp.no.Code 800/805	08.93-06.99	BO,RAB	0 265 006 264
Fg.no. →A344660,→F331440, Comp. no. Code 805,Comp.no.Code 806	08.93-06.99	BO,LAB	0 265 006 248
		BO,RAB	0 265 006 242
Wheel speed sensor, rear	08.93-06.99	BO,LAB, MET BO,MET, RAB BO,OEA	0 265 006 192 0 265 006 172 0 265 002 212



230 [202]	2,3l 110 kW M 111.974 4 Zyl.		
Air mass meter, gasoline injection	09.96-04.00	FGK KUT	0 280 217 114 0 280 218 081
Speed sensor, ignition/injection	09.96-04.00		0 281 002 123
Wheel speed sensor, front	09.96-04.00	BO,LAB BO,RAB	0 265 006 266 0 265 006 264
Wheel speed sensor, rear	09.96-04.00	BO,LAB, MET BO,MET, RAB BO,OEA	0 265 006 192 0 265 006 172 0 265 002 212
230 [203]	2,5l 150 kW M 272.920 6 Zyl.		
Throttle valve assembly	06.05-07.07		0 280 750 017
Air mass meter, gasoline injection	06.05-07.07		0 280 218 190
Phase sensor	06.05-07.07		0 232 103 050
Speed sensor, ignition/injection	06.05-07.07		0 261 210 170
Knock sensor	06.05-07.07		0 261 231 188
230 [204]	2,5l 150 kW M 272.921 6 Zyl.		
Throttle valve assembly	08.07→		0 280 750 017
Air mass meter, gasoline injection	08.07→		0 280 218 190
Phase sensor	08.07→	LAB	0 232 103 050
Knock sensor	08.07→		0 261 231 188
230 Coupé [203]	2,5l 150 kW M 272.920 6 Zyl.		
Throttle valve assembly	06.05→		0 280 750 017
Air mass meter, gasoline injection	06.05→		0 280 218 190
Phase sensor	06.05→		0 232 103 050
Speed sensor, ignition/injection	06.05→		0 261 210 170
Knock sensor	06.05→		0 261 231 188
230 KOMPRESSOR [202]	2,3l 142 kW M 111.975 4 Zyl.		
Throttle valve assembly			
Mot.no. 000268→015300, Comp. no. Code 807/808,Comp.no.Code 809	09.95-04.00	AG	0 205 003 044
Mot.no. 005591→012652, Comp. no. Code 807/808,Comp.no.Code 809	09.95-04.00	GS	0 205 003 044
Mot.no. 012653→,Comp. no. Code 809, Comp.no.Code 808	09.95-04.00	GS	0 280 750 074
Mot.no. 015301→,Comp. no. Code 809, Comp.no.Code 808	09.95-04.00	AG	0 280 750 074
Air mass meter, gasoline injection	09.95-04.00	FGK KUT	0 280 217 114 0 280 218 081
Speed sensor, ignition/injection			
Mot.no. →012652	09.95-04.00	GS	0 281 002 123
Mot.no. →015300	09.95-04.00	AG	0 281 002 123
Mot.no. 012653→	09.95-04.00	GS	0 261 210 170
Mot.no. 015301→	09.95-04.00	AG	0 261 210 170
Pressure sensor, ESP, (electronic stability program)			
Fg.no. A 809595→,F 894084→	09.95-04.00		0 265 005 307
Wheel speed sensor, front			
Fg.no. →A809594,→F894083, 202...A/B/C/D/E,Comp. no. Code 806/809, Comp.no.Code 800/805	09.95-04.00	BO,LAB BO,RAB	0 265 006 266 0 265 006 264
Wheel speed sensor, rear	09.95-04.00	BO,LAB, MET BO,MET, RAB BO,OEA	0 265 006 192 0 265 006 172 0 265 002 212
230 KOMPRESSOR, Coupé [203]	1,8l 141 kW M 271.948 4 Zyl.		
Throttle valve assembly	02.04-05.05		0 280 750 076
Phase sensor	02.04-05.05		0 232 103 050
Speed sensor, ignition/injection	02.04-05.05		0 261 210 170
230 KOMPRESSOR Coupé [203]	2,3l 145 kW M 111.981 4 Zyl.		
Throttle valve assembly	01.01-01.04		0 280 750 074

Product				

◀ Serie C

230 4MATIC [204]	2,5l	150 kW	M 272.911	6 Zyl.
Throttle valve assembly	08.07→		0 280 750 017	
Air mass meter, gasoline injection	08.07→		0 280 218 190	
Phase sensor	08.07→	LAB	0 232 103 050	
Knock sensor	08.07→		0 261 231 188	
240 [202]	2,4l	125 kW	M 112.910	6 Zyl.
Throttle valve assembly	06.97-04.00		0 205 003 046	
Air mass meter, gasoline injection	06.97-04.00		0 280 217 515	
Phase sensor	06.97-04.00		0 232 103 050	
Speed sensor, ignition/injection				
Mot.no. →370998	06.97-04.00		0 261 210 141	
Mot.no. 370999→	06.97-04.00		0 261 210 170	
Knock sensor	06.97-04.00		0 261 231 110	
Pedal position sensor, EMS (electronic engine management)				
Fg.no. →A653728,→F758207,	06.97-04.00		0 205 001 302	
Comp. no. Code 808, ~~Comp. no. Code 809~~				
Duo sensor, acceleration and yaw rate, brake system	06.97-04.00		0 265 005 201	
Pressure sensor, ESP, (electronic stability program)				
Fg.no. A 809595→,F 894084→	06.97-04.00		0 265 005 307	
Wheel speed sensor, front				
Fg.no. 202...A/B/C/D/E	06.97-04.00	BO,LAB	0 265 006 266	
		BO,RAB	0 265 006 264	
Wheel speed sensor, rear	06.97-04.00	BO,LAB,	0 265 006 192	
		MET		
		BO,MET,	0 265 006 172	
		RAB		
		BO,OEA	0 265 002 212	
240 [203]	2,6l	125 kW	M 112.912	6 Zyl.
Throttle valve assembly	05.00-05.05		0 280 750 019	
Air mass meter, gasoline injection	05.00-05.05		0 280 217 515	
Phase sensor	05.00-05.05		0 232 103 050	
Speed sensor, ignition/injection	05.00-05.05		0 261 210 170	
Knock sensor	05.00-05.05		0 261 231 110	
Pressure sensor, ESP, (electronic stability program)				
Fg.no. →A 216361/F 161299	05.00-05.05		0 265 005 307	
240 4MATIC [203]	2,6l	125 kW	M 112.916	6 Zyl.
Throttle valve assembly	09.02-06.05		0 280 750 019	
Air mass meter, gasoline injection	09.02-06.05		0 280 217 515	
Phase sensor	09.02-06.05		0 232 103 050	
Speed sensor, ignition/injection	09.02-06.05		0 261 210 170	
Knock sensor	09.02-06.05		0 261 231 110	
250 D [202]	2,5l	83 kW	OM 605.910	5 Zyl.
Pulse generator, diesel	05.93-08.95		0 281 002 100	
Speed sensor, diesel	05.93-08.95		0 281 002 100	
Pedal position sensor, diesel				
Fg.no. A 218853→,F 159752→	05.93-08.95		0 205 001 029	
Fg.no. →A 218852,→F 159751	05.93-08.95		0 205 001 008	
Wheel speed sensor, front				
Fg.no. →A344660,→F331440,	05.93-08.95	BO,LAB	0 265 006 248	
Comp. no. Code 805, ~~Comp. no. Code 806~~		BO,RAB	0 265 006 242	
Wheel speed sensor, rear	05.93-08.95	BO,LAB,	0 265 006 192	
		MET		
		BO,MET,	0 265 006 172	
		RAB		
		BO,OEA	0 265 002 212	
250 D Turbo [202]	2,5l	110 kW	OM 605.960	5 Zyl.
Air mass meter, diesel	09.95-04.00		0 280 217 114	
Pulse generator, diesel				
Mot.no. →007447, ~~Comp. no. Code 807~~	09.95-04.00	AG	0 281 002 100	
Mot.no. →014999, ~~Comp. no. Code 807~~	09.95-04.00	GS	0 281 002 100	
Mot.no. 007448→,Comp. no. Code 807	09.95-04.00	AG	0 281 002 123	
Mot.no. 015000→,Comp. no. Code 807	09.95-04.00	GS	0 281 002 123	

Product				

Pedal position sensor, diesel	09.95-04.00		0 205 001 029	
Pressure sensor, ESP, (electronic stability program)				
Fg.no. A 809595→,F 894084→	09.95-04.00		0 265 005 307	
Wheel speed sensor, front				
Fg.no. A334661→A809594,	09.95-04.00	BO,LAB	0 265 006 266	
F331441→F894083,202...A/B/C/D/E,				
Comp. no. Code 806/809,				
~~Comp. no. Code 800/805~~				
Fg.no. A344661→A809594,	09.95-04.00	BO,RAB	0 265 006 264	
F331441→F894083,202...A/B/C/D/E,				
Comp. no. Code 806/809,				
~~Comp. no. Code 800/805~~				
Fg.no. →A344660,→F331440,	09.95-04.00	BO,LAB	0 265 006 248	
Comp. no. Code 805, ~~Comp. no. Code 806~~		BO,RAB	0 265 006 242	
Wheel speed sensor, rear	09.95-04.00	BO,LAB,	0 265 006 192	
		MET		
		BO,MET,	0 265 006 172	
		RAB		
		BO,OEA	0 265 002 212	
270 CDI [203]	2,7l	125 kW	OM 612.962	5 Zyl.
Speed sensor, diesel	12.00-08.04		0 261 210 170	
High-pressure sensor (CR system)	12.00-08.04		0 281 002 498	
Pressure sensor, ESP, (electronic stability program)				
Fg.no. →A 216361/F 161299	12.00-08.04		0 265 005 307	
280 [202]	2,8l	142 kW	M 104.941	6 Zyl.
Throttle valve assembly				
Mot.no. 006909→,Comp. no. Code 807	05.93-05.97	ASR,GS,	0 205 003 042	
		OTT		
Mot.no. 084643→,Comp. no. Code 807	05.93-05.97	AG,ASR,	0 205 003 042	
		OTT		
Air mass meter, gasoline injection				
Mot.no. →12/52 084642, ~~Comp. no. Code 807~~	05.93-05.97		0 280 217 500	
Mot.no. 006909→,Comp. no. Code 807	05.93-05.97	GS	0 280 217 517	
Mot.no. 084643→, ~~Comp. no. Code 807~~	08.96-05.97		0 280 218 080	
Mot.no. 084643→,Comp. no. Code 807	05.93-05.97	AG	0 280 217 517	
Speed sensor, ignition/injection				
Mot.no. →004555	05.93-05.97	GS	0 261 210 085	
Mot.no. →042151	05.93-05.97	AG	0 261 210 085	
Mot.no. 004556→006908	05.93-05.97	GS	0 261 210 122	
Mot.no. 006909→	05.93-05.97	GS	0 261 210 141	
Mot.no. 042152→084642	05.93-05.97	AG	0 261 210 122	
Mot.no. 084643→	05.93-05.97	AG	0 261 210 141	
Pedal position sensor, EMS (electronic engine management)	09.96-05.97		0 205 001 302	
Wheel speed sensor, front				
Fg.no. A334661→A809594,	05.93-05.97	BO,LAB	0 265 006 266	
F331441→F894083,202...A/B/C/D/E,				
Comp. no. Code 806/809,				
~~Comp. no. Code 800/805~~				
Fg.no. A344661→A809594,	05.93-05.97	BO,RAB	0 265 006 264	
F331441→F894083,202...A/B/C/D/E,				
Comp. no. Code 806/809,				
~~Comp. no. Code 800/805~~				
Fg.no. →A344660,→F331440,	05.93-05.97	BO,LAB	0 265 006 248	
Comp. no. Code 805, ~~Comp. no. Code 806~~		BO,RAB	0 265 006 242	
Wheel speed sensor, rear	05.93-05.97	BO,LAB,	0 265 006 192	
		MET		
		BO,MET,	0 265 006 172	
		RAB		
		BO,OEA	0 265 002 212	



280 [202]			2,8l 145 kW M 112.920 6 Zyl.
Throttle valve assembly			
Comp. no. Code 800	06.97-04.00		0 205 003 046
Comp. no. Code 801	06.97-04.00		0 280 750 019
Air mass meter, gasoline injection	06.97-04.00		0 280 217 515
Phase sensor	06.97-04.00		0 232 103 050
Speed sensor, ignition/injection			
Mot.no. →370998	06.97-04.00		0 261 210 141
Mot.no. 370999→	06.97-04.00		0 261 210 170
Knock sensor	06.97-04.00		0 261 231 110
Pedal position sensor, EMS (electronic engine management)			
Fg.no. →A653728,→F758207, Comp. no. Code 808,Comp. no. Code 809	06.97-04.00		0 205 001 302
Duo sensor, acceleration and yaw rate, brake system	06.97-04.00		0 265 005 201
Pressure sensor, ESP, (electronic stability program)			
Fg.no. A 809595→,F 894084→	06.97-04.00		0 265 005 307
Wheel speed sensor, front			
Fg.no. 202...A/B/C/D/E	06.97-04.00	BO,LAB	0 265 006 266
		BO,RAB	0 265 006 264
Wheel speed sensor, rear			
	06.97-04.00	BO,LAB, MET	0 265 006 192
		BO,MET, RAB	0 265 006 172
		BO,OEA	0 265 002 212
280 [203]			3,0l 170 kW M 272.940 6 Zyl.
Throttle valve assembly			
	06.05-02.07		0 280 750 017
Air mass meter, gasoline injection	06.05-02.07		0 280 218 190
Phase sensor	06.05-02.07		0 232 103 050
Speed sensor, ignition/injection	06.05-02.07		0 261 210 170
Knock sensor	06.05-02.07		0 261 231 188
280 [204]			3,0l 170 kW M 272.947 6 Zyl.
Throttle valve assembly			
	03.07→		0 280 750 017
Air mass meter, gasoline injection	03.07→		0 280 218 190
Phase sensor	03.07→	LAB	0 232 103 050
Knock sensor	03.07→		0 261 231 188
280 4MATIC [203]			3,0l 170 kW M 272.941 6 Zyl.
Throttle valve assembly			
	07.05-08.07		0 280 750 017
Air mass meter, gasoline injection	07.05-08.07		0 280 218 190
Phase sensor	07.05-08.07		0 232 103 050
Speed sensor, ignition/injection	07.05-08.07		0 261 210 170
Knock sensor	07.05-08.07		0 261 231 188
280 4MATIC [204]			3,0l 170 kW M 272.948 6 Zyl.
Throttle valve assembly			
	07.07→		0 280 750 017
Air mass meter, gasoline injection	07.07→		0 280 218 190
Phase sensor	07.07→	LAB	0 232 103 050
Knock sensor	07.07→		0 261 231 188
320 [203]			3,2l 160 kW M 112.946 6 Zyl.
Throttle valve assembly			
	05.00-05.05		0 280 750 019
Air mass meter, gasoline injection	05.00-05.05		0 280 217 515
Phase sensor	05.00-05.05		0 232 103 050
Speed sensor, ignition/injection	05.00-05.05		0 261 210 170
Knock sensor	05.00-05.05		0 261 231 110
Pressure sensor, ESP, (electronic stability program)			
Fg.no. →A 216361/F 161299	05.00-05.05		0 265 005 307
320 CDI [203]			3,0l 165 kW OM 642.910 6 Zyl.
Speed sensor, diesel			
	09.04-05.07		0 261 210 170
320 Coupé [203]			3,2l 160 kW M 112.946 6 Zyl.
Throttle valve assembly			
	09.02-05.05		0 280 750 019
Air mass meter, gasoline injection	09.02-05.05		0 280 217 515
Phase sensor	09.02-05.05		0 232 103 050



Speed sensor, ignition/injection	09.02-05.05		0 261 210 170
Knock sensor	09.02-05.05		0 261 231 110
320 4MATIC [203]	3,2l	160 kW M 112.953	6 Zyl.
Throttle valve assembly	09.02-06.05		0 280 750 019
Air mass meter, gasoline injection	09.02-06.05		0 280 217 515
Phase sensor	09.02-06.05		0 232 103 050
Speed sensor, ignition/injection	09.02-06.05		0 261 210 170
Knock sensor	09.02-06.05		0 261 231 110
350 [203]	3,5l	200 kW M 272.960	6 Zyl.
Throttle valve assembly	06.05-02.07		0 280 750 017
Air mass meter, gasoline injection	06.05-02.07		0 280 218 190
Phase sensor	06.05-02.07		0 232 103 050
Speed sensor, ignition/injection	06.05-02.07		0 261 210 170
Knock sensor	06.05-02.07		0 261 231 110
350 [204]	3,5l	200 kW M 272.961	6 Zyl.
Throttle valve assembly	03.07→		0 280 750 017
Air mass meter, gasoline injection	03.07→		0 280 218 190
Phase sensor	03.07→	LAB	0 232 103 050
Knock sensor	03.07→		0 261 231 188
350 Coupé [203]	3,5l	200 kW M 272.960	6 Zyl.
Throttle valve assembly	06.05→		0 280 750 017
Air mass meter, gasoline injection	06.05→		0 280 218 190
Phase sensor	06.05→		0 232 103 050
Speed sensor, ignition/injection	06.05→		0 261 210 170
Knock sensor	06.05→		0 261 231 110
350 4MATIC [203]	3,5l	200 kW M 272.970	6 Zyl.
Throttle valve assembly	07.05-08.07		0 280 750 017
Air mass meter, gasoline injection	07.05-08.07		0 280 218 190
Phase sensor	07.05-08.07		0 232 103 050
Speed sensor, ignition/injection	07.05-08.07		0 261 210 170
Knock sensor	07.05-08.07		0 261 231 110
350 4MATIC [204]	3,5l	200 kW M 272.971	6 Zyl.
Throttle valve assembly	07.07→		0 280 750 017
Air mass meter, gasoline injection	07.07→		0 280 218 190
Phase sensor	07.07→	LAB	0 232 103 050
Knock sensor	07.07→		0 261 231 188

Serie C (T-Modell)

30 AMG CDIT [203]			3,0l 170 kW OM 612.990 5 Zyl.
Air mass meter, diesel			
	01.03-08.04		0 281 002 535
Speed sensor, diesel			
	01.03-08.04		0 261 210 170
High-pressure sensor (CR system)			
Mot.no. →30 287865,→40 176145, →50 846433,→60 001942	01.03-08.04		0 281 002 498
Mot.no. 30 287866→,40 176146→, 50 846434→,60 001943→	01.03-08.04		0 281 002 700
32 AMG KOMPRESSOR T [203]			3,2l 260 kW M 112.961 6 Zyl.
Throttle valve assembly			
	01.01-01.04		0 280 750 017
Phase sensor			
	01.01-01.04		0 232 103 050
Speed sensor, ignition/injection			
	01.01-01.04		0 261 210 170
Knock sensor			
	01.01-01.04		0 261 231 110
Pressure sensor, ESP, (electronic stability program)			
Fg.no. →A 216361/F 161299	01.01-01.04		0 265 005 307
43 AMG T [202]			4,3l 225 kW M 113.944 8 Zyl.
Throttle valve assembly			
	10.97-02.01		0 205 003 048
Air mass meter, gasoline injection			
	10.97-02.01		0 280 217 810
Phase sensor			
	10.97-02.01	NOC	0 232 103 050
Speed sensor, ignition/injection			
	10.97-02.01	FKW	0 261 210 170
Knock sensor			
	10.97-02.01		0 261 231 110
Pedal position sensor, EMS (electronic engine management)			
	10.97-02.01		0 205 001 302





◀ Serie C (T-Modell)

Duo sensor, acceleration and yaw rate, brake system	10.97-02.01		0 265 005 201
Pressure sensor, ESP, (electronic stability program)			
Fg.no. F 984084→	10.97-02.01		0 265 005 307
Wheel speed sensor, front	10.97-02.01	BO,LAB	0 265 006 266
		BO,RAB	0 265 006 264
Wheel speed sensor, rear			
Fg.no. →F894083,Comp. no. Code 808/809, ~~Comp.no. Code 800/807~~	10.97-02.01	LAB	0 265 006 192
		RAB	0 265 006 172
55 AMG T [203]	5,4l	270 kW	M 113.988 8 Zyl.
Throttle valve assembly	02.04-08.07		0 280 750 017
Air mass meter, gasoline injection	02.04-08.07		0 280 217 810
Phase sensor	02.04-08.07		0 232 103 050
Speed sensor, ignition/injection	02.04-08.07		0 261 210 170
Knock sensor	02.04-08.07		0 261 231 110
180 KOMPRESSOR T [203]	1,8l	105 kW	M 271.946 4 Zyl.
Throttle valve assembly	09.02-08.07		0 280 750 076
Phase sensor	09.02-08.07		0 232 103 050
Speed sensor, ignition/injection	09.02-08.07		0 261 210 170
180 KOMPRESSOR T [204]	1,8l	115 kW	M 271.952 4 Zyl.
Throttle valve assembly	09.07→		0 280 750 076
Phase sensor	09.07→		0 232 103 050
Speed sensor, ignition/injection	09.07→		0 261 210 170
180 T [202]	1,8l	90 kW	M 111.920 4 Zyl.
Air mass meter, gasoline injection	05.96-02.01		0 280 217 100
Speed sensor, ignition/injection	05.96-02.01		0 261 210 085
Pressure sensor, ESP, (electronic stability program)			
Fg.no. F 984084→	05.96-02.01		0 265 005 307
Wheel speed sensor, rear			
Fg.no. →F894083,Comp. no. Code 808/809, ~~Comp.no. Code 800/807~~	05.96-02.01	BO,LAB, MET	0 265 006 192
		BO,MET, RAB	0 265 006 172
180 T [202]	1,8l	90 kW	M 111.921 4 Zyl.
Throttle valve assembly			
Mot.no. 060039→,Comp. no. Code 809, ~~Comp.no. Code 808~~	05.96-02.01	AG,OTT	0 280 750 074
Mot.no. 106154→,Comp. no. Code 809, ~~Comp.no. Code 808~~	05.96-02.01	GS,OTT	0 280 750 074
Air mass meter, gasoline injection	05.96-02.01	FGK	0 280 217 114
		KUT	0 280 218 081
Speed sensor, ignition/injection			
Mot.no. →060038	05.96-02.01	AG	0 281 002 123
Mot.no. →106153	05.96-02.01	GS	0 281 002 123
Mot.no. 060039→	05.96-02.01	AG	0 261 210 170
Mot.no. 106154→	05.96-02.01	GS	0 261 210 170
Pressure sensor, ESP, (electronic stability program)			
Fg.no. F 984084→	05.96-02.01		0 265 005 307
Wheel speed sensor, rear			
Fg.no. →F894083,Comp. no. Code 808/809, ~~Comp.no. Code 800/807~~	05.96-02.01	BO,LAB, MET	0 265 006 192
		BO,MET, RAB	0 265 006 172
180 T [202]	2,0l	95 kW	M 111.952 4 Zyl.
Throttle valve assembly	09.00-02.01		0 280 750 074
Speed sensor, ignition/injection	09.00-02.01		0 261 210 170
180 T [203]	2,0l	95 kW	M 111.951 4 Zyl.
Throttle valve assembly	01.01-08.02		0 280 750 067
Speed sensor, ignition/injection	01.01-08.02		0 261 210 170
Pressure sensor, ESP, (electronic stability program)			
Fg.no. →A 216361/F 161299	01.01-08.02		0 265 005 307



200 CDIT [202]	2,2l	75 kW	OM 611.960 4 Zyl.
Air mass meter, diesel			
Mot.no. →30 055905	03.98-02.01		0 280 217 114
Mot.no. 30 055906→	03.98-02.01		0 281 002 384
Pulse generator, diesel	03.98-02.01		0 281 002 123
High-pressure sensor (CR system)	03.98-02.01		0 281 002 498
Pressure sensor, ESP, (electronic stability program)			
Fg.no. F 984084→	03.98-02.01		0 265 005 307
Wheel speed sensor, rear			
Fg.no. →F894083,Comp. no. Code 808/809, ~~Comp.no. Code 800/807~~	03.98-02.01	BO,LAB, MET	0 265 006 192
		BO,MET, RAB	0 265 006 172
200 CDIT [203]	2,2l	75/90 kW	OM 646.962 4 Zyl.
Air mass meter, diesel	03.03-08.07		0 281 002 535
Speed sensor, diesel	03.03-08.07		0 261 210 170
High-pressure sensor (CR system)	03.03-08.07		0 281 002 504
200 CDIT [203]	2,2l	85 kW	OM 611.962 4 Zyl.
Speed sensor, diesel	10.01-02.03		0 261 210 170
High-pressure sensor (CR system)	10.01-02.03		0 281 002 498
Pressure sensor, ESP, (electronic stability program)			
Fg.no. →A 216361/F 161299	10.01-02.03		0 265 005 307
200 CDIT [204]	2,2l	100 kW	OM 646.811 4 Zyl.
Air mass meter, diesel	09.07→		0 281 002 535
Speed sensor, diesel	09.07→		0 261 210 170
200 CGI KOMPRESSOR T [203]	1,8l	125 kW	M 271.942 4 Zyl.
Throttle valve assembly	04.03-08.04		0 280 750 076
Phase sensor	04.03-08.04		0 232 103 050
Speed sensor, ignition/injection	04.03-08.04		0 261 210 170
200 D T [202]	2,0l	65 kW	OM 604.915 4 Zyl.
Speed sensor, diesel	09.96-06.99		0 281 002 123
Wheel speed sensor, rear			
Fg.no. →F873443,Comp. no. Code 808/809, ~~Comp.no. Code 800/807~~	09.96-06.99	BO,LAB, MET	0 265 006 192
		BO,MET, RAB	0 265 006 172
200 KOMPRESSOR T [202]	2,0l	120 kW	M 111.956 4 Zyl.
Throttle valve assembly	04.00-02.01		0 280 750 074
Speed sensor, ignition/injection	04.00-02.01		0 261 210 170
200 KOMPRESSOR T [202]	2,0l	132/141 kW	M 111.944 4 Zyl.
Throttle valve assembly			
Mot.no. 002224→,Comp. no. Code 809, ~~Comp.no. Code 808~~	05.96-03.00	AG	0 280 750 074
Mot.no. 015671→,Comp. no. Code 809, ~~Comp.no. Code 808~~	05.96-03.00	GS	0 280 750 074
Air mass meter, gasoline injection	05.96-03.00	FGK	0 280 217 114
		KUT	0 280 218 081
Speed sensor, ignition/injection			
Mot.no. →060038	05.96-03.00	AG	0 281 002 123
Mot.no. →106153	05.96-03.00	GS	0 281 002 123
Mot.no. 060039→	05.96-03.00	AG	0 261 210 170
Mot.no. 106154→	05.96-03.00	GS	0 261 210 170
Wheel speed sensor, rear			
Fg.no. →F894083,Comp. no. Code 808/809, ~~Comp.no. Code 800/807~~	05.96-03.00	BO,LAB, MET	0 265 006 192
		BO,MET, RAB	0 265 006 172
200 KOMPRESSOR T [203]	1,8l	120 kW	M 271.940 4 Zyl.
Throttle valve assembly	09.02-08.07		0 280 750 076
Phase sensor	09.02-08.07		0 232 103 050
Speed sensor, ignition/injection	09.02-08.07		0 261 210 170



M



Product			
200 KOMPRESSOR T [203] 2,0l 120 kW M 111.955 4 Zyl.			
Throttle valve assembly	01.01-08.02		0 280 750 074
Speed sensor, ignition/injection	01.01-08.02		0 261 210 170
Pressure sensor, ESP, (electronic stability program)			
Fg.no. →A 216361/F 161299	01.01-08.02		0 265 005 307
200 KOMPRESSOR T [204] 1,8l 135 kW M 271.950 4 Zyl.			
Throttle valve assembly	09.07→		0 280 750 076
Phase sensor	09.07→		0 232 103 050
Speed sensor, ignition/injection	09.07→		0 261 210 170
200 T [202] 2,0l 100 kW M 111.941 4 Zyl.			
Air mass meter, gasoline injection	05.96-02.01		0 280 217 100
Speed sensor, ignition/injection	05.96-02.01		0 261 210 085
Pressure sensor, ESP, (electronic stability program)			
Fg.no. F 984084→	05.96-02.01		0 265 005 307
Wheel speed sensor, rear			
Fg.no. →F894083, Comp. no. Code 808/809, Comp.no. Code 800/807	05.96-02.01	BO, LAB, MET	0 265 006 192
		BO, MET, RAB	0 265 006 172
200 T [202] 2,0l 100 kW M 111.945 4 Zyl.			
Throttle valve assembly			
Mot.no. 060039→, Comp. no. Code 809, Comp.no. Code 808	05.96-02.01	AG, OTT	0 280 750 074
Mot.no. 106154→, Comp. no. Code 809, Comp.no. Code 808	05.96-02.01	GS, OTT	0 280 750 074
Air mass meter, gasoline injection	05.96-02.01	FGK	0 280 217 114
		KUT	0 280 218 081
Speed sensor, ignition/injection			
Mot.no. →026604	05.96-02.01	GS	0 281 002 123
Mot.no. →056855	05.96-02.01	AG	0 281 002 123
Mot.no. 026605→	05.96-02.01	GS	0 261 210 170
Mot.no. 056856→	05.96-02.01	AG	0 261 210 170
Wheel speed sensor, rear			
Fg.no. →F894083, Comp. no. Code 808/809, Comp.no. Code 800/807	05.96-02.01	BO, LAB, MET	0 265 006 192
		BO, MET, RAB	0 265 006 172
220 CDIT [202] 2,2l 92 kW OM 611.960 4 Zyl.			
Air mass meter, diesel			
Mot.no. →30 055905	12.97-02.01		0 280 217 114
Mot.no. 30 055906→	12.97-02.01		0 281 002 384
Pulse generator, diesel	12.97-02.01		0 281 002 123
High-pressure sensor (CR system)	12.97-02.01		0 281 002 498
Pressure sensor, ESP, (electronic stability program)			
Fg.no. F 984084→	12.97-02.01		0 265 005 307
Wheel speed sensor, rear			
Fg.no. →F894083, Comp. no. Code 808/809, Comp.no. Code 800/807	12.97-02.01	BO, LAB, MET	0 265 006 192
		BO, MET, RAB	0 265 006 172
220 CDIT [203] 2,2l 105 kW OM 611.962 4 Zyl.			
Speed sensor, diesel	01.01-02.03		0 261 210 170
High-pressure sensor (CR system)	01.01-02.03		0 281 002 498
Pressure sensor, ESP, (electronic stability program)			
Fg.no. →A 216361/F 161299	01.01-02.03		0 265 005 307
220 CDIT [203] 2,2l 110 kW OM 646.963 4 Zyl.			
Air mass meter, diesel	03.03-08.07		0 281 002 535
Speed sensor, diesel	03.03-08.07		0 261 210 170
High-pressure sensor (CR system)	03.03-08.07		0 281 002 504
220 CDIT [204] 2,2l 125 kW OM 646.811 4 Zyl.			
Air mass meter, diesel	09.07→		0 281 002 535
Speed sensor, diesel	09.07→		0 261 210 170



220 DT [202] 2,2l 55-70 kW OM 604.910 4 Zyl.			
Speed sensor, diesel			
Mot.no. →018030	05.96-06.99	AG	0 281 002 100
Mot.no. →086383	05.96-06.99	GS	0 281 002 100
Mot.no. 018031→	05.96-06.99	AG	0 281 002 123
Mot.no. 086384→	05.96-06.99	GS	0 281 002 123
Pedal position sensor, diesel	05.96-09.96		0 205 001 029
Wheel speed sensor, rear			
Fg.no. →F873443, Comp. no. Code 808/809, Comp.no. Code 800/807	05.96-06.99	BO, LAB, MET	0 265 006 192
		BO, MET, RAB	0 265 006 172
230 KOMPRESSOR T [202] 2,3l 142 kW M 111.975 4 Zyl.			
Throttle valve assembly			
Mot.no. 000268→015300, Comp. no. Code 807/808, Comp.no. Code 809	06.97-02.01	AG	0 205 003 044
Mot.no. 005591→012652, Comp. no. Code 807/808, Comp.no. Code 809	06.97-02.01	GS	0 205 003 044
Mot.no. 012653→, Comp. no. Code 809, Comp.no. Code 808	06.97-02.01	GS	0 280 750 074
Mot.no. 015301→, Comp. no. Code 809, Comp.no. Code 808	06.97-02.01	AG	0 280 750 074
Air mass meter, gasoline injection	06.97-02.01	FGK	0 280 217 114
		KUT	0 280 218 081
Speed sensor, ignition/injection			
Mot.no. →012652	06.97-02.01	GS	0 281 002 123
Mot.no. →015300	06.97-02.01	AG	0 281 002 123
Mot.no. 012653→	06.97-02.01	GS	0 261 210 170
Mot.no. 015301→	06.97-02.01	AG	0 261 210 170
Pressure sensor, ESP, (electronic stability program)			
Fg.no. F 984084→	06.97-02.01		0 265 005 307
Wheel speed sensor, rear			
Fg.no. →F894083, Comp. no. Code 808/809, Comp.no. Code 800/807	06.97-02.01	BO, LAB, BO, RAB	0 265 006 192
			0 265 006 172
230 KOMPRESSOR T [203] 1,8l 141 kW M 271.948 4 Zyl.			
Throttle valve assembly	02.04-05.05		0 280 750 076
Phase sensor	02.04-05.05		0 232 103 050
Speed sensor, ignition/injection	02.04-05.05		0 261 210 170
230 T [202] 2,3l 110 kW M 111.974 4 Zyl.			
Air mass meter, gasoline injection	05.96-05.97	FGK	0 280 217 114
		KUT	0 280 218 081
Speed sensor, ignition/injection	05.96-05.97		0 281 002 123
Wheel speed sensor, rear			
Fg.no. →F873443, Comp. no. Code 808/809, Comp.no. Code 800/807	05.96-05.97	BO, LAB, MET	0 265 006 192
		BO, MET, RAB	0 265 006 172
230 T [203] 2,5l 150 kW M 272.920 6 Zyl.			
Throttle valve assembly	06.05-08.07		0 280 750 017
Air mass meter, gasoline injection	06.05-08.07		0 280 218 190
Phase sensor	06.05-08.07		0 232 103 050
Speed sensor, ignition/injection	06.05-08.07		0 261 210 170
Knock sensor	06.05-08.07		0 261 231 188
230 T [204] 2,5l 150 kW M 272.921 6 Zyl.			
Throttle valve assembly	09.07→		0 280 750 017
Air mass meter, gasoline injection	09.07→		0 280 218 190
Phase sensor	09.07→	LAB	0 232 103 050
Knock sensor	09.07→		0 261 231 188
240 T [202] 2,4l 125 kW M 112.910 6 Zyl.			
Throttle valve assembly	06.97-02.01		0 205 003 046
Air mass meter, gasoline injection	06.97-02.01		0 280 217 515
Phase sensor	06.97-02.01		0 232 103 050



Product				
◀ Serie C (T-Modell)				
Speed sensor, ignition/injection				
Mot.no. →370998	06.97-02.01			0 261 210 141
Mot.no. 370999→	06.97-02.01			0 261 210 170
Knock sensor	06.97-02.01			0 261 231 110
Duo sensor, acceleration and yaw rate, brake system	06.97-02.01			0 265 005 201
Pressure sensor, ESP, (electronic stability program)				
Fg.no. F 984084→	06.97-02.01			0 265 005 307
Wheel speed sensor, front	06.97-02.01	BO,LAB		0 265 006 266
		BO,RAB		0 265 006 264
Wheel speed sensor, rear				
Fg.no. →F894083,Comp. no. Code 808/809, Comp.no. Code 800/807	06.97-02.01	BO,LAB		0 265 006 192
		BO,RAB		0 265 006 172
240 T [202]	2,6 l	125 kW	M 112.915	6 Zyl.
Throttle valve assembly	08.00-02.01			0 280 750 019
Phase sensor	08.00-02.01	NOC		0 232 103 050
Speed sensor, ignition/injection	08.00-02.01			0 261 210 170
Knock sensor	08.00-02.01			0 261 231 110
Wheel speed sensor, front	08.00-02.01	BO,LAB		0 265 006 266
		BO,RAB		0 265 006 264
240 T [203]	2,6 l	125 kW	M 112.912	6 Zyl.
Throttle valve assembly	01.01-05.05			0 280 750 019
Air mass meter, gasoline injection	01.01-05.05			0 280 217 515
Phase sensor	01.01-05.05			0 232 103 050
Speed sensor, ignition/injection	01.01-05.05			0 261 210 170
Knock sensor	01.01-05.05			0 261 231 110
Pressure sensor, ESP, (electronic stability program)				
Fg.no. →A 216361/F 161299	01.01-05.05			0 265 005 307
240 4MATIC T [203]	2,6 l	125 kW	M 112.916	6 Zyl.
Throttle valve assembly	09.02-06.05			0 280 750 019
Air mass meter, gasoline injection	09.02-06.05			0 280 217 515
Phase sensor	09.02-06.05			0 232 103 050
Speed sensor, ignition/injection	09.02-06.05			0 261 210 170
Knock sensor	09.02-06.05			0 261 231 110
250 D Turbo T [202]	2,5 l	110 kW	OM 605.960	5 Zyl.
Air mass meter, diesel	05.96-02.01			0 280 217 114
Pulse generator, diesel				
Mot.no. →007447,Comp.no. Code 807	05.96-02.01	AG		0 281 002 100
Mot.no. →014999,Comp.no. Code 807	05.96-02.01	GS		0 281 002 100
Mot.no. 007448→,Comp. no. Code 807	05.96-02.01	AG		0 281 002 123
Mot.no. 015000→,Comp. no. Code 807	05.96-02.01	GS		0 281 002 123
Pedal position sensor, diesel	05.96-02.01			0 205 001 029
Pressure sensor, ESP, (electronic stability program)				
Fg.no. F 984084→	05.96-02.01			0 265 005 307
Wheel speed sensor, rear				
Fg.no. →F894083,Comp. no. Code 808/809, Comp.no. Code 800/807	05.96-02.01	BO,LAB, MET		0 265 006 192
		BO,MET, RAB		0 265 006 172
270 CDI T [203]	2,7 l	125 kW	OM 612.962	5 Zyl.
Speed sensor, diesel	01.01-08.04			0 261 210 170
High-pressure sensor (CR system)	01.01-08.04			0 281 002 498
Pressure sensor, ESP, (electronic stability program)				
Fg.no. →A 216361/F 161299	01.01-08.04			0 265 005 307
280 T [202]	2,8 l	145 kW	M 112.920	6 Zyl.
Throttle valve assembly				
Comp. no. Code 800	06.97-02.01			0 205 003 046
Comp. no. Code 801	06.97-02.01			0 280 750 019
Air mass meter, gasoline injection	06.97-02.01			0 280 217 515
Phase sensor	06.97-02.01			0 232 103 050
Speed sensor, ignition/injection				
Mot.no. →370998	06.97-02.01			0 261 210 141
Mot.no. 370999→	06.97-02.01			0 261 210 170

Product				
Knock sensor	06.97-02.01			0 261 231 110
Pedal position sensor, EMS (electronic engine management)	06.97-02.01			0 205 001 302
Duo sensor, acceleration and yaw rate, brake system	06.97-02.01			0 265 005 201
Pressure sensor, ESP, (electronic stability program)				
Fg.no. F 984084→	06.97-02.01			0 265 005 307
Wheel speed sensor, front	06.97-02.01	BO,LAB		0 265 006 266
		BO,RAB		0 265 006 264
Wheel speed sensor, rear				
Fg.no. →F894083,Comp. no. Code 808/809, Comp.no. Code 800/807	06.97-02.01	LAB		0 265 006 192
		RAB		0 265 006 172
280 T [203]	3,0 l	170 kW	M 272.940	6 Zyl.
Throttle valve assembly	06.05-08.07			0 280 750 017
Air mass meter, gasoline injection	06.05-08.07			0 280 218 190
Phase sensor	06.05-08.07			0 232 103 050
Speed sensor, ignition/injection	06.05-08.07			0 261 210 170
Knock sensor	06.05-08.07			0 261 231 188
280 T [204]	3,0 l	170 kW	M 272.947	6 Zyl.
Throttle valve assembly	09.07→			0 280 750 017
Air mass meter, gasoline injection	09.07→			0 280 218 190
Phase sensor	09.07→	LAB		0 232 103 050
Knock sensor	09.07→			0 261 231 188
280 4MATIC T [203]	3,0 l	170 kW	M 272.941	6 Zyl.
Throttle valve assembly	07.05-08.07			0 280 750 017
Air mass meter, gasoline injection	07.05-08.07			0 280 218 190
Phase sensor	07.05-08.07			0 232 103 050
Speed sensor, ignition/injection	07.05-08.07			0 261 210 170
Knock sensor	07.05-08.07			0 261 231 188
320 CDI T [203]	3,0 l	165 kW	OM 642.910	6 Zyl.
Speed sensor, diesel	09.04-08.07			0 261 210 170
320 T [203]	3,2 l	160 kW	M 112.946	6 Zyl.
Throttle valve assembly	01.01-05.05			0 280 750 019
Air mass meter, gasoline injection	01.01-05.05			0 280 217 515
Phase sensor	01.01-05.05			0 232 103 050
Speed sensor, ignition/injection	01.01-05.05			0 261 210 170
Knock sensor	01.01-05.05			0 261 231 110
320 4MATIC T [203]	3,2 l	160 kW	M 112.953	6 Zyl.
Throttle valve assembly	09.02-06.05			0 280 750 019
Air mass meter, gasoline injection	09.02-06.05			0 280 217 515
Phase sensor	09.02-06.05			0 232 103 050
Speed sensor, ignition/injection	09.02-06.05			0 261 210 170
Knock sensor	09.02-06.05			0 261 231 110
350 T [203]	3,5 l	200 kW	M 272.960	6 Zyl.
Throttle valve assembly	06.05-08.07			0 280 750 017
Air mass meter, gasoline injection	06.05-08.07			0 280 218 190
Phase sensor	06.05-08.07			0 232 103 050
Speed sensor, ignition/injection	06.05-08.07			0 261 210 170
Knock sensor	06.05-08.07			0 261 231 110
350 T [204]	3,5 l	200 kW	M 272.961	6 Zyl.
Throttle valve assembly	09.07→			0 280 750 017
Air mass meter, gasoline injection	09.07→			0 280 218 190
Phase sensor	09.07→	LAB		0 232 103 050
Knock sensor	09.07→			0 261 231 188
350 4MATIC T [203]	3,5 l	200 kW	M 272.970	6 Zyl.
Throttle valve assembly	07.05-08.07			0 280 750 017
Air mass meter, gasoline injection	07.05-08.07			0 280 218 190
Phase sensor	07.05-08.07			0 232 103 050
Speed sensor, ignition/injection	07.05-08.07			0 261 210 170
Knock sensor	07.05-08.07			0 261 231 110

Product



Serie CL

55 AMG Coupé [215]			5,4l 265 kW M 113.986 8 Zyl.
Throttle valve assembly	09.99-08.00		0 205 003 048
	09.00-08.02		0 280 750 017
Air mass meter, gasoline injection	09.99-08.02		0 280 217 810
Phase sensor	09.99-08.02		0 232 103 050
Speed sensor, ignition/injection	09.99-08.02		0 261 210 170
Knock sensor	09.99-08.02		0 261 231 110
Duo sensor, acceleration and yaw rate, brake system	09.99-08.02		0 265 005 258
Pressure sensor, ESP, (electronic stability program)	09.99-08.02		0 265 005 303
Wheel speed sensor, front	09.99-08.02		0 265 007 002
Wheel speed sensor, rear	09.99-08.02	LAB	0 265 007 008
		RAB	0 265 007 006
55 AMG KOMPRESSOR Coupé [215]			5,4l 368 kW M 113.991 8 Zyl.
Throttle valve assembly	09.02-08.06		0 280 750 045
Phase sensor	09.02-08.06		0 232 103 050
Speed sensor, ignition/injection	09.02-08.06		0 261 210 170
Knock sensor	09.02-08.06		0 261 231 110
Duo sensor, acceleration and yaw rate, brake system	09.02-08.06		0 265 005 258
Pressure sensor, ESP, (electronic stability program)	09.02-08.06		0 265 005 303
Wheel speed sensor, front	09.02-08.06		0 265 007 002
Wheel speed sensor, rear	09.02-08.06	LAB	0 265 007 121
		RAB	0 265 007 123
63 AMG Coupé [216]			6,2l 386 kW M 156.984 8 Zyl.
Knock sensor	01.07→		0 261 231 188
65 AMG Coupé [215]			6,0l 450 kW M 275.980 12 Zyl.
Speed sensor, ignition/injection	09.03-08.06		0 261 210 170
Knock sensor	09.03-08.06		0 261 231 110
Duo sensor, acceleration and yaw rate, brake system	09.03-08.06		0 265 005 258
Pressure sensor, ESP, (electronic stability program)	09.03-08.06		0 265 005 303
Wheel speed sensor, front	09.03-08.06		0 265 007 128
Wheel speed sensor, rear	09.03-08.06	LAB	0 265 007 121
		RAB	0 265 007 123
65 AMG Coupé [216]			6,0l 450 kW M 275.982 12 Zyl.
Speed sensor, ignition/injection	07.07→		0 261 210 170
Knock sensor	07.07→		0 261 231 110
500 Coupé [215]			5,0l 225 kW M 113.960 8 Zyl.
Throttle valve assembly	09.99-08.00		0 205 003 048
	09.00-05.06		0 280 750 017
Air mass meter, gasoline injection	09.99-05.06		0 280 217 810
Phase sensor	09.99-05.06		0 232 103 050
Speed sensor, ignition/injection	09.99-05.06		0 261 210 170
Knock sensor	09.99-05.06		0 261 231 110
Duo sensor, acceleration and yaw rate, brake system	09.99-05.06		0 265 005 258
Pressure sensor, ESP, (electronic stability program)	09.99-05.06		0 265 005 303
Wheel speed sensor, front	09.99-05.06		0 265 007 002
Wheel speed sensor, rear	09.99-05.06	LAB	0 265 007 008
		RAB	0 265 007 006
500 Coupé [216]			5,5l 285 kW M 273.961 8 Zyl.
Throttle valve assembly	06.06→		0 280 750 184
Air mass meter, gasoline injection	06.06→		0 280 218 190
Phase sensor	06.06→	LAB	0 232 103 050
Knock sensor	06.06→		0 261 231 188
600 Coupé [215]			5,5l 368 kW M 275.950 12 Zyl.
Throttle valve assembly	09.02-08.06		0 280 750 125
Speed sensor, ignition/injection	09.02-08.06		0 261 210 170
Knock sensor	09.02-08.06		0 261 231 110

Product



Duo sensor, acceleration and yaw rate, brake system	09.02-08.06		0 265 005 258
Pressure sensor, ESP, (electronic stability program)	09.02-08.06		0 265 005 303
Wheel speed sensor, front	09.02-08.06		0 265 007 128
Wheel speed sensor, rear	09.02-08.06	LAB	0 265 007 121
		RAB	0 265 007 123
600 Coupé [215]			5,8l 270 kW M 137.970 12 Zyl.
Throttle valve assembly	09.99-08.02		0 280 750 015
Air mass meter, gasoline injection	09.99-08.02		0 280 217 810
Speed sensor, ignition/injection	09.99-08.02		0 261 210 170
Knock sensor	09.99-08.02		0 261 231 110
Duo sensor, acceleration and yaw rate, brake system	09.99-08.02		0 265 005 258
Pressure sensor, ESP, (electronic stability program)	09.99-08.02		0 265 005 303
Wheel speed sensor, front	09.99-08.02		0 265 007 002
Wheel speed sensor, rear	09.99-08.02	LAB	0 265 007 008
		RAB	0 265 007 006
600 Coupé [216]			5,5l 380 kW M 275.953 12 Zyl.
Throttle valve assembly	09.06→		0 280 750 125
Speed sensor, ignition/injection	09.06→		0 261 210 170
Knock sensor	09.06→		0 261 231 110

Serie CLK

55 AMG Cabrio [208]			5,4l 255 kW M 113.984 8 Zyl.
Throttle valve assembly	09.00-04.02		0 280 750 019
Phase sensor	09.00-04.02	NOC	0 232 103 050
Speed sensor, ignition/injection	09.00-04.02	FKW	0 261 210 170
Knock sensor	09.00-04.02		0 261 231 110
Lateral acceleration sensor, brake system	09.00-04.02		0 265 005 231
Duo sensor, acceleration and yaw rate, brake system	09.00-04.02		0 265 005 201
Wheel speed sensor, front	09.00-04.02	LAB	0 265 006 266
Fg.no. 202...A/B/C/D/E	09.00-04.02	BO,RAB	0 265 006 264
Wheel speed sensor, rear	09.00-04.02	LAB	0 265 006 192
		RAB	0 265 006 172
55 AMG Cabrio [209]			5,4l 270 kW M 113.987 8 Zyl.
Throttle valve assembly	02.03→		0 280 750 017
Air mass meter, gasoline injection	02.03→		0 280 217 810
Phase sensor	02.03→		0 232 103 050
Speed sensor, ignition/injection	02.03→		0 261 210 170
Knock sensor	02.03→		0 261 231 110
55 AMG Coupé [208]			5,4l 255 kW M 113.984 8 Zyl.
Throttle valve assembly	05.99-08.00		0 205 003 046
	09.00-04.02		0 280 750 019
Phase sensor	05.99-04.02	NOC	0 232 103 050
Speed sensor, ignition/injection	05.99-04.02	FKW	0 261 210 170
Knock sensor	05.99-04.02		0 261 231 110
Duo sensor, acceleration and yaw rate, brake system	05.99-04.02		0 265 005 201
Wheel speed sensor, front	05.99-04.02	LAB	0 265 006 266
Fg.no. 202...A/B/C/D/E	05.99-04.02	BO,RAB	0 265 006 264
Wheel speed sensor, rear	05.99-04.02	LAB	0 265 006 192
		RAB	0 265 006 172
55 AMG Coupé [209]			5,4l 270 kW M 113.987 8 Zyl.
Throttle valve assembly	09.02→		0 280 750 017
Air mass meter, gasoline injection	09.02→		0 280 217 810
Phase sensor	09.02→		0 232 103 050
Speed sensor, ignition/injection	09.02→		0 261 210 170
Knock sensor	09.02→		0 261 231 110
63 AMG Cabrio, Coupé [209]			6,2l 354 kW M 156.982 8 Zyl.
Knock sensor	09.06→		0 261 231 188



M



◀ Serie CLK

200 Cabrio [208]		2,0l	100 kW	M 111.945	4 Zyl.
Air mass meter, gasoline injection	06.98-06.00	FGK	0 280 217 114		
		KUT	0 280 218 081		
Speed sensor, ignition/injection					
Mot.no. →026604	06.98-06.00	GS	0 281 002 123		
Mot.no. →056855	06.98-06.00	AG	0 281 002 123		
Mot.no. 026605→	06.98-06.00	GS	0 261 210 170		
Mot.no. 056856→	06.98-06.00	AG	0 261 210 170		
Pressure sensor, ESP, (electronic stability program)		06.98-06.00	0 265 005 307		
200 CGI KOMPRESSOR Cabrio [209]		1,8l	125 kW	M 271.942	4 Zyl.
Throttle valve assembly	06.03-08.04		0 280 750 076		
Phase sensor	06.03-08.04		0 232 103 050		
Speed sensor, ignition/injection	06.03-08.04		0 261 210 170		
200 CGI KOMPRESSOR Coupé [209]		1,8l	125 kW	M 271.942	4 Zyl.
Throttle valve assembly	05.02-08.04		0 280 750 076		
Phase sensor	05.02-08.04		0 232 103 050		
Speed sensor, ignition/injection	05.02-08.04		0 261 210 170		
200 Coupé [208]		2,0l	100 kW	M 111.945	4 Zyl.
Air mass meter, gasoline injection	06.97-06.00	FGK	0 280 217 114		
		KUT	0 280 218 081		
Speed sensor, ignition/injection					
Mot.no. →026604	06.97-06.00	GS	0 281 002 123		
Mot.no. →056855	06.97-06.00	AG	0 281 002 123		
Mot.no. 026605→	06.97-06.00	GS	0 261 210 170		
Mot.no. 056856→	06.97-06.00	AG	0 261 210 170		
Pressure sensor, ESP, (electronic stability program)		06.97-06.00	0 265 005 307		
200 KOMPRESSOR Cabrio [208]		2,0l	120 kW	M 111.956	4 Zyl.
Throttle valve assembly	06.00-01.03		0 280 750 045		
Air mass meter, gasoline injection	06.00-01.03		0 280 217 114		
Speed sensor, ignition/injection	06.00-01.03		0 261 210 170		
Pressure sensor, ESP, (electronic stability program)		06.00-01.03	0 265 005 307		
200 KOMPRESSOR Cabrio [208]		2,0l	142 kW	M 111.944	4 Zyl.
Air mass meter, gasoline injection	09.96-05.00	FGK	0 280 217 114		
		KUT	0 280 218 081		
Speed sensor, ignition/injection					
Mot.no. →002223	09.96-05.00	AG	0 281 002 123		
Mot.no. →015670	09.96-05.00	GS	0 281 002 123		
Mot.no. 002224→	09.96-05.00	AG	0 261 210 170		
Mot.no. 015671→	09.96-05.00	GS	0 261 210 170		
Pressure sensor, ESP, (electronic stability program)		09.96-05.00	0 265 005 307		
200 KOMPRESSOR Cabrio [209]		1,8l	120/135 kW	M 271.940; M 271.955	4 Zyl.
Throttle valve assembly	02.03→		0 280 750 076		
Phase sensor	02.03→		0 232 103 050		
Speed sensor, ignition/injection	02.03→		0 261 210 170		
200 KOMPRESSOR Coupé [208]		2,0l	120 kW	M 111.956	4 Zyl.
Throttle valve assembly	06.00-04.02		0 280 750 045		
Speed sensor, ignition/injection	06.00-04.02		0 261 210 170		
Pressure sensor, ESP, (electronic stability program)		06.00-04.02	0 265 005 307		
200 KOMPRESSOR Coupé [208]		2,0l	142 kW	M 111.944	4 Zyl.
Throttle valve assembly	06.97-06.00		0 205 003 044		
Air mass meter, gasoline injection	06.97-06.00	FGK	0 280 217 114		
		KUT	0 280 218 081		
Speed sensor, ignition/injection					
Mot.no. →002223	06.97-06.00	AG	0 281 002 123		
Mot.no. →015670	06.97-06.00	GS	0 281 002 123		
Mot.no. 002224→	06.97-06.00	AG	0 261 210 170		
Mot.no. 015671→	06.97-06.00	GS	0 261 210 170		
Pressure sensor, ESP, (electronic stability program)		06.97-06.00	0 265 005 307		
200 KOMPRESSOR Coupé [209]		1,8l	120/135 kW	M 271.940; M 271.955	4 Zyl.
Throttle valve assembly	09.02→		0 280 750 076		
Phase sensor	09.02→		0 232 103 050		
Speed sensor, ignition/injection	09.02→		0 261 210 170		



220 CDI Coupé [209]		2,1l	110 kW	OM 646.966	4 Zyl.
Air mass meter, diesel		04.05→	0 281 002 535		
Speed sensor, diesel		04.05→	0 261 210 170		
High-pressure sensor (CR system)		04.05→	0 281 002 504		
230 KOMPRESSOR Cabrio [208]		2,3l	142 kW	M 111.975	4 Zyl.
Throttle valve assembly		06.98-05.00	0 205 003 044		
Air mass meter, gasoline injection		06.98-05.00	FGK	0 280 217 114	
			KUT	0 280 218 081	
Speed sensor, ignition/injection					
Mot.no. →012652		06.98-05.00	GS	0 281 002 123	
Mot.no. →015300		06.98-05.00	AG	0 281 002 123	
Mot.no. 012653→		06.98-05.00	GS	0 261 210 170	
Mot.no. 015301→		06.98-05.00	AG	0 261 210 170	
Pressure sensor, ESP, (electronic stability program)		06.98-05.00	0 265 005 307		
230 KOMPRESSOR Cabrio [208]		2,3l	145 kW	M 111.982	4 Zyl.
Throttle valve assembly		06.00-01.03	0 280 750 045		
Speed sensor, ignition/injection		06.00-01.03	0 261 210 170		
Pressure sensor, ESP, (electronic stability program)		06.00-01.03	0 265 005 307		
230 KOMPRESSOR Coupé [208]		2,3l	142 kW	M 111.975	4 Zyl.
Throttle valve assembly		06.97-06.00	0 205 003 044		
Air mass meter, gasoline injection		06.97-06.00	FGK	0 280 217 114	
			KUT	0 280 218 081	
Speed sensor, ignition/injection					
Mot.no. →012652		06.97-06.00	GS	0 281 002 123	
Mot.no. →015300		06.97-06.00	AG	0 281 002 123	
Mot.no. 012653→		06.97-06.00	GS	0 261 210 170	
Mot.no. 015301→		06.97-06.00	AG	0 261 210 170	
Pressure sensor, ESP, (electronic stability program)		06.97-06.00	0 265 005 307		
230 KOMPRESSOR Coupé [208]		2,3l	145 kW	M 111.982	4 Zyl.
Throttle valve assembly		06.00-04.02	0 280 750 045		
Speed sensor, ignition/injection		06.00-04.02	0 261 210 170		
Pressure sensor, ESP, (electronic stability program)		06.00-04.02	0 265 005 307		
240 Cabrio [209]		2,6l	125 kW	M 112.912	6 Zyl.
Throttle valve assembly		02.03→	0 280 750 019		
Air mass meter, gasoline injection		02.03→	0 280 217 515		
Phase sensor		02.03→	0 232 103 050		
Speed sensor, ignition/injection		02.03→	0 261 210 170		
Knock sensor		02.03→	0 261 231 110		
240 Coupé [209]		2,6l	125 kW	M 112.912	6 Zyl.
Throttle valve assembly		05.02→	0 280 750 019		
Air mass meter, gasoline injection		05.02→	0 280 217 515		
Phase sensor		05.02→	0 232 103 050		
Speed sensor, ignition/injection		05.02→	0 261 210 170		
Knock sensor		05.02→	0 261 231 110		
270 CDI Coupé [209]		2,7l	125 kW	OM 612.962; 967	5 Zyl.
Speed sensor, diesel		09.02→	0 261 210 170		
High-pressure sensor (CR system)		09.02→	0 281 002 498		
280 Cabrio, Coupé [209]		3,0l	170 kW	M 272.940	6 Zyl.
Throttle valve assembly		04.05→	0 280 750 017		
Air mass meter, gasoline injection		04.05→	0 280 218 190		
Phase sensor		04.05→	LAB	0 232 103 050	
Knock sensor		04.05→	0 261 231 188		
320 Cabrio [208]		3,2l	160 kW	M 112.940	6 Zyl.
Throttle valve assembly		06.98-08.00	0 205 003 046		
		09.00-01.03	0 280 750 019		
Air mass meter, gasoline injection		06.98-01.03	0 280 217 515		
Phase sensor		06.98-01.03	0 232 103 037		
Speed sensor, ignition/injection					
Mot.no. →370998		06.98-01.03	0 261 210 141		
Mot.no. 370999→		06.98-01.03	FKW	0 261 210 170	
Knock sensor		06.98-01.03	0 261 231 110		
Duo sensor, acceleration and yaw rate, brake system		06.98-01.03	0 265 005 201		



Wheel speed sensor, front	06.98-01.03	LAB,MFD	0 265 006 266
		MFD,RAB	0 265 006 264
Wheel speed sensor, rear	06.98-01.03	LAB,MFD	0 265 006 192
		MFD,RAB	0 265 006 172
320 Cabrio [209]	3,2l	160 kW	M 112.955 6 Zyl.
Throttle valve assembly	02.03→		0 280 750 019
Air mass meter, gasoline injection	02.03→		0 280 217 515
Phase sensor	02.03→		0 232 103 050
Speed sensor, ignition/injection	02.03→		0 261 210 170
Knock sensor	02.03→		0 261 231 110
320 CDI Cabrio, Coupé [209]	3,0l	165 kW	OM 642.910 6 Zyl.
Speed sensor, diesel	04.05→		0 261 210 170
High-pressure sensor (CR system)	04.05→		0 281 002 504
320 Coupé [208]	3,2l	160 kW	M 112.940 6 Zyl.
Throttle valve assembly	01.97-08.00		0 205 003 046
	09.00-06.02		0 280 750 019
Air mass meter, gasoline injection	01.97-06.02		0 280 217 515
Phase sensor	01.97-06.02		0 232 103 037
Speed sensor, ignition/injection			
Mot.no. →370998	01.97-06.02		0 261 210 141
Mot.no. 370999→	01.97-06.02	FKW	0 261 210 170
Knock sensor	01.97-06.02		0 261 231 110
Duo sensor, acceleration and yaw rate, brake system	01.97-06.02		0 265 005 201
Wheel speed sensor, front	01.97-06.02	LAB,MFD	0 265 006 266
		MFD,RAB	0 265 006 264
Wheel speed sensor, rear	01.97-06.02	LAB,MFD	0 265 006 192
		MFD,RAB	0 265 006 172
320 Coupé [209]	3,2l	160 kW	M 112.955 6 Zyl.
Throttle valve assembly	05.02→		0 280 750 019
Air mass meter, gasoline injection	05.02→		0 280 217 515
Phase sensor	05.02→		0 232 103 050
Speed sensor, ignition/injection	05.02→		0 261 210 170
Knock sensor	05.02→		0 261 231 110
350 Cabrio, Coupé [209]	3,5l	200 kW	M 272.960 6 Zyl.
Throttle valve assembly	04.05→		0 280 750 017
Air mass meter, gasoline injection	04.05→		0 280 218 190
Phase sensor	04.05→	LAB	0 232 103 050
Knock sensor	04.05→		0 261 231 188
430 Cabrio [208]	4,3l	205 kW	M 113.943 8 Zyl.
Phase sensor	09.98-01.03	NOC	0 232 103 050
Speed sensor, ignition/injection	09.98-01.03	FKW	0 261 210 170
Knock sensor	09.98-01.03		0 261 231 110
Duo sensor, acceleration and yaw rate, brake system	09.98-01.03		0 265 005 201
Wheel speed sensor, front	09.98-01.03	LAB,MFD	0 265 006 266
		MFD,RAB	0 265 006 264
Wheel speed sensor, rear	09.98-01.03	LAB,MFD	0 265 006 192
		MFD,RAB	0 265 006 172
430 Coupé [208]	4,3l	205 kW	M 113.943 8 Zyl.
Throttle valve assembly	08.98-04.02		0 205 003 048
Air mass meter, gasoline injection	08.98-04.02		0 280 217 810
Phase sensor	08.98-04.02	NOC	0 232 103 050
Speed sensor, ignition/injection	08.98-04.02	FKW	0 261 210 170
Knock sensor	08.98-04.02		0 261 231 110
Duo sensor, acceleration and yaw rate, brake system	08.98-04.02		0 265 005 201
Wheel speed sensor, front	08.98-04.02	LAB,MFD	0 265 006 266
		MFD,RAB	0 265 006 264
Wheel speed sensor, rear	08.98-04.02	LAB,MFD	0 265 006 192
		MFD,RAB	0 265 006 172



500 Cabrio [209]	5,0l	225 kW	M 113.968 8 Zyl.
Throttle valve assembly	02.03-07.06		0 280 750 017
Air mass meter, gasoline injection	02.03-07.06		0 280 217 810
Phase sensor	02.03-07.06		0 232 103 050
Speed sensor, ignition/injection	02.03-07.06		0 261 210 170
Knock sensor	02.03-07.06		0 261 231 110
500 Cabrio [209]	5,0l	285 kW	M 273.967 8 Zyl.
Throttle valve assembly	08.06→		0 280 750 184
Air mass meter, gasoline injection	08.06→		0 280 218 190
Phase sensor	08.06→	LAB	0 232 103 050
Knock sensor	08.06→		0 261 231 188
500 Coupé [209]	5,0l	225 kW	M 113.968 8 Zyl.
Throttle valve assembly	05.02-07.06		0 280 750 017
Air mass meter, gasoline injection	05.02-07.06		0 280 217 810
Phase sensor	05.02-07.06		0 232 103 050
Speed sensor, ignition/injection	05.02-07.06		0 261 210 170
Knock sensor	05.02-07.06		0 261 231 110
500 Coupé [209]	5,0l	285 kW	M 273.967 8 Zyl.
Throttle valve assembly	08.06→		0 280 750 184
Air mass meter, gasoline injection	08.06→		0 280 218 190
Phase sensor	08.06→	LAB	0 232 103 050
Knock sensor	08.06→		0 261 231 188

Serie CLS

55 AMG Coupé [219]	5,4l	350 kW	M 113.990 8 Zyl.
Throttle valve assembly	01.05-05.06		0 280 750 045
Air mass meter, gasoline injection	01.05-05.06		0 280 217 810
Phase sensor	01.05-05.06		0 232 103 050
Speed sensor, ignition/injection	01.05-05.06		0 261 210 170
Knock sensor	01.05-05.06		0 261 231 110
Duo sensor, acceleration and yaw rate, brake system	01.05-05.06		0 265 005 298
Wheel speed sensor, front	01.05-05.06		0 265 007 499
Wheel speed sensor, rear	01.05-05.06		0 265 007 500
63 AMG Coupé [219]	6,2l	378 kW	M 156.983 8 Zyl.
Knock sensor	06.06→		0 261 231 188
Duo sensor, acceleration and yaw rate, brake system	06.06→		0 265 005 298
Wheel speed sensor, front	06.06→		0 265 007 499
Wheel speed sensor, rear	06.06→		0 265 007 500
320 CDI Coupé [219]	3,0l	165 kW	OM 642.920 6 Zyl.
High-pressure sensor (CR system)	05.05→		0 281 002 504
Duo sensor, acceleration and yaw rate, brake system	05.05→		0 265 005 298
Wheel speed sensor, front	05.05→		0 265 007 499
Wheel speed sensor, rear	05.05→		0 265 007 500
350 CGI Coupé [219]	3,5l	215 kW	M 272.985 6 Zyl.
Throttle valve assembly	07.06→		0 280 750 017
Air mass meter, gasoline injection	07.06→		0 280 218 190
Phase sensor	07.06→	LAB	0 232 103 050
Knock sensor	07.06→		0 261 231 188
Duo sensor, acceleration and yaw rate, brake system	07.06→		0 265 005 298
Wheel speed sensor, front	07.06→		0 265 007 499
Wheel speed sensor, rear	07.06→		0 265 007 500
350 Coupé [219]	3,5l	200 kW	M 272.964 6 Zyl.
Throttle valve assembly	06.04-06.06		0 280 750 017
Air mass meter, gasoline injection	06.04-06.06		0 280 218 190
Phase sensor	06.04-06.06	LAB	0 232 103 050
Knock sensor	06.04-06.06		0 261 231 188
Duo sensor, acceleration and yaw rate, brake system	06.04-06.06		0 265 005 298



◀ Serie CLS

Wheel speed sensor, front	06.04-06.06		0 265 007 499
Wheel speed sensor, rear	06.04-06.06		0 265 007 500
500 Coupé [219]	5,0l	225 kW M 113.967	8 Zyl.
Throttle valve assembly	06.04-03.06		0 280 750 017
Air mass meter, gasoline injection	06.04-03.06		0 280 217 810
Phase sensor	06.04-03.06		0 232 103 050
Speed sensor, ignition/injection	06.04-03.06		0 261 210 170
Knock sensor	06.04-03.06		0 261 231 110
Duo sensor, acceleration and yaw rate, brake system	06.04-03.06		0 265 005 298
Wheel speed sensor, front	06.04-03.06		0 265 007 499
Wheel speed sensor, rear	06.04-03.06		0 265 007 500
500 Coupé [219]	5,5l	285 kW M 273.960	8 Zyl.
Throttle valve assembly	04.06→		0 280 750 184
Air mass meter, gasoline injection	04.06→		0 280 218 190
Phase sensor	04.06→	LAB	0 232 103 050
Knock sensor	04.06→		0 261 231 188
Duo sensor, acceleration and yaw rate, brake system	04.06→		0 265 005 298
Wheel speed sensor, front	04.06→		0 265 007 499
Wheel speed sensor, rear	04.06→		0 265 007 500



Serie E

36 AMG Cabrio [124]	3,6l	195 kW M 104.992	6 Zyl.
Air mass meter, gasoline injection	03.93-02.94		0 280 217 500
Speed sensor, ignition/injection	03.93-02.94	RLE	0 261 210 066
Mot.no. →004356	03.93-02.94	GS,LLE	0 261 210 055
Mot.no. →072236	03.93-02.94	AG,LLE	0 261 210 055
Mot.no. 004357→	03.93-02.94	GS,LLE	0 261 210 122
Mot.no. 072237→	03.93-02.94	AG,LLE	0 261 210 122
Wheel speed sensor, front	03.93-02.94	LAB	0 265 006 111
		RAB	0 265 006 109
Wheel speed sensor, rear	03.93-02.94	AOS	0 265 002 244
		ASR,LAB	0 265 002 206
		ASR,RAB	0 265 002 204
36 AMG Cabrio [124]	3,6l	200 kW M 104.992	6 Zyl.
Air mass meter, gasoline injection	03.94-06.98		0 280 217 500
Speed sensor, ignition/injection	03.94-06.98	LLE	0 261 210 055
		RLE	0 261 210 066
Wheel speed sensor, front	03.94-06.98	LAB	0 265 006 111
		RAB	0 265 006 109
Wheel speed sensor, rear	03.94-06.98	AOS	0 265 002 244
		ASR,LAB	0 265 002 206
		ASR,RAB	0 265 002 204
36 AMG Coupé [124]	3,6l	195/200 kW M 104.992	6 Zyl.
Air mass meter, gasoline injection	03.93-06.96		0 280 217 500
Speed sensor, ignition/injection	03.93-06.96	RLE	0 261 210 066
Mot.no. →004356	03.93-06.96	GS,LLE	0 261 210 055
Mot.no. →072236	03.93-06.96	AG,LLE	0 261 210 055
Mot.no. 004357→	03.93-06.96	GS,LLE	0 261 210 122
Mot.no. 072237→	03.93-06.96	AG,LLE	0 261 210 122
Wheel speed sensor, front	03.93-06.96	LAB	0 265 001 284
		RAB	0 265 001 282
Wheel speed sensor, rear	03.93-06.96	AOS	0 265 002 210
		ASR,LAB	0 265 002 206
		ASR,RAB	0 265 002 204
50 AMG [210]	5,0l	205-235 kW M 119.980,985	8 Zyl.
Throttle valve assembly	01.96-08.97		0 205 003 037
Air mass meter, gasoline injection	01.96-08.97		0 280 217 807
Phase sensor	01.96-08.97		0 232 103 037
Speed sensor, ignition/injection	01.96-08.97		0 281 002 123
Knock sensor	01.96-08.97		0 261 231 110



Pedal position sensor, EMS (electronic engine management)			
Fg.no. →A962231	01.96-08.97		0 205 001 302
Duo sensor, acceleration and yaw rate, brake system	01.96-08.97		0 265 005 201
Wheel speed sensor, front	01.96-08.97	LAB	0 265 006 190
		RAB	0 265 006 188
Wheel speed sensor, rear	01.96-08.97	LAB	0 265 006 178
		RAB	0 265 006 194
55 AMG KOMPRESSOR [211]	5,4l	350 kW M 113.990	8 Zyl.
Throttle valve assembly	10.02-05.06		0 280 750 045
Air mass meter, gasoline injection	10.02-05.06		0 280 217 810
Phase sensor	10.02-05.06		0 232 103 050
Speed sensor, ignition/injection	10.02-05.06		0 261 210 170
Knock sensor	10.02-05.06		0 261 231 110
Duo sensor, acceleration and yaw rate, brake system	10.02-05.06		0 265 005 258
Wheel speed sensor, front	10.02-05.06		0 265 007 499
Wheel speed sensor, rear	10.02-05.06		0 265 007 500
60 AMG [124]	6,0l	280 kW M 119.974	8 Zyl.
Air mass meter, gasoline injection	07.93-06.95		0 280 214 004
			0 986 280 121
Speed sensor, ignition/injection	07.93-06.95		0 261 210 085
Knock sensor	07.93-06.95		0 261 231 062
Temperature sensor, intake air, injection system	07.93-06.95		0 280 130 047
Wheel speed sensor, front			
Fg.no. C013141→	07.93-06.95	LAB	0 265 001 284
		RAB	0 265 001 282
Fg.no. →C013142	07.93-06.95	LAB	0 265 006 111
		RAB	0 265 006 109
Wheel speed sensor, rear	07.93-06.95	LAB	0 265 002 238
		RAB	0 265 002 108
63 AMG [211]	6,2l	378 kW M 156.983	8 Zyl.
Knock sensor	06.06→		0 261 231 188
Duo sensor, acceleration and yaw rate, brake system	06.06→		0 265 005 298
Wheel speed sensor, front	06.06→		0 265 007 745
Wheel speed sensor, rear	06.06→		0 265 007 700
200 [124]	2,0l	100 kW M 111.940	4 Zyl.
Speed sensor, ignition/injection	07.93-07.95		0 261 210 055
Wheel speed sensor, front			
Fg.no. C009356→,B891779→C009354,	07.93-07.95	LAB	0 265 006 111
Comp. no. Code 859		RAB	0 265 006 109
Fg.no. →C009355,B891779→C009354,	07.93-07.95	LAB	0 265 001 284
Comp. no. Code 859		RAB	0 265 001 282
Wheel speed sensor, rear	07.93-07.95		0 265 002 208
200 [210]	2,0l	100 kW M 111.942	4 Zyl.
Air mass meter, gasoline injection	06.95-02.01	FGK	0 280 217 114
		KUT	0 280 218 081
Speed sensor, ignition/injection			
Mot.no. 055850 →	06.95-02.01	AG	0 261 210 170
Mot.no. 057355 →	06.95-02.01	GS	0 261 210 170
Mot.no. →055849	06.95-02.01	AG	0 281 002 123
Mot.no. →057354	06.95-02.01	GS	0 281 002 123
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. B174000→,Comp.no. Code 800,	06.95-02.01		0 265 005 258
Fg.no. X037894→			
Fg.no. →B173999,Comp.no. Code 801,	06.95-02.01		0 265 005 201
Fg.no. →X044900			
Wheel speed sensor, front	06.95-02.01	LAB	0 265 006 190
		RAB	0 265 006 188
Wheel speed sensor, rear	06.95-02.01	LAB	0 265 006 178
		RAB	0 265 006 194



M



200 Cabrio [124]		2,0l 100 kW M 111.940 4 Zyl.	
Speed sensor, ignition/injection	07.93-06.98		0 261 210 055
Wheel speed sensor, front	07.93-06.98	LAB	0 265 006 111
		RAB	0 265 006 109
Wheel speed sensor, rear	07.93-06.98		0 265 002 254
200 CDI [210]		2,1l 85 kW OM 611.961 4 Zyl.	
Air mass meter, diesel	07.99-08.99		0 281 002 152
Pulse generator, diesel	07.99-08.99		0 281 002 123
Speed sensor, diesel	09.99-03.02		0 261 210 170
High-pressure sensor (CR system)	07.99-03.02		0 281 002 498
Duo sensor, acceleration and yaw rate, brake system	07.99-03.02		0 265 005 258
Wheel speed sensor, front	07.99-03.02	LAB	0 265 006 190
		RAB	0 265 006 188
Wheel speed sensor, rear	07.99-03.02	LAB	0 265 006 178
		RAB	0 265 006 194
200 CDI [210]		2,2l 75 kW OM 611.961 4 Zyl.	
Air mass meter, diesel	07.98-08.99		0 281 002 152
Pulse generator, diesel	07.98-08.99		0 281 002 123
Speed sensor, diesel	09.99-03.02		0 261 210 170
High-pressure sensor (CR system)	07.98-03.02		0 281 002 498
Duo sensor, acceleration and yaw rate, brake system	07.98-03.02		0 265 005 258
Wheel speed sensor, front	07.98-03.02	LAB	0 265 006 190
		RAB	0 265 006 188
Wheel speed sensor, rear	07.98-03.02	LAB	0 265 006 178
		RAB	0 265 006 194
200 CDI [211]		2,1l 75/90 kW OM 646.951 4 Zyl.	
Air mass meter, diesel	07.02→		0 281 002 535
Speed sensor, diesel	07.02→		0 261 210 170
High-pressure sensor (CR system)	07.02→		0 281 002 504
Duo sensor, acceleration and yaw rate, brake system	07.02→		0 265 005 258
Wheel speed sensor, front	07.02→		0 265 007 499
Wheel speed sensor, rear	07.02→		0 265 007 500
200 CDI [211]		2,1l 100 kW OM 646.821 4 Zyl.	
Air mass meter, diesel	04.06→		0 281 002 535
Speed sensor, diesel	04.06→		0 261 210 170
Duo sensor, acceleration and yaw rate, brake system	04.06→		0 265 005 298
Wheel speed sensor, front	04.06→		0 265 007 745
Wheel speed sensor, rear	04.06→		0 265 007 700
200 Coupé [124]		2,0l 100 kW M 111.940 4 Zyl.	
Speed sensor, ignition/injection	07.93-06.97		0 261 210 055
Wheel speed sensor, front	07.93-06.97	LAB	0 265 006 111
		RAB	0 265 006 109
Fg.no. →C009355, B891779→C009354, Comp. no. Code 859	07.93-06.97	LAB	0 265 001 284
		RAB	0 265 001 282
Wheel speed sensor, rear	07.93-06.97		0 265 002 208
200 D [124]		2,0l 55 kW OM 601.912 4 Zyl.	
Wheel speed sensor, front	07.93-06.95	LAB	0 265 001 284
		RAB	0 265 001 282
Fg.no. →A060861	07.93-06.95	LAB	0 265 001 128
		RAB	0 265 001 126
Wheel speed sensor, rear			
Fg.no. A203047→	07.93-06.95		0 265 002 208
200 D [210]		2,0l 65 kW OM 604.917 4 Zyl.	
Pulse generator, diesel	03.97-06.99		0 281 002 123
Pedal position sensor, diesel			
Fg.no. A 117064→,J 024802→	03.97-06.99		0 205 001 302
Fg.no. →A 177063,→J 024801	03.97-06.99		0 205 001 029



Wheel speed sensor, front	03.97-06.99	LAB	0 265 006 190
		RAB	0 265 006 188
Wheel speed sensor, rear	03.97-06.99	LAB	0 265 006 178
		RAB	0 265 006 194
200 KOMPRESSOR [210]	2,0l	120 kW M	111.957 4 Zyl.
Throttle valve assembly	09.00-03.02		0 280 750 074
Speed sensor, ignition/injection	09.00-03.02		0 261 210 170
Duo sensor, acceleration and yaw rate, brake system	09.00-03.02		0 265 005 258
Wheel speed sensor, front	09.00-03.02	LAB	0 265 006 190
		RAB	0 265 006 188
Wheel speed sensor, rear	09.00-03.02	LAB	0 265 006 178
		RAB	0 265 006 194
200 KOMPRESSOR [210]	2,0l	137 kW M	111.947 4 Zyl.
Throttle valve assembly	09.97-08.00		0 205 003 044
Air mass meter, gasoline injection	09.97-08.00	FGK	0 280 217 114
		KUT	0 280 218 081
Speed sensor, ignition/injection			
Mot.no. →001935	09.97-08.00	AG	0 281 002 123
Mot.no. →001936	09.97-08.00	AG	0 261 210 170
Mot.no. →005503	09.97-08.00	GS	0 281 002 123
Mot.no. →005504	09.97-08.00	GS	0 261 210 170
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. B174000→, Comp.no. Code 800, Fg.no. X037894→	09.97-08.00		0 265 005 258
Fg.no. →B173999, Comp.no. Code 801, Fg.no. →X044900	09.97-08.00		0 265 005 201
Wheel speed sensor, front	09.97-08.00	LAB	0 265 006 190
		RAB	0 265 006 188
Wheel speed sensor, rear	09.97-08.00	LAB	0 265 006 178
		RAB	0 265 006 194
200 KOMPRESSOR [211]	1,8l	120 kW M	271.941 4 Zyl.
Throttle valve assembly	03.02-03.06		0 280 750 076
Phase sensor	03.02-03.06	AUS,NOC	0 232 103 037
		EIN,NOC	0 232 103 050
Speed sensor, ignition/injection	03.02-03.06		0 261 210 170
Duo sensor, acceleration and yaw rate, brake system	03.02-03.06		0 265 005 258
Wheel speed sensor, front	03.02-03.06		0 265 007 499
Wheel speed sensor, rear	03.02-03.06		0 265 007 500
200 KOMPRESSOR [211]	1,8l	135 kW M	271.956 4 Zyl.
Throttle valve assembly	04.06→		0 280 750 076
Phase sensor	04.06→		0 232 103 037
Speed sensor, ignition/injection	04.06→		0 261 210 170
Duo sensor, acceleration and yaw rate, brake system	04.06→		0 265 005 298
Wheel speed sensor, front	04.06→		0 265 007 745
Wheel speed sensor, rear	04.06→		0 265 007 700
200 KOMPRESSOR NGT [211]	1,8l	120 kW M	271.941 4 Zyl.
Throttle valve assembly	04.04→		0 280 750 076
Phase sensor	04.04→	AUS,NOC	0 232 103 037
		EIN,NOC	0 232 103 050
Speed sensor, ignition/injection	04.04→		0 261 210 170
Duo sensor, acceleration and yaw rate, brake system	04.04→		0 265 005 258
Wheel speed sensor, front	04.04→		0 265 007 499
Wheel speed sensor, rear	04.04→		0 265 007 500
220 [124]	2,2l	110 kW M	111.960 4 Zyl.
Air mass meter, gasoline injection	07.93-06.95		0 280 217 100
Speed sensor, ignition/injection			
Mot.no. →079783	07.93-06.95	AG,LLE	0 261 210 055
Mot.no. →080036	07.93-06.95	GS,LLE	0 261 210 055

Product				

◀ Serie E

Speed sensor, ignition/injection			
Mot.no. →079784→	07.93-06.95	GS, LLE	0 261 210 122
Mot.no. →080037→	07.93-06.95	AG, LLE	0 261 210 122
Knock sensor			
Mot.no. →079783	07.93-06.95	AG	0 261 231 098
Mot.no. →080036	07.93-06.95	GS	0 261 231 098
Wheel speed sensor, front			
Fg.no. C009356→, B891779→C009354,	07.93-06.95	LAB	0 265 006 111
Comp. no. Code 859		RAB	0 265 006 109
Fg.no. →C009355, B891779→C009354,	07.93-06.95	LAB	0 265 001 284
Comp. no. Code 859		RAB	0 265 001 282
Wheel speed sensor, rear	07.93-06.95		0 265 002 208
220 Cabrio [124]	2,2l 110 kW M 111.960 4 Zyl.		
Air mass meter, gasoline injection	07.93-06.98		0 280 217 100
Speed sensor, ignition/injection			
Mot.no. →079783	07.93-06.98	AG, LLE	0 261 210 055
Mot.no. →080036	07.93-06.98	GS, LLE	0 261 210 055
Mot.no. 079784→	07.93-06.98	GS, LLE	0 261 210 122
Mot.no. 080037→	07.93-06.98	AG, LLE	0 261 210 122
Knock sensor			
Mot.no. →079783	07.93-06.98	AG	0 261 231 098
Mot.no. →080036	07.93-06.98	GS	0 261 231 098
Wheel speed sensor, front	07.93-06.98	LAB	0 265 006 111
		RAB	0 265 006 109
Wheel speed sensor, rear	07.93-06.98		0 265 002 254
220 CDI [210]	2,1l 105 kW OM 611.961 4 Zyl.		
Air mass meter, diesel	07.99-08.99		0 281 002 152
Pulse generator, diesel	07.99-08.99		0 281 002 123
Speed sensor, diesel	09.99-03.02		0 261 210 170
High-pressure sensor (CR system)	07.99-03.02		0 281 002 498
Duo sensor, acceleration and yaw rate, brake system	07.99-03.02		0 265 005 258
Wheel speed sensor, front	07.99-03.02	LAB	0 265 006 190
		RAB	0 265 006 188
Wheel speed sensor, rear	07.99-03.02	LAB	0 265 006 178
		RAB	0 265 006 194
220 CDI [210]	2,2l 92 kW OM 611.961 4 Zyl.		
Air mass meter, diesel	07.98-06.99		0 281 002 152
Pulse generator, diesel	07.98-06.99		0 281 002 123
High-pressure sensor (CR system)	07.98-06.99		0 281 002 498
Duo sensor, acceleration and yaw rate, brake system	07.98-06.99		0 265 005 258
Wheel speed sensor, front	07.98-06.99	LAB	0 265 006 190
		RAB	0 265 006 188
Wheel speed sensor, rear	07.98-06.99	LAB	0 265 006 178
		RAB	0 265 006 194
220 CDI [211]	2,1l 100/110 kW OM 646.961 4 Zyl.		
Air mass meter, diesel	03.02→		0 281 002 535
Speed sensor, diesel	03.02→		0 261 210 170
High-pressure sensor (CR system)	03.02→		0 281 002 504
Duo sensor, acceleration and yaw rate, brake system	03.02→		0 265 005 258
Wheel speed sensor, front	03.02→		0 265 007 499
Wheel speed sensor, rear	03.02→		0 265 007 500
220 CDI [211]	2,1l 125 kW OM 646.821 4 Zyl.		
Air mass meter, diesel	04.06→		0 281 002 535
Speed sensor, diesel	04.06→		0 261 210 170
Duo sensor, acceleration and yaw rate, brake system	04.06→		0 265 005 298
Wheel speed sensor, front	04.06→		0 265 007 745
Wheel speed sensor, rear	04.06→		0 265 007 700

Product				

220 Coupé [124]	2,2l 110 kW M 111.960 4 Zyl.		
Air mass meter, gasoline injection	07.93-06.97		0 280 217 100
Speed sensor, ignition/injection			
Mot.no. →079783	07.93-06.97	AG, LLE	0 261 210 055
Mot.no. →080036	07.93-06.97	GS, LLE	0 261 210 055
Mot.no. 079784→	07.93-06.97	GS, LLE	0 261 210 122
Mot.no. 080037→	07.93-06.97	AG, LLE	0 261 210 122
Knock sensor			
Mot.no. →079783	07.93-06.97	AG	0 261 231 098
Mot.no. →080036	07.93-06.97	GS	0 261 231 098
Wheel speed sensor, front			
Fg.no. C009356→, B891779→C009354,	07.93-06.97	LAB	0 265 006 111
Comp. no. Code 859		RAB	0 265 006 109
Fg.no. →C009355, B891779→C009354,	07.93-06.97	LAB	0 265 001 284
Comp. no. Code 859		RAB	0 265 001 282
Wheel speed sensor, rear	07.93-06.97		0 265 002 208
220 D [210]	2,2l 55-70 kW OM 604.912 4 Zyl.		
Pulse generator, diesel	06.95-06.99		0 281 002 123
Pedal position sensor, diesel			
Fg.no. A 117064→, J 024802→	06.95-06.99		0 205 001 302
Fg.no. →A 177063, →J 024801	06.95-06.99		0 205 001 029
Wheel speed sensor, front	06.95-06.99	LAB	0 265 006 190
		RAB	0 265 006 188
Wheel speed sensor, rear	06.95-06.99	LAB	0 265 006 178
		RAB	0 265 006 194
230 [210]	2,3l 110 kW M 111.970 4 Zyl.		
Air mass meter, gasoline injection			
Mot.no. →013233	06.95-08.97	GS	0 280 217 100
Mot.no. →042470	06.95-08.97	AG	0 280 217 100
Mot.no. 013234→	06.95-08.97	GS, KAT	0 280 217 114
		GS, KUT	0 280 218 081
Mot.no. 042471→	06.95-08.97	AG, KAT	0 280 217 114
		AG, KUT	0 280 218 081
Speed sensor, ignition/injection	06.95-08.97		0 281 002 123
Duo sensor, acceleration and yaw rate, brake system	06.95-08.97		0 265 005 258
Wheel speed sensor, front	06.95-08.97	LAB	0 265 006 190
		RAB	0 265 006 188
Wheel speed sensor, rear	06.95-08.97	LAB	0 265 006 178
		RAB	0 265 006 194
230 [211]	2,5l 150 kW M 272.922 6 Zyl.		
Air mass meter, gasoline injection	09.07→		0 280 218 190
Phase sensor	09.07→	LAB	0 232 103 050
Knock sensor	09.07→		0 261 231 188
Duo sensor, acceleration and yaw rate, brake system	09.07→		0 265 005 298
Wheel speed sensor, front	09.07→		0 265 007 745
Wheel speed sensor, rear	09.07→		0 265 007 700
240 [210]	2,4l 125 kW M 112.911 6 Zyl.		
Throttle valve assembly	09.97-06.99		0 205 003 046
Air mass meter, gasoline injection	09.97-06.99		0 280 217 515
Phase sensor	09.97-06.99		0 232 103 037
Speed sensor, ignition/injection			
Mot.no. →370998	09.97-06.99		0 261 210 141
Mot.no. 370999→	09.97-06.99		0 261 210 170
Knock sensor	09.97-06.99		0 261 231 110
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. B174000→, Comp. no. Code 800,	09.97-06.99		0 265 005 258
Fg.no. X037894→			
Fg.no. →B173999, Comp. no. Code 801,	09.97-06.99		0 265 005 201
Fg.no. →X044900			



Product				
Wheel speed sensor, front	09.97-06.99	LAB	0 265 006 190	
		RAB	0 265 006 188	
Wheel speed sensor, rear	09.97-06.99	LAB	0 265 006 178	
		RAB	0 265 006 194	
240 [210]	2,6l 125 kW M 112.914 6 Zyl.			
Throttle valve assembly	09.00-03.02		0 280 750 019	
Air mass meter, gasoline injection	09.00-03.02		0 280 217 515	
Phase sensor	09.00-03.02		0 232 103 050	
Speed sensor, ignition/injection	09.00-03.02		0 261 210 170	
Knock sensor	09.00-03.02		0 261 231 110	
Duo sensor, acceleration and yaw rate, brake system	09.00-03.02		0 265 005 258	
Wheel speed sensor, front	09.00-03.02	LAB	0 265 006 190	
		RAB	0 265 006 188	
Wheel speed sensor, rear	09.00-03.02	LAB	0 265 006 178	
		RAB	0 265 006 194	
240 [211]	2,6l 130 kW M 112.913 6 Zyl.			
Throttle valve assembly	03.02-03.05		0 280 750 019	
Air mass meter, gasoline injection	03.02-03.05		0 280 217 515	
Phase sensor	03.02-03.05		0 232 103 050	
Speed sensor, ignition/injection	03.02-03.05		0 261 210 170	
Knock sensor	03.02-03.05		0 261 231 110	
Duo sensor, acceleration and yaw rate, brake system	03.02-03.05		0 265 005 258	
Wheel speed sensor, front	03.02-03.05		0 265 007 499	
Wheel speed sensor, rear	03.02-03.05		0 265 007 500	
240 4MATIC [211]	2,6l 130 kW M 112.917 6 Zyl.			
Throttle valve assembly	09.03→		0 280 750 019	
Air mass meter, gasoline injection	09.03→		0 280 217 515	
Phase sensor	09.03→		0 232 103 050	
Speed sensor, ignition/injection	09.03→		0 261 210 170	
Knock sensor	09.03→		0 261 231 110	
Duo sensor, acceleration and yaw rate, brake system	09.03→		0 265 005 258	
Wheel speed sensor, rear	09.03→		0 265 007 500	
250 D [124]	2,5l 83 kW OM 605.911 5 Zyl.			
Wheel speed sensor, front	07.93-06.95	LAB	0 265 006 111	
		RAB	0 265 006 109	
Wheel speed sensor, rear	07.93-06.95		0 265 002 208	
250 D [210]	2,5l 83 kW OM 605.912 5 Zyl.			
Pulse generator, diesel	06.95-06.99		0 281 002 123	
Pedal position sensor, diesel	06.95-06.99		0 205 001 029	
Wheel speed sensor, front	06.95-06.99	LAB	0 265 006 190	
		RAB	0 265 006 188	
Wheel speed sensor, rear	06.95-06.99	LAB	0 265 006 178	
		RAB	0 265 006 194	
250 D Turbo [124]	2,5l 93 kW OM 602.962 5 Zyl.			
Wheel speed sensor, front	07.93-06.95	LAB	0 265 001 284	
		RAB	0 265 001 282	
Wheel speed sensor, rear				
Fg.no. A203047→	07.93-06.95		0 265 002 208	
250 D Turbo [210]	2,5l 110 kW OM 605.962 5 Zyl.			
Pulse generator, diesel	09.97-06.99		0 281 002 123	
Pedal position sensor, diesel	09.97-06.99		0 205 001 029	
Wheel speed sensor, front	09.97-06.99	LAB	0 265 006 190	
		RAB	0 265 006 188	
Wheel speed sensor, rear	09.97-06.99	LAB	0 265 006 178	
		RAB	0 265 006 194	
270 CDI [210]	2,7l 125 kW OM 612.961 5 Zyl.			
Speed sensor, diesel	06.99-03.02		0 261 210 170	
High-pressure sensor (CR system)				
Mot.no. →287865	06.99-03.02		0 281 002 498	
Mot.no. 287866→	06.99-03.02		0 281 002 700	

Duo sensor, acceleration and yaw rate, brake system	06.99-03.02		0 265 005 258	
Wheel speed sensor, front	06.99-03.02	LAB	0 265 006 190	
		RAB	0 265 006 188	
Wheel speed sensor, rear	06.99-03.02	LAB	0 265 006 178	
		RAB	0 265 006 194	
270 CDI [211]	2,7l 130 kW OM 647.961 5 Zyl.			
Air mass meter, diesel	03.02-03.05		0 281 002 535	
Speed sensor, diesel	03.02-03.05		0 261 210 170	
High-pressure sensor (CR system)	03.02-03.05		0 281 002 504	
Duo sensor, acceleration and yaw rate, brake system	03.02-03.05		0 265 005 258	
Wheel speed sensor, front	03.02-03.05		0 265 007 499	
Wheel speed sensor, rear	03.02-03.05		0 265 007 500	
280 [124]	2,8l 142 kW M 104.942 6 Zyl.			
Air mass meter, gasoline injection	07.93-06.95		0 280 217 500	
Speed sensor, ignition/injection				
Mot.no. →005789	07.93-06.95	GS,LLE	0 261 210 055	
		GS,RLE	0 261 210 066	
Mot.no. →048696	07.93-06.95	AG,LLE	0 261 210 055	
		AG,RLE	0 261 210 066	
Mot.no. 005790→	07.93-06.95	GS	0 261 210 122	
Mot.no. 048697→	07.93-06.95	AG	0 261 210 122	
Wheel speed sensor, front				
Fg.no. C009356→,B891779→C009354,	07.93-06.95	LAB	0 265 006 111	
Comp. no. Code 859		RAB	0 265 006 109	
Fg.no. →C009355,B891779→C009354,	07.93-06.95	LAB	0 265 001 284	
~~Comp. no. Code 859~~		RAB	0 265 001 282	
Wheel speed sensor, rear	07.93-06.95	AOS	0 265 002 210	
		ASR,LAB	0 265 002 206	
		ASR,RAB	0 265 002 204	
280 [210]	2,8l 142 kW M 104.945 6 Zyl.			
Air mass meter, gasoline injection	01.96-02.97		0 280 217 500	
Speed sensor, ignition/injection	01.96-02.97		0 261 210 122	
Wheel speed sensor, front	01.96-02.97	LAB	0 265 006 190	
		RAB	0 265 006 188	
Wheel speed sensor, rear	01.96-02.97	LAB	0 265 006 178	
		RAB	0 265 006 194	
280 [210]	2,8l 150 kW M 112.921 6 Zyl.			
Throttle valve assembly	06.95-08.00		0 205 003 046	
	09.00-01.03		0 280 750 019	
Air mass meter, gasoline injection	06.95-01.03		0 280 217 515	
Phase sensor	06.95-01.03		0 232 103 037	
Speed sensor, ignition/injection				
Mot.no. →370998	06.95-01.03		0 261 210 141	
Mot.no. 370999→	06.95-01.03		0 261 210 170	
Knock sensor	06.95-01.03		0 261 231 110	
Pedal position sensor, EMS (electronic engine management)				
Fg.no. →A962231	06.95-01.03		0 205 001 302	
Duo sensor, acceleration and yaw rate, brake system				
Fg.no. B174000→,Comp.no. Code 800,	06.95-01.03		0 265 005 258	
Fg.no. X037894→				
Fg.no. →B173999,Comp.no. Code 801,	06.95-01.03		0 265 005 201	
Fg.no. →X044900				
Wheel speed sensor, front	06.95-01.03	LAB	0 265 006 190	
		RAB	0 265 006 188	
Wheel speed sensor, rear	06.95-01.03	LAB	0 265 006 178	
		RAB	0 265 006 194	
280 [211]	3,0l 170 kW M 272.943 6 Zyl.			
Throttle valve assembly	04.05→		0 280 750 017	
Air mass meter, gasoline injection	04.05→		0 280 218 190	

Product				

◀ Serie E

Phase sensor	04.05→	LAB	0 232 103 050
Knock sensor	04.05→		0 261 231 188
Duo sensor, acceleration and yaw rate, brake system	04.05→		0 265 005 298
Wheel speed sensor, front	04.05→		0 265 007 745
Wheel speed sensor, rear	04.05→		0 265 007 700
280 CDI [211]	3,0l 140 kW OM 642.920 6 Zyl.		
High-pressure sensor (CR system)	04.05→		0 281 002 504
Duo sensor, acceleration and yaw rate, brake system	04.05→		0 265 005 298
Wheel speed sensor, front	04.05→		0 265 007 745
Wheel speed sensor, rear	04.05→		0 265 007 700
280 CDI [211]	3,2l 130 kW OM 648.961 6 Zyl.		
Air mass meter, diesel	04.04-03.05		0 281 002 535
Speed sensor, diesel	04.04-03.05		0 261 210 170
High-pressure sensor (CR system)	04.04-03.05		0 281 002 504
Duo sensor, acceleration and yaw rate, brake system	04.04-03.05		0 265 005 258
Wheel speed sensor, front	04.04-03.05		0 265 007 499
Wheel speed sensor, rear	04.04-03.05		0 265 007 700
280 CDI 4MATIC [211]	3,0l 140 kW OM 642.921 6 Zyl.		
High-pressure sensor (CR system)	04.05→		0 281 002 504
Duo sensor, acceleration and yaw rate, brake system	04.05→		0 265 005 298
Wheel speed sensor, front	04.05→		0 265 007 745
Wheel speed sensor, rear	04.05→		0 265 007 700
280 4MATIC [210]	2,8l 150 kW M 112.921 6 Zyl.		
Throttle valve assembly	03.97-08.00		0 205 003 046
	09.00-01.03		0 280 750 019
Air mass meter, gasoline injection	03.97-01.03		0 280 217 515
Phase sensor	03.97-01.03		0 232 103 037
Speed sensor, ignition/injection			
Mot.no. →370998	03.97-01.03		0 261 210 141
Mot.no. 370999→	03.97-01.03		0 261 210 170
Knock sensor	03.97-01.03		0 261 231 110
Pedal position sensor, EMS (electronic engine management)			
Fg.no. →A962231	03.97-01.03		0 205 001 302
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. B174000→, Comp.no. Code 800,	03.97-01.03		0 265 005 258
Fg.no. X037894→			
Fg.no. →B173999, Comp.no. Code 801,	03.97-01.03		0 265 005 201
Fg.no. →X044900			
Pressure sensor, ESP, (electronic stability program)	07.99-01.03		0 265 005 303
Fg.no. →B 173367	07.99-01.03		0 265 005 307
Wheel speed sensor, front	03.97-01.03	LAB	0 265 006 358
		RAB	0 265 006 356
Wheel speed sensor, rear	03.97-01.03	LAB	0 265 006 178
		RAB	0 265 006 194
280 4MATIC [211]	3,0l 170 kW M 272.944 6 Zyl.		
Throttle valve assembly	04.05→		0 280 750 017
Air mass meter, gasoline injection	04.05→		0 280 218 190
Phase sensor	04.05→	LAB	0 232 103 050
Knock sensor	04.05→		0 261 231 188
Duo sensor, acceleration and yaw rate, brake system	04.05→		0 265 005 298
Wheel speed sensor, front	04.05→		0 265 007 745
Wheel speed sensor, rear	04.05→		0 265 007 700
290 D Turbo [210]	2,9l 95 kW OM 602.982 5 Zyl.		
Air mass meter, diesel	01.96-06.99		0 280 217 509
Pulse generator, diesel	01.96-06.99		0 281 002 123
Pedal position sensor, diesel	01.96-06.99		0 205 001 029

Product				

Wheel speed sensor, front	01.96-06.99	LAB	0 265 006 190
		RAB	0 265 006 188
Wheel speed sensor, rear	01.96-06.99	LAB	0 265 006 178
		RAB	0 265 006 194
300 Bluetec [211]	3,0l 155 kW OM 642.920 6 Zyl.		
Duo sensor, acceleration and yaw rate, brake system	12.07→		0 265 005 298
Wheel speed sensor, front	12.07→		0 265 007 745
Wheel speed sensor, rear	12.07→		0 265 007 700
300 D [124]	3,0l 100 kW OM 606.910 6 Zyl.		
Wheel speed sensor, front	07.93-06.95	LAB	0 265 006 111
		RAB	0 265 006 109
Wheel speed sensor, rear	07.93-06.95		0 265 002 208
300 D [210]	3,0l 100 kW OM 606.912 6 Zyl.		
Pulse generator, diesel	06.95-08.97		0 281 002 123
Pedal position sensor, diesel	06.95-08.97	LLE	0 205 001 029
		RLE	0 205 001 302
Wheel speed sensor, front	06.95-08.97	LAB	0 265 006 190
		RAB	0 265 006 188
Wheel speed sensor, rear	06.95-08.97	LAB	0 265 006 178
		RAB	0 265 006 194
300 D Turbo [124]	3,0l 108 kW OM 603.960 6 Zyl.		
Wheel speed sensor, front	07.93-06.95	LAB	0 265 001 284
		RAB	0 265 001 282
Wheel speed sensor, rear			
Fg.no. A203047→	07.93-06.95		0 265 002 208
300 D Turbo [210]	3,0l 130 kW OM 606.962 6 Zyl.		
Air mass meter, diesel	03.97-06.99		0 281 002 152
Pulse generator, diesel	03.97-06.99		0 281 002 123
Pedal position sensor, diesel	03.97-06.99		0 205 001 029
Duo sensor, acceleration and yaw rate, brake system	03.97-06.99		0 265 005 201
Wheel speed sensor, front	03.97-06.99	LAB	0 265 006 190
		RAB	0 265 006 188
Wheel speed sensor, rear	03.97-06.99	LAB	0 265 006 178
		RAB	0 265 006 194
300 D Turbo 4MATIC [124]	3,0l 108 kW OM 603.963 6 Zyl.		
Air flow sensor, diesel	07.93-06.95		0 281 002 024
			0 281 002 028
Temperature sensor, coolant, diesel	07.93-06.95		0 280 130 035
Wheel speed sensor, front	07.93-06.95	LAB	0 265 001 300
		RAB	0 265 001 298
Wheel speed sensor, rear			
Fg.no. A203047→	07.93-06.95		0 265 002 208
300 4MATIC [124]	3,0l 132 kW M 103.985 6 Zyl.		
Air flow sensor, gasoline injection	07.93-06.95		0 438 121 033
			0 986 439 333
Speed sensor, ignition/injection	07.93-06.95		0 261 210 051
Temperature sensor, intake air, injection system	07.93-06.95		0 280 130 047
Temperature sensor, coolant, injection system			
Mot.no. →002187	07.93-06.95	2PO,GS	0 280 130 044
Mot.no. →008267	07.93-06.95	2PO,AG	0 280 130 044
Wheel speed sensor, front	07.93-06.95	LAB	0 265 001 300
		RAB	0 265 001 298
Wheel speed sensor, rear			
Fg.no. A203047→	07.93-06.95		0 265 002 208
320 [124]	3,2l 162 kW M 104.992 6 Zyl.		
Air mass meter, gasoline injection	07.93-06.95		0 280 217 500
Speed sensor, ignition/injection			
Mot.no. →004356	07.93-06.95	GS,LLE	0 261 210 055
Mot.no. →072236	07.93-06.95	AG,LLE	0 261 210 055
Mot.no. 004357→	07.93-06.95	GS,LLE	0 261 210 122
Mot.no. 072237→	07.93-06.95	AG,LLE	0 261 210 122



Wheel speed sensor, front				
Fg.no. C009356→,B891779→C009354,	07.93-06.95	LAB	0 265 006 111	
Comp. no. Code 859		RAB	0 265 006 109	
Fg.no. →C009355,B891779→C009354,	07.93-06.95	LAB	0 265 001 284	
Comp. no. Code 859		RAB	0 265 001 282	
Wheel speed sensor, rear	07.93-06.95		0 265 002 210	
		ASR,LAB	0 265 002 206	
		ASR,RAB	0 265 002 204	
320 [210]	3,2l 162/170 kW	M 104.995	6 Zyl.	
Air mass meter, gasoline injection				
Mot.no. →12/52 050146,Comp. no. Code 807	06.95-08.97		0 280 217 500	
Mot.no. 050174→,Comp. no. Code 807	06.95-08.97		0 280 218 080	
Speed sensor, ignition/injection	06.95-08.97		0 261 210 122	
Wheel speed sensor, front	06.95-08.97	LAB	0 265 006 190	
		RAB	0 265 006 188	
Wheel speed sensor, rear	06.95-08.97	LAB	0 265 006 178	
		RAB	0 265 006 194	
320 [210]	3,2l 165 kW	M 112.941	6 Zyl.	
Throttle valve assembly	03.97-03.02		0 205 003 046	
Air mass meter, gasoline injection	03.97-03.02		0 280 217 515	
Phase sensor	03.97-03.02		0 232 103 050	
Speed sensor, ignition/injection				
Mot.no. →370998	03.97-03.02		0 261 210 141	
Mot.no. 370999→	03.97-03.02		0 261 210 170	
Knock sensor	03.97-03.02		0 261 231 110	
Duo sensor, acceleration and yaw rate, brake system				
Fg.no. B174000→,Comp. no. Code 800,	03.97-03.02		0 265 005 258	
Fg.no. X037894→				
Fg.no. →B173999,Comp. no. Code 801,	03.97-03.02		0 265 005 201	
Fg.no. →X044900				
Wheel speed sensor, front	03.97-03.02	LAB	0 265 006 190	
		RAB	0 265 006 188	
Wheel speed sensor, rear	03.97-03.02	LAB	0 265 006 178	
		RAB	0 265 006 194	
320 [211]	3,2l 165 kW	M 112.949	6 Zyl.	
Throttle valve assembly	03.02-03.05		0 280 750 019	
Air mass meter, gasoline injection	03.02-03.05		0 280 217 515	
Phase sensor	03.02-03.05		0 232 103 050	
Speed sensor, ignition/injection	03.02-03.05		0 261 210 170	
Knock sensor	03.02-03.05		0 261 231 110	
Duo sensor, acceleration and yaw rate, brake system	03.02-03.05		0 265 005 258	
Wheel speed sensor, front	03.02-03.05		0 265 007 499	
Wheel speed sensor, rear	03.02-03.05		0 265 007 500	
320 Cabrio [124]	3,2l 162-170 kW	M 104.992	6 Zyl.	
Air mass meter, gasoline injection	05.93-06.98		0 280 217 500	
Speed sensor, ignition/injection				
Mot.no. →004356	05.93-06.98	GS,LLE	0 261 210 055	
Mot.no. →072236	05.93-06.98	AG,LLE	0 261 210 055	
Mot.no. 004357→	05.93-06.98	GS,LLE	0 261 210 122	
Mot.no. 072237→	05.93-06.98	AG,LLE	0 261 210 122	
Wheel speed sensor, front	05.93-06.98	LAB	0 265 006 111	
		RAB	0 265 006 109	
Wheel speed sensor, rear	05.93-06.98	AOS	0 265 002 244	
		ASR,LAB	0 265 002 206	
		ASR,RAB	0 265 002 204	
320 CDI [210]	3,2l 145 kW	OM 613.961	6 Zyl.	
Speed sensor, diesel	06.99-03.02		0 261 210 170	
High-pressure sensor (CR system)	06.99-03.02		0 281 002 498	
Duo sensor, acceleration and yaw rate, brake system	06.99-03.02		0 265 005 258	



Wheel speed sensor, front	06.99-03.02	LAB	0 265 006 190	
		RAB	0 265 006 188	
Wheel speed sensor, rear	06.99-03.02	LAB	0 265 006 178	
		RAB	0 265 006 194	
320 CDI [211]	3,0l 165 kW	OM 642.920	6 Zyl.	
High-pressure sensor (CR system)	04.05→		0 281 002 504	
Duo sensor, acceleration and yaw rate, brake system	04.05→		0 265 005 298	
Wheel speed sensor, front	04.05→		0 265 007 745	
Wheel speed sensor, rear	04.05→		0 265 007 700	
320 CDI [211]	3,2l 150 kW	OM 648.961	6 Zyl.	
Air mass meter, diesel	11.02-03.05		0 281 002 535	
Speed sensor, diesel	11.02-03.05		0 261 210 170	
High-pressure sensor (CR system)	11.02-03.05		0 281 002 504	
Duo sensor, acceleration and yaw rate, brake system	11.02-03.05		0 265 005 258	
Wheel speed sensor, front	11.02-03.05		0 265 007 499	
Wheel speed sensor, rear	11.02-03.05		0 265 007 500	
320 CDI 4MATIC [211]	3,0l 165 kW	OM 642.921	6 Zyl.	
High-pressure sensor (CR system)	04.05→		0 281 002 504	
Duo sensor, acceleration and yaw rate, brake system	04.05→		0 265 005 298	
Wheel speed sensor, front	04.05→		0 265 007 745	
Wheel speed sensor, rear	04.05→		0 265 007 700	
320 Coupé [124]	3,2l 162 kW	M 104.992	6 Zyl.	
Air mass meter, gasoline injection	07.93-06.98		0 280 217 500	
Speed sensor, ignition/injection				
Mot.no. →004356	07.93-06.98	GS,LLE	0 261 210 055	
Mot.no. →072236	07.93-06.98	AG,LLE	0 261 210 055	
Mot.no. 004357→	07.93-06.98	GS,LLE	0 261 210 122	
Mot.no. 072237→	07.93-06.98	AG,LLE	0 261 210 122	
Wheel speed sensor, front	07.93-06.98	LAB	0 265 001 284	
		RAB	0 265 001 282	
Wheel speed sensor, rear	07.93-06.98	AOS	0 265 002 210	
		ASR,LAB	0 265 002 206	
		ASR,RAB	0 265 002 204	
320 4MATIC [210]	3,2l 165 kW	M 112.941	6 Zyl.	
Throttle valve assembly	09.97-03.02		0 205 003 046	
Air mass meter, gasoline injection	09.97-03.02		0 280 217 515	
Phase sensor	09.97-03.02		0 232 103 050	
Speed sensor, ignition/injection				
Mot.no. →370998	09.97-03.02		0 261 210 141	
Mot.no. 370999→	09.97-03.02		0 261 210 170	
Knock sensor	09.97-03.02		0 261 231 110	
Pedal position sensor, EMS (electronic engine management)				
Fg.no. →A962231	09.97-03.02		0 205 001 302	
Duo sensor, acceleration and yaw rate, brake system				
Fg.no. B174000→,Comp. no. Code 800,	09.97-03.02		0 265 005 258	
Fg.no. X037894→				
Fg.no. →B173999,Comp. no. Code 801,	09.97-03.02		0 265 005 201	
Fg.no. →X044900				
Wheel speed sensor, front	09.97-03.02	LAB	0 265 006 358	
		RAB	0 265 006 356	
Wheel speed sensor, rear	09.97-03.02	LAB	0 265 006 178	
		RAB	0 265 006 194	
320 4MATIC [211]	3,2l 165 kW	M 112.954	6 Zyl.	
Throttle valve assembly	09.03-03.05		0 280 750 019	
Air mass meter, gasoline injection	09.03-03.05		0 280 217 515	
Phase sensor	09.03-03.05		0 232 103 050	
Speed sensor, ignition/injection	09.03-03.05		0 261 210 170	
Knock sensor	09.03-03.05		0 261 231 110	



◀ Serie E


Duo sensor, acceleration and yaw rate, brake system	09.03-03.05		0 265 005 258
Wheel speed sensor, rear	09.03-03.05		0 265 007 500
350 [211]	3,5l 200 kW M 272.964 6 Zyl.		
Throttle valve assembly	04.05→		0 280 750 017
Air mass meter, gasoline injection	04.05→		0 280 218 190
Phase sensor	04.05→	LAB	0 232 103 050
Knock sensor	04.05→		0 261 231 188
Duo sensor, acceleration and yaw rate, brake system	04.05→		0 265 005 298
Wheel speed sensor, front	04.05→		0 265 007 745
Wheel speed sensor, rear	04.05→		0 265 007 700
350 CGI [211]	3,5l 215 kW M 272.985 6 Zyl.		
Throttle valve assembly	12.07→		0 280 750 017
Air mass meter, gasoline injection	12.07→		0 280 218 190
Phase sensor	12.07→		0 232 103 050
Knock sensor	12.07→		0 261 231 188
Duo sensor, acceleration and yaw rate, brake system	12.07→		0 265 005 298
Wheel speed sensor, front	12.07→		0 265 007 745
Wheel speed sensor, rear	12.07→		0 265 007 700
350 4MATIC [211]	3,5l 200 kW M 272.972 6 Zyl.		
Throttle valve assembly	04.05→		0 280 750 017
Air mass meter, gasoline injection	04.05→		0 280 218 190
Phase sensor	04.05→	LAB	0 232 103 050
Knock sensor	04.05→		0 261 231 188
Duo sensor, acceleration and yaw rate, brake system	04.05→		0 265 005 298
Wheel speed sensor, front	04.05→		0 265 007 745
Wheel speed sensor, rear	04.05→		0 265 007 700
400 CDI [211]	4,0l 191 kW OM 628.961 8 Zyl.		
Speed sensor, diesel	02.03-04.05		0 261 210 170
High-pressure sensor (CR system)			
Mot.no. →40035995	02.03-04.05		0 281 002 498
Mot.no. 40035996→	02.03-04.05		0 281 002 700
Duo sensor, acceleration and yaw rate, brake system	02.03-04.05		0 265 005 258
Wheel speed sensor, front	02.03-04.05		0 265 007 499
Wheel speed sensor, rear	02.03-04.05		0 265 007 500
420 [124]	4,2l 205/210 kW M 119.975 8 Zyl.		
Air mass meter, gasoline injection	07.93-06.95		0 280 214 004
			0 986 280 121
Speed sensor, ignition/injection	07.93-06.95		0 261 210 085
Knock sensor	07.93-06.95		0 261 231 062
Temperature sensor, intake air, injection system	07.93-06.95		0 280 130 047
Wheel speed sensor, front			
Fg.no. C013141→	07.93-06.95	LAB	0 265 001 284
		RAB	0 265 001 282
Fg.no. →C013142	07.93-06.95	LAB	0 265 006 111
		RAB	0 265 006 109
Wheel speed sensor, rear	07.93-06.95	AOS	0 265 002 210
		ASR,LAB	0 265 002 238
		ASR,RAB	0 265 002 108
420 [210]	4,2l 205 kW M 119.985 8 Zyl.		
Throttle valve assembly	01.96-08.97		0 205 003 037
Air mass meter, gasoline injection	01.96-08.97		0 280 217 807
Phase sensor	01.96-08.97		0 232 103 037
Speed sensor, ignition/injection	01.96-08.97		0 281 002 123
Knock sensor	01.96-08.97		0 261 231 110
Pedal position sensor, EMS (electronic engine management)			
Fg.no. →A962231	01.96-08.97		0 205 001 302



Duo sensor, acceleration and yaw rate, brake system	01.96-08.97		0 265 005 201
Wheel speed sensor, front	01.96-08.97	LAB	0 265 006 190
		RAB	0 265 006 188
Wheel speed sensor, rear	01.96-08.97	LAB	0 265 006 178
		RAB	0 265 006 194
420 CDI [211]	4,0l 231 kW OM 629.910 8 Zyl.		
Phase sensor	09.05→		0 232 103 050
High-pressure sensor (CR system)	09.05→		0 281 002 504
Duo sensor, acceleration and yaw rate, brake system	09.05→		0 265 005 298
Wheel speed sensor, front	09.05→		0 265 007 745
Wheel speed sensor, rear	09.05→		0 265 007 700
430 [210]	4,3l 205 kW M 113.940 8 Zyl.		
Throttle valve assembly	09.97-08.00		0 205 003 048
	09.00-03.02		0 280 750 017
Air mass meter, gasoline injection	09.97-03.02		0 280 217 810
Phase sensor	09.97-03.02		0 232 103 050
Speed sensor, ignition/injection	09.97-03.02		0 261 210 170
Knock sensor	09.97-03.02		0 261 231 110
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. B174000→, Comp.no. Code 800,	09.97-03.02		0 265 005 258
Fg.no. X037894→			
Fg.no. →B173999, Comp.no. Code 801,	09.97-03.02		0 265 005 201
Fg.no. →X044900			
Wheel speed sensor, front	09.97-03.02	LAB	0 265 006 190
		RAB	0 265 006 188
Wheel speed sensor, rear	09.97-03.02	LAB	0 265 006 178
		RAB	0 265 006 194
430 4MATIC [210]	4,3l 205 kW M 113.940 8 Zyl.		
Throttle valve assembly	06.99-08.00		0 205 003 048
	09.00-03.02		0 280 750 017
Air mass meter, gasoline injection	06.99-03.02		0 280 217 810
Phase sensor	06.99-03.02		0 232 103 050
Speed sensor, ignition/injection	06.99-03.02		0 261 210 170
Knock sensor	06.99-03.02		0 261 231 110
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. B174000→, Comp.no. Code 800,	06.99-03.02		0 265 005 258
Fg.no. X037894→			
Fg.no. →B173999, Comp.no. Code 801,	06.99-03.02		0 265 005 201
Fg.no. →X044900			
Wheel speed sensor, front	06.99-03.02	LAB	0 265 006 358
		RAB	0 265 006 356
Wheel speed sensor, rear	06.99-03.02	LAB	0 265 006 178
		RAB	0 265 006 194
500 [124]	5,0l 235 kW M 119.974 8 Zyl.		
Air mass meter, gasoline injection	07.93-06.95		0 280 214 004
			0 986 280 121
Speed sensor, ignition/injection	07.93-06.95		0 261 210 085
Knock sensor	07.93-06.95		0 261 231 062
Temperature sensor, intake air, injection system	07.93-06.95		0 280 130 047
Wheel speed sensor, front			
Fg.no. C013141→	07.93-06.95	LAB	0 265 001 284
		RAB	0 265 001 282
Fg.no. →C013142	07.93-06.95	LAB	0 265 006 111
		RAB	0 265 006 109
Wheel speed sensor, rear	07.93-06.95	LAB	0 265 002 238
		RAB	0 265 002 108



M



Product					
500 [124]	5,0l 235-240 kW M 119.974 8 Zyl.				
Air mass meter, gasoline injection	07.93-06.95			0 280 214 004	
				0 986 280 121	
Speed sensor, ignition/injection	07.93-06.95			0 261 210 085	
Knock sensor	07.93-06.95			0 261 231 062	
Temperature sensor, intake air, injection system	07.93-06.95			0 280 130 047	
Acceleration sensor, ABS	07.93-05.94			0 265 005 107	
	06.94-06.95			0 265 005 107	
	07.93-05.94			0 265 005 107	
Wheel speed sensor, front					
Fg.no. C013141→	07.93-06.95	LAB		0 265 001 284	
		RAB		0 265 001 282	
Fg.no. →C013142	07.93-06.95	LAB		0 265 006 111	
		RAB		0 265 006 109	
Wheel speed sensor, rear	07.93-06.95	LAB		0 265 002 238	
		RAB		0 265 002 108	
500 [211]	5,0l 225 kW M 113.967 8 Zyl.				
Throttle valve assembly	03.02-03.06			0 280 750 017	
Air mass meter, gasoline injection	03.02-03.06			0 280 217 810	
Phase sensor	03.02-03.06			0 232 103 050	
Speed sensor, ignition/injection	03.02-03.06			0 261 210 170	
Knock sensor	03.02-03.06			0 261 231 110	
Duo sensor, acceleration and yaw rate, brake system	03.02-03.06			0 265 005 258	
Wheel speed sensor, front	03.02-03.06			0 265 007 499	
Wheel speed sensor, rear	03.02-03.06			0 265 007 500	
500 [211]	5,5l 285 kW M 273.960 8 Zyl.				
Throttle valve assembly	04.06→			0 280 750 184	
Air mass meter, gasoline injection	04.06→			0 280 218 190	
Phase sensor	04.06→	LAB		0 232 103 050	
Knock sensor	04.06→			0 261 231 188	
Duo sensor, acceleration and yaw rate, brake system	04.06→			0 265 005 298	
Wheel speed sensor, front	04.06→			0 265 007 745	
Wheel speed sensor, rear	04.06→			0 265 007 700	
500 4MATIC [211]	5,0l 225 kW M 113.969 8 Zyl.				
Throttle valve assembly	09.03-08.06			0 280 750 017	
Air mass meter, gasoline injection	09.03-08.06			0 280 217 810	
Phase sensor	09.03-08.06			0 232 103 050	
Speed sensor, ignition/injection	09.03-08.06			0 261 210 170	
Knock sensor	09.03-08.06			0 261 231 110	
Duo sensor, acceleration and yaw rate, brake system	09.03-08.06			0 265 005 258	
Wheel speed sensor, rear	09.03-08.06			0 265 007 500	
500 4MATIC [211]	5,5l 285 kW M 273.962 8 Zyl.				
Throttle valve assembly	09.06→			0 280 750 184	
Air mass meter, gasoline injection	09.06→			0 280 218 190	
Phase sensor	09.06→	LAB		0 232 103 050	
Knock sensor	09.06→			0 261 231 188	
Duo sensor, acceleration and yaw rate, brake system	09.06→			0 265 005 298	
Wheel speed sensor, front	09.06→			0 265 007 745	
Wheel speed sensor, rear	09.06→			0 265 007 700	

Serie E (T-Modell)

36 AMG T [124]	3,6l 195-200 kW M 104.992 6 Zyl.				
Air mass meter, gasoline injection	03.94-05.96			0 280 217 500	
Speed sensor, ignition/injection					
Mot.no. →004356	03.94-05.96	GS,LLE		0 261 210 055	
Mot.no. →072236	03.94-05.96	AG,LLE		0 261 210 055	
Mot.no. 004357→	03.94-05.96	GS,LLE		0 261 210 122	
Mot.no. 072237→	03.94-05.96	AG,LLE		0 261 210 122	



Wheel speed sensor, front					
Fg.no. F264121→	03.94-05.96	LAB		0 265 006 111	
		RAB		0 265 006 109	
Fg.no. →F264120	03.94-05.96	LAB		0 265 001 284	
		RAB		0 265 001 282	
Wheel speed sensor, rear	03.94-05.96	AOS		0 265 002 210	
		ASR,LAB		0 265 002 206	
		ASR,RAB		0 265 002 204	
55 AMG KOMPRESSOR T [211]	5,4l 350 kW M 113.990 8 Zyl.				
Throttle valve assembly	09.03-05.06			0 280 750 045	
Air mass meter, gasoline injection	09.03-05.06			0 280 217 810	
Phase sensor	09.03-05.06			0 232 103 050	
Speed sensor, ignition/injection	09.03-05.06			0 261 210 170	
Knock sensor	09.03-05.06			0 261 231 110	
Duo sensor, acceleration and yaw rate, brake system	09.03-05.06			0 265 005 258	
Wheel speed sensor, front	09.03-05.06			0 265 007 499	
Wheel speed sensor, rear	09.03-05.06			0 265 007 500	
55 AMG T [210]	5,5l 260 kW M 113.980 8 Zyl.				
Throttle valve assembly	03.98-08.00			0 205 003 048	
	09.00-01.03			0 280 750 017	
Air mass meter, gasoline injection	03.98-01.03			0 280 217 810	
Phase sensor	03.98-01.03			0 232 103 050	
Speed sensor, ignition/injection					
Mot.no. →002692	03.98-01.03			0 261 210 141	
Mot.no. 002693→	03.98-01.03			0 261 210 170	
Knock sensor	03.98-01.03			0 261 231 110	
Pedal position sensor, EMS (electronic engine management)					
Fg.no. →A962231	03.98-01.03			0 205 001 302	
Duo sensor, acceleration and yaw rate, brake system	03.98-01.03			0 265 005 201	
Pressure sensor, ESP, (electronic stability program)	06.00-01.03			0 265 005 303	
	07.99-05.00			0 265 005 307	
Wheel speed sensor, front	03.98-01.03	LAB		0 265 006 190	
		RAB		0 265 006 188	
Wheel speed sensor, rear	03.98-01.03	LAB		0 265 006 178	
		RAB		0 265 006 194	
63 AMG T [211]	6,2l 378 kW M 156.983 8 Zyl.				
Knock sensor	06.06→			0 261 231 188	
Duo sensor, acceleration and yaw rate, brake system	06.06→			0 265 005 298	
Wheel speed sensor, front	06.06→			0 265 007 745	
Wheel speed sensor, rear	06.06→			0 265 007 700	
200 CDI [211]	2,1l 100 kW OM 646.821 4 Zyl.				
Air mass meter, diesel	04.07→			0 281 002 535	
Speed sensor, diesel	04.07→			0 261 210 170	
Wheel speed sensor, front	04.07→			0 265 007 745	
Wheel speed sensor, rear	04.07→			0 265 007 700	
200 KOMPRESSOR T [210]	2,0l 120 kW M 111.957 4 Zyl.				
Throttle valve assembly	09.00-01.03			0 280 750 074	
Speed sensor, ignition/injection	09.00-01.03			0 261 210 170	
Duo sensor, acceleration and yaw rate, brake system	09.00-01.03			0 265 005 258	
Pressure sensor, ESP, (electronic stability program)	09.00-01.03			0 265 005 303	
Fg.no. →B 173367	09.00-01.03			0 265 005 307	
Wheel speed sensor, front	09.00-01.03	LAB		0 265 006 190	
		RAB		0 265 006 188	
Wheel speed sensor, rear	09.00-01.03	LAB		0 265 006 178	
		RAB		0 265 006 194	



Product

◀ Serie E (T-Modell)


200 KOMPRESSOR T [210]		2,0l 137 kW M 111.947 4 Zyl.	
Throttle valve assembly	09.97-01.03		0 205 003 044
Air mass meter, gasoline injection	09.97-01.03	FGK	0 280 217 114
		KUT	0 280 218 081
Speed sensor, ignition/injection			
Mot.no. →001935	09.97-01.03	AG	0 281 002 123
Mot.no. →001936	09.97-01.03	AG	0 261 210 170
Mot.no. →005503	09.97-01.03	GS	0 281 002 123
Mot.no. →005504	09.97-01.03	GS	0 261 210 170
Duo sensor, acceleration and yaw rate, brake system	09.97-01.03		0 265 005 201
Wheel speed sensor, front	09.97-01.03	LAB	0 265 006 190
		RAB	0 265 006 188
Wheel speed sensor, rear	09.97-01.03	LAB	0 265 006 178
		RAB	0 265 006 194
200 KOMPRESSOR T [211]		1,8l 120 kW M 271.941 4 Zyl.	
Throttle valve assembly	02.03-03.06		0 280 750 076
Phase sensor	02.03-03.06	AUS,NOC	0 232 103 037
		EIN,NOC	0 232 103 050
Speed sensor, ignition/injection	02.03-03.06		0 261 210 170
Duo sensor, acceleration and yaw rate, brake system	02.03-03.06		0 265 005 258
Wheel speed sensor, front	02.03-03.06		0 265 007 499
Wheel speed sensor, rear	02.03-03.06		0 265 007 500
200 KOMPRESSOR T [211]		1,8l 135 kW M 271.956 4 Zyl.	
Throttle valve assembly	04.06→		0 280 750 076
Phase sensor	04.06→		0 232 103 037
Speed sensor, ignition/injection	04.06→		0 261 210 170
Duo sensor, acceleration and yaw rate, brake system	04.06→		0 265 005 298
Wheel speed sensor, front	04.06→		0 265 007 745
Wheel speed sensor, rear	04.06→		0 265 007 700
200 T [124]		2,0l 100 kW M 111.940 4 Zyl.	
Speed sensor, ignition/injection	07.93-05.96		0 261 210 055
Wheel speed sensor, front Fg.no. F264121→	07.93-05.96	LAB	0 265 006 111
		RAB	0 265 006 109
Fg.no. →F264120	07.93-05.96	LAB	0 265 001 284
		RAB	0 265 001 282
Wheel speed sensor, rear Fg.no. F005650→	07.93-05.96		0 265 002 208
200 T [210]		2,0l 100 kW M 111.942 4 Zyl.	
Air mass meter, gasoline injection	05.96-01.03	FGK	0 280 217 114
		KUT	0 280 218 081
Speed sensor, ignition/injection			
Mot.no. 055850 →	05.96-06.99	AG	0 261 210 170
Mot.no. 057355 →	05.96-06.99	GS	0 261 210 170
Mot.no. →055849	05.96-06.99	AG	0 281 002 123
Mot.no. →057354	05.96-06.99	GS	0 281 002 123
Duo sensor, acceleration and yaw rate, brake system	05.96-01.03		0 265 005 201
Pressure sensor, ESP, (electronic stability program)	07.99-01.03		0 265 005 303
Fg.no. →B 173367	07.99-01.03		0 265 005 307
Wheel speed sensor, front	05.96-01.03	LAB	0 265 006 190
		RAB	0 265 006 188
Wheel speed sensor, rear	05.96-01.03	LAB	0 265 006 178
		RAB	0 265 006 194
220 CDIT [210]		2,1l 105 kW OM 611.961 4 Zyl.	
Air mass meter, diesel	07.99-08.99		0 281 002 152
Pulse generator, diesel	07.99-08.99		0 281 002 123
Speed sensor, diesel	09.99-01.03		0 261 210 170
High-pressure sensor (CR system)	07.99-01.03		0 281 002 498
Duo sensor, acceleration and yaw rate, brake system	07.99-01.03		0 265 005 258

Product

Pressure sensor, ESP, (electronic stability program)	07.99-01.03		0 265 005 303
Wheel speed sensor, front	07.99-01.03	LAB	0 265 006 190
		RAB	0 265 006 188
Wheel speed sensor, rear	07.99-01.03	LAB	0 265 006 178
		RAB	0 265 006 194
220 CDIT [210]		2,2l 92 kW OM 611.961	4 Zyl.
Air mass meter, diesel	07.98-06.99		0 281 002 152
Pulse generator, diesel	07.98-06.99		0 281 002 123
High-pressure sensor (CR system)	07.98-06.99		0 281 002 498
Duo sensor, acceleration and yaw rate, brake system	07.98-06.99		0 265 005 258
Wheel speed sensor, front	07.98-06.99	LAB	0 265 006 190
		RAB	0 265 006 188
Wheel speed sensor, rear	07.98-06.99	LAB	0 265 006 178
		RAB	0 265 006 194
220 CDIT [211]		2,1l 100/110 kW OM 646.961	4 Zyl.
Air mass meter, diesel	02.03→		0 281 002 535
Speed sensor, diesel	02.03→		0 261 210 170
High-pressure sensor (CR system)	02.03→		0 281 002 504
Duo sensor, acceleration and yaw rate, brake system	02.03→		0 265 005 258
Wheel speed sensor, front	02.03→		0 265 007 499
Wheel speed sensor, rear	02.03→		0 265 007 500
220 CDIT [211]		2,1l 125 kW OM 646.821	4 Zyl.
Air mass meter, diesel	04.06→		0 281 002 535
Speed sensor, diesel	04.06→		0 261 210 170
Duo sensor, acceleration and yaw rate, brake system	04.06→		0 265 005 298
Wheel speed sensor, front	04.06→		0 265 007 745
Wheel speed sensor, rear	04.06→		0 265 007 700
220 T [124]		2,2l 110 kW M 111.960	4 Zyl.
Air mass meter, gasoline injection	07.93-05.96		0 280 217 100
Speed sensor, ignition/injection			
Mot.no. →079783	07.93-05.96	AG,LLE	0 261 210 055
Mot.no. →080036	07.93-05.96	GS,LLE	0 261 210 055
Mot.no. 079784→	07.93-05.96	GS,LLE	0 261 210 122
Mot.no. 080037→	07.93-05.96	AG,LLE	0 261 210 122
Knock sensor			
Mot.no. →079783	07.93-05.96	AG	0 261 231 098
Mot.no. →080036	07.93-05.96	GS	0 261 231 098
Wheel speed sensor, front			
Fg.no. F264121→	07.93-05.96	LAB	0 265 006 111
		RAB	0 265 006 109
Fg.no. →F264120	07.93-05.96	LAB	0 265 001 284
		RAB	0 265 001 282
Wheel speed sensor, rear			
Fg.no. F005650→	07.93-05.96		0 265 002 208
230 [211]		2,5l 150 kW M 272.922	6 Zyl.
Air mass meter, gasoline injection	09.07→		0 280 218 190
Phase sensor	09.07→	LAB	0 232 103 050
Knock sensor	09.07→		0 261 231 188
Duo sensor, acceleration and yaw rate, brake system	09.07→		0 265 005 298
Wheel speed sensor, front	09.07→		0 265 007 745
Wheel speed sensor, rear	09.07→		0 265 007 700
230 T [210]		2,3l 110 kW M 111.970	4 Zyl.
Air mass meter, gasoline injection			
Mot.no. →013233	05.96-08.97	GS	0 280 217 100
Mot.no. →042470	05.96-08.97	AG	0 280 217 100
Mot.no. 013234→	05.96-08.97	GS,KAT	0 280 217 114
		GS,KUT	0 280 218 081
Mot.no. 042471→	05.96-08.97	AG,KAT	0 280 217 114
		AG,KUT	0 280 218 081



Speed sensor, ignition/injection	05.96-08.97		0 281 002 123
Duo sensor, acceleration and yaw rate, brake system	05.96-08.97		0 265 005 258
Wheel speed sensor, front	05.96-08.97	LAB	0 265 006 190
		RAB	0 265 006 188
Wheel speed sensor, rear	05.96-08.97	LAB	0 265 006 178
		RAB	0 265 006 194
240 T [210]	2,4 l 125 kW M 112.911 6 Zyl.		
Throttle valve assembly	09.97-01.03		0 205 003 046
Air mass meter, gasoline injection	09.97-01.03		0 280 217 515
Phase sensor	09.97-01.03		0 232 103 037
Speed sensor, ignition/injection			
Mot.no. →370998	09.97-01.03		0 261 210 141
Mot.no. 370999→	09.97-01.03		0 261 210 170
Knock sensor	09.97-01.03		0 261 231 110
Duo sensor, acceleration and yaw rate, brake system	09.97-01.03		0 265 005 201
Pressure sensor, ESP, (electronic stability program)	07.99-01.03		0 265 005 303
Fg.no. →B 173367	07.99-01.03		0 265 005 307
Wheel speed sensor, front	09.97-01.03	LAB	0 265 006 190
		RAB	0 265 006 188
Wheel speed sensor, rear	09.97-01.03	LAB	0 265 006 178
		RAB	0 265 006 194
240 T [210]	2,6 l 125 kW M 112.914 6 Zyl.		
Throttle valve assembly	06.99-01.03		0 280 750 019
Air mass meter, gasoline injection	06.99-01.03		0 280 217 515
Phase sensor	06.99-01.03		0 232 103 050
Speed sensor, ignition/injection	06.99-01.03		0 261 210 170
Knock sensor	06.99-01.03		0 261 231 110
Duo sensor, acceleration and yaw rate, brake system	06.99-01.03		0 265 005 258
Wheel speed sensor, front	06.99-01.03	LAB	0 265 006 190
		RAB	0 265 006 188
Wheel speed sensor, rear	06.99-01.03	LAB	0 265 006 178
		RAB	0 265 006 194
240 T [211]	2,6 l 130 kW M 112.913 6 Zyl.		
Throttle valve assembly	02.03-03.05		0 280 750 019
Air mass meter, gasoline injection	02.03-03.05		0 280 217 515
Phase sensor	02.03-03.05		0 232 103 050
Speed sensor, ignition/injection	02.03-03.05		0 261 210 170
Knock sensor	02.03-03.05		0 261 231 110
Duo sensor, acceleration and yaw rate, brake system	02.03-03.05		0 265 005 258
Wheel speed sensor, front	02.03-03.05		0 265 007 499
Wheel speed sensor, rear	02.03-03.05		0 265 007 500
240 4MATIC T [211]	2,6 l 130 kW M 112.917 6 Zyl.		
Throttle valve assembly	09.03→		0 280 750 019
Air mass meter, gasoline injection	09.03→		0 280 217 515
Phase sensor	09.03→		0 232 103 050
Speed sensor, ignition/injection	09.03→		0 261 210 170
Knock sensor	09.03→		0 261 231 110
Duo sensor, acceleration and yaw rate, brake system	09.03→		0 265 005 258
Wheel speed sensor, rear	09.03→		0 265 007 500
250 DT [124]	2,5 l 83 kW OM 605.911 5 Zyl.		
Wheel speed sensor, front	07.93-05.96	LAB	0 265 006 111
		RAB	0 265 006 109
Wheel speed sensor, rear			
Fg.no. F005650→	07.93-05.96		0 265 002 208
250 DT [210]	2,5 l 83 kW OM 605.912 5 Zyl.		
Pulse generator, diesel	05.96-06.98		0 281 002 123
Pedal position sensor, diesel	05.96-06.98		0 205 001 029



Wheel speed sensor, front	05.96-06.98	LAB	0 265 006 190
		RAB	0 265 006 188
Wheel speed sensor, rear	05.96-06.98	LAB	0 265 006 178
		RAB	0 265 006 194
250 D Turbo T [124]	2,5 l 93 kW OM 602.962 5 Zyl.		
Wheel speed sensor, front	07.93-06.95	LAB	0 265 006 111
		RAB	0 265 006 109
Wheel speed sensor, rear			
Fg.no. F005650→	07.93-06.95		0 265 002 208
250 D Turbo T [210]	2,5 l 110 kW OM 605.962 5 Zyl.		
Pulse generator, diesel	09.97-08.99		0 281 002 123
Pedal position sensor, diesel	09.97-08.99		0 205 001 029
Wheel speed sensor, front	09.97-08.99	LAB	0 265 006 190
		RAB	0 265 006 188
Wheel speed sensor, rear	09.97-08.99	LAB	0 265 006 178
		RAB	0 265 006 194
270 CDI T [210]	2,7 l 125 kW OM 612.961 5 Zyl.		
Speed sensor, diesel	06.99-01.03		0 261 210 170
High-pressure sensor (CR system)			
Mot.no. →287865	06.99-01.03		0 281 002 498
Mot.no. 287866→	06.99-01.03		0 281 002 700
Duo sensor, acceleration and yaw rate, brake system	06.99-01.03		0 265 005 258
Pressure sensor, ESP, (electronic stability program)	06.99-01.03		0 265 005 303
Wheel speed sensor, front	06.99-01.03	LAB	0 265 006 190
		RAB	0 265 006 188
Wheel speed sensor, rear	06.99-01.03	LAB	0 265 006 178
		RAB	0 265 006 194
270 CDI T [211]	2,7 l 130 kW OM 647.961 5 Zyl.		
Air mass meter, diesel	02.03-03.05		0 281 002 535
Speed sensor, diesel	02.03-03.05		0 261 210 170
High-pressure sensor (CR system)	02.03-03.05		0 281 002 504
Duo sensor, acceleration and yaw rate, brake system	02.03-03.05		0 265 005 258
Wheel speed sensor, front	02.03-03.05		0 265 007 499
Wheel speed sensor, rear	02.03-03.05		0 265 007 500
280 CDI T [211]	3,0 l 140 kW OM 642.920 6 Zyl.		
High-pressure sensor (CR system)	04.05→		0 281 002 504
Duo sensor, acceleration and yaw rate, brake system	04.05→		0 265 005 298
Wheel speed sensor, front	04.05→		0 265 007 745
Wheel speed sensor, rear	04.05→		0 265 007 700
280 CDI T [211]	3,2 l 130 kW OM 648.961 6 Zyl.		
Air mass meter, diesel	04.04-03.05		0 281 002 535
Speed sensor, diesel	04.04-03.05		0 261 210 170
High-pressure sensor (CR system)	04.04-03.05		0 281 002 504
Duo sensor, acceleration and yaw rate, brake system	04.04-03.05		0 265 005 258
Wheel speed sensor, front	04.04-03.05		0 265 007 499
Wheel speed sensor, rear	04.04-03.05		0 265 007 700
280 CDI 4MATIC T [211]	3,0 l 140 kW OM 642.921 6 Zyl.		
High-pressure sensor (CR system)	04.05→		0 281 002 504
Duo sensor, acceleration and yaw rate, brake system	04.05→		0 265 005 298
Wheel speed sensor, front	04.05→		0 265 007 745
Wheel speed sensor, rear	04.05→		0 265 007 700
280 T [124]	2,8 l 142-145 kW M 104.942 6 Zyl.		
Air mass meter, gasoline injection	07.93-05.96		0 280 217 500
Speed sensor, ignition/injection			
Mot.no. →005789	07.93-05.96	GS, LLE	0 261 210 055
		GS, RLE	0 261 210 066
Mot.no. →048696	07.93-05.96	AG, LLE	0 261 210 055
		AG, RLE	0 261 210 066



◀ Serie E (T-Modell)

Speed sensor, ignition/injection			
Mot.no. 005790→	07.93-05.96	GS	0 261 210 122
Mot.no. 048697→	07.93-05.96	AG	0 261 210 122
Wheel speed sensor, front			
Fg.no. F264121→	07.93-05.96	LAB	0 265 006 111
		RAB	0 265 006 109
Fg.no. →F264120	07.93-05.96	LAB	0 265 001 284
		RAB	0 265 001 282
Wheel speed sensor, rear			
	07.93-05.96	AOS	0 265 002 210
		ASR,LAB	0 265 002 206
		ASR,RAB	0 265 002 204
280 T [210] 2,8l 150 kW M 112.921 6 Zyl.			
Throttle valve assembly			
	07.96-08.00		0 205 003 046
	09.00-01.03		0 280 750 019
Air mass meter, gasoline injection	07.96-01.03		0 280 217 515
Phase sensor	07.96-01.03		0 232 103 037
Speed sensor, ignition/injection			
Mot.no. →370998	07.96-01.03		0 261 210 141
Mot.no. 370999→	07.96-01.03		0 261 210 170
Knock sensor	07.96-01.03		0 261 231 110
Duo sensor, acceleration and yaw rate, brake system	07.96-01.03		0 265 005 201
Pressure sensor, ESP, (electronic stability program)	07.96-01.03		0 265 005 307
Wheel speed sensor, front			
	07.96-01.03	LAB	0 265 006 190
		RAB	0 265 006 188
Wheel speed sensor, rear			
	07.96-01.03	LAB	0 265 006 178
		RAB	0 265 006 194
280 T [211] 3,0l 170 kW M 272.943 6 Zyl.			
Throttle valve assembly			
	04.05→		0 280 750 017
Air mass meter, gasoline injection	04.05→		0 280 218 190
Phase sensor	04.05→	LAB	0 232 103 050
Knock sensor	04.05→		0 261 231 188
Duo sensor, acceleration and yaw rate, brake system	04.05→		0 265 005 298
Wheel speed sensor, front			
	04.05→		0 265 007 745
Wheel speed sensor, rear			
	04.05→		0 265 007 700
280 4MATIC T [210] 2,8l 150 kW M 112.921 6 Zyl.			
Throttle valve assembly			
	03.97-08.00		0 205 003 046
	09.00-01.03		0 280 750 019
Air mass meter, gasoline injection	03.97-01.03		0 280 217 515
Phase sensor	03.97-01.03		0 232 103 037
Speed sensor, ignition/injection			
Mot.no. →370998	03.97-01.03		0 261 210 141
Mot.no. 370999→	03.97-01.03		0 261 210 170
Knock sensor	03.97-01.03		0 261 231 110
Pedal position sensor, EMS (electronic engine management)			
Fg.no. →A962231	03.97-01.03		0 205 001 302
Duo sensor, acceleration and yaw rate, brake system			
	03.97-01.03		0 265 005 201
Wheel speed sensor, front			
	03.97-01.03	LAB	0 265 006 358
		RAB	0 265 006 356
Wheel speed sensor, rear			
	03.97-01.03	LAB	0 265 006 178
		RAB	0 265 006 194
280 4MATIC T [211] 3,0l 170 kW M 272.944 6 Zyl.			
Throttle valve assembly			
	04.05→		0 280 750 017
Air mass meter, gasoline injection	04.05→		0 280 218 190
Phase sensor	04.05→	LAB	0 232 103 050
Knock sensor	04.05→		0 261 231 188
Duo sensor, acceleration and yaw rate, brake system	04.05→		0 265 005 298
Wheel speed sensor, front			
	04.05→		0 265 007 745
Wheel speed sensor, rear			
	04.05→		0 265 007 700



290 D Turbo T [210] 2,9l 95 kW OM 602.982 5 Zyl.			
Air mass meter, diesel			
	05.96-06.99		0 280 217 509
Pulse generator, diesel			
	05.96-06.99		0 281 002 123
Pedal position sensor, diesel			
	05.96-06.99		0 205 001 029
Wheel speed sensor, front			
	05.96-06.99	LAB	0 265 006 190
		RAB	0 265 006 188
Wheel speed sensor, rear			
	05.96-06.99	LAB	0 265 006 178
		RAB	0 265 006 194
300 D T [124] 3,0l 100 kW OM 606.910 6 Zyl.			
Wheel speed sensor, front			
	07.93-05.96	LAB	0 265 006 111
		RAB	0 265 006 109
Wheel speed sensor, rear			
Fg.no. F005650→	07.93-05.96		0 265 002 208
300 D Turbo T [124] 3,0l 105-108 kW OM 603.960 6 Zyl.			
Wheel speed sensor, front			
	07.93-05.96	LAB	0 265 006 111
		RAB	0 265 006 109
Wheel speed sensor, rear			
Fg.no. F005650→	07.93-05.96		0 265 002 208
300 D Turbo T [210] 3,0l 130 kW OM 606.962 6 Zyl.			
Air mass meter, diesel			
	03.97-06.99		0 281 002 152
Pulse generator, diesel			
	03.97-06.99		0 281 002 123
Pedal position sensor, diesel			
	03.97-06.99		0 205 001 029
Duo sensor, acceleration and yaw rate, brake system			
	03.97-06.99		0 265 005 201
Wheel speed sensor, front			
	03.97-06.99	LAB	0 265 006 190
		RAB	0 265 006 188
Wheel speed sensor, rear			
	03.97-06.99	LAB	0 265 006 178
		RAB	0 265 006 194
300 D Turbo 4MATIC T [124] 3,0l 105-108 kW OM 603.963 6 Zyl.			
Air flow sensor, diesel			
	07.93-05.96		0 281 002 024
			0 281 002 028
Temperature sensor, coolant, diesel			
	07.93-05.96		0 280 130 035
Wheel speed sensor, front			
Fg.no. F128718→	07.93-05.96	LAB	0 265 001 300
		RAB	0 265 001 298
Fg.no. →F128717	07.93-05.96	LAB	0 265 001 400
		RAB	0 265 001 398
Wheel speed sensor, rear			
Fg.no. F005650→	07.93-05.96		0 265 002 208
300 4MATIC T [124] 3,0l 132 kW M 103.985 6 Zyl.			
Air flow sensor, gasoline injection			
	07.93-06.95		0 438 121 033
			0 986 439 333
Speed sensor, ignition/injection			
	07.93-06.95		0 261 210 051
Temperature sensor, intake air, injection system			
	07.93-06.95		0 280 130 047
Temperature sensor, coolant, injection system			
Mot.no. →002187	07.93-06.95	2PO,GS	0 280 130 044
Mot.no. →008267	07.93-06.95	2PO,AG	0 280 130 044
Wheel speed sensor, front			
Fg.no. F128718→	07.93-06.95	LAB	0 265 001 300
		RAB	0 265 001 298
Fg.no. →F128717	07.93-06.95	LAB	0 265 001 400
		RAB	0 265 001 398
Wheel speed sensor, rear			
Fg.no. F005650→	07.93-06.95		0 265 002 208
320 CDIT [210] 3,2l 145 kW OM 613.961 6 Zyl.			
Speed sensor, diesel			
	07.99-01.03		0 261 210 170
High-pressure sensor (CR system)			
	07.99-01.03		0 281 002 498
Duo sensor, acceleration and yaw rate, brake system			
	07.99-01.03		0 265 005 258
Pressure sensor, ESP, (electronic stability program)			
	07.99-01.03		0 265 005 303
Wheel speed sensor, front			
	07.99-01.03	LAB	0 265 006 190
		RAB	0 265 006 188



Wheel speed sensor, rear	07.99-01.03	LAB	0 265 006 178
		RAB	0 265 006 194
320 CDIT [211]	3,0l 165 kW OM 642.920	6 Zyl.	
High-pressure sensor (CR system)	04.05→		0 281 002 504
Duo sensor, acceleration and yaw rate, brake system	04.05→		0 265 005 298
Wheel speed sensor, front	04.05→		0 265 007 745
Wheel speed sensor, rear	04.05→		0 265 007 700
320 CDIT [211]	3,2l 150 kW OM 648.961	6 Zyl.	
Air mass meter, diesel	02.03-03.05		0 281 002 535
Speed sensor, diesel	02.03-03.05		0 261 210 170
High-pressure sensor (CR system)	02.03-03.05		0 281 002 504
Duo sensor, acceleration and yaw rate, brake system	02.03-03.05		0 265 005 258
Wheel speed sensor, front	02.03-03.05		0 265 007 499
Wheel speed sensor, rear	02.03-03.05		0 265 007 500
320 CDI 4MATIC T [211]	3,0l 165 kW OM 642.921	6 Zyl.	
High-pressure sensor (CR system)	04.05→		0 281 002 504
Duo sensor, acceleration and yaw rate, brake system	04.05→		0 265 005 298
Wheel speed sensor, front	04.05→		0 265 007 745
Wheel speed sensor, rear	04.05→		0 265 007 700
320 T [124]	3,2l 162 kW M 104.992	6 Zyl.	
Air mass meter, gasoline injection	07.93-05.96		0 280 217 500
Speed sensor, ignition/injection			
Mot.no. →004356	07.93-05.96	GS,LLE	0 261 210 055
Mot.no. →072236	07.93-05.96	AG,LLE	0 261 210 055
Mot.no. 004357→	07.93-05.96	GS,LLE	0 261 210 122
Mot.no. 072237→	07.93-05.96	AG,LLE	0 261 210 122
Wheel speed sensor, front			
Fg.no. F264121→	07.93-05.96	LAB	0 265 006 111
		RAB	0 265 006 109
Fg.no. →F264120	07.93-05.96	LAB	0 265 001 284
		RAB	0 265 001 282
Wheel speed sensor, rear	07.93-05.96	AOS	0 265 002 210
		ASR,LAB	0 265 002 206
		ASR,RAB	0 265 002 204
320 T [210]	3,2l 165 kW M 112.941	6 Zyl.	
Throttle valve assembly	03.97-01.03		0 205 003 046
Air mass meter, gasoline injection	03.97-01.03		0 280 217 515
Phase sensor	03.97-01.03		0 232 103 050
Speed sensor, ignition/injection			
Mot.no. →370998	03.97-01.03		0 261 210 141
Mot.no. 370999→	03.97-01.03		0 261 210 170
Knock sensor	03.97-01.03		0 261 231 110
Pedal position sensor, EMS (electronic engine management)			
Fg.no. →A962231	03.97-01.03		0 205 001 302
Duo sensor, acceleration and yaw rate, brake system	03.97-01.03		0 265 005 201
Wheel speed sensor, front	03.97-01.03	LAB	0 265 006 190
		RAB	0 265 006 188
Wheel speed sensor, rear	03.97-01.03	LAB	0 265 006 178
		RAB	0 265 006 194
320 T [211]	3,2l 165 kW M 112.949	6 Zyl.	
Throttle valve assembly	02.03-03.05		0 280 750 019
Air mass meter, gasoline injection	02.03-03.05		0 280 217 515
Phase sensor	02.03-03.05		0 232 103 050
Speed sensor, ignition/injection	02.03-03.05		0 261 210 170
Knock sensor	02.03-03.05		0 261 231 110
Duo sensor, acceleration and yaw rate, brake system	02.03-03.05		0 265 005 258



Wheel speed sensor, front	02.03-03.05		0 265 007 499
Wheel speed sensor, rear	02.03-03.05		0 265 007 500
320 4MATIC T [210]	3,2l 165 kW M 112.941	6 Zyl.	
Throttle valve assembly	06.97-02.01		0 205 003 046
Air mass meter, gasoline injection	06.97-02.01		0 280 217 515
Phase sensor	06.97-02.01		0 232 103 050
Speed sensor, ignition/injection			
Mot.no. →370998	06.97-02.01		0 261 210 141
Mot.no. 370999→	06.97-02.01		0 261 210 170
Knock sensor	06.97-02.01		0 261 231 110
Pedal position sensor, EMS (electronic engine management)			
Fg.no. →A962231	06.97-02.01		0 205 001 302
Duo sensor, acceleration and yaw rate, brake system	06.97-02.01		0 265 005 201
Wheel speed sensor, front	06.97-02.01	LAB	0 265 006 358
		RAB	0 265 006 356
Wheel speed sensor, rear	06.97-02.01	LAB	0 265 006 178
		RAB	0 265 006 194
320 4MATIC T [211]	3,2l 165 kW M 112.954	6 Zyl.	
Throttle valve assembly	09.03-03.05		0 280 750 019
Air mass meter, gasoline injection	09.03-03.05		0 280 217 515
Phase sensor	09.03-03.05		0 232 103 050
Speed sensor, ignition/injection	09.03-03.05		0 261 210 170
Knock sensor	09.03-03.05		0 261 231 110
Duo sensor, acceleration and yaw rate, brake system	09.03-03.05		0 265 005 258
Wheel speed sensor, rear	09.03-03.05		0 265 007 500
350 CGI [211]	3,5l 215 kW M 272.985	6 Zyl.	
Throttle valve assembly	12.07→		0 280 750 017
Air mass meter, gasoline injection	12.07→		0 280 218 190
Phase sensor	12.07→		0 232 103 050
Knock sensor	12.07→		0 261 231 188
Duo sensor, acceleration and yaw rate, brake system	12.07→		0 265 005 298
Wheel speed sensor, front	12.07→		0 265 007 745
Wheel speed sensor, rear	12.07→		0 265 007 700
350 T [211]	3,5l 200 kW M 272.964	6 Zyl.	
Throttle valve assembly	04.05→		0 280 750 017
Air mass meter, gasoline injection	04.05→		0 280 218 190
Phase sensor	04.05→	LAB	0 232 103 050
Knock sensor	04.05→		0 261 231 188
Duo sensor, acceleration and yaw rate, brake system	04.05→		0 265 005 298
Wheel speed sensor, front	04.05→		0 265 007 745
Wheel speed sensor, rear	04.05→		0 265 007 700
350 4MATIC T [211]	3,5l 200 kW M 272.972	6 Zyl.	
Throttle valve assembly	04.05→		0 280 750 017
Air mass meter, gasoline injection	04.05→		0 280 218 190
Phase sensor	04.05→	LAB	0 232 103 050
Knock sensor	04.05→		0 261 231 188
Duo sensor, acceleration and yaw rate, brake system	04.05→		0 265 005 298
Wheel speed sensor, front	04.05→		0 265 007 745
Wheel speed sensor, rear	04.05→		0 265 007 700
420 T [210]	4,2l 205 kW M 119.985	8 Zyl.	
Throttle valve assembly	05.96-08.97		0 205 003 037
Air mass meter, gasoline injection	05.96-08.97		0 280 217 807
Phase sensor	05.96-08.97		0 232 103 037
Speed sensor, ignition/injection	05.96-08.97		0 281 002 123
Knock sensor	05.96-08.97		0 261 231 110

Product				

◀ Serie E (T-Modell)

Pedal position sensor, EMS (electronic engine management)			
Fg.no. →A962231	05.96-08.97		0 205 001 302
Duo sensor, acceleration and yaw rate, brake system	05.96-08.97		0 265 005 201
Wheel speed sensor, front	05.96-08.97	LAB	0 265 006 190
		RAB	0 265 006 188
Wheel speed sensor, rear	05.96-08.97	LAB	0 265 006 178
		RAB	0 265 006 194
430 T [210]	4,3l	205 kW	M 113.940 8 Zyl.
Throttle valve assembly	09.97-08.00		0 205 003 048
	09.00-01.03		0 280 750 017
Air mass meter, gasoline injection	09.97-01.03		0 280 217 810
Phase sensor	09.97-01.03		0 232 103 050
Speed sensor, ignition/injection	09.97-01.03		0 261 210 170
Knock sensor	09.97-01.03		0 261 231 110
Duo sensor, acceleration and yaw rate, brake system	09.97-01.03		0 265 005 201
Wheel speed sensor, front	09.97-01.03	LAB	0 265 006 190
		RAB	0 265 006 188
Wheel speed sensor, rear	09.97-01.03	LAB	0 265 006 178
		RAB	0 265 006 194
430 4MATIC T [210]	4,3l	205 kW	M 113.940 8 Zyl.
Throttle valve assembly	06.97-08.00		0 205 003 048
	09.00-01.03		0 280 750 017
Air mass meter, gasoline injection	06.97-01.03		0 280 217 810
Phase sensor	06.97-01.03		0 232 103 050
Speed sensor, ignition/injection	06.97-01.03		0 261 210 170
Knock sensor	06.97-01.03		0 261 231 110
Duo sensor, acceleration and yaw rate, brake system	06.97-01.03		0 265 005 201
Pressure sensor, ESP, (electronic stability program)	06.97-01.03		0 265 005 303
Fg.no. →B 173367	06.97-01.03		0 265 005 307
Wheel speed sensor, front	06.97-01.03	LAB	0 265 006 358
		RAB	0 265 006 356
Wheel speed sensor, rear	06.97-01.03	LAB	0 265 006 178
		RAB	0 265 006 194
500 T [211]	5,0l	225 kW	M 113.967 8 Zyl.
Throttle valve assembly	09.03-03.06		0 280 750 017
Air mass meter, gasoline injection	09.03-03.06		0 280 217 810
Phase sensor	09.03-03.06		0 232 103 050
Speed sensor, ignition/injection	09.03-03.06		0 261 210 170
Knock sensor	09.03-03.06		0 261 231 110
Duo sensor, acceleration and yaw rate, brake system	09.03-03.06		0 265 005 258
Wheel speed sensor, front	09.03-03.06		0 265 007 499
Wheel speed sensor, rear	09.03-03.06		0 265 007 500
500 T [211]	5,5l	285 kW	M 273.960 8 Zyl.
Throttle valve assembly	04.06→		0 280 750 184
Air mass meter, gasoline injection	04.06→		0 280 218 190
Phase sensor	04.06→	LAB	0 232 103 050
Knock sensor	04.06→		0 261 231 188
Duo sensor, acceleration and yaw rate, brake system	04.06→		0 265 005 298
Wheel speed sensor, front	04.06→		0 265 007 745
Wheel speed sensor, rear	04.06→		0 265 007 700
500 4MATIC T [211]	5,0l	225 kW	M 113.969 8 Zyl.
Throttle valve assembly	09.03-08.06		0 280 750 017
Air mass meter, gasoline injection	09.03-08.06		0 280 217 810
Phase sensor	09.03-08.06		0 232 103 050
Speed sensor, ignition/injection	09.03-08.06		0 261 210 170
Knock sensor	09.03-08.06		0 261 231 110

Product				

Duo sensor, acceleration and yaw rate, brake system	09.03-08.06		0 265 005 258
Wheel speed sensor, rear	09.03-08.06		0 265 007 500
500 4MATIC T [211]	5,5l	285 kW	M 273.962 8 Zyl.
Throttle valve assembly	09.06→		0 280 750 184
Air mass meter, gasoline injection	09.06→		0 280 218 190
Phase sensor	09.06→	LAB	0 232 103 050
Knock sensor	09.06→		0 261 231 188
Duo sensor, acceleration and yaw rate, brake system	09.06→		0 265 005 298
Wheel speed sensor, front	09.06→		0 265 007 745
Wheel speed sensor, rear	09.06→		0 265 007 700

Serie G

55 AMG [463]	5,4l	260 kW	M 113.982 8 Zyl.
Throttle valve assembly	04.99-03.04		0 280 750 017
Phase sensor	04.99-03.04	NOC	0 232 103 050
Speed sensor, ignition/injection	04.99-03.04	FKW	0 261 210 170
Duo sensor, acceleration and yaw rate, brake system	04.99-03.04		0 265 005 258
Wheel speed sensor, front	04.99-03.04		0 265 002 262
55 AMG KOMPRESSOR [463]	5,4l	350-368 kW	M 113.993 8 Zyl.
Air mass meter, gasoline injection	04.04→		0 280 217 810
Phase sensor	04.04→	NOC	0 232 103 050
Speed sensor, ignition/injection	04.04→	FKW	0 261 210 170
Knock sensor	04.04→		0 261 231 110
Duo sensor, acceleration and yaw rate, brake system	04.04→		0 265 005 258
200 GE [463]	2,0l	80 kW	M 102.965 4 Zyl.
Air flow sensor, gasoline injection	01.90-07.93	KAT	0 438 121 043
			0 986 439 343
Speed sensor, ignition/injection	01.90-07.93		0 261 210 066
Temperature sensor, intake air, injection system	01.90-07.93		0 280 130 047
Acceleration sensor, ABS	01.90-07.93		0 265 002 230
Wheel speed sensor, rear			
Fg.no. →082464	01.90-07.93	LAB	0 265 001 292
		RAB	0 265 001 290
230 [463]	2,3l	93 kW	M 102.989 4 Zyl.
Air flow sensor, gasoline injection	08.90-10.94	KAT	0 438 121 043
			0 986 439 343
Speed sensor, ignition/injection	08.90-10.94		0 261 210 066
Temperature sensor, intake air, injection system	08.90-10.94		0 280 130 047
Acceleration sensor, ABS	08.90-10.93		0 265 002 230
	11.93-10.94	4-K	0 265 002 230
			0 265 005 040
Wheel speed sensor, front	07.94-10.94		0 265 002 262
Wheel speed sensor, rear			
Fg.no. →082464	08.90-10.94	LAB	0 265 001 292
		RAB	0 265 001 290
230 G [461]	2,3l	66 kW	M 115.974 4 Zyl.
Air flow sensor, gasoline injection	04.92-09.93	KAT	0 438 121 043
			0 986 439 343
Speed sensor, ignition/injection	04.92-09.93		0 261 210 055
Pulse generator, ignition/Jetronic	04.92-09.93	WW	0 261 210 066
230 GE [460]	2,3l	90-92 kW	M 102.987 4 Zyl.
Air flow sensor, gasoline injection	03.86-08.92	KAT	0 438 121 043
			0 986 439 343
Speed sensor, ignition/injection	03.86-08.89		0 261 210 014
Temperature sensor, intake air, injection system	03.86-08.92		0 280 130 047
Temperature sensor, coolant, injection system	03.86-08.89		0 280 130 044



Product			
230 GE [460]	2,3l 92 kW M 102.987 4 Zyl.		
Air flow sensor, gasoline injection	09.85-08.89	0 986 439 301	F 026 TX2 060
Temperature sensor, intake air, injection system	09.85-08.89	0 280 130 047	
Temperature sensor, coolant, injection system	09.85-08.89	0 280 130 042	
230 GE [461]	2,3l 90/92 kW M 102.979; M 102.979; 996; M 102.996 4 Zyl.		
Air flow sensor, gasoline injection	04.92-09.95 KAT	0 438 121 043	0 986 439 343
Speed sensor, ignition/injection	04.92-09.95	0 261 210 066	
230 GE [461]	2,3l 92 kW M 102.997 4 Zyl.		
Air flow sensor, gasoline injection	04.92-09.95 KAT	0 438 121 043	0 986 439 343
230 GE [463]	2,3l 92-95 kW M 102.989 4 Zyl.		
Air flow sensor, gasoline injection	09.89-07.93 KAT	0 438 121 043	0 986 439 343
Speed sensor, ignition/injection	09.89-07.93	0 261 210 066	
Temperature sensor, intake air, injection system	09.89-07.93	0 280 130 047	
Acceleration sensor, ABS	09.89-07.93	0 265 002 230	
Wheel speed sensor, rear			
Fg.no. →082464	09.89-07.93 LAB	0 265 001 292	
	RAB	0 265 001 290	
250 GD [463]	2,5l 69 kW OM 602.931 5 Zyl.		
Acceleration sensor, ABS	09.89-07.93	0 265 002 230	
Wheel speed sensor, rear			
Fg.no. →082464	09.89-07.93 LAB	0 265 001 292	
	RAB	0 265 001 290	
270 CDI [463]	2,7l 115 kW OM 612.965 5 Zyl.		
Speed sensor, diesel	10.01→	0 261 210 170	
High-pressure sensor (CR system)			
Mot.no. →30 287865, →40 176145, →50 846433, →60 001942	10.01→	0 281 002 498	
Mot.no. 30 287866→, 40 176146→, 50 846434→, 60 001943→	10.01→	0 281 002 700	
Duo sensor, acceleration and yaw rate, brake system	10.01→	0 265 005 258	
280 GE [460]	2,8l 110-115 kW M 110.994 6 Zyl.		
Air flow sensor, gasoline injection	06.80-08.89	0 438 120 115	
300 [463]	3,0l 125 kW M 103.987 6 Zyl.		
Temperature sensor, intake air, injection system	09.93-10.94	0 280 130 047	
Acceleration sensor, ABS	09.93-10.93	0 265 002 230	
	11.93-10.94 4-K	0 265 002 230	0 265 005 040
Wheel speed sensor, front	07.94-10.94	0 265 002 262	
Wheel speed sensor, rear			
Fg.no. →082464	09.93-10.94 LAB	0 265 001 292	
	RAB	0 265 001 290	
300 [463]	3,0l 126 kW M 103.987 6 Zyl.		
Air flow sensor, gasoline injection	08.93-10.94	0 438 121 033	0 986 439 333
Temperature sensor, intake air, injection system	08.93-10.94	0 280 130 047	
Acceleration sensor, ABS	08.93-10.93	0 265 002 230	
	11.93-10.94 4-K	0 265 002 230	0 265 005 040
Wheel speed sensor, front	07.94-10.94	0 265 002 262	
300 D [463]	3,0l 83 kW OM 603.931 6 Zyl.		
Acceleration sensor, ABS	04.90-10.93	0 265 002 230	
	11.93-10.94 4-K	0 265 002 230	0 265 005 040
Wheel speed sensor, front	07.94-10.94	0 265 002 262	
300 D Turbo [463]	3,0l 130 kW OM 606.964 6 Zyl.		
Pedal position sensor, diesel	09.96-11.00	0 205 001 029	



300 GD [463]	3,0l 83 kW OM 603.931 6 Zyl.		
Acceleration sensor, ABS	09.89-10.93	0 265 002 230	
Wheel speed sensor, front	07.94-07.97	0 265 002 262	
300 GE [463]	3,0l 125 kW M 103.987 6 Zyl.		
Temperature sensor, intake air, injection system	08.90-08.93	0 280 130 047	
Acceleration sensor, ABS	08.90-08.93	0 265 002 230	
	4-K	0 265 002 230	
Wheel speed sensor, rear			
Fg.no. →082464	08.90-08.93 LAB	0 265 001 292	
	RAB	0 265 001 290	
300 GE [463]	3,0l 126 kW M 103.987 6 Zyl.		
Air flow sensor, gasoline injection	09.89-07.93	0 438 121 033	0 986 439 333
Temperature sensor, intake air, injection system	09.89-07.93	0 280 130 047	
Acceleration sensor, ABS	09.89-07.93	0 265 002 230	
320 [463]	3,2l 154 kW M 112.945 6 Zyl.		
Throttle valve assembly	06.97-11.97	0 205 003 046	
Air mass meter, gasoline injection	06.97-11.97 FGK	0 280 217 810	
	KUT	0 280 218 083	
Phase sensor	06.97-11.97 NOC	0 232 103 050	
Knock sensor	06.97-11.97	0 261 231 110	
Duo sensor, acceleration and yaw rate, brake system	06.97-11.97	0 265 005 258	
Wheel speed sensor, front	06.97-11.97	0 265 002 262	
320 [463]	3,2l 155 kW M 104.996 6 Zyl.		
Air mass meter, gasoline injection	08.93-11.97	0 280 217 500	
Speed sensor, ignition/injection	08.93-11.97	0 261 210 122	
Wheel speed sensor, front	07.94-11.97	0 265 002 262	
320 [463]	3,2l 158 kW M 112.945 6 Zyl.		
Throttle valve assembly			
Comp. no. Code 800	12.97-08.00	0 205 003 046	
Comp. no. Code 801	09.00→	0 280 750 019	
Air mass meter, gasoline injection	12.97→ FGK	0 280 217 515	
	KUT	0 280 218 082	
Phase sensor	12.97→ NOC	0 232 103 050	
Knock sensor	12.97→	0 261 231 110	
350 D Turbo [463]	3,5l 100 kW OM 603.972 6 Zyl.		
Wheel speed sensor, front	07.94-06.96	0 265 002 262	
350 GD Turbo [463]	3,5l 100 kW OM 603.972 6 Zyl.		
Wheel speed sensor, front	09.91-08.93	0 265 002 262	
400 CDI [463]	4,0l 184 kW OM 628.962 8 Zyl.		
Speed sensor, diesel	12.00→	0 261 210 170	
High-pressure sensor (CR system)			
Mot.no. →40035995	12.00→	0 281 002 498	
Mot.no. 40035996→	12.00→	0 281 002 700	
Duo sensor, acceleration and yaw rate, brake system	12.00→	0 265 005 258	
500 [463]	5,0l 218 kW M 113.962 8 Zyl.		
Throttle valve assembly			
Mot.no. →205217	04.98-09.05	0 205 003 048	
Mot.no. 205218→	04.98-09.05	0 280 750 017	
Air mass meter, gasoline injection	04.98-09.05 FGK	0 280 217 810	
	KUT	0 280 218 083	
Phase sensor	04.98-09.05 NOC	0 232 103 050	
Speed sensor, ignition/injection	04.98-09.05 FKW	0 261 210 170	
Knock sensor	04.98-09.05	0 261 231 110	
Duo sensor, acceleration and yaw rate, brake system	06.98-09.05	0 265 005 258	
Wheel speed sensor, front	06.99-09.05	0 265 002 262	
500 AMG GE [463]	5,0l 195 kW M 117.965 8 Zyl.		
Temperature sensor, intake air, injection system	03.93-09.01	0 280 130 047	
Acceleration sensor, ABS	03.93-10.93	0 265 002 230	
Wheel speed sensor, front	07.94-09.01	0 265 002 262	

Product				

◀ Serie G

Wheel speed sensor, rear			
Fg.no. →082464	03.93-09.01	LAB	0 265 001 292
		RAB	0 265 001 290

Serie GL

420 CDI [164]	4,0l 225 kW OM 629.912 8 Zyl.
Phase sensor	02.06→ 0 232 103 050
450 [164]	4,7l 250 kW M 273.923 8 Zyl.
Throttle valve assembly	02.06→ 0 280 750 184
Air mass meter, gasoline injection	02.06→ 0 280 218 190
Phase sensor	02.06→ LAB 0 232 103 050
Knock sensor	02.06→ 0 261 231 188
500 [164]	5,5l 285 kW M 273.963 8 Zyl.
Throttle valve assembly	02.06→ 0 280 750 184
Air mass meter, gasoline injection	02.06→ 0 280 218 190
Phase sensor	02.06→ LAB 0 232 103 050
Knock sensor	02.06→ 0 261 231 188

Serie ML

55 AMG [163]	5,4l 255 kW M 113.981 8 Zyl.
Air mass meter, gasoline injection	03.00-06.05 FGK 0 280 217 810
	KUT 0 280 218 083
Phase sensor	03.00-06.05 NOC 0 232 103 050
Speed sensor, ignition/injection	03.00-06.05 FKW 0 261 210 170
Knock sensor	03.00-06.05 0 261 231 110
63 AMG [164]	6,2l 375 kW M 156.980 8 Zyl.
Knock sensor	02.06→ 0 261 231 188
230 [163]	2,3l 110 kW M 111.977 4 Zyl.
Air mass meter, gasoline injection	03.98-06.00 FGK 0 280 217 114
	KUT 0 280 218 081
Speed sensor, ignition/injection	03.98-06.00 0 261 210 170
Pedal position sensor, EMS (electronic engine management)	
Fg.no. →A 012282	03.98-06.00 0 205 001 302
270 CDI [163]	2,7l 120 kW OM 612.963 5 Zyl.
Speed sensor, diesel	11.99-06.05 0 261 210 170
High-pressure sensor (CR system)	
Mot.no. →30 287865,→40 176145,→50 846433,→60 001942	11.99-06.05 0 281 002 498
Mot.no. 30 287866→,40 176146→,50 846434→,60 001943→	11.99-06.05 0 281 002 700
280 CDI [164]	3,0l 140 kW OM 642.940 6 Zyl.
High-pressure sensor (CR system)	07.05→ 0 281 002 504
320 [163]	3,2l 160 kW M 112.942 6 Zyl.
Throttle valve assembly	03.98-07.02 0 205 003 046
Air mass meter, gasoline injection	03.98-07.02 FGK 0 280 217 515
	KUT 0 280 218 082
Phase sensor	03.98-07.02 NOC 0 232 103 037
Speed sensor, ignition/injection	
Mot.no. →358406	03.98-07.02 0 261 210 141
Mot.no. 358407→	03.98-07.02 0 261 210 170
Knock sensor	03.98-07.02 0 261 231 110
Pedal position sensor, EMS (electronic engine management)	
Fg.no. →A 012282	03.98-07.02 0 205 001 302
320 CDI [164]	3,0l 165 kW OM 642.940 6 Zyl.
High-pressure sensor (CR system)	07.05→ 0 281 002 504
350 [163]	3,7l 173/180 kW M 112.970 6 Zyl.
Phase sensor	08.02-06.05 0 232 103 050
Speed sensor, ignition/injection	08.02-06.05 0 261 210 170
Knock sensor	08.02-06.05 0 261 231 110

Product				

Pedal position sensor, EMS (electronic engine management)		
Fg.no. →A 012282	08.02-06.05	0 205 001 302
350 [164]	3,5l 200 kW M 272.967 6 Zyl.	
Throttle valve assembly	07.05→	0 280 750 017
Air mass meter, gasoline injection	07.05→	0 280 218 190
Phase sensor	07.05→ LAB	0 232 103 050
Knock sensor	07.05→	0 261 231 188
400 CDI [163]	4,0l 184 kW OM 628.963 8 Zyl.	
Speed sensor, diesel	09.01-06.05	0 261 210 170
High-pressure sensor (CR system)		
Mot.no. →40035995	09.01-06.05	0 281 002 498
Mot.no. 40035996→	09.01-06.05	0 281 002 700
420 CDI [164]	4,0l 225 kW OM 629.912 8 Zyl.	
Phase sensor	02.06→	0 232 103 050
430 [163]	4,3l 200 kW M 113.942 8 Zyl.	
Air mass meter, gasoline injection	06.98-07.02 FGK	0 280 217 810
	KUT	0 280 218 083
Phase sensor	06.98-07.02 NOC	0 232 103 050
Speed sensor, ignition/injection	06.98-07.02 FKW	0 261 210 170
Knock sensor	06.98-07.02	0 261 231 110

Pedal position sensor, EMS (electronic engine management)		
Fg.no. →A 012282	06.98-07.02	0 205 001 302
500 [163]	5,0l 215 kW M 113.965 8 Zyl.	
Throttle valve assembly	09.01-06.05	0 280 750 017
Phase sensor	09.01-06.05 NOC	0 232 103 050
Speed sensor, ignition/injection	09.01-06.05 FKW	0 261 210 170
Knock sensor	09.01-06.05	0 261 231 110
Pedal position sensor, EMS (electronic engine management)		
Fg.no. →A 012282	09.01-06.05	0 205 001 302
500 [164]	5,0l 225 kW M 113.964 8 Zyl.	
Throttle valve assembly	07.05→	0 280 750 017
Air mass meter, gasoline injection	07.05→	0 280 217 810
Phase sensor	07.05→	0 232 103 050
Speed sensor, ignition/injection	07.05→	0 261 210 170
Knock sensor	07.05→	0 261 231 110

Serie R

63 AMG 4MATIC [251]	6,2l 375 kW M 156.980 8 Zyl.
Knock sensor	04.06→ 0 261 231 188
280 [251]	3,0l 170 kW M 272.945 6 Zyl.
Throttle valve assembly	05.07→ 0 280 750 017
Air mass meter, gasoline injection	05.07→ 0 280 218 190
Phase sensor	05.07→ LAB 0 232 103 050
Knock sensor	05.07→ 0 261 231 188
280 CDI [251]	3,0l 140 kW OM 642.950 6 Zyl.
Boost pressure sensor, Diesel	05.07→ 0 261 230 143
280 CDI 4MATIC [251]	3,0l 140 kW OM 642.950 6 Zyl.
High-pressure sensor (CR system)	04.06→ 0 281 002 504
Boost pressure sensor, Diesel	04.06→ 0 261 230 143
320 CDI 4MATIC [251]	3,0l 165 kW OM 642.950 6 Zyl.
High-pressure sensor (CR system)	02.06→ 0 281 002 504
Boost pressure sensor, Diesel	02.06→ 0 261 230 143
350 [251]	3,5l 200 kW M 272.967 6 Zyl.
Throttle valve assembly	05.07→ 0 280 750 017
Air mass meter, gasoline injection	05.07→ 0 280 218 190
Phase sensor	05.07→ LAB 0 232 103 050
Knock sensor	05.07→ 0 261 231 188



M

Product



350 4MATIC [251]	3,5l 200 kW M 272.967 6 Zyl.
Throttle valve assembly	02.06→ 0 280 750 017
Air mass meter, gasoline injection	02.06→ 0 280 218 190
Phase sensor	02.06→ LAB 0 232 103 050
Knock sensor	02.06→ 0 261 231 188
500 4MATIC [251]	5,0l 225 kW M 113.971 8 Zyl.
Throttle valve assembly	02.06-04.07 0 280 750 017
Air mass meter, gasoline injection	02.06-04.07 0 280 217 810
Phase sensor	02.06-04.07 0 232 103 050
Speed sensor, ignition/injection	02.06-04.07 0 261 210 170
Knock sensor	02.06-04.07 0 261 231 110
500 4MATIC [251]	5,0l 285 kW M 273.963 8 Zyl.
Throttle valve assembly	05.07→ 0 280 750 184
Air mass meter, gasoline injection	05.07→ 0 280 218 190
Phase sensor	05.07→ LAB 0 232 103 050
Knock sensor	05.07→ 0 261 231 188

Serie S

CL 420 Coupé [140]	4,2l 205 kW M 119.971,981 8 Zyl.
Throttle valve assembly	
Engine type M119.981	06.96-08.99 0 205 003 037
Air mass meter, gasoline injection	
Mot.no. M119.981	06.96-08.99 0 280 217 807
Engine type M119.971	06.96-08.99 0 280 214 004
	0 986 280 121
Phase sensor	
Engine type M 119.981	06.96-08.99 0 232 103 037
Speed sensor, ignition/injection	
Engine type M 119.971	06.96-08.99 0 261 210 055
Engine type M 119.981	06.96-08.99 0 281 002 123
Knock sensor	
Engine type M 119.971	06.96-08.99 0 261 231 054
Engine type M 119.981	06.96-08.99 0 261 231 110
Temperature sensor, intake air, injection system	
Engine type M119.971	06.96-08.99 0 280 130 047
Pedal position sensor, EMS (electronic engine management)	06.96-08.99 0 205 001 302
Duo sensor, acceleration and yaw rate, brake system	06.96-08.99 0 265 005 201
Pressure sensor, ESP, (electronic stability program)	06.96-08.99 0 265 005 300
Wheel speed sensor, front	06.96-08.99 LAB 0 265 001 410
	RAB 0 265 001 408
Wheel speed sensor, rear	
Fg.no. →A212244	06.96-08.99 LAB 0 265 002 218
	RAB 0 265 002 216
CL 500 Coupé [140]	5,0l 235 kW M 119.970,980 8 Zyl.
Throttle valve assembly	
Engine type M119.980	09.96-08.99 0 205 003 037
Air mass meter, gasoline injection	
Mot.no. M119.980	09.96-08.99 0 280 217 807
Engine type M119.970	09.96-08.99 0 280 214 004
	0 986 280 121
Phase sensor	
Engine type M 119.980	09.96-08.99 0 232 103 037
Speed sensor, ignition/injection	
Engine type M 119.970	09.96-08.99 0 261 210 055
Engine type M 119.980	09.96-08.99 0 281 002 123
Knock sensor	09.96-08.99 0 261 231 054
Temperature sensor, intake air, injection system	
Engine type M119.970	09.96-08.99 0 280 130 047

Product



Pedal position sensor, EMS (electronic engine management)	09.96-08.99 0 205 001 302
Duo sensor, acceleration and yaw rate, brake system	09.96-08.99 0 265 005 201
Pressure sensor, ESP, (electronic stability program)	09.96-08.99 0 265 005 300
Wheel speed sensor, front	09.96-08.99 LAB 0 265 001 410
	RAB 0 265 001 408
Wheel speed sensor, rear	09.96-08.99 OAS 0 265 002 220
Fg.no. →A212244	09.96-08.99 ASR,LAB 0 265 002 218
	ASR,RAB 0 265 002 216
CL 600 Coupé [140]	6,0l 290 kW M 120.982 12 Zyl.
Throttle valve assembly	06.96-08.99 0 205 003 039
Air mass meter, gasoline injection	06.96-08.99 0 280 217 509
Phase sensor	06.96-08.99 FKW 0 281 002 123
	NOC 0 232 103 050
Knock sensor	06.96-08.99 0 261 231 110
Pedal position sensor, EMS (electronic engine management)	06.96-08.99 0 205 001 302
Duo sensor, acceleration and yaw rate, brake system	06.96-08.99 0 265 005 201
Pressure sensor, ESP, (electronic stability program)	06.96-08.99 0 265 005 300
Wheel speed sensor, front	06.96-08.99 LAB 0 265 001 410
	RAB 0 265 001 408
Wheel speed sensor, rear	
Fg.no. →A212244	06.96-08.99 LAB 0 265 002 218
	RAB 0 265 002 216
55 AMG [220]	5,4l 265 kW 113.986 8 Zyl.
Air mass meter, gasoline injection	08.00-08.02 0 280 217 810
Phase sensor	08.00-08.02 NOC 0 232 103 050
Speed sensor, ignition/injection	08.00-08.02 0 261 210 170
Knock sensor	08.00-08.02 0 261 231 110
Duo sensor, acceleration and yaw rate, brake system	
Fg.no. A 322444→	08.00-08.02 0 265 005 258
Fg.no. →A 322443	08.00-08.02 0 265 005 258
Pressure sensor, ESP, (electronic stability program)	08.00-08.02 0 265 005 303
Wheel speed sensor, front	08.00-08.02 0 265 007 002
Wheel speed sensor, rear	08.00-08.02 FMS,LAB 0 265 007 121
	FMS,RAB 0 265 007 123
	LAB 0 265 007 008
	LAB,OSS 0 265 007 008
	OSS,RAB 0 265 007 006
	RAB 0 265 007 006
55 AMG KOMPRESSOR [220]	5,4l 368 kW 113.991 8 Zyl.
Phase sensor	09.02-08.05 NOC 0 232 103 050
Speed sensor, ignition/injection	09.02-08.05 0 261 210 170
Knock sensor	09.02-08.05 0 261 231 110
Duo sensor, acceleration and yaw rate, brake system	09.02-08.05 0 265 005 258
Pressure sensor, ESP, (electronic stability program)	09.02-08.05 0 265 005 303
Wheel speed sensor, front	09.02-08.05 0 265 007 002
Wheel speed sensor, rear	09.02-08.05 LAB 0 265 007 121
	RAB 0 265 007 123
63 AMG [221]	6,2l 386 kW M 156.984 8 Zyl.
Knock sensor	12.06→ 0 261 231 188
65 AMG [220]	6,0l 450 kW M 275.980 12 Zyl.
Speed sensor, ignition/injection	02.04-08.05 0 261 210 170
Knock sensor	02.04-08.05 0 261 231 110
Duo sensor, acceleration and yaw rate, brake system	02.04-08.05 0 265 005 258
Pressure sensor, ESP, (electronic stability program)	02.04-08.05 0 265 005 303
Wheel speed sensor, front	02.04-08.05 0 265 007 128



Product



◀ Serie S

Wheel speed sensor, rear	02.04-08.05	FMS,LAB	0 265 007 121
		FMS,RAB	0 265 007 123
		LAB,OSS	0 265 007 008
		OSS,RAB	0 265 007 006
65 AMG [221]		6,0l 450 kW M 275.982 12 Zyl.	
Speed sensor, ignition/injection	07.06→		0 261 210 170
Knock sensor	07.06→		0 261 231 110
260 SE [126]		2,6l 118-122 kW M 103.941 6 Zyl.	
Air flow sensor, gasoline injection	09.85-06.91		0 438 121 033
			0 986 439 333
Temperature sensor, intake air, injection system	09.85-06.91		0 280 130 047
Temperature sensor, coolant, injection system			
Mot.no. →004196	09.85-06.91	2PO,GS	0 280 130 044
Mot.no. →013693	09.85-06.91	2PO,AG	0 280 130 044
Wheel speed sensor, front	09.85-08.89	ABS,LAB	0 265 001 021
		ABS,RAB	0 265 001 020
	09.89-06.91	LAB	0 265 001 280
		RAB	0 265 001 278
Wheel speed sensor, rear	09.85-06.91		0 265 002 258
		ASR	0 265 002 260
280 [140]		2,8l 142-145 kW M 104.944 6 Zyl.	
Throttle valve assembly			
Mot.no. 001152→,Comp. no. Code 807	06.93-09.98	ASR,HMG	0 205 003 042
Mot.no. 017173→,Comp. no. Code 807	06.93-09.98	ASR,GMG	0 205 003 042
Air mass meter, gasoline injection			
Mot.no. →001151,Comp. no. Code 807	06.93-09.98	GS	0 280 217 500
Mot.no. →017172,Comp. no. Code 807	06.93-09.98	AG	0 280 217 500
Mot.no. 001152→,Comp. no. Code 807	06.93-09.98	GS	0 280 217 517
Mot.no. 017173→,Comp. no. Code 807	06.93-09.98	AG	0 280 217 517
Speed sensor, ignition/injection	06.93-09.98		0 261 210 122
Pedal position sensor, EMS (electronic engine management)	06.93-09.98	RLE	0 205 001 302
Wheel speed sensor, front	06.93-09.98	LAB	0 265 001 410
		RAB	0 265 001 408
Wheel speed sensor, rear	06.93-09.98	OAS	0 265 002 220
Fg.no. →A212244	06.93-09.98	ASR,LAB	0 265 002 218
		ASR,RAB	0 265 002 234
280 [220]		2,8l 150 kW M 112.922 6 Zyl.	
Throttle valve assembly	01.99-08.02		0 205 003 046
Air mass meter, gasoline injection	01.99-08.05		0 280 217 515
Phase sensor	01.99-08.05		0 232 103 050
Speed sensor, ignition/injection	01.99-08.05		0 261 210 170
Knock sensor	01.99-08.05		0 261 231 110
Duo sensor, acceleration and yaw rate, brake system	01.99-08.05		0 265 005 258
Fg.no. A 138351→A 322443	01.99-08.02		0 265 005 258
Fg.no. A 322444→	01.99-08.02		0 265 005 258
Fg.no. →A 138350	01.99-08.02		0 265 005 201
Pressure sensor, ESP, (electronic stability program)	01.99-08.05		0 265 005 303
Wheel speed sensor, front	01.99-08.05		0 265 007 002
Wheel speed sensor, rear	01.99-08.05	LAB	0 265 007 008
		RAB	0 265 007 006
300 D Turbo [140]		3,0l 130 kW OM 606.961 6 Zyl.	
Speed sensor, diesel	06.96-09.98		0 281 002 123
Pedal position sensor, diesel	06.96-09.98		0 205 001 029
Wheel speed sensor, front	06.96-09.98	LAB	0 265 001 410
		RAB	0 265 001 408
300 SD Turbo [140]		3,5l 100-110 kW OM 603.971 6 Zyl.	
Air flow sensor, diesel	07.91-05.93		0 281 002 077
Pressure sensor, intake manifold, diesel	07.91-05.93		0 281 002 059
Temperature sensor, coolant, diesel	07.91-05.93		0 280 130 035
Wheel speed sensor, front	07.91-05.93	LAB	0 265 001 410
		RAB	0 265 001 408

Product




Wheel speed sensor, rear				
Fg.no. A212245→	07.91-05.93	OAS	0 265 002 248	
Fg.no. →A212244	07.91-05.93	OAS	0 265 002 220	
300 SDL Turbo [126]	3,0l 107-110 kW	OM 603.961	6 Zyl.	
Air flow sensor, diesel	11.85-12.87		0 281 002 024	
			0 281 002 028	
Wheel speed sensor, front	11.85-12.87	ABS,LAB	0 265 001 021	
		ABS,RAB	0 265 001 020	
300 SE [126]	3,0l 132-138 kW	M 103.981	6 Zyl.	
Air flow sensor, gasoline injection	09.85-06.91		0 438 121 033	
			0 986 439 333	
Pressure sensor, intake manifold, gasoline	09.85-06.91		0 280 101 003	
Temperature sensor, intake air, injection system	09.85-06.91		0 280 130 047	
Temperature sensor, coolant, injection system	09.85-06.91	2PO	0 280 130 044	
Wheel speed sensor, front	09.85-08.89	ABS,LAB	0 265 001 021	
	09.89-06.91	LAB	0 265 001 280	
Wheel speed sensor, rear	09.85-06.91		0 265 002 258	
300 SE [140]	3,2l 170 kW	M 104.994	6 Zyl.	
Throttle valve assembly				
Mot.no. 073223→	03.91-04.93	ASR,LLE	0 205 003 042	
Air mass meter, gasoline injection				
Mot.no. →073222,Comp. no. Code 807	03.91-04.93		0 280 217 500	
Mot.no. 073223→,Comp. no. Code 807	03.91-04.93		0 280 217 517	
Pedal position sensor, EMS (electronic engine management)	03.91-04.93	RLE	0 205 001 302	
Wheel speed sensor, front	03.91-04.93	LAB	0 265 001 410	
		RAB	0 265 001 408	
Wheel speed sensor, rear	03.91-04.93	OAS	0 265 002 220	
Fg.no. →A212244	03.91-04.93	ASR,LAB	0 265 002 218	
		ASR,RAB	0 265 002 234	
300 SE, SEL [126]	3,0l 132-138 kW	M 103.981	6 Zyl.	
Air flow sensor, gasoline injection	09.85-06.91		0 438 121 033	
			0 986 439 333	
Temperature sensor, intake air, injection system	09.85-06.91		0 280 130 047	
Temperature sensor, coolant, injection system	09.85-06.91	2PO	0 280 130 044	
Wheel speed sensor, front	09.85-08.89	ABS,LAB	0 265 001 021	
		ABS,RAB	0 265 001 020	
	09.89-06.91	LAB	0 265 001 280	
		RAB	0 265 001 278	
Wheel speed sensor, rear	09.85-06.91		0 265 002 258	
300 SE, SEL [126]	3,0l 138 kW	M 103.981	6 Zyl.	
Air flow sensor, gasoline injection	12.85-08.87		0 438 121 033	
			0 986 439 333	
Temperature sensor, intake air, injection system	12.85-08.87		0 280 130 047	
Temperature sensor, coolant, injection system	12.85-08.87	2PO	0 280 130 044	
Wheel speed sensor, front	12.85-08.87	ABS,LAB	0 265 001 021	
		ABS,RAB	0 265 001 020	
300 SE 2.8 [140]	2,8l 142-145 kW	M 104.944	6 Zyl.	
Throttle valve assembly				
Mot.no. 001152→,Comp. no. Code 807	09.92-05.93	ASR,HMG	0 205 003 042	
Mot.no. 017173→,Comp. no. Code 807	09.92-05.93	ASR,GMG	0 205 003 042	
Air mass meter, gasoline injection				
Mot.no. →001151,Comp. no. Code 807	09.92-05.93	GS	0 280 217 500	
Mot.no. →017172,Comp. no. Code 807	09.92-05.93	AG	0 280 217 500	
Mot.no. 001152→,Comp. no. Code 807	09.92-05.93	GS	0 280 217 517	
Mot.no. 017173→,Comp. no. Code 807	09.92-05.93	AG	0 280 217 517	
Speed sensor, ignition/injection	09.92-05.93		0 261 210 122	
Pedal position sensor, EMS (electronic engine management)	09.92-05.93	RLE	0 205 001 302	
Wheel speed sensor, front	09.92-05.93	LAB	0 265 001 410	
		RAB	0 265 001 408	



Wheel speed sensor, rear	09.92-05.93	OAS	0 265 002 220
Fg.no. →A212244	09.92-05.93	ASR,LAB	0 265 002 218
		ASR,RAB	0 265 002 234
300 SEL [126]	3,0l	132 kW M 103.981	6 Zyl.
Air flow sensor, gasoline injection	09.85-06.91		0 438 121 033
			0 986 439 333
Pressure sensor, intake manifold, gasoline	09.85-06.91		0 280 101 003
Temperature sensor, intake air, injection system	09.85-06.91		0 280 130 047
Temperature sensor, coolant, injection system	09.85-06.91	2PO	0 280 130 044
Wheel speed sensor, front	09.85-08.89	ABS,LAB	0 265 001 021
		ABS,RAB	0 265 001 020
	09.89-06.91	LAB	0 265 001 280
		RAB	0 265 001 278
Wheel speed sensor, rear	09.89-06.91		0 265 002 258
300 SEL 3.2 [140]	3,2l	170 kW M 104.990	6 Zyl.
Air mass meter, gasoline injection	03.91-05.93		0 280 213 018
			0 986 280 125
Knock sensor	03.91-05.93		0 261 231 056
Temperature sensor, intake air, injection system	03.91-05.93		0 280 130 047
Pedal position sensor, EMS (electronic engine management)	03.91-05.93	RLE	0 205 001 302
Wheel speed sensor, front	03.91-05.93	LAB	0 265 001 410
		RAB	0 265 001 408
Wheel speed sensor, rear	03.91-05.93	OAS	0 265 002 220
Fg.no. →A212244	03.91-05.93	ASR,LAB	0 265 002 218
		ASR,RAB	0 265 002 234
320 [140]	3,2l	170 kW M 104.990	6 Zyl.
Air mass meter, gasoline injection	03.93-09.98		0 280 213 018
			0 986 280 125
Knock sensor	03.93-09.98		0 261 231 056
Temperature sensor, intake air, injection system	03.93-09.98		0 280 130 047
Pedal position sensor, EMS (electronic engine management)	03.93-09.98	RLE	0 205 001 302
Wheel speed sensor, front	03.93-09.98	LAB	0 265 001 410
		RAB	0 265 001 408
Wheel speed sensor, rear	03.93-09.98	OAS	0 265 002 220
Fg.no. →A212244	03.93-09.98	ASR,LAB	0 265 002 218
		ASR,RAB	0 265 002 234
320 [140]	3,2l	170 kW M 104.994	6 Zyl.
Throttle valve assembly			
Mot.no. 073223→	05.93-09.98	ASR,LLE	0 205 003 042
Air mass meter, gasoline injection			
Mot.no. →073222, Comp. no. Code 807	05.93-09.98		0 280 217 500
Mot.no. 073223→, Comp. no. Code 807	05.93-09.98		0 280 217 517
Pedal position sensor, EMS (electronic engine management)	05.93-09.98	RLE	0 205 001 302
Wheel speed sensor, front	05.93-09.98	LAB	0 265 001 410
		RAB	0 265 001 408
Wheel speed sensor, rear	05.93-09.98	OAS	0 265 002 220
Fg.no. →A212244	05.93-09.98	ASR,LAB	0 265 002 218
		ASR,RAB	0 265 002 234
320 [220]	3,2l	165 kW M 112.944	6 Zyl.
Throttle valve assembly	10.98-08.02		0 205 003 046
Air mass meter, gasoline injection	10.98-08.02		0 280 217 515
Phase sensor	10.98-08.02		0 232 103 050
Speed sensor, ignition/injection	10.98-08.02		0 261 210 170
Knock sensor	10.98-08.02		0 261 231 110
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. A 138351→A 322443	10.98-08.02		0 265 005 258
Fg.no. A 322444→	10.98-08.02		0 265 005 258
Fg.no. →A 138350	10.98-08.02		0 265 005 201
Pressure sensor, ESP, (electronic stability program)	10.98-08.02		0 265 005 303




Wheel speed sensor, front	10.98-08.02		0 265 007 002
Wheel speed sensor, rear	10.98-08.02	FMS,LAB	0 265 007 121
		FMS,RAB	0 265 007 123
		LAB	0 265 007 008
		LAB,OSS	0 265 007 008
		OSS,RAB	0 265 007 006
		RAB	0 265 007 006
320 CDI [220]	3,2l	145 kW OM 613.960	6 Zyl.
Speed sensor, diesel	06.99-08.02		0 261 210 170
High-pressure sensor (CR system)	06.99-08.02		0 281 002 498
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. A 322444→	06.99-08.02		0 265 005 258
Fg.no. →A 322443	06.99-08.02		0 265 005 258
Pressure sensor, ESP, (electronic stability program)	06.99-08.02		0 265 005 303
Wheel speed sensor, front	06.99-08.02		0 265 007 002
Wheel speed sensor, rear	06.99-08.02	FMS,LAB	0 265 007 121
		FMS,RAB	0 265 007 123
		LAB	0 265 007 008
		LAB,OSS	0 265 007 008
		OSS,RAB	0 265 007 006
		RAB	0 265 007 006
320 CDI [220]	3,2l	150 kW OM 648.960	6 Zyl.
Air mass meter, diesel	09.02-08.05		0 281 002 535
Speed sensor, diesel	09.02-08.05		0 261 210 170
High-pressure sensor (CR system)	09.02-08.05		0 281 002 504
Duo sensor, acceleration and yaw rate, brake system	09.02-08.05		0 265 005 258
Pressure sensor, ESP, (electronic stability program)	09.02-08.05		0 265 005 303
Wheel speed sensor, front	09.02-08.05		0 265 007 002
Wheel speed sensor, rear	09.02-08.05	FMS,LAB	0 265 007 121
		FMS,RAB	0 265 007 123
		LAB	0 265 007 008
		LAB,OSS	0 265 007 008
		OSS,RAB	0 265 007 006
		RAB	0 265 007 006
320 CDI [221]	3,0l	173 kW OM 642.930	6 Zyl.
High-pressure sensor (CR system)	12.05→		0 281 002 504
350 [220]	3,7l	180 kW M 112.972	6 Zyl.
Air mass meter, gasoline injection	09.02-08.05		0 280 217 515
Phase sensor	09.02-08.05	NOC	0 232 103 050
Speed sensor, ignition/injection	09.02-08.05		0 261 210 170
Knock sensor	09.02-08.05		0 261 231 110
Duo sensor, acceleration and yaw rate, brake system	09.02-08.05		0 265 005 258
Pressure sensor, ESP, (electronic stability program)	09.02-08.05		0 265 005 303
Wheel speed sensor, front	09.02-08.05		0 265 007 002
Wheel speed sensor, rear	09.02-08.05	FMS,LAB	0 265 007 121
		FMS,RAB	0 265 007 123
		LAB	0 265 007 008
		LAB,OSS	0 265 007 008
		OSS,RAB	0 265 007 006
		RAB	0 265 007 006
350 [221]	3,5l	200 kW M 272.965	6 Zyl.
Throttle valve assembly	09.05→		0 280 750 017
Air mass meter, gasoline injection	09.05→		0 280 218 190
Phase sensor	09.05→	LAB	0 232 103 050
Knock sensor	09.05→		0 261 231 188
350 D Turbo [140]	3,5l	100-110 kW OM 603.971	6 Zyl.
Air flow sensor, diesel	06.93-06.96		0 281 002 077
Pressure sensor, intake manifold, diesel	06.93-06.96		0 281 002 059
Temperature sensor, coolant, diesel	06.93-06.96		0 280 130 035



◀ Serie S

Wheel speed sensor, front	06.93-06.96	LAB	0 265 001 410
		RAB	0 265 001 408
Wheel speed sensor, rear			
Fg.no. A212245→	06.93-06.96	OAS	0 265 002 248
Fg.no. →A212244	06.93-06.96	OAS	0 265 002 220
350 SDL Turbo [126]	3,5 l 100 kW OM 603.970	6 Zyl.	
Air flow sensor, diesel	03.90-06.91		0 281 002 024
			0 281 002 028
Pressure sensor, intake manifold, diesel	03.90-06.91		0 281 002 059
Temperature sensor, coolant, diesel	03.90-06.91		0 280 130 035
Wheel speed sensor, front	03.90-06.91	LAB	0 265 001 280
		RAB	0 265 001 278
Wheel speed sensor, rear	03.90-06.91		0 265 002 258
350 4MATIC [220]	3,7 l 180 kW M 112.975	6 Zyl.	
Air mass meter, gasoline injection	06.03-08.05		0 280 217 515
Phase sensor	06.03-08.05	NOC	0 232 103 050
Speed sensor, ignition/injection	06.03-08.05		0 261 210 170
Knock sensor	06.03-08.05		0 261 231 110
Duo sensor, acceleration and yaw rate, brake system	06.03-08.05		0 265 005 258
Pressure sensor, ESP, (electronic stability program)	06.03-08.05		0 265 005 303
Wheel speed sensor, rear	06.03-08.05	LAB	0 265 007 008
		RAB	0 265 007 006
400 CDI [220]	4,0 l 184/191 kW OM 628.960	8 Zyl.	
Speed sensor, diesel	06.99-08.05		0 261 210 170
High-pressure sensor (CR system)	06.99-08.05		0 281 002 498
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. A 322444→	06.99-08.05		0 265 005 258
Fg.no. →A 322443	06.99-08.05		0 265 005 258
Pressure sensor, ESP, (electronic stability program)	06.99-08.05		0 265 005 303
Wheel speed sensor, front	06.99-08.05		0 265 007 002
Wheel speed sensor, rear	06.99-08.05	FMS,LAB	0 265 007 121
		FMS,RAB	0 265 007 123
		LAB	0 265 007 008
		LAB,OSS	0 265 007 008
		OSS,RAB	0 265 007 006
		RAB	0 265 007 006
400 SE [140]	4,2 l 205-210 kW M 119.971;981	8 Zyl.	
Throttle valve assembly			
Engine type M119.981	02.91-05.93		0 205 003 037
Air mass meter, gasoline injection	02.91-05.93		0 280 214 004
			0 986 280 121
Speed sensor, ignition/injection	02.91-05.93		0 261 210 055
Knock sensor	02.91-05.93		0 261 231 054
Temperature sensor, intake air, injection system	02.91-05.93		0 280 130 047
Pedal position sensor, EMS (electronic engine management)	02.91-05.93		0 205 001 302
Acceleration sensor, ABS	02.91-05.93		0 265 005 107
Wheel speed sensor, front	02.91-05.93	LAB	0 265 001 410
		RAB	0 265 001 408
Wheel speed sensor, rear	02.91-05.93	OAS	0 265 002 220
Fg.no. →A212244	02.91-05.93	ASR,LAB	0 265 002 218
		ASR,RAB	0 265 002 234
400 SEL [140]	4,2 l 205-210 kW M 119.971;981	8 Zyl.	
Throttle valve assembly			
Engine type M119.981	06.93-08.95		0 205 003 037
Air mass meter, gasoline injection			
Mot.no. M119.981	06.93-08.95		0 280 217 807
Engine type M119.971	06.93-08.95		0 280 214 004
			0 986 280 121
Speed sensor, ignition/injection	06.93-08.95		0 261 210 055
Knock sensor	06.93-08.95		0 261 231 054



Temperature sensor, intake air, injection system			
Engine type M119.971	06.93-08.95		0 280 130 047
Pedal position sensor, EMS (electronic engine management)	06.93-08.95		0 205 001 302
Wheel speed sensor, front	06.93-08.95	LAB	0 265 001 410
		RAB	0 265 001 408
Wheel speed sensor, rear	06.93-08.95	OAS	0 265 002 220
Fg.no. →A212244	06.93-08.95	ASR,LAB	0 265 002 218
		ASR,RAB	0 265 002 234
420 [140]	4,2 l 205-210 kW M 119.971;981	8 Zyl.	
Throttle valve assembly			
Engine type M119.981	06.93-09.98		0 205 003 037
Air mass meter, gasoline injection	06.93-09.98		0 280 214 004
			0 986 280 121
Speed sensor, ignition/injection	06.93-09.98		0 261 210 055
Knock sensor	06.93-09.98		0 261 231 054
Temperature sensor, intake air, injection system	06.93-09.98		0 280 130 047
Pedal position sensor, EMS (electronic engine management)	06.93-09.98		0 205 001 302
Acceleration sensor, ABS	06.93-05.94		0 265 005 107
	06.94-09.98		0 265 005 107
Wheel speed sensor, front	06.93-09.98	LAB	0 265 001 410
		RAB	0 265 001 408
Wheel speed sensor, rear	06.93-09.98	OAS	0 265 002 220
Fg.no. →A212244	06.93-09.98	ASR,LAB	0 265 002 218
		ASR,RAB	0 265 002 234
420 [140]	4,2 l 210 kW M 119.971;981	8 Zyl.	
Throttle valve assembly			
Engine type M119.981	09.95-09.98		0 205 003 037
Air mass meter, gasoline injection			
Mot.no. M119.981	09.95-09.98		0 280 217 807
Engine type M119.971	09.95-09.98		0 280 214 004
			0 986 280 121
Phase sensor	09.95-09.98		0 232 103 037
Speed sensor, ignition/injection	09.95-09.98		0 281 002 123
Knock sensor	09.95-09.98		0 261 231 110
Temperature sensor, intake air, injection system			
Engine type M119.971	09.95-09.98		0 280 130 047
Pedal position sensor, EMS (electronic engine management)	09.95-09.98		0 205 001 302
Duo sensor, acceleration and yaw rate, brake system	09.95-09.98		0 265 005 201
Wheel speed sensor, front	09.95-09.98	LAB	0 265 001 410
		RAB	0 265 001 408
Wheel speed sensor, rear	09.95-09.98	OAS	0 265 002 220
Fg.no. →A212244	09.95-09.98	ASR,LAB	0 265 002 218
		ASR,RAB	0 265 002 234
420 CDI [221]	4,0 l 235 kW OM 629.911	8 Zyl.	
Phase sensor	12.06→		0 232 103 050
420 Coupé [140]	4,2 l 205-210 kW M 119.971;981	8 Zyl.	
Throttle valve assembly			
Engine type M119.981	03.94-05.96		0 205 003 037
Air mass meter, gasoline injection			
Mot.no. M119.981	03.94-05.96		0 280 217 807
Engine type M119.971	03.94-05.96		0 280 214 004
			0 986 280 121
Speed sensor, ignition/injection	03.94-05.96		0 261 210 055
Knock sensor	03.94-05.96		0 261 231 054
Temperature sensor, intake air, injection system			
Engine type M119.971	03.94-05.96		0 280 130 047
Pedal position sensor, EMS (electronic engine management)	03.94-05.96		0 205 001 302



Duo sensor, acceleration and yaw rate, brake system	05.95-05.96		0 265 005 201
Pressure sensor, ESP, (electronic stability program)	05.95-05.96		0 265 005 300
Wheel speed sensor, front	03.94-05.96	LAB	0 265 001 410
		RAB	0 265 001 408
Wheel speed sensor, rear			
Fg.no. →A212244	03.94-05.96	LAB	0 265 002 218
		RAB	0 265 002 216
420 SE, SEL [126]	4,2l	150 kW M 116.965	8 Zyl.
Air flow sensor, gasoline injection	12.85-12.86		0 438 121 037
			0 986 439 337
Temperature sensor, intake air, injection system	12.85-12.86		0 280 130 047
Temperature sensor, coolant, injection system	12.85-12.86		0 280 130 044
Wheel speed sensor, front	12.85-12.86	ABS,LAB	0 265 001 021
		ABS,RAB	0 265 001 020
420 SE, SEL [126]	4,2l	150-170 kW M 116.965	8 Zyl.
Air flow sensor, gasoline injection	09.85-06.91		0 438 121 037
			0 986 439 337
Knock sensor	09.88-06.91		0 261 231 009
Temperature sensor, intake air, injection system	09.85-06.91		0 280 130 047
Temperature sensor, coolant, injection system	09.85-08.87		0 280 130 044
Wheel speed sensor, front	09.85-08.89	ABS,LAB	0 265 001 021
		ABS,RAB	0 265 001 020
	09.89-06.91	LAB	0 265 001 280
		RAB	0 265 001 278
Wheel speed sensor, rear	09.85-06.91		0 265 002 258
	09.87-06.91	ASR,LAB	0 265 002 029
		ASR,RAB	0 265 002 027
420 SEC [126]	4,2l	150-170 kW M 116.965	8 Zyl.
Air flow sensor, gasoline injection	10.85-06.91		0 438 121 037
			0 986 439 337
Knock sensor	09.88-06.91		0 261 231 009
Temperature sensor, intake air, injection system	10.85-06.91		0 280 130 047
Temperature sensor, coolant, injection system	10.85-08.87		0 280 130 044
Wheel speed sensor, front	10.85-08.89	ABS,LAB	0 265 001 021
		ABS,RAB	0 265 001 020
	09.89-06.91	LAB	0 265 001 280
		RAB	0 265 001 278
Wheel speed sensor, rear	10.85-06.91		0 265 002 258
	09.87-06.91	ASR,LAB	0 265 002 029
		ASR,RAB	0 265 002 027
420 SEL [126]	4,2l	150 kW M 116.965	8 Zyl.
Air flow sensor, gasoline injection	09.85-06.91		0 438 121 037
			0 986 439 337
Pressure sensor, intake manifold, gasoline	09.85-06.91		0 280 101 003
Temperature sensor, intake air, injection system	09.85-06.91		0 280 130 047
Temperature sensor, coolant, injection system	09.85-08.87		0 280 130 044
Wheel speed sensor, front	09.85-08.89	ABS,LAB	0 265 001 021
		ABS,RAB	0 265 001 020
	09.89-06.91	LAB	0 265 001 280
		RAB	0 265 001 278
Wheel speed sensor, rear	09.85-06.91		0 265 002 258
	09.87-06.91	ASR,LAB	0 265 002 029
		ASR,RAB	0 265 002 027
430 [220]	4,3l	205 kW M 113.941	8 Zyl.
Throttle valve assembly	10.98-08.05		0 205 003 048
Air mass meter, gasoline injection	10.98-08.05		0 280 217 810
Phase sensor	10.98-08.05	NOC	0 232 103 050
Speed sensor, ignition/injection	10.98-08.05	FKW	0 261 210 170
Knock sensor	10.98-08.05		0 261 231 110



Duo sensor, acceleration and yaw rate, brake system			
Fg.no. A 138351→A 322443	10.98-08.05		0 265 005 258
Fg.no. A 322444→	10.98-08.05		0 265 005 258
Fg.no. →A 138350	10.98-08.05		0 265 005 201
Pressure sensor, ESP, (electronic stability program)	10.98-08.05		0 265 005 303
Wheel speed sensor, front	10.98-08.05		0 265 007 002
Wheel speed sensor, rear	10.98-08.05	FMS,LAB	0 265 007 121
		FMS,RAB	0 265 007 123
		LAB	0 265 007 008
		LAB,OSS	0 265 007 008
		OSS,RAB	0 265 007 006
		RAB	0 265 007 006
430 4MATIC [220]	4,3l	205 kW M 113.948	8 Zyl.
Air mass meter, gasoline injection	09.02-08.05		0 280 217 810
Phase sensor	09.02-08.05	NOC	0 232 103 050
Speed sensor, ignition/injection	09.02-08.05	FKW	0 261 210 170
Knock sensor	09.02-08.05		0 261 231 110
Duo sensor, acceleration and yaw rate, brake system	09.02-08.05		0 265 005 258
Pressure sensor, ESP, (electronic stability program)	09.02-08.05		0 265 005 303
Wheel speed sensor, rear	09.02-08.05	FMS,LAB	0 265 007 121
		FMS,RAB	0 265 007 123
		LAB	0 265 007 008
		LAB,OSS	0 265 007 008
		OSS,RAB	0 265 007 006
		RAB	0 265 007 006
450, 4MATIC [221]	4,7l	250 kW M 273.922	8 Zyl.
Throttle valve assembly	06.06→		0 280 750 184
Air mass meter, gasoline injection	06.06→		0 280 218 190
Phase sensor	06.06→	LAB	0 232 103 050
Knock sensor	06.06→		0 261 231 188
500 [140]	5,0l	235-240 kW M 119.970;980	8 Zyl.
Throttle valve assembly			
Engine type M119.980	06.93-09.98		0 205 003 037
Air mass meter, gasoline injection			
Mot.no. M119.980	06.93-09.98		0 280 217 807
Engine type M119.970	06.93-09.98		0 280 214 004
			0 986 280 121
Speed sensor, ignition/injection	06.93-09.98		0 261 210 055
Knock sensor	06.93-09.98		0 261 231 054
Temperature sensor, intake air, injection system			
Engine type M119.970	06.93-09.98		0 280 130 047
Pedal position sensor, EMS (electronic engine management)	06.93-09.98		0 205 001 302
Acceleration sensor, ABS	06.94-09.98		0 265 005 107
Wheel speed sensor, front	06.93-09.98	LAB	0 265 001 410
		RAB	0 265 001 408
Wheel speed sensor, rear	06.93-09.98	OAS	0 265 002 220
Fg.no. →A212244	06.93-09.98	ASR,LAB	0 265 002 218
		ASR,RAB	0 265 002 234
500 [220]	5,0l	225 kW M 113.960	8 Zyl.
Throttle valve assembly	10.98-08.05		0 205 003 048
Air mass meter, gasoline injection	10.98-08.05		0 280 217 810
Phase sensor	10.98-08.05	NOC	0 232 103 050
Speed sensor, ignition/injection	10.98-08.05	FKW	0 261 210 170
Knock sensor	10.98-08.05		0 261 231 110
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. A 138351→A 322443	10.98-08.05		0 265 005 258
Fg.no. A 322444→	10.98-08.05		0 265 005 258
Fg.no. →A 138350	10.98-08.05		0 265 005 201
Pressure sensor, ESP, (electronic stability program)	10.98-08.05		0 265 005 303

Product



◀ Serie S

Wheel speed sensor, front	10.98-08.05		0 265 007 002
Wheel speed sensor, rear	10.98-08.05	FMS,LAB	0 265 007 121
		FMS,RAB	0 265 007 123
		LAB	0 265 007 008
		LAB,OSS	0 265 007 008
		OSS,RAB	0 265 007 006
		RAB	0 265 007 006
500 [221]	5,5 l	285 kW	M 273.961 8 Zyl.
Throttle valve assembly	09.05→		0 280 750 184
Air mass meter, gasoline injection	09.05→		0 280 218 190
Phase sensor	09.05→	LAB	0 232 103 050
Knock sensor	09.05→		0 261 231 188
500 Coupé [140]	5,0 l	235-240 kW	M 119.970;980 8 Zyl.
Throttle valve assembly			
Engine type M119.980	06.93-08.96		0 205 003 037
Air mass meter, gasoline injection			
Mot.no. M119.980	06.93-08.96		0 280 217 807
Engine type M119.970	06.93-08.96		0 280 214 004
			0 986 280 121
Speed sensor, ignition/injection	06.93-08.96		0 261 210 055
Knock sensor	06.93-08.96		0 261 231 054
Temperature sensor, intake air, injection system			
Engine type M119.970	06.93-08.96		0 280 130 047
Pedal position sensor, EMS (electronic engine management)	06.93-08.96		0 205 001 302
Duo sensor, acceleration and yaw rate, brake system	05.95-08.96		0 265 005 201
Pressure sensor, ESP, (electronic stability program)	05.95-08.96		0 265 005 300
Wheel speed sensor, front	06.93-08.96	LAB	0 265 001 410
		RAB	0 265 001 408
Wheel speed sensor, rear	06.93-08.96	OAS	0 265 002 220
Fg.no. →A212244	06.93-08.96	ASR,LAB	0 265 002 218
		ASR,RAB	0 265 002 216
500 SE [140]	5,0 l	235-240 kW	M 119.970;980 8 Zyl.
Throttle valve assembly			
Engine type M119.980	02.91-05.93		0 205 003 037
Air mass meter, gasoline injection			
Mot.no. M119.980	02.91-05.93		0 280 217 807
Engine type M119.970	02.91-05.93		0 280 214 004
			0 986 280 121
Speed sensor, ignition/injection	02.91-05.93		0 261 210 055
Knock sensor	02.91-05.93		0 261 231 054
Temperature sensor, intake air, injection system			
Engine type M119.970	02.91-05.93		0 280 130 047
Pedal position sensor, EMS (electronic engine management)	02.91-05.93		0 205 001 302
Acceleration sensor, ABS	02.91-05.93		0 265 005 107
Wheel speed sensor, front	02.91-05.93	LAB	0 265 001 410
		RAB	0 265 001 408
Wheel speed sensor, rear	02.91-05.93	OAS	0 265 002 220
Fg.no. →A212244	02.91-05.93	ASR,LAB	0 265 002 218
		ASR,RAB	0 265 002 234
500 SE, SEL, SEC [126]	5,0 l	164-195 kW	M 117.965 8 Zyl.
Air flow sensor, gasoline injection	09.85-06.91		0 438 121 037
			0 986 439 337
Speed sensor, ignition/injection	09.85-06.91		0 261 210 022
Knock sensor	09.88-06.91		0 261 231 009
Temperature sensor, intake air, injection system	09.85-06.91		0 280 130 047
Temperature sensor, coolant, injection system	09.85-08.87		0 280 130 044
Wheel speed sensor, front	09.85-08.89	ABS,LAB	0 265 001 021
		ABS,RAB	0 265 001 020
	09.89-06.91	LAB	0 265 001 280
		RAB	0 265 001 278

Product



Wheel speed sensor, rear	09.85-06.91		0 265 002 258
	09.87-06.91	ASR,LAB	0 265 002 029
		ASR,RAB	0 265 002 027
500 SEC [140]	5,0 l	235-240 kW	M 119.970;980 8 Zyl.
Throttle valve assembly			
Engine type M119.980	10.92-05.93		0 205 003 037
Air mass meter, gasoline injection			
Mot.no. M119.980	10.92-05.93		0 280 217 807
Engine type M119.970	10.92-05.93		0 280 214 004
			0 986 280 121
Speed sensor, ignition/injection	10.92-05.93		0 261 210 055
Knock sensor	10.92-05.93		0 261 231 054
Temperature sensor, intake air, injection system			
Engine type M119.970	10.92-05.93		0 280 130 047
Pedal position sensor, EMS (electronic engine management)	10.92-05.93		0 205 001 302
Wheel speed sensor, front	10.92-05.93	LAB	0 265 001 410
		RAB	0 265 001 408
Wheel speed sensor, rear	10.92-05.93	OAS	0 265 002 220
Fg.no. →A212244	10.92-05.93	ASR,LAB	0 265 002 218
		ASR,RAB	0 265 002 216
500 4MATIC [220]	5,0 l	225 kW	M 113.966 8 Zyl.
Air mass meter, gasoline injection	09.02-08.05		0 280 217 810
Phase sensor	09.02-08.05	NOC	0 232 103 050
Speed sensor, ignition/injection	09.02-08.05	FKW	0 261 210 170
Knock sensor	09.02-08.05		0 261 231 110
Duo sensor, acceleration and yaw rate, brake system	09.02-08.05		0 265 005 258
Pressure sensor, ESP, (electronic stability program)	09.02-08.05		0 265 005 303
Wheel speed sensor, rear	09.02-08.05	FMS,LAB	0 265 007 121
		FMS,RAB	0 265 007 123
		LAB	0 265 007 008
		LAB,OSS	0 265 007 008
		OSS,RAB	0 265 007 006
		RAB	0 265 007 006
500 4MATIC [221]	5,5 l	285 kW	M 273.968 8 Zyl.
Throttle valve assembly	06.06→		0 280 750 184
Air mass meter, gasoline injection	06.06→		0 280 218 190
Phase sensor	06.06→	LAB	0 232 103 050
Knock sensor	06.06→		0 261 231 188
560 SEC [126]	5,6 l	178 kW	M 117.968 8 Zyl.
Air flow sensor, gasoline injection	10.85-06.91		0 438 121 037
			0 986 439 337
Speed sensor, ignition/injection	10.85-06.91		0 261 210 022
Knock sensor	09.88-06.91		0 261 231 009
Pressure sensor, intake manifold, gasoline	10.85-06.91		0 280 101 003
Temperature sensor, intake air, injection system	10.85-06.91		0 280 130 047
Temperature sensor, coolant, injection system	10.85-08.87		0 280 130 044
Wheel speed sensor, front	10.85-08.89	ABS,LAB	0 265 001 021
		ABS,RAB	0 265 001 020
	09.89-06.91	LAB	0 265 001 280
		RAB	0 265 001 278
Wheel speed sensor, rear	10.85-06.91		0 265 002 258
	09.87-06.91	ASR,LAB	0 265 002 029
		ASR,RAB	0 265 002 027
560 SEC [126]	5,6 l	220 kW	M 117.968 8 Zyl.
Air flow sensor, gasoline injection	10.85-08.87		0 438 121 036
Speed sensor, ignition/injection	10.85-08.87		0 261 210 022
Temperature sensor, intake air, injection system	10.85-08.87		0 280 130 047
Temperature sensor, coolant, injection system	10.85-08.87		0 280 130 044
Wheel speed sensor, front	10.85-08.87	ABS,LAB	0 265 001 021
		ABS,RAB	0 265 001 020



M



Product			
560 SEL [126]	5,6l 177 kW M 117.968 8 Zyl.		
Air flow sensor, gasoline injection	09.87-06.91		0 438 121 037 0 986 439 337
Speed sensor, ignition/injection	09.87-06.91		0 261 210 022
Pressure sensor, intake manifold, gasoline	09.87-06.91		0 280 101 003
Temperature sensor, intake air, injection system	09.87-06.91		0 280 130 047
Wheel speed sensor, front	09.87-08.89	ABS,LAB	0 265 001 021
		ABS,RAB	0 265 001 020
	09.89-06.91	LAB	0 265 001 280
		RAB	0 265 001 278
Wheel speed sensor, rear	09.87-06.91		0 265 002 258
		ASR,LAB	0 265 002 029
		ASR,RAB	0 265 002 027
560 SEL [126]	5,6l 178 kW M 117.968 8 Zyl.		
Air flow sensor, gasoline injection	10.85-06.91		0 438 121 037 0 986 439 337
Speed sensor, ignition/injection	10.85-06.91		0 261 210 022
Knock sensor	09.88-06.91		0 261 231 009
Pressure sensor, intake manifold, gasoline	10.85-06.91		0 280 101 003
Temperature sensor, intake air, injection system	10.85-06.91		0 280 130 047
Temperature sensor, coolant, injection system	10.85-08.87		0 280 130 044
Wheel speed sensor, front	10.85-08.89	ABS,LAB	0 265 001 021
		ABS,RAB	0 265 001 020
	09.89-06.91	LAB	0 265 001 280
		RAB	0 265 001 278
Wheel speed sensor, rear	10.85-06.91		0 265 002 258
	09.87-06.91	ASR,LAB	0 265 002 029
		ASR,RAB	0 265 002 027
560 SEL [126]	5,6l 220 kW M 117.968 8 Zyl.		
Air flow sensor, gasoline injection	10.85-08.87		0 438 121 036
Speed sensor, ignition/injection	10.85-08.87		0 261 210 022
Temperature sensor, intake air, injection system	10.85-08.87		0 280 130 047
Temperature sensor, coolant, injection system	10.85-08.87		0 280 130 044
Wheel speed sensor, front	10.85-08.87	ABS,LAB	0 265 001 021
		ABS,RAB	0 265 001 020
600 [140]	6,0l 290-300 kW M 120.980;982 12 Zyl.		
Throttle valve assembly			
Mot.no. 021143→,Engine type M120.982	06.93-09.98	LAB	0 205 003 027
		RAB	0 205 003 029
Engine type M120.982	06.93-09.98		0 205 003 037
Air mass meter, gasoline injection			
Engine type M120.980	06.93-09.98		0 280 213 015 0 986 280 126
Engine type M120.982	06.93-09.98		0 280 217 509
Phase sensor	06.93-09.98	NOC	0 232 103 050
Knock sensor	06.93-09.98	LAB	0 261 231 050
		RAB	0 261 231 052
Temperature sensor, intake air, injection system			
Engine type M120.980	06.93-09.98		0 280 130 047
Pedal position sensor, EMS (electronic engine management)	06.93-09.98		0 205 001 302
Acceleration sensor, ABS	06.93-05.94		0 265 005 107
	06.94-09.98		0 265 005 107
Wheel speed sensor, front	06.93-09.98	LAB	0 265 001 410
		RAB	0 265 001 408
Wheel speed sensor, rear	06.93-09.98	OAS	0 265 002 220
Fg.no. →A212244	06.93-09.98	ASR,LAB	0 265 002 218
		ASR,RAB	0 265 002 216
600 [220]	5,5l 368 kW M 275.950 12 Zyl.		
Speed sensor, ignition/injection	09.02-08.05		0 261 210 170
Knock sensor	09.02-08.05		0 261 231 110
Duo sensor, acceleration and yaw rate, brake system	09.02-08.05		0 265 005 258



Pressure sensor, ESP, (electronic stability program)	09.02-08.05		0 265 005 303
Wheel speed sensor, front	09.02-08.05		0 265 007 128
Wheel speed sensor, rear	09.02-08.05	LAB	0 265 007 121
		RAB	0 265 007 123
600 [220]	5,8l 270 kW M 137.970 12 Zyl.		
Air mass meter, gasoline injection	08.99-08.05		0 280 217 810
Speed sensor, ignition/injection	08.99-08.05		0 261 210 170
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. A 322444→	08.99-08.05		0 265 005 258
Fg.no. →A 322443	08.99-08.05		0 265 005 258
Pressure sensor, ESP, (electronic stability program)	08.99-08.05		0 265 005 303
Wheel speed sensor, front	08.99-08.05		0 265 007 002
Wheel speed sensor, rear	08.99-08.02	FMS,LAB	0 265 007 121
		FMS,RAB	0 265 007 123
	08.99-08.05	LAB	0 265 007 008
	08.99-08.02	LAB,OSS	0 265 007 008
		OSS,RAB	0 265 007 006
	08.99-08.05	RAB	0 265 007 006
600 [221]	5,5l 380 kW M 275.953 12 Zyl.		
Throttle valve assembly	12.05→		0 280 750 125
Speed sensor, ignition/injection	12.05→		0 261 210 170
Knock sensor	12.05→		0 261 231 110
600 Coupé [140]	6,0l 290-300 kW M 120.980;982 12 Zyl.		
Throttle valve assembly			
Mot.no. 021143→,Engine type M120.982	06.93-05.96	LAB	0 205 003 027
		RAB	0 205 003 029
Engine type M120.982	06.93-05.96		0 205 003 037
Air mass meter, gasoline injection			
Engine type M120.980	06.93-05.96		0 280 213 015 0 986 280 126
Engine type M120.982	06.93-05.96		0 280 217 509
Phase sensor	06.93-05.96	NOC	0 232 103 050
Knock sensor	06.93-05.96	LAB	0 261 231 050
		RAB	0 261 231 052
Temperature sensor, intake air, injection system			
Engine type M120.980	06.93-05.96		0 280 130 047
Pedal position sensor, EMS (electronic engine management)	06.93-05.96		0 205 001 302
Acceleration sensor, ABS			
Fg.no. →A 290166	06.93-05.96	OFD	0 265 005 107
Duo sensor, acceleration and yaw rate, brake system	05.95-05.96		0 265 005 201
Pressure sensor, ESP, (electronic stability program)	05.95-05.96		0 265 005 300
Wheel speed sensor, front	06.93-05.96	LAB	0 265 001 410
		RAB	0 265 001 408
Wheel speed sensor, rear			
Fg.no. →A212244	06.93-05.96	LAB	0 265 002 218
		RAB	0 265 002 216
600 SE [140]	6,0l 290-300 kW M 120.980;982 12 Zyl.		
Throttle valve assembly			
Mot.no. 021143→,Engine type M120.982	04.91-05.93	LAB	0 205 003 027
		RAB	0 205 003 029
Engine type M120.982	04.91-05.93		0 205 003 037
Air mass meter, gasoline injection			
Engine type M120.980	04.91-05.93		0 280 213 015 0 986 280 126
Engine type M120.982	04.91-05.93		0 280 217 509
Phase sensor	04.91-05.93	FKW	0 281 002 123
		NOC	0 232 103 050
Knock sensor	04.91-05.93	LAB	0 261 231 050
		RAB	0 261 231 052



Product

◀ Serie S

Temperature sensor, intake air, injection system			
Engine type M120.980	04.91-05.93		0 280 130 047
Pedal position sensor, EMS (electronic engine management)	04.91-05.93		0 205 001 302
Acceleration sensor, ABS	04.91-05.93		0 265 005 107
Wheel speed sensor, front	04.91-05.93	LAB	0 265 001 410
		RAB	0 265 001 408
Wheel speed sensor, rear	04.91-05.93	OAS	0 265 002 220
Fg.no. →A212244	04.91-05.93	ASR,LAB	0 265 002 218
		ASR,RAB	0 265 002 216
600 SEC [140]	6,0l 290-300 kW	M 120.980;982	12 Zyl.
Throttle valve assembly			
Mot.no. 021143→,Engine type M120.982	09.92-05.93	LAB	0 205 003 027
		RAB	0 205 003 029
Engine type M120.982	09.92-05.93		0 205 003 037
Air mass meter, gasoline injection			
Engine type M120.980	09.92-05.93		0 280 213 015
			0 986 280 126
Engine type M120.982	09.92-05.93		0 280 217 509
Phase sensor	09.92-05.93	FKW	0 281 002 123
		NOC	0 232 103 050
Knock sensor	09.92-05.93	LAB	0 261 231 050
		RAB	0 261 231 052
Temperature sensor, intake air, injection system			
Engine type M120.980	09.92-05.93		0 280 130 047
Pedal position sensor, EMS (electronic engine management)	09.92-05.93		0 205 001 302
Acceleration sensor, ABS			
Fg.no. →A 290166	09.92-05.93	OFD	0 265 005 107
Wheel speed sensor, front	09.92-05.93	LAB	0 265 001 410
		RAB	0 265 001 408
Wheel speed sensor, rear	09.92-05.93	LAB	0 265 002 218
		RAB	0 265 002 216

Serie SL

55 AMG [230] 5,4l 368 kW M 113.992 8 Zyl.			
Throttle valve assembly	10.01-08.02		0 280 750 015
Phase sensor	10.01-12.05		0 232 103 050
Speed sensor, ignition/injection	10.01-12.05		0 261 210 170
Knock sensor	10.01-12.05		0 261 231 110
Duo sensor, acceleration and yaw rate, brake system	10.01-05.04		0 265 005 258
	06.04-08.05		0 265 005 298
	09.05-12.05		0 265 005 642
Wheel speed sensor, front	10.01-12.05		0 265 007 696
Wheel speed sensor, rear			
Fg.no. F 030152→	10.01-12.05		0 265 007 744
Fg.no. →F 030151	10.01-12.05		0 265 007 585
55 AMG [230] 5,4l 380 kW M 113.995 8 Zyl.			
Phase sensor	01.06→		0 232 103 050
Speed sensor, ignition/injection	01.06→		0 261 210 170
Knock sensor	01.06→		0 261 231 110
Duo sensor, acceleration and yaw rate, brake system	01.06→		0 265 005 642
Wheel speed sensor, front	01.06→		0 265 007 743
Wheel speed sensor, rear	01.06→		0 265 007 744
60 AMG [129] 6,0l 280 kW M 119.982 8 Zyl.			
Phase sensor	07.93-06.98		0 232 103 037
Speed sensor, ignition/injection	07.93-06.98		0 281 002 123
Knock sensor	07.93-06.98		0 261 231 110
Wheel speed sensor, front	07.93-06.98	LAB	0 265 001 224
		RAB	0 265 001 222

Product

Wheel speed sensor, rear	07.93-06.98	OAS	0 265 002 214
Fg.no. F105255→	07.93-06.98	ASR,LAB	0 265 006 186
		ASR,RAB	0 265 006 184
Fg.no. →F105254	07.93-06.98	ASR,LAB	0 265 002 224
		ASR,RAB	0 265 002 222
65 AMG [230] 6,0l 450 kW M 275.981 12 Zyl.			
Speed sensor, ignition/injection	09.04→		0 261 210 170
Knock sensor	09.04→		0 261 231 110
Duo sensor, acceleration and yaw rate, brake system	09.04-08.05		0 265 005 298
	09.05→		0 265 005 642
Wheel speed sensor, front	09.04→		0 265 007 696
Wheel speed sensor, rear	09.04→		0 265 007 744
280 [129] 2,8l 142 kW M 104.943 6 Zyl.			
Air mass meter, gasoline injection			
Mot.no. →001545	07.93-05.98	GS	0 280 217 500
Mot.no. →006577	07.93-05.98	AG	0 280 217 500
Mot.no. 001546→	07.93-05.98	GS	0 280 217 517
Mot.no. 006578→	07.93-05.98	AG	0 280 217 517
Speed sensor, ignition/injection	07.93-05.98		0 261 210 122
Wheel speed sensor, front	07.93-05.98	LAB	0 265 006 132
		RAB	0 265 006 130
Wheel speed sensor, rear	07.93-05.98	OAS	0 265 002 214
Fg.no. F105255→	07.93-05.98	ASR,LAB	0 265 006 186
		ASR,RAB	0 265 006 184
Fg.no. →F105254	07.93-05.98	ASR,LAB	0 265 002 224
		ASR,RAB	0 265 002 222
280 [129] 2,8l 150 kW M 112.923 6 Zyl.			
Throttle valve assembly	06.98-08.01		0 205 003 046
Air mass meter, gasoline injection	06.98-08.01		0 280 217 515
Phase sensor	06.98-08.01		0 232 103 050
Speed sensor, ignition/injection	06.98-08.01		0 261 210 170
Knock sensor	06.98-08.01		0 261 231 110
Duo sensor, acceleration and yaw rate, brake system	06.98-08.01		0 265 005 201
Pressure sensor, ESP, (electronic stability program)			
Fg.no. Ident 07/99→	06.98-08.01		0 265 005 307
Wheel speed sensor, front	06.98-08.01	LAB	0 265 006 292
		RAB	0 265 006 280
Wheel speed sensor, rear	06.98-08.01	LAB	0 265 006 186
		RAB	0 265 006 184
300 SL [107] 3,0l 132 kW M 103.982 6 Zyl.			
Air flow sensor, gasoline injection	09.85-08.89		0 438 121 033
			0 986 439 333
Pressure sensor, intake manifold, gasoline	09.85-08.89		0 280 101 003
Temperature sensor, intake air, injection system	09.85-08.89		0 280 130 047
Temperature sensor, coolant, injection system	09.85-08.89	2PO	0 280 130 044
Wheel speed sensor	09.85-08.86	HI	0 265 002 004
	09.86-08.89	HI	0 265 002 256
		LAB,VO	0 265 001 128
		RAB,VO	0 265 001 126
	09.85-08.86	VO	0 265 001 012
300 SL [107] 3,0l 132-138 kW M 103.982 6 Zyl.			
Air flow sensor, gasoline injection	09.85-08.89		0 438 121 033
			0 986 439 333
Temperature sensor, intake air, injection system	09.85-08.89		0 280 130 047
Temperature sensor, coolant, injection system	09.85-08.89	2PO	0 280 130 044
Wheel speed sensor	09.85-08.86	HI	0 265 002 004
	09.86-08.89	HI	0 265 002 256
		LAB,VO	0 265 001 128
		RAB,VO	0 265 001 126
	09.85-08.86	VO	0 265 001 012



Product			
300 SL [129]	3,0l 140 kW M 103.984 6 Zyl.		
Air flow sensor, gasoline injection	03.89-06.93	0 438 121 033	0 986 439 333
Temperature sensor, intake air, injection system	03.89-06.93	0 280 130 047	
Wheel speed sensor, front	03.89-06.93	LAB 0 265 001 224	RAB 0 265 001 222
Wheel speed sensor, rear	09.90-06.93	ASR,LAB 0 265 002 224	ASR,RAB 0 265 002 222
	03.89-06.93	OAS 0 265 002 202	
300 SL-24 [129]	3,0l 170 kW M 104.981 6 Zyl.		
Air flow sensor, gasoline injection	03.89-06.93	0 438 121 082	F 026 TX2 061
		0 986 439 382	
Temperature sensor, intake air, injection system			
Fg.no. B091699→,F124697→	03.89-06.93	0 280 130 047	
Wheel speed sensor, rear	09.90-06.93	ASR,LAB 0 265 002 224	ASR,RAB 0 265 002 222
	03.89-06.93	OAS 0 265 002 214	
320 [129]	3,2l 165 kW M 112.943 6 Zyl.		
Throttle valve assembly	06.98-08.01	0 205 003 046	
Air mass meter, gasoline injection	06.98-08.01	0 280 217 515	
Phase sensor	06.98-08.01	0 232 103 050	
Speed sensor, ignition/injection	06.98-08.01	0 261 210 170	
Knock sensor	06.98-08.01	0 261 231 110	
Duo sensor, acceleration and yaw rate, brake system	06.98-08.01	0 265 005 201	
Pressure sensor, ESP, (electronic stability program)			
Fg.no. Ident 07/99→	06.98-08.01	0 265 005 307	
Wheel speed sensor, front	06.98-08.01	LAB 0 265 006 292	RAB 0 265 006 280
Wheel speed sensor, rear	06.98-08.01	LAB 0 265 006 186	RAB 0 265 006 184
320 [129]	3,2l 170 kW M 104.991 6 Zyl.		
Air mass meter, gasoline injection			
Mot.no. →12/52,22/62 022857, Comp.no. Code 807	07.93-05.98	0 280 217 500	
Mot.no. 022858→,Comp.no. Code 807	07.93-05.98	0 280 218 080	
Mot.no. 022858→,Comp.no. Code 807	07.93-05.98	0 280 217 517	
Wheel speed sensor, front	07.93-05.98	LAB 0 265 006 132	RAB 0 265 006 130
Wheel speed sensor, rear	07.93-05.98	ASR,LAB 0 265 002 224	ASR,RAB 0 265 002 222
		OAS 0 265 002 214	
350 [230]	3,5l 200 kW M 272.966 6 Zyl.		
Throttle valve assembly	01.06→	0 280 750 017	
Phase sensor	01.06→	LAB 0 232 103 050	
Knock sensor	01.06→	0 261 231 188	
Duo sensor, acceleration and yaw rate, brake system	01.06→	0 265 005 642	
Wheel speed sensor, front	01.06→	0 265 007 743	
Wheel speed sensor, rear	01.06→	0 265 007 744	
350 [230]	3,7l 180 kW M 112.973 6 Zyl.		
Air mass meter, gasoline injection	03.03-12.05	0 280 217 515	
Phase sensor	03.03-12.05	0 232 103 050	
Speed sensor, ignition/injection	03.03-12.05	0 261 210 170	
Knock sensor	03.03-12.05	0 261 231 110	
Duo sensor, acceleration and yaw rate, brake system	03.03-05.04	0 265 005 258	06.04-08.05 0 265 005 298
	09.05-12.05	0 265 005 642	
Wheel speed sensor, front	03.03-12.05	0 265 007 696	
Wheel speed sensor, rear			
Fg.no. F 030152→	03.03-12.05	0 265 007 744	
Fg.no. →F 030151	03.03-12.05	0 265 007 585	



420 SL [107]	4,2l 150-160 kW M 116.964 8 Zyl.		
Air flow sensor, gasoline injection	01.86-08.89	0 438 121 037	0 986 439 337
Knock sensor	09.88-08.89	0 261 231 009	
Temperature sensor, intake air, injection system	01.86-08.89	0 280 130 047	
Temperature sensor, coolant, injection system	01.86-08.87	0 280 130 044	
Wheel speed sensor	01.86-08.86	HI 0 265 002 004	
	09.86-08.89	HI 0 265 002 256	
		LAB,VO 0 265 001 128	
		RAB,VO 0 265 001 126	
	01.86-08.86	VO 0 265 001 012	
500 [129]	5,0l 225 kW M 113.961 8 Zyl.		
Throttle valve assembly	06.98-08.01	0 205 003 048	
Air mass meter, gasoline injection	06.98-08.01	0 280 217 810	
Phase sensor	06.98-08.01	0 232 103 050	
Speed sensor, ignition/injection	06.98-08.01	0 261 210 170	
Knock sensor	06.98-08.01	0 261 231 110	
Pedal position sensor, EMS (electronic engine management)	06.98-08.01	0 205 001 302	
Duo sensor, acceleration and yaw rate, brake system	06.98-08.01	0 265 005 201	
Pressure sensor, ESP, (electronic stability program)			
Fg.no. Ident 07/99→	06.98-08.01	0 265 005 307	
Wheel speed sensor, front	06.98-08.01	LAB 0 265 006 292	RAB 0 265 006 280
Wheel speed sensor, rear	06.98-08.01	LAB 0 265 006 186	RAB 0 265 006 184
500 [129]	5,0l 235-240 kW M 119.972 8 Zyl.		
Air mass meter, gasoline injection	07.93-09.95	0 280 214 004	0 986 280 121
Knock sensor	07.93-09.95	0 261 231 026	
Temperature sensor, intake air, injection system	07.93-09.95	0 280 130 047	
Wheel speed sensor, front	07.93-09.95	LAB 0 265 001 224	RAB 0 265 001 222
Wheel speed sensor, rear	07.93-09.95	OAS 0 265 002 214	
Fg.no. F105255→	07.93-09.95	ASR,LAB 0 265 006 186	ASR,RAB 0 265 006 184
Fg.no. →F105254	07.93-09.95	ASR,LAB 0 265 002 224	ASR,RAB 0 265 002 222
500 [129]	5,0l 235-240 kW M 119.982 8 Zyl.		
Phase sensor	09.95-05.98	0 232 103 037	
Speed sensor, ignition/injection	09.95-05.98	0 281 002 123	
Knock sensor	09.95-05.98	0 261 231 110	
Wheel speed sensor, front	09.95-05.98	LAB 0 265 001 224	RAB 0 265 001 222
Wheel speed sensor, rear	09.95-05.98	OAS 0 265 002 214	
Fg.no. F105255→	09.95-05.98	ASR,LAB 0 265 006 186	ASR,RAB 0 265 006 184
Fg.no. →F105254	09.95-05.98	ASR,LAB 0 265 002 224	ASR,RAB 0 265 002 222
500 [230]	5,0l 225 kW M 113.963 8 Zyl.		
Throttle valve assembly	10.01-08.02	0 280 750 015	
Air mass meter, gasoline injection	10.01-12.05	0 280 217 810	
Phase sensor	10.01-12.05	0 232 103 050	
Speed sensor, ignition/injection	10.01-12.05	0 261 210 170	
Knock sensor	10.01-12.05	0 261 231 110	
Duo sensor, acceleration and yaw rate, brake system	10.01-05.04	0 265 005 258	06.04-08.05 0 265 005 298
	09.05-12.05	0 265 005 642	
Wheel speed sensor, front	10.01-12.05	0 265 007 696	
Wheel speed sensor, rear			
Fg.no. F 030152→	10.01-12.05	0 265 007 744	
Fg.no. →F 030151	10.01-12.05	0 265 007 585	



Product



◀ Serie SL

500 [230]		5,5l 285 kW M 273.965 8 Zyl.	
Throttle valve assembly	01.06→		0 280 750 184
Phase sensor	01.06→	LAB	0 232 103 050
Knock sensor	01.06→		0 261 231 188
Duo sensor, acceleration and yaw rate, brake system	01.06→		0 265 005 642
Wheel speed sensor, front	01.06→		0 265 007 743
Wheel speed sensor, rear	01.06→		0 265 007 744
500 SL [107]		5,0l 164-180 kW M 117.964 8 Zyl.	
Air flow sensor, gasoline injection	01.86-08.89		0 438 121 037
			0 986 439 337
Speed sensor, ignition/injection	01.86-08.89		0 261 210 039
Knock sensor	09.88-08.89		0 261 231 009
Temperature sensor, intake air, injection system	01.86-08.89		0 280 130 047
Temperature sensor, coolant, injection system	01.86-08.89		0 280 130 044
Wheel speed sensor	01.86-08.86	HI	0 265 002 004
		HI	0 265 002 256
		LAB,VO	0 265 001 128
		RAB,VO	0 265 001 126
	01.86-08.86	VO	0 265 001 012
500 SL [129]		5,0l 235-240 kW M 119.960 8 Zyl.	
Air flow sensor, gasoline injection	03.89-08.92		F 026 TX2 057
			0 986 TX2 057
Knock sensor	03.89-08.92		0 261 231 026
Temperature sensor, intake air, injection system	03.89-08.92		0 280 130 047
Wheel speed sensor, front	03.89-08.92	LAB	0 265 001 224
		RAB	0 265 001 222
Wheel speed sensor, rear	03.89-08.92	OAS	0 265 002 214
Fg.no. F105255→	03.89-08.92	ASR,LAB	0 265 006 186
		ASR,RAB	0 265 006 184
Fg.no. →F105254	03.89-08.92	ASR,LAB	0 265 002 224
		ASR,RAB	0 265 002 222
500 SL [129]		5,0l 235-240 kW M 119.972 8 Zyl.	
Air mass meter, gasoline injection	09.92-06.93		0 280 214 004
			0 986 280 121
Knock sensor	09.92-06.93		0 261 231 026
Temperature sensor, intake air, injection system	09.92-06.93		0 280 130 047
Wheel speed sensor, front	09.92-06.93	LAB	0 265 001 224
		RAB	0 265 001 222
Wheel speed sensor, rear	09.92-06.93	OAS	0 265 002 214
Fg.no. F105255→	09.92-06.93	ASR,LAB	0 265 006 186
		ASR,RAB	0 265 006 184
Fg.no. →F105254	09.92-06.93	ASR,LAB	0 265 002 224
		ASR,RAB	0 265 002 222
560 SL [107]		5,6l 178 kW M 117.967 8 Zyl.	
Air flow sensor, gasoline injection	09.85-08.89		0 438 121 037
			0 986 439 337
Speed sensor, ignition/injection	01.86-08.89		0 261 210 039
Pressure sensor, intake manifold, gasoline	09.85-08.89		0 280 101 003
Temperature sensor, coolant, injection system	09.85-08.89		0 280 130 044
Wheel speed sensor	09.85-08.86	HI	0 265 002 004
	09.86-08.89	HI	0 265 002 256
		LAB,VO	0 265 001 128
	RAB,VO	0 265 001 126	
	09.85-08.86	VO	0 265 001 012
600 [129]		6,0l 290 kW M 120.981 12 Zyl.	
Throttle valve assembly	09.93-09.95	LAB	0 205 003 021
		RAB	0 205 003 023
Air mass meter, gasoline injection	07.93-09.95		0 280 213 015
			0 986 280 126
Phase sensor	07.93-09.95	HI,LAB	0 261 210 049
		LAB,VO	0 261 210 070
		RAB,VO	0 261 210 068

Product



Knock sensor	07.93-09.95	LAB	0 261 231 082
		RAB	0 261 231 080
Acceleration sensor, ABS	07.93-09.95		0 265 005 107
Duo sensor, acceleration and yaw rate, brake system	07.93-09.95		0 265 005 201
Pressure sensor, ESP, (electronic stability program)	09.95-09.95		0 265 005 300
Wheel speed sensor, front			
Fg.no. F125158→,Comp. no. Code 806, Comp.no. Code 805	07.93-09.95	LAB	0 265 006 292
		RAB	0 265 006 280
Fg.no. →F125157,Comp. no. Code 805, Comp.no. Code 806	07.93-09.95	LAB	0 265 006 132
Fg.no. →F125157,Comp. no. Code 806, Comp.no. Code 805	07.93-09.95		0 265 006 130
Wheel speed sensor, rear			
Fg.no. F105255→	07.93-09.95	LAB	0 265 006 186
		RAB	0 265 006 184
Fg.no. →F105254	07.93-09.95	LAB	0 265 002 114
		RAB	0 265 002 112
600 [129]		6,0l 290 kW M 120.983 12 Zyl.	
Throttle valve assembly	06.98-08.01		0 205 003 039
Air mass meter, gasoline injection	06.98-08.01		0 280 217 509
Phase sensor	09.95-08.01		0 232 103 037
Speed sensor, ignition/injection	09.95-08.01		0 281 002 123
Knock sensor	09.95-08.01		0 261 231 110
Pedal position sensor, EMS (electronic engine management)	06.98-08.01		0 205 001 302
Acceleration sensor, ABS	09.95-08.01		0 265 005 107
Duo sensor, acceleration and yaw rate, brake system	09.95-08.01		0 265 005 201
Pressure sensor, ESP, (electronic stability program)			
Fg.no. Ident 07/99→	06.98-08.01		0 265 005 307
Wheel speed sensor, front			
Fg.no. F125158→,Comp. no. Code 806, Comp.no. Code 805	09.95-08.01	LAB	0 265 006 292
		RAB	0 265 006 280
Fg.no. →F125157,Comp. no. Code 805, Comp.no. Code 806	09.95-08.01	LAB	0 265 006 132
Fg.no. →F125157,Comp. no. Code 806, Comp.no. Code 805	09.95-08.01		0 265 006 130
Wheel speed sensor, rear			
Fg.no. F105255→	09.95-08.01	LAB	0 265 006 186
		RAB	0 265 006 184
Fg.no. →F105254	09.95-08.01	LAB	0 265 002 114
		RAB	0 265 002 112
600 [230]		5,5l 368 kW M 275.951 12 Zyl.	
Throttle valve assembly	03.03-12.05		0 280 750 125
Speed sensor, ignition/injection	03.03-12.05		0 261 210 170
Knock sensor	03.03-12.05		0 261 231 110
Duo sensor, acceleration and yaw rate, brake system	03.03-05.04		0 265 005 258
	06.04-08.05		0 265 005 298
	09.05-12.05		0 265 005 642
Wheel speed sensor, front	03.03-12.05		0 265 007 696
Wheel speed sensor, rear	03.03-12.05		0 265 007 744
600 [230]		5,5l 380 kW M 275.954 12 Zyl.	
Throttle valve assembly	01.06→		0 280 750 125
Speed sensor, ignition/injection	01.06→		0 261 210 170
Knock sensor	01.06→		0 261 231 110
Duo sensor, acceleration and yaw rate, brake system	01.06→		0 265 005 642
Wheel speed sensor, front	01.06→		0 265 007 743
Wheel speed sensor, rear	01.06→		0 265 007 744
600 SL [129]		6,0l 290 kW M 120.981;983 12 Zyl.	
Throttle valve assembly	07.92-06.93	LAB	0 205 003 021
		RAB	0 205 003 023



Air mass meter, gasoline injection			
Engine type 120.981	07.92-06.93		0 280 213 015 0 986 280 126
Engine type 120.983	07.92-06.93		0 280 217 509
Phase sensor	07.92-06.93		0 232 103 037
Speed sensor, ignition/injection	07.92-06.93		0 281 002 123
Knock sensor			
Engine type M 119.983	07.92-06.93		0 261 231 110
Engine type M 120.981	07.92-06.93	LAB	0 261 231 082
		RAB	0 261 231 080
Acceleration sensor, ABS	07.92-06.93		0 265 005 107
Duo sensor, acceleration and yaw rate, brake system	07.92-06.93		0 265 005 201
Wheel speed sensor, front			
Fg.no. F125158→, Comp. no. Code 806, ~~Comp. no. Code 805~~	07.92-06.93	LAB	0 265 006 292
		RAB	0 265 006 280
Fg.no. →F125157, Comp. no. Code 805, ~~Comp. no. Code 806~~	07.92-06.93	LAB	0 265 006 132
Fg.no. →F125157, Comp. no. Code 806, ~~Comp. no. Code 805~~	07.92-06.93		0 265 006 130
Wheel speed sensor, rear			
Fg.no. F105255→	07.92-06.93	LAB	0 265 006 186
		RAB	0 265 006 184
Fg.no. →F105254	07.92-06.93	LAB	0 265 002 114
		RAB	0 265 002 112

Serie SLK

32 AMG KOMPRESSOR [170]		3,2l	260 kW	M 112.960	6 Zyl.
Phase sensor	06.99-03.04			0 232 103	050
Speed sensor, ignition/injection	06.99-03.04			0 261 210	170
Knock sensor	06.99-03.04			0 261 231	110
55 AMG [171]		5,4l	265 kW	M 113.989	8 Zyl.
Throttle valve assembly	04.04→			0 280 750	017
Air mass meter, gasoline injection	04.04→			0 280 217	810
Phase sensor	04.04→			0 232 103	050
Speed sensor, ignition/injection	04.04→			0 261 210	170
Knock sensor	04.04→			0 261 231	110
200 [170]		2,0l	100 kW	M 111.946	4 Zyl.
Air mass meter, gasoline injection	09.96-01.00	FGK		0 280 217	114
		KUT		0 280 218	081
Speed sensor, ignition/injection	07.98-01.00			0 261 210	170
	09.96-06.98			0 281 002	123
200 KOMPRESSOR [170]		2,0l	120 kW	M 111.958	4 Zyl.
Throttle valve assembly	02.00-03.04			0 280 750	045
Speed sensor, ignition/injection	02.00-03.04			0 261 210	170
200 KOMPRESSOR [170]		2,0l	135 kW	M 111.943	4 Zyl.
Throttle valve assembly	09.96-01.00			0 205 003	044
Air mass meter, gasoline injection	09.96-01.00	FGK		0 280 217	114
		KUT		0 280 218	081
Speed sensor, ignition/injection	07.98-01.00			0 261 210	170
	09.96-06.98			0 281 002	123
Pedal position sensor, EMS (electronic engine management)	09.96-01.00			0 205 001	302
200 KOMPRESSOR [171]		1,8l	120 kW	M 271.944	4 Zyl.
Throttle valve assembly	04.04→			0 280 750	076
Phase sensor	04.04→			0 232 103	050
Speed sensor, ignition/injection	04.04→			0 261 210	170
230 KOMPRESSOR [170]		2,3l	142 kW	M 111.973	4 Zyl.
Throttle valve assembly	09.96-01.00			0 205 003	044
Air mass meter, gasoline injection	09.96-01.00	FGK		0 280 217	114
		KUT		0 280 218	081



Speed sensor, ignition/injection	07.98-01.00		0 261 210 170
	09.96-06.98		0 281 002 123
Pedal position sensor, EMS (electronic engine management)	09.96-01.00		0 205 001 302
230 KOMPRESSOR [170]	2,3l	145 kW M	111.983 4 Zyl.
Throttle valve assembly	02.00-03.04		0 280 750 045
Speed sensor, ignition/injection	02.00-03.04		0 261 210 170
280 [171]	3,0l	170 kW M	272.942 6 Zyl.
Throttle valve assembly	05.05→		0 280 750 017
Air mass meter, gasoline injection	05.05→		0 280 218 190
Phase sensor	05.05→	LAB	0 232 103 050
Knock sensor	05.05→		0 261 231 188
320 [170]	3,2l	160 kW M	112.947 6 Zyl.
Air mass meter, gasoline injection	06.99-03.04	FGK	0 280 217 515
		KUT	0 280 218 082
Phase sensor	06.99-03.04		0 232 103 050
Speed sensor, ignition/injection	06.99-03.04		0 261 210 170
Knock sensor	06.99-03.04		0 261 231 110
350 [171]	3,5l	200 kW M	272.963 6 Zyl.
Throttle valve assembly	04.04→		0 280 750 017
Air mass meter, gasoline injection	04.04→		0 280 218 190
Phase sensor	04.04→	LAB	0 232 103 050
Knock sensor	04.04→		0 261 231 188

Serie SLR

5.4 [199]			
			5,4l 460 kW M 155.980 8 Zyl.
Phase sensor	04.04→		0 232 103 050
Speed sensor, ignition/injection	04.04→		0 261 210 170
Knock sensor	04.04→		0 261 231 110
Duo sensor, acceleration and yaw rate, brake system	04.04→		0 265 005 258
Wheel speed sensor, front	04.04→		0 265 007 743
Wheel speed sensor, rear	04.04→		0 265 007 744
5.4 722 Edition [199]			
			5,4l 478 kW M 155.980 8 Zyl.
Phase sensor	07.06→		0 232 103 050
Speed sensor, ignition/injection	07.06→		0 261 210 170
Knock sensor	07.06→		0 261 231 110
Duo sensor, acceleration and yaw rate, brake system	07.06→		0 265 005 258
Wheel speed sensor, front	07.06→		0 265 007 743
Wheel speed sensor, rear	07.06→		0 265 007 744

Serie V

200 [638 TON]			
			2,0l 95 kW M 111.950 4 Zyl.
Air mass meter, gasoline injection	04.96-09.03		0 280 217 114
Speed sensor, ignition/injection	04.96-09.03	FKW	0 261 210 170
Wheel speed sensor, front	04.96-09.03		0 265 006 214
Wheel speed sensor, rear	04.96-09.03		0 265 006 215
200 [638 TON]			
			2,0l 100 kW M 111.948 4 Zyl.
Air mass meter, gasoline injection	04.96-09.03		0 280 217 523
Pedal position sensor, EMS (electronic engine management)	04.96-09.03		0 205 001 029
Wheel speed sensor, front	04.96-09.03		0 265 006 214
Wheel speed sensor, rear	04.96-09.03		0 265 006 215
200 CDI [638 TON]			
			2,2l 75 kW OM 611.980 4 Zyl.
Air mass meter, diesel	06.99-09.03		0 280 217 114
Speed sensor, diesel	06.99-09.03	FKW	0 261 210 170
High-pressure sensor (CR system)	06.99-09.03		0 281 002 700
Wheel speed sensor, front	06.99-09.03		0 265 006 214
Wheel speed sensor, rear	06.99-09.03		0 265 006 215



Product				

◀ Serie V

220 CDI [638 TON]	2,2l 90 kW OM 611.980 4 Zyl.
Air mass meter, diesel	06.99-09.03 0 280 217 114
Speed sensor, diesel	06.99-09.03 FKW 0 261 210 170
High-pressure sensor (CR system)	06.99-09.03 0 281 002 700
Wheel speed sensor, front	06.99-09.03 0 265 006 214
Wheel speed sensor, rear	06.99-09.03 0 265 006 215
230 [638 TON]	2,3l 105 kW M 111.978 4 Zyl.
Air mass meter, gasoline injection	04.96-09.03 0 280 217 523
Wheel speed sensor, front	04.96-09.03 0 265 006 214
Wheel speed sensor, rear	04.96-09.03 0 265 006 215
230 [638 TON]	2,3l 105 kW M 111.980 4 Zyl.
Air mass meter, gasoline injection	04.96-09.03 0 280 217 114
Speed sensor, ignition/injection	04.96-09.03 0 261 210 170
Wheel speed sensor, front	04.96-09.03 0 265 006 214
Wheel speed sensor, rear	04.96-09.03 0 265 006 215
230 TD [638 TON]	2,3l 72 kW OM 601.970 4 Zyl.
Air mass meter, diesel	04.96-09.03 0 280 217 523
Pedal position sensor, diesel	04.96-09.03 0 205 001 029
Wheel speed sensor, front	04.96-09.03 0 265 006 214
Wheel speed sensor, rear	04.96-09.03 0 265 006 215
280 [638 TON]	2,8l 128 kW M 104.900 6 Zyl.
Air mass meter, gasoline injection	04.96-09.03 0 280 217 523
Pedal position sensor, EMS (electronic engine management)	04.96-09.03 0 205 001 029
Wheel speed sensor, front	04.96-09.03 0 265 006 214
Wheel speed sensor, rear	04.96-09.03 0 265 006 215

Serie 124

200	2,0l 75-80 kW M 102.922 4 Zyl.
Speed sensor, ignition/injection	12.84-10.90 0 261 210 066
Wheel speed sensor, front	
Fg.no. A060862→	12.84-10.90 LAB 0 265 001 284
	RAB 0 265 001 282
Fg.no. →A060861	12.84-10.90 LAB 0 265 001 128
	RAB 0 265 001 126
Wheel speed sensor, rear	
Fg.no. A203047→	12.84-10.90 0 265 002 208
200 CE Cabrio	2,0l 100 kW M 111.940 4 Zyl.
Speed sensor, ignition/injection	06.91-06.93 0 261 210 055
Wheel speed sensor, front	06.91-06.93 LAB 0 265 006 111
	RAB 0 265 006 109
Wheel speed sensor, rear	06.91-06.93 0 265 002 254
200 CE Coupé	2,0l 90 kW M 102.963 4 Zyl.
Air flow sensor, gasoline injection	09.89-06.93 KAT,VFA 0 438 121 043
	☛ 0 986 439 343
	OKA 0 986 439 301
	☛ F 026 TX2 060
Speed sensor, ignition/injection	09.89-06.93 0 261 210 066
Temperature sensor, intake air, injection system	09.89-06.93 KAT,VFA 0 280 130 047
Temperature sensor, coolant, injection system	09.89-06.93 OKA 0 280 130 035
Mot.no. →009689	09.89-06.93 2PO,AG, 0 280 130 044
	KAT
Mot.no. →036265	09.89-06.93 2PO,GS, 0 280 130 044
	KAT
Wheel speed sensor, front	09.89-06.93 LAB 0 265 001 284
	RAB 0 265 001 282
Wheel speed sensor, rear	09.89-06.93 0 265 002 208
200 CE Coupé	2,0l 100 kW M 111.940 4 Zyl.
Speed sensor, ignition/injection	09.92-06.93 0 261 210 055
Wheel speed sensor, front	
Fg.no. C009356→,B891779→C009354,	09.92-06.93 LAB 0 265 006 111
Comp. no. Code 859	RAB 0 265 006 109

Product				

Wheel speed sensor, front			
Fg.no. →C009355,B891779→C009354,	09.92-06.93 LAB 0 265 001 284		
Comp.no. Code 859	RAB 0 265 001 282		
Wheel speed sensor, rear	09.92-06.93 0 265 002 208		
200 D	2,0l 53-55 kW OM 601.912 4 Zyl.		
Wheel speed sensor, front			
Fg.no. A060862→	12.84-06.93 LAB 0 265 001 284		
	RAB 0 265 001 282		
Fg.no. →A060861	12.84-06.93 LAB 0 265 001 128		
	RAB 0 265 001 126		
Wheel speed sensor, rear			
Fg.no. A203047→	12.84-06.93 0 265 002 208		
200 E	2,0l 87-90 kW M 102.963 4 Zyl.		
Air flow sensor, gasoline injection	06.86-10.92 KAT,VFA 0 438 121 043		
	☛ 0 986 439 343		
	OKA 0 986 439 301		
	☛ F 026 TX2 060		
Speed sensor, ignition/injection	06.86-10.92 0 261 210 066		
Temperature sensor, intake air, injection system	06.86-10.92 KAT,VFA 0 280 130 047		
Temperature sensor, coolant, injection system	06.86-10.92 OKA 0 280 130 035		
Mot.no. →009689	06.86-10.92 2PO,AG, 0 280 130 044		
	KAT		
Mot.no. →036265	06.86-10.92 2PO,GS, 0 280 130 044		
	KAT		
Wheel speed sensor, front			
Fg.no. A060862→	06.86-10.92 LAB 0 265 001 284		
	RAB 0 265 001 282		
Fg.no. →A060861	06.86-10.92 LAB 0 265 001 128		
	RAB 0 265 001 126		
Wheel speed sensor, rear			
Fg.no. A203047→	06.86-10.92 0 265 002 208		
200 E	2,0l 100 kW M 111.940 4 Zyl.		
Speed sensor, ignition/injection	09.92-06.93 0 261 210 055		
Wheel speed sensor, front			
Fg.no. C009356→,B891779→C009354,	09.92-06.93 LAB 0 265 006 111		
Comp. no. Code 859	RAB 0 265 006 109		
Fg.no. →C009355,B891779→C009354,	09.92-06.93 LAB 0 265 001 284		
Comp.no. Code 859	RAB 0 265 001 282		
Wheel speed sensor, rear	09.92-06.93 0 265 002 208		
220 CE Cabrio	2,2l 110 kW M 111.960 4 Zyl.		
Air mass meter, gasoline injection	07.91-06.93 0 280 217 100		
Speed sensor, ignition/injection			
Mot.no. →079783	07.91-06.93 AG,LLE 0 261 210 055		
Mot.no. →080036	07.91-06.93 GS,LLE 0 261 210 055		
Mot.no. 079784→	07.91-06.93 GS,LLE 0 261 210 122		
Mot.no. 080037→	07.91-06.93 AG,LLE 0 261 210 122		
Knock sensor			
Mot.no. →079783	07.91-06.93 AG 0 261 231 098		
Mot.no. →080036	07.91-06.93 GS 0 261 231 098		
Wheel speed sensor, front	07.91-06.93 LAB 0 265 006 111		
	RAB 0 265 006 109		
Wheel speed sensor, rear	07.91-06.93 0 265 002 254		
220 CE Coupé	2,2l 110 kW M 111.960 4 Zyl.		
Air mass meter, gasoline injection	09.92-06.93 0 280 217 100		
Speed sensor, ignition/injection			
Mot.no. →079783	09.92-06.93 AG,LLE 0 261 210 055		
Mot.no. →080036	09.92-06.93 GS,LLE 0 261 210 055		
Mot.no. 079784→	09.92-06.93 GS,LLE 0 261 210 122		
Mot.no. 080037→	09.92-06.93 AG,LLE 0 261 210 122		
Knock sensor			
Mot.no. →079783	09.92-06.93 AG 0 261 231 098		
Mot.no. →080036	09.92-06.93 GS 0 261 231 098		



Wheel speed sensor, front			
Fg.no. C009356→,B891779→C009354,	09.92-06.93	LAB	0 265 006 111
Comp. no. Code 859		RAB	0 265 006 109
Fg.no. →C009355,B891779→C009354,	09.92-06.93	LAB	0 265 001 284
Comp. no. Code 859		RAB	0 265 001 282
Wheel speed sensor, rear	09.92-06.93		0 265 002 208
220 E	2,2l 110 kW M 111.960 4 Zyl.		
Air mass meter, gasoline injection	09.92-06.93		0 280 217 100
Speed sensor, ignition/injection			
Mot.no. →079783	09.92-06.93	AG,LLE	0 261 210 055
Mot.no. →080036	09.92-06.93	GS,LLE	0 261 210 055
Mot.no. 079784→	09.92-06.93	GS,LLE	0 261 210 122
Mot.no. 080037→	09.92-06.93	AG,LLE	0 261 210 122
Knock sensor			
Mot.no. →079783	09.92-06.93	AG	0 261 231 098
Mot.no. →080036	09.92-06.93	GS	0 261 231 098
Wheel speed sensor, front			
Fg.no. C009356→,B891779→C009354,	09.92-06.93	LAB	0 265 006 111
Comp. no. Code 859		RAB	0 265 006 109
Fg.no. →C009355,B891779→C009354,	09.92-06.93	LAB	0 265 001 284
Comp. no. Code 859		RAB	0 265 001 282
Wheel speed sensor, rear	09.92-06.93		0 265 002 208
230 CE Coupé	2,3l 97-100 kW M 102.982 4 Zyl.		
Air flow sensor, gasoline injection	03.87-08.92	KAT,VFA	0 438 121 043
		☛ 0 986 439 343	
		OKA	0 986 439 301
		☛ F 026 TX2 060	
Speed sensor, ignition/injection	03.87-08.92		0 261 210 066
Temperature sensor, intake air, injection system	03.87-08.92		0 280 130 047
Temperature sensor, coolant, injection system	03.87-08.92	OKA	0 280 130 035
		2PO,KAT	0 280 130 044
Wheel speed sensor, front	03.87-08.92	LAB	0 265 001 284
		RAB	0 265 001 282
Wheel speed sensor, rear	03.87-08.92		0 265 002 208
230 E	2,3l 97-100 kW M 102.982 4 Zyl.		
Air flow sensor, gasoline injection	12.84-06.93	KAT,VFA	0 438 121 043
		☛ 0 986 439 343	
		OKA	0 986 439 301
		☛ F 026 TX2 060	
Speed sensor, ignition/injection	12.84-06.93		0 261 210 066
Temperature sensor, intake air, injection system	12.84-06.93		0 280 130 047
Temperature sensor, coolant, injection system	12.84-06.93	OKA	0 280 130 035
		2PO,KAT	0 280 130 044
Wheel speed sensor, front			
Fg.no. A060862→	12.84-06.93	LAB	0 265 001 284
		RAB	0 265 001 282
Fg.no. →A060861	12.84-06.93	LAB	0 265 001 128
		RAB	0 265 001 126
Wheel speed sensor, rear			
Fg.no. A203047→	12.84-06.93		0 265 002 208
250 D	2,5l 66-69 kW OM 602.912 5 Zyl.		
Wheel speed sensor, front			
Fg.no. A060862→	04.85-08.93	LAB	0 265 001 284
		RAB	0 265 001 282
Fg.no. →A060861	04.85-08.93	LAB	0 265 001 128
		RAB	0 265 001 126
Wheel speed sensor, rear			
Fg.no. A203047→	04.85-08.93		0 265 002 208
250 D	2,5l 69 kW OM 602.912 5 Zyl.		
Wheel speed sensor, front	09.89-06.93	LAB	0 265 001 284
		RAB	0 265 001 282
Wheel speed sensor, rear			
Fg.no. A203047→	09.89-06.93		0 265 002 208



250 D Turbo			
2,5l 93 kW OM 602.962 5 Zyl.			
Air flow sensor, diesel	09.88-06.93		0 281 002 035
Pressure sensor, intake manifold, diesel	09.88-06.93		0 281 002 059
Temperature sensor, coolant, diesel	09.88-06.93		0 280 130 035
Wheel speed sensor, front	09.88-06.93	LAB	0 265 001 284
		RAB	0 265 001 282
Wheel speed sensor, rear			
Fg.no. A203047→	09.88-06.93		0 265 002 208
260 E	2,6l 118-122/125 kW M 103.940 6 Zyl.		
Air flow sensor, gasoline injection	09.85-10.92		0 438 121 033
		☛	0 986 439 333
Speed sensor, ignition/injection	09.85-10.92		0 261 210 051
Temperature sensor, intake air, injection system	09.85-10.92		0 280 130 047
Temperature sensor, coolant, injection system	09.85-10.92	2PO	0 280 130 044
Wheel speed sensor, front			
Fg.no. A060862→	09.85-10.92	LAB	0 265 001 284
		RAB	0 265 001 282
Fg.no. →A060861	09.85-10.92	LAB	0 265 001 128
		RAB	0 265 001 126
Wheel speed sensor, rear			
	09.85-10.92	AOS	0 265 002 210
		ASR,LAB	0 265 002 206
		ASR,RAB	0 265 002 204
260 E 4MATIC	2,6l 118-122 kW M 103.943 6 Zyl.		
Air flow sensor, gasoline injection	09.86-08.92		0 438 121 033
		☛	0 986 439 333
Speed sensor, ignition/injection	09.86-08.92		0 261 210 051
Temperature sensor, intake air, injection system	09.86-08.92		0 280 130 047
Temperature sensor, coolant, injection system			
Mot.no. →000452	09.86-08.92	2PO,GS	0 280 130 044
Mot.no. →001081	09.86-08.92	2PO,AG	0 280 130 044
Wheel speed sensor, front	09.86-08.92	LAB	0 265 001 300
		RAB	0 265 001 298
Wheel speed sensor, rear			
Fg.no. A203047→	09.86-08.92		0 265 002 208
280 E	2,8l 142-145 kW M 104.942 6 Zyl.		
Air mass meter, gasoline injection	09.89-06.93		0 280 217 500
Speed sensor, ignition/injection			
Mot.no. →005789	09.89-06.93	GS,LLE	0 261 210 055
		GS,RLE	0 261 210 066
Mot.no. →048696	09.89-06.93	AG,LLE	0 261 210 055
		AG,RLE	0 261 210 066
Mot.no. 005790→	09.89-06.93	GS	0 261 210 122
Mot.no. 048697→	09.89-06.93	AG	0 261 210 122
Wheel speed sensor, front			
Fg.no. C009356→,B891779→C009354,	09.89-06.93	LAB	0 265 006 111
Comp. no. Code 859		RAB	0 265 006 109
Fg.no. →C009355,B891779→C009354,	09.89-06.93	LAB	0 265 001 284
Comp. no. Code 859		RAB	0 265 001 282
Wheel speed sensor, rear			
	09.89-06.93	AOS	0 265 002 210
		ASR,LAB	0 265 002 206
		ASR,RAB	0 265 002 204
300 AMG E 3.4	3,4l 200 kW M 104.980 6 Zyl.		
Speed sensor, ignition/injection	02.92-02.94		0 261 210 051
Temperature sensor, intake air, injection system			
Fg.no. B091699→,F124697→	02.92-02.94		0 280 130 047
Wheel speed sensor, front			
	02.92-02.94	LAB	0 265 001 284
		RAB	0 265 001 282
Wheel speed sensor, rear			
	02.92-02.94	AOS	0 265 002 210
		ASR,LAB	0 265 002 206
		ASR,RAB	0 265 002 204

Product				

◀ Serie 124

300 AMG CE 3.4 Coupé 3,0l 200 kW M 104.980 6 Zyl.				
Speed sensor, ignition/injection	09.89-08.92			0 261 210 051
Temperature sensor, intake air, injection system				
Fg.no. B091699→,F124697→	09.89-08.92			0 280 130 047
Wheel speed sensor, front	09.89-08.92	LAB		0 265 001 284
		RAB		0 265 001 282
Wheel speed sensor, rear	09.89-08.92	AOS		0 265 002 210
		ASR,LAB		0 265 002 206
		ASR,RAB		0 265 002 204
300 CE Cabrio 3,2l 162 kW M 104.992 6 Zyl.				
Air mass meter, gasoline injection	04.92-04.93			0 280 217 500
Speed sensor, ignition/injection				
Mot.no. →004356	04.92-04.93	GS,LLE		0 261 210 055
Mot.no. →072236	04.92-04.93	AG,LLE		0 261 210 055
Mot.no. 004357→	04.92-04.93	GS,LLE		0 261 210 122
Mot.no. 072237→	04.92-04.93	AG,LLE		0 261 210 122
Wheel speed sensor, front	04.92-04.93	LAB		0 265 006 111
		RAB		0 265 006 109
Wheel speed sensor, rear	04.92-04.93	AOS		0 265 002 244
		ASR,LAB		0 265 002 206
		ASR,RAB		0 265 002 204
300 CE Coupé 3,0l 132-138 kW M 103.983 6 Zyl.				
Air flow sensor, gasoline injection	03.87-06.93			0 438 121 033
				0 986 439 333
Speed sensor, ignition/injection	03.87-06.93			0 261 210 051
Temperature sensor, intake air, injection system	03.87-06.93			0 280 130 047
Temperature sensor, coolant, injection system	03.87-06.93	2PO		0 280 130 044
Wheel speed sensor, front	03.87-06.93	LAB		0 265 001 284
		RAB		0 265 001 282
Wheel speed sensor, rear	03.87-06.93	AOS		0 265 002 208
		ASR,LAB		0 265 002 206
		ASR,RAB		0 265 002 204
300 CE-24 Cabrio 3,0l 162 kW M 104.980 6 Zyl.				
Speed sensor, ignition/injection	04.92-06.93			0 261 210 051
Temperature sensor, intake air, injection system				
Fg.no. B091699→,F124697→	04.92-06.93			0 280 130 047
Wheel speed sensor, front	04.92-06.93	LAB		0 265 001 284
		RAB		0 265 001 282
Wheel speed sensor, rear	04.92-06.93	AOS		0 265 002 244
		ASR,LAB		0 265 002 206
		ASR,RAB		0 265 002 204
300 CE-24 Coupé 3,0l 162/170 kW M 104.980 6 Zyl.				
Speed sensor, ignition/injection	09.89-06.93			0 261 210 051
Temperature sensor, intake air, injection system				
Fg.no. B091699→,F124697→	09.89-06.93			0 280 130 047
Wheel speed sensor, front	09.89-06.93	LAB		0 265 001 284
		RAB		0 265 001 282
Wheel speed sensor, rear	09.89-06.93	AOS		0 265 002 210
		ASR,LAB		0 265 002 206
		ASR,RAB		0 265 002 204
300 D 3,0l 80-83 kW OM 603.912 6 Zyl.				
Wheel speed sensor, front				
Fg.no. A060862→	01.85-06.93	LAB		0 265 001 284
		RAB		0 265 001 282
Fg.no. →A060861	01.85-06.93	LAB		0 265 001 128
		RAB		0 265 001 126
Wheel speed sensor, rear				
Fg.no. A203047→	01.85-06.93			0 265 002 208
300 D Turbo 3,0l 105-108 kW OM 603.960 6 Zyl.				
Air flow sensor, diesel	09.86-06.93			0 281 002 024
				0 281 002 028
Pressure sensor, intake manifold, diesel	09.86-06.93			0 280 101 003
Temperature sensor, coolant, diesel	09.86-06.93			0 280 130 035

Product				

Wheel speed sensor, front	09.86-06.93	LAB		0 265 001 284
		RAB		0 265 001 282
Wheel speed sensor, rear				
Fg.no. A203047→	09.86-06.93			0 265 002 208
300 D Turbo 2.5 2,5l 90 kW OM 602.962 5 Zyl.				
Air flow sensor, diesel	09.89-08.92			0 281 002 035
Pressure sensor, intake manifold, diesel	09.89-08.92			0 281 002 059
Temperature sensor, coolant, diesel	09.89-08.92			0 280 130 035
Wheel speed sensor, front	09.89-08.92	LAB		0 265 001 284
		RAB		0 265 001 282
Wheel speed sensor, rear				
Fg.no. A203047→	09.89-08.92			0 265 002 208
300 D Turbo 4MATIC 3,0l 105/108 kW OM 603.963 6 Zyl.				
Air flow sensor, diesel	09.86-06.93			0 281 002 024
				0 281 002 028
Temperature sensor, coolant, diesel	09.86-06.93			0 280 130 035
Wheel speed sensor, front	09.86-06.93	LAB		0 265 001 300
		RAB		0 265 001 298
Wheel speed sensor, rear				
Fg.no. A203047→	09.86-06.93			0 265 002 208
300 D 4MATIC 3,0l 80-83 kW OM 603.913 6 Zyl.				
Wheel speed sensor, front	09.86-06.93	LAB		0 265 001 300
		RAB		0 265 001 298
Wheel speed sensor, rear				
Fg.no. A203047→	09.86-06.93			0 265 002 208
300 E 3,0l 132-138 kW M 103.980;983 6 Zyl.				
Air flow sensor, gasoline injection	01.85-08.93			0 438 121 033
				0 986 439 333
Speed sensor, ignition/injection	01.85-08.93			0 261 210 051
Pressure sensor, intake manifold, gasoline	01.85-08.93			0 280 101 003
Temperature sensor, intake air, injection system	01.85-08.93			0 280 130 047
Wheel speed sensor, front				
Fg.no. A060862→	01.85-08.93	LAB		0 265 001 284
		RAB		0 265 001 282
Fg.no. →A060861	01.85-08.93	LAB		0 265 001 128
		RAB		0 265 001 126
Wheel speed sensor, rear	01.85-08.93	ASR,LAB		0 265 002 206
		ASR,RAB		0 265 002 204
Fg.no. A203047→	01.85-08.93	AOS		0 265 002 208
300 E 2.8 2,8l 145 kW M 104.942 6 Zyl.				
Air mass meter, gasoline injection	09.89-06.93			0 280 217 500
Speed sensor, ignition/injection				
Mot.no. →005789	09.89-06.93	GS,LLE		0 261 210 055
		GS,RLE		0 261 210 066
Mot.no. →048696	09.89-06.93	AG,LLE		0 261 210 055
		AG,RLE		0 261 210 066
Mot.no. 005790→	09.89-06.93	GS		0 261 210 122
Mot.no. 048697→	09.89-06.93	AG		0 261 210 122
Wheel speed sensor, front				
Fg.no. C009356→,B891779→C009354,	09.89-06.93	LAB		0 265 006 111
Comp. no. Code 859		RAB		0 265 006 109
Fg.no. →C009355,B891779→C009354,	09.89-06.93	LAB		0 265 001 284
Comp.no. Code 859		RAB		0 265 001 282
Wheel speed sensor, rear	09.89-06.93	AOS		0 265 002 210
		ASR,LAB		0 265 002 206
		ASR,RAB		0 265 002 204
300 E 4MATIC 3,0l 132-138 kW M 103.985 6 Zyl.				
Air flow sensor, gasoline injection	09.86-06.93			0 438 121 033
				0 986 439 333
Speed sensor, ignition/injection	09.86-06.93			0 261 210 051
Temperature sensor, intake air, injection system	09.86-06.93			0 280 130 047



M

Product				
Temperature sensor, coolant, injection system				
Mot.no. →002187	09.86-06.93	2PO,GS		0 280 130 044
Mot.no. →008267	09.86-06.93	2PO,AG		0 280 130 044
Wheel speed sensor, front	09.86-06.93	LAB		0 265 001 300
		RAB		0 265 001 298
Wheel speed sensor, rear				
Fg.no. A203047→	09.86-06.93			0 265 002 208
300 E-24	3,0l 162-170 kW	M 104.980	6 Zyl.	
Speed sensor, ignition/injection	09.88-10.92			0 261 210 051
Temperature sensor, intake air, injection system				
Fg.no. B091699→,F124697→	09.88-10.92			0 280 130 047
Wheel speed sensor, front	09.88-10.92	LAB		0 265 001 284
		RAB		0 265 001 282
Wheel speed sensor, rear	09.88-10.92	AOS		0 265 002 210
		ASR,LAB		0 265 002 206
		ASR,RAB		0 265 002 204
320 CE Coupé	3,2l 162 kW	M 104.992	6 Zyl.	
Air mass meter, gasoline injection	09.92-06.93			0 280 217 500
Speed sensor, ignition/injection				
Mot.no. →004356	09.92-06.93	GS,LLE		0 261 210 055
Mot.no. →072236	09.92-06.93	AG,LLE		0 261 210 055
Mot.no. 004357→	09.92-06.93	GS,LLE		0 261 210 122
Mot.no. 072237→	09.92-06.93	AG,LLE		0 261 210 122
Wheel speed sensor, front	09.92-06.93	LAB		0 265 001 284
		RAB		0 265 001 282
Wheel speed sensor, rear	09.92-06.93	AOS		0 265 002 210
		ASR,LAB		0 265 002 206
		ASR,RAB		0 265 002 204
320 E	3,2l 162 kW	M 104.992	6 Zyl.	
Air mass meter, gasoline injection	09.92-06.93			0 280 217 500
Speed sensor, ignition/injection				
Mot.no. →004356	09.92-06.93	GS,LLE		0 261 210 055
Mot.no. →072236	09.92-06.93	AG,LLE		0 261 210 055
Mot.no. 004357→	09.92-06.93	GS,LLE		0 261 210 122
Mot.no. 072237→	09.92-06.93	AG,LLE		0 261 210 122
Wheel speed sensor, front				
Fg.no. C009356→,B891779→C009354,	09.92-06.93	LAB		0 265 006 111
Comp. no. Code 859		RAB		0 265 006 109
Fg.no. →C009355,B891779→C009354,	09.92-06.93	LAB		0 265 001 284
Comp. no. Code 859		RAB		0 265 001 282
Wheel speed sensor, rear	09.92-06.93	AOS		0 265 002 210
		ASR,LAB		0 265 002 206
		ASR,RAB		0 265 002 204
400 E	4,2l 205/210 kW	M 119.975	8 Zyl.	
Air mass meter, gasoline injection	09.91-06.93			0 280 214 004
				0 986 280 121
Speed sensor, ignition/injection	09.91-06.93			0 261 210 085
Knock sensor	09.91-06.93			0 261 231 062
Temperature sensor, intake air, injection system	09.91-06.93			0 280 130 047
Wheel speed sensor, front				
Fg.no. C013141→	09.91-06.93	LAB		0 265 001 284
		RAB		0 265 001 282
Fg.no. →C013142	09.91-06.93	LAB		0 265 006 111
		RAB		0 265 006 109
Wheel speed sensor, rear	09.91-06.93	AOS		0 265 002 210
		ASR,LAB		0 265 002 238
		ASR,RAB		0 265 002 108
500 AMG E 6.0	6,0l 276 kW	M 119.974	8 Zyl.	
Air mass meter, gasoline injection	01.91-06.93			0 280 214 004
				0 986 280 121
Speed sensor, ignition/injection	01.91-06.93			0 261 210 085
Knock sensor	01.91-06.93			0 261 231 062

Product				
Temperature sensor, intake air, injection system	01.91-06.93			0 280 130 047
Wheel speed sensor, front				
Fg.no. C013141→	01.91-06.93	LAB		0 265 001 284
		RAB		0 265 001 282
Fg.no. →C013142	01.91-06.93	LAB		0 265 006 111
		RAB		0 265 006 109
Wheel speed sensor, rear	01.91-06.93	LAB		0 265 002 238
		RAB		0 265 002 108
500 E	5,0l 240 kW	M 119.974	8 Zyl.	
Air mass meter, gasoline injection	01.91-06.93			0 280 214 004
				0 986 280 121
Speed sensor, ignition/injection	01.91-06.93			0 261 210 085
Knock sensor	01.91-06.93			0 261 231 062
Temperature sensor, intake air, injection system	01.91-06.93			0 280 130 047
Wheel speed sensor, front				
Fg.no. C013141→	01.91-06.93	LAB		0 265 001 284
		RAB		0 265 001 282
Fg.no. →C013142	01.91-06.93	LAB		0 265 006 111
		RAB		0 265 006 109
Wheel speed sensor, rear	01.91-06.93	LAB		0 265 002 238
		RAB		0 265 002 108
Serie 124 (T-Modell)				
200 T	2,0l 77-80 kW	M 102.922	4 Zyl.	
Speed sensor, ignition/injection	09.85-05.90			0 261 210 066
Wheel speed sensor, front	09.85-05.90	LAB		0 265 001 284
		RAB		0 265 001 282
Wheel speed sensor, rear				
Fg.no. F005650→	09.85-05.90			0 265 002 208
200 TD	2,0l 53-55 kW	OM 601.912	4 Zyl.	
Wheel speed sensor, front	09.85-08.91	LAB		0 265 001 284
		RAB		0 265 001 282
Wheel speed sensor, rear				
Fg.no. F005650→	09.85-08.91			0 265 002 208
200 TE	2,0l 87-90 kW	M 102.963	4 Zyl.	
Air flow sensor, gasoline injection	09.88-10.92	KAT,VFA		0 438 121 043
				0 986 439 343
		OKA		0 986 439 301
				0 266 TX2 060
Speed sensor, ignition/injection	09.88-10.92			0 261 210 066
Temperature sensor, intake air, injection system	09.88-10.92	KAT,VFA		0 280 130 047
Temperature sensor, coolant, injection system	09.88-10.92	OKA		0 280 130 035
Mot.no. →009689	09.88-10.92	2PO,AG,		0 280 130 044
		KAT		
Mot.no. →036265	09.88-10.92	2PO,GS,		0 280 130 044
		KAT		
Wheel speed sensor, front	09.88-10.92	LAB		0 265 001 284
		RAB		0 265 001 282
Wheel speed sensor, rear				
Fg.no. F005650→	09.88-10.92			0 265 002 208
200 TE	2,0l 100 kW	M 111.940	4 Zyl.	
Speed sensor, ignition/injection	09.92-06.93			0 261 210 055
Wheel speed sensor, front				
Fg.no. F264121→	09.92-06.93	LAB		0 265 006 111
		RAB		0 265 006 109
Fg.no. →F264120	09.92-06.93	LAB		0 265 001 284
		RAB		0 265 001 282
Wheel speed sensor, rear				
Fg.no. F005650→	09.92-06.93			0 265 002 208

Product				

◀ Serie 124 (T-Modell)

220 TE	2,2l 110 kW M 111.960 4 Zyl.
Air mass meter, gasoline injection	09.92-06.93 0 280 217 100
Speed sensor, ignition/injection	
Mot.no. →079783	09.92-06.93 AG, LLE 0 261 210 055
Mot.no. →080036	09.92-06.93 GS, LLE 0 261 210 055
Mot.no. 079784→	09.92-06.93 GS, LLE 0 261 210 122
Mot.no. 080037→	09.92-06.93 AG, LLE 0 261 210 122
Knock sensor	
Mot.no. →079783	09.92-06.93 AG 0 261 231 098
Mot.no. →080036	09.92-06.93 GS 0 261 231 098
Wheel speed sensor, front	
Fg.no. F264121→	09.92-06.93 LAB 0 265 006 111
	RAB 0 265 006 109
Fg.no. →F264120	09.92-06.93 LAB 0 265 001 284
	RAB 0 265 001 282
Wheel speed sensor, rear	
Fg.no. F005650→	09.92-06.93 0 265 002 208
230 TE	2,3l 97-100 kW M 102.982 4 Zyl.
Air flow sensor, gasoline injection	09.85-08.93 KAT, VFA 0 438 121 043
	OKA 0 986 439 343
	F 026 TX2 060
Speed sensor, ignition/injection	09.85-08.93 0 261 210 066
Temperature sensor, intake air, injection system	09.85-08.93 0 280 130 047
Temperature sensor, coolant, injection system	09.85-08.93 OKA 0 280 130 035
	2PO, KAT 0 280 130 044
Wheel speed sensor, front	09.85-08.93 LAB 0 265 001 284
	RAB 0 265 001 282
Wheel speed sensor, rear	
Fg.no. F005650→	09.85-08.93 0 265 002 208
250 TD	2,5l 66-69 kW OM 602.912 5 Zyl.
Wheel speed sensor, front	01.85-06.93 LAB 0 265 001 284
	RAB 0 265 001 282
Wheel speed sensor, rear	
Fg.no. F005650→	01.85-06.93 0 265 002 208
250 TD Turbo	2,5l 93 kW OM 602.962 5 Zyl.
Wheel speed sensor, front	09.90-06.93 LAB 0 265 006 111
	RAB 0 265 006 109
Wheel speed sensor, rear	
Fg.no. F005650→	09.90-06.93 0 265 002 208
260 TE	2,6l 118-122 kW M 103.940 6 Zyl.
Air flow sensor, gasoline injection	09.85-08.92 0 438 121 033
	0 986 439 333
Speed sensor, ignition/injection	09.85-08.92 0 261 210 051
Temperature sensor, intake air, injection system	09.85-08.92 0 280 130 047
Temperature sensor, coolant, injection system	09.85-08.92 2PO 0 280 130 044
Wheel speed sensor, front	09.85-08.92 LAB 0 265 001 284
	RAB 0 265 001 282
Wheel speed sensor, rear	09.85-08.92 ASR, LAB 0 265 002 206
	ASR, RAB 0 265 002 204
Fg.no. F005650→	09.85-08.92 AOS 0 265 002 208
280 TE	2,8l 142 kW M 104.942 6 Zyl.
Air mass meter, gasoline injection	09.92-06.93 0 280 217 500
Speed sensor, ignition/injection	
Mot.no. →005789	09.92-06.93 GS, LLE 0 261 210 055
	GS, RLE 0 261 210 066
Mot.no. →048696	09.92-06.93 AG, LLE 0 261 210 055
	AG, RLE 0 261 210 066
Mot.no. 005790→	09.92-06.93 GS 0 261 210 122
Mot.no. 048697→	09.92-06.93 AG 0 261 210 122
Wheel speed sensor, front	
Fg.no. F264121→	09.92-06.93 LAB 0 265 006 111
	RAB 0 265 006 109

Product				

Wheel speed sensor, front			
Fg.no. →F264120	09.92-06.93 LAB 0 265 001 284		
	RAB 0 265 001 282		
Wheel speed sensor, rear	09.92-06.93 AOS 0 265 002 210		
	ASR, LAB 0 265 002 206		
	ASR, RAB 0 265 002 204		
300 AMG TE 3.4	3,4l 190 kW M 104.980 6 Zyl.		
Speed sensor, ignition/injection	09.89-08.92 0 261 210 051		
Temperature sensor, intake air, injection system			
Fg.no. B091699→, F124697→	09.89-08.92 0 280 130 047		
Wheel speed sensor, front	09.89-08.92 LAB 0 265 001 284		
	RAB 0 265 001 282		
Wheel speed sensor, rear	09.89-08.92 AOS 0 265 002 210		
	ASR, LAB 0 265 002 206		
	ASR, RAB 0 265 002 204		
300 D Turbo 4MATIC T	3,0l 105/108 kW OM 603.963 6 Zyl.		
Air flow sensor, diesel	09.86-06.93 0 281 002 024		
	0 281 002 028		
Temperature sensor, coolant, diesel	09.86-06.93 0 280 130 035		
Wheel speed sensor, front			
Fg.no. F128718→	09.86-06.93 LAB 0 265 001 300		
	RAB 0 265 001 298		
Fg.no. →F128717	09.86-06.93 LAB 0 265 001 400		
	RAB 0 265 001 398		
Wheel speed sensor, rear			
Fg.no. F005650→	09.86-06.93 0 265 002 208		
300 TD	3,0l 80/83 kW OM 603.912 6 Zyl.		
Wheel speed sensor, front	09.86-06.93 LAB 0 265 001 284		
	RAB 0 265 001 282		
Wheel speed sensor, rear			
Fg.no. F005650→	09.86-06.93 0 265 002 208		
300 TD Turbo	3,0l 105-108 kW OM 603.960 6 Zyl.		
Air flow sensor, diesel	09.86-06.93 0 281 002 024		
	0 281 002 028		
Pressure sensor, intake manifold, diesel	09.86-06.93 0 280 101 003		
Temperature sensor, coolant, diesel	09.86-06.93 0 280 130 035		
Wheel speed sensor, front	09.86-06.93 LAB 0 265 006 111		
	RAB 0 265 006 109		
Wheel speed sensor, rear			
Fg.no. F005650→	09.86-06.93 0 265 002 208		
300 TE	3,0l 132-138 kW M 103.983 6 Zyl.		
Air flow sensor, gasoline injection	01.86-08.92 0 438 121 033		
	0 986 439 333		
Speed sensor, ignition/injection	01.86-08.92 0 261 210 051		
Temperature sensor, intake air, injection system	01.86-08.92 0 280 130 047		
Temperature sensor, coolant, injection system	01.86-08.92 2PO 0 280 130 044		
Wheel speed sensor, front	01.86-08.92 LAB 0 265 001 284		
	RAB 0 265 001 282		
Wheel speed sensor, rear	01.86-08.92 ASR, LAB 0 265 002 206		
	ASR, RAB 0 265 002 204		
Fg.no. F005650→	01.86-08.92 AOS 0 265 002 208		
300 TE 4MATIC	3,0l 132/138 kW M 103.985 6 Zyl.		
Air flow sensor, gasoline injection	09.86-06.93 0 438 121 033		
	0 986 439 333		
Speed sensor, ignition/injection	09.86-06.93 0 261 210 051		
Temperature sensor, intake air, injection system	09.86-06.93 0 280 130 047		
Temperature sensor, coolant, injection system			
Mot.no. →002187	09.86-06.93 2PO, GS 0 280 130 044		
Mot.no. →008267	09.86-06.93 2PO, AG 0 280 130 044		



M



Wheel speed sensor, front			
Fg.no. F128718→	09.86-06.93	LAB	0 265 001 300
		RAB	0 265 001 298
Fg.no. →F128717	09.86-06.93	LAB	0 265 001 400
		RAB	0 265 001 398
Wheel speed sensor, rear			
Fg.no. F005650→	09.86-06.93		0 265 002 208
300 TE-24	3,0l 162 kW M 104.980 6 Zyl.		
Speed sensor, ignition/injection	09.89-08.92		0 261 210 051
Temperature sensor, intake air, injection system			
Fg.no. B091699→,F124697→	09.89-08.92		0 280 130 047
Wheel speed sensor, front	09.89-08.92	LAB	0 265 001 284
		RAB	0 265 001 282
Wheel speed sensor, rear	09.89-08.92	AOS	0 265 002 210
		ASR,LAB	0 265 002 206
		ASR,RAB	0 265 002 204
320 TE	3,2l 162 kW M 104.992 6 Zyl.		
Air mass meter, gasoline injection	09.92-06.93		0 280 217 500
Speed sensor, ignition/injection			
Mot.no. →004356	09.92-06.93	GS,LLE	0 261 210 055
Mot.no. →072236	09.92-06.93	AG,LLE	0 261 210 055
Mot.no. 004357→	09.92-06.93	GS,LLE	0 261 210 122
Mot.no. 072237→	09.92-06.93	AG,LLE	0 261 210 122
Wheel speed sensor, front			
Fg.no. F264121→	09.92-06.93	LAB	0 265 006 111
		RAB	0 265 006 109
Fg.no. →F264120	09.92-06.93	LAB	0 265 001 284
		RAB	0 265 001 282
Wheel speed sensor, rear	09.92-06.93	AOS	0 265 002 210
		ASR,LAB	0 265 002 206
		ASR,RAB	0 265 002 204

Serie 190

190 [201]	2,0l 63/66 kW M 102.921; M 102.938 4 Zyl.		
Wheel speed sensor, front	10.82-09.88	LAB	0 265 001 128
		RAB	0 265 001 126
Wheel speed sensor, rear			
Fg.no. A287298→	10.82-09.88		0 265 002 230
Fg.no. →A287297	10.82-09.88		0 265 002 008
190 [201]	2,0l 75-77 kW M 102.924 4 Zyl.		
Speed sensor, ignition/injection	09.88-08.93		0 261 210 055
Wheel speed sensor, front	09.88-08.93	LAB	0 265 001 288
		RAB	0 265 001 286
Wheel speed sensor, rear	09.88-08.93	EDS	0 265 002 232
		OED	0 265 002 230
190 D [201]	2,0l 53/55 kW OM 601.911 4 Zyl.		
Wheel speed sensor, front	09.83-08.93	LAB	0 265 001 288
		RAB	0 265 001 286
Wheel speed sensor, rear	09.83-08.93	EDS	0 265 002 232
		OED	0 265 002 230
190 D 2.5 [201]	2,5l 66/69 kW OM 602.911 5 Zyl.		
Wheel speed sensor, front	04.85-08.93	LAB	0 265 001 288
		RAB	0 265 001 286
Wheel speed sensor, rear	04.85-08.93	EDS	0 265 002 232
		OED	0 265 002 230
190 D 2.5 Turbo [201]	2,5l 90 kW OM 602.961 5 Zyl.		
Wheel speed sensor, front	01.88-12.88	LAB	0 265 001 288
		RAB	0 265 001 286
Wheel speed sensor, rear	01.88-12.88		0 265 002 232
190 D 2.5 Turbo [201]	2,5l 93 kW OM 602.961 5 Zyl.		
Air flow sensor, diesel	09.88-08.93		0 281 002 035
Temperature sensor, coolant, diesel	09.88-08.93		0 280 130 035



Wheel speed sensor, front	09.88-08.93	LAB	0 265 001 288
		RAB	0 265 001 286
Wheel speed sensor, rear	09.88-08.93		0 265 002 232
190 E [201]	2,0l 83 kW M 102.961 4 Zyl.		
Temperature sensor, intake air, injection system	09.84-08.86		0 280 130 047
Temperature sensor, coolant, injection system	09.84-08.86		0 280 130 035
Wheel speed sensor, front	09.84-08.86	LAB	0 265 001 288
		RAB	0 265 001 286
Wheel speed sensor, rear	09.84-08.86	EDS	0 265 002 232
		OED	0 265 002 230
190 E [201]	2,0l 85 kW M 102.962 4 Zyl.		
Air flow sensor, gasoline injection			
Mot.no. 026320→	09.85-08.86	AG	0 438 121 043
			0 986 439 343
Mot.no. 052714→	09.85-08.86	GS	0 438 121 043
			0 986 439 343
Speed sensor, ignition/injection	09.85-08.86		0 261 210 055
Temperature sensor, intake air, injection system	09.85-08.86		0 280 130 047
Temperature sensor, coolant, injection system			
Mot.no. →122335	09.85-08.86	AG	0 280 130 044
Mot.no. →236868	09.85-08.86	GS	0 280 130 044
Wheel speed sensor, front	09.85-08.86	LAB	0 265 001 288
		RAB	0 265 001 286
Wheel speed sensor, rear	09.85-08.86	EDS	0 265 002 232
		OED	0 265 002 230
190 E [201]	2,0l 89 kW M 102.961 4 Zyl.		
Air flow sensor, gasoline injection	10.82-08.89		0 986 439 301
			0 F 026 TX2 060
Temperature sensor, intake air, injection system	10.82-08.89		0 280 130 047
Temperature sensor, coolant, injection system	10.82-08.89		0 280 130 035
Wheel speed sensor, front	10.82-08.89	LAB	0 265 001 288
		RAB	0 265 001 286
Wheel speed sensor, rear	10.82-08.89	EDS	0 265 002 232
		OED	0 265 002 230
190 E [201]	2,0l 90 kW M 102.962 4 Zyl.		
Air flow sensor, gasoline injection	09.86-08.88		0 438 121 043
			0 986 439 343
Speed sensor, ignition/injection	09.84-08.88		0 261 210 055
Temperature sensor, intake air, injection system	09.84-08.88		0 280 130 047
Temperature sensor, coolant, injection system	09.84-08.88		0 280 130 044
Wheel speed sensor, front	09.84-08.88	LAB	0 265 001 288
		RAB	0 265 001 286
Wheel speed sensor, rear	09.84-08.88	EDS	0 265 002 232
		OED	0 265 002 230
190 E 1.8 [201]	1,7l 77 kW M 102.919 4 Zyl.		
Air flow sensor, gasoline injection	05.92-08.93	KAT	0 438 121 043
			0 986 439 343
Speed sensor, ignition/injection	05.92-08.93		0 261 210 055
Temperature sensor, intake air, injection system	05.92-08.93		0 280 130 047
Temperature sensor, coolant, injection system	05.92-08.93	KOK	0 280 130 035
Wheel speed sensor, front	05.92-08.93	LAB	0 265 001 288
		RAB	0 265 001 286
Wheel speed sensor, rear	05.92-08.93	EDS	0 265 002 232
		OED	0 265 002 230
190 E 1.8 [201]	1,8l 80 kW M 102.910 4 Zyl.		
Air flow sensor, gasoline injection	03.90-08.93	KAT	0 438 121 043
			0 986 439 343
Speed sensor, ignition/injection	03.90-08.93		0 261 210 055
Temperature sensor, intake air, injection system	03.90-08.93		0 280 130 047
Wheel speed sensor, front	03.90-08.93	LAB	0 265 001 288
		RAB	0 265 001 286
Wheel speed sensor, rear	03.90-08.93	EDS	0 265 002 232
		OED	0 265 002 230



Product



◀ Serie 190

190 E 2.0 [201]		2,0l	87 kW	M 102.962	4 Zyl.
Air flow sensor, gasoline injection					
Mot.no. 026320→	09.86-09.93	AG	0 438 121 043	🔌 0 986 439 343	
Mot.no. 052714→	09.86-09.93	GS	0 438 121 043	🔌 0 986 439 343	
Speed sensor, ignition/injection					
		09.86-09.93		0 261 210 055	
Temperature sensor, intake air, injection system					
		09.86-09.93		0 280 130 047	
Temperature sensor, coolant, injection system					
Mot.no. →122335	09.86-09.93	AG	0 280 130 044		
Mot.no. →236868	09.86-09.93	GS	0 280 130 044		
Wheel speed sensor, front	09.86-09.93	LAB	0 265 001 288		
		RAB	0 265 001 286		
Wheel speed sensor, rear	09.86-09.93	EDS	0 265 002 232		
		OED	0 265 002 230		
190 E 2.3 [201]		2,2l	87 kW	M 102.985	4 Zyl.
Speed sensor, ignition/injection					
		09.84-08.86		0 261 210 055	
Temperature sensor, intake air, injection system					
		09.84-08.86		0 280 130 047	
Temperature sensor, coolant, injection system					
Mot.no. →033729	09.84-08.86	GS	0 280 130 044		
Mot.no. →080064	09.84-08.86	AG	0 280 130 044		
Wheel speed sensor, front	09.84-08.86	LAB	0 265 001 288		
		RAB	0 265 001 286		
Wheel speed sensor, rear	09.84-08.86	EDS	0 265 002 232		
		OED	0 265 002 230		
190 E 2.3 [201]		2,3l	97 kW	M 102.985	4 Zyl.
Air flow sensor, gasoline injection					
09.89-08.92	KAT,VFA	0 438 121 043	🔌 0 986 439 343		
		0 986 439 301	🔌 F 026 TX2 060		
Speed sensor, ignition/injection					
		09.89-08.92		0 261 210 055	
Pressure sensor, intake manifold, gasoline					
		09.89-08.92		0 280 101 003	
Temperature sensor, intake air, injection system					
		09.89-08.92		0 280 130 047	
Temperature sensor, coolant, injection system					
Mot.no. →033729	09.89-08.92	KOK	0 280 130 035		
Mot.no. →080064	09.89-08.92	GS	0 280 130 044		
Mot.no. →080064	09.89-08.92	AG	0 280 130 044		
Wheel speed sensor, front	09.89-08.92	LAB	0 265 001 288		
		RAB	0 265 001 286		
Wheel speed sensor, rear	09.89-08.92		0 265 002 232		
190 E 2.3 [201]		2,3l	100 kW	M 102.985	4 Zyl.
Air flow sensor, gasoline injection					
09.86-08.93	KAT,VFA	0 438 121 043	🔌 0 986 439 343		
		0 986 439 301	🔌 F 026 TX2 060		
Speed sensor, ignition/injection					
		09.86-08.93		0 261 210 055	
Temperature sensor, intake air, injection system					
		09.86-08.93		0 280 130 047	
Temperature sensor, coolant, injection system					
Mot.no. →033729	09.86-08.93	KOK	0 280 130 035		
Mot.no. →080064	09.86-08.93	GS	0 280 130 044		
Mot.no. →080064	09.86-08.93	AG	0 280 130 044		
Wheel speed sensor, front	09.86-08.93	LAB	0 265 001 288		
		RAB	0 265 001 286		
Wheel speed sensor, rear	09.86-08.93		0 265 002 232		
190 E 2.3-16 [201]		2,3l	125 kW	M 102.983	4 Zyl.
Speed sensor, ignition/injection					
		09.85-12.88		0 261 210 066	
Pressure sensor, intake manifold, gasoline					
		09.85-12.88		0 280 101 003	
Temperature sensor, intake air, injection system					
		09.85-12.88		0 280 130 047	
Temperature sensor, coolant, injection system					
		09.85-12.88		0 280 130 044	
Wheel speed sensor, front	09.85-12.88	LAB	0 265 001 128		
		RAB	0 265 001 126		
Wheel speed sensor, rear					
Fg.no. A240012→,F205611→	09.85-12.88		0 265 002 232		
Fg.no. →A240011,→F205610	09.85-12.88		0 265 002 008		

Product



190 E 2.3-16 [201]		2,3l	130/136 kW	M 102.983	4 Zyl.
Speed sensor, ignition/injection		04.84-08.88		0 261 210 066	
Temperature sensor, intake air, injection system		04.84-08.88		0 280 130 047	
Temperature sensor, coolant, injection system		04.84-08.88		0 280 130 044	
Wheel speed sensor, front	04.84-08.88	LAB	0 265 001 128		
		RAB	0 265 001 126		
Wheel speed sensor, rear					
Fg.no. A240012→,F205611→	04.84-08.88	0 265 002 232			
Fg.no. →A240011,→F205610	04.84-08.88	0 265 002 008			
190 E 2.5-16 [201]		2,5l	143/150 kW	M 102.990	4 Zyl.
Speed sensor, ignition/injection		09.88-08.93		0 261 210 066	
Temperature sensor, intake air, injection system		09.88-08.93		0 280 130 047	
Wheel speed sensor, front	09.88-08.93	LAB	0 265 001 288		
		RAB	0 265 001 286		
Wheel speed sensor, rear	09.88-08.93	0 265 002 232			
190 E 2.5-16 Evolution I [201]		2,5l	143-150 kW	M 102.991	4 Zyl.
Speed sensor, ignition/injection		03.89-04.90		0 261 210 066	
Temperature sensor, intake air, injection system		03.89-04.90		0 280 130 047	
Wheel speed sensor, front	03.89-04.90	LAB	0 265 001 128		
		RAB	0 265 001 126		
Wheel speed sensor, rear	03.89-04.90	0 265 002 232			
190 E 2.5-16 Evolution II [201]		2,5l	173 kW	M 102.992	4 Zyl.
Speed sensor, ignition/injection		05.90-08.93		0 261 210 066	
Temperature sensor, intake air, injection system		05.90-08.93		0 280 130 047	
Wheel speed sensor, front	05.90-08.93	LAB	0 265 001 128		
		RAB	0 265 001 126		
Wheel speed sensor, rear	05.90-08.93	0 265 002 232			
190 E 2.6 [201]		2,6l	118/122 kW	M 103.942	6 Zyl.
Air flow sensor, gasoline injection	09.86-08.93	0 438 121 033			
		🔌 0 986 439 333			
Speed sensor, ignition/injection		09.86-08.93		0 261 210 049	
Pressure sensor, intake manifold, gasoline		09.86-08.93		0 280 101 003	
Temperature sensor, intake air, injection system		09.86-08.93		0 280 130 047	
Temperature sensor, coolant, injection system					
Mot.no. →014906	09.86-08.93	GS	0 280 130 044		
Mot.no. →033963	09.86-08.93	AG	0 280 130 044		
Wheel speed sensor, front	09.86-08.93	LAB	0 265 001 288		
		RAB	0 265 001 286		
Wheel speed sensor, rear	09.86-08.93	0 265 002 232			
190 E 3.2 AMG [201]		3,2l	172 kW	M 103.983	6 Zyl.
Air flow sensor, gasoline injection	09.88-08.93	0 438 121 033			
		🔌 0 986 439 333			
Temperature sensor, intake air, injection system		09.88-08.93		0 280 130 047	
Temperature sensor, coolant, injection system					
Mot.no. →181461	09.88-08.93	0 280 130 044			
Wheel speed sensor, front	09.88-08.93	LAB	0 265 001 288		
		RAB	0 265 001 286		
Wheel speed sensor, rear	09.88-08.93	0 265 002 232			

Sprinter

208 CDI [T1N]		2,2l	60 kW	OM 611.987	DE LA	4 Zyl.
Air mass meter, diesel		04.00-05.06		0 280 217 517		
Speed sensor, diesel		04.00-05.06		FKW	0 261 210 170	
High-pressure sensor (CR system)		04.00-05.06		0 281 002 700		
Accelerator pedal module	04.00-05.06				0 281 002 334	
		AG,SEG			0 281 002 336	
Wheel speed sensor, front		04.00-05.06	H01	0 265 004 009		
Wheel speed sensor, rear		04.00-05.06	H01	0 265 004 010		
208 D [T1N]		2,3l	58-60 kW	OM 601.943	4 Zyl.	
Pedal position sensor, diesel		02.95-03.00		0 205 001 029		
Wheel speed sensor, front		02.95-03.00	H01	0 265 004 009		
Wheel speed sensor, rear		02.95-03.00	H01	0 265 004 010		



M

Product



209 CDI [NCV3]	2,1 l 65 kW OM 646.984 DE 22 LA 4 Zyl.
Speed sensor, diesel	04.06→ FKW 0 261 210 170
High-pressure sensor (CR system)	04.06→ 0 281 002 682
Boost pressure sensor, Diesel	04.06→ 0 261 230 143
Duo sensor, acceleration and yaw rate, brake system	04.06→ 0 265 005 628
210 D [T1N]	2,9 l 75 kW OM 602.980 DE LA 5 Zyl.
Speed sensor, diesel	01.97-03.00 OHL 0 281 002 123
Pedal position sensor, diesel	01.97-03.00 0 205 001 029
Wheel speed sensor, front	01.97-03.00 H01 0 265 004 009
Wheel speed sensor, rear	01.97-03.00 H01 0 265 004 010
211 CDI [NCV3]	2,1 l 80 kW OM 646.985 DE 22 LA 4 Zyl.
Speed sensor, diesel	04.06→ FKW 0 261 210 170
High-pressure sensor (CR system)	04.06→ 0 281 002 682
Duo sensor, acceleration and yaw rate, brake system	04.06→ 0 265 005 628
211 CDI [T1N]	2,2 l 80 kW OM 611.981 DE LA 4 Zyl.
Air mass meter, diesel	04.00-05.06 0 280 217 517
Speed sensor, diesel	04.00-05.06 FKW 0 261 210 170
High-pressure sensor (CR system)	04.00-05.06 0 281 002 700
Accelerator pedal module	04.00-05.06 0 281 002 334
	AG,SEG 0 281 002 336
Wheel speed sensor, front	04.00-05.06 H01 0 265 004 009
Wheel speed sensor, rear	04.00-05.06 H01 0 265 004 010
212 D [T1N]	2,9 l 90 kW OM 602.980 DE LA 5 Zyl.
Speed sensor, diesel	02.95-03.00 OHL 0 281 002 123
Pedal position sensor, diesel	02.95-03.00 0 205 001 029
Wheel speed sensor, front	02.95-03.00 H01 0 265 004 009
Wheel speed sensor, rear	02.95-03.00 H01 0 265 004 010
213 CDI [NCV3]	2,1 l 95 kW OM 646.986 DE 22 LA 4 Zyl.
Speed sensor, diesel	04.06→ FKW 0 261 210 170
High-pressure sensor (CR system)	04.06→ 0 281 002 682
Boost pressure sensor, Diesel	
Comp. no. 522630/13	04.06→ TNK 0 261 230 143
Comp. no. 522630/15	04.06→ TNK 0 261 230 153
Duo sensor, acceleration and yaw rate, brake system	04.06→ 0 265 005 628
213 CDI [T1N]	2,2 l 95 kW OM 611.981 DE LA 4 Zyl.
Air mass meter, diesel	04.00-05.06 0 280 217 517
Speed sensor, diesel	04.00-05.06 FKW 0 261 210 170
High-pressure sensor (CR system)	04.00-05.06 0 281 002 700
Accelerator pedal module	04.00-05.06 0 281 002 334
	AG,SEG 0 281 002 336
Wheel speed sensor, front	04.00-05.06 H01 0 265 004 009
Wheel speed sensor, rear	04.00-05.06 H01 0 265 004 010
214 [T1N]	2,3 l 105 kW M 111.979 4 Zyl.
Air mass meter, gasoline injection	02.95-03.00 0 280 217 114
Wheel speed sensor, front	02.95-03.00 H01 0 265 004 009
Wheel speed sensor, rear	02.95-03.00 H01 0 265 004 010
214 [T1N]	2,3 l 105-108 kW M 111.984 4 Zyl.
Air mass meter, gasoline injection	04.00-05.06 0 280 217 114
Speed sensor, ignition/injection	04.00-05.06 FKW 0 261 210 170
Wheel speed sensor, front	04.00-05.06 H01 0 265 004 009
Wheel speed sensor, rear	04.00-05.06 H01 0 265 004 010
214 NGT [T1N]	2,3 l 95 kW M 111 4 Zyl.
Wheel speed sensor, front	04.00-05.06 H01 0 265 004 009
Wheel speed sensor, rear	04.00-05.06 H01 0 265 004 010
215 CDI [NCV3]	2,1 l 110 kW OM 646.9... DE 22 LA 4 Zyl.
Speed sensor, diesel	04.06→ FKW 0 261 210 170
High-pressure sensor (CR system)	04.06→ 0 281 002 682
Duo sensor, acceleration and yaw rate, brake system	04.06→ 0 265 005 628

Product



216 CDI [T1N]	2,7 l 115 kW OM 612.981 DE LA 5 Zyl.
Air mass meter, diesel	04.00-05.06 0 280 217 517
Speed sensor, diesel	04.00-05.06 FKW 0 261 210 170
High-pressure sensor (CR system)	
Mot.no. →30 287865,→40 176145,→50 846433,→60 001942	04.00-05.06 0 281 002 498
Mot.no. 30 287866→,40 176146→,50 846434→,60 001943→	04.00-05.06 0 281 002 700
Accelerator pedal module	04.00-05.06 0 281 002 334
	AG,SEG 0 281 002 336
Wheel speed sensor, front	04.00-05.06 H01 0 265 004 009
Wheel speed sensor, rear	04.00-05.06 H01 0 265 004 010
218 CDI [NCV3]	3,0 l 135 kW OM 642.992 6 Zyl.
Air mass meter, diesel	04.06→ 0 281 002 656
High-pressure sensor (CR system)	04.06→ 0 281 002 504
Duo sensor, acceleration and yaw rate, brake system	04.06→ 0 265 005 628
224 [NCV3]	3,5 l 190 kW M 272.979 6 Zyl.
Air mass meter, gasoline injection	04.06→ 0 280 218 190
Knock sensor	04.06→ 0 261 231 188
Duo sensor, acceleration and yaw rate, brake system	04.06→ 0 265 005 628
308 CDI [T1N]	2,2 l 60 kW OM 611.987 DE LA 4 Zyl.
Air mass meter, diesel	04.00-05.06 0 280 217 517
Speed sensor, diesel	04.00-05.06 FKW 0 261 210 170
High-pressure sensor (CR system)	04.00-05.06 0 281 002 700
Accelerator pedal module	04.00-05.06 AG,SEG 0 281 002 336
	GS 0 281 002 334
Wheel speed sensor, front	04.00-05.06 H01 0 265 004 009
Wheel speed sensor, rear	04.00-05.06 H01 0 265 004 010
308 D, D James Cook [T1N]	2,3 l 58 kW OM 601.943 4 Zyl.
Pedal position sensor, diesel	02.95-03.00 0 205 001 029
Wheel speed sensor, front	02.95-03.00 H01 0 265 004 009
Wheel speed sensor, rear	02.95-03.00 H01 0 265 004 010
309 CDI [NCV3]	2,1 l 65 kW OM 646.984 DE 22 LA 4 Zyl.
Speed sensor, diesel	04.06→ FKW 0 261 210 170
High-pressure sensor (CR system)	04.06→ 0 281 002 682
Boost pressure sensor, Diesel	04.06→ 0 261 230 143
Duo sensor, acceleration and yaw rate, brake system	04.06→ 0 265 005 628
310 D, D James Cook [T1N]	2,9 l 75 kW OM 602.980 DE LA 5 Zyl.
Speed sensor, diesel	01.97-03.00 OHL 0 281 002 123
Pedal position sensor, diesel	01.97-03.00 0 205 001 029
Wheel speed sensor, front	01.97-03.00 H01 0 265 004 009
Wheel speed sensor, rear	01.97-03.00 H01 0 265 004 010
311 CDI	2,2 l 80 kW OM 611 LA 4 Zyl.
Speed sensor, diesel	06.01-12.04 FKW 0 261 210 170
311 CDI [NCV3]	2,1 l 80 kW OM 646.985 DE 22 LA 4 Zyl.
Speed sensor, diesel	04.06→ FKW 0 261 210 170
High-pressure sensor (CR system)	04.06→ 0 281 002 682
Duo sensor, acceleration and yaw rate, brake system	04.06→ 0 265 005 628
311 CDI [T1N]	2,1 l 80 kW OM 611.981 DE LA 4 Zyl.
Air mass meter, diesel	08.02-05.06 0 280 217 517
Speed sensor, diesel	08.02-05.06 FKW 0 261 210 170
High-pressure sensor (CR system)	08.02-05.06 0 281 002 700
Accelerator pedal module	08.02-05.06 AG,SEG 0 281 002 336
	GS 0 281 002 334
Wheel speed sensor, front	08.02-05.06 H01 0 265 004 009
Wheel speed sensor, rear	08.02-05.06 H01 0 265 004 010

Product				
◀ Sprinter				
311 CDI [T1N]	2,2l 80 kW OM 611.981 DE LA 4 Zyl.			
Air mass meter, diesel	04.00-05.06			0 280 217 517
Speed sensor, diesel	04.00-05.06	FKW		0 261 210 170
High-pressure sensor (CR system)	04.00-05.06			0 281 002 700
Accelerator pedal module	04.00-05.06	AG,SEG		0 281 002 336
		GS		0 281 002 334
Wheel speed sensor, front	04.00-05.06	H01		0 265 004 009
Wheel speed sensor, rear	04.00-05.06	H01		0 265 004 010
312 D, D James Cook [T1N]	2,9l 90 kW OM 602.980 DE LA 5 Zyl.			
Speed sensor, diesel	02.95-03.00	OHL		0 281 002 123
Pedal position sensor, diesel	02.95-03.00			0 205 001 029
Wheel speed sensor, front	02.95-03.00	H01		0 265 004 009
Wheel speed sensor, rear	02.95-03.00	H01		0 265 004 010
313 CDI	2,2l 95 kW OM 611 LA 4 Zyl.			
Speed sensor, diesel	06.01→	FKW		0 261 210 170
313 CDI [NCV3]	2,1l 95 kW OM 646.986 DE 22 LA 4 Zyl.			
Speed sensor, diesel	04.06→	FKW		0 261 210 170
High-pressure sensor (CR system)	04.06→			0 281 002 682
Boost pressure sensor, Diesel				
Comp. no. 522630/13	04.06→	TNK		0 261 230 143
Comp. no. 522630/15	04.06→	TNK		0 261 230 153
Duo sensor, acceleration and yaw rate, brake system	04.06→			0 265 005 628
313 CDI [T1N]	2,2l 95 kW OM 611.981 DE LA 4 Zyl.			
Air mass meter, diesel	04.00-05.06			0 280 217 517
Speed sensor, diesel	04.00-05.06	FKW		0 261 210 170
High-pressure sensor (CR system)	04.00-05.06			0 281 002 700
Accelerator pedal module	04.00-05.06	AG,SEG		0 281 002 336
		GS		0 281 002 334
Wheel speed sensor, front	04.00-05.06	H01		0 265 004 009
Wheel speed sensor, rear	04.00-05.06	H01		0 265 004 010
314 [T1N]	2,3l 105 kW M 111.979 4 Zyl.			
Air mass meter, gasoline injection	02.95-03.00			0 280 217 114
Wheel speed sensor, front	02.95-03.00	H01		0 265 004 009
Wheel speed sensor, rear	02.95-03.00	H01		0 265 004 010
314 [T1N]	2,3l 105-108 kW M 111.984 4 Zyl.			
Throttle valve assembly	04.00-05.06			0 280 750 074
Air mass meter, gasoline injection	04.00-05.06			0 280 217 114
Speed sensor, ignition/injection	04.00-05.06	FKW		0 261 210 170
Wheel speed sensor, front	04.00-05.06	H01		0 265 004 009
Wheel speed sensor, rear	04.00-05.06	H01		0 265 004 010
314 James Cook [T1N]	2,3l 105 kW M 111.979 4 Zyl.			
Air mass meter, gasoline injection	02.95-08.02			0 280 217 114
Wheel speed sensor, front	02.95-08.02	H01		0 265 004 009
Wheel speed sensor, rear	02.95-08.02	H01		0 265 004 010
314 James Cook [T1N]	2,3l 105-108 kW M 111.984 4 Zyl.			
Throttle valve assembly	08.02-05.06			0 280 750 074
Air mass meter, gasoline injection	08.02-05.06			0 280 217 114
Speed sensor, ignition/injection	08.02-05.06	FKW		0 261 210 170
Wheel speed sensor, front	08.02-05.06	H01		0 265 004 009
Wheel speed sensor, rear	08.02-05.06	H01		0 265 004 010
314 NGT [T1N]	2,3l 95 kW M 111 4 Zyl.			
Wheel speed sensor, front	04.00-05.06	H01		0 265 004 009
Wheel speed sensor, rear	04.00-05.06	H01		0 265 004 010
315 CDI [NCV3]	2,1l 110 kW OM 646.9... DE 22 LA 4 Zyl.			
Speed sensor, diesel	04.06→	FKW		0 261 210 170
High-pressure sensor (CR system)	04.06→			0 281 002 682
Duo sensor, acceleration and yaw rate, brake system	04.06→			0 265 005 628
316 CDI [T1N]	2,7l 115 kW OM 612.981 DE LA 5 Zyl.			
Air mass meter, diesel	04.00-05.06			0 280 217 517
Speed sensor, diesel	04.00-05.06	FKW		0 261 210 170

Product				
High-pressure sensor (CR system)				
Mot.no. →30 287865,→40 176145,→50 846433,→60 001942	04.00-05.06			0 281 002 498
Mot.no. 30 287866→,40 176146→,50 846434→,60 001943→	04.00-05.06			0 281 002 700
Accelerator pedal module	04.00-05.06	AG,SEG		0 281 002 336
		GS		0 281 002 334
Wheel speed sensor, front	04.00-05.06	H01		0 265 004 009
Wheel speed sensor, rear	04.00-05.06	H01		0 265 004 010
316 CDI [T1N]	2,7l 115 kW OM 647.981 DE 27 LA 5 Zyl.			
Air mass meter, diesel	10.04-05.06			0 281 002 656
Speed sensor, diesel	10.04-05.06	FKW		0 261 210 170
High-pressure sensor (CR system)	10.04-05.06			0 281 002 504
Wheel speed sensor, front	10.04-05.06	H01		0 265 004 009
Wheel speed sensor, rear	10.04-05.06	H01		0 265 004 010
316 CDI James Cook [T1N]	2,7l 115 kW OM 612.981 DE LA 5 Zyl.			
Air mass meter, diesel	04.01-05.06			0 280 217 517
Speed sensor, diesel	04.01-05.06	FKW		0 261 210 170
High-pressure sensor (CR system)				
Mot.no. →30 287865,→40 176145,→50 846433,→60 001942	04.01-05.06			0 281 002 498
Mot.no. 30 287866→,40 176146→,50 846434→,60 001943→	04.01-05.06			0 281 002 700
Accelerator pedal module	04.01-05.06	AG,SEG		0 281 002 336
		GS		0 281 002 334
Wheel speed sensor, front	04.01-05.06	H01		0 265 004 009
Wheel speed sensor, rear	04.01-05.06	H01		0 265 004 010
318 CDI [NCV3]	3,0l 135 kW OM 642.992 6 Zyl.			
Air mass meter, diesel	04.06→			0 281 002 656
High-pressure sensor (CR system)	04.06→			0 281 002 504
Duo sensor, acceleration and yaw rate, brake system	04.06→			0 265 005 628
324 [NCV3]	3,5l 190 kW M 272.979 6 Zyl.			
Air mass meter, gasoline injection	04.06→			0 280 218 190
Knock sensor	04.06→			0 261 231 188
Duo sensor, acceleration and yaw rate, brake system	04.06→			0 265 005 628
408 CDI [T1N]	2,2l 60 kW OM 611.987 DE LA 4 Zyl.			
Air mass meter, diesel	04.00-05.06			0 280 217 517
Speed sensor, diesel	04.00-05.06	FKW		0 261 210 170
High-pressure sensor (CR system)	04.00-05.06			0 281 002 700
Accelerator pedal module	04.00-05.06			0 281 002 334
		AG,SEG		0 281 002 336
Wheel speed sensor, front	04.00-05.06	H01		0 265 004 009
Wheel speed sensor, rear	04.00-05.06	H01		0 265 004 010
408 D [T1N]	2,3l 58 kW OM 601.943 4 Zyl.			
Pedal position sensor, diesel	02.95-03.00			0 205 001 029
Wheel speed sensor, front	02.95-03.00	H01		0 265 004 009
Wheel speed sensor, rear	02.95-03.00	H01		0 265 004 010
410 D [T1N]	2,9l 75 kW OM 602.980 DE LA 5 Zyl.			
Speed sensor, diesel	01.97-03.00	OHL		0 281 002 123
Pedal position sensor, diesel	01.97-03.00			0 205 001 029
Wheel speed sensor, front	01.97-03.00	H01		0 265 004 009
Wheel speed sensor, rear	01.97-03.00	H01		0 265 004 010
411 CDI [NCV3]	2,1l 80 kW OM 646.985 DE 22 LA 4 Zyl.			
Speed sensor, diesel	04.06→	FKW		0 261 210 170
High-pressure sensor (CR system)	04.06→			0 281 002 682
Duo sensor, acceleration and yaw rate, brake system	04.06→			0 265 005 628
411 CDI [T1N]	2,2l 80 kW OM 611.981 DE LA 4 Zyl.			
Air mass meter, diesel	04.00-05.06			0 280 217 517
Speed sensor, diesel	04.00-05.06	FKW		0 261 210 170
High-pressure sensor (CR system)	04.00-05.06			0 281 002 700





Accelerator pedal module	04.00-05.06		0 281 002 334
		AG,SEG	0 281 002 336
Wheel speed sensor, front	04.00-05.06	H01	0 265 004 009
Wheel speed sensor, rear	04.00-05.06	H01	0 265 004 010
412 D [T1N]	2,9l 90 kW OM 602.980 DE LA 5 Zyl.		
Speed sensor, diesel	02.95-03.00	OHL	0 281 002 123
Pedal position sensor, diesel	02.95-03.00		0 205 001 029
Wheel speed sensor, front	02.95-03.00	H01	0 265 004 009
Wheel speed sensor, rear	02.95-03.00	H01	0 265 004 010
413 CDI	2,2l 95 kW OM 611 LA 4 Zyl.		
Speed sensor, diesel	06.01→	FKW	0 261 210 170
413 CDI [T1N]	2,2l 95 kW OM 611.981 DE LA 4 Zyl.		
Air mass meter, diesel	04.00-05.06		0 280 217 517
Speed sensor, diesel	04.00-05.06	FKW	0 261 210 170
High-pressure sensor (CR system)	04.00-05.06		0 281 002 700
Accelerator pedal module	04.00-05.06		0 281 002 334
		AG,SEG	0 281 002 336
Wheel speed sensor, front	04.00-05.06	H01	0 265 004 009
Wheel speed sensor, rear	04.00-05.06	H01	0 265 004 010
414 [T1N]	2,3l 105 kW M 111.979 4 Zyl.		
Air mass meter, gasoline injection	02.95-03.00		0 280 217 114
Wheel speed sensor, front	02.95-03.00	H01	0 265 004 009
Wheel speed sensor, rear	02.95-03.00	H01	0 265 004 010
414 [T1N]	2,3l 105-108 kW M 111.984 4 Zyl.		
Air mass meter, gasoline injection	04.00-05.06		0 280 217 114
Speed sensor, ignition/injection	04.00-05.06	FKW	0 261 210 170
Wheel speed sensor, front	04.00-05.06	H01	0 265 004 009
Wheel speed sensor, rear	04.00-05.06	H01	0 265 004 010
415 CDI [NCV3]	2,1l 110 kW OM 646.9... DE 22 LA 4 Zyl.		
Speed sensor, diesel	04.06→	FKW	0 261 210 170
High-pressure sensor (CR system)	04.06→		0 281 002 682
Duo sensor, acceleration and yaw rate, brake system	04.06→		0 265 005 628
416 CDI [T1N]	2,7l 115 kW OM 612.981 DE LA 5 Zyl.		
Air mass meter, diesel	04.00-05.06		0 280 217 517
Speed sensor, diesel	04.00-05.06	FKW	0 261 210 170
High-pressure sensor (CR system)			
Mot.no. →30 287865, →40 176145, →50 846433, →60 001942	04.00-05.06		0 281 002 498
Mot.no. 30 287866→, 40 176146→, 50 846434→, 60 001943→	04.00-05.06		0 281 002 700
Accelerator pedal module	04.00-05.06		0 281 002 334
		AG,SEG	0 281 002 336
Wheel speed sensor, front	04.00-05.06	H01	0 265 004 009
Wheel speed sensor, rear	04.00-05.06	H01	0 265 004 010
416 CDI [T1N]	2,7l 115 kW OM 647.981 DE 27 LA 5 Zyl.		
Air mass meter, diesel	10.04-05.06		0 281 002 656
Speed sensor, diesel	10.04-05.06	FKW	0 261 210 170
High-pressure sensor (CR system)	10.04-05.06		0 281 002 504
Wheel speed sensor, front	10.04-05.06	H01	0 265 004 009
Wheel speed sensor, rear	10.04-05.06	H01	0 265 004 010
418 CDI [NCV3]	3,0l 135 kW OM 642.992 6 Zyl.		
Air mass meter, diesel	04.06→		0 281 002 656
High-pressure sensor (CR system)	04.06→		0 281 002 504
Duo sensor, acceleration and yaw rate, brake system	04.06→		0 265 005 628
424 [NCV3]	3,5l 190 kW M 272.979 6 Zyl.		
Air mass meter, gasoline injection	04.06→		0 280 218 190
Knock sensor	04.06→		0 261 231 188
Duo sensor, acceleration and yaw rate, brake system	04.06→		0 265 005 628



509 CDI [NCV3]	2,1l 65 kW OM 646.984 DE 22 LA 4 Zyl.		
Speed sensor, diesel	04.06→	FKW	0 261 210 170
High-pressure sensor (CR system)	04.06→		0 281 002 682
Boost pressure sensor, Diesel	04.06→		0 261 230 143
Duo sensor, acceleration and yaw rate, brake system	04.06→		0 265 005 628
511 CDI [NCV3]	2,1l 80 kW OM 646.985 DE 22 LA 4 Zyl.		
Speed sensor, diesel	04.06→	FKW	0 261 210 170
High-pressure sensor (CR system)	04.06→		0 281 002 682
Duo sensor, acceleration and yaw rate, brake system	04.06→		0 265 005 628
515 CDI [NCV3]	2,1l 110 kW OM 646.9... DE 22 LA 4 Zyl.		
Speed sensor, diesel	04.06→	FKW	0 261 210 170
High-pressure sensor (CR system)	04.06→		0 281 002 682
Duo sensor, acceleration and yaw rate, brake system	04.06→		0 265 005 628
518 CDI [NCV3]	3,0l 135 kW OM 642.992 6 Zyl.		
Air mass meter, diesel	04.06→		0 281 002 656
High-pressure sensor (CR system)	04.06→		0 281 002 504
Duo sensor, acceleration and yaw rate, brake system	04.06→		0 265 005 628
524 [NCV3]	3,5l 190 kW M 272.979 6 Zyl.		
Air mass meter, gasoline injection	04.06→		0 280 218 190
Knock sensor	04.06→		0 261 231 188
Duo sensor, acceleration and yaw rate, brake system	04.06→		0 265 005 628
616 CDI [T1N]	2,7l 115 kW OM 612.981 DE LA 5 Zyl.		
Air mass meter, diesel	02.01-05.06		0 280 217 517
Speed sensor, diesel	02.01-05.06	FKW	0 261 210 170
High-pressure sensor (CR system)			
Mot.no. →30 287865, →40 176145, →50 846433, →60 001942	02.01-05.06		0 281 002 498
Mot.no. 30 287866→, 40 176146→, 50 846434→, 60 001943→	02.01-05.06		0 281 002 700
Accelerator pedal module	02.01-05.06		0 281 002 334
		AG,SEG	0 281 002 336
Wheel speed sensor, front	02.01-05.06	H01	0 265 004 009
Wheel speed sensor, rear	02.01-05.06	H01	0 265 004 010

Vaneo

1.6 [414]	1,6l 60/75 kW M 166.961 4 Zyl.		
Speed sensor, ignition/injection	02.02-08.05		0 261 210 170
Duo sensor, acceleration and yaw rate, brake system	02.02-08.05		0 265 005 258
Pressure sensor, ESP, (electronic stability program)	02.02-08.05		0 265 005 303
Wheel speed sensor, front	02.02-08.05	LAB	0 265 006 370
		RAB	0 265 006 368
Wheel speed sensor, rear	02.02-08.05		0 265 006 372
1.7 CDI [414]	1,7l 55/67 kW OM 668.914 4 Zyl.		
Air mass meter, diesel			
Mot.no. →30210110	02.02-08.05		0 281 002 281
Speed sensor, diesel	02.02-08.05		0 261 210 170
High-pressure sensor (CR system)	02.02-08.05		0 281 002 498
Duo sensor, acceleration and yaw rate, brake system	02.02-08.05		0 265 005 258
Pressure sensor, ESP, (electronic stability program)	02.02-08.05		0 265 005 303
Wheel speed sensor, front	02.02-08.05	LAB	0 265 006 370
		RAB	0 265 006 368
Wheel speed sensor, rear	02.02-08.05		0 265 006 372



Product



◀ Vaneo

1.9 [414]		1,9l 92 kW M 166.991 4 Zyl.
Speed sensor, ignition/injection	02.02-08.05	0 261 210 170
Duo sensor, acceleration and yaw rate, brake system	02.02-08.05	0 265 005 258
Pressure sensor, ESP, (electronic stability program)	02.02-08.05	0 265 005 303
Wheel speed sensor, front	02.02-08.05	LAB 0 265 006 370
		RAB 0 265 006 368
Wheel speed sensor, rear	02.02-08.05	0 265 006 372

Vario

0 810 [T2W]		4,2l 75 kW OM 904.904 LA 4 Zyl.
Boost pressure sensor, Diesel		
Mot.no. →040487	09.96-01.01	0 281 002 468
Mot.no. 040488→	09.96-01.01	0 281 002 244
Wheel speed sensor, front	09.96-01.01	AA 0 265 004 012
		NAA 0 265 004 011
Wheel speed sensor, rear	09.96-01.01	LAB 0 265 004 015
		RAB 0 265 004 016

0 812 [T2W]		2,9l 90 kW OM 602.98... LA 5 Zyl.
Speed sensor, diesel	09.96-01.01	OHL 0 281 002 123
Pedal position sensor, diesel	09.96-01.01	0 205 001 029
Wheel speed sensor, front	09.96-01.01	AA 0 265 004 012
		NAA 0 265 004 011
Wheel speed sensor, rear	09.96-01.01	LAB 0 265 004 015
		RAB 0 265 004 016

0 814 [T2W]		4,2l 100 kW OM 904.908 LA 4 Zyl.
Boost pressure sensor, Diesel		
Mot.no. →040487	09.96-01.01	0 281 002 468
Mot.no. 040488→	09.96-01.01	0 281 002 244
Pedal position sensor, diesel	09.96-01.01	0 205 001 029
Wheel speed sensor, front	09.96-01.01	AA 0 265 004 012
		NAA 0 265 004 011
Wheel speed sensor, rear	09.96-01.01	LAB 0 265 004 015
		RAB 0 265 004 016

0 815 [T2W]		4,2l 112 kW OM 904.923 LA 4 Zyl.
Boost pressure sensor, Diesel		
Mot.no. →040487	09.96-01.01	0 281 002 468
Mot.no. 040488→	09.96-01.01	0 281 002 244
Wheel speed sensor, front	09.96-01.01	AA 0 265 004 012
		NAA 0 265 004 011
Wheel speed sensor, rear	09.96-01.01	LAB 0 265 004 015
		RAB 0 265 004 016

512 D [T2W]		2,9l 90 kW OM 602.984 LA 5 Zyl.
Speed sensor, diesel	09.96-01.01	OHL 0 281 002 123
Pedal position sensor, diesel	09.96-01.01	0 205 001 029
Wheel speed sensor, front	09.96-01.01	AA 0 265 004 012
		NAA 0 265 004 011
Wheel speed sensor, rear	09.96-01.01	LAB 0 265 004 015
		RAB 0 265 004 016

612 D [T2W]		2,9l 90 kW OM 602.984,985 LA 5 Zyl.
Speed sensor, diesel	09.96-01.01	OHL 0 281 002 123
Pedal position sensor, diesel	09.96-01.01	0 205 001 029
Wheel speed sensor, front	09.96-01.01	AA 0 265 004 012
		NAA 0 265 004 011
Wheel speed sensor, rear	09.96-01.01	LAB 0 265 004 015
		RAB 0 265 004 016

613 D [T2W]		4,2l 95 kW OM 900.917 (904 LA) 4 Zyl.
Boost pressure sensor, Diesel		
	09.06→	0 281 002 468
Wheel speed sensor, front	09.06→	AA 0 265 004 012
		NAA 0 265 004 011
Wheel speed sensor, rear	09.06→	LAB 0 265 004 015
		RAB 0 265 004 016

Product



614 D [T2W]		4,2l 100 kW OM 904.908 LA 4 Zyl.
Boost pressure sensor, Diesel		
Mot.no. →040487	09.96-01.01	0 281 002 468
Mot.no. 040488→	09.96-01.01	0 281 002 244
Pedal position sensor, diesel	09.96-01.01	0 205 001 029
Wheel speed sensor, front	09.96-01.01	AA 0 265 004 012
		NAA 0 265 004 011
Wheel speed sensor, rear	09.96-01.01	LAB 0 265 004 015
		RAB 0 265 004 016

614 D [T2W]		4,2l 100 kW OM 904.914 LA 4 Zyl.
Boost pressure sensor, Diesel		
Mot.no. →040487	01.01-09.06	0 281 002 468
Mot.no. 040488→	01.01-09.06	0 281 002 244
Wheel speed sensor, front	01.01-09.06	AA 0 265 004 012
		NAA 0 265 004 011
Wheel speed sensor, rear	01.01-09.06	LAB 0 265 004 015
		RAB 0 265 004 016

615 D [T2W]		4,2l 110/112 kW OM 904.923 LA; OM 904.936 LA 4 Zyl.
Boost pressure sensor, Diesel		
Mot.no. →040487	10.98-09.06	0 281 002 468
Mot.no. 040488→	10.98-09.06	0 281 002 244
Wheel speed sensor, front	10.98-09.06	AA 0 265 004 012
		NAA 0 265 004 011
Wheel speed sensor, rear	10.98-09.06	LAB 0 265 004 015
		RAB 0 265 004 016

616 D [T2W]		4,2l 115 kW OM 900.918 (904 LA) 4 Zyl.
Boost pressure sensor, Diesel		
	09.06→	0 281 002 468
Wheel speed sensor, front	09.06→	AA 0 265 004 012
		NAA 0 265 004 011
Wheel speed sensor, rear	09.06→	LAB 0 265 004 015
		RAB 0 265 004 016

618 D [T2W]		4,2l 130 kW OM 900.919 (904 LA) 4 Zyl.
Boost pressure sensor, Diesel		
	09.06→	0 281 002 468
Wheel speed sensor, front	09.06→	AA 0 265 004 012
		NAA 0 265 004 011
Wheel speed sensor, rear	09.06→	LAB 0 265 004 015
		RAB 0 265 004 016

618 D [T2W]		4,2l 130 kW OM 904.964 LA 4 Zyl.
Boost pressure sensor, Diesel		
Mot.no. →040487	06.03-09.06	0 281 002 468
Mot.no. 040488→	06.03-09.06	0 281 002 244
Wheel speed sensor, front	06.03-09.06	AA 0 265 004 012
		NAA 0 265 004 011
Wheel speed sensor, rear	06.03-09.06	LAB 0 265 004 015
		RAB 0 265 004 016

810 DT [T2W]		4,2l 75 kW OM 904.904 LA 4 Zyl.
Boost pressure sensor, Diesel		
Mot.no. →040487	09.96-09.06	0 281 002 468
Mot.no. 040488→	09.96-09.06	0 281 002 244
Pedal position sensor, diesel	09.96-09.06	0 205 001 029
Wheel speed sensor, front	09.96-09.06	AA 0 265 004 012
		NAA 0 265 004 011
Wheel speed sensor, rear	09.96-09.06	LAB 0 265 004 015
		RAB 0 265 004 016

812 D [T2W]		2,9l 90 kW OM 602.984,985 LA 5 Zyl.
Speed sensor, diesel	09.96-09.06	OHL 0 281 002 123
Pedal position sensor, diesel	09.96-09.06	0 205 001 029
Wheel speed sensor, front	09.96-09.06	AA 0 265 004 012
		NAA 0 265 004 011
Wheel speed sensor, rear	09.96-09.06	LAB 0 265 004 015
		RAB 0 265 004 016



Product			
813 D/DA [T2W] 4,2l 95 kW OM 900.917 (904 LA) 4 Zyl.			
Boost pressure sensor, Diesel	09.06→		0 281 002 468
Wheel speed sensor, front	09.06→	AA	0 265 004 012
		NAA	0 265 004 011
Wheel speed sensor, rear	09.06→	LAB	0 265 004 015
		RAB	0 265 004 016
814 D [T2W] 4,2l 100 kW OM 904.908 LA 4 Zyl.			
Boost pressure sensor, Diesel			
Mot.no. →040487	09.96-01.01		0 281 002 468
Mot.no. 040488→	09.96-01.01		0 281 002 244
Pedal position sensor, diesel	09.96-01.01		0 205 001 029
Wheel speed sensor, front	09.96-01.01	AA	0 265 004 012
		NAA	0 265 004 011
Wheel speed sensor, rear	09.96-01.01	LAB	0 265 004 015
		RAB	0 265 004 016
814 D [T2W] 4,2l 100 kW OM 904.914 LA 4 Zyl.			
Boost pressure sensor, Diesel			
Mot.no. →040487	01.01-09.06		0 281 002 468
Mot.no. 040488→	01.01-09.06		0 281 002 244
Wheel speed sensor, front	01.01-09.06	AA	0 265 004 012
		NAA	0 265 004 011
Wheel speed sensor, rear	01.01-09.06	LAB	0 265 004 015
		RAB	0 265 004 016
814 DA [T2W] 4,2l 100-112 kW OM 904.908,923 LA 4 Zyl.			
Boost pressure sensor, Diesel			
Mot.no. →040487	09.96-01.01		0 281 002 468
Mot.no. 040488→	09.96-01.01		0 281 002 244
Pedal position sensor, diesel	09.96-01.01		0 205 001 029
Wheel speed sensor, front	09.96-01.01	AA	0 265 004 012
		NAA	0 265 004 011
Wheel speed sensor, rear	09.96-01.01	LAB	0 265 004 015
		RAB	0 265 004 016
815 D [T2W] 4,2l 110 kW OM 904.923,936 LA 4 Zyl.			
Boost pressure sensor, Diesel			
Mot.no. →040487	01.01-09.06		0 281 002 468
Mot.no. 040488→	01.01-09.06		0 281 002 244
Wheel speed sensor, front	01.01-09.06	AA	0 265 004 012
		NAA	0 265 004 011
Wheel speed sensor, rear	01.01-09.06	LAB	0 265 004 015
		RAB	0 265 004 016
815 DA [T2W] 4,2l 112 kW OM 904.908,923 LA 4 Zyl.			
Boost pressure sensor, Diesel			
Mot.no. →040487	01.96-01.01		0 281 002 468
Mot.no. 040488→	01.96-01.01		0 281 002 244
Pedal position sensor, diesel	01.96-01.01		0 205 001 029
Wheel speed sensor, front	01.96-01.01	AA	0 265 004 012
		NAA	0 265 004 011
Wheel speed sensor, rear	01.96-01.01	LAB	0 265 004 015
		RAB	0 265 004 016
816 D/DA [T2W] 4,2l 115 kW OM 900.918 (904 LA) 4 Zyl.			
Boost pressure sensor, Diesel	09.06→		0 281 002 468
Wheel speed sensor, front	09.06→	AA	0 265 004 012
		NAA	0 265 004 011



Wheel speed sensor, rear	09.06→	LAB	0 265 004 015
		RAB	0 265 004 016
818 D [T2W] 4,2l 130 kW OM 904.964 LA 4 Zyl.			
Boost pressure sensor, Diesel			
Mot.no. →040487	06.03-09.06		0 281 002 468
Mot.no. 040488→	06.03-09.06		0 281 002 244
Wheel speed sensor, front	06.03-09.06	AA	0 265 004 012
		NAA	0 265 004 011
Wheel speed sensor, rear	06.03-09.06	LAB	0 265 004 015
		RAB	0 265 004 016
818 D/DA [T2W] 4,2l 130 kW OM 900.919 (904 LA) 4 Zyl.			
Boost pressure sensor, Diesel	09.06→		0 281 002 468
Wheel speed sensor, front	09.06→	AA	0 265 004 012
		NAA	0 265 004 011
Wheel speed sensor, rear	09.06→	LAB	0 265 004 015
		RAB	0 265 004 016

Viano

2.0 CDI [639 TON] 2,1l 80/85 kW OM 646.981; OM 646.982 4 Zyl.			
Air mass meter, diesel	09.03→		0 281 002 585
Speed sensor, diesel	09.03→		0 261 210 170
High-pressure sensor (CR system)	09.03→		0 281 002 504
Boost pressure sensor, Diesel	09.03→		0 261 230 141
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →195055	09.03→		0 265 005 258
Fg.no. 195056→	09.03→		0 265 005 628
Steering angle sensor, ESP (electronic stability program)	09.03→		0 265 005 429
2.2 CDI [639 TON] 2,1l 110 kW OM 646.982 4 Zyl.			
Air mass meter, diesel	09.03→		0 281 002 585
Speed sensor, diesel	09.03→		0 261 210 170
High-pressure sensor (CR system)	09.03→		0 281 002 504
Boost pressure sensor, Diesel	09.03→		0 261 230 141
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →195055	09.03→		0 265 005 258
Fg.no. 195056→	09.03→		0 265 005 628
Steering angle sensor, ESP (electronic stability program)	09.03→		0 265 005 429
3.0 [639 TON] 3,2l 140 kW M 112.951 6 Zyl.			
Air mass meter, gasoline injection	09.03→		0 280 217 515
Phase sensor	09.03→	NOC	0 232 103 037
Speed sensor, ignition/injection	09.03→	FKW	0 261 210 170
Knock sensor	09.03→		0 261 231 110
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →195055	09.03→		0 265 005 258
Fg.no. 195056→	09.03→		0 265 005 628
Steering angle sensor, ESP (electronic stability program)	09.03→		0 265 005 429
3.0 CDI [639 TON] 3,0l 150 kW OM 642.990 6 Zyl.			
Air mass meter, diesel			
Fg.no. →298499	04.06-11.06		0 281 002 656
High-pressure sensor (CR system)	04.06→		0 281 002 504
Boost pressure sensor, Diesel	04.06→		0 261 230 143
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →195055	04.06→		0 265 005 258
Fg.no. 195056→	04.06→		0 265 005 628
Steering angle sensor, ESP (electronic stability program)	04.06→		0 265 005 429



◀ Viano

3.2 [639 TON]		3,2l 160 kW M 112.951 6 Zyl.
Air mass meter, gasoline injection	09.03→	0 280 217 515
Phase sensor	09.03→ NOC	0 232 103 037
Speed sensor, ignition/injection	09.03→ FKW	0 261 210 170
Knock sensor	09.03→	0 261 231 110
Duo sensor, acceleration and yaw rate, brake system		
Fg.no. →195055	09.03→	0 265 005 258
Fg.no. 195056→	09.03→	0 265 005 628
Steering angle sensor, ESP (electronic stability program)	09.03→	0 265 005 429
3.5 [639 TON]		3,7l 170 kW M 112.976 6 Zyl.
Throttle valve assembly	06.04→	0 280 750 019
Air mass meter, gasoline injection	06.04→	0 280 217 515
Phase sensor	06.04→ NOC	0 232 103 037
Speed sensor, ignition/injection	06.04→ FKW	0 261 210 170
Knock sensor	06.04→	0 261 231 110
Duo sensor, acceleration and yaw rate, brake system		
Fg.no. →195055	06.04→	0 265 005 258
Fg.no. 195056→	06.04→	0 265 005 628
Steering angle sensor, ESP (electronic stability program)	06.04→	0 265 005 429

Vito

108 CDI [638 TON]		2,2l 60 kW OM 611.980 4 Zyl.
Air mass meter, diesel	04.99-09.03	0 280 217 114
Speed sensor, diesel	04.99-09.03 FKW	0 261 210 170
High-pressure sensor (CR system)	04.99-09.03	0 281 002 700
Wheel speed sensor, front	04.99-09.03	0 265 006 214
Wheel speed sensor, rear	04.99-09.03	0 265 006 215
108 D [638 TON]		2,3l 60 kW OM 601.942 4 Zyl.
Air mass meter, diesel	11.95-09.03	0 280 217 523
Pedal position sensor, diesel	11.95-09.03	0 205 001 029
Wheel speed sensor, front	11.95-09.03	0 265 006 214
Wheel speed sensor, rear	11.95-09.03	0 265 006 215
109 CDI [639 TON]		2,1l 65/70 kW OM 646.980; OM 646.983 4 Zyl.
Air mass meter, diesel	10.03→	0 281 002 585
Speed sensor, diesel	10.03→	0 261 210 170
High-pressure sensor (CR system)	10.03→	0 281 002 504
Boost pressure sensor, Diesel	10.03→	0 261 230 141
Duo sensor, acceleration and yaw rate, brake system		
Fg.no. →195055	10.03→	0 265 005 258
Fg.no. 195056→	10.03→	0 265 005 628
Steering angle sensor, ESP (electronic stability program)	10.03→	0 265 005 429
110 CDI [638 TON]		2,2l 75 kW OM 611.980 4 Zyl.
Air mass meter, diesel	04.99-09.03	0 280 217 114
Speed sensor, diesel	04.99-09.03 FKW	0 261 210 170
High-pressure sensor (CR system)	04.99-09.03	0 281 002 700
Wheel speed sensor, front	04.99-09.03	0 265 006 214
Wheel speed sensor, rear	04.99-09.03	0 265 006 215
110 D [638 TON]		2,3l 72 kW OM 601.970 4 Zyl.
Air mass meter, diesel	11.95-09.03	0 280 217 523
Pedal position sensor, diesel	11.95-09.03	0 205 001 029
Wheel speed sensor, front	11.95-09.03	0 265 006 214
Wheel speed sensor, rear	11.95-09.03	0 265 006 215
111 CDI [639 TON]		2,1l 80/85 kW OM 646.981; OM 646.982 4 Zyl.
Air mass meter, diesel	10.03→	0 281 002 585
Speed sensor, diesel	10.03→	0 261 210 170



High-pressure sensor (CR system)	10.03→	0 281 002 504
Boost pressure sensor, Diesel	10.03→	0 261 230 141
Duo sensor, acceleration and yaw rate, brake system		
Fg.no. →195055	10.03→	0 265 005 258
Fg.no. 195056→	10.03→	0 265 005 628
Steering angle sensor, ESP (electronic stability program)	10.03→	0 265 005 429
112 CDI [638 TON]		2,2l 90 kW OM 611.980 4 Zyl.
Air mass meter, diesel	04.99-09.03	0 280 217 114
Speed sensor, diesel	04.99-09.03 FKW	0 261 210 170
High-pressure sensor (CR system)	04.99-09.03	0 281 002 700
Wheel speed sensor, front	04.99-09.03	0 265 006 214
Wheel speed sensor, rear	04.99-09.03	0 265 006 215
113 [638 TON]		2,0l 95 kW M 111.950 4 Zyl.
Air mass meter, gasoline injection	11.95-09.03	0 280 217 114
Speed sensor, ignition/injection	11.95-09.03 FKW	0 261 210 170
Wheel speed sensor, front	11.95-09.03	0 265 006 214
Wheel speed sensor, rear	11.95-09.03	0 265 006 215
113 [638 TON]		2,0l 100 kW M 111.948 4 Zyl.
Air mass meter, gasoline injection	11.95-09.03	0 280 217 523
Pedal position sensor, EMS (electronic engine management)	11.95-09.03	0 205 001 029
Wheel speed sensor, front	11.95-09.03	0 265 006 214
Wheel speed sensor, rear	11.95-09.03	0 265 006 215
114 [638 TON]		2,3l 105 kW M 111.978 4 Zyl.
Air mass meter, gasoline injection	11.95-09.03	0 280 217 523
Wheel speed sensor, front	11.95-09.03	0 265 006 214
Wheel speed sensor, rear	11.95-09.03	0 265 006 215
114 [638 TON]		2,3l 105 kW M 111.980 4 Zyl.
Air mass meter, gasoline injection	11.95-09.03	0 280 217 114
Speed sensor, ignition/injection	11.95-09.03	0 261 210 170
Wheel speed sensor, front	11.95-09.03	0 265 006 214
Wheel speed sensor, rear	11.95-09.03	0 265 006 215
115 CDI [639 TON]		2,1l 110 kW OM 646.982 4 Zyl.
Air mass meter, diesel	10.03→	0 281 002 585
Speed sensor, diesel	10.03→	0 261 210 170
High-pressure sensor (CR system)	10.03→	0 281 002 504
Boost pressure sensor, Diesel	10.03→	0 261 230 141
Duo sensor, acceleration and yaw rate, brake system		
Fg.no. →195055	10.03→	0 265 005 258
Fg.no. 195056→	10.03→	0 265 005 628
Steering angle sensor, ESP (electronic stability program)	10.03→	0 265 005 429
119 [639 TON]		3,2l 140 kW M 112.951 6 Zyl.
Air mass meter, gasoline injection	10.03→	0 280 217 515
Phase sensor	10.03→ NOC	0 232 103 037
Speed sensor, ignition/injection	10.03→ FKW	0 261 210 170
Knock sensor	10.03→	0 261 231 110
Duo sensor, acceleration and yaw rate, brake system		
Fg.no. →195055	10.03→	0 265 005 258
Fg.no. 195056→	10.03→	0 265 005 628
Steering angle sensor, ESP (electronic stability program)	10.03→	0 265 005 429
120 CDI [639 TON]		3,0l 150 kW OM 642.990 6 Zyl.
Air mass meter, diesel		
Fg.no. →298499	04.06-11.06	0 281 002 656
High-pressure sensor (CR system)	04.06→	0 281 002 504
Boost pressure sensor, Diesel	04.06→	0 261 230 143



Duo sensor, acceleration and yaw rate, brake system		
Fg.no. →195055	04.06→	0 265 005 258
Fg.no. 195056→	04.06→	0 265 005 628
Steering angle sensor, ESP (electronic stability program)	04.06→	0 265 005 429
122 [639 TON]	3,2l 160 kW M 112.951 6 Zyl.	
Air mass meter, gasoline injection	10.03→	0 280 217 515
Phase sensor	10.03→	0 232 103 037
Speed sensor, ignition/injection	10.03→	0 261 210 170
Knock sensor	10.03→	0 261 231 110
Duo sensor, acceleration and yaw rate, brake system		
Fg.no. →195055	10.03→	0 265 005 258
Fg.no. 195056→	10.03→	0 265 005 628
Steering angle sensor, ESP (electronic stability program)	10.03→	0 265 005 429
123 [639 TON]	3,7l 170 kW M 112.976 6 Zyl.	
Throttle valve assembly	06.04→	0 280 750 019
Air mass meter, gasoline injection	06.04→	0 280 217 515
Phase sensor	06.04→	0 232 103 037
Speed sensor, ignition/injection	06.04→	0 261 210 170
Knock sensor	06.04→	0 261 231 110
Duo sensor, acceleration and yaw rate, brake system		
Fg.no. →195055	06.04→	0 265 005 258
Fg.no. 195056→	06.04→	0 265 005 628
Steering angle sensor, ESP (electronic stability program)	06.04→	0 265 005 429

2t

207 D [T1]	2,4l 53 kW OM 616.937,939 4 Zyl.	
Wheel speed sensor, front	01.88-01.89	0 265 001 126
Wheel speed sensor, rear	01.88-08.88	LAB 0 265 001 240 RAB 0 265 001 239
Fg.no. →P 217440	01.88-01.89	EFV,LAB 0 265 001 240 EFV,RAB 0 265 001 239
208 D [T1]	2,3l 58-60 kW OM 601.940 4 Zyl.	
Wheel speed sensor, front	10.88-06.95	0 265 001 126
Wheel speed sensor, rear		
Fg.no. →P 217440	10.88-06.95	EFV,LAB 0 265 001 240 EFV,RAB 0 265 001 239
209 D [T1]	3,0l 65 kW OM 617.913 5 Zyl.	
Wheel speed sensor, front	01.88-01.89	0 265 001 126
Wheel speed sensor, rear	01.88-08.88	LAB 0 265 001 240 RAB 0 265 001 239
Fg.no. →P 217440	01.88-01.89	EFV,LAB 0 265 001 240 EFV,RAB 0 265 001 239
210 [T1]	2,3l 70-77 kW M 102.942; M 102.945 4 Zyl.	
Wheel speed sensor, front	01.88-06.95	0 265 001 126
Wheel speed sensor, rear	01.88-08.88	LAB 0 265 001 240 RAB 0 265 001 239
Fg.no. →P 217440	01.88-06.95	EFV,LAB 0 265 001 240 EFV,RAB 0 265 001 239
210 D [T1]	2,9l 70-72 kW OM 602.940 5 Zyl.	
Wheel speed sensor, front	10.88-06.95	0 265 001 126
Wheel speed sensor, rear		
Fg.no. →P 217440	10.88-06.95	EFV,LAB 0 265 001 240 EFV,RAB 0 265 001 239



3t		
307 D [T1]	2,4l 53 kW OM 616.937,939 4 Zyl.	
Wheel speed sensor, rear	01.88-08.88	LAB 0 265 001 240 09.88-01.89 LAB 0 265 001 240 01.88-08.88 RAB 0 265 001 239 09.88-01.89 RAB 0 265 001 239
308 D [T1]	2,3l 58-60 kW OM 601.940 4 Zyl.	
Wheel speed sensor, rear	10.88-06.95	LAB 0 265 001 240 10.88-02.94 RAB 0 265 001 239
309 D [T1]	3,0l 65 kW OM 617.913 5 Zyl.	
Wheel speed sensor, rear	01.88-08.88	LAB 0 265 001 240 09.88-01.89 LAB 0 265 001 240 01.88-08.88 RAB 0 265 001 239 09.88-01.89 RAB 0 265 001 239
310 [T1]	2,3l 70-77 kW M 102.942 4 Zyl.	
Wheel speed sensor, rear	01.88-08.88	LAB 0 265 001 240 09.88-06.95 LAB 0 265 001 240 01.88-08.88 RAB 0 265 001 239
310 [T1]	2,3l 70-77 kW M 102.942; M 102.945 4 Zyl.	
Wheel speed sensor, rear	01.88-08.88	LAB 0 265 001 240 09.88-02.94 RAB 0 265 001 239
310 [T1]	2,3l 70-77 kW M 102.945 4 Zyl.	
Wheel speed sensor, rear	09.88-06.95	LAB 0 265 001 240 01.88-08.88 RAB 0 265 001 239 09.88-02.94 RAB 0 265 001 239
310 D [T1]	2,9l 70-72 kW OM 602.940 5 Zyl.	
Wheel speed sensor, rear	10.88-06.95	LAB 0 265 001 240 10.88-02.94 RAB 0 265 001 239

4t

407 D [T1]	2,4l 53 kW OM 616.913,939 4 Zyl.	
Wheel speed sensor, rear	01.88-08.88	LAB 0 265 001 240 09.88-01.89 LAB 0 265 001 240 01.88-08.88 RAB 0 265 001 239 09.88-01.89 RAB 0 265 001 239
408 D [T1]	2,3l 58-60 kW OM 601.940 4 Zyl.	
Wheel speed sensor, rear	11.88-06.95	LAB 0 265 001 240 11.88-02.94 RAB 0 265 001 239
409 D [T1]	3,0l 65 kW OM 617.913 5 Zyl.	
Wheel speed sensor, rear	01.88-08.88	LAB 0 265 001 240 09.88-01.89 LAB 0 265 001 240 01.88-08.88 RAB 0 265 001 239 09.88-01.89 RAB 0 265 001 239
410 [T1]	2,3l 70-77 kW M 102 4 Zyl.	
Wheel speed sensor, rear	01.88-08.88	LAB 0 265 001 240 09.88-06.95 LAB 0 265 001 240 01.88-08.88 LAB 0 265 001 240 09.88-06.95 LAB 0 265 001 240 01.88-08.88 RAB 0 265 001 239 09.88-02.94 RAB 0 265 001 239 01.88-08.88 RAB 0 265 001 239
410 D [T1]	2,9l 70-72 kW OM 602.940 5 Zyl.	
Wheel speed sensor, rear	11.88-06.95	LAB 0 265 001 240 11.88-02.94 RAB 0 265 001 239





Product				

MG

MGF

1.6i 16V	1,6l	82 kW	16K4F	4 Zyl.
Wheel speed sensor, front	10.01-03.02			0 265 006 269
Wheel speed sensor, rear	10.01-03.02	LAB		0 265 006 270
		RAB		0 265 006 271
1.8i 16V	1,8l	88/107 kW	18K4F; 18K4K	4 Zyl.
Wheel speed sensor, front	10.95-03.02			0 265 006 269
Wheel speed sensor, rear	10.95-03.02	LAB		0 265 006 270
		RAB		0 265 006 271
1.8 16V Trophy	1,8l	118 kW	K-Serie	4 Zyl.
Wheel speed sensor, front	03.01-03.02			0 265 006 269
Wheel speed sensor, rear	03.01-03.02	LAB		0 265 006 270
		RAB		0 265 006 271

MGTF

115 1.6i 16V	1,6l	85 kW	16 K4F K-Serie	4 Zyl.
Wheel speed sensor, front	03.02-05.05			0 265 006 269
Wheel speed sensor, rear				
Fg.no. AD 9638→	03.02-05.05	LAB		0 265 006 270
		RAB		0 265 006 271
120 1.8i 16V Stepspeed	1,8l	88 kW	18 K4F K-Serie	4 Zyl.
Wheel speed sensor, front	03.02-05.05			0 265 006 269
Wheel speed sensor, rear				
Fg.no. AD 9638→	03.02-05.05	LAB		0 265 006 270
		RAB		0 265 006 271
135 1.8i 16V	1,8l	100 kW	18 K4F K-Serie	4 Zyl.
Wheel speed sensor, front	03.02-05.05			0 265 006 269
Wheel speed sensor, rear				
Fg.no. AD 9638→	03.02-05.05	LAB		0 265 006 270
		RAB		0 265 006 271
160 1.8i 16V	1,8l	118 kW	18 K4F K-Serie- VVC	4 Zyl.
Wheel speed sensor, front	03.02-05.05			0 265 006 269
Wheel speed sensor, rear				
Fg.no. AD 9638→	03.02-05.05	LAB		0 265 006 270
		RAB		0 265 006 271

ZR

2.0 D Turbo	2,0l	74 kW	TCie	4 Zyl.
Air mass meter, diesel	10.01-05.05			0 280 218 012
Speed sensor, diesel	10.01-05.05	BO		0 281 002 121
Pedal position sensor, diesel	10.01-05.05			0 281 002 370
Wheel speed sensor, front	10.01-05.05	LAB		0 265 006 305
		RAB		0 265 006 306
Wheel speed sensor, rear	10.01-05.05			0 265 006 307
105 1.4i 16V	1,4l	76 kW	K-Serie	4 Zyl.
Wheel speed sensor, front	10.01-05.05	LAB		0 265 006 305
		RAB		0 265 006 306
Wheel speed sensor, rear	10.01-05.05			0 265 006 307
120 1.8i 16V	1,8l	86 kW	18 K4F K-Serie	4 Zyl.
Wheel speed sensor, front	10.01-05.05	LAB		0 265 006 305
		RAB		0 265 006 306
Wheel speed sensor, rear	10.01-05.05			0 265 006 307
160 1.8i 16V	1,8l	118 kW	18 K4K K-Serie-VVC	4 Zyl.
Wheel speed sensor, front	10.01-05.05	LAB		0 265 006 305
		RAB		0 265 006 306
Wheel speed sensor, rear	10.01-05.05			0 265 006 307

Product				

ZS

2.0 TD	2,0l	74 kW	TCie	4 Zyl.
Air mass meter, diesel	10.01-05.05			0 280 218 012
Speed sensor, diesel	10.01-05.05	BO		0 281 002 121
Temperature sensor, intake air, diesel	10.01-05.05			0 280 130 039
Pedal position sensor, diesel	10.01-05.05			0 281 002 370
Wheel speed sensor, front	10.01-05.05	LAB		0 265 006 258
		RAB		0 265 006 259
Wheel speed sensor, rear	10.01-05.05	4SB,LAB		0 265 006 267
		4SB,RAB		0 265 006 268
110 1.6i 16V	1,6l	80 kW	K-Serie	4 Zyl.
Wheel speed sensor, front				
Fg.no. YD 471064→	03.05-05.05	LAB		0 265 006 258
		RAB		0 265 006 259
Fg.no. →YD 471063	03.05-05.05	GS,LAB		0 265 006 258
		GS,RAB		0 265 006 259
Wheel speed sensor, rear	03.05-05.05	4SB,LAB		0 265 006 267
		4SB,RAB		0 265 006 268
120 1.8i 16V	1,8l	86 kW	18 K4F K-Serie	4 Zyl.
Wheel speed sensor, front	10.01-05.05	LAB		0 265 006 258
		RAB		0 265 006 259
Wheel speed sensor, rear	10.01-05.05	4SB,LAB		0 265 006 267
		4SB,RAB		0 265 006 268
180 2.5i 24V	2,5l	130 kW	2.5KV6	6 Zyl.
Wheel speed sensor, front	10.01-05.05	LAB		0 265 006 258
		RAB		0 265 006 259
Wheel speed sensor, rear	10.01-05.05	4SB,LAB		0 265 006 267
		4SB,RAB		0 265 006 268

ZT

135 2.0 CDTi	2,0l	96 kW	204D2	4 Zyl.
Air mass meter, diesel	10.02-05.05			0 928 400 520
190 2.0 CDT	2,0l	85 kW	204D2	4 Zyl.
Air mass meter, diesel	10.01-05.05			0 928 400 520

ZT-Tourer

135 2.0 CDTi	2,0l	96 kW	204D2	4 Zyl.
Air mass meter, diesel	10.02-05.05			0 928 400 520
190 2.0 CDT	2,0l	85 kW	204D2	4 Zyl.
Air mass meter, diesel	10.01-05.05			0 928 400 520

MINI (BMW)

Mini Coupé

Cooper [R 56]	1,6l	88 kW	N12 B16...	4 Zyl.
Air mass meter, gasoline injection	11.06→			0 280 218 205
Phase sensor	11.06→	NOC		0 232 103 064
Pressure sensor, intake manifold, gasoline	11.06→			0 261 230 136
Cooper S [R 56]	1,6l	128 kW	N14 B16A	4 Zyl.
Air mass meter, gasoline injection	11.06→			0 280 218 205
Phase sensor	11.06→	NOC		0 232 103 064
Pressure sensor, intake manifold, gasoline	11.06→			0 261 230 135
Boost pressure sensor, gasoline	11.06→			0 261 230 134
One 1.4 d [R 50]	1,4l	55 kW	1 ND	4 Zyl.
Air mass meter, diesel	03.03-09.05			0 281 002 621
One 1.4i [R 56]	1,4l	70 kW	N12 B14A	4 Zyl.
Phase sensor	03.07→	NOC		0 232 103 064
Pressure sensor, intake manifold, gasoline	03.07→			0 261 230 136



MITSUBISHI				
Carisma				
1.3 i 16V [DA]		1,3l 60 kW 4G13 4 Zyl.		
Wheel speed sensor, front	07.01-12.03	LAB	0 265 006 224	
		RAB	0 265 006 223	
1.6 i 16V [DA]		1,6l 66/73-76 kW 4G92 Kat. 4 Zyl.		
Wheel speed sensor, front	05.96-12.03	LAB	0 265 006 224	
		RAB	0 265 006 223	
Wheel speed sensor, rear	05.96-06.00	LAB,TBR	0 265 006 327	
		RAB,TBR	0 265 006 294	
1.8 GDI [DA]		1,8l 92 kW 4G93 4 Zyl.		
Wheel speed sensor, front	05.97-12.03	LAB	0 265 006 224	
		RAB	0 265 006 223	
Wheel speed sensor, rear	05.97-06.00	LAB,TBR	0 265 006 327	
		RAB,TBR	0 265 006 294	
1.8 i 16V [DA]		1,8l 85/103 kW 4G93 DOHC/SOHC Kat. 4 Zyl.		
Wheel speed sensor, front	05.96-02.99	LAB	0 265 006 224	
		RAB	0 265 006 223	
Wheel speed sensor, rear	05.96-02.99	LAB,TBR	0 265 006 327	
		RAB,TBR	0 265 006 294	
1.9 D Turbo [DA]		1,9l 66 kW F8Q 4 Zyl.		
Wheel speed sensor, front	05.96-06.00	LAB	0 265 006 224	
		RAB	0 265 006 223	
Wheel speed sensor, rear	05.96-06.00	LAB	0 265 006 327	
		RAB	0 265 006 294	
1.9 DI-D [DA]		1,9l 75/85 kW F9Q-200; F9Q-204 4 Zyl.		
Wheel speed sensor, front	07.00-12.03	LAB	0 265 006 224	
		RAB	0 265 006 223	
Carisma Hatchback				
1.6 i 16V [DA]		1,6l 66 kW 4G92 Kat. 4 Zyl.		
Wheel speed sensor, front	05.95-02.99	LAB	0 265 006 224	
		RAB	0 265 006 223	
Wheel speed sensor, rear	05.96-02.99	LAB,TBR	0 265 006 327	
		05.95-04.96	LAB,TBR	0 265 006 328
	05.96-02.99	RAB,TBR	0 265 006 225	
		RAB,TBR	0 265 006 294	
1.6 i 16V [DA]		1,6l 73-76 kW 4G92 Kat. 4 Zyl.		
Wheel speed sensor, front	05.97-12.03	LAB	0 265 006 224	
		RAB	0 265 006 223	
Wheel speed sensor, rear	05.97-06.00	LAB,TBR	0 265 006 327	
		RAB,TBR	0 265 006 294	
1.8 GDI [DA]		1,8l 92 kW 4G93; 4G93 Kat. 4 Zyl.		
Wheel speed sensor, front	05.97-12.03	LAB	0 265 006 224	
		RAB	0 265 006 223	
Wheel speed sensor, rear	05.97-06.00	LAB,TBR	0 265 006 327	
		05.97-12.03	RAB,TBR	0 265 006 294
1.8 i 16V [DA]		1,8l 85 kW 4G93 SOHC Kat. 4 Zyl.		
Wheel speed sensor, front	05.95-02.99	LAB	0 265 006 224	
		RAB	0 265 006 223	
Wheel speed sensor, rear	05.96-02.99	LAB,TBR	0 265 006 327	
		05.95-04.96	LAB,TBR	0 265 006 328
	05.96-02.99	RAB,TBR	0 265 006 225	
		RAB,TBR	0 265 006 294	
1.8 i 16V [DA]		1,8l 103 kW 4G93 DOHC Kat. 4 Zyl.		
Wheel speed sensor, front	05.95-04.97	LAB	0 265 006 224	
		RAB	0 265 006 223	
Wheel speed sensor, rear	05.95-04.96	LAB,TBR	0 265 006 328	
		RAB,TBR	0 265 006 225	



1.9 D Turbo [DA]		1,9l 66 kW F8Q 4 Zyl.	
Wheel speed sensor, front	05.96-06.00	LAB	0 265 006 224
		RAB	0 265 006 223
Wheel speed sensor, rear	05.96-06.00	LAB	0 265 006 327
		RAB	0 265 006 294
1.9 DI-D [DA]		1,9l 75/85 kW F9Q-200; F9Q-204 4 Zyl.	
Wheel speed sensor, front	07.00-12.03	LAB	0 265 006 224
		RAB	0 265 006 223
Colt			
CZT 1.5 Turbo [CZ]		1,5l 110 kW 4G15T 4 Zyl.	
Yaw rate sensor, brake system	01.05→		0 265 005 600
Wheel speed sensor, front	01.05→	LAB	0 265 007 637
		RAB	0 265 007 683
Wheel speed sensor, rear	01.05→		0 265 007 638
1.1 [CZ]		1,1l 55 kW 3A91 3 Zyl.	
Knock sensor	08.04→		0 261 231 187
Pressure sensor, intake manifold, gasoline	08.04→		0 261 230 118
Yaw rate sensor, brake system	08.04→		0 265 005 600
Wheel speed sensor, front	08.04→		0 265 007 637
Wheel speed sensor, rear	08.04→		0 265 007 638
1.3 [CZ]		1,3l 70 kW 4A90 4 Zyl.	
Knock sensor	04.04→		0 261 231 187
Pressure sensor, intake manifold, gasoline	04.04→		0 261 230 118
Yaw rate sensor, brake system	04.04→		0 265 005 600
Wheel speed sensor, front	04.04→		0 265 007 637
Wheel speed sensor, rear	04.04→		0 265 007 638
1.5 [CZ]		1,5l 80 kW 4A91 4 Zyl.	
Knock sensor	04.04→		0 261 231 187
Pressure sensor, intake manifold, gasoline	04.04→		0 261 230 118
Yaw rate sensor, brake system	04.04→		0 265 005 600
Wheel speed sensor, front	04.04→		0 265 007 637
Wheel speed sensor, rear	04.04→		0 265 007 638
1.5 DI-D [CZ]		1,5l 50/70 kW OM 639.393 3 Zyl.	
Yaw rate sensor, brake system	08.04→		0 265 005 600
Wheel speed sensor, front	08.04→		0 265 007 637
Wheel speed sensor, rear	08.04→		0 265 007 638
Spacestar			
1.3 i [DG]		1,3l 60 kW 4G13 4 Zyl.	
Wheel speed sensor, front	06.98→	LAB	0 265 006 224
		RAB	0 265 006 223
Wheel speed sensor, rear	06.98-04.02	LAB,TBR	0 265 006 327
		RAB,TBR	0 265 006 294
1.6 i [DG]		1,6l 72 kW 4G18 4 Zyl.	
Wheel speed sensor, front	04.01→	LAB	0 265 006 224
		RAB	0 265 006 223
1.8 GDI [DG]		1,8l 87-90 kW 4G93-G 4 Zyl.	
Wheel speed sensor, front	08.98-08.02	LAB	0 265 006 224
		RAB	0 265 006 223
Wheel speed sensor, rear	08.98-08.02	LAB,TBR	0 265 006 327
		RAB,TBR	0 265 006 294
1.8 i [DG]		1,8l 82 kW 4G93-3 4 Zyl.	
Wheel speed sensor, front	09.02→	LAB	0 265 006 224
		RAB	0 265 006 223
1.9 DI-D [DG]		1,9l 75/85 kW F9Q 4 Zyl.	
Wheel speed sensor, front	06.00→	LAB	0 265 006 224
		RAB	0 265 006 223



Product



<



Product



Wheel speed sensor, front	03.01-07.02	LAB		0 265 006 702
		RAB		0 265 006 703
1.5 i [N16E]	1,5l 72 kW QG15DE 4 Zyl.			
Air mass meter, gasoline injection	08.02-07.04			0 280 218 094
Wheel speed sensor, front	08.02→	LAB		0 265 006 702
		RAB		0 265 006 703
1.8 i [N16E]	1,8l 84 kW QG18DE 4 Zyl.			
Air mass meter, gasoline injection	03.01-07.02			0 280 218 094
Temperature sensor, coolant, injection system	03.01-07.02			0 280 130 081
Wheel speed sensor, front	03.01-07.02	LAB		0 265 006 702
		RAB		0 265 006 703
1.8 i [N16E]	1,8l 85 kW QG18DE 4 Zyl.			
Air mass meter, gasoline injection	08.02-07.04			0 280 218 094
Wheel speed sensor, front	08.02→	LAB		0 265 007 553
		RAB		0 265 007 552
Wheel speed sensor, rear	02.03→	LAB,MFD		0 265 007 555
		MFD,RAB		0 265 007 554
2.2 D Turbo [N16]	2,2l 81 kW YD22DDT 4 Zyl.			
Air mass meter, diesel	04.00-03.01			0 280 218 005
				🔧 0 986 280 232
2.2 D Turbo [N16E]	2,2l 81 kW YD22DDT 4 Zyl.			
Air mass meter, diesel	03.01-02.03			0 280 218 005
				🔧 0 986 280 232
Temperature sensor, cylinder head	03.01-02.03			0 280 130 081
Wheel speed sensor, front	03.01-02.03	LAB		0 265 006 702
		RAB		0 265 006 703
2.2 D Turbo [N16E]	2,2l 82/100 kW YD22DDT 4 Zyl.			
Wheel speed sensor, front	02.03→	LAB		0 265 007 553
		RAB		0 265 007 552
Wheel speed sensor, rear	02.03→	LAB		0 265 007 555
		RAB		0 265 007 554

Almera Tino				
1.8 i [V10M]	1,8l 84-85 kW QG18DE 4 Zyl.			
Air mass meter, gasoline injection	05.00-11.00			0 280 218 005
				🔧 0 986 280 232
	12.00-07.04			0 280 218 094
Temperature sensor, coolant, injection system	05.00-12.05			0 280 130 081
Wheel speed sensor, front	12.00-02.03	LAB		0 265 006 704
	03.03-12.05	LAB		0 265 007 557
	12.00-02.03	RAB		0 265 006 705
	03.03-12.05	RAB		0 265 007 556
Wheel speed sensor, rear	03.03-12.05	LAB		0 265 007 559
		RAB		0 265 007 558
2.0 i [V10M]	2,0l 99-100 kW SR20DE 4 Zyl.			
Air mass meter, gasoline injection	05.00-01.03			0 280 218 096
Temperature sensor, coolant, injection system	05.00-01.03			0 280 130 081
Wheel speed sensor, front	12.00-01.03	LAB		0 265 006 704
		RAB		0 265 006 705
2.2 D Turbo [V10M]	2,2l 81-84 kW YD22DDTI 4 Zyl.			
Air mass meter, diesel	05.00-01.03			0 280 218 005
				🔧 0 986 280 232
Temperature sensor, coolant, diesel	05.00-01.03			0 280 130 081
Wheel speed sensor, front	12.00-01.03	LAB		0 265 006 704
		RAB		0 265 006 705
2.2 D Turbo [V10M]	2,2l 82/100 kW YD22DDTI 4 Zyl.			
Wheel speed sensor, front	02.03-12.05	LAB		0 265 007 557
		RAB		0 265 007 556
Wheel speed sensor, rear	02.03-12.05	LAB		0 265 007 559
		RAB		0 265 007 558



Altimax			
2.4i [L30]	2,4l 112-116 kW	KA24DE 4 Zyl.	
Temperature sensor, coolant, injection system	06.97-08.01		0 280 130 081
2.4i [U13]	2,4l 110-112 kW	KA24DE 4 Zyl.	
Temperature sensor, coolant, injection system	08.94-02.96	TW	0 280 130 081
3.5 [L31]	3,5l 183 kW	VQ35DE 6 Zyl.	
Air mass meter, gasoline injection	09.01-09.03		0 280 218 154
Micra			
1.0i [K11E]	1,0l 40-44 kW	CG10DE 4 Zyl.	
Throttle valve assembly	08.00-12.00		0 280 750 051
	01.01-10.02		0 280 750 117
Throttle valve sensor	07.00-10.02		0 280 122 014
Phase sensor	07.00-10.02	NOC	0 232 103 033
Speed sensor, ignition/injection	07.00-10.02	FKW	0 261 210 201
Temperature sensor, coolant, injection system	08.92-12.95		0 280 130 073
	01.96-10.02		0 280 130 081
Wheel speed sensor, front	08.00-11.00	LAB	0 265 006 658
	12.00-10.02	LAB	0 265 006 714
	01.96-07.00	LAB,RBA	0 265 006 255
	12.00-10.02	RAB	0 265 006 715
	01.96-11.00	RAB,RBA	0 265 006 254
Wheel speed sensor, rear	01.96-02.98	RBA	0 265 006 256
	03.98-10.02	RBA	0 265 006 382
1.0i [K12E]	1,0l 48 kW	CG10DE 4 Zyl.	
Temperature sensor, coolant, injection system	11.02-05.05		0 280 130 081
Wheel speed sensor, front	11.02-05.05		0 265 007 537
Wheel speed sensor, rear	11.02-05.05	LAB	0 265 007 538
		RAB	0 265 007 539
1.2i [K12E]	1,2l 48/59 kW	CG12DE; CR12DE 4 Zyl.	
Temperature sensor, coolant, injection system	11.02→		0 280 130 081
Duo sensor, acceleration and yaw rate, brake system	08.03→		0 265 005 265
Wheel speed sensor, front	11.02→		0 265 007 537
Wheel speed sensor, rear	11.02→	LAB	0 265 007 538
		RAB	0 265 007 539
1.3i [K11E]	1,3l 55 kW	CG13DE 4 Zyl.	
Temperature sensor, coolant, injection system	08.92-12.95		0 280 130 073
	05.95-02.98		0 280 130 081
	01.96-07.00		0 280 130 081
Wheel speed sensor, front	01.96→	LAB,RBA	0 265 006 255
		RAB,RBA	0 265 006 254
Wheel speed sensor, rear	01.96-02.98	RBA	0 265 006 256
	03.98-07.00	RBA	0 265 006 382
1.4i [K11E]	1,4l 60 kW	CGA3DE 4 Zyl.	
Throttle valve assembly	07.00-12.00		0 280 750 051
	01.01-10.02		0 280 750 117
Throttle valve sensor	07.00-10.02		0 280 122 014
Phase sensor	07.00-10.02	NOC	0 232 103 033
Speed sensor, ignition/injection	07.00-10.02	FKW	0 261 210 201
Temperature sensor, coolant, injection system	07.00-10.02		0 280 130 081
Wheel speed sensor, front	07.00-11.00	LAB	0 265 006 658
	12.00-10.02	LAB	0 265 006 714
	07.00-11.00	RAB	0 265 006 254
	12.00-10.02	RAB	0 265 006 715
Wheel speed sensor, rear	07.00-10.02		0 265 006 382
1.4i [K12E]	1,4l 65 kW	CGA3DE; CR14DE 4 Zyl.	
Temperature sensor, coolant, injection system	11.02→		0 280 130 081
Duo sensor, acceleration and yaw rate, brake system	08.03→		0 265 005 265
Wheel speed sensor, front	11.02→		0 265 007 537



Wheel speed sensor, rear	11.02→	LAB	0 265 007 538
		RAB	0 265 007 539
1.5 D [K11E]	1,5l 42 kW	TD15 4 Zyl.	
Wheel speed sensor, front	07.00-11.00	LAB	0 265 006 658
	12.00-10.02	LAB	0 265 006 714
	07.00-11.00	RAB	0 265 006 254
	12.00-10.02	RAB	0 265 006 715
Wheel speed sensor, rear	07.00-10.02		0 265 006 382
1.5 D Turbo [K12E]	1,5l 48-50/60-63 kW	K9K 4 Zyl.	
Wheel speed sensor, front	02.03→		0 265 007 537
Wheel speed sensor, rear	02.03→	LAB	0 265 007 538
		RAB	0 265 007 539
1.6i [K12E]	1,6l 81 kW	HR16DE 4 Zyl.	
Temperature sensor, coolant, injection system	06.05→		0 280 130 081
Duo sensor, acceleration and yaw rate, brake system	06.05→		0 265 005 265
Wheel speed sensor, front	06.05→		0 265 007 537
Wheel speed sensor, rear	06.05→	LAB	0 265 007 538
		RAB	0 265 007 539
Micra CC			
1.4i [K12E]	1,4l 65 kW	CR14DE 4 Zyl.	
Temperature sensor, coolant, injection system	09.05→		0 280 130 081
Duo sensor, acceleration and yaw rate, brake system	09.05→		0 265 005 265
Wheel speed sensor, front	09.05→		0 265 007 537
Wheel speed sensor, rear	09.05→	LAB	0 265 007 538
		RAB	0 265 007 539
1.6i [K12E]	1,6l 81 kW	HR16DE 4 Zyl.	
Temperature sensor, coolant, injection system	09.05→		0 280 130 081
Duo sensor, acceleration and yaw rate, brake system	09.05→		0 265 005 265
Wheel speed sensor, front	09.05→		0 265 007 537
Wheel speed sensor, rear	09.05→	LAB	0 265 007 538
		RAB	0 265 007 539
Navara			
2.5 dCi [D40]	2,5l 106 kW	YD25DDTI 4 Zyl.	
Temperature sensor, coolant, diesel	05.05-02.06		0 280 130 081
2.5 dCi 4x4 [D40]	2,5l 128 kW	YD25DDTI 4 Zyl.	
Temperature sensor, coolant, diesel	05.05-02.06		0 280 130 081
Note			
1.4 [E11]	1,4l 65 kW	CR14DE 4 Zyl.	
Duo sensor, acceleration and yaw rate, brake system	01.06→		0 265 005 265
Wheel speed sensor, front	01.06→		0 265 007 537
Wheel speed sensor, rear	01.06→	LAB	0 265 007 538
		RAB	0 265 007 539
1.5 dCi 70 [E11]	1,5l 50 kW	K9K 4 Zyl.	
Wheel speed sensor, front	01.06→		0 265 007 537
Wheel speed sensor, rear	01.06→	LAB	0 265 007 538
		RAB	0 265 007 539
1.5 dCi 90 [E11]	1,5l 63 kW	K9K 4 Zyl.	
Duo sensor, acceleration and yaw rate, brake system	01.06→		0 265 005 265
Wheel speed sensor, front	01.06→		0 265 007 537
Wheel speed sensor, rear	01.06→	LAB	0 265 007 538
		RAB	0 265 007 539





Product				

◀ Note

1.6 [E11]		1,6l 81 kW HR16DE 4 Zyl.
Duo sensor, acceleration and yaw rate, brake system	01.06→	0 265 005 265
Wheel speed sensor, front	01.06→	0 265 007 537
Wheel speed sensor, rear	01.06→	LAB 0 265 007 538
		RAB 0 265 007 539

Pathfinder

2.5 D Turbo [R51]		2,5l 128 kW YD25DDTI 4 Zyl.
Temperature sensor, cylinder head	01.05-02.06	0 280 130 081

Pintara

2.0i [R31]		2,0l 78 kW CA20E 4 Zyl.
Air flow sensor, gasoline injection	06.86-12.90	0 280 202 111
		🔧 0 986 280 073
Temperature sensor, coolant, injection system	01.87-12.89	0 280 130 063

Primera

2.0i [P11E]		2,0l 103 kW SR20DE 4 Zyl.
Air mass meter, gasoline injection	02.01→	0 280 218 096

Primera Hatchback

1.6 [P12E]		1,6l 78-80 kW QG16DE 4 Zyl.
Air mass meter, gasoline injection	05.02-06.04	0 280 218 094
Temperature sensor, coolant, injection system	05.02→	0 280 130 081
Wheel speed sensor, front	05.02→	LAB 0 265 007 463
		RAB 0 265 007 464
Wheel speed sensor, rear	05.02-09.02	LAB 0 265 007 465
	10.02→	LAB 0 265 007 632
	05.02-09.02	RAB 0 265 007 466
	10.02→	RAB 0 265 007 633

1.6i [P10E]		1,6l 71-75 kW GA16DE 4 Zyl.
Temperature sensor, coolant, injection system	05.93-09.94	0 280 130 071
	09.94-06.96	0 280 130 073

1.6i [P11E]		1,6l 66-73 kW GA16DE 4 Zyl.
Temperature sensor, coolant, injection system	06.96-05.99	0 280 130 081
Wheel speed sensor, front	06.96-05.99	LAB 0 265 006 233
		RAB 0 265 006 232
Wheel speed sensor, rear	06.96-08.97	LAB 0 265 006 237
	05.98-05.99	LAB 0 265 006 237
	09.97-04.98	LAB 0 265 006 379
	05.98-05.99	RAB 0 265 006 236
	06.96-08.97	RAB 0 265 006 236
	09.97-04.98	RAB 0 265 006 378

1.6i [P11E]		1,6l 73 kW GA16DE 4 Zyl.
Temperature sensor, coolant, injection system	06.99-12.01	0 280 130 081
Wheel speed sensor, front	06.99-12.01	LAB 0 265 006 233
		RAB 0 265 006 232
Wheel speed sensor, rear	06.99-08.00	LAB 0 265 006 237
	09.00-12.01	LAB 0 265 006 708
	06.99-08.00	RAB 0 265 006 236
	09.00-12.01	RAB 0 265 006 709

1.6i [P11E]		1,6l 78 kW QG16DE 4 Zyl.
Air mass meter, gasoline injection	09.00-12.01	0 280 218 094
Temperature sensor, coolant, injection system	09.00-12.01	0 280 130 081
Wheel speed sensor, front	09.00-12.01	LAB 0 265 006 233
		RAB 0 265 006 232

Product				

Wheel speed sensor, rear	09.00-12.01	LAB	0 265 006 708
	09.00-09.00	LAB,TW	0 265 006 237
	09.00-12.01	RAB	0 265 006 709
	09.00-09.00	RAB,TW	0 265 006 236

1.8 [P12E]		1,8l 85 kW QG18DE 4 Zyl.
Air mass meter, gasoline injection	05.02-06.04	0 280 218 094
Temperature sensor, coolant, injection system	05.02→	0 280 130 081
Duo sensor, acceleration and yaw rate, brake system	08.03→	0 265 005 265

Wheel speed sensor, front	05.02→	LAB	0 265 007 463
		RAB	0 265 007 464

Wheel speed sensor, rear	05.02-09.02	LAB	0 265 007 465
	10.02→	LAB	0 265 007 632
	05.02-09.02	RAB	0 265 007 466
	10.02→	RAB	0 265 007 633

1.8i [P11E]		1,8l 84 kW QG18DE 4 Zyl.
Air mass meter, gasoline injection	06.99-09.00	0 280 218 005
		🔧 0 986 280 232
	10.00-12.01	0 280 218 094

Temperature sensor, coolant, injection system	06.99-12.01	0 280 130 081
Wheel speed sensor, front	06.99-12.01	LAB 0 265 006 233
		RAB 0 265 006 232

Wheel speed sensor, rear	06.99-08.00	LAB	0 265 006 237
	09.00-12.01	LAB	0 265 006 708
	06.99-08.00	RAB	0 265 006 236
	09.00-12.01	RAB	0 265 006 709

1.9 D Turbo [P12E]		1,9l 85-88 kW F9Q 4 Zyl.
Duo sensor, acceleration and yaw rate, brake system	08.03→	0 265 005 265

Wheel speed sensor, front	01.03→	LAB	0 265 007 463
		RAB	0 265 007 464

Wheel speed sensor, rear	01.03→	LAB	0 265 007 632
		RAB	0 265 007 633

2.0 [P12E]		2,0l 103 kW QR20DE 4 Zyl.
Air mass meter, gasoline injection	05.02-06.04	0 280 218 096
Duo sensor, acceleration and yaw rate, brake system	08.03→	0 265 005 265
Wheel speed sensor, front	05.02→	LAB 0 265 007 463
		RAB 0 265 007 464

Wheel speed sensor, rear	05.02-09.02	LAB	0 265 007 465
	10.02→	LAB	0 265 007 632
	05.02-09.02	RAB	0 265 007 466
	10.02→	RAB	0 265 007 633

2.0 D Turbo [P11E]		2,0l 66 kW CD20T 4 Zyl.
Air mass meter, diesel	10.97-12.01	0 281 002 207
Temperature sensor, coolant, diesel	10.97-12.01	0 280 130 081
Wheel speed sensor, front	06.96-12.01	LAB 0 265 006 233
		RAB 0 265 006 232

Wheel speed sensor, rear	06.96-08.97	LAB	0 265 006 237
	05.98-08.00	LAB	0 265 006 237
	09.97-04.98	LAB	0 265 006 379
	09.00-12.01	LAB	0 265 006 708
	06.96-08.97	RAB	0 265 006 236
	05.98-08.00	RAB	0 265 006 236
	09.97-04.98	RAB	0 265 006 378
	09.00-12.01	RAB	0 265 006 709

2.0i [P10E]		2,0l 85/89 kW SR20Di 4 Zyl.
Temperature sensor, coolant, injection system	06.90-05.93	0 280 130 064
Wheel speed sensor, front	06.90-05.93	LAB 0 265 001 274
		RAB 0 265 001 273
Wheel speed sensor, rear	06.90-05.93	LAB 0 265 001 276
		RAB 0 265 001 275



2.0i [P10E]		2,0l 85-92 kW SR20DE 4 Zyl.	
Temperature sensor, coolant, injection system	09.94-06.96		0 280 130 073
Wheel speed sensor, front	09.94-06.96	LAB	0 265 001 274
		RAB	0 265 001 273
Wheel speed sensor, rear	09.94-06.96	LAB	0 265 001 276
		RAB	0 265 001 275
2.0i [P10E]		2,0l 110 kW SR20DE 4 Zyl.	
Temperature sensor, coolant, injection system	06.90-05.93		0 280 130 064
	06.93-09.94		0 280 130 071
	10.94-06.96		0 280 130 073
Wheel speed sensor, front	06.90-06.96	LAB	0 265 001 274
		RAB	0 265 001 273
Wheel speed sensor, rear	06.90-06.96	LAB	0 265 001 276
		RAB	0 265 001 275
2.0i [P10E]		2,0l 112 kW SR20DE 4 Zyl.	
Temperature sensor, coolant, injection system	06.90-05.93		0 280 130 064
Wheel speed sensor, front	06.90-05.93	LAB	0 265 001 274
		RAB	0 265 001 273
Wheel speed sensor, rear	06.90-05.93	LAB	0 265 001 276
		RAB	0 265 001 275
2.0i [P11E]		2,0l 85/96 kW SR20DE; SR20DEL 4 Zyl.	
Temperature sensor, coolant, injection system	06.96-06.99		0 280 130 081
Wheel speed sensor, front	06.96-06.99	LAB	0 265 006 233
		RAB	0 265 006 232
Wheel speed sensor, rear	06.96-08.97	LAB	0 265 006 237
	09.97-10.97	LAB	0 265 006 379
	06.96-08.97	RAB	0 265 006 236
	09.97-10.97	RAB	0 265 006 378
2.0i [P11E]		2,0l 96 kW SR20DEL 4 Zyl.	
Wheel speed sensor, rear	05.98-06.99	LAB	0 265 006 237
	10.97-04.98	LAB	0 265 006 379
	05.98-06.99	RAB	0 265 006 236
	10.97-04.98	RAB	0 265 006 378
2.0i [P11E]		2,0l 103 kW SR20DE 4 Zyl.	
Air mass meter, gasoline injection	06.99-12.01		0 280 218 096
Temperature sensor, coolant, injection system	06.99-12.01		0 280 130 081
Wheel speed sensor, front	06.99-12.01	LAB	0 265 006 233
		RAB	0 265 006 232
Wheel speed sensor, rear	06.99-08.00	LAB	0 265 006 237
	09.00-12.01	LAB	0 265 006 708
	06.99-08.00	RAB	0 265 006 236
	09.00-12.01	RAB	0 265 006 709
2.0i GT [P11E]		2,0l 110 kW SR20DE; SR20DEH 4 Zyl.	
Temperature sensor, coolant, injection system	06.96-06.99		0 280 130 081
Wheel speed sensor, front	06.96-06.99	LAB	0 265 006 233
		RAB	0 265 006 232
Wheel speed sensor, rear	06.96-08.97	LAB	0 265 006 237
	09.97-10.97	LAB	0 265 006 379
	06.96-08.97	RAB	0 265 006 236
	09.97-10.97	RAB	0 265 006 378
2.0i GT [P11E]		2,0l 110 kW SR20DEH 4 Zyl.	
Wheel speed sensor, rear	05.98-06.99	LAB	0 265 006 237
	10.97-04.98	LAB	0 265 006 379
	05.98-06.99	RAB	0 265 006 236
	10.97-04.98	RAB	0 265 006 378
2.0i 4WD [P10E]		2,0l 85/89 kW SR20Di 4 Zyl.	
Temperature sensor, coolant, injection system	04.91-05.93		0 280 130 064
Wheel speed sensor, front	04.91-05.93	LAB	0 265 001 313
		RAB	0 265 001 312
2.0i 4WD [P10E]		2,0l 110 kW SR20DE 4 Zyl.	
Temperature sensor, coolant, injection system	04.91-05.93		0 280 130 064
	06.93-09.94		0 280 130 071
	10.94-06.96		0 280 130 073



Wheel speed sensor, front	10.94-06.96	LAB	0 265 001 274
	04.91-09.94	LAB	0 265 001 313
	10.94-06.96	RAB	0 265 001 273
	04.91-09.94	RAB	0 265 001 312
Wheel speed sensor, rear	09.94-06.96	LAB	0 265 001 276
		RAB	0 265 001 275
2.0 i 4WD [P10E]		2,0 l 112 kW SR20DE 4 Zyl.	
Temperature sensor, coolant, injection system	04.91-05.93		0 280 130 064
Wheel speed sensor, front	04.91-05.93	LAB	0 265 001 313
		RAB	0 265 001 312
2.2 D Turbo [P12E]		2,2 l 93 kW YD22DDT 4 Zyl.	
Air mass meter, diesel	05.02-06.04		0 280 218 005
			0 986 280 232
Duo sensor, acceleration and yaw rate, brake system	08.03→		0 265 005 265
Wheel speed sensor, front	05.02→	LAB	0 265 007 463
		RAB	0 265 007 464
Wheel speed sensor, rear	05.02-09.02	LAB	0 265 007 465
	10.02→	LAB	0 265 007 632
	05.02-09.02	RAB	0 265 007 466
	10.02→	RAB	0 265 007 633
2.2 D Turbo [P12E]		2,2 l 100-102 kW YD22DDT 4 Zyl.	
Duo sensor, acceleration and yaw rate, brake system	08.03→		0 265 005 265
Wheel speed sensor, front	01.03→	LAB	0 265 007 463
		RAB	0 265 007 464
Wheel speed sensor, rear	01.03→	LAB	0 265 007 632
		RAB	0 265 007 633

Primera Sedan

1.6 [P12E]	1,6l 78-80 kW		QG16DE 4 Zyl.
Air mass meter, gasoline injection	12.01-06.04		0 280 218 094
Temperature sensor, coolant, injection system	12.01→		0 280 130 081
Wheel speed sensor, front	12.01→	LAB	0 265 007 463
		RAB	0 265 007 464
Wheel speed sensor, rear	12.01-09.02	LAB	0 265 007 465
	10.02→	LAB	0 265 007 632
	12.01-09.02	RAB	0 265 007 466
	10.02→	RAB	0 265 007 633
1.6 i [P10E]	1,6l 71-75 kW		GA16DE 4 Zyl.
Temperature sensor, coolant, injection system	05.93-09.94		0 280 130 071
	09.94-06.96		0 280 130 073
1.6 i [P11E]	1,6l 66-73 kW		GA16DE 4 Zyl.
Temperature sensor, coolant, injection system	06.96-05.99		0 280 130 081
Wheel speed sensor, front	06.96-05.99	LAB	0 265 006 233
		RAB	0 265 006 232
Wheel speed sensor, rear	06.96-08.97	LAB	0 265 006 237
	05.98-05.99	LAB	0 265 006 237
	09.97-04.98	LAB	0 265 006 379
	06.96-08.97	RAB	0 265 006 236
	05.98-05.99	RAB	0 265 006 236
	09.97-04.98	RAB	0 265 006 378
1.6 i [P11E]	1,6l 73 kW		GA16DE 4 Zyl.
Temperature sensor, coolant, injection system	06.99-12.01		0 280 130 081
Wheel speed sensor, front	06.99-12.01	LAB	0 265 006 233
		RAB	0 265 006 232
Wheel speed sensor, rear	06.99-08.00	LAB	0 265 006 237
	09.00-12.01	LAB	0 265 006 708
	06.99-08.00	RAB	0 265 006 236
	09.00-12.01	RAB	0 265 006 709





Product

◀ Primera Sedan

1.6 i [P11E]		1,6l 78 kW QG16DE 4 Zyl.	
Air mass meter, gasoline injection	09.00-12.01		0 280 218 094
Temperature sensor, coolant, injection system	09.00-12.01		0 280 130 081
Wheel speed sensor, front	09.00-12.01	LAB	0 265 006 233
		RAB	0 265 006 232
Wheel speed sensor, rear	09.00-12.01	LAB	0 265 006 708
	09.00-09.00	LAB,TW	0 265 006 237
	09.00-12.01	RAB	0 265 006 709
	09.00-09.00	RAB,TW	0 265 006 236
1.8 [P12E]		1,8l 85 kW QG18DE 4 Zyl.	
Air mass meter, gasoline injection	12.01-06.04		0 280 218 094
Temperature sensor, coolant, injection system	12.01→		0 280 130 081
Duo sensor, acceleration and yaw rate, brake system	08.03→		0 265 005 265
Wheel speed sensor, front	12.01→	LAB	0 265 007 463
		RAB	0 265 007 464
Wheel speed sensor, rear	12.01-09.02	LAB	0 265 007 465
	10.02→	LAB	0 265 007 632
	12.01-09.02	RAB	0 265 007 466
	10.02→	RAB	0 265 007 633
1.8 i [P11E]		1,8l 84 kW QG18DE 4 Zyl.	
Air mass meter, gasoline injection	06.99-09.00		0 280 218 005
			0 986 280 232
	10.00-12.01		0 280 218 094
Temperature sensor, coolant, injection system	06.99-12.01		0 280 130 081
Wheel speed sensor, front	06.99-12.01	LAB	0 265 006 233
		RAB	0 265 006 232
Wheel speed sensor, rear	06.99-08.00	LAB	0 265 006 237
	09.00-12.01	LAB	0 265 006 708
	06.99-08.00	RAB	0 265 006 236
	09.00-12.01	RAB	0 265 006 709
1.9 D Turbo [P12E]		1,9l 85-88 kW F9Q 4 Zyl.	
Duo sensor, acceleration and yaw rate, brake system	08.03→		0 265 005 265
Wheel speed sensor, front	01.03→	LAB	0 265 007 463
		RAB	0 265 007 464
Wheel speed sensor, rear	01.03→	LAB	0 265 007 632
		RAB	0 265 007 633
2.0 [P12E]		2,0l 103 kW QR20DE 4 Zyl.	
Air mass meter, gasoline injection	12.01-06.04		0 280 218 096
Duo sensor, acceleration and yaw rate, brake system	08.03→		0 265 005 265
Wheel speed sensor, front	12.01→	LAB	0 265 007 463
		RAB	0 265 007 464
Wheel speed sensor, rear	12.01-09.02	LAB	0 265 007 465
	10.02→	LAB	0 265 007 632
	12.01-09.02	RAB	0 265 007 466
	10.02→	RAB	0 265 007 633
2.0 D Turbo [P11E]		2,0l 66 kW CD20T 4 Zyl.	
Air mass meter, diesel	10.97-12.01		0 281 002 207
Temperature sensor, coolant, diesel	10.97-12.01		0 280 130 081
Wheel speed sensor, front	06.96-12.01	LAB	0 265 006 233
		RAB	0 265 006 232
Wheel speed sensor, rear	06.96-08.97	LAB	0 265 006 237
	05.98-08.00	LAB	0 265 006 237
	09.97-04.98	LAB	0 265 006 379
	09.00-12.01	LAB	0 265 006 708
	06.96-08.97	RAB	0 265 006 236
	05.98-08.00	RAB	0 265 006 236
	09.97-04.98	RAB	0 265 006 378
	09.00-12.01	RAB	0 265 006 709

Product

2.0i [P10E]		2,0l 85/89 kW SR20Di 4 Zyl.	
Temperature sensor, coolant, injection system	06.90-05.93		0 280 130 064
Wheel speed sensor, front	06.90-05.93	LAB	0 265 001 274
		RAB	0 265 001 273
Wheel speed sensor, rear	06.90-05.93	LAB	0 265 001 276
		RAB	0 265 001 275
2.0i [P10E]		2,0l 85-92 kW SR20DE 4 Zyl.	
Temperature sensor, coolant, injection system	09.94-06.96		0 280 130 073
Wheel speed sensor, front	09.94-06.96	LAB	0 265 001 274
		RAB	0 265 001 273
Wheel speed sensor, rear	09.94-06.96	LAB	0 265 001 276
		RAB	0 265 001 275
2.0i [P10E]		2,0l 110 kW SR20DE 4 Zyl.	
Temperature sensor, coolant, injection system	06.90-05.93		0 280 130 064
	06.93-09.94		0 280 130 071
	10.94-06.96		0 280 130 073
Wheel speed sensor, front	06.90-06.96	LAB	0 265 001 274
		RAB	0 265 001 273
Wheel speed sensor, rear	06.90-06.96	LAB	0 265 001 276
		RAB	0 265 001 275
2.0i [P10E]		2,0l 112 kW SR20DE 4 Zyl.	
Temperature sensor, coolant, injection system	06.90-05.93		0 280 130 064
Wheel speed sensor, front	06.90-05.93	LAB	0 265 001 274
		RAB	0 265 001 273
Wheel speed sensor, rear	06.90-05.93	LAB	0 265 001 276
		RAB	0 265 001 275
2.0i [P11E]		2,0l 85/96 kW SR20DE; SR20DEL 4 Zyl.	
Temperature sensor, coolant, injection system	06.96-06.99		0 280 130 081
Wheel speed sensor, front	06.96-06.99	LAB	0 265 006 233
		RAB	0 265 006 232
Wheel speed sensor, rear	06.96-08.97	LAB	0 265 006 237
	09.97-10.97	LAB	0 265 006 379
	06.96-08.97	RAB	0 265 006 236
	09.97-10.97	RAB	0 265 006 378
2.0i [P11E]		2,0l 96 kW SR20DEL 4 Zyl.	
Wheel speed sensor, rear	05.98-06.99	LAB	0 265 006 237
	10.97-04.98	LAB	0 265 006 379
	05.98-06.99	RAB	0 265 006 236
	10.97-04.98	RAB	0 265 006 378
2.0i [P11E]		2,0l 103 kW SR20DE 4 Zyl.	
Air mass meter, gasoline injection	06.99-12.01		0 280 218 096
Temperature sensor, coolant, injection system	06.99-12.01		0 280 130 081
Wheel speed sensor, front	06.99-12.01	LAB	0 265 006 233
		RAB	0 265 006 232
Wheel speed sensor, rear	06.99-08.00	LAB	0 265 006 237
	09.00-12.01	LAB	0 265 006 708
	06.99-08.00	RAB	0 265 006 236
	09.00-12.01	RAB	0 265 006 709
2.0i GT [P11E]		2,0l 110 kW SR20DE; SR20DEH 4 Zyl.	
Temperature sensor, coolant, injection system	06.96-06.99		0 280 130 081
Wheel speed sensor, front	06.96-06.99	LAB	0 265 006 233
		RAB	0 265 006 232
Wheel speed sensor, rear	06.96-08.97	LAB	0 265 006 237
	09.97-10.97	LAB	0 265 006 379
	06.96-08.97	RAB	0 265 006 236
	09.97-10.97	RAB	0 265 006 378
2.0i GT [P11E]		2,0l 110 kW SR20DEH 4 Zyl.	
Wheel speed sensor, rear	05.98-06.99	LAB	0 265 006 237
	10.97-04.98	LAB	0 265 006 379
	05.98-06.99	RAB	0 265 006 236
	10.97-04.98	RAB	0 265 006 378



Product			
2.0 i 4WD [P10E]	2,0l 85/89 kW SR20Di 4 Zyl.		
Temperature sensor, coolant, injection system	04.91-05.93		0 280 130 064
Wheel speed sensor, front	04.91-05.93	LAB	0 265 001 313
		RAB	0 265 001 312
2.0 i 4WD [P10E]	2,0l 110 kW SR20DE 4 Zyl.		
Temperature sensor, coolant, injection system	04.91-05.93		0 280 130 064
	06.93-09.94		0 280 130 071
	10.94-06.96		0 280 130 073
Wheel speed sensor, front	10.94-06.96	LAB	0 265 001 274
	04.91-09.94	LAB	0 265 001 313
	10.94-06.96	RAB	0 265 001 273
	04.91-09.94	RAB	0 265 001 312
Wheel speed sensor, rear	09.94-06.96	LAB	0 265 001 276
		RAB	0 265 001 275
2.0 i 4WD [P10E]	2,0l 112 kW SR20DE 4 Zyl.		
Temperature sensor, coolant, injection system	04.91-05.93		0 280 130 064
Wheel speed sensor, front	04.91-05.93	LAB	0 265 001 313
		RAB	0 265 001 312
2.2 D Turbo [P12E]	2,2l 93 kW YD22DDT 4 Zyl.		
Air mass meter, diesel	12.01-06.04		0 280 218 005
			0 986 280 232
Duo sensor, acceleration and yaw rate, brake system	08.03→		0 265 005 265
Wheel speed sensor, front	12.01→	LAB	0 265 007 463
		RAB	0 265 007 464
Wheel speed sensor, rear	12.01-09.02	LAB	0 265 007 465
	10.02→	LAB	0 265 007 632
	12.01-09.02	RAB	0 265 007 466
	10.02→	RAB	0 265 007 633
2.2 D Turbo [P12E]	2,2l 100-102 kW YD22DDT 4 Zyl.		
Duo sensor, acceleration and yaw rate, brake system	08.03→		0 265 005 265
Wheel speed sensor, front	01.03→	LAB	0 265 007 463
		RAB	0 265 007 464
Wheel speed sensor, rear	01.03→	LAB	0 265 007 632
		RAB	0 265 007 633

Primera Wagon

1.6 [P12E]	1,6l 80 kW QG16DE 4 Zyl.		
Air mass meter, gasoline injection	12.01-06.04		0 280 218 094
Temperature sensor, coolant, injection system	12.01→		0 280 130 081
Wheel speed sensor, front	12.01→	LAB	0 265 007 463
		RAB	0 265 007 464
Wheel speed sensor, rear	12.01-09.02	LAB	0 265 007 465
	10.02→	LAB	0 265 007 632
	12.01-09.02	RAB	0 265 007 466
	10.02→	RAB	0 265 007 633
1.6 i [WP11E]	1,6l 66 kW GA16DE 4 Zyl.		
Temperature sensor, coolant, injection system	01.98-06.99		0 280 130 081
Wheel speed sensor, front	01.98-06.99	LAB	0 265 006 233
		RAB	0 265 006 232
Wheel speed sensor, rear	01.98-06.99	LAB	0 265 006 237
		RAB	0 265 006 236
1.6 i [WP11E]	1,6l 73 kW GA16DE 4 Zyl.		
Temperature sensor, coolant, injection system	01.98-12.01		0 280 130 081
Wheel speed sensor, front	01.98-12.01	LAB	0 265 006 233
		RAB	0 265 006 232
Wheel speed sensor, rear	01.98-06.99	LAB	0 265 006 237
		RAB	0 265 006 236



1.8 [P12E]	1,8l 85 kW QG18DE 4 Zyl.		
Air mass meter, gasoline injection	12.01-06.04		0 280 218 094
Temperature sensor, coolant, injection system	12.01→		0 280 130 081
Duo sensor, acceleration and yaw rate, brake system	08.03→		0 265 005 265
Wheel speed sensor, front	12.01→	LAB	0 265 007 463
		RAB	0 265 007 464
Wheel speed sensor, rear	12.01-09.02	LAB	0 265 007 465
	10.02→	LAB	0 265 007 632
	12.01-09.02	RAB	0 265 007 466
	10.02→	RAB	0 265 007 633
1.8 i [WP11E]	1,8l 84 kW QG18DE 4 Zyl.		
Air mass meter, gasoline injection	06.99-09.00		0 280 218 005
			0 986 280 232
	10.00-12.01		0 280 218 094
Temperature sensor, coolant, injection system	06.99-12.01		0 280 130 081
Wheel speed sensor, front	06.99-12.01	LAB	0 265 006 233
		RAB	0 265 006 232
Wheel speed sensor, rear	06.99-12.01	LAB	0 265 006 379
		RAB	0 265 006 378
1.9 D Turbo [P12E]	1,9l 85-88 kW F9Q 4 Zyl.		
Duo sensor, acceleration and yaw rate, brake system	08.03→		0 265 005 265
Wheel speed sensor, front	01.03→	LAB	0 265 007 463
		RAB	0 265 007 464
Wheel speed sensor, rear	01.03→	LAB	0 265 007 632
		RAB	0 265 007 633
2.0 [P12E]	2,0l 103 kW QR20DE 4 Zyl.		
Air mass meter, gasoline injection	12.01-06.04		0 280 218 096
Duo sensor, acceleration and yaw rate, brake system	08.03→		0 265 005 265
Wheel speed sensor, front	12.01→	LAB	0 265 007 463
		RAB	0 265 007 464
Wheel speed sensor, rear	12.01-09.02	LAB	0 265 007 465
	10.02→	LAB	0 265 007 632
	12.01-09.02	RAB	0 265 007 466
	10.02→	RAB	0 265 007 633
2.0 D Turbo [WP11E]	2,0l 66 kW CD20T 4 Zyl.		
Air mass meter, diesel	01.98-12.01		0 281 002 207
Temperature sensor, coolant, diesel	01.98-12.01		0 280 130 081
Wheel speed sensor, front	01.98-12.01	LAB	0 265 006 233
		RAB	0 265 006 232
Wheel speed sensor, rear	01.98-06.99	LAB	0 265 006 237
	07.99-12.01	LAB	0 265 006 379
	01.98-06.99	RAB	0 265 006 236
	07.99-12.01	RAB	0 265 006 378
2.0 i [WP11E]	2,0l 85/96 kW SR20DE 4 Zyl.		
Temperature sensor, coolant, injection system	01.98-06.99		0 280 130 081
Wheel speed sensor, front	01.98-06.99	LAB	0 265 006 233
		RAB	0 265 006 232
Wheel speed sensor, rear	01.98-06.99	LAB	0 265 006 237
		RAB	0 265 006 236
2.0 i [WP11E]	2,0l 103 kW SR20DE 4 Zyl.		
Air mass meter, gasoline injection	06.99-12.01		0 280 218 096
Temperature sensor, coolant, injection system	06.99-12.01		0 280 130 081
Wheel speed sensor, front	06.99-12.01	LAB	0 265 006 233
		RAB	0 265 006 232
Wheel speed sensor, rear	06.99-12.01	LAB	0 265 006 379
		RAB	0 265 006 378
2.0 i [W10]	2,0l 85/89 kW SR20Di 4 Zyl.		
Temperature sensor, coolant, injection system	07.90-07.94		0 280 130 064
Wheel speed sensor, front	07.90-07.94	LAB	0 265 001 274
		RAB	0 265 001 273



Product				

◀ Primera Wagon

Wheel speed sensor, rear	07.90-07.94	LAB	0 265 001 276
		RAB	0 265 001 275
2.2 D Turbo [P12E]	2,2l	93 kW	YD2DDT 4 Zyl.
Air mass meter, diesel	12.01-06.04		0 280 218 005
			0 986 280 232
Duo sensor, acceleration and yaw rate, brake system	08.03→		0 265 005 265
Wheel speed sensor, front	12.01→	LAB	0 265 007 463
		RAB	0 265 007 464
Wheel speed sensor, rear	12.01-09.02	LAB	0 265 007 465
	10.02→	LAB	0 265 007 632
	12.01-09.02	RAB	0 265 007 466
	10.02→	RAB	0 265 007 633
2.2 D Turbo [P12E]	2,2l	100-102 kW	YD2DDT 4 Zyl.
Duo sensor, acceleration and yaw rate, brake system	08.03→		0 265 005 265
Wheel speed sensor, front	01.03→	LAB	0 265 007 463
		RAB	0 265 007 464
Wheel speed sensor, rear	01.03→	LAB	0 265 007 632
		RAB	0 265 007 633

Pulsar Hatchback

1.8 i [N13] 1,8l 79 kW 18LE 4 Zyl.	
Temperature sensor, coolant, injection system	08.87-10.91 0 280 130 026

Qashqai

1.5 dCi [J10] 1,5l 78 kW K9K 4 Zyl.	
Wheel speed sensor, front	12.06→ 0 265 007 905
Wheel speed sensor, rear	12.06→ 0 265 007 908
1.6 [J10] 1,6l 84 kW HR16DE 4 Zyl.	
Wheel speed sensor, front	12.06→ 0 265 007 905
Wheel speed sensor, rear	12.06→ 0 265 007 908
2.0 [J10] 2,0l 103 kW MR20DE 4 Zyl.	
Wheel speed sensor, front	12.06→ 0 265 007 905
Wheel speed sensor, rear	12.06→ 0 265 007 908
2.0 4x4 [J10] 2,0l 103 kW MR20DE 4 Zyl.	
Wheel speed sensor, front	12.06→ 0 265 007 905
Wheel speed sensor, rear	12.06→ 0 265 007 909

Quest

3.0 [V40] 3,0l 113 kW VG30E 6 Zyl.	
Temperature sensor, coolant, injection system	10.95-09.98 0 280 130 081
Wheel speed sensor, front	04.92-09.98 LAB 0 265 001 317
	04.92-11.93 RAB 0 265 001 316
	09.95-09.98 RAB 0 265 001 415
	04.92-09.98 LAB 0 265 001 319
Wheel speed sensor, rear	RAB 0 265 001 318
3.3 s [V41] 3,3l 125 kW VG33E 6 Zyl.	
Temperature sensor, coolant, injection system	10.98-04.03 0 280 130 081

Serena

1.6 i [C23M] 1,6l 71 kW GA16DE 4 Zyl.	
Temperature sensor, coolant, injection system	07.92-09.94 0 280 130 071
	10.94-06.96 0 280 130 073
	07.96-11.01 0 280 130 081

Product				

2.0 i [C23M] 2,0l 93 kW SR20DE 4 Zyl.	
Temperature sensor, coolant, injection system	07.92-11.01 0 280 130 071
	07.92-10.95 0 280 130 071
	07.92-11.01 0 280 130 071
	07.92-10.95 0 280 130 071
	11.95-06.96 0 280 130 073
	07.96-11.01 0 280 130 081

Terrano II

2.4 i [R20] 2,4l 85-87 kW KA24E 4 Zyl.	
Temperature sensor, coolant, injection system	05.96-02.04 0 280 130 081
Wheel speed sensor, front	05.96-02.02 LAB 0 265 006 670
	03.02→ LAB 0 265 006 756
	05.96-02.02 RAB 0 265 006 671
	03.02→ RAB 0 265 006 755
Wheel speed sensor, rear	11.96-12.99 0 265 006 281
	05.96→ TU3 0 265 006 281
	05.96-02.02 TU5 0 265 006 285
	03.02→ TU5 0 265 006 779
2.7 D Turbo [R20] 2,7l 74 kW TD27T 4 Zyl.	
Wheel speed sensor, front	10.99-02.02 LAB 0 265 006 670
	RAB 0 265 006 671
Wheel speed sensor, rear	10.99-02.02 TU3 0 265 006 281
	TU5 0 265 006 285
2.7 D Turbo [R20] 2,7l 92 kW TD27Ti 4 Zyl.	
Air mass meter, diesel	11.98→ 0 281 002 207
	06.03→ 0 281 002 597
	10.97→ GS 0 281 002 207
	10.00-02.02 GS 0 281 002 207
Speed sensor, diesel	11.97→ GS 0 281 002 191
Temperature sensor, coolant, diesel	01.97→ 0 280 130 081
Wheel speed sensor, front	11.96→ LAB 0 265 006 670
	01.96-02.02 LAB 0 265 006 670
	03.02→ LAB 0 265 006 756
	11.96→ RAB 0 265 006 671
	01.96-02.02 RAB 0 265 006 671
	03.02→ RAB 0 265 006 755
	11.96→ 0 265 006 281
	11.98→ TU3 0 265 006 281
	01.96-06.02 TU3 0 265 006 281
	07.02→ TU3 0 265 006 778
Wheel speed sensor, rear	11.98→ TU5 0 265 006 285
	01.96-06.02 TU5 0 265 006 285
	07.02→ TU5 0 265 006 779
3.0 D Turbo [R20] 3,0l 113 kW ZD30 4 Zyl.	
Wheel speed sensor, front	02.02→ LAB 0 265 006 756
	RAB 0 265 006 755
Wheel speed sensor, rear	02.02-06.02 TU3 0 265 006 281
	07.02→ TU3 0 265 006 778
	02.02-06.02 TU5 0 265 006 285
	07.02→ TU5 0 265 006 779

Vanette Cargo

1.6 i [C23M] 1,6l 71-72 kW GA16DE 4 Zyl.	
Temperature sensor, coolant, injection system	07.92-11.01 0 280 130 071
	07.92-09.94 0 280 130 071
	10.94-06.96 0 280 130 073
	07.96-11.01 0 280 130 081

Product



OPEL

Agila

1.0i 1,0l 43 kW Z 10 XE 3 Zyl.			
Throttle valve assembly	06.00-08.03		0 280 750 044
Air mass meter, gasoline injection	06.00-08.03		0 280 218 031
			0 986 280 230
Phase sensor	06.00-08.03	NOC	0 232 103 021
Speed sensor, ignition/injection	06.00-08.03	FKW	0 261 210 151
Knock sensor	06.00-08.03		0 261 231 120
Temperature sensor, coolant, injection system			
Mot.no. →19T85744	06.00-08.03		0 281 002 169
Mot.no. 19T85745→	06.00-08.03		0 281 002 170
1.0 Twinport 1,0l 44 kW Z 10 XEP 3 Zyl.			
Throttle valve assembly	08.03-02.08		0 280 750 133
Air mass meter, gasoline injection	08.03-02.08		0 280 218 119
Phase sensor			
Fg.no. →5G999999	08.03-02.08	NOC	0 232 103 052
Fg.no. 6G000001→	08.03-02.08	NOC	0 232 103 067
Speed sensor, ignition/injection	08.03-02.08	FKW	0 261 210 151
Knock sensor	08.03-02.08		0 261 231 173
1.2i 1,2l 55 kW Z 12 XE 4 Zyl.			
Throttle valve assembly	06.00-06.04		0 280 750 044
Air mass meter, gasoline injection	06.00-06.04		0 280 218 031
			0 986 280 230
Phase sensor	06.00-06.04	NOC	0 232 103 021
Speed sensor, ignition/injection	06.00-06.04	FKW	0 261 210 151
Knock sensor	06.00-06.04		0 261 231 120
Temperature sensor, coolant, injection system			
Mot.no. →19T85744	06.00-06.04		0 281 002 169
Mot.no. 19T85745→	06.00-06.04		0 281 002 170
1.2 Twinport 1,2l 59 kW Z 12 XEP 4 Zyl.			
Throttle valve assembly	07.04-02.08		0 280 750 133
Air mass meter, gasoline injection	07.04-02.08		0 280 218 119
Phase sensor	07.04-02.08	NOC	0 232 103 052
Speed sensor, ignition/injection	07.04-02.08	FKW	0 261 210 151
Knock sensor	07.04-02.08		0 261 231 173
1.3 CDTi 1,2l 51 kW Z 13 DT 4 Zyl.			
Air mass meter, diesel	08.03-02.08		0 281 002 619
High-pressure sensor (CR system)	08.03-02.08		0 281 002 534
Pressure sensor, intake manifold, diesel	08.03-02.08		0 281 002 510

Antara

3.2 V6 3,2l 165-167 kW Z 32 SE 6 Zyl.			
Knock sensor	05.06→		0 261 231 174

Ascona

1.8i [C] 1,8l 74 kW C 18 NE 4 Zyl.			
Throttle valve sensor	01.85-08.86		0 280 120 301
Air flow sensor, gasoline injection	01.85-08.86		0 280 202 076
Temperature sensor, coolant, injection system	01.85-08.86		0 280 130 107
1.8i [C] 1,8l 85 kW 18 E 4 Zyl.			
Throttle valve sensor	09.82-08.86		0 280 120 301
Air flow sensor, gasoline injection	09.82-08.86		0 280 202 033
	CH,S 09.83-08.86		0 280 202 054
Temperature sensor, coolant, injection system	09.82-08.86		0 280 130 107

Product



1.8i [C] 1,8l 85 kW 18 SE 4 Zyl.			
Throttle valve sensor	09.86-08.88		0 280 120 316
Air flow sensor, gasoline injection	09.86-08.88		0 280 202 602
			0 986 280 019
Speed sensor, ignition/injection	09.86-08.88		0 261 210 030
Temperature sensor, coolant, injection system	09.86-08.88		0 280 130 107
1.8 S [C] 1,8l 62 kW E 18 NV; S 18 NV 4 Zyl.			
Temperature sensor, coolant, injection system	09.87-08.88		0 280 130 107
2.0i [C] 2,0l 74 kW 20 S (NEF) 4 Zyl.			
Temperature sensor, coolant, injection system	03.87-08.88		0 280 130 107
2.0i [C] 2,0l 85/95 kW 20 NE, C 20 NE; 20 SEH 4 Zyl.			
Throttle valve sensor	09.86-08.88		0 280 120 316
Speed sensor, ignition/injection	09.86-08.88		0 261 210 030
Pressure sensor, intake manifold, gasoline	09.86-08.88		0 280 101 007
Temperature sensor, coolant, injection system	09.86-08.88		0 280 130 107
Wheel speed sensor	01.87-08.88	HI,LAB	0 265 001 147
		HI,RAB	0 265 001 145
		VO	0 265 001 144

Astra

1.2i [G] 1,2l 48 kW X 12 XE 4 Zyl.			
Throttle valve assembly	09.97-09.03		0 205 003 050
Throttle valve sensor	09.97-09.03		0 280 122 014
Air mass meter, gasoline injection	09.97-09.03		0 280 217 123
Phase sensor	09.97-09.03	NOC	0 232 103 021
Speed sensor, ignition/injection	09.97-09.03	FKW	0 261 210 151
Knock sensor	09.97-09.03		0 261 231 120
Temperature sensor, coolant, injection system	09.97-09.03		0 281 002 169
1.2i [G] 1,2l 55 kW Z 12 XE 4 Zyl.			
Throttle valve assembly	09.00-09.03		0 280 750 044
Air mass meter, gasoline injection	09.00-09.03		0 280 218 031
			0 986 280 230
Phase sensor	09.00-09.03	NOC	0 232 103 021
Speed sensor, ignition/injection	09.00-09.03	FKW	0 261 210 151
Knock sensor	09.00-09.03		0 261 231 120
Temperature sensor, coolant, injection system	09.00-09.03		0 281 002 169
1.2i Twinport [H] 1,2l 59 kW Z 12 XEP 4 Zyl.			
Throttle valve assembly	03.07→		0 280 750 133
Air mass meter, gasoline injection	03.07→		0 280 218 119
Phase sensor	03.07→	NOC	0 232 103 052
Speed sensor, ignition/injection	03.07→	FKW	0 261 210 151
Knock sensor	03.07→		0 261 231 173
Temperature sensor, coolant, injection system	03.07→		0 281 002 170
1.3 CDTi [H] 1,3l 66 kW Z 13 DTH 4 Zyl.			
Air mass meter, diesel	08.05→		0 281 002 683
High-pressure sensor (CR system)	08.05→		0 281 002 534
Boost pressure sensor, Diesel	08.05→		0 281 002 437
1.4i [F] 1,4l 44/60/66 kW C/X 14 NZ; X 14 XE; 14 SE / C 14 SE 4 Zyl.			
Temperature sensor, coolant, injection system	09.91-02.98		0 280 130 107
1.4i [G] 1,4l 66 kW X 14 XE 4 Zyl.			
Temperature sensor, coolant, injection system	09.97-09.00		0 281 002 169
1.4i [H] 1,4l 55 kW Z 14 XEL 4 Zyl.			
Throttle valve assembly	09.04-09.05		0 280 750 133
Air mass meter, gasoline injection	09.04-09.05		0 280 218 119
Phase sensor			
Fg.no. →52999999, →55999999, →58999999	09.04-09.05	NOC	0 232 103 052
Fg.no. 62000001→, 65000001→, 68000001→	09.04-09.05	NOC	0 232 103 067
Speed sensor, ignition/injection	09.04-09.05	FKW	0 261 210 151
Knock sensor	09.04-09.05		0 261 231 173
Temperature sensor, coolant, injection system	09.04-09.05		0 281 002 170



Product

◀ Astra

1.4 Twinport [G]		1,4l 66 kW Z 14 XEP 4 Zyl.
Throttle valve assembly	09.03-01.04	0 280 750 133
Phase sensor	09.03-01.04 NOC	0 232 103 021
Speed sensor, ignition/injection	09.03-01.04 FKW	0 261 210 151
Knock sensor	09.03-01.04	0 261 231 173
Temperature sensor, coolant, injection system	09.03-01.04	0 281 002 170
1.4 Twinport [H]		1,4l 66 kW Z 14 XEP 4 Zyl.
Throttle valve assembly	03.04→	0 280 750 133
Air mass meter, gasoline injection	03.04→	0 280 218 119
Phase sensor		
Fg.no. →42999999,→45999999,→48999999	03.04→ NOC	0 232 103 021
Fg.no. 52000001→52999999,55000001→55999999,58000001→58999999	03.04→ NOC	0 232 103 052
Fg.no. 62000001→,65000001→,68000001→	03.04→ NOC	0 232 103 067
Speed sensor, ignition/injection	03.04→ FKW	0 261 210 151
Knock sensor	03.04→	0 261 231 173
Temperature sensor, coolant, injection system	03.04→	0 281 002 170
1.6 i [F]		1,6l 52/55 kW C/E 16 NZ; X 16 SZ,SZR; 16 LZ2,NZ2,16 NZR 4 Zyl.
Temperature sensor, coolant, injection system	09.91-02.98	0 280 130 107
1.6 i [F]		1,6l 74 kW C 16 SE; X 16 XEL 4 Zyl.
Temperature sensor, coolant, injection system	03.92-02.98	0 280 130 107
1.6 i [G]		1,6l 55/74 kW C 16 SEL; X 16 SZR; X 16 XEL 4 Zyl.
Temperature sensor, coolant, injection system	09.97-01.04	0 281 002 169
1.6 i [G]		1,6l 74 kW Z 16 XE 4 Zyl.
Yaw rate sensor, brake system	09.00-01.04	0 265 005 262
Steering angle sensor, ESP (electronic stability program)	09.00-01.04	0 265 005 435
Pressure sensor, ESP, (electronic stability program)	09.00-01.04	0 265 005 303
1.6 i Twinport [G]		1,6l 76 kW Z 16 XEP 4 Zyl.
Yaw rate sensor, brake system	03.03-01.04	0 265 005 262
Steering angle sensor, ESP (electronic stability program)	03.03-01.04	0 265 005 435
Pressure sensor, ESP, (electronic stability program)	03.03-01.04	0 265 005 303
1.6 Turbo [H]		1,6l 132 kW Z 16 LET 4 Zyl.
Air mass meter, gasoline injection	02.07→	0 280 218 142
Phase sensor	02.07→ NOC	0 232 103 052
Knock sensor	02.07→	0 261 231 173
Pressure sensor, intake manifold, gasoline	02.07→	0 261 230 009
1.7 CDTi [G]		1,7l 59 kW Z 17 DTL 4 Zyl.
Air mass meter, diesel	03.03-01.04	0 281 002 549
1.7 CDTi [H]		1,7l 59/74 kW Z 17 DTH; Z 17 DTL 4 Zyl.
Air mass meter, diesel	03.04-03.07	0 281 002 683
1.7 DT [G]		1,7l 50 kW X 17 DTL 4 Zyl.
Air mass meter, diesel	03.98-08.00	0 281 002 180
Speed sensor, diesel	03.98-08.00	0 281 002 285
Temperature sensor, coolant, diesel	03.98-08.00	0 281 002 259
Accelerator pedal module	03.98-08.00 AG,LLE	0 281 002 236
	AG,RLE	0 281 002 237
1.7 DTi [G]		1,7l 55 kW Y 17 DT 4 Zyl.
Air mass meter, diesel	09.00-01.04	0 281 002 180
1.8 i [F]		1,8l 66 kW C 18 NZ 4 Zyl.
Temperature sensor, coolant, injection system	09.91-02.98	0 280 130 107
1.8 i [F]		1,8l 82 kW 18 SE 4 Zyl.
Throttle valve sensor	09.95-09.96	0 280 120 316
Air mass meter, gasoline injection	09.95-09.96	0 280 217 003
Temperature sensor, intake air, injection system	09.95-09.96	0 280 130 073
1.8 i [F]		1,8l 85 kW C 18 SEL; C 18 XEL; X 18 XE 4 Zyl.
Throttle valve sensor	09.95-08.98	0 280 122 001
1.8 i [F]		1,8l 92 kW C 18 XE 4 Zyl.
Throttle valve sensor	09.93-02.98	0 280 122 001

Product

1.8 i [F]		1,8l 99 kW 18SEL 16V 4 Zyl.
Temperature sensor, intake air, injection system	01.96-12.98	0 280 130 073
1.8 i [G]		1,8l 85 kW X 18 XE1 4 Zyl.
Yaw rate sensor, brake system	09.97-08.00	0 265 005 261
Steering angle sensor, ESP (electronic stability program)	09.97-08.00	0 265 005 435
Pressure sensor, ESP, (electronic stability program)	09.97-08.00	0 265 005 303
1.8 i [G]		1,8l 85 kW Z 18 XEL 4 Zyl.
Yaw rate sensor, brake system	03.01-01.04	0 265 005 262
Steering angle sensor, ESP (electronic stability program)		
Fg.no. 12000001→,1H000001→,22000001→,25000001→,26000001→,28000001→,2H000001→,1B000001→	03.01-01.04	0 265 005 435
Pressure sensor, ESP, (electronic stability program)	03.01-01.04	0 265 005 303
1.8 i [G]		1,8l 92 kW Z 18 XE 4 Zyl.
Yaw rate sensor, brake system	09.00-01.04	0 265 005 262
Steering angle sensor, ESP (electronic stability program)	09.00-01.04	0 265 005 435
Pressure sensor, ESP, (electronic stability program)	09.00-01.04	0 265 005 303
1.9 CDTi [H]		1,9l 74 kW Z 19... 4 Zyl.
Air mass meter, diesel	09.05→	0 281 002 683
Speed sensor, diesel	09.05→	0 281 002 603
Phase sensor	09.05→ NOC	0 281 002 213
High-pressure sensor (CR system)	09.05→	0 281 002 534
1.9 CDTi [H]		1,9l 88 kW Z 19... 4 Zyl.
High-pressure sensor (CR system)	04.04→	0 281 002 534
Boost pressure sensor, Diesel	04.04→	0 281 002 437
1.9 CDTi [H]		1,9l 110 kW Z 19 DTH 4 Zyl.
Air mass meter, diesel	04.04→	0 281 002 683
Boost pressure sensor, Diesel	04.04→	0 281 002 437
2.0 DT [G]		2,0l 60 kW X 20 DTL 4 Zyl.
Air mass meter, diesel	03.98-08.00	0 281 002 180
Speed sensor, diesel	03.98-08.00	0 281 002 138
Temperature sensor, coolant, diesel	03.98-08.00	0 281 002 169
Accelerator pedal module	03.98-08.00 AG,LLE	0 281 002 236
	AG,RLE	0 281 002 237
2.0 DTi [G]		2,0l 74 kW Y 20 DTH 4 Zyl.
Air mass meter, diesel		
Fg.no. →Y2999999,→Y5999999,→Y6999999,→Y8999999,→YH999999	09.00-01.04	0 281 002 180
Fg.no. 12000001→22999999,15000001→25999999,16000001→26999999,18000001→28999999,1H000001→2B999999,→2H999999	09.00-01.04	0 281 002 428
Fg.no. 32000001→,35000001→,36000001→,38000001→,3B000001→,3H000001→	09.00-01.04	0 281 002 478
Speed sensor, diesel	09.00-01.04	0 281 002 138
Pressure sensor, intake manifold, diesel		
Fg.no. →Y2999999,→Y5999999,→Y6999999,→Y8999999,→YB999999,→YH999999	09.00-01.04	0 281 002 137
Fg.no. 12000001→22999999,15000001→25999999,16000001→26999999,18000001→28999999,1B000001→2B999999,1H000001→2H999999	09.00-01.04	0 281 002 438




Temperature sensor, coolant, diesel	09.00-01.04		0 281 002 169
Accelerator pedal module	09.00-01.04	AG,LLE	0 281 002 236
		AG,RLE	0 281 002 237
2.0 DTL [G]		2,0l 60 kW Y 20 DTL 4 Zyl.	
Air mass meter, diesel			
Fg.no. →Y2999999,→Y5999999, →Y6999999,→Y8999999,→YH999999	09.00-01.04		0 281 002 180
Fg.no. 12000001→,15000001→, 16000001→,18000001→,1H000001→	09.00-01.04		0 281 002 428
Speed sensor, diesel	09.00-01.04		0 281 002 138
Temperature sensor, coolant, diesel	09.00-01.04		0 281 002 169
Accelerator pedal module	09.00-01.04	AG,LLE	0 281 002 236
		AG,RLE	0 281 002 237
2.0 i [F]		2,0l 85 kW C 20 NE/20 NE 4 Zyl.	
Throttle valve sensor	09.91-02.98		0 280 122 001
Air mass meter, gasoline injection	09.91-02.98		0 280 217 003
Speed sensor, ignition/injection			
Fg.no. S2000001→,S3000001→, S4000001→,S5000001→, S6000001→,S8000001→	09.91-02.98		0 261 210 030
Temperature sensor, intake air, injection system	09.91-02.98		0 280 130 073
Temperature sensor, coolant, injection system	09.91-02.98		0 280 130 107
2.0 i [F]		2,0l 100 kW X 20 XEV 4 Zyl.	
Throttle valve sensor	01.95-02.98		0 280 122 001
2.0 i [F]		2,0l 110 kW C 20 XE/XE-LN 4 Zyl.	
Throttle valve sensor	09.91-08.92		0 280 120 436
	09.92-02.98		0 280 122 004
Air mass meter, gasoline injection			
Fg.no. P2500001→,P3000001→, P4000001→,P5000001→, P6000001→,P8000001→	09.91-02.98		0 280 217 106
Fg.no. →NA2999999,→NE2999999, →N2999999,→N4999999,→N5999999, →N6999999	09.91-02.98		0 280 212 015
			0 986 280 113
Speed sensor, ignition/injection	09.91-02.98		0 261 210 030
Knock sensor	09.91-06.95		0 261 231 006
Temperature sensor, intake air, injection system	09.91-02.98		0 280 130 073
Temperature sensor, coolant, injection system	09.91-02.98		0 280 130 107
2.0 i [G]		2,0l 100 kW X 20 XEV 4 Zyl.	
Throttle valve sensor	09.97-01.04		0 280 122 014
2.0 i [G]		2,0l 100 kW 20SEL 4 Zyl.	
Throttle valve sensor	10.99-12.01		0 280 122 001
Knock sensor	10.99-12.01		0 261 231 007
Temperature sensor, intake air, injection system	10.99-12.01		0 280 130 073
Temperature sensor, coolant, injection system	10.99-12.01		0 280 130 107
2.0 i [G]		2,0l 118 kW X 20 XER 4 Zyl.	
Throttle valve sensor	10.99-09.02		0 280 122 014
2.0 Turbo [G]		2,0l 141-147 kW Z 20 LET 4 Zyl.	
Air mass meter, gasoline injection	09.02-01.04		0 280 218 051
			0 986 280 231
Phase sensor	09.02-01.04		0 232 103 015
Speed sensor, ignition/injection	09.02-01.04	FKW	0 261 210 150
Knock sensor	09.02-01.04		0 261 231 116
Pressure sensor, intake manifold, gasoline	09.02-01.04		0 261 230 009
Temperature sensor, coolant, injection system	09.02-01.04		0 281 002 169
Yaw rate sensor, brake system	09.02-01.04		0 265 005 262
Steering angle sensor, ESP (electronic stability program)	09.02-01.04		0 265 005 435
Pressure sensor, ESP, (electronic stability program)	09.02-01.04		0 265 005 303
2.0 Turbo [H]		2,0l 125/147 kW Z 20 LEL; Z 20 LER 4 Zyl.	
Air mass meter, gasoline injection	03.04→		0 280 218 142
Phase sensor	03.04→	NOC	0 232 103 015
Speed sensor, ignition/injection	03.04→	FKW	0 261 210 150



Knock sensor	03.04→		0 261 231 181
Pressure sensor, intake manifold, gasoline	03.04→		0 281 002 137
Temperature sensor, coolant, injection system	03.04→		0 281 002 169
2.0 Turbo [H]		2,0l 177 kW Z 20 LEH 4 Zyl.	
Air mass meter, gasoline injection			
Fg.no. →52999999,→55999999, →58999999	09.05→		0 280 218 164
Fg.no. 62000001→,65000001→, 68000001→	09.05→		0 280 218 211
Phase sensor	09.05→	NOC	0 232 103 015
Speed sensor, ignition/injection	09.05→	FKW	0 261 210 150
Knock sensor	09.05→		0 261 231 181
Pressure sensor, intake manifold, gasoline	09.05→		0 281 002 137
Temperature sensor, coolant, injection system	09.05→		0 281 002 169
2.2 DTI [G]		2,2l 92 kW Y 22 DTR 4 Zyl.	
Air flow sensor, diesel	09.01-01.04		0 281 002 478
Speed sensor, diesel	09.01-01.04	FKW	0 281 002 138
Boost pressure sensor, Diesel	09.01-01.04		0 281 002 437
Temperature sensor, coolant, diesel	09.01-01.04		0 281 002 170
Yaw rate sensor, brake system			
Fg.no. 22000001→,2B000001→, 2H000001→,25000001→, 26000001→,28000001→	09.01-01.04		0 265 005 262
Steering angle sensor, ESP (electronic stability program)			
Fg.no. 12000001→,1H000001→, 22000001→,25000001→,26000001→, 28000001→,2H000001→,1B000001→	09.01-01.04		0 265 005 435
Pressure sensor, ESP, (electronic stability program)	09.01-01.04		0 265 005 303
2.2 i [G]		2,2l 108 kW Z 22 SE 4 Zyl.	
Yaw rate sensor, brake system	09.00-01.04		0 265 005 262
Steering angle sensor, ESP (electronic stability program)			
Fg.no. 12000001→,1H000001→, 22000001→,25000001→,26000001→, 28000001→,2H000001→,1B000001→	09.00-01.04		0 265 005 435
Pressure sensor, ESP, (electronic stability program)	09.00-01.04		0 265 005 303

Astra Cabrio

1.4 i [F]		1,4l 44/60/66 kW C/X 14 NZ; X 14 XE; 14 SE/ C 14 SE 4 Zyl.	
Temperature sensor, coolant, injection system	09.91-02.98		0 280 130 107
1.4 i [G]		1,4l 66 kW X 14 XE 4 Zyl.	
Temperature sensor, coolant, injection system	09.97-02.05		0 281 002 169
1.6 i [F]		1,6l 52/55 kW C/E 16 NZ; X 16 SZ,SZR; 16 LZ2,NZ2,16 NZR 4 Zyl.	
Temperature sensor, coolant, injection system	09.91-02.98		0 280 130 107
1.6 i [F]		1,6l 74 kW X 16 XEL 4 Zyl.	
Temperature sensor, coolant, injection system	09.94-02.98		0 280 130 107
1.6 i [G]		1,6l 74 kW X 16 XEL 4 Zyl.	
Temperature sensor, coolant, injection system	09.97-08.00		0 281 002 169
1.6 i TwinTop [H]		1,6l 85 kW Z 16 XER 4 Zyl.	
Pressure sensor, intake manifold, gasoline	01.07→		0 261 230 009
1.6 i TwinTop [H]		1,6l 132 kW Z 16 LET 4 Zyl.	
Air mass meter, gasoline injection	02.07→		0 280 218 142
Phase sensor	02.07→	NOC	0 232 103 052
Pressure sensor, intake manifold, gasoline	02.07→		0 261 230 009
1.6 Twinport [G]		1,6l 76 kW Z 16 XEP 4 Zyl.	
Yaw rate sensor, brake system	03.03-08.05		0 265 005 262
Steering angle sensor, ESP (electronic stability program)	03.03-08.05		0 265 005 435
Pressure sensor, ESP, (electronic stability program)	03.03-08.05		0 265 005 303
1.7 CDTI [G]		1,7l 59 kW Z 17 DTL Turbo 4 Zyl.	
Air mass meter, diesel	03.03-08.05		0 281 002 549





Product				

◀ Astra Cabrio

1.8 i [F]	1,8 l 66 kW C 18 NZ 4 Zyl.
Temperature sensor, coolant, injection system	09.91-02.98 0 280 130 107
1.8 i [F]	1,8 l 85 kW C 18 XEL; X 18 XE 4 Zyl.
Throttle valve sensor	09.95-08.98 0 280 122 001
1.8 i [F]	1,8 l 92 kW C 18 XE 4 Zyl.
Throttle valve sensor	09.93-02.98 0 280 122 001
1.8 i [G]	1,8 l 92 kW Z 18 XE 4 Zyl.
Yaw rate sensor, brake system	09.00-08.05 0 265 005 262
Steering angle sensor, ESP (electronic stability program)	
Fg.no. 1B000001→	09.00-08.05 0 265 005 433
Pressure sensor, ESP, (electronic stability program)	09.00-08.05 0 265 005 303
1.9 CDTi TwinTop [H]	1,9 l 110 kW Z 19 DTH 4 Zyl.
Air mass meter, diesel	09.05→ 0 281 002 683
High-pressure sensor (CR system)	09.05→ 0 281 002 706
Boost pressure sensor, Diesel	09.05→ 0 281 002 437
2.0 i [F]	2,0 l 85 kW C 20 NE / 20 NE 4 Zyl.
Throttle valve sensor	09.91-02.98 0 280 122 001
Air mass meter, gasoline injection	09.91-02.98 0 280 217 003
Speed sensor, ignition/injection	
Fg.no. S2000001→,S3000001→,S4000001→,S5000001→,S6000001→,S8000001→	09.91-02.98 0 261 210 030
Temperature sensor, intake air, injection system	09.91-02.98 0 280 130 073
Temperature sensor, coolant, injection system	09.91-02.98 0 280 130 107
2.0 i [F]	2,0 l 100 kW X 20 XEV 4 Zyl.
Throttle valve sensor	01.95-02.98 0 280 122 001
2.0 i [F]	2,0 l 110 kW C 20 XE / XE-LN 4 Zyl.
Throttle valve sensor	09.91-08.92 0 280 120 436
	09.92-02.98 0 280 122 004
Air mass meter, gasoline injection	
Fg.no. P2500001→,P3000001→,P4000001→,P5000001→,P6000001→,P8000001→	09.91-02.98 0 280 217 106
Fg.no. →NA299999,→NE299999,→N299999,→N499999,→N599999,→N699999	09.91-02.98 0 280 212 015 0 986 280 113
Speed sensor, ignition/injection	09.91-02.98 0 261 210 030
Knock sensor	09.91-06.95 0 261 231 006
Temperature sensor, intake air, injection system	09.91-02.98 0 280 130 073
Temperature sensor, coolant, injection system	09.91-02.98 0 280 130 107
2.0 i Turbo TwinTop [H]	2,0 l 125/147 kW Z 20 LEL; Z 20 LER 4 Zyl.
Air mass meter, gasoline injection	09.05→ 0 280 218 142
Phase sensor	09.05→ NOC 0 232 103 015
Speed sensor, ignition/injection	09.05→ FKW 0 261 210 150
Knock sensor	09.05→ 0 261 231 181
Pressure sensor, intake manifold, gasoline	09.05→ 0 281 002 137
Temperature sensor, coolant, injection system	09.05→ 0 281 002 169
2.0 Turbo [G]	2,0 l 141-147 kW Z 20 LET 4 Zyl.
Throttle valve sensor	03.02-08.05 0 280 122 014
Air mass meter, gasoline injection	03.02-08.05 0 280 218 051 0 986 280 231
Phase sensor	03.02-08.05 0 232 103 015
Speed sensor, ignition/injection	03.02-08.05 FKW 0 261 210 150
Knock sensor	03.02-08.05 0 261 231 116
Temperature sensor, coolant, injection system	03.02-08.05 0 281 002 169
Yaw rate sensor, brake system	03.02-08.05 0 265 005 262
Steering angle sensor, ESP (electronic stability program)	
Fg.no. 12000001→,1H000001→,22000001→,25000001→,26000001→,28000001→,2H000001→,1B000001→	03.02-08.05 0 265 005 435
Pressure sensor, ESP, (electronic stability program)	03.02-08.05 0 265 005 303

Product				

2.2 DTi [G]	2,2 l 92 kW Y 22 DTR 4 Zyl.
Air flow sensor, diesel	03.02-08.05 0 281 002 478
Speed sensor, diesel	03.02-08.05 FKW 0 281 002 138
Boost pressure sensor, Diesel	03.02-08.05 0 281 002 437
Temperature sensor, coolant, diesel	03.02-08.05 0 281 002 170
Yaw rate sensor, brake system	03.02-08.05 0 265 005 262
Steering angle sensor, ESP (electronic stability program)	
Fg.no. →YB999999	03.02-08.05 0 265 005 433
Fg.no. 12000001→,1H000001→,22000001→,25000001→,26000001→,28000001→,2H000001→,1B000001→	03.02-08.05 0 265 005 435
Pressure sensor, ESP, (electronic stability program)	03.02-08.05 0 265 005 303
2.2 i [G]	2,2 l 108 kW Z 22 SE 4 Zyl.
Yaw rate sensor, brake system	09.00-08.05 0 265 005 262
Steering angle sensor, ESP (electronic stability program)	09.00-08.05 0 265 005 435
Pressure sensor, ESP, (electronic stability program)	09.00-08.05 0 265 005 303

Astra Caravan

1.2 i [G]	1,2 l 48 kW X 12 XE 4 Zyl.
Throttle valve assembly	09.97-09.03 0 205 003 050
Throttle valve sensor	09.97-09.03 0 280 122 014
Air mass meter, gasoline injection	09.97-09.03 0 280 217 123
Phase sensor	09.97-09.03 NOC 0 232 103 021
Speed sensor, ignition/injection	09.97-09.03 FKW 0 261 210 151
Knock sensor	09.97-09.03 0 261 231 120
Temperature sensor, coolant, injection system	09.97-09.03 0 281 002 169
1.2 i [G]	1,2 l 55 kW Z 12 XE 4 Zyl.
Throttle valve assembly	09.00-09.03 0 280 750 044
Air mass meter, gasoline injection	09.00-09.03 0 280 218 031 0 986 280 230
Phase sensor	09.00-09.03 NOC 0 232 103 021
Speed sensor, ignition/injection	09.00-09.03 FKW 0 261 210 151
Knock sensor	09.00-09.03 0 261 231 120
Temperature sensor, coolant, injection system	09.00-09.03 0 281 002 169
1.2 Twinport [H]	1,2 l 59 kW Z 12 XEP 4 Zyl.
Throttle valve assembly	03.07→ 0 280 750 133
Air mass meter, gasoline injection	03.07→ 0 280 218 119
Phase sensor	03.07→ NOC 0 232 103 052
Speed sensor, ignition/injection	03.07→ FKW 0 261 210 151
Knock sensor	03.07→ 0 261 231 173
Temperature sensor, coolant, injection system	03.07→ 0 281 002 170
1.3 CDTi [H]	1,3 l 66 kW Z 13 DTH 4 Zyl.
Air mass meter, diesel	08.05→ 0 281 002 683
High-pressure sensor (CR system)	08.05→ 0 281 002 534
Boost pressure sensor, Diesel	08.05→ 0 281 002 437
1.4 [H]	1,4 l 55 kW Z 14 XEL 4 Zyl.
Throttle valve assembly	09.04-09.05 0 280 750 133
Air mass meter, gasoline injection	09.04-09.05 0 280 218 119
Phase sensor	
Fg.no. →52999999,→55999999,→58999999	09.04-09.05 NOC 0 232 103 052
Fg.no. 62000001→,65000001→,68000001→	09.04-09.05 NOC 0 232 103 067
Speed sensor, ignition/injection	09.04-09.05 FKW 0 261 210 151
Knock sensor	09.04-09.05 0 261 231 173
Temperature sensor, coolant, injection system	09.04-09.05 0 281 002 170
1.4 i [F]	1,4 l 44/60/66 kW C/X 14 NZ; X 14 XE; 14 SE / C 14 SE 4 Zyl.
Temperature sensor, coolant, injection system	09.91-02.98 0 280 130 107
1.4 i [G]	1,4 l 66 kW X 14 XE 4 Zyl.
Temperature sensor, coolant, injection system	09.97-09.00 0 281 002 169

Product




1.4 Twinport [G]	1,4 l 66 kW Z 14 XEP 4 Zyl.
Throttle valve assembly	09.03-03.04 0 280 750 133
Phase sensor	09.03-03.04 NOC 0 232 103 021
Speed sensor, ignition/injection	09.03-03.04 FKW 0 261 210 151
Knock sensor	09.03-03.04 0 261 231 173
Temperature sensor, coolant, injection system	09.03-03.04 0 281 002 170
1.4 Twinport [H]	1,4 l 66 kW Z 14 XEP 4 Zyl.
Throttle valve assembly	08.04→ 0 280 750 133
Air mass meter, gasoline injection	08.04→ 0 280 218 119
Phase sensor	
Fg.no. →42999999,→45999999,→48999999	08.04→ NOC 0 232 103 021
Fg.no. 52000001→52999999, 55000001→55999999, 58000001→58999999	08.04→ NOC 0 232 103 052
Fg.no. 62000001→,65000001→, 68000001→	08.04→ NOC 0 232 103 067
Speed sensor, ignition/injection	08.04→ FKW 0 261 210 151
Knock sensor	08.04→ 0 261 231 173
Temperature sensor, coolant, injection system	08.04→ 0 281 002 170
1.6 i [F]	1,6 l 52/55 kW C/E 16 NZ; X 16 SZ, SZR; 16 LZ2, NZ2, NZR 4 Zyl.
Temperature sensor, coolant, injection system	09.91-02.98 0 280 130 107
1.6 i [F]	1,6 l 74 kW C 16 SE; X 16 XEL 4 Zyl.
Temperature sensor, coolant, injection system	03.92-02.98 0 280 130 107
1.6 i [G]	1,6 l 55/74 kW C 16 SEL; X 16 SZR; X 16 XEL 4 Zyl.
Temperature sensor, coolant, injection system	09.97-06.04 0 281 002 169
1.6 i [G]	1,6 l 74 kW Z 16 XE 4 Zyl.
Yaw rate sensor, brake system	09.00-06.04 0 265 005 262
Steering angle sensor, ESP (electronic stability program)	09.00-06.04 0 265 005 435
Pressure sensor, ESP, (electronic stability program)	09.00-06.04 0 265 005 303
1.6 i CNG [G]	1,6 l 69-73 kW Z 16 YNG 4 Zyl.
Yaw rate sensor, brake system	09.02-06.04 0 265 005 262
Steering angle sensor, ESP (electronic stability program)	09.02-06.04 0 265 005 435
1.6 i Twinport [G]	1,6 l 76 kW Z 16 XEP 4 Zyl.
Yaw rate sensor, brake system	03.03-06.04 0 265 005 262
Steering angle sensor, ESP (electronic stability program)	03.03-06.04 0 265 005 435
Pressure sensor, ESP, (electronic stability program)	03.03-06.04 0 265 005 303
1.6 Turbo [H]	1,6 l 132 kW Z 16 LET 4 Zyl.
Air mass meter, gasoline injection	09.07→ 0 280 218 142
Phase sensor	09.07→ NOC 0 232 103 052
Knock sensor	09.07→ 0 261 231 173
Pressure sensor, intake manifold, gasoline	09.07→ 0 261 230 009
1.7 CDTi [G]	1,7 l 59 kW Z 17 DTL 4 Zyl.
Air mass meter, diesel	03.03-06.04 0 281 002 549
1.7 CDTi [H]	1,7 l 59/74 kW Z 17 DTH; Z 17 DTL 4 Zyl.
Air mass meter, diesel	08.04-03.07 0 281 002 683
1.7 DT [G]	1,7 l 50 kW X 17 DTL 4 Zyl.
Air mass meter, diesel	03.98-08.00 0 281 002 180
Speed sensor, diesel	03.98-08.00 0 281 002 285
Temperature sensor, coolant, diesel	03.98-08.00 0 281 002 259
Accelerator pedal module	03.98-08.00 AG,LLE 0 281 002 236
	AG,RLE 0 281 002 237
1.7 DTi [G]	1,7 l 55 kW Y 17 DT 4 Zyl.
Air mass meter, diesel	09.00-06.04 0 281 002 180
1.8 i [F]	1,8 l 66 kW C 18 NZ 4 Zyl.
Temperature sensor, coolant, injection system	09.91-02.98 0 280 130 107
1.8 i [F]	1,8 l 82 kW 18 SE 4 Zyl.
Throttle valve sensor	09.95-09.96 0 280 120 316
Air mass meter, gasoline injection	09.95-09.96 0 280 217 003
Temperature sensor, intake air, injection system	09.95-09.96 0 280 130 073

Product



1.8 i [F]	1,8 l 85 kW C 18 SEL; C 18 XEL; X 18 XE 4 Zyl.
Throttle valve sensor	09.95-08.98 0 280 122 001
1.8 i [F]	1,8 l 92 kW C 18 XE 4 Zyl.
Throttle valve sensor	09.93-02.98 0 280 122 001
1.8 i [G]	1,8 l 85 kW X 18 XE1 4 Zyl.
Yaw rate sensor, brake system	09.97-08.00 0 265 005 261
Steering angle sensor, ESP (electronic stability program)	09.97-08.00 0 265 005 435
Pressure sensor, ESP, (electronic stability program)	09.97-08.00 0 265 005 303
1.8 i [G]	1,8 l 85 kW Z 18 XEL 4 Zyl.
Yaw rate sensor, brake system	03.01-06.04 0 265 005 262
Steering angle sensor, ESP (electronic stability program)	
Fg.no. 12000001→,1H000001→, 22000001→,25000001→,26000001→, 28000001→,2H000001→,1B000001→	03.01-06.04 0 265 005 435
Pressure sensor, ESP, (electronic stability program)	03.01-06.04 0 265 005 303
1.8 i [G]	1,8 l 92 kW Z 18 XE 4 Zyl.
Yaw rate sensor, brake system	09.00-06.04 0 265 005 262
Steering angle sensor, ESP (electronic stability program)	09.00-06.04 0 265 005 435
Pressure sensor, ESP, (electronic stability program)	09.00-06.04 0 265 005 303
1.9 CDTi [H]	1,9 l 74 kW Z 19 ... 4 Zyl.
Air mass meter, diesel	09.05→ 0 281 002 683
Speed sensor, diesel	09.05→ 0 281 002 603
Phase sensor	09.05→ NOC 0 281 002 213
High-pressure sensor (CR system)	09.05→ 0 281 002 534
1.9 CDTi [H]	1,9 l 88 kW Z 19 ... 4 Zyl.
High-pressure sensor (CR system)	09.04→ 0 281 002 534
Boost pressure sensor, Diesel	09.04→ 0 281 002 437
1.9 CDTi [H]	1,9 l 110 kW Z 19 DTH 4 Zyl.
Air mass meter, diesel	09.04→ 0 281 002 683
Boost pressure sensor, Diesel	09.04→ 0 281 002 437
2.0 DT [G]	2,0 l 60 kW X 20 DTL 4 Zyl.
Air mass meter, diesel	03.98-08.00 0 281 002 180
Speed sensor, diesel	03.98-08.00 0 281 002 138
Temperature sensor, coolant, diesel	03.98-08.00 0 281 002 169
Accelerator pedal module	03.98-08.00 AG,LLE 0 281 002 236
	AG,RLE 0 281 002 237
2.0 DTi [G]	2,0 l 74 kW Y 20 DTH 4 Zyl.
Air mass meter, diesel	
Fg.no. →Y2999999,→Y5999999,→Y6999999,→Y8999999,→YH999999	09.00-06.04 0 281 002 180
Fg.no. 12000001→22999999, 15000001→25999999, 16000001→26999999, 18000001→28999999, 1H000001→2B999999,→2H999999	09.00-06.04 0 281 002 428
Fg.no. 32000001→,35000001→, 36000001→,38000001→,3B000001→, 3H000001→	09.00-06.04 0 281 002 478
Speed sensor, diesel	09.00-06.04 0 281 002 138
Pressure sensor, intake manifold, diesel	
Fg.no. →Y2999999,→Y5999999,→Y6999999,→Y8999999,→YB999999,→YH999999	09.00-06.04 0 281 002 137
Fg.no. 12000001→22999999, 15000001→25999999, 16000001→26999999, 18000001→28999999, 1B000001→2B999999, 1H000001→2H999999	09.00-06.04 0 281 002 438



</

Product				
Air mass meter, gasoline injection				
Fg.no. 62000001→,65000001→,68000001→	09.05→			0 280 218 211
Phase sensor	09.05→	NOC		0 232 103 015
Speed sensor, ignition/injection	09.05→	FKW		0 261 210 150
Knock sensor	09.05→			0 261 231 181
Pressure sensor, intake manifold, gasoline	09.05→			0 281 002 137
Temperature sensor, coolant, injection system	09.05→			0 281 002 169
2.2 DTi [G]	2,2 l	92 kW	Y 22 DTR	4 Zyl.
Air flow sensor, diesel	09.01-06.04			0 281 002 478
Speed sensor, diesel	09.01-06.04	FKW		0 281 002 138
Boost pressure sensor, Diesel	09.01-06.04			0 281 002 437
Temperature sensor, coolant, diesel	09.01-06.04			0 281 002 170
Yaw rate sensor, brake system				
Fg.no. 22000001→,2B000001→,2H000001→,25000001→,26000001→,28000001→	09.01-06.04			0 265 005 262
Steering angle sensor, ESP (electronic stability program)				
Fg.no. 12000001→,1H000001→,22000001→,25000001→,26000001→,28000001→,2H000001→,1B000001→	09.01-06.04			0 265 005 435
Pressure sensor, ESP, (electronic stability program)	09.01-06.04			0 265 005 303
2.2 i [G]	2,2 l	108 kW	Z 22 SE	4 Zyl.
Yaw rate sensor, brake system	09.00-06.04			0 265 005 262
Steering angle sensor, ESP (electronic stability program)				
Fg.no. 12000001→,1H000001→,22000001→,25000001→,26000001→,28000001→,2H000001→,1B000001→	09.00-06.04			0 265 005 435
Pressure sensor, ESP, (electronic stability program)	09.00-06.04			0 265 005 303
Astra Classic				
1.4 i [F-Classi	1,4 l	44 kW	X 14 NZ	4 Zyl.
Temperature sensor, intake air, injection system	09.97-08.00			0 280 130 107
1.6 i [F-Classi	1,6 l	55 kW	X 16 SZR	4 Zyl.
Temperature sensor, intake air, injection system	09.97-08.00			0 280 130 107
1.6 i [F-Classi	1,6 l	74 kW	X 16 XEL	4 Zyl.
Temperature sensor, coolant, injection system	09.97-08.00			0 280 130 093
Astra Classic Caravan				
1.4 i [F-Classi	1,4 l	44 kW	X 14 NZ	4 Zyl.
Temperature sensor, intake air, injection system	09.97-08.00			0 280 130 107
1.6 i [F-Classi	1,6 l	55 kW	X 16 SZR	4 Zyl.
Temperature sensor, intake air, injection system	09.97-08.00			0 280 130 107
1.6 i [F-Classi	1,6 l	74 kW	X 16 XEL	4 Zyl.
Temperature sensor, coolant, injection system	09.97-08.00			0 280 130 093
Astra Coupé				
1.6 Twinport [G]	1,6 l	76 kW	Z 16 XEP	4 Zyl.
Pressure sensor, ESP, (electronic stability program)	03.03-02.05			0 265 005 303
1.7 CDTi [G]	1,7 l	59 kW	Z 17 DTL	4 Zyl.
Air mass meter, diesel	03.03-02.05			0 281 002 549
1.8 i [G]	1,8 l	85 kW	Z 18 XEL	4 Zyl.
Yaw rate sensor, brake system	03.01-02.05			0 265 005 262
Steering angle sensor, ESP (electronic stability program)	03.01-02.05			0 265 005 435
Pressure sensor, ESP, (electronic stability program)	03.01-02.05			0 265 005 303

Product



1.8i [G]	1,8l 92 kW Z 18 XE 4 Zyl.
Yaw rate sensor, brake system	09.00-02.05 0 265 005 262
Steering angle sensor, ESP (electronic stability program)	09.00-02.05 0 265 005 433
Pressure sensor, ESP, (electronic stability program)	09.00-02.05 0 265 005 303
2.0 Turbo [G]	2,0l 141-147 kW Z 20 LET 4 Zyl.
Throttle valve sensor	09.00-02.05 0 280 122 014
Air mass meter, gasoline injection	09.00-02.05 0 280 218 051
	0 986 280 231
Phase sensor	09.00-02.05 0 232 103 015
Speed sensor, ignition/injection	09.00-02.05 FKW 0 261 210 150
Knock sensor	09.00-02.05 0 261 231 116
Temperature sensor, coolant, injection system	09.00-02.05 0 281 002 169
Yaw rate sensor, brake system	09.00-02.05 0 265 005 262
Steering angle sensor, ESP (electronic stability program)	
Fg.no. 12000001→, 1H000001→, 22000001→, 25000001→, 26000001→, 28000001→, 2H000001→, 1B000001→	09.00-02.05 0 265 005 435
Pressure sensor, ESP, (electronic stability program)	09.00-02.05 0 265 005 303
2.2 DTi [G]	2,2l 92 kW Y 22 DTR 4 Zyl.
Air flow sensor, diesel	03.02-02.05 0 281 002 478
Speed sensor, diesel	03.02-02.05 FKW 0 281 002 138
Boost pressure sensor, Diesel	03.02-02.05 0 281 002 437
Temperature sensor, coolant, diesel	03.02-02.05 0 281 002 170
Yaw rate sensor, brake system	03.02-02.05 0 265 005 262
Steering angle sensor, ESP (electronic stability program)	
Fg.no. 12000001→, 1H000001→, 22000001→, 25000001→, 26000001→, 28000001→, 2H000001→, 1B000001→	03.02-02.05 0 265 005 435
Pressure sensor, ESP, (electronic stability program)	03.02-02.05 0 265 005 303
2.2i [G]	2,2l 108 kW Z 22 SE 4 Zyl.
Yaw rate sensor, brake system	09.00-02.05 0 265 005 262
Steering angle sensor, ESP (electronic stability program)	09.00-02.05 0 265 005 435
Pressure sensor, ESP, (electronic stability program)	09.00-02.05 0 265 005 303

Astra GTC

1.3 CDTi [H]	1,3l 66 kW Z 13 DTH 4 Zyl.
Air mass meter, diesel	06.05→ 0 281 002 683
High-pressure sensor (CR system)	06.05→ 0 281 002 534
Boost pressure sensor, Diesel	06.05→ 0 281 002 437
1.4 Twinport [H]	1,4l 55 kW Z 14 XEL 4 Zyl.
Throttle valve assembly	09.05→ 0 280 750 133
Air mass meter, gasoline injection	09.05→ 0 280 218 119
Phase sensor	
Fg.no. →52999999, →55999999, →58999999	09.05→ NOC 0 232 103 052
Fg.no. 62000001→, 65000001→, 68000001→	09.05→ NOC 0 232 103 067
Speed sensor, ignition/injection	09.05→ FKW 0 261 210 151
Knock sensor	09.05→ 0 261 231 173
Temperature sensor, coolant, injection system	09.05→ 0 281 002 170
1.4 Twinport [H]	1,4l 66 kW Z 14 XEP 4 Zyl.
Throttle valve assembly	03.05→ 0 280 750 133
Air mass meter, gasoline injection	03.05→ 0 280 218 119
Phase sensor	
Fg.no. →42999999, →45999999, →48999999	03.05→ NOC 0 232 103 021
Fg.no. 52000001→52999999, 55000001→55999999, 58000001→58999999	03.05→ NOC 0 232 103 052


Product




Phase sensor			
Fg.no. 62000001→,65000001→, 68000001→	03.05→	NOC	0 232 103 067
Speed sensor, ignition/injection	03.05→	FKW	0 261 210 151
Knock sensor	03.05→		0 261 231 173
Temperature sensor, coolant, injection system	03.05→		0 281 002 170
1.7 CDTi [H]	1,7l 59/74 kW Z 17 DTH; Z 17 DTL 4 Zyl.		
Air mass meter, diesel	03.05-03.07		0 281 002 683
1.9 CDTi [H]	1,9l 88/110 kW Z 19 DTH; Z 19 DTJ 4 Zyl.		
Air mass meter, diesel	03.05→		0 281 002 683
High-pressure sensor (CR system)	03.05→		0 281 002 706
Boost pressure sensor, Diesel	03.05→		0 281 002 437
2.0 Turbo [H]	2,0l 125/147 kW Z 20 LEL; Z 20 LER 4 Zyl.		
Air mass meter, gasoline injection	03.05→		0 280 218 142
Phase sensor	03.05→	NOC	0 232 103 015
Speed sensor, ignition/injection	03.05→	FKW	0 261 210 150
Knock sensor	03.05→		0 261 231 181
Pressure sensor, intake manifold, gasoline	03.05→		0 281 002 137
Temperature sensor, coolant, injection system	03.05→		0 281 002 169
2.0 Turbo [H]	2,0l 177 kW Z 20 LEH 4 Zyl.		
Air mass meter, gasoline injection			
Fg.no. →52999999,→55999999, →58999999	08.05→		0 280 218 164
Fg.no. 62000001→,65000001→, 68000001→	08.05→		0 280 218 211
Phase sensor	08.05→	NOC	0 232 103 015
Speed sensor, ignition/injection	08.05→	FKW	0 261 210 150
Knock sensor	08.05→		0 261 231 181
Pressure sensor, intake manifold, gasoline	08.05→		0 281 002 137
Temperature sensor, coolant, injection system	08.05→		0 281 002 169

Calibra

2.0i	2,0l 85 kW C 20 NE 4 Zyl.
Throttle valve sensor	06.90-03.97 0 280 122 001
Speed sensor, ignition/injection	06.90-03.97 0 261 210 030
Temperature sensor, coolant, injection system	06.90-03.97 0 280 130 107
Wheel speed sensor, front	
Fg.no. L1000001→M1999999	06.90-03.97 0 265 001 206
Wheel speed sensor, rear	
Fg.no. L1000001→M1999999	06.90-03.97 AA,LAB 0 265 001 226
	LAB,NAA 0 265 001 233
	NAA,RAB 0 265 001 232
Fg.no. N1000001→	06.90-03.97 AA,LAB 0 265 006 487
	AA,RAB 0 265 006 486
	LAB,NAA 0 265 003 094
	NAA,RAB 0 265 003 093
2.0i	2,0l 100 kW X 20 XEV 4 Zyl.
Throttle valve sensor	09.93-08.96 0 280 122 001
Wheel speed sensor, front	
Fg.no. L1000001→M1999999	09.93-08.96 0 265 001 206
Wheel speed sensor, rear	
Fg.no. L1000001→M1999999	09.93-08.96 LAB,NAA 0 265 001 233
Fg.no. N1000001→	09.93-08.96 AA,LAB 0 265 006 487
	AA,RAB 0 265 006 486
	LAB,NAA 0 265 003 094
	NAA,RAB 0 265 003 093
2.0i	2,0l 110 kW C 20 XE,XE-LN 4 Zyl.
Throttle valve sensor	06.90-03.97 0 280 120 326
Air mass meter, gasoline injection	
Mot.no. →14002934	06.90-03.97 0 280 212 015
	0 986 280 113
Mot.no. 14002935→	06.90-03.97 0 280 217 106



Product				
◀ Calibra				
Speed sensor, ignition/injection	06.90-03.97			0 261 210 030
Knock sensor	06.90-03.97			0 261 231 006
Temperature sensor, intake air, injection system				
Fg.no. P1000001→,P9000001→	06.90-03.97			0 280 130 073
Temperature sensor, coolant, injection system	06.90-03.97			0 280 130 107
Wheel speed sensor, front				
Fg.no. L1000001→M1999999	06.90-03.97			0 265 001 206
Wheel speed sensor, rear				
Fg.no. L1000001→M1999999	06.90-03.97	AA,LAB	0 265 001 226	
		LAB,NAA	0 265 001 233	
		NAA,RAB	0 265 001 232	
Fg.no. N1000001→	06.90-03.97	AA,LAB	0 265 006 487	
		AA,RAB	0 265 006 486	
		LAB,NAA	0 265 003 094	
		NAA,RAB	0 265 003 093	
2.0 i Turbo 2,0l 150 kW C 20 LET 4 Zyl.				
Throttle valve sensor	03.92-03.97			0 280 122 004
Air mass meter, gasoline injection	03.92-03.97			0 280 213 024
				0 986 280 140
Speed sensor, ignition/injection	03.92-03.97			0 261 210 030
Knock sensor	03.92-03.97			0 261 231 006
Temperature sensor, intake air, injection system	03.92-03.97			0 280 130 039
Temperature sensor, coolant, injection system	03.92-03.97			0 280 130 107
Wheel speed sensor, front				
Fg.no. L1000001→M1999999	03.92-03.97			0 265 001 206
Wheel speed sensor, rear				
Fg.no. L1000001→M1999999	03.92-03.97	AA,LAB	0 265 001 226	
		LAB,NAA	0 265 001 233	
		NAA,RAB	0 265 001 232	
Fg.no. N1000001→	03.92-03.97	AA,LAB	0 265 006 487	
		AA,RAB	0 265 006 486	
		LAB,NAA	0 265 003 094	
		NAA,RAB	0 265 003 093	
2.5 i V6 2,5l 125 kW C 25 XE; X 25 XE 6 Zyl.				
Air mass meter, gasoline injection	04.93-03.97			0 280 217 503
Phase sensor				
Fg.no. →S1035178,→R9003232	04.93-03.97			0 232 103 001
Temperature sensor, coolant, injection system	04.93-03.97			0 280 130 107
Wheel speed sensor, front				
Fg.no. L1000001→M1999999	04.93-03.97			0 265 001 206
Wheel speed sensor, rear				
Fg.no. L1000001→M1999999	04.93-03.97	LAB,NAA	0 265 001 233	
Fg.no. N1000001→	04.93-03.97	AA,LAB	0 265 006 487	
		AA,RAB	0 265 006 486	
		LAB,NAA	0 265 003 094	
		NAA,RAB	0 265 003 093	
Combo				
1.2 i 1,2l 33 kW C 12 NZ; X 12 SZ; 12 NZ 4 Zyl.				
Temperature sensor, coolant, injection system				
Fg.no. W3000001→	09.94-10.01			0 280 130 093
Fg.no. →V6999999	09.94-10.01			0 280 130 107
1.3 CDTi [Tour] 1,3l 51/55 kW ... 13 DT; Z 13 DTJ 4 Zyl.				
Air mass meter, diesel	09.04→			0 281 002 549
High-pressure sensor (CR system)	09.04→			0 281 002 534
Pressure sensor, intake manifold, diesel				
Fg.no. →53999999,→54999999,→56999999	09.04→			0 281 002 510
Fg.no. 63000001→,64000001→,66000001→	09.04→			0 281 002 844



Product				
1.4 i 1,4l 44 kW C 14 NZ; X 14 SZ 4 Zyl.				
Temperature sensor, intake air, injection system				
Fg.no. W3000001→	09.94-10.01			0 280 130 093
Fg.no. →V6999999	09.94-10.01			0 280 130 107
Temperature sensor, coolant, injection system				
Fg.no. W3000001→	09.94-10.01			0 280 130 093
Fg.no. →V6999999	09.94-10.01			0 280 130 107
1.4 i 1,4l 60/66 kW C 14 SE; C 14 SEL 4 Zyl.				
Temperature sensor, coolant, injection system				
Fg.no. W3000001→	09.94-10.01			0 280 130 093
Fg.no. →V6999999	09.94-10.01			0 280 130 107
1.4 i Twinport [Tour] 1,4l 66 kW Z 14 XEP 4 Zyl.				
Throttle valve assembly	09.04→			0 280 750 133
Air mass meter, gasoline injection	09.04→			0 280 218 119
Phase sensor				
Fg.no. →44999999,→46999999	09.04→	NOC		0 232 103 021
Fg.no. 54000001→,56000001→	09.04→	NOC		0 232 103 052
Speed sensor, ignition/injection	09.04→	FKW		0 261 210 151
Knock sensor	09.04→			0 261 231 173
Temperature sensor, coolant, injection system	09.04→			0 281 002 170
1.6 CNG [Tour] 1,6l 69-71 kW Y 16 YNG 4 Zyl.				
Pressure sensor, ESP, (electronic stability program)	04.05→			0 265 005 303
1.6 i [Tour] 1,6l 69 kW Z 16 YNG 4 Zyl.				
Pressure sensor, ESP, (electronic stability program)	06.06→			0 265 005 303
1.7 CDTi [Tour] 1,7l 74 kW Z 17 DTH 4 Zyl.				
Air mass meter, diesel	09.04→			0 281 002 549
1.7 DI [Tour] 1,7l 48 kW Y 17 DTL 4 Zyl.				
Air mass meter, diesel	10.01-08.04			0 281 002 180
1.7 DTi [Tour] 1,7l 55 kW Y 17 DT 4 Zyl.				
Air mass meter, diesel	10.01-08.04			0 281 002 180
Corsa				
1.0 i [B] 1,0l 40 kW X 10 XE 3 Zyl.				
Throttle valve sensor	09.96-09.00			0 280 122 014
Air mass meter, gasoline injection	09.96-09.00			0 280 217 123
Phase sensor	09.96-09.00	NOC		0 232 103 021
Speed sensor, ignition/injection	09.96-09.00	FKW		0 261 210 151
Knock sensor	09.96-09.00			0 261 231 120
Temperature sensor, coolant, injection system	09.96-09.00	KZB		0 281 002 169
1.0 i 12V [C] 1,0l 43 kW Z 10 XE 3 Zyl.				
Air mass meter, gasoline injection	09.00-08.03			0 280 218 031
				0 986 280 230
Phase sensor	09.00-08.03	NOC		0 232 103 021
Speed sensor, ignition/injection	09.00-08.03	FKW		0 261 210 151
Knock sensor	09.00-08.03			0 261 231 120
Temperature sensor, coolant, injection system				
Mot.no. →19T75858	09.00-08.03			0 281 002 169
Mot.no. 19T75859→	09.00-08.03			0 281 002 170
1.0 Twinport [C] 1,0l 44 kW Z 10 XEP 3 Zyl.				
Throttle valve assembly	09.03-09.06			0 280 750 133
Air mass meter, gasoline injection	09.03-09.06			0 280 218 119
Phase sensor	09.03-09.06	NOC,TW		0 232 103 021
Fg.no. →54999999,→56999999	09.03-09.06	NOC		0 232 103 052
Fg.no. 64000001→,66000001→	09.03-09.06	NOC		0 232 103 067
Speed sensor, ignition/injection	09.03-09.06	FKW		0 261 210 151
Knock sensor	09.03-09.06			0 261 231 173
Temperature sensor, coolant, injection system	09.03-09.06			0 281 002 170
Yaw rate sensor, brake system	09.03-09.06			0 265 005 270
Pressure sensor, ESP, (electronic stability program)	09.03-09.06			0 265 005 303
1.0 Twinport [D] 1,0l 44 kW Z 10 XEP 3 Zyl.				
Throttle valve assembly	07.06→			0 280 750 133
Phase sensor	07.06→	NOC		0 232 103 067



Knock sensor	07.06→	0 261 231 173
Pressure sensor, intake manifold, gasoline	07.06→	0 261 230 101
Temperature sensor, coolant, injection system	07.06→	0 281 002 170
Yaw rate sensor, brake system	07.06→ MBH	0 265 005 657
	NBA	0 265 005 656
Wheel speed sensor, front	07.06→	0 265 007 671
Wheel speed sensor, rear	07.06→ STB	0 265 007 768
	4SB	0 265 007 769
1.2 i [A]	1,2l 33 kW C 12 NZ 4 Zyl.	
Temperature sensor, coolant, injection system	09.90-08.94	0 280 130 107
1.2 i [B]	1,2l 33 kW C 12 NZ; X 12 SZ; 12 NZ 4 Zyl.	
Temperature sensor, coolant, injection system		
Fg.no. W3000001→	03.93-08.00	0 280 130 093
Fg.no. →V6999999	03.93-08.00	0 280 130 107
1.2 i [B]	1,2l 48 kW X 12 XE 4 Zyl.	
Throttle valve sensor	09.97-08.00	0 280 122 014
Air mass meter, gasoline injection	09.97-08.00	0 280 217 123
Phase sensor	09.97-08.00 NOC	0 232 103 021
Speed sensor, ignition/injection	09.97-08.00 FKW	0 261 210 151
Knock sensor	09.97-08.00	0 261 231 120
Temperature sensor, coolant, injection system	09.97-08.00 KZB	0 281 002 169
1.2 i Twinport [C]	1,2l 59 kW Z 12 XEP 4 Zyl.	
Throttle valve assembly	07.04-09.06	0 280 750 133
Air mass meter, gasoline injection	07.04-09.06	0 280 218 119
Phase sensor	07.04-09.06 NOC	0 232 103 021
Fg.no. →54999999, →56999999	07.04-09.06 NOC	0 232 103 052
Fg.no. 64000001→, 66000001→	07.04-09.06 NOC	0 232 103 067
Speed sensor, ignition/injection	07.04-09.06 FKW	0 261 210 151
Knock sensor	07.04-09.06	0 261 231 173
Temperature sensor, coolant, injection system	07.04-09.06	0 281 002 170
Yaw rate sensor, brake system	07.04-09.06	0 265 005 270
Pressure sensor, ESP, (electronic stability program)	07.04-09.06	0 265 005 303
1.2 i Twinport [D]	1,2l 59 kW Z 12 XEP 4 Zyl.	
Throttle valve assembly	07.06→	0 280 750 133
Phase sensor	07.06→ NOC	0 232 103 067
Knock sensor	07.06→	0 261 231 173
Pressure sensor, intake manifold, gasoline	07.06→	0 261 230 101
Temperature sensor, coolant, injection system	07.06→	0 281 002 170
Yaw rate sensor, brake system	07.06→ MBH	0 265 005 657
	NBA	0 265 005 656
Wheel speed sensor, front	07.06→	0 265 007 671
Wheel speed sensor, rear	07.06→ STB	0 265 007 768
	4SB	0 265 007 769
1.2 i 16V [C]	1,2l 55 kW Z 12 XE 4 Zyl.	
Air mass meter, gasoline injection	09.00-06.04	0 280 218 031
		0 986 280 230
Phase sensor	09.00-06.04 NOC	0 232 103 021
Speed sensor, ignition/injection	09.00-06.04 FKW	0 261 210 151
Knock sensor	09.00-06.04	0 261 231 120
Temperature sensor, coolant, injection system		
Mot.no. →19T75858	09.00-06.04	0 281 002 169
Mot.no. 19T75859→	09.00-06.04	0 281 002 170
Yaw rate sensor, brake system	09.00-06.04	0 265 005 270
1.3 CDTi [C]	1,3l 51 kW ... 13 DT 4 Zyl.	
Air mass meter, diesel	09.03-09.06	0 281 002 549
High-pressure sensor (CR system)	09.03-09.06	0 281 002 534
Pressure sensor, intake manifold, diesel	09.03-09.06	0 281 002 510
Yaw rate sensor, brake system	09.03-09.06	0 265 005 270
Pressure sensor, ESP, (electronic stability program)	09.03-09.06	0 265 005 303
1.3 CDTi [C]	1,3l 55 kW Z 13 DTJ 4 Zyl.	
Air mass meter, diesel	09.05-09.06	0 281 002 683
High-pressure sensor (CR system)	09.05-09.06	0 281 002 706



Pressure sensor, intake manifold, diesel	09.05-09.06	0 281 002 510
Pressure sensor, ESP, (electronic stability program)	09.05-09.06	0 265 005 303
1.3 CDTi [D]	1,3l 55/66 kW A 13 DTH; A 13 DTJ; Z 13 DTJ 4 Zyl.	
High-pressure sensor (CR system)	07.06→	0 281 002 706
Pressure sensor, intake manifold, diesel	07.06→	0 281 002 844
Yaw rate sensor, brake system	07.06→ MBH	0 265 005 657
	NBA	0 265 005 656
Wheel speed sensor, front	07.06→	0 265 007 671
Wheel speed sensor, rear	07.06→ STB	0 265 007 768
	4SB	0 265 007 769
1.3 CDTi [D]	1,3l 66 kW Z 13 DTH 4 Zyl.	
High-pressure sensor (CR system)	07.06→	0 281 002 706
Boost pressure sensor, Diesel	07.06→	0 281 002 437
Pressure sensor, intake manifold, diesel	07.06→	0 281 002 844
Yaw rate sensor, brake system	07.06→ MBH	0 265 005 657
	NBA	0 265 005 656
Wheel speed sensor, front	07.06→	0 265 007 671
Wheel speed sensor, rear	07.06→ STB	0 265 007 768
	4SB	0 265 007 769
1.4 i [A]	1,4l 40-44/60 kW C 14 NZ; C 14 SE 4 Zyl.	
Temperature sensor, coolant, injection system	01.90-08.94	0 280 130 107
1.4 i [B]	1,4l 44 kW C 14 NZ; X 14 SZ 4 Zyl.	
Temperature sensor, intake air, injection system		
Fg.no. W3000001→	03.93-09.00	0 280 130 093
Fg.no. →V6999999	03.93-09.00	0 280 130 107
Temperature sensor, coolant, injection system		
Fg.no. W3000001→	03.93-09.00	0 280 130 093
Fg.no. →V6999999	03.93-09.00	0 280 130 107
1.4 i [B]	1,4l 60/63/66 kW C 14 SE; C 14 SEL; X 14 XE 4 Zyl.	
Temperature sensor, coolant, injection system		
Fg.no. W3000001→	03.93-08.00	0 280 130 093
Fg.no. →V6999999	03.93-08.00	0 280 130 107
1.4 Twinport [C]	1,4l 66 kW Z 14 XEP 4 Zyl.	
Throttle valve assembly	09.03-09.06	0 280 750 133
Air mass meter, gasoline injection	09.03-09.06	0 280 218 119
Phase sensor	09.03-09.06 NOC	0 232 103 021
	NOC, RAB	0 232 103 052
Speed sensor, ignition/injection	09.03-09.06 FKW	0 261 210 151
Knock sensor	09.03-09.06	0 261 231 173
Temperature sensor, coolant, injection system	09.03-09.06	0 281 002 170
Yaw rate sensor, brake system	09.03-09.06	0 265 005 270
Pressure sensor, ESP, (electronic stability program)	09.03-09.06	0 265 005 303
1.4 Twinport [D]	1,4l 66 kW Z 14 XEP 4 Zyl.	
Throttle valve assembly	07.06→	0 280 750 133
Phase sensor	07.06→ NOC	0 232 103 067
Knock sensor	07.06→	0 261 231 173
Pressure sensor, intake manifold, gasoline	07.06→	0 261 230 101
Temperature sensor, coolant, injection system	07.06→	0 281 002 170
Yaw rate sensor, brake system	07.06→ MBH	0 265 005 657
	NBA	0 265 005 656
Wheel speed sensor, front	07.06→	0 265 007 671
Wheel speed sensor, rear	07.06→ STB	0 265 007 768
	4SB	0 265 007 769
1.6 CNG [C]	1,6l 71 kW Y 16 YNG; Z 16 YNG 4 Zyl.	
Yaw rate sensor, brake system	03.06-09.06	0 265 005 270
Pressure sensor, ESP, (electronic stability program)	03.06-09.06	0 265 005 303
1.6 GSi [B]	1,6l 80 kW C 16 XE 4 Zyl.	
Temperature sensor, coolant, injection system		
Fg.no. →V6999999	03.93-08.00	0 280 130 107
1.6 i [A]	1,6l 55 kW C 16 NZ 4 Zyl.	
Temperature sensor, coolant, injection system	04.89-08.94	0 280 130 107



Product				

◀ Corsa

1.6 i [A]	1,6 l 72 kW C16 SEI 4 Zyl.
Throttle valve sensor	09.89-03.93 0 280 122 001
Air flow sensor, gasoline injection	09.89-03.93 0 280 200 202 0 986 280 052
1.6 i [A]	1,6 l 74 kW C 16 SE 4 Zyl.
Air flow sensor, gasoline injection	05.88-03.93 0 280 200 603
1.6 i [A]	1,6 l 74 kW E 16 SE 4 Zyl.
Throttle valve sensor	05.88-03.93 0 280 120 316
Temperature sensor, coolant, injection system	05.88-08.94 0 280 130 107
1.6 i [B]	1,6 l 74 kW C 16 SEL 4 Zyl.
Temperature sensor, coolant, injection system	
Fg.no. W3000001→,W4000001→, W6000001→	06.98-08.00 0 280 130 093
1.6 i [C]	1,6 l 62 kW Z 16 SE 4 Zyl.
Yaw rate sensor, brake system	09.01-08.05 0 265 005 270
Pressure sensor, ESP, (electronic stability program)	09.01-08.05 0 265 005 303
1.6 i GSi [B]	1,6 l 78 kW X 16 XE 4 Zyl.
Temperature sensor, coolant, injection system	
Fg.no. W3000001→,W4000001→, W6000001→	03.93-08.99 0 280 130 093
Fg.no. →V6999999	03.93-08.99 0 280 130 107
1.6 i OPC Turbo [D]	1,6 l 141 kW Z 16 LER 4 Zyl.
Air mass meter, gasoline injection	02.07→ 0 280 218 142
Phase sensor	02.07→ NOC 0 232 103 052
Knock sensor	02.07→ 0 261 231 173
Yaw rate sensor, brake system	02.07→ MBH 0 265 005 657 NBA 0 265 005 656
Wheel speed sensor, front	02.07→ 0 265 007 671
Wheel speed sensor, rear	02.07→ STB 0 265 007 768 4SB 0 265 007 769
1.7 CDTi [C]	1,7 l 74 kW Z 17 DTH 4 Zyl.
Air mass meter, diesel	09.03-09.06 0 281 002 549
Yaw rate sensor, brake system	09.03-09.06 0 265 005 270
Pressure sensor, ESP, (electronic stability program)	09.03-09.06 0 265 005 303
1.7 CDTi [D]	1,7 l 92 kW A 17 DTR; Z 17 DTR 4 Zyl.
Yaw rate sensor, brake system	07.06→ MBH 0 265 005 657 NBA 0 265 005 656
Wheel speed sensor, front	07.06→ 0 265 007 671
Wheel speed sensor, rear	07.06→ STB 0 265 007 768 4SB 0 265 007 769
1.7 DI [C]	1,7 l 48 kW Y 17 DTL 4 Zyl.
Air mass meter, diesel	09.00-08.03 0 281 002 180
Pressure sensor, ESP, (electronic stability program)	09.00-08.03 0 265 005 303
1.7 DTi	1,7 l 55 kW Y 17 DTL 4 Zyl.
Air mass meter, gasoline injection	10.02-12.05 0 281 002 184
Air mass meter, diesel	10.02-12.05 0 281 002 180
1.7 DTi [C]	1,7 l 55 kW Y 17 DT 4 Zyl.
Air mass meter, diesel	09.00-08.03 0 281 002 180
Pressure sensor, ESP, (electronic stability program)	09.00-08.03 0 265 005 303
1.8 i 16V [C]	1,8 l 92 kW Z 18 XE 4 Zyl.
Yaw rate sensor, brake system	09.01-08.05 0 265 005 270
Pressure sensor, ESP, (electronic stability program)	09.01-08.05 0 265 005 303

Frontera



2.0 i [A]	2,0 l 85 kW C 20 NE 4 Zyl.
Throttle valve sensor	09.91-08.95 0 280 122 001
Air flow sensor, gasoline injection	
Fg.no. →NV522066	09.91-08.95 0 280 202 210 0 986 280 063
Speed sensor, ignition/injection	09.91-08.95 0 261 210 030
Temperature sensor, coolant, injection system	09.91-08.95 0 280 130 107

Product				


2.0 i [A]	2,0 l 85 kW X 20 SE 4 Zyl.
Throttle valve sensor	02.95-08.98 0 280 122 001
Air mass meter, gasoline injection	02.95-08.98 0 280 217 003
Speed sensor, ignition/injection	02.95-08.98 0 261 210 030
Knock sensor	02.95-08.98 0 261 231 007
2.2 DTi [B]	2,2 l 85/88 kW X 22 DTH; Y 22 DTH 4 Zyl.
Air mass meter, diesel	09.98-09.04 0 281 002 184
Speed sensor, diesel	09.98-09.04 0 281 002 138
Temperature sensor, coolant, diesel	09.98-09.04 0 281 002 169
Temperature sensor, intake air, diesel	09.98-09.04 0 261 230 009
2.2 i [A]	2,2 l 100 kW X 22 XE 4 Zyl.
Throttle valve sensor	02.95-08.98 0 280 122 001
Air mass meter, gasoline injection	02.95-08.98 0 280 217 003
Speed sensor, ignition/injection	
Fg.no. →TV899999	02.95-08.98 0 261 210 030
Knock sensor	02.95-08.98 0 261 231 007
Temperature sensor, coolant, injection system	02.95-08.98 0 280 130 107
2.3 TD [A]	2,3 l 74 kW 23 DT 4 Zyl.
Air mass meter, diesel	09.91-08.95 0 281 002 144
2.4 i [A]	2,4 l 92 kW C 24 NE CIH 4 Zyl.
Throttle valve sensor	09.91-08.95 0 280 122 001
Air flow sensor, gasoline injection	09.91-08.95 0 280 202 211 0 986 280 091
Speed sensor, ignition/injection	09.91-08.95 0 261 210 031
Temperature sensor, coolant, injection system	09.91-08.95 0 280 130 107
2.5 TDS Turbo [A]	2,5 l 85 kW Venturi-25TD VM41B 0 Zyl.
Air mass meter, diesel	06.96-08.98 0 281 002 144
Speed sensor, diesel	06.96-08.98 0 281 002 096
Pedal position sensor, diesel	06.96-08.98 LLE 0 205 001 055 RLE 0 205 001 054

Kadett

1.3 [E]	1,3 l 44 kW 13 N, NB 4 Zyl.
Wheel speed sensor, front	03.89-08.91 0 265 006 488
Wheel speed sensor, rear	03.89-08.91 LAB,LIM 0 265 001 236 LIM,RAB 0 265 001 235
1.3 i [E]	1,3 l 44 kW C 13 N 4 Zyl.
Wheel speed sensor, front	03.89-08.91 0 265 006 488
Wheel speed sensor, rear	03.89-08.91 LAB,LIM 0 265 001 236 LIM,RAB 0 265 001 235
1.4 [E]	1,4 l 44/55 kW E 14 LV; 14 NV 4 Zyl.
Wheel speed sensor, front	01.90-08.91 0 265 006 488
Wheel speed sensor, rear	01.90-08.91 LAB,LIM 0 265 001 236 LIM,RAB 0 265 001 235
1.4 i [E]	1,4 l 44 kW C 14 NZ 4 Zyl.
Temperature sensor, coolant, injection system	01.90-08.91 0 280 130 107
Wheel speed sensor, front	01.90-08.91 0 265 006 488
Wheel speed sensor, rear	01.90-08.91 LAB,LIM 0 265 001 236 LIM,RAB 0 265 001 235
1.5 TD [E]	1,5 l 53 kW 15 DT 4 Zyl.
Wheel speed sensor, front	03.89-08.91 0 265 006 488
Wheel speed sensor, rear	03.89-08.91 LAB,LIM 0 265 001 236 LIM,RAB 0 265 001 235
1.6 [E]	1,6 l 60 kW 16 SV 4 Zyl.
Wheel speed sensor, front	03.89-08.91 0 265 006 488
Wheel speed sensor, rear	03.89-08.91 LAB,LIM 0 265 001 236 LIM,RAB 0 265 001 235
1.6 i [E]	1,6 l 55 kW C 16 LZ; C 16 NZ; E 16 NZ 4 Zyl.
Temperature sensor, coolant, injection system	
Fg.no. J2791968→,J5273428→	09.86-08.93 0 280 130 107
Wheel speed sensor, front	03.89-08.93 0 265 006 488



Wheel speed sensor, rear	03.89-08.93	LAB, LIM	0 265 001 236
		LIM, RAB	0 265 001 235
1.6 i [E]	1,6 l 74 kW E 16 SE 4 Zyl.		
Throttle valve sensor	04.89-08.91		0 280 120 316
Air flow sensor, gasoline injection	04.89-08.91		0 280 202 602
			0 986 280 019
Temperature sensor, coolant, injection system	04.89-08.91		0 280 130 026
Wheel speed sensor, front	04.89-08.91		0 265 006 488
Wheel speed sensor, rear	04.89-08.91	LAB, LIM	0 265 001 236
		LIM, RAB	0 265 001 235
1.7 D/DR [E]	1,7 l 42 kW 17 D/DR 4 Zyl.		
Wheel speed sensor, front	03.89-08.91		0 265 006 488
Wheel speed sensor, rear	03.89-08.91	LAB, LIM	0 265 001 236
		LIM, RAB	0 265 001 235
1.7 TD [E]	1,7 l 60 kW 17 DT/TC4EE1 4 Zyl.		
Wheel speed sensor, front	02.90-08.91		0 265 006 488
Wheel speed sensor, rear	02.90-08.91	LAB, LIM	0 265 001 236
		LIM, RAB	0 265 001 235
1.8 [E]	1,8 l 62 kW S 18 NV 4 Zyl.		
Temperature sensor, coolant, injection system	09.86-08.91		0 280 130 107
Wheel speed sensor, front	03.89-08.91		0 265 006 488
Wheel speed sensor, rear	03.89-08.91	LAB, LIM	0 265 001 236
		LIM, RAB	0 265 001 235
1.8 i [E]	1,8 l 66 kW C 18 NZ 4 Zyl.		
Temperature sensor, coolant, injection system	09.90-08.91		0 280 130 107
Wheel speed sensor, front	09.90-08.91		0 265 006 488
Wheel speed sensor, rear	09.90-08.91	LAB, LIM	0 265 001 236
		LIM, RAB	0 265 001 235
1.8 i [E]	1,8 l 74 kW C 18 NE 4 Zyl.		
Throttle valve sensor	10.85-08.86		0 280 120 301
Air flow sensor, gasoline injection	10.85-08.86		0 280 202 076
Temperature sensor, coolant, injection system	10.85-08.86		0 280 130 107
1.8 i [E]	1,8 l 82-85 kW 18 E 4 Zyl.		
Throttle valve sensor	09.86-08.91		0 280 120 316
Air flow sensor, gasoline injection	09.86-08.91		0 280 202 602
			0 986 280 019
Speed sensor, ignition/injection	09.86-08.91		0 261 210 030
Temperature sensor, coolant, injection system	09.86-08.91		0 280 130 107
Wheel speed sensor, front	03.89-08.91		0 265 006 488
Wheel speed sensor, rear	03.89-08.91	LAB, LIM	0 265 001 236
		LIM, RAB	0 265 001 235
1.8 i [E]	1,8 l 85 kW 18 E 4 Zyl.		
Throttle valve sensor	09.84-08.86		0 280 120 301
Air flow sensor, gasoline injection	CH, S 09.84-08.86		0 280 202 054
	CH, S 09.84-08.86		0 280 202 033
Temperature sensor, coolant, injection system	09.84-08.86		0 280 130 107
1.8 S [E]	1,8 l 62 kW E 18 NV 4 Zyl.		
Temperature sensor, coolant, injection system	09.87-08.91		0 280 130 107
Wheel speed sensor, front	03.89-08.91		0 265 006 488
Wheel speed sensor, rear	03.89-08.91	LAB, LIM	0 265 001 236
		LIM, RAB	0 265 001 235
2.0 i [E]	2,0 l 85 kW C 20 NE; 20 NE 4 Zyl.		
Throttle valve sensor	09.86-08.88		0 280 120 316
	09.88-08.91		0 280 122 001
Speed sensor, ignition/injection	09.86-08.91		0 261 210 030
Pressure sensor, intake manifold, gasoline	09.86-08.91		0 280 101 007
Temperature sensor, coolant, injection system	09.86-08.91		0 280 130 107
Wheel speed sensor, front	03.89-08.91		0 265 006 488
Wheel speed sensor, rear	03.89-08.91	LAB, LIM	0 265 001 236
		LIM, RAB	0 265 001 235
2.0 i [E]	2,0 l 91 kW 20 SER 4 Zyl.		
Throttle valve sensor	09.87-08.88		0 280 120 316
	09.88-08.91		0 280 122 001



Pressure sensor, intake manifold, gasoline	09.87-08.91		0 280 101 007
Temperature sensor, coolant, injection system	09.87-08.91		0 280 130 107
Wheel speed sensor, front	03.89-08.91		0 265 006 488
Wheel speed sensor, rear	03.89-08.91	LAB, LIM	0 265 001 236
		LIM, RAB	0 265 001 235
2.0 i [E]	2,0 l 95 kW 20 SEH 4 Zyl.		
Throttle valve sensor	09.86-08.88		0 280 120 316
	09.88-08.91		0 280 122 001
Speed sensor, ignition/injection	09.86-08.91		0 261 210 030
Pressure sensor, intake manifold, gasoline	09.86-08.91		0 280 101 007
Temperature sensor, coolant, injection system	09.86-08.91		0 280 130 107
Wheel speed sensor, front	03.89-08.91		0 265 006 488
Wheel speed sensor, rear	03.89-08.91	LAB, LIM	0 265 001 236
		LIM, RAB	0 265 001 235
2.0 i [E]	2,0 l 110-115 kW C 20 XE / XEJ; 20 XE 4 Zyl.		
Throttle valve sensor	03.88-08.91		0 280 120 326
Air mass meter, gasoline injection	03.88-08.91		0 280 212 015
			0 986 280 113
Speed sensor, ignition/injection	03.88-08.91		0 261 210 030
Knock sensor	03.88-08.91		0 261 231 006
Temperature sensor, coolant, injection system	03.88-08.91		0 280 130 107
Wheel speed sensor, front	03.89-08.91		0 265 006 488
Wheel speed sensor, rear	03.89-08.91	LAB, LIM	0 265 001 236
		LIM, RAB	0 265 001 235

Manta

2.0 i [B]	2,0 l 77-81 kW 20 E CIH; 20 E CIH Kat. 4 Zyl.		
Throttle valve sensor	09.81-08.88		0 280 120 301
Air flow sensor, gasoline injection	09.81-08.88		0 280 202 030
Temperature sensor, coolant, injection system	09.81-08.88		0 280 130 026

Meriva

1.3 CDTI	1,3 l 55 kW ... 13 DT 4 Zyl.		
Air mass meter, diesel	04.05→		0 281 002 620
High-pressure sensor (CR system)	04.05→		0 281 002 706
Yaw rate sensor, brake system			
Fg.no. →44999999	04.05→		0 265 005 262
Fg.no. 54000001→54999999	04.05→		0 265 005 270
Fg.no. 64000001→	04.05→	MBH	0 265 005 657
		NBA	0 265 005 656
Pressure sensor, ESP, (electronic stability program)	04.05→		0 265 005 303
1.3 CDTI	1,3 l 55 kW Z 13 DTJ 4 Zyl.		
High-pressure sensor (CR system)	09.03→		0 281 002 706
Yaw rate sensor, brake system			
Fg.no. →44999999	09.03→		0 265 005 262
Fg.no. 54000001→54999999	09.03→		0 265 005 270
Fg.no. 64000001→	09.03→	MBH	0 265 005 657
		NBA	0 265 005 656
Pressure sensor, ESP, (electronic stability program)	09.03→		0 265 005 303
1.4 i Twinport	1,4 l 66 kW Z 14 XEP 4 Zyl.		
Throttle valve assembly	07.04→		0 280 750 133
Air mass meter, gasoline injection	07.04→		0 280 218 119
Phase sensor			
Fg.no. →44999999	07.04→	NOC	0 232 103 021
Fg.no. 54000001→54999999	07.04→	NOC	0 232 103 052
Fg.no. 64000001→	07.04→	NOC	0 232 103 067
Speed sensor, ignition/injection	07.04→	FKW	0 261 210 151
Knock sensor	07.04→		0 261 231 173
Temperature sensor, coolant, injection system	07.04→		0 281 002 170

Product				
◀ Meriva				
Yaw rate sensor, brake system				
Fg.no. →44999999	07.04→			0 265 005 262
Fg.no. 54000001→54999999	07.04→			0 265 005 270
Fg.no. 64000001→	07.04→	MBH		0 265 005 657
		NBA		0 265 005 656
Pressure sensor, ESP, (electronic stability program)	07.04→			0 265 005 303
1.6 i	1,6 l	64 kW	Z 16 SE	4 Zyl.
Yaw rate sensor, brake system				
Fg.no. →44999999	03.03-09.05			0 265 005 262
Fg.no. 54000001→54999999	03.03-09.05			0 265 005 270
Fg.no. 64000001→	03.03-09.05	MBH		0 265 005 657
		NBA		0 265 005 656
Pressure sensor, ESP, (electronic stability program)	03.03-09.05			0 265 005 303
1.6 i OPC Turbo	1,6 l	132 kW	Z 16 LET	4 Zyl.
Air mass meter, gasoline injection	09.05→			0 280 218 142
Phase sensor	09.05→	NOC		0 232 103 052
Knock sensor	09.05→			0 261 231 173
Pressure sensor, intake manifold, gasoline	09.05→			0 281 002 137
Yaw rate sensor, brake system				
Fg.no. →44999999	09.05→			0 265 005 262
Fg.no. 54000001→54999999	09.05→			0 265 005 270
Fg.no. 64000001→	09.05→	MBH		0 265 005 657
		NBA		0 265 005 656
Pressure sensor, ESP, (electronic stability program)	09.05→			0 265 005 303
1.6 i 16V Twinport	1,6 l	74/77 kW	Z 16 XE; Z 16 XEP	4 Zyl.
Yaw rate sensor, brake system				
Fg.no. →44999999	03.03→			0 265 005 262
Fg.no. 54000001→54999999	03.03→			0 265 005 270
Fg.no. 64000001→	03.03→	MBH		0 265 005 657
		NBA		0 265 005 656
Pressure sensor, ESP, (electronic stability program)	03.03→			0 265 005 303
1.7 CDTi	1,7 l	74 kW	Z 17 DTH	4 Zyl.
Air mass meter, diesel	09.03-09.05			0 281 002 620
Yaw rate sensor, brake system				
Fg.no. →44999999	09.03-09.05			0 265 005 262
Fg.no. 54000001→54999999	09.03-09.05			0 265 005 270
Fg.no. 64000001→	09.03-09.05	MBH		0 265 005 657
		NBA		0 265 005 656
Pressure sensor, ESP, (electronic stability program)	09.03-09.05			0 265 005 303
1.7 CDTi	1,7 l	92 kW	A 17 ...; Z 17 DT...	4 Zyl.
Yaw rate sensor, brake system				
Fg.no. →44999999	09.06→			0 265 005 262
Fg.no. 54000001→54999999	09.06→			0 265 005 270
Fg.no. 64000001→	09.06→	MBH		0 265 005 657
		NBA		0 265 005 656
Pressure sensor, ESP, (electronic stability program)	09.06→			0 265 005 303
1.7 DTi	1,7 l	55 kW	Y 17 DT	4 Zyl.
Yaw rate sensor, brake system				
Fg.no. →44999999	03.03-09.05			0 265 005 262
Fg.no. 54000001→54999999	03.03-09.05			0 265 005 270
Fg.no. 64000001→	03.03-09.05	MBH		0 265 005 657
		NBA		0 265 005 656
Pressure sensor, ESP, (electronic stability program)	03.03-09.05			0 265 005 303
1.8 i 16V	1,8 l	92 kW	Z 18 XE	4 Zyl.
Yaw rate sensor, brake system				
Fg.no. →44999999	03.03→			0 265 005 262
Fg.no. 54000001→54999999	03.03→			0 265 005 270
Fg.no. 64000001→	03.03→	MBH		0 265 005 657
		NBA		0 265 005 656
Pressure sensor, ESP, (electronic stability program)	03.03→			0 265 005 303



Product				
Monza				
2.2 i [A]	2,2 l	85 kW	22 E CIH	4 Zyl.
Throttle valve sensor	11.84-08.86			0 280 120 301
Air flow sensor, gasoline injection	11.84-08.86			0 280 202 068
Temperature sensor, coolant, injection system	11.84-08.86			0 280 130 032
Wheel speed sensor	11.84-08.86	HI		0 265 001 056
		VO		0 265 001 055
2.5 i [A]	2,5 l	100 kW	S 25 E CIH	6 Zyl.
Throttle valve sensor	09.84-08.86			0 280 120 200
Air flow sensor, gasoline injection	09.84-08.86			0 280 202 024
Temperature sensor, coolant, injection system	09.84-08.86			0 280 130 026
Relay, Jetronic	09.84-08.86			0 332 514 124
Wheel speed sensor	09.84-08.86	HI		0 265 001 056
		VO		0 265 001 055
2.5 i [A]	2,5 l	100 kW	25 E CIH	6 Zyl.
Throttle valve sensor	05.81-08.86			0 280 120 200
Air flow sensor, gasoline injection	05.81-08.86			0 280 202 024
Temperature sensor, coolant, injection system	05.81-08.86			0 280 130 026
Relay, Jetronic	05.81-08.86			0 332 514 124
2.5 i [A]	2,5 l	100-103 kW	25 E/H CIH	6 Zyl.
Throttle valve sensor	09.84-08.86			0 280 120 301
Air flow sensor, gasoline injection	09.84-08.86			0 280 202 053
Temperature sensor, coolant, injection system	09.84-08.86			0 280 130 032
Wheel speed sensor	09.84-08.86	HI		0 265 001 056
		VO		0 265 001 055
3.0 i [A]	3,0 l	115 kW	C 30 NE/LE	6 Zyl.
Throttle valve sensor	09.85-08.86			0 280 120 301
Air flow sensor, gasoline injection	09.85-08.86			0 280 202 084
Temperature sensor, coolant, injection system	09.85-08.86			0 280 130 032
Wheel speed sensor	09.85-08.86	HI		0 265 001 056
		VO		0 265 001 055
3.0 i [A]	3,0 l	132 kW	30 E/S 30 E CIH	6 Zyl.
Throttle valve sensor	01.83-08.86			0 280 120 200
Air flow sensor, gasoline injection	01.83-08.86			0 280 202 007
Temperature sensor, coolant, injection system	01.83-08.86			0 280 130 026
Relay, Jetronic	01.83-08.86			0 332 514 124
Wheel speed sensor	09.83-08.86	HI		0 265 001 056
		VO		0 265 001 055
3.0 i [A]	3,0 l	132 kW	30 E CIH	6 Zyl.
Throttle valve sensor	01.83-08.86			0 280 120 301
Air flow sensor, gasoline injection	01.83-08.86			0 280 202 037
Temperature sensor, coolant, injection system	01.83-08.86			0 280 130 032
Wheel speed sensor	09.83-08.86	HI		0 265 001 056
		VO		0 265 001 055
Omega				
1.8 [A]	1,8 l	60/65 kW	E 18 NVR; S 18 NV; 18 NV	4 Zyl.
Speed sensor, ignition/injection	09.86-03.94			0 261 210 030
Temperature sensor, coolant, injection system	09.86-03.94			0 280 130 107
Wheel speed sensor	09.86-03.94	HI		0 265 001 134
Fg.no. J1185910→	09.86-03.94	VO		0 265 001 220
Fg.no. →J1185909	09.86-03.94	VO		0 265 001 143
1.8 i [A]	1,8 l	85 kW	18 SEH	4 Zyl.
Throttle valve sensor	09.86-03.94			0 280 120 316
Air flow sensor, gasoline injection	09.86-03.94			0 280 202 602
				0 986 280 019
Speed sensor, ignition/injection	09.86-03.94			0 261 210 030
Temperature sensor, coolant, injection system	09.86-03.94			0 280 130 107
Wheel speed sensor	09.86-03.94	HI		0 265 001 134
Fg.no. J1185910→	09.86-03.94	VO		0 265 001 220
Fg.no. →J1185909	09.86-03.94	VO		0 265 001 143

Product



1.8 S [A]	1,8l 66 kW 18 SV 4 Zyl.
Speed sensor, ignition/injection	09.86-03.94 0 261 210 030
Temperature sensor, coolant, injection system	09.86-03.94 0 280 130 107
Wheel speed sensor	09.86-03.94 HI 0 265 001 134
Fg.no. J1185910→	09.86-03.94 VO 0 265 001 220
Fg.no. →J1185909	09.86-03.94 VO 0 265 001 143
2.0 DTI Turbo [B]	2,0l 74 kW X 20 DTH 4 Zyl.
Air mass meter, diesel	09.97-08.00 0 281 002 180
Speed sensor, diesel	09.97-08.00 0 281 002 138
Temperature sensor, coolant, injection system	09.97-08.00 0 281 002 169
Pedal position sensor, diesel	
Fg.no. →V1999999	09.97-08.00 0 205 001 039
2.0 i [A]	2,0l 74 kW C 20 NEJ/NEF 4 Zyl.
Throttle valve sensor	
Fg.no. L1019855→	06.89-02.92 0 280 122 001
Air flow sensor, gasoline injection	
Fg.no. →L1019854	06.89-02.92 0 280 202 210
	0 986 280 063
Speed sensor, ignition/injection	06.89-02.92 0 261 210 030
Temperature sensor, coolant, injection system	06.89-02.92 0 280 130 107
Wheel speed sensor	06.89-02.92 HI 0 265 001 134
Fg.no. J1185910→	06.89-02.92 VO 0 265 001 220
Fg.no. →J1185909	06.89-02.92 VO 0 265 001 143
2.0 i [A]	2,0l 85 kW C 20 NE 4 Zyl.
Throttle valve sensor	
Fg.no. L1019855→	09.86-03.94 0 280 122 001
Fg.no. →L1019854	09.86-03.94 0 280 120 316
Air flow sensor, gasoline injection	
Fg.no. →L1019854	09.86-03.94 0 280 202 210
	0 986 280 063
Speed sensor, ignition/injection	09.86-03.94 0 261 210 030
Pressure sensor, intake manifold, gasoline	09.86-08.89 0 280 101 007
Temperature sensor, coolant, injection system	09.86-03.94 0 280 130 107
Wheel speed sensor	09.86-03.94 HI 0 265 001 134
Fg.no. J1185910→	09.86-03.94 VO 0 265 001 220
Fg.no. →J1185909	09.86-03.94 VO 0 265 001 143
2.0 i [A]	2,0l 90 kW 20 SE 4 Zyl.
Throttle valve sensor	
Fg.no. L1019855→	09.86-03.94 0 280 122 001
Fg.no. →L1019854	09.86-03.94 0 280 120 316
Air flow sensor, gasoline injection	09.86-03.94 0 280 202 210
	0 986 280 063
Speed sensor, ignition/injection	09.86-03.94 0 261 210 030
Pressure sensor, intake manifold, gasoline	09.86-08.89 0 280 101 007
Temperature sensor, coolant, injection system	09.86-03.94 0 280 130 107
Wheel speed sensor	09.86-03.94 HI 0 265 001 134
Fg.no. J1185910→	09.86-03.94 VO 0 265 001 220
Fg.no. →J1185909	09.86-03.94 VO 0 265 001 143
2.0 i [B]	2,0l 85 kW X 20 SE; 20 SE 4 Zyl.
Throttle valve sensor	04.94-08.98 0 280 122 001
Air mass meter, gasoline injection	04.94-08.98 0 280 217 106
Knock sensor	04.94-08.98 0 261 231 006
Temperature sensor, intake air, injection system	04.94-08.98 0 280 130 073
Temperature sensor, coolant, injection system	04.94-08.98 0 280 130 107
2.0 i [B]	2,0l 100 kW X 20 XEV 4 Zyl.
Throttle valve sensor	09.93-08.99 0 280 122 001
2.2 DTI [B]	2,2l 88 kW Y 22 DTH Turbo 4 Zyl.
Air mass meter, diesel	06.00-07.03 0 281 002 428
Speed sensor, diesel	06.00-07.03 0 281 002 138
Pedal position sensor, diesel	06.00-07.03 0 280 752 027


Product



2.3 D [A]	2,3l 54 kW 23 YD 4 Zyl.
Temperature sensor, coolant, diesel	09.86-03.94 2PO 0 280 130 107
Wheel speed sensor	09.86-03.94 HI 0 265 001 134
Fg.no. J1185910→	09.86-03.94 VO 0 265 001 220
Fg.no. →J1185909	09.86-03.94 VO 0 265 001 143
2.3 TD [A]	2,3l 66/74 kW 23 DTR; 23 YDT 4 Zyl.
Temperature sensor, coolant, diesel	09.86-03.94 2PO 0 280 130 107
Wheel speed sensor	09.86-03.94 HI 0 265 001 134
Fg.no. J1185910→	09.86-03.94 VO 0 265 001 220
Fg.no. →J1185909	09.86-03.94 VO 0 265 001 143
2.4 i [A]	2,4l 92 kW C 24 NE CIH 4 Zyl.
Throttle valve sensor	09.88-03.94 0 280 122 001
Air flow sensor, gasoline injection	09.88-03.94 0 280 202 211
	0 986 280 091
Speed sensor, ignition/injection	09.88-03.94 0 261 210 031
Temperature sensor, coolant, injection system	09.88-03.94 0 280 130 107
Wheel speed sensor	09.88-03.94 HI 0 265 001 134
Fg.no. J1185910→	09.88-03.94 VO 0 265 001 220
Fg.no. →J1185909	09.88-03.94 VO 0 265 001 143
2.5 DTI Turbo [B]	2,5l 110 kW Y 25 TD 6 Zyl.
Air mass meter, diesel	06.01-09.03 0 281 002 564
2.5 i [B]	2,5l 125 kW X 25 XE 6 Zyl.
Throttle valve sensor	
Fg.no. V1000001→	04.94-11.00 0 280 122 014
Fg.no. →T1999999	04.94-11.00 0 280 122 001
Air mass meter, gasoline injection	
Mot.no. →08137540	04.94-11.00 0 280 217 503
Mot.no. 08137541→	04.94-11.00 0 280 217 519
Phase sensor	04.94-11.00 MTS 0 232 103 008
	OTS 0 232 103 001
Mot.no. →08149313	04.94-11.00 0 232 103 008
Mot.no. 08149314→	04.94-11.00 0 232 103 017
Knock sensor	
Mot.no. →08137540	04.94-11.00 0 261 231 079
Mot.no. 08137541→	04.94-11.00 0 261 231 116
Temperature sensor, intake air, injection system	
Mot.no. →01837540	04.94-11.00 0 280 130 073
Mot.no. 08137541→	04.94-11.00 0 280 130 092
Temperature sensor, coolant, injection system	
Mot.no. →08137540	04.94-11.00 0 280 130 107
Mot.no. 08137541→	04.94-11.00 0 280 130 093
2.5 TD [B]	2,5l 96 kW U 25 TD -R6 Turbo; X 25 TD Turbo 6 Zyl.
Pedal position sensor, diesel	
Fg.no. S1155598→	04.94-02.01 LLE 0 205 001 039
Fg.no. S1156241→	04.94-02.01 RLE 0 205 001 039
Fg.no. →S1155597	04.94-02.01 LLE 0 205 001 019
Fg.no. →S1156240	04.94-02.01 RLE 0 205 001 019
2.6 i [A]	2,6l 110 kW C 26 NE CIH 6 Zyl.
Throttle valve sensor	09.90-03.94 0 280 122 001
Speed sensor, ignition/injection	09.90-03.94 0 261 210 031
Temperature sensor, coolant, injection system	09.90-03.94 0 280 130 107
Wheel speed sensor	09.90-03.94 HI 0 265 001 134
Fg.no. J1185910→	09.90-03.94 VO 0 265 001 220
Fg.no. →J1185909	09.90-03.94 VO 0 265 001 143
2.6 i [B]	2,6l 132 kW Y 26 SE 6 Zyl.
Air mass meter, gasoline injection	09.00-09.03 0 281 002 184
Phase sensor	09.00-09.03 0 232 103 025
Speed sensor, ignition/injection	
Mot.no. 08149314→	09.00-09.03 0 261 210 131
Knock sensor	
Mot.no. 08137541→	09.00-09.03 0 261 231 116



O



Product				

◀ Omega

3.0i [A]			3,0l 115 kW C 30 LE CIH 6 Zyl.		
Throttle valve sensor	03.87-12.87			0 280 120 301	
		AG		0 280 120 412	
Air flow sensor, gasoline injection	03.87-12.87			0 280 202 201	
Speed sensor, ignition/injection	03.87-12.87			0 261 210 031	
Temperature sensor, coolant, injection system	03.87-12.87			0 280 130 107	
3.0i [A]			3,0l 130 kW C 30 NE CIH 6 Zyl.		
Throttle valve sensor					
Fg.no. L1019855→	01.88-03.94			0 280 122 001	
Fg.no. →L1019854	01.88-03.94			0 280 120 316	
Air flow sensor, gasoline injection	01.88-03.94			0 280 203 032	
				0 986 280 074	
Speed sensor, ignition/injection	01.88-03.94			0 261 210 031	
Temperature sensor, coolant, injection system	01.88-03.94			0 280 130 069	
Wheel speed sensor	01.88-03.94	HI		0 265 001 134	
Fg.no. J1185910→	01.88-03.94	VO		0 265 001 220	
Fg.no. →J1185909	01.88-03.94	VO		0 265 001 143	
3.0i [A]			3,0l 130 kW 30 NE CIH 6 Zyl.		
Throttle valve sensor	03.87-12.89			0 280 120 301	
		AG		0 280 120 405	
Temperature sensor, coolant, injection system	03.87-12.89			0 280 130 069	
Wheel speed sensor	03.87-12.89	HI		0 265 001 134	
Fg.no. J1185910→	03.87-12.89	VO		0 265 001 220	
Fg.no. →J1185909	03.87-12.89	VO		0 265 001 143	
3.0i [A]			3,0l 147-150 kW C 30 SE, SEJ 6 Zyl.		
Throttle valve sensor	09.89-03.94			0 280 122 001	
Air flow sensor, gasoline injection	09.89-03.94			0 280 203 032	
				0 986 280 074	
Knock sensor	09.89-03.94			0 261 231 006	
Temperature sensor, coolant, injection system	09.89-03.94			0 280 130 107	
Wheel speed sensor	09.89-03.94	HI		0 265 001 134	
Fg.no. J1185910→	09.89-03.94	VO		0 265 001 220	
Fg.no. →J1185909	09.89-03.94	VO		0 265 001 143	
3.0i [B]			3,0l 155 kW X 30 XE 6 Zyl.		
Throttle valve sensor	04.94-02.01			0 280 122 001	
Fg.no. V1000001→	04.94-02.01			0 280 122 014	
Air mass meter, gasoline injection					
Mot.no. →08137540	04.94-02.01			0 280 217 503	
Mot.no. 08137541→	04.94-02.01			0 280 217 519	
Phase sensor	04.94-02.01	MTS		0 232 103 008	
		OTS		0 232 103 001	
Mot.no. →08149313	04.94-02.01			0 232 103 008	
Mot.no. 08149314→	04.94-02.01			0 232 103 017	
Speed sensor, ignition/injection					
Mot.no. 08149314→	04.94-02.01			0 261 210 131	
Knock sensor					
Mot.no. →08137540	04.94-02.01			0 261 231 079	
Mot.no. 08137541→	04.94-02.01			0 261 231 116	
Temperature sensor, intake air, injection system					
Mot.no. →01837540	04.94-02.01			0 280 130 073	
Mot.no. 08137541→	04.94-02.01			0 280 130 092	
Temperature sensor, coolant, injection system					
Mot.no. →08137540	04.94-02.01			0 280 130 107	
Mot.no. 08137541→	04.94-02.01			0 280 130 093	
3.2i [B]			3,2l 160 kW Y 32 SE 6 Zyl.		
Throttle valve assembly	09.00-09.03			0 280 750 006	
Air mass meter, gasoline injection	09.00-09.03			0 281 002 184	
Phase sensor	09.00-09.03			0 232 103 025	
Speed sensor, ignition/injection					
Mot.no. 08149314→	09.00-09.03			0 261 210 131	
Knock sensor					
Mot.no. 08137541→	09.00-09.03			0 261 231 116	

Product				

Rekord

1.8 [E]			1,8l 55 kW 18 N 4 Zyl.		
Wheel speed sensor	09.84-08.86	VO		0 265 001 055	
1.8 i [E]			1,8l 74 kW C 18 NV 4 Zyl.		
Throttle valve sensor	05.85-08.86			0 280 120 301	
Air flow sensor, gasoline injection	05.85-08.86			0 280 202 089	
Temperature sensor, coolant, injection system	05.85-08.86			0 280 130 026	
Wheel speed sensor	05.85-08.86	VO		0 265 001 055	
1.8 S [E]			1,8l 59/66 kW S 18 S; 18 S 4 Zyl.		
Wheel speed sensor	09.84-08.86	VO		0 265 001 055	
2.0 S [E]			2,0l 74 kW 20 S CIH 4 Zyl.		
Wheel speed sensor	09.84-08.86	VO		0 265 001 055	
2.2 i [E]			2,2l 85 kW 22 E CIH 4 Zyl.		
Throttle valve sensor	11.84-08.86			0 280 120 301	
Air flow sensor, gasoline injection	11.84-08.86			0 280 202 068	
Temperature sensor, coolant, injection system	11.84-08.86			0 280 130 032	
Wheel speed sensor	11.84-08.86	VO		0 265 001 055	
2.3 D [E]			2,3l 52 kW 23 D 4 Zyl.		
Wheel speed sensor	09.84-08.86	VO		0 265 001 055	
2.3 TD [E]			2,3l 63 kW 23 DT 4 Zyl.		
Wheel speed sensor	09.84-08.86	VO		0 265 001 055	

Senator

2.2 i [A]			2,2l 85 kW 22 E 4 Zyl.		
Throttle valve sensor	11.84-08.87			0 280 120 301	
Air flow sensor, gasoline injection	11.84-08.87			0 280 202 068	
Temperature sensor, coolant, injection system	11.84-08.87			0 280 130 032	
Wheel speed sensor	11.84-08.87	HI		0 265 001 056	
		VO		0 265 001 055	
2.3 D Complex [A]			2,3l 70 kW 23 DC 4 Zyl.		
Wheel speed sensor	11.84-08.87	HI		0 265 001 056	
		VO		0 265 001 055	
2.3 TD [A]			2,3l 64 kW 23 TD 4 Zyl.		
Wheel speed sensor	11.84-08.87	HI		0 265 001 056	
		VO		0 265 001 055	
2.5 i [A]			2,5l 100 kW S 25 E/H CIH 6 Zyl.		
Throttle valve sensor	09.84-08.87			0 280 120 200	
Air flow sensor, gasoline injection	09.84-08.87			0 280 202 024	
Temperature sensor, coolant, injection system	09.84-08.87			0 280 130 026	
Relay, Jetronic	09.84-08.87			0 332 514 124	
Wheel speed sensor	09.84-08.87	HI		0 265 001 056	
		VO		0 265 001 055	
2.5 i [A]			2,5l 100-103 kW 25 E CIH 6 Zyl.		
Throttle valve sensor	09.84-08.87			0 280 120 301	
Air flow sensor, gasoline injection	09.84-08.87			0 280 202 053	
Temperature sensor, coolant, injection system	09.84-08.87			0 280 130 032	
Wheel speed sensor	09.84-08.87	HI		0 265 001 056	
		VO		0 265 001 055	
2.5 i [B]			2,5l 103 kW 25 NE CIH 6 Zyl.		
Throttle valve sensor	09.87-12.89			0 280 120 301	
Air flow sensor, gasoline injection	09.87-12.89			0 280 202 053	
Temperature sensor, coolant, injection system	09.87-12.89			0 280 130 032	
Wheel speed sensor	09.87-12.89	HI		0 265 001 134	
Fg.no. N1085998→	09.88-12.89	VO		0 265 001 220	
Fg.no. →J1185909	09.87-12.89	VO		0 265 001 143	
2.6 i [B]			2,6l 110 kW C 26 NE CIH 6 Zyl.		
Throttle valve sensor	09.90-09.93			0 280 122 001	
Air flow sensor, gasoline injection	09.90-09.93			0 280 202 207	
Speed sensor, ignition/injection	09.90-09.93			0 261 210 031	
Temperature sensor, coolant, injection system	09.90-09.93			0 280 130 107	

Product



Wheel speed sensor	09.90-09.93	HI	0 265 001 134
Fg.no. N1085998→	09.90-09.93	VO	0 265 001 220
Fg.no. →J1185909	09.90-09.93	VO	0 265 001 143
3.0 i [A]	3,0l 115 kW C 30 NE/C 30 LE	6 Zyl.	
Throttle valve sensor	09.85-08.87		0 280 120 301
Air flow sensor, gasoline injection	09.85-08.87		0 280 202 084
Temperature sensor, coolant, injection system	09.85-08.87		0 280 130 032
Wheel speed sensor	09.85-08.87	HI	0 265 001 056
		VO	0 265 001 055
3.0 i [A]	3,0l 132 kW S 30 E CIH	6 Zyl.	
Throttle valve sensor	01.83-08.87		0 280 120 301
Air flow sensor, gasoline injection	01.83-08.87		0 280 202 007
Temperature sensor, coolant, injection system	01.83-08.87		0 280 130 026
Relay, Jetronic	01.83-08.87		0 332 514 124
Wheel speed sensor	09.83-08.87	HI	0 265 001 056
		VO	0 265 001 055
3.0 i [A]	3,0l 132 kW 30 E CIH	6 Zyl.	
Throttle valve sensor	01.83-08.87		0 280 120 301
Air flow sensor, gasoline injection	01.83-08.87		0 280 202 037
Temperature sensor, coolant, injection system	01.83-08.87		0 280 130 032
Wheel speed sensor	09.83-08.87	HI	0 265 001 056
		VO	0 265 001 055
3.0 i [B]	3,0l 115 kW C 30 LE CIH	6 Zyl.	
Throttle valve sensor	09.87-09.93		0 280 120 301
	04.88-09.93	AG	0 280 120 405
Air flow sensor, gasoline injection	09.87-09.93		0 280 202 201
Speed sensor, ignition/injection	09.87-09.93		0 261 210 031
Temperature sensor, coolant, injection system	09.87-09.93		0 280 130 107
Wheel speed sensor	09.87-09.93	HI	0 265 001 134
Fg.no. N1085998→	09.88-09.93	VO	0 265 001 220
Fg.no. →J1185909	09.87-09.93	VO	0 265 001 143
3.0 i [B]	3,0l 130 kW C 30 NE CIH	6 Zyl.	
Throttle valve sensor			
Fg.no. L1019855→	09.89-09.93		0 280 122 001
Fg.no. →L1019854	01.88-08.89		0 280 120 316
Fg.no. →1019854	04.88-09.93	AG	0 280 120 412
Air flow sensor, gasoline injection	01.88-09.93		0 280 203 032
			0 986 280 074
Speed sensor, ignition/injection	01.88-09.93		0 261 210 031
Temperature sensor, coolant, injection system	01.88-09.93		0 280 130 107
Wheel speed sensor	01.88-09.93	HI	0 265 001 134
Fg.no. N1085998→	09.88-09.93	VO	0 265 001 220
Fg.no. →J1185909	01.88-09.93	VO	0 265 001 143
3.0 i [B]	3,0l 130 kW 30 NE CIH	6 Zyl.	
Throttle valve sensor	01.88-12.89		0 280 120 301
	04.88-12.89	AG	0 280 120 405
Temperature sensor, coolant, injection system	01.88-12.89		0 280 130 032
Wheel speed sensor	01.88-12.89	HI	0 265 001 134
Fg.no. N1085998→	09.88-12.89	VO	0 265 001 220
Fg.no. →J1185909	01.88-12.89	VO	0 265 001 143
3.0 i 24V [B]	3,0l 150 kW C 30 SE	6 Zyl.	
Throttle valve sensor	09.89-09.93		0 280 122 001
Air flow sensor, gasoline injection	09.89-09.93		0 280 203 032
			0 986 280 074
Knock sensor	09.89-09.93		0 261 231 006
Temperature sensor, coolant, injection system	09.89-09.93		0 280 130 107
Wheel speed sensor	09.89-09.93	HI	0 265 001 134
Fg.no. N1085998→	09.89-09.93	VO	0 265 001 220
Fg.no. →J1185909	09.89-09.93	VO	0 265 001 143
3.6 i [B]	3,6l 145 kW C 3.6 NE Irmischer	6 Zyl.	
Speed sensor, ignition/injection	08.89-09.93		0 261 210 031

Product



4.0 i [B]	4,0l 200 kW C 40 SE	6 Zyl.	
Air flow sensor, gasoline injection	01.91-09.93		0 280 203 025
			0 986 280 043

Signum

1.8 i	1,8l 90 kW Z 18 XE	4 Zyl.	
Phase sensor	05.03-02.05	NOC	0 232 103 021
1.9 CDTi	1,9l 74 kW Z 19 DTL	4 Zyl.	
Air mass meter, diesel	08.05→		0 281 002 683
Speed sensor, diesel	08.05→		0 281 002 603
Phase sensor	08.05→	NOC	0 281 002 213
High-pressure sensor (CR system)	08.05→		0 281 002 706
Boost pressure sensor, Diesel	08.05→		0 281 002 437
1.9 CDTi	1,9l 88 kW Z 19 DT	4 Zyl.	
Air mass meter, diesel	04.04→		0 281 002 683
Speed sensor, diesel	04.04→		0 281 002 603
Phase sensor	04.04→	NOC	0 281 002 213
Boost pressure sensor, Diesel	04.04→		0 281 002 437
1.9 CDTi	1,9l 110 kW Z 19 DTH	4 Zyl.	
Air mass meter, diesel	04.04→		0 281 002 683
High-pressure sensor (CR system)	04.04→		0 281 002 706
Boost pressure sensor, Diesel	04.04→		0 281 002 437
2.0 DTi	2,0l 74 kW Y 20 DTH	4 Zyl.	
Air mass meter, diesel	05.03-09.05		0 281 002 479
Speed sensor, diesel			
Fg.no. →17G23740	05.03-09.05	FKW	0 281 002 138
Fg.no. 17G23741→	05.03-09.05	FKW	0 281 002 662
Temperature sensor, coolant, diesel	05.03-09.05		0 281 002 473
2.0 Turbo	2,0l 129 kW Z 20 NET	4 Zyl.	
Speed sensor, ignition/injection	05.03→	FKW	0 261 210 229
2.2 DTi	2,2l 86-92 kW Y 22 DTR	4 Zyl.	
Air mass meter, diesel	05.03-09.05		0 281 002 479
Speed sensor, diesel	05.03-09.05	FKW	0 281 002 138
Temperature sensor, coolant, diesel	05.03-09.05		0 281 002 473
2.8 V6 Turbo	2,8l 169/184 kW Z 28 NEL; Z 28 NET	6 Zyl.	
Knock sensor	09.05→		0 261 231 174
Pressure sensor, intake manifold, gasoline	09.05→		0 261 230 101
Temperature sensor, coolant, injection system	09.05→		0 280 130 122
3.0 CDTi	3,0l 130-135 kW Y 30 DT	6 Zyl.	
Air mass meter, diesel	05.03→		0 281 002 605
3.0 CDTi	3,0l 130-135 kW Z 30 DT	6 Zyl.	
Air mass meter, diesel	09.05→		0 281 002 773
3.2 V6	3,2l 155 kW Z 32 SE	6 Zyl.	
Throttle valve assembly	05.03-09.05		0 280 750 119
Air mass meter, gasoline injection	05.03-09.05		0 280 218 087
Phase sensor	05.03-09.05	NOC	0 232 103 025
Speed sensor, ignition/injection	05.03-09.05	FKW	0 261 210 206
Knock sensor	05.03-09.05		0 261 231 116

Sintra

2.2 i 16V	2,2l 104 kW X 22 XE	4 Zyl.	
Throttle valve sensor	09.96-09.99		0 280 122 001
Phase sensor	09.96-09.99	NOC	0 232 103 015
Knock sensor	09.96-09.99		0 261 231 079
Pressure sensor, intake manifold, gasoline	09.96-09.99		0 261 230 009
Temperature sensor, intake air, injection system			
Fg.no. XD100001→	09.96-09.99		0 280 130 092
Fg.no. →WD199999	09.96-09.99		0 280 130 073
Temperature sensor, coolant, injection system	09.96-09.99		0 281 002 169




O

Product



◀ Sintra

2.2 TD		2,2l 85 kW X 22 DTH 4 Zyl.	
Air mass meter, diesel	09.97-09.99		0 281 002 184
Speed sensor, diesel	09.97-09.99		0 281 002 138
Pressure sensor, intake manifold, diesel	09.97-09.99		0 281 002 137
Temperature sensor, coolant, injection system	09.97-09.99		0 280 130 107
Pedal position sensor, diesel	09.97-09.99	LLE	0 205 001 039
		RLE	0 205 001 042
3.0i 24V		3,0l 148 kW X 30 XE 6 Zyl.	
Throttle valve sensor	09.96-09.99		0 280 122 001
Air mass meter, gasoline injection	09.96-09.99		0 280 217 503
Phase sensor	09.96-09.99		0 232 103 008
Knock sensor	09.96-09.99		0 261 231 079
Temperature sensor, intake air, injection system	09.96-09.99		0 280 130 092
Temperature sensor, coolant, injection system	09.96-09.99		0 281 002 169
Pedal position sensor, diesel	09.96-09.99	LLE	0 205 001 039
		RLE	0 205 001 042



Speedster

2.0 Turbo2,0l 147 kW Z 20 LET 4 Zyl.			
Air mass meter, gasoline injection	04.03-09.06		0 280 218 051
			0 986 280 231
Phase sensor	04.03-09.06	NOC	0 232 103 015
Speed sensor, ignition/injection	04.03-09.06	FKW	0 261 210 150
Knock sensor	04.03-09.06		0 261 231 116
Pressure sensor, intake manifold, gasoline	04.03-09.06		0 261 230 009
Temperature sensor, coolant, injection system	04.03-09.06		0 281 002 169

Tigra

1.4i [A]1,4l 63-66 kW X 14 XE 4 Zyl.			
Temperature sensor, coolant, injection system			
Fg.no. W3000001→,W4000001→,	09.94-08.99		0 280 130 093
W6000001→			
Fg.no. →V6999999	09.94-08.99		0 280 130 107
1.6i [A]1,6l 78 kW X 16 XE 4 Zyl.			
Temperature sensor, coolant, injection system			
Fg.no. W3000001→	09.94-08.99		0 280 130 093
Fg.no. W3000001→,W4000001→,	09.94-08.99		0 280 130 093
W6000001→			
Fg.no. →V6999999	09.94-08.99		0 280 130 107
1.6i 16V [A]1,6l 74 kW C 16 SEL 4 Zyl.			
Temperature sensor, coolant, injection system			
Fg.no. W3000001→,W4000001→,	08.97-08.98		0 280 130 093
W6000001→			

Tigra TwinTop

1.3 CDTi [B]1,3l 51 kW Z 13 DT 4 Zyl.			
Air mass meter, diesel	06.04→		0 281 002 549
High-pressure sensor (CR system)	06.04→		0 281 002 534
Pressure sensor, intake manifold, diesel	06.04→		0 281 002 510
Yaw rate sensor, brake system	06.04→		0 265 005 270
Pressure sensor, ESP, (electronic stability program)	06.04→		0 265 005 303
1.4i [B]1,4l 66 kW Z 14 XEP 4 Zyl.			
Throttle valve assembly	06.04→		0 280 750 133
Air mass meter, gasoline injection	06.04→		0 280 218 119
Phase sensor			
Fg.no. →4E999999	06.04→	NOC	0 232 103 021
Fg.no. 5E000001→5E999999	06.04→	NOC	0 232 103 052
Fg.no. 6E000001→	06.04→	NOC	0 232 103 067
Speed sensor, ignition/injection	06.04→	FKW	0 261 210 151
Knock sensor	06.04→		0 261 231 173

Product



Temperature sensor, coolant, injection system	06.04→	0 281 002 170
Yaw rate sensor, brake system	06.04→	0 265 005 270
Pressure sensor, ESP, (electronic stability program)	06.04→	0 265 005 303
1.8 i [B]1,8l 92 kW Z 18 XE 4 Zyl.		
Yaw rate sensor, brake system	06.04→	0 265 005 270
Pressure sensor, ESP, (electronic stability program)	06.04→	0 265 005 303

Vectra

1.4 [A]1,4l 55 kW 14 NV 4 Zyl.			
Wheel speed sensor, front			
Fg.no. →M1999999,→N5000039,	09.88-09.92		0 265 001 206
→MV999999			
Wheel speed sensor, rear			
Fg.no. →NV999999,→N1999999,	09.88-09.92	L10,RAB	0 265 001 207
→N5999999		L13,LAB	0 265 001 208
1.6 i [A]1,6l 52 kW X 16 SZ 4 Zyl.			
Temperature sensor, coolant, injection system	09.93-08.95		0 280 130 107
Wheel speed sensor, front			
Fg.no. →M1999999,→N5000039,	09.93-08.95		0 265 001 206
→MV999999			
Wheel speed sensor, rear			
Fg.no. →NV999999,→N1999999,	09.93-08.95	L10,RAB	0 265 001 207
→N5999999		L13,LAB	0 265 001 208
1.6 i [A]1,6l 55 kW C 16 LZ2; C 16 NZ2 4 Zyl.			
Speed sensor, ignition/injection	09.92-08.95		0 261 210 030
Temperature sensor, coolant, injection system	09.92-08.95		0 280 130 107
Wheel speed sensor, front			
Fg.no. →M1999999,→N5000039,	09.92-08.95		0 265 001 206
→MV999999			
Wheel speed sensor, rear			
Fg.no. →NV999999,→N1999999,	09.92-08.95	L10,RAB	0 265 001 207
→N5999999		L13,LAB	0 265 001 208
1.6 i [B]1,6l 55 kW X 16 SZR 4 Zyl.			
Temperature sensor, coolant, injection system			
Fg.no. →02GE3893,→V1999999,	09.96-07.03		0 280 130 107
→V5999999,→V7999999			
Fg.no. 02GE3894→,W1000001→,	09.96-07.03		0 280 130 093
W5000001→,W7000001→			
1.6 i [B]1,6l 55 kW 16 LZ2 4 Zyl.			
Temperature sensor, coolant, injection system	09.95-07.03		0 280 130 107
1.6 i KAT [A]1,6l 55-60 kW E 16 NZ / C 16 NZ 4 Zyl.			
Temperature sensor, coolant, injection system	09.88-08.95		0 280 130 107
Wheel speed sensor, front			
Fg.no. →M1999999,→N5000039,	09.88-08.95		0 265 001 206
→MV999999			
Wheel speed sensor, rear			
Fg.no. →NV999999,→N1999999,	09.88-08.95	L10,RAB	0 265 001 207
→N5999999		L13,LAB	0 265 001 208
1.6 i 16V [B]1,6l 74 kW X 16 XEL 4 Zyl.			
Temperature sensor, coolant, injection system	09.95-07.02		0 280 130 093
1.6 S [A]1,6l 60 kW 16 SV 4 Zyl.			
Wheel speed sensor, front			
Fg.no. →M1999999,→N5000039,	09.88-08.95		0 265 001 206
→MV999999			
Wheel speed sensor, rear			
Fg.no. →NV999999,→N1999999,	09.88-08.95	L10,RAB	0 265 001 207
→N5999999		L13,LAB	0 265 001 208
1.7 D [A]1,7l 42 kW 17 D / DR 4 Zyl.			
Wheel speed sensor, front			
Fg.no. →M1999999,→N5000039,	10.88-08.95		0 265 001 206
→MV999999			



Wheel speed sensor, rear			
Fg.no. →NV999999,→N1999999, →N5999999	10.88-08.95	L10,RAB L13,LAB	0 265 001 207 0 265 001 208
1.7 TD [A]	1,7l 60 kW 17 DT/TC4 EE1 4 Zyl.		
Wheel speed sensor, front			
Fg.no. →M1999999,→N5000039, →MV999999	03.90-08.95		0 265 001 206
Wheel speed sensor, rear			
Fg.no. →NV999999,→N1999999, →N5999999	03.90-08.95	L10,RAB L13,LAB	0 265 001 207 0 265 001 208
1.8 [A]	1,8l 66 kW 18 SV 4 Zyl.		
Speed sensor, ignition/injection			
Fg.no. →P1999999,→P5999999, →P7999999	09.89-08.95		0 261 210 030
Wheel speed sensor, front			
Fg.no. →M1999999,→N5000039, →MV999999	09.89-08.95		0 265 001 206
Wheel speed sensor, rear			
Fg.no. →NV999999,→N1999999, →N5999999	09.89-08.95	L10,RAB L13,LAB	0 265 001 207 0 265 001 208
1.8 i [A]	1,8l 66 kW C 18 NZ 4 Zyl.		
Speed sensor, ignition/injection			
Fg.no. →P1999999,→P5999999, →P7999999	03.90-08.95		0 261 210 030
Temperature sensor, coolant, injection system	03.90-08.95		0 280 130 107
Wheel speed sensor, front			
Fg.no. →M1999999,→N5000039, →MV999999	03.90-08.95		0 265 001 206
Wheel speed sensor, rear			
Fg.no. →NV999999,→N1999999, →N5999999	03.90-08.95	L10,RAB L13,LAB	0 265 001 207 0 265 001 208
1.8 i 16V [B]	1,8l 85 kW X 18 XE 4 Zyl.		
Throttle valve sensor	09.95-09.00		0 280 122 001
1.8 S [A]	1,8l 65 kW E 18 NVR 4 Zyl.		
Speed sensor, ignition/injection	09.88-08.95		0 261 210 030
Wheel speed sensor, front			
Fg.no. →M1999999,→N5000039, →MV999999	09.88-08.95		0 265 001 206
Wheel speed sensor, rear			
Fg.no. →NV999999,→N1999999, →N5999999	09.88-08.95	L10,RAB L13,LAB	0 265 001 207 0 265 001 208
1.8 S 4x4 [A]	1,8l 65 kW E 18 NVR 4 Zyl.		
Speed sensor, ignition/injection	01.89-08.95		0 261 210 030
Wheel speed sensor, front			
Fg.no. →M1999999,→N5000039, →MV999999	01.89-08.95		0 265 001 206
Wheel speed sensor, rear			
Fg.no. N1000001→	01.89-08.95	AA,LAB AA,RAB	0 265 006 487 0 265 006 486
Fg.no. →M1999999	01.89-08.95	AA,LAB	0 265 001 226
1.8 4x4 [A]	1,8l 66 kW 18 SV 4 Zyl.		
Speed sensor, ignition/injection			
Fg.no. →P1999999,→P5999999, →P7999999	09.89-08.95		0 261 210 030
Wheel speed sensor, front			
Fg.no. →M1999999,→N5000039, →MV999999	09.89-08.95		0 265 001 206
Wheel speed sensor, rear			
Fg.no. N1000001→	09.89-08.95	AA,LAB AA,RAB	0 265 006 487 0 265 006 486
Fg.no. →M1999999	09.89-08.95	AA,LAB	0 265 001 226



1.9 CDTi [C]		1,9l 74 kW Z 19 DTL 4 Zyl.	
Air mass meter, diesel	09.05→		0 281 002 683
Speed sensor, diesel	09.05→		0 281 002 603
Phase sensor	09.05→	NOC	0 281 002 213
High-pressure sensor (CR system)	09.05→		0 281 002 706
Boost pressure sensor, Diesel	09.05→		0 281 002 437
1.9 CDTi [C]		1,9l 88 kW Z 19 DT 4 Zyl.	
Air mass meter, diesel	04.04→		0 281 002 683
Speed sensor, diesel	04.04→		0 281 002 603
Phase sensor	04.04→	NOC	0 281 002 213
High-pressure sensor (CR system)	04.04→		0 281 002 534
Boost pressure sensor, Diesel	04.04→		0 281 002 437
1.9 CDTi [C]		1,9l 110 kW Z 19 DTH 4 Zyl.	
Air mass meter, diesel	04.04-03.07		0 281 002 683
High-pressure sensor (CR system)	04.04-03.07		0 281 002 534
Boost pressure sensor, Diesel	04.04-03.07		0 281 002 437
1.9 CDTi GTS [C]		1,9l 74 kW Z 19 DTL 4 Zyl.	
Air mass meter, diesel	09.05→		0 281 002 683
Speed sensor, diesel	09.05→		0 281 002 603
Phase sensor	09.05→	NOC	0 281 002 213
High-pressure sensor (CR system)	09.05→		0 281 002 706
Boost pressure sensor, Diesel	09.05→		0 281 002 437
1.9 CDTi GTS [C]		1,9l 88 kW Z 19 DT 4 Zyl.	
Air mass meter, diesel	04.04→		0 281 002 683
Speed sensor, diesel	04.04→		0 281 002 603
Phase sensor	04.04→	NOC	0 281 002 213
High-pressure sensor (CR system)	04.04→		0 281 002 534
Boost pressure sensor, Diesel	04.04→		0 281 002 437
1.9 CDTi GTS [C]		1,9l 110 kW Z 19 DTH 4 Zyl.	
Air mass meter, diesel	04.04-03.07		0 281 002 683
High-pressure sensor (CR system)	04.04-03.07		0 281 002 534
Boost pressure sensor, Diesel	04.04-03.07		0 281 002 437
2.0 Di [B]		2,0l 60 kW X 20 DTL 16V Turbo 4 Zyl.	
Air mass meter, diesel			
Fg.no. W1000001→	09.96-08.02		0 281 002 180
Fg.no. →V7999999	09.96-08.02		0 281 002 139
Speed sensor, diesel	09.96-08.02		0 281 002 138
Pressure sensor, intake manifold, diesel	09.96-08.02		0 281 002 137
Temperature sensor, intake air, injection system	09.96-08.02		0 280 130 073
Temperature sensor, coolant, diesel	09.96-08.02		0 281 002 169
Temperature sensor, intake air, diesel	09.96-08.02		0 280 130 073
Pedal position sensor, diesel			
Fg.no. W1285447→,W7154259→	09.96-08.02	LLE	0 281 002 476
Fg.no. →W1285446,→W5276825, →W7154258	09.96-08.02	LLE RLE	0 205 001 042 0 205 001 039
2.0 DTi [B]		2,0l 74 kW X 20 DTH 4 Zyl.	
Air mass meter, diesel	09.97-08.03		0 281 002 180
Speed sensor, diesel	09.97-08.03		0 281 002 138
Pressure sensor, intake manifold, diesel	09.97-08.03	TW	0 281 002 137
			0 281 002 438
Temperature sensor, coolant, diesel	09.97-08.03		0 281 002 169
Pedal position sensor, diesel			
Fg.no. W1285447→,W7154259→	09.97-08.03	LLE	0 281 002 476
Fg.no. →W1285446,→W5276825, →W7154258	09.97-08.03	LLE RLE	0 205 001 042 0 205 001 039
2.0 DTi [B]		2,0l 74 kW Y 20 DTH 4 Zyl.	
Air mass meter, diesel	09.00-09.03		0 281 002 428
Speed sensor, diesel	09.00-09.03		0 281 002 138
Pressure sensor, intake manifold, diesel	09.00-09.03		0 281 002 438
Temperature sensor, coolant, diesel	09.00-09.03		0 281 002 169
Pedal position sensor, diesel	09.00-09.03	LLE	0 281 002 476




Product				

◀ Vectra

2.0DTI, DTIGTS [C]		2,0l 74 kW Y 20 DTH 4 Zyl.	
Air mass meter, diesel	04.02-09.05		0 281 002 479
Speed sensor, diesel	04.02-09.05		0 281 002 138
Speed sensor, ignition/injection			
Mot.no. →17G23740	04.02-09.05	FKW	0 281 002 138
Mot.no. 17G23741→	04.02-09.05	FKW	0 281 002 662
Temperature sensor, coolant, diesel	04.02-09.05		0 281 002 473
2.0i [A]		2,0l 74-85 kW 20 NE,C 20 NE(NEF) 4 Zyl.	
Throttle valve sensor	09.88-08.90		0 280 120 316
	09.90-08.95		0 280 122 004
	09.88-08.90	AG	0 280 120 412
Air flow sensor, gasoline injection	09.88-08.89		0 280 202 210
			0 986 280 063
Speed sensor, ignition/injection			
Fg.no. →P1999999,→P5999999,→P7999999	09.88-08.95		0 261 210 030
Pressure sensor, intake manifold, gasoline	09.88-08.89		0 280 101 007
Temperature sensor, coolant, injection system	09.88-08.95		0 280 130 107
Wheel speed sensor, front			
Fg.no. →M1999999,→N5000039,→MV999999	09.88-08.95		0 265 001 206
Wheel speed sensor, rear			
Fg.no. →NV999999,→N1999999,→N5999999	09.88-08.95	L10,RAB	0 265 001 207
		L13,LAB	0 265 001 208
2.0i [A]		2,0l 95 kW 20 SEH 4 Zyl.	
Throttle valve sensor	09.88-08.90		0 280 120 316
	09.90-08.95		0 280 122 001
	09.88-08.90	AG	0 280 120 412
Air flow sensor, gasoline injection	09.88-08.95		0 280 202 210
			0 986 280 063
Speed sensor, ignition/injection			
	09.88-08.93		0 261 210 030
Pressure sensor, intake manifold, gasoline	09.88-08.89		0 280 101 007
Temperature sensor, coolant, injection system	09.88-08.95		0 280 130 107
Wheel speed sensor, front			
Fg.no. →M1999999,→N5000039,→MV999999	09.88-08.95		0 265 001 206
Wheel speed sensor, rear			
Fg.no. →NV999999,→N1999999,→N5999999	09.88-08.95	L10,RAB	0 265 001 207
		L13,LAB	0 265 001 208
2.0i [B]		2,0l 82 kW 20 NEJ 4 Zyl.	
Throttle valve sensor	09.95-02.02		0 280 122 001
Air mass meter, gasoline injection	09.95-02.02		0 280 217 106
Knock sensor	09.95-02.02		0 261 231 006
Temperature sensor, intake air, injection system	09.95-02.02		0 280 130 073
Temperature sensor, coolant, injection system	09.95-02.02		0 280 130 107
2.0i [B]		2,0l 100 kW C 20 SEL 4 Zyl.	
Throttle valve sensor	05.97-09.02		0 280 122 001
2.0i 4x4 [A]		2,0l 85 kW 20 NE, C 20 NE 4 Zyl.	
Throttle valve sensor	01.89-08.90		0 280 120 316
	09.90-08.95		0 280 122 004
	01.89-08.90	AG	0 280 120 412
Air flow sensor, gasoline injection	01.89-08.89		0 280 202 210
			0 986 280 063
Speed sensor, ignition/injection			
Fg.no. →P1999999,→P5999999,→P7999999	01.89-08.95		0 261 210 030
Pressure sensor, intake manifold, gasoline	01.89-08.89		0 280 101 007
Temperature sensor, coolant, injection system	01.89-08.95		0 280 130 107
Wheel speed sensor, front			
Fg.no. →M1999999,→N5000039,→MV999999	01.89-08.95		0 265 001 206

Product				

Wheel speed sensor, rear			
Fg.no. N1000001→	01.89-08.95	AA,LAB	0 265 006 487
		AA,RAB	0 265 006 486
Fg.no. →M1999999	01.89-08.95	AA,LAB	0 265 001 226
2.0 i 4x4 [A]		2,0l 95 kW 20 SEH 4 Zyl.	
Throttle valve sensor	01.89-08.90		0 280 120 316
	09.90-08.95		0 280 122 001
	01.89-08.90	AG	0 280 120 412
Air flow sensor, gasoline injection	01.89-08.95		0 280 202 210
			 0 986 280 063
Speed sensor, ignition/injection	01.89-08.93		0 261 210 030
Pressure sensor, intake manifold, gasoline	01.89-08.89		0 280 101 007
Temperature sensor, coolant, injection system	01.89-08.95		0 280 130 107
Wheel speed sensor, front			
Fg.no. →M1999999,→N5000039,→MV999999	01.89-08.95		0 265 001 206
Wheel speed sensor, rear			
Fg.no. N1000001→	01.89-08.95	AA,LAB	0 265 006 487
		AA,RAB	0 265 006 486
Fg.no. →M1999999	01.89-08.95	AA,LAB	0 265 001 226
2.0 i 4x4 [A]		2,0l 150 kW C 20 LET Turbo 4 Zyl.	
Throttle valve sensor	09.92-08.95		0 280 120 412
Air mass meter, gasoline injection	09.92-08.95		0 280 213 024
			 0 986 280 140
Speed sensor, ignition/injection	09.92-08.93		0 261 210 030
Knock sensor	09.92-08.95	MIL	0 261 231 079
		OHL	0 261 231 006
Temperature sensor, intake air, injection system	09.92-08.95		0 280 130 039
Temperature sensor, coolant, injection system	09.92-08.95		0 280 130 107
Wheel speed sensor, front			
Fg.no. →M1999999,→N5000039,→MV999999	09.92-08.95		0 265 001 206
Wheel speed sensor, rear			
Fg.no. N1000001→	09.92-08.95	AA,LAB	0 265 006 487
		AA,RAB	0 265 006 486
Fg.no. →M1999999	09.92-08.95	AA,LAB	0 265 001 226
2.0 i 16V [A]		2,0l 100 kW X 20 XEV 4 Zyl.	
Throttle valve sensor	11.93-08.95		0 280 122 001
Wheel speed sensor, front			
Fg.no. →M1999999,→N5000039,→MV999999	11.93-08.95		0 265 001 206
Wheel speed sensor, rear			
Fg.no. →NV999999,→N1999999,→N5999999	11.93-08.95	L10,RAB	0 265 001 207
		L13,LAB	0 265 001 208
2.0 i 16V [A]		2,0l 110 kW C20XE (XEJ-LN); 20 XE / (XEJ) 4 Zyl.	
Throttle valve sensor			
Fg.no. →NV999999,→N1999999,→N5999999	09.92-08.95		0 280 120 326
Air mass meter, gasoline injection	09.92-08.95		0 280 217 106
Speed sensor, ignition/injection	09.92-08.93		0 261 210 030
Knock sensor	09.92-08.95	MIL	0 261 231 079
		OHL	0 261 231 006
Temperature sensor, intake air, injection system			
Fg.no. P1000001→,P5000001→,P7500001→	09.92-08.95		0 280 130 073
Temperature sensor, coolant, injection system	09.92-08.95		0 280 130 107
Wheel speed sensor, front			
Fg.no. →M1999999,→N5000039,→MV999999	09.92-08.95		0 265 001 206
Wheel speed sensor, rear			
Fg.no. NV100001→NV999999, N1000001→N1999999, N5000001→N5999999	09.92-08.95	LAB	0 265 003 094
		RAB	0 265 003 093



Wheel speed sensor, rear			
Fg.no. →MV999999, →M1999999, →M5999999	09.92-08.95	LAB	0 265 001 233
		RAB	0 265 001 232
2.0 i 16V [B]	2,0 l	100 kW	X 20 XEV 4 Zyl.
Throttle valve sensor	09.95-09.02		0 280 122 001
2.0 Turbo, Turbo GTS [C]	2,0 l	129 kW	Z 20 NET 4 Zyl.
Speed sensor, ignition/injection	03.03→	FKW	0 261 210 229
2.2 DTI [B]	2,2 l	92 kW	Y 22 DTR 4 Zyl.
Air mass meter, diesel	09.00-09.03		0 281 002 428
Speed sensor, diesel	09.00-09.03		0 281 002 138
Pressure sensor, intake manifold, diesel	09.00-09.03		0 281 002 438
Temperature sensor, coolant, diesel	09.00-09.03		0 281 002 169
Pedal position sensor, diesel	09.00-09.03	LLE	0 281 002 476
2.2 DTI, DTI GTS [C]	2,2 l	86-92 kW	Y 22 DTR 4 Zyl.
Air mass meter, diesel	04.02-09.05		0 281 002 479
Speed sensor, diesel	04.02-09.05		0 281 002 138
Speed sensor, ignition/injection			
Mot.no. →17G23740	04.02-09.05	FKW	0 281 002 138
Mot.no. 17G23741→	04.02-09.05	FKW	0 281 002 662
Temperature sensor, coolant, diesel	04.02-09.05		0 281 002 473
2.2 i [B]	2,2 l	106 kW	C 22 SEL 4 Zyl.
Throttle valve sensor	06.00-09.02		0 280 122 001
2.5 i [A]	2,5 l	125 kW	C 25 XE V6 6 Zyl.
Throttle valve sensor	02.93-08.95		0 280 122 001
Phase sensor			
Fg.no. →S1035178	02.93-08.95		0 232 103 001
Knock sensor	02.93-08.95		0 261 231 079
Temperature sensor, intake air, injection system	02.93-08.95		0 280 130 073
Temperature sensor, coolant, injection system	02.93-08.95		0 280 130 107
Wheel speed sensor, front			
Fg.no. →M1999999, →N5000039, →MV999999	02.93-08.95		0 265 001 206
2.5 i V6 [B]	2,5 l	125-143 kW	X 25 XE 6 Zyl.
Throttle valve sensor			
Fg.no. W1000001→, W5000001→, W7000001→, XL000001→	09.97-09.00		0 280 122 014
Fg.no. →V1999999, →V5999999, →V7999999	09.95-09.00		0 280 122 001
Air mass meter, gasoline injection			
Fg.no. W1000001→, W5000001→, W7000001→, XL000001→	09.95-09.00		0 280 217 519
Fg.no. →V1999999, →V5999999, →V7999999	09.95-09.00		0 280 217 503
Knock sensor	09.95-09.00		0 261 231 079
Temperature sensor, intake air, injection system			
Fg.no. W1000001→	09.95-09.00		0 280 130 092
Fg.no. →V7999999	09.95-09.00		0 280 130 073
Temperature sensor, coolant, injection system			
Fg.no. W1000001→, W5000001→, W7000001→, XL000001→	09.95-09.00		0 280 130 093
Fg.no. →V7999999	09.95-09.00		0 280 130 107
2.6 V6 [B]	2,6 l	130 kW	Y 26 SE 6 Zyl.
Air mass meter, gasoline injection	09.00-09.02		0 281 002 184
Phase sensor	09.00-09.02		0 232 103 025
Speed sensor, ignition/injection	09.00-09.02		0 261 210 206
Knock sensor	09.00-09.02		0 261 231 116
Temperature sensor, coolant, injection system	09.00-09.02		0 281 002 169
2.8 GTS Turbo, Turbo [C]	2,8 l	169/184-188 kW	Z 28 NEL; Z 28 NET 6 Zyl.
Knock sensor	08.05→		0 261 231 174
Pressure sensor, intake manifold, gasoline	08.05→		0 261 230 101
Temperature sensor, coolant, injection system	08.05→		0 280 130 122
3.0 CDTi [C]	3,0 l	130 kW	Y 30 DT 6 Zyl.
Air mass meter, diesel	03.03-08.05		0 281 002 605



3.0 CDTi [C]	3,0 l	135 kW	Z 30 DT 6 Zyl.
Air mass meter, diesel	08.05→		0 281 002 773
3.0 CDTi GTS [C]	3,0 l	130 kW	Y 30 DT 6 Zyl.
Air mass meter, diesel	03.03-08.05		0 281 002 605
3.0 CDTi GTS [C]	3,0 l	135 kW	Z 30 DT 6 Zyl.
Air mass meter, diesel	08.05→		0 281 002 773
3.2 i, i GTS [C]	3,2 l	155 kW	Z 32 SE 6 Zyl.
Throttle valve assembly	08.02-09.05		0 280 750 119
Air mass meter, gasoline injection	08.02-09.05		0 280 218 087
Phase sensor	08.02-09.05	NOC	0 232 103 025
Speed sensor, ignition/injection	08.02-09.05	FKW	0 261 210 206
Knock sensor	08.02-09.05		0 261 231 116
Temperature sensor, coolant, injection system	08.02-09.05		0 281 002 170
2000 i 16V [A]	2,0 l	110-115 kW	C 20XE (XEJ-LN); 20 XE / (XEJ) 4 Zyl.
Throttle valve sensor			
Fg.no. →NV999999, →N1999999, →N5999999	09.89-08.92		0 280 120 326
Air mass meter, gasoline injection			
	09.89-08.92		0 280 212 015
			0 986 280 113
Speed sensor, ignition/injection	09.89-08.92		0 261 210 030
Knock sensor	09.89-08.92	MIL	0 261 231 079
		OHL	0 261 231 006
Temperature sensor, intake air, injection system			
Fg.no. P1000001→, P5000001→, P7500001→	09.89-08.92		0 280 130 073
Temperature sensor, coolant, injection system	09.89-08.92		0 280 130 107
Wheel speed sensor, front			
Fg.no. →M1999999, →N5000039, →MV999999	09.89-08.92		0 265 001 206
Wheel speed sensor, rear			
Fg.no. NV100001→, NV999999, N1000001→, N1999999, N5000001→, N5999999	09.89-08.92	LAB	0 265 003 094
		RAB	0 265 003 093
Fg.no. →MV999999, →M1999999, →M5999999	09.89-08.92	LAB	0 265 001 233
		RAB	0 265 001 232
2000 i 16V 4x4 [A]	2,0 l	110 kW	C 20XE (XEJ-LN); 20 XE / XEJ 4 Zyl.
Throttle valve sensor			
Fg.no. →NV999999, →N1999999, →N5999999	09.89-08.92		0 280 120 326
Air mass meter, gasoline injection			
	09.89-08.92		0 280 212 015
			0 986 280 113
Speed sensor, ignition/injection	09.89-08.92		0 261 210 030
Knock sensor	09.89-08.92	MIL	0 261 231 079
		OHL	0 261 231 006
Temperature sensor, intake air, injection system			
Fg.no. P1000001→, P5000001→, P7500001→	09.89-08.92		0 280 130 073
Temperature sensor, coolant, injection system	09.89-08.92		0 280 130 107
Wheel speed sensor, front			
Fg.no. →M1999999, →N5000039, →MV999999	09.89-08.92		0 265 001 206
Wheel speed sensor, rear			
Fg.no. N1000001→	09.89-08.92	AA,LAB	0 265 006 487
		AA,RAB	0 265 006 486
Fg.no. →M1999999	09.89-08.92	AA,LAB	0 265 001 226

Vectra Caravan

1.6 i [B]	1,6 l	55 kW	X 16 SZR 4 Zyl.
Temperature sensor, coolant, injection system			
Fg.no. →02GE3893, →V1999999, →V5999999, →V7999999	09.96-09.00		0 280 130 107

Product				

◀ Vectra Caravan

Temperature sensor, coolant, injection system			
Fg.no. 02GE3894→,W1000001→, W5000001→,W7000001→	09.96-09.00		0 280 130 093
1.6 i [B]		1,6 l 55 kW 16 L22 4 Zyl.	
Temperature sensor, coolant, injection system	09.95-07.00		0 280 130 107
1.6 i 16V [B]		1,6 l 74 kW X 16 XEL 4 Zyl.	
Temperature sensor, coolant, injection system	11.96-07.02		0 280 130 093
1.8 i 16V [B]		1,8 l 85 kW X 18 XE 4 Zyl.	
Throttle valve sensor	09.95-09.00		0 280 122 001
1.9 CDTi [C]		1,9 l 74 kW Z 19 DTL 4 Zyl.	
Air mass meter, diesel	09.05→		0 281 002 683
Speed sensor, diesel	09.05→		0 281 002 603
Phase sensor	09.05→	NOC	0 281 002 213
High-pressure sensor (CR system)	09.05→		0 281 002 706
Boost pressure sensor, Diesel	09.05→		0 281 002 437
1.9 CDTi [C]		1,9 l 88 kW Z 19 DT 4 Zyl.	
Air mass meter, diesel	04.04→		0 281 002 683
Speed sensor, diesel	04.04→		0 281 002 603
Phase sensor	04.04→	NOC	0 281 002 213
High-pressure sensor (CR system)	04.04→		0 281 002 534
Boost pressure sensor, Diesel	04.04→		0 281 002 437
1.9 CDTi [C]		1,9 l 110 kW Z 19 DTH 4 Zyl.	
Air mass meter, diesel	04.04-03.07		0 281 002 683
High-pressure sensor (CR system)	04.04-03.07		0 281 002 534
Boost pressure sensor, Diesel	04.04-03.07		0 281 002 437
2.0 Di [B]		2,0 l 60 kW X 20 DTL 16V Turbo 4 Zyl.	
Air mass meter, diesel			
Fg.no. W1000001→	09.96-08.00		0 281 002 180
Fg.no. →V7999999	09.96-08.00		0 281 002 139
Speed sensor, diesel	09.96-08.00		0 281 002 138
Pressure sensor, intake manifold, diesel	09.96-08.00		0 281 002 137
Temperature sensor, intake air, injection system	09.96-08.00		0 280 130 073
Temperature sensor, coolant, diesel	09.96-08.00		0 281 002 169
Temperature sensor, intake air, diesel	09.96-08.00		0 280 130 073
Pedal position sensor, diesel			
Fg.no. W1285447→,W7154259→	09.96-08.00	LLE	0 281 002 476
Fg.no. →W1285446,→W5276825, →W7154258	09.96-08.00	LLE	0 205 001 042
		RLE	0 205 001 039
2.0 DTi [B]		2,0 l 74 kW X 20 DTH 4 Zyl.	
Air mass meter, diesel	09.97-08.03		0 281 002 180
Speed sensor, diesel	09.97-08.03		0 281 002 138
Pressure sensor, intake manifold, diesel	09.97-08.03	TW	0 281 002 137
			0 281 002 438
Temperature sensor, coolant, diesel	09.97-08.03		0 281 002 169
Pedal position sensor, diesel			
Fg.no. W1285447→,W7154259→	09.97-08.03	LLE	0 281 002 476
Fg.no. →W1285446,→W5276825, →W7154258	09.97-08.03	LLE	0 205 001 042
		RLE	0 205 001 039
2.0 DTi [B]		2,0 l 74 kW Y 20 DTH 4 Zyl.	
Air mass meter, diesel	09.00-09.03		0 281 002 428
Speed sensor, diesel	09.00-09.03		0 281 002 138
Pressure sensor, intake manifold, diesel	09.00-09.03		0 281 002 438
Temperature sensor, coolant, diesel	09.00-09.03		0 281 002 169
Pedal position sensor, diesel	09.00-09.03	LLE	0 281 002 476
2.0 DTi [C]		2,0 l 74 kW Y 20 DTH 4 Zyl.	
Air mass meter, diesel	09.03-09.05		0 281 002 479
Speed sensor, diesel	09.03-09.05		0 281 002 138
Speed sensor, ignition/injection			
Mot.no. →17G23740	09.03-09.05	FKW	0 281 002 138
Mot.no. 17G23741→	09.03-09.05	FKW	0 281 002 662
Temperature sensor, coolant, diesel	09.03-09.05		0 281 002 473

Product				

2.0 i [B]		2,0 l 82 kW 20 NEJ 4 Zyl.	
Throttle valve sensor	09.95-02.02		0 280 122 001
Air mass meter, gasoline injection	09.95-02.02		0 280 217 106
Knock sensor	09.95-02.02		0 261 231 006
Temperature sensor, intake air, injection system	09.95-02.02		0 280 130 073
Temperature sensor, coolant, injection system	09.95-02.02		0 280 130 107
2.0 i [B]		2,0 l 100 kW C 20 SEL 4 Zyl.	
Throttle valve sensor	05.97-09.02		0 280 122 001
2.0 i 16V [B]		2,0 l 100 kW X 20 XEV 4 Zyl.	
Throttle valve sensor	09.95-09.02		0 280 122 001
2.0 Turbo [C]		2,0 l 129 kW Z 20 NET 4 Zyl.	
Speed sensor, ignition/injection	09.03→	FKW	0 261 210 229
2.2 DTi [B]		2,2 l 92 kW Y 22 DTR 4 Zyl.	
Air mass meter, diesel	09.00-09.03		0 281 002 428
Speed sensor, diesel	09.00-09.03		0 281 002 138
Pressure sensor, intake manifold, diesel	09.00-09.03		0 281 002 438
Temperature sensor, coolant, diesel	09.00-09.03		0 281 002 169
Pedal position sensor, diesel	09.00-09.03	LLE	0 281 002 476
2.2 DTi [C]		2,2 l 86-92 kW Y 22 DTR 4 Zyl.	
Air mass meter, diesel	09.03-09.05		0 281 002 479
Speed sensor, diesel	09.03-09.05		0 281 002 138
Speed sensor, ignition/injection			
Mot.no. →17G23740	09.03-09.05	FKW	0 281 002 138
Mot.no. 17G23741→	09.03-09.05	FKW	0 281 002 662
Temperature sensor, coolant, diesel	09.03-09.05		0 281 002 473
2.5 i V6 [B]		2,5 l 125-143 kW X 25 XE 6 Zyl.	
Throttle valve sensor			
Fg.no. W1000001→,W5000001→, W7000001→,XL000001→	09.97-06.00		0 280 122 014
Fg.no. →V1999999,→V5999999, →V7999999	09.96-06.00		0 280 122 001
Air mass meter, gasoline injection			
Fg.no. W1000001→,W5000001→, W7000001→,XL000001→	09.96-06.00		0 280 217 519
Fg.no. →V1999999,→V5999999, →V7999999	09.96-06.00		0 280 217 503
Knock sensor	09.96-06.00		0 261 231 079
Temperature sensor, intake air, injection system			
Fg.no. W1000001→	09.96-06.00		0 280 130 092
Fg.no. →V7999999	09.96-06.00		0 280 130 073
Temperature sensor, coolant, injection system			
Fg.no. W1000001→,W5000001→, W7000001→,XL000001→	09.96-06.00		0 280 130 093
Fg.no. →V7999999	09.96-06.00		0 280 130 107
2.6 V6 [B]		2,6 l 130 kW Y 26 SE 6 Zyl.	
Air mass meter, gasoline injection	09.00-09.02		0 281 002 184
Phase sensor	09.00-09.02		0 232 103 025
Speed sensor, ignition/injection	09.00-09.02		0 261 210 206
Knock sensor	09.00-09.02		0 261 231 116
Temperature sensor, coolant, injection system	09.00-09.02		0 281 002 169
2.8 Turbo [C]		2,8 l 169/184-188 kW Z 28 NEL; Z 28 NET 6 Zyl.	
Knock sensor	08.05→		0 261 231 174
Pressure sensor, intake manifold, gasoline	08.05→		0 261 230 101
Temperature sensor, coolant, injection system	08.05→		0 280 130 122
3.0 CDTi [C]		3,0 l 130 kW Y 30 DT 6 Zyl.	
Air mass meter, diesel	09.03-08.05		0 281 002 605
3.0 CDTi [C]		3,0 l 135 kW Z 30 DT 6 Zyl.	
Air mass meter, diesel	08.05→		0 281 002 773
3.2 i [C]		3,2 l 155 kW Z 32 SE 6 Zyl.	
Throttle valve assembly	09.03-09.05		0 280 750 119
Air mass meter, gasoline injection	09.03-09.05		0 280 218 087
Phase sensor	09.03-09.05	NOC	0 232 103 025



Speed sensor, ignition/injection	09.03-09.05	FKW	0 261 210 206
Knock sensor	09.03-09.05		0 261 231 116
Temperature sensor, coolant, injection system	09.03-09.05		0 281 002 170

Vivaro

1.9 CDTI	1,9l 60 kW F9Q-762 4 Zyl.
Wheel speed sensor, front	
Fg.no. 7V600001→, 7Y000001→	03.01-10.06 0 265 008 077
1.9 DTI	1,9l 74 kW F9Q-760 4 Zyl.
Wheel speed sensor, front	
Fg.no. 7V600001→, 7Y000001→	03.01-10.06 0 265 008 077
2.0 CDTI	2,0l 66/84 kW M9R-780 4 Zyl.
Wheel speed sensor, front	
Fg.no. 7V600001→, 7Y000001→	08.06→ 0 265 008 077
2.0 16V	2,0l 86-88 kW F4R... 4 Zyl.
Wheel speed sensor, front	
Fg.no. 7V600001→, 7Y000001→	03.01→ 0 265 008 077
2.5 CDTI	2,5l 99/107 kW G9U-630; G9U-730 4 Zyl.
Wheel speed sensor, front	
Fg.no. 7V600001→, 7Y000001→	09.02→ 0 265 008 077

Zafira

1.6 i [A]	1,6l 74 kW X 16 XEL 4 Zyl.
Temperature sensor, coolant, injection system	03.99-08.99 0 281 002 169
1.8 i [A]	1,8l 85 kW X 18 XE 1 4 Zyl.
Steering angle sensor, ESP (electronic stability program)	
Fg.no. →Y2999999, →YH999999	03.99-08.00 0 265 005 433
Pressure sensor, ESP, (electronic stability program)	03.99-08.00 0 265 005 303
1.8 i [A]	1,8l 92 kW Z 18 XE 4 Zyl.
Yaw rate sensor, brake system	09.00-07.05 0 265 005 262
Steering angle sensor, ESP (electronic stability program)	09.00-07.05 0 265 005 435
Pressure sensor, ESP, (electronic stability program)	09.00-07.05 0 265 005 303
1.9 CDTI [B]	1,9l 74/88 kW Z 19 DT; Z 19 DTL 4 Zyl.
Speed sensor, diesel	07.05→ 0 281 002 603
Phase sensor	07.05→ NOC 0 281 002 213
High-pressure sensor (CR system)	07.05→ 0 281 002 706
Boost pressure sensor, Diesel	07.05→ 0 281 002 437
1.9 CDTI [B]	1,9l 110 kW Z 19 DTH 4 Zyl.
High-pressure sensor (CR system)	07.05→ 0 281 002 706
Boost pressure sensor, Diesel	07.05→ 0 281 002 437
2.0 DI [A]	2,0l 60 kW X 20 DTL Turbo 4 Zyl.
Air mass meter, diesel	
Fg.no. →Y8999999, →YT999999	03.99-08.00 0 281 002 180
Fg.no. 12000001→, 1T000001→	03.99-08.00 0 281 002 428
Speed sensor, diesel	03.99-08.00 0 281 002 138
Temperature sensor, coolant, diesel	03.99-08.00 0 281 002 169
Accelerator pedal module	03.99-08.00 LLE 0 281 002 298
	RLE 0 281 002 299
2.0 DTI [A]	2,0l 74 kW Y 20 DTH Turbo 4 Zyl.
Air mass meter, diesel	
Fg.no. →Y2999999, →Y5999999, →Y6999999, →Y8999999, →YH999999	04.99-07.05 0 281 002 180
Fg.no. 12000001→, 22999999, 15000001→, 25999999, 16000001→, 26999999, 18000001→, 28999999, 1H000001→, 2H999999	04.99-07.05 0 281 002 428



Air mass meter, diesel		
Fg.no. 32000001→,35000001→, 36000001→,38000001→,3H000001→, 3H000001→	04.99-07.05	0 281 002 478
Speed sensor, diesel	04.99-07.05	0 281 002 138
Pressure sensor, intake manifold, diesel		
Fg.no. →Y2999999,→Y5999999,→Y6999999, →Y8999999,→YB999999,→YH999999	04.99-07.05	0 281 002 137
Fg.no. 12000001→22999999, 15000001→25999999, 16000001→26999999, 18000001→28999999, 1B000001→2B999999, 1H000001→2H999999	04.99-07.05	0 281 002 438
Fg.no. 32000001→,35000001→, 36000001→,38000001→,3B000001→, 3H000001→	04.99-07.05	0 281 002 437
Temperature sensor, coolant, diesel	04.99-07.05	0 281 002 169
Accelerator pedal module	04.99-07.05	LLE 0 281 002 298
		RLE 0 281 002 299
2.0 i Turbo [B]	2,0l 147 kW	Z 20 LER 4 Zyl.
Air mass meter, gasoline injection	07.05→	0 280 218 142
Phase sensor	07.05→	NOC 0 232 103 015
Speed sensor, ignition/injection	07.05→	FKW 0 261 210 150
Knock sensor	07.05→	0 261 231 181
Pressure sensor, intake manifold, gasoline	07.05→	0 281 002 137
Temperature sensor, coolant, injection system	07.05→	0 281 002 169
2.0 i Turbo [B]	2,0l 177 kW	Z 20 LEH 4 Zyl.
Air mass meter, gasoline injection	01.06→	0 280 218 211
Phase sensor	01.06→	NOC 0 232 103 015
Speed sensor, ignition/injection	01.06→	FKW 0 261 210 150
Knock sensor	01.06→	0 261 231 181
Pressure sensor, intake manifold, gasoline	01.06→	0 281 002 137
Temperature sensor, coolant, injection system	01.06→	0 281 002 169
2.0 Turbo [A]	2,0l 141-147 kW	Z 20 LET 4 Zyl.
Air mass meter, gasoline injection	09.01-07.05	0 280 218 051
		 0 986 280 231
Phase sensor	09.01-07.05	NOC 0 232 103 015
Speed sensor, ignition/injection	09.01-07.05	FKW 0 261 210 150
Pressure sensor, intake manifold, gasoline	09.01-07.05	0 261 230 009
Temperature sensor, coolant, injection system	09.01-07.05	0 281 002 169
Yaw rate sensor, brake system	09.01-07.05	0 265 005 262
Steering angle sensor, ESP (electronic stability program)	09.01-07.05	0 265 005 435
Pressure sensor, ESP, (electronic stability program)	09.01-07.05	0 265 005 303
2.2 [A]	2,2l 108 kW	Z 22 SE 4 Zyl.
Yaw rate sensor, brake system	09.00-07.05	0 265 005 262
Steering angle sensor, ESP (electronic stability program)	09.00-07.05	0 265 005 435
Pressure sensor, ESP, (electronic stability program)	09.00-07.05	0 265 005 303
2.2 DTI [A]	2,2l 92 kW	Y 22 DTR 4 Zyl.
Air flow sensor, diesel	03.02-07.05	0 281 002 478
Speed sensor, diesel	03.02-07.05	FKW 0 281 002 138
Boost pressure sensor, Diesel	03.02-07.05	0 281 002 437
Temperature sensor, coolant, diesel	03.02-07.05	0 281 002 170
Yaw rate sensor, brake system	03.02-07.05	0 265 005 262
Steering angle sensor, ESP (electronic stability program)	03.02-07.05	0 265 005 435
Pressure sensor, ESP, (electronic stability program)	03.02-07.05	0 265 005 303



PEUGEOT				
Boxer				
1.9 D [U3]		1,9l 50/51 kW DJY; D9B 4 Zyl.		
Wheel speed sensor, front				
Fg.no. 15445358→	02.94-04.00			0 265 006 427
Wheel speed sensor, rear				
Fg.no. 15445358→	02.94-02.02	LAB		0 265 006 405
		RAB		0 265 006 406
1.9 D Turbo [U3]		1,9l 66/68 kW DHX; D8C 4 Zyl.		
Wheel speed sensor, front				
Fg.no. 15445358→	02.94-04.00			0 265 006 427
Wheel speed sensor, rear				
Fg.no. 15445358→	02.94-02.02	LAB		0 265 006 405
		RAB		0 265 006 406
2.0 [U3]		2,0l 79 kW R5B 4 Zyl.		
Wheel speed sensor, front				
Fg.no. 15445358→	02.94-04.00			0 265 006 427
Wheel speed sensor, rear				
Fg.no. 15445358→	02.94-02.02	LAB		0 265 006 405
		RAB		0 265 006 406
2.0 HDi [U3]		2,0l 62 kW RHV 4 Zyl.		
High-pressure sensor (CR system)	09.01-02.02			0 281 002 283
Wheel speed sensor, rear				
Fg.no. 15445358→	09.01-02.02	LAB		0 265 006 405
		RAB		0 265 006 406
2.0 HDi [U5]		2,0l 62 kW RHV 4 Zyl.		
High-pressure sensor (CR system)	02.02→			0 281 002 283
Yaw rate sensor, brake system	02.02→			0 265 005 127
2.0 i [U3]		2,0l 80 kW RFW 4 Zyl.		
Wheel speed sensor, front				
Fg.no. 15445358→	02.94-04.00			0 265 006 427
Wheel speed sensor, rear				
Fg.no. 15445358→	02.94-02.02	LAB		0 265 006 405
		RAB		0 265 006 406
2.0 i [U5]		2,0l 80 kW RFL 4 Zyl.		
Yaw rate sensor, brake system	02.02→			0 265 005 127
2.2 HDi [U5]		2,2l 77 kW 4HY 4 Zyl.		
High-pressure sensor (CR system)	02.02→			0 281 002 283
Yaw rate sensor, brake system	02.02→			0 265 005 127
2.5 D [U3]		2,5l 62/63 kW T9A; 8140 67 4 Zyl.		
Wheel speed sensor, front				
Fg.no. 15445358→	02.94-04.00			0 265 006 427
Wheel speed sensor, rear				
Fg.no. 15445358→	02.94-02.02	LAB		0 265 006 405
		RAB		0 265 006 406
2.5 D Turbo [U3]		2,5l 76 kW THZ; T8A 4 Zyl.		
Wheel speed sensor, front				
Fg.no. 15445358→	02.94-04.00			0 265 006 427
Wheel speed sensor, rear				
Fg.no. 15445358→	02.94-02.02	LAB		0 265 006 405
		RAB		0 265 006 406
2.5 TDi [U3]		2,5l 79 kW THX 4 Zyl.		
Wheel speed sensor, front				
Fg.no. 15445358→	10.96-04.00			0 265 006 427
Wheel speed sensor, rear				
Fg.no. 15445358→	10.96-02.02	LAB		0 265 006 405
		RAB		0 265 006 406
2.8 D [U3]		2,8l 64 kW 8140 63 4 Zyl.		
Wheel speed sensor, front				
Fg.no. 15445358→	01.99-04.00			0 265 006 427



Wheel speed sensor, rear				
Fg.no. 15445358→	01.99-02.02	LAB		0 265 006 405
		RAB		0 265 006 406
2.8 D Turbo [U3]		2,8l 90 kW 8140 43 4 Zyl.		
Wheel speed sensor, front				
Fg.no. 15445358→	10.99-04.00			0 265 006 427
Wheel speed sensor, rear				
Fg.no. 15445358→	10.99-02.02	LAB		0 265 006 405
		RAB		0 265 006 406
2.8 D Turbo [U5]		2,8l 90 kW 8140 43 4 Zyl.		
Yaw rate sensor, brake system	02.02→			0 265 005 127
2.8 HDi [U3]		2,8l 94 kW 8140 43s 4 Zyl.		
Wheel speed sensor, rear				
Fg.no. 15445358→	09.00-02.02	LAB		0 265 006 405
		RAB		0 265 006 406
2.8 HDi [U5]		2,8l 94/107 kW 8140 43s 4 Zyl.		
Yaw rate sensor, brake system	02.02→			0 265 005 127
Expert				
1.6 HDi [G9]		1,6l 66 kW 9HU 4 Zyl.		
Yaw rate sensor, brake system	02.07→			0 265 005 606
Wheel speed sensor, front	02.07→			0 265 007 790
Wheel speed sensor, rear	02.07→			0 265 007 791
1.6 i [U64]		1,6l 58 kW 220 A2.000 4 Zyl.		
Temperature sensor, coolant, injection system	09.95→			0 280 130 026
Wheel speed sensor, front				
Org.no. 7481→9050	06.97-08.01			0 265 006 388
Org.no. 9051→	09.01→			0 265 006 730
Wheel speed sensor, rear				
Org.no. 7481→7601	06.97-09.97			0 265 006 426
Org.no. 7602→9050	10.97-08.01			0 265 006 504
Org.no. 9051→	09.01→			0 265 006 731
1.8 i [U64]		1,8l 70 kW L6B 4 Zyl.		
Wheel speed sensor, front				
Org.no. 7481→9050	06.97-08.01			0 265 006 388
Org.no. 9051→	09.01→			0 265 006 730
Wheel speed sensor, rear				
Org.no. 7481→7601	06.97-09.97			0 265 006 426
Org.no. 7602→9050	10.97-08.01			0 265 006 504
Org.no. 9051→	09.01→			0 265 006 731
1.9 D [U64]		1,9l 51 kW D9B 4 Zyl.		
Wheel speed sensor, front				
Org.no. 7481→9050	06.97-08.01			0 265 006 388
Org.no. 9051→	09.01→			0 265 006 730
Wheel speed sensor, rear				
Org.no. 7481→7601	06.97-09.97			0 265 006 426
Org.no. 7602→9050	10.97-08.01			0 265 006 504
Org.no. 9051→	09.01→			0 265 006 731
1.9 D [U64]		1,9l 51 kW WJZ 4 Zyl.		
Wheel speed sensor, front				
	06.98-08.01			0 265 006 388
Wheel speed sensor, rear				
	06.98-08.01			0 265 006 504
1.9 D [U64]		1,9l 52 kW WJY 4 Zyl.		
Wheel speed sensor, front				
	09.01→			0 265 006 730
Wheel speed sensor, rear				
	09.01→			0 265 006 731
1.9 D Turbo [U64]		1,9l 66-68 kW DHX; D8B 4 Zyl.		
Wheel speed sensor, front				
Org.no. 7481→9050	06.97-08.01			0 265 006 388
Org.no. 9051→	09.01→			0 265 006 730
Wheel speed sensor, rear				
Org.no. 7481→7601	06.97-09.97			0 265 006 426
Org.no. 7602→9050	10.97-08.01			0 265 006 504
Org.no. 9051→	09.01→			0 265 006 731



Product



2.0 HDi [G9]		2,0l 88/100 kW RHK; RHR 4 Zyl.
Yaw rate sensor, brake system	02.07→	0 265 005 606
Wheel speed sensor, front	02.07→	0 265 007 790
Wheel speed sensor, rear	02.07→	0 265 007 791
2.0 HDi [U64]		2,0l 70/80 kW RHX; RHZ 4 Zyl.
High-pressure sensor (CR system)	10.99→	BO 0 281 002 283
Wheel speed sensor, front		
Org.no. →9050	10.99-08.01	0 265 006 388
Org.no. 9051→	09.01→	0 265 006 730
Wheel speed sensor, rear		
Org.no. →9050	10.99-08.01	0 265 006 504
Org.no. 9051→	09.01→	0 265 006 731
2.0 HDi [U64]		2,0l 81 kW RHW 4 Zyl.
High-pressure sensor (CR system)	06.00→	0 281 002 283
Wheel speed sensor, front		
Org.no. →9050	06.00-08.01	0 265 006 388
Org.no. 9051→	09.01→	0 265 006 730
Wheel speed sensor, rear		
Org.no. →9050	06.00-08.01	0 265 006 504
Org.no. 9051→	09.01→	0 265 006 731
2.0 i 16V [G9]		2,0l 103 kW RFJ 4 Zyl.
Pressure sensor, intake manifold, gasoline	02.07→	0 261 230 043
Yaw rate sensor, brake system	02.07→	0 265 005 606
Wheel speed sensor, front	02.07→	0 265 007 790
Wheel speed sensor, rear	02.07→	0 265 007 791
2.0 i 16V [U64]		2,0l 100 kW RFN 4 Zyl.
Pressure sensor, intake manifold, gasoline	03.00→	0 261 230 057
Wheel speed sensor, front		
Org.no. →9050	03.00-08.01	0 265 006 388
Org.no. 9051→	09.01→	0 265 006 730
Wheel speed sensor, rear		
Org.no. →9050	03.00-08.01	0 265 006 504
Org.no. 9051→	09.01→	0 265 006 731

Partner

Electrique [M4] 24 kW SA18 0 Zyl.		
Wheel speed sensor, front	01.98-08.02	0 265 006 200
Wheel speed sensor, rear		
Org.no. →8938	01.98-05.01	0 265 006 209
Org.no. 8939→	06.01-08.02	0 265 006 659
1.1 i [M4]		1,1l 44 kW HDY; HDZ 4 Zyl.
Temperature sensor, coolant, injection system	07.96-08.02	0 280 130 084
Wheel speed sensor, front	07.96-08.02	0 265 006 200
Wheel speed sensor, rear		
Org.no. →8938	07.96-05.01	0 265 006 209
Org.no. 8939→	06.01-08.02	0 265 006 659
1.1 i [M4]		1,1l 44 kW HFX 4 Zyl.
Pressure sensor, intake manifold, gasoline	09.00-08.02	0 261 230 043
Wheel speed sensor, front	09.00-08.02	0 265 006 200
Wheel speed sensor, rear		
Org.no. →8938	09.00-05.01	0 265 006 209
Org.no. 8939→	06.01-08.02	0 265 006 659
1.1 i [M5]		1,1l 44 kW HFX 4 Zyl.
Knock sensor	09.02→	0 261 231 128
Pressure sensor, intake manifold, gasoline	09.02→	0 261 230 043
Wheel speed sensor, front		
Org.no. →10220	09.02-11.04	0 265 006 200
Org.no. 10221→	12.04→	0 265 007 666
Wheel speed sensor, rear		
Org.no. →9582	09.02-02.03	0 265 006 659
Org.no. 9583→10220	03.03-11.04	0 265 006 793
Org.no. 10221→	12.04→	0 265 007 668

Product




Wheel speed sensor, rear		
Org.no. 10221→10478	12.04-07.05	RAB 0 265 007 667
Org.no. 10479→	08.05→	RAB 0 265 007 883
1.4 [M4]		1,4l 51-52 kW K5A 4 Zyl.
Wheel speed sensor, front	11.96-08.02	0 265 006 200
Wheel speed sensor, rear		
Org.no. →8938	11.96-05.01	0 265 006 209
Org.no. 8939→	06.01-08.02	0 265 006 659
1.4 i [M4]		1,4l 55 kW KFW 4 Zyl.
Pressure sensor, intake manifold, gasoline	09.00-08.02	0 261 230 043
Wheel speed sensor, front	09.00-08.02	0 265 006 200
Wheel speed sensor, rear		
Org.no. →8938	09.00-05.01	0 265 006 209
Org.no. 8939→	06.01-08.02	0 265 006 659
1.4 i [M4]		1,4l 55 kW KFX 4 Zyl.
Knock sensor	04.98-08.02	N14 0 261 231 128
Pressure sensor, intake manifold, gasoline	07.96-08.02	BGB 0 261 230 057
Org.no. →8056	07.96-12.98	0 261 230 012
Org.no. 8057→	01.99-08.02	0 261 230 057
Wheel speed sensor, front	07.96-08.02	0 265 006 200
Wheel speed sensor, rear		
Org.no. →8938	07.96-05.01	0 265 006 209
Org.no. 8939→	06.01-08.02	0 265 006 659
1.4 i [M4]		1,4l 55 kW K6C 4 Zyl.
Pressure sensor, intake manifold, gasoline		
Org.no. →8056	06.98-12.98	0 261 230 012
Org.no. 8057→	01.99-08.02	0 261 230 057
Wheel speed sensor, front	06.98-08.02	0 265 006 200
Wheel speed sensor, rear		
Org.no. →8938	06.98-05.01	0 265 006 209
Org.no. 8939→	06.01-08.02	0 265 006 659
1.4 i [M5]		1,4l 55 kW KFW 4 Zyl.
Knock sensor	09.02→	0 261 231 128
Pressure sensor, intake manifold, gasoline	09.02→	0 261 230 043
Wheel speed sensor, front		
Org.no. →10220	09.02-11.04	0 265 006 200
Org.no. 10221→	12.04→	0 265 007 666
Wheel speed sensor, rear		
Org.no. →9582	09.02-02.03	0 265 006 659
Org.no. 9583→10220	03.03-11.04	0 265 006 793
Org.no. 10221→	12.04→	LAB 0 265 007 668
Org.no. 10221→10478	12.04-07.05	RAB 0 265 007 667
Org.no. 10479→	08.05→	RAB 0 265 007 883
1.6 HDi [M5]		1,6l 55 kW 9HW 4 Zyl.
Wheel speed sensor, front	09.05→	0 265 007 666
1.6 HDi [M5]		1,6l 66 kW 9HX 4 Zyl.
Yaw rate sensor, brake system	09.05→	0 265 005 290
Wheel speed sensor, front	09.05→	0 265 007 666
Wheel speed sensor, rear	09.05→	LAB 0 265 007 668
		RAB 0 265 007 883
1.6 i 16V [M4]		1,6l 80 kW NFU 4 Zyl.
Throttle valve assembly	09.00-08.02	0 280 750 085
Knock sensor	09.00-08.02	0 261 231 128
Pressure sensor, intake manifold, gasoline	09.00-08.02	0 261 230 043
Wheel speed sensor, front	09.00-08.02	0 265 006 200
Wheel speed sensor, rear		
Org.no. →8938	09.00-05.01	0 265 006 209
Org.no. 8939→	06.01-08.02	0 265 006 659
1.6 i 16V [M5]		1,6l 80 kW NFU 4 Zyl.
Throttle valve assembly	09.02→	0 280 750 085
Knock sensor	09.02→	0 261 231 168
Pressure sensor, intake manifold, gasoline	09.02→	0 261 230 043
Yaw rate sensor, brake system	09.02→	0 265 005 290

Product				
◀ Partner				
Wheel speed sensor, front				
Org.no. →10220	09.02-11.04			0 265 006 200
Org.no. 10221→	12.04→			0 265 007 666
Wheel speed sensor, rear				
Org.no. →9582	09.02-02.03	TBR		0 265 006 659
Org.no. →10220	09.02-11.04	SBR		0 265 006 732
Org.no. 9583→10220	03.03-11.04	TBR		0 265 006 793
Org.no. 10221→	12.04→	LAB		0 265 007 668
Org.no. 10221→10478	12.04-07.05	RAB		0 265 007 667
Org.no. 10479→	08.05→	RAB		0 265 007 883
1.8 D [M4]	1,8 l	43-44 kW	A9A	4 Zyl.
Wheel speed sensor, front	07.96-08.02			0 265 006 200
Wheel speed sensor, rear				
Org.no. →8938	07.96-05.01			0 265 006 209
Org.no. 8939→	06.01-08.02			0 265 006 659
1.8 i	1,8 l	66 kW	XU7JB	4 Zyl.
Temperature sensor, coolant, injection system	10.99→			0 280 130 084
1.8 i [M4]	1,8 l	66 kW	LFX	4 Zyl.
Pressure sensor, intake manifold, gasoline				
Org.no. →8056	03.97-12.98			0 261 230 012
Org.no. 8057→	01.99-08.02			0 261 230 057
Wheel speed sensor, front	03.97-08.02			0 265 006 200
Wheel speed sensor, rear				
Org.no. →8938	03.97-05.01			0 265 006 209
Org.no. 8939→	06.01-08.02			0 265 006 659
1.9 D [M4]	1,9 l	50/51/52 kW	DJY; D9B; WJY; WJZ	4 Zyl.
Wheel speed sensor, front	07.96-08.02			0 265 006 200
Wheel speed sensor, rear				
Org.no. →8938	07.96-05.01			0 265 006 209
Org.no. 8939→	06.01-08.02			0 265 006 659
1.9 D [M5]	1,9 l	52 kW	WJY	4 Zyl.
Wheel speed sensor, front				
Org.no. →10220	09.02-11.04			0 265 006 200
Org.no. 10221→	12.04→			0 265 007 666
Wheel speed sensor, rear				
Org.no. →9582	09.02-02.03			0 265 006 659
Org.no. 9583→10220	03.03-11.04			0 265 006 793
Org.no. 10221→	12.04→	LAB		0 265 007 668
Org.no. 10221→10478	12.04-07.05	RAB		0 265 007 667
Org.no. 10479→	08.05→	RAB		0 265 007 883
2.0 HDi [M4]	2,0 l	66 kW	RHY	4 Zyl.
High-pressure sensor (CR system)	12.99-08.02	BO		0 281 002 283
Wheel speed sensor, front	12.99-08.02			0 265 006 200
Wheel speed sensor, rear				
Org.no. →8938	12.99-05.01			0 265 006 209
Org.no. 8939→	06.01-08.02			0 265 006 659
2.0 HDi [M5]	2,0 l	66 kW	RHY	4 Zyl.
High-pressure sensor (CR system)	09.02→			0 281 002 283
Yaw rate sensor, brake system	09.02→			0 265 005 290
Wheel speed sensor, front				
Org.no. →10220	09.02-11.04			0 265 006 200
Org.no. 10221→	12.04→			0 265 007 666
Wheel speed sensor, rear				
Org.no. →9582	09.02-02.03	TBR		0 265 006 659
Org.no. →10220	09.02-11.04	SBR		0 265 006 732
Org.no. 9583→10220	03.03-11.04	TBR		0 265 006 793
Org.no. 10221→	12.04→	LAB		0 265 007 668
Org.no. 10221→10478	12.04-07.05	RAB		0 265 007 667
Org.no. 10479→	08.05→	RAB		0 265 007 883

Product				
2.0 HDi				
2,0 l 66 kW DW10TD 4 Zyl.				
High-pressure sensor (CR system)	10.00→			0 281 002 283
Wheel speed sensor, front	10.00→	BO,LAB		0 265 006 201
		BO,RAB		0 265 006 200
Wheel speed sensor, rear	10.00→	LIM,SBR		0 265 006 202
Ranch				
1.4 i [M4]				
1,4 l 55 kW KFX 4 Zyl.				
Knock sensor	04.98→	N14		0 261 231 128
Pressure sensor, intake manifold, gasoline	07.97→	BGB		0 261 230 057
Org.no. →8056	07.97-12.98			0 261 230 012
Org.no. 8057→	01.99→			0 261 230 057
Wheel speed sensor, front	07.97→			0 265 006 200
Wheel speed sensor, rear				
Org.no. →8938	07.97-05.01			0 265 006 209
Org.no. 8939→	06.01→			0 265 006 659
1.9 D [M4]				1,9 l 51 kW D9B 4 Zyl.
Wheel speed sensor, front	07.97-10.98			0 265 006 200
Wheel speed sensor, rear	07.97-10.98			0 265 006 209
1.9 D [M4]				1,9 l 51 kW WJZ 4 Zyl.
Wheel speed sensor, front	11.98→			0 265 006 200
Wheel speed sensor, rear				
Org.no. →8938	11.98-05.01			0 265 006 209
Org.no. 8939→	06.01→			0 265 006 659
106				
1.0 i [S1]				
1,0 l 33/37 kW CDY; CDZ 4 Zyl.				
Temperature sensor, coolant, injection system	07.92-04.96			0 280 130 026
1.1 i [S1]				1,1 l 44 kW HDZ 4 Zyl.
Temperature sensor, coolant, injection system	09.91-12.93			0 280 130 026
1.1 i [S2]				1,1 l 44 kW HFX 4 Zyl.
Pressure sensor, intake manifold, gasoline	03.00-05.05			0 261 230 043
1.3 i [S1]				1,3 l 72-74 kW MFZ 4 Zyl.
Knock sensor	10.93-04.96			0 261 231 045
Temperature sensor, coolant, injection system	10.93-04.96			0 280 130 026
1.4 i [S1]				1,4 l 55 kW KDX 4 Zyl.
Temperature sensor, coolant, injection system	12.92-04.96			0 280 130 026
1.4 i [S1]				1,4 l 69/72 kW KFZ; K6B 4 Zyl.
Throttle valve sensor	09.91-04.96			0 280 122 001
Temperature sensor, intake air, injection system	09.91-04.96			0 280 130 039
1.4 i [S2]				1,4 l 55 kW KFW 4 Zyl.
Pressure sensor, intake manifold, gasoline	03.00-05.05			0 261 230 043
1.4 i [S2]				1,4 l 55 kW KFX 4 Zyl.
Knock sensor	05.96-05.05	NL4		0 261 231 128
Pressure sensor, intake manifold, gasoline				
Org.no. →8056	05.96-12.98			0 261 230 012
Org.no. 8057→	01.99-05.05			0 261 230 057
1.6 i [S1]				1,6 l 65-66 kW NFZ 4 Zyl.
Throttle valve sensor	06.93-04.96	AG		0 280 122 011
	06.93-01.95	GS		0 280 122 001
	02.95-04.96	GS		0 280 122 003
Pressure sensor, intake manifold, gasoline	06.93-04.96			0 261 230 004
Temperature sensor, intake air, injection system	06.93-04.96			0 280 130 039
Temperature sensor, coolant, injection system	06.93-04.96			0 280 130 026
1.6 i [S1]				1,6 l 76-77 kW NFY 4 Zyl.
Throttle valve sensor	06.93-04.96			0 280 122 003
Knock sensor	06.93-04.96			0 261 231 045
Pressure sensor, intake manifold, gasoline	06.93-04.96			0 261 230 004
Temperature sensor, intake air, injection system	06.93-04.96			0 280 130 039
Temperature sensor, coolant, injection system	06.93-04.96			0 280 130 026






1.6 i [S2]		1,6 l 65-66 kW NFZ 4 Zyl.	
Throttle valve sensor	05.96-05.05	AG	0 280 122 011
		GS	0 280 122 003
Pressure sensor, intake manifold, gasoline	05.96-05.05		0 261 230 004
Temperature sensor, intake air, injection system	05.96-05.05		0 280 130 039
1.6 i [S2]		1,6 l 74-77 kW NFW; NFY 4 Zyl.	
Throttle valve sensor	05.96-05.05		0 280 122 003
Temperature sensor, intake air, injection system	05.96-05.05		0 280 130 039
1.6 i 16S [S2]		1,6 l 87-88 kW NFX 4 Zyl.	
Pressure sensor, intake manifold, gasoline			
Org.no. →8056	05.96-12.98		0 261 230 012
Org.no. 8057→	01.99-05.05		0 261 230 057

107

1.0 i [B0]		1,0 l 50 kW CFA 3 Zyl.	
Wheel speed sensor, front	06.05→		0 265 007 687
Wheel speed sensor, rear	06.05→		0 265 007 688
1.4 HDi [B0]		1,4 l 40 kW 8HT 4 Zyl.	
Wheel speed sensor, front	06.05→		0 265 007 687
Wheel speed sensor, rear	06.05→		0 265 007 688

205

1.0 i		1,0 l 33-37 kW CDZ,CDY 4 Zyl.	
Temperature sensor, coolant, injection system	07.92-09.98		0 280 130 026
1.1 i		1,1 l 44 kW HDZ, HDY <TU1M> 4 Zyl.	
Temperature sensor, coolant, injection system	07.89-09.98		0 280 130 026
1.4 i		1,4 l 55-58 kW KDX <TU3MC Kat.(Gußmot.)>; KDY/KDZ <TU3M Kat.> 4 Zyl.	
Temperature sensor, coolant, injection system	07.88-09.98		0 280 130 026
1.6 i		1,6 l 65 kW BDY <XU5M Kat.> 4 Zyl.	
Temperature sensor, intake air, injection system	11.90-09.98		0 280 130 039
1.6 i		1,6 l 76 kW 180A,180Z, B6A,B6B 4 Zyl.	
Throttle valve sensor	10.88-10.90		0 280 120 310
Air flow sensor, gasoline injection	10.88-10.90		0 280 202 056
			0 986 280 028
Temperature sensor, coolant, injection system	10.88-10.90		0 280 130 026
Relay, Jetronic	10.88-10.90		0 280 230 006
1.6 i		1,6 l 76 kW 180A,180Z, B6A,B6B 4 Zyl.	
Throttle valve sensor	10.83-10.87		0 280 120 310
Air flow sensor, gasoline injection	10.83-10.87		0 280 202 056
			0 986 280 028
Temperature sensor, coolant, injection system	10.83-10.87		0 280 130 026
Relay, Jetronic	CH,S 10.83-10.87		0 280 230 006
1.6 i		1,6 l 83 kW B6D <XU5JA> 4 Zyl.	
Throttle valve sensor	10.86-10.90		0 280 120 327
Air flow sensor, gasoline injection	10.85-10.90		0 280 202 056
			0 986 280 028
Temperature sensor, coolant, injection system	10.85-10.90		0 280 130 026
Relay, Jetronic	10.85-10.90		0 280 230 006
1.6 i		1,6 l 83 kW B6E <XU5JA> 4 Zyl.	
Throttle valve sensor	11.90-09.98		0 280 120 327
Air flow sensor, gasoline injection	11.90-09.98		0 280 202 056
			0 986 280 028
1.9 i		1,9 l 75 kW DFZ 4 Zyl.	
Throttle valve sensor	10.86-10.94		0 280 120 327
Air flow sensor, gasoline injection	10.86-10.94		0 280 202 097
			0 986 280 070
Temperature sensor, coolant, injection system	10.86-10.94		0 280 130 026
Relay, Jetronic	10.86-10.94		0 280 230 006



1.9 i		1,9 l 88 kW DFY,DKZ <XU9JAZ Kat.> 4 Zyl.	
Throttle valve sensor	10.87-10.94		0 280 120 327
Speed sensor, ignition/injection	10.87-10.94		0 261 210 043
Temperature sensor, coolant, injection system	10.87-10.94		0 280 130 026
1.9 i		1,9 l 90-94 kW D6A; D6B 4 Zyl.	
Throttle valve sensor	10.86-09.98		0 280 120 327
Air flow sensor, gasoline injection	10.86-09.98		0 280 202 109
			0 986 280 013
Temperature sensor, coolant, injection system	10.86-09.98		0 280 130 026
Relay, Jetronic	10.86-09.98		0 280 230 006

206

1.1 i [T1]		1,1 l 44 kW HFX 4 Zyl.	
Pressure sensor, intake manifold, gasoline	03.00→		0 261 230 043
Accelerator pedal module			
Org.no. →9932	03.00-02.04	LLE,PAK	0 280 752 237
1.1 i [T1]		1,1 l 44 kW HFY; HFZ 4 Zyl.	
Pressure sensor, intake manifold, gasoline			
Org.no. →8028	06.98-11.98		0 261 230 012
Org.no. 8029→	12.98→		0 261 230 057
Accelerator pedal module			
Org.no. →9932	06.98-02.04	LLE,PAK	0 280 752 237
1.4 HDi [T1]		1,4 l 50 kW 8HX/8HZ 4 Zyl.	
High-pressure sensor (CR system)	09.01→		0 281 002 283
Accelerator pedal module			
Org.no. →9932	09.01-02.04	LLE,PAK	0 280 752 237
1.4 i		1,4 l 55 kW TU3JP 4 Zyl.	
Pressure sensor, intake manifold, gasoline	02.04-12.05		0 261 230 043
1.4 i [T1]		1,4 l 55 kW KFW 4 Zyl.	
Pressure sensor, intake manifold, gasoline	03.00→		0 261 230 043
Accelerator pedal module			
Org.no. →9932	03.00-02.04	LLE,PAK	0 280 752 237
1.4 i [T1]		1,4 l 55 kW KFX 4 Zyl.	
Knock sensor	06.98→	IF4	0 261 231 128
Pressure sensor, intake manifold, gasoline			
Org.no. →8028	06.98-11.98		0 261 230 012
Org.no. 8029→	12.98→		0 261 230 057
Accelerator pedal module			
Org.no. →9932	06.98-02.04	LLE,PAK	0 280 752 237
1.4 i [T1]		1,4 l 55 kW K6C/K6D 4 Zyl.	
Pressure sensor, intake manifold, gasoline			
Org.no. →8028	06.98-11.98		0 261 230 012
Org.no. 8029→	12.98→		0 261 230 057
Accelerator pedal module			
Org.no. →9932	06.98-02.04	LLE,PAK	0 280 752 237
1.4 i 16V [T1]		1,4 l 65 kW KFU 4 Zyl.	
Knock sensor	10.03→		0 261 231 168
Pressure sensor, intake manifold, gasoline	10.03→		0 261 230 043
Accelerator pedal module			
Org.no. →9932	10.03-02.04	LLE,PAK	0 280 752 237
1.6 i		1,6 l 65 kW NFZ 4 Zyl.	
Pressure sensor, intake manifold, gasoline	10.99-10.03		0 261 230 034
1.6 i [T1]		1,6 l 66 kW NFZ 4 Zyl.	
Knock sensor	06.98→		0 261 231 128
Pressure sensor, intake manifold, gasoline			
Org.no. →8028	06.98-11.98		0 261 230 012
Org.no. 8029→	12.98→		0 261 230 057
Accelerator pedal module			
Org.no. →9932	06.98-02.04	LLE,PAK	0 280 752 237



Product

◀ 206

1.6 i 16V		1,6 l 79 kW TU5JP4 4 Zyl.	
Throttle valve assembly	06.01-04.05	0 280 750 085	
Pressure sensor, intake manifold, gasoline	06.01-04.05	0 261 230 043	
Accelerator pedal module	06.01-04.05	0 280 755 026	
1.6 i 16V [T1]		1,6 l 80 kW NFU 4 Zyl.	
Throttle valve assembly	03.00→	0 280 750 085	
Knock sensor			
Org.no. 9457→	10.02→	0 261 231 168	
Pressure sensor, intake manifold, gasoline	03.00→	0 261 230 043	
Accelerator pedal module			
Org.no. →9932	03.00-02.04 LLE,PAK	0 280 752 237	
1.9 D [T1]		1,9 l 51/52 kW WJY; WJZ 4 Zyl.	
Accelerator pedal module			
Org.no. →9932	06.98-02.04 LLE,PAK	0 280 752 237	
2.0 HDi [T1]		2,0 l 66 kW RHY 4 Zyl.	
High-pressure sensor (CR system)	05.99→	BO 0 281 002 283	
Accelerator pedal module			
Org.no. →9932	04.99-02.04 LLE,PAK	0 280 752 237	
2.0 i RC [T1]		2,0 l 130 kW RFK 4 Zyl.	
Pressure sensor, intake manifold, gasoline	03.03→	0 261 230 043	
Accelerator pedal module			
Org.no. →9932	03.03-02.04 LLE,PAK	0 280 752 237	
2.0 i S16 [T1]		2,0 l 99 kW RFR 4 Zyl.	
Pressure sensor, intake manifold, gasoline	01.99-09.00	0 261 230 034	
Accelerator pedal module	01.99-09.00 LLE,PAK	0 280 752 237	
2.0 i S16 [T1]		2,0 l 100 kW RFN 4 Zyl.	
Pressure sensor, intake manifold, gasoline	10.00→	0 261 230 034	
Accelerator pedal module			
Org.no. →9932	10.00-02.04 LLE,PAK	0 280 752 237	

206 CC

1.6 i 16V [T1]		1,6 l 80 kW NFU 4 Zyl.	
Throttle valve assembly	09.00→	0 280 750 085	
Knock sensor			
Org.no. 9457→	10.02→	0 261 231 168	
Pressure sensor, intake manifold, gasoline	09.00→	0 261 230 043	
Accelerator pedal module			
Org.no. →9932	09.00-02.04 LLE,PAK	0 280 752 237	
2.0 i S16 [T1]		2,0 l 100 kW RFN 4 Zyl.	
Pressure sensor, intake manifold, gasoline	09.00→	0 261 230 034	
Accelerator pedal module			
Org.no. →9932	09.00-02.04 LLE,PAK	0 280 752 237	

206 SW

1.1 i [T1]		1,1 l 44 kW HFX 4 Zyl.	
Pressure sensor, intake manifold, gasoline	03.02→	0 261 230 043	
Accelerator pedal module			
Org.no. →9932	03.02-02.04 LLE,PAK	0 280 752 237	
1.4 HDi [T1]		1,4 l 50 kW 8HX 4 Zyl.	
High-pressure sensor (CR system)	03.02→	0 281 002 283	
Accelerator pedal module			
Org.no. →9932	03.02-02.04 LLE,PAK	0 280 752 237	
1.4 i [T1]		1,4 l 55 kW KFW 4 Zyl.	
Pressure sensor, intake manifold, gasoline	03.02→	0 261 230 043	
Accelerator pedal module			
Org.no. →9932	03.02-02.04 LLE,PAK	0 280 752 237	
1.4 i 16V [T1]		1,4 l 65 kW KFU 4 Zyl.	
Knock sensor	10.03→	0 261 231 168	
Pressure sensor, intake manifold, gasoline	10.03→	0 261 230 043	
Accelerator pedal module			
Org.no. →9932	10.03-02.04 LLE,PAK	0 280 752 237	

Product

1.6 i 16V		1,6 l 79 kW N6A 4 Zyl.	
Throttle valve assembly	03.04-04.05	0 280 750 085	
Pressure sensor, intake manifold, gasoline	03.04-04.05	0 261 230 043	
1.6 i 16V [T1]		1,6 l 80 kW NFU 4 Zyl.	
Throttle valve assembly	03.02→	0 280 750 085	
Knock sensor			
Org.no. 9457→	10.02→	0 261 231 168	
Pressure sensor, intake manifold, gasoline	03.02→	0 261 230 043	
Accelerator pedal module			
Org.no. →9932	03.02-02.04 LLE,PAK	0 280 752 237	
2.0 HDi [T1]		2,0 l 66 kW RHY 4 Zyl.	
High-pressure sensor (CR system)	03.02→	0 281 002 283	
Accelerator pedal module			
Org.no. →9932	03.02-02.04 LLE,PAK	0 280 752 237	
2.0 i S16 [T1]		2,0 l 100 kW RFN 4 Zyl.	
Pressure sensor, intake manifold, gasoline	03.02→	0 261 230 034	
Accelerator pedal module			
Org.no. →9932	03.02-02.04 LLE,PAK	0 280 752 237	

207

1.4 HDi [A7]		1,4 l 50 kW 8HZ 4 Zyl.	
Wheel speed sensor, rear	05.06→	0 265 007 707	
1.4 i [A7]		1,4 l 54 kW KFU 4 Zyl.	
Knock sensor	05.06→	0 261 231 168	
Pressure sensor, intake manifold, gasoline	05.06→	0 261 230 043	
Wheel speed sensor, rear	05.06→	0 265 007 707	
1.4 i [A7]		1,4 l 70 kW 8FS 4 Zyl.	
Phase sensor	06.07→	0 232 103 064	
Pressure sensor, intake manifold, gasoline	06.07→	0 261 230 136	
Wheel speed sensor, rear	06.07→	0 265 007 707	
1.4 i 16V [A7]		1,4 l 65 kW KFU 4 Zyl.	
Knock sensor	05.06→	0 261 231 168	
Pressure sensor, intake manifold, gasoline	05.06→	0 261 230 043	
Wheel speed sensor, rear	05.06→	0 265 007 707	
1.6 HDi [A7]		1,6 l 66/80 kW 9HV; 9HX; 9HZ / 9HY 4 Zyl.	
Wheel speed sensor, rear	05.06→	0 265 007 707	
1.6 i [A7]		1,6 l 80 kW NFU 4 Zyl.	
Knock sensor	05.06→	0 261 231 168	
Pressure sensor, intake manifold, gasoline	05.06→	0 261 230 043	
Wheel speed sensor, rear	05.06→	0 265 007 707	
1.6 i [A7]		1,6 l 88 kW 5FW 4 Zyl.	
Phase sensor	03.07→	0 232 103 064	
Pressure sensor, intake manifold, gasoline	03.07→	0 261 230 136	
Wheel speed sensor, rear	03.07→	0 265 007 707	
1.6 i [A7]		1,6 l 110 kW 5FX 4 Zyl.	
Phase sensor			
Org.no. 10958→	11.06→	0 232 103 064	
Knock sensor	07.06→	0 261 231 197	
Pressure sensor, intake manifold, gasoline	07.06→	0 261 230 135	
Temperature sensor, intake air, injection system	07.06→	0 261 230 134	
Wheel speed sensor, rear	07.06→	0 265 007 707	
1.6 i RC [A7]		1,6 l 128 kW 5FY 4 Zyl.	
Phase sensor	04.07→	0 232 103 064	
Knock sensor	04.07→	0 261 231 197	
Pressure sensor, intake manifold, gasoline	04.07→	0 261 230 135	
Temperature sensor, intake air, injection system	04.07→	0 261 230 134	
Wheel speed sensor, rear	04.07→	0 265 007 707	



Product



207 CC

1.6 HDi [A7] 1,6 l 80 kW 9HZ 4 Zyl.		
Wheel speed sensor, rear	03.07→	0 265 007 707
1.6 i [A7] 1,6 l 88 kW 5FW 4 Zyl.		
Phase sensor	03.07→	0 232 103 064
Pressure sensor, intake manifold, gasoline	03.07→	0 261 230 136
Wheel speed sensor, rear	03.07→	0 265 007 707
1.6 i [A7] 1,6 l 110 kW 5FX 4 Zyl.		
Phase sensor	03.07→	0 232 103 064
Knock sensor	03.07→	0 261 231 197
Pressure sensor, intake manifold, gasoline	03.07→	0 261 230 135
Temperature sensor, intake air, injection system	03.07→	0 261 230 134
Wheel speed sensor, rear	03.07→	0 265 007 707

207 SW

1.4 i [A7] 1,4 l 54 kW KfV 4 Zyl.		
Knock sensor	06.07→	0 261 231 168
Pressure sensor, intake manifold, gasoline	06.07→	0 261 230 043
Wheel speed sensor, rear	06.07→	0 265 007 707
1.4 i [A7] 1,4 l 70 kW 8FS 4 Zyl.		
Phase sensor	06.07→	0 232 103 064
Pressure sensor, intake manifold, gasoline	06.07→	0 261 230 136
Wheel speed sensor, rear	06.07→	0 265 007 707
1.6 HDi [A7] 1,6 l 66/80 kW 9HV; 9HX; 9HZ/ 9HY 4 Zyl.		
Wheel speed sensor, rear	06.07→	0 265 007 707
1.6 i [A7] 1,6 l 88 kW 5FW 4 Zyl.		
Phase sensor	06.07→	0 232 103 064
Pressure sensor, intake manifold, gasoline	06.07→	0 261 230 136
Wheel speed sensor, rear	06.07→	0 265 007 707

305

1.9 i 1,9 l 72 kW DFZ <XU9J1 Kat.> 4 Zyl.		
Throttle valve sensor	10.82-08.87	0 280 120 310
Air flow sensor, gasoline injection	10.82-07.90	0 280 202 097
		0 986 280 070
Temperature sensor, coolant, injection system	01.86-07.90	0 280 130 026
Relay, Jetronic	01.86-07.90	0 280 230 006

306

1.1 i [N3] 1,1 l 40/44 kW HDY; HDZ 4 Zyl.		
Temperature sensor, coolant, injection system	01.93-12.95	BO 0 280 130 026
Wheel speed sensor, front	01.93-04.97	BO,LAB 0 265 006 201
		BO,RAB 0 265 006 200
Wheel speed sensor, rear	10.95-04.97	BO,LWG 0 265 006 204
		BO,NLW 0 265 006 203
	01.93-09.95	BO,TBR 0 265 006 204
1.4 [N3] 1,4 l 44 kW K3A 4 Zyl.		
Wheel speed sensor, front	01.93-04.97	BO,LAB 0 265 006 201
		BO,RAB 0 265 006 200
Wheel speed sensor, rear	10.95-04.97	BO,NLW 0 265 006 203
	01.93-09.95	BO,TBR 0 265 006 204
1.4 [N3] 1,4 l 55 kW K2D 4 Zyl.		
Wheel speed sensor, front	01.93-05.96	BO,LAB 0 265 006 201
		BO,RAB 0 265 006 200
Wheel speed sensor, rear	10.95-05.96	BO,LWG 0 265 006 204
		BO,NLW 0 265 006 203
	01.93-09.95	BO,TBR 0 265 006 204

Product



1.4 [N3] 1,4 l 55 kW K5A 4 Zyl.		
Wheel speed sensor, front	06.96-04.97	BO,LAB 0 265 006 201
		BO,RAB 0 265 006 200
Wheel speed sensor, rear	06.96-04.97	BO,LWG 0 265 006 204
		BO,NLW 0 265 006 203
1.4 [N5] 1,4 l 55 kW K5A 4 Zyl.		
Wheel speed sensor, front	05.97-10.03	LAB 0 265 006 201
		RAB 0 265 006 200
Wheel speed sensor, rear	05.97-10.03	STB 0 265 006 203
1.4 i [N3] 1,4 l 55 kW KDX 4 Zyl.		
Temperature sensor, coolant, injection system	01.93-04.97	BO 0 280 130 026
Wheel speed sensor, front	01.93-04.97	BO,LAB 0 265 006 201
		BO,RAB 0 265 006 200
Wheel speed sensor, rear	10.95-04.97	BO,LWG 0 265 006 204
		BO,NLW 0 265 006 203
	01.93-09.95	BO,TBR 0 265 006 204
1.4 i [N3] 1,4 l 55 kW KFX 4 Zyl.		
Pressure sensor, intake manifold, gasoline	09.96-04.97	0 261 230 012
Wheel speed sensor, front	09.96-04.97	BO,LAB 0 265 006 201
		BO,RAB 0 265 006 200
Wheel speed sensor, rear	09.96-04.97	BO,LWG 0 265 006 204
		BO,NLW 0 265 006 203
1.4 i [N5] 1,4 l 55 kW KFW 4 Zyl.		
Pressure sensor, intake manifold, gasoline	10.00-10.03	0 261 230 043
Wheel speed sensor, front	10.00-10.03	LAB 0 265 006 201
		RAB 0 265 006 200
Wheel speed sensor, rear	10.00-10.03	LIM,STB 0 265 006 203
		LWG,STB 0 265 006 441
1.4 i [N5] 1,4 l 55 kW KFX 4 Zyl.		
Knock sensor	05.97-10.03	IF4 0 261 231 128
Pressure sensor, intake manifold, gasoline		
Org.no. →8056	05.97-12.98	0 261 230 012
Org.no. 8057→	01.99-10.03	0 261 230 057
Temperature sensor, coolant, injection system	05.97-10.03	BO 0 280 130 084
Wheel speed sensor, front	05.97-10.03	LAB 0 265 006 201
		RAB 0 265 006 200
Wheel speed sensor, rear	05.97-10.03	LIM,STB 0 265 006 203
		LWG,STB 0 265 006 441
1.4 i [N5] 1,4 l 55 kW K6C 4 Zyl.		
Pressure sensor, intake manifold, gasoline	05.97-10.03	0 261 230 043
Org.no. →8056	05.97-12.98	0 261 230 012
Org.no. 8057→	01.99-10.03	0 261 230 057
Wheel speed sensor, front	05.97-10.03	LAB 0 265 006 201
		RAB 0 265 006 200
Wheel speed sensor, rear	05.97-10.03	LIM,STB 0 265 006 203
		LWG,STB 0 265 006 441
1.4 i [N5] 1,4 l 55 kW K6D 4 Zyl.		
Pressure sensor, intake manifold, gasoline	05.97-10.03	0 261 230 043
Wheel speed sensor, front	05.97-10.03	LAB 0 265 006 201
		RAB 0 265 006 200
Wheel speed sensor, rear	05.97-10.03	LIM,STB 0 265 006 203
		LWG,STB 0 265 006 441
1.6 i [N3] 1,6 l 65-66 kW NFZ 4 Zyl.		
Throttle valve sensor	01.93-04.97	0 280 122 001
Pressure sensor, intake manifold, gasoline	01.93-04.97	0 261 230 004
Temperature sensor, intake air, injection system	01.93-04.97	0 280 130 039
Temperature sensor, coolant, injection system	01.93-04.97	BO 0 280 130 026
Wheel speed sensor, front	01.93-04.97	BO,LAB 0 265 006 201
		BO,RAB 0 265 006 200
Wheel speed sensor, rear	10.95-04.97	BO,NLW 0 265 006 203
	01.93-09.95	BO,TBR 0 265 006 204

Product				
◀ 306				
1.6 i [N5]	1,6l 65-66 kW NFZ 4 Zyl.			
Throttle valve sensor				
Org.no. →7874	05.97-06.98			0 280 122 003
Knock sensor				
Org.no. 7875→	03.98-10.03			0 261 231 128
Pressure sensor, intake manifold, gasoline				
Org.no. →7874	05.97-05.98			0 261 230 004
Org.no. 7875→8119	06.98-02.99			0 261 230 012
Org.no. 8120→	03.99-10.03			0 261 230 057
Temperature sensor, intake air, injection system				
Org.no. →7874	05.97-05.98			0 280 130 039
Temperature sensor, coolant, injection system	05.97-10.03	BO		0 280 130 084
Wheel speed sensor, front	05.97-10.03	LAB		0 265 006 201
		RAB		0 265 006 200
Wheel speed sensor, rear	05.97-10.03	STB		0 265 006 203
1.6 i [N5]	1,6l 74 kW NFT 4 Zyl.			
Knock sensor	10.00-10.03			0 261 231 128
Pressure sensor, intake manifold, gasoline	10.00-10.03			0 261 230 043
Wheel speed sensor, front	10.00-10.03	LAB		0 265 006 201
		RAB		0 265 006 200
Wheel speed sensor, rear	10.00-10.03	STB		0 265 006 203
1.8 D [N3]	1,8l 44 kW A9A; 161A 4 Zyl.			
Wheel speed sensor, front	05.93-04.97	BO,LAB		0 265 006 201
		BO,RAB		0 265 006 200
Wheel speed sensor, rear	10.95-04.97	BO,LWG		0 265 006 204
		BO,NLW		0 265 006 203
	05.93-09.95	BO,TBR		0 265 006 204
1.8 D [N5]	1,8l 44 kW A9A,161A 4 Zyl.			
Wheel speed sensor, front	05.97-10.03	LAB		0 265 006 201
		RAB		0 265 006 200
Wheel speed sensor, rear	05.97-10.03	LIM,STB		0 265 006 203
		LWG,STB		0 265 006 441
1.8 i	1,8l 74 kW XU7JP 4 Zyl.			
Temperature sensor, coolant, injection system	03.97→			0 280 130 068
1.8 i [N3]	1,8l 74-76 kW LFZ; L6A 4 Zyl.			
Wheel speed sensor, front	01.93-04.97	BO,LAB		0 265 006 201
		BO,RAB		0 265 006 200
Wheel speed sensor, rear	10.95-04.97	BO,NLW		0 265 006 203
	01.93-09.95	BO,TBR		0 265 006 204
1.8 i [N5]	1,8l 74-76 kW LFZ; L6A 4 Zyl.			
Wheel speed sensor, front	05.97-10.03	LAB		0 265 006 201
		RAB		0 265 006 200
Wheel speed sensor, rear	05.97-10.03	STB		0 265 006 203
1.8 i 16V	1,8l 86 kW XU7JP4 4 Zyl.			
Temperature sensor, coolant, injection system	10.99→			0 280 130 084
Wheel speed sensor, front	10.99→			0 265 006 203
				0 265 006 389
		BO,LAB		0 265 006 201
		BO,RAB		0 265 006 200
Wheel speed sensor, rear	10.99→			0 265 006 209
1.8 i 16V [N5]	1,8l 81 kW LFY 4 Zyl.			
Throttle valve sensor	05.97-10.03			0 280 122 003
Pressure sensor, intake manifold, gasoline				
Org.no. →8035	05.97-11.98			0 261 230 012
Org.no. 8036→	12.98-10.03			0 261 230 034
Wheel speed sensor, front	05.97-10.03	LAB		0 265 006 201
		RAB		0 265 006 200
Wheel speed sensor, rear	05.97-10.03	4SB		0 265 006 202
1.9 D [N3]	1,9l 47-48 kW DJZ 4 Zyl.			
Wheel speed sensor, front	05.93-06.94	BO,LAB		0 265 006 201
		BO,RAB		0 265 006 200
Wheel speed sensor, rear	05.93-06.94	BO,TBR		0 265 006 204

Product				
1.9 D [N3]	1,9l 50/51 kW DJY; D9B 4 Zyl.			
Wheel speed sensor, front	05.93-04.97	BO,LAB		0 265 006 201
		BO,RAB		0 265 006 200
Wheel speed sensor, rear	10.95-04.97	BO,LWG		0 265 006 204
		BO,NLW		0 265 006 203
	05.93-09.95	BO,TBR		0 265 006 204
1.9 D [N5]	1,9l 50 kW DJY 4 Zyl.			
Wheel speed sensor, front	05.97-10.03	LAB		0 265 006 201
		RAB		0 265 006 200
Wheel speed sensor, rear	05.97-10.03	LIM,STB		0 265 006 203
		LWG,STB		0 265 006 441
1.9 D [N5]	1,9l 51 kW D9B 4 Zyl.			
Wheel speed sensor, front	05.97-10.03	LAB		0 265 006 201
		RAB		0 265 006 200
Wheel speed sensor, rear	05.97-10.03	STB		0 265 006 203
1.9 D [N5]	1,9l 51/52 kW WJY; WJZ 4 Zyl.			
Wheel speed sensor, front	09.98-10.03	LAB		0 265 006 201
		RAB		0 265 006 200
Wheel speed sensor, rear	09.98-10.03	LIM,STB		0 265 006 203
		LWG,STB		0 265 006 441
1.9 D Turbo [N3]	1,9l 66-67/68 kW DHY; D8A 4 Zyl.			
Wheel speed sensor, front	05.93-04.97	BO,LAB		0 265 006 201
		BO,RAB		0 265 006 200
Wheel speed sensor, rear	10.95-04.97	BO,NLW		0 265 006 203
	05.93-09.95	BO,TBR		0 265 006 204
1.9 D Turbo [N5]	1,9l 55/66 kW DHW; DHY 4 Zyl.			
Wheel speed sensor, front	05.97-10.03	LAB		0 265 006 201
		RAB		0 265 006 200
Wheel speed sensor, rear	05.97-10.03	STB		0 265 006 203
2.0 HDi [N5]	2,0l 66 kW RHY 4 Zyl.			
High-pressure sensor (CR system)	06.99-10.03	BO		0 281 002 283
Wheel speed sensor, front	06.99-10.03	LAB		0 265 006 201
		RAB		0 265 006 200
Wheel speed sensor, rear	06.99-10.03	4SB		0 265 006 202
2.0 HDi	2,0l 66 kW 4 Zyl.			
High-pressure sensor (CR system)	12.00→			0 281 002 283
Wheel speed sensor, front	12.00→	BO,LAB		0 265 006 201
		BO,RAB		0 265 006 200
Wheel speed sensor, rear	12.00→	LIM,SBR		0 265 006 202
2.0 i [N3]	2,0l 89-90 kW RFX; R6D 4 Zyl.			
Knock sensor	08.93-04.97			0 261 231 071
Wheel speed sensor, front	08.93-04.97	BO,LAB		0 265 006 201
		BO,RAB		0 265 006 200
Wheel speed sensor, rear	08.93-04.97			0 265 006 202
2.0 i 16V [N3]	2,0l 110-114 kW RFT; RFY 4 Zyl.			
Throttle valve sensor	08.93-06.95			0 280 122 001
	07.95-04.97			0 280 122 003
Knock sensor	08.93-04.97			0 261 231 071
Wheel speed sensor, front	08.93-04.97	BO,LAB		0 265 006 201
		BO,RAB		0 265 006 200
Wheel speed sensor, rear	08.93-04.97			0 265 006 202
2.0 i 16V [N3]	2,0l 120 kW RFS 4 Zyl.			
Throttle valve sensor	07.96-04.97			0 280 122 009
Pressure sensor, intake manifold, gasoline	07.96-04.97			0 261 230 012
Wheel speed sensor, front	07.96-04.97	BO,LAB		0 265 006 201
		BO,RAB		0 265 006 200
Wheel speed sensor, rear	07.96-04.97			0 265 006 202
2.0 i 16V [N5]	2,0l 97-99 kW RFV 4 Zyl.			
Throttle valve sensor	05.97-10.03	GS		0 280 122 003
Org.no. →7902	05.97-10.03	AG		0 280 122 003
Org.no. 7903→	07.98-10.03	AG		0 280 122 005





Product			
Knock sensor			
Org.no. →8133	05.97-02.99		0 261 231 109
Org.no. 8134→	03.99-10.03		0 261 231 130
Pressure sensor, intake manifold, gasoline			
Org.no. →8056	05.97-12.98		0 261 230 012
Org.no. 8057→	01.99-10.03		0 261 230 057
Wheel speed sensor, front	05.97-10.03	LAB	0 265 006 201
		RAB	0 265 006 200
Wheel speed sensor, rear	05.97-10.03	4SB	0 265 006 202
2.0 i 16V [N5]			2,0l 97-99 kW R6E 4 Zyl.
Throttle valve sensor	05.97-10.03		0 280 122 003
Knock sensor			
Org.no. →8133	05.97-02.99		0 261 231 109
Org.no. 8134→	03.99-10.03		0 261 231 130
Pressure sensor, intake manifold, gasoline			
Org.no. →8056	05.97-12.98		0 261 230 012
Org.no. 8057→	01.99-10.03		0 261 230 057
Wheel speed sensor, front	05.97-10.03	LAB	0 265 006 201
		RAB	0 265 006 200
Wheel speed sensor, rear	05.97-10.03	4SB	0 265 006 202
2.0 i 16V [N5]			2,0l 120 kW RFS 4 Zyl.
Throttle valve sensor	05.97-10.03		0 280 122 009
Pressure sensor, intake manifold, gasoline			
Org.no. →8056	05.97-12.98		0 261 230 012
Org.no. 8057→	01.99-10.03		0 261 230 057
Wheel speed sensor, front	05.97-10.03	LAB	0 265 006 201
		RAB	0 265 006 200
Wheel speed sensor, rear	05.97-10.03	4SB	0 265 006 202

306 Break

1.4 [N5]			1,4l 55 kW K5A 4 Zyl.
Wheel speed sensor, front	05.97-03.02	LAB	0 265 006 201
		RAB	0 265 006 200
Wheel speed sensor, rear	05.97-03.02	STB	0 265 006 441
1.4 i [N5]			1,4l 55 kW KFW 4 Zyl.
Pressure sensor, intake manifold, gasoline	10.00-03.02		0 261 230 043
Wheel speed sensor, front	10.00-03.02	LAB	0 265 006 201
		RAB	0 265 006 200
Wheel speed sensor, rear	10.00-03.02	STB	0 265 006 441
1.4 i [N5]			1,4l 55 kW KFX 4 Zyl.
Knock sensor	05.97-03.02	IF4	0 261 231 128
Pressure sensor, intake manifold, gasoline			
Org.no. →8056	05.97-12.98		0 261 230 012
Org.no. 8057→	01.99-03.02		0 261 230 057
Temperature sensor, coolant, injection system	05.97-03.02	BO	0 280 130 084
Wheel speed sensor, front	05.97-03.02	LAB	0 265 006 201
		RAB	0 265 006 200
Wheel speed sensor, rear	05.97-03.02	STB	0 265 006 441
1.4 i [N5]			1,4l 55 kW K6C 4 Zyl.
Pressure sensor, intake manifold, gasoline	05.97-03.02		0 261 230 043
Org.no. →8056	05.97-12.98		0 261 230 012
Org.no. 8057→	01.99-03.02		0 261 230 057
Wheel speed sensor, front	05.97-03.02	LAB	0 265 006 201
		RAB	0 265 006 200
Wheel speed sensor, rear	05.97-03.02	STB	0 265 006 441
1.4 i [N5]			1,4l 55 kW K6D 4 Zyl.
Pressure sensor, intake manifold, gasoline	05.97-03.02		0 261 230 043
Wheel speed sensor, front	05.97-03.02	LAB	0 265 006 201
		RAB	0 265 006 200
Wheel speed sensor, rear	05.97-03.02	STB	0 265 006 441



1.6 i [N5]			1,6l 65-66 kW NFZ 4 Zyl.
Throttle valve sensor			
Org.no. →7874	05.97-06.98		0 280 122 003
Knock sensor			
Org.no. 7875→	03.98-10.00		0 261 231 128
Pressure sensor, intake manifold, gasoline			
Org.no. →7874	05.97-05.98		0 261 230 004
Org.no. 7875→8119	06.98-02.99		0 261 230 012
Org.no. 8120→	03.99-10.00		0 261 230 057
Temperature sensor, intake air, injection system			
Org.no. →7874	05.97-05.98		0 280 130 039
Temperature sensor, coolant, injection system	05.97-10.00	BO	0 280 130 084
Wheel speed sensor, front	05.97-10.00	LAB	0 265 006 201
		RAB	0 265 006 200
Wheel speed sensor, rear	05.97-10.00	STB	0 265 006 441
1.6 i [N5]			1,6l 74 kW NFT 4 Zyl.
Knock sensor	10.00-03.02		0 261 231 128
Pressure sensor, intake manifold, gasoline	10.00-03.02		0 261 230 043
Wheel speed sensor, front	10.00-03.02	LAB	0 265 006 201
		RAB	0 265 006 200
Wheel speed sensor, rear	10.00-03.02	STB	0 265 006 441
1.8 i [N5]			1,8l 74-76 kW LFZ; L6A 4 Zyl.
Wheel speed sensor, front	05.97-03.02	LAB	0 265 006 201
		RAB	0 265 006 200
Wheel speed sensor, rear	05.97-03.02	STB	0 265 006 441
1.8 i 16V [N5]			1,8l 81 kW LFY 4 Zyl.
Throttle valve sensor	05.97-03.02		0 280 122 003
Pressure sensor, intake manifold, gasoline			
Org.no. →8035	05.97-11.98		0 261 230 012
Org.no. 8036→	12.98-03.02		0 261 230 034
Wheel speed sensor, front	05.97-03.02	LAB	0 265 006 201
		RAB	0 265 006 200
Wheel speed sensor, rear	05.97-03.02	4SB	0 265 006 202
1.9 D [N5]			1,9l 50/51/52 kW DJY; D9B; WJY; WJZ 4 Zyl.
Wheel speed sensor, front	05.97-03.02	LAB	0 265 006 201
		RAB	0 265 006 200
Wheel speed sensor, rear	05.97-03.02	STB	0 265 006 441
1.9 D Turbo [N5]			1,9l 55/66 kW DHV; DHY 4 Zyl.
Wheel speed sensor, front	05.97-03.02	LAB	0 265 006 201
		RAB	0 265 006 200
Wheel speed sensor, rear	05.97-03.02	STB	0 265 006 441
2.0 HDi [N5]			2,0l 66 kW RHY 4 Zyl.
High-pressure sensor (CR system)	06.99-03.02	BO	0 281 002 283
Wheel speed sensor, front	06.99-03.02	LAB	0 265 006 201
		RAB	0 265 006 200
Wheel speed sensor, rear	06.99-03.02	4SB	0 265 006 202
2.0 i 16V [N5]			2,0l 97-99 kW RFV 4 Zyl.
Throttle valve sensor	05.97-03.02	GS	0 280 122 003
Org.no. →7902	05.97-03.02	AG	0 280 122 003
Org.no. 7903→	07.98-03.02	AG	0 280 122 005
Knock sensor			
Org.no. →8133	05.97-02.99		0 261 231 109
Org.no. 8134→	03.99-03.02		0 261 231 130
Pressure sensor, intake manifold, gasoline			
Org.no. →8056	05.97-12.98		0 261 230 012
Org.no. 8057→	01.99-03.02		0 261 230 057
Wheel speed sensor, front	05.97-03.02	LAB	0 265 006 201
		RAB	0 265 006 200
Wheel speed sensor, rear	05.97-03.02	4SB	0 265 006 202

Product				
306 Cabriolet				
1.6 i [N3]	1,6 l 65-66 kW NFZ 4 Zyl.			
Throttle valve sensor	01.93-04.97			0 280 122 001
Pressure sensor, intake manifold, gasoline	01.93-04.97			0 261 230 004
Temperature sensor, intake air, injection system	01.93-04.97			0 280 130 039
Temperature sensor, coolant, injection system	01.93-04.97	BO		0 280 130 026
Wheel speed sensor, front	01.93-04.97	BO,LAB		0 265 006 201
		BO,RAB		0 265 006 200
Wheel speed sensor, rear	01.93-09.95	BO,TBR		0 265 006 204
1.6 i [N5]	1,6 l 65-66 kW NFZ 4 Zyl.			
Throttle valve sensor				
Org.no. →7874	05.97-06.98			0 280 122 003
Knock sensor				
Org.no. 7875→	03.98-10.03			0 261 231 128
Pressure sensor, intake manifold, gasoline				
Org.no. →7874	05.97-05.98			0 261 230 004
Org.no. 7875→8119	06.98-02.99			0 261 230 012
Org.no. 8120→	03.99-10.03			0 261 230 057
Temperature sensor, intake air, injection system				
Org.no. →7874	05.97-05.98			0 280 130 039
Temperature sensor, coolant, injection system	05.97-10.03	BO		0 280 130 084
Wheel speed sensor, front	05.97-10.03	LAB		0 265 006 201
		RAB		0 265 006 200
Wheel speed sensor, rear	05.97-10.03	STB		0 265 006 203
1.6 i [N5]	1,6 l 74 kW NFT 4 Zyl.			
Knock sensor	10.00-10.03			0 261 231 128
Pressure sensor, intake manifold, gasoline	10.00-10.03			0 261 230 043
Wheel speed sensor, front	10.00-10.03	LAB		0 265 006 201
		RAB		0 265 006 200
Wheel speed sensor, rear	10.00-10.03	STB		0 265 006 203
1.8 i [N3]	1,8 l 74-76 kW LFZ; L6A 4 Zyl.			
Wheel speed sensor, front	01.93-04.97	BO,LAB		0 265 006 201
		BO,RAB		0 265 006 200
Wheel speed sensor, rear	01.93-09.95	BO,TBR		0 265 006 204
1.8 i [N5]	1,8 l 74-76 kW LFZ 4 Zyl.			
Wheel speed sensor, front	05.97-10.03	LAB		0 265 006 201
		RAB		0 265 006 200
Wheel speed sensor, rear	05.97-10.03	STB		0 265 006 203
1.8 i 16V [N5]	1,8 l 81 kW LFY 4 Zyl.			
Throttle valve sensor	05.97-10.03			0 280 122 003
Pressure sensor, intake manifold, gasoline				
Org.no. →8035	05.97-11.98			0 261 230 012
Org.no. 8036→	12.98-10.03			0 261 230 034
Wheel speed sensor, front	05.97-10.03	LAB		0 265 006 201
		RAB		0 265 006 200
Wheel speed sensor, rear	05.97-10.03	4SB		0 265 006 202
2.0 i [N3]	2,0 l 89-90 kW RFX; R6D 4 Zyl.			
Knock sensor	08.93-04.97			0 261 231 071
Wheel speed sensor, front	08.93-04.97	BO,LAB		0 265 006 201
		BO,RAB		0 265 006 200
Wheel speed sensor, rear	08.93-04.97			0 265 006 202
2.0 i 16V [N5]	2,0 l 97-99 kW RFV 4 Zyl.			
Throttle valve sensor	05.97-10.03	GS		0 280 122 003
Org.no. →7902	05.97-10.03	AG		0 280 122 003
Org.no. 7903→	07.98-10.03	AG		0 280 122 005
Knock sensor				
Org.no. →8133	05.97-02.99			0 261 231 109
Org.no. 8134→	03.99-10.03			0 261 231 130
Pressure sensor, intake manifold, gasoline				
Org.no. →8056	05.97-12.98			0 261 230 012
Org.no. 8057→	01.99-10.03			0 261 230 057



Product				
Wheel speed sensor, front	05.97-10.03	LAB		0 265 006 201
		RAB		0 265 006 200
Wheel speed sensor, rear	05.97-10.03	4SB		0 265 006 202
307				
1.4 HDi [T5]	1,4 l 50 kW 8HZ 4 Zyl.			
High-pressure sensor (CR system)	10.01-05.05			0 281 002 283
Yaw rate sensor, brake system	10.01-05.05			0 265 005 290
Wheel speed sensor, front	10.01-05.05	TW		0 265 007 423
Wheel speed sensor, rear	10.01-05.05	TW		0 265 007 424
				0 265 007 664
				0 265 007 779
1.4 i [T5]	1,4 l 55 kW KFW 4 Zyl.			
Pressure sensor, intake manifold, gasoline	08.00-05.05			0 261 230 043
Yaw rate sensor, brake system	08.00-05.05			0 265 005 290
Wheel speed sensor, front	08.00-05.05	TW		0 265 007 423
Wheel speed sensor, rear	08.00-05.05	TW		0 265 007 424
				0 265 007 664
				0 265 007 779
1.4 i [T6]	1,4 l 65 kW KFU 4 Zyl.			
Knock sensor	06.05→			0 261 231 168
Pressure sensor, intake manifold, gasoline	06.05→			0 261 230 043
Yaw rate sensor, brake system	06.05→			0 265 005 606
Wheel speed sensor, rear	06.05→			0 265 007 779
1.4 i 16V [T5]	1,4 l 65 kW KFU 4 Zyl.			
Knock sensor	11.03-05.05			0 261 231 168
Pressure sensor, intake manifold, gasoline	11.03-05.05			0 261 230 043
Yaw rate sensor, brake system	11.03-05.05			0 265 005 290
Wheel speed sensor, front	11.03-05.05	TW		0 265 007 423
Wheel speed sensor, rear	11.03-05.05	TW		0 265 007 424
				0 265 007 664
				0 265 007 779
1.6 HDi [T5]	1,6 l 80 kW 9HZ/ 9HY 4 Zyl.			
Yaw rate sensor, brake system	02.04-05.05			0 265 005 290
Wheel speed sensor, front	02.04-05.05	TW		0 265 007 423
Wheel speed sensor, rear	02.04-05.05	TW		0 265 007 424
				0 265 007 664
				0 265 007 779
1.6 HDi [T6]	1,6 l 66 kW 9HV 4 Zyl.			
Yaw rate sensor, brake system	06.07→			0 265 005 714
1.6 HDi [T6]	1,6 l 66/80 kW 9HX; 9HZ/ 9HY 4 Zyl.			
Yaw rate sensor, brake system	06.05→			0 265 005 606
Wheel speed sensor, rear	06.05→			0 265 007 779
1.6 i [T5]	1,6 l 80 kW NFU 4 Zyl.			
Throttle valve assembly	08.00-05.05			0 280 750 085
Knock sensor				
Org.no. 9457→	10.02-05.05			0 261 231 168
Pressure sensor, intake manifold, gasoline	08.00-05.05			0 261 230 043
Accelerator pedal module	08.00-05.05	LLE		0 280 752 235
		RLE		0 280 752 236
Yaw rate sensor, brake system	08.00-05.05			0 265 005 290
Wheel speed sensor, front	08.00-05.05	TW		0 265 007 423
Wheel speed sensor, rear	08.00-05.05	TW		0 265 007 424
				0 265 007 664
				0 265 007 779
1.6 i [T6]	1,6 l 80 kW NFU 4 Zyl.			
Throttle valve assembly	06.05→			0 280 750 085
Knock sensor	06.05→			0 261 231 168
Pressure sensor, intake manifold, gasoline	06.05→			0 261 230 043
Accelerator pedal module	06.05→	LLE		0 280 752 235
		RLE		0 280 752 236



Yaw rate sensor, brake system	06.05→	0 265 005 606
Wheel speed sensor, rear	06.05→	0 265 007 779
1.6 i 16V [T5]	1,6 l 78 kW NFU 4 Zyl.	
Throttle valve assembly	06.04→ BO	0 280 750 085
Knock sensor		
Org.no. 9457→	06.04→	0 261 231 168
Pressure sensor, intake manifold, gasoline	06.04→	0 261 230 043
Yaw rate sensor, brake system	06.04→	0 265 005 290
2.0 HDi [T5]	2,0 l 66 kW RHY 4 Zyl.	
High-pressure sensor (CR system)	08.00-05.05 BO	0 281 002 283
Yaw rate sensor, brake system	08.00-05.05	0 265 005 290
Wheel speed sensor, front	08.00-05.05 TW	0 265 007 423
Wheel speed sensor, rear	08.00-05.05 TW	0 265 007 424
		0 265 007 664
		0 265 007 779
2.0 HDi [T5]	2,0 l 79 kW RHS 4 Zyl.	
High-pressure sensor (CR system)	03.02-05.05	0 281 002 283
Yaw rate sensor, brake system	03.02-05.05	0 265 005 290
Wheel speed sensor, front	03.02-05.05 TW	0 265 007 423
Wheel speed sensor, rear	03.02-05.05 TW	0 265 007 424
		0 265 007 664
		0 265 007 779
2.0 HDi [T5]	2,0 l 100 kW RHR 4 Zyl.	
Accelerator pedal module	10.03-05.05 LLE	0 280 752 235
	RLE	0 280 752 236
Yaw rate sensor, brake system	10.03-05.05	0 265 005 290
Wheel speed sensor, front	10.03-05.05 TW	0 265 007 423
Wheel speed sensor, rear	10.03-05.05 TW	0 265 007 424
		0 265 007 664
		0 265 007 779
2.0 HDi [T6]	2,0 l 100 kW RHR 4 Zyl.	
Accelerator pedal module	06.05→ LLE	0 280 752 235
	RLE	0 280 752 236
Yaw rate sensor, brake system	06.05→	0 265 005 606
Wheel speed sensor, rear	06.05→	0 265 007 779
2.0 i [T5]	2,0 l 100 kW RFN 4 Zyl.	
Pressure sensor, intake manifold, gasoline	08.00-05.05	0 261 230 057
Yaw rate sensor, brake system	08.00-05.05	0 265 005 290
Wheel speed sensor, front	08.00-05.05 TW	0 265 007 423
Wheel speed sensor, rear	08.00-05.05 TW	0 265 007 424
		0 265 007 664
		0 265 007 779
2.0 i [T6]	2,0 l 103 kW RFJ 4 Zyl.	
Pressure sensor, intake manifold, gasoline	06.05→	0 261 230 043
Yaw rate sensor, brake system	06.05→	0 265 005 606
Wheel speed sensor, rear	06.05→	0 265 007 779
2.0 i [T6]	2,0 l 130 kW RFK 4 Zyl.	
Pressure sensor, intake manifold, gasoline	06.05→	0 261 230 043
Yaw rate sensor, brake system	06.05→	0 265 005 606
Wheel speed sensor, rear	06.05→	0 265 007 664
2.0 i 16V [T5]	2,0 l 99 kW RFN 4 Zyl.	
Pressure sensor, intake manifold, gasoline	06.04-02.07	0 261 230 058
Yaw rate sensor, brake system	06.04-02.07	0 265 005 290

307 Break/SW

1.4 HDi [T5]	1,4 l 50 kW 8HZ 4 Zyl.	
High-pressure sensor (CR system)	03.02-05.05	0 281 002 283
Yaw rate sensor, brake system	03.02-05.05	0 265 005 290
Wheel speed sensor, front	03.02-05.05 TW	0 265 007 423
Wheel speed sensor, rear	03.02-05.05 TW	0 265 007 424
		0 265 007 664
		0 265 007 779



1.4 i [T6]	1,4 l 65 kW KFU 4 Zyl.	
Knock sensor	06.05→	0 261 231 168
Pressure sensor, intake manifold, gasoline	06.05→	0 261 230 043
Yaw rate sensor, brake system	06.05→	0 265 005 606
Wheel speed sensor, rear	06.05→	0 265 007 779
1.4 i 16V [T5]	1,4 l 65 kW KFU 4 Zyl.	
Knock sensor	11.03-05.05	0 261 231 168
Pressure sensor, intake manifold, gasoline	11.03-05.05	0 261 230 043
Yaw rate sensor, brake system	11.03-05.05	0 265 005 290
Wheel speed sensor, front	11.03-05.05 TW	0 265 007 423
Wheel speed sensor, rear	11.03-05.05 TW	0 265 007 424
		0 265 007 664
		0 265 007 779
1.6 HDi [T5]	1,6 l 80 kW 9HZ/9HY 4 Zyl.	
Yaw rate sensor, brake system	02.04-05.05	0 265 005 290
Wheel speed sensor, front	02.04-05.05 TW	0 265 007 423
Wheel speed sensor, rear	02.04-05.05 TW	0 265 007 424
		0 265 007 664
		0 265 007 779
1.6 HDi [T6]	1,6 l 66 kW 9HV 4 Zyl.	
Yaw rate sensor, brake system	06.07→	0 265 005 714
1.6 HDi [T6]	1,6 l 66/80 kW 9HX; 9HZ/9HY 4 Zyl.	
Yaw rate sensor, brake system	06.05→	0 265 005 606
Wheel speed sensor, rear	06.05→	0 265 007 779
1.6 i [T5]	1,6 l 80 kW NFU 4 Zyl.	
Throttle valve assembly	03.02-05.05	0 280 750 085
Knock sensor		
Org.no. 9457→	10.02-05.05	0 261 231 168
Pressure sensor, intake manifold, gasoline	03.02-05.05	0 261 230 043
Accelerator pedal module	03.02-05.05 LLE	0 280 752 235
	RLE	0 280 752 236
Yaw rate sensor, brake system	03.02-05.05	0 265 005 290
Wheel speed sensor, front	03.02-05.05 TW	0 265 007 423
Wheel speed sensor, rear	03.02-05.05 TW	0 265 007 424
		0 265 007 664
		0 265 007 779
1.6 i 16V [T6]	1,6 l 80 kW NFU 4 Zyl.	
Throttle valve assembly	06.05→	0 280 750 085
Knock sensor	06.05→	0 261 231 168
Pressure sensor, intake manifold, gasoline	06.05→	0 261 230 043
Accelerator pedal module	06.05→ LLE	0 280 752 235
	RLE	0 280 752 236
Yaw rate sensor, brake system	06.05→	0 265 005 606
Wheel speed sensor, rear	06.05→	0 265 007 779
2.0 HDi [T5]	2,0 l 66 kW RHY 4 Zyl.	
High-pressure sensor (CR system)	03.02-05.05 BO	0 281 002 283
Yaw rate sensor, brake system	03.02-05.05	0 265 005 290
Wheel speed sensor, front	03.02-05.05 TW	0 265 007 423
Wheel speed sensor, rear	03.02-05.05 TW	0 265 007 424
		0 265 007 664
		0 265 007 779
2.0 HDi [T5]	2,0 l 79 kW RHS 4 Zyl.	
High-pressure sensor (CR system)	03.02-05.05	0 281 002 283
Yaw rate sensor, brake system	03.02-05.05	0 265 005 290
Wheel speed sensor, front	03.02-05.05 TW	0 265 007 423
Wheel speed sensor, rear	03.02-05.05 TW	0 265 007 424
		0 265 007 664
		0 265 007 779
2.0 HDi [T5]	2,0 l 100 kW RHR 4 Zyl.	
Accelerator pedal module	10.03-05.05 LLE	0 280 752 235
	RLE	0 280 752 236
Yaw rate sensor, brake system	10.03-05.05	0 265 005 290
Wheel speed sensor, front	10.03-05.05 TW	0 265 007 423



Product

◀ 307 Break/SW

Wheel speed sensor, rear	10.03-05.05	TW	0 265 007 424 0 265 007 664 0 265 007 779
2.0 HDi [T6] 2,0l 100 kW RHR 4 Zyl.			
Accelerator pedal module	06.05→	LLE	0 280 752 235
		RLE	0 280 752 236
Yaw rate sensor, brake system	06.05→		0 265 005 606
Wheel speed sensor, rear	06.05→		0 265 007 779
2.0 i [T5] 2,0l 100 kW RFN 4 Zyl.			
Pressure sensor, intake manifold, gasoline	03.02-05.05		0 261 230 057
Yaw rate sensor, brake system	03.02-05.05		0 265 005 290
Wheel speed sensor, front	03.02-05.05	TW	0 265 007 423
Wheel speed sensor, rear	03.02-05.05	TW	0 265 007 424 0 265 007 664 0 265 007 779

2.0 i [T6] 2,0l 103 kW RFJ 4 Zyl.			
Pressure sensor, intake manifold, gasoline	06.05→		0 261 230 043
Yaw rate sensor, brake system	06.05→		0 265 005 606
Wheel speed sensor, rear	06.05→		0 265 007 779

307 CC

1.6 i [T6] 1,6l 80 kW NFU 4 Zyl.			
Throttle valve assembly	06.05→		0 280 750 085
Knock sensor	06.05→		0 261 231 168
Pressure sensor, intake manifold, gasoline	06.05→		0 261 230 043
Accelerator pedal module	06.05→	LLE	0 280 752 235
		RLE	0 280 752 236
Yaw rate sensor, brake system	06.05→		0 265 005 606
Wheel speed sensor, rear	06.05→		0 265 007 779
2.0 HDi [T6] 2,0l 100 kW RHR 4 Zyl.			
Accelerator pedal module	06.05→	LLE	0 280 752 235
		RLE	0 280 752 236
Yaw rate sensor, brake system	06.05→		0 265 005 606
Wheel speed sensor, rear	06.05→		0 265 007 779
2.0 i [T5] 2,0l 100 kW RFN 4 Zyl.			
Pressure sensor, intake manifold, gasoline	10.03-05.05		0 261 230 058
Yaw rate sensor, brake system	10.03-05.05		0 265 005 290
Wheel speed sensor, front	10.03-05.05	TW	0 265 007 423
Wheel speed sensor, rear	10.03-05.05	TW	0 265 007 424 0 265 007 664 0 265 007 779

2.0 i [T6] 2,0l 103 kW RFJ 4 Zyl.			
Pressure sensor, intake manifold, gasoline	06.05→		0 261 230 043
Yaw rate sensor, brake system	06.05→		0 265 005 606
Wheel speed sensor, rear	06.05→		0 265 007 779
2.0 i Sport [T5] 2,0l 130 kW RFK 4 Zyl.			
Pressure sensor, intake manifold, gasoline	10.03-05.05		0 261 230 043
Yaw rate sensor, brake system	10.03-05.05		0 265 005 290
Wheel speed sensor, front	10.03-05.05	TW	0 265 007 423
Wheel speed sensor, rear	10.03-05.05	TW	0 265 007 424 0 265 007 664 0 265 007 779

2.0 i Sport [T6] 2,0l 130 kW RFK 4 Zyl.			
Pressure sensor, intake manifold, gasoline	06.05→		0 261 230 043
Yaw rate sensor, brake system	06.05→		0 265 005 606
Wheel speed sensor, rear	06.05→		0 265 007 664

Product

308

1.4 i [T7] 1,4l 70 kW 8FS 4 Zyl.			
Phase sensor	09.07→		0 232 103 064
Pressure sensor, intake manifold, gasoline	09.07→		0 261 230 136
Yaw rate sensor, brake system	09.07→		0 265 005 714
1.6 HDi [T7] 1,6l 66/80 kW 9HV; 9HX; 9HZ 4 Zyl.			
Yaw rate sensor, brake system	09.07→		0 265 005 714
1.6 i [T7] 1,6l 88 kW 5FW 4 Zyl.			
Phase sensor	09.07→		0 232 103 064
Pressure sensor, intake manifold, gasoline	09.07→		0 261 230 136
Yaw rate sensor, brake system	09.07→		0 265 005 714
1.6 i [T7] 1,6l 103-110 kW 5FX 4 Zyl.			
Phase sensor	09.07→		0 232 103 064
Knock sensor	09.07→		0 261 231 197
Pressure sensor, intake manifold, gasoline	09.07→		0 261 230 135
Temperature sensor, intake air, injection system	09.07→		0 261 230 134
Yaw rate sensor, brake system	09.07→		0 265 005 715
2.0 HDi [T7] 2,0l 100 kW RHR 4 Zyl.			
Yaw rate sensor, brake system	09.07→		0 265 005 714

309

1.1 i 1,1l 40-44 kW HDZ, HDY <TU1MZ Kat.> 4 Zyl.			
Temperature sensor, coolant, injection system	10.90-12.93		0 280 130 026
1.4 i 1,4l 55-58 kW KDY <TU3M Kat.>; KDZ <TU3M Kat.> 4 Zyl.			
Temperature sensor, coolant, injection system	10.88-12.93		0 280 130 026
1.6 i 1,6l 76/83 kW B6A, B6B <XU5J>; B6D <XU5JA> 4 Zyl.			
Throttle valve sensor	11.85-08.87		0 280 120 310
	09.87-09.90		0 280 120 327
Air flow sensor, gasoline injection	11.85-09.90		0 280 202 056 🔧 0 986 280 028
Temperature sensor, coolant, injection system	11.85-09.90		0 280 130 026
Relay, Jetronic	11.85-09.90		0 280 230 006
1.6 i 1,6l 85 kW 180A, 180Z <XU5J> 4 Zyl.			
Throttle valve sensor	11.85-08.87		0 280 120 310
	09.87-10.87		0 280 120 327
Air flow sensor, gasoline injection	11.85-10.87		0 280 202 056 🔧 0 986 280 028
1.6 i 1,6l 90 kW B6E <XU5JA> 4 Zyl.			
Throttle valve sensor	10.90-12.93		0 280 120 327
Air flow sensor, gasoline injection	10.90-12.93		0 280 202 056 🔧 0 986 280 028
1.9 GTI 1,9l 94 kW D6B <XU9JA> 4 Zyl.			
Throttle valve sensor	10.86-08.87		0 280 120 310
	09.87-12.93		0 280 120 327
Air flow sensor, gasoline injection	10.86-12.93		0 280 202 109 🔧 0 986 280 013
Temperature sensor, coolant, injection system	10.86-12.93		0 280 130 026
Relay, Jetronic	10.86-12.93		0 280 230 006
1.9 i 1,9l 72 kW DFZ <XU9J1 Kat.> 4 Zyl.			
Throttle valve sensor	03.86-08.87		0 280 120 310
	09.87-12.93		0 280 120 327
Air flow sensor, gasoline injection	03.86-12.93		0 280 202 097 🔧 0 986 280 070
Temperature sensor, coolant, injection system	03.86-12.93		0 280 130 026
Relay, Jetronic	03.86-12.93		0 280 230 006
1.9 i 1,9l 80 kW DDZ <XU9M Kat.> 4 Zyl.			
Temperature sensor, coolant, injection system	07.88-12.93		0 280 130 026
1.9 i 1,9l 88-90 kW DKZ, DFY <XU9JAZ Kat.> 4 Zyl.			
Throttle valve sensor	07.88-12.93		0 280 120 327
Speed sensor, ignition/injection	07.88-12.93		0 261 210 043
Temperature sensor, coolant, injection system	07.88-12.93		0 280 130 026

Product



1.9i 16V	1,9l 108/116 kW DFW; D6C <XU9J4/K> 4 Zyl.
Throttle valve sensor	02.90-12.93 0 280 120 327
Speed sensor, ignition/injection	02.90-12.93 0 261 210 043
Knock sensor	02.90-12.93 0 261 231 006
Temperature sensor, coolant, injection system	02.90-12.93 0 280 130 026

405

1.4 [4]	1,4l 55 kW K2D <TU3.2> 4 Zyl.
Wheel speed sensor, front	06.92-04.97 BO 0 265 006 314
Wheel speed sensor, rear	06.92-04.97 BO 0 265 006 315
1.4 [15]	1,4l 44/51/55 kW K1G <TU3A>; K2D <TU3F2>; K3A <TU3TR> 4 Zyl.
Wheel speed sensor, front	10.89-06.92 BO, OAA 0 265 003 064
Fg.no. →S71021434	06.92-12.92 BO 0 265 006 314
Wheel speed sensor, rear	06.92-12.92 BO 0 265 006 315
	10.89-06.92 BO, OAA 0 265 003 065

1.4i [4]	1,4l 55 kW KDX <TU3MC Kat.> 4 Zyl.
Temperature sensor, coolant, injection system	06.92-04.97 0 280 130 026
Wheel speed sensor, front	06.92-04.97 BO 0 265 006 314
Wheel speed sensor, rear	06.92-04.97 BO 0 265 006 315

1.6 [4]	1,6l 65/68 kW B2A <XU52C>; B5A <XU52C> 4 Zyl.
Wheel speed sensor, front	06.92-04.97 BO 0 265 006 314
Wheel speed sensor, rear	06.92-04.97 BO 0 265 006 315
1.6 [15]	1,6l 53/65/68 kW B1D/E <XU51C>; B2A/B/C, B5A <XU52C> 4 Zyl.
Wheel speed sensor, front	10.89-06.92 BO, OAA 0 265 003 064
Fg.no. →S71021434	06.92-12.92 BO 0 265 006 314
Wheel speed sensor, rear	06.92-12.92 BO 0 265 006 315
	10.89-06.92 BO, OAA 0 265 003 065

1.6i [4]	1,6l 65 kW BDY <XU5M Kat.> 4 Zyl.
Temperature sensor, intake air, injection system	06.92-04.97 0 280 130 039
Wheel speed sensor, front	06.92-04.97 BO 0 265 006 314
Wheel speed sensor, rear	06.92-04.97 BO 0 265 006 315

1.6i [4]	1,6l 65 kW BFZ <XU5JP> 4 Zyl.
Wheel speed sensor, front	09.94-04.97 BO 0 265 006 314
Wheel speed sensor, rear	09.94-04.97 BO 0 265 006 315
1.6i [15]	1,6l 65 kW BDY <XU5M Kat.> 4 Zyl.
Wheel speed sensor, front	09.90-06.92 BO, OAA 0 265 003 064
Fg.no. →S71021434	06.92-12.92 BO 0 265 006 314
Wheel speed sensor, rear	06.92-12.92 BO 0 265 006 315
	09.90-06.92 BO, OAA 0 265 003 065

1.6i [15]	1,6l 65 kW BDZ <XU5M Kat.> 4 Zyl.
Wheel speed sensor, front	10.89-09.90 BO, OAA 0 265 003 064
Wheel speed sensor, rear	10.89-09.90 BO, OAA 0 265 003 065

1.8 D [15]	1,8l 44 kW A9A <XUD7>; 161A <XUD7> 4 Zyl.
Wheel speed sensor, front	10.90-06.92 BO, OAA 0 265 003 064
Fg.no. →S71021434	06.92-12.92 BO 0 265 006 314
Wheel speed sensor, rear	06.92-12.92 BO 0 265 006 315
	10.90-06.92 BO, OAA 0 265 003 065

1.8 D Turbo [15]	1,8l 64-66 kW AJZ <XUD7TEY>; A8A, A8B <XUD7TE> 4 Zyl.
Wheel speed sensor, front	10.89-06.92 BO, OAA 0 265 003 064
Fg.no. →S71021434	06.92-12.92 BO 0 265 006 314
Wheel speed sensor, rear	06.92-12.92 BO 0 265 006 315
	10.89-06.92 BO, OAA 0 265 003 065

1.8i	1,8l 74 kW XU7UP 4 Zyl.
Temperature sensor, coolant, injection system	04.96→ 0 280 130 068

1.8i [4]	1,8l 74 kW LFZ <XU7JP Kat.>; L6A <XU7JP> 4 Zyl.
Pressure sensor, intake manifold, gasoline	06.92-04.97 BO 0 261 230 004
Wheel speed sensor, front	06.92-04.97 BO 0 265 006 314
Wheel speed sensor, rear	06.92-04.97 BO 0 265 006 315

1.9 [4]	1,9l 71/80 kW D2H <XU92C>; D5A <XU92C> 4 Zyl.
Wheel speed sensor, front	06.92-04.97 BO 0 265 006 314
Wheel speed sensor, rear	06.92-04.97 BO 0 265 006 315

Product



1.9 [15]	1,9l 70/71 kW D2C <XU92C>; D5A <XU92CTR> 4 Zyl.
Wheel speed sensor, front	10.89-06.92 BO, OAA 0 265 003 064
Fg.no. →S71021434	06.92-12.92 BO 0 265 006 314
Wheel speed sensor, rear	06.92-12.92 BO 0 265 006 315
	10.89-06.92 BO, OAA 0 265 003 065

1.9 [15]	1,9l 80/81 kW D2D <XU92C>; D2H <XU92C> 4 Zyl.
Wheel speed sensor, front	07.87-12.92 AA, BO 0 265 006 314
	10.89-06.92 BO, OAA 0 265 003 064
Fg.no. →S71021434	06.92-12.92 BO 0 265 006 314
Wheel speed sensor, rear	06.92-12.92 BO 0 265 006 315
	10.89-06.92 BO, OAA 0 265 003 065

1.9 D [4]	1,9l 47/50/51 kW DJY, DJZ <XUD9Y>; D9B <XUD9A> 4 Zyl.
Wheel speed sensor, front	06.92-04.97 BO 0 265 006 314
Wheel speed sensor, rear	06.92-04.97 BO 0 265 006 315

1.9 D [15]	1,9l 47/51 kW DJZ <XUD9Y>; D9B <XUD9A> 4 Zyl.
Wheel speed sensor, front	10.89-06.92 BO, OAA 0 265 003 064
Fg.no. →S71021434	06.92-12.92 BO 0 265 006 314
Wheel speed sensor, rear	06.92-12.92 BO 0 265 006 315
	10.89-06.92 BO, OAA 0 265 003 065

1.9 D Turbo [4]	1,9l 66-68 kW DHY <XUD9TE Kat.>; D8A <XUD9TE> 4 Zyl.
Wheel speed sensor, front	06.92-04.97 BO 0 265 006 314
Wheel speed sensor, rear	06.92-04.97 BO 0 265 006 315

1.9i [4]	1,9l 89 kW D6D <XU9J2> 4 Zyl.
Throttle valve sensor	06.92-04.97 0 280 122 001
Speed sensor, ignition/injection	06.92-04.97 0 261 210 043
Temperature sensor, intake air, injection system	06.92-04.97 0 280 130 039
Temperature sensor, coolant, injection system	06.92-04.97 0 280 130 026
Acceleration sensor, ABS	06.92-04.97 0 265 005 111
Wheel speed sensor, front	06.92-04.97 BO 0 265 006 314
Wheel speed sensor, rear	06.92-04.97 BO 0 265 006 315

1.9i [15]	1,9l 77 kW DFZ <XU9J1 Kat.> 4 Zyl.
Throttle valve sensor	07.87-12.92 0 280 120 327
Air flow sensor, gasoline injection	07.87-12.92 0 280 202 097
	0 986 280 070

Temperature sensor, coolant, injection system	07.87-12.92 0 280 130 026
Relay, Jetronic	07.87-12.92 0 280 230 006
Acceleration sensor, ABS	07.87-12.92 0 265 005 111
Wheel speed sensor, front	07.87-12.92 AA, BO 0 265 006 314
	10.89-06.92 BO, OAA 0 265 003 064
Fg.no. →S71021434	06.92-12.92 BO 0 265 006 314
Wheel speed sensor, rear	06.92-12.92 BO 0 265 006 315
	10.89-06.92 BO, OAA 0 265 003 065

1.9i [15]	1,9l 80 kW DDZ <XU9M Kat.> 4 Zyl.
Temperature sensor, coolant, injection system	07.88-12.92 0 280 130 026
Acceleration sensor, ABS	07.88-12.92 0 265 005 111
Wheel speed sensor, front	07.88-12.92 AA, BO 0 265 006 314
	10.89-06.92 BO, OAA 0 265 003 064
Fg.no. →S71021434	06.92-12.92 BO 0 265 006 314
Wheel speed sensor, rear	06.92-12.92 BO 0 265 006 315
	10.89-06.92 BO, OAA 0 265 003 065

1.9i [15]	1,9l 82 kW DFV <XU9J2 Kat.> 4 Zyl.
Throttle valve sensor	07.87-12.92 0 280 120 327
Air flow sensor, gasoline injection	07.87-12.92 0 280 202 602
	0 986 280 019

Speed sensor, ignition/injection	07.87-12.92 0 261 210 043
Temperature sensor, coolant, injection system	07.87-12.92 0 280 130 026
Acceleration sensor, ABS	07.87-12.92 0 265 005 111
Wheel speed sensor, front	07.87-12.92 AA, BO 0 265 006 314
	10.89-06.92 BO, OAA 0 265 003 064
Fg.no. →S71021434	06.92-12.92 BO 0 265 006 314
Wheel speed sensor, rear	06.92-12.92 BO 0 265 006 315
	10.89-06.92 BO, OAA 0 265 003 065



Product



◀ 405

1.9i [15]			1,9l 88 kW DKZ,DFY <XU9JAZ Kat.> 4 Zyl.
Throttle valve sensor	07.88-12.92		0 280 120 327
Speed sensor, ignition/injection	07.88-12.92		0 261 210 043
Temperature sensor, coolant, injection system	07.88-12.92		0 280 130 026
Acceleration sensor, ABS	07.88-12.92		0 265 005 111
Wheel speed sensor, front	07.88-12.92	AA,BO	0 265 006 314
	10.89-06.92	BO,OAA	0 265 003 064
Fg.no. →S71021434	06.92-12.92	BO	0 265 006 314
Wheel speed sensor, rear	06.92-12.92	BO	0 265 006 315
	10.89-06.92	BO,OAA	0 265 003 065
1.9i [15]			1,9l 90-92 kW D6A <XU9J2> 4 Zyl.
Throttle valve sensor	07.87-12.92		0 280 120 327
Air flow sensor, gasoline injection	07.87-12.92		0 280 202 602
			0 986 280 019
Temperature sensor, coolant, injection system	07.87-12.92		0 280 130 026
Acceleration sensor, ABS	07.87-12.92		0 265 005 111
Wheel speed sensor, front	07.87-12.92	AA,BO	0 265 006 314
	10.89-06.92	BO,OAA	0 265 003 064
Fg.no. →S71021434	06.92-12.92	BO	0 265 006 314
Wheel speed sensor, rear	06.92-12.92	BO	0 265 006 315
	10.89-06.92	BO,OAA	0 265 003 065
1.9i [15]			1,9l 90-92 kW D6D <XU9J2> 4 Zyl.
Speed sensor, ignition/injection	07.87-12.92		0 261 210 043
Temperature sensor, coolant, injection system	07.87-12.92		0 280 130 026
Acceleration sensor, ABS	07.87-12.92		0 265 005 111
Wheel speed sensor, front	07.87-12.92	AA,BO	0 265 006 314
	10.89-06.92	BO,OAA	0 265 003 064
Fg.no. →S71021434	06.92-12.92	BO	0 265 006 314
Wheel speed sensor, rear	06.92-12.92	BO	0 265 006 315
	10.89-06.92	BO,OAA	0 265 003 065
1.9i 16V [15]			1,9l 108-111/116 kW DFW <XU9J4Z Kat.>; D6C <XU9J4/K> 4 Zyl.
Throttle valve sensor	07.87-12.92		0 280 120 327
Speed sensor, ignition/injection	07.87-12.92		0 261 210 043
Knock sensor	03.88-12.92		0 261 231 006
Temperature sensor, coolant, injection system	07.87-12.92		0 280 130 026
Acceleration sensor, ABS	07.87-12.92		0 265 005 111
Wheel speed sensor, front	07.87-12.92	AA,BO	0 265 006 314
	10.89-06.92	BO,OAA	0 265 003 064
Fg.no. →S71021434	06.92-12.92	BO	0 265 006 314
Wheel speed sensor, rear	06.92-12.92	BO	0 265 006 315
	10.89-06.92	BO,OAA	0 265 003 065
2.0i [4]			2,0l 89 kW RFX <XU10J2 Kat.>; R6D <XU10J2> 4 Zyl.
Knock sensor	06.92-04.97	BO	0 261 231 071
Acceleration sensor, ABS	06.92-04.97		0 265 005 111
Wheel speed sensor, front	06.92-04.97	BO	0 265 006 314
Wheel speed sensor, rear	06.92-04.97	BO	0 265 006 315
2.0i Mi16 [4]			2,0l 110-118 kW RFT <XU10J4>; RFY <XU10J4> 4 Zyl.
Throttle valve sensor	01.93-06.95		0 280 122 001
	07.95-04.97		0 280 122 003
Knock sensor	01.93-04.97	BO	0 261 231 071
Acceleration sensor, ABS	01.93-04.97		0 265 005 111
Wheel speed sensor, front	01.93-04.97	BO	0 265 006 314
Wheel speed sensor, rear	01.93-04.97	BO	0 265 006 315
2.0i T16 4x4 [4]			2,0l 144-159 kW RGZ <XU10J4TE> 4 Zyl.
Knock sensor	09.92-04.97	BO	0 261 231 071
Acceleration sensor, ABS	09.92-04.97		0 265 005 111
Wheel speed sensor, front	09.92-04.97	BO	0 265 006 314
Wheel speed sensor, rear	09.92-04.97	BO	0 265 003 081
2.0i 4x4 [4]			2,0l 89 kW RFX <XU10J2 Kat.> 4 Zyl.
Knock sensor	06.92-04.97	BO	0 261 231 071
Acceleration sensor, ABS	06.92-04.97		0 265 005 111
Wheel speed sensor, front	06.92-04.97	BO	0 265 006 314
Wheel speed sensor, rear	06.92-04.97	BO	0 265 003 081



Product



405 Break

1.4 [4]			1,4l 55 kW K2D <TU3.2> 4 Zyl.
Wheel speed sensor, front	06.92-04.97	BO	0 265 006 314
Wheel speed sensor, rear	06.92-04.97	BO	0 265 006 315
1.4 [15]			1,4l 55 kW K2D 4 Zyl.
Wheel speed sensor, front	06.91-06.92	BO,OAA	0 265 003 064
Fg.no. →S71021434	06.92-09.92	BO	0 265 006 314
Wheel speed sensor, rear	06.92-09.92	BO	0 265 006 315
	06.91-06.92	BO,OAA	0 265 003 065
1.4i [4]			1,4l 55 kW KDX <TU3MC Kat.> 4 Zyl.
Temperature sensor, coolant, injection system	06.92-04.97		0 280 130 026
Wheel speed sensor, front	06.92-04.97	BO	0 265 006 314
Wheel speed sensor, rear	06.92-04.97	BO	0 265 006 315
1.6 [4]			1,6l 65/68 kW B2A <XU52C>; B5A <XU52C> 4 Zyl.
Wheel speed sensor, front	06.92-04.97	BO	0 265 006 314
Wheel speed sensor, rear	06.92-04.97	BO	0 265 006 315
1.6 [15]			1,6l 53/65/68 kW B1D,B1E; B2A, B2B, B2C; B5A 4 Zyl.
Wheel speed sensor, front	10.89-06.92	BO,OAA	0 265 003 064
Fg.no. →S71021434	06.92-12.92	BO	0 265 006 314
Wheel speed sensor, rear	06.92-12.92	BO	0 265 006 315
	10.89-06.92	BO,OAA	0 265 003 065
1.6i [4]			1,6l 65 kW BDY <XU5M Kat.> 4 Zyl.
Temperature sensor, intake air, injection system	06.92-04.97		0 280 130 039
Wheel speed sensor, front	06.92-04.97	BO	0 265 006 314
Wheel speed sensor, rear	06.92-04.97	BO	0 265 006 315
1.6i [4]			1,6l 65 kW BFZ <XU5JP> 4 Zyl.
Wheel speed sensor, front	09.94-04.97	BO	0 265 006 314
Wheel speed sensor, rear	09.94-04.97	BO	0 265 006 315
1.6i [15]			1,6l 65 kW BDY 4 Zyl.
Wheel speed sensor, front	09.90-06.92	BO,OAA	0 265 003 064
Fg.no. →S71021434	06.92-12.92	BO	0 265 006 314
Wheel speed sensor, rear	06.92-12.92	BO	0 265 006 315
	09.90-06.92	BO,OAA	0 265 003 065
1.6i [15]			1,6l 65 kW BDZ 4 Zyl.
Wheel speed sensor, front	10.89-09.90	BO,OAA	0 265 003 064
Wheel speed sensor, rear	10.89-09.90	BO,OAA	0 265 003 065
1.8 D Turbo [15]			1,8l 64-66 kW AJZ; A8A,A8B 4 Zyl.
Wheel speed sensor, front	10.89-06.92	BO,OAA	0 265 003 064
Fg.no. →S71021434	06.92-12.92	BO	0 265 006 314
Wheel speed sensor, rear	06.92-12.92	BO	0 265 006 315
	10.89-06.92	BO,OAA	0 265 003 065
1.8i [4]			1,8l 74 kW LFZ <XU7JP Kat.>; L6A <XU7JP> 4 Zyl.
Pressure sensor, intake manifold, gasoline	06.92-04.97	BO	0 261 230 004
Wheel speed sensor, front	06.92-04.97	BO	0 265 006 314
Wheel speed sensor, rear	06.92-04.97	BO	0 265 006 315
1.9 [4]			1,9l 71/80 kW D2H <XU92C>; D5A <XU92C> 4 Zyl.
Wheel speed sensor, front	06.92-04.97	BO	0 265 006 314
Wheel speed sensor, rear	06.92-04.97	BO	0 265 006 315
1.9 [15]			1,9l 70/71 kW D2C; D5A 4 Zyl.
Wheel speed sensor, front	10.89-06.92	BO,OAA	0 265 003 064
Fg.no. →S71021434	06.92-12.92	BO	0 265 006 314
Wheel speed sensor, rear	06.92-12.92	BO	0 265 006 315
	10.89-06.92	BO,OAA	0 265 003 065
1.9 [15]			1,9l 80/81 kW D2D; D2H 4 Zyl.
Wheel speed sensor, front	07.88-12.92	AA,BO	0 265 006 314
	10.89-06.92	BO,OAA	0 265 003 064
Fg.no. →S71021434	06.92-12.92	BO	0 265 006 314
Wheel speed sensor, rear	06.92-12.92	BO	0 265 006 315
	10.89-06.92	BO,OAA	0 265 003 065
1.9 D [4]			1,9l 47/50/51 kW DJY,DJZ <XUD9Y>; D9B <XUD9A> 4 Zyl.
Wheel speed sensor, front	06.92-04.97	BO	0 265 006 314
Wheel speed sensor, rear	06.92-04.97	BO	0 265 006 315



Product



1.9 D [15]		1,9l 47/51 kW DJZ; D9B 4 Zyl.	
Wheel speed sensor, front	10.89-06.92	BO, OAA	0 265 003 064
Fg.no. → S71021434	06.92-12.92	BO	0 265 006 314
Wheel speed sensor, rear	06.92-12.92	BO	0 265 006 315
	10.89-06.92	BO, OAA	0 265 003 065
1.9 D Turbo [4]		1,9l 66-68 kW DHY <XUD9TE Kat.>; D8A <XUD9TE> 4 Zyl.	
Wheel speed sensor, front	06.92-04.97	BO	0 265 006 314
Wheel speed sensor, rear	06.92-04.97	BO	0 265 006 315
1.9 i [4]		1,9l 89 kW D6D <XU9J2> 4 Zyl.	
Throttle valve sensor	06.92-04.97		0 280 122 001
Speed sensor, ignition/injection	06.92-04.97		0 261 210 043
Temperature sensor, intake air, injection system	06.92-04.97		0 280 130 039
Temperature sensor, coolant, injection system	06.92-04.97		0 280 130 026
Acceleration sensor, ABS	06.92-04.97		0 265 005 111
Wheel speed sensor, front	06.92-04.97	BO	0 265 006 314
Wheel speed sensor, rear	06.92-04.97	BO	0 265 006 315
1.9 i [15]		1,9l 77 kW DFZ 4 Zyl.	
Throttle valve sensor	07.88-12.92		0 280 120 327
Air flow sensor, gasoline injection	07.88-12.92		0 280 202 097
			0 986 280 070
Temperature sensor, coolant, injection system	07.88-12.92		0 280 130 026
Relay, Jetronic	07.88-12.92		0 280 230 006
Acceleration sensor, ABS	07.88-12.92		0 265 005 111
Wheel speed sensor, front	07.88-12.92	AA, BO	0 265 006 314
	10.89-06.92	BO, OAA	0 265 003 064
Fg.no. → S71021434	06.92-12.92	BO	0 265 006 314
Wheel speed sensor, rear	06.92-12.92	BO	0 265 006 315
	10.89-06.92	BO, OAA	0 265 003 065
1.9 i [15]		1,9l 80 kW DDZ 4 Zyl.	
Temperature sensor, coolant, injection system	07.88-12.92		0 280 130 026
Acceleration sensor, ABS	07.88-12.92		0 265 005 111
Wheel speed sensor, front	07.88-12.92	AA, BO	0 265 006 314
	10.89-06.92	BO, OAA	0 265 003 064
Fg.no. → S71021434	06.92-12.92	BO	0 265 006 314
Wheel speed sensor, rear	06.92-12.92	BO	0 265 006 315
	10.89-06.92	BO, OAA	0 265 003 065
1.9 i [15]		1,9l 88 kW DKZ, DFY 4 Zyl.	
Throttle valve sensor	07.88-12.92		0 280 120 327
Speed sensor, ignition/injection	07.88-12.92		0 261 210 043
Temperature sensor, coolant, injection system	07.88-12.92		0 280 130 026
Acceleration sensor, ABS	07.88-12.92		0 265 005 111
Wheel speed sensor, front	07.88-12.92	AA, BO	0 265 006 314
	10.89-06.92	BO, OAA	0 265 003 064
Fg.no. → S71021434	06.92-12.92	BO	0 265 006 314
Wheel speed sensor, rear	06.92-12.92	BO	0 265 006 315
	10.89-06.92	BO, OAA	0 265 003 065
1.9 i [15]		1,9l 90-92 kW D6A 4 Zyl.	
Throttle valve sensor	07.88-12.92		0 280 120 327
Air flow sensor, gasoline injection	07.88-12.92		0 280 202 602
			0 986 280 019
Temperature sensor, coolant, injection system	07.88-12.92		0 280 130 026
Acceleration sensor, ABS	07.88-12.92		0 265 005 111
Wheel speed sensor, front	07.88-12.92	AA, BO	0 265 006 314
	10.89-06.92	BO, OAA	0 265 003 064
Fg.no. → S71021434	06.92-12.92	BO	0 265 006 314
Wheel speed sensor, rear	06.92-12.92	BO	0 265 006 315
	10.89-06.92	BO, OAA	0 265 003 065
1.9 i [15]		1,9l 90-92 kW D6D 4 Zyl.	
Speed sensor, ignition/injection	07.88-12.92		0 261 210 043
Temperature sensor, coolant, injection system	07.88-12.92		0 280 130 026
Acceleration sensor, ABS	07.88-12.92		0 265 005 111

Product



Wheel speed sensor, front	07.88-12.92	AA, BO	0 265 006 314
	10.89-06.92	BO, OAA	0 265 003 064
Fg.no. → S71021434	06.92-12.92	BO	0 265 006 314
Wheel speed sensor, rear	06.92-12.92	BO	0 265 006 315
	10.89-06.92	BO, OAA	0 265 003 065
2.0 i [4]		2,0l 89 kW RFX <XU10J2 Kat.>; R6D <XU10J2> 4 Zyl.	
Knock sensor	06.92-04.97	BO	0 261 231 071
Acceleration sensor, ABS	06.92-04.97		0 265 005 111
Wheel speed sensor, front	06.92-04.97	BO	0 265 006 314
Wheel speed sensor, rear	06.92-04.97	BO	0 265 006 315
2.0 i 4x4 [4]		2,0l 89 kW RFX <XU10J2 Kat.> 4 Zyl.	
Knock sensor	06.92-04.97	BO	0 261 231 071
Wheel speed sensor, front	06.92-04.97	BO	0 265 006 314
Wheel speed sensor, rear	06.92-04.97	BO	0 265 003 081
406			
1.6 i [D8]		1,6l 65 kW BFZ 4 Zyl.	
Wheel speed sensor, front	10.95-03.99		0 265 006 205
Wheel speed sensor, rear	10.95-03.99		0 265 006 206
1.6 i [D9]		1,6l 65 kW BFZ 4 Zyl.	
Yaw rate sensor, brake system			
Org.no. → 9064	04.99-09.01		0 265 005 290
Org.no. 9065 →	10.01-06.04		0 265 005 253
Steering angle sensor, ESP (electronic stability program)	04.99-06.04		0 265 005 404
Wheel speed sensor, front	04.99-06.04		0 265 006 205
Wheel speed sensor, rear	04.99-06.04		0 265 006 206
1.8 i [D8]		1,8l 66 kW LFX 4 Zyl.	
Pressure sensor, intake manifold, gasoline			
Org.no. → 8028	09.97-11.98		0 261 230 012
Wheel speed sensor, front	09.97-03.99		0 265 006 205
Wheel speed sensor, rear	09.97-03.99		0 265 006 206
1.8 i [D8]		1,8l 74-76 kW L6A 4 Zyl.	
Wheel speed sensor, front	12.95-03.99		0 265 006 205
Wheel speed sensor, rear	12.95-03.99		0 265 006 206
1.8 i [D9]		1,8l 66/74-76 kW LFX; L6A 4 Zyl.	
Yaw rate sensor, brake system			
Org.no. → 9064	04.99-09.01		0 265 005 290
Org.no. 9065 →	10.01-06.04		0 265 005 253
Steering angle sensor, ESP (electronic stability program)	04.99-06.04		0 265 005 404
Wheel speed sensor, front	04.99-06.04		0 265 006 205
Wheel speed sensor, rear	04.99-06.04		0 265 006 206
1.8 i 16V [D8]		1,8l 81-82 kW LFY 4 Zyl.	
Throttle valve sensor	09.97-03.99	GS	0 280 122 003
Knock sensor	10.95-03.99	AG	0 261 231 109
Pressure sensor, intake manifold, gasoline			
Org.no. → 8028	10.95-11.98		0 261 230 012
Wheel speed sensor, front	10.95-03.99		0 265 006 205
Wheel speed sensor, rear	10.95-03.99		0 265 006 206
1.8 i 16V [D9]		1,8l 81-82 kW LFY 4 Zyl.	
Throttle valve sensor	04.99-06.04	GS	0 280 122 003
Knock sensor	04.99-06.04	BO	0 261 231 130
Pressure sensor, intake manifold, gasoline	04.99-06.04	NGA	0 261 230 057
Yaw rate sensor, brake system			
Org.no. → 9064	04.99-09.01		0 265 005 290
Org.no. 9065 →	10.01-06.04		0 265 005 253
Steering angle sensor, ESP (electronic stability program)	04.99-06.04		0 265 005 404
Wheel speed sensor, front	04.99-06.04		0 265 006 205
Wheel speed sensor, rear	04.99-06.04		0 265 006 206

Product



◀ 406

1.8 i 16V [D9]	1,8 l 85 kW 6FZ 4 Zyl.
Pressure sensor, intake manifold, gasoline	10.00-06.04 NGA 0 261 230 057
Yaw rate sensor, brake system	
Org.no. →9064	10.00-09.01 0 265 005 290
Org.no. 9065→	10.01-06.04 0 265 005 253
Steering angle sensor, ESP (electronic stability program)	10.00-06.04 0 265 005 404
Wheel speed sensor, front	10.00-06.04 0 265 006 205
Wheel speed sensor, rear	10.00-06.04 0 265 006 206
1.9 D Turbo [D8]	1,9 l 55/66-68 kW DHW; DHX; D8B 4 Zyl.
Wheel speed sensor, front	12.95-03.99 0 265 006 205
Wheel speed sensor, rear	12.95-03.99 0 265 006 206
2.0 HDi [D8]	2,0 l 80 kW RHZ 4 Zyl.
Wheel speed sensor, front	10.98-03.99 0 265 006 205
Wheel speed sensor, rear	10.98-03.99 0 265 006 206
2.0 HDi [D9]	2,0 l 66/79/80 kW RHS; RHY; RHZ 4 Zyl.
High-pressure sensor (CR system)	04.99-06.04 0 281 002 283
Yaw rate sensor, brake system	
Org.no. →9064	04.99-09.01 0 265 005 290
Org.no. 9065→	10.01-06.04 0 265 005 253
Steering angle sensor, ESP (electronic stability program)	04.99-06.04 0 265 005 404
Wheel speed sensor, front	04.99-06.04 0 265 006 205
Wheel speed sensor, rear	04.99-06.04 0 265 006 206
2.0 HPI [D9]	2,0 l 103 kW RLZ 4 Zyl.
Yaw rate sensor, brake system	
Org.no. →9064	10.00-09.01 0 265 005 290
Org.no. 9065→	10.01-06.04 0 265 005 253
Steering angle sensor, ESP (electronic stability program)	10.00-06.04 0 265 005 404
Wheel speed sensor, front	10.00-06.04 0 265 006 205
Wheel speed sensor, rear	10.00-06.04 0 265 006 206
2.0 i Turbo [D8]	2,0 l 108-110 kW RGX 4 Zyl.
Throttle valve sensor	04.96-03.99 0 280 122 003
Knock sensor	04.96-03.99 0 261 231 109
Wheel speed sensor, front	04.96-03.99 0 265 006 205
Wheel speed sensor, rear	04.96-03.99 0 265 006 206
2.0 i 16V [D8]	2,0 l 97-99 kW RFV; R6E 4 Zyl.
Throttle valve sensor	10.95-03.99 AG 0 280 122 005
	GS 0 280 122 003
Knock sensor	
Org.no. →7664	10.95-11.97 0 261 231 109
Org.no. 7665→	12.97-03.99 0 261 231 045
Pressure sensor, intake manifold, gasoline	
Org.no. 7329→	01.97-03.99 0 261 230 012
Wheel speed sensor, front	10.95-03.99 0 265 006 205
Wheel speed sensor, rear	10.95-03.99 0 265 006 206
2.0 i 16V [D9]	2,0 l 97 kW RFV 4 Zyl.
Throttle valve sensor	04.99-06.04 AG 0 280 122 005
	GS 0 280 122 003
Knock sensor	04.99-06.04 0 261 231 130
Pressure sensor, intake manifold, gasoline	04.99-06.04 0 261 230 034
Yaw rate sensor, brake system	
Org.no. →9064	04.99-09.01 0 265 005 290
Org.no. 9065→	10.01-06.04 0 265 005 253
Steering angle sensor, ESP (electronic stability program)	04.99-06.04 0 265 005 404
Wheel speed sensor, front	04.99-06.04 0 265 006 205
Wheel speed sensor, rear	04.99-06.04 0 265 006 206
2.0 i 16V [D9]	2,0 l 99 kW RFR 4 Zyl.
Pressure sensor, intake manifold, gasoline	04.99-08.00 0 261 230 034
Yaw rate sensor, brake system	04.99-08.00 0 265 005 290

Product



Steering angle sensor, ESP (electronic stability program)	04.99-08.00 0 265 005 404
Wheel speed sensor, front	04.99-08.00 0 265 006 205
Wheel speed sensor, rear	04.99-08.00 0 265 006 206
2.0 i 16V [D9]	2,0 l 100 kW RFN 4 Zyl.
Yaw rate sensor, brake system	
Org.no. →9064	08.00-09.01 0 265 005 290
Org.no. 9065→	10.01-06.04 0 265 005 253
Steering angle sensor, ESP (electronic stability program)	08.00-06.04 0 265 005 404
Wheel speed sensor, front	08.00-06.04 0 265 006 205
Wheel speed sensor, rear	08.00-06.04 0 265 006 206
2.1 D Turbo [D8]	2,1 l 80-81 kW P8C 4 Zyl.
Temperature sensor, intake air, diesel	12.95-03.99 0 280 130 039
Wheel speed sensor, front	12.95-03.99 0 265 006 205
Wheel speed sensor, rear	12.95-03.99 0 265 006 206
2.2 HDi [D9]	2,2 l 98 kW 4HX 4 Zyl.
High-pressure sensor (CR system)	03.00-06.04 0 281 002 283
Yaw rate sensor, brake system	
Org.no. →9064	03.00-09.01 0 265 005 290
Org.no. 9065→	10.01-06.04 0 265 005 253
Steering angle sensor, ESP (electronic stability program)	03.00-06.04 0 265 005 404
Wheel speed sensor, front	03.00-06.04 0 265 006 205
Wheel speed sensor, rear	03.00-06.04 0 265 006 206
2.2 i 16V [D9]	2,2 l 116 kW 3FZ 4 Zyl.
Pressure sensor, intake manifold, gasoline	04.99-06.04 0 261 230 057
Yaw rate sensor, brake system	
Org.no. →9064	04.99-09.01 0 265 005 290
Org.no. 9065→	10.01-06.04 0 265 005 253
Steering angle sensor, ESP (electronic stability program)	04.99-06.04 0 265 005 404
Wheel speed sensor, front	04.99-06.04 0 265 006 205
Wheel speed sensor, rear	04.99-06.04 0 265 006 206
3.0 i [D8]	3,0 l 140 kW XFZ 6 Zyl.
Knock sensor	08.96-03.99 0 261 231 125
Pressure sensor, intake manifold, gasoline	
Org.no. →8028	08.96-11.98 0 261 230 012
Wheel speed sensor, front	08.96-03.99 0 265 006 205
Wheel speed sensor, rear	08.96-03.99 0 265 006 206
3.0 i [D9]	3,0 l 140 kW XFZ 6 Zyl.
Throttle valve sensor	04.99-06.04 0 280 122 009
Knock sensor	04.99-06.04 0 261 231 125
Pressure sensor, intake manifold, gasoline	04.99-06.04 0 261 230 034
Yaw rate sensor, brake system	
Org.no. →9064	04.99-09.01 0 265 005 290
Org.no. 9065→	10.01-06.04 0 265 005 253
Steering angle sensor, ESP (electronic stability program)	04.99-06.04 0 265 005 404
Wheel speed sensor, front	04.99-06.04 0 265 006 205
Wheel speed sensor, rear	04.99-06.04 0 265 006 206
3.0 i [D9]	3,0 l 150 kW XFX 6 Zyl.
Throttle valve assembly	12.99-06.04 0 280 750 041
Knock sensor	12.99-06.04 KZB 0 261 231 071
Pressure sensor, intake manifold, gasoline	12.99-06.04 0 261 230 041
Yaw rate sensor, brake system	
Org.no. →9064	12.99-09.01 0 265 005 290
Org.no. 9065→	10.01-06.04 0 265 005 253
Steering angle sensor, ESP (electronic stability program)	12.99-06.04 0 265 005 404
Wheel speed sensor, front	12.99-06.04 0 265 006 205
Wheel speed sensor, rear	12.99-06.04 0 265 006 206

Product



406 Break

1.8 i [D8]			1,8l 66 kW LFX 4 Zyl.
Pressure sensor, intake manifold, gasoline			
Org.no. →8028	09.97-11.98		0 261 230 012
Wheel speed sensor, front	09.97-03.99		0 265 006 205
Wheel speed sensor, rear	09.97-03.99		0 265 006 206
1.8 i [D8]			1,8l 74-76 kW L6A 4 Zyl.
Wheel speed sensor, front	10.96-03.99		0 265 006 205
Wheel speed sensor, rear	10.96-03.99		0 265 006 206
1.8 i [D9]			1,8l 66/74-76 kW LFX; L6A 4 Zyl.
Yaw rate sensor, brake system			
Org.no. →9064	04.99-09.01		0 265 005 290
Org.no. 9065→	10.01-06.04		0 265 005 253
Steering angle sensor, ESP (electronic stability program)	04.99-06.04		0 265 005 404
Wheel speed sensor, front	04.99-06.04		0 265 006 205
Wheel speed sensor, rear	04.99-06.04		0 265 006 206
1.8 i 16V [D8]			1,8l 81-82 kW LFY 4 Zyl.
Throttle valve sensor	09.97-03.99	GS	0 280 122 003
Knock sensor	10.96-03.99	AG	0 261 231 109
Pressure sensor, intake manifold, gasoline			
Org.no. →8028	10.96-11.98		0 261 230 012
Wheel speed sensor, front	10.96-03.99		0 265 006 205
Wheel speed sensor, rear	10.96-03.99		0 265 006 206
1.8 i 16V [D9]			1,8l 81 kW LFY 4 Zyl.
Throttle valve sensor	04.99-06.04	GS	0 280 122 003
Knock sensor	04.99-06.04	BO	0 261 231 130
Pressure sensor, intake manifold, gasoline	04.99-06.04	NGA	0 261 230 057
Yaw rate sensor, brake system			
Org.no. →9064	04.99-09.01		0 265 005 290
Org.no. 9065→	10.01-06.04		0 265 005 253
Steering angle sensor, ESP (electronic stability program)	04.99-06.04		0 265 005 404
Wheel speed sensor, front	04.99-06.04		0 265 006 205
Wheel speed sensor, rear	04.99-06.04		0 265 006 206
1.8 i 16V [D9]			1,8l 85 kW 6FZ 4 Zyl.
Pressure sensor, intake manifold, gasoline	10.00-06.04	NGA	0 261 230 057
Yaw rate sensor, brake system			
Org.no. →9064	10.00-09.01		0 265 005 290
Org.no. 9065→	10.01-06.04		0 265 005 253
Steering angle sensor, ESP (electronic stability program)	10.00-06.04		0 265 005 404
Wheel speed sensor, front	10.00-06.04		0 265 006 205
Wheel speed sensor, rear	10.00-06.04		0 265 006 206
1.9 D Turbo [D8]			1,9l 55/66-68 kW DHW; DHX; D8B 4 Zyl.
Wheel speed sensor, front	10.96-03.99		0 265 006 205
Wheel speed sensor, rear	10.96-03.99		0 265 006 206
2.0 HDi [D8]			2,0l 80 kW RHZ 4 Zyl.
Wheel speed sensor, front	10.98-03.99		0 265 006 205
Wheel speed sensor, rear	10.98-03.99		0 265 006 206
2.0 HDi [D9]			2,0l 66/79/80 kW RHS; RHY; RHZ 4 Zyl.
High-pressure sensor (CR system)	04.99-06.04		0 281 002 283
Yaw rate sensor, brake system			
Org.no. →9064	04.99-09.01		0 265 005 290
Org.no. 9065→	10.01-06.04		0 265 005 253
Steering angle sensor, ESP (electronic stability program)	04.99-06.04		0 265 005 404
Wheel speed sensor, front	04.99-06.04		0 265 006 205
Wheel speed sensor, rear	04.99-06.04		0 265 006 206

Product



2.0 HPi [D9]			2,0l 103 kW RLZ 4 Zyl.
Yaw rate sensor, brake system			
Org.no. →9064	10.00-09.01		0 265 005 290
Org.no. 9065→	10.01-06.04		0 265 005 253
Steering angle sensor, ESP (electronic stability program)	10.00-06.04		0 265 005 404
Wheel speed sensor, front	10.00-06.04		0 265 006 205
Wheel speed sensor, rear	10.00-06.04		0 265 006 206
2.0 i Turbo [D8]			2,0l 108-110 kW RGX 4 Zyl.
Throttle valve sensor	10.96-03.99		0 280 122 003
Knock sensor	10.96-03.99		0 261 231 109
Wheel speed sensor, front	10.96-03.99		0 265 006 205
Wheel speed sensor, rear	10.96-03.99		0 265 006 206
2.0 i 16V [D8]			2,0l 97-99 kW RFV; R6E 4 Zyl.
Throttle valve sensor	10.96-03.99	AG	0 280 122 005
		GS	0 280 122 003
Knock sensor			
Org.no. →7664	10.96-11.97		0 261 231 109
Org.no. 7665→	12.97-03.99		0 261 231 045
Pressure sensor, intake manifold, gasoline			
Org.no. 7329→	01.97-03.99		0 261 230 012
Wheel speed sensor, front	10.96-03.99		0 265 006 205
Wheel speed sensor, rear	10.96-03.99		0 265 006 206
2.0 i 16V [D9]			2,0l 97 kW RFV 4 Zyl.
Throttle valve sensor	04.99-06.04	AG	0 280 122 005
		GS	0 280 122 003
Knock sensor	04.99-06.04		0 261 231 130
Pressure sensor, intake manifold, gasoline	04.99-06.04		0 261 230 034
Yaw rate sensor, brake system			
Org.no. →9064	04.99-09.01		0 265 005 290
Org.no. 9065→	10.01-06.04		0 265 005 253
Steering angle sensor, ESP (electronic stability program)	04.99-06.04		0 265 005 404
Wheel speed sensor, front	04.99-06.04		0 265 006 205
Wheel speed sensor, rear	04.99-06.04		0 265 006 206
2.0 i 16V [D9]			2,0l 99 kW RFR 4 Zyl.
Pressure sensor, intake manifold, gasoline	04.99-10.00		0 261 230 034
Yaw rate sensor, brake system	04.99-10.00		0 265 005 290
Steering angle sensor, ESP (electronic stability program)	04.99-10.00		0 265 005 404
Wheel speed sensor, front	04.99-10.00		0 265 006 205
Wheel speed sensor, rear	04.99-10.00		0 265 006 206
2.0 i 16V [D9]			2,0l 100 kW RFN 4 Zyl.
Yaw rate sensor, brake system			
Org.no. →9064	10.00-09.01		0 265 005 290
Org.no. 9065→	10.01-06.04		0 265 005 253
Steering angle sensor, ESP (electronic stability program)	10.00-06.04		0 265 005 404
Wheel speed sensor, front	10.00-06.04		0 265 006 205
Wheel speed sensor, rear	10.00-06.04		0 265 006 206
2.1 D Turbo [D8]			2,1l 80-81 kW P8C 4 Zyl.
Temperature sensor, intake air, diesel	10.96-03.99		0 280 130 039
Wheel speed sensor, front	10.96-03.99		0 265 006 205
Wheel speed sensor, rear	10.96-03.99		0 265 006 206
2.2 HDi [D9]			2,2l 98 kW 4HX 4 Zyl.
High-pressure sensor (CR system)	03.00-06.04		0 281 002 283
Yaw rate sensor, brake system			
Org.no. →9064	03.00-09.01		0 265 005 290
Org.no. 9065→	10.01-06.04		0 265 005 253
Steering angle sensor, ESP (electronic stability program)	03.00-06.04		0 265 005 404
Wheel speed sensor, front	03.00-06.04		0 265 006 205
Wheel speed sensor, rear	03.00-06.04		0 265 006 206



P



Product



◀ 406 Break

2.2 i 16V [D9]		2,2l 116 kW 3FZ 4 Zyl.
Pressure sensor, intake manifold, gasoline	04.99-06.04	0 261 230 057
Yaw rate sensor, brake system		
Org.no. →9064	04.99-09.01	0 265 005 290
Org.no. 9065→	10.01-06.04	0 265 005 253
Steering angle sensor, ESP (electronic stability program)	04.99-06.04	0 265 005 404
Wheel speed sensor, front	04.99-06.04	0 265 006 205
Wheel speed sensor, rear	04.99-06.04	0 265 006 206
3.0 i [D8]		3,0l 140 kW XFZ 6 Zyl.
Knock sensor	10.96-03.99	0 261 231 125
Pressure sensor, intake manifold, gasoline		
Org.no. →8028	10.96-11.98	0 261 230 012
Wheel speed sensor, front	10.96-03.99	0 265 006 205
Wheel speed sensor, rear	10.96-03.99	0 265 006 206
3.0 i [D9]		3,0l 140 kW XFX 6 Zyl.
Throttle valve sensor	04.99-06.04	0 280 122 009
Knock sensor	04.99-06.04	0 261 231 125
Pressure sensor, intake manifold, gasoline	04.99-06.04	0 261 230 034
Yaw rate sensor, brake system		
Org.no. →9064	04.99-09.01	0 265 005 290
Org.no. 9065→	10.01-06.04	0 265 005 253
Steering angle sensor, ESP (electronic stability program)	04.99-06.04	0 265 005 404
Wheel speed sensor, front	04.99-06.04	0 265 006 205
Wheel speed sensor, rear	04.99-06.04	0 265 006 206
3.0 i [D9]		3,0l 150 kW XFX 6 Zyl.
Throttle valve assembly	12.99-06.04	0 280 750 041
Knock sensor	12.99-06.04	KZB 0 261 231 071
Pressure sensor, intake manifold, gasoline	12.99-06.04	0 261 230 041
Yaw rate sensor, brake system		
Org.no. →9064	12.99-09.01	0 265 005 290
Org.no. 9065→	10.01-06.04	0 265 005 253
Steering angle sensor, ESP (electronic stability program)	12.99-06.04	0 265 005 404
Wheel speed sensor, front	12.99-06.04	0 265 006 205
Wheel speed sensor, rear	12.99-06.04	0 265 006 206

406 Coupé

1.8 i 16V [D8]		1,8l 81 kW LFY 4 Zyl.
Throttle valve sensor	09.97-03.99	GS 0 280 122 003
Knock sensor	09.97-03.99	AG 0 261 231 109
Pressure sensor, intake manifold, gasoline		
Org.no. →8028	09.97-11.98	0 261 230 012
Wheel speed sensor, front	09.97-03.99	0 265 006 205
Wheel speed sensor, rear	09.97-03.99	0 265 006 206
2.0 i 16V [D8]		2,0l 97-99 kW RFV 4 Zyl.
Knock sensor		
Org.no. →7664	03.97-11.97	0 261 231 109
Org.no. 7665→	12.97-03.99	0 261 231 045
Pressure sensor, intake manifold, gasoline		
Org.no. 7329→	03.97-03.99	0 261 230 012
Wheel speed sensor, front	03.97-03.99	0 265 006 205
Wheel speed sensor, rear	03.97-03.99	0 265 006 206
2.0 i 16V [D9]		2,0l 97-99 kW RFV 4 Zyl.
Throttle valve sensor		
	04.99-02.05	AG 0 280 122 005
		GS 0 280 122 003
Knock sensor	04.99-02.05	0 261 231 130
Pressure sensor, intake manifold, gasoline	04.99-02.05	0 261 230 034
Yaw rate sensor, brake system		
Org.no. →9064	04.99-09.01	0 265 005 290
Org.no. 9065→	10.01-02.05	0 265 005 253

Product



Steering angle sensor, ESP (electronic stability program)	04.99-02.05	0 265 005 404
Wheel speed sensor, front	04.99-02.05	0 265 006 205
Wheel speed sensor, rear	04.99-02.05	0 265 006 206
2.0 i 16V [D9]		2,0l 99 kW RFR 4 Zyl.
Pressure sensor, intake manifold, gasoline	04.99-10.00	0 261 230 034
Yaw rate sensor, brake system	04.99-10.00	0 265 005 290
Steering angle sensor, ESP (electronic stability program)	04.99-10.00	0 265 005 404
Wheel speed sensor, front	04.99-10.00	0 265 006 205
Wheel speed sensor, rear	04.99-10.00	0 265 006 206
2.0 i 16V [D9]		2,0l 100 kW RFN 4 Zyl.
Yaw rate sensor, brake system		
Org.no. →9064	10.00-09.01	0 265 005 290
Org.no. 9065→	10.01-02.05	0 265 005 253
Steering angle sensor, ESP (electronic stability program)	10.00-02.05	0 265 005 404
Wheel speed sensor, front	10.00-02.05	0 265 006 205
Wheel speed sensor, rear	10.00-02.05	0 265 006 206
2.2 HDi [D9]		2,2l 98 kW 4HX 4 Zyl.
High-pressure sensor (CR system)	03.00-02.05	0 281 002 283
Yaw rate sensor, brake system		
Org.no. →9064	03.00-09.01	0 265 005 290
Org.no. 9065→	10.01-02.05	0 265 005 253
Steering angle sensor, ESP (electronic stability program)	03.00-02.05	0 265 005 404
Wheel speed sensor, front	03.00-02.05	0 265 006 205
Wheel speed sensor, rear	03.00-02.05	0 265 006 206
2.2 i 16V [D9]		2,2l 116 kW 3FZ 4 Zyl.
Pressure sensor, intake manifold, gasoline	03.02-02.05	0 261 230 057
Yaw rate sensor, brake system	03.02-02.05	0 265 005 253
Steering angle sensor, ESP (electronic stability program)	03.02-02.05	0 265 005 404
Wheel speed sensor, front	03.02-02.05	0 265 006 205
Wheel speed sensor, rear	03.02-02.05	0 265 006 206
3.0 i [D8]		3,0l 140 kW XFZ 6 Zyl.
Knock sensor	03.97-03.99	0 261 231 125
Pressure sensor, intake manifold, gasoline		
Org.no. →8028	03.97-11.98	0 261 230 012
Wheel speed sensor, front	03.97-03.99	0 265 006 205
Wheel speed sensor, rear	03.97-03.99	0 265 006 206
3.0 i [D9]		3,0l 140 kW XFX 6 Zyl.
Throttle valve sensor	04.99-02.05	0 280 122 009
Knock sensor	04.99-02.05	0 261 231 125
Pressure sensor, intake manifold, gasoline		
	04.99-02.05	0 261 230 034
Yaw rate sensor, brake system		
Org.no. →9064	04.99-09.01	0 265 005 290
Org.no. 9065→	10.01-02.05	0 265 005 253
Steering angle sensor, ESP (electronic stability program)	04.99-02.05	0 265 005 404
Wheel speed sensor, front	04.99-02.05	0 265 006 205
Wheel speed sensor, rear	04.99-02.05	0 265 006 206
3.0 i [D9]		3,0l 150 kW XFX 6 Zyl.
Throttle valve assembly	12.99-02.05	0 280 750 041
Knock sensor	12.99-02.05	KZB 0 261 231 071
Pressure sensor, intake manifold, gasoline	12.99-02.05	0 261 230 041
Yaw rate sensor, brake system		
Org.no. →9064	12.99-09.01	0 265 005 290
Org.no. 9065→	10.01-02.05	0 265 005 253
Steering angle sensor, ESP (electronic stability program)	12.99-02.05	0 265 005 404
Wheel speed sensor, front	12.99-02.05	0 265 006 205
Wheel speed sensor, rear	12.99-02.05	0 265 006 206



Product



407

1.8 i [D2]	1,8 l 85/92 kW 6FY; 6FZ 4 Zyl.
Pressure sensor, intake manifold, gasoline	05.04→ 0 261 230 043
2.0 i [D2]	2,0 l 103 kW RFJ 4 Zyl.
Pressure sensor, intake manifold, gasoline	10.05→ 0 261 230 043
2.2 i [D2]	2,2 l 116 kW 3FZ 4 Zyl.
Pressure sensor, intake manifold, gasoline	05.04→ 0 261 230 057
2.2 i [D2]	2,2 l 120 kW 3FY 4 Zyl.
Pressure sensor, intake manifold, gasoline	10.05→ 0 261 230 043
3.0 i [D2]	3,0 l 155 kW XfV 6 Zyl.
Throttle valve assembly	05.04→ 0 280 750 041
Knock sensor	05.04→ HI, KZB 0 261 231 130 KZG, VO 0 261 231 071
Pressure sensor, intake manifold, gasoline	05.04→ 0 261 230 058

407 Coupé

2.2 i [D2]	2,2 l 120 kW 3FY 4 Zyl.
Pressure sensor, intake manifold, gasoline	10.05→ 0 261 230 043
3.0 i [D2]	3,0 l 155 kW XfV 6 Zyl.
Throttle valve assembly	10.05→ 0 280 750 041
Knock sensor	10.05→ HI, KZB 0 261 231 130 KZG, VO 0 261 231 071
Pressure sensor, intake manifold, gasoline	10.05→ 0 261 230 058

407 SW

1.8 i [D2]	1,8 l 85/92 kW 6FY; 6FZ 4 Zyl.
Pressure sensor, intake manifold, gasoline	05.04→ 0 261 230 043
2.0 i [D2]	2,0 l 103 kW RFJ 4 Zyl.
Pressure sensor, intake manifold, gasoline	10.05→ 0 261 230 043
2.2 i [D2]	2,2 l 116 kW 3FZ 4 Zyl.
Pressure sensor, intake manifold, gasoline	05.04→ 0 261 230 057
2.2 i [D2]	2,2 l 120 kW 3FY 4 Zyl.
Pressure sensor, intake manifold, gasoline	10.05→ 0 261 230 043
3.0 i [D2]	3,0 l 155 kW XfV 6 Zyl.
Throttle valve assembly	05.04→ 0 280 750 041
Knock sensor	05.04→ HI, KZB 0 261 231 130 KZG, VO 0 261 231 071
Pressure sensor, intake manifold, gasoline	05.04→ 0 261 230 058

505

2.0 i	2,0 l 71 kW 4 Zyl.
Speed relay	07.81-06.87 0 280 230 100 0 280 230 101
2.0 i	2,0 l 81/83 kW 829B <ZEJ>; 829-90 <ZEJ> 4 Zyl.
Air flow sensor, gasoline injection	08.79-12.89 0 438 120 099
2.2 i	2,2 l 84 kW 851X <ZDJL Kat.> 4 Zyl.
Throttle valve sensor	03.86-12.93 0 280 120 301
Air flow sensor, gasoline injection	03.86-12.93 KAT 0 280 202 098
Temperature sensor, coolant, injection system	03.86-12.93 0 280 130 026
Relay, Jetronic	03.86-12.93 0 280 230 006 09.87-12.93 0 280 230 014
2.2 i	2,2 l 90-96 kW 851B, 851Y <ZDJL> 4 Zyl.
Throttle valve sensor	08.83-12.93 0 280 120 301
Air flow sensor, gasoline injection	10.85-12.93 AGR, OKA 0 280 202 070 08.83-12.93 OAR 0 280 202 051 0 986 280 051
Temperature sensor, coolant, injection system	08.83-12.93 0 280 130 026
Relay, Jetronic	08.83-12.93 0 280 230 006

Product



2.2 i Turbo	2,2 l 105-116 kW 176W, 176X 4 Zyl.
Throttle valve sensor	03.84-12.88 0 280 120 305
Air flow sensor, gasoline injection	03.84-12.88 0 280 202 057
Knock sensor	01.86-12.88 0 261 231 006
Pressure sensor, intake manifold, gasoline	03.84-12.88 0 280 101 001
Temperature sensor, coolant, injection system	03.84-12.88 0 280 130 026
Relay, Jetronic	03.84-12.88 0 280 230 009
2.2 i Turbo	2,2 l 114-120 kW 176A, 176B, 176C <N9T> 4 Zyl.
Throttle valve sensor	01.83-06.88 0 280 120 305
Air flow sensor, gasoline injection	10.82-06.88 OAR 0 280 202 044
Knock sensor	01.86-06.88 0 261 231 006
Pressure sensor, intake manifold, gasoline	10.82-06.88 0 280 101 001
Temperature sensor, coolant, injection system	01.83-06.88 0 280 130 026
Relay, Jetronic	01.83-06.88 0 280 230 006
2.3 D Turbo	2,3 l 54-59 kW 147 4 Zyl.
Air flow sensor, diesel	09.83-06.86 0 281 002 008
2.5 D Turbo	2,5 l 66-70 kW 152A, 152Y <XD3T> 4 Zyl.
Air flow sensor, diesel	10.83-12.93 0 281 002 008
2.5 D Turbo	2,5 l 77 kW 152B <XD3TE> 4 Zyl.
Air flow sensor, diesel	10.86-12.93 0 281 002 029
Pulse generator, diesel	10.86-12.93 0 281 002 030
Pressure sensor, intake manifold, diesel	10.86-12.93 0 281 002 018
Temperature sensor, coolant, diesel	10.86-12.93 0 280 130 026
Pedal position sensor, diesel	10.86-12.93 0 132 009 305
2.8 i V6	2,8 l 105/122 kW 154F <ZN3J>; 154X <ZN3J Kat.> 6 Zyl.
Throttle valve sensor	06.86-12.93 0 280 120 301
Air mass meter, gasoline injection	06.86-12.93 0 280 213 006 0 986 280 115
Speed sensor, ignition/injection	06.86-12.93 0 261 210 029
Knock sensor	06.86-12.93 0 261 231 007
Temperature sensor, coolant, injection system	06.86-12.93 0 280 130 032

604

2.8 i V6	2,8 l 110-114 kW 154A <ZNJK> 6 Zyl.
Air flow sensor, gasoline injection	06.83-06.86 0 438 120 065
Speed relay	06.83-06.86 0 280 230 112
Relay, Jetronic	06.83-06.86 0 280 230 112

605

2.0 [Y30]	2,0 l 79/84 kW R2A <XU102C>; R5A <XU102C> 4 Zyl.
Wheel speed sensor, front	10.89-05.99 BO 0 265 006 207
Wheel speed sensor, rear	10.89-05.99 BO 0 265 006 208
2.0 i [Y30]	2,0 l 79 kW RDZ <XU10M KAT.> 4 Zyl.
Temperature sensor, intake air, injection system	06.89-06.94 0 280 130 039
Wheel speed sensor, front	06.89-06.94 BO 0 265 006 207
Wheel speed sensor, rear	06.89-06.94 BO 0 265 006 208
2.0 i [Y30]	2,0 l 89-90 kW RFZ <XU10J2 KAT.> 4 Zyl.
Throttle valve sensor	06.89-06.94 0 280 122 001
Pressure sensor, intake manifold, gasoline	06.93-06.94 0 261 230 004
Temperature sensor, intake air, injection system	06.89-06.94 0 280 130 039
Wheel speed sensor, front	06.89-06.94 BO 0 265 006 207
Wheel speed sensor, rear	06.89-06.94 BO 0 265 006 208
2.0 i [Y30]	2,0 l 94 kW R6A <XU10J2> 4 Zyl.
Throttle valve sensor	10.89-05.99 AG 0 280 120 323 10.89-06.90 GS 0 280 120 323
Air flow sensor, gasoline injection	10.89-06.90 0 280 202 118 0 986 280 057 10.89-05.99 AG 0 280 202 118 0 986 280 057
Temperature sensor, intake air, injection system	10.89-05.99 0 280 130 039

Product				
◀ 605				
Temperature sensor, coolant, injection system	10.89-09.90			0 280 130 026
	10.89-05.99	AG		0 280 130 026
Wheel speed sensor, front	10.89-05.99	BO		0 265 006 207
Wheel speed sensor, rear	10.89-05.99	BO		0 265 006 208
2.0 i Turbo [Y30]	2,0 l	104 kW	RGY <XU10J2TE KAT.>	4 Zyl.
Throttle valve sensor	07.92-06.94			0 280 122 001
Knock sensor	07.92-06.94	KZG		0 261 231 071
Wheel speed sensor, front	07.92-06.94	BO		0 265 006 207
Wheel speed sensor, rear	07.92-06.94	BO		0 265 006 208
2.0 i Turbo [Y30]	2,0 l	104-110 kW	RGX <XU10J2TE KAT.>	4 Zyl.
Throttle valve sensor	07.94-06.95			0 280 122 001
	07.95-05.99			0 280 122 003
Knock sensor	07.94-05.99			0 261 231 109
Wheel speed sensor, front	07.94-05.99	BO		0 265 006 207
Wheel speed sensor, rear	07.94-05.99	BO		0 265 006 208
2.0 i 16V [Y30]	2,0 l	97 kW	RFV,R6E <XU10J4R KAT.>	4 Zyl.
Throttle valve sensor	07.94-05.99			0 280 122 003
Knock sensor				
Org.no. →8133	07.94-02.99			0 261 231 109
Org.no. 8134→	03.99-05.99			0 261 231 130
Pressure sensor, intake manifold, gasoline				
Org.no. 7329→8056	01.97-12.98			0 261 230 012
Org.no. 8057→	01.99-05.99			0 261 230 057
Wheel speed sensor, front	07.94-05.99	BO		0 265 006 207
Wheel speed sensor, rear	07.94-05.99	BO		0 265 006 208
2.1 D [Y30]	2,1 l	60-61 kW	PJZ,P9A <XUD11A>	4 Zyl.
Wheel speed sensor, front	06.89-06.94	BO		0 265 006 207
Wheel speed sensor, rear	06.89-06.94	BO		0 265 006 208
2.1 D Turbo [Y30]	2,1 l	80-81 kW	PHZ,P8A,P8B <XUD11ATE>	4 Zyl.
Wheel speed sensor, front	06.89-10.96	BO		0 265 006 207
Wheel speed sensor, rear	06.89-10.96	BO		0 265 006 208
2.1 D Turbo [Y30]	2,1 l	80-81 kW	P8C <XUD11BTE>	4 Zyl.
Temperature sensor, intake air, diesel	07.94-05.99			0 280 130 039
Pedal position sensor, diesel				
Org.no. →6992	07.94-12.95	GS		0 205 001 015
Wheel speed sensor, front	07.94-05.99	BO		0 265 006 207
Wheel speed sensor, rear	07.94-05.99	BO		0 265 006 208
2.5 D Turbo [Y30]	2,5 l	94-96 kW	THY <DK5ATE>	4 Zyl.
Air flow sensor, diesel	07.94-05.99			0 281 002 128
Pressure sensor, intake manifold, diesel	07.94-05.99	N03,N07		0 281 002 063
		N05		0 281 002 122
Temperature sensor, intake air, diesel	07.94-05.99			0 280 130 039
Pedal position sensor, diesel	07.94-05.99			0 205 001 015
Wheel speed sensor, front	07.94-05.99	BO		0 265 006 207
Wheel speed sensor, rear	07.94-05.99	BO		0 265 006 208
3.0 i [Y30]	3,0 l	123 kW	SFZ <ZPJ KAT.>	6 Zyl.
Knock sensor	10.89-01.91	KZB		0 261 231 033
		KZU		0 261 231 034
Temperature sensor, intake air, injection system	10.89-10.93			0 280 130 039
Wheel speed sensor, front	10.89-10.93	BO		0 265 006 207
Wheel speed sensor, rear	10.89-10.93	BO		0 265 006 208
3.0 i [Y30]	3,0 l	123-125 kW	UFZ <ZPJ KAT.>	6 Zyl.
Throttle valve sensor	07.93-05.99	ASR		0 280 122 005
		OAS		0 280 122 003
Knock sensor	07.93-05.99	KZB		0 261 231 070
		KZG		0 261 231 071
Temperature sensor, intake air, injection system	07.93-05.99			0 280 130 039
Wheel speed sensor, front	07.93-05.99	BO		0 265 006 207
Wheel speed sensor, rear	07.93-05.99	BO		0 265 006 208
3.0 i [Y30]	3,0 l	125 kW	S6A <ZPJ>	6 Zyl.
Temperature sensor, intake air, injection system	10.89-10.93			0 280 130 039
Wheel speed sensor, front	10.89-10.93	BO		0 265 006 207
Wheel speed sensor, rear	10.89-10.93	BO		0 265 006 208



Product				
607				
3.0 i [Y30]	3,0 l	140-143 kW	XFZ <ES9J4>	6 Zyl.
Throttle valve sensor	03.97-05.99			0 280 122 009
Knock sensor	03.97-05.99	KZG		0 261 231 125
Pressure sensor, intake manifold, gasoline	03.97-05.99			0 261 230 012
Wheel speed sensor, front	03.97-05.99	BO		0 265 006 207
Wheel speed sensor, rear	03.97-05.99	BO		0 265 006 208
3.0 i 24V [Y30]	3,0 l	147 kW	SKZ <ZPJ4 KAT.>	6 Zyl.
Knock sensor	06.90-01.91	KZB		0 261 231 033
		KZU		0 261 231 034
Temperature sensor, intake air, injection system	06.90-09.93			0 280 130 039
Wheel speed sensor, front	06.90-09.93	BO		0 265 006 207
Wheel speed sensor, rear	06.90-09.93	BO		0 265 006 208
3.0 i 24V [Y30]	3,0 l	147 kW	UKZ <ZPJ4 KAT.>	6 Zyl.
Throttle valve sensor	07.93-05.99	ASR		0 280 122 005
Knock sensor	07.93-05.99	KZB		0 261 231 070
		KZG		0 261 231 071
Temperature sensor, intake air, injection system	07.93-05.99			0 280 130 039
Wheel speed sensor, front	07.93-05.99	BO		0 265 006 207
Wheel speed sensor, rear	07.93-05.99	BO		0 265 006 208
607				
2.0 HDi [Z8]	2,0 l	79/80 kW	RHS; RHZ	4 Zyl.
High-pressure sensor (CR system)	03.00-11.04			0 281 002 283
Yaw rate sensor, brake system	03.00-11.04			0 265 005 290
Steering angle sensor, ESP (electronic stability program)	03.00-11.04			0 265 005 404
Wheel speed sensor, front	03.00-11.04			0 265 006 544
Wheel speed sensor, rear	03.00-11.04			0 265 006 545
2.0 HDi [Z9]	2,0 l	79 kW	RHS	4 Zyl.
High-pressure sensor (CR system)	12.04→			0 281 002 283
Yaw rate sensor, brake system				
Org.no. →10919	12.04→			0 265 005 606
Org.no. 10920→	12.04→			0 265 005 629
2.0 HDi [Z9]	2,0 l	100 kW	RHR / RHL	4 Zyl.
Yaw rate sensor, brake system				
Org.no. →10919	03.06→			0 265 005 606
Org.no. 10920→	03.06→			0 265 005 629
2.0 i 16V [Z8]	2,0 l	100 kW	RFN	4 Zyl.
Pressure sensor, intake manifold, gasoline	03.00-11.04			0 261 230 057
Yaw rate sensor, brake system	03.00-11.04			0 265 005 290
Steering angle sensor, ESP (electronic stability program)	03.00-11.04			0 265 005 404
Wheel speed sensor, front	03.00-11.04			0 265 006 544
Wheel speed sensor, rear	03.00-11.04			0 265 006 545
2.2 HDi [Z8]	2,2 l	98 kW	4HX	4 Zyl.
High-pressure sensor (CR system)	03.00-11.04			0 281 002 283
Yaw rate sensor, brake system	03.00-11.04			0 265 005 290
Steering angle sensor, ESP (electronic stability program)	03.00-11.04			0 265 005 404
Wheel speed sensor, front	03.00-11.04			0 265 006 544
Wheel speed sensor, rear	03.00-11.04			0 265 006 545
2.2 HDi [Z9]	2,2 l	98 kW	4HX	4 Zyl.
High-pressure sensor (CR system)	12.04→			0 281 002 283
Yaw rate sensor, brake system				
Org.no. →10919	12.04→			0 265 005 606
Org.no. 10920→	12.04→			0 265 005 629
2.2 HDi [Z9]	2,2 l	125 kW	4H ...	4 Zyl.
Yaw rate sensor, brake system				
Org.no. →10919	05.06→			0 265 005 606
Org.no. 10920→	05.06→			0 265 005 629



Product



2.2 i [Z9]			2,2 l 116 kW 3FY; 3FZ 4 Zyl.
Pressure sensor, intake manifold, gasoline	12.04→		0 261 230 057
Yaw rate sensor, brake system			
Org.no. →10919	12.04→		0 265 005 606
Org.no. 10920→	12.04→		0 265 005 629
2.2 i 16V [Z8]			2,2 l 116 kW 3FZ 4 Zyl.
Pressure sensor, intake manifold, gasoline	03.00-11.04		0 261 230 034
Yaw rate sensor, brake system	03.00-11.04		0 265 005 290
Steering angle sensor, ESP (electronic stability program)	03.00-11.04		0 265 005 404
Wheel speed sensor, front	03.00-11.04		0 265 006 544
Wheel speed sensor, rear	03.00-11.04		0 265 006 545
2.7 HDi [Z9]			2,7 l 150 kW UHZ 6 Zyl.
Yaw rate sensor, brake system			
Org.no. →10919	12.04→		0 265 005 606
Org.no. 10920→	12.04→		0 265 005 629
3.0 i [Z8]			2,9 l 152 kW XFX 6 Zyl.
Throttle valve assembly	03.00-11.04		0 280 750 041
Knock sensor	03.00-11.04	KZB	0 261 231 071
Pressure sensor, intake manifold, gasoline	03.00-11.04		0 261 230 041
Yaw rate sensor, brake system	03.00-11.04		0 265 005 290
Steering angle sensor, ESP (electronic stability program)	03.00-11.04		0 265 005 404
Wheel speed sensor, front	03.00-11.04		0 265 006 544
Wheel speed sensor, rear	03.00-11.04		0 265 006 545
3.0 i [Z9]			3,0 l 155 kW XFX 6 Zyl.
Throttle valve assembly	12.04→		0 280 750 041
Knock sensor	12.04→	HI, KZB	0 261 231 130
Pressure sensor, intake manifold, gasoline	12.04→		0 261 230 058
Yaw rate sensor, brake system			
Org.no. →10919	12.04→		0 265 005 606
Org.no. 10920→	12.04→		0 265 005 629

806

1.8 i [U60]			1,8 l 73 kW LFW 4 Zyl.
Wheel speed sensor, front			
Org.no. 7481→	06.97-08.02	BO	0 265 006 388
Wheel speed sensor, rear			
Org.no. 7481→7601	06.97-09.97	BO	0 265 006 426
Org.no. 7602→	10.97-08.02	BO	0 265 006 504
1.9 D Turbo [U60]			1,9 l 66-68 kW DHX; D8B 4 Zyl.
Wheel speed sensor, front			
Org.no. 7481→	06.97-08.02	BO	0 265 006 388
Wheel speed sensor, rear			
Org.no. 7481→7601	06.97-09.97	BO	0 265 006 426
Org.no. 7602→	10.97-08.02	BO	0 265 006 504
2.0 HDi [U60]			2,0 l 80 kW RHZ 4 Zyl.
High-pressure sensor (CR system)	08.99-08.02	BO	0 281 002 283
Wheel speed sensor, front	08.99-08.02		0 265 006 388
Wheel speed sensor, rear	08.99-08.02		0 265 006 504
2.0 HDi [U60]			2,0 l 81 kW RHW 4 Zyl.
High-pressure sensor (CR system)	06.00-08.02		0 281 002 283
Wheel speed sensor, front	06.00-08.02		0 265 006 388
Wheel speed sensor, rear	06.00-08.02		0 265 006 504
2.0 i [U60]			2,0 l 89-90 kW RFU 4 Zyl.
Knock sensor			
Org.no. →8133	06.94-02.99		0 261 231 071
Org.no. 8134→	03.99-08.02		0 261 231 130
Wheel speed sensor, front			
Org.no. 7481→	06.97-08.02	BO	0 265 006 388

Product



Wheel speed sensor, rear			
Org.no. 7481→7601	06.97-09.97	BO	0 265 006 426
Org.no. 7602→	10.97-08.02	BO	0 265 006 504
2.0 i Turbo [U60]			2,0 l 108-110 kW RGX 4 Zyl.
Throttle valve sensor			
Org.no. →6778	06.94-06.95		0 280 122 001
Org.no. 6779→	07.95-08.02		0 280 122 003
Knock sensor			
Org.no. →8133	06.94-02.99		0 261 231 071
Org.no. 8134→	03.99-08.02		0 261 231 130
Wheel speed sensor, front			
Org.no. 7481→	06.97-08.02	BO	0 265 006 388
Wheel speed sensor, rear			
Org.no. 7481→7601	06.97-09.97	BO	0 265 006 426
Org.no. 7602→	10.97-08.02	BO	0 265 006 504
2.0 i 16V [U60]			2,0 l 97-99 kW RFV 4 Zyl.
Throttle valve sensor	05.98-09.00		0 280 122 003
Knock sensor			
Org.no. →8133	05.98-02.99		0 261 231 109
Org.no. 8134→	03.99-09.00	EFV	0 261 231 130
Pressure sensor, intake manifold, gasoline			
Org.no. →8056	05.98-12.98		0 261 230 012
Org.no. 8057→	01.99-09.00		0 261 230 057
Wheel speed sensor, front	05.98-09.00		0 265 006 388
Wheel speed sensor, rear	05.98-09.00		0 265 006 504
2.0 i 16V [U60]			2,0 l 100 kW RFN 4 Zyl.
Pressure sensor, intake manifold, gasoline	09.00-08.02		0 261 230 057
Wheel speed sensor, front	09.00-08.02		0 265 006 388
Wheel speed sensor, rear	09.00-08.02		0 265 006 504
2.1 D Turbo [U60]			2,1 l 80 kW P8C 4 Zyl.
Temperature sensor, intake air, diesel	04.96-08.00		0 280 130 039
Wheel speed sensor, front			
Org.no. 7481→	06.97-08.00	BO	0 265 006 388
Wheel speed sensor, rear			
Org.no. 7481→7601	06.97-09.97	BO	0 265 006 426
Org.no. 7602→	10.97-08.00	BO	0 265 006 504

807

2.0 HDi [V2]			2,0 l 81 kW RHT / RHM; RHW 4 Zyl.
High-pressure sensor (CR system)	06.02→		0 281 002 283
Yaw rate sensor, brake system			
Org.no. →10562	06.02-10.05		0 265 005 290
Org.no. 10563→	11.05→		0 265 005 606
Wheel speed sensor, front	06.02→	LAB	0 265 007 083
		RAB	0 265 007 084
2.0 HDi [V2]			2,0 l 88/100 kW RHK; RHR 4 Zyl.
Yaw rate sensor, brake system	03.06→		0 265 005 606
Wheel speed sensor, front	03.06→	LAB	0 265 007 083
		RAB	0 265 007 084
2.0 i 16V [V2]			2,0 l 100 kW RFN 4 Zyl.
Pressure sensor, intake manifold, gasoline	06.02→		0 261 230 058
Yaw rate sensor, brake system	06.02→		0 265 005 290
Wheel speed sensor, front	06.02→	LAB	0 265 007 083
		RAB	0 265 007 084
2.0 i 16V [V2]			2,0 l 103 kW RFJ 4 Zyl.
Pressure sensor, intake manifold, gasoline	10.05→		0 261 230 043
Yaw rate sensor, brake system	10.05→		0 265 005 606
Wheel speed sensor, front	10.05→	LAB	0 265 007 083
		RAB	0 265 007 084

Product



◀ 807

2.2 HDi [V2]		2,2l 94 kW 4HW 4 Zyl.
High-pressure sensor (CR system)	06.02→	0 281 002 283
Yaw rate sensor, brake system		
Org.no. →10562	06.02-10.05	0 265 005 290
Org.no. 10563→	11.05→	0 265 005 606
Wheel speed sensor, front	06.02→	LAB 0 265 007 083
		RAB 0 265 007 084
2.2 i 16V [V2]		2,2l 116 kW 3FZ 4 Zyl.
Pressure sensor, intake manifold, gasoline	06.02→	0 261 230 057
Yaw rate sensor, brake system	06.02→	0 265 005 290
Wheel speed sensor, front	06.02→	LAB 0 265 007 083
		RAB 0 265 007 084
3.0 i [V2]		2,9l 152 kW XFW 6 Zyl.
Throttle valve assembly	06.02→	0 280 750 041
Pressure sensor, intake manifold, gasoline	06.02→	0 261 230 058
Yaw rate sensor, brake system	06.02→	0 265 005 290
Wheel speed sensor, front	06.02→	LAB 0 265 007 083
		RAB 0 265 007 084



1007

1.4 i [A8]		1,4l 54/65 kW KFU; KVF 4 Zyl.
Knock sensor	04.05→	0 261 231 168
Pressure sensor, intake manifold, gasoline	04.05→	0 261 230 043
1.6 i [A8]		1,6l 80 kW NFU 4 Zyl.
Throttle valve assembly	04.05→	0 280 750 085
Knock sensor	04.05→	0 261 231 168
Pressure sensor, intake manifold, gasoline	04.05→	0 261 230 043

PONTIAC

Firebird Coupé

5.0i Trans Am		5,0l 142 kW LB9 8 Zyl.
Air mass meter, gasoline injection	09.86-07.89	0 280 213 009
		 0 986 280 105
5.7 GTA		5,7l 168 kW L98 8 Zyl.
Air mass meter, gasoline injection	09.87-07.89	0 280 213 009
		 0 986 280 105

PORSCHE

Boxster

2.5 [986]		2,5l 150 kW M 96.20 6 Zyl.
Throttle valve sensor	10.96-08.99	0 280 122 016
Phase sensor	10.96-08.97	0 232 103 037
	09.97-08.99	NOC 0 232 103 022
Speed sensor, ignition/injection	10.96-08.99	0 261 210 204
		EFV 0 261 210 204
Knock sensor	10.96-08.99	0 261 231 120
		EFV 0 261 231 148
Temperature sensor, intake air, injection system	10.96-08.99	0 280 130 092
Wheel speed sensor	10.96-08.99	0 265 006 344
2.7 [986]		2,7l 162 kW M 96.22 6 Zyl.
Throttle valve assembly	09.99-08.02	0 280 750 007
Throttle valve sensor	09.99-08.02	0 280 122 016
Phase sensor	09.99-08.02	NOC 0 232 103 022
Speed sensor, ignition/injection	09.99-08.02	0 261 210 204
		EFV 0 261 210 204

Product



Knock sensor	09.99-08.02		0 261 231 120
		EFV	0 261 231 148
Temperature sensor, intake air, injection system	09.99-08.02		0 280 130 092
Pedal position sensor, EMS (electronic engine management)	09.99-08.02		0 280 752 010
Wheel speed sensor	09.99-08.01		0 265 006 344
	09.01-08.02	MFD	0 265 006 344
		OFD	0 265 007 439
2.7 [986]	2,7l 168 kW	M 96.23	6 Zyl.
Throttle valve assembly	09.02-08.04		0 280 750 007
Throttle valve sensor	09.02-08.04		0 280 122 016
Phase sensor	09.02-08.04		0 232 103 040
Speed sensor, ignition/injection	09.02-08.04		0 261 210 248
Knock sensor	09.02-08.04		0 261 231 120
		EFV	0 261 231 148
Pedal position sensor, EMS (electronic engine management)	09.02-08.04		0 280 752 010
Wheel speed sensor	09.02-08.04	MFD	0 265 006 344
		OFD	0 265 007 439
2.7 [987]	2,7l 176/180 kW	M 96.25; M 97.20	6 Zyl.
Throttle valve assembly	09.04→		0 280 750 007
Phase sensor	09.04→		0 232 103 057
Knock sensor	09.04→		0 261 231 173
Wheel speed sensor	09.04→		0 265 007 624
3.2 S [986]	3,2l 185 kW	M 96.21	6 Zyl.
Throttle valve assembly	09.99-08.02		0 280 750 007
Throttle valve sensor	09.99-08.02		0 280 122 016
Phase sensor	09.99-08.02	NOC	0 232 103 022
Speed sensor, ignition/injection	09.99-08.02		0 261 210 204
		EFV	0 261 210 204
Knock sensor	09.99-08.02		0 261 231 120
		EFV	0 261 231 148
Temperature sensor, intake air, injection system	09.99-08.02		0 280 130 092
Pedal position sensor, EMS (electronic engine management)	09.99-08.02		0 280 752 010
Wheel speed sensor	09.99-08.01		0 265 006 344
	09.01-08.02	MFD	0 265 006 344
		OFD	0 265 007 439
3.2 S [986]	3,2l 191-196 kW	M 96.24	6 Zyl.
Throttle valve assembly	09.02-08.04		0 280 750 007
Throttle valve sensor	09.02-08.04		0 280 122 016
Phase sensor	09.02-08.04		0 232 103 040
Speed sensor, ignition/injection	09.02-08.04		0 261 210 248
Knock sensor	09.02-08.04		0 261 231 120
		EFV	0 261 231 148
Pedal position sensor, EMS (electronic engine management)	09.02-08.04		0 280 752 010
Wheel speed sensor	09.02-08.04	MFD	0 265 006 344
		OFD	0 265 007 439
3.2 S [987]	3,2l 206 kW	M 96.26	6 Zyl.
Throttle valve assembly	09.04-08.06		0 280 750 007
Phase sensor	09.04-08.06		0 232 103 057
Knock sensor	09.04-08.06		0 261 231 173
Wheel speed sensor	09.04-08.06		0 265 007 624
3.4 S [987]	3,4l 217 kW	M 97.21	6 Zyl.
Throttle valve assembly	09.06→		0 280 750 007
Phase sensor	09.06→		0 232 103 057
Knock sensor	09.06→		0 261 231 173
Wheel speed sensor	09.06→		0 265 007 624



P

Product



Carrera GT

5.7	5,7l 450 kW M80.01 10 Zyl.
Throttle valve assembly	10.04→ 0 280 750 007
Phase sensor	10.04→ 0 232 103 040
Knock sensor	10.04→ 0 261 231 148
Pedal position sensor, EMS (electronic engine management)	10.04→ 0 280 752 010

Cayenne

3.2 [9PA]	3,2l 184 kW M02.2Y 6 Zyl.
Phase sensor	09.02-01.07 0 232 103 019
4.5 S [9PA]	4,5l 250 kW M48.00 8 Zyl.
Air mass meter, gasoline injection	09.02-01.07 0 281 002 435
	0 986 284 006
Phase sensor	09.02-01.07 NOC 0 232 103 022
Speed sensor, ignition/injection	09.02-01.07 0 261 210 239
Knock sensor	09.02-01.07 0 261 231 148
4.5 Turbo [9PA]	4,5l 331/368 kW M48.50 8 Zyl.
Air mass meter, gasoline injection	09.02-01.07 0 280 218 071
	0 986 280 221
Phase sensor	09.02-01.07 NOC 0 232 103 022
Speed sensor, ignition/injection	09.02-01.07 0 261 210 239
Knock sensor	09.02-01.07 0 261 231 148

Cayman

2.7 [987C]	2,7l 180 kW M97.20 6 Zyl.
Phase sensor	09.06→ 0 232 103 057
Speed sensor, ignition/injection	09.06→ 0 261 210 248
Knock sensor	09.06→ 0 261 231 173
Wheel speed sensor	09.06→ 0 265 007 624

Cayman S

3.4 [987C]	3,4l 217 kW M97.21 6 Zyl.
Phase sensor	11.05→ 0 232 103 057
Speed sensor, ignition/injection	11.05→ 0 261 210 248
Knock sensor	11.05→ 0 261 231 173
Wheel speed sensor	11.05→ 0 265 007 624

911

3.2 Carrera	3,2l 152/160/170 kW 930.20; 930.21; 930.25 6 Zyl.
Throttle valve sensor	08.83-07.89 0 280 120 309
Air flow sensor, gasoline injection	08.83-07.89 0 280 203 023
	0 986 280 026
Speed sensor, ignition/injection	08.83-07.89 0 261 210 005
Temperature sensor, cylinder head	08.83-07.89 0 280 130 034
3.2 Carrera	3,2l 170 kW 930.26 6 Zyl.
Air flow sensor, gasoline injection	08.84-07.88 0 280 203 023
	0 986 280 026
Speed sensor, ignition/injection	08.84-07.88 0 261 210 005
Temperature sensor, cylinder head	08.84-07.88 0 280 130 034
3.3 Turbo	3,3l 210 kW 930.68 6 Zyl.
Throttle valve sensor	08.85-08.89 0 280 120 107
3.3 Turbo	3,3l 221 kW 930.66 6 Zyl.
Air flow sensor, gasoline injection	08.82-08.88 0 438 120 085
3.3 Turbo [964]	3,3l 235 kW 30.69 6 Zyl.
Throttle valve sensor	12.90-08.92 0 280 120 107
Speed sensor, ignition/injection	12.90-08.92 0 261 210 059
Knock sensor	12.90-08.92 0 261 231 018

Product



Pressure sensor, intake manifold, gasoline	12.90-08.92 0 280 101 001
Temperature sensor, intake air, injection system	12.90-08.92 0 261 220 002
Wheel speed sensor, front	12.90-08.92 0 265 001 229
Wheel speed sensor, rear	12.90-08.92 0 265 001 146
3.4 24V Carrera [996]	3,4l 220 kW M96.01 6 Zyl.
Throttle valve sensor	09.97-08.99 0 280 122 016
Phase sensor	09.97-08.99 NOC 0 232 103 022
Speed sensor, ignition/injection	09.97-08.99 0 261 210 204
Knock sensor	09.97-08.99 0 261 231 120
Temperature sensor, intake air, injection system	09.97-08.99 0 280 130 092
Wheel speed sensor	09.97-08.99 0 265 006 344
3.4 24V Carrera [996]	3,4l 220 kW M96.04 6 Zyl.
Throttle valve sensor	09.99-08.01 0 280 122 016
Phase sensor	09.99-08.01 NOC 0 232 103 022
Speed sensor, ignition/injection	09.99-08.01 0 261 210 204
Knock sensor	09.99-08.01 0 261 231 120
Temperature sensor, intake air, injection system	09.99-08.01 0 280 130 092
Pedal position sensor, EMS (electronic engine management)	09.99-08.01 0 280 752 010
Wheel speed sensor	09.99-08.01 0 265 006 344
3.4 24V Carrera Cabrio [996]	3,4l 220 kW M96.01 6 Zyl.
Throttle valve sensor	02.98-08.99 0 280 122 016
Phase sensor	02.98-08.99 NOC 0 232 103 022
Speed sensor, ignition/injection	02.98-08.99 0 261 210 204
Knock sensor	02.98-08.99 0 261 231 120
Temperature sensor, intake air, injection system	02.98-08.99 0 280 130 092
Wheel speed sensor	02.98-08.99 0 265 006 344
3.4 24V Carrera 4 [996]	3,4l 220 kW M96.02 6 Zyl.
Throttle valve sensor	09.98-08.99 0 280 122 016
Phase sensor	09.98-08.99 NOC 0 232 103 022
Speed sensor, ignition/injection	09.98-08.99 0 261 210 204
Knock sensor	09.98-08.99 0 261 231 120
Temperature sensor, intake air, injection system	09.98-08.99 0 280 130 092
Lateral acceleration sensor, brake system	09.98-08.99 0 265 005 127
Wheel speed sensor	09.98-08.99 0 265 006 344
3.4 24V Carrera 4 Cabrio [996]	3,4l 220 kW M96.02 6 Zyl.
Throttle valve sensor	09.98-08.99 0 280 122 016
Phase sensor	09.98-08.99 NOC 0 232 103 022
Speed sensor, ignition/injection	09.98-08.99 0 261 210 204
Knock sensor	09.98-08.99 0 261 231 120
Temperature sensor, intake air, injection system	09.98-08.99 0 280 130 092
Pedal position sensor, EMS (electronic engine management)	09.98-08.99 0 280 752 010
Lateral acceleration sensor, brake system	09.98-08.99 0 265 005 127
Wheel speed sensor	09.98-08.99 0 265 006 344
3.6 Carrera [993]	3,6l 200 kW M64.05 / M64.06 6 Zyl.
Throttle valve sensor	09.93-08.95 0 280 122 004
Air mass meter, gasoline injection	09.93-08.95 0 280 217 803
Speed sensor, ignition/injection	09.93-08.95 0 261 210 136
Knock sensor	09.93-08.95 0 261 231 118
Temperature sensor, intake air, injection system	09.93-08.95 0 280 130 073
Lateral acceleration sensor, brake system	09.93-08.95 FMT 0 265 005 108
Wheel speed sensor, rear	09.93-08.95 0 265 006 101
3.6 Carrera [993]	3,6l 200 kW M64.07 / M64.08 6 Zyl.
Throttle valve sensor	09.93-08.95 0 280 122 004
Air mass meter, gasoline injection	09.93-08.95 0 280 217 803
Speed sensor, ignition/injection	09.93-08.95 AG 0 261 210 059
Knock sensor	09.93-08.95 0 261 231 118
Temperature sensor, intake air, injection system	09.93-08.95 0 280 130 073
Lateral acceleration sensor, brake system	09.93-08.95 FMT 0 265 005 108
Wheel speed sensor, rear	09.93-08.95 0 265 006 101


Product				
◀ 911				
3.6 Carrera [993]	3,6 l	210 kW	M64.21 / M64.22	6 Zyl.
Throttle valve sensor	09.95-08.97		0 280 122 004	
Air mass meter, gasoline injection	09.95-08.97		0 280 217 803	
Speed sensor, ignition/injection	09.95-08.97		0 261 210 136	
Knock sensor	09.95-08.97		0 261 231 118	
Temperature sensor, cylinder head	09.95-08.97		0 280 130 097	
Wheel speed sensor, front	09.95-08.97		0 265 006 107	
3.6 Carrera [993]	3,6 l	210 kW	M64.23 / M64.24	6 Zyl.
Throttle valve sensor	09.95-08.97		0 280 122 004	
Air mass meter, gasoline injection	09.95-08.97		0 280 217 803	
Speed sensor, ignition/injection	09.95-08.97	AG	0 261 210 059	
Knock sensor	09.95-08.97		0 261 231 118	
Wheel speed sensor, front	09.95-08.97		0 265 006 107	
3.6 Carrera [996]	3,6 l	235 kW	M96.03	6 Zyl.
Throttle valve sensor	09.01-07.04		0 280 122 016	
Phase sensor	09.01-07.04	NOC	0 232 103 022	
Speed sensor, ignition/injection	09.01-08.02		0 261 210 204	
	09.02-07.04		0 261 210 248	
Knock sensor	09.01-07.04		0 261 231 120	
Temperature sensor, intake air, injection system	09.01-07.04		0 280 130 092	
Pedal position sensor, EMS (electronic engine management)	09.01-07.04		0 280 752 010	
Wheel speed sensor, front	09.01-07.04	MFD	0 265 006 344	
		OFD	0 265 007 439	
Wheel speed sensor, rear	09.01-07.04		0 265 006 344	
3.6 Carrera [996]	3,6 l	254 kW	M96.03	6 Zyl.
Throttle valve sensor	06.02-07.04		0 280 122 016	
Speed sensor, ignition/injection	09.02-07.04		0 261 210 248	
Knock sensor	06.02-07.04		0 261 231 120	
Temperature sensor, intake air, injection system	06.02-07.04		0 280 130 092	
Wheel speed sensor, front	06.02-07.04	MFD	0 265 006 344	
		OFD	0 265 007 439	
Wheel speed sensor, rear	06.02-07.04		0 265 006 344	
3.6 Carrera [997]	3,6 l	235-239 kW	M96.05	6 Zyl.
Phase sensor	08.04→		0 232 103 057	
Speed sensor, ignition/injection	08.04→		0 261 210 248	
Knock sensor	08.04→		0 261 231 173	
Wheel speed sensor	08.04→		0 265 007 624	
3.6 Carrera Cabrio [996]	3,6 l	235 kW	M96.03	6 Zyl.
Throttle valve sensor	09.01-07.04		0 280 122 016	
Phase sensor	09.01-07.04	NOC	0 232 103 022	
Speed sensor, ignition/injection	09.01-08.02		0 261 210 204	
	09.02-07.04		0 261 210 248	
Knock sensor	09.01-07.04		0 261 231 120	
Temperature sensor, intake air, injection system	09.01-07.04		0 280 130 092	
Pedal position sensor, EMS (electronic engine management)	09.01-07.04		0 280 752 010	
Wheel speed sensor, front	09.01-07.04	MFD	0 265 006 344	
		OFD	0 265 007 439	
Wheel speed sensor, rear	09.01-07.04		0 265 006 344	
3.6 Carrera Cabrio [996]	3,6 l	254 kW	M96.03	6 Zyl.
Throttle valve sensor	06.02-07.04		0 280 122 016	
Speed sensor, ignition/injection	09.02-07.04		0 261 210 248	
Knock sensor	06.02-07.04		0 261 231 120	
Temperature sensor, intake air, injection system	06.02-07.04		0 280 130 092	
Wheel speed sensor, front	06.02-07.04	MFD	0 265 006 344	
		OFD	0 265 007 439	
Wheel speed sensor, rear	06.02-07.04		0 265 006 344	
3.6 Carrera Cabrio [997]	3,6 l	235-239 kW	M96.05	6 Zyl.
Phase sensor	04.05→		0 232 103 057	
Speed sensor, ignition/injection	04.05→		0 261 210 248	
Knock sensor	04.05→		0 261 231 173	
Wheel speed sensor	04.05→		0 265 007 624	

Product				
3.6 Carrera Targa [996]	3,6 l	235/254 kW	M96.03	6 Zyl.
Throttle valve sensor	12.01-07.04		0 280 122 016	
Phase sensor	12.01-07.04	NOC	0 232 103 022	
Speed sensor, ignition/injection	12.01-08.02		0 261 210 204	
	09.02-07.04		0 261 210 248	
Knock sensor	12.01-07.04		0 261 231 120	
Temperature sensor, intake air, injection system	12.01-07.04		0 280 130 092	
Pedal position sensor, EMS (electronic engine management)	12.01-07.04		0 280 752 010	
Wheel speed sensor, front	12.01-07.04	MFD	0 265 006 344	
		OFD	0 265 007 439	
Wheel speed sensor, rear	12.01-07.04		0 265 006 344	
3.6 Carrera Turbo 4x4 [997]	3,6 l	353 kW	M97.70	6 Zyl.
Phase sensor	03.06→		0 232 103 040	
Speed sensor, ignition/injection	03.06→	FMT	0 261 210 248	
		GS	0 261 210 205	
Knock sensor	03.06→		0 261 231 148	
Wheel speed sensor	03.06→		0 265 007 624	
3.6 Carrera 2 [964]	3,6 l	184 kW	64.01/.02	6 Zyl.
Throttle valve sensor	09.89-08.93	AG	9 999 999 999	
Speed sensor, ignition/injection	09.89-08.93		0 261 210 059	
Knock sensor	09.89-08.93		0 261 231 018	
Pressure sensor, intake manifold, gasoline	09.89-08.93		0 280 101 001	
Temperature sensor, cylinder head	09.89-08.93		0 280 130 059	
Wheel speed sensor, front	09.89-05.93		0 265 001 229	
	05.93-08.93	LAB	0 265 006 145	
		RAB	0 265 006 144	
Wheel speed sensor, rear	09.89-08.92		0 265 001 230	
	09.92-08.93		0 265 006 146	
3.6 Carrera 2RS [964]	3,6 l	184/191 kW	64.01; 64.03	6 Zyl.
Speed sensor, ignition/injection	08.91-08.93		0 261 210 059	
Knock sensor	08.91-08.93		0 261 231 018	
Pressure sensor, intake manifold, gasoline	08.91-08.93		0 280 101 001	
Temperature sensor, cylinder head	08.91-08.93		0 280 130 059	
Wheel speed sensor, front	08.91-05.93		0 265 001 229	
	05.93-08.93	LAB	0 265 006 145	
		RAB	0 265 006 144	
Wheel speed sensor, rear	08.91-08.92		0 265 001 230	
	09.92-08.93		0 265 006 146	
3.6 Carrera 4 [964]	3,6 l	184 kW	64.01	6 Zyl.
Speed sensor, ignition/injection	09.89-08.93		0 261 210 059	
Knock sensor	09.89-08.93		0 261 231 018	
Pressure sensor, intake manifold, gasoline	09.89-08.93		0 280 101 001	
Temperature sensor, cylinder head	09.89-08.93		0 280 130 059	
Wheel speed sensor, front	09.89-05.93		0 265 001 229	
	05.93-08.93	LAB	0 265 006 145	
		RAB	0 265 006 144	
Wheel speed sensor, rear	09.89-08.92	TKV	0 265 001 230	
	09.92-08.93	TKV	0 265 006 146	
	09.89-08.92	TLV	0 265 001 146	
	09.92-08.93	TLV	0 265 006 142	
3.6 Carrera 4 [993]	3,6 l	200 kW	M64.05	6 Zyl.
Throttle valve sensor	09.94-08.95		0 280 122 004	
Air mass meter, gasoline injection	09.94-08.95		0 280 217 803	
Speed sensor, ignition/injection	09.94-08.95		0 261 210 136	
Knock sensor	09.94-08.95		0 261 231 118	
Temperature sensor, intake air, injection system	09.94-08.95		0 280 130 073	
Lateral acceleration sensor, brake system	09.94-08.95	FMT	0 265 005 108	
Wheel speed sensor, rear	09.94-08.95		0 265 006 101	
3.6 Carrera 4 [993]	3,6 l	200 kW	M64.07	6 Zyl.
Throttle valve sensor	09.94-08.95		0 280 122 004	
Air mass meter, gasoline injection	09.94-08.95		0 280 217 803	
Knock sensor	09.94-08.95		0 261 231 118	





P



Temperature sensor, intake air, injection system	09.94-08.95		0 280 130 073
Lateral acceleration sensor, brake system	09.94-08.95	FMT	0 265 005 108
Wheel speed sensor, rear	09.94-08.95		0 265 006 101
3.6 Carrera 4 [993]	3,6 l 210 kW		M64.21 6 Zyl.
Throttle valve sensor	09.95-08.97		0 280 122 004
Air mass meter, gasoline injection	09.95-08.97		0 280 217 803
Speed sensor, ignition/injection	09.95-08.97		0 261 210 136
Knock sensor	09.95-08.97		0 261 231 118
Temperature sensor, cylinder head	09.95-08.97		0 280 130 097
Wheel speed sensor, front	09.95-08.97		0 265 006 107
3.6 Carrera 4 [993]	3,6 l 210 kW		M64.23 6 Zyl.
Throttle valve sensor	09.95-08.97		0 280 122 004
Air mass meter, gasoline injection	09.95-08.97		0 280 217 803
Knock sensor	09.95-08.97		0 261 231 118
Wheel speed sensor, front	09.95-08.97		0 265 006 107
3.6 Carrera 4 [996]	3,6 l 235 kW		M96.03 6 Zyl.
Throttle valve sensor	09.01-07.04		0 280 122 016
Phase sensor	09.01-07.04	NOC	0 232 103 022
Speed sensor, ignition/injection	09.01-08.02		0 261 210 204
	09.02-07.04		0 261 210 248
Knock sensor	09.01-07.04		0 261 231 120
Temperature sensor, intake air, injection system	09.01-07.04		0 280 130 092
Pedal position sensor, EMS (electronic engine management)	09.01-07.04		0 280 752 010
Wheel speed sensor, front	09.01-07.04	MFD	0 265 006 344
		OFD	0 265 007 439
Wheel speed sensor, rear	09.01-07.04		0 265 006 344
3.6 Carrera 4 [996]	3,6 l 254 kW		M96.03 6 Zyl.
Throttle valve sensor	06.02-07.04		0 280 122 016
Speed sensor, ignition/injection	09.02-07.04		0 261 210 248
Knock sensor	06.02-07.04		0 261 231 120
Temperature sensor, intake air, injection system	06.02-07.04		0 280 130 092
Wheel speed sensor, front	06.02-07.04	MFD	0 265 006 344
		OFD	0 265 007 439
Wheel speed sensor, rear	06.02-07.04		0 265 006 344
3.6 Carrera 4 [997]	3,6 l 235-239 kW		M96.05 6 Zyl.
Phase sensor	08.04→		0 232 103 057
Speed sensor, ignition/injection	08.04→		0 261 210 248
Knock sensor	08.04→		0 261 231 173
Wheel speed sensor	08.04→		0 265 007 624
3.6 Carrera 4 Cabrio [996]	3,6 l 235 kW		M96.03 6 Zyl.
Throttle valve sensor	09.01-07.04		0 280 122 016
Phase sensor	09.01-07.04	NOC	0 232 103 022
Speed sensor, ignition/injection	09.01-08.02		0 261 210 204
	09.02-07.04		0 261 210 248
Knock sensor	09.01-07.04		0 261 231 120
Temperature sensor, intake air, injection system	09.01-07.04		0 280 130 092
Pedal position sensor, EMS (electronic engine management)	09.01-07.04		0 280 752 010
Wheel speed sensor, front	09.01-07.04	MFD	0 265 006 344
		OFD	0 265 007 439
Wheel speed sensor, rear	09.01-07.04		0 265 006 344
3.6 Carrera 4 Cabrio [996]	3,6 l 254 kW		M96.03 6 Zyl.
Throttle valve sensor	06.02-07.04		0 280 122 016
Phase sensor	06.02-07.04	NOC	0 232 103 022
Speed sensor, ignition/injection	06.02-08.02		0 261 210 204
	09.02-07.04		0 261 210 248
Knock sensor	06.02-07.04		0 261 231 120
Temperature sensor, intake air, injection system	06.02-07.04		0 280 130 092
Wheel speed sensor, front	06.02-07.04	MFD	0 265 006 344
		OFD	0 265 007 439
Wheel speed sensor, rear	06.02-07.04		0 265 006 344



3.6 Carrera 4 Cabrio [997]	3,6 l 235-239 kW		M96.05 6 Zyl.
Phase sensor	08.04→		0 232 103 057
Speed sensor, ignition/injection	08.04→		0 261 210 248
Knock sensor	08.04→		0 261 231 173
Wheel speed sensor	08.04→		0 265 007 624
3.6 Carrera 4 S [996]	3,6 l 235 kW		M96.03 6 Zyl.
Throttle valve sensor	09.01-07.04		0 280 122 016
Phase sensor	09.01-07.04	NOC	0 232 103 022
Speed sensor, ignition/injection	09.01-08.02		0 261 210 204
	09.02-07.04		0 261 210 248
	09.01-08.02	EFV	0 261 210 204
Knock sensor	09.01-07.04		0 261 231 120
Temperature sensor, intake air, injection system	09.01-07.04		0 280 130 092
Pedal position sensor, EMS (electronic engine management)	09.01-07.04		0 280 752 010
Wheel speed sensor, front	09.01-07.04	MFD	0 265 006 344
		OFD	0 265 007 439
Wheel speed sensor, rear	09.01-07.04		0 265 006 344
3.6 Carrera 4 S [996]	3,6 l 254 kW		M96.03 6 Zyl.
Throttle valve sensor	06.02-07.04		0 280 122 016
Speed sensor, ignition/injection	09.02-07.04		0 261 210 248
Knock sensor	06.02-07.04		0 261 231 120
Temperature sensor, intake air, injection system	06.02-07.04		0 280 130 092
Wheel speed sensor, front	06.02-07.04	MFD	0 265 006 344
		OFD	0 265 007 439
Wheel speed sensor, rear	06.02-07.04		0 265 006 344
3.6 Carrera 4 S Cabrio [996]	3,6 l 235 kW		M96.03 6 Zyl.
Throttle valve sensor	10.03-07.04		0 280 122 016
Phase sensor	10.03-07.04	NOC	0 232 103 022
Speed sensor, ignition/injection	10.03-07.04		0 261 210 248
Knock sensor	10.03-07.04		0 261 231 120
Temperature sensor, intake air, injection system	10.03-07.04		0 280 130 092
Wheel speed sensor, front	10.03-07.04	MFD	0 265 006 344
		OFD	0 265 007 439
Wheel speed sensor, rear	10.03-07.04		0 265 006 344
3.6 Carrera 4S [993]	3,6 l 210 kW		M64.21 6 Zyl.
Throttle valve sensor	09.95-08.97		0 280 122 004
Air mass meter, gasoline injection	09.95-08.97		0 280 217 803
Speed sensor, ignition/injection	09.95-08.97		0 261 210 136
Knock sensor	09.95-08.97		0 261 231 118
Temperature sensor, cylinder head	09.95-08.97		0 280 130 097
Wheel speed sensor, front	09.95-08.97		0 265 006 107
3.6 GT2 [996T/GT2, 3]	3,6 l 340 kW		M96.70/S 6 Zyl.
Throttle valve assembly	06.01→		0 280 750 007
Speed sensor, ignition/injection	06.01→		0 261 210 205
Knock sensor	06.01→		0 261 231 148
Pedal position sensor, EMS (electronic engine management)	06.01→		0 280 752 010
Wheel speed sensor	06.01-08.03		0 265 006 344
	09.03→		0 265 007 439
3.6 GT2 [996T/GT2, 3]	3,6 l 355 kW		M96.70/S 6 Zyl.
Throttle valve assembly	10.03→		0 280 750 007
Speed sensor, ignition/injection	10.03→		0 261 210 205
Knock sensor	10.03→		0 261 231 148
Pedal position sensor, EMS (electronic engine management)	10.03→		0 280 752 010
Wheel speed sensor	10.03→		0 265 007 439
3.6 GT3 [996T/GT2, 3]	3,6 l 265 kW		M96.76 6 Zyl.
Throttle valve sensor	03.99-08.01		0 280 122 016
Speed sensor, ignition/injection	03.99-08.01		0 261 210 205
Knock sensor	03.99-08.01		0 261 231 148
Temperature sensor, intake air, injection system	03.99-08.01		0 280 130 092
Wheel speed sensor	03.99-08.01		0 265 006 344



Product

◀ 911


3.6 GT3 [996T/GT2, 3]		3,6l 280 kW M96.79 6 Zyl.
Throttle valve sensor	09.03→	0 280 122 016
Speed sensor, ignition/injection	09.03→	0 261 210 249
Knock sensor	09.03→	0 261 231 148
Wheel speed sensor	09.03→	0 265 006 344
3.6 GT3 [997 GT3]		3,6l 305 kW M97.76 6 Zyl.
Phase sensor	03.06→	0 232 103 057
Speed sensor, ignition/injection	03.06→	0 261 210 249
Knock sensor	03.06→	0 261 231 148
Wheel speed sensor	03.06→	0 265 007 624
3.6 Targa [993]		3,6l 210 kW M64.21 / M64.22 6 Zyl.
Throttle valve sensor	09.95-08.97	0 280 122 004
Air mass meter, gasoline injection	09.95-08.97	0 280 217 803
Speed sensor, ignition/injection	09.95-08.97	0 261 210 136
Knock sensor	09.95-08.97	0 261 231 118
Temperature sensor, cylinder head	09.95-08.97	0 280 130 097
Wheel speed sensor, front	09.95-08.97	0 265 006 107
3.6 Targa [993]		3,6l 210 kW M64.23 / M64.24 6 Zyl.
Throttle valve sensor	09.95-08.97	0 280 122 004
Air mass meter, gasoline injection	09.95-08.97	0 280 217 803
Speed sensor, ignition/injection	09.95-08.97 AG	0 261 210 059
Knock sensor	09.95-08.97	0 261 231 118
Wheel speed sensor, front	09.95-08.97	0 265 006 107
3.6 Targa 4 [993]		3,6l 210 kW M64.21 6 Zyl.
Throttle valve sensor	09.95-08.97	0 280 122 004
Air mass meter, gasoline injection	09.95-08.97	0 280 217 803
Speed sensor, ignition/injection	09.95-08.97	0 261 210 136
Knock sensor	09.95-08.97	0 261 231 118
Temperature sensor, cylinder head	09.95-08.97	0 280 130 097
Wheel speed sensor, front	09.95-08.97	0 265 006 107
3.6 Targa 4 [993]		3,6l 210 kW M64.23 6 Zyl.
Throttle valve sensor	09.95-08.97	0 280 122 004
Air mass meter, gasoline injection	09.95-08.97	0 280 217 803
Knock sensor	09.95-08.97	0 261 231 118
Wheel speed sensor, front	09.95-08.97	0 265 006 107
3.6 Targa 4 [997]		3,6l 235-239 kW M96.05 6 Zyl.
Phase sensor	08.06→	0 232 103 057
Speed sensor, ignition/injection	08.06→	0 261 210 248
Knock sensor	08.06→	0 261 231 173
Wheel speed sensor	08.06→	0 265 007 624
3.6 Turbo [964]		3,6l 265 kW 64.50 6 Zyl.
Throttle valve sensor	02.93-08.93	0 280 120 107
Air flow sensor, gasoline injection	02.93-08.93	0 438 120 221
Pressure sensor, intake manifold, gasoline	02.93-08.93	0 280 101 001
Temperature sensor, intake air, injection system	02.93-08.93	0 261 220 002
Wheel speed sensor, front	02.93-05.93	0 265 001 229
	05.93-08.93 LAB	0 265 006 145
	RAB	0 265 006 144
Wheel speed sensor, rear	02.93-08.93	0 265 006 142
3.6 Turbo [993]		3,6l 300 kW M64.60 6 Zyl.
Throttle valve sensor	09.94-08.97	0 280 122 004
Air mass meter, gasoline injection	09.94-08.97	0 280 217 809
Speed sensor, ignition/injection	09.94-08.97	0 261 210 136
Knock sensor	09.94-08.97	0 261 231 118
Temperature sensor, intake air, injection system	09.94-08.97	0 280 130 085
Temperature sensor, cylinder head	09.95-08.97	0 280 130 097
Wheel speed sensor, front	09.95-08.97	0 265 006 107
Wheel speed sensor, rear	09.94-08.95	0 265 006 101
3.6 Turbo Cabrio 4x4 [996T/GT2, 3]		3,6l 309 kW M96.70 6 Zyl.
Throttle valve assembly	10.03→	0 280 750 007
Speed sensor, ignition/injection	10.03→	FMT 0 261 210 248
		GS 0 261 210 205
Knock sensor	10.03→	0 261 231 148

Product

Pedal position sensor, EMS (electronic engine management)	10.03→	0 280 752 010
Wheel speed sensor	10.03→	0 265 007 439
3.6 Turbo Coupé 4x4 [996T/GT2, 3]		3,6l 309 kW M96.70 6 Zyl.
Throttle valve assembly	06.00→	0 280 750 007
Phase sensor	06.00→	NOC 0 232 103 022
Speed sensor, ignition/injection	06.00-08.02	FMT 0 261 210 204
	09.02→	FMT 0 261 210 248
	06.00→	GS 0 261 210 205
Knock sensor	06.00→	0 261 231 148
Pedal position sensor, EMS (electronic engine management)	06.00→	0 280 752 010
Wheel speed sensor	06.00-08.03	0 265 006 344
	09.03→	0 265 007 439
3.6 Turbo GT2 Carrera [993]		3,6l 316 kW M64.60R 6 Zyl.
Throttle valve sensor	01.95-05.97	0 280 122 004
Air mass meter, gasoline injection	01.95-05.97	0 280 217 809
Speed sensor, ignition/injection	01.95-05.97	0 261 210 136
Knock sensor	01.95-05.97	0 261 231 118
Temperature sensor, intake air, injection system	01.95-05.97	0 280 130 085
Temperature sensor, cylinder head	09.95-05.97	0 280 130 097
Wheel speed sensor, front	09.95-05.97	0 265 006 107
Wheel speed sensor, rear	01.95-08.95	0 265 006 101
3.6 Turbo S Cabrio 4x4 [996T/GT2, 3]		3,6l 331 kW M96.70E 6 Zyl.
Throttle valve assembly	10.03→	0 280 750 007
Speed sensor, ignition/injection	10.03→	FMT 0 261 210 248
		GS 0 261 210 205
Knock sensor	10.03→	0 261 231 148
Pedal position sensor, EMS (electronic engine management)	10.03→	0 280 752 010
Wheel speed sensor	10.03→	0 265 007 439
3.6 Turbo S Coupé 4x4 [996T/GT2, 3]		3,6l 331 kW M96.70E 6 Zyl.
Throttle valve assembly	02.03→	0 280 750 007
Speed sensor, ignition/injection	02.03→	FMT 0 261 210 248
		GS 0 261 210 205
Knock sensor	02.03→	0 261 231 148
Pedal position sensor, EMS (electronic engine management)	02.03→	0 280 752 010
Wheel speed sensor	02.03-08.03	0 265 006 344
	09.03→	0 265 007 439
3.8 Carrera RS [993]		3,8l 220 kW M64.20 6 Zyl.
Throttle valve sensor	09.94-08.97	0 280 122 004
Air mass meter, gasoline injection	09.94-08.97	0 280 217 803
Speed sensor, ignition/injection	09.94-08.97	0 261 210 136
Knock sensor	09.94-08.97	0 261 231 118
Temperature sensor, cylinder head	09.95-08.97	0 280 130 097
Wheel speed sensor, front	09.95-08.97	0 265 006 107
Wheel speed sensor, rear	09.94-08.95	0 265 006 101
3.8 Carrera S [997]		3,8l 261 kW M97.01 6 Zyl.
Phase sensor	08.04→	0 232 103 057
Speed sensor, ignition/injection	08.04→	0 261 210 248
Knock sensor	08.04→	0 261 231 173
Wheel speed sensor	08.04→	0 265 007 624
3.8 Carrera S Cabrio [997]		3,8l 261 kW M97.01 6 Zyl.
Phase sensor	04.05→	0 232 103 057
Speed sensor, ignition/injection	04.05→	0 261 210 248
Knock sensor	04.05→	0 261 231 173
Wheel speed sensor	04.05→	0 265 007 624
3.8 Carrera 4S, Cabrio [997]		3,8l 261 kW M97.01 6 Zyl.
Phase sensor	10.05→	0 232 103 057
Speed sensor, ignition/injection	10.05→	0 261 210 248
Knock sensor	10.05→	0 261 231 173
Wheel speed sensor	10.05→	0 265 007 624



P




3.8 Targa 4S [997]		
	3,8l 261 kW M97.01 6 Zyl.	
Phase sensor	08.06→	0 232 103 057
Speed sensor, ignition/injection	08.06→	0 261 210 248
Knock sensor	08.06→	0 261 231 173
Wheel speed sensor	08.06→	0 265 007 624

924

2.5 S		
	2,5l 110/118 kW M 44.07/.08; M 44.09/.10 4 Zyl.	
Throttle valve sensor	09.85-07.88	0 280 120 308
Air flow sensor, gasoline injection	09.85-07.88	0 280 202 064
		0 986 280 041
Speed sensor, ignition/injection	09.85-07.88	0 261 210 003
Temperature sensor, coolant, injection system	09.85-07.88	0 280 130 026

928

4.7 S		
	4,7l 228 kW M 28.21,.22 8 Zyl.	
Throttle valve sensor	08.83-07.86	0 280 120 308
Air mass meter, gasoline injection	08.83-07.86	0 280 214 001
		0 986 280 124
Speed sensor, ignition/injection	08.83-07.86	0 261 210 003
Temperature sensor, intake air, injection system	08.83-07.86	0 280 130 039
Temperature sensor, coolant, injection system	08.83-07.86	0 280 130 032
Wheel speed sensor, front	08.85-07.86	0 265 001 119
Wheel speed sensor, rear	08.85-07.86	0 265 001 118
5.0 GT		
	5,0l 243 kW M 28.47 8 Zyl.	
Throttle valve sensor	01.89-07.91	0 280 120 322
Air mass meter, gasoline injection	01.89-07.91	0 280 214 001
		0 986 280 124
Phase sensor	01.89-07.91	0 232 101 005
Speed sensor, ignition/injection	01.89-07.91	0 261 210 003
Knock sensor	01.89-07.90	0 261 231 008
	08.90-07.91	0 261 231 036
Temperature sensor, coolant, injection system	01.89-07.91	0 280 130 032
Wheel speed sensor, front	01.89-07.91	0 265 001 119
Wheel speed sensor, rear	01.89-07.91	0 265 001 118
5.0 S4		
	5,0l 200-215 kW M 28.43,.44; M 28.45,.46 8 Zyl.	
Throttle valve sensor	12.84-07.86	0 280 120 308
Air mass meter, gasoline injection	12.84-07.86	0 280 214 001
		0 986 280 124
Speed sensor, ignition/injection	12.84-07.86	0 261 210 003
Temperature sensor, intake air, injection system	12.84-07.86	0 280 130 039
Temperature sensor, coolant, injection system	12.84-07.86	0 280 130 032
Wheel speed sensor, front	08.85-07.86	0 265 001 119
Wheel speed sensor, rear	08.85-07.86	0 265 001 118
5.0 S4		
	5,0l 235 kW M 28.41,.42 8 Zyl.	
Throttle valve sensor	08.86-07.91	0 280 120 322
Air mass meter, gasoline injection	08.86-07.91	0 280 214 001
		0 986 280 124
Phase sensor	08.86-07.91	0 232 101 005
Speed sensor, ignition/injection	08.86-07.91	0 261 210 003
Knock sensor	08.86-07.90	0 261 231 008
	08.90-07.91	0 261 231 036
Temperature sensor, coolant, injection system	08.86-07.91	0 280 130 032
Wheel speed sensor, front	08.86-07.91	0 265 001 119
Wheel speed sensor, rear	08.86-07.91	0 265 001 118
5.0 S4/CS		
	5,0l 235 kW M 28.41 8 Zyl.	
Throttle valve sensor	08.87-07.89	0 280 120 322
Air mass meter, gasoline injection	08.87-07.89	0 280 214 001
		0 986 280 124
Phase sensor	08.87-07.89	0 232 101 005



Wheel speed sensor, front	08.87-07.89	0 265 001 119
Wheel speed sensor, rear	08.87-07.89	0 265 001 118
5.4 GTS		
	5,4l 257 kW M 28.49/.50 8 Zyl.	
Throttle valve sensor	08.91-08.93	0 280 120 322
	09.93-11.95	0 280 120 437
Air mass meter, gasoline injection	08.91-11.95	0 280 214 001
		0 986 280 124
Phase sensor	08.91-11.95	0 232 101 005
Speed sensor, ignition/injection	08.91-11.95	0 261 210 003
Knock sensor	08.91-11.95	0 261 231 036
Temperature sensor, coolant, injection system	08.91-11.95	0 280 130 032
Wheel speed sensor, front	08.91-05.93	0 265 001 119
	06.93-11.95	0 265 006 141
Wheel speed sensor, rear	08.91-11.95	0 265 001 118

944

2.5		
	2,5l 110/118/120 kW M 44.05/.06; M 44.07/.08; M 44.09/.10 4 Zyl.	
Throttle valve sensor	01.85-07.88	0 280 120 308
Air flow sensor, gasoline injection	01.85-07.88	0 280 202 064
		0 986 280 041
Speed sensor, ignition/injection	01.85-07.88	0 261 210 003
Temperature sensor, coolant, injection system	01.85-07.88	0 280 130 026
Wheel speed sensor, front	01.85-07.88	0 265 001 119
	EFV	0 265 006 141
Wheel speed sensor, rear	01.85-07.88	0 265 001 146
	EFV	0 265 006 142
2.5 S		
	2,5l 135-140 kW M 44.40 4 Zyl.	
Throttle valve sensor	08.86-07.88	0 280 120 308
Air flow sensor, gasoline injection	08.86-07.88	0 280 203 029
		0 986 280 048
Phase sensor	08.86-07.88	0 232 101 005
Speed sensor, ignition/injection	08.86-07.88	0 261 210 003
Temperature sensor, coolant, injection system	08.86-07.88	0 280 130 026
Wheel speed sensor, front	08.86-07.88	0 265 001 119
	EFV	0 265 006 141
Wheel speed sensor, rear	08.86-07.88	0 265 001 146
	EFV	0 265 006 142
2.5 Turbo		
	2,5l 162/184 kW M 44.50; M 44.51; M 44.52 4 Zyl.	
Throttle valve sensor	08.85-07.91	0 280 120 400
Air flow sensor, gasoline injection	08.85-07.91	0 280 203 026
		0 986 280 042
Speed sensor, ignition/injection	08.85-07.91	0 261 210 003
Knock sensor	08.85-07.91	0 261 231 006
Temperature sensor, coolant, injection system	08.85-07.91	0 280 130 026
Wheel speed sensor, front	08.85-07.91	0 265 001 119
	EFV	0 265 006 141
Wheel speed sensor, rear	08.85-07.91	0 265 001 146
	EFV	0 265 006 142
2.7		
	2,7l 121 kW M 44.11,.12 4 Zyl.	
Throttle valve sensor	11.88-07.89	0 280 120 308
Air flow sensor, gasoline injection	11.88-07.89	0 280 202 064
		0 986 280 041
Speed sensor, ignition/injection	11.88-07.89	0 261 210 003
Knock sensor	11.88-07.89	0 261 231 006
Temperature sensor, coolant, injection system	11.88-07.89	0 280 130 026
Wheel speed sensor, front	11.88-07.89	0 265 001 119
	EFV	0 265 006 141
Wheel speed sensor, rear	11.88-07.89	0 265 001 146
	EFV	0 265 006 142

Product				
◀ 944				
3.0S2	3,0l	155 kW	M 44.41	4 Zyl.
Throttle valve sensor	12.88-07.91		0 280 120 308	
Air flow sensor, gasoline injection	12.88-07.91		0 280 203 029	
			0 986 280 048	
Phase sensor	12.88-07.91		0 232 101 005	
Speed sensor, ignition/injection	12.88-07.91		0 261 210 003	
Knock sensor	12.88-07.91		0 261 231 006	
Temperature sensor, coolant, injection system	12.88-07.91		0 280 130 026	
Wheel speed sensor, front	12.88-07.91		0 265 001 119	
		EFV	0 265 006 141	
Wheel speed sensor, rear	12.88-07.91		0 265 001 146	
		EFV	0 265 006 142	



959			
2.8		2,8l	330 kW 959.50 6 Zyl.
Speed sensor, ignition/injection	05.86-07.88		0 261 210 003
Temperature sensor, coolant, injection system	05.86-07.88		0 280 130 026

P

968				
3.0	3,0l 176kW M 44.43/.44 4 Zyl.			
Throttle valve sensor	08.91-11.95		0 280 122 001	
Air mass meter, gasoline injection	08.91-11.95		0 280 213 017	
			0 986 280 139	
Phase sensor	08.91-11.95		0 232 101 013	
Speed sensor, ignition/injection	08.91-11.95		0 261 210 003	
Knock sensor	08.91-11.95		0 261 231 006	
Temperature sensor, coolant, injection system	08.91-11.95		0 280 130 026	
Lateral acceleration sensor, brake system	08.93-08.95	FMT	0 265 005 108	
Wheel speed sensor, front	08.91-05.93		0 265 001 119	
	06.93-11.95		0 265 006 141	
Wheel speed sensor, rear	08.91-05.93		0 265 001 146	
	06.93-11.95		0 265 006 142	

RENAULT

Alpine			
A 610 3.0i Turbo [D503]	3,0l	184 kW	Z7X 744 Kat. 6 Zyl.
Knock sensor	03.91-12.95		0 261 231 007
Acceleration sensor, ABS	03.91-07.92		0 265 005 004
	08.92-12.95		0 265 005 041
2.5i Turbo	2,5l	136/147 kW	Z7U 730; Z7U 734 Kat. 6 Zyl.
Acceleration sensor, ABS	03.85-08.92		0 265 005 004
2.9	2,9l	116 kW	Z6W 700; Z6W 702 6 Zyl.
Acceleration sensor, ABS	03.85-08.92		0 265 005 004

Avantime					
2.0 16V Turbo [XEO]		2,0l	120 kW	F4R 760; F4R 761; F4R 769	4 Zyl.
Wheel speed sensor, front	09.01-12.03	LAB	0 265 006 283		
		RAB	0 265 006 282		
Wheel speed sensor, rear	09.01-12.03		0 265 006 284		
2.2 DCI [XEO]		2,2l	110 kW	G9T 712	4 Zyl.
High-pressure sensor (CR system)	12.01-12.03		0 281 002 534		
Wheel speed sensor, front	12.01-12.03	LAB	0 265 006 283		
		RAB	0 265 006 282		
Wheel speed sensor, rear	12.01-12.03		0 265 006 284		

Product				

3.0 V6 24V [XE0]	3,0l	152 kW	L7X 720; L7X 721; L7X 722	6 Zyl.
Wheel speed sensor, front	09.01-12.03	LAB	0 265 006 283	
		RAB	0 265 006 282	
Wheel speed sensor, rear	09.01-12.03		0 265 006 284	

Clio				
1.6 i 16V		1,6l 81 kW K4M 740 4 Zyl.		
Wheel speed sensor, front	06.00→	LAB	0 265 006 384	
		RAB	0 265 006 383	
Wheel speed sensor, rear	06.00→		0 265 006 385	
1.6 i 16V [BB01]		1,6l 81 kW K4M 740 4 Zyl.		
Wheel speed sensor, front	05.00→	LAB	0 265 006 384	
		RAB	0 265 006 383	
Wheel speed sensor, rear	05.00→		0 265 006 385	

Clio I				
Electrique [X57]		21 kW 2BD 701 0 Zyl.		
Wheel speed sensor, rear	06.95-02.98	LAB	0 265 006 443	
		RAB	0 265 006 444	
1.1 [X57]		1,1l 35-36 kW C1E 700 4 Zyl.		
Wheel speed sensor, rear	06.90-03.96	LAB	0 265 006 443	
		RAB	0 265 006 444	
1.2 [X57]		1,2l 40-44 kW E5F 710; E5F 716 4 Zyl.		
Wheel speed sensor, rear	06.90-02.98	LAB	0 265 006 443	
		RAB	0 265 006 444	
1.2 i [X57]		1,2l 40 kW C3G 700,720 4 Zyl.		
Wheel speed sensor, rear	09.95-03.96	LAB	0 265 006 443	
		RAB	0 265 006 444	
1.2 i [X57]		1,2l 40-44 kW D7F 730; E7F 700,704,706,750 Kat. 4 Zyl.		
Wheel speed sensor, front	06.90-02.98		0 265 006 442	
Wheel speed sensor, rear	06.90-02.98	LAB	0 265 006 443	
		RAB	0 265 006 444	
1.2 i [X57]		1,2l 44 kW E7F 708; E7F 708 Kat. 4 Zyl.		
Wheel speed sensor, front	01.94-02.98		0 265 006 442	
Wheel speed sensor, rear	01.94-02.98	LAB	0 265 006 443	
		RAB	0 265 006 444	

1.4 [X57]	1,4l	55-57 kW	E6J 712,713; E6J 718; E6J 760	4 Zyl.
Wheel speed sensor, rear	06.90-02.98	LAB	0 265 006 443	
		RAB	0 265 006 444	

1.4 i [X57]	1,4l	55-59 kW	E7J 601,716,718,719,754,756,757 Kat.	4 Zyl.
Wheel speed sensor, front	06.90-02.98		0 265 006 442	
Wheel speed sensor, rear	06.90-02.98	LAB	0 265 006 443	
		RAB	0 265 006 444	

1.4 i [X57]	1,4l	58-59 kW	E7J 710,711 Kat.	4 Zyl.
Wheel speed sensor, front	06.90-02.98		0 265 006 442	
Wheel speed sensor, rear	06.90-02.98	LAB	0 265 006 443	
		RAB	0 265 006 444	

1.6 i	1,6l	66 kW	K7M 746	4 Zyl.
Speed sensor, ignition/injection	01.96-06.97		0 261 210 137	
Temperature sensor, intake air, injection system	01.96-06.97		3 437 010 533	
Temperature sensor, coolant, injection system	01.96-06.97		0 280 130 068	
Wheel speed sensor, front	01.96-06.97	LAB	0 265 006 384	
		RAB	0 265 006 383	

Wheel speed sensor, rear	01.96-06.97		0 265 006 385	
1.7 [X57]	1,7l	66-68 kW	F2N 770	4 Zyl.
Wheel speed sensor, front	06.90-03.96		0 265 006 442	
Wheel speed sensor, rear	06.90-03.96	LAB	0 265 006 443	
		RAB	0 265 006 444	





Product			
1.8 i [X57]	1,8 l 65-70 kW F3P 710,714,744,745,754,755 Kat. 4 Zyl.		
Wheel speed sensor, front	06.90-02.98		0 265 006 442
Wheel speed sensor, rear	06.90-02.98	LAB	0 265 006 443
		RAB	0 265 006 444
1.8 i [X57]	1,8 l 66/79-81 kW F3P 712,755,758 Kat.; F3P 748,758 4 Zyl.		
Wheel speed sensor, front	07.92-02.98		0 265 006 442
Wheel speed sensor, rear	07.92-02.98	LAB	0 265 006 443
		RAB	0 265 006 444
1.8 i 16V [X57]	1,8 l 99-103 kW F7P 720; F7P 722 Kat. 4 Zyl.		
Wheel speed sensor, front	03.91-03.96		0 265 006 442
Wheel speed sensor, rear	03.91-03.96	LAB	0 265 006 443
		RAB	0 265 006 444
1.9 D [X57]	1,9 l 47 kW F8Q 672,676,678,692,696 4 Zyl.		
Wheel speed sensor, front	10.94-02.98		0 265 006 442
Wheel speed sensor, rear	10.94-02.98	LAB	0 265 006 443
		RAB	0 265 006 444
1.9 D [X57]	1,9 l 47-48 kW F8Q 714,730,732 4 Zyl.		
Wheel speed sensor, front	06.90-02.98		0 265 006 442
Wheel speed sensor, rear	06.90-02.98	LAB	0 265 006 443
		RAB	0 265 006 444
2.0 i Williams [X57]	2,0 l 108-110 kW F7R 700 4 Zyl.		
Wheel speed sensor, front	07.92-03.96		0 265 006 442
Wheel speed sensor, rear	07.92-03.96	LAB	0 265 006 443
		RAB	0 265 006 444

Clio II

1.0 i [BB./CB./SB.]	1,0 l 43 kW D7D 760 4 Zyl.		
Duo sensor, acceleration and yaw rate, brake system	03.99-11.04		0 265 005 263
Wheel speed sensor, front	03.99-11.02		0 265 006 383
	12.02-11.04		0 265 007 527
Wheel speed sensor, rear	03.99-11.02	LAB,OTK	0 265 006 384
	12.02-11.04	LAB,OTK	0 265 007 529
	03.99-11.02	OTK,RAB	0 265 006 385
	12.02-11.04	OTK,RAB	0 265 007 528
1.0 i 16V [BB./CB./SB.]	1,0 l 50 kW D4D 700 4 Zyl.		
Duo sensor, acceleration and yaw rate, brake system	06.01-11.04		0 265 005 263
Wheel speed sensor, front	06.01-11.02		0 265 006 383
	12.02-11.04		0 265 007 527
Wheel speed sensor, rear	06.01-11.02	LAB,OTK	0 265 006 384
	12.02-11.04	LAB,OTK	0 265 007 529
	06.01-11.02	OTK,RAB	0 265 006 385
	12.02-11.04	OTK,RAB	0 265 007 528
1.0 i 16V [BB./CB./SB.]	1,0 l 50 kW D4D 706 4 Zyl.		
Duo sensor, acceleration and yaw rate, brake system	12.04-10.07		0 265 005 263
Wheel speed sensor, front	12.04-10.07		0 265 007 527
Wheel speed sensor, rear	12.04-10.07	LAB,OTK	0 265 007 529
		OTK,RAB	0 265 007 528
1.2 i [BB./CB./SB.]	1,2 l 43 kW D7F 720,722,726,744,746 4 Zyl.		
Duo sensor, acceleration and yaw rate, brake system	03.98-10.07		0 265 005 263
Wheel speed sensor, front	03.98-11.02		0 265 006 383
	12.02-10.07		0 265 007 527
Wheel speed sensor, rear	03.98-11.02	LAB,OTK	0 265 006 384
	12.02-10.07	LAB,OTK	0 265 007 529
	03.98-11.02	OTK,RAB	0 265 006 385
	12.02-10.07	OTK,RAB	0 265 007 528



1.2 i [BB./CB./SB.]	1,2 l 43 kW D7F 764,766 4 Zyl.		
Duo sensor, acceleration and yaw rate, brake system	03.98-10.07		0 265 005 263
Wheel speed sensor, front	03.98-11.02		0 265 006 383
	12.02-10.07		0 265 007 527
Wheel speed sensor, rear	03.98-11.02	LAB,OTK	0 265 006 384
	12.02-10.07	LAB,OTK	0 265 007 529
	03.98-11.02	OTK,RAB	0 265 006 385
	12.02-10.07	OTK,RAB	0 265 007 528
1.2 i 16V [BB./CB./SB.]	1,2 l 55 kW D4F 706,712,714 4 Zyl.		
Duo sensor, acceleration and yaw rate, brake system	03.00-03.04		0 265 005 263
Wheel speed sensor, front	03.00-11.02		0 265 006 383
	12.02-03.04		0 265 007 527
Wheel speed sensor, rear	03.00-11.02	LAB,OTK	0 265 006 384
	12.02-03.04	LAB,OTK	0 265 007 529
	03.00-11.02	OTK,RAB	0 265 006 385
	12.02-03.04	OTK,RAB	0 265 007 528
1.2 i 16V [BB./CB./SB.]	1,2 l 55 kW D4F 722; D4F 728 4 Zyl.		
Duo sensor, acceleration and yaw rate, brake system	10.03-10.07		0 265 005 263
Wheel speed sensor, front	10.03-10.07		0 265 007 527
Wheel speed sensor, rear	10.03-10.07	LAB,OTK	0 265 007 529
		OTK,RAB	0 265 007 528
1.4 i [BB./CB./SB.]	1,4 l 55 kW E7J 634; E7J 635; E7J 780; K7J 700 4 Zyl.		
Duo sensor, acceleration and yaw rate, brake system	03.98-10.07		0 265 005 263
Wheel speed sensor, front	03.98-11.02		0 265 006 383
	12.02-10.07		0 265 007 527
Wheel speed sensor, rear	03.98-11.02	LAB,OTK	0 265 006 384
	12.02-10.07	LAB,OTK	0 265 007 529
	03.98-11.02	OTK,RAB	0 265 006 385
	12.02-10.07	OTK,RAB	0 265 007 528
1.4 i 16V [BB./CB./SB.]	1,4 l 70-72 kW K4J 710,711,712,713,715 4 Zyl.		
Duo sensor, acceleration and yaw rate, brake system	10.99-10.07		0 265 005 263
Wheel speed sensor, front	10.99-11.02		0 265 006 383
	12.02-10.07		0 265 007 527
Wheel speed sensor, rear	10.99-11.02	LAB,OTK	0 265 006 384
	12.02-10.07	LAB,OTK	0 265 007 529
	10.99-11.02	OTK,RAB	0 265 006 385
	12.02-10.07	OTK,RAB	0 265 007 528
1.5 DCI [BB./CB./SB.]	1,5 l 48 kW K9K 700; K9K 704 4 Zyl.		
Boost pressure sensor, Diesel	12.02-10.07		0 281 002 593
Duo sensor, acceleration and yaw rate, brake system	06.01-10.07		0 265 005 263
Wheel speed sensor, front	06.01-11.02		0 265 006 383
	12.02-10.07		0 265 007 527
Wheel speed sensor, rear	06.01-11.02	LAB,OTK	0 265 006 384
	12.02-10.07	LAB,OTK	0 265 007 529
	06.01-11.02	OTK,RAB	0 265 006 385
	12.02-10.07	OTK,RAB	0 265 007 528
1.5 DCI [BB./CB./SB.]	1,5 l 50 kW K9K 714 4 Zyl.		
Boost pressure sensor, Diesel	10.05-10.07		0 281 002 593
Duo sensor, acceleration and yaw rate, brake system	10.05-10.07		0 265 005 263
Wheel speed sensor, front	10.05-10.07		0 265 007 527
Wheel speed sensor, rear	10.05-10.07	LAB,OTK	0 265 007 529
		OTK,RAB	0 265 007 528
1.5 DCI [BB./CB./SB.]	1,5 l 60 kW K9K 702; K9K 710 4 Zyl.		
Boost pressure sensor, Diesel	12.02-10.07		0 281 002 593
Duo sensor, acceleration and yaw rate, brake system	06.01-10.07		0 265 005 263



Product				
◀ Clio II				
Wheel speed sensor, front	06.01-11.02			0 265 006 383
	12.02-10.07			0 265 007 527
Wheel speed sensor, rear	06.01-11.02	LAB,OTK		0 265 006 384
	12.02-10.07	LAB,OTK		0 265 007 529
	06.01-11.02	OTK,RAB		0 265 006 385
	12.02-10.07	OTK,RAB		0 265 007 528
1.5 DCI [BB./CB./SB.]		1,5 l 74 kW K9K 712 4 Zyl.		
Boost pressure sensor, Diesel	03.03-10.07			0 281 002 573
Duo sensor, acceleration and yaw rate, brake system	03.03-10.07			0 265 005 263
Wheel speed sensor, front	03.03-10.07			0 265 007 527
Wheel speed sensor, rear	03.03-10.07	LAB,OTK		0 265 007 529
		OTK,RAB		0 265 007 528
1.6 i [BB./CB./SB.]		1,6 l 66 kW K4M 736,742 4 Zyl.		
Duo sensor, acceleration and yaw rate, brake system	12.02-10.07			0 265 005 263
Wheel speed sensor, front	12.02-10.07			0 265 007 527
Wheel speed sensor, rear	12.02-10.07	LAB,OTK		0 265 007 529
		OTK,RAB		0 265 007 528
1.6 i [BB./CB./SB.]		1,6 l 66 kW K4M 743,744,745,746; K7M 744 4 Zyl.		
Duo sensor, acceleration and yaw rate, brake system	03.98-10.07			0 265 005 263
Wheel speed sensor, front	03.98-11.02			0 265 006 383
	12.02-10.07			0 265 007 527
Wheel speed sensor, rear	03.98-11.02	LAB,OTK		0 265 006 384
	12.02-10.07	LAB,OTK		0 265 007 529
	03.98-11.02	OTK,RAB		0 265 006 385
	12.02-10.07	OTK,RAB		0 265 007 528
1.6 i [BB./CB./SB.]		1,6 l 66/81 kW K4M 740; K7M 745 4 Zyl.		
Duo sensor, acceleration and yaw rate, brake system	03.98-10.07			0 265 005 263
Wheel speed sensor, front	03.98-11.02			0 265 006 383
	12.02-10.07			0 265 007 527
Wheel speed sensor, rear	03.98-11.02	LAB,OTK		0 265 006 384
	12.02-10.07	LAB,OTK		0 265 007 529
	03.98-11.02	OTK,RAB		0 265 006 385
	12.02-10.07	OTK,RAB		0 265 007 528
1.6 i 16V [BB./CB./SB.]		1,6 l 79 kW K4M 708; K4M 748 4 Zyl.		
Duo sensor, acceleration and yaw rate, brake system	06.98-10.07			0 265 005 263
Wheel speed sensor, front	06.98-11.02			0 265 006 383
	12.02-10.07			0 265 007 527
Wheel speed sensor, rear	06.98-11.02	LAB,OTK		0 265 006 384
	12.02-10.07	LAB,OTK		0 265 007 529
	06.98-11.02	OTK,RAB		0 265 006 385
	12.02-10.07	OTK,RAB		0 265 007 528
1.9 D [BB./CB./SB.]		1,9 l 47-48 kW F8Q 630; F8Q 632; F8Q 662 4 Zyl.		
Duo sensor, acceleration and yaw rate, brake system	03.98-10.07			0 265 005 263
Wheel speed sensor, front	03.98-11.02			0 265 006 383
	12.02-10.07			0 265 007 527
Wheel speed sensor, rear	03.98-11.02	LAB,OTK		0 265 006 384
	12.02-10.07	LAB,OTK		0 265 007 529
	03.98-11.02	OTK,RAB		0 265 006 385
	12.02-10.07	OTK,RAB		0 265 007 528
1.9 D DTI [BB./CB./SB.]		1,9 l 59 kW F9Q 780; F9Q 782 4 Zyl.		
Duo sensor, acceleration and yaw rate, brake system	03.99-10.07			0 265 005 263
Wheel speed sensor, front	03.99-11.02			0 265 006 383
	12.02-10.07			0 265 007 527



Product				
Wheel speed sensor, rear	03.99-11.02	LAB,OTK		0 265 006 384
	12.02-10.07	LAB,OTK		0 265 007 529
	03.99-11.02	OTK,RAB		0 265 006 385
	12.02-10.07	OTK,RAB		0 265 007 528
2.0 16V [BB./CB./SB.]		2,0 l 124 kW F4R 730; F4R 732; F4R 736 4 Zyl.		
Duo sensor, acceleration and yaw rate, brake system	03.99-10.07			0 265 005 263
Wheel speed sensor, front	03.99-11.02			0 265 006 383
	12.02-10.07			0 265 007 527
Wheel speed sensor, rear	03.99-11.02	LAB,OTK		0 265 006 384
	12.02-10.07	LAB,OTK		0 265 007 529
	03.99-11.02	OTK,RAB		0 265 006 385
	12.02-10.07	OTK,RAB		0 265 007 528
2.0 16V [BB./CB./SB.]		2,0 l 124 kW F4R 738 4 Zyl.		
Duo sensor, acceleration and yaw rate, brake system	03.03-10.07			0 265 005 263
Wheel speed sensor, front	03.03-10.07			0 265 007 527
Wheel speed sensor, rear	03.03-10.07	LAB,OTK		0 265 007 529
		OTK,RAB		0 265 007 528
3.0 24V Sport [BB./CB./SB.]		3,0 l 170 kW L7X 760 6 Zyl.		
Pressure sensor, intake manifold, gasoline	09.00-11.02			0 261 230 041
Wheel speed sensor, front	09.00-11.02	LAB		0 265 006 384
		RAB		0 265 006 385
Wheel speed sensor, rear	09.00-11.02	LAB		0 265 006 384
		RAB		0 265 006 383
3.0 24V Sport [BB./CB./SB.]		3,0 l 170/188 kW L7X 762 6 Zyl.		
Throttle valve assembly	09.00-06.05			0 280 750 154
Pressure sensor, intake manifold, gasoline	09.00-06.05			0 261 230 041
Wheel speed sensor, front	09.00-06.05	LAB		0 265 006 384
		RAB		0 265 006 385
Wheel speed sensor, rear	09.00-06.05	LAB		0 265 006 384
		RAB		0 265 006 383
Clio III				
1.2 [BR./CR.]		1,1 l 55/57,5 kW D4F 740; D4F 764 4 Zyl.		
Duo sensor, acceleration and yaw rate, brake system	06.05→			0 265 005 263
Wheel speed sensor, front	06.05→			0 265 007 742
Wheel speed sensor, rear	06.05→	LAB,OTK		0 265 007 606
		OTK,RAB		0 265 007 607
		TKO		0 265 007 597
1.4 [BR./CR.]		1,4 l 72 kW K4J 780 4 Zyl.		
Duo sensor, acceleration and yaw rate, brake system	06.05→			0 265 005 263
Wheel speed sensor, front	06.05→			0 265 007 742
Wheel speed sensor, rear	06.05→	LAB,OTK		0 265 007 606
		OTK,RAB		0 265 007 607
		TKO		0 265 007 597
1.5 DCI [BR./CR.]		1,5 l 50 kW K9K 752 4 Zyl.		
Boost pressure sensor, Diesel	11.05→			0 281 002 593
Duo sensor, acceleration and yaw rate, brake system	11.05→			0 265 005 263
Wheel speed sensor, front	11.05→			0 265 007 742
Wheel speed sensor, rear	11.05→	LAB,OTK		0 265 007 606
		OTK,RAB		0 265 007 607
		TKO		0 265 007 597
1.5 DCI [BR./CR.]		1,5 l 50/63 kW K9K 760; K9K 762; K9K 766; K9K 768 4 Zyl.		
Boost pressure sensor, Diesel	06.05→			0 281 002 566
Duo sensor, acceleration and yaw rate, brake system	06.05→			0 265 005 263
Wheel speed sensor, front	06.05→			0 265 007 742



Wheel speed sensor, rear	06.05→	LAB,OTK	0 265 007 606
		OTK,RAB	0 265 007 607
		TKO	0 265 007 597
1.5 DCI [BR./CR.]		1,5 l 65 kW K9K 750 4 Zyl.	
Boost pressure sensor, Diesel	11.05→		0 281 002 573
Duo sensor, acceleration and yaw rate, brake system	11.05→		0 265 005 263
Wheel speed sensor, front	11.05→		0 265 007 742
Wheel speed sensor, rear	11.05→	LAB,OTK	0 265 007 606
		OTK,RAB	0 265 007 607
		TKO	0 265 007 597
1.5 DCI [BR./CR.]		1,5 l 78 kW K9K 764 4 Zyl.	
Boost pressure sensor, Diesel	06.05→		0 281 002 566
Duo sensor, acceleration and yaw rate, brake system	06.05→		0 265 005 263
Wheel speed sensor, front	06.05→		0 265 007 742
Wheel speed sensor, rear	06.05→	LAB,OTK	0 265 007 606
		OTK,RAB	0 265 007 607
		TKO	0 265 007 597
1.5 DCI [BR./CR.]		1,5 l 78 kW K9K 772 4 Zyl.	
Duo sensor, acceleration and yaw rate, brake system	03.06→		0 265 005 263
Wheel speed sensor, front	03.06→		0 265 007 742
Wheel speed sensor, rear	03.06→	LAB,OTK	0 265 007 606
		OTK,RAB	0 265 007 607
		TKO	0 265 007 597
1.6 [BR./CR.]		1,6 l 65/82 kW K4M 800; K4M 801; K4M 802; K4M 804 4 Zyl.	
Duo sensor, acceleration and yaw rate, brake system	06.05→		0 265 005 263
Wheel speed sensor, front	06.05→		0 265 007 742
Wheel speed sensor, rear	06.05→	LAB,OTK	0 265 007 606
		OTK,RAB	0 265 007 607
		TKO	0 265 007 597
2.0 [BR./CR.]		2,0 l 102 kW M4R 700; M4R 701 4 Zyl.	
Duo sensor, acceleration and yaw rate, brake system	06.05→		0 265 005 263
Wheel speed sensor, front	06.05→		0 265 007 742
Wheel speed sensor, rear	06.05→	LAB,OTK	0 265 007 606
		OTK,RAB	0 265 007 607
		TKO	0 265 007 597
2.0 Sport [BR./CR.]		2,0 l 145 kW F4R 830 4 Zyl.	
Duo sensor, acceleration and yaw rate, brake system	12.05→		0 265 005 263
Wheel speed sensor, front	12.05→	LAB	0 265 007 810
		RAB	0 265 007 809
Wheel speed sensor, rear	12.05→		0 265 007 811

Clio Sedan

1.6 i 16V		1,6 l 81 kW K4M 740 4 Zyl.	
Wheel speed sensor, front	01.01→	LAB	0 265 006 384
		RAB	0 265 006 383
Wheel speed sensor, rear	01.01→		0 265 006 385

Espace I

2.0 i [J11/13]		2,0 l 86 kW J7R 760 4 Zyl.	
Throttle valve sensor	06.87-12.90		0 280 120 301
Wheel speed sensor, front	01.88-12.90	LAB	0 265 001 069
		RAB	0 265 001 068
Wheel speed sensor, rear	01.88-12.90		0 265 001 242
2.0 i Quadra [J11/13]		2,0 l 86 kW J7R 760 4 Zyl.	
Throttle valve sensor	01.88-12.90		0 280 120 301
Acceleration sensor, ABS	01.88-12.90		0 265 005 012
Wheel speed sensor, front	01.88-12.90	LAB	0 265 001 069
		RAB	0 265 001 068



2.2 i [J11/13]		2,2 l 79-81 kW J7T 770 Kat. 4 Zyl.	
Throttle valve sensor	07.86-12.90		0 280 120 301
Wheel speed sensor, front	01.88-12.90	LAB	0 265 001 069
		RAB	0 265 001 068
Wheel speed sensor, rear	01.88-12.90		0 265 001 242
2.2 i Quadra [J11/13]		2,2 l 79-81 kW J7T 770 Kat. 4 Zyl.	
Throttle valve sensor	01.88-12.90		0 280 120 301
Acceleration sensor, ABS	01.88-12.90		0 265 005 012
Wheel speed sensor, front	01.88-12.90	LAB	0 265 001 069
		RAB	0 265 001 068

Espace II

2.0 i [J63]		2,0 l 77 kW J7R 768 4 Zyl.	
Throttle valve sensor	01.91-09.96	GS	0 280 120 301
Wheel speed sensor, front	01.91-09.96	LAB	0 265 001 069
		RAB	0 265 001 068
Wheel speed sensor, rear	01.91-09.96		0 265 001 242
2.1 D Turbo [J63]		2,1 l 65 kW J8S 610 4 Zyl.	
Wheel speed sensor, front	06.92-09.96	LAB	0 265 001 069
		RAB	0 265 001 068
Wheel speed sensor, rear	06.92-09.96		0 265 001 242
2.1 D Turbo [J63]		2,1 l 65 kW J8S 772 4 Zyl.	
Acceleration sensor, ABS	01.91-09.92	AA	0 265 005 012
	10.92-10.93	AA	0 265 005 038
Wheel speed sensor, front	01.91-10.93	LAB	0 265 001 069
		RAB	0 265 001 068
Wheel speed sensor, rear	01.91-10.93		0 265 001 242
2.1 D Turbo [J63]		2,1 l 65/66 kW J8S 612; J8S 776; J8S 778 4 Zyl.	
Wheel speed sensor, front	01.91-09.96	LAB	0 265 001 069
		RAB	0 265 001 068
Wheel speed sensor, rear	01.91-09.96		0 265 001 242
2.2 i [J63]		2,2 l 79-81 kW J7T 772; J7T 772,773 4 Zyl.	
Throttle valve sensor	01.91-09.96	GS	0 280 120 301
Acceleration sensor, ABS	01.91-09.92	AA	0 265 005 012
	10.92-09.96	AA	0 265 005 038
Wheel speed sensor, front	01.91-09.96	LAB	0 265 001 069
		RAB	0 265 001 068
Wheel speed sensor, rear	01.91-09.96		0 265 001 242
2.2 i [J63]		2,2 l 79-81 kW J7T 776 4 Zyl.	
Throttle valve sensor	05.93-09.96	GS	0 280 120 301
Wheel speed sensor, front	05.93-09.96	LAB	0 265 001 069
		RAB	0 265 001 068
Wheel speed sensor, rear	05.93-09.96		0 265 001 242
2.9 i [J63]		2,9 l 110-113 kW Z7W 712,713; Z7W 717 6 Zyl.	
Wheel speed sensor, front	01.91-09.96	LAB	0 265 001 069
		RAB	0 265 001 068
Wheel speed sensor, rear	01.91-09.96		0 265 001 242

Espace III

1.9 dTi [JE0]		1,9 l 72 kW F9Q 720; F9Q 722 4 Zyl.	
Wheel speed sensor, front	02.99-10.02	LAB	0 265 006 283
		RAB	0 265 006 282
Wheel speed sensor, rear	02.99-10.02		0 265 006 284
2.0 i [JE0]		2,0 l 83,5 kW F3R 728; F3R 729; F3R 768; F3R 769 4 Zyl.	
Wheel speed sensor, front	10.96-10.02	LAB	0 265 006 283
		RAB	0 265 006 282
Wheel speed sensor, rear	10.96-10.02		0 265 006 284
2.0 i GPL [JE0]		2,0 l 83,5 kW F3R 742 4 Zyl.	
Wheel speed sensor, front	02.98-10.02	LAB	0 265 006 283
		RAB	0 265 006 282
Wheel speed sensor, rear	02.98-10.02		0 265 006 284





Product

◀ Espace III

2.0i 16V [JE0]	2,0l	102-103 kW	F4R 700; F4R 701	4 Zyl.
Wheel speed sensor, front	10.98-10.02	LAB	0 265 006 283	
		RAB	0 265 006 282	
Wheel speed sensor, rear	10.98-10.02		0 265 006 284	
2.2 D Turbo [JE0]	2,2l	83 kW	G8T 714; G8T 716	4 Zyl.
Wheel speed sensor, front	10.96-10.02	LAB	0 265 006 283	
		RAB	0 265 006 282	
Wheel speed sensor, rear	10.96-10.02		0 265 006 284	
2.2 DCI [JE0]	2,2l	95 kW	G9T 710	4 Zyl.
Wheel speed sensor, front	07.00-10.02	LAB	0 265 006 283	
		RAB	0 265 006 282	
Wheel speed sensor, rear	07.00-10.02		0 265 006 284	
3.0i V6 [JE0]	3,0l	123 kW	Z7X 775	4 Zyl.
Knock sensor	10.96-10.02	KZB	0 261 231 070	
		KZG	0 261 231 071	
Wheel speed sensor, front	10.96-10.02	LAB	0 265 006 283	
		RAB	0 265 006 282	
Wheel speed sensor, rear	10.96-10.02		0 265 006 284	
3.0i V6 24V [JE0]	3,0l	140 kW	L7X 727	6 Zyl.
Knock sensor	10.98-10.02		0 261 231 125	
Wheel speed sensor, front	10.98-10.02	LAB	0 265 006 283	
		RAB	0 265 006 282	
Wheel speed sensor, rear	10.98-10.02		0 265 006 284	

Espace IV

1.9 DCI [JK0]	1,9l	88 kW	F9Q 820	4 Zyl.
Boost pressure sensor, Diesel	11.02-08.03		0 281 002 552	
	09.03-12.06		0 281 002 566	
2.0 DCI [JK0]	2,0l	110/127 kW	M9R 760	4 Zyl.
Boost pressure sensor, Diesel	05.05→		0 281 002 740	
2.0 Turbo [JK0]	2,0l	120 kW	F4R 794; F4R 795	4 Zyl.
Boost pressure sensor, gasoline	09.03-12.06		0 281 002 616	
2.0 Turbo [JK0]	2,0l	125 kW	F4R 796; F4R 797; F4R 896; F4R 897	4 Zyl.
Pressure sensor, intake manifold, gasoline	06.04→		0 281 002 616	
2.0 16V [JK0]	2,0l	100 kW	F4R 792	4 Zyl.
Pressure sensor, intake manifold, gasoline	07.04→		0 281 002 616	
2.2 DCI [JK0]	2,2l	102 kW	G9T 645	4 Zyl.
Boost pressure sensor, Diesel	07.05→		0 281 002 566	
2.2 DCI [JK0]	2,2l	110 kW	G9T 642	4 Zyl.
High-pressure sensor (CR system)	11.02-12.06		0 281 002 534	
2.2 DCI [JK0]	2,2l	110 kW	G9T 742; G9T 743	4 Zyl.
Boost pressure sensor, Diesel	11.02-08.03		0 281 002 552	
	09.03-12.06		0 281 002 566	
3.0 dV6 [JK0]	3,0l	130/133 kW	P9X 701; P9X 715	6 Zyl.
Air mass meter, diesel	11.02→		0 280 218 079	

Kangoo

1.0i [FC./KC.]	1,0l	43 kW	D7D 700; D7D 760	4 Zyl.
Wheel speed sensor, front	09.98-03.03		0 265 006 528	
	04.03→		0 265 007 527	
Wheel speed sensor, rear	09.98-03.03	ERH,LAB	0 265 006 400	
	04.03→	ERH,LAB	0 265 007 532	
	09.98-03.03	ERH,RAB	0 265 006 401	
	04.03→	ERH,RAB	0 265 007 531	
	09.98-03.03	LAB,NON	0 265 006 386	
	04.03→	LAB,NON	0 265 007 534	
	09.98-03.03	NON,RAB	0 265 006 387	
	04.03→	NON,RAB	0 265 007 533	
1.0i 16V [FC./KC.]	1,0l	50 kW	D4D 700; D4D 720	4 Zyl.
Wheel speed sensor, front	02.01-03.03		0 265 006 528	
	04.03→		0 265 007 527	

Product

Wheel speed sensor, rear	02.01-03.03	ERH,LAB	0 265 006 400	
	04.03→	ERH,LAB	0 265 007 532	
	02.01-03.03	ERH,RAB	0 265 006 401	
	04.03→	ERH,RAB	0 265 007 531	
	02.01-03.03	LAB,NON	0 265 006 386	
	04.03→	LAB,NON	0 265 007 534	
	02.01-03.03	NON,RAB	0 265 006 387	
	04.03→	NON,RAB	0 265 007 533	
1.2 GPL [FC./KC.]	1,2l	44 kW	D7F 710; D7F 722	4 Zyl.
Wheel speed sensor, front	10.97-03.03		0 265 006 528	
	04.03→		0 265 007 527	
Wheel speed sensor, rear	10.97-03.03	ERH,LAB	0 265 006 400	
	04.03→	ERH,LAB	0 265 007 532	
	10.97-03.03	ERH,RAB	0 265 006 401	
	04.03→	ERH,RAB	0 265 007 531	
	10.97-03.03	LAB,NON	0 265 006 386	
	04.03→	LAB,NON	0 265 007 534	
	10.97-03.03	NON,RAB	0 265 006 387	
	04.03→	NON,RAB	0 265 007 533	
1.2 i [FC./KC.]	1,2l	44 kW	D7F 710	4 Zyl.
Wheel speed sensor, front	10.97-04.98		0 265 006 528	
Wheel speed sensor, rear	10.97-04.98	ERH,LAB	0 265 006 400	
		ERH,RAB	0 265 006 401	
		LAB,NON	0 265 006 386	
		NON,RAB	0 265 006 387	
1.2 i [FC./KC.]	1,2l	44 kW	D7F 720,726,744,746,764	4 Zyl.
Wheel speed sensor, front	03.98-03.03		0 265 006 528	
	04.03→		0 265 007 527	
Wheel speed sensor, rear	03.98-03.03	ERH,LAB	0 265 006 400	
	04.03→	ERH,LAB	0 265 007 532	
	03.98-03.03	ERH,RAB	0 265 006 401	
	04.03→	ERH,RAB	0 265 007 531	
	03.98-03.03	LAB,NON	0 265 006 386	
	04.03→	LAB,NON	0 265 007 534	
	03.98-03.03	NON,RAB	0 265 006 387	
	04.03→	NON,RAB	0 265 007 533	
1.2 i [FC./KC.]	1,2l	44 kW	D7F 766	4 Zyl.
Wheel speed sensor, front	03.02-03.03		0 265 006 528	
	04.03→		0 265 007 527	
Wheel speed sensor, rear	03.02-03.03	ERH,LAB	0 265 006 400	
	04.03→	ERH,LAB	0 265 007 532	
	03.02-03.03	ERH,RAB	0 265 006 401	
	04.03→	ERH,RAB	0 265 007 531	
	03.02-03.03	LAB,NON	0 265 006 386	
	04.03→	LAB,NON	0 265 007 534	
	03.02-03.03	NON,RAB	0 265 006 387	
	04.03→	NON,RAB	0 265 007 533	
1.2 i 16V [FC./KC.]	1,2l	55 kW	D4F 712,714,716	4 Zyl.
Wheel speed sensor, front	05.00-03.03		0 265 006 528	
	04.03→		0 265 007 527	
Wheel speed sensor, rear	05.00-03.03	ERH,LAB	0 265 006 400	
	04.03→	ERH,LAB	0 265 007 532	
	05.00-03.03	ERH,RAB	0 265 006 401	
	04.03→	ERH,RAB	0 265 007 531	
	05.00-03.03	LAB,NON	0 265 006 386	
	04.03→	LAB,NON	0 265 007 534	
	05.00-03.03	NON,RAB	0 265 006 387	
	04.03→	NON,RAB	0 265 007 533	



Product		1.2i 16V [FC./KC.]		1,2l 55 kW D4F 730 4 Zyl.	
Wheel speed sensor, front	04.04→				0 265 007 527
Wheel speed sensor, rear	04.04→		ERH,LAB		0 265 007 532
			ERH,RAB		0 265 007 531
			LAB,NON		0 265 007 534
			NON,RAB		0 265 007 533
1.4i [FC./KC.]		1,4l 55 kW E7J 634,635,780; K7J 700,701 4 Zyl.			
Wheel speed sensor, front	10.97-03.03				0 265 006 528
	04.03→				0 265 007 527
Wheel speed sensor, rear	10.97-03.03	ERH,LAB			0 265 006 400
	04.03→	ERH,LAB			0 265 007 532
	10.97-03.03	ERH,RAB			0 265 006 401
	04.03→	ERH,RAB			0 265 007 531
	10.97-03.03	LAB,NON			0 265 006 386
	04.03→	LAB,NON			0 265 007 534
	10.97-03.03	NON,RAB			0 265 006 387
	04.03→	NON,RAB			0 265 007 533
1.5 DCI [FC./KC.]		1,5l K9K 716 4 Zyl.			
Boost pressure sensor, Diesel	04.05→				0 281 002 593
Wheel speed sensor, front	04.05→				0 265 007 527
Wheel speed sensor, rear	04.05→		ERH,LAB		0 265 007 532
			ERH,RAB		0 265 007 531
			LAB,NON		0 265 007 534
			NON,RAB		0 265 007 533
1.5 DCI [FC./KC.]		1,5l 48 kW K9K 700; K9K 704 4 Zyl.			
Boost pressure sensor, Diesel	11.02→				0 281 002 593
Wheel speed sensor, front	05.00-03.03				0 265 006 528
	04.03→				0 265 007 527
Wheel speed sensor, rear	05.00-03.03	ERH,LAB			0 265 006 400
	04.03→	ERH,LAB			0 265 007 532
	05.00-03.03	ERH,RAB			0 265 006 401
	04.03→	ERH,RAB			0 265 007 531
	05.00-03.03	LAB,NON			0 265 006 386
	04.03→	LAB,NON			0 265 007 534
	05.00-03.03	NON,RAB			0 265 006 387
	04.03→	NON,RAB			0 265 007 533
1.5 DCI [FC./KC.]		1,5l 50 kW K9K 714 4 Zyl.			
Boost pressure sensor, Diesel	04.05→				0 281 002 593
Wheel speed sensor, front	04.05→				0 265 007 527
Wheel speed sensor, rear	04.05→		ERH,LAB		0 265 007 532
			ERH,RAB		0 265 007 531
			LAB,NON		0 265 007 534
			NON,RAB		0 265 007 533
1.5 DCI [FC./KC.]		1,5l 60 kW K9K 702; K9K 710 4 Zyl.			
Boost pressure sensor, Diesel	11.02→				0 281 002 593
Wheel speed sensor, front	02.01-03.03				0 265 006 528
	04.03→				0 265 007 527
Wheel speed sensor, rear	02.01-03.03	ERH,LAB			0 265 006 400
	04.03→	ERH,LAB			0 265 007 532
	02.01-03.03	ERH,RAB			0 265 006 401
	04.03→	ERH,RAB			0 265 007 531
	02.01-03.03	LAB,NON			0 265 006 386
	04.03→	LAB,NON			0 265 007 534
	02.01-03.03	NON,RAB			0 265 006 387
	04.03→	NON,RAB			0 265 007 533
1.5 DCI [FC./KC.]		1,5l 62 kW K9K 718 4 Zyl.			
Boost pressure sensor, Diesel	04.05→				0 281 002 593
Wheel speed sensor, front	04.05→				0 265 007 527
Wheel speed sensor, rear	04.05→		ERH,LAB		0 265 007 532
			ERH,RAB		0 265 007 531
			LAB,NON		0 265 007 534
			NON,RAB		0 265 007 533



Product		1.6i [FC./KC.]		1,6l 66/70 kW K4M 708,730,732,754; K7M 746 4 Zyl.	
Wheel speed sensor, front	09.99-03.03				0 265 006 528
	04.03→				0 265 007 527
Wheel speed sensor, rear	09.99-03.03	ERH,LAB			0 265 006 400
	04.03→	ERH,LAB			0 265 007 532
	09.99-03.03	ERH,RAB			0 265 006 401
	04.03→	ERH,RAB			0 265 007 531
	09.99-03.03	LAB,NON			0 265 006 386
	04.03→	LAB,NON			0 265 007 534
	09.99-03.03	NON,RAB			0 265 006 387
	04.03→	NON,RAB			0 265 007 533
1.6i [FC./KC.]		1,6l 70 kW K4M 750,752,753 4 Zyl.			
Wheel speed sensor, front	06.00-03.03				0 265 006 528
	04.03→				0 265 007 527
Wheel speed sensor, rear	06.00-03.03	ERH,LAB			0 265 006 400
	04.03→	ERH,LAB			0 265 007 532
	06.00-03.03	ERH,RAB			0 265 006 401
	04.03→	ERH,RAB			0 265 007 531
	06.00-03.03	LAB,NON			0 265 006 386
	04.03→	LAB,NON			0 265 007 534
	06.00-03.03	NON,RAB			0 265 006 387
	04.03→	NON,RAB			0 265 007 533
1.6i 4x4 [FC./KC.]		1,6l 70 kW K4M 708,750,752,753,754 4 Zyl.			
Wheel speed sensor, front	06.00→				0 265 006 710
Wheel speed sensor, rear	06.00→				0 265 006 711
1.9 D [FC./KC.]		1,9l 40/47-48 kW F8Q 630,632,662 4 Zyl.			
Wheel speed sensor, front	10.97-03.03				0 265 006 528
	04.03→				0 265 007 527
Wheel speed sensor, rear	10.97-03.03	ERH,LAB			0 265 006 400
	04.03→	ERH,LAB			0 265 007 532
	10.97-03.03	ERH,RAB			0 265 006 401
	04.03→	ERH,RAB			0 265 007 531
	10.97-03.03	LAB,NON			0 265 006 386
	04.03→	LAB,NON			0 265 007 534
	10.97-03.03	NON,RAB			0 265 006 387
	04.03→	NON,RAB			0 265 007 533
1.9 D DCI [FC./KC.]		1,9l 59 kW F9Q 790 4 Zyl.			
Wheel speed sensor, front	05.00-03.03				0 265 006 528
	04.03→				0 265 007 527
Wheel speed sensor, rear	05.00-03.03	ERH,LAB			0 265 006 400
	04.03→	ERH,LAB			0 265 007 532
	05.00-03.03	ERH,RAB			0 265 006 401
	04.03→	ERH,RAB			0 265 007 531
	05.00-03.03	LAB,NON			0 265 006 386
	04.03→	LAB,NON			0 265 007 534
	05.00-03.03	NON,RAB			0 265 006 387
	04.03→	NON,RAB			0 265 007 533
1.9 D DCI 4x4 [FC./KC.]		1,9l 59 kW F9Q 782; F9Q 790 4 Zyl.			
Wheel speed sensor, front	05.00→				0 265 006 710
Wheel speed sensor, rear	05.00→				0 265 006 711
1.9 D DTI [FC./KC.]		1,9l 59 kW F9Q 780 4 Zyl.			
Wheel speed sensor, front	09.98-03.03				0 265 006 528
	04.03→				0 265 007 527
Wheel speed sensor, rear	09.98-03.03	ERH,LAB			0 265 006 400
	04.03→	ERH,LAB			0 265 007 532
	09.98-03.03	ERH,RAB			0 265 006 401
	04.03→	ERH,RAB			0 265 007 531
	09.98-03.03	LAB,NON			0 265 006 386
	04.03→	LAB,NON			0 265 007 534
	09.98-03.03	NON,RAB			0 265 006 387
	04.03→	NON,RAB			0 265 007 533





Product

Laguna I

1.9 DTI [B56]				1,9l 72 kW F9Q 716 4 Zyl.
Speed sensor, diesel	10.97-09.99			0 281 002 175
2.0 i 16V [B56]				2,0l 102 kW N7Q 700; N7Q 704 4 Zyl.
Phase sensor	09.95-02.01			0 232 101 030
3.0 i [B56]				3,0l 123-125 kW Z7X 760; Z7X 765; Z7X 767 6 Zyl.
Knock sensor	01.94-02.01	KZB		0 261 231 070
		KZG		0 261 231 071
3.0 i 24V [B56]				3,0l 143 kW L7X 700; L7X 701 6 Zyl.
Knock sensor	03.97-02.01			0 261 231 125

Laguna I Grandtour

1.9 DTI [K56]				1,9l 72 kW F9Q 716 4 Zyl.
Speed sensor, diesel	10.97-09.99			0 281 002 175
1.9 DTI [S56]				1,9l 72 kW F9Q 716 4 Zyl.
Speed sensor, diesel	03.98-02.01			0 281 002 175
2.0 i 16V [K56]				2,0l 102 kW N7Q 700; N7Q 704 4 Zyl.
Phase sensor	09.95-02.01			0 232 101 030
3.0 i [K56]				3,0l 123-125 kW Z7X 765; Z7X 767 6 Zyl.
Knock sensor	03.96-02.01	KZB		0 261 231 070
		KZG		0 261 231 071
3.0 i 24V [K56]				3,0l 143 kW L7X 700; L7X 701 6 Zyl.
Knock sensor	03.97-02.01			0 261 231 125

Laguna II

1.9 DCI [BG.]				1,9l 68 kW F9Q 664 4 Zyl.
Boost pressure sensor, Diesel	01.05-09.07			0 281 002 566
1.9 DCI [BG.]				1,9l 74 kW F9Q 752; F9Q 754 4 Zyl.
Boost pressure sensor, Diesel	03.01-09.07			0 281 002 552
1.9 DCI [BG.]				1,9l 81-96 kW F9Q 670; F9Q 674 4 Zyl.
Boost pressure sensor, Diesel	09.04-09.07			0 281 002 566
1.9 DCI [BG.]				1,9l 88 kW F9Q 750 4 Zyl.
Boost pressure sensor, Diesel	03.01-08.03			0 281 002 552
	09.03-09.07			0 281 002 566
2.0 DCI [BG.]				2,0l 110/127 kW M9R 740; M9R 760 4 Zyl.
Boost pressure sensor, Diesel	09.04-09.07			0 281 002 740
2.0 T [BG.]				2,0l 120 kW F4R 764 4 Zyl.
Pressure sensor, intake manifold, gasoline	09.03-09.07			0 281 002 616
2.0 T [BG.]				2,0l 120/150 kW F4R 765,784,786,787,886 4 Zyl.
Pressure sensor, intake manifold, gasoline	07.02-09.07			0 281 002 616
2.0 T [BG.]				2,0l 150 kW F4R 887 4 Zyl.
Pressure sensor, intake manifold, gasoline	01.05-09.07			0 281 002 616
2.2 DCI [BG.]				2,2l 102 kW G9T 605 4 Zyl.
Boost pressure sensor, Diesel	07.05-09.07			0 281 002 566
2.2 DCI [BG.]				2,2l 110 kW G9T 600 4 Zyl.
High-pressure sensor (CR system)	07.02-09.07			0 281 002 534
Boost pressure sensor, Diesel	07.02-09.07			0 281 002 566
2.2 DCI [BG.]				2,2l 110 kW G9T 702; G9T 703 4 Zyl.
Boost pressure sensor, Diesel	03.01-09.07			0 281 002 552
3.0 V6 24V [BG.]				3,0l 152 kW L7X 731; L7X 733 6 Zyl.
Pressure sensor, intake manifold, gasoline	03.01-09.07			0 261 230 041

Laguna II Grandtour

1.9 DCI [KG.]				1,9l 68 kW F9Q 664 4 Zyl.
Boost pressure sensor, Diesel	01.05-09.07			0 281 002 566
1.9 DCI [KG.]				1,9l 74 kW F9Q 752; F9Q 754 4 Zyl.
Boost pressure sensor, Diesel	03.01-09.07			0 281 002 552
1.9 DCI [KG.]				1,9l 81-96 kW F9Q 670; F9Q 674 4 Zyl.
Boost pressure sensor, Diesel	01.05-09.07			0 281 002 566



Product

1.9 DCI [KG.]				1,9l 88 kW F9Q 750 4 Zyl.
Boost pressure sensor, Diesel	03.01-08.03			0 281 002 552
	09.03-09.07			0 281 002 566
2.0 DCI [KG.]				2,0l 110/127 kW M9R 740,760 4 Zyl.
Boost pressure sensor, Diesel	09.04-09.07			0 281 002 740
2.0 T [KG.]				2,0l 120 kW F4R 764,765,786,787,886 4 Zyl.
Pressure sensor, intake manifold, gasoline	09.03-09.07			0 281 002 616
2.0 T [KG.]				2,0l 120/150 kW F4R 784,887 4 Zyl.
Pressure sensor, intake manifold, gasoline	01.05-09.07			0 281 002 616
2.2 DCI [KG.]				2,2l 102 kW G9T 605 4 Zyl.
Boost pressure sensor, Diesel	07.05-09.07			0 281 002 566
2.2 DCI [KG.]				2,2l 110 kW G9T 600 4 Zyl.
High-pressure sensor (CR system)	07.02-09.07			0 281 002 534
Boost pressure sensor, Diesel	07.02-09.07			0 281 002 566
2.2 DCI [KG.]				2,2l 110 kW G9T 702; G9T 703 4 Zyl.
Boost pressure sensor, Diesel	03.01-09.07			0 281 002 552
3.0 V6 24V [KG.]				3,0l 152 kW L7X 733 6 Zyl.
Pressure sensor, intake manifold, gasoline	04.04-09.07			0 261 230 041

Logan

1.4 MPI [KS./LS.]				1,4l 55 kW K7J 710 4 Zyl.
Wheel speed sensor, front	07.04→			0 265 007 742
Wheel speed sensor, rear	07.04→	LAB		0 265 007 583
		RAB		0 265 007 582
1.5 dCi [KS./LS.]				1,5l 48/50 kW K9K 790,792 4 Zyl.
Boost pressure sensor, Diesel	06.05→			0 281 002 593
Wheel speed sensor, front	06.05→			0 265 007 742
Wheel speed sensor, rear	06.05→	LAB		0 265 007 583
		RAB		0 265 007 582
1.6 MPI [KS./LS.]				1,6l 64 kW K7M 710 4 Zyl.
Wheel speed sensor, front	07.04→			0 265 007 742
Wheel speed sensor, rear	07.04→	LAB		0 265 007 583
		RAB		0 265 007 582
1.6 16V [KS./LS.]				1,6l 77 kW K4M 690 4 Zyl.
Wheel speed sensor, front	12.05→			0 265 007 742
Wheel speed sensor, rear	12.05→	LAB		0 265 007 583
		RAB		0 265 007 582

Master

T28-35				2,2l 67 kW J7T 782 Kat. 4 Zyl.
Throttle valve sensor	09.80-09.97			0 280 120 301
1.9 dCi 80 [X70]				1,9l 60 kW F9Q 774 4 Zyl.
Boost pressure sensor, Diesel	10.03-10.06			0 281 002 573
2.2 dCi 90 [X70]				2,2l 66 kW G9T 750 4 Zyl.
Boost pressure sensor, Diesel	10.03-10.06			0 281 002 573
2.5 dCi 16V				2,5l 85 kW G9U-724 4 Zyl.
Boost pressure sensor, Diesel	10.04→			0 281 002 573
2.5 dCi 100, dCi 110 [X70]				2,5l 73 kW G9U 754 4 Zyl.
Boost pressure sensor, Diesel	10.03-10.06			0 281 002 573
2.5 dCi 120 [X70]				2,5l 84 kW G9U 724; G9U 750; G9U 754 4 Zyl.
Boost pressure sensor, Diesel	07.02-10.06			0 281 002 573
2.5 dCi 120 FAP				2,5l 88 kW G9U 632 (M1) 4 Zyl.
Boost pressure sensor, Diesel	11.06→			0 281 002 566
2.5 dCi 150 FAP				2,5l 107 kW G9U 632 (MY) 4 Zyl.
Boost pressure sensor, Diesel	11.06→			0 281 002 566
2.8 dTi 110 [X70]				2,8l 84 kW S9W 700 4 Zyl.
Speed sensor, diesel	10.97-12.98			0 281 002 093
2.8 dTi 120 [X70]				2,8l 84 kW S9W 702 4 Zyl.
Speed sensor, diesel	10.97-12.98			0 281 002 093
3.0 dCi 140 [X70]				3,0l 100 kW ZD3 200; ZD3 202 4 Zyl.
High-pressure sensor (CR system)	10.03-10.06			0 281 002 534





Megane I			
1.4 i [X64]	1,4 l	51-55 kW	E7J 626 4 Zyl.
Pressure sensor, intake manifold, gasoline	03.99-10.02	0 281 002 616	
1.4 i 16V [X64]	1,4 l	70 kW	K4J 714; K4J 750 4 Zyl.
Pressure sensor, intake manifold, gasoline	06.98-10.02	0 281 002 616	
Duo sensor, acceleration and yaw rate, brake system	01.01-10.02	TKO	0 265 005 263
1.6 i 16V [X64]	1,6 l	79 kW	K4M 700; K4M 701 4 Zyl.
Pressure sensor, intake manifold, gasoline	06.98-10.02	0 281 002 616	
Duo sensor, acceleration and yaw rate, brake system	01.01-10.02	TKO	0 265 005 263
1.6 i 16V [X64]	1,6 l	79 kW	K4M 704; K4M 706 4 Zyl.
Pressure sensor, intake manifold, gasoline	03.99-10.02	0 281 002 616	
1.6 i 16V [X64]	1,6 l	79 kW	K4M 708 4 Zyl.
Pressure sensor, intake manifold, gasoline	05.00-10.02	0 281 002 616	
Duo sensor, acceleration and yaw rate, brake system	01.01-10.02	TKO	0 265 005 263
1.6 i 16V [X64]	1,6 l	79 kW	K4M 709; K4M 712 4 Zyl.
Pressure sensor, intake manifold, gasoline	05.00-10.02	0 281 002 616	
1.8 i 16V [X64]	1,8 l	85/88 kW	F4P 720; F4P 722 4 Zyl.
Duo sensor, acceleration and yaw rate, brake system	03.99-10.02	TKO	0 265 005 263
1.9 DTI [X64]	1,9 l	59 kW	F9Q 744 4 Zyl.
Duo sensor, acceleration and yaw rate, brake system	01.01-10.02	TKO	0 265 005 263
1.9 DTI [X64]	1,9 l	69 kW	F9Q 730 4 Zyl.
Air mass meter, diesel	06.97-02.99	0 281 002 195	
Speed sensor, diesel	06.97-02.99	0 281 002 175	
Pedal position sensor, diesel	06.97-02.99	LLE	0 206 001 021
		RLE	0 281 002 221
1.9 DTI [X64]	1,9 l	72 kW	F9Q 731 4 Zyl.
Pedal position sensor, diesel	03.99-03.99	LLE	0 206 001 021
		RLE	0 281 002 221
1.9 DTI [X64]	1,9 l	72 kW	F9Q 734 4 Zyl.
Speed sensor, diesel	06.97-06.98	0 281 002 175	
Pedal position sensor, diesel	06.97-02.99	LLE	0 206 001 021
		RLE	0 281 002 221
1.9 DTI [X64]	1,9 l	72 kW	F9Q 736 4 Zyl.
Pedal position sensor, diesel	03.99-03.99	LLE	0 206 001 021
		RLE	0 281 002 221
2.0 i 16V [X64]	2,0 l	101,5 kW	F4R 740 4 Zyl.
Pressure sensor, intake manifold, gasoline	05.00-10.02	0 281 002 616	
Duo sensor, acceleration and yaw rate, brake system	05.00-10.02	0 265 005 263	
2.0 i 16V [X64]	2,0 l	103 kW	F4R 746 4 Zyl.
Duo sensor, acceleration and yaw rate, brake system	05.00-10.02	0 265 005 263	
2.0 i 16V [X64]	2,0 l	108-110 kW	F7R 710; F7R 714 4 Zyl.
Knock sensor	01.96-10.02	0 261 231 046	

Megane I Cabrio			
2.0 i 16V [X64]	2,0 l	108 kW	F7R 710; F7R 714 4 Zyl.
Knock sensor	09.96-09.03	0 261 231 046	

Megane I Classic			
1.9 DCI [X64]	1,9 l	72-75 kW	F9Q 732 4 Zyl.
Boost pressure sensor, Diesel	11.02-09.03	0 281 002 593	
1.9 DTI [X64]	1,9 l	59 kW	F9Q 744 4 Zyl.
Duo sensor, acceleration and yaw rate, brake system	11.00-09.03	0 265 005 263	



1.9 DTI [X64]	1,9 l	72 kW	F9Q 730 4 Zyl.
Air mass meter, diesel	08.97-09.03	0 281 002 195	
Pulse generator, diesel	08.97-09.03	0 281 002 175	
Pedal position sensor, diesel	08.97-09.03	LLE	0 206 001 021
		RLE	0 281 002 221
1.9 DTI [X64]	1,9 l	72 kW	F9Q 734 4 Zyl.
Pulse generator, diesel	08.97-06.98	0 281 002 175	
Pedal position sensor, diesel	08.97-02.99	LLE	0 206 001 021
		RLE	0 281 002 221

Megane I Coupé			
1.9 DTI [X64]	1,9 l	72 kW	F9Q 734 4 Zyl.
Pulse generator, diesel	06.97-06.98	0 281 002 175	
2.0 i 16V [X64]	2,0 l	108 kW	F7R 710; F7R 714 4 Zyl.
Knock sensor	01.96-10.02	0 261 231 046	

Megane I Grandtour			
1.9 DCI [X64]	1,9 l	72-75 kW	F9Q 732 4 Zyl.
Boost pressure sensor, Diesel	11.02-09.03	0 281 002 593	

Megane II			
1.4 16V [LM.]	1,4 l	72 kW	K4J 730,732,740 4 Zyl.
Duo sensor, acceleration and yaw rate, brake system	10.03→	0 265 005 263	
1.5 DCI [LM.]	1,5 l	60 kW	K4J 730,732,740 4 Zyl.
Boost pressure sensor, Diesel	11.02→	0 281 002 573	
Duo sensor, acceleration and yaw rate, brake system	11.02→	0 265 005 263	
1.5 DCI [LM.]	1,5 l	63/78 kW	K9K 724; K9K 732 4 Zyl.
Boost pressure sensor, Diesel	09.04→	0 281 002 566	
Duo sensor, acceleration and yaw rate, brake system	09.04→	0 265 005 263	
1.6 16V [LM.]	1,6 l	83 kW	K4M 760,761,762,764,768 4 Zyl.
Duo sensor, acceleration and yaw rate, brake system	10.03→	0 265 005 263	
1.6 16V [LM.]	1,6 l	83 kW	K4M 812; K4M 813 4 Zyl.
Duo sensor, acceleration and yaw rate, brake system	05.05→	0 265 005 263	
1.9 DCI [LM.]	1,9 l	68/88 kW	F9Q 800; F9Q 808 4 Zyl.
Boost pressure sensor, Diesel	10.03→	0 281 002 566	
Duo sensor, acceleration and yaw rate, brake system	10.03→	0 265 005 263	
1.9 DCI [LM.]	1,9 l	96 kW	F9Q 803; F9Q 804; F9Q 814 4 Zyl.
Duo sensor, acceleration and yaw rate, brake system	05.04→	0 265 005 263	
2.0 DCI [LM.]	2,0 l	110 kW	M9R 700 4 Zyl.
Boost pressure sensor, Diesel	09.04→	0 281 002 740	
Duo sensor, acceleration and yaw rate, brake system	09.04→	0 265 005 263	
2.0 16V [LM.]	2,0 l	99 kW	F4R 770; F4R 771 4 Zyl.
Duo sensor, acceleration and yaw rate, brake system	09.02→	0 265 005 263	

Megane II Cabrio			
1.5 DCI [EM.]	1,5 l	78 kW	K9K 732 4 Zyl.
Boost pressure sensor, Diesel	12.05→	0 281 002 566	
Duo sensor, acceleration and yaw rate, brake system	12.05→	0 265 005 263	





Product

◀ Megane II Cabrio

1.6 16V [EM.]	1,6l 83 kW K4M 760; K4M 761; K4M 812; K4M 813 4 Zyl.
Duo sensor, acceleration and yaw rate, brake system	10.03→ 0 265 005 263
1.9 DCI [EM.]	1,9l 88 kW F9Q 800 4 Zyl.
Boost pressure sensor, Diesel	10.03→ 0 281 002 566
Duo sensor, acceleration and yaw rate, brake system	10.03→ 0 265 005 263
1.9 DCI [EM.]	1,9l 96 kW F9Q 803; F9Q 804; F9Q 814 4 Zyl.
Duo sensor, acceleration and yaw rate, brake system	05.04→ 0 265 005 263
2.0 DCI [EM.]	2,0l 110 kW M9R 700 4 Zyl.
Boost pressure sensor, Diesel	09.04→ 0 281 002 740
Duo sensor, acceleration and yaw rate, brake system	09.04→ 0 265 005 263
2.0 T [EM.]	2,0l 120 kW F4R 776 4 Zyl.
Boost pressure sensor, gasoline	10.03→ 0 281 002 616
Duo sensor, acceleration and yaw rate, brake system	10.03→ 0 265 005 263
2.0 16V [EM.]	2,0l 99 kW F4R 770; F4R 771 4 Zyl.
Duo sensor, acceleration and yaw rate, brake system	10.03→ 0 265 005 263

Megane II Grandtour

1.4 16V [KM.]	1,4l 72 kW K4J 730; K4J 740 4 Zyl.
Duo sensor, acceleration and yaw rate, brake system	10.03→ 0 265 005 263
1.5 DCI [KM.]	1,5l 60 kW K9K 722; K9K 728; K9K 729 4 Zyl.
Boost pressure sensor, Diesel	10.03→ 0 281 002 573
Duo sensor, acceleration and yaw rate, brake system	10.03→ 0 265 005 263
1.5 DCI [KM.]	1,5l 63/78 kW K9K 724; K9K 732 4 Zyl.
Boost pressure sensor, Diesel	10.04→ 0 281 002 566
Duo sensor, acceleration and yaw rate, brake system	10.04→ 0 265 005 263
1.6 16V [KM.]	1,6l 83 kW K4M 760,761,762,764,768 4 Zyl.
Duo sensor, acceleration and yaw rate, brake system	10.03→ 0 265 005 263
1.6 16V [KM.]	1,6l 83 kW K4M 812; K4M 813 4 Zyl.
Duo sensor, acceleration and yaw rate, brake system	05.05→ 0 265 005 263
1.9 DCI [KM.]	1,9l 68/88 kW F9Q 800; F9Q 808 4 Zyl.
Boost pressure sensor, Diesel	10.03→ 0 281 002 566
Duo sensor, acceleration and yaw rate, brake system	10.03→ 0 265 005 263
1.9 DCI [KM.]	1,9l 96 kW F9Q 803; F9Q 804; F9Q 814 4 Zyl.
Duo sensor, acceleration and yaw rate, brake system	05.04→ 0 265 005 263
2.0 DCI [KM.]	2,0l 110 kW M9R 700 4 Zyl.
Boost pressure sensor, Diesel	09.04→ 0 281 002 740
Duo sensor, acceleration and yaw rate, brake system	09.04→ 0 265 005 263
2.0 16V [KM.]	2,0l 99 kW F4R 770; F4R 771 4 Zyl.
Duo sensor, acceleration and yaw rate, brake system	10.03→ 0 265 005 263

Megane II Hatchback

1.4 16V [BM./CM./GM./SM.]	1,4l 72 kW K4J 730; K4J 732; K4J 740 4 Zyl.
Duo sensor, acceleration and yaw rate, brake system	11.02→ 0 265 005 263

Product

1.5 DCI [BM./CM./GM./SM.]	1,5l 60 kW K9K 722; K9K 728; K9K 729 4 Zyl.
Boost pressure sensor, Diesel	11.02→ 0 281 002 573
Duo sensor, acceleration and yaw rate, brake system	11.02→ 0 265 005 263
1.5 DCI [BM./CM./GM./SM.]	1,5l 63/78 kW K9K 724; K9K 732 4 Zyl.
Boost pressure sensor, Diesel	10.04→ 0 281 002 566
Duo sensor, acceleration and yaw rate, brake system	10.04→ 0 265 005 263
1.6 16V [BM./CM./GM./SM.]	1,6l 83 kW K4M 760,761,764,788,812 4 Zyl.
Duo sensor, acceleration and yaw rate, brake system	11.02→ 0 265 005 263
1.6 16V [BM./CM./GM./SM.]	1,6l 83 kW K4M 813 4 Zyl.
Duo sensor, acceleration and yaw rate, brake system	05.05→ 0 265 005 263
1.9 DCI [BM./CM./GM./SM.]	1,9l 68/88 kW F9Q 800; F9Q 808 4 Zyl.
Boost pressure sensor, Diesel	11.02→ 0 281 002 566
Duo sensor, acceleration and yaw rate, brake system	11.02→ 0 265 005 263
1.9 DCI [BM./CM./GM./SM.]	1,9l 96 kW F9Q 803; F9Q 804; F9Q 814 4 Zyl.
Duo sensor, acceleration and yaw rate, brake system	05.04→ 0 265 005 263
2.0 DCI [BM./CM./GM./SM.]	2,0l 110 kW M9R 700 4 Zyl.
Boost pressure sensor, Diesel	09.04→ 0 281 002 740
Duo sensor, acceleration and yaw rate, brake system	09.04→ 0 265 005 263
2.0 T [BM./CM./GM./SM.]	2,0l 120 kW F4R 776 4 Zyl.
Boost pressure sensor, gasoline	05.04→ 0 281 002 616
Duo sensor, acceleration and yaw rate, brake system	05.04→ 0 265 005 263
2.0 16V [BM./CM./GM./SM.]	2,0l 99 kW F4R 770; F4R 771 4 Zyl.
Duo sensor, acceleration and yaw rate, brake system	11.02→ 0 265 005 263
2.0 16V Sport [BM./CM./GM./SM.]	2,0l 165 kW F4R 774 4 Zyl.
Boost pressure sensor, gasoline	03.03→ 0 281 002 616
Duo sensor, acceleration and yaw rate, brake system	03.03→ 0 265 005 263

Modus

1.2 i 16V [FP./JP.]	1,2l 55/57,5 kW D4F 740; D4F 764 4 Zyl.
Duo sensor, acceleration and yaw rate, brake system	09.04→ 0 265 005 263
Wheel speed sensor, front	09.04→ 0 265 007 742
Wheel speed sensor, rear	09.04→ LAB,OTK 0 265 007 606 OTK,RAB 0 265 007 607 TKO 0 265 007 597
1.4 i 16V [FP./JP.]	1,4l 72 kW K4J 770; K4J 780 4 Zyl.
Duo sensor, acceleration and yaw rate, brake system	06.04-12.06 0 265 005 263
Wheel speed sensor, front	06.04-12.06 0 265 007 742
Wheel speed sensor, rear	06.04-12.06 LAB,OTK 0 265 007 606 OTK,RAB 0 265 007 607 TKO 0 265 007 597
1.5 DCI [FP./JP.]	1,5l 50 kW K9K 752 4 Zyl.
Boost pressure sensor, Diesel	09.04→ 0 281 002 593
Duo sensor, acceleration and yaw rate, brake system	09.04→ 0 265 005 263
Wheel speed sensor, front	09.04→ 0 265 007 742
Wheel speed sensor, rear	09.04→ LAB,OTK 0 265 007 606 OTK,RAB 0 265 007 607 TKO 0 265 007 597



Product			
1.5 DCI [FP./JP.]	1,5l 50/63 kW K9K 760,762,766,768	4 Zyl.	
Boost pressure sensor, Diesel	09.04→		0 281 002 566
Duo sensor, acceleration and yaw rate, brake system	09.04→		0 265 005 263
Wheel speed sensor, front	09.04→		0 265 007 742
Wheel speed sensor, rear	09.04→	LAB,OTK	0 265 007 606
		OTK,RAB	0 265 007 607
		TKO	0 265 007 597
1.5 DCI [FP./JP.]	1,5l 65 kW K9K 750	4 Zyl.	
Boost pressure sensor, Diesel	09.04-12.06		0 281 002 573
Duo sensor, acceleration and yaw rate, brake system	09.04-12.06		0 265 005 263
Wheel speed sensor, front	09.04-12.06		0 265 007 742
Wheel speed sensor, rear	09.04-12.06	LAB,OTK	0 265 007 606
		OTK,RAB	0 265 007 607
		TKO	0 265 007 597
1.5 DCI [FP./JP.]	1,5l 78 kW K9K 764	4 Zyl.	
Boost pressure sensor, Diesel	09.04→		0 281 002 566
Duo sensor, acceleration and yaw rate, brake system	09.04→		0 265 005 263
Wheel speed sensor, front	09.04→		0 265 007 742
Wheel speed sensor, rear	09.04→	LAB,OTK	0 265 007 606
		OTK,RAB	0 265 007 607
		TKO	0 265 007 597
1.5 DCI [FP./JP.]	1,5l 78 kW K9K 772	4 Zyl.	
Duo sensor, acceleration and yaw rate, brake system	02.06→		0 265 005 263
Wheel speed sensor, front	02.06→		0 265 007 742
Wheel speed sensor, rear	02.06→	LAB,OTK	0 265 007 606
		OTK,RAB	0 265 007 607
		TKO	0 265 007 597
1.6 i 16V [FP./JP.]	1,6l 65/82/83 kW K4M 790,792,794,800,801	4 Zyl.	
Duo sensor, acceleration and yaw rate, brake system	09.04→		0 265 005 263
Wheel speed sensor, front	09.04→		0 265 007 742
Wheel speed sensor, rear	09.04→	LAB,OTK	0 265 007 606
		OTK,RAB	0 265 007 607
		TKO	0 265 007 597
1.6 i 16V [FP./JP.]	1,6l 83 kW K4M 791	4 Zyl.	
Duo sensor, acceleration and yaw rate, brake system	09.04→		0 265 005 263
Wheel speed sensor, front	09.04→		0 265 007 742
Wheel speed sensor, rear	09.04→	LAB,OTK	0 265 007 606
		OTK,RAB	0 265 007 607
		TKO	0 265 007 597

Safrane

2.0 i [B54]	2,0l 77/97-99 kW J7R 732,733,734,735,738,739	4 Zyl.	
Wheel speed sensor, front	04.92-09.96	LAB	0 265 006 361
		RAB	0 265 006 362
Wheel speed sensor, rear	04.92-09.96		0 265 006 363
2.0 i 16V [B54]	2,0l 100 kW N7Q 710; N7Q 711	4 Zyl.	
Phase sensor	10.96-12.00		0 232 101 030
Wheel speed sensor, front	10.96-12.00	LAB	0 265 006 361
		RAB	0 265 006 362
Wheel speed sensor, rear	10.96-12.00		0 265 006 363
2.1 D Turbo [B54]	2,1l 65-66 kW J8S 760	4 Zyl.	
Wheel speed sensor, front	04.92-09.96	LAB	0 265 006 361
		RAB	0 265 006 362
Wheel speed sensor, rear	04.92-09.96		0 265 006 363



2.2 i [B54]	2,2l 79-81/101-104 kW J7T 760,761,762,763,766,767	4 Zyl.	
Wheel speed sensor, front	04.92-09.96	LAB	0 265 006 361
		RAB	0 265 006 362
Wheel speed sensor, rear	04.92-09.96		0 265 006 363
2.2 12V D Turbo [B54]	2,2l 83 kW G8T 740	4 Zyl.	
Wheel speed sensor, front	10.96-12.00	LAB	0 265 006 361
		RAB	0 265 006 362
Wheel speed sensor, rear	10.96-12.00		0 265 006 363
2.5 D Turbo [B54]	2,5l 83-85 kW S8U 762,763	4 Zyl.	
Wheel speed sensor, front	04.92-09.96	LAB	0 265 006 361
		RAB	0 265 006 362
Wheel speed sensor, rear	04.92-09.96		0 265 006 363
2.5 i 20V [B54]	2,5l 121 kW N7U 700; N7U 701	5 Zyl.	
Air mass meter, gasoline injection	10.96-12.00		0 280 217 107
Phase sensor	10.96-12.00		0 232 101 030
Wheel speed sensor, front	10.96-12.00	LAB	0 265 006 361
		RAB	0 265 006 362
Wheel speed sensor, rear	10.96-12.00		0 265 006 363
3.0 i [B54]	3,0l 123-125 kW Z7X 721	6 Zyl.	
Knock sensor	08.92-09.96	LAB	0 261 231 071
		RAB	0 261 231 070
Acceleration sensor, ABS	08.92-07.93	AA	0 265 005 111
3.0 i [B54]	3,0l 123-125 kW Z7X 721; Z7X 722,723	6 Zyl.	
Knock sensor	04.92-09.96	LAB	0 261 231 071
		RAB	0 261 231 070
Acceleration sensor, ABS	07.93-09.96	AA	0 265 005 111
Wheel speed sensor, front	08.92-09.96	LAB	0 265 006 361
		RAB	0 265 006 362
Wheel speed sensor, rear	08.92-09.96		0 265 006 363
3.0 i [B54]	3,0l 123-125 kW Z7X 722,723	6 Zyl.	
Acceleration sensor, ABS	04.92-07.93	AA	0 265 005 111
3.0 i [B54]	3,0l 123-125 kW Z7X 722,723; Z7X 753	6 Zyl.	
Knock sensor	08.92-09.96	LAB	0 261 231 071
		RAB	0 261 231 070
Acceleration sensor, ABS	07.93-09.96	AA	0 265 005 111
Wheel speed sensor, front	04.92-09.96	LAB	0 265 006 361
		RAB	0 265 006 362
Wheel speed sensor, rear	04.92-09.96		0 265 006 363
3.0 i [B54]	3,0l 123-125 kW Z7X 753	6 Zyl.	
Acceleration sensor, ABS	08.92-07.93	AA	0 265 005 111
		AA	0 265 005 111
Wheel speed sensor, front	08.92-09.96	LAB	0 265 006 361
		RAB	0 265 006 362
Wheel speed sensor, rear	08.92-09.96		0 265 006 363
3.0 i [B54]	3,0l 123-125 kW Z7X 755	6 Zyl.	
Knock sensor	10.96-12.00	LAB	0 261 231 071
		RAB	0 261 231 070
Wheel speed sensor, front	10.96-12.00	LAB	0 265 006 361
		RAB	0 265 006 362
Wheel speed sensor, rear	10.96-12.00		0 265 006 363
3.0 i Biturbo [B54]	3,0l 190-197 kW Z7X 726	6 Zyl.	
Knock sensor	02.93-09.96	LAB	0 261 231 071
		RAB	0 261 231 070
Acceleration sensor, ABS	02.93-07.93	AA	0 265 005 111
Wheel speed sensor, front	02.93-09.96	LAB	0 265 006 361
		RAB	0 265 006 362
Wheel speed sensor, rear	02.93-09.96		0 265 006 363
3.0 i 24V [B54]	3,0l 140 kW L7X 713	6 Zyl.	
Knock sensor	03.99-12.00		0 261 231 125
Wheel speed sensor, front	03.99-12.00	LAB	0 265 006 361
		RAB	0 265 006 362
Wheel speed sensor, rear	03.99-12.00		0 265 006 363





Product				

Scenic I				
1.4 i [JA]	1,4 l	70 kW	K4J 714; K4J 750	4 Zyl.
Duo sensor, acceleration and yaw rate, brake system	08.98-04.03		0 265 005 263	
1.6 i [JA]	1,6 l	79 kW	K4M 700,701,706,707,708	4 Zyl.
Duo sensor, acceleration and yaw rate, brake system	08.98→		0 265 005 263	
1.6 i [JA]	1,6 l	79 kW	K4M 709; K4M 712	4 Zyl.
Duo sensor, acceleration and yaw rate, brake system	03.99-04.03		0 265 005 263	
1.6 i [JA]	1,6 l	79 kW	K4M 776	4 Zyl.
Duo sensor, acceleration and yaw rate, brake system	05.05→		0 265 005 263	
1.8 i [JA]	1,8 l	85/88 kW	F4P 720; F4P 722	4 Zyl.
Duo sensor, acceleration and yaw rate, brake system	09.00-04.03		0 265 005 263	
1.9 DCI [JA]	1,9 l	75 kW	F9Q 732	4 Zyl.
Boost pressure sensor, Diesel	10.01-04.03		0 281 002 593	
Duo sensor, acceleration and yaw rate, brake system	03.99-04.03		0 265 005 263	
1.9 DCI [JA]	1,9 l	75 kW	F9Q 733	4 Zyl.
Boost pressure sensor, Diesel	11.02-04.03		0 281 002 593	
Duo sensor, acceleration and yaw rate, brake system	10.99-04.03		0 265 005 263	
1.9 DCI [JA]	1,9 l	75 kW	F9Q 738	4 Zyl.
Boost pressure sensor, Diesel	09.00-04.03		0 281 002 593	
Duo sensor, acceleration and yaw rate, brake system	09.00-04.03		0 265 005 263	
1.9 DCI [JA]	1,9 l	75 kW	F9Q 740	4 Zyl.
Boost pressure sensor, Diesel	10.01-04.03		0 281 002 593	
Duo sensor, acceleration and yaw rate, brake system	06.00-04.03		0 265 005 263	
1.9 DCI [JA]	1,9 l	75 kW	F9Q 746; F9Q 748	4 Zyl.
Duo sensor, acceleration and yaw rate, brake system	02.01-04.03		0 265 005 263	
1.9 DCI [JA]	1,9 l	75 kW	F9Q 796	4 Zyl.
Boost pressure sensor, Diesel	11.02-04.03		0 281 002 593	
Duo sensor, acceleration and yaw rate, brake system	06.97-04.03		0 265 005 263	
1.9 DCI RX4 [JA]	1,9 l	75 kW	F9Q 732	4 Zyl.
Boost pressure sensor, Diesel	10.01-04.03		0 281 002 593	
1.9 DCI RX4 [JA]	1,9 l	75 kW	F9Q 733	4 Zyl.
Boost pressure sensor, Diesel	11.02-04.03		0 281 002 593	
1.9 DCI RX4 [JA]	1,9 l	75 kW	F9Q 740	4 Zyl.
Boost pressure sensor, Diesel	10.01-01.03		0 281 002 593	
1.9 DCI RX4 [JA]	1,9 l	75 kW	F9Q 746; F9Q 748	4 Zyl.
Duo sensor, acceleration and yaw rate, brake system	02.01-04.03		0 265 005 263	
1.9 DCI RX4 [JA]	1,9 l	75 kW	F9Q 796	4 Zyl.
Boost pressure sensor, Diesel	11.02-04.03		0 281 002 593	
1.9 DTI [JA]	1,9 l	59 kW	F9Q 744	4 Zyl.
Duo sensor, acceleration and yaw rate, brake system	11.00-04.03		0 265 005 263	
1.9 DTI [JA]	1,9 l	72 kW	F9Q 734	4 Zyl.
Speed sensor, diesel	06.97-06.98		0 281 002 175	
Pedal position sensor, diesel	06.97-01.99	LLE	0 206 001 021	
	06.97-02.99	RLE	0 281 002 255	
2.0 i [JA]	2,0 l	101,5/102 kW	F4R 740,741,744,746,747	4 Zyl.
Duo sensor, acceleration and yaw rate, brake system	03.99→		0 265 005 263	

Product				

Scenic II				
1.4 16V [JM.]	1,4 l	72 kW	K4J 730; K4J 740	4 Zyl.
Duo sensor, acceleration and yaw rate, brake system	05.03→		0 265 005 263	
1.5 DCI [JM.]	1,5 l	60-63 kW	K9K 722	4 Zyl.
Boost pressure sensor, Diesel	05.03-12.06		0 281 002 573	
Duo sensor, acceleration and yaw rate, brake system	05.03-12.06		0 265 005 263	
1.5 DCI [JM.]	1,5 l	63 kW	K9K 724	4 Zyl.
Boost pressure sensor, Diesel	09.05-12.06		0 281 002 566	
Duo sensor, acceleration and yaw rate, brake system	09.05-12.06		0 265 005 263	
1.5 DCI [JM.]	1,5 l	74-78 kW	K9K 728; K9K 729	4 Zyl.
Boost pressure sensor, Diesel	05.03→		0 281 002 573	
Duo sensor, acceleration and yaw rate, brake system	05.03→		0 265 005 263	
1.5 DCI [JM.]	1,5 l	78 kW	K9K 732	4 Zyl.
Boost pressure sensor, Diesel	09.04→		0 281 002 566	
Duo sensor, acceleration and yaw rate, brake system	09.04→		0 265 005 263	
1.6 16V [JM.]	1,6 l	83 kW	K4M 760,761,762,764,766	4 Zyl.
Duo sensor, acceleration and yaw rate, brake system	05.03→		0 265 005 263	
1.6 16V [JM.]	1,6 l	83 kW	K4M 782,788,812,813	4 Zyl.
Duo sensor, acceleration and yaw rate, brake system	05.03→		0 265 005 263	
1.9 DCI [JM.]	1,9 l	88 kW	F9Q 812	4 Zyl.
Boost pressure sensor, Diesel	05.03→		0 281 002 566	
Duo sensor, acceleration and yaw rate, brake system	05.03→		0 265 005 263	
1.9 DCI [JM.]	1,9 l	96 kW	F9Q 803; F9Q 804; F9Q 814	4 Zyl.
Duo sensor, acceleration and yaw rate, brake system	05.03→		0 265 005 263	
2.0 DCI [JM.]	2,0 l	110 kW	M9R 700	4 Zyl.
Boost pressure sensor, Diesel	09.04→		0 281 002 740	
Duo sensor, acceleration and yaw rate, brake system	09.04→		0 265 005 263	
2.0 DCI [JM.]	2,0 l	110 kW	M9R 720; M9R 721	4 Zyl.
Duo sensor, acceleration and yaw rate, brake system	09.04→		0 265 005 263	
2.0 16V [JM.]	2,0 l	99 kW	F4R 770; F4R 771	4 Zyl.
Duo sensor, acceleration and yaw rate, brake system	05.03→		0 265 005 263	
2.0 16V Turbo [JM.]	2,0 l	120 kW	F4R 776	4 Zyl.
Pressure sensor, intake manifold, gasoline	06.03→		0 281 002 616	
Duo sensor, acceleration and yaw rate, brake system	06.03→		0 265 005 263	
Sport Spider				
2.0	2,0 l	108-110 kW	F7R 710; F7R 712; F7R 714; F7R 720	4 Zyl.
Knock sensor	05.96-10.99		0 261 231 046	
Thalia II				
1.0 i 16V [LB.]	1,0 l	50 kW	D4D 700	4 Zyl.
Duo sensor, acceleration and yaw rate, brake system	06.01-11.04		0 265 005 263	
Wheel speed sensor, front	06.01-11.02		0 265 006 383	
	12.02-11.04		0 265 007 527	
Wheel speed sensor, rear	06.01-11.04	LAB	0 265 006 384	
		RAB	0 265 006 385	



Product		
1.2 i [LB.]	1,2 l 43 kW D7F 726 4 Zyl.	
Duo sensor, acceleration and yaw rate, brake system	06.01-10.07	0 265 005 263
Wheel speed sensor, front	06.01-11.02	0 265 006 383
	12.02-10.07	0 265 007 527
Wheel speed sensor, rear	06.01-10.07 LAB	0 265 006 384
	RAB	0 265 006 385
1.2 i 16V [LB.]	1,2 l 55 kW D4F 706 4 Zyl.	
Duo sensor, acceleration and yaw rate, brake system	09.01-03.04	0 265 005 263
Wheel speed sensor, front	09.01-11.02	0 265 006 383
	12.02-03.04	0 265 007 527
Wheel speed sensor, rear	09.01-03.04 LAB	0 265 006 384
	RAB	0 265 006 385
1.2 i 16V [LB.]	1,2 l 55 kW D4F 712 4 Zyl.	
Duo sensor, acceleration and yaw rate, brake system	09.01-10.07	0 265 005 263
Wheel speed sensor, front	09.01-11.02	0 265 006 383
	12.02-10.07	0 265 007 527
Wheel speed sensor, rear	09.01-11.02 LAB,OTK	0 265 006 384
	12.02-10.07 LAB,OTK	0 265 007 529
	09.01-11.02 OTK,RAB	0 265 006 385
	12.02-10.07 OTK,RAB	0 265 007 528
1.2 i 16V [LB.]	1,2 l 55 kW D4F 728 4 Zyl.	
Duo sensor, acceleration and yaw rate, brake system	04.04-10.07	0 265 005 263
Wheel speed sensor, front	04.04-10.07	0 265 007 527
Wheel speed sensor, rear	04.04-10.07 LAB,OTK	0 265 007 529
	OTK,RAB	0 265 007 528
1.4 i [LB.]	1,4 l 55 kW K7J 700 4 Zyl.	
Duo sensor, acceleration and yaw rate, brake system	10.99-10.07	0 265 005 263
Wheel speed sensor, front	10.99-11.02	0 265 006 383
	12.02-10.07	0 265 007 527
Wheel speed sensor, rear	10.99-10.07 LAB	0 265 006 384
	RAB	0 265 006 385
1.4 i 16V [LB.]	1,4 l 70-72 kW K4J 712; K4J 713 4 Zyl.	
Duo sensor, acceleration and yaw rate, brake system	06.01-10.07	0 265 005 263
Wheel speed sensor, front	06.01-11.02	0 265 006 383
	12.02-10.07	0 265 007 527
Wheel speed sensor, rear	06.01-10.07 LAB	0 265 006 384
	RAB	0 265 006 385
1.5 DCI [LB.]	1,5 l 48 kW K9K 700 4 Zyl.	
Boost pressure sensor, Diesel	12.02-10.07	0 281 002 593
Duo sensor, acceleration and yaw rate, brake system	09.01-10.07	0 265 005 263
Wheel speed sensor, front	09.01-11.02	0 265 006 383
	12.02-10.07	0 265 007 527
Wheel speed sensor, rear	09.01-10.07 LAB	0 265 006 384
	RAB	0 265 006 385
1.5 DCI [LB.]	1,5 l 60 kW K9K 706 4 Zyl.	
Boost pressure sensor, Diesel	05.04-10.07	0 281 002 552
Duo sensor, acceleration and yaw rate, brake system	05.04-10.07	0 265 005 263
Wheel speed sensor, front	05.04-10.07	0 265 007 527
1.6 i [LB.]	1,6 l 66 kW K4M 732; K4M 734 4 Zyl.	
Duo sensor, acceleration and yaw rate, brake system	11.01-10.07	0 265 005 263
Wheel speed sensor, front	11.01-11.02	0 265 006 383
	12.02-10.07	0 265 007 527
Wheel speed sensor, rear	11.01-10.07 LAB	0 265 006 384
	RAB	0 265 006 385



1.6 i [LB.]	1,6 l 66 kW K4M 742; K4M 743 4 Zyl.	
Duo sensor, acceleration and yaw rate, brake system	01.04-10.07	0 265 005 263
Wheel speed sensor, front	01.04-10.07	0 265 007 527
Wheel speed sensor, rear	01.04-10.07 LAB,OTK	0 265 007 529
	OTK,RAB	0 265 007 528
1.6 i [LB.]	1,6 l 66/81 kW K4M 740; K4M 746 4 Zyl.	
Duo sensor, acceleration and yaw rate, brake system	10.99-10.07	0 265 005 263
Wheel speed sensor, front	10.99-11.02	0 265 006 383
	12.02-10.07	0 265 007 527
Wheel speed sensor, rear	10.99-10.07 LAB	0 265 006 384
	RAB	0 265 006 385
1.9 D [LB.]	1,9 l 47-48 kW F8Q 630 4 Zyl.	
Duo sensor, acceleration and yaw rate, brake system	10.99-10.07	0 265 005 263
Wheel speed sensor, front	10.99-11.02	0 265 006 383
	12.02-10.07	0 265 007 527
Wheel speed sensor, rear	10.99-10.07 LAB	0 265 006 384
	RAB	0 265 006 385

Trafic

1.4	1,4 l 36 kW 847 700 4 Zyl.	
Wheel speed sensor, front	09.80-10.97 LAB	0 265 006 156
	RAB	0 265 006 157
Wheel speed sensor, rear	09.80-10.97 LAB	0 265 006 154
	RAB	0 265 006 155
1.6	1,6 l 48/49 kW A1M 707; A1M 708 4 Zyl.	
Wheel speed sensor, front	09.80-02.89 LAB	0 265 006 156
	RAB	0 265 006 157
Wheel speed sensor, rear	09.80-02.89 LAB	0 265 006 154
	RAB	0 265 006 155
1.7	1,7 l 50-58 kW F1N 720; F1N 724,720 4 Zyl.	
Wheel speed sensor, front	10.84-10.97 LAB	0 265 006 156
	RAB	0 265 006 157
Wheel speed sensor, rear	10.84-10.97 LAB	0 265 006 154
	RAB	0 265 006 155
1.9 D	1,9 l 47-48 kW F8Q 600; F8Q 606 4 Zyl.	
Wheel speed sensor, front	11.97-05.01 LAB	0 265 006 156
	RAB	0 265 006 157
Wheel speed sensor, rear	11.97-05.01 LAB	0 265 006 154
	RAB	0 265 006 155
1.9 DCI [EL./FL./JL.]	1,9 l 60/74 kW F9Q 760; F9Q 762 4 Zyl.	
Boost pressure sensor, Diesel	12.02-12.06	0 281 002 593
2.0	2,0 l 59 kW J5R 716 4 Zyl.	
Wheel speed sensor, front	09.80-10.97 LAB	0 265 006 156
	RAB	0 265 006 157
Wheel speed sensor, rear	09.80-10.97 LAB	0 265 006 154
	RAB	0 265 006 155
2.1 D	2,1 l 43/47 kW J8S 622; J8S 758; 852 750 4 Zyl.	
Wheel speed sensor, front	09.80-10.97 LAB	0 265 006 156
	RAB	0 265 006 157
Wheel speed sensor, rear	09.80-10.97 LAB	0 265 006 154
	RAB	0 265 006 155
2.2 i	2,2 l 69-71 kW J7T 780 Kat. 4 Zyl.	
Throttle valve sensor	03.89-10.97	0 280 120 301
Wheel speed sensor, front	03.89-10.97 LAB	0 265 006 156
	RAB	0 265 006 157
Wheel speed sensor, rear	03.89-10.97 LAB	0 265 006 154
	RAB	0 265 006 155





Product



◀ Traffic

2.2 i		2,2l 74 kW J7T 600 Kat. 4 Zyl.	
Wheel speed sensor, front	09.94-10.97	LAB	0 265 006 156
		RAB	0 265 006 157
Wheel speed sensor, rear	09.94-10.97	LAB	0 265 006 154
		RAB	0 265 006 155
2.5 D		2,5l 55 kW S8U 758; S8U 782; 8140.67.2500; 8140.67.2580 4 Zyl.	
Wheel speed sensor, front	03.89-05.01	LAB	0 265 006 156
		RAB	0 265 006 157
Wheel speed sensor, rear	03.89-05.01	LAB	0 265 006 154
		RAB	0 265 006 155
2.5 D 4x4		2,5l 55 kW S8U 758; S8U 780; S8U 782 4 Zyl.	
Wheel speed sensor, front	11.97-05.01	LAB	0 265 006 156
		RAB	0 265 006 157
Wheel speed sensor, rear	11.97-05.01	LAB	0 265 006 154
		RAB	0 265 006 155
2.5 DCI [EL./FL./JL.]		2,5l 98 kW G9U 730 4 Zyl.	
Boost pressure sensor, Diesel	06.02-12.06		0 281 002 552

Twingo I			
1.2 i [C0./S0.]	1,2l 40-44 kW	D7F 700; D7F 701	4 Zyl.
Wheel speed sensor, rear	12.02-05.07	LAB	0 265 007 583
		RAB	0 265 007 582
1.2 i [C0./S0.]	1,2l 43 kW	D7F 702	4 Zyl.
Wheel speed sensor, front	12.02-05.07		0 265 007 527
Wheel speed sensor, rear	12.02-05.07	LAB	0 265 007 583
		RAB	0 265 007 582
1.2 i [C0./S0.]	1,2l 43 kW	D7F 703	4 Zyl.
Wheel speed sensor, rear	12.02-05.07	LAB	0 265 007 583
		RAB	0 265 007 582
1.2 i [C0./S0.]	1,2l 43 kW	D7F 703 EOBD; D7F 704	4 Zyl.
Wheel speed sensor, front	12.02-05.07		0 265 007 527
Wheel speed sensor, rear	12.02-05.07	LAB	0 265 007 583
		RAB	0 265 007 582
1.2 i [C0./S0.]	1,2l 43 kW	D7F 706	4 Zyl.
Wheel speed sensor, rear	12.02-05.07	LAB	0 265 007 583
		RAB	0 265 007 582
1.2 i [C0./S0.]	1,2l 43 kW	D7F 708	4 Zyl.
Wheel speed sensor, front	12.02-05.07		0 265 007 527
Wheel speed sensor, rear	12.02-05.07	LAB	0 265 007 583
		RAB	0 265 007 582
1.2 i 16V [C0./S0.]	1,2l 55 kW	D4F 702; D4F 704; D4F 708	4 Zyl.
Wheel speed sensor, front	12.02-05.07		0 265 007 527
Wheel speed sensor, rear	12.02-05.07	LAB	0 265 007 583
		RAB	0 265 007 582

Vel Satis			
2.0 [BJ0]		2,0l 120 kW F4R 762; F4R 763; F4R 764 4 Zyl.	
Pressure sensor, intake manifold, gasoline	09.03-12.06		0 281 002 616
2.0 [BJ0]		2,0l 120 kW F4R 765; F4R 766; F4R 767 4 Zyl.	
Pressure sensor, intake manifold, gasoline	04.02-12.06		0 281 002 616
2.0 T [BJ0]		2,0l 125 kW F4R 867 4 Zyl.	
Pressure sensor, intake manifold, gasoline	07.05→		0 281 002 616
2.2 DCI [BJ0]		2,2l 102 kW G9T 606 4 Zyl.	
Boost pressure sensor, Diesel	07.05→		0 281 002 566
2.2 DCI [BJ0]		2,2l 110 kW G9T 600 4 Zyl.	
High-pressure sensor (CR system)	09.02→		0 281 002 534
Boost pressure sensor, Diesel	09.02→		0 281 002 566
2.2 DCI [BJ0]		2,2l 110 kW G9T 702; G9T 703 4 Zyl.	
Boost pressure sensor, Diesel	04.02-08.03		0 281 002 552
	09.03→		0 281 002 566

Product



3.0 DCI V6 [BJ0]		3,0l 130/133 kW P9X 701; P9X 715 6 Zyl.	
Air mass meter, diesel	04.02→		0 280 218 079

Winnebago			
2.2 i		2,2l 79 kW J7T 736 4 Zyl.	
Throttle valve sensor	03.88-12.00		0 280 120 301

5			
1.7 i		1,7l 69 kW F3N 702,722 Kat. 4 Zyl.	
Throttle valve sensor	10.86-12.96		0 280 120 301

11			
1.7 i		1,7l 69 kW F3N 708,722 Kat. 4 Zyl.	
Throttle valve sensor	06.87-03.91		0 280 120 301

18 Break			
2.2 i		2,2l 76-77 kW J7T 718,719 Kat. 4 Zyl.	
Throttle valve sensor	10.83-02.86		0 280 120 301
Air flow sensor, gasoline injection	10.83-02.86		0 280 202 049
			0 986 280 053
Pressure sensor, intake manifold, gasoline	10.83-02.86		0 280 101 001
Temperature sensor, coolant, injection system	10.83-02.86		0 280 130 023
Relay, Jetronic	10.83-02.86		0 280 230 006

19

1.2 i [X53]		1,2 l 46 kW E7F 730 Kat. 4 Zyl.	
Wheel speed sensor, front	04.93-12.01	BO	0 265 006 735
Wheel speed sensor, rear	04.93-12.01	BO,LAB	0 265 006 737
		BO,RAB	0 265 006 736
1.4 i [X53]		1,4 l 55-59 kW E7J 700,706,742,745 Kat. 4 Zyl.	
Wheel speed sensor, front	04.93-12.01	BO	0 265 006 735
Wheel speed sensor, rear	04.93-12.01	BO,LAB	0 265 006 737
		BO,RAB	0 265 006 736
1.7 [X53]		1,7 l 55-56/68 kW F2N 720,721,724,726,727 4 Zyl.	
Wheel speed sensor, front	04.93-12.95	BO	0 265 006 735
Wheel speed sensor, rear	04.93-12.95	BO,LAB	0 265 006 737
		BO,RAB	0 265 006 736
1.7 i [X53]		1,7 l 54 kW F3N 740 Kat.; F3N 741 Kat. 4 Zyl.	
Knock sensor	09.88-12.95		0 261 231 006
Wheel speed sensor, front	04.93-12.95	BO	0 265 006 735
Wheel speed sensor, rear	04.93-12.95	BO,LAB	0 265 006 737
		BO,RAB	0 265 006 736

1.7 i [X53]		1,7l 66-70 kW F3N 742 Kat.; F3N 743 Kat. 4 Zyl.	
Throttle valve sensor	09.88-12.95		0 280 120 301
Wheel speed sensor, front	04.93-12.95	BO	0 265 006 735
Wheel speed sensor, rear	04.93-12.95	BO,LAB	0 265 006 737
		BO,RAB	0 265 006 736
1.7 i [X53]		1,7l 66-70 kW F3N 746 4 Zyl.	
Knock sensor	06.89-12.95		0 261 231 006
Wheel speed sensor, front	04.93-12.95	BO	0 265 006 735
Wheel speed sensor, rear	04.93-12.95	BO,LAB	0 265 006 737
		BO,RAB	0 265 006 736
1.8 i [X53]		1,8l 65 kW F3P 704,705,706,707,708 Kat. 4 Zyl.	
Wheel speed sensor, front	04.93-12.95	BO	0 265 006 735
Wheel speed sensor, rear	04.93-12.95	BO,LAB	0 265 006 737
		BO,RAB	0 265 006 736



1.8i [X53] 1,8l 65-66/79-83 kW F3P 682,700,706,760,765 Kat. 4 Zyl.			
Wheel speed sensor, front	04.93-12.95	BO	0 265 006 735
Wheel speed sensor, rear	04.93-12.95	BO,LAB BO,RAB	0 265 006 737 0 265 006 736
1.8i 16V [X53] 1,8l 99-101 kW F7P 704 Kat. 4 Zyl.			
Wheel speed sensor, front	04.93-12.95	BO	0 265 006 735
Wheel speed sensor, rear	04.93-12.95	BO,LAB BO,RAB	0 265 006 737 0 265 006 736
1.9 D [X53] 1,9l 47 kW F8Q 706,742,764 4 Zyl.			
Wheel speed sensor, front	04.93-12.01	BO	0 265 006 735
Wheel speed sensor, rear	04.93-12.01	BO,LAB BO,RAB	0 265 006 737 0 265 006 736
1.9 D Turbo [X53] 1,9l 66-68 kW F8Q 610,740,744,768 4 Zyl.			
Wheel speed sensor, front	04.93-12.01	BO	0 265 006 735
Wheel speed sensor, rear	04.93-12.01	BO,LAB BO,RAB	0 265 006 737 0 265 006 736

19 Cabrio

1.7i [X53] 1,7l 66-70 kW F3N 742,743 Kat. 4 Zyl.			
Throttle valve sensor	09.88-12.95		0 280 120 301
Wheel speed sensor, front	04.93-12.95	BO	0 265 006 735
Wheel speed sensor, rear	04.93-12.95	BO,LAB BO,RAB	0 265 006 737 0 265 006 736
1.8i [X53] 1,8l 65 kW F3P 704,705,706,707,708 Kat. 4 Zyl.			
Wheel speed sensor, front	04.93-12.95	BO	0 265 006 735
Wheel speed sensor, rear	04.93-12.95	BO,LAB BO,RAB	0 265 006 737 0 265 006 736
1.8i [X53] 1,8l 65-66/79-83 kW F3P 682,706,760,764,765 Kat. 4 Zyl.			
Wheel speed sensor, front	04.93-12.95	BO	0 265 006 735
Wheel speed sensor, rear	04.93-12.95	BO,LAB BO,RAB	0 265 006 737 0 265 006 736
1.8i 16V [X53] 1,8l 99-101 kW F7P 704 Kat. 4 Zyl.			
Wheel speed sensor, front	04.93-12.95	BO	0 265 006 735
Wheel speed sensor, rear	04.93-12.95	BO,LAB BO,RAB	0 265 006 737 0 265 006 736

19 Sedan

1.6i 1,6l 61 kW C3L 4 Zyl.			
Speed sensor, ignition/injection	01.93-05.00		0 261 210 137
Temperature sensor, intake air, injection system	01.93-05.00		0 280 130 068

21

1.7i [L48] 1,7l 66-70 kW F3N 722,723 Kat. 4 Zyl.			
Throttle valve sensor	03.86-12.94	GS	0 280 120 301
2.0i [L48] 2,0l 86/88/98-102 kW J7R 746,747 Kat.; J7R 750,751,754 4 Zyl.			
Throttle valve sensor	10.86-12.94	GS	0 280 120 301
2.0i Turbo [L48] 2,0l 119-129 kW J7R 752 4 Zyl.			
Throttle valve sensor	04.87-03.92	GS	0 280 120 301
2.2i [L48] 2,2l 79-81 kW J7T 754,755 Kat. 4 Zyl.			
Throttle valve sensor	07.86-12.94	GS	0 280 120 301

21 Fastback

1.7i [B48] 1,7l 66-70 kW F3N 722,723 Kat. 4 Zyl.			
Throttle valve sensor	09.89-12.93	GS	0 280 120 301
2.0i [B48] 2,0l 85-86/88 kW J7R 746,747 Kat.; J7R 750,751 4 Zyl.			
Throttle valve sensor	09.89-12.93	GS	0 280 120 301
2.2i [B48] 2,2l 79-81 kW J7T 754,755 Kat. 4 Zyl.			
Throttle valve sensor	09.89-12.93	GS	0 280 120 301



21 Nevada

1.7i [K48] 1,7l 66-70 kW F3N 722,723 Kat. 4 Zyl.			
Throttle valve sensor	06.86-12.95		0 280 120 301
2.0i [K48] 2,0l 85-88 kW J7R 750,751 4 Zyl.			
Throttle valve sensor	10.86-12.95		0 280 120 301
2.2i [K48] 2,2l 79-81 kW J7T 754,755 Kat.; J7T 756 Kat. 4 Zyl.			
Throttle valve sensor	10.86-12.95		0 280 120 301

25

2.0 2,0l 74 kW J6R 706,707; J6R 760,762,763 4 Zyl.			
Wheel speed sensor, front	01.85-12.92	LAB RAB	0 265 001 069 0 265 001 068
Wheel speed sensor, rear	01.85-12.92	LAB RAB	0 265 001 071 0 265 001 070

2.0i 2,0l 88/99-100/103 kW J7R 720,721; J7R 722,723; J7R 726 Kat. 4 Zyl.			
Throttle valve sensor	06.87-12.92		0 280 120 301
Wheel speed sensor, front	06.87-12.92	LAB RAB	0 265 001 069 0 265 001 068
Wheel speed sensor, rear	06.87-12.92	LAB RAB	0 265 001 071 0 265 001 070

2.1 D 2,1l 46/50-51 kW J8S 706; J8S 736 4 Zyl.			
Wheel speed sensor, front	01.85-12.92	LAB RAB	0 265 001 069 0 265 001 068
Wheel speed sensor, rear	01.85-12.92	LAB RAB	0 265 001 071 0 265 001 070

2.1 D Turbo 2,1l 63 kW J8S 708; J8S 738 4 Zyl.			
Wheel speed sensor, front	01.85-12.92	LAB RAB	0 265 001 069 0 265 001 068
Wheel speed sensor, rear	01.85-12.92	LAB RAB	0 265 001 071 0 265 001 070

2.2i 2,2l 79 kW J7T 708 4 Zyl.			
Throttle valve sensor	10.85-10.86		0 280 120 301
Air flow sensor, gasoline injection	10.85-10.86		0 280 202 049 0 986 280 053

Pressure sensor, intake manifold, gasoline	10.85-10.86		0 280 101 001
Relay, Jetronic	10.85-10.86		0 280 230 006
Wheel speed sensor, front	10.85-10.86	LAB RAB	0 265 001 069 0 265 001 068
Wheel speed sensor, rear	10.85-10.86	LAB RAB	0 265 001 071 0 265 001 070

2.2i 2,2l 79-81 kW J7T 732,733 Kat. 4 Zyl.			
Throttle valve sensor	10.86-12.92		0 280 120 301
Wheel speed sensor, front	10.86-12.92	LAB RAB	0 265 001 069 0 265 001 068
Wheel speed sensor, rear	10.86-12.92	LAB RAB	0 265 001 071 0 265 001 070

2.2i 2,2l 89 kW J7T 706,707 4 Zyl.			
Throttle valve sensor	10.85-10.86		0 280 120 301
Temperature sensor, coolant, injection system	01.84-10.86		0 280 130 026
Wheel speed sensor, front	01.85-10.86	LAB RAB	0 265 001 069 0 265 001 068
Wheel speed sensor, rear	01.85-10.86	LAB RAB	0 265 001 071 0 265 001 070

2.2i 2,2l 89 kW J7T 714 4 Zyl.			
Temperature sensor, coolant, injection system	01.84-04.88		0 280 130 026
Wheel speed sensor, front	01.85-04.88	LAB RAB	0 265 001 069 0 265 001 068
Wheel speed sensor, rear	01.85-04.88	LAB RAB	0 265 001 071 0 265 001 070





Product				

◀ 25

2.2 i		2,2l 89 kW J7T 715 4 Zyl.	
Wheel speed sensor, front	01.85-04.88	LAB	0 265 001 069
		RAB	0 265 001 068
Wheel speed sensor, rear	01.85-04.88	LAB	0 265 001 071
		RAB	0 265 001 070
2.2 i		2,2l 91 kW J7T 730,731 4 Zyl.	
Throttle valve sensor	10.86-05.90		0 280 120 301
Wheel speed sensor, front	10.86-05.90	LAB	0 265 001 069
		RAB	0 265 001 068
Wheel speed sensor, rear	10.86-05.90	LAB	0 265 001 071
		RAB	0 265 001 070
2.5 i Turbo		2,5l 133/147-151 kW Z7U 700; Z7U 702,704 6 Zyl.	
Wheel speed sensor, front	01.85-12.92	LAB	0 265 001 069
		RAB	0 265 001 068
Wheel speed sensor, rear	01.85-12.92	LAB	0 265 001 071
		RAB	0 265 001 070
2.7 i		2,7l 104 kW Z7V 708; Z7V 709; Z7V 711 6 Zyl.	
Air flow sensor, gasoline injection	01.84-08.89		0 438 121 021
Temperature sensor, coolant, injection system	01.84-08.89		0 280 130 028
Wheel speed sensor, front	01.85-08.89	LAB	0 265 001 069
		RAB	0 265 001 068
Wheel speed sensor, rear	01.85-08.89	LAB	0 265 001 071
		RAB	0 265 001 070
2.9 i		2,9l 100 kW Z7W 702 6 Zyl.	
Air flow sensor, gasoline injection	10.86-06.87		0 438 121 048
Temperature sensor, coolant, injection system	10.86-06.87		0 280 130 028
Wheel speed sensor, front	10.86-06.87	LAB	0 265 001 069
		RAB	0 265 001 068
Wheel speed sensor, rear	10.86-06.87	LAB	0 265 001 071
		RAB	0 265 001 070
2.9 i		2,9l 110-112/115 kW Z7W 700,701,709; Z7W 706,707 Kat. 6 Zyl.	
Wheel speed sensor, front	06.87-12.92	LAB	0 265 001 069
		RAB	0 265 001 068
Wheel speed sensor, rear	06.87-12.92	LAB	0 265 001 071
		RAB	0 265 001 070

ROLLS-ROYCE

Corniche			
6.8		6,8l 162 kW OHV V8 8 Zyl.	
Throttle valve sensor	07.89-12.90		0 280 120 300
Air flow sensor, gasoline injection	07.89-03.93		F 026 TX2 056
			🐼 F 026 TX2 056
Speed sensor, ignition/injection	07.89-03.93		0 261 210 047
Temperature sensor, coolant, injection system	07.89-03.93		0 280 130 026
6.8		6,8l 176 kW OHV V8 8 Zyl.	
Throttle valve sensor	01.86-12.90		0 280 120 300
Air flow sensor, gasoline injection	07.89-03.93		F 026 TX2 056
			🐼 F 026 TX2 056
	01.86-03.89		0 438 120 213
Speed sensor, ignition/injection	07.89-03.93		0 261 210 047
Temperature sensor, coolant, injection system	01.89-03.93		0 280 130 026
6.8		6,8l 176 kW OHV V8 Kat. 8 Zyl.	
Throttle valve sensor	01.87-05.90		0 280 120 300
Air flow sensor, gasoline injection	01.87-05.90		0 438 120 214
6.8		6,8l 184 kW L 410 M 8 Zyl.	
Throttle valve sensor	04.93-08.94		0 280 122 007
Air mass meter, gasoline injection	04.93-08.94		0 280 217 801
Speed sensor, ignition/injection	04.93-08.94		0 261 210 047
Temperature sensor, intake air, injection system	04.93-08.94		0 280 130 039
Temperature sensor, coolant, injection system	04.93-08.94		0 280 130 026

Product				

Drophead

6.8 [RR2]		6,7l 338 kW N73 B68 12 Zyl.	
Air mass meter, gasoline injection	06.07→		0 280 218 076

Flying

6.8 Spur V8		6,8l 182 kW OHV V8 8 Zyl.	
Throttle valve sensor	08.94-07.95		0 280 122 007
Air mass meter, gasoline injection	08.94-07.95		0 280 217 801
Phase sensor	08.94-07.95		0 232 103 010
Pulse generator, ignition/Jetronic	08.94-07.95		0 261 210 047
Pressure sensor, intake manifold, gasoline	08.94-07.95		0 261 230 004
Temperature sensor, intake air, injection system	08.94-07.95		0 280 130 039
Temperature sensor, coolant, injection system	08.94-07.95		0 280 130 026

Phantom

6.8 [RR1]		6,7l 338 kW N73 B68 12 Zyl.	
Air mass meter, gasoline injection	03.03→		0 280 218 076

Silver Spirit

6.8		6,8l 162 kW OHV V8 8 Zyl.	
Throttle valve sensor	01.87-03.93		0 280 120 300
Air flow sensor, gasoline injection	07.89-03.93		F 026 TX2 056
			🐼 F 026 TX2 056
	01.87-07.89		0 438 120 214
Speed sensor, ignition/injection	07.89-03.93		0 261 210 047
6.8		6,8l 176 kW OHV V8 8 Zyl.	
Throttle valve sensor	03.86-03.89		0 280 120 300
Air flow sensor, gasoline injection	07.89-03.93		F 026 TX2 056
			🐼 F 026 TX2 056
	03.86-03.89		0 438 120 213
Speed sensor, ignition/injection	07.89-03.93		0 261 210 047
6.8		6,8l 180 kW OHV V8 8 Zyl.	
Air flow sensor, gasoline injection	10.80-12.86		0 438 120 157
6.8		6,8l 184 kW L 410 MN 1T 4 Zyl.	
Throttle valve sensor	03.94-05.98		0 280 122 007
Air mass meter, gasoline injection	03.94-05.98		0 280 217 801
Phase sensor	08.95-05.98		0 232 103 010
Speed sensor, ignition/injection	03.94-05.98		0 261 210 047
Pressure sensor, intake manifold, gasoline	08.95-05.98		0 261 230 004
Temperature sensor, intake air, injection system	03.94-08.95		0 280 130 039
	08.95-05.98		0 280 130 039
Temperature sensor, coolant, injection system	03.94-05.98		0 280 130 026

Silver Spur

6.8		6,8l 162 kW OHV V8 8 Zyl.	
Throttle valve sensor	01.87-03.93		0 280 120 300
Air flow sensor, gasoline injection	07.89-03.93		F 026 TX2 056
			🐼 F 026 TX2 056
	01.87-07.89		0 438 120 214
Speed sensor, ignition/injection	07.89-03.93		0 261 210 047
6.8		6,8l 176 kW OHV V8 8 Zyl.	
Throttle valve sensor	03.86-05.90		0 280 120 300
Air flow sensor, gasoline injection	03.86-05.90		0 438 120 213
6.8		6,8l 180 kW OHV V8 8 Zyl.	
Air flow sensor, gasoline injection	10.80-12.86		0 438 120 157
6.8		6,8l 182 kW OHV V8 8 Zyl.	
Throttle valve sensor	04.93-12.98		0 280 122 007
Air mass meter, gasoline injection	04.93-12.98		0 280 217 801



Phase sensor	08.95-12.98	0 232 103 010
Speed sensor, ignition/injection	04.93-12.98	0 261 210 047
Pressure sensor, intake manifold, gasoline	08.95-12.98	0 261 230 004
Temperature sensor, intake air, injection system	08.95-12.98	0 280 130 039
Temperature sensor, coolant, injection system	04.93-12.98	0 280 130 026

ROVER

Maestro

2.0i	2,0l 83 kW 20 H-EFI 4 Zyl.
Relay, Jetronic	09.88-12.93 DID 0 332 014 112

Montego

2.0i, iEstate	2,0l 83 kW 20 H 4 Zyl.
Relay, Jetronic	09.88-12.93 DID 0 332 014 112

Serie 200

211i	1,1l 44-45 kW 11K2D 4 Zyl.
Wheel speed sensor, front	03.96-03.00 LAB 0 265 006 305
	11.95-02.96 LAB 0 265 006 474
	03.96-03.00 RAB 0 265 006 306
	11.95-02.96 RAB 0 265 006 473
Wheel speed sensor, rear	11.95-02.96 LAB 0 265 006 476
	RAB 0 265 006 475
Fg.no. WD 267264→	11.95-03.00 4SB 0 265 006 307
214 Cabrio	1,4l 66 kW 14 K4C 4 Zyl.
Wheel speed sensor, front	10.92-02.96 LAB 0 265 006 474
	RAB 0 265 006 473
Wheel speed sensor, rear	10.92-02.96 LAB 0 265 006 476
	RAB 0 265 006 475
214i	1,4l 55 kW 14K2A 4 Zyl.
Wheel speed sensor, front	01.93-02.96 LAB 0 265 006 474
	RAB 0 265 006 473
Wheel speed sensor, rear	01.93-02.96 LAB 0 265 006 476
	RAB 0 265 006 475
214i	1,4l 55 kW 14K2F 4 Zyl.
Wheel speed sensor, front	03.96-03.00 LAB 0 265 006 305
	10.95-02.96 LAB 0 265 006 474
	03.96-03.00 RAB 0 265 006 306
	10.95-02.96 RAB 0 265 006 473
Wheel speed sensor, rear	10.95-02.96 LAB 0 265 006 476
	RAB 0 265 006 475
Fg.no. WD 267264→	10.95-03.00 4SB 0 265 006 307
214i 16V	1,4l 66-70 kW 14K4C 4 Zyl.
Wheel speed sensor, front	10.89-09.93 LAB 0 265 006 474
	RAB 0 265 006 473
Wheel speed sensor, rear	10.89-09.93 LAB 0 265 006 476
	RAB 0 265 006 475
214S	1,4l 55-56 kW 4 Zyl.
Wheel speed sensor, front	10.89-12.92 LAB 0 265 006 474
	RAB 0 265 006 473
Wheel speed sensor, rear	10.89-12.92 LAB 0 265 006 476
	RAB 0 265 006 475
214Si 16V	1,4l 76 kW K16 4 Zyl.
Wheel speed sensor, front	10.92-02.96 LAB 0 265 006 474
	RAB 0 265 006 473
Wheel speed sensor, rear	10.92-02.96 LAB 0 265 006 476
	RAB 0 265 006 475



214 Si 16V Cabrio	1,4l 76 kW K16 4 Zyl.
Wheel speed sensor, front	03.96-03.96 LAB 0 265 006 305
	10.92-02.96 LAB 0 265 006 474
	03.96-03.96 RAB 0 265 006 306
	10.92-02.96 RAB 0 265 006 473
Wheel speed sensor, rear	03.96-03.96 LAB 0 265 006 267
	10.92-02.96 LAB 0 265 006 476
	03.96-03.96 RAB 0 265 006 268
	10.92-02.96 RAB 0 265 006 475
214 16V Coupé	1,4l 76 kW 14KAF 4 Zyl.
Wheel speed sensor, front	03.96-03.00 LAB 0 265 006 305
	10.95-02.96 LAB 0 265 006 474
	03.96-03.00 RAB 0 265 006 306
	10.95-02.96 RAB 0 265 006 473
Wheel speed sensor, rear	10.95-02.96 LAB 0 265 006 476
	RAB 0 265 006 475
Fg.no. WD 267264→	10.95-03.00 4SB 0 265 006 307
216 GTi 16V	1,6l 90-96 kW D16A... 4 Zyl.
Wheel speed sensor, rear	09.90-02.96 LAB 0 265 006 476
	RAB 0 265 006 475
216 GTi 16V Cabrio	1,6l 90 kW D16A8 4 Zyl.
Wheel speed sensor, rear	01.92-02.96 LAB 0 265 006 476
	RAB 0 265 006 475
216i 16V	1,6l 82-85 kW D16... 4 Zyl.
Wheel speed sensor, rear	10.89-02.96 LAB 0 265 006 476
	RAB 0 265 006 475
216i 16V Cabrio, i 16V Coupé	1,6l 82 kW 16K4F 4 Zyl.
Wheel speed sensor, front	03.96-03.00 LAB 0 265 006 305
	RAB 0 265 006 306
Wheel speed sensor, rear	03.96-03.00 LAB 0 265 006 267
	RAB 0 265 006 268
216i 16V Coupé	1,6l 90 kW D1622 4 Zyl.
Wheel speed sensor, rear	10.89-02.96 LAB 0 265 006 476
	RAB 0 265 006 475
216 Vitesse	1,6l 76 kW 16 H 4 Zyl.
Relay, Jetronic	03.85-12.89 DID 0 332 014 112
216 16V	1,6l 82 kW 16K4F 4 Zyl.
Wheel speed sensor, front	03.96-03.00 LAB 0 265 006 305
	10.95-02.96 LAB 0 265 006 474
	03.96-03.00 RAB 0 265 006 306
	10.95-02.96 RAB 0 265 006 473
Wheel speed sensor, rear	03.96-03.00 0 265 006 307
	10.95-02.96 LAB 0 265 006 476
	RAB 0 265 006 475
Fg.no. WD 267264→	10.95-03.00 4SB 0 265 006 307
218 D Turbo	1,8l 65 kW XUD7TE 4 Zyl.
Wheel speed sensor, front	10.92-02.96 LAB 0 265 006 474
	RAB 0 265 006 473
Wheel speed sensor, rear	10.92-02.96 LAB 0 265 006 476
	RAB 0 265 006 475
218i 16V	1,8l 88/107 kW S; 18K4K-VVC- 4 Zyl.
Wheel speed sensor, front	03.96-03.00 LAB 0 265 006 305
	09.95-02.96 LAB 0 265 006 474
	03.96-03.00 RAB 0 265 006 306
	09.95-02.96 RAB 0 265 006 473
Wheel speed sensor, rear	09.95-02.96 LAB 0 265 006 476
	RAB 0 265 006 475
Fg.no. WD 267264→	09.95-03.00 4SB 0 265 006 307
218i 16V Coupé	1,8l 107 kW 4 Zyl.
Wheel speed sensor, front	03.96-03.00 LAB 0 265 006 305
	RAB 0 265 006 306
Wheel speed sensor, rear	03.96-03.00 LAB 0 265 006 267
	RAB 0 265 006 268





Product

◀ Serie 200

218 1.9 D		1,9l 52 kW PSA 4 Zyl.	
Wheel speed sensor, front	10.92-12.94	LAB	0 265 006 474
		RAB	0 265 006 473
Wheel speed sensor, rear	10.92-12.94	LAB	0 265 006 476
		RAB	0 265 006 475
220 GTi 16V		2,0l 103 kW T16 4 Zyl.	
Wheel speed sensor, front	03.96-06.96	LAB	0 265 006 305
	09.91-02.96	LAB	0 265 006 474
	03.96-06.96	RAB	0 265 006 306
	09.91-02.96	RAB	0 265 006 473
Wheel speed sensor, rear	03.96-06.96		0 265 006 307
	09.91-02.96	LAB	0 265 006 476
		RAB	0 265 006 475
220 GTi/GSi		2,0l 100 kW T16 4 Zyl.	
Wheel speed sensor, front	03.96-06.96	LAB	0 265 006 305
	10.92-02.96	LAB	0 265 006 474
	03.96-06.96	RAB	0 265 006 306
	10.92-02.96	RAB	0 265 006 473
Wheel speed sensor, rear	03.96-06.96		0 265 006 307
	10.92-02.96	LAB	0 265 006 476
		RAB	0 265 006 475
220 i Turbo, i Turbo Coupé		2,0l 147 kW 20T4G 4 Zyl.	
Wheel speed sensor, front	03.96-06.96	LAB	0 265 006 305
	01.93-02.96	LAB	0 265 006 474
	03.96-06.96	RAB	0 265 006 306
	01.93-02.96	RAB	0 265 006 473
Wheel speed sensor, rear	03.96-06.96		0 265 006 307
	01.93-02.96	LAB	0 265 006 476
		RAB	0 265 006 475
220 SD		2,0l 63 kW 20 T 2R 4 Zyl.	
Air mass meter, diesel			
Fg.no. YD 471565→	09.95-03.00		0 280 218 012
Fg.no. →YD 471564	09.95-03.00		0 281 002 120
Speed sensor, diesel	09.95-03.00	BO	0 281 002 121
Pressure sensor, intake manifold, diesel			
Fg.no. →YD 471564	09.95-03.00		0 281 002 119
Temperature sensor, intake air, diesel	09.95-03.00		0 280 130 039
Wheel speed sensor, front	03.96-03.00	LAB	0 265 006 305
	09.95-02.96	LAB	0 265 006 474
	03.96-03.00	RAB	0 265 006 306
	09.95-02.96	RAB	0 265 006 473
Wheel speed sensor, rear	09.95-02.96	LAB	0 265 006 476
		RAB	0 265 006 475
Fg.no. WD 267264→	09.95-03.00	4SB	0 265 006 307
220 SDI		2,0l 77 kW 20T 2N 4 Zyl.	
Air mass meter, diesel			
Fg.no. YD 471565→	09.95-03.00		0 280 218 012
Fg.no. →YD 471564	09.95-03.00		0 281 002 120
Speed sensor, diesel	09.95-03.00	BO	0 281 002 121
Pressure sensor, intake manifold, diesel			
Fg.no. →YD 471564	09.95-03.00		0 281 002 119
Temperature sensor, intake air, diesel	09.95-03.00		0 280 130 039
Wheel speed sensor, front	03.96-03.00	LAB	0 265 006 305
	09.95-02.96	LAB	0 265 006 474
	03.96-03.00	RAB	0 265 006 306
	09.95-02.96	RAB	0 265 006 473
Wheel speed sensor, rear	09.95-02.96	LAB	0 265 006 476
		RAB	0 265 006 475
Fg.no. WD 267264→	09.95-03.00	4SB	0 265 006 307

Product

Serie 400

414 Si 16V		1,4l 76 kW K16 4 Zyl.	
Wheel speed sensor, front	05.95-03.00	LAB	0 265 006 258
		RAB	0 265 006 259
Wheel speed sensor, rear	05.95-03.00	4SB,LAB	0 265 006 267
		4SB,RAB	0 265 006 268
414 16V		1,4l 66-70 kW 14K4C 4 Zyl.	
Wheel speed sensor, front	04.90-10.92	LAB	0 265 006 474
		RAB	0 265 006 473
Wheel speed sensor, rear	04.90-10.92	LAB	0 265 006 476
		RAB	0 265 006 475
414 16V		1,4l 76 kW K14K4F 4 Zyl.	
Wheel speed sensor, front	05.95-02.96	GS,LAB	0 265 006 258
		GS,RAB	0 265 006 259
	01.93-04.95	LAB	0 265 006 474
		RAB	0 265 006 473
Wheel speed sensor, rear	01.93-04.95	LAB	0 265 006 476
		RAB	0 265 006 475
	05.95-02.96	4SB,LAB	0 265 006 267
		4SB,RAB	0 265 006 268
416 GSi 16V		1,6l 82-85 kW D16Z2 4 Zyl.	
Wheel speed sensor, front	05.95-02.96	GS,LAB	0 265 006 258
		GS,RAB	0 265 006 259
Wheel speed sensor, rear	04.90-02.96	LAB	0 265 006 476
		RAB	0 265 006 475
	05.95-02.96	4SB,LAB	0 265 006 267
		4SB,RAB	0 265 006 268
416 GTi 16V		1,6l 90-96 kW 16V ZC 4 Zyl.	
Wheel speed sensor, front	05.95-02.96	GS,LAB	0 265 006 258
		GS,RAB	0 265 006 259
Wheel speed sensor, rear	04.90-02.96	LAB	0 265 006 476
		RAB	0 265 006 475
	05.95-02.96	4SB,LAB	0 265 006 267
		4SB,RAB	0 265 006 268
416 i 16V		1,6l 82/83 kW ; K16 4 Zyl.	
Wheel speed sensor, front	05.95-02.96	GS,LAB	0 265 006 258
		GS,RAB	0 265 006 259
	03.96-03.00	LAB	0 265 006 305
		RAB	0 265 006 306
Wheel speed sensor, rear	05.95-03.00	4SB,LAB	0 265 006 267
		4SB,RAB	0 265 006 268
418 D 1.9		1,9l 49 kW XUD9 4 Zyl.	
Wheel speed sensor, front	09.91-04.95	LAB	0 265 006 474
		RAB	0 265 006 473
Wheel speed sensor, rear	09.91-04.95	LAB	0 265 006 476
		RAB	0 265 006 475
418 GSi 16V Coupé		1,8l 107 kW 4 Zyl.	
Wheel speed sensor, front	01.97-12.98	GS,LAB	0 265 006 258
		GS,RAB	0 265 006 259
Wheel speed sensor, rear	01.97-12.98	4SB,LAB	0 265 006 267
		4SB,RAB	0 265 006 268
418 TD		1,8l 65 kW XUD7TE 4 Zyl.	
Wheel speed sensor, front	05.95-02.96	GS,LAB	0 265 006 258
		GS,RAB	0 265 006 259
	09.91-04.95	LAB	0 265 006 474
		RAB	0 265 006 473
Wheel speed sensor, rear	09.91-04.95	LAB	0 265 006 476
		RAB	0 265 006 475
	05.95-02.96	4SB,LAB	0 265 006 267
		4SB,RAB	0 265 006 268



R



420 i Turbo 16V		2,0l 147 kW 20 T4G 4 Zyl.	
Wheel speed sensor, front	05.95-02.96	GS,LAB	0 265 006 258
		GS,RAB	0 265 006 259
	01.93-04.95	LAB	0 265 006 474
		RAB	0 265 006 473
Wheel speed sensor, rear	01.93-04.95	LAB	0 265 006 476
		RAB	0 265 006 475
	05.95-02.96	4SB,LAB	0 265 006 267
		4SB,RAB	0 265 006 268
420 SD		2,0l 63 kW 20T2R-TCieM 4 Zyl.	
Air mass meter, diesel			
Fg.no. YD 471064→	10.95-03.00		0 280 218 012
Fg.no. →YD 471063	10.95-03.00		0 281 002 120
Speed sensor, diesel	10.95-03.00	BO	0 281 002 121
Pressure sensor, intake manifold, diesel			
Fg.no. →YD 471063	10.95-03.00		0 281 002 119
Temperature sensor, intake air, diesel	10.95-03.00		0 280 130 039
Wheel speed sensor, front	10.95-03.00	GS,LAB	0 265 006 258
		GS,RAB	0 265 006 259
Wheel speed sensor, rear	10.95-03.00	4SB,LAB	0 265 006 267
		4SB,RAB	0 265 006 268
420 SDI		2,0l 77 kW 20T2N-TCie 4 Zyl.	
Air mass meter, diesel			
Fg.no. YD 471064→	10.95-03.00		0 280 218 012
Fg.no. →YD 471063	10.95-03.00		0 281 002 120
Speed sensor, diesel	10.95-03.00	BO	0 281 002 121
Pressure sensor, intake manifold, diesel			
Fg.no. →YD 471063	10.95-03.00		0 281 002 119
Temperature sensor, intake air, diesel	10.95-03.00		0 280 130 039
Wheel speed sensor, front	10.95-03.00	GS,LAB	0 265 006 258
		GS,RAB	0 265 006 259
Wheel speed sensor, rear	10.95-03.00	4SB,LAB	0 265 006 267
		4SB,RAB	0 265 006 268
420 16V		2,0l 100 kW 20T 4H 4 Zyl.	
Wheel speed sensor, front	10.95-03.00	GS,LAB	0 265 006 258
		GS,RAB	0 265 006 259
Wheel speed sensor, rear	10.95-03.00	4SB,LAB	0 265 006 267
		4SB,RAB	0 265 006 268
420 16V		2,0l 103 kW T16 4 Zyl.	
Wheel speed sensor, front	05.95-02.96	GS,LAB	0 265 006 258
		GS,RAB	0 265 006 259
	02.92-04.95	LAB	0 265 006 474
		RAB	0 265 006 473
Wheel speed sensor, rear	02.92-04.95	LAB	0 265 006 476
		RAB	0 265 006 475
	05.95-02.96	4SB,LAB	0 265 006 267
		4SB,RAB	0 265 006 268

Serie 400 Tourer

414 Si 16V		1,4l 76 kW K16 4 Zyl.	
Wheel speed sensor, front	05.95-03.00	LAB	0 265 006 258
		RAB	0 265 006 259
Wheel speed sensor, rear	05.95-03.00	4SB,LAB	0 265 006 267
		4SB,RAB	0 265 006 268
416 GSi 16V		1,6l 82-85 kW D16Z2 4 Zyl.	
Wheel speed sensor, front	05.95-02.96	GS,LAB	0 265 006 258
		GS,RAB	0 265 006 259
Wheel speed sensor, rear	04.90-02.96	LAB	0 265 006 476
		RAB	0 265 006 475
	05.95-02.96	4SB,LAB	0 265 006 267
		4SB RAB	0 265 006 268



416 GTi 16V		1,6l 90-96 kW 16V ZC 4 Zyl.
Wheel speed sensor, front	05.95-02.96	GS,LAB 0 265 006 258
		GS,RAB 0 265 006 259
Wheel speed sensor, rear	04.90-02.96	LAB 0 265 006 476
		RAB 0 265 006 475
	05.95-02.96	4SB,LAB 0 265 006 267
		4SB,RAB 0 265 006 268
416 i 16V		1,6l 82 kW D16B2/D16Y3 4 Zyl.
Wheel speed sensor, front	03.96-03.00	LAB 0 265 006 305
		RAB 0 265 006 306
Wheel speed sensor, rear	02.96-03.00	4SB,LAB 0 265 006 267
		4SB,RAB 0 265 006 268
418 D 1.9		1,9l 49 kW XUD9 4 Zyl.
Wheel speed sensor, front	09.91-04.95	LAB 0 265 006 474
		RAB 0 265 006 473
Wheel speed sensor, rear	09.91-04.95	LAB 0 265 006 476
		RAB 0 265 006 475
418 i 16V		1,8l 107 kW 4 Zyl.
Wheel speed sensor, front	03.96-12.98	LAB 0 265 006 305
		RAB 0 265 006 306
Wheel speed sensor, rear	03.96-12.98	4SB,LAB 0 265 006 267
		4SB,RAB 0 265 006 268
418 TD		1,8l 65 kW XUD7TE 4 Zyl.
Wheel speed sensor, front	03.96-03.00	LAB 0 265 006 305
		RAB 0 265 006 306
Wheel speed sensor, rear	02.96-03.00	4SB,LAB 0 265 006 267
		4SB,RAB 0 265 006 268

Serie 600

620 i 16V Turbo		2,0l 147 kW T16-Turbo 4 Zyl.	
Wheel speed sensor, front			
Fg.no. →AM 246796	04.93-12.98	LAB	0 265 006 168
		RAB	0 265 006 167
Wheel speed sensor, rear			
Fg.no. →AM 246796	04.93-12.98	LAB	0 265 006 170
		RAB	0 265 006 169
620 SDi		2,0l 77 kW 20T2N-TCIE 4 Zyl.	
Air mass meter, diesel	03.95-12.98	BO	0 281 002 120
Speed sensor, diesel	03.95-12.98		0 281 002 121
Pressure sensor, intake manifold, diesel	03.95-12.98		0 281 002 119
Temperature sensor, coolant, diesel	03.95-12.98		0 280 130 026
Temperature sensor, intake air, diesel	03.95-12.98		0 280 130 039
Wheel speed sensor, front			
Fg.no. →AM 246796	03.95-12.98	LAB	0 265 006 168
		RAB	0 265 006 167
Wheel speed sensor, rear			
Fg.no. →AM 246796	03.95-12.98	LAB	0 265 006 170
		RAB	0 265 006 169

Serie 800

820		2,0l 74/88 kW ; 20 HS 4 Zyl.	
Wheel speed sensor, front	10.86-10.91	LAB	0 265 006 104
		RAB	0 265 006 103
Wheel speed sensor, rear	10.86-10.91	LAB	0 265 006 106
		RAB	0 265 006 105
820 i		2,0l 98/103 kW M16i; 20H 4 Zyl.	
Relay, Jetronic	10.86-10.91	DID	0 332 014 112
Wheel speed sensor, front	10.86-10.91	LAB	0 265 006 104
		RAB	0 265 006 103
Wheel speed sensor, rear	10.86-10.91	LAB	0 265 006 106
		RAB	0 265 006 105



Product



◀ Serie 800

820 i 16V		2,0l 100-103 kW ; 20T4H 4 Zyl.	
Wheel speed sensor, front	01.92-09.99	LAB	0 265 006 104
		RAB	0 265 006 103
Wheel speed sensor, rear	01.92-09.99	LAB	0 265 006 106
		RAB	0 265 006 105
820 i 16V Turbo		2,0l 132-147 kW T16 4 Zyl.	
Wheel speed sensor, front	01.92-01.99	LAB	0 265 006 104
		RAB	0 265 006 103
Wheel speed sensor, rear	01.92-01.99	LAB	0 265 006 106
		RAB	0 265 006 105
825 i		2,5l 110/125 kW C25A V6 6 Zyl.	
Wheel speed sensor, front	10.86-10.88	LAB	0 265 006 104
		RAB	0 265 006 103
Wheel speed sensor, rear	10.86-10.88	LAB	0 265 006 106
		RAB	0 265 006 105
825 i, i Coupé		2,5l 129 kW 25K4F 6 Zyl.	
Wheel speed sensor, front	01.96-12.98	LAB	0 265 006 104
		RAB	0 265 006 103
Wheel speed sensor, rear	01.96-12.98	LAB	0 265 006 106
		RAB	0 265 006 105
825 i Si		2,5l 129 kW C25A V6 6 Zyl.	
Wheel speed sensor, front	10.86-10.88	LAB	0 265 006 104
		RAB	0 265 006 103
Wheel speed sensor, rear	10.86-10.88	LAB	0 265 006 106
		RAB	0 265 006 105
825 i Sterling		2,5l 110/125 kW C25A V6 6 Zyl.	
Wheel speed sensor, front	01.87-10.88	LAB	0 265 006 104
		RAB	0 265 006 103
Wheel speed sensor, rear	01.87-10.88	LAB	0 265 006 106
		RAB	0 265 006 105
825 TD		2,5l 87 kW VM 4 Zyl.	
Wheel speed sensor, front	10.88-10.91	LAB	0 265 006 104
		RAB	0 265 006 103
Wheel speed sensor, rear	10.88-10.91	LAB	0 265 006 106
		RAB	0 265 006 105
825 TD		2,5l 87/88 kW VM-425-SLIER; VM-425-SLIRR 4 Zyl.	
Speed sensor, diesel	10.91-12.98		0 281 002 145
Wheel speed sensor, front	10.91-12.98	LAB	0 265 006 104
		RAB	0 265 006 103
Wheel speed sensor, rear	10.91-12.98	LAB	0 265 006 106
		RAB	0 265 006 105
825 TD		2,5l 92 kW VM-425-CLIER 4 Zyl.	
Air mass meter, diesel	01.96-12.98		0 281 002 120
Speed sensor, diesel			
Fg.no. 230967→	01.96-12.98		0 281 002 145
Temperature sensor, coolant, diesel	01.96-12.98		0 280 130 055
Wheel speed sensor, front	01.96-12.98	LAB	0 265 006 104
		RAB	0 265 006 103
Wheel speed sensor, rear	01.96-12.98	LAB	0 265 006 106
		RAB	0 265 006 105
827 i Si, i Sterling		2,7l 124/130 kW C27A V6 6 Zyl.	
Wheel speed sensor, front	02.88-10.91	LAB	0 265 006 104
		RAB	0 265 006 103
Wheel speed sensor, rear	02.88-10.91	LAB	0 265 006 106
		RAB	0 265 006 105
827 i 24V		2,7l 124-130 kW C27A1 V6 6 Zyl.	
Wheel speed sensor, front	01.92-01.96	LAB	0 265 006 104
		RAB	0 265 006 103
Wheel speed sensor, rear	01.92-01.96	LAB	0 265 006 106
		RAB	0 265 006 105
827 i 24V Coupé		2,7l 124 kW C27A V6 6 Zyl.	
Wheel speed sensor, front	01.92-01.96	LAB	0 265 006 104
		RAB	0 265 006 103

Product



Wheel speed sensor, rear	01.92-01.96	LAB	0 265 006 106
		RAB	0 265 006 105

25			
1.1 i 16V		1,1l 55 kW 11 K4F 4 Zyl.	
Wheel speed sensor, front	02.03-05.05	LAB	0 265 006 305
		RAB	0 265 006 306
Wheel speed sensor, rear			
Fg.no. →YD 471564	02.03-05.05	4SB	0 265 006 307
1.4 i 16V		1,4l 62/76 kW 14 K4F; 14 K4M 4 Zyl.	
Wheel speed sensor, front	02.00-05.05	LAB	0 265 006 305
		RAB	0 265 006 306
Wheel speed sensor, rear			
Fg.no. →YD 471564	02.00-05.05	4SB	0 265 006 307
1.6 i 16V		1,6l 80 kW 16 K4F 4 Zyl.	
Wheel speed sensor, front	02.00-05.05	LAB	0 265 006 305
		RAB	0 265 006 306
Wheel speed sensor, rear			
Fg.no. →YD 471564	02.00-05.05	4SB	0 265 006 307
1.8 i 16V		1,8l 86/107 kW 18 K4F; 18 K4K-VVC 4 Zyl.	
Wheel speed sensor, front	02.00-10.04	LAB	0 265 006 305
		RAB	0 265 006 306
Wheel speed sensor, rear			
Fg.no. →YD 471564	02.00-10.04	4SB	0 265 006 307
2.0 iDT		2,0l 74/83 kW TCie; 20 T2N-TCie 4 Zyl.	
Air mass meter, diesel			
Fg.no. YD 471565→	02.00-05.05		0 280 218 012
Fg.no. →YD 471564	02.00-05.05		0 281 002 120
Speed sensor, diesel	02.00-05.05	BO	0 281 002 121
Boost pressure sensor, Diesel			
Fg.no. YD 471565→	02.00-05.05		0 281 002 389
Fg.no. →YD 471564	02.00-05.05		0 281 002 119
Temperature sensor, intake air, diesel	02.00-05.05		0 280 130 039
Pedal position sensor, diesel			
Fg.no. YD 471565→	02.00-05.05		0 281 002 370
Wheel speed sensor, front	02.00-05.05	LAB	0 265 006 305
		RAB	0 265 006 306
Wheel speed sensor, rear			
Fg.no. →YD 471564	02.00-05.05	4SB	0 265 006 307
45			
1.4 16V		1,4l 76 kW 14 K4F 4 Zyl.	
Wheel speed sensor, front	02.00-05.05	LAB	0 265 006 258
		RAB	0 265 006 259
Wheel speed sensor, rear	02.00-05.05	4SB,LAB	0 265 006 267
		4SB,RAB	0 265 006 268
1.6 16V		1,6l 80 kW 16 K4F 4 Zyl.	
Wheel speed sensor, front	02.00-05.05	LAB	0 265 006 258
		RAB	0 265 006 259
Wheel speed sensor, rear	02.00-05.05	4SB,LAB	0 265 006 267
		4SB,RAB	0 265 006 268
1.8 16V		1,8l 86 kW 18 K4F 4 Zyl.	
Wheel speed sensor, front	02.00-05.05	LAB	0 265 006 258
		RAB	0 265 006 259
Wheel speed sensor, rear	02.00-05.05	4SB,LAB	0 265 006 267
		4SB,RAB	0 265 006 268
2.0 iDT		2,0l 74/83 kW TCie; 20 T2N-TCie 4 Zyl.	
Air mass meter, diesel			
Fg.no. YD 471064→	02.00-05.05		0 280 218 012
Fg.no. →YD 471063	02.00-05.05		0 281 002 120
Speed sensor, diesel	02.00-05.05	BO	0 281 002 121



Pressure sensor, intake manifold, diesel			
Fg.no. →YD 471063	02.00-05.05		0 281 002 119
Temperature sensor, intake air, diesel	02.00-05.05		0 280 130 039
Pedal position sensor, diesel			
Fg.no. YD 471064→	02.00-05.05		0 281 002 370
Wheel speed sensor, front	02.00-05.05	LAB	0 265 006 258
		RAB	0 265 006 259
Wheel speed sensor, rear	02.00-05.05	4SB,LAB	0 265 006 267
		4SB,RAB	0 265 006 268
2.0 V6		2,0l 110 kW 20 K4F 6 Zyl.	
Wheel speed sensor, front	02.00-05.05	LAB	0 265 006 258
		RAB	0 265 006 259
Wheel speed sensor, rear	02.00-05.05	4SB,LAB	0 265 006 267
		4SB,RAB	0 265 006 268

75

2.0 CDT 2,0l 85 kW M 47 R 4 Zyl.		
Air mass meter, diesel	01.99-12.02	0 928 400 520
2.0 CDTi 2,0l 96 kW M 47 R 4 Zyl.		
Air mass meter, diesel	01.03-05.05	0 928 400 520

75 Tourer

2.0 CDT 2,0l 85 kW M 47 R 4 Zyl.		
Air mass meter, diesel	01.01-12.02	0 928 400 520
2.0 CDTi 2,0l 96 kW M 47 R 4 Zyl.		
Air mass meter, diesel	01.03-05.05	0 928 400 520

2000-3500

3500 Vitesse Inj. 3,5l 139-142 kW V 8 8 Zyl.		
Air flow sensor, gasoline injection	10.82-10.86	0 280 202 046
		0 986 280 027
Relay, Jetronic	10.82-10.86	0 332 014 113


SAAB (SAAB AUTOMOBILE AB)

9-3

1.8 t [9440] 2,0l 110 kW B207E 4 Zyl.		
Speed sensor, ignition/injection	09.02→	0 261 210 229
1.9 TiD [9440] 1,9l 88 kW Z19DT 4 Zyl.		
Speed sensor, diesel	09.04→	0 281 002 603
Phase sensor	09.04→	0 281 002 213
Boost pressure sensor, Diesel	09.04→	0 281 002 437
1.9 TiD [9440] 1,9l 110 kW Z19DTH 4 Zyl.		
Boost pressure sensor, Diesel	09.04→	0 281 002 437
2.0 i 16V [9400] 2,0l 96 kW B204i 4 Zyl.		
Throttle valve sensor	03.98-08.00	0 280 122 014
Air mass meter, gasoline injection	03.98-08.00	0 280 217 120
Speed sensor, ignition/injection	03.98-08.00	0 261 210 269
Knock sensor	03.98-08.00	0 261 231 046
Temperature sensor, coolant, injection system	03.98-08.00	0 280 130 094
Wheel speed sensor, front	03.98-08.00	0 265 006 331
2.0 i 16V Turbo [9400] 2,0l 110 kW B205E 4 Zyl.		
Throttle valve sensor	09.99-08.02	0 280 122 014
Air mass meter, gasoline injection	09.99-08.02	0 280 217 120
Speed sensor, ignition/injection	09.99-08.02	0 261 210 269
Knock sensor	09.99-08.02	0 261 231 046
Temperature sensor, coolant, injection system	09.99-08.02	0 280 130 094
Wheel speed sensor, front	09.99-08.02	0 265 006 331



2.0 i 16V Turbo [9400] 2,0l 113 kW B204E 4 Zyl.		
Throttle valve sensor	09.98-08.00	0 280 122 014
Air mass meter, gasoline injection	09.98-08.00	0 280 217 120
Speed sensor, ignition/injection	09.98-08.00	0 261 210 030
Knock sensor	09.98-08.00	0 261 231 046
Temperature sensor, coolant, injection system	09.98-08.00	0 280 130 094
Wheel speed sensor, front	09.98-08.00	0 265 006 331
2.0 i 16V Turbo [9400] 2,0l 136 kW B204L 4 Zyl.		
Throttle valve sensor	03.98-08.00	0 280 122 014
Air mass meter, gasoline injection	03.98-08.00	0 280 217 120
Speed sensor, ignition/injection	03.98-08.00	0 261 210 269
Knock sensor	03.98-08.00	0 261 231 046
Temperature sensor, coolant, injection system	03.98-08.00	0 280 130 094
Wheel speed sensor, front	03.98-08.00	0 265 006 331
2.0 i 16V Turbo [9400] 2,0l 136 kW B205L 4 Zyl.		
Throttle valve sensor	09.99-08.02	0 280 122 014
Air mass meter, gasoline injection	09.99-08.02	0 280 217 120
Speed sensor, ignition/injection	09.99-08.02	0 261 210 269
Temperature sensor, coolant, injection system	09.99-08.02	0 280 130 094
Wheel speed sensor, front	09.99-08.02	0 265 006 331
2.0 i 16V Turbo [9400] 2,0l 147 kW B204R 4 Zyl.		
Throttle valve sensor	09.98-08.00	0 280 122 014
Air mass meter, gasoline injection	09.98-08.00	0 280 217 120
Speed sensor, ignition/injection	09.98-08.00	0 261 210 269
Knock sensor	09.98-08.00	0 261 231 046
Temperature sensor, coolant, injection system	09.98-08.00	0 280 130 094
Wheel speed sensor, front	09.98-08.00	0 265 006 331
2.0 i 16V Turbo [9400] 2,0l 151 kW B205R 4 Zyl.		
Throttle valve sensor	09.99-08.02	0 280 122 014
Air mass meter, gasoline injection	09.99-08.02	0 280 217 120
Speed sensor, ignition/injection	09.99-08.02	0 261 210 269
Temperature sensor, coolant, injection system	09.99-08.02	0 280 130 094
Wheel speed sensor, front	09.99-08.02	0 265 006 331
2.0 T Aero [9440] 2,0l 154 kW B207R 4 Zyl.		
Speed sensor, ignition/injection	02.03→	0 261 210 229
2.0 t Sport [9440] 2,0l 129 kW B207L 4 Zyl.		
Speed sensor, ignition/injection	09.02-08.06	0 261 210 229
2.2 16V D Turbo [9400] 2,2l 85/92 kW D223L 4 Zyl.		
Air mass meter, diesel		
Fg.no. →12020000	03.98-09.02	0 281 002 212
Fg.no. 12020001→	03.98-09.02	0 281 002 443
Speed sensor, diesel	03.98-09.02	0 281 002 138
Wheel speed sensor, front	03.98-09.02	0 265 006 331
2.3 i 16V [9400] 2,3l 110 kW B234i 4 Zyl.		
Throttle valve sensor	03.98-08.00	0 280 122 014
Air mass meter, gasoline injection	03.98-08.00	0 280 217 120
Speed sensor, ignition/injection	03.98-08.00	0 261 210 269
Knock sensor	03.98-08.00	0 261 231 046
Temperature sensor, coolant, injection system	03.98-08.00	0 280 130 094
Wheel speed sensor, front	03.98-08.00	0 265 006 331
2.3 i 16V Turbo [9400] 2,3l 125/169 kW B235R 4 Zyl.		
Throttle valve sensor	01.99-08.00	0 280 122 014
Air mass meter, gasoline injection	01.99-08.00	0 280 217 120
Speed sensor, ignition/injection	01.99-08.00	0 261 210 269
Knock sensor	01.99-08.00	0 261 231 046
Temperature sensor, coolant, injection system	01.99-08.00	0 280 130 094
Wheel speed sensor, front	01.99-08.00	0 265 006 331
2.8 Turbo V6 [9440] 2,8l 184 kW B284 6 Zyl.		
Pressure sensor, intake manifold, gasoline	09.05→	0 261 230 101
Temperature sensor, coolant, injection system	09.05→	0 280 130 122



Product



9-3 Cabriolet

1.8 t [9440]	1,8l 110 kW B207E 4 Zyl.
Speed sensor, ignition/injection	08.03→ 0 261 210 229
1.9 TiD [9440]	1,9l 110 kW Z19DTH 4 Zyl.
Boost pressure sensor, Diesel	01.06→ 0 281 002 437
2.0 i 16V [9400]	2,0l 96 kW B204l 4 Zyl.
Throttle valve sensor	03.98-08.00 0 280 122 014
Air mass meter, gasoline injection	03.98-08.00 0 280 217 120
Speed sensor, ignition/injection	03.98-08.00 0 261 210 269
Knock sensor	03.98-08.00 0 261 231 046
Temperature sensor, coolant, injection system	03.98-08.00 0 280 130 094
Wheel speed sensor, front	03.98-08.00 0 265 006 331
2.0 i 16V Turbo [9400]	2,0l 113 kW B204E 4 Zyl.
Throttle valve sensor	09.98-08.00 0 280 122 014
Air mass meter, gasoline injection	09.98-08.00 0 280 217 120
Speed sensor, ignition/injection	09.98-08.00 0 261 210 030
Knock sensor	09.98-08.00 0 261 231 046
Temperature sensor, coolant, injection system	09.98-08.00 0 280 130 094
Wheel speed sensor, front	09.98-08.00 0 265 006 331
2.0 i 16V Turbo [9400]	2,0l 136 kW B204L 4 Zyl.
Throttle valve sensor	03.98-08.00 0 280 122 014
Air mass meter, gasoline injection	03.98-08.00 0 280 217 120
Speed sensor, ignition/injection	03.98-08.00 0 261 210 269
Knock sensor	03.98-08.00 0 261 231 046
Temperature sensor, coolant, injection system	03.98-08.00 0 280 130 094
Wheel speed sensor, front	03.98-08.00 0 265 006 331
2.0 i 16V Turbo [9400]	2,0l 136 kW B205L 4 Zyl.
Throttle valve sensor	09.99-08.03 0 280 122 014
Air mass meter, gasoline injection	09.99-08.03 0 280 217 120
Speed sensor, ignition/injection	09.99-08.03 0 261 210 269
Temperature sensor, coolant, injection system	09.99-08.03 0 280 130 094
Wheel speed sensor, front	09.99-08.03 0 265 006 331
2.0 i 16V Turbo [9400]	2,0l 147 kW B204R 4 Zyl.
Throttle valve sensor	09.98-08.00 0 280 122 014
Air mass meter, gasoline injection	09.98-08.00 0 280 217 120
Speed sensor, ignition/injection	09.98-08.00 0 261 210 269
Knock sensor	09.98-08.00 0 261 231 046
Temperature sensor, coolant, injection system	09.98-08.00 0 280 130 094
Wheel speed sensor, front	09.98-08.00 0 265 006 331
2.0 t [9400]	2,0l 110 kW B205E 4 Zyl.
Air mass meter, gasoline injection	10.98-07.03 0 280 217 120
Speed sensor, ignition/injection	10.98-07.03 0 261 210 269
Wheel speed sensor, front	10.98-07.03 0 265 006 331
2.0 t [9440]	2,0l 129 kW B207L 4 Zyl.
Speed sensor, ignition/injection	08.03→ 0 261 210 229
2.0 T [9400]	2,0l 151 kW B205R 4 Zyl.
Air mass meter, gasoline injection	10.99-07.03 0 280 217 120
Speed sensor, ignition/injection	10.99-07.03 0 261 210 269
Wheel speed sensor, front	10.99-07.03 0 265 006 331
2.0 T [9440]	2,0l 154 kW B207R 4 Zyl.
Speed sensor, ignition/injection	08.03→ 0 261 210 229
2.3 i 16V [9400]	2,3l 110 kW B234l 4 Zyl.
Throttle valve sensor	03.98-08.00 0 280 122 014
Air mass meter, gasoline injection	03.98-08.00 0 280 217 120
Speed sensor, ignition/injection	03.98-08.00 0 261 210 269
Knock sensor	03.98-08.00 0 261 231 046
Temperature sensor, coolant, injection system	03.98-08.00 0 280 130 094
Wheel speed sensor, front	03.98-08.00 0 265 006 331
2.8 Turbo V6 [9440]	2,8l 184 kW B284 6 Zyl.
Pressure sensor, intake manifold, gasoline	09.05→ 0 261 230 101
Temperature sensor, coolant, injection system	09.05→ 0 280 130 122

Product



9-3 Coupé

2.0 i 16V [9400]	2,0l 96 kW B204l 4 Zyl.
Throttle valve sensor	03.98-08.00 0 280 122 014
Air mass meter, gasoline injection	03.98-08.00 0 280 217 120
Speed sensor, ignition/injection	03.98-08.00 0 261 210 269
Knock sensor	03.98-08.00 0 261 231 046
Temperature sensor, coolant, injection system	03.98-08.00 0 280 130 094
Wheel speed sensor, front	03.98-08.00 0 265 006 331
2.0 i 16V Turbo [9400]	2,0l 136 kW B204L 4 Zyl.
Throttle valve sensor	03.98-08.00 0 280 122 014
Air mass meter, gasoline injection	03.98-08.00 0 280 217 120
Speed sensor, ignition/injection	03.98-08.00 0 261 210 269
Knock sensor	03.98-08.00 0 261 231 046
Temperature sensor, coolant, injection system	03.98-08.00 0 280 130 094
Wheel speed sensor, front	03.98-08.00 0 265 006 331
2.0 i 16V Turbo [9400]	2,0l 136 kW B205L 4 Zyl.
Throttle valve sensor	09.99-08.03 0 280 122 014
Air mass meter, gasoline injection	09.99-08.03 0 280 217 120
Speed sensor, ignition/injection	09.99-08.03 0 261 210 269
Temperature sensor, coolant, injection system	09.99-08.03 0 280 130 094
Wheel speed sensor, front	09.99-08.03 0 265 006 331
2.0 i 16V Turbo [9400]	2,0l 147 kW B204R 4 Zyl.
Throttle valve sensor	09.98-08.00 0 280 122 014
Air mass meter, gasoline injection	09.98-08.00 0 280 217 120
Speed sensor, ignition/injection	09.98-08.00 0 261 210 269
Knock sensor	09.98-08.00 0 261 231 046
Temperature sensor, coolant, injection system	09.98-08.00 0 280 130 094
Wheel speed sensor, front	09.98-08.00 0 265 006 331
2.0 i 16V Turbo [9400]	2,0l 151 kW B205R 4 Zyl.
Throttle valve sensor	09.99-08.02 0 280 122 014
Air mass meter, gasoline injection	09.99-08.02 0 280 217 120
Speed sensor, ignition/injection	09.99-08.02 0 261 210 269
Temperature sensor, coolant, injection system	09.99-08.02 0 280 130 094
Wheel speed sensor, front	09.99-08.02 0 265 006 331
2.2 16V D Turbo [9400]	2,2l 92 kW D223L 4 Zyl.
Air mass meter, diesel	
Fg.no. →12020000	11.00-09.02 0 281 002 212
Fg.no. 12020001→	11.00-09.02 0 281 002 443
Speed sensor, diesel	11.00-09.02 0 281 002 138
Wheel speed sensor, front	11.00-09.02 0 265 006 331
2.3 i 16V Turbo [9400]	2,3l 165 kW B235R 4 Zyl.
Throttle valve sensor	09.99-08.00 0 280 122 014
Air mass meter, gasoline injection	09.99-08.00 0 280 217 120
Speed sensor, ignition/injection	09.99-08.00 0 261 210 269
Knock sensor	09.99-08.00 0 261 231 046
Temperature sensor, coolant, injection system	09.99-08.00 0 280 130 094
Wheel speed sensor, front	09.99-08.00 0 265 006 331

9-3 Kombi

1.9 TiD [9440]	1,9l 88 kW Z19DT 4 Zyl.
Speed sensor, diesel	03.05→ 0 281 002 603
Phase sensor	03.05→ 0 281 002 213
Boost pressure sensor, Diesel	03.05→ 0 281 002 437
1.9 TiD [9440]	1,9l 110 kW Z19DTH 4 Zyl.
Boost pressure sensor, Diesel	03.05→ 0 281 002 437
2.8 T Sport V6 [9440]	2,8l 184 kW B284 6 Zyl.
Pressure sensor, intake manifold, gasoline	03.05→ 0 261 230 101
Temperature sensor, coolant, injection system	03.05→ 0 280 130 122

Product



9-5

1.9 TiD	1,9l 110 kW Z19DTH 4 Zyl.
Pressure sensor, intake manifold, diesel	09.05→ 0 281 002 437
Pressure sensor, ESP, (electronic stability program)	09.05→ 0 265 005 303
2.0 t	2,0l 110/140 kW B205E 4 Zyl.
Speed sensor, ignition/injection	06.97→ 0 261 210 269
2.2 TiD	2,2l 88 kW D223L 4 Zyl.
Speed sensor, diesel	03.02→ 0 281 002 138
Pedal position sensor, diesel	03.02→ 0 281 002 539
2.3 t	2,3l 125/136 kW B235E 4 Zyl.
Speed sensor, ignition/injection	06.97→ 0 261 210 269
2.3 T	2,3l 162 kW B235L 4 Zyl.
Speed sensor, ignition/injection	09.03→ 0 261 210 269
2.3 Turbo	2,3l 169/184 kW B235R 4 Zyl.
Speed sensor, ignition/injection	05.99→ 0 261 210 269
3.0 t	3,0l 147 kW B308E 6 Zyl.
Speed sensor, ignition/injection	06.97-08.03 0 261 210 169
3.0 TiD	3,0l 130 kW D308L 6 Zyl.
Air mass meter, diesel	
Fg.no. 330027124→	09.01→ 0 281 002 605
Pedal position sensor, diesel	09.01→ RLE 0 281 002 539

9-5 Kombi

1.9 TiD	1,9l 110 kW Z19DTH 4 Zyl.
Pressure sensor, intake manifold, diesel	01.06→ 0 281 002 437
Pressure sensor, ESP, (electronic stability program)	01.06→ 0 265 005 303
2.0 t	2,0l 110/140 kW B205E 4 Zyl.
Speed sensor, ignition/injection	06.98→ 0 261 210 269
2.2 TiD	2,2l 88 kW D223L 4 Zyl.
Speed sensor, diesel	03.02→ 0 281 002 138
Pedal position sensor, diesel	03.02→ 0 281 002 539
2.3 t	2,3l 125/136 kW B235E 4 Zyl.
Speed sensor, ignition/injection	06.99→ 0 261 210 269
2.3 T	2,3l 162 kW B235L 4 Zyl.
Speed sensor, ignition/injection	09.03→ 0 261 210 269
2.3 Turbo	2,3l 169/184 kW B235R 4 Zyl.
Speed sensor, ignition/injection	05.99→ 0 261 210 269
3.0 t	3,0l 147 kW B308E 6 Zyl.
Speed sensor, ignition/injection	06.97-08.03 0 261 210 169
3.0 TiD	3,0l 130 kW D308L 6 Zyl.
Air mass meter, diesel	
Fg.no. 330027124→	09.01→ 0 281 002 605
Pedal position sensor, diesel	09.01→ RLE 0 281 002 539


900

2.0 i	2,0l 81 kW B 201 I Kat. 4 Zyl.
Throttle valve sensor	02.84-08.91 AG 0 280 120 300
Air flow sensor, gasoline injection	09.83-08.91 0 438 120 159
2.0 i	2,0l 85-87 kW B 201 I 4 Zyl.
Air flow sensor, gasoline injection	09.83-08.90 0 438 120 071
2.0 i [II]	2,0l 98 kW B 206 I Kat. 4 Zyl.
Throttle valve sensor	09.93-08.95 0 280 122 001
	09.95-08.96 0 280 122 004
	09.96-08.98 0 280 122 014
Air mass meter, gasoline injection	09.93-08.95 0 280 217 105
	09.95-08.96 0 280 217 119
	09.96-08.98 0 280 217 120
Speed sensor, ignition/injection	09.93-08.95 0 261 210 030
	09.95-08.98 0 261 210 269
Knock sensor	09.96-08.98 0 261 231 046

Product



Temperature sensor, coolant, injection system	09.93-08.95 0 280 130 075
	09.95-08.98 0 280 130 094
Wheel speed sensor, front	09.95-08.98 0 265 006 331
2.0 i Cabrio, i Coupé [II]	2,0l 98 kW B 206 I Kat. 4 Zyl.
Throttle valve sensor	03.94-08.95 0 280 122 001
	09.95-08.96 0 280 122 004
	09.96-08.98 0 280 122 014
Air mass meter, gasoline injection	03.94-08.95 0 280 217 105
	09.95-08.96 0 280 217 119
	09.96-08.98 0 280 217 120
Speed sensor, ignition/injection	03.94-08.95 0 261 210 030
	09.95-08.98 0 261 210 269
Knock sensor	03.94-08.98 0 261 231 046
Temperature sensor, coolant, injection system	03.94-08.95 0 280 130 075
	09.95-08.98 0 280 130 094
Wheel speed sensor, front	09.95-08.98 0 265 006 331
2.0 i S, i S Cabrio, i S Coupé [II]	2,0l 96 kW B 204 I Kat. 4 Zyl.
Throttle valve sensor	09.94-08.95 0 280 122 001
	09.95-08.96 0 280 122 004
	09.96-08.98 0 280 122 014
Air mass meter, gasoline injection	09.94-08.95 0 280 217 105
	09.95-08.96 0 280 217 119
	09.96-08.98 0 280 217 120
Speed sensor, ignition/injection	09.94-08.95 0 261 210 030
	09.95-08.98 0 261 210 269
Knock sensor	09.96-08.98 0 261 231 046
Temperature sensor, coolant, injection system	09.94-08.95 0 280 130 075
	09.95-08.98 0 280 130 094
Wheel speed sensor, front	09.95-08.98 0 265 006 331
2.0 i Turbo [II]	2,0l 136 kW B 204 L Kat. 4 Zyl.
Throttle valve sensor	09.93-08.95 0 280 122 001
	09.95-08.96 0 280 122 004
	09.96-08.98 0 280 122 014
Air mass meter, gasoline injection	09.93-08.95 0 280 217 105
	09.95-08.96 0 280 217 119
	09.96-08.98 0 280 217 120
Speed sensor, ignition/injection	09.93-08.95 0 261 210 030
	09.95-08.98 0 261 210 269
Temperature sensor, coolant, injection system	09.93-08.95 0 280 130 075
	09.95-08.98 0 280 130 094
Wheel speed sensor, front	09.95-08.98 0 265 006 331
2.0 i Turbo Cabrio, i Turbo Coupé [II]	2,0l 136 kW B 204 L Kat. 4 Zyl.
Throttle valve sensor	03.94-08.95 0 280 122 001
	09.95-08.96 0 280 122 004
	09.96-08.98 0 280 122 014
Air mass meter, gasoline injection	03.94-08.95 0 280 217 105
	09.95-08.96 0 280 217 119
	09.96-08.98 0 280 217 120
Speed sensor, ignition/injection	03.94-08.95 0 261 210 030
	09.95-08.98 0 261 210 269
Temperature sensor, coolant, injection system	03.94-08.95 0 280 130 075
	09.95-08.98 0 280 130 094
Wheel speed sensor, front	09.95-08.98 0 265 006 331
2.0 i 16	2,0l 92-93 kW B 202 I Kat. 4 Zyl.
Throttle valve sensor	09.85-08.92 0 280 120 300
Air mass meter, gasoline injection	09.85-08.87 0 280 212 005
	 0 986 280 112
	09.87-08.92 0 280 212 013
	 0 986 280 109
Knock sensor	09.85-07.86 0 261 231 001
	08.86-08.92 0 261 231 006
Temperature sensor, coolant, injection system	09.85-08.92 0 280 130 026





Product				

◀ 900

2.0i 16		2,0l 92-98 kW B 202l 4 Zyl.	
Throttle valve sensor	09.88-08.93	0 280 120 300	
Air mass meter, gasoline injection	09.88-08.93	0 280 212 017	
		0 986 280 119	
Knock sensor	09.88-08.93	0 261 231 006	
Temperature sensor, coolant, injection system	09.88-08.93	0 280 130 026	
2.0i 16		2,0l 92-98 kW B 202l Kat. 4 Zyl.	
Throttle valve sensor	09.89-08.92	0 280 120 300	
Air mass meter, gasoline injection	09.89-08.92	0 280 212 013	
		0 986 280 109	
Knock sensor	09.89-08.92	0 261 231 006	
Temperature sensor, coolant, injection system	09.89-08.92	0 280 130 026	
2.0i 16 Cabrio		2,0l 92-99 kW B 202l Kat. 4 Zyl.	
Throttle valve sensor	09.89-08.93	0 280 120 300	
Air mass meter, gasoline injection	09.89-08.93	0 280 212 013	
		0 986 280 109	
Knock sensor	09.89-08.93	0 261 231 006	
Temperature sensor, coolant, injection system	09.89-08.93	0 280 130 026	
2.0 turbo		2,0l 102-110 kW B 201 S 4 Zyl.	
Air flow sensor, gasoline injection	09.85-08.90	0 438 120 087	
Knock sensor	09.85-07.86	0 261 231 001	
	08.86-08.90	0 261 231 006	
2.0 turbo		2,0l 103 kW B 201 S Kat. 4 Zyl.	
Throttle valve sensor	09.85-09.90 AG	0 280 120 300	
Air flow sensor, gasoline injection	09.85-09.90	0 438 120 159	
Knock sensor	09.85-07.86	0 261 231 001	
	08.86-09.90	0 261 231 006	
2.0 turbo 16		2,0l 104-107 kW B 202 S Kat. 4 Zyl.	
Throttle valve sensor	09.91-08.93 BO	0 280 120 300	
Air mass meter, gasoline injection	09.91-08.93 BO	0 280 212 013	
		0 986 280 109	
Temperature sensor, coolant, injection system	09.91-08.93 BO	0 280 130 026	
2.0 turbo 16		2,0l 118 kW B 202 L Kat. 4 Zyl.	
Throttle valve sensor	08.84-08.89	0 280 120 300	
Air mass meter, gasoline injection	08.84-08.88	0 280 212 005	
		0 986 280 112	
	09.88-08.93	0 280 212 013	
		0 986 280 109	
Knock sensor	08.84-07.86	0 261 231 001	
	08.86-08.93	0 261 231 006	
Temperature sensor, coolant, injection system	08.84-08.89	0 280 130 026	
2.0 turbo 16		2,0l 129-132 kW B 202 L 4 Zyl.	
Throttle valve sensor	02.84-08.89	0 280 120 300	
Air mass meter, gasoline injection	02.84-08.88	0 280 212 005	
		0 986 280 112	
	09.88-08.89	0 280 212 017	
		0 986 280 119	
Knock sensor	02.84-07.86	0 261 231 001	
	08.86-08.93	0 261 231 006	
Temperature sensor, coolant, injection system	02.84-08.89	0 280 130 026	
2.0 turbo 16 Cabrio		2,0l 118 kW B 202 L Kat. 4 Zyl.	
Throttle valve sensor	09.90-08.93 BO	0 280 120 300	
Air mass meter, gasoline injection	09.90-08.93 BO	0 280 212 013	
		0 986 280 109	
Knock sensor	09.90-08.93	0 261 231 006	
Temperature sensor, coolant, injection system	09.90-08.93 BO	0 280 130 026	
2.1i 16		2,1l 100-103 kW B 212l Kat. 4 Zyl.	
Throttle valve sensor	09.90-08.93	0 280 122 001	
Air mass meter, gasoline injection	09.90-08.93	0 280 212 019	
		0 986 280 117	
Knock sensor	09.90-08.93	0 261 231 006	
Temperature sensor, coolant, injection system	09.90-08.93	0 280 130 026	

Product				


2.1i 16 Cabrio		2,1l 103 kW B 212l Kat. 4 Zyl.	
Throttle valve sensor	09.91-08.93	0 280 122 001	
Air mass meter, gasoline injection	09.91-08.93	0 280 212 019	
		0 986 280 117	
Knock sensor	09.91-08.93	0 261 231 006	
Temperature sensor, coolant, injection system	09.91-08.93	0 280 130 026	
2.3i [II]		2,3l 110 kW B 234l Kat. 4 Zyl.	
Throttle valve sensor	09.93-08.95	0 280 122 001	
	09.95-08.96	0 280 122 004	
	09.96-08.98	0 280 122 014	
Air mass meter, gasoline injection	09.93-08.95	0 280 217 105	
	09.95-08.96	0 280 217 119	
	09.96-08.98	0 280 217 120	
Speed sensor, ignition/injection	09.93-08.95	0 261 210 030	
	09.95-08.98	0 261 210 269	
Knock sensor	09.96-08.98	0 261 231 046	
Temperature sensor, coolant, injection system	09.93-08.95	0 280 130 075	
	09.95-08.98	0 280 130 094	
Wheel speed sensor, front	09.95-08.98	0 265 006 331	
2.3i Cabrio, Coupé [II]		2,3l 110 kW B 234l Kat. 4 Zyl.	
Throttle valve sensor	03.94-08.95	0 280 122 001	
	09.95-08.96	0 280 122 004	
	09.96-08.98	0 280 122 014	
Air mass meter, gasoline injection	03.94-08.95	0 280 217 105	
	09.95-08.96	0 280 217 119	
	09.96-08.98	0 280 217 120	
Speed sensor, ignition/injection	03.94-08.95	0 261 210 030	
	09.95-08.98	0 261 210 269	
Knock sensor	09.96-08.98	0 261 231 046	
Temperature sensor, coolant, injection system	03.94-08.95	0 280 130 075	
	09.95-08.98	0 280 130 094	
Wheel speed sensor, front	09.95-08.98	0 265 006 331	
2.5i [II]		2,5l 125 kW B 258l 6 Zyl.	
Air mass meter, gasoline injection	09.93-08.95	0 280 217 105	
	09.95-08.96	0 280 217 119	
	09.96-10.98	0 280 217 120	
	09.93-08.95	0 280 217 503	
	09.96-10.98	0 280 217 519	
	09.95-08.96	0 280 217 520	
Knock sensor	09.95-10.98	0 261 231 115	
Temperature sensor, intake air, injection system	09.93-08.95	0 280 130 073	
	09.95-10.98	0 280 130 092	
Temperature sensor, coolant, injection system	09.93-10.98	0 280 130 068	
Wheel speed sensor, front	09.95-10.98	0 265 006 331	
2.5i Cabrio [II]		2,5l 125 kW B 258l 6 Zyl.	
Air mass meter, gasoline injection	03.94-08.95	0 280 217 503	
	09.96-10.98	0 280 217 519	
	09.95-08.96	0 280 217 520	
Knock sensor	09.95-10.98	0 261 231 115	
Temperature sensor, intake air, injection system	03.94-08.95	0 280 130 073	
	09.95-10.98	0 280 130 092	
Temperature sensor, coolant, injection system	03.94-10.98	0 280 130 068	
Wheel speed sensor, front	09.95-10.98	0 265 006 331	
2.5i Coupé [II]		2,5l 125 kW B 258l 6 Zyl.	
Air mass meter, gasoline injection	03.94-08.95	0 280 217 105	
	09.95-08.96	0 280 217 119	
	09.96-10.98	0 280 217 120	
Knock sensor	09.95-10.98	0 261 231 115	
Temperature sensor, intake air, injection system	03.94-08.95	0 280 130 073	
	09.95-10.98	0 280 130 092	
Temperature sensor, coolant, injection system	03.94-10.98	0 280 130 068	
Wheel speed sensor, front	09.95-10.98	0 265 006 331	



9000		
2.0 CD Turbo 2,0l 118-120 kW B 202 L 4 Zyl.		
Throttle valve sensor	05.88-08.90	0 280 120 300
Air mass meter, gasoline injection	05.88-08.88	0 280 212 005
		0 986 280 112
	09.88-08.93	0 280 212 013
		0 986 280 109
Temperature sensor, coolant, injection system	05.88-08.93	0 280 130 026
2.0 CD Turbo 2,0l 129-136 kW B 202 L 4 Zyl.		
Throttle valve sensor	05.88-08.90	0 280 120 300
	09.90-08.92	0 280 122 001
Air mass meter, gasoline injection	05.88-08.88	0 280 212 005
		0 986 280 112
	09.89-08.90	0 280 212 017
		0 986 280 119
	09.90-08.92	0 280 212 018
Knock sensor	05.88-08.92 TW	0 261 231 006
Temperature sensor, coolant, injection system	05.88-08.92	0 280 130 026
2.0 CD Turbo 16V 2,0l 108 kW B 202 S 4 Zyl.		
Air mass meter, gasoline injection	09.92-12.98 KAT	0 280 212 013
		0 986 280 109
		OKA 0 280 212 018
Speed sensor, ignition/injection	09.93-12.98	0 261 210 030
Knock sensor	09.92-08.93	0 261 231 006
Temperature sensor, coolant, injection system	09.92-08.93	0 280 130 026
	09.93-12.98 ASR	0 280 130 032
		OAS 0 280 130 075
2.0 CD 16V 2,0l 92-96 kW B 202 I 4 Zyl.		
Throttle valve sensor	09.89-08.90	0 280 120 300
	09.90-08.93	0 280 122 001
Temperature sensor, coolant, injection system	09.89-08.93	0 280 130 026
2.0 CS 2,0l 96 kW B 204 L 4 Zyl.		
Throttle valve sensor	09.93-08.94	0 280 122 001
	09.94-08.96	0 280 122 008
	09.96-12.98	0 280 122 014
Speed sensor, ignition/injection	09.93-12.98	0 261 210 030
Temperature sensor, coolant, injection system	09.93-12.98	0 280 130 075
2.0 CS Turbo 2,0l 110 kW B 204 E 4 Zyl.		
Throttle valve sensor	09.96-12.98	0 280 122 014
Speed sensor, ignition/injection	09.94-12.98	0 261 210 030
2.0 i 16V 2,0l 90-92 kW B 202 I 4 Zyl.		
Throttle valve sensor	08.86-08.90	0 280 120 300
	09.90-08.93	0 280 122 001
Air mass meter, gasoline injection	08.86-08.87 KAT	0 280 212 009
		0 986 280 135
	09.87-08.93 KAT	0 280 212 011
		0 986 280 131
	08.86-08.93 OKA	0 280 212 014
		0 986 280 108
Knock sensor	08.87-08.93	0 261 231 006
Temperature sensor, coolant, injection system	08.86-08.93	0 280 130 026
2.0 i 16V 2,0l 94-96 kW B 202 I 4 Zyl.		
Throttle valve sensor	12.85-08.90	0 280 120 300
	09.90-08.93	0 280 122 001
Air mass meter, gasoline injection	12.85-08.87	0 280 212 009
		0 986 280 135
	09.87-08.90	0 280 212 014
		0 986 280 108
	09.90-08.93	0 280 212 022
		0 986 280 133
Knock sensor	08.86-08.93 TW	0 261 231 006
Temperature sensor, coolant, injection system	12.85-08.93	0 280 130 026



2.0 Turbo 16V 2,0l 118 kW B 202 L 4 Zyl.	
Throttle valve sensor	09.84-08.88 0 280 120 300
Air mass meter, gasoline injection	09.84-08.88 0 280 212 005
	0 986 280 112
Knock sensor	09.84-07.86 0 261 231 001
Temperature sensor, coolant, injection system	09.84-08.88 0 280 130 026
	AG 0 280 130 055
2.0 Turbo 16V 2,0l 118-120 kW B 202 L 4 Zyl.	
Throttle valve sensor	09.85-08.88 0 280 120 300
Air mass meter, gasoline injection	09.85-08.88 0 280 212 005
	0 986 280 112
Knock sensor	09.85-07.86 0 261 231 001
	08.86-08.88 TW 0 261 231 006
Temperature sensor, coolant, injection system	09.85-08.88 0 280 130 026
	AG 0 280 130 055
2.0 Turbo 16V 2,0l 118-121 kW B 202 L 4 Zyl.	
Throttle valve sensor	01.90-08.90 0 280 120 300
	09.90-08.93 0 280 122 001
Air mass meter, gasoline injection	01.90-08.93 0 280 212 013
	0 986 280 109
Knock sensor	01.90-08.93 TW 0 261 231 006
2.0 Turbo 16V 2,0l 127-129 kW B 202 L 4 Zyl.	
Throttle valve sensor	09.84-08.90 0 280 120 300
Air mass meter, gasoline injection	09.84-08.88 0 280 212 005
	0 986 280 112
	09.89-08.90 0 280 212 017
	0 986 280 119
Knock sensor	08.86-08.90 TW 0 261 231 006
Temperature sensor, coolant, injection system	09.84-08.90 0 280 130 026
2.3 CD Turbo 2,3l 143 kW B 234 L 4 Zyl.	
Throttle valve sensor	09.90-08.93 0 280 122 001
Air mass meter, gasoline injection	09.90-08.93 0 280 213 012
	0 986 280 110
Temperature sensor, coolant, injection system	09.90-08.93 0 280 130 026
2.3 CD Turbo Ecopow. 2,3l 125 kW B 234 E 4 Zyl.	
Throttle valve sensor	09.93-08.94 0 280 122 001
	09.94-08.96 0 280 122 008
	09.96-12.98 0 280 122 014
Speed sensor, ignition/injection	09.93-12.98 0 261 210 030
Temperature sensor, coolant, injection system	09.93-12.98 0 280 130 075
2.3 CD Turbo S 2,3l 143 kW B 234 L 4 Zyl.	
Throttle valve sensor	09.90-08.93 0 280 122 001
Air mass meter, gasoline injection	09.90-08.93 0 280 213 012
	0 986 280 110
Temperature sensor, coolant, injection system	09.90-08.93 0 280 130 026
2.3 CD 16V 2,3l 107 kW B 234 I 4 Zyl.	
Throttle valve sensor	09.89-08.90 0 280 120 300
	09.90-08.93 0 280 122 001
Air mass meter, gasoline injection	09.89-08.93 0 280 212 019
	0 986 280 117
Temperature sensor, coolant, injection system	09.89-08.93 0 280 130 026
2.3 CD 16V 2,3l 108 kW B 234 I 4 Zyl.	
Throttle valve sensor	09.93-08.94 0 280 122 001
	09.94-08.96 0 280 122 008
	09.96-12.98 0 280 122 014
Speed sensor, ignition/injection	09.93-12.98 0 261 210 030
Temperature sensor, coolant, injection system	09.93-12.98 0 280 130 075
2.3 CD 16V 2,3l 110 kW B 234 I 4 Zyl.	
Throttle valve sensor	09.90-08.93 0 280 122 001
Air mass meter, gasoline injection	09.90-08.93 0 280 212 022
	0 986 280 133
Temperature sensor, coolant, injection system	09.90-08.93 0 280 130 026



Product				
◀ 9000				
2.3 CDE Turbo2,3l 147 kW B 234 L 4 Zyl.				
Throttle valve sensor	09.93-08.94	0 280 122 001		
	09.94-08.96	0 280 122 008		
	09.96-12.98	0 280 122 014		
Speed sensor, ignition/injection	09.93-12.98	0 261 210 030		
Temperature sensor, coolant, injection system	09.93-12.98	0 280 130 075		
2.3 CDE Turbo Ecopower2,3l 125 kW B 234 E 4 Zyl.				
Throttle valve sensor	09.96-12.98	0 280 122 014		
Speed sensor, ignition/injection	09.94-12.98	0 261 210 030		
2.3 CS Aero Turbo2,3l 165 kW B 234 R 4 Zyl.				
Throttle valve sensor	09.94-08.96	0 280 122 008		
	09.96-12.98	0 280 122 014		
Air mass meter, gasoline injection	09.92-08.93	0 280 213 012		
		0 986 280 110		
2.3 CS Turbo2,3l 143 kW B 234 L 4 Zyl.				
Throttle valve sensor	09.91-08.93	0 280 122 001		
Air mass meter, gasoline injection	09.91-08.93	0 280 213 012		
		0 986 280 110		
Temperature sensor, coolant, injection system	09.91-08.93	0 280 130 026		
2.3 CS Turbo Ecopower2,3l 125 kW B 234 E 4 Zyl.				
Throttle valve sensor	09.93-08.94	0 280 122 001		
	09.94-08.96	0 280 122 008		
	09.96-12.98	0 280 122 014		
Speed sensor, ignition/injection	09.93-12.98	0 261 210 030		
Temperature sensor, coolant, injection system	09.93-12.98	0 280 130 075		
2.3 CS Turbo S2,3l 143 kW B 234 L 4 Zyl.				
Throttle valve sensor	09.91-08.93	0 280 122 001		
Air mass meter, gasoline injection	09.91-08.93	0 280 213 012		
		0 986 280 110		
Temperature sensor, coolant, injection system	09.91-08.93	0 280 130 026		
2.3 CS 16V2,3l 107 kW B 234 I 4 Zyl.				
Throttle valve sensor	09.91-08.93	0 280 122 001		
Air mass meter, gasoline injection	09.91-08.93	0 280 212 019		
		0 986 280 117		
Temperature sensor, coolant, injection system	09.91-08.93	0 280 130 026		
2.3 CS 16V2,3l 108 kW B 234 I 4 Zyl.				
Throttle valve sensor	09.93-08.94	0 280 122 001		
	09.94-08.96	0 280 122 008		
	09.96-12.98	0 280 122 014		
Speed sensor, ignition/injection	09.93-12.98	0 261 210 030		
Temperature sensor, coolant, injection system	09.93-12.98	0 280 130 075		
2.3 CSE Turbo2,3l 147 kW B 234 L 4 Zyl.				
Throttle valve sensor	09.93-08.94	0 280 122 001		
	09.94-08.96	0 280 122 008		
	09.96-12.98	0 280 122 014		
Speed sensor, ignition/injection	09.93-12.98	0 261 210 030		
Temperature sensor, coolant, injection system	09.93-12.98	0 280 130 075		
2.3 i 16V2,3l 107-114 kW B 234 I 4 Zyl.				
Throttle valve sensor	09.89-08.90	0 280 120 300		
	09.90-08.93	0 280 122 001		
Air mass meter, gasoline injection	09.89-08.93	0 280 212 019		
		0 986 280 117		
Temperature sensor, coolant, injection system	09.89-08.93	0 280 130 026		
2.3 i 16V2,3l 110 kW B 234 I 4 Zyl.				
Throttle valve sensor	09.90-08.93	0 280 122 001		
Air mass meter, gasoline injection	09.90-08.93	0 280 212 022		
		0 986 280 133		
Temperature sensor, coolant, injection system	09.90-08.93	0 280 130 026		
2.3 Turbo 16V2,3l 143 kW B 234 L 4 Zyl.				
Throttle valve sensor	09.90-08.93	0 280 122 001		
Air mass meter, gasoline injection	09.90-08.93	0 280 213 012		
		0 986 280 110		
Temperature sensor, coolant, injection system	09.90-08.93	0 280 130 026		



Product				
3.0 CD, CS3,0l 155 kW B 308 I 6 Zyl.				
Air mass meter, gasoline injection	09.96-12.98	0 280 217 522		
	09.94-08.95	0 280 217 525		
	09.95-08.96	0 280 217 525		
	09.94-08.95	0 280 217 525		
	09.95-08.96	ALA	0 280 217 521	
3.0 Griffin3,0l 155 kW B 308 I 6 Zyl.				
Air mass meter, gasoline injection	09.96-12.98	0 280 217 522		
	09.94-08.96	0 280 217 525		
SEAT				
Alhambra				
1.8 T [7V8]1,8l 110 kW AJH 4 Zyl.				
Air mass meter, gasoline injection	05.98-02.00	0 280 217 117		
		0 986 280 201		
Phase sensor	05.98-02.00	0 232 101 024		
Speed sensor, ignition/injection	05.98-02.00	0 261 210 147		
Temperature sensor, intake air, injection system	05.98-02.00	0 280 130 085		
1.8 T [7V9]1,8l 110 kW AWC 4 Zyl.				
Throttle valve assembly	06.00→	0 280 750 065		
Air mass meter, gasoline injection	06.00→	0 280 218 060		
		0 986 280 216		
Phase sensor	06.00→	0 232 101 024		
Knock sensor	06.00→	0 261 231 146		
Boost pressure sensor, gasoline				
Fg.no. →7M..2..510 000	06.00-08.01	0 281 002 177		
Fg.no. 7M..2..510 001→	09.01→	0 281 002 399		
Temperature sensor, intake air, injection system	06.00→	0 280 130 085		
1.9 TDI [7V8]1,9l 66 kW AHU 4 Zyl.				
Air mass meter, diesel				
Fg.no. 7M..W..507 042→	09.97-02.00	0 281 002 757		
		WW	0 280 217 121	
			0 986 280 202	
Pedal position sensor, diesel				
Fg.no. →7M..W..507 041	07.96-08.97	AG	0 205 001 031	
		GS	0 205 001 032	
1.9 TDI [7V8]1,9l 66 kW 1Z 4 Zyl.				
Pedal position sensor, diesel	03.96-07.96	AG	0 205 001 031	
		GS	0 205 001 032	
1.9 TDI [7V8]1,9l 81 kW AFN 4 Zyl.				
Air mass meter, diesel				
Fg.no. 7M..W..507 042→	09.97-02.00	0 281 002 757		
		WW	0 280 217 121	
			0 986 280 202	
1.9 TDI [7V9]1,9l 66/85 kW ANU; AUY 4 Zyl.				
Air mass meter, diesel	06.00→	0 281 002 757		
		WW	0 280 217 121	
			0 986 280 202	
Boost pressure sensor, Diesel				
Fg.no. →7M..2..505 000	06.00-06.01	0 281 002 177		
Fg.no. 7M..2..505 001→	07.01→	0 281 002 399		
1.9 TDI [7V9]1,9l 85 kW BVK 4 Zyl.				
Air mass meter, diesel	11.05-05.06	0 281 002 531		
		0 986 284 009		
Boost pressure sensor, Diesel	11.05-05.06	0 281 002 399		
1.9 TDI [7V9]1,9l 96/110 kW ASZ; BTB 4 Zyl.				
Air mass meter, diesel	11.02-06.06	0 281 002 461		
		0 986 284 007		
Boost pressure sensor, Diesel	11.02-06.06	0 281 002 401		



1.9 TDI 4Motion [7V9]		1,9l 85 kW AUY 4 Zyl.
Air mass meter, diesel	06.00→	0 281 002 757
	WW	0 280 217 121
		0 986 280 202
Boost pressure sensor, Diesel		
Fg.no. →7M..2..505 000	06.00-06.01	0 281 002 177
Fg.no. 7M..2..505 001→	07.01→	0 281 002 399
1.9 TDI 4Motion [7V9]		1,9l 96 kW ASZ 4 Zyl.
Air mass meter, diesel	11.02-05.06	0 281 002 461
		0 986 284 007
Boost pressure sensor, Diesel	11.02-05.06	0 281 002 401
2.0 [7V8]		2,0l 85 kW ADY 4 Zyl.
Knock sensor	03.96-02.00	0 261 231 077
Temperature sensor, intake air, injection system	03.96-02.00	0 280 130 073
2.0 [7V9]		2,0l 85 kW ATM 4 Zyl.
Throttle valve assembly	06.00→	0 280 750 057
Air mass meter, gasoline injection	06.00→	0 280 218 060
		0 986 280 216
Phase sensor	06.00→	0 232 101 031
Knock sensor	06.00→	0 261 231 146
2.0 TDI [7V9]		2,0l 103 kW BRT 4 Zyl.
Air mass meter, diesel	11.05→	0 281 002 461
		0 986 284 007
Boost pressure sensor, Diesel	11.05→	0 281 002 401
2.8 [7V9]		2,8l 150 kW AYL 6 Zyl.
Throttle valve assembly	06.00→	0 280 750 086
Air mass meter, gasoline injection	06.00→	0 280 218 017
		0 986 280 208
Phase sensor	06.00→	0 232 103 019
Knock sensor	06.00→	0 261 231 146
2.8 4Motion [7V9]		2,8l 150 kW AYL 6 Zyl.
Throttle valve assembly	05.02→	0 280 750 086
Air mass meter, gasoline injection	05.02→	0 280 218 017
		0 986 280 208
Phase sensor	05.02→	0 232 103 019
Knock sensor	05.02→	0 261 231 146

Altea

1.4 [5P]		1,4l 63 kW BXW 4 Zyl.
Knock sensor	05.06→	0 261 231 146
Pressure sensor, intake manifold, gasoline	05.06→	0 261 230 095
1.6 [5P]		1,6l 75 kW BGU; BSE; BSF 4 Zyl.
Speed sensor, ignition/injection	03.04→	0 261 210 199
Knock sensor	03.04→	0 261 231 146
Pressure sensor, intake manifold, gasoline	03.04→	0 261 230 031
1.8 TFSI [5P]		1,8l 118 kW BYT; BZB 4 Zyl.
Boost pressure sensor, gasoline	01.07→	0 261 230 073
1.9 TDI [5P]		1,9l 77 kW BJB; BKC 4 Zyl.
Air mass meter, diesel	04.04-05.06	0 281 002 531
		0 986 284 009
Speed sensor, diesel	04.04-05.06	0 261 210 233
Boost pressure sensor, Diesel	04.04-05.06	0 281 002 399
1.9 TDI [5P]		1,9l 77 kW BLS 4 Zyl.
Air mass meter, diesel	10.05→	0 281 002 531
		0 986 284 009
Speed sensor, diesel	10.05→	0 261 210 233
Boost pressure sensor, Diesel	10.05→	0 281 002 401
1.9 TDI [5P]		1,9l 77 kW BXE 4 Zyl.
Air mass meter, diesel	02.06→	0 281 002 531
		0 986 284 009
Speed sensor, diesel	02.06→	0 261 210 233
Boost pressure sensor, Diesel	02.06→	0 281 002 399



2.0 FSI [5P]		2,0l 110 kW BLR; BLY; BVY; BVZ 4 Zyl.
Pressure sensor, intake manifold, gasoline	05.04→	0 261 230 031
2.0 TDI [5P]		2,0l 100/103/125 kW AZV; BKD; BMM; BMN 4 Zyl.
Air mass meter, diesel	03.04→	0 281 002 461
		0 986 284 007
Boost pressure sensor, Diesel	03.04→	0 281 002 401
2.0 TFSI [5P]		2,0l 147 kW BWA 4 Zyl.
Speed sensor, ignition/injection	05.06→	0 261 210 199
Boost pressure sensor, gasoline	05.06→	0 261 230 073

Arosa

1.0 [6H1]		1,0l 37 kW AER 4 Zyl.
Knock sensor	02.97-09.99	0 261 231 045
Pressure sensor, intake manifold, gasoline	02.97-09.99	0 261 230 011
Accelerator pedal module	02.97-09.99	0 280 752 214
Pedal position sensor, EMS (electronic engine management)	02.97-09.99	0 280 752 018
1.0 [6H1]		1,0l 37 kW AHT 4 Zyl.
Accelerator pedal module	10.97-02.00	0 280 752 214
Pedal position sensor, EMS (electronic engine management)	10.97-02.00	0 280 752 018
1.0 [6H1]		1,0l 37 kW ALD 4 Zyl.
Throttle valve assembly		
Fg.no. →6H..Y..006 230	01.99-11.99	0 280 750 049
Fg.no. 6H..Y..006 231→	12.99-07.00	0 280 750 095
Speed sensor, ignition/injection		
Fg.no. →6H..Y..023 700	01.99-06.00	0 261 210 188
Pressure sensor, intake manifold, gasoline	01.99-07.00	0 261 230 031
Accelerator pedal module	01.99-07.00	0 280 752 214
Pedal position sensor, EMS (electronic engine management)	01.99-07.00	0 280 752 018
1.0 [6H1]		1,0l 37 kW ALL 4 Zyl.
Knock sensor	10.97-05.99	0 261 231 045
Pressure sensor, intake manifold, gasoline	10.97-05.99	0 261 230 011
Accelerator pedal module	10.97-05.99	0 280 752 214
Pedal position sensor, EMS (electronic engine management)	10.97-05.99	0 280 752 018
1.0 [6H1]		1,0l 37 kW ANV 4 Zyl.
Throttle valve assembly		
Fg.no. →6H..Y..006 230	01.99-11.99	0 280 750 049
Fg.no. 6H..Y..006 231→	12.99-07.00	0 280 750 095
Speed sensor, ignition/injection		
Fg.no. →6H..Y..023 700	01.99-06.00	0 261 210 188
Knock sensor	01.99-07.00	0 261 231 045
Pressure sensor, intake manifold, gasoline	01.99-07.00	0 261 230 031
Accelerator pedal module	01.99-07.00	0 280 752 214
Pedal position sensor, EMS (electronic engine management)	01.99-07.00	0 280 752 018
1.0 [6H1]		1,0l 37 kW AUC 4 Zyl.
Throttle valve assembly	05.00-06.04	0 280 750 095
Speed sensor, ignition/injection		
Fg.no. →6H..Y..023 700	05.00-06.00	0 261 210 188
Fg.no. 6H..Y..027 001→6H..1..004 300	09.00-10.00	0 261 210 188
Fg.no. 6H..1..004 301→	11.00-06.04	0 261 210 213
Knock sensor	05.00-06.04	0 261 231 045
Pressure sensor, intake manifold, gasoline	05.00-06.04	0 261 230 031
Accelerator pedal module	05.00-06.04	0 280 752 214
Pedal position sensor, EMS (electronic engine management)	05.00-06.04	0 280 752 018
1.4 [6H1]		1,4l 44 kW AEX 4 Zyl.
Knock sensor	02.97-11.97	0 261 231 045
Pressure sensor, intake manifold, gasoline	02.97-11.97	0 261 230 011




</

Cordoba

1.0 [6K2]		1,0l 37 kW AER 4 Zyl.	
Knock sensor	09.96-06.99	0 261 231 045	
Pressure sensor, intake manifold, gasoline	09.96-06.99	0 261 230 011	
1.0 [6K2]		1,0l 37 kW ALD 4 Zyl.	
Throttle valve assembly	05.99-12.02	0 280 750 049	
Speed sensor, ignition/injection			
Fg.no. →6K..1..071 000	05.99-06.00	TW	0 261 210 188
Fg.no. 6K..1..158 801→	11.00-12.02	TW	0 261 210 213
Knock sensor	05.99-12.02	0 261 231 045	
Pressure sensor, intake manifold, gasoline	05.99-12.02	0 261 230 011	
Pedal position sensor, EMS (electronic engine management)	05.99-12.02	0 280 752 012	

Product				
1.0 [6K2]				
1,0l 37 kW ANV 4 Zyl.				
Throttle valve assembly				
Mot.no. →027 842	05.99-07.00			0 280 750 049
Mot.no. 027 843→	05.99-07.00			0 280 750 095
Speed sensor, ignition/injection	05.99-07.00	TW		0 261 210 188
Knock sensor	05.99-07.00			0 261 231 045
Pressure sensor, intake manifold, gasoline	05.99-07.00			0 261 230 011
Pedal position sensor, EMS (electronic engine management)	05.99-07.00			0 280 752 012
1.0 [6K2]				
1,0l 37 kW AUC 4 Zyl.				
Throttle valve assembly	07.00-12.02			0 280 750 049
Speed sensor, ignition/injection				
Fg.no. 6K..1..158 801→	11.00-12.02	TW		0 261 210 213
Knock sensor	07.00-12.02			0 261 231 045
Pressure sensor, intake manifold, gasoline	07.00-12.02			0 261 230 011
Pedal position sensor, EMS (electronic engine management)	07.00-12.02			0 280 752 012
1.2 [6L2]				
1,2l 47 kW AZQ 3 Zyl.				
Pressure sensor, intake manifold, gasoline	10.02-04.04			0 261 230 031
Accelerator pedal module	10.02-04.04	AG,RLE		0 280 752 220
		GS,LLE		0 280 752 214
Duo sensor, acceleration and yaw rate, brake system	10.02-04.04			0 265 005 252
Pressure sensor, ESP, (electronic stability program)	10.02-04.04			0 265 005 303
1.2 [6L2]				
1,2l 47 kW BME 3 Zyl.				
Pressure sensor, intake manifold, gasoline	11.04-06.06			0 261 230 031
Accelerator pedal module	11.04-06.06	GS,LLE		0 280 752 214
Fg.no. →6L..6..570 000	11.04-05.06	AG,RLE		0 280 752 220
Duo sensor, acceleration and yaw rate, brake system	11.04-06.06			0 265 005 601
1.2 [6L2]				
1,2l 51 kW BXV 3 Zyl.				
Pressure sensor, intake manifold, gasoline	05.06→			0 261 230 031
Accelerator pedal module	05.06→	GS,LLE		0 280 752 214
Duo sensor, acceleration and yaw rate, brake system	05.06→			0 265 005 601
1.4 [6K2]				
1,4l 44 kW AEX 4 Zyl.				
Knock sensor	01.96-12.97			0 261 231 045
Pressure sensor, intake manifold, gasoline	01.96-12.97			0 261 230 011
1.4 [6K2]				
1,4l 44 kW AKK 4 Zyl.				
Throttle valve assembly	05.99-12.02			0 280 750 049
Speed sensor, ignition/injection				
Fg.no. →6K..1..158 800	05.99-10.00	BM6		0 261 210 188
Fg.no. 6K..1..158 801→	11.00-12.02	BM6		0 261 210 213
Knock sensor	05.99-12.02			0 261 231 045
Pressure sensor, intake manifold, gasoline	05.99-12.02			0 261 230 031
Pedal position sensor, EMS (electronic engine management)	05.99-12.02			0 280 752 012
1.4 [6K2]				
1,4l 44 kW AKV 4 Zyl.				
Knock sensor	12.97-06.99			0 261 231 045
Pressure sensor, intake manifold, gasoline	12.97-06.99			0 261 230 011
1.4 [6K2]				
1,4l 44 kW ANW 4 Zyl.				
Throttle valve assembly				
Mot.no. →051 560	05.99-08.00			0 280 750 049
Mot.no. 051 561→	05.99-08.00			0 280 750 095
Speed sensor, ignition/injection	05.99-08.00	TW		0 261 210 188
Knock sensor	05.99-08.00			0 261 231 045
Pressure sensor, intake manifold, gasoline	05.99-08.00			0 261 230 031
Pedal position sensor, EMS (electronic engine management)	05.99-08.00			0 280 752 012
1.4 [6K2]				
1,4l 44 kW ANX; APQ 4 Zyl.				
Knock sensor	12.97-05.98			0 261 231 045
Pressure sensor, intake manifold, gasoline	12.97-05.98			0 261 230 011





Product			
1.4 [6K2] 1,4l 44 kW AUD 4 Zyl.			
Throttle valve assembly			
Mot.no. →020 027	06.00-12.02		0 280 750 049
Mot.no. 020 028→	06.00-12.02		0 280 750 095
Speed sensor, ignition/injection			
Fg.no. →6K..1..158 800	06.00-10.00	BM6	0 261 210 188
Fg.no. 6K..1..158 801→	11.00-12.02	BM6	0 261 210 213
Knock sensor	06.00-12.02		0 261 231 045
Pressure sensor, intake manifold, gasoline	06.00-12.02		0 261 230 031
Pedal position sensor, EMS (electronic engine management)	06.00-12.02		0 280 752 012
1.4 [6K2] 1,4l 55 kW APE; AUA 4 Zyl.			
Knock sensor	09.99-12.02		0 261 231 045
Pedal position sensor, EMS (electronic engine management)	09.99-12.02		0 280 752 012
1.4 [6K2] 1,4l 74 kW AFH 4 Zyl.			
Knock sensor	07.96-12.02		0 261 231 045
1.4 [6K2] 1,4l 74 kW AQQ; AUB 4 Zyl.			
Knock sensor	09.99-12.02		0 261 231 045
Pedal position sensor, EMS (electronic engine management)	09.99-12.02		0 280 752 012
1.4 [6L2] 1,4l 55 kW BBY 4 Zyl.			
Speed sensor, ignition/injection			
Fg.no. 6L..3..126 001→	11.02-04.04	GS	0 261 210 257
Knock sensor	09.02-04.04		0 261 231 146
Accelerator pedal module	09.02-04.04	AG,RLE	0 280 752 220
		GS,LLE	0 280 752 214
Duo sensor, acceleration and yaw rate, brake system	09.02-04.04		0 265 005 252
Pressure sensor, ESP, (electronic stability program)	09.02-04.04		0 265 005 303
1.4 [6L2] 1,4l 55 kW BKY 4 Zyl.			
Knock sensor	05.04-06.06		0 261 231 146
Pressure sensor, intake manifold, gasoline	05.04-06.06		0 261 230 095
Accelerator pedal module	05.04-06.06	GS,LLE	0 280 752 214
Fg.no. →6L..6..570 000	05.04-05.06	AG,RLE	0 280 752 220
Duo sensor, acceleration and yaw rate, brake system	05.04-06.06		0 265 005 601
1.4 [6L2] 1,4l 63 kW BXW 4 Zyl.			
Knock sensor	05.06-11.06		0 261 231 146
Pressure sensor, intake manifold, gasoline	05.06-11.06		0 261 230 095
Accelerator pedal module	05.06-11.06	GS,LLE	0 280 752 214
Duo sensor, acceleration and yaw rate, brake system	05.06-11.06		0 265 005 601
1.4 [6L2] 1,4l 74 kW BBZ 4 Zyl.			
Knock sensor	10.02→		0 261 231 146
Accelerator pedal module	10.02→	GS,LLE	0 280 752 214
Fg.no. →6L..6..570 000	10.02-05.06	AG,RLE	0 280 752 220
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →6L..4..232 600	10.02-04.04		0 265 005 252
Fg.no. 6L..4..232 601→	05.04→		0 265 005 601
1.4 TDI [6L2] 1,4l 51 kW BNM 3 Zyl.			
Air mass meter, diesel	05.05→		0 281 002 531
			0 986 284 009
Boost pressure sensor, Diesel	05.05→		0 281 002 399
Duo sensor, acceleration and yaw rate, brake system	05.05→		0 265 005 601
1.4 TDI [6L2] 1,4l 55 kW AMF 3 Zyl.			
Air mass meter, diesel	10.02-12.05		0 281 002 531
			0 986 284 009
Boost pressure sensor, Diesel	10.02-12.05		0 281 002 399




Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →6L..4..232 600	10.02-04.04		0 265 005 252
Fg.no. 6L..4..232 601→	05.04-12.05		0 265 005 601
1.4 TDI [6L2] 1,4l 58/59 kW BMS; BNV 3 Zyl.			
Air mass meter, diesel	05.05→		0 281 002 531
			0 986 284 009
Boost pressure sensor, Diesel	05.05→		0 281 002 399
Duo sensor, acceleration and yaw rate, brake system	05.05→		0 265 005 601
1.6 1,6l 74 kW AKL 4 Zyl.			
Speed sensor, ignition/injection	10.99→	FKW	0 261 210 147
1.6 [6K2] 1,6l 55 kW AEE; ALM 4 Zyl.			
Knock sensor	03.97-12.02		0 261 231 045
1.6 [6K2] 1,6l 74 kW AEH 4 Zyl.			
Phase sensor	05.99-12.02		0 232 101 031
		WW	0 232 101 038
Speed sensor, ignition/injection	05.99-12.02		0 261 210 147
1.6 [6K2] 1,6l 74 kW AFT 4 Zyl.			
Knock sensor	12.95-11.02		0 261 231 036
Temperature sensor, intake air, injection system	12.95-11.02		0 280 130 039
1.6 [6K2] 1,6l 74 kW AKL 4 Zyl.			
Phase sensor	05.99-12.02		0 232 101 031
		WW	0 232 101 038
Speed sensor, ignition/injection	05.99-12.02		0 261 210 147
1.6 [6K2] 1,6l 74 kW APF 4 Zyl.			
Phase sensor	09.99-10.00		0 232 101 031
Speed sensor, ignition/injection	09.99-10.00		0 261 210 199
1.6 [6K2] 1,6l 74 kW AUR 4 Zyl.			
Phase sensor	05.00-12.02		0 232 101 031
		WW	0 232 101 038
Speed sensor, ignition/injection	05.00-12.02		0 261 210 199
1.6 [6L2] 1,6l 74 kW BAH 4 Zyl.			
Knock sensor	04.03→		0 261 231 146
Pressure sensor, intake manifold, gasoline	04.03→		0 261 230 095
Accelerator pedal module	04.03→	GS,LLE	0 280 752 214
Fg.no. →6L..6..570 000	04.03-05.06	AG,RLE	0 280 752 220
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →6L..4..232 600	04.03-04.04		0 265 005 252
Fg.no. 6L..4..232 601→	05.04→		0 265 005 601
1.6 [6L2] 1,6l 77 kW BTS 4 Zyl.			
Knock sensor	11.06→		0 261 231 146
Pressure sensor, intake manifold, gasoline	11.06→		0 261 230 095
Accelerator pedal module	11.06→	GS,LLE	0 280 752 214
Duo sensor, acceleration and yaw rate, brake system	11.06→		0 265 005 601
1.8 [6K2] 1,8l 95 kW ADL 4 Zyl.			
Knock sensor	09.93-06.96		0 261 231 077
1.8 T Cupra [6K2] 1,8l 115 kW AQX; AYP 4 Zyl.			
Throttle valve assembly	05.99-12.02		0 280 750 036
Air mass meter, gasoline injection	05.99-12.02		0 280 218 032
			0 986 280 210
Phase sensor	05.99-12.02		0 232 101 024
Speed sensor, ignition/injection	05.99-12.02		0 261 210 147
Temperature sensor, intake air, injection system	05.99-12.02		0 280 130 085
Pedal position sensor, EMS (electronic engine management)	05.99-12.02		0 280 752 012
1.9 SDI [6K2] 1,9l 47 kW AEY 4 Zyl.			
Pedal position sensor, diesel	12.95-12.02		0 205 001 032

◀ Cordoba		
1.9 SDI [6L2]		1,9l 47 kW ASY 4 Zyl.
Duo sensor, acceleration and yaw rate, brake system		
Fg.no. →6L..4..232 600	09.02-04.04	0 265 005 252
Fg.no. 6L..4..232 601→	05.04-12.05	0 265 005 601
1.9 TDI		1,9l 66 kW AGR 4 Zyl.
Air mass meter, diesel	01.00→	0 281 002 216  0 986 284 001
Pedal position sensor, diesel	01.00→	0 281 002 286
	10.00→	0 281 002 339
1.9 TDI [6K2]		1,9l 66 kW AGR 4 Zyl.
Air mass meter, diesel	05.99-12.02	0 281 002 216  0 986 284 001
Boost pressure sensor, Diesel	05.99-12.02	0 281 002 177
1.9 TDI [6K2]		1,9l 66 kW AHU 4 Zyl.
Pressure sensor, intake manifold, diesel	07.96-12.02	0 261 230 037
Pedal position sensor, diesel	07.96-12.02	0 205 001 032
1.9 TDI [6K2]		1,9l 66 kW ALH 4 Zyl.
Air mass meter, diesel	05.99-05.01	0 281 002 216  0 986 284 001
Boost pressure sensor, Diesel	05.99-05.01	0 281 002 177
1.9 TDI [6K2]		1,9l 66 kW 1Z 4 Zyl.
Pressure sensor, intake manifold, diesel	07.96-12.96	0 261 230 037
Pedal position sensor, diesel	07.96-12.96	0 205 001 032
1.9 TDI [6K2]		1,9l 81 kW AFN 4 Zyl.
Pressure sensor, intake manifold, diesel	03.97-12.02	0 261 230 037
Pedal position sensor, diesel	03.97-12.02	0 205 001 032
1.9 TDI [6K2]		1,9l 81 kW ASV 4 Zyl.
Air mass meter, diesel	05.99-12.02	0 281 002 216  0 986 284 001
Boost pressure sensor, Diesel	05.99-12.02	0 281 002 177
1.9 TDI [6L2]		1,9l 74 kW ATD 4 Zyl.
Air mass meter, diesel	09.02-09.05	0 281 002 531  0 986 284 009
Boost pressure sensor, Diesel	09.02-09.05	0 281 002 399
Duo sensor, acceleration and yaw rate, brake system		
Fg.no. →6L..4..232 600	09.02-04.04	0 265 005 252
Fg.no. 6L..4..232 601→	05.04-09.05	0 265 005 601
1.9 TDI [6L2]		1,9l 74 kW AXR 4 Zyl.
Air mass meter, diesel	05.05→	0 281 002 531  0 986 284 009
Boost pressure sensor, Diesel	05.05→	0 281 002 399
Duo sensor, acceleration and yaw rate, brake system		
1.9 TDI [6L2]		1,9l 74 kW BMT 4 Zyl.
Air mass meter, diesel	09.06-12.06	0 281 002 531  0 986 284 009
Duo sensor, acceleration and yaw rate, brake system	09.06-12.06	0 265 005 601
Duo sensor, acceleration and yaw rate, brake system		
1.9 TDI [6L2]		1,9l 96 kW ASZ 4 Zyl.
Air mass meter, diesel	10.02-09.05	0 281 002 461  0 986 284 007
Boost pressure sensor, Diesel	10.02-09.05	0 281 002 401
Duo sensor, acceleration and yaw rate, brake system		
Fg.no. →6L..4..232 600	10.02-04.04	0 265 005 252
Fg.no. 6L..4..232 601→	05.04-09.05	0 265 005 601
1.9 TDI [6L2]		1,9l 96 kW BLT 4 Zyl.
Air mass meter, diesel	05.05→	0 281 002 461  0 986 284 007
Boost pressure sensor, Diesel	05.05→	0 281 002 401

Duo sensor, acceleration and yaw rate, brake system	05.05→		0 265 005 601
2.0 [6K2]		2,0l 85 kW AGG 4 Zyl.	
Knock sensor	04.96-12.02		0 261 231 077
2.0 [6K2]		2,0l 85 kW 2E 4 Zyl.	
Speed sensor, ignition/injection	09.93-04.96		0 356 914 213
Knock sensor	09.93-04.96		0 261 231 077
2.0 [6K2]		2,0l 110 kW ABF 4 Zyl.	
Knock sensor	06.96-12.02		0 261 231 077
2.0 [6L2]		2,0l 85 kW AZL 4 Zyl.	
Throttle valve assembly			
Fg.no. →6L..4..184 000	09.02-02.04		0 280 750 061
Air mass meter, gasoline injection	09.02-04.05		0 280 218 060
			0 986 280 216
Phase sensor	09.02-04.05		0 232 101 031
Speed sensor, ignition/injection	09.02-04.05		0 261 210 199
Knock sensor	09.02-04.05		0 261 231 146
Accelerator pedal module	09.02-04.05	AG,RLE	0 280 752 220
		GS,LLF	0 280 752 214
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →6L..4..232 600	09.02-04.04		0 265 005 252
Fg.no. 6L..4..232 601→	05.04-04.05		0 265 005 601
Pressure sensor, ESP, (electronic stability program)	09.02-04.05		0 265 005 303
2.0 [6L2]		2,0l 85 kW BBX 4 Zyl.	
Throttle valve assembly	04.03-06.06	TW	0 280 750 061
Air mass meter, gasoline injection	04.03-06.06		0 280 218 060
			0 986 280 216
Phase sensor	04.03-06.06		0 232 101 031
Speed sensor, ignition/injection	04.03-06.06		0 261 210 199
Knock sensor	04.03-06.06		0 261 231 146
Pressure sensor, intake manifold, gasoline	04.03-06.06		0 261 230 095
Accelerator pedal module	04.03-06.06	GS,LLF	0 280 752 214
Fg.no. →6L..6..570 000	04.03-05.06	AG,RLE	0 280 752 220
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →6L..4..232 600	04.03-04.04		0 265 005 252
Fg.no. 6L..4..232 601→	05.04-06.06		0 265 005 601

Cordoba Vario			
1.4 [6K5]		1,4l	44 kW AEX 4 Zyl.
Knock sensor	05.97-08.97		0 261 231 045
Pressure sensor, intake manifold, gasoline	05.97-08.97		0 261 230 011
1.4 [6K5]		1,4l	44 kW AKK 4 Zyl.
Throttle valve assembly	08.99-08.02		0 280 750 049
Speed sensor, ignition/injection			
Fg.no. →6K..1..158 800	08.99-10.00	BM6	0 261 210 188
Fg.no. 6K..1..158 801→	11.00-08.02	BM6	0 261 210 213
Knock sensor	08.99-08.02		0 261 231 045
Pressure sensor, intake manifold, gasoline	08.99-08.02		0 261 230 031
Pedal position sensor, EMS (electronic engine management)	08.99-08.02		0 280 752 012
1.4 [6K5]		1,4l	44 kW AKV 4 Zyl.
Knock sensor	09.97-12.02		0 261 231 045
Pressure sensor, intake manifold, gasoline	09.97-12.02		0 261 230 011
1.4 [6K5]		1,4l	44 kW ANW 4 Zyl.
Throttle valve assembly			
Mot.no. →051 560	05.99-08.00		0 280 750 049
Mot.no. 051 561→	05.99-08.00		0 280 750 095
Speed sensor, ignition/injection	05.99-08.00	TW	0 261 210 188
Knock sensor	05.99-08.00		0 261 231 045



Pressure sensor, intake manifold, gasoline	05.99-08.00	0 261 230 031
Pedal position sensor, EMS (electronic engine management)	05.99-08.00	0 280 752 012
1.4 [6K5]	1,4l 44 kW ANX; APQ 4 Zyl.	
Knock sensor	12.97-12.02	0 261 231 045
Pressure sensor, intake manifold, gasoline	12.97-12.02	0 261 230 011
1.4 [6K5]	1,4l 44 kW AUD 4 Zyl.	
Throttle valve assembly		
Mot.no. →020 027	06.00-12.02	0 280 750 049
Mot.no. 020 028→	06.00-12.02	0 280 750 095
Speed sensor, ignition/injection		
Fg.no. →6K..1..158 800	06.00-10.00 BM6	0 261 210 188
Fg.no. 6K..1..158 801→	11.00-12.02 BM6	0 261 210 213
Knock sensor	06.00-12.02	0 261 231 045
Pressure sensor, intake manifold, gasoline	06.00-12.02	0 261 230 031
Pedal position sensor, EMS (electronic engine management)	06.00-12.02	0 280 752 012
1.4 [6K5]	1,4l 55/74 kW APE; AQQ 4 Zyl.	
Knock sensor	05.99-07.00	0 261 231 045
Pedal position sensor, EMS (electronic engine management)	05.99-07.00	0 280 752 012
1.6	1,6l 76 kW AKL 4 Zyl.	
Speed sensor, ignition/injection	10.99→ FKW	0 261 210 147
1.6 [6K5]	1,6l 55 kW AEE; ALM 4 Zyl.	
Knock sensor	05.97-08.02	0 261 231 045
1.6 [6K5]	1,6l 74 kW AEH 4 Zyl.	
Phase sensor	05.99-12.02	0 232 101 031
	WW	0 232 101 038
Speed sensor, ignition/injection	05.99-12.02	0 261 210 147
1.6 [6K5]	1,6l 74 kW AFT 4 Zyl.	
Knock sensor	04.97-06.99	0 261 231 036
Temperature sensor, intake air, injection system	04.97-06.99	0 280 130 039
1.6 [6K5]	1,6l 74 kW AKL 4 Zyl.	
Air mass meter, gasoline injection	06.99-09.99	0 280 218 032
		0 986 280 210
Phase sensor	06.99-08.02	0 232 101 031
	WW	0 232 101 038
Speed sensor, ignition/injection	06.99-08.02	0 261 210 147
1.6 [6K5]	1,6l 74 kW APF 4 Zyl.	
Phase sensor	09.99-10.00	0 232 101 031
Speed sensor, ignition/injection	09.99-10.00	0 261 210 199
1.6 [6K5]	1,6l 74 kW AUR 4 Zyl.	
Phase sensor	07.00-08.02	0 232 101 031
	WW	0 232 101 038
Speed sensor, ignition/injection	07.00-08.02	0 261 210 199
1.9 SDI [6K5]	1,9l 47 kW AEY 4 Zyl.	
Pedal position sensor, diesel	06.97-06.99	0 205 001 032
1.9 TDI [6K5]	1,9l 66 kW AGR 4 Zyl.	
Air mass meter, diesel	05.99-08.02	0 281 002 216
		0 986 284 001
Boost pressure sensor, Diesel	05.99-08.02	0 281 002 177
1.9 TDI [6K5]	1,9l 66 kW AHU 4 Zyl.	
Pressure sensor, intake manifold, diesel	06.97-06.99	0 261 230 037
Pedal position sensor, diesel	06.97-06.99	0 205 001 032
1.9 TDI [6K5]	1,9l 66 kW ALH 4 Zyl.	
Air mass meter, diesel	05.99-05.01	0 281 002 216
		0 986 284 001
Boost pressure sensor, Diesel	05.99-05.01	0 281 002 177
1.9 TDI [6K5]	1,9l 81 kW AFN 4 Zyl.	
Pressure sensor, intake manifold, diesel	02.98-06.99	0 261 230 037
Pedal position sensor, diesel	02.98-06.99	0 205 001 032



1.9 TDI [6K5]	1,9l 81 kW ASV 4 Zyl.	
Air mass meter, diesel	05.99-08.02	0 281 002 216
		0 986 284 001
Boost pressure sensor, Diesel	05.99-08.02	0 281 002 177
Ibiza		
1.0 [6K1]	1,0l 37 kW AER 4 Zyl.	
Knock sensor	09.96-10.99	0 261 231 045
Pressure sensor, intake manifold, gasoline	09.96-10.99	0 261 230 011
1.0 [6K1]	1,0l 37 kW ALD 4 Zyl.	
Throttle valve assembly	05.99-05.02	0 280 750 049
Speed sensor, ignition/injection		
Fg.no. →6K..1..071 000	05.99-06.00 TW	0 261 210 188
Fg.no. 6K..1..158 801→	11.00-05.02 TW	0 261 210 213
Knock sensor	05.99-05.02	0 261 231 045
Pressure sensor, intake manifold, gasoline	05.99-05.02	0 261 230 011
Pedal position sensor, EMS (electronic engine management)	05.99-05.02	0 280 752 012
1.0 [6K1]	1,0l 37 kW ANV 4 Zyl.	
Throttle valve assembly		
Mot.no. →027 842	05.99-07.00	0 280 750 049
Mot.no. 027 843→	05.99-07.00	0 280 750 095
Speed sensor, ignition/injection	05.99-07.00 TW	0 261 210 188
Knock sensor	05.99-07.00	0 261 231 045
Pressure sensor, intake manifold, gasoline	05.99-07.00	0 261 230 011
Pedal position sensor, EMS (electronic engine management)	05.99-07.00	0 280 752 012
1.0 [6K1]	1,0l 37 kW AUC 4 Zyl.	
Throttle valve assembly	07.00-05.02	0 280 750 049
Speed sensor, ignition/injection		
Fg.no. 6K..1..158 801→	11.00-05.02 TW	0 261 210 213
Knock sensor	07.00-05.02	0 261 231 045
Pressure sensor, intake manifold, gasoline	07.00-05.02	0 261 230 011
Pedal position sensor, EMS (electronic engine management)	07.00-05.02	0 280 752 012
1.2 [6L1]	1,2l 44 kW BBM 4 Zyl.	
Knock sensor	06.07→	0 261 231 146
1.2 [6L1]	1,2l 47 kW AZQ 3 Zyl.	
Pressure sensor, intake manifold, gasoline	11.01-04.04	0 261 230 031
Accelerator pedal module	11.01-04.04 AG,RLE	0 280 752 220
	GS,LLE	0 280 752 214
Duo sensor, acceleration and yaw rate, brake system	11.01-04.04	0 265 005 252
1.2 [6L1]	1,2l 47 kW BME 3 Zyl.	
Knock sensor	11.04→ 2PO	0 261 231 146
Pressure sensor, intake manifold, gasoline	11.04→	0 261 230 031
Accelerator pedal module	11.04→ AG,RLE	0 280 752 220
	GS,LLE	0 280 752 214
Duo sensor, acceleration and yaw rate, brake system	11.04→	0 265 005 601
1.2 [6L1]	1,2l 51 kW BVX 3 Zyl.	
Knock sensor	05.06→	0 261 231 146
Pressure sensor, intake manifold, gasoline	05.06→	0 261 230 031
Accelerator pedal module	05.06→ AG,RLE	0 280 752 220
	GS,LLE	0 280 752 214
Duo sensor, acceleration and yaw rate, brake system	05.06→	0 265 005 601
1.2 i [Y..]	1,2l 51 kW 021 C.1000 4 Zyl.	
Throttle valve sensor	12.89-05.93	0 280 120 315
Air flow sensor, gasoline injection	12.89-05.93	0 280 200 052
		0 986 280 058

Product				
Ibiza				
Temperature sensor, cylinder head	12.89-05.93			0 280 130 026
Relay, Jetronic	12.89-05.93			0 280 230 009
1.4 [6K1]		1,4l	44 kW AEX	4 Zyl.
Knock sensor	12.95-12.97			0 261 231 045
Pressure sensor, intake manifold, gasoline	12.95-12.97			0 261 230 011
1.4 [6K1]		1,4l	44 kW AKK	4 Zyl.
Throttle valve assembly	05.99-05.02			0 280 750 049
Speed sensor, ignition/injection				
Fg.no. →6K..1..158 800	05.99-10.00	BM6		0 261 210 188
Fg.no. 6K..1..158 801→	11.00-05.02	BM6		0 261 210 213
Knock sensor	05.99-05.02			0 261 231 045
Pressure sensor, intake manifold, gasoline	05.99-05.02			0 261 230 031
Pedal position sensor, EMS (electronic engine management)	05.99-05.02			0 280 752 012
1.4 [6K1]		1,4l	44 kW AKV	4 Zyl.
Knock sensor	12.97-10.99			0 261 231 045
Pressure sensor, intake manifold, gasoline	12.97-10.99			0 261 230 011
1.4 [6K1]		1,4l	44 kW ANW	4 Zyl.
Throttle valve assembly				
Mot.no. →051 560	05.99-08.00			0 280 750 049
Mot.no. 051 561→	05.99-08.00			0 280 750 095
Speed sensor, ignition/injection	05.99-08.00	TW		0 261 210 188
Knock sensor	05.99-08.00			0 261 231 045
Pressure sensor, intake manifold, gasoline	05.99-08.00			0 261 230 031
Pedal position sensor, EMS (electronic engine management)	05.99-08.00			0 280 752 012
1.4 [6K1]		1,4l	44 kW ANX; APQ	4 Zyl.
Knock sensor	12.97-10.99			0 261 231 045
Pressure sensor, intake manifold, gasoline	12.97-10.99			0 261 230 011
1.4 [6K1]		1,4l	44 kW AUD	4 Zyl.
Throttle valve assembly				
Mot.no. →020 027	06.00-05.02			0 280 750 049
Mot.no. 020 028→	06.00-05.02			0 280 750 095
Speed sensor, ignition/injection				
Fg.no. →6K..1..158 800	06.00-10.00	BM6		0 261 210 188
Fg.no. 6K..1..158 801→	11.00-05.02	BM6		0 261 210 213
Knock sensor	06.00-05.02			0 261 231 045
Pressure sensor, intake manifold, gasoline	06.00-05.02			0 261 230 031
Pedal position sensor, EMS (electronic engine management)	06.00-05.02			0 280 752 012
1.4 [6K1]		1,4l	55 kW APE; AUA	4 Zyl.
Knock sensor	05.99-05.02			0 261 231 045
Pedal position sensor, EMS (electronic engine management)	05.99-05.02			0 280 752 012
1.4 [6K1]		1,4l	74 kW AFH	4 Zyl.
Knock sensor	11.96-10.99			0 261 231 045
1.4 [6K1]		1,4l	74 kW AQQ; AUB	4 Zyl.
Knock sensor	09.99-05.02			0 261 231 045
Pedal position sensor, EMS (electronic engine management)	09.99-05.02			0 280 752 012
1.4 [6L1]		1,4l	55 kW BBY	4 Zyl.
Speed sensor, ignition/injection				
Fg.no. 6L..3..126 001→	11.02-04.04	GS		0 261 210 257
Accelerator pedal module	01.02-04.04	AG,RLE		0 280 752 220
		GS,LLE		0 280 752 214
Duo sensor, acceleration and yaw rate, brake system	01.02-04.04			0 265 005 252
1.4 [6L1]		1,4l	55 kW BKY	4 Zyl.
Pressure sensor, intake manifold, gasoline	05.04→			0 261 230 095
Accelerator pedal module	05.04→	AG,RLE		0 280 752 220
		GS,LLE		0 280 752 214
Duo sensor, acceleration and yaw rate, brake system	05.04→			0 265 005 601

Product				
1.4 [6L1] 1,4l 63 kW BXW 4 Zyl.				
Knock sensor	05.06→			0 261 231 146
Pressure sensor, intake manifold, gasoline	05.06→			0 261 230 095
Accelerator pedal module	05.06→	AG,RLE		0 280 752 220
		GS,LLE		0 280 752 214
Duo sensor, acceleration and yaw rate, brake system	05.06→			0 265 005 601
1.4 [6L1] 1,4l 74 kW AUB 4 Zyl.				
Knock sensor	09.01-05.02			0 261 231 146
Accelerator pedal module	09.01-05.02	AG,RLE		0 280 752 220
		GS,LLE		0 280 752 214
Duo sensor, acceleration and yaw rate, brake system	09.01-05.02			0 265 005 252
1.4 [6L1] 1,4l 74 kW BBZ 4 Zyl.				
Knock sensor	04.02→			0 261 231 146
Accelerator pedal module	04.02→	AG,RLE		0 280 752 220
		GS,LLE		0 280 752 214
Duo sensor, acceleration and yaw rate, brake system				
Fg.no. →6L..4..232 600	04.02-04.04			0 265 005 252
Fg.no. 6L..4..232 601→	05.04→			0 265 005 601
1.4 TDI [6L1] 1,4l 51 kW BNM 3 Zyl.				
Air mass meter, diesel	05.05→			0 281 002 531
				0 986 284 009
Boost pressure sensor, Diesel	05.05→			0 281 002 399
Duo sensor, acceleration and yaw rate, brake system	05.05→			0 265 005 601
1.4 TDI [6L1] 1,4l 55 kW AMF 3 Zyl.				
Air mass meter, diesel	05.02→			0 281 002 531
				0 986 284 009
Boost pressure sensor, Diesel	05.02→			0 281 002 399
Duo sensor, acceleration and yaw rate, brake system				
Fg.no. →6L..4..232 600	05.02-04.04			0 265 005 252
Fg.no. 6L..4..232 601→	05.04→			0 265 005 601
1.4 TDI [6L1] 1,4l 59 kW BMS; BNV 3 Zyl.				
Air mass meter, diesel	05.05→			0 281 002 531
				0 986 284 009
Boost pressure sensor, Diesel	05.05→			0 281 002 399
Duo sensor, acceleration and yaw rate, brake system	05.05→			0 265 005 601
1.5 i [Y..] 1,5l 65-70 kW 4 Zyl.				
Air flow sensor, gasoline injection	11.89-05.93			0 280 200 050
Temperature sensor, cylinder head	11.89-05.93			0 280 130 026
Relay, Jetronic	11.89-05.93			0 280 230 009
1.5 i [Y..] 1,5l 66 kW 021 A 2000 4 Zyl.				
Throttle valve sensor	10.86-05.93			0 280 120 315
Air flow sensor, gasoline injection	10.86-05.93			0 280 200 050
Temperature sensor, cylinder head	10.86-05.93			0 280 130 026
Relay, Jetronic	10.86-05.93			0 280 230 009
1.5 i [Y..] 1,5l 74 kW 021 A 2000 4 Zyl.				
Throttle valve sensor	10.86-05.93			0 280 120 315
Air flow sensor, gasoline injection	10.86-05.93			0 280 200 045
Temperature sensor, cylinder head	10.86-05.93			0 280 130 026
Relay, Jetronic	10.86-05.93			0 280 230 009
1.6 1,6l 76 kW AKL 4 Zyl.				
Speed sensor, ignition/injection	10.99→	FKW		0 261 210 147
1.6 [6K1] 1,6l 55 kW AEE; ALM 4 Zyl.				
Knock sensor	03.97-05.02			0 261 231 045
1.6 [6K1] 1,6l 74 kW AEH 4 Zyl.				
Phase sensor	05.99-05.02			0 232 101 031
		WW		0 232 101 038
Speed sensor, ignition/injection	05.99-05.02			0 261 210 147





Product		
1.6 [6K1]	1,6l 74 kW AFT 4 Zyl.	
Knock sensor	12.95-10.99	0 261 231 036
Temperature sensor, intake air, injection system	12.95-10.99	0 280 130 039
1.6 [6K1]	1,6l 74 kW AKL 4 Zyl.	
Phase sensor	05.99-05.02	0 232 101 031
	WW	0 232 101 038
Speed sensor, ignition/injection	05.99-05.02	0 261 210 147
1.6 [6K1]	1,6l 74 kW APF 4 Zyl.	
Phase sensor	09.99-10.00	0 232 101 031
Speed sensor, ignition/injection	09.99-10.00	0 261 210 199
1.6 [6K1]	1,6l 74 kW AUR 4 Zyl.	
Phase sensor	07.00-05.02	0 232 101 031
	WW	0 232 101 038
Speed sensor, ignition/injection	07.00-05.02	0 261 210 199
1.6 [6L1]	1,6l 74 kW BAH 4 Zyl.	
Knock sensor	04.03→	0 261 231 146
Pressure sensor, intake manifold, gasoline	04.03→	0 261 230 095
Accelerator pedal module	04.03→	AG,RLE 0 280 752 220
	GS,LLE	0 280 752 214
Duo sensor, acceleration and yaw rate, brake system		
Fg.no. →6L..4..232 600	04.03-04.04	0 265 005 252
Fg.no. 6L..4..232 601→	05.04→	0 265 005 601
1.6 [6L1]	1,6l 77 kW BTS 4 Zyl.	
Knock sensor	11.06→	0 261 231 146
Pressure sensor, intake manifold, gasoline	11.06→	0 261 230 095
Accelerator pedal module	11.06→	AG,RLE 0 280 752 220
	GS,LLE	0 280 752 214
Duo sensor, acceleration and yaw rate, brake system	11.06→	0 265 005 601
1.7 i [Y..]	1,7l 72-76 kW 4 Zyl.	
Throttle valve sensor	01.91-05.93	0 280 120 315
Temperature sensor, cylinder head	01.91-05.93	0 280 130 026
Relay, Jetronic	01.91-05.93	0 280 230 009
1.8 [6K1]	1,8l 95 kW ADL 4 Zyl.	
Knock sensor	09.93-06.96	0 261 231 077
1.8 T [6L1]	1,8l 110 kW BJX 4 Zyl.	
Throttle valve assembly	12.03→	0 280 750 115
Air mass meter, gasoline injection	12.03→	0 280 218 063
		0 986 280 217
Phase sensor	12.03→	0 232 101 024
Speed sensor, ignition/injection	12.03→	0 261 210 199
Knock sensor	12.03→	0 261 231 146
Boost pressure sensor, gasoline	12.03→	0 281 002 399
Accelerator pedal module	12.03→	AG,RLE 0 280 752 220
	GS,LLE	0 280 752 214
Duo sensor, acceleration and yaw rate, brake system		
Fg.no. →6L..4..232 600	12.03-04.04	0 265 005 252
Fg.no. 6L..4..232 601→	05.04→	0 265 005 601
1.8 T [6L1]	1,8l 110 kW BKV 4 Zyl.	
Throttle valve assembly	12.03→	0 280 750 115
Air mass meter, gasoline injection	12.03→	0 280 218 063
		0 986 280 217
Phase sensor	12.03→	0 232 101 024
Speed sensor, ignition/injection	12.03→	0 261 210 199
Knock sensor	12.03→	0 261 231 146
Accelerator pedal module	12.03→	AG,RLE 0 280 752 220
	GS,LLE	0 280 752 214
Duo sensor, acceleration and yaw rate, brake system		
Fg.no. →6L..4..232 600	12.03-04.04	0 265 005 252
Fg.no. 6L..4..232 601→	05.04→	0 265 005 601



1.8 T Cupra [6K1]	1,8l 115 kW AQX; AYP 4 Zyl.	
Throttle valve assembly	10.99-05.02	0 280 750 115
Air mass meter, gasoline injection	10.99-05.02	0 280 218 032
		0 986 280 210
Phase sensor	10.99-05.02	0 232 101 024
Speed sensor, ignition/injection	10.99-05.02	0 261 210 147
Temperature sensor, intake air, injection system	10.99-05.02	0 280 130 085
Pedal position sensor, EMS (electronic engine management)	10.99-05.02	0 280 752 012
1.8 T Cupra R [6L1]	1,8l 132 kW BBU; BLZ 4 Zyl.	
Throttle valve assembly	05.04→	0 280 750 115
Air mass meter, gasoline injection	05.04→	0 280 218 063
		0 986 280 217
Phase sensor	05.04→	0 232 101 024
Speed sensor, ignition/injection	05.04→	0 261 210 199
Knock sensor	05.04→	0 261 231 146
Boost pressure sensor, gasoline	05.04→	0 281 002 399
Accelerator pedal module		
Fg.no. →6L..7..029 300	05.04-06.06	LLE 0 280 752 214
Duo sensor, acceleration and yaw rate, brake system	05.04→	0 265 005 601
1.9 SDI [6K1]	1,9l 47 kW AEY 4 Zyl.	
Pedal position sensor, diesel	12.95-10.99	0 205 001 032
1.9 SDI [6L1]	1,9l 47 kW ASY 4 Zyl.	
Duo sensor, acceleration and yaw rate, brake system		
Fg.no. →6L..4..232 600	01.02-04.04	0 265 005 252
Fg.no. 6L..4..232 601→	05.04-12.05	0 265 005 601
1.9 TDI [6K1]	1,9l 66 kW AGR 4 Zyl.	
Air mass meter, diesel	05.99-05.02	0 281 002 216
		0 986 284 001
Boost pressure sensor, Diesel	05.99-05.02	0 281 002 177
1.9 TDI [6K1]	1,9l 66 kW AHU 4 Zyl.	
Pressure sensor, intake manifold, diesel	12.96-06.99	0 261 230 037
Pedal position sensor, diesel	12.96-06.99	0 205 001 032
1.9 TDI [6K1]	1,9l 66 kW ALH 4 Zyl.	
Air mass meter, diesel	05.99-05.02	0 281 002 216
		0 986 284 001
Boost pressure sensor, Diesel	05.99-05.02	0 281 002 177
1.9 TDI [6K1]	1,9l 66 kW 1Z 4 Zyl.	
Pressure sensor, intake manifold, diesel	07.96-12.96	0 261 230 037
Pedal position sensor, diesel	07.96-12.96	0 205 001 032
1.9 TDI [6K1]	1,9l 81 kW AFN 4 Zyl.	
Pressure sensor, intake manifold, diesel	03.97-06.99	0 261 230 037
Pedal position sensor, diesel	03.97-06.99	0 205 001 032
1.9 TDI [6K1]	1,9l 81 kW ASV 4 Zyl.	
Air mass meter, diesel	05.99-05.02	0 281 002 216
		0 986 284 001
Boost pressure sensor, Diesel	05.99-05.02	0 281 002 177
1.9 TDI [6L1]	1,9l 74 kW ATD 4 Zyl.	
Air mass meter, diesel		
Fg.no. →6L..2..050 000	09.01-03.02	0 281 002 757
	WW	0 280 217 121
		0 986 280 202
Fg.no. 6L..2..050 001→	04.02→	0 281 002 531
		0 986 284 009
Boost pressure sensor, Diesel	09.01→	0 281 002 399
Duo sensor, acceleration and yaw rate, brake system		
Fg.no. →6L..4..232 600	09.01-04.04	0 265 005 252
Fg.no. 6L..4..232 601→	05.04→	0 265 005 601





Product				

◀ Ibiza

1.9 TDI [6L1] 1,9l 74 kW AXR; BMT 4 Zyl.			
Air mass meter, diesel	05.05→	0 281 002 531	0 986 284 009
Boost pressure sensor, Diesel	05.05→	0 281 002 399	
Duo sensor, acceleration and yaw rate, brake system	05.05→	0 265 005 601	
1.9 TDI [6L1] 1,9l 96 kW ASZ 4 Zyl.			
Air mass meter, diesel	11.01→	0 281 002 461	0 986 284 007
Boost pressure sensor, Diesel	11.01→	0 281 002 401	
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →6L..4..232 600	11.01-04.04	0 265 005 252	
Fg.no. 6L..4..232 601→	05.04→	0 265 005 601	
1.9 TDI [6L1] 1,9l 96/118 kW BLT; BUK 4 Zyl.			
Air mass meter, diesel	05.05→	0 281 002 461	0 986 284 007
Boost pressure sensor, Diesel	05.05→	0 281 002 401	
Duo sensor, acceleration and yaw rate, brake system	05.05→	0 265 005 601	
1.9 TDI Cupra R [6L1] 1,9l 118 kW BPX 4 Zyl.			
Air mass meter, diesel	03.04→	0 281 002 461	0 986 284 007
Boost pressure sensor, Diesel	03.04→	0 281 002 401	
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →6L..4..232 600	03.04-04.04	0 265 005 252	
Fg.no. 6L..4..232 601→	05.04→	0 265 005 601	
2.0 [6K1] 2,0l 85 kW AGG 4 Zyl.			
Knock sensor	04.96-10.99	0 261 231 077	
2.0 [6K1] 2,0l 85 kW 2E 4 Zyl.			
Speed sensor, ignition/injection	03.93-04.96	0 356 914 213	
Knock sensor	03.93-04.96	0 261 231 077	
2.0 [6K1] 2,0l 110 kW ABF 4 Zyl.			
Knock sensor	06.96-10.99	0 261 231 077	
2.0 [6L1] 2,0l 85 kW AZL 4 Zyl.			
Throttle valve assembly			
Fg.no. →6L..4..184 000	07.02-02.04	0 280 750 061	
Air mass meter, gasoline injection	07.02-04.04	0 280 218 060	0 986 280 216
Phase sensor	07.02-04.04	0 232 101 031	
Speed sensor, ignition/injection	07.02-04.04	0 261 210 199	
Knock sensor	07.02-04.04	0 261 231 146	
Accelerator pedal module	07.02-04.04	AG,RLE 0 280 752 220	GS,LLE 0 280 752 214
Duo sensor, acceleration and yaw rate, brake system	07.02-04.04	0 265 005 252	
2.0 [6L1] 2,0l 85 kW BBX 4 Zyl.			
Throttle valve assembly			
Fg.no. →6L..4..184 000	04.03-02.04	0 280 750 061	
Air mass meter, gasoline injection	04.03→	0 280 218 060	0 986 280 216
Phase sensor	04.03→	0 232 101 031	
Speed sensor, ignition/injection	04.03→	0 261 210 199	
Knock sensor	04.03→	0 261 231 146	
Pressure sensor, intake manifold, gasoline	04.03→	0 261 230 095	
Accelerator pedal module	04.03→	AG,RLE 0 280 752 220	GS,LLE 0 280 752 214
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →6L..4..232 600	04.03-04.04	0 265 005 252	
Fg.no. 6L..4..232 601→	05.04→	0 265 005 601	

Product				

Inca

1.4 [6K9] 1,4l 44 kW AEX; AKV; APQ 4 Zyl.			
Knock sensor	11.95-06.03	0 261 231 045	
Pressure sensor, intake manifold, gasoline	11.95-06.03	0 261 230 011	
1.4 [6K9] 1,4l 44 kW AUD 4 Zyl.			
Throttle valve assembly			
Mot.no. →020 027	09.00-06.03	0 280 750 049	
Mot.no. 020 028→	09.00-06.03	0 280 750 095	
Speed sensor, ignition/injection	09.00-06.03	0 261 210 188	
Knock sensor	09.00-06.03	0 261 231 045	
Pressure sensor, intake manifold, gasoline	09.00-06.03	TW 0 261 230 011	0 261 230 031
1.4 [6K9] 1,4l 55 kW AUA 4 Zyl.			
Knock sensor	09.00-06.03	0 261 231 045	
Pressure sensor, intake manifold, gasoline	09.00-06.03	TW 0 261 230 011	
1.6 [6K9] 1,6l 55 kW AEE 4 Zyl.			
Knock sensor	06.97-09.00	0 261 231 045	
1.6 EFI 1,6l 66 kW MY4 4 Zyl.			
Pressure sensor, intake manifold, gasoline	11.98→	0 261 230 095	

Leon

1.4 [1M1] 1,4l 55 kW AHW 4 Zyl.			
Knock sensor	12.99-05.02	0 261 231 146	
Accelerator pedal module	12.99-05.02	AG,RLE 0 280 752 213	GS,LLE 0 280 752 214
		GS,RLE 0 280 752 210	
1.4 [1M1] 1,4l 55 kW APE 4 Zyl.			
Phase sensor	12.99-05.00	0 232 101 031	
Knock sensor	12.99-05.00	0 261 231 146	
Pressure sensor, intake manifold, gasoline	12.99-05.00	0 261 230 031	
Accelerator pedal module	12.99-05.00	AG,RLE 0 280 752 213	GS,LLE 0 280 752 214
		GS,RLE 0 280 752 210	
1.4 [1M1] 1,4l 55 kW AXP; BCA 4 Zyl.			
Knock sensor	06.00-04.04	0 261 231 146	
Pressure sensor, intake manifold, gasoline	06.00-04.04	0 261 230 031	
Accelerator pedal module	06.00-04.04	AG,RLE 0 280 752 213	GS,LLE 0 280 752 214
		GS,RLE 0 280 752 210	
1.4 [1P1] 1,4l 63 kW BXW 4 Zyl.			
Knock sensor	06.06→	0 261 231 146	
Pressure sensor, intake manifold, gasoline	06.06→	0 261 230 095	
1.6 [1M1] 1,6l 74 kW AEH; AKL 4 Zyl.			
Phase sensor	10.98-07.04	0 232 101 031	
Speed sensor, ignition/injection	10.98-07.04	0 261 210 147	
Accelerator pedal module	10.98-07.04	AG,RLE 0 280 752 213	GS,LLE 0 280 752 214
Fg.no. 1M..Y..000 001→	05.99-07.04	GS,RLE 0 280 752 210	
1.6 [1M1] 1,6l 75 kW BFQ 4 Zyl.			
Speed sensor, ignition/injection	10.05→	0 261 210 199	
Knock sensor	10.05→	0 261 231 146	
Accelerator pedal module	10.05→	AG,RLE 0 280 752 213	GS,LLE 0 280 752 214
		GS,RLE 0 280 752 210	
1.6 [1M1] 1,6l 77 kW AUS 4 Zyl.			
Speed sensor, ignition/injection			
Fg.no. →1M..1..033 000	06.00-09.00	0 261 210 194	
Knock sensor			
Fg.no. →1M..1..026 000	06.00-08.00	0 261 231 045	
Fg.no. 1M..1..026 001→	09.00-04.01	0 261 231 146	



Accelerator pedal module	06.00-04.01	AG,RLE	0 280 752 213
		GS,LLE	0 280 752 214
		GS,RLE	0 280 752 210
1.6 [1M1]			1,6l 77 kW AZD 4 Zyl.
Speed sensor, ignition/injection			
Fg.no. →1M..1..033 000	09.00-09.00		0 261 210 194
Knock sensor	09.00-04.02		0 261 231 146
Pressure sensor, intake manifold, gasoline	09.00-04.02		0 261 230 031
Accelerator pedal module	09.00-04.02	AG,RLE	0 280 752 213
		GS,LLE	0 280 752 214
		GS,RLE	0 280 752 210
1.6 [1M1]			1,6l 77 kW BCB 4 Zyl.
Knock sensor	04.02→		0 261 231 146
Accelerator pedal module	04.02→	AG,RLE	0 280 752 213
		GS,LLE	0 280 752 214
		GS,RLE	0 280 752 210
1.6 [1P1]			1,6l 75 kW BSE,BSF 4 Zyl.
Speed sensor, ignition/injection	07.05→		0 261 210 199
Knock sensor	07.05→		0 261 231 146
Pressure sensor, intake manifold, gasoline	07.05→		0 261 230 031
1.8 [1M1]			1,8l 92 kW AGN 4 Zyl.
Air mass meter, gasoline injection	10.98-12.03		0 280 218 002
			0 986 280 205
Phase sensor	10.98-12.03		0 232 101 024
Speed sensor, ignition/injection	10.98-12.03		0 261 210 147
Knock sensor			
Fg.no. →1M..X..025 000	10.98-04.99	KZA	0 261 231 075
Accelerator pedal module	10.98-12.03	AG,RLE	0 280 752 213
		GS,LLE	0 280 752 214
Fg.no. 1M..Y..000 001→	05.99-12.03	GS,RLE	0 280 752 210
1.8 [1M1]			1,8l 92 kW APG 4 Zyl.
Throttle valve assembly	12.99-07.04		0 280 750 026
Air mass meter, gasoline injection	12.99-07.04		0 280 218 060
			0 986 280 216
Phase sensor	12.99-07.04		0 232 101 024
Speed sensor, ignition/injection	12.99-07.04		0 261 210 147
Accelerator pedal module	12.99-07.04	AG,RLE	0 280 752 213
		GS,LLE	0 280 752 214
		GS,RLE	0 280 752 210
1.8 FSI [1P1]			1,8l 118 kW BZB 4 Zyl.
Boost pressure sensor, gasoline	06.07→		0 261 230 073
1.8 T [1M1]			1,8l 132 kW APP 4 Zyl.
Throttle valve assembly	12.99-12.00		0 280 750 036
Air mass meter, gasoline injection			
Fg.no. →1M..1B023 000,→1M..1R028 000	12.99-07.00		0 280 218 032
			0 986 280 210
Fg.no. 1M..1B023 001→,1M..1R028 001→	08.00-12.00		0 280 218 063
			0 986 280 217
Phase sensor	12.99-12.00		0 232 101 024
Speed sensor, ignition/injection	12.99-12.00		0 261 210 147
Boost pressure sensor, gasoline	12.99-12.00		0 281 002 177
Temperature sensor, intake air, injection system	12.99-12.00		0 280 130 085
Accelerator pedal module	12.99-12.00	AG,RLE	0 280 752 213
		GS,LLE	0 280 752 214
		GS,RLE	0 280 752 210
1.8 T [1M1]			1,8l 132 kW ARY; AUQ 4 Zyl.
Throttle valve assembly	09.00-04.04		0 280 750 036
Air mass meter, gasoline injection	09.00-04.04		0 280 218 063
			0 986 280 217
Phase sensor	09.00-04.04		0 232 101 024
Speed sensor, ignition/injection	09.00-04.04		0 261 210 199
Knock sensor	09.00-04.04	KZA	0 261 231 146



Boost pressure sensor, gasoline			
Fg.no. →1M..3..112 874	09.00-02.03		0 281 002 177
Fg.no. 1M..3..112 875→	03.03-04.04		0 281 002 399
Temperature sensor, intake air, injection system	09.00-04.04		0 280 130 085
Accelerator pedal module	09.00-04.04	AG,RLE	0 280 752 213
		GS,LLE	0 280 752 214
		GS,RLE	0 280 752 210
1.8 T Cupra R [1M1]			1,8l 154/165 kW AMK; BAM 4 Zyl.
Throttle valve assembly	05.02→		0 280 750 036
Air mass meter, gasoline injection	05.02→		0 280 218 065
			0 986 280 218
Phase sensor	05.02→		0 232 101 024
Speed sensor, ignition/injection	05.02→		0 261 210 178
Knock sensor	05.02→		0 261 231 146
Boost pressure sensor, gasoline	05.02→		0 261 230 073
Temperature sensor, intake air, injection system	05.02→		0 280 130 085
Accelerator pedal module	05.02→	AG,RLE	0 280 752 213
		GS,LLE	0 280 752 214
		GS,RLE	0 280 752 210
1.8 T Syncro [1M1]			1,8l 132 kW AJQ 4 Zyl.
Throttle valve assembly	03.00-01.01		0 280 750 036
Air mass meter, gasoline injection	03.00-01.01		0 280 218 032
			0 986 280 210
Speed sensor, ignition/injection	03.00-01.01		0 261 210 147
Boost pressure sensor, gasoline	03.00-01.01		0 281 002 177
Temperature sensor, intake air, injection system	03.00-01.01		0 280 130 085
Accelerator pedal module	03.00-01.01	AG,RLE	0 280 752 213
		GS,LLE	0 280 752 214
		GS,RLE	0 280 752 210
1.8 T Syncro [1M1]			1,8l 132 kW ARY 4 Zyl.
Throttle valve assembly	09.00-04.04		0 280 750 036
Air mass meter, gasoline injection	09.00-04.04		0 280 218 063
			0 986 280 217
Phase sensor	09.00-04.04		0 232 101 024
Speed sensor, ignition/injection	09.00-04.04		0 261 210 199
Knock sensor	09.00-04.04	KZA	0 261 231 146
Boost pressure sensor, gasoline			
Fg.no. →1M..3..112 874	09.00-02.03		0 281 002 177
Fg.no. 1M..3..112 875→	03.03-04.04		0 281 002 399
Temperature sensor, intake air, injection system	09.00-04.04		0 280 130 085
Accelerator pedal module	09.00-04.04	AG,RLE	0 280 752 213
		GS,LLE	0 280 752 214
		GS,RLE	0 280 752 210
1.9 TDI [1M1]			1,9l 66 kW AGR 4 Zyl.
Air mass meter, diesel	12.99-09.02		0 281 002 757
		WW	0 280 217 121
			0 986 280 202
Boost pressure sensor, Diesel	12.99-09.02		0 281 002 177
1.9 TDI [1M1]			1,9l 66 kW ALH 4 Zyl.
Air mass meter, diesel	03.99-07.04	EU2	0 281 002 757
		EU2,WW	0 280 217 121
			0 986 280 202
		EU3	0 281 002 531
			0 986 284 009
Boost pressure sensor, Diesel			
Fg.no. →1M..3..112 874	03.99-02.03		0 281 002 177
Fg.no. 1M..3..112 875→	03.03-07.04		0 281 002 399
1.9 TDI [1M1]			1,9l 74 kW AXR 4 Zyl.
Air mass meter, diesel	10.05→		0 281 002 531
			0 986 284 009
Boost pressure sensor, Diesel	10.05→		0 281 002 399

Product				
Leon				
1.9 TDI [1M1]	1,9l	81 kW	AHF	4 Zyl.
Air mass meter, diesel	04.99-09.02	WW	0 281 002 757	
			0 280 217 121	
			0 986 280 202	
Boost pressure sensor, Diesel	10.98-09.02		0 281 002 177	
1.9 TDI [1M1]	1,9l	81 kW	ASV	4 Zyl.
Air mass meter, diesel	10.99-07.04	EU2	0 281 002 757	
			0 280 217 121	
		EU2,WW	0 986 280 202	
			0 281 002 531	
			0 986 284 009	
Boost pressure sensor, Diesel				
Fg.no. →1M..3..112 874	10.99-02.03		0 281 002 177	
Fg.no. 1M..3..112 875→	03.03-07.04		0 281 002 399	
1.9 TDI [1M1]	1,9l	96 kW	ASZ	4 Zyl.
Air mass meter, diesel	05.03→		0 281 002 461	
			0 986 284 007	
Boost pressure sensor, Diesel	05.03→		0 281 002 401	
1.9 TDI [1P1]	1,9l	66 kW	BXF	4 Zyl.
Speed sensor, diesel	06.07→		0 261 210 233	
1.9 TDI [1P1]	1,9l	77 kW	BKC; BLS	4 Zyl.
Air mass meter, diesel	07.05→		0 281 002 531	
			0 986 284 009	
Speed sensor, diesel	07.05→	TW	0 261 210 233	
			0 261 210 233	
Boost pressure sensor, Diesel	07.05→		0 281 002 399	
1.9 TDI [1P1]	1,9l	77 kW	BXE	4 Zyl.
Speed sensor, diesel	02.06→		0 261 210 233	
1.9 TDI Cupra, Cupra Syncro [1M1]	1,9l	110 kW	ARL	4 Zyl.
Air mass meter, diesel	09.00-05.02		0 280 217 529	
			0 986 280 204	
Fg.no. 1M..3..011 801→	06.02-07.04		0 281 002 461	
			0 986 284 007	
Boost pressure sensor, Diesel	09.00-07.04		0 281 002 401	
2.0 FSI [1P1]	2,0l	110 kW	BLR; BLY; BVY; BVZ	4 Zyl.
Knock sensor	07.05→	TW	0 261 231 146	
Pressure sensor, intake manifold, gasoline	07.05→		0 261 230 031	
2.0 TDI [1P1]	2,0l	100/103 kW	AZV; BKD; BMM	4 Zyl.
Air mass meter, diesel	07.05→		0 281 002 461	
			0 986 284 007	
Boost pressure sensor, Diesel	07.05→		0 281 002 401	
2.0 TFSI [1P1]	2,0l	136-147 kW	BWA	4 Zyl.
Speed sensor, ignition/injection	11.05→		0 261 210 199	
Boost pressure sensor, gasoline	11.05→		0 261 230 073	
2.0 TFSI [1P1]	2,0l	177 kW	BWJ	4 Zyl.
Speed sensor, ignition/injection	11.06→		0 261 210 199	
2.8 [1M1]	2,8l	150 kW	AUE	6 Zyl.
Throttle valve assembly	10.00-07.01		0 280 750 097	
Air mass meter, gasoline injection	10.00-07.01		0 280 218 017	
			0 986 280 208	
Phase sensor	10.00-07.01		0 232 103 019	
Knock sensor	10.00-07.01	TW	0 261 231 146	
Accelerator pedal module	10.00-07.01	AG,RLE	0 280 752 213	
		GS,LLE	0 280 752 214	
		GS,RLE	0 280 752 210	
2.8 [1M1]	2,8l	150 kW	BDE	6 Zyl.
Throttle valve assembly	05.02-04.04		0 280 750 097	
Air mass meter, gasoline injection	05.02-04.04		0 280 218 017	
			0 986 280 208	
Phase sensor	05.02-04.04		0 232 103 019	
Knock sensor	05.02-04.04	TW	0 261 231 146	

Product				
Accelerator pedal module	05.02-04.04	AG,RLE	0 280 752 213	
		GS,LLE	0 280 752 214	
		GS,RLE	0 280 752 210	
2.8 Cupra Syncro [1M1]	2,8l	150 kW	AUE; BDE	6 Zyl.
Throttle valve assembly	10.00-04.04		0 280 750 097	
Air mass meter, gasoline injection	10.00-04.04		0 280 218 017	
			 0 986 280 208	
Phase sensor	10.00-04.04		0 232 103 019	
Knock sensor	10.00-04.04	TW	0 261 231 146	
Accelerator pedal module	10.00-04.04	AG,RLE	0 280 752 213	
		GS,LLE	0 280 752 214	
		GS,RLE	0 280 752 210	
Malaga				
1.2 i		1,2l	51 kW	4 Zyl.
Throttle valve sensor	12.89-12.93		0 280 120 315	
Air flow sensor, gasoline injection	12.89-12.93		0 280 200 052	
			 0 986 280 058	
Temperature sensor, cylinder head	12.89-12.93		0 280 130 026	
Relay, Jetronic	12.89-12.93		0 280 230 009	
1.5 i		1,5l	66/70 kW	; 021 A 2000 4 Zyl.
Throttle valve sensor	10.86-12.93		0 280 120 315	
Air flow sensor, gasoline injection	10.86-12.93		0 280 200 050	
Temperature sensor, cylinder head	10.86-12.93		0 280 130 026	
Relay, Jetronic	10.86-12.93		0 280 230 009	
1.7 i		1,7l	77 kW	4 Zyl.
Throttle valve sensor	01.91-12.93		0 280 120 315	
Temperature sensor, cylinder head	01.91-12.93		0 280 130 026	
Relay, Jetronic	01.91-12.93		0 280 230 009	
Toledo				
1.4 [1M2]		1,4l	55 kW	AHW 4 Zyl.
Knock sensor	07.99-05.02		0 261 231 146	
Accelerator pedal module	07.99-05.02	AG,RLE	0 280 752 213	
		GS,LLE	0 280 752 214	
		GS,RLE	0 280 752 210	
1.4 [1M2]		1,4l	55 kW	AXP 4 Zyl.
Knock sensor	06.00-02.02		0 261 231 146	
Pressure sensor, intake manifold, gasoline	06.00-02.02		0 261 230 031	
Accelerator pedal module	06.00-02.02	AG,RLE	0 280 752 213	
		GS,LLE	0 280 752 214	
		GS,RLE	0 280 752 210	
1.4 [5P2]		1,4l	63 kW	BXW 4 Zyl.
Knock sensor	05.06-06.07		0 261 231 146	
Pressure sensor, intake manifold, gasoline	05.06-06.07		0 261 230 095	
1.6 [1L2]		1,6l	55 kW	ABN; EZ; 1F 4 Zyl.
Knock sensor	05.91-03.99		0 261 231 036	
1.6 [1L2]		1,6l	74 kW	AFT 4 Zyl.
Knock sensor	11.96-03.99		0 261 231 036	
Temperature sensor, intake air, injection system	11.96-03.99	HDK	0 280 130 039	
1.6 [1M2]		1,6l	74 kW	AEH; AKL 4 Zyl.
Phase sensor	04.99-05.02		0 232 101 031	
Speed sensor, ignition/injection	04.99-05.02		0 261 210 147	
Accelerator pedal module	04.99-05.02	AG,RLE	0 280 752 213	
		GS,LLE	0 280 752 214	
Fg.no. 1M..Y..000 001→	05.99-05.02	GS,RLE	0 280 752 210	
1.6 [1M2]		1,6l	77 kW	AUS 4 Zyl.
Speed sensor, ignition/injection				
Fg.no. →1M..1..033 000	06.00-09.00		0 261 210 194	






Knock sensor			
Fg.no. →1M..1..026 000	06.00-08.00		0 261 231 045
Fg.no. 1M..1..026 001→	09.00-04.01		0 261 231 146
Accelerator pedal module	06.00-04.01	AG,RLE	0 280 752 213
		GS,LLE	0 280 752 214
		GS,RLE	0 280 752 210
1.6 [1M2]	1,6l 77 kW	AZD 4 Zyl.	
Speed sensor, ignition/injection			
Fg.no. →1M..1..033 000	09.00-09.00		0 261 210 194
Knock sensor	09.00-04.02		0 261 231 146
Pressure sensor, intake manifold, gasoline	09.00-04.02		0 261 230 031
Accelerator pedal module	09.00-04.02	AG,RLE	0 280 752 213
		GS,LLE	0 280 752 214
		GS,RLE	0 280 752 210
1.6 [1M2]	1,6l 77 kW	BCB 4 Zyl.	
Knock sensor	04.02-07.04		0 261 231 146
Accelerator pedal module	04.02-07.04	AG,RLE	0 280 752 213
		GS,LLE	0 280 752 214
		GS,RLE	0 280 752 210
1.6 [5P2]	1,6l 75 kW	BGU; BSE; BSF 4 Zyl.	
Speed sensor, ignition/injection	09.04→		0 261 210 199
Knock sensor	09.04→		0 261 231 146
Pressure sensor, intake manifold, gasoline	09.04→		0 261 230 031
1.8 [1L2]	1,8l 66 kW	RP 4 Zyl.	
Knock sensor	05.91-11.93		0 261 231 036
1.8 [1L2]	1,8l 95 kW	PL 4 Zyl.	
Air flow sensor, gasoline injection	05.91-03.94		F 026 TX2 063
			☛ F 026 TX2 063
Knock sensor	05.91-03.94		0 261 231 036
1.8 [1L2]	1,8l 98-102 kW	KR 4 Zyl.	
Air flow sensor, gasoline injection	05.91-11.92		F 026 TX2 050
			☛ F 026 TX2 050
Knock sensor	05.91-11.92		0 261 231 036
1.8 [1M2]	1,8l 92 kW	AGN 4 Zyl.	
Air mass meter, gasoline injection	04.99-12.03		0 280 218 002
			☛ 0 986 280 205
Phase sensor	04.99-12.03		0 232 101 024
Speed sensor, ignition/injection	04.99-12.03		0 261 210 147
Knock sensor			
Fg.no. →1M..X..025 000	04.99-04.99		0 261 231 075
Accelerator pedal module	04.99-12.03	AG,RLE	0 280 752 213
		GS,LLE	0 280 752 214
Fg.no. 1M..Y..000 001→	05.99-12.03	GS,RLE	0 280 752 210
1.8 [1M2]	1,8l 92 kW	APG 4 Zyl.	
Throttle valve assembly	05.99-05.02		0 280 750 026
Air mass meter, gasoline injection	05.99-05.02		0 280 218 060
			☛ 0 986 280 216
Phase sensor	05.99-05.02		0 232 101 024
Speed sensor, ignition/injection	05.99-05.02		0 261 210 147
Accelerator pedal module	05.99-05.02	AG,RLE	0 280 752 213
		GS,LLE	0 280 752 214
		GS,RLE	0 280 752 210
1.8 FSI [5P2]	1,8l 118 kW	BZB 4 Zyl.	
Boost pressure sensor, gasoline	06.07→		0 261 230 073
1.8 T [1M2]	1,8l 132 kW	AUQ 4 Zyl.	
Throttle valve assembly	09.00-05.02		0 280 750 036
Air mass meter, gasoline injection	09.00-05.02		0 280 218 063
			☛ 0 986 280 217
Phase sensor	09.00-05.02		0 232 101 024
Speed sensor, ignition/injection	09.00-05.02		0 261 210 199
Knock sensor	09.00-05.02	KZA	0 261 231 146
Boost pressure sensor, gasoline	09.00-05.02		0 281 002 177
Temperature sensor, intake air, injection system	09.00-05.02		0 280 130 085



Accelerator pedal module	09.00-05.02	AG,RLE	0 280 752 213
		GS,LLE	0 280 752 214
		GS,RLE	0 280 752 210
1.9 TDI [1L2]	1,9l 66/81 kW	AFN; AHU; 1Z 4 Zyl.	
Pressure sensor, intake manifold, diesel	04.95-03.99		0 261 230 037
Pedal position sensor, diesel	04.95-03.99		0 205 001 032
1.9 TDI [1M2]	1,9l 66 kW	AGR 4 Zyl.	
Air mass meter, diesel	04.99-09.02		0 281 002 757
		WW	0 280 217 121
			☛ 0 986 280 202
Boost pressure sensor, Diesel	04.99-09.02		0 281 002 177
1.9 TDI [1M2]	1,9l 66 kW	ALH 4 Zyl.	
Air mass meter, dieselPR no. OGD,PR no. OGE	04.99-07.04	OOB	0 281 002 757
		OOB,WW	0 280 217 121
			☛ 0 986 280 202
PR no. OGZ	04.99-07.04	OBD	0 281 002 531
			☛ 0 986 284 009
Boost pressure sensor, Diesel			
Fg.no. →1M..3..112 874	04.99-02.03		0 281 002 177
Fg.no. 1M..3..112 875→	03.03-07.04		0 281 002 399
1.9 TDI [1M2]	1,9l 81 kW	AHF 4 Zyl.	
Air mass meter, diesel	04.99-09.02		0 281 002 757
		WW	0 280 217 121
			☛ 0 986 280 202
Boost pressure sensor, Diesel	04.99-09.02		0 281 002 177
1.9 TDI [1M2]	1,9l 81 kW	ASV 4 Zyl.	
Air mass meter, dieselPR no. OGD,PR no. OGE	05.99-12.03	OOB	0 281 002 757
		OOB,WW	0 280 217 121
			☛ 0 986 280 202
PR no. OGZ	05.99-12.03	OBD	0 281 002 531
			☛ 0 986 284 009
Boost pressure sensor, Diesel			
Fg.no. →1M..3..112 874	05.99-02.03		0 281 002 177
Fg.no. 1M..3..112 875→	03.03-12.03		0 281 002 399
1.9 TDI [1M2]	1,9l 96 kW	ASZ 4 Zyl.	
Air mass meter, diesel	05.03-07.04		0 281 002 461
			☛ 0 986 284 007
Boost pressure sensor, Diesel	05.03-07.04		0 281 002 401
1.9 TDI [1M2]	1,9l 110 kW	ARL 4 Zyl.	
Air mass meter, diesel	09.00-05.02		0 280 217 529
			☛ 0 986 280 204
Boost pressure sensor, Diesel	09.00-05.02		0 281 002 394
1.9 TDI [5P2]	1,9l 77 kW	BJB; BKC 4 Zyl.	
Air mass meter, diesel	09.04-02.06		0 281 002 531
			☛ 0 986 284 009
Speed sensor, diesel	09.04-02.06	TW	0 261 210 233
Boost pressure sensor, Diesel	09.04-02.06		0 281 002 399
1.9 TDI [5P2]	1,9l 77 kW	BLS 4 Zyl.	
Air mass meter, diesel	10.05→		0 281 002 531
			☛ 0 986 284 009
Speed sensor, diesel	10.05→	TW	0 261 210 233
Boost pressure sensor, Diesel	10.05→		0 281 002 401
1.9 TDI [5P2]	1,9l 77 kW	BXE 4 Zyl.	
Air mass meter, diesel	02.06→		0 281 002 531
			☛ 0 986 284 009
Speed sensor, diesel	02.06→	TW	0 261 210 233
Boost pressure sensor, Diesel	02.06→		0 281 002 399
2.0 [1L2]	2,0l 85 kW	AGG 4 Zyl.	
Knock sensor	03.96-03.99		0 261 231 077
2.0 [1L2]	2,0l 85 kW	2E 4 Zyl.	
Speed sensor, ignition/injection	05.91-06.96		0 356 914 213
Knock sensor	05.91-06.96		0 261 231 077





Product



◀ Toledo

2.0 [1L2]		2,0l 110 kW ABF 4 Zyl.	
Knock sensor	03.94-03.99	0 261 231 077	
2.0 FSI [5P2]		2,0l 110 kW BLR; BLY; BVY; BVZ 4 Zyl.	
Pressure sensor, intake manifold, gasoline	09.04→	0 261 230 031	
2.0 TDI [5P2]		2,0l 100/103/125 kW AZV; BKD; BMM; BMN 4 Zyl.	
Air mass meter, diesel	09.04→	0 281 002 461	
		0 986 284 007	
Boost pressure sensor, Diesel	09.04→	0 281 002 401	
2.0 TFSI [5P2]		2,0l 147 kW BWA 4 Zyl.	
Boost pressure sensor, gasoline	11.05→	0 261 230 073	
2.3 [1M2]		2,3l 110 kW AGZ 5 Zyl.	
Air mass meter, gasoline injection	04.99-11.00	0 280 217 529	
		0 986 280 204	
Phase sensor	04.99-11.00	0 232 103 019	
Speed sensor, ignition/injection	04.99-11.00	0 261 210 177	
Knock sensor	04.99-11.00	0 261 231 146	
Temperature sensor, intake air, injection system	04.99-11.00	0 280 130 085	
Accelerator pedal module	04.99-11.00	AG,RLE	0 280 752 213
		GS,LLE	0 280 752 214
	Fg.no. 1M..Y..000 001→	GS,RLE	0 280 752 210
2.3 [1M2]		2,3l 125 kW AQN 5 Zyl.	
Throttle valve assembly	09.00-11.03	0 280 750 097	
Air mass meter, gasoline injection	09.00-11.03	0 280 218 017	
		0 986 280 208	
Phase sensor	09.00-11.03	0 232 103 019	
Knock sensor	09.00-11.03	OHL	0 261 231 146
Accelerator pedal module	09.00-11.03	AG,RLE	0 280 752 213
		GS,LLE	0 280 752 214
		GS,RLE	0 280 752 210

SKODA

Fabia

1.2 [6Y3]		1,2l 40 kW AWY 3 Zyl.	
Knock sensor	08.02-05.04	0 261 231 146	
Accelerator pedal module	08.02-05.04	AG,RLE	0 280 752 220
		GS,LLE	0 280 752 214
Duo sensor, acceleration and yaw rate, brake system			
	Fg.no. →6Y..4..115 000	08.02-04.04	0 265 005 252
	Fg.no. 6Y..4..115 001→	05.04-05.04	0 265 005 692
1.2 [6Y3]		1,2l 47 kW AZQ 3 Zyl.	
Pressure sensor, intake manifold, gasoline	02.03-11.04	0 261 230 031	
Accelerator pedal module	02.03-11.04	AG,RLE	0 280 752 220
		GS,LLE	0 280 752 214
Duo sensor, acceleration and yaw rate, brake system			
	Fg.no. →6Y..4..115 000	02.03-04.04	0 265 005 252
	Fg.no. 6Y..4..115 001→	05.04-11.04	0 265 005 692
1.4 [6Y3]		1,4l 44/50 kW AME; AQW; AZE; AZF 4 Zyl.	
Accelerator pedal module	09.99-05.03	AG,RLE	0 280 752 220
		GS,LLE	0 280 752 214
Duo sensor, acceleration and yaw rate, brake system			
	09.99-05.03	0 265 005 252	
1.4 [6Y3]		1,4l 55 kW AUA 4 Zyl.	
Knock sensor	09.99-08.03	0 261 231 146	
Accelerator pedal module	09.99-08.03	AG,RLE	0 280 752 220
		GS,LLE	0 280 752 214
Duo sensor, acceleration and yaw rate, brake system			
	09.99-08.03	0 265 005 252	

Product



1.4 [6Y3]		1,4l 55 kW BBY 4 Zyl.	
Speed sensor, ignition/injection			
Fg.no. 6Y..3..712 485→	12.02-05.04	GS	0 261 210 257
Knock sensor	09.00-05.04		0 261 231 146
Pressure sensor, intake manifold, gasoline			
Fg.no. 6Y..4..893 313→	09.03-05.04		0 261 230 095
Accelerator pedal module	09.00-05.04	AG,RLE	0 280 752 220
		GS,LLE	0 280 752 214
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →6Y..4..115 000	09.00-04.04		0 265 005 252
Fg.no. 6Y..4..115 001→	05.04-05.04		0 265 005 692
1.4 [6Y3]		1,4l 55 kW BKY 4 Zyl.	
Knock sensor	05.04-12.07		0 261 231 146
Pressure sensor, intake manifold, gasoline	05.04-12.07		0 261 230 095
Accelerator pedal module	05.04-12.07	AG,RLE	0 280 752 220
		GS,LLE	0 280 752 214
Duo sensor, acceleration and yaw rate, brake system	05.04-12.07		0 265 005 692
1.4 [6Y3]		1,4l 74 kW AUB 4 Zyl.	
Knock sensor	09.99-08.03		0 261 231 146
Accelerator pedal module	09.99-08.03	AG,RLE	0 280 752 220
		GS,LLE	0 280 752 214
Duo sensor, acceleration and yaw rate, brake system	09.99-08.03		0 265 005 252
1.4 [6Y3]		1,4l 74 kW BBZ 4 Zyl.	
Knock sensor	09.00-12.07		0 261 231 146
Accelerator pedal module	09.00-12.07	AG,RLE	0 280 752 220
		GS,LLE	0 280 752 214
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →6Y..4..115 000	09.00-04.04		0 265 005 252
Fg.no. 6Y..4..115 001→	05.04-12.07		0 265 005 692
1.4 TDI [6Y3]		1,4l 51 kW BNM 3 Zyl.	
Air mass meter, diesel	10.05-12.07		0 281 002 531
			0 986 284 009
Boost pressure sensor, Diesel	10.05-12.07		0 281 002 399
Accelerator pedal module	10.05-12.07	GS,LLE	0 281 002 377
Duo sensor, acceleration and yaw rate, brake system	10.05-12.07		0 265 005 692
1.4 TDI [6Y3]		1,4l 55 kW AMF 3 Zyl.	
Air mass meter, diesel	05.03-10.05		0 281 002 531
			0 986 284 009
Boost pressure sensor, Diesel	05.03-10.05		0 281 002 399
Accelerator pedal module	05.03-10.05	GS,LLE	0 281 002 377
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →6Y..4..115 000	05.03-04.04		0 265 005 252
Fg.no. 6Y..4..115 001→	05.04-10.05		0 265 005 692
1.4 TDI [6Y3]		1,4l 59 kW BNV 3 Zyl.	
Air mass meter, diesel	10.05-12.07		0 281 002 531
			0 986 284 009
Boost pressure sensor, Diesel	10.05-12.07		0 281 002 399
Accelerator pedal module	10.05-12.07	GS,LLE	0 281 002 377
Duo sensor, acceleration and yaw rate, brake system	10.05-12.07		0 265 005 692
1.9 SDI [6Y3]		1,9l 47 kW ASY 4 Zyl.	
Accelerator pedal module	09.99-12.07	GS,LLE	0 281 002 377
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →6Y..4..115 000	09.99-04.04		0 265 005 252
Fg.no. 6Y..4..115 001→	05.04-12.07		0 265 005 692



Product



1.9 TDI [6Y3]		1,9l 74 kW ATD 4 Zyl.
Air mass meter, diesel		
Fg.no. →6Y..2..532 833,→6Y..2X040 209	09.99-04.02	0 281 002 757
	WW	0 280 217 121
		0 986 280 202
Fg.no. 6Y..2..532 834→,6Y..2X040 210→	05.02-10.05	0 281 002 531
		0 986 284 009
Boost pressure sensor, Diesel		
Fg.no. →6Y..4..115 000	09.99-04.04	0 281 002 177
Fg.no. 6Y..4..115 001→	05.04-10.05	0 281 002 399
Accelerator pedal module	09.99-10.05	GS,LLE 0 281 002 377
Duo sensor, acceleration and yaw rate, brake system		
Fg.no. →6Y..4..115 000	09.99-04.04	0 265 005 252
Fg.no. 6Y..4..115 001→	05.04-10.05	0 265 005 692
2.0 [6Y3]		2,0l 85 kW AZL 4 Zyl.
Throttle valve assembly		
Fg.no. →6Y..4..095 000	07.00-03.04	0 280 750 061
Air mass meter, gasoline injection		
	07.00-12.07	0 280 218 060
		0 986 280 216
Phase sensor	07.00-12.07	0 232 101 031
Speed sensor, ignition/injection		
Fg.no. →6Y..2..389 395	07.00-09.01	0 261 210 147
Fg.no. 6Y..2..389 396→	10.01-12.07	0 261 210 199
Knock sensor	07.00-12.07	0 261 231 146
Accelerator pedal module	07.00-12.07	AG,RLE 0 280 752 220
		GS,LLE 0 280 752 214
Duo sensor, acceleration and yaw rate, brake system		
Fg.no. →6Y..4..115 000	07.00-04.04	0 265 005 252
Fg.no. 6Y..4..115 001→	05.04-12.07	0 265 005 692

Fabia Combi

1.2 [5J5]		1,2l 51 kW BZG 3 Zyl.
Knock sensor	10.07→	0 261 231 146
Pressure sensor, intake manifold, gasoline	10.07→	0 261 230 031
1.2 [6Y5]		1,2l 40 kW AWY 3 Zyl.
Knock sensor	08.02-05.04	0 261 231 146
Accelerator pedal module	08.02-05.04	AG,RLE 0 280 752 220
		GS,LLE 0 280 752 214
Duo sensor, acceleration and yaw rate, brake system		
Fg.no. →6Y..4..115 000	08.02-04.04	0 265 005 252
Fg.no. 6Y..4..115 001→	05.04-05.04	0 265 005 692
1.2 [6Y5]		1,2l 40 kW BMD 3 Zyl.
Knock sensor	05.04-12.07	0 261 231 146
Accelerator pedal module	05.04-12.07	AG,RLE 0 280 752 220
		GS,LLE 0 280 752 214
Duo sensor, acceleration and yaw rate, brake system		
Fg.no. →6Y..4..115 000	05.04-12.07	0 265 005 692
1.2 [6Y5]		1,2l 47 kW AZQ 3 Zyl.
Pressure sensor, intake manifold, gasoline	02.03-11.04	0 261 230 031
Accelerator pedal module	02.03-11.04	AG,RLE 0 280 752 220
		GS,LLE 0 280 752 214
Duo sensor, acceleration and yaw rate, brake system		
Fg.no. →6Y..4..115 000	02.03-04.04	0 265 005 252
Fg.no. 6Y..4..115 001→	05.04-11.04	0 265 005 692
1.2 [6Y5]		1,2l 47 kW BME 3 Zyl.
Knock sensor	11.04-12.07	0 261 231 146
Pressure sensor, intake manifold, gasoline	11.04-12.07	0 261 230 031

Product



Accelerator pedal module	11.04-12.07	AG,RLE 0 280 752 220
		GS,LLE 0 280 752 214
Duo sensor, acceleration and yaw rate, brake system	11.04-12.07	0 265 005 692
1.4 [5J5]		1,4l 63 kW BXW 4 Zyl.
Knock sensor	10.07→	0 261 231 146
Pressure sensor, intake manifold, gasoline	10.07→	0 261 230 095
1.4 [6Y5]		1,4l 44/50 kW AME; AQW; ATZ; AZE; AZF 4 Zyl.
Accelerator pedal module	12.99-05.03	AG,RLE 0 280 752 220
		GS,LLE 0 280 752 214
Duo sensor, acceleration and yaw rate, brake system	12.99-05.03	0 265 005 252
1.4 [6Y5]		1,4l 55 kW AUA 4 Zyl.
Knock sensor	09.00-08.03	0 261 231 146
Accelerator pedal module	09.00-08.03	AG,RLE 0 280 752 220
		GS,LLE 0 280 752 214
Duo sensor, acceleration and yaw rate, brake system	09.00-08.03	0 265 005 252
1.4 [6Y5]		1,4l 55 kW BBY 4 Zyl.
Speed sensor, ignition/injection		
Fg.no. 6Y..3..712 485→	12.02-05.04	GS 0 261 210 257
Knock sensor	09.00-05.04	0 261 231 146
Pressure sensor, intake manifold, gasoline		
Fg.no. 6Y..4..893 313→	09.03-05.04	0 261 230 095
Accelerator pedal module	09.00-05.04	AG,RLE 0 280 752 220
		GS,LLE 0 280 752 214
Duo sensor, acceleration and yaw rate, brake system		
Fg.no. →6Y..4..115 000	09.00-04.04	0 265 005 252
Fg.no. 6Y..4..115 001→	05.04-05.04	0 265 005 692
1.4 [6Y5]		1,4l 55 kW BKY 4 Zyl.
Knock sensor	05.04-12.07	0 261 231 146
Pressure sensor, intake manifold, gasoline	05.04-12.07	0 261 230 095
Accelerator pedal module	05.04-12.07	AG,RLE 0 280 752 220
		GS,LLE 0 280 752 214
Duo sensor, acceleration and yaw rate, brake system	05.04-12.07	0 265 005 692
1.4 [6Y5]		1,4l 74 kW AUB 4 Zyl.
Knock sensor	09.00-08.03	0 261 231 146
Accelerator pedal module	09.00-08.03	AG,RLE 0 280 752 220
		GS,LLE 0 280 752 214
Duo sensor, acceleration and yaw rate, brake system	09.00-08.03	0 265 005 252
1.4 [6Y5]		1,4l 74 kW BBZ 4 Zyl.
Knock sensor	09.00-12.07	0 261 231 146
Accelerator pedal module	09.00-12.07	AG,RLE 0 280 752 220
		GS,LLE 0 280 752 214
Duo sensor, acceleration and yaw rate, brake system		
Fg.no. →6Y..4..115 000	09.00-04.04	0 265 005 252
Fg.no. 6Y..4..115 001→	05.04-12.07	0 265 005 692
1.4 TDI [5J5]		1,4l 51/59 kW BMS; BNM; BNV 4 Zyl.
Air mass meter, diesel	10.07→	0 281 002 531
		0 986 284 009
Boost pressure sensor, Diesel	10.07→	0 281 002 399
1.4 TDI [6Y5]		1,4l 51 kW BNM 3 Zyl.
Air mass meter, diesel	10.05-12.07	0 281 002 531
		0 986 284 009
Boost pressure sensor, Diesel	10.05-12.07	0 281 002 399
Accelerator pedal module	10.05-12.07	GS,LLE 0 281 002 377
Duo sensor, acceleration and yaw rate, brake system	10.05-12.07	0 265 005 692



Product

◀ Fabia Combi

1.4 TDI [6Y5]		1,4l 55 kW AMF 3 Zyl.
Air mass meter, diesel	05.03-10.05	0 281 002 531 🔌 0 986 284 009
Boost pressure sensor, Diesel	05.03-10.05	0 281 002 399
Accelerator pedal module	05.03-10.05	GS,LLE 0 281 002 377
Duo sensor, acceleration and yaw rate, brake system		
Fg.no. →6Y..4..115 000	05.03-04.04	0 265 005 252
Fg.no. 6Y..4..115 001→	05.04-10.05	0 265 005 692
1.4 TDI [6Y5]		1,4l 59 kW BNV 3 Zyl.
Air mass meter, diesel	10.05-12.07	0 281 002 531 🔌 0 986 284 009
Boost pressure sensor, Diesel	10.05-12.07	0 281 002 399
Accelerator pedal module	10.05-12.07	GS,LLE 0 281 002 377
Duo sensor, acceleration and yaw rate, brake system	10.05-12.07	0 265 005 692
1.6 [5J5]		1,6l 77 kW BTS 4 Zyl.
Knock sensor	10.07→	0 261 231 146
Pressure sensor, intake manifold, gasoline	10.07→	0 261 230 095
1.9 SDI [6Y5]		1,9l 47 kW ASY 4 Zyl.
Accelerator pedal module	08.00-12.07	GS,LLE 0 281 002 377
Duo sensor, acceleration and yaw rate, brake system		
Fg.no. →6Y..4..115 000	08.00-04.04	0 265 005 252
Fg.no. 6Y..4..115 001→	05.04-12.07	0 265 005 692
1.9 TDI [5J5]		1,9l 77 kW BLS;BSW 4 Zyl.
Air mass meter, diesel	10.07→	0 281 002 531 🔌 0 986 284 009
Boost pressure sensor, Diesel	10.07→	0 281 002 399
1.9 TDI [6Y5]		1,9l 74 kW ATD 4 Zyl.
Air mass meter, diesel	08.00-04.02	0 281 002 757
Fg.no. →6Y..2..532 833,→6Y..2X040 209		WW 0 280 217 121 🔌 0 986 280 202
Fg.no. 6Y..2..532 834→,6Y..2X040 210→	05.02-10.05	0 281 002 531 🔌 0 986 284 009
Boost pressure sensor, Diesel		
Fg.no. →6Y..4..115 000	08.00-04.04	0 281 002 177
Fg.no. 6Y..4..115 001→	05.04-10.05	0 281 002 399
Accelerator pedal module	08.00-10.05	GS,LLE 0 281 002 377
Duo sensor, acceleration and yaw rate, brake system		
Fg.no. →6Y..4..115 000	08.00-04.04	0 265 005 252
Fg.no. 6Y..4..115 001→	05.04-10.05	0 265 005 692
1.9 TDI [6Y5]		1,9l 74 kW AXR 4 Zyl.
Air mass meter, diesel	10.05-12.07	0 281 002 531 🔌 0 986 284 009
Boost pressure sensor, Diesel	10.05-12.07	0 281 002 399
Accelerator pedal module	10.05-12.07	GS,LLE 0 281 002 377
2.0 [6Y5]		2,0l 85 kW AZL 4 Zyl.
Throttle valve assembly		
Fg.no. →6Y..4..095 000	09.00-03.04	0 280 750 061
Air mass meter, gasoline injection	09.00-12.07	0 280 218 060 🔌 0 986 280 216
Phase sensor	09.00-12.07	0 232 101 031
Speed sensor, ignition/injection		
Fg.no. →6Y..2..389 395	09.00-09.01	0 261 210 147
Fg.no. 6Y..2..389 396→	10.01-12.07	0 261 210 199
Knock sensor	09.00-12.07	0 261 231 146
Accelerator pedal module	09.00-12.07	AG,RLE 0 280 752 220 GS,LLE 0 280 752 214

Product

Duo sensor, acceleration and yaw rate, brake system		
Fg.no. →6Y..4..115 000	09.00-04.04	0 265 005 252
Fg.no. 6Y..4..115 001→	05.04-12.07	0 265 005 692

Fabia Schrägheck			
1.0 [6Y2]		1,0l 37 kW AQV; ARV 4 Zyl.	
Accelerator pedal module	09.99-08.02	AG,RLE 0 280 752 220 GS,LLE 0 280 752 214	
Duo sensor, acceleration and yaw rate, brake system		09.99-08.02	0 265 005 252
1.2 [5J2]		1,2l 44 kW BBM 3 Zyl.	
Knock sensor	12.06→	0 261 231 146	
Accelerator pedal module	12.06→	GS,LLE 0 280 752 214	
Duo sensor, acceleration and yaw rate, brake system		12.06→	0 265 005 692
1.2 [5J2]		1,2l 51 kW BZG 3 Zyl.	
Knock sensor	01.07→	0 261 231 146	
Pressure sensor, intake manifold, gasoline	01.07→	0 261 230 031	
Accelerator pedal module	01.07→	GS,LLE 0 280 752 214	
Duo sensor, acceleration and yaw rate, brake system		01.07→	0 265 005 692
1.2 [6Y2]		1,2l 40 kW AWY 3 Zyl.	
Knock sensor	07.01-05.04	0 261 231 146	
Accelerator pedal module	07.01-05.04	AG,RLE 0 280 752 220 GS,LLE 0 280 752 214	
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →6Y..4..115 000	07.01-04.04	0 265 005 252	
Fg.no. 6Y..4..115 001→	05.04-05.04	0 265 005 692	
1.2 [6Y2]		1,2l 40 kW BMD 3 Zyl.	
Knock sensor	05.04-04.07	0 261 231 146	
Accelerator pedal module	05.04-04.07	AG,RLE 0 280 752 220 GS,LLE 0 280 752 214	
Duo sensor, acceleration and yaw rate, brake system		05.04-04.07	0 265 005 692
1.2 [6Y2]		1,2l 47 kW AZQ 3 Zyl.	
Pressure sensor, intake manifold, gasoline	02.03-11.04	0 261 230 031	
Accelerator pedal module	02.03-11.04	AG,RLE 0 280 752 220 GS,LLE 0 280 752 214	
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →6Y..4..115 000	02.03-04.04	0 265 005 252	
Fg.no. 6Y..4..115 001→	05.04-11.04	0 265 005 692	
1.2 [6Y2]		1,2l 47 kW BME 3 Zyl.	
Knock sensor	11.04-04.07	0 261 231 146	
Pressure sensor, intake manifold, gasoline	11.04-04.07	0 261 230 031	
Accelerator pedal module	11.04-04.07	AG,RLE 0 280 752 220 GS,LLE 0 280 752 214	
Duo sensor, acceleration and yaw rate, brake system		11.04-04.07	0 265 005 692
1.4 [5J2]		1,4l 63 kW BXW 4 Zyl.	
Knock sensor	01.07→	0 261 231 146	
Pressure sensor, intake manifold, gasoline	01.07→	0 261 230 095	
Accelerator pedal module	01.07→	GS,LLE 0 280 752 214	
Duo sensor, acceleration and yaw rate, brake system		01.07→	0 265 005 692
1.4 [6Y2]		1,4l 44/50 kW AME; AQW; ATZ; AZE; AZF 4 Zyl.	
Accelerator pedal module	09.99-05.03	AG,RLE 0 280 752 220 GS,LLE 0 280 752 214	
Duo sensor, acceleration and yaw rate, brake system		09.99-05.03	0 265 005 252



Product



1.4 [6Y2] 1,4l 55 kW AUA 4 Zyl.			
Knock sensor	09.99-08.03		0 261 231 146
Accelerator pedal module	09.99-08.03	AG,RLE	0 280 752 220
		GS,LLE	0 280 752 214
Duo sensor, acceleration and yaw rate, brake system	09.99-08.03		0 265 005 252
1.4 [6Y2] 1,4l 55 kW BBY 4 Zyl.			
Speed sensor, ignition/injection			
Fg.no. 6Y..3..712 485→	12.02-05.04	GS	0 261 210 257
Knock sensor	09.00-05.04		0 261 231 146
Pressure sensor, intake manifold, gasoline			
Fg.no. 6Y..4..893 313→	09.03-05.04		0 261 230 095
Accelerator pedal module	09.00-05.04	AG,RLE	0 280 752 220
		GS,LLE	0 280 752 214
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →6Y..4..115 000	09.00-04.04		0 265 005 252
Fg.no. 6Y..4..115 001→	05.04-05.04		0 265 005 692
1.4 [6Y2] 1,4l 55 kW BKY 4 Zyl.			
Knock sensor	05.04-04.07		0 261 231 146
Pressure sensor, intake manifold, gasoline	05.04-04.07		0 261 230 095
Accelerator pedal module	05.04-04.07	AG,RLE	0 280 752 220
		GS,LLE	0 280 752 214
Duo sensor, acceleration and yaw rate, brake system	05.04-04.07		0 265 005 692
1.4 [6Y2] 1,4l 74 kW AUB 4 Zyl.			
Knock sensor	09.99-08.03		0 261 231 146
Accelerator pedal module	09.99-08.03	AG,RLE	0 280 752 220
		GS,LLE	0 280 752 214
Duo sensor, acceleration and yaw rate, brake system	09.99-08.03		0 265 005 252
1.4 [6Y2] 1,4l 74 kW BBZ 4 Zyl.			
Knock sensor	09.00-04.07		0 261 231 146
Accelerator pedal module	09.00-04.07	AG,RLE	0 280 752 220
		GS,LLE	0 280 752 214
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →6Y..4..115 000	09.00-04.04		0 265 005 252
Fg.no. 6Y..4..115 001→	05.04-04.07		0 265 005 692
1.4 TDI [5J2] 1,4l 51/59 kW BMS; BNM; BNV 4 Zyl.			
Air mass meter, diesel	01.07→		0 281 002 531
			0 986 284 009
Boost pressure sensor, Diesel	01.07→		0 281 002 399
Duo sensor, acceleration and yaw rate, brake system	01.07→		0 265 005 692
1.4 TDI [6Y2] 1,4l 51 kW BNM 3 Zyl.			
Air mass meter, diesel	10.05-04.07		0 281 002 531
			0 986 284 009
Boost pressure sensor, Diesel	10.05-04.07		0 281 002 399
Accelerator pedal module	10.05-04.07	GS,LLE	0 281 002 377
Duo sensor, acceleration and yaw rate, brake system	10.05-04.07		0 265 005 692
1.4 TDI [6Y2] 1,4l 55 kW AMF 3 Zyl.			
Air mass meter, diesel	05.03-04.07		0 281 002 531
			0 986 284 009
Boost pressure sensor, Diesel	05.03-04.07		0 281 002 399
Accelerator pedal module	05.03-04.07	GS,LLE	0 281 002 377
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →6Y..4..115 000	05.03-04.04		0 265 005 252
Fg.no. 6Y..4..115 001→	05.04-04.07		0 265 005 692

Product



1.4 TDI [6Y2] 1,4l 59 kW BNV 3 Zyl.			
Air mass meter, diesel	10.05-04.07		0 281 002 531
			0 986 284 009
Boost pressure sensor, Diesel	10.05-04.07		0 281 002 399
Accelerator pedal module	10.05-04.07	GS,LLE	0 281 002 377
Duo sensor, acceleration and yaw rate, brake system	10.05-04.07		0 265 005 692
1.6 [5J2] 1,6l 77 kW BTS 4 Zyl.			
Knock sensor	04.07→		0 261 231 146
Pressure sensor, intake manifold, gasoline	04.07→		0 261 230 095
Accelerator pedal module	04.07→	GS,LLE	0 280 752 214
Duo sensor, acceleration and yaw rate, brake system	04.07→		0 265 005 692
1.9 SDI [6Y2] 1,9l 47 kW ASY 4 Zyl.			
Accelerator pedal module	09.99-04.07	GS,LLE	0 281 002 377
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →6Y..4..115 000	09.99-04.04		0 265 005 252
Fg.no. 6Y..4..115 001→	05.04-04.07		0 265 005 692
1.9 TDI [5J2] 1,9l 77 kW BLS; BSW 4 Zyl.			
Air mass meter, diesel	04.07→		0 281 002 531
			0 986 284 009
Boost pressure sensor, Diesel	04.07→		0 281 002 399
Duo sensor, acceleration and yaw rate, brake system	04.07→		0 265 005 692
1.9 TDI [6Y2] 1,9l 74 kW ATD 4 Zyl.			
Air mass meter, diesel			
Fg.no. →6Y..2..532 833, →6Y..2X040 209	09.99-04.02		0 281 002 757
		WW	0 280 217 121
			0 986 280 202
Fg.no. 6Y..2..532 834→, 6Y..2X040 210→	05.02-04.07		0 281 002 531
			0 986 284 009
Boost pressure sensor, Diesel			
Fg.no. →6Y..4..115 000	09.99-04.04		0 281 002 177
Fg.no. 6Y..4..115 001→	05.04-04.07		0 281 002 399
Accelerator pedal module	09.99-04.07	GS,LLE	0 281 002 377
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →6Y..4..115 000	09.99-04.04		0 265 005 252
Fg.no. 6Y..4..115 001→	05.04-04.07		0 265 005 692
1.9 TDI [6Y2] 1,9l 74 kW AXR 4 Zyl.			
Air mass meter, diesel	10.05-04.07		0 281 002 531
			0 986 284 009
Boost pressure sensor, Diesel	10.05-04.07		0 281 002 399
Accelerator pedal module	10.05-04.07	GS,LLE	0 281 002 377
1.9 TDI RS [6Y2] 1,9l 96 kW ASZ 4 Zyl.			
Air mass meter, diesel	06.03-10.05		0 281 002 461
			0 986 284 007
Boost pressure sensor, Diesel	06.03-10.05		0 281 002 401
Accelerator pedal module	06.03-10.05	GS,LLE	0 281 002 377
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →6Y..4..115 000	06.03-04.04		0 265 005 252
Fg.no. 6Y..4..115 001→	05.04-10.05		0 265 005 692
1.9 TDI RS [6Y2] 1,9l 96 kW BLT 4 Zyl.			
Air mass meter, diesel	10.05-04.07		0 281 002 461
			0 986 284 007
Boost pressure sensor, Diesel	10.05-04.07		0 281 002 401
2.0 [6Y2] 2,0l 85 kW AZL 4 Zyl.			
Throttle valve assembly			
Fg.no. →6Y..4..095 000	07.00-03.04		0 280 750 061
Air mass meter, gasoline injection	07.00-04.07		0 280 218 060
			0 986 280 216

Product				
◀ Fabia Schrägheck				
Phase sensor	07.00-04.07			0 232 101 031
Speed sensor, ignition/injection				
Fg.no. →6Y..2..389 395	07.00-09.01			0 261 210 147
Fg.no. 6Y..2..389 396→	10.01-04.07			0 261 210 199
Knock sensor	07.00-04.07			0 261 231 146
Accelerator pedal module	07.00-04.07	AG,RLE		0 280 752 220
		GS,LLE		0 280 752 214
Duo sensor, acceleration and yaw rate, brake system				
Fg.no. →6Y..4..115 000	07.00-04.04			0 265 005 252
Fg.no. 6Y..4..115 001→	05.04-04.07			0 265 005 692

Favorit				
135				1,3l 40 kW 4 Zyl.
Speed sensor, ignition/injection	05.89-10.93			0 261 210 064
Temperature sensor, coolant, injection system	05.89-09.94			0 280 130 026
136 i.e.				1,3l 40 kW A01 4 Zyl.
Speed sensor, ignition/injection	08.92-12.92			0 261 210 064
Temperature sensor, coolant, injection system	08.92-09.94			0 280 130 026
136 i.e.				1,3l 40/50 kW A02 4 Zyl.
Temperature sensor, coolant, injection system	09.94-12.98			0 280 130 026
136 i.e.				1,3l 50 kW A01 4 Zyl.
Temperature sensor, coolant, injection system	07.93-09.94			0 280 130 026

Felicia Fun				
1.3 [6UF]				1,3l 50 kW AMH 4 Zyl.
Temperature sensor, coolant, injection system	08.96-03.01			0 280 130 026
1.6 [6UF]				1,6l 55 kW AEE 4 Zyl.
Temperature sensor, coolant, injection system	08.96-03.01			0 280 130 026
1.9 D [6UF]				1,9l 47 kW AEF 4 Zyl.
Temperature sensor, coolant, diesel	08.96-03.01			0 280 130 026

Forman				
1.3 i.e.				1,3l 40/50 kW 4 Zyl.
Temperature sensor, coolant, injection system	08.92-12.95			0 280 130 026

Octavia				
1.4 [1U2]				1,4l 44 kW AMD 4 Zyl.
Accelerator pedal module	06.99-03.01	GS,LLE		0 280 752 214
1.4 [1U2]				1,4l 55 kW AXP 4 Zyl.
Knock sensor	08.00-01.02			0 261 231 146
Temperature sensor, intake air, injection system	08.00-01.02			0 261 230 031
Accelerator pedal module	08.00-01.02	GS,LLE		0 280 752 214
1.4 [1U2]				1,4l 55 kW BCA 4 Zyl.
Speed sensor, ignition/injection	01.02→			0 261 210 213
Knock sensor	01.02→			0 261 231 146
Temperature sensor, intake air, injection system	01.02→			0 261 230 031
Accelerator pedal module	01.02→	GS,LLE		0 280 752 214
1.4 [123]				1,4l 55 kW BUD 4 Zyl.
Knock sensor	05.04→			0 261 231 146
Pressure sensor, intake manifold, gasoline	05.04→			0 261 230 095
1.4 [123]				1,4l 59 kW BUD 4 Zyl.
Pressure sensor, intake manifold, gasoline	05.06→			0 261 230 095
1.6 [1U2]				1,6l 55 kW AEE 4 Zyl.
Knock sensor	09.96-09.04			0 261 231 045
Accelerator pedal module				
Fg.no. 1U..X..134 001→	09.98-09.04	GS,LLE		0 280 752 214

Product				
Pedal position sensor, EMS (electronic engine management)				
Fg.no. 1U..V..033 907→1U..X..134 000	08.97-08.98	GS,LLE		0 281 002 269
1.6 [1U2]				1,6l 74 kW AEH 4 Zyl.
Phase sensor	11.96-09.04			0 232 101 031
Speed sensor, ignition/injection	11.96-09.04			0 261 210 147
Temperature sensor, intake air, injection system				
Fg.no. →1U..V..029 000	11.96-07.97			0 280 130 085
Accelerator pedal module				
Fg.no. 1U..X..134 001→	09.98-09.04	GS,LLE		0 280 752 214
Pedal position sensor, EMS (electronic engine management)				
Fg.no. 1U..V..033 907→1U..X..134 000	08.97-08.98	GS,LLE		0 281 002 269
1.6 [1U2]				1,6l 74 kW AKL 4 Zyl.
Phase sensor	08.00-05.07			0 232 101 031
Speed sensor, ignition/injection	08.00-05.07			0 261 210 147
Accelerator pedal module	08.00-05.07	GS,LLE		0 280 752 214
1.6 [1U2]				1,6l 75 kW AVU 4 Zyl.
Phase sensor	08.00-04.02			0 232 101 038
Speed sensor, ignition/injection	08.00-04.02			0 261 210 199
Accelerator pedal module	08.00-04.02	GS,LLE		0 280 752 214
1.6 [1U2]				1,6l 75 kW BFQ 4 Zyl.
Speed sensor, ignition/injection	08.00→			0 261 210 199
Knock sensor	08.00→			0 261 231 146
Accelerator pedal module	08.00→	GS,LLE		0 280 752 214
1.6 [123]				1,6l 75 kW BGU; BSE; BSF 4 Zyl.
Speed sensor, ignition/injection	05.04→			0 261 210 199
Knock sensor	05.04→			0 261 231 146
Pressure sensor, intake manifold, gasoline	05.04→			0 261 230 031
1.6 FSI [123]				1,6l 85 kW BLF 4 Zyl.
Speed sensor, ignition/injection	05.04→	AG		0 261 210 250
Knock sensor	05.04→			0 261 231 146
Pressure sensor, intake manifold, gasoline	05.04→			0 261 230 095
1.8 [1U2]				1,8l 92 kW AGN 4 Zyl.
Air mass meter, gasoline injection				
Fg.no. 1U..V..028 928→	07.97-04.99			0 280 218 002
				0 986 280 205
Phase sensor	09.96-04.99			0 232 101 024
Speed sensor, ignition/injection	09.96-04.99			0 261 210 147
Temperature sensor, intake air, injection system	09.96-04.99			0 280 130 085
Accelerator pedal module				
Fg.no. 1U..X..134 001→	09.98-04.99	GS,LLE		0 280 752 214
Pedal position sensor, EMS (electronic engine management)				
Fg.no. 1U..V..033 907→1U..X..134 000	08.97-08.98	GS,LLE		0 281 002 269
1.8 RS [1U2]				1,8l 132 kW AUQ 4 Zyl.
Throttle valve assembly	08.00-09.04			0 280 750 036
Air mass meter, gasoline injection	08.00-09.04			0 280 218 063
				0 986 280 217
Phase sensor	08.00-09.04			0 232 101 024
Speed sensor, ignition/injection	08.00-09.04			0 261 210 199
Knock sensor	08.00-09.04			0 261 231 146
Boost pressure sensor, gasoline				
Fg.no. →1U..3..758 379,→1U..3A016 199,→1U..38692 715	08.00-01.03			0 281 002 177
Fg.no. 1U..3..758 380→,1U..3A016 200→,1U..38692 716→	02.03-09.04			0 281 002 399
Temperature sensor, intake air, injection system				
Fg.no. →1U..3..716 385,→1U..3A008 026,→1U..38680 305	08.00-09.02			0 280 130 085
Accelerator pedal module	08.00-09.04	GS,LLE		0 280 752 214



Product			
1.8 T [1U2]	1,8l 110 kW AGU 4 Zyl.		
Air mass meter, gasoline injection	03.98-09.04	0 280 217 117	0 986 280 201
Phase sensor	03.98-09.04	0 232 101 024	
Speed sensor, ignition/injection	03.98-09.04	0 261 210 147	
Boost pressure sensor, gasoline			
Fg.no. →1U..3..758 379,→1U..3A016 199,→1U..38692 715	03.98-01.03	0 281 002 177	
Fg.no. 1U..3..758 380→,1U..3A016 200→,1U..38692 716→	02.03-09.04	0 281 002 399	
Temperature sensor, intake air, injection system			
Fg.no. →1U..3..716 385,→1U..3A008 026,→1U..38680 305	03.98-09.02	0 280 130 085	
Accelerator pedal module			
Fg.no. 1U..X..134 001→	09.98-09.04 GS, LLE	0 280 752 214	
Pedal position sensor, EMS (electronic engine management)			
Fg.no. →1U..X..134 000	03.98-08.98 GS, LLE	0 281 002 269	
1.8 T [1U2]	1,8l 110 kW ARX 4 Zyl.		
Throttle valve assembly	08.00-01.06	0 280 750 036	
Air mass meter, gasoline injection	08.00-01.06	0 280 218 063	0 986 280 217
Phase sensor	08.00-01.06	0 232 101 024	
Speed sensor, ignition/injection	08.00-01.06	0 261 210 147	
Knock sensor	08.00-01.06	0 261 231 146	
Boost pressure sensor, gasoline			
Fg.no. →1U..3..758 379,→1U..3A016 199,→1U..38692 715	08.00-01.03	0 281 002 177	
Fg.no. 1U..3..758 380→,1U..3A016 200→,1U..38692 716→	02.03-01.06	0 281 002 399	
Temperature sensor, intake air, injection system			
Fg.no. →1U..3..716 385,→1U..3A008 026,→1U..38680 305	08.00-09.02	0 280 130 085	
Accelerator pedal module	08.00-01.06 GS, LLE	0 280 752 214	
1.8 T [1U2]	1,8l 110 kW ARZ 4 Zyl.		
Throttle valve assembly	01.00-07.00	0 280 750 036	
Air mass meter, gasoline injection	01.00-07.00	0 280 218 032	0 986 280 210
Phase sensor	01.00-07.00	0 232 101 024	
Speed sensor, ignition/injection	01.00-07.00	0 261 210 147	
Temperature sensor, intake air, injection system	01.00-07.00	0 280 130 085	
Accelerator pedal module	01.00-07.00 GS, LLE	0 280 752 214	
1.8 T [1U2]	1,8l 110 kW AUM 4 Zyl.		
Throttle valve assembly	08.00→	0 280 750 036	
Air mass meter, gasoline injection	08.00→	0 280 218 063	0 986 280 217
Phase sensor	08.00→	0 232 101 024	
Speed sensor, ignition/injection	08.00→	0 261 210 147	
Knock sensor	08.00→	0 261 231 146	
Boost pressure sensor, gasoline			
Fg.no. →1U..3..758 379,→1U..3A016 199,→1U..38692 715	08.00-01.03	0 281 002 177	
Fg.no. 1U..3..758 380→,1U..3A016 200→,1U..38692 716→	02.03→	0 281 002 399	
Temperature sensor, intake air, injection system			
Fg.no. →1U..3..716 385,→1U..3A008 026,→1U..38680 305	08.00-09.02	0 280 130 085	
Accelerator pedal module	08.00→ GS, LLE	0 280 752 214	
1.8 T 4x4 [1U2]	1,8l 110 kW AGU 4 Zyl.		
Air mass meter, gasoline injection	08.00→	0 280 217 117	0 986 280 201
Phase sensor	08.00→	0 232 101 024	




Speed sensor, ignition/injection	08.00→	0 261 210 147	
Boost pressure sensor, gasoline			
Fg.no. →1U..3..758 379,→1U..3A016 199,→1U..38692 715	08.00-01.03	0 281 002 177	
Fg.no. 1U..3..758 380→,1U..3A016 200→,1U..38692 716→	02.03→	0 281 002 399	
Temperature sensor, intake air, injection system			
Fg.no. →1U..3..716 385,→1U..3A008 026,→1U..38680 305	08.00-09.02	0 280 130 085	
Accelerator pedal module	08.00→ GS, LLE	0 280 752 214	
1.8 T 4x4 [1U2]	1,8l 110 kW ARX 4 Zyl.		
Throttle valve assembly	08.00-01.06	0 280 750 036	
Air mass meter, gasoline injection	08.00-01.06	0 280 218 063	0 986 280 217
Phase sensor	08.00-01.06	0 232 101 024	
Speed sensor, ignition/injection	08.00-01.06	0 261 210 147	
Knock sensor	08.00-01.06	0 261 231 146	
Boost pressure sensor, gasoline			
Fg.no. →1U..3..758 379,→1U..3A016 199,→1U..38692 715	08.00-01.03	0 281 002 177	
Fg.no. 1U..3..758 380→,1U..3A016 200→,1U..38692 716→	02.03-01.06	0 281 002 399	
Temperature sensor, intake air, injection system			
Fg.no. →1U..3..716 385,→1U..3A008 026,→1U..38680 305	08.00-09.02	0 280 130 085	
Accelerator pedal module	08.00-01.06 GS, LLE	0 280 752 214	
1.8 T 4x4 [1U2]	1,8l 110 kW ARZ 4 Zyl.		
Throttle valve assembly	01.00-07.00	0 280 750 036	
Air mass meter, gasoline injection	01.00-07.00	0 280 218 032	0 986 280 210
Phase sensor	01.00-07.00	0 232 101 024	
Speed sensor, ignition/injection	01.00-07.00	0 261 210 147	
Temperature sensor, intake air, injection system	01.00-07.00	0 280 130 085	
Accelerator pedal module	01.00-07.00 GS, LLE	0 280 752 214	
1.8 T 4x4 [1U2]	1,8l 110 kW AUM 4 Zyl.		
Throttle valve assembly	08.00→	0 280 750 036	
Air mass meter, gasoline injection	08.00→	0 280 218 063	0 986 280 217
Phase sensor	08.00→	0 232 101 024	
Speed sensor, ignition/injection	08.00→	0 261 210 147	
Knock sensor	08.00→	0 261 231 146	
Boost pressure sensor, gasoline			
Fg.no. →1U..3..758 379,→1U..3A016 199,→1U..38692 715	08.00-01.03	0 281 002 177	
Fg.no. 1U..3..758 380→,1U..3A016 200→,1U..38692 716→	02.03→	0 281 002 399	
Temperature sensor, intake air, injection system			
Fg.no. →1U..3..716 385,→1U..3A008 026,→1U..38680 305	08.00-09.02	0 280 130 085	
Accelerator pedal module	08.00→ GS, LLE	0 280 752 214	
1.9 TDI [1U2]	1,9l 66 kW AGR 4 Zyl.		
Air mass meter, diesel			
Fg.no. 1U..W..134 001→	08.98→	0 281 002 757	
	WW	0 280 217 121	0 986 280 202
Boost pressure sensor, Diesel			
Fg.no. →1U..3..768 637,→1U..3A016 277,→1U..38696 292	09.96-02.03	0 281 002 177	
Fg.no. 1U..3..768 638→,1U..3A016 278→,1U..38696 293→	03.03→	0 281 002 399	



Product				
◀ Octavia				
1.9 TDI [1U2]		1,9l 66 kW ALH 4 Zyl.		
Air mass meter, diesel				
Fg.no. →1U..3..836 957, →1U..3A016 708, →1U..38712 468	08.00-07.03		0 281 002 757	
		WW	0 280 217 121	
			 0 986 280 202	
Fg.no. 1U..3..836 958→, 1U..3A016 709→, 1U..38712 469→	08.03→		0 281 002 531	
			 0 986 284 009	
Boost pressure sensor, Diesel				
Fg.no. →1U..3..768 637, →1U..3A016 277, →1U..38696 292	08.00-02.03		0 281 002 177	
Fg.no. 1U..3..768 638→, 1U..3A016 278→, 1U..38696 293→	03.03→		0 281 002 399	
1.9 TDI [1U2]		1,9l 74 kW ATD 4 Zyl.		
Air mass meter, diesel				
Fg.no. →1U..3..666 021, →1U..38665 263	08.00-04.02		0 281 002 757	
		WW	0 280 217 121	
			 0 986 280 202	
Fg.no. 1U..3..666 022→, 1U..38665 264→	05.02-09.04		0 281 002 531	
			 0 986 284 009	
Boost pressure sensor, Diesel				
Fg.no. →1U..3..768 637, →1U..3A016 277, →1U..38696 292	08.00-02.03		0 281 002 177	
Fg.no. 1U..3..768 638→, 1U..3A016 278→, 1U..38696 293→	03.03-09.04		0 281 002 399	
1.9 TDI [1U2]		1,9l 74 kW AXR 4 Zyl.		
Air mass meter, diesel		10.05→	0 281 002 531	
			 0 986 284 009	
Boost pressure sensor, Diesel		10.05→	0 281 002 399	
1.9 TDI [1U2]		1,9l 81 kW AHF 4 Zyl.		
Air mass meter, diesel				
Fg.no. 1U..W..134 001→	08.98-01.06		0 281 002 757	
		WW	0 280 217 121	
			 0 986 280 202	
Boost pressure sensor, Diesel				
Fg.no. →1U..3..768 637, →1U..3A016 277, →1U..38696 292	05.97-02.03		0 281 002 177	
Fg.no. 1U..3..768 638→, 1U..3A016 278→, 1U..38696 293→	03.03-01.06		0 281 002 399	
1.9 TDI [1U2]		1,9l 81 kW ASV 4 Zyl.		
Air mass meter, diesel				
Fg.no. →1U..3..836 957, →1U..3A016 708, →1U..38712 468	08.00-07.03		0 281 002 757	
		WW	0 280 217 121	
			 0 986 280 202	
Fg.no. 1U..3..836 958→, 1U..3A016 709→, 1U..38712 469→	08.03-01.06		0 281 002 531	
			 0 986 284 009	
Boost pressure sensor, Diesel				
Fg.no. →1U..3..768 637, →1U..3A016 277, →1U..38696 292	08.00-02.03		0 281 002 177	
Fg.no. 1U..3..768 638→, 1U..3A016 278→, 1U..38696 293→	03.03-01.06		0 281 002 399	
1.9 TDI [1U2]		1,9l 96 kW ASZ 4 Zyl.		
Air mass meter, diesel		01.03-09.04	0 281 002 461	
			 0 986 284 007	
Boost pressure sensor, Diesel		01.03-09.04	0 281 002 401	
1.9 TDI [1Z3]		1,9l 77 kW BJB; BKC; BLS; BXE 4 Zyl.		
Air mass meter, diesel		05.04→	0 281 002 531	
			 0 986 284 009	
Pressure sensor, intake manifold, diesel		05.04→	0 281 002 399	
1.9 TDI 4x4 [1Z3]		1,9l 77 kW BKC; BLS; BXE 4 Zyl.		
Air mass meter, diesel		11.04→	0 281 002 531	
			 0 986 284 009	
Pressure sensor, intake manifold, diesel		11.04→	0 281 002 399	

Product				



Octavia Combi			
1.4 [1U5]	1,4l 55 kW AXP 4 Zyl.		
Knock sensor	08.00-01.02		0 261 231 146
Temperature sensor, intake air, injection system	08.00-01.02		0 261 230 031
Accelerator pedal module	08.00-01.02	GS,LLE	0 280 752 214
1.4 [1U5]	1,4l 55 kW BCA 4 Zyl.		
Speed sensor, ignition/injection	01.02→		0 261 210 213
Knock sensor	01.02→		0 261 231 146
Temperature sensor, intake air, injection system	01.02→		0 261 230 031
Accelerator pedal module	01.02→	GS,LLE	0 280 752 214
1.4 [1Z5]	1,4l 55 kW BCA 4 Zyl.		
Knock sensor	05.04→		0 261 231 146
Pressure sensor, intake manifold, gasoline	05.04→		0 261 230 095
1.4 [1Z5]	1,4l 59 kW BUD 4 Zyl.		
Pressure sensor, intake manifold, gasoline	05.06→		0 261 230 095
1.6 [1U5]	1,6l 55 kW AEE 4 Zyl.		
Knock sensor	08.00-09.04		0 261 231 045
Accelerator pedal module	08.00-09.04	GS,LLE	0 280 752 214
1.6 [1U5]	1,6l 74 kW AEH; AKL 4 Zyl.		
Phase sensor	02.97-09.04		0 232 101 031
Speed sensor, ignition/injection	02.97-09.04		0 261 210 147
Temperature sensor, intake air, injection system			
Fg.no. →1U..V..029 000	02.97-07.97		0 280 130 085
Accelerator pedal module			
Fg.no. 1U..X..134 001→	09.98-09.04	GS,LLE	0 280 752 214
Pedal position sensor, EMS (electronic engine management)			
Fg.no. 1U..V..033 907→1U..X..134 000	08.97-08.98	GS,LLE	0 281 002 269
1.6 [1U5]	1,6l 75 kW AVU 4 Zyl.		
Phase sensor	08.00-04.02		0 232 101 038
Speed sensor, ignition/injection	08.00-04.02		0 261 210 199
Accelerator pedal module	08.00-04.02	GS,LLE	0 280 752 214
1.6 [1U5]	1,6l 75 kW BFQ 4 Zyl.		
Speed sensor, ignition/injection	08.00→		0 261 210 199
Knock sensor	08.00→		0 261 231 146
Accelerator pedal module	08.00→	GS,LLE	0 280 752 214
1.6 [1Z5]	1,6l 75 kW BGU; BSE; BSF 4 Zyl.		
Speed sensor, ignition/injection	05.04→		0 261 210 199
Knock sensor	05.04→		0 261 231 146
Pressure sensor, intake manifold, gasoline	05.04→		0 261 230 031
1.6 FSI [1Z5]	1,6l 85 kW BLF 4 Zyl.		
Speed sensor, ignition/injection	05.04→	AG	0 261 210 250
Knock sensor	05.04→		0 261 231 146
Pressure sensor, intake manifold, gasoline	05.04→		0 261 230 095
1.8 [1U5]	1,8l 92 kW AGN 4 Zyl.		
Air mass meter, gasoline injection			
Fg.no. 1U..V..028 928→	07.97-04.99		0 280 218 002
			0 986 280 205
Phase sensor	10.96-04.99		0 232 101 024
Speed sensor, ignition/injection	10.96-04.99		0 261 210 147
Temperature sensor, intake air, injection system	10.96-04.99		0 280 130 085
Accelerator pedal module			
Fg.no. 1U..X..134 001→	09.98-04.99	GS,LLE	0 280 752 214
Pedal position sensor, EMS (electronic engine management)			
Fg.no. 1U..V..033 907→1U..X..134 000	08.97-08.98	GS,LLE	0 281 002 269
1.8 RS [1U5]	1,8l 132 kW AUQ 4 Zyl.		
Throttle valve assembly	01.03-01.06		0 280 750 036
Air mass meter, gasoline injection	01.03-01.06		0 280 218 063
			0 986 280 217
Speed sensor, ignition/injection	01.03-01.06		0 261 210 199



Knock sensor	01.03-01.06		0 261 231 146
Boost pressure sensor, gasoline			
Fg.no. →1U..3..758 379,→1U..3A016 199,→1U..38692 715	01.03-01.03		0 281 002 177
Fg.no. 1U..3..758 380→,1U..3A016 200→,1U..38692 716→	02.03-01.06		0 281 002 399
Accelerator pedal module	01.03-01.06	GS,LLE	0 280 752 214
1.8 T [1U5]	1,8l 110 kW AGU 4 Zyl.		
Air mass meter, gasoline injection	03.98→		0 280 217 117
			0 986 280 201
Phase sensor	03.98→		0 232 101 024
Speed sensor, ignition/injection	03.98→		0 261 210 147
Boost pressure sensor, gasoline			
Fg.no. →1U..3..758 379,→1U..3A016 199,→1U..38692 715	03.98-01.03		0 281 002 177
Fg.no. 1U..3..758 380→,1U..3A016 200→,1U..38692 716→	02.03→		0 281 002 399
Temperature sensor, intake air, injection system			
Fg.no. →1U..3..716 385,→1U..3A008 026,→1U..38680 305	03.98-09.02		0 280 130 085
Accelerator pedal module			
Fg.no. 1U..X..134 001→	09.98→	GS,LLE	0 280 752 214
Pedal position sensor, EMS (electronic engine management)			
Fg.no. →1U..X..134 000	03.98-08.98	GS,LLE	0 281 002 269
1.8 T [1U5]	1,8l 110 kW ARX 4 Zyl.		
Throttle valve assembly	08.00-01.06		0 280 750 036
Air mass meter, gasoline injection	08.00-01.06		0 280 218 063
			0 986 280 217
Phase sensor	08.00-01.06		0 232 101 024
Speed sensor, ignition/injection	08.00-01.06		0 261 210 147
Knock sensor	08.00-01.06		0 261 231 146
Boost pressure sensor, gasoline			
Fg.no. →1U..3..758 379,→1U..3A016 199,→1U..38692 715	08.00-01.03		0 281 002 177
Fg.no. 1U..3..758 380→,1U..3A016 200→,1U..38692 716→	02.03-01.06		0 281 002 399
Temperature sensor, intake air, injection system			
Fg.no. →1U..3..716 385,→1U..3A008 026,→1U..38680 305	08.00-09.02		0 280 130 085
Accelerator pedal module	08.00-01.06	GS,LLE	0 280 752 214
1.8 T [1U5]	1,8l 110 kW ARZ 4 Zyl.		
Throttle valve assembly	01.00-07.00		0 280 750 036
Air mass meter, gasoline injection	01.00-07.00		0 280 218 032
			0 986 280 210
Phase sensor	01.00-07.00		0 232 101 024
Speed sensor, ignition/injection	01.00-07.00		0 261 210 147
Temperature sensor, intake air, injection system	01.00-07.00		0 280 130 085
Accelerator pedal module	01.00-07.00	GS,LLE	0 280 752 214
1.8 T [1U5]	1,8l 110 kW AUM 4 Zyl.		
Throttle valve assembly	08.00→		0 280 750 036
Air mass meter, gasoline injection	08.00→		0 280 218 063
			0 986 280 217
Phase sensor	08.00→		0 232 101 024
Speed sensor, ignition/injection	08.00→		0 261 210 147
Knock sensor	08.00→		0 261 231 146
Boost pressure sensor, gasoline			
Fg.no. →1U..3..758 379,→1U..3A016 199,→1U..38692 715	08.00-01.03		0 281 002 177
Fg.no. 1U..3..758 380→,1U..3A016 200→,1U..38692 716→	02.03→		0 281 002 399



Product				

◀ Octavia Combi

Temperature sensor, intake air, injection system			
Fg.no. →1U..3..716 385,→1U..3A008 026,→1U..38680 305	08.00-09.02		0 280 130 085
Accelerator pedal module	08.00→	GS,LLE	0 280 752 214
1.8 T 4x4 [1U5]		1,8 l 110 kW AGU 4 Zyl.	
Air mass meter, gasoline injection	08.00→		0 280 217 117 0 986 280 201
Phase sensor	08.00→		0 232 101 024
Speed sensor, ignition/injection	08.00→		0 261 210 147
Boost pressure sensor, gasoline			
Fg.no. →1U..3..758 379,→1U..3A016 199,→1U..38692 715	08.00-01.03		0 281 002 177
Fg.no. 1U..3..758 380→,1U..3A016 200→,1U..38692 716→	02.03→		0 281 002 399
Temperature sensor, intake air, injection system			
Fg.no. →1U..3..716 385,→1U..3A008 026,→1U..38680 305	08.00-09.02		0 280 130 085
Accelerator pedal module	08.00→	GS,LLE	0 280 752 214
1.8 T 4x4 [1U5]		1,8 l 110 kW ARX 4 Zyl.	
Throttle valve assembly	08.00-01.06		0 280 750 036
Air mass meter, gasoline injection	08.00-01.06		0 280 218 063 0 986 280 217
Phase sensor	08.00-01.06		0 232 101 024
Speed sensor, ignition/injection	08.00-01.06		0 261 210 147
Knock sensor	08.00-01.06		0 261 231 146
Boost pressure sensor, gasoline			
Fg.no. →1U..3..758 379,→1U..3A016 199,→1U..38692 715	08.00-01.03		0 281 002 177
Fg.no. 1U..3..758 380→,1U..3A016 200→,1U..38692 716→	02.03-01.06		0 281 002 399
Temperature sensor, intake air, injection system			
Fg.no. →1U..3..716 385,→1U..3A008 026,→1U..38680 305	08.00-09.02		0 280 130 085
Accelerator pedal module	08.00-01.06	GS,LLE	0 280 752 214
1.8 T 4x4 [1U5]		1,8 l 110 kW ARZ 4 Zyl.	
Throttle valve assembly	01.00-07.00		0 280 750 036
Air mass meter, gasoline injection	01.00-07.00		0 280 218 032 0 986 280 210
Phase sensor	01.00-07.00		0 232 101 024
Speed sensor, ignition/injection	01.00-07.00		0 261 210 147
Temperature sensor, intake air, injection system	01.00-07.00		0 280 130 085
Accelerator pedal module	01.00-07.00	GS,LLE	0 280 752 214
1.8 T 4x4 [1U5]		1,8 l 110 kW AUM 4 Zyl.	
Throttle valve assembly	08.00→		0 280 750 036
Air mass meter, gasoline injection	08.00→		0 280 218 063 0 986 280 217
Phase sensor	08.00→		0 232 101 024
Speed sensor, ignition/injection	08.00→		0 261 210 147
Knock sensor	08.00→		0 261 231 146
Boost pressure sensor, gasoline			
Fg.no. →1U..3..758 379,→1U..3A016 199,→1U..38692 715	08.00-01.03		0 281 002 177
Fg.no. 1U..3..758 380→,1U..3A016 200→,1U..38692 716→	02.03→		0 281 002 399
Temperature sensor, intake air, injection system			
Fg.no. →1U..3..716 385,→1U..3A008 026,→1U..38680 305	08.00-09.02		0 280 130 085
Accelerator pedal module	08.00→	GS,LLE	0 280 752 214
1.9 TDI [1U5]		1,9 l 66 kW AGR 4 Zyl.	
Air mass meter, diesel	08.00→	WW	0 281 002 757 0 986 280 202

Product				

Boost pressure sensor, Diesel			
Fg.no. →1U..3..768 637,→1U..3A016 277,→1U..38696 292	08.00-02.03		0 281 002 177
Fg.no. 1U..3..768 638→,1U..3A016 278→,1U..38696 293→	03.03→		0 281 002 399
1.9 TDI [1U5]		1,9 l 66 kW ALH 4 Zyl.	
Air mass meter, diesel			
Fg.no. →1U..3..836 957,→1U..3A016 708,→1U..38712 468	08.00-07.03	WW	0 281 002 757 0 280 217 121 0 986 280 202
Fg.no. 1U..3..836 958→,1U..3A016 709→,1U..38712 469→	08.03→		0 281 002 531 0 986 284 009
Boost pressure sensor, Diesel			
Fg.no. →1U..3..768 637,→1U..3A016 277,→1U..38696 292	08.00-02.03		0 281 002 177
Fg.no. 1U..3..768 638→,1U..3A016 278→,1U..38696 293→	03.03→		0 281 002 399
1.9 TDI [1U5]		1,9 l 74 kW ATD 4 Zyl.	
Air mass meter, diesel			
Fg.no. →1U..3..666 021,→1U..38665 263	08.00-04.02	WW	0 281 002 757 0 280 217 121 0 986 280 202
Fg.no. 1U..3..666 022→,1U..38665 264→	05.02-09.04		0 281 002 531 0 986 284 009
Boost pressure sensor, Diesel			
Fg.no. →1U..3..768 637,→1U..3A016 277,→1U..38696 292	08.00-02.03		0 281 002 177
Fg.no. 1U..3..768 638→,1U..3A016 278→,1U..38696 293→	03.03-09.04		0 281 002 399
1.9 TDI [1U5]		1,9 l 74 kW AXR 4 Zyl.	
Air mass meter, diesel			
	10.05→		0 281 002 531 0 986 284 009
Boost pressure sensor, Diesel			
	10.05→		0 281 002 399
1.9 TDI [1U5]		1,9 l 81 kW AHF 4 Zyl.	
Air mass meter, diesel			
Fg.no. 1U..W..134 001→	08.98-01.06	WW	0 281 002 757 0 280 217 121 0 986 280 202
Boost pressure sensor, Diesel			
Fg.no. →1U..3..768 637,→1U..3A016 277,→1U..38696 292	08.97-02.03		0 281 002 177
Fg.no. 1U..3..768 638→,1U..3A016 278→,1U..38696 293→	03.03-01.06		0 281 002 399
1.9 TDI [1U5]		1,9 l 81 kW ASV 4 Zyl.	
Air mass meter, diesel			
Fg.no. →1U..3..836 957,→1U..3A016 708,→1U..38712 468	08.00-07.03	WW	0 281 002 757 0 280 217 121 0 986 280 202
Fg.no. 1U..3..836 958→,1U..3A016 709→,1U..38712 469→	08.03-01.06		0 281 002 531 0 986 284 009
Boost pressure sensor, Diesel			
Fg.no. →1U..3..768 637,→1U..3A016 277,→1U..38696 292	08.00-02.03		0 281 002 177
Fg.no. 1U..3..768 638→,1U..3A016 278→,1U..38696 293→	03.03-01.06		0 281 002 399
1.9 TDI [1U5]		1,9 l 96 kW ASZ 4 Zyl.	
Air mass meter, diesel			
	01.03-09.04		0 281 002 461 0 986 284 007
Boost pressure sensor, Diesel			
	01.03-09.04		0 281 002 401
1.9 TDI [1Z5]		1,9 l 77 kW BJB; BKC; BLS; BXE 4 Zyl.	
Air mass meter, diesel			
	05.04→		0 281 002 531 0 986 284 009
Pressure sensor, intake manifold, diesel			
	05.04→		0 281 002 399



Product			
1.9 TDI 4x4 [1U5] 1,9l 66 kW AGR 4 Zyl.			
Air mass meter, diesel	08.00→		0 281 002 757
		WW	0 280 217 121
			0 986 280 202
Boost pressure sensor, Diesel			
Fg.no. →1U..3..768 637,→1U..3A016 277,→1U..38696 292	08.00-02.03		0 281 002 177
Fg.no. 1U..3..768 638→,1U..3A016 278→,1U..38696 293→	03.03→		0 281 002 399
1.9 TDI 4x4 [1U5] 1,9l 74 kW ATD 4 Zyl.			
Air mass meter, diesel			
Fg.no. →1U..3..666 021,→1U..38665 263	08.00-04.02		0 281 002 757
		WW	0 280 217 121
			0 986 280 202
Fg.no. 1U..3..666 022→,1U..38665 264→	05.02-01.06		0 281 002 531
			0 986 284 009
Boost pressure sensor, Diesel			
Fg.no. →1U..3..768 637,→1U..3A016 277,→1U..38696 292	08.00-02.03		0 281 002 177
Fg.no. 1U..3..768 638→,1U..3A016 278→,1U..38696 293→	03.03-01.06		0 281 002 399
1.9 TDI 4x4 [1Z5] 1,9l 77 kW BKC 4 Zyl.			
Air mass meter, diesel	11.04→		0 281 002 531
			0 986 284 009
Speed sensor, diesel	11.04→	TW	0 261 210 233
Pressure sensor, intake manifold, diesel	11.04→		0 281 002 399
1.9 TDI 4x4 [1Z5] 1,9l 77 kW BLS 4 Zyl.			
Air mass meter, diesel	05.06→		0 281 002 531
			0 986 284 009
Pressure sensor, intake manifold, diesel	05.06→		0 281 002 399
1.9 TDI 4x4 [1Z5] 1,9l 77 kW BXE 4 Zyl.			
Air mass meter, diesel	03.06→		0 281 002 531
			0 986 284 009
Speed sensor, diesel	03.06→	TW	0 261 210 233
Pressure sensor, intake manifold, diesel	03.06→		0 281 002 399
2.0 [1U5] 2,0l 85 kW AEG; APK; AQY 4 Zyl.			
Air mass meter, gasoline injection	08.00-01.05		0 280 218 002
			0 986 280 205
Phase sensor	08.00-01.05		0 232 101 031
Speed sensor, ignition/injection	08.00-01.05		0 261 210 147
Knock sensor	08.00-01.05		0 261 231 146
Accelerator pedal module	08.00-01.05	GS,LLE	0 280 752 214
2.0 [1U5] 2,0l 85 kW AZH 4 Zyl.			
Throttle valve assembly	08.00-09.04		0 280 750 061
Air mass meter, gasoline injection	08.00-09.04		0 280 218 002
			0 986 280 205
Phase sensor	08.00-09.04		0 232 101 031
Speed sensor, ignition/injection	08.00-09.04		0 261 210 147
Knock sensor	08.00-09.04		0 261 231 146
Accelerator pedal module	08.00-09.04	GS,LLE	0 280 752 214
2.0 [1U5] 2,0l 85 kW AZJ 4 Zyl.			
Throttle valve assembly	03.02-01.06		0 280 750 061
Air mass meter, gasoline injection	03.02-01.06		0 280 218 060
			0 986 280 216
Phase sensor	03.02-01.06		0 232 101 031
Speed sensor, ignition/injection	03.02-01.06		0 261 210 199
Knock sensor	03.02-01.06		0 261 231 146
Accelerator pedal module	03.02-01.06	GS,LLE	0 280 752 214
2.0 FSI [1Z5] 2,0l 110 kW BLR; BLY; BVY; BVZ 4 Zyl.			
Knock sensor	11.04→	OHL	0 261 231 146
Pressure sensor, intake manifold, gasoline	11.04→		0 261 230 031



2.0 FSI 4x4 [1Z5] 2,0l 110 kW BLX; BVX 4 Zyl.	
Knock sensor	11.04→ OHL 0 261 231 146
Pressure sensor, intake manifold, gasoline	11.04→ 0 261 230 031
2.0 RS [1Z5] 2,0l 147 kW BWA 4 Zyl.	
Speed sensor, ignition/injection	10.05→ 0 261 210 199
Boost pressure sensor, gasoline	10.05→ 0 261 230 073
2.0 TDI [1Z5] 2,0l 100/103 kW AZV; BKD; BMM 4 Zyl.	
Air mass meter, diesel	05.04→ 0 281 002 461
	0 986 284 007
Pressure sensor, intake manifold, diesel	05.04→ 0 281 002 401
2.0 TDI 4x4 [1Z5] 2,0l 103 kW BMM 4 Zyl.	
Air mass meter, diesel	12.05→ 0 281 002 461
	0 986 284 007
Pressure sensor, intake manifold, diesel	12.05→ 0 281 002 401
2.0 4x4 [1U5] 2,0l 85 kW AEG; APK; AQY 4 Zyl.	
Air mass meter, gasoline injection	08.00-01.05 0 280 218 002
	0 986 280 205
Phase sensor	08.00-01.05 0 232 101 031
Speed sensor, ignition/injection	08.00-01.05 0 261 210 147
Knock sensor	08.00-01.05 0 261 231 146
Accelerator pedal module	08.00-01.05 GS,LLE 0 280 752 214
2.0 4x4 [1U5] 2,0l 85 kW AZH 4 Zyl.	
Throttle valve assembly	08.00-09.04 0 280 750 061
Air mass meter, gasoline injection	08.00-09.04 0 280 218 002
	0 986 280 205
Phase sensor	08.00-09.04 0 232 101 031
Speed sensor, ignition/injection	08.00-09.04 0 261 210 147
Knock sensor	08.00-09.04 0 261 231 146
Accelerator pedal module	08.00-09.04 GS,LLE 0 280 752 214
2.0 4x4 [1U5] 2,0l 85 kW AZJ 4 Zyl.	
Throttle valve assembly	03.02-01.06 0 280 750 061
Air mass meter, gasoline injection	03.02-01.06 0 280 218 060
	0 986 280 216
Phase sensor	03.02-01.06 0 232 101 031
Knock sensor	03.02-01.06 0 261 231 146
Accelerator pedal module	03.02-01.06 GS,LLE 0 280 752 214

Pick-Up

135 i.e. 1,3l 40 kW 4 Zyl.	
Temperature sensor, coolant, injection system	07.93-12.97 0 280 130 026

Roomster

1.2 [5J7] 1,2l 47 kW BME 3 Zyl.	
Knock sensor	05.06-01.07 0 261 231 146
Pressure sensor, intake manifold, gasoline	05.06-01.07 0 261 230 031
Accelerator pedal module	05.06-01.07 GS,LLE 0 280 752 214
Duo sensor, acceleration and yaw rate, brake system	05.06-01.07 0 265 005 692
1.2 [5J7] 1,2l 51 kW BZG 3 Zyl.	
Pressure sensor, intake manifold, gasoline	01.07→ 0 261 230 031
Accelerator pedal module	01.07→ GS,LLE 0 280 752 214
Duo sensor, acceleration and yaw rate, brake system	01.07→ 0 265 005 692
1.4 [5J7] 1,4l 63 kW BXW 4 Zyl.	
Knock sensor	05.06→ 0 261 231 146
Pressure sensor, intake manifold, gasoline	05.06→ 0 261 230 095
Accelerator pedal module	05.06→ GS,LLE 0 280 752 214
Duo sensor, acceleration and yaw rate, brake system	05.06→ 0 265 005 692



Product



◀ Roomster

1.4 TDI [5J7]			1,4l 51/59 kW BMS; BNM; BNV 3 Zyl.
Air mass meter, diesel	05.06→	0 281 002 531	🔍 0 986 284 009
Boost pressure sensor, Diesel	05.06→	0 281 002 399	
Duo sensor, acceleration and yaw rate, brake system	05.06→	0 265 005 692	
1.6 [5J7]			1,6l 77 kW BTS 4 Zyl.
Knock sensor	05.06→	0 261 231 146	
Pressure sensor, intake manifold, gasoline	05.06→	0 261 230 095	
Accelerator pedal module	05.06→	GS,LLE 0 280 752 214	
Duo sensor, acceleration and yaw rate, brake system	05.06→	0 265 005 692	
1.9 TDI [5J7]			1,9l 74/77 kW AXR; BLS; BSW 4 Zyl.
Air mass meter, diesel	03.06→	0 281 002 531	🔍 0 986 284 009
Boost pressure sensor, Diesel	03.06→	0 281 002 399	
Duo sensor, acceleration and yaw rate, brake system	03.06→	0 265 005 692	

Superb

1.8 T [3U4]			1,8l 110 kW AWT 4 Zyl.
Throttle valve assembly	12.01→	0 280 750 009	
Air mass meter, gasoline injection	12.01→	0 280 218 100	🔍 0 986 280 223
Phase sensor	12.01→	0 232 101 024	
Speed sensor, ignition/injection	12.01→	0 281 002 222	
Boost pressure sensor, gasoline			
Fg.no. →3U..3..033 808	12.01-12.02	0 281 002 177	
Fg.no. 3U..3..033 809→	01.03→	0 261 230 073	
Temperature sensor, intake air, injection system			
Fg.no. →3U..3..026 512	12.01-08.02	0 280 130 085	
Duo sensor, acceleration and yaw rate, brake system	12.01→	0 265 005 252	
1.9 TDI [3U4]			1,9l 74 kW AVB 4 Zyl.
Air mass meter, diesel	02.02-10.05	0 281 002 463	🔍 0 986 284 008
Boost pressure sensor, Diesel			
Fg.no. →3U..3..023 228	02.02-06.02	0 281 002 177	
Fg.no. 3U..3..023 229→	07.02-10.05	0 281 002 399	
Duo sensor, acceleration and yaw rate, brake system	02.02-10.05	0 265 005 252	
1.9 TDI [3U4]			1,9l 77/85 kW BPZ; BSV 4 Zyl.
Air mass meter, diesel	10.05→	0 281 002 461	🔍 0 986 284 007
Boost pressure sensor, Diesel	10.05→	0 281 002 399	
Duo sensor, acceleration and yaw rate, brake system	10.05→	0 265 005 252	
1.9 TDI [3U4]			1,9l 96 kW AVF; AWX 4 Zyl.
Air mass meter, diesel	12.01→	0 281 002 461	🔍 0 986 284 007
Boost pressure sensor, Diesel	12.01→	0 281 002 401	
Duo sensor, acceleration and yaw rate, brake system	12.01→	0 265 005 252	
2.0 [3U4]			2,0l 85 kW AZM 4 Zyl.
Phase sensor	12.01→	0 232 101 031	
Speed sensor, ignition/injection	12.01→	0 261 210 147	
Duo sensor, acceleration and yaw rate, brake system	12.01→	0 265 005 252	
2.0 TDI [3U4]			2,0l 91/103 kW BSS; BWW 4 Zyl.
Air mass meter, diesel	10.05→	0 281 002 461	🔍 0 986 284 007
Boost pressure sensor, Diesel	10.05→	0 281 002 401	

Product



Duo sensor, acceleration and yaw rate, brake system	10.05→	0 265 005 252	
2.5 TDI [3U4]			2,5l 114 kW AYM 6 Zyl.
Speed sensor, diesel	12.01-08.03	0 281 002 222	
Boost pressure sensor, Diesel	12.01-08.03	0 281 002 177	
Duo sensor, acceleration and yaw rate, brake system	12.01-08.03	0 265 005 252	
2.5 TDI [3U4]			2,5l 120 kW BDG 6 Zyl.
Speed sensor, diesel	06.03→	0 281 002 222	
Boost pressure sensor, Diesel	06.03→	0 281 002 399	
Duo sensor, acceleration and yaw rate, brake system	06.03→	0 265 005 252	
2.8 [3U4]			2,8l 140/142 kW AMX; BBG 6 Zyl.
Throttle valve assembly	12.01→	0 280 750 030	
Phase sensor	12.01→	0 232 101 024	
Speed sensor, ignition/injection	12.01→	AG 0 261 210 147	GS 0 261 210 178
Temperature sensor, intake air, injection system			
Fg.no. →3U..3..026 512	12.01-08.02	0 280 130 085	
Duo sensor, acceleration and yaw rate, brake system	12.01→	0 265 005 252	

SMART (MCC)

Forfour

1.1			1,1l 47/55 kW 3 Zyl.
Pressure sensor, intake manifold, gasoline	01.04-06.07	0 261 230 118	
Lateral acceleration sensor, brake system	01.04-06.07	0 265 005 600	
Wheel speed sensor, front	01.04-06.07	0 265 007 637	
Wheel speed sensor, rear	01.04-06.07	0 265 007 638	
1.3			1,3l 70 kW 4 Zyl.
Pressure sensor, intake manifold, gasoline	01.04-06.07	0 261 230 118	
Lateral acceleration sensor, brake system	01.04-06.07	0 265 005 600	
Wheel speed sensor, front	01.04-06.07	0 265 007 637	
Wheel speed sensor, rear	01.04-06.07	0 265 007 638	
1.5			1,5l 80 kW 4 Zyl.
Pressure sensor, intake manifold, gasoline	01.04-06.07	0 261 230 118	
Lateral acceleration sensor, brake system	01.04-06.07	0 265 005 600	
Wheel speed sensor, front	01.04-06.07	0 265 007 637	
Wheel speed sensor, rear	01.04-06.07	0 265 007 638	
1.5 Brabus			1,5l 130 kW 4 Zyl.
Lateral acceleration sensor, brake system	04.05-06.07	0 265 005 600	
Wheel speed sensor, front	04.05-06.07	0 265 007 637	
Wheel speed sensor, rear	04.05-06.07	0 265 007 638	
1.5 cdi			1,5l 50/70 kW 639.939 3 Zyl.
Speed sensor, diesel	09.04-06.07	FKW 0 261 210 170	
High-pressure sensor (CR system)	09.04-06.07	0 281 002 504	
Lateral acceleration sensor, brake system	09.04-06.07	0 265 005 600	
Wheel speed sensor, front	09.04-06.07	0 265 007 637	
Wheel speed sensor, rear	09.04-06.07	0 265 007 638	
1.5 Sportstyle			1,5l 90 kW 4 Zyl.
Pressure sensor, intake manifold, gasoline	04.04-06.07	0 261 230 118	
Lateral acceleration sensor, brake system	04.04-06.07	0 265 005 600	
Wheel speed sensor, front	04.04-06.07	0 265 007 637	
Wheel speed sensor, rear	04.04-06.07	0 265 007 638	

Fortwo Cabrio

0.7			0,7l 45 kW 160.920 3 Zyl.
Throttle valve assembly	02.04-03.07	0 205 003 055	
Speed sensor, ignition/injection	02.04-03.07	0 261 210 141	



Knock sensor	02.04-03.07	0 261 231 133
Pressure sensor, intake manifold, gasoline	02.04-03.07	0 261 230 049
0.7 Brabus	0,7 l 55 kW 160.910 3 Zyl.	
Throttle valve assembly	02.04-03.07	0 205 003 055
Speed sensor, ignition/injection	02.04-03.07	0 261 210 141
Knock sensor	02.04-03.07	0 261 231 133
Pressure sensor, intake manifold, gasoline	02.04-03.07	0 261 230 049
0.8	0,8 l 33 kW 3 Zyl.	
Speed sensor, diesel	04.07→	0 261 210 141
Pressure sensor, intake manifold, diesel	04.07→	0 261 230 141
Duo sensor, acceleration and yaw rate, brake system	04.07→	0 265 005 687
0.8 cdi	0,8 l 30 kW OM 660.940 3 Zyl.	
Speed sensor, diesel	02.04-03.07 FKW	0 261 210 141
Pressure sensor, intake manifold, gasoline	02.04-03.07	0 261 230 049
High-pressure sensor (CR system)	02.04-03.07	0 281 002 238
1.0	1,0 l 52/62 kW 3 Zyl.	
Duo sensor, acceleration and yaw rate, brake system	04.07→	0 265 005 687
1.0 Brabus	1,0 l 72 kW 3 Zyl.	
Duo sensor, acceleration and yaw rate, brake system	04.07→	0 265 005 687
1.0 mhd	1,0 l 52 kW 3 Zyl.	
Duo sensor, acceleration and yaw rate, brake system	10.07→	0 265 005 687

Fortwo Coupé

0.7	0,7 l 37/45 kW 3 Zyl.	
Throttle valve assembly	02.04-03.07	0 205 003 055
Speed sensor, ignition/injection	02.04-03.07	0 261 210 141
Knock sensor	02.04-03.07	0 261 231 133
Pressure sensor, intake manifold, gasoline	02.04-03.07	0 261 230 049
0.7 Brabus	0,7 l 55 kW 3 Zyl.	
Throttle valve assembly	02.04-03.07	0 205 003 055
Speed sensor, ignition/injection	02.04-03.07	0 261 210 141
Knock sensor	02.04-03.07	0 261 231 133
Pressure sensor, intake manifold, gasoline	02.04-03.07	0 261 230 049
0.8	0,8 l 33 kW 3 Zyl.	
Speed sensor, diesel	04.07→	0 261 210 141
Pressure sensor, intake manifold, diesel	04.07→	0 261 230 141
Duo sensor, acceleration and yaw rate, brake system	04.07→	0 265 005 687
0.8 cdi	0,8 l 30 kW OM 660.940 3 Zyl.	
Speed sensor, diesel	02.04-03.07 FKW	0 261 210 141
Pressure sensor, intake manifold, gasoline	02.04-03.07	0 261 230 049
High-pressure sensor (CR system)	02.04-03.07	0 281 002 238
1.0	1,0 l 45/52/62 kW 3 Zyl.	
Duo sensor, acceleration and yaw rate, brake system	04.07→	0 265 005 687
1.0 Brabus	1,0 l 72 kW 3 Zyl.	
Duo sensor, acceleration and yaw rate, brake system	04.07→	0 265 005 687
1.0 mhd	1,0 l 52 kW 3 Zyl.	
Duo sensor, acceleration and yaw rate, brake system	10.07→	0 265 005 687

Roadster

0.7	0,7 l 45/60 kW 160.921; 160.922 3 Zyl.	
Throttle valve assembly	04.03-11.05	0 205 003 055
Speed sensor, ignition/injection	04.03-11.05	0 261 210 141
Knock sensor	04.03-11.05	0 261 231 133



Pressure sensor, intake manifold, gasoline	04.03-11.05	0 261 230 049
Wheel speed sensor, front	04.03-11.05	0 265 006 753
Brabus	0,7 l 74 kW 160.923 3 Zyl.	
Throttle valve assembly	12.03-11.05	0 205 003 055
Speed sensor, ignition/injection	12.03-11.05	0 261 210 141
Knock sensor	12.03-11.05	0 261 231 133
Pressure sensor, intake manifold, gasoline	12.03-11.05	0 261 230 049
Wheel speed sensor, front	12.03-11.05	0 265 006 753

Roadster-Coupé


0.7	0,7 l 45/60 kW 160.921; 160.922 3 Zyl.	
Throttle valve assembly	04.03-11.05	0 205 003 055
Speed sensor, ignition/injection	04.03-11.05	0 261 210 141
Knock sensor	04.03-11.05	0 261 231 133
Pressure sensor, intake manifold, gasoline	04.03-11.05	0 261 230 049
Wheel speed sensor, front	04.03-11.05	0 265 006 753
Brabus	0,7 l 74 kW 160.923 3 Zyl.	
Throttle valve assembly	12.03-11.05	0 205 003 055
Speed sensor, ignition/injection	12.03-11.05	0 261 210 141
Knock sensor	12.03-11.05	0 261 231 133
Pressure sensor, intake manifold, gasoline	12.03-11.05	0 261 230 049
Wheel speed sensor, front	12.03-11.05	0 265 006 753

Smart Cabrio

0.6	0,6 l 40/45/52 kW 3 Zyl.	
Throttle valve assembly	03.00-01.04	0 205 003 055
Speed sensor, ignition/injection	03.00-01.04	0 261 210 141
Knock sensor	03.00-01.04	0 261 231 133
Pressure sensor, intake manifold, gasoline	03.00-01.04	0 261 230 049
0.7	0,7 l 45 kW 3 Zyl.	
Throttle valve assembly	01.03-01.04	0 205 003 055
Speed sensor, ignition/injection	01.03-01.04	0 261 210 141
Knock sensor	01.03-01.04	0 261 231 133
Pressure sensor, intake manifold, gasoline	01.03-01.04	0 261 230 049
BRABUS	0,7 l 55 kW 3 Zyl.	
Throttle valve assembly	01.03-01.04	0 205 003 055
Speed sensor, ignition/injection	01.03-01.04	0 261 210 141
Knock sensor	01.03-01.04	0 261 231 133
cdi	0,8 l 30 kW OM 660 3 Zyl.	
Speed sensor, diesel	03.01-01.04 FKW	0 261 210 141
Pressure sensor, intake manifold, gasoline	03.01-01.04	0 261 230 049
High-pressure sensor (CR system)	03.01-01.04	0 281 002 238

Smart Coupé

0.6	0,6 l 33/37/40/45/52 kW 3 Zyl.	
Throttle valve assembly	07.98-01.04	0 205 003 055
Speed sensor, ignition/injection	07.98-01.04	0 261 210 141
Knock sensor	07.98-01.04	0 261 231 133
Pressure sensor, intake manifold, gasoline	07.98-01.04	0 261 230 049
0.7	0,7 l 45 kW 3 Zyl.	
Throttle valve assembly	01.03-01.04	0 205 003 055
Speed sensor, ignition/injection	01.03-01.04	0 261 210 141
Knock sensor	01.03-01.04	0 261 231 133
Pressure sensor, intake manifold, gasoline	01.03-01.04	0 261 230 049
BRABUS	0,7 l 55 kW 3 Zyl.	
Throttle valve assembly	01.03-01.04	0 205 003 055
Speed sensor, ignition/injection	01.03-01.04	0 261 210 141
Knock sensor	01.03-01.04	0 261 231 133
Pressure sensor, intake manifold, gasoline	01.03-01.04	0 261 230 049



Product



Smart Coupé

cdi		0,8l 30 kW OM 660 3 Zyl.
Speed sensor, diesel	11.99-01.04	FKW 0 261 210 141
Pressure sensor, intake manifold, gasoline	11.99-01.04	0 261 230 049
High-pressure sensor (CR system)	11.99-01.04	0 281 002 238

Smart Crossblade

0.6		0,6l 52 kW 3 Zyl.
Throttle valve assembly	10.02-01.04	0 205 003 055
Speed sensor, ignition/injection	10.02-01.04	0 261 210 141
Knock sensor	10.02-01.04	0 261 231 133
Pressure sensor, intake manifold, gasoline	10.02-01.04	0 261 230 049

SSANGYONG

Istana

2.3i 16V [L]		2,3l 110 kW M161 E23 4 Zyl.
Air mass meter, gasoline injection	11.96→	0 280 217 100
Speed sensor, ignition/injection	11.96→	0 281 002 123
Wheel speed sensor, front	11.96→	LAB 0 265 006 338
		RAB 0 265 006 339
Wheel speed sensor, rear	11.96→	0 265 006 341

Korando

2.0i [KJ]		2,0l 94 kW M161 E20 4 Zyl.
Air mass meter, gasoline injection	07.96-12.05	0 280 217 100
Speed sensor, ignition/injection	07.96-12.05	0 281 002 123
Wheel speed sensor, front	07.96-12.05	0 265 006 134
Wheel speed sensor, rear	07.96-12.05	0 265 006 343
2.3 D [KJ]		2,3l 58-59 kW OM661 D23 4 Zyl.
Wheel speed sensor, front	07.96-12.05	0 265 006 134
Wheel speed sensor, rear	07.96-12.05	0 265 006 343
2.3i 16V [KJ]		2,3l 103-105 kW M161 E23 4 Zyl.
Air mass meter, gasoline injection	07.96-12.05	0 280 217 100
Speed sensor, ignition/injection	07.96-12.05	0 281 002 123
Wheel speed sensor, front	07.96-12.05	0 265 006 134
Wheel speed sensor, rear	07.96-12.05	0 265 006 343
2.9 D [KJ]		2,9l 70-73 kW OM662 D29 5 Zyl.
Wheel speed sensor, front	07.96-12.05	0 265 006 134
Wheel speed sensor, rear	07.96-12.05	0 265 006 343
2.9 TD Intercooler [KJ]		2,9l 88-97 kW OM662 LA 5 Zyl.
Wheel speed sensor, front	07.96-12.05	0 265 006 134
Wheel speed sensor, rear	07.96-12.05	0 265 006 343
3.2 i [KJ]		3,2l 154-162 kW M162.995 E32 6 Zyl.
Speed sensor, ignition/injection	07.96-12.05	0 261 210 122
Wheel speed sensor, front	07.96-12.05	0 265 006 134
Wheel speed sensor, rear	07.96-12.05	0 265 006 343

Musso

2.0i [MJ]		2,0l 100 kW M161 E20 4 Zyl.
Air mass meter, gasoline injection	05.96-12.05	0 280 217 100
Speed sensor, ignition/injection	05.96-12.05	0 281 002 123
Wheel speed sensor, front	05.96-12.05	0 265 006 134
Wheel speed sensor, rear	05.96-12.05	0 265 006 135
2.3 D [MJ]		2,3l 57-58 kW OM661 D23 4 Zyl.
Wheel speed sensor, front	07.93-12.05	0 265 006 134
Wheel speed sensor, rear	07.93-12.05	0 265 006 135

Product



2.3i [MJ]		2,3l 103-110 kW M161 E23 4 Zyl.
Air mass meter, gasoline injection	05.96-12.05	0 280 217 100
Speed sensor, ignition/injection	05.96-12.05	0 281 002 123
Wheel speed sensor, front	05.96-12.05	0 265 006 134
Wheel speed sensor, rear	05.96-12.05	0 265 006 135
2.9 D [MJ]		2,9l 70-73 kW OM 662 D29 5 Zyl.
Wheel speed sensor, front	07.93-12.05	0 265 006 134
Wheel speed sensor, rear	07.93-12.05	0 265 006 135
2.9 D [MJ]		2,9l 88 kW OM 662 5 Zyl.
Wheel speed sensor, front	07.93-04.05	0 265 006 134
2.9 TD Intercooler [MJ]		2,9l 88 kW OM 662 D29 5 Zyl.
Wheel speed sensor, front	05.97-12.05	0 265 006 134
Wheel speed sensor, rear	05.97-12.05	0 265 006 135
3.2 i [MJ]		3,2l 162 kW M162 E32 6 Zyl.
Air mass meter, gasoline injection	01.96-12.05	0 280 217 517
Speed sensor, ignition/injection	07.96-12.05	0 261 210 122
Wheel speed sensor, front	01.96-12.05	0 265 006 134
Wheel speed sensor, rear	01.96-12.05	0 265 006 135

STEYR (STEYR-DAIMLER-PUCH AG)

G

300 DT		3,0l 130 kW MB OM 606.964 6 Zyl.
Speed sensor, diesel	01.98→	0 281 002 123
Pedal position sensor, diesel	01.98→	0 205 001 029
Wheel speed sensor, front	01.98→	0 265 002 262
320		3,2l 158 kW MB M 112.945 6 Zyl.
Throttle valve assembly	01.98→	0 205 003 046
Air mass meter, gasoline injection	01.98→	0 280 217 515
Phase sensor	01.98→	NOC 0 232 103 022
		0 232 103 037
Speed sensor, ignition/injection	01.98→	0 261 210 170
Knock sensor	01.98→	0 261 231 110
Wheel speed sensor, front	01.98→	0 265 002 262
500 V8		5,0l 218 kW MB M 113.962 8 Zyl.
Throttle valve assembly	01.98→	0 205 003 048
Air mass meter, gasoline injection	01.98→	0 280 217 810
Speed sensor, ignition/injection	01.98→	0 261 210 170
Knock sensor	01.98→	0 261 231 110
Wheel speed sensor, front	01.98→	0 265 002 262

SUZUKI

Alto

0.8 i		0,8l 26,5 kW JL368Q3 3 Zyl.
Throttle valve sensor	07.99-06.07	0 280 122 019
Knock sensor	07.99-06.07	0 261 231 036
Pressure sensor, intake manifold, gasoline	07.99-06.07	0 261 230 011
Temperature sensor, intake air, injection system	07.99-06.07	0 280 130 037

Ignis Hatchback

1.3 DDiS D Turbo		1,2l 51 kW Z13DT 4 Zyl.
Air mass meter, diesel	10.03-12.06	0 281 002 619
Pressure sensor, intake manifold, diesel	10.03-12.06	0 281 002 510



Product



Swift Hatchback

1.3 DDiS D Turbo [MZ]	1,2l 51 kW Z13DT 4 Zyl.
Air mass meter, diesel	08.05→ 0 281 002 619
Pressure sensor, intake manifold, diesel	08.05→ 0 281 002 510

Wagon R+

1.3 DDiS D Turbo [MM]	1,3l 51 kW Z13DT 4 Zyl.
Air mass meter, diesel	09.03-03.06 0 281 002 619
Pressure sensor, intake manifold, diesel	09.03-03.06 0 281 002 510

TATA (TELCO)

Estate

2.0 i 16V [TE]	2,0l 103 kW 4PL 4 Zyl.
Throttle valve sensor	10.95→ 0 280 122 001
Air mass meter, gasoline injection	10.95→ 0 280 217 111
Phase sensor	10.95→ 0 232 103 003
Speed sensor, ignition/injection	10.95→ 0 281 002 102
Knock sensor	10.95→ 0 261 231 091
Temperature sensor, coolant, injection system	10.95→ 0 280 130 026

Sierra

2.0 i 16V	2,0l 103 kW 4PL 4 Zyl.
Throttle valve sensor	10.95→ 0 280 122 001
Air mass meter, gasoline injection	10.95→ 0 280 217 111
Phase sensor	10.95→ 0 232 103 003
Speed sensor, ignition/injection	10.95→ 0 281 002 102
Knock sensor	10.95→ 0 261 231 091
Temperature sensor, coolant, injection system	10.95→ 0 280 130 026

Tatamobile

2.0 i 16V	2,0l 103 kW 4 Zyl.
Throttle valve sensor	10.95→ 0 280 122 001
Air mass meter, gasoline injection	10.95→ 0 280 217 111
Phase sensor	10.95→ 0 232 103 003
Speed sensor, ignition/injection	10.95→ 0 281 002 102
Knock sensor	10.95→ 0 261 231 091
Temperature sensor, coolant, injection system	10.95→ 0 280 130 026

TOYOTA

Auris


1.4 [E15]	1,4l 71 kW 4ZZFE 4 Zyl.
Phase sensor	10.06→ NOC 0 232 103 029
Knock sensor	10.06→ 0 261 231 149
1.4 D-4D [E15]	1,4l 66 kW 1NDTV 4 Zyl.
Wheel speed sensor, rear	03.07→ DRK 0 265 007 802
2.0 D-4D [E15]	2,0l 93 kW 1ADFTV 4 Zyl.
Wheel speed sensor, rear	10.06→ DRK 0 265 007 802
2.2 D-CAT [E15]	2,2l 130 kW 2AD-FHV 4 Zyl.
Duo sensor, acceleration and yaw rate, brake system	02.07→ 0 265 005 650
Wheel speed sensor, front	02.07→ LAB 0 265 007 806
Wheel speed sensor, rear	02.07→ DRK 0 265 007 802

Product



Avensis

1.6 i 16V [T25]	1,6l 81 kW 3ZZFE 4 Zyl.
Duo sensor, acceleration and yaw rate, brake system	01.03-04.06 0 265 005 273
	05.06→ 0 265 005 297
Steering angle sensor, ESP (electronic stability program)	01.03→ 0 265 005 487
Wheel speed sensor, front	01.03→ LAB 0 265 006 676
	RAB 0 265 006 677
1.8 i 16V [T25]	1,8l 95 kW 1ZZFE 4 Zyl.
Duo sensor, acceleration and yaw rate, brake system	01.03-04.06 0 265 005 273
	05.06→ 0 265 005 297
Steering angle sensor, ESP (electronic stability program)	01.03→ 0 265 005 487
Wheel speed sensor, front	01.03→ LAB 0 265 006 676
	RAB 0 265 006 677
2.0 D Turbo [T25]	2,0l 85 kW 1CDFTV 4 Zyl.
Duo sensor, acceleration and yaw rate, brake system	03.03-04.06 0 265 005 273
Steering angle sensor, ESP (electronic stability program)	03.03-04.06 0 265 005 487
Wheel speed sensor, front	03.03-04.06 LAB 0 265 006 676
	RAB 0 265 006 677
2.0 D-4D [T25]	2,0l 93 kW 1ADFTV 4 Zyl.
Duo sensor, acceleration and yaw rate, brake system	04.06→ 0 265 005 297
Steering angle sensor, ESP (electronic stability program)	04.06→ 0 265 005 487
Wheel speed sensor, front	04.06→ LAB 0 265 006 676
	RAB 0 265 006 677
2.0 i 16V [T25]	2,0l 108-114 kW 1AZFSE 4 Zyl.
Duo sensor, acceleration and yaw rate, brake system	01.03-04.06 0 265 005 273
	05.06→ 0 265 005 297
Steering angle sensor, ESP (electronic stability program)	01.03→ 0 265 005 487
Wheel speed sensor, front	01.03→ LAB 0 265 006 676
	RAB 0 265 006 677
2.2 D-CAT [T25]	2,2l 130 kW 2AD-FHV 4 Zyl.
Duo sensor, acceleration and yaw rate, brake system	04.05-04.06 0 265 005 273
	05.06→ 0 265 005 297
Steering angle sensor, ESP (electronic stability program)	04.05→ 0 265 005 487
Wheel speed sensor, front	04.05→ LAB 0 265 006 676
	RAB 0 265 006 677
2.2 D-4D [T25]	2,2l 110 kW 2AD-FTV 4 Zyl.
Duo sensor, acceleration and yaw rate, brake system	04.05-04.06 0 265 005 273
	05.06→ 0 265 005 297
Steering angle sensor, ESP (electronic stability program)	04.05→ 0 265 005 487
Wheel speed sensor, front	04.05→ LAB 0 265 006 676
	RAB 0 265 006 677
2.4 i [T25]	2,4l 120 kW 2AZFSE 4 Zyl.
Duo sensor, acceleration and yaw rate, brake system	09.03-04.06 0 265 005 273
	05.06→ 0 265 005 297
Steering angle sensor, ESP (electronic stability program)	09.03→ 0 265 005 487
Wheel speed sensor, front	09.03→ LAB 0 265 006 676
	RAB 0 265 006 677





Product

Avensis Liftback			
1.6 i 16V [T22]		1,6l 74/81 kW 4AFE 4 Zyl.	
Knock sensor	10.97-07.00	LLE	0 261 231 045
Wheel speed sensor, front	10.97-07.00	LAB	0 265 006 665
		RAB	0 265 006 666
Wheel speed sensor, rear	10.97-07.00	LAB	0 265 006 667
		RAB	0 265 006 668
1.6 i 16V [T22]		1,6l 81 kW 3ZZFE 4 Zyl.	
Wheel speed sensor, front	07.00-01.03	LAB	0 265 006 665
		RAB	0 265 006 666
Wheel speed sensor, rear	07.00-01.03	LAB	0 265 006 667
		RAB	0 265 006 668
1.6 i 16V [T25]		1,6l 81 kW 3ZZFE 4 Zyl.	
Duo sensor, acceleration and yaw rate, brake system	01.03-04.06		0 265 005 273
	05.06→		0 265 005 297
Steering angle sensor, ESP (electronic stability program)	01.03→		0 265 005 487
Wheel speed sensor, front	01.03→	LAB	0 265 006 676
		RAB	0 265 006 677
1.8 i 16V [T22]		1,8l 81/95 kW 1ZZFE; 7AFE 4 Zyl.	
Wheel speed sensor, front	10.97-01.03	LAB	0 265 006 665
		RAB	0 265 006 666
Wheel speed sensor, rear	10.97-01.03	LAB	0 265 006 667
		RAB	0 265 006 668
1.8 i 16V [T25]		1,8l 95 kW 1ZZFE 4 Zyl.	
Duo sensor, acceleration and yaw rate, brake system	01.03-04.06		0 265 005 273
	05.06→		0 265 005 297
Steering angle sensor, ESP (electronic stability program)	01.03→		0 265 005 487
Wheel speed sensor, front	01.03→	LAB	0 265 006 676
		RAB	0 265 006 677
2.0 D Turbo [T22]		2,0l 66/85 kW 1CDFTV; 2CTE 4 Zyl.	
Wheel speed sensor, front	10.97-01.03	LAB	0 265 006 665
		RAB	0 265 006 666
Wheel speed sensor, rear	10.97-01.03	LAB	0 265 006 667
		RAB	0 265 006 668
2.0 D Turbo [T25]		2,0l 85 kW 1CDFTV 4 Zyl.	
Duo sensor, acceleration and yaw rate, brake system	03.03-04.06		0 265 005 273
Steering angle sensor, ESP (electronic stability program)	03.03-04.06		0 265 005 487
Wheel speed sensor, front	03.03-04.06	LAB	0 265 006 676
		RAB	0 265 006 677
2.0 D-4D [T25]		2,0l 93 kW 1ADFTV 4 Zyl.	
Duo sensor, acceleration and yaw rate, brake system	04.06→		0 265 005 297
Steering angle sensor, ESP (electronic stability program)	04.06→		0 265 005 487
Wheel speed sensor, front	04.06→	LAB	0 265 006 676
		RAB	0 265 006 677
2.0 i 16V [T22]		2,0l 94/110 kW 1AZFSE; 3SFE 4 Zyl.	
Wheel speed sensor, front	10.97-01.03	LAB	0 265 006 665
		RAB	0 265 006 666
Wheel speed sensor, rear	10.97-01.03	LAB	0 265 006 667
		RAB	0 265 006 668
2.0 i 16V [T25]		2,0l 110 kW 1AZFSE 4 Zyl.	
Duo sensor, acceleration and yaw rate, brake system	01.03-04.06		0 265 005 273
	05.06→		0 265 005 297
Steering angle sensor, ESP (electronic stability program)	01.03→		0 265 005 487
Wheel speed sensor, front	01.03→	LAB	0 265 006 676
		RAB	0 265 006 677

Product

2.2 D-CAT [T25]		2,2l 130 kW 2AD-FHV 4 Zyl.	
Duo sensor, acceleration and yaw rate, brake system	04.05-04.06		0 265 005 273
	05.06→		0 265 005 297
Steering angle sensor, ESP (electronic stability program)	04.05→		0 265 005 487
Wheel speed sensor, front	04.05→	LAB	0 265 006 676
		RAB	0 265 006 677
2.2 D-4D [T25]		2,2l 110 kW 2AD-FTV 4 Zyl.	
Duo sensor, acceleration and yaw rate, brake system	04.05-04.06		0 265 005 273
	05.06→		0 265 005 297
Steering angle sensor, ESP (electronic stability program)	04.05→		0 265 005 487
Wheel speed sensor, front	04.05→	LAB	0 265 006 676
		RAB	0 265 006 677
2.4 i [T25]		2,4l 120 kW 2AZFSE 4 Zyl.	
Duo sensor, acceleration and yaw rate, brake system	09.03-04.06		0 265 005 273
	05.06→		0 265 005 297
Steering angle sensor, ESP (electronic stability program)	09.03→		0 265 005 487
Wheel speed sensor, front	09.03→	LAB	0 265 006 676
		RAB	0 265 006 677

Avensis Sedan			
1.6 i 16V [T22]		1,6l 74/81 kW 4AFE 4 Zyl.	
Knock sensor	10.97-07.00	LLE	0 261 231 045
Wheel speed sensor, front	10.97-07.00	LAB	0 265 006 665
		RAB	0 265 006 666
Wheel speed sensor, rear	10.97-07.00	LAB	0 265 006 667
		RAB	0 265 006 668
1.6 i 16V [T22]		1,6l 81 kW 3ZZFE 4 Zyl.	
Wheel speed sensor, front	07.00-01.03	LAB	0 265 006 665
		RAB	0 265 006 666
Wheel speed sensor, rear	07.00-01.03	LAB	0 265 006 667
		RAB	0 265 006 668
1.8 i 16V [T22]		1,8l 81/95 kW 1ZZFE; 7AFE 4 Zyl.	
Wheel speed sensor, front	10.97-01.03	LAB	0 265 006 665
		RAB	0 265 006 666
Wheel speed sensor, rear	10.97-01.03	LAB	0 265 006 667
		RAB	0 265 006 668
2.0 D Turbo [T22]		2,0l 66/85 kW 1CDFTV; 2CT; 2CTE 4 Zyl.	
Wheel speed sensor, front	10.97-01.03	LAB	0 265 006 665
		RAB	0 265 006 666
Wheel speed sensor, rear	10.97-01.03	LAB	0 265 006 667
		RAB	0 265 006 668
2.0 i 16V [T22]		2,0l 94/110 kW 1AZFSE; 3SFE 4 Zyl.	
Wheel speed sensor, front	10.97-01.03	LAB	0 265 006 665
		RAB	0 265 006 666
Wheel speed sensor, rear	10.97-01.03	LAB	0 265 006 667
		RAB	0 265 006 668

Avensis Wagon			
1.6 i 16V [T22]		1,6l 74/81 kW 4AFE 4 Zyl.	
Knock sensor	10.97-07.00	LLE	0 261 231 045
Wheel speed sensor, front	10.97-07.00	LAB	0 265 006 665
		RAB	0 265 006 666
Wheel speed sensor, rear	10.97-07.00	LAB	0 265 006 667
		RAB	0 265 006 668
1.6 i 16V [T22]		1,6l 81 kW 3ZZFE 4 Zyl.	
Wheel speed sensor, front	07.00-01.03	LAB	0 265 006 665
		RAB	0 265 006 666



Wheel speed sensor, rear	07.00-01.03	LAB	0 265 006 667
		RAB	0 265 006 668
1.6 i 16V [T25]	1,6 l 81 kW 3ZZFE 4 Zyl.		
Duo sensor, acceleration and yaw rate, brake system	01.03-04.06		0 265 005 273
	05.06→		0 265 005 297
Steering angle sensor, ESP (electronic stability program)	01.03→		0 265 005 487
Wheel speed sensor, front	01.03→	LAB	0 265 006 676
		RAB	0 265 006 677
1.8 i 16V [T22]	1,8 l 81/95 kW 1ZZFE; 7AFE 4 Zyl.		
Wheel speed sensor, front	10.97-01.03	LAB	0 265 006 665
		RAB	0 265 006 666
Wheel speed sensor, rear	10.97-01.03	LAB	0 265 006 667
		RAB	0 265 006 668
1.8 i 16V [T25]	1,8 l 95 kW 1ZZFE 4 Zyl.		
Duo sensor, acceleration and yaw rate, brake system	01.03-04.06		0 265 005 273
	05.06→		0 265 005 297
Steering angle sensor, ESP (electronic stability program)	01.03→		0 265 005 487
Wheel speed sensor, front	01.03→	LAB	0 265 006 676
		RAB	0 265 006 677
2.0 D Turbo [T22]	2,0 l 66/85 kW 1CDFTV; 2CTE 4 Zyl.		
Wheel speed sensor, front	10.97-01.03	LAB	0 265 006 665
		RAB	0 265 006 666
Wheel speed sensor, rear	10.97-01.03	LAB	0 265 006 667
		RAB	0 265 006 668
2.0 D Turbo [T25]	2,0 l 85 kW 1CDFTV 4 Zyl.		
Duo sensor, acceleration and yaw rate, brake system	03.03-04.06		0 265 005 273
Steering angle sensor, ESP (electronic stability program)	03.03-04.06		0 265 005 487
Wheel speed sensor, front	03.03-04.06	LAB	0 265 006 676
		RAB	0 265 006 677
2.0 D-4D [T25]	2,0 l 93 kW 1ADFTV 4 Zyl.		
Duo sensor, acceleration and yaw rate, brake system	04.06→		0 265 005 297
Steering angle sensor, ESP (electronic stability program)	04.06→		0 265 005 487
Wheel speed sensor, front	04.06→	LAB	0 265 006 676
		RAB	0 265 006 677
2.0 i 16V [T22]	2,0 l 94/110 kW 1AZFSE; 3SFE 4 Zyl.		
Wheel speed sensor, front	10.97-01.03	LAB	0 265 006 665
		RAB	0 265 006 666
Wheel speed sensor, rear	10.97-01.03	LAB	0 265 006 667
		RAB	0 265 006 668
2.0 i 16V [T25]	2,0 l 110 kW 1AZFSE 4 Zyl.		
Duo sensor, acceleration and yaw rate, brake system	01.03-04.06		0 265 005 273
	05.06→		0 265 005 297
Steering angle sensor, ESP (electronic stability program)	01.03→		0 265 005 487
Wheel speed sensor, front	01.03→	LAB	0 265 006 676
		RAB	0 265 006 677
2.2 D-CAT [T25]	2,2 l 130 kW 2AD-FHV 4 Zyl.		
Duo sensor, acceleration and yaw rate, brake system	04.05-04.06		0 265 005 273
	05.06→		0 265 005 297
Steering angle sensor, ESP (electronic stability program)	04.05→		0 265 005 487
Wheel speed sensor, front	04.05→	LAB	0 265 006 676
		RAB	0 265 006 677
2.2 D-4D [T25]	2,2 l 110 kW 2AD-FTV 4 Zyl.		
Duo sensor, acceleration and yaw rate, brake system	04.05-04.06		0 265 005 273
	05.06→		0 265 005 297



Steering angle sensor, ESP (electronic stability program)	04.05→		0 265 005 487
Wheel speed sensor, front	04.05→	LAB	0 265 006 676
		RAB	0 265 006 677
2.4 i [T25]	2,4 l 120 kW 2AZFSE 4 Zyl.		
Duo sensor, acceleration and yaw rate, brake system	09.03-04.06		0 265 005 273
	05.06→		0 265 005 297
Steering angle sensor, ESP (electronic stability program)	09.03→		0 265 005 487
Wheel speed sensor, front	09.03→	LAB	0 265 006 676
		RAB	0 265 006 677

Aygo

1.0 i	1,0 l 50 kW 1KRFE 3 Zyl.		
Phase sensor	02.05→		0 232 103 069
Wheel speed sensor, front	02.05→		0 265 007 687
Wheel speed sensor, rear	02.05→		0 265 007 688
1.4 HDi	1,4 l 40 kW 2WZTV 4 Zyl.		
Wheel speed sensor, front	02.05→		0 265 007 687
Wheel speed sensor, rear	02.05→		0 265 007 688

Carina E Liftback

1.6 i 16V [T19]	1,6 l 75 kW 4AFE 4 Zyl.		
Throttle valve sensor	02.94-01.96		0 280 122 008
Knock sensor	03.94-01.96	GS	0 261 231 103
Wheel speed sensor, front	11.94-01.96	LAB	0 265 001 417
		RAB	0 265 001 416
1.6 i 16V [T19]	1,6 l 79 kW 4AFE 4 Zyl.		
Throttle valve sensor	12.93-10.97		0 280 122 008
Knock sensor	03.94-10.97	GS	0 261 231 103
Wheel speed sensor, front	11.94-01.96	LAB	0 265 001 417
	02.96-10.97	LAB	0 265 001 417
	11.94-01.96	RAB	0 265 001 416
	02.96-10.97	RAB	0 265 001 416
Wheel speed sensor, rear	02.96-10.97	LAB	0 265 001 419
		RAB	0 265 001 418
1.6 i 16V [T19]	1,6 l 85 kW 4AFE 4 Zyl.		
Knock sensor	03.94-10.97	GS	0 261 231 103
Wheel speed sensor, front	11.94-01.96	LAB	0 265 001 417
	02.96-10.97	LAB	0 265 001 417
	11.94-01.96	RAB	0 265 001 416
	02.96-10.97	RAB	0 265 001 416
Wheel speed sensor, rear	02.96-10.97	LAB	0 265 001 419
		RAB	0 265 001 418
1.8 i 16V [T19]	1,8 l 79 kW 7AFE 4 Zyl.		
Wheel speed sensor, front	12.94-01.96	LAB	0 265 001 417
	02.96-10.97	LAB	0 265 001 417
	12.94-01.96	RAB	0 265 001 416
	02.96-10.97	RAB	0 265 001 416
Wheel speed sensor, rear	02.96-10.97	LAB	0 265 001 419
		RAB	0 265 001 418
2.0 D [T19]	2,0 l 53-54 kW 2C 4 Zyl.		
Wheel speed sensor, front	11.94-01.96	LAB	0 265 001 417
		RAB	0 265 001 416
2.0 D Turbo [T19]	2,0 l 61 kW 2CT 4 Zyl.		
Wheel speed sensor, front	01.96-10.97	LAB	0 265 001 417
	02.96-10.97	RAB	0 265 001 416
Wheel speed sensor, rear	02.96-10.97	LAB	0 265 001 419
		RAB	0 265 001 418



Product				

◀ Carina E Liftback

2.0i 16V [T19]	2,0l 98 kW 3SFE 4 Zyl.		
Wheel speed sensor, front	11.94-01.96	LAB	0 265 001 417
	02.96-10.97	LAB	0 265 001 417
	11.94-01.96	RAB	0 265 001 416
	02.96-10.97	RAB	0 265 001 416
Wheel speed sensor, rear	02.96-10.97	LAB	0 265 001 419
		RAB	0 265 001 418

Carina E Sedan

1.6i 16V [T19]	1,6l 75 kW 4AFE 4 Zyl.		
Throttle valve sensor	02.94-01.96		0 280 122 008
Knock sensor	03.94-01.96	GS	0 261 231 103
Wheel speed sensor, front	11.94-01.96	LAB	0 265 001 417
		RAB	0 265 001 416

1.6i 16V [T19]	1,6l 79 kW 4AFE 4 Zyl.		
Throttle valve sensor	12.92-10.97		0 280 122 008
Knock sensor	03.94-10.97	GS	0 261 231 103
Wheel speed sensor, front	11.94-01.96	LAB	0 265 001 417
	02.96-10.97	LAB	0 265 001 417
	11.94-01.96	RAB	0 265 001 416
	02.96-10.97	RAB	0 265 001 416
Wheel speed sensor, rear	02.96-10.97	LAB	0 265 001 419
		RAB	0 265 001 418

1.6i 16V [T19]	1,6l 85 kW 4AFE 4 Zyl.		
Knock sensor	03.94-10.97	GS	0 261 231 103
Wheel speed sensor, front	11.94-01.96	LAB	0 265 001 417
	02.96-10.97	LAB	0 265 001 417
	11.94-01.96	RAB	0 265 001 416
	02.96-10.97	RAB	0 265 001 416
Wheel speed sensor, rear	02.96-10.97	LAB	0 265 001 419
		RAB	0 265 001 418

1.8i 16V [T19]	1,8l 79 kW 7AFE 4 Zyl.		
Wheel speed sensor, front	12.94-01.96	LAB	0 265 001 417
	02.96-10.97	LAB	0 265 001 417
	12.94-01.96	RAB	0 265 001 416
	02.96-10.97	RAB	0 265 001 416
Wheel speed sensor, rear	02.96-10.97	LAB	0 265 001 419
		RAB	0 265 001 418

2.0D [T19]	2,0l 53-54 kW 2C 4 Zyl.		
Wheel speed sensor, front	11.94-01.96	LAB	0 265 001 417
		RAB	0 265 001 416

2.0D Turbo [T19]	2,0l 61 kW 2CT 4 Zyl.		
Wheel speed sensor, front	01.96-10.97	LAB	0 265 001 417
	02.96-10.97	RAB	0 265 001 416

Wheel speed sensor, rear	02.96-10.97	LAB	0 265 001 419
		RAB	0 265 001 418

2.0i 16V [T19]	2,0l 98 kW 3SFE 4 Zyl.		
Wheel speed sensor, front	11.94-01.96	LAB	0 265 001 417
	02.96-10.97	LAB	0 265 001 417
	11.94-01.96	RAB	0 265 001 416
	02.96-10.97	RAB	0 265 001 416
Wheel speed sensor, rear	02.96-10.97	LAB	0 265 001 419
		RAB	0 265 001 418

Carina E Wagon

1.6i 16V [T19]	1,6l 79 kW 4AFE 4 Zyl.		
Knock sensor	05.95-10.97	GS	0 261 231 103
Wheel speed sensor, front	05.95-01.96	LAB	0 265 001 417
	02.96-10.97	LAB	0 265 001 417
	05.95-01.96	RAB	0 265 001 416
	02.96-10.97	RAB	0 265 001 416

Product				

Wheel speed sensor, rear	02.96-10.97	LAB	0 265 001 419
		RAB	0 265 001 418

1.8i 16V [T19]	1,8l 79 kW 7AFE 4 Zyl.		
Wheel speed sensor, front	05.95-01.96	LAB	0 265 001 417
	02.96-10.97	LAB	0 265 001 417
	05.95-01.96	RAB	0 265 001 416
	02.96-10.97	RAB	0 265 001 416
Wheel speed sensor, rear	02.96-10.97	LAB	0 265 001 419
		RAB	0 265 001 418

2.0D [T19]	2,0l 53-54 kW 2C 4 Zyl.		
Wheel speed sensor, front	05.95-01.96	LAB	0 265 001 417
		RAB	0 265 001 416

2.0D Turbo [T19]	2,0l 61 kW 2CT 4 Zyl.		
Wheel speed sensor, front	01.96-10.97	LAB	0 265 001 417
	02.96-10.97	RAB	0 265 001 416

Wheel speed sensor, rear	02.96-10.97	LAB	0 265 001 419
		RAB	0 265 001 418

2.0i 16V [T19]	2,0l 98 kW 3SFE 4 Zyl.		
Wheel speed sensor, front	05.95-01.96	LAB	0 265 001 417
	02.96-10.97	LAB	0 265 001 417
	05.95-01.96	RAB	0 265 001 416
	02.96-10.97	RAB	0 265 001 416
Wheel speed sensor, rear	02.96-10.97	LAB	0 265 001 419
		RAB	0 265 001 418

Corolla

1.4i [E12]	1,4l 71 kW 4ZZFE 4 Zyl.		
Speed sensor, ignition/injection	09.02-07.07	NOC	0 232 103 029
Knock sensor	09.02-07.07		0 261 231 149

Corolla Altis

1.6i	1,6l 82 kW 3ZZFE 4 Zyl.		
Phase sensor	05.01→		0 281 002 406
1.8i	1,8l 101 kW 1ZZFE 4 Zyl.		
Phase sensor	03.99→		0 281 002 406

Corolla Hatchback

1.4D Turbo [E12]	1,4l 66 kW 1NDTV 4 Zyl.		
Duo sensor, acceleration and yaw rate, brake system	09.02→		0 265 005 297

Steering angle sensor, ESP (electronic stability program)	09.02→		0 265 005 487

1.4i 16V [E11]	1,4l 71 kW 4ZZFE 4 Zyl.		
Throttle valve sensor	10.99-07.01		0 280 122 008
Knock sensor	10.99-07.01		0 261 231 149

1.4i 16V [E12]	1,4l 71 kW 4ZZFE 4 Zyl.		
Speed sensor, ignition/injection	11.01→	NOC	0 232 103 029
Knock sensor	11.01→		0 261 231 149
Duo sensor, acceleration and yaw rate, brake system	11.01→		0 265 005 297
Steering angle sensor, ESP (electronic stability program)	11.01→		0 265 005 487

1.6i 16V [E12]	1,6l 81 kW 3ZZFE 4 Zyl.		
Duo sensor, acceleration and yaw rate, brake system	11.01→		0 265 005 297

1.8i 16V [E12]	1,8l 140-165 kW 2ZZGE 4 Zyl.		
Duo sensor, acceleration and yaw rate, brake system	11.01-05.04		0 265 005 273
	06.04→		0 265 005 297
Steering angle sensor, ESP (electronic stability program)	11.01→		0 265 005 487



Wheel speed sensor, front	11.01→	LAB	0 265 006 676
		RAB	0 265 006 677

Corolla Liftback

1.4 i 16V [E11]		1,4 l 71 kW 4ZZFE 4 Zyl.	
Throttle valve sensor	10.99-09.01		0 280 122 008
Knock sensor	10.99-09.01		0 261 231 149

Corolla RunX

1.4 i [E12]		1,4 l 71 kW 4ZZFE 4 Zyl.	
Speed sensor, ignition/injection	09.02-07.07	NOC	0 232 103 029
Knock sensor	09.02-07.07		0 261 231 149

Corolla Sedan

1.4 D Turbo [E12]		1,4 l 66 kW 1NDTV 4 Zyl.	
Duo sensor, acceleration and yaw rate, brake system	01.02→		0 265 005 297
Steering angle sensor, ESP (electronic stability program)	01.02→		0 265 005 487
1.4 i 16V [E11]		1,4 l 71 kW 4ZZFE 4 Zyl.	
Throttle valve sensor	10.99-09.01		0 280 122 008
Knock sensor	10.99-09.01		0 261 231 149
1.4 i 16V [E12]		1,4 l 71 kW 4ZZFE 4 Zyl.	
Speed sensor, ignition/injection	10.01→	NOC	0 232 103 029
Knock sensor	10.01→		0 261 231 149
Duo sensor, acceleration and yaw rate, brake system	10.01→		0 265 005 297
Steering angle sensor, ESP (electronic stability program)	10.01→		0 265 005 487
1.6 i 16V [E12]		1,6 l 81 kW 3ZZFE 4 Zyl.	
Duo sensor, acceleration and yaw rate, brake system	10.01→		0 265 005 297
1.8 i 16V		1,8 l 100 kW 1ZZFE 4 Zyl.	
Wheel speed sensor, front	05.02→	LAB	0 265 006 676
		RAB	0 265 006 677

Corolla Verso

1.6 i 16V [R10/11]		1,6 l 81 kW 3ZZFE 4 Zyl.	
Duo sensor, acceleration and yaw rate, brake system	02.04→		0 265 005 297
Steering angle sensor, ESP (electronic stability program)	02.04→	TW	0 265 005 487
Wheel speed sensor, front	02.04→	LAB	0 265 006 676
		RAB	0 265 006 677
1.8 i 16V [R10/11]		1,8 l 95 kW 1ZZFE 4 Zyl.	
Duo sensor, acceleration and yaw rate, brake system	02.04→		0 265 005 297
Steering angle sensor, ESP (electronic stability program)	02.04→	TW	0 265 005 487
Wheel speed sensor, front	02.04→	LAB	0 265 006 676
		RAB	0 265 006 677
1.8 i 16V [R11]		1,8 l 95 kW 1ZZFE 4 Zyl.	
Duo sensor, acceleration and yaw rate, brake system	02.04→		0 265 005 297
Steering angle sensor, ESP (electronic stability program)	02.04→	TW	0 265 005 487
Wheel speed sensor, front	02.04→	LAB	0 265 006 676
		RAB	0 265 006 677




2.0 D Turbo [E12]		2,0 l 66 kW 1CDFTV 4 Zyl.	
Knock sensor	09.01-01.04		0 261 231 149
2.0 D Turbo [R10/11]		2,0 l 66 kW 1CDFTV 4 Zyl.	
Duo sensor, acceleration and yaw rate, brake system	02.04-08.05		0 265 005 297
Steering angle sensor, ESP (electronic stability program)	02.04-08.05	TW	0 265 005 432
Wheel speed sensor, front	02.04-08.05	LAB	0 265 006 676
		RAB	0 265 006 677
2.2 D-CAT [R10/11]		2,2 l 130 kW 2AD-FHV 4 Zyl.	
Duo sensor, acceleration and yaw rate, brake system	08.05→		0 265 005 297
Steering angle sensor, ESP (electronic stability program)	08.05→		0 265 005 487
Wheel speed sensor, front	08.05→	LAB	0 265 006 676
		RAB	0 265 006 677
2.2 D-4D [R10/11]		2,2 l 100 kW 2AD-FTV 4 Zyl.	
Duo sensor, acceleration and yaw rate, brake system	08.05→		0 265 005 297
Steering angle sensor, ESP (electronic stability program)	08.05→		0 265 005 487
Wheel speed sensor, front	08.05→	LAB	0 265 006 676
		RAB	0 265 006 677

Corolla Wagon

1.4 D Turbo [E12]		1,4 l 66 kW 1NDTV 4 Zyl.	
Duo sensor, acceleration and yaw rate, brake system	01.02→		0 265 005 297
Steering angle sensor, ESP (electronic stability program)	01.02→		0 265 005 487
1.4 i 16V [E11]		1,4 l 71 kW 4ZZFE 4 Zyl.	
Throttle valve sensor	10.99-09.01		0 280 122 008
Knock sensor	10.99-09.01		0 261 231 149
1.4 i 16V [E12]		1,4 l 71 kW 4ZZFE 4 Zyl.	
Speed sensor, ignition/injection	10.01→	NOC	0 232 103 029
Knock sensor	10.01→		0 261 231 149
Duo sensor, acceleration and yaw rate, brake system	10.01→		0 265 005 297
Steering angle sensor, ESP (electronic stability program)	10.01→		0 265 005 487
1.6 i 16V [E12]		1,6 l 81 kW 3ZZFE 4 Zyl.	
Duo sensor, acceleration and yaw rate, brake system	10.01→		0 265 005 297
1.8 i 16V Fielder		1,8 l 100 kW 1ZZFE 4 Zyl.	
Wheel speed sensor, front	05.04→	LAB	0 265 006 676
		RAB	0 265 006 677

Yaris

1.0 i 16V [P1]		1,0 l 50 kW 1SZ-FE 4 Zyl.	
Knock sensor	01.01-02.03		0 261 231 045
Wheel speed sensor, front	01.01→	LAB	0 265 006 674
		RAB	0 265 006 675
1.0 VVT-i [P9]		1,0 l 51 kW 1KR-FE 3 Zyl.	
Phase sensor	08.05→	NOC	0 232 103 069
1.3 i 16V [P1]		1,3 l 63 kW 2SZ-FE 4 Zyl.	
Phase sensor	05.02→	NOC	0 232 103 036
Wheel speed sensor, front	05.02→	LAB	0 265 006 674
		RAB	0 265 006 675
1.3 VVT-i [P9]		1,3 l 64 kW 2SZ-FE 4 Zyl.	
Phase sensor	11.05→	NOC	0 232 103 036





Product

◀ Yaris

1.4 D Turbo [P1]		1,4l 55 kW 1ND-TV 4 Zyl.
Phase sensor	10.01→	0 281 002 406
Wheel speed sensor, front	02.03→	LAB 0 265 006 674
		RAB 0 265 006 675
1.4 D-4D [P9]		1,4l 66 kW 1ND-TV 4 Zyl.
Speed sensor, diesel	11.05→	NOC 0 281 002 406

Yaris Verso	
1.4 D Turbo [P2]	
Phase sensor	08.01-09.05 FKW 0 281 002 406

UAZ

Hunter	
2.2 D 4x4 [UAZ-315148]	
Throttle valve sensor	01.06→ 0 280 122 001
Speed sensor, ignition/injection	01.06→ 0 261 210 113
2.7 i 4x4 [UAZ-315195]	
Throttle valve sensor	01.06→ 0 280 122 001
Air mass meter, gasoline injection	01.06→ TW 0 280 212 014
	0 986 280 108
	0 280 218 037
	0 986 280 108
Phase sensor	01.06→ 0 232 103 006
	Speed sensor, ignition/injection 01.06→ 0 261 210 113
	Knock sensor 01.06→ 0 261 231 046
	Pressure sensor, intake manifold, gasoline 01.06→ TW 0 261 230 004

Patriot	
2.7 4x4 [UAZ-3163]	
Throttle valve sensor	09.05→ 0 280 122 001
Air mass meter, gasoline injection	09.05→ 0 280 218 037
	TW 0 280 212 014
	0 986 280 108
	0 280 218 037
Phase sensor	09.05→ 0 232 103 006
	Speed sensor, ignition/injection 09.05→ 0 261 210 113
	Knock sensor 09.05→ 0 261 231 046
	Pressure sensor, intake manifold, gasoline 09.05→ TW 0 261 230 004
Acceleration sensor, ABS	09.06→ 0 265 005 146
	Wheel speed sensor, front 09.06→ LAB 0 265 007 799
	RAB 0 265 007 800

3160	
2.4 i	
Throttle valve sensor	08.97→ 0 280 122 001
Air mass meter, gasoline injection	08.97→ 0 280 212 022
	0 986 280 133
Phase sensor	08.97→ 0 232 103 006
Knock sensor	08.97→ 0 261 231 046

Product

31605	
2.9 i	
Throttle valve sensor	08.97→ 0 280 122 001
Air mass meter, gasoline injection	08.97→ 0 280 212 022
	0 986 280 133
Phase sensor	08.97→ 0 232 103 006
Knock sensor	08.97→ 0 261 231 046

VAUXHALL

Agila	
1.0 i	
Throttle valve assembly	09.99-08.03 0 280 750 044
Air mass meter, gasoline injection	09.99-08.03 0 280 218 031
	0 986 280 230
Phase sensor	09.99-08.03 NOC 0 232 103 021
Speed sensor, ignition/injection	09.99-08.03 FKW 0 261 210 151
Knock sensor	09.99-08.03 0 261 231 120
Temperature sensor, coolant, injection system	
Mot.no. →19T85744	09.99-08.03 0 281 002 169
	Mot.no. 19T85745→ 09.99-08.03 0 281 002 170
1.0 Twinport	
Throttle valve assembly	08.03-02.08 0 280 750 133
Air mass meter, gasoline injection	08.03-02.08 0 280 218 119
Phase sensor	
Fg.no. →5G999999	08.03-02.08 NOC 0 232 103 052
	Fg.no. 6G000001→ 08.03-02.08 NOC 0 232 103 067
Speed sensor, ignition/injection	08.03-02.08 FKW 0 261 210 151
Knock sensor	08.03-02.08 0 261 231 173
1.2 i	
Throttle valve assembly	09.00-06.04 0 280 750 044
Air mass meter, gasoline injection	09.00-06.04 0 280 218 031
	0 986 280 230
Phase sensor	09.00-06.04 NOC 0 232 103 021
Speed sensor, ignition/injection	09.00-06.04 FKW 0 261 210 151
Knock sensor	09.00-06.04 0 261 231 120
Temperature sensor, coolant, injection system	
Mot.no. →19T85744	09.00-06.04 0 281 002 169
	Mot.no. 19T85745→ 09.00-06.04 0 281 002 170
1.2 Twinport	
Throttle valve assembly	07.04-02.08 0 280 750 133
Air mass meter, gasoline injection	07.04-02.08 0 280 218 119
Phase sensor	07.04-02.08 NOC 0 232 103 052
Speed sensor, ignition/injection	07.04-02.08 FKW 0 261 210 151
Knock sensor	07.04-02.08 0 261 231 173

Antara	
3.2 V6	
Knock sensor	05.06→ 0 261 231 174

Astra	
1.2 i [G]	
Throttle valve assembly	09.97-08.00 0 205 003 050
Throttle valve sensor	09.97-08.00 0 280 122 014
Air mass meter, gasoline injection	09.97-08.00 0 280 217 123
Phase sensor	09.97-08.00 NOC 0 232 103 021
Speed sensor, ignition/injection	09.97-08.00 FKW 0 261 210 151



Knock sensor	09.97-08.00		0 261 231 120
Temperature sensor, coolant, injection system	09.97-08.00		0 281 002 169
1.2 i [G]	1,2 l 55 kW Z 12 XE 4 Zyl.		
Air mass meter, gasoline injection	09.00-08.05		0 280 218 031 0 986 280 230
Phase sensor	09.00-08.05	NOC	0 232 103 021
Speed sensor, ignition/injection	09.00-08.05	FKW	0 261 210 151
Knock sensor	09.00-08.05		0 261 231 120
Temperature sensor, coolant, injection system	09.00-08.05		0 281 002 169
1.2 Twinport [H]	1,2 l 59 kW Z 12 XEP 4 Zyl.		
Throttle valve assembly	03.07→		0 280 750 133
Air mass meter, gasoline injection	03.07→		0 280 218 119
Phase sensor	03.07→	NOC	0 232 103 052
Speed sensor, ignition/injection	03.07→	FKW	0 261 210 151
Knock sensor	03.07→		0 261 231 173
Temperature sensor, coolant, injection system	03.07→		0 281 002 170
1.3 [E]	1,3 l 44 kW 13 N, NB 4 Zyl.		
Wheel speed sensor, front	03.89-08.91		0 265 006 488
Wheel speed sensor, rear	03.89-08.91	LAB, LIM LIM, RAB	0 265 001 236 0 265 001 235
1.3 CDTi [H]	1,3 l 66 kW Z 13 DTH 4 Zyl.		
High-pressure sensor (CR system)	01.06→		0 281 002 534
Boost pressure sensor, Diesel	01.06→		0 281 002 437
1.3 i [E]	1,3 l 44 kW C 13 N 4 Zyl.		
Wheel speed sensor, front	03.89-08.91		0 265 006 488
Wheel speed sensor, rear	03.89-08.91	LAB, LIM LIM, RAB	0 265 001 236 0 265 001 235
1.4 i [E]	1,4 l 44 kW C 14 NZ 4 Zyl.		
Temperature sensor, coolant, injection system	01.90-08.91		0 280 130 107
1.4 i [F]	1,4 l 44/60/66 kW C 14 NZ; X 14 NZ/XE; 14 SE/ C 14 SE 4 Zyl.		
Temperature sensor, coolant, injection system	09.90-02.98		0 280 130 107
1.4 i [G]	1,4 l 66 kW X 14 XE 4 Zyl.		
Temperature sensor, coolant, injection system	09.97-08.00		0 281 002 169
1.4 i [H]	1,4 l 55 kW Z 14 XEL 4 Zyl.		
Throttle valve assembly	09.04→		0 280 750 133
Air mass meter, gasoline injection	09.04→		0 280 218 119
Phase sensor			
Fg.no. →52999999, →55999999, →58999999	09.04→	NOC	0 232 103 052
Fg.no. 62000001→, 65000001→, 68000001→	09.04→	NOC	0 232 103 067
Speed sensor, ignition/injection	09.04→	FKW	0 261 210 151
Knock sensor	09.04→		0 261 231 173
Temperature sensor, coolant, injection system	09.04→		0 281 002 170
1.4 Twinport [H]	1,4 l 66 kW Z 14 XEP 4 Zyl.		
Throttle valve assembly	03.04→		0 280 750 133
Air mass meter, gasoline injection	03.04→		0 280 218 119
Phase sensor			
Fg.no. →42999999, →45999999, →48999999	03.04→	NOC	0 232 103 021
Fg.no. 52000001→52999999, 55000001→55999999, 58000001→58999999	03.04→	NOC	0 232 103 052
Fg.no. 62000001→, 65000001→, 68000001→	03.04→	NOC	0 232 103 067
Speed sensor, ignition/injection	03.04→	FKW	0 261 210 151
Knock sensor	03.04→		0 261 231 173
Temperature sensor, coolant, injection system	03.04→		0 281 002 170
1.4 Twinport Dualfuel [H]	1,4 l 66 kW Z 14 XEP 4 Zyl.		
Throttle valve assembly	04.05→		0 280 750 133
Air mass meter, gasoline injection	04.05→		0 280 218 119



Phase sensor			
Fg.no. →42999999, →45999999, →48999999	04.05→	NOC	0 232 103 021
Fg.no. 52000001→52999999, 55000001→55999999, 58000001→58999999	04.05→	NOC	0 232 103 052
Fg.no. 62000001→, 65000001→, 68000001→	04.05→	NOC	0 232 103 067
Speed sensor, ignition/injection	04.05→	FKW	0 261 210 151
Knock sensor	04.05→		0 261 231 173
Temperature sensor, coolant, injection system	04.05→		0 281 002 170
1.6 i [E]	1,6 l 55 kW C 16 LZ; C 16 NZ; E 16 NZ 4 Zyl.		
Temperature sensor, coolant, injection system			
Fg.no. J2791968→, J5273428→	09.84-12.91		0 280 130 107
1.6 i [F]	1,6 l 52/55/74 kW C/E 16 NZ; C 16 SE; X 16 SZ/SZR; 16 LZ2/NZ2 4 Zyl.		
Temperature sensor, coolant, injection system	09.91-02.98		0 280 130 107
1.6 i [F]	1,6 l 74 kW X 16 XEL 4 Zyl.		
Temperature sensor, coolant, injection system	01.94-02.98		0 280 130 107
1.6 i [G]	1,6 l 55 kW X 16 SZR 4 Zyl.		
Temperature sensor, coolant, injection system	09.97-08.05		0 281 002 169
1.6 i [G]	1,6 l 62 kW Z 16 SE 4 Zyl.		
Yaw rate sensor, brake system	09.00-08.05		0 265 005 262
Steering angle sensor, ESP (electronic stability program)	09.00-08.05		0 265 005 435
Pressure sensor, ESP, (electronic stability program)	09.00-08.05		0 265 005 303
1.6 i [G]	1,6 l 74 kW C 16 SEL; X 16 XEL 4 Zyl.		
Temperature sensor, coolant, injection system	09.97-08.05		0 281 002 169
1.6 i [G]	1,6 l 74 kW Z 16 XE 4 Zyl.		
Yaw rate sensor, brake system	09.00-08.05		0 265 005 262
Steering angle sensor, ESP (electronic stability program)	09.00-08.05		0 265 005 435
Pressure sensor, ESP, (electronic stability program)	09.00-08.05		0 265 005 303
1.6 i [G]	1,6 l 74 kW Z 16 XEP 4 Zyl.		
Yaw rate sensor, brake system	09.02-08.05		0 265 005 262
Steering angle sensor, ESP (electronic stability program)	09.02-08.05		0 265 005 435
1.6 i Dualfuel [G]	1,6 l 63-73 kW Z 16 YNG 4 Zyl.		
Yaw rate sensor, brake system	09.02-08.05		0 265 005 262
Steering angle sensor, ESP (electronic stability program)	09.02-08.05		0 265 005 435
1.6 Turbo [H]	1,6 l 132 kW Z 16 LET 4 Zyl.		
Air mass meter, gasoline injection	03.07→		0 280 218 142
Phase sensor	03.07→	NOC	0 232 103 052
Knock sensor	03.07→		0 261 231 173
Pressure sensor, intake manifold, gasoline	03.07→		0 261 230 009
1.7 CDTi 16V [G]	1,7 l 59 kW Z 17 DTL 4 Zyl.		
Air mass meter, diesel	03.03-08.05		0 281 002 549
1.7 DT [G]	1,7 l 50 kW X 17 DTL 4 Zyl.		
Air mass meter, diesel	03.98-08.00		0 281 002 180
Speed sensor, diesel	03.98-08.00		0 281 002 285
Temperature sensor, coolant, diesel	03.98-08.00		0 281 002 259
Accelerator pedal module	03.98-08.00	LLE	0 281 002 278
1.7 DTi [G]	1,7 l 55 kW Y 17 DT 4 Zyl.		
Air mass meter, diesel	09.00-08.05		0 281 002 180
1.8 i [E]	1,8 l 74/82 kW C 18 NE; 18 E 4 Zyl.		
Temperature sensor, coolant, injection system	09.84-08.91		0 280 130 107
1.8 i [E]	1,8 l 82-85 kW 18 SE 4 Zyl.		
Throttle valve sensor	09.86-08.91		0 280 120 316
Air flow sensor, gasoline injection	09.86-08.91		0 280 202 602 0 986 280 019
Speed sensor, ignition/injection	09.86-08.91		0 261 210 030
Temperature sensor, coolant, injection system	09.86-08.91		0 280 130 107

Product				
◀ Astra				
1.8 i [F]	1,8 l 66 kW C 18 NZ 4 Zyl.			
Temperature sensor, coolant, injection system	09.91-02.98			0 280 130 107
1.8 i [F]	1,8 l 82 kW 18 SE 4 Zyl.			
Air mass meter, gasoline injection	06.96-02.98			0 280 217 003
Temperature sensor, intake air, injection system	06.96-02.98			0 280 130 073
1.8 i [G]	1,8 l 92 kW Z 18 XE 4 Zyl.			
Yaw rate sensor, brake system	09.00-08.05			0 265 005 262
Steering angle sensor, ESP (electronic stability program)	09.00-08.05			0 265 005 435
Pressure sensor, ESP, (electronic stability program)	09.00-08.05			0 265 005 303
1.8 i Dualfuel [G]	1,8 l 87-93 kW Z 18 XE 4 Zyl.			
Yaw rate sensor, brake system	09.02-08.05			0 265 005 262
Steering angle sensor, ESP (electronic stability program)	09.02-08.05			0 265 005 435
Pressure sensor, ESP, (electronic stability program)	09.02-08.05			0 265 005 303
1.9 CDTi [H]	1,9 l 74 kW Z 19 ... 4 Zyl.			
Phase sensor	09.05→ NOC			0 281 002 213
High-pressure sensor (CR system)	09.05→			0 281 002 534
1.9 CDTi [H]	1,9 l 88 kW Z 19 DTJ 4 Zyl.			
High-pressure sensor (CR system)	03.04→			0 281 002 534
Pressure sensor, intake manifold, diesel	03.04→			0 281 002 437
1.9 CDTi [H]	1,9 l 110 kW Z 19 DTH 4 Zyl.			
Pressure sensor, intake manifold, diesel	03.04→			0 281 002 437
2.0 DTi [G]	2,0 l 74 kW Y 20 DTH 4 Zyl.			
Air mass meter, diesel				
Fg.no. →Y8999999,→YT999999	09.00-08.05			0 281 002 180
Mot.no. 12000001→,1T000001→	09.00-08.05			0 281 002 428
Speed sensor, diesel	09.00-08.05			0 281 002 138
Temperature sensor, coolant, diesel	09.00-08.05			0 281 002 169
Accelerator pedal module	09.00-08.05 GS, LLE			0 281 002 278
Yaw rate sensor, brake system	09.00-08.05			0 265 005 262
Steering angle sensor, ESP (electronic stability program)	09.00-08.05			0 265 005 435
Pressure sensor, ESP, (electronic stability program)	09.00-08.05			0 265 005 303
2.0 DTL [G]	2,0 l 60 kW X 20 DTL 4 Zyl.			
Air mass meter, diesel				
Fg.no. →Y8999999,→YT999999	03.98-08.00			0 281 002 180
Mot.no. 12000001→,1T000001→	03.98-08.00			0 281 002 428
Speed sensor, diesel	03.98-08.00			0 281 002 138
Temperature sensor, coolant, diesel	03.98-08.00			0 281 002 169
Accelerator pedal module	03.98-08.00 AG, LLE			0 281 002 236
	AG, RLE			0 281 002 237
	GS, LLE			0 281 002 278
Yaw rate sensor, brake system				
Fg.no. →12999999,→1H999999	03.98-08.00			0 265 005 262
Steering angle sensor, ESP (electronic stability program)				
Fg.no. 22000001→,2H000001→	03.98-08.00			0 265 005 435
Pressure sensor, ESP, (electronic stability program)	03.98-08.00			0 265 005 303
2.0 DTL [G]	2,0 l 60 kW Y 20 DTL 4 Zyl.			
Air mass meter, diesel				
Mot.no. 12000001→,1T000001→	09.00-08.05			0 281 002 428
Speed sensor, diesel	09.00-08.05			0 281 002 138
Temperature sensor, coolant, diesel	09.00-08.05			0 281 002 169
Accelerator pedal module	09.00-08.05 AG, LLE			0 281 002 236
	AG, RLE			0 281 002 237
	GS, LLE			0 281 002 278
Yaw rate sensor, brake system	09.00-08.05			0 265 005 262
Steering angle sensor, ESP (electronic stability program)	09.00-08.05			0 265 005 435
Pressure sensor, ESP, (electronic stability program)	09.00-08.05			0 265 005 303
2.0 i [E]	2,0 l 85 kW C 20 NE; 20 NE 4 Zyl.			
Temperature sensor, coolant, injection system	09.86-08.91			0 280 130 107

Product				
2.0 i [E]	2,0 l 95 kW 20 SEH 4 Zyl.			
Throttle valve sensor	09.86-08.91			0 280 120 316
Air flow sensor, gasoline injection	09.86-08.91			0 280 202 210
				0 986 280 063
Speed sensor, ignition/injection	09.86-08.91			0 261 210 030
Pressure sensor, intake manifold, gasoline	09.86-08.91			0 280 101 007
Temperature sensor, coolant, injection system	09.86-08.91			0 280 130 107
2.0 i [E]	2,0 l 110-115 kW C 20 XE (XEJ); 20 XE 4 Zyl.			
Temperature sensor, coolant, injection system	05.88-08.91			0 280 130 107
2.0 i [F]	2,0 l 85 kW C 20 NE, 20 NE 4 Zyl.			
Throttle valve sensor	09.91-02.98			0 280 122 001
Air mass meter, gasoline injection	09.91-02.98			0 280 217 003
Temperature sensor, intake air, injection system	09.91-02.98			0 280 130 073
Temperature sensor, coolant, injection system	09.91-02.98			0 280 130 107
2.0 i [F]	2,0 l 110 kW C 20 XE, XE-LN 4 Zyl.			
Throttle valve sensor	09.91-02.98			0 280 120 436
Air mass meter, gasoline injection				
Mot.no. →14002934	09.91-02.98			0 280 212 015
				0 986 280 113
Mot.no. 14002935→	09.91-02.98			0 280 217 106
Temperature sensor, intake air, injection system	09.91-02.98			0 280 130 073
Temperature sensor, coolant, injection system	09.91-02.98			0 280 130 107
2.0 i [G]	2,0 l 100 kW X 20 XEV 4 Zyl.			
Throttle valve sensor	09.97-08.05			0 280 122 014
Yaw rate sensor, brake system				
Fg.no. →12999999,→1H999999	09.97-08.05			0 265 005 262
Fg.no. 22000001→,2B000001→, 2H000001→	09.97-08.05			0 265 005 262
Steering angle sensor, ESP (electronic stability program)				
Fg.no. 22000001→,2H000001→	09.97-08.05			0 265 005 435
Pressure sensor, ESP, (electronic stability program)	09.97-08.05			0 265 005 303
2.0 i [G]	2,0 l 118 kW X 20 XER 4 Zyl.			
Yaw rate sensor, brake system	09.00-08.05			0 265 005 262
Steering angle sensor, ESP (electronic stability program)	09.00-08.05			0 265 005 435
Pressure sensor, ESP, (electronic stability program)	09.00-08.05			0 265 005 303
2.0 Turbo [G]	2,0 l 141 kW Z 20 LET 4 Zyl.			
Air mass meter, gasoline injection	07.02-08.05			0 280 218 051
				0 986 280 231
Phase sensor	07.02-08.05			0 232 103 015
Speed sensor, ignition/injection	07.02-08.05 FKW			0 261 210 150
Knock sensor	07.02-08.05			0 261 231 116
Pressure sensor, intake manifold, gasoline	07.02-08.05			0 261 230 009
Temperature sensor, coolant, injection system	07.02-08.05			0 281 002 169
Yaw rate sensor, brake system	07.02-08.05			0 265 005 262
Steering angle sensor, ESP (electronic stability program)	07.02-08.05			0 265 005 435
Pressure sensor, ESP, (electronic stability program)	07.02-08.05			0 265 005 303
2.0 Turbo [H]	2,0 l 125 kW Z 20 LEL 4 Zyl.			
Air mass meter, gasoline injection	03.04→			0 280 218 142
Phase sensor	03.04→ NOC			0 232 103 015
Speed sensor, ignition/injection	03.04→ FKW			0 261 210 150
Knock sensor	03.04→			0 261 231 181
2.0 Turbo [H]	2,0 l 177 kW Z 20 LEH 4 Zyl.			
Air mass meter, gasoline injection				
Fg.no. →52999999,→55999999, →58999999	03.05→			0 280 218 164
Fg.no. 62000001→,65000001→, 68000001→	03.05→			0 280 218 211
Phase sensor	03.05→ NOC			0 232 103 015
Speed sensor, ignition/injection	03.05→ FKW			0 261 210 150
Knock sensor	03.05→			0 261 231 181





Pressure sensor, intake manifold, gasoline	03.05→	0 281 002 137
Temperature sensor, coolant, injection system	03.05→	0 281 002 169
2.0 Turbo 16V [H]	2,0l 147 kW Z 20 LER 4 Zyl.	
Air mass meter, gasoline injection	03.04→	0 280 218 142
Phase sensor	03.04→ NOC	0 232 103 015
Speed sensor, ignition/injection	03.04→ FKW	0 261 210 150
Knock sensor	03.04→	0 261 231 181
Pressure sensor, intake manifold, gasoline	03.04→	0 281 002 137
Temperature sensor, coolant, injection system	03.04→	0 281 002 169
2.2 DTi [G]	2,2l 92 kW Y 22 DTR 4 Zyl.	
Yaw rate sensor, brake system	09.01-08.05	0 265 005 262
Steering angle sensor, ESP (electronic stability program)	09.01-08.05	0 265 005 435
Pressure sensor, ESP, (electronic stability program)	09.01-08.05	0 265 005 303
2.2 i [G]	2,2l 108 kW Z 22 SE 4 Zyl.	
Yaw rate sensor, brake system	09.00-08.05	0 265 005 262
Steering angle sensor, ESP (electronic stability program)	09.00-08.05	0 265 005 435
Pressure sensor, ESP, (electronic stability program)	09.00-08.05	0 265 005 303

Astra Cabrio

1.6 i TwinTop [H]	1,6l 85 kW Z 16 XER 4 Zyl.	
Pressure sensor, intake manifold, gasoline	03.07→	0 261 230 009
1.6 i TwinTop [H]	1,6l 132 kW Z 16 LET 4 Zyl.	
Air mass meter, gasoline injection	03.07→	0 280 218 142
Phase sensor	03.07→ NOC	0 232 103 052
Pressure sensor, intake manifold, gasoline	03.07→	0 261 230 009
1.9 CDTi TwinTop [H]	1,9l 110 kW Z 19 DTH 4 Zyl.	
High-pressure sensor (CR system)	09.05→	0 281 002 706
Boost pressure sensor, Diesel	09.05→	0 281 002 437
2.0 i Turbo TwinTop [H]	2,0l 125/147 kW Z 20 LEL; Z 20 LER 4 Zyl.	
Air mass meter, gasoline injection	09.05→	0 280 218 142
Phase sensor	09.05→ NOC	0 232 103 015
Speed sensor, ignition/injection	09.05→ FKW	0 261 210 150
Knock sensor	09.05→	0 261 231 181
Pressure sensor, intake manifold, gasoline	09.05→	0 281 002 137
Temperature sensor, coolant, injection system	09.05→	0 281 002 169

Astra Convertible

1.4 i [F]	1,4l 44/60/66 kW C 14 NZ; X 14 XE; 14 SE/ C 14 SE 4 Zyl.	
Temperature sensor, coolant, injection system	09.90-02.98	0 280 130 107
1.6 i [F]	1,6l 52/55/74 kW X 16 SZ; X 16 SZR; X 16 XEL; 16 LZ2, 16NZ2 4 Zyl.	
Temperature sensor, coolant, injection system	09.91-02.98	0 280 130 107
1.6 i [G]	1,6l 74 kW Z 16 XE 4 Zyl.	
Yaw rate sensor, brake system	09.00-08.05	0 265 005 262
Steering angle sensor, ESP (electronic stability program)	09.00-08.05	0 265 005 435
Pressure sensor, ESP, (electronic stability program)	09.00-08.05	0 265 005 303
1.6 i Twinport [G]	1,6l 76 kW Z 16 XEP 4 Zyl.	
Yaw rate sensor, brake system	03.03-08.05	0 265 005 262
Steering angle sensor, ESP (electronic stability program)	03.03-08.05	0 265 005 435
Pressure sensor, ESP, (electronic stability program)	03.03-08.05	0 265 005 303
1.8 i [F]	1,8l 66 kW C 18 NZ 4 Zyl.	
Temperature sensor, coolant, injection system	09.91-02.98	0 280 130 107
1.8 i [G]	1,8l 92 kW Z 18 XE 4 Zyl.	
Yaw rate sensor, brake system	09.00-08.05	0 265 005 262
Steering angle sensor, ESP (electronic stability program)	09.00-08.05	0 265 005 435
Pressure sensor, ESP, (electronic stability program)	09.00-08.05	0 265 005 303



2.0 i [F]	2,0l 85 kW C 20 NE, 20 NE 4 Zyl.	
Throttle valve sensor	09.91-02.98	0 280 122 001
Air mass meter, gasoline injection	09.91-02.98	0 280 217 003
Temperature sensor, intake air, injection system	09.91-02.98	0 280 130 073
Temperature sensor, coolant, injection system	09.91-02.98	0 280 130 107
2.0 i Turbo [G]	2,0l 141 kW Z 20 LET 4 Zyl.	
Air mass meter, gasoline injection	03.02-08.05	0 280 218 051
		0 986 280 231
Phase sensor	03.02-08.05	0 232 103 015
Speed sensor, ignition/injection	03.02-08.05	0 261 210 150
Knock sensor	03.02-08.05	0 261 231 116
Temperature sensor, coolant, injection system	03.02-08.05	0 281 002 169
Yaw rate sensor, brake system	03.02-08.05	0 265 005 262
Steering angle sensor, ESP (electronic stability program)	03.02-08.05	0 265 005 435
Pressure sensor, ESP, (electronic stability program)	03.02-08.05	0 265 005 303
2.2 i [G]	2,2l 108 kW Z 22 SE 4 Zyl.	
Yaw rate sensor, brake system	09.00-08.05	0 265 005 262
Steering angle sensor, ESP (electronic stability program)	09.00-08.05	0 265 005 435
Pressure sensor, ESP, (electronic stability program)	09.00-08.05	0 265 005 303

Astra Coupé

1.6 i Twinport [G]	1,6l 76 kW Z 16 XEP 4 Zyl.	
Pressure sensor, ESP, (electronic stability program)	03.03-08.05	0 265 005 303
1.8 i [G]	1,8l 85/92 kW Z 18 XE; Z 18 XEL 4 Zyl.	
Yaw rate sensor, brake system	09.00-08.05	0 265 005 262
Steering angle sensor, ESP (electronic stability program)	09.00-08.05	0 265 005 435
Pressure sensor, ESP, (electronic stability program)	09.00-08.05	0 265 005 303
1.8 i Dualfuel [G]	1,8l 87-93 kW Z 18 XE 4 Zyl.	
Yaw rate sensor, brake system	09.02-08.05	0 265 005 262
Steering angle sensor, ESP (electronic stability program)	09.02-08.05	0 265 005 435
Pressure sensor, ESP, (electronic stability program)	09.02-08.05	0 265 005 303
2.0 i Turbo [G]	2,0l 141 kW Z 20 LET 4 Zyl.	
Air mass meter, gasoline injection	09.00-08.05	0 280 218 051
		0 986 280 231
Phase sensor	09.00-08.05	0 232 103 015
Speed sensor, ignition/injection	09.00-08.05	0 261 210 150
Knock sensor	09.00-08.05	0 261 231 116
Temperature sensor, coolant, injection system	09.00-08.05	0 281 002 169
Yaw rate sensor, brake system	09.00-08.05	0 265 005 262
Steering angle sensor, ESP (electronic stability program)	09.00-08.05	0 265 005 435
Pressure sensor, ESP, (electronic stability program)	09.00-08.05	0 265 005 303
2.2 i [G]	2,2l 108 kW Z 22 SE 4 Zyl.	
Yaw rate sensor, brake system	09.00-08.05	0 265 005 262
Steering angle sensor, ESP (electronic stability program)	09.00-08.05	0 265 005 435
Pressure sensor, ESP, (electronic stability program)	09.00-08.05	0 265 005 303

Astra Estate

1.2 Twinport [H]	1,2l 59 kW Z 12 XEP 4 Zyl.	
Throttle valve assembly	03.07→	0 280 750 133
Air mass meter, gasoline injection	03.07→	0 280 218 119
Phase sensor	03.07→ NOC	0 232 103 052
Speed sensor, ignition/injection	03.07→ FKW	0 261 210 151
Knock sensor	03.07→	0 261 231 173
Temperature sensor, coolant, injection system	03.07→	0 281 002 170



Product

◀ Astra Estate

1.3 CDTi [H]	1,3l	66 kW	Z 13 DTH	4 Zyl.
High-pressure sensor (CR system)	06.05→		0 281 002 534	
Boost pressure sensor, Diesel	06.05→		0 281 002 437	
1.4 [H]	1,4l	55 kW	Z 14 XEL	4 Zyl.
Throttle valve assembly	09.04→		0 280 750 133	
Air mass meter, gasoline injection	09.04→		0 280 218 119	
Phase sensor				
Fg.no. →52999999,→55999999, →58999999	09.04→	NOC	0 232 103 052	
Fg.no. 62000001→,65000001→, 68000001→	09.04→	NOC	0 232 103 067	
Speed sensor, ignition/injection	09.04→	FKW	0 261 210 151	
Knock sensor	09.04→		0 261 231 173	
Temperature sensor, coolant, injection system	09.04→		0 281 002 170	
1.4 i [F]	1,4l	44/60/66 kW	C 14 NZ; X 14 NZ; X 14 XE; 14 SE/ C 14 SE	4 Zyl.
Temperature sensor, coolant, injection system	09.90-02.98		0 280 130 107	
1.4 Twinport [H]	1,4l	66 kW	Z 14 XEP	4 Zyl.
Throttle valve assembly	08.04→		0 280 750 133	
Air mass meter, gasoline injection	08.04→		0 280 218 119	
Phase sensor				
Fg.no. →42999999,→45999999, →48999999	08.04→	NOC	0 232 103 021	
Fg.no. 52000001→52999999, 55000001→55999999, 58000001→58999999	08.04→	NOC	0 232 103 052	
Fg.no. 62000001→,65000001→, 68000001→	08.04→	NOC	0 232 103 067	
Speed sensor, ignition/injection	08.04→	FKW	0 261 210 151	
Knock sensor	08.04→		0 261 231 173	
Temperature sensor, coolant, injection system	08.04→		0 281 002 170	
1.6 i [F]	1,6l	52/55/74 kW	C/E 16 NZ; C 16 SE; X 16 SZ/SZR; 16 LZ2/Z2	4 Zyl.
Temperature sensor, coolant, injection system	09.91-02.98		0 280 130 107	
1.6 i [F]	1,6l	74 kW	X 16 XEL	4 Zyl.
Temperature sensor, coolant, injection system	01.94-02.98		0 280 130 107	
1.6 i Dualfuel [G]	1,6l	63-73 kW	Z 16 YNG	4 Zyl.
Yaw rate sensor, brake system	09.02-08.05		0 265 005 262	
Steering angle sensor, ESP (electronic stability program)	09.02-08.05		0 265 005 435	
1.6 Turbo [H]	1,6l	132 kW	Z 16 LET	4 Zyl.
Air mass meter, gasoline injection	09.07→		0 280 218 142	
Phase sensor	09.07→	NOC	0 232 103 052	
Knock sensor	09.07→		0 261 231 173	
Pressure sensor, intake manifold, gasoline	09.07→		0 261 230 009	
1.7 CDTi [G]	1,7l	59 kW	Z 17 DTL	4 Zyl.
Air mass meter, diesel	03.03-08.05		0 281 002 549	
1.8 i [F]	1,8l	66 kW	C 18 NZ	4 Zyl.
Temperature sensor, coolant, injection system	09.91-02.98		0 280 130 107	
1.8 i Dualfuel [G]	1,8l	87-93 kW	Z 18 XE	4 Zyl.
Yaw rate sensor, brake system	09.02-08.05		0 265 005 262	
Steering angle sensor, ESP (electronic stability program)	09.02-08.05		0 265 005 435	
Pressure sensor, ESP, (electronic stability program)	09.02-08.05		0 265 005 303	
1.9 CDTi [H]	1,9l	74 kW	Z 19 ...	4 Zyl.
Phase sensor	09.05→	NOC	0 281 002 213	
High-pressure sensor (CR system)	09.05→		0 281 002 534	
1.9 CDTi [H]	1,9l	88 kW	Z 19 DTJ	4 Zyl.
High-pressure sensor (CR system)	08.04→		0 281 002 534	
Pressure sensor, intake manifold, diesel	08.04→		0 281 002 437	
1.9 CDTi [H]	1,9l	110 kW	Z 19 DTH	4 Zyl.
Pressure sensor, intake manifold, diesel	08.04→		0 281 002 437	
2.0 i [F]	2,0l	85 kW	C 20 NE, 20 NE	4 Zyl.
Throttle valve sensor	09.91-02.98		0 280 122 001	
Air mass meter, gasoline injection	09.91-02.98		0 280 217 003	

Product

Temperature sensor, intake air, injection system	09.91-02.98		0 280 130 073	
Temperature sensor, coolant, injection system	09.91-02.98		0 280 130 107	
2.0 i [F]	2,0l	110 kW	C 20 XE,XE-LN	4 Zyl.
Throttle valve sensor	09.91-02.98		0 280 120 436	
Air mass meter, gasoline injection				
Mot.no. →14002934	09.91-02.98		0 280 212 015	
				0 986 280 113
Mot.no. 14002935→	09.91-02.98		0 280 217 106	
Temperature sensor, intake air, injection system	09.91-02.98		0 280 130 073	
Temperature sensor, coolant, injection system	09.91-02.98		0 280 130 107	
2.0 Turbo [G]	2,0l	141 kW	Z 20 LET	4 Zyl.
Air mass meter, gasoline injection	09.02-08.05		0 280 218 051	
				0 986 280 231
Phase sensor	09.02-08.05		0 232 103 015	
Speed sensor, ignition/injection	09.02-08.05		0 261 210 150	
Knock sensor	09.02-08.05		0 261 231 116	
Temperature sensor, coolant, injection system	09.02-08.05		0 281 002 169	
Yaw rate sensor, brake system	09.02-08.05		0 265 005 262	
Steering angle sensor, ESP (electronic stability program)	09.02-08.05		0 265 005 435	
Pressure sensor, ESP, (electronic stability program)	09.02-08.05		0 265 005 303	
2.0 Turbo [H]	2,0l	125 kW	Z 20 LEL	4 Zyl.
Air mass meter, gasoline injection	08.04→		0 280 218 142	
Phase sensor	08.04→	NOC	0 232 103 015	
Speed sensor, ignition/injection	08.04→	FKW	0 261 210 150	
Knock sensor	08.04→		0 261 231 181	
Pressure sensor, intake manifold, gasoline	08.04→		0 281 002 137	
Temperature sensor, coolant, injection system	08.04→		0 281 002 169	
2.0 Turbo [H]	2,0l	177 kW	Z 20 LEH	4 Zyl.
Air mass meter, gasoline injection				
Fg.no. →52999999,→55999999, →58999999	09.05→		0 280 218 164	
Fg.no. 62000001→,65000001→, 68000001→	09.05→		0 280 218 211	
Phase sensor	09.05→	NOC	0 232 103 015	
Speed sensor, ignition/injection	09.05→	FKW	0 261 210 150	
Knock sensor	09.05→		0 261 231 181	
Pressure sensor, intake manifold, gasoline	09.05→		0 281 002 137	
Temperature sensor, coolant, injection system	09.05→		0 281 002 169	
2.0 Turbo 16V [H]	2,0l	147 kW	Z 20 LER	4 Zyl.
Air mass meter, gasoline injection	08.04→		0 280 218 142	
Phase sensor	08.04→	NOC	0 232 103 015	
Speed sensor, ignition/injection	08.04→	FKW	0 261 210 150	
Knock sensor	08.04→		0 261 231 181	
Pressure sensor, intake manifold, gasoline	08.04→		0 281 002 137	
Temperature sensor, coolant, injection system	08.04→		0 281 002 169	

Astra GTC

1.4 Twinport [H]	1,4l	55 kW	Z 14 XEL	4 Zyl.
Throttle valve assembly	09.05→		0 280 750 133	
Air mass meter, gasoline injection	09.05→		0 280 218 119	
Phase sensor				
Fg.no. →52999999,→55999999, →58999999	09.05→	NOC	0 232 103 052	
Fg.no. 62000001→,65000001→, 68000001→	09.05→	NOC	0 232 103 067	
Speed sensor, ignition/injection	09.05→	FKW	0 261 210 151	
Knock sensor	09.05→		0 261 231 173	
Temperature sensor, coolant, injection system	09.05→		0 281 002 170	
1.4 Twinport [H]	1,4l	66 kW	Z 14 XEP	4 Zyl.
Throttle valve assembly	06.05→		0 280 750 133	
Air mass meter, gasoline injection	06.05→		0 280 218 119	



Phase sensor			
Fg.no. →42999999,→45999999, →48999999	06.05→	NOC	0 232 103 021
Fg.no. 52000001→52999999, 55000001→55999999, 58000001→58999999	06.05→	NOC	0 232 103 052
Fg.no. 62000001→,65000001→, 68000001→	06.05→	NOC	0 232 103 067
Speed sensor, ignition/injection	06.05→	FKW	0 261 210 151
Knock sensor	06.05→		0 261 231 173
Temperature sensor, coolant, injection system	06.05→		0 281 002 170
1.7 CDTi [H]	1,7 l 59/74 kW Z 17 DTH; Z 17 DTL	4 Zyl.	
Speed sensor, ignition/injection	06.05-03.07	FKW	0 281 002 603
1.9 CDTi [H]	1,9 l 88 kW Z 19 DTJ	4 Zyl.	
High-pressure sensor (CR system)	06.05→		0 281 002 534
Pressure sensor, intake manifold, diesel	06.05→		0 281 002 437
1.9 CDTi [H]	1,9 l 110 kW Z 19 DTH	4 Zyl.	
Pressure sensor, intake manifold, diesel	06.05→		0 281 002 437
2.0 Turbo [H]	2,0 l 125 kW Z 20 LEL	4 Zyl.	
Air mass meter, gasoline injection	06.05→		0 280 218 142
Phase sensor	06.05→	NOC	0 232 103 015
Speed sensor, ignition/injection	06.05→	FKW	0 261 210 150
Knock sensor	06.05→		0 261 231 181
Pressure sensor, intake manifold, gasoline	06.05→		0 281 002 137
Temperature sensor, coolant, injection system	06.05→		0 281 002 169
2.0 Turbo 16V [H]	2,0 l 147 kW Z 20 LER	4 Zyl.	
Air mass meter, gasoline injection	06.05→		0 280 218 142
Phase sensor	06.05→	NOC	0 232 103 015
Speed sensor, ignition/injection	06.05→	FKW	0 261 210 150
Knock sensor	06.05→		0 261 231 181
Pressure sensor, intake manifold, gasoline	06.05→		0 281 002 137
Temperature sensor, coolant, injection system	06.05→		0 281 002 169
2.0 Turbo 16V [H]	2,0 l 177 kW Z 20 LEH	4 Zyl.	
Air mass meter, gasoline injection			
Fg.no. →52999999,→55999999, →58999999	06.05→		0 280 218 164
Fg.no. 62000001→,65000001→, 68000001→	06.05→		0 280 218 211
Phase sensor	06.05→	NOC	0 232 103 015
Speed sensor, ignition/injection	06.05→	FKW	0 261 210 150
Knock sensor	06.05→		0 261 231 181
Pressure sensor, intake manifold, gasoline	06.05→		0 281 002 137
Temperature sensor, coolant, injection system	06.05→		0 281 002 169

Belmont			
1.8 i	1,8 l 82-85 kW 18 SE	4 Zyl.	
Throttle valve sensor	09.86-09.93		0 280 120 316
Air flow sensor, gasoline injection	09.86-09.93		0 280 202 602
			0 986 280 019
Speed sensor, ignition/injection	09.86-09.93		0 261 210 030
Temperature sensor, coolant, injection system	09.86-09.93		0 280 130 026

Calibra			
2.0 i	2,0 l 85 kW C 20 NE	4 Zyl.	
Throttle valve sensor	03.90-03.98		0 280 120 316
Temperature sensor, coolant, injection system	03.90-03.98		0 280 130 107
Wheel speed sensor, front			
Fg.no. L1000001→M1999999	03.90-03.98		0 265 001 206



Wheel speed sensor, rear			
Fg.no. L1000001→M1999999	03.90-03.98	AA,LAB	0 265 001 226
		LAB,NAA	0 265 001 233
		NAA,RAB	0 265 001 232
Fg.no. N1000001→	03.90-03.98	AA,LAB	0 265 006 487
		AA,RAB	0 265 006 486
		LAB,NAA	0 265 003 094
		NAA,RAB	0 265 003 093
2.0 i	2,0 l 100 kW X 20 XEV	4 Zyl.	
Wheel speed sensor, front			
Fg.no. L1000001→M1999999	09.93-07.97		0 265 001 206
Wheel speed sensor, rear			
Fg.no. L1000001→M1999999	09.93-07.97	AA,LAB	0 265 001 226
		LAB,NAA	0 265 001 233
		NAA,RAB	0 265 001 232
Fg.no. N1000001→	09.93-07.97	AA,LAB	0 265 006 487
		AA,RAB	0 265 006 486
		LAB,NAA	0 265 003 094
		NAA,RAB	0 265 003 093
2.0 i	2,0 l 110 kW C 20 XE,XE-LN	4 Zyl.	
Throttle valve sensor	03.90-03.97		0 280 120 326
Air mass meter, gasoline injection			
Mot.no. →14002934	03.90-03.97		0 280 212 015
			0 986 280 113
Mot.no. 14002935→	03.90-03.97		0 280 217 106
Knock sensor	03.90-03.97		0 261 231 006
Temperature sensor, coolant, injection system	03.90-03.97		0 280 130 107
Wheel speed sensor, front			
Fg.no. L1000001→M1999999	03.90-03.97		0 265 001 206
Wheel speed sensor, rear			
Fg.no. L1000001→M1999999	03.90-03.97	AA,LAB	0 265 001 226
		LAB,NAA	0 265 001 233
		NAA,RAB	0 265 001 232
Fg.no. N1000001→	03.90-03.97	AA,LAB	0 265 006 487
		AA,RAB	0 265 006 486
		LAB,NAA	0 265 003 094
		NAA,RAB	0 265 003 093
2.0 i turbo	2,0 l 150 kW C 20 LET	4 Zyl.	
Air mass meter, gasoline injection	03.92-07.97		0 280 213 024
			0 986 280 140
Temperature sensor, intake air, injection system	03.92-07.97		0 280 130 039
Temperature sensor, coolant, injection system	03.92-07.97		0 280 130 107
Wheel speed sensor, front			
Fg.no. L1000001→M1999999	03.92-07.97		0 265 001 206
Wheel speed sensor, rear			
Fg.no. L1000001→M1999999	03.92-07.97	AA,LAB	0 265 001 226
		LAB,NAA	0 265 001 233
		NAA,RAB	0 265 001 232
Fg.no. N1000001→	03.92-07.97	AA,LAB	0 265 006 487
		AA,RAB	0 265 006 486
		LAB,NAA	0 265 003 094
		NAA,RAB	0 265 003 093
2.5 i	2,5 l 125 kW C 25 XE,X25 XE V6	6 Zyl.	
Air mass meter, gasoline injection	04.93-03.97		0 280 217 503
Phase sensor			
Fg.no. →S1035178,→R9003232	04.93-03.97		0 232 103 001
Temperature sensor, coolant, injection system	04.93-03.97		0 280 130 107
Wheel speed sensor, front			
Fg.no. L1000001→M1999999	04.93-03.97		0 265 001 206

Product				
◀ Calibra				
Wheel speed sensor, rear				
Fg.no. L1000001→M1999999	04.93-03.97	AA,LAB	0 265 001 226	
		LAB,NAA	0 265 001 233	
		NAA,RAB	0 265 001 232	
Fg.no. N1000001→	04.93-03.97	AA,LAB	0 265 006 487	
		AA,RAB	0 265 006 486	
		LAB,NAA	0 265 003 094	
		NAA,RAB	0 265 003 093	

Carlton				
1.8 [III]	1,8l 60/65-66 kW 18 NV; 18 SV/18NVR	4 Zyl.		
Speed sensor, ignition/injection	09.86-10.94		0 261 210 030	
Temperature sensor, coolant, injection system	09.86-10.94		0 280 130 107	
Wheel speed sensor	09.86-10.94		0 265 001 134	
Fg.no. J1185910→	09.86-10.94	VO	0 265 001 220	
Fg.no. →J1185909	09.86-10.94	VO	0 265 001 143	
1.8 i [III]	1,8l 85 kW 18 SEH	4 Zyl.		
Throttle valve sensor	09.86-10.94		0 280 120 316	
Air flow sensor, gasoline injection	09.86-10.94		0 280 202 602	
			0 986 280 019	
Speed sensor, ignition/injection	09.86-10.94		0 261 210 030	
Temperature sensor, coolant, injection system	09.86-10.94		0 280 130 107	
Wheel speed sensor	09.86-10.94		0 265 001 134	
Fg.no. J1185910→	09.86-10.94	VO	0 265 001 220	
Fg.no. →J1185909	09.86-10.94	VO	0 265 001 143	
2.0 i [III]	2,0l 73-74/85 kW C 20 NE; C 20 NEJ/NEF	4 Zyl.		
Air flow sensor, gasoline injection				
Fg.no. →L1019854	09.86-10.94		0 280 202 210	
			0 986 280 063	
Speed sensor, ignition/injection	09.86-10.94		0 261 210 030	
Temperature sensor, coolant, injection system	09.86-10.94		0 280 130 107	
Wheel speed sensor	09.86-10.94		0 265 001 134	
Fg.no. J1185910→	09.86-10.94	VO	0 265 001 220	
Fg.no. →J1185909	09.86-10.94	VO	0 265 001 143	
2.0 i [III]	2,0l 90 kW 20 SE	4 Zyl.		
Throttle valve sensor	09.86-10.94		0 280 120 316	
Air flow sensor, gasoline injection	09.86-10.94		0 280 202 210	
			0 986 280 063	
Speed sensor, ignition/injection	09.86-10.94		0 261 210 030	
Pressure sensor, intake manifold, gasoline	09.86-10.94		0 280 101 007	
Temperature sensor, coolant, injection system	09.86-10.94		0 280 130 107	
Wheel speed sensor	09.86-10.94		0 265 001 134	
Fg.no. J1185910→	09.86-10.94	VO	0 265 001 220	
Fg.no. →J1185909	09.86-10.94	VO	0 265 001 143	
2.3 D [III]	2,3l 54 kW 23 YD	4 Zyl.		
Temperature sensor, coolant, diesel	09.86-10.94	2PO	0 280 130 107	
Wheel speed sensor	09.86-10.94		0 265 001 134	
Fg.no. J1185910→	09.86-10.94	VO	0 265 001 220	
Fg.no. →J1185909	09.86-10.94	VO	0 265 001 143	
2.3 TD Interc. [III]	2,3l 74 kW 23 DTR	4 Zyl.		
Temperature sensor, coolant, diesel	09.88-10.94	2PO	0 280 130 107	
Wheel speed sensor	09.88-10.94		0 265 001 134	
Fg.no. J1185910→	09.88-10.94	VO	0 265 001 220	
Fg.no. →J1185909	09.88-10.94	VO	0 265 001 143	
2.3 YTD [III]	2,3l 66 kW 23 YDT	4 Zyl.		
Temperature sensor, coolant, diesel	09.86-09.88	2PO	0 280 130 107	
Wheel speed sensor	09.86-09.88		0 265 001 134	
Fg.no. J1185910→	09.86-09.88	VO	0 265 001 220	
Fg.no. →J1185909	09.86-09.88	VO	0 265 001 143	



Product				
2.4 i [III]	2,4l 92 kW C 24 NE CIH	4 Zyl.		
Air flow sensor, gasoline injection	09.86-10.94		0 280 202 211	
			0 986 280 091	
Temperature sensor, coolant, injection system	09.86-10.94		0 280 130 107	
Wheel speed sensor	09.86-10.94		0 265 001 134	
Fg.no. J1185910→	09.86-10.94	VO	0 265 001 220	
Fg.no. →J1185909	09.86-10.94	VO	0 265 001 143	
2.6 i [III]	2,6l 110 kW C 26 NE CIH	6 Zyl.		
Temperature sensor, coolant, injection system	09.90-10.94		0 280 130 107	
Wheel speed sensor	09.90-10.94		0 265 001 134	
Fg.no. J1185910→	09.90-10.94	VO	0 265 001 220	
Fg.no. →J1185909	09.90-10.94	VO	0 265 001 143	
3.0 i [III]	3,0l 115 kW C 30 LE CIH	6 Zyl.		
Air flow sensor, gasoline injection	03.87-12.87		0 280 202 201	
Temperature sensor, coolant, injection system	03.87-12.87		0 280 130 107	
3.0 i [III]	3,0l 130 kW C 30 NE CIH	6 Zyl.		
Air flow sensor, gasoline injection	03.87-10.94		0 280 203 032	
			0 986 280 074	
Speed sensor, ignition/injection	03.87-10.94		0 261 210 031	
Temperature sensor, coolant, injection system	03.87-10.94		0 280 130 069	
Wheel speed sensor	03.87-10.94		0 265 001 134	
Fg.no. J1185910→	03.87-10.94	VO	0 265 001 220	
Fg.no. →J1185909	03.87-10.94	VO	0 265 001 143	
3.0 i [III]	3,0l 130 kW 30 NE CIH	6 Zyl.		
Temperature sensor, coolant, injection system	03.87-10.94		0 280 130 069	
Wheel speed sensor	03.87-10.94		0 265 001 134	
Fg.no. J1185910→	03.87-10.94	VO	0 265 001 220	
Fg.no. →J1185909	03.87-10.94	VO	0 265 001 143	
3.0 i [III]	3,0l 147-150 kW C 30 SE/SEJ	6 Zyl.		
Air flow sensor, gasoline injection	01.89-10.94		0 280 203 032	
			0 986 280 074	
Temperature sensor, coolant, injection system	01.89-10.94		0 280 130 107	
Wheel speed sensor	01.89-10.94		0 265 001 134	
Fg.no. J1185910→	01.89-10.94	VO	0 265 001 220	
Fg.no. →J1185909	01.89-10.94	VO	0 265 001 143	


Cavalier				
1.4 [III]	1,4l 55 kW 14 NV	4 Zyl.		
Wheel speed sensor, front				
Fg.no. →M1999999, →N5000039, →MV999999	09.88-11.95		0 265 001 206	
Wheel speed sensor, rear				
Fg.no. →NV999999, →N1999999, →N5999999	09.88-11.95	L10,RAB	0 265 001 207	
		L13,LAB	0 265 001 208	
1.6 i [III]	1,6l 52 kW X 16 SZ	4 Zyl.		
Temperature sensor, coolant, injection system	09.94-11.95		0 280 130 107	
Wheel speed sensor, front				
Fg.no. →M1999999, →N5000039, →MV999999	09.94-11.95		0 265 001 206	
Wheel speed sensor, rear				
Fg.no. →NV999999, →N1999999, →N5999999	09.94-11.95	L10,RAB	0 265 001 207	
		L13,LAB	0 265 001 208	
1.6 i [III]	1,6l 55 kW C 16 L22	4 Zyl.		
Speed sensor, ignition/injection	09.94-08.95		0 261 210 030	
Temperature sensor, coolant, injection system	09.94-08.95		0 280 130 107	
Wheel speed sensor, front				
Fg.no. →M1999999, →N5000039, →MV999999	09.94-08.95		0 265 001 206	
Wheel speed sensor, rear				
Fg.no. →NV999999, →N1999999, →N5999999	09.94-08.95	L10,RAB	0 265 001 207	
		L13,LAB	0 265 001 208	



Product			
1.6 i KAT [III]	1,6 l 55-60 kW E16 NZ, C16 NZ 4 Zyl.		
Temperature sensor, coolant, injection system	09.88-11.95		0 280 130 107
Wheel speed sensor, front			
Fg.no. →M1999999, →N5000039, →MV999999	09.88-11.95		0 265 001 206
Wheel speed sensor, rear			
Fg.no. →NV999999, →N1999999, →N5999999	09.88-11.95	L10,RAB	0 265 001 207
		L13,LAB	0 265 001 208
1.6 S [III]	1,6 l 60 kW 16 SV 4 Zyl.		
Wheel speed sensor, front			
Fg.no. →M1999999, →N5000039, →MV999999	09.88-08.95		0 265 001 206
Wheel speed sensor, rear			
Fg.no. →NV999999, →N1999999, →N5999999	09.88-08.95	L10,RAB	0 265 001 207
		L13,LAB	0 265 001 208
1.7 D [III]	1,7 l 42 kW 17 D/DR 4 Zyl.		
Wheel speed sensor, front			
Fg.no. →M1999999, →N5000039, →MV999999	09.88-11.95		0 265 001 206
Wheel speed sensor, rear			
Fg.no. →NV999999, →N1999999, →N5999999	09.88-11.95	L10,RAB	0 265 001 207
		L13,LAB	0 265 001 208
1.7 TD [III]	1,7 l 60 kW 17 DT/TC4 EE1 4 Zyl.		
Wheel speed sensor, front			
Fg.no. →M1999999, →N5000039, →MV999999	09.88-11.95		0 265 001 206
Wheel speed sensor, rear			
Fg.no. →NV999999, →N1999999, →N5999999	09.88-11.95	L10,RAB	0 265 001 207
		L13,LAB	0 265 001 208
1.8 [III]	1,8 l 62 kW E 18 NV/S 18 NV 4 Zyl.		
Temperature sensor, intake air, injection system	08.86-08.88		0 280 130 107
1.8 [III]	1,8 l 66 kW 18 SV 4 Zyl.		
Speed sensor, ignition/injection			
Fg.no. →P1999999, →P5999999, →P7999999	09.88-08.95		0 261 210 030
Wheel speed sensor, front			
Fg.no. →M1999999, →N5000039, →MV999999	09.88-08.95		0 265 001 206
Wheel speed sensor, rear			
Fg.no. →NV999999, →N1999999, →N5999999	09.88-08.95	L10,RAB	0 265 001 207
		L13,LAB	0 265 001 208
1.8 i [II]	1,8 l 74 kW C 18 NE 4 Zyl.		
Temperature sensor, intake air, injection system	01.85-08.86		0 280 130 107
1.8 i [III]	1,8 l 82 kW 18 SE 4 Zyl.		
Throttle valve sensor	09.86-08.88		0 280 120 316
Air flow sensor, gasoline injection	09.86-08.88		0 280 202 602
			0 986 280 019
Speed sensor, ignition/injection	09.86-08.88		0 261 210 030
Temperature sensor, intake air, injection system	09.86-08.88		0 280 130 107
1.8 i [III]	1,8 l 85 kW 18 E 4 Zyl.		
Temperature sensor, intake air, injection system	09.81-08.88		0 280 130 107
1.8 i [III]	1,8 l 66 kW C 18 NZ 4 Zyl.		
Speed sensor, ignition/injection			
Fg.no. →P1999999, →P5999999, →P7999999	09.88-11.95		0 261 210 030
Temperature sensor, coolant, injection system	09.88-11.95		0 280 130 107
Wheel speed sensor, front			
Fg.no. →M1999999, →N5000039, →MV999999	09.88-11.95		0 265 001 206
Wheel speed sensor, rear			
Fg.no. →NV999999, →N1999999, →N5999999	09.88-11.95	L10,RAB	0 265 001 207
		L13,LAB	0 265 001 208



1.8 S [III]	1,8 l 65 kW E 18 NVR 4 Zyl.		
Speed sensor, ignition/injection	09.88-08.95		0 261 210 030
Wheel speed sensor, front			
Fg.no. →M1999999, →N5000039, →MV999999	09.88-08.95		0 265 001 206
Wheel speed sensor, rear			
Fg.no. →NV999999, →N1999999, →N5999999	09.88-08.95	L10,RAB	0 265 001 207
		L13,LAB	0 265 001 208
2.0 i [III]	2,0 l 85/90-95 kW 20 NE, C 20 NE; 20 SE/ SEH 4 Zyl.		
Throttle valve sensor	09.86-08.88		0 280 120 316
Air flow sensor, gasoline injection	09.86-08.88		0 280 202 210
			0 986 280 063
Speed sensor, ignition/injection	09.86-08.88		0 261 210 030
Pressure sensor, intake manifold, gasoline	09.86-08.88		0 280 101 007
Temperature sensor, intake air, injection system	09.86-08.88		0 280 130 107
2.0 i [III]	2,0 l 85/86 kW C 20 NE; 20 NE 4 Zyl.		
Speed sensor, ignition/injection			
Fg.no. →P1999999, →P5999999, →P7999999	09.88-11.95		0 261 210 030
Temperature sensor, coolant, injection system	09.88-11.95		0 280 130 107
Wheel speed sensor, front			
Fg.no. →M1999999, →N5000039, →MV999999	09.88-11.95		0 265 001 206
Wheel speed sensor, rear			
Fg.no. →NV999999, →N1999999, →N5999999	09.88-11.95	L10,RAB	0 265 001 207
		L13,LAB	0 265 001 208
2.0 i [III]	2,0 l 95 kW 20 SEH 4 Zyl.		
Air flow sensor, gasoline injection	09.88-08.95		0 280 202 210
			0 986 280 063
Speed sensor, ignition/injection	09.88-08.95		0 261 210 030
Temperature sensor, coolant, injection system	09.88-08.95		0 280 130 107
Wheel speed sensor, front			
Fg.no. →M1999999, →N5000039, →MV999999	09.88-08.95		0 265 001 206
Wheel speed sensor, rear			
Fg.no. →NV999999, →N1999999, →N5999999	09.88-08.95	L10,RAB	0 265 001 207
		L13,LAB	0 265 001 208
2.0 i 4x4 [III]	2,0 l 95 kW 20 SEH 4 Zyl.		
Air flow sensor, gasoline injection	09.88-08.95		0 280 202 210
			0 986 280 063
Speed sensor, ignition/injection	09.88-08.95		0 261 210 030
Temperature sensor, coolant, injection system	09.88-08.95		0 280 130 107
Wheel speed sensor, front			
Fg.no. →M1999999, →N5000039, →MV999999	09.88-08.95		0 265 001 206
Wheel speed sensor, rear			
Fg.no. N1000001 →	09.88-08.95	AA,LAB	0 265 006 487
		AA,RAB	0 265 006 486
Fg.no. →M1999999	09.88-08.95	AA,LAB	0 265 001 226
2.0 i 4x4 [III]	2,0 l 150 kW C20LET 4 Zyl.		
Speed sensor, ignition/injection	09.92-08.95		0 261 210 030
Knock sensor	09.92-08.95	MIL	0 261 231 079
		OHL	0 261 231 006
Temperature sensor, intake air, injection system	09.92-08.95		0 280 130 039
Temperature sensor, coolant, injection system	09.92-08.95		0 280 130 107
Wheel speed sensor, front			
Fg.no. →M1999999, →N5000039, →MV999999	09.92-08.95		0 265 001 206
Wheel speed sensor, rear			
Fg.no. N1000001 →	09.92-08.95	AA,LAB	0 265 006 487
		AA,RAB	0 265 006 486
Fg.no. →M1999999	09.92-08.95	AA,LAB	0 265 001 226




Product				
◀ Cavalier				
2.0i 16V [III] 2,0l 100 kW X 20 XEV 4 Zyl.				
Wheel speed sensor, front				
Fg.no. →M1999999, →N5000039, →MV999999	09.93-11.95			0 265 001 206
Wheel speed sensor, rear				
Fg.no. →NV999999, →N1999999, →N5999999	09.93-11.95	L10,RAB		0 265 001 207
		L13,LAB		0 265 001 208
2.0i 16V [III] 2,0l 110 kW C20XE(XEJ-LN); 20 XE/XEJ 4 Zyl.				
Throttle valve sensor				
Fg.no. →M1999999, →N1999999, →N5999999	09.88-08.95			0 280 120 326
Speed sensor, ignition/injection	09.88-11.95			0 261 210 030
Knock sensor	09.88-11.95	MIL		0 261 231 079
		OHL		0 261 231 006
Temperature sensor, intake air, injection system				
Fg.no. P1000001→, P5000001→, P7500001→	09.88-11.95			0 280 130 073
Temperature sensor, coolant, injection system	09.88-11.95			0 280 130 107
Wheel speed sensor, front				
Fg.no. →M1999999, →N5000039, →MV999999	09.88-11.95			0 265 001 206
Wheel speed sensor, rear				
Fg.no. NV100001→NV999999, N1000001→N1999999, N5000001→N5999999	09.88-11.95	LAB		0 265 003 094
		RAB		0 265 003 093
Fg.no. →MV999999, →M1999999, →M5999999	09.88-11.95	LAB		0 265 001 233
		RAB		0 265 001 232
2.0i 16V 4x4 [III] 2,0l 110 kW C 20 XE (XEJ-LN) 4 Zyl.				
Throttle valve sensor				
Fg.no. →NV999999, →N1999999, →N5999999	09.88-08.95			0 280 120 326
Speed sensor, ignition/injection	09.88-11.95			0 261 210 030
Knock sensor	09.88-11.95	MIL		0 261 231 079
		OHL		0 261 231 006
Temperature sensor, intake air, injection system				
Fg.no. P1000001→, P5000001→, P7500001→	09.88-11.95			0 280 130 073
Temperature sensor, coolant, injection system	09.88-11.95			0 280 130 107
Wheel speed sensor, front				
Fg.no. →M1999999, →N5000039, →MV999999	09.88-11.95			0 265 001 206
Wheel speed sensor, rear				
Fg.no. N1000001→	09.88-11.95	AA,LAB		0 265 006 487
		AA,RAB		0 265 006 486
Fg.no. →M1999999	09.88-11.95	AA,LAB		0 265 001 226
2.5i [III] 2,5l 125 kW C 25XE V6 6 Zyl.				
Phase sensor				
Fg.no. →S1035178	02.93-11.95			0 232 103 001
Knock sensor	02.93-11.95			0 261 231 079
Temperature sensor, intake air, injection system	02.93-11.95			0 280 130 073
Temperature sensor, coolant, injection system	02.93-11.95			0 280 130 107
Wheel speed sensor, front				
Fg.no. →M1999999, →N5000039, →MV999999	02.93-11.95			0 265 001 206

Combo

1.2i 1,2l 33 kW C 12 NZ; X 12 SZ; 12 NZ 4 Zyl.				
Temperature sensor, coolant, injection system				
Fg.no. W3000001→	09.94-10.01			0 280 130 093
Fg.no. →V6999999	09.94-10.01			0 280 130 107

Product				
1.3 CDTi [Tour] 1,3l 51/55 kW ... 13 DT; Z 13 DTJ 4 Zyl.				
Air mass meter, diesel	09.04→			0 281 002 549
High-pressure sensor (CR system)	09.04→			0 281 002 534
Pressure sensor, intake manifold, diesel				
Fg.no. →53999999, →54999999, →56999999	09.04→			0 281 002 510
Fg.no. 63000001→, 64000001→, 66000001→	09.04→			0 281 002 844
1.4i 1,4l 44/60/66 kW C 14 NZ; C 14 SE; C 14 SEL; X 14 SZ 4 Zyl.				
Temperature sensor, coolant, injection system				
Fg.no. W3000001→	09.94-10.01			0 280 130 093
Fg.no. →V6999999	09.94-10.01			0 280 130 107
1.4i Twinport [Tour] 1,4l 66 kW Z 14 XEP 4 Zyl.				
Throttle valve assembly	01.04→			0 280 750 133
Air mass meter, gasoline injection	01.04→			0 280 218 119
Phase sensor				
Fg.no. →44999999, →46999999	01.04→	NOC		0 232 103 021
Fg.no. 54000001→, 56000001→	01.04→	NOC		0 232 103 052
Speed sensor, ignition/injection	01.04→	FKW		0 261 210 151
Knock sensor	01.04→			0 261 231 173
Temperature sensor, coolant, injection system	01.04→			0 281 002 170
1.4i Twinport Dualfuel [Tour] 1,4l 65 kW Z 14 XEP 4 Zyl.				
Throttle valve assembly	09.04→			0 280 750 133
Air mass meter, gasoline injection	09.04→			0 280 218 119
Phase sensor				
Fg.no. →44999999, →46999999	09.04→	NOC		0 232 103 021
Fg.no. 54000001→, 56000001→	09.04→	NOC		0 232 103 052
Speed sensor, ignition/injection	09.04→	FKW		0 261 210 151
Knock sensor	09.04→			0 261 231 173
Temperature sensor, coolant, injection system	09.04→			0 281 002 170
1.6 CNG [Tour] 1,6l 69-71 kW Y 16 YNG 4 Zyl.				
Pressure sensor, ESP, (electronic stability program)	04.05→			0 265 005 303
1.6i [Tour] 1,6l 69 kW Z 16 YNG 4 Zyl.				
Pressure sensor, ESP, (electronic stability program)	06.06→			0 265 005 303
1.7 CDTi [Tour] 1,7l 74 kW Z 17 DTH 4 Zyl.				
Air mass meter, diesel	09.04→			0 281 002 549
1.7 DI [Tour] 1,7l 48 kW Y 17 DTL Turbo 4 Zyl.				
Air mass meter, diesel	09.01-08.04			0 281 002 180
1.7 DTi [Tour] 1,7l 55 kW Y 17 DT Turbo 4 Zyl.				
Air mass meter, diesel	10.01-08.04			0 281 002 180
Corsa				
1.0i [B] 1,0l 40 kW X 10 XE 3 Zyl.				
Throttle valve sensor	09.96-09.00			0 280 122 014
Air mass meter, gasoline injection	09.96-09.00			0 280 217 123
Phase sensor	09.96-09.00	NOC		0 232 103 021
Speed sensor, ignition/injection	09.96-09.00	FKW		0 261 210 151
Knock sensor	09.96-09.00			0 261 231 120
Temperature sensor, coolant, injection system	09.96-09.00	KZB		0 281 002 169
1.0i 12V [C] 1,0l 43 kW Z 10 XE 3 Zyl.				
Air mass meter, gasoline injection	09.00-08.03			0 280 218 031
				0 986 280 230
Phase sensor	09.00-08.03	NOC		0 232 103 021
Speed sensor, ignition/injection	09.00-08.03	FKW		0 261 210 151
Knock sensor	09.00-08.03			0 261 231 120
Temperature sensor, coolant, injection system				
Mot.no. →19T75858	09.00-08.03			0 281 002 169
Mot.no. 19T5859→	09.00-08.03			0 281 002 170
1.0 Twinport [C] 1,0l 44 kW Z 10 XEP 3 Zyl.				
Throttle valve assembly	09.03-08.05			0 280 750 133
Air mass meter, gasoline injection	09.03-08.05			0 280 218 119





Phase sensor	09.03-08.05	NOC,TW	0 232 103 021
Fg.no. →54999999,→56999999	09.03-08.05	NOC	0 232 103 052
Fg.no. 64000001→,66000001→	09.03-08.05	NOC	0 232 103 067
Speed sensor, ignition/injection	09.03-08.05	FKW	0 261 210 151
Knock sensor	09.03-08.05		0 261 231 173
Temperature sensor, coolant, injection system	09.03-08.05		0 281 002 170
Yaw rate sensor, brake system	09.03-08.05		0 265 005 270
1.0 Twinport [D]	1,0l 44 kW Z 10 XEP 3 Zyl.		
Throttle valve assembly	07.06→		0 280 750 133
Phase sensor	07.06→	NOC	0 232 103 067
Knock sensor	07.06→		0 261 231 173
Pressure sensor, intake manifold, gasoline	07.06→		0 261 230 101
Temperature sensor, coolant, injection system	07.06→		0 281 002 170
Yaw rate sensor, brake system	07.06→	MBH	0 265 005 657
		NBA	0 265 005 656
Wheel speed sensor, front	07.06→		0 265 007 671
Wheel speed sensor, rear	07.06→	STB	0 265 007 768
		4SB	0 265 007 769
1.2 i [B]	1,2l 33 kW C 12 NZ; X 12 SZ; 12 NZ 4 Zyl.		
Temperature sensor, coolant, injection system			
Fg.no. W3000001→	09.94-08.00		0 280 130 093
Fg.no. →V6999999	09.94-08.00		0 280 130 107
1.2 i [B]	1,2l 48 kW X 12 XE 4 Zyl.		
Throttle valve sensor	09.97-08.00		0 280 122 014
Air mass meter, gasoline injection	09.97-08.00		0 280 217 123
Phase sensor	09.97-08.00	NOC	0 232 103 021
Speed sensor, ignition/injection	09.97-08.00	FKW	0 261 210 151
Knock sensor	09.97-08.00		0 261 231 120
Temperature sensor, coolant, injection system	09.97-08.00	KZB	0 281 002 169
1.2 i 16V [C]	1,2l 55 kW Z 12 XE 4 Zyl.		
Air mass meter, gasoline injection	09.00-08.04		0 280 218 031
			0 986 280 230
Phase sensor	09.00-08.04	NOC	0 232 103 021
Speed sensor, ignition/injection	09.00-08.04	FKW	0 261 210 151
Knock sensor	09.00-08.04		0 261 231 120
Temperature sensor, coolant, injection system			
Mot.no. →19T75858	09.00-08.04		0 281 002 169
Mot.no. 19T5859→	09.00-08.04		0 281 002 170
1.2 Twinport [C]	1,2l 59 kW Z 12 XEP 4 Zyl.		
Throttle valve assembly	09.04-09.06		0 280 750 133
Air mass meter, gasoline injection	09.04-09.06		0 280 218 119
Phase sensor	09.04-09.06	NOC,TW	0 232 103 021
Fg.no. →54999999,→56999999	09.04-09.06	NOC	0 232 103 052
Fg.no. 64000001→,66000001→	09.04-09.06	NOC	0 232 103 067
Speed sensor, ignition/injection	09.04-09.06	FKW	0 261 210 151
Knock sensor	09.04-09.06		0 261 231 173
Temperature sensor, coolant, injection system	09.04-09.06		0 281 002 170
Yaw rate sensor, brake system	09.04-09.06		0 265 005 270
Pressure sensor, ESP, (electronic stability program)	09.04-09.06		0 265 005 303
1.2 Twinport [D]	1,2l 59 kW Z 12 XEP 4 Zyl.		
Throttle valve assembly	07.06→		0 280 750 133
Phase sensor	07.06→	NOC	0 232 103 067
Knock sensor	07.06→		0 261 231 173
Pressure sensor, intake manifold, gasoline	07.06→		0 261 230 101
Temperature sensor, coolant, injection system	07.06→		0 281 002 170
Yaw rate sensor, brake system	07.06→	MBH	0 265 005 657
		NBA	0 265 005 656
Wheel speed sensor, front	07.06→		0 265 007 671
Wheel speed sensor, rear	07.06→	STB	0 265 007 768
		4SB	0 265 007 769
1.2 Twinport Dualfuel [C]	1,2l 59 kW Z 12 XEP 4 Zyl.		
Throttle valve assembly	09.04-09.06		0 280 750 133
Air mass meter, gasoline injection	09.04-09.06		0 280 218 119




Phase sensor	09.04-09.06	NOC,TW	0 232 103 021
Fg.no. →54999999,→56999999	09.04-09.06	NOC	0 232 103 052
Fg.no. 64000001→,66000001→	09.04-09.06	NOC	0 232 103 067
Speed sensor, ignition/injection	09.04-09.06	FKW	0 261 210 151
Knock sensor	09.04-09.06		0 261 231 173
Temperature sensor, coolant, injection system	09.04-09.06		0 281 002 170
Yaw rate sensor, brake system	09.04-09.06		0 265 005 270
Pressure sensor, ESP, (electronic stability program)	09.04-09.06		0 265 005 303
1.2 16V Dualfuel [C]	1,2l 55 kW Z 12 XE 4 Zyl.		
Air mass meter, gasoline injection	08.01-08.04		0 280 218 031
			0 986 280 230
Phase sensor	08.01-08.04	NOC	0 232 103 021
Speed sensor, ignition/injection	08.01-08.04	FKW	0 261 210 151
Knock sensor	08.01-08.04		0 261 231 120
Temperature sensor, coolant, injection system			
Mot.no. →19T75858	08.01-08.04		0 281 002 169
Mot.no. 19T5859→	08.01-08.04		0 281 002 170
1.3 CDTi [C]	1,3l 51 kW ... 13 DT 4 Zyl.		
Air mass meter, diesel	09.03-09.06		0 281 002 549
High-pressure sensor (CR system)	09.03-09.06		0 281 002 534
Pressure sensor, intake manifold, diesel	09.03-09.06		0 281 002 510
Yaw rate sensor, brake system	09.03-09.06		0 265 005 270
1.3 CDTi [C]	1,3l 55 kW Z 13 DTJ 4 Zyl.		
High-pressure sensor (CR system)	09.05-09.06		0 281 002 706
Pressure sensor, intake manifold, diesel	09.05-09.06		0 281 002 510
Pressure sensor, ESP, (electronic stability program)	09.05-09.06		0 265 005 303
1.3 CDTi [D]	1,3l 55/66 kW A 13 DTH; A 13 DTJ; Z 13 DTJ 4 Zyl.		
High-pressure sensor (CR system)	07.06→		0 281 002 706
Pressure sensor, intake manifold, diesel	07.06→		0 281 002 844
Yaw rate sensor, brake system	07.06→	MBH	0 265 005 657
		NBA	0 265 005 656
Wheel speed sensor, front	07.06→		0 265 007 671
Wheel speed sensor, rear	07.06→	STB	0 265 007 768
		4SB	0 265 007 769
1.3 CDTi [D]	1,3l 66 kW Z 13 DTH 4 Zyl.		
High-pressure sensor (CR system)	07.06→		0 281 002 706
Boost pressure sensor, Diesel	07.06→		0 281 002 437
Pressure sensor, intake manifold, diesel	07.06→		0 281 002 844
Yaw rate sensor, brake system	07.06→	MBH	0 265 005 657
		NBA	0 265 005 656
Wheel speed sensor, front	07.06→		0 265 007 671
Wheel speed sensor, rear	07.06→	STB	0 265 007 768
		4SB	0 265 007 769
1.4 i [B]	1,4l 44 kW C 14 NZ; X 14 SZ 4 Zyl.		
Temperature sensor, intake air, injection system			
Fg.no. W3000001→	09.94-08.00		0 280 130 093
Fg.no. →V6999999	09.94-08.00		0 280 130 107
Temperature sensor, coolant, injection system	09.94-08.00	KOB	0 280 130 093
Fg.no. W3000001→	09.94-08.00		0 280 130 093
Fg.no. →V6999999	09.94-08.00		0 280 130 107
1.4 i [B]	1,4l 60/63 kW C 14 SE; C 14 SEL 4 Zyl.		
Temperature sensor, coolant, injection system			
Fg.no. W3000001→	09.94-08.00		0 280 130 093
Fg.no. →V6999999	09.94-08.00		0 280 130 107
1.4 i [B]	1,4l 66 kW X 14 XE 4 Zyl.		
Temperature sensor, coolant, injection system	09.94-08.99	KOB	0 280 130 093
Fg.no. W3000001→	09.94-08.99		0 280 130 093
Fg.no. →V6999999	09.94-08.99		0 280 130 107
1.4 Twinport [C]	1,4l 66 kW Z 14 XEP 4 Zyl.		
Throttle valve assembly	09.03-08.05		0 280 750 133
Air mass meter, gasoline injection	09.03-08.05		0 280 218 119
Phase sensor	09.03-08.05	NOC	0 232 103 021
Speed sensor, ignition/injection	09.03-08.05	FKW	0 261 210 151

</

Product				
Speed sensor, ignition/injection	02.95-08.98	0 261 210 030		
Knock sensor	02.95-08.98	0 261 231 007		
2.2 DTi [B]	2,2l 85/88 kW X 22 DTH; Y 22 DTH 4 Zyl.			
Air mass meter, diesel	09.98-09.04	0 281 002 184		
Speed sensor, diesel	09.98-09.04	0 281 002 138		
Temperature sensor, coolant, diesel	09.98-09.04	0 281 002 169		
Temperature sensor, intake air, diesel	09.98-09.04	0 261 230 009		
2.2 i [A]	2,2l 100 kW X 22 XE 4 Zyl.			
Throttle valve sensor	02.95-08.98	0 280 122 001		
Air mass meter, gasoline injection	02.95-08.98	0 280 217 003		
Speed sensor, ignition/injection				
Fg.no. →TV8999999	02.95-08.98	0 261 210 030		
Knock sensor	02.95-08.98	0 261 231 007		
Temperature sensor, coolant, injection system	02.95-08.98	0 280 130 107		
2.3 TD [A]	2,3l 74 kW 23 DT 4 Zyl.			
Air mass meter, diesel	01.92-08.95	0 281 002 144		
2.4 i [A]	2,4l 92 kW C 24 NE CIH 4 Zyl.			
Throttle valve sensor	01.92-08.95	0 280 122 001		
Air flow sensor, gasoline injection	01.92-08.95	0 280 202 211		
		👁 0 986 280 091		
Speed sensor, ignition/injection	01.92-08.95	0 261 210 031		
Temperature sensor, coolant, injection system	01.92-08.95	0 280 130 107		
2.5 TDS Turbo [A]	2,5l 85 kW Venturi-25TD VM41B 4 Zyl.			
Air mass meter, diesel	06.96-08.98	0 281 002 144		
Pedal position sensor, diesel	06.96-08.98	LLE	0 205 001 055	
		RLE	0 205 001 054	
Meriva				
1.3 CDTi	1,2l 55 kW ... 13 DT 4 Zyl.			
Air mass meter, diesel	09.05→	0 281 002 620		
High-pressure sensor (CR system)	09.05→	0 281 002 706		
Yaw rate sensor, brake system				
Fg.no. →449999999	09.05→	0 265 005 262		
Fg.no. 54000001→549999999	09.05→	0 265 005 270		
Fg.no. 64000001→	09.05→	MBH	0 265 005 657	
		NBA	0 265 005 656	
Pressure sensor, ESP, (electronic stability program)	09.05→	0 265 005 303		
1.3 CDTi	1,2l 55 kW Z 13 DTJ 4 Zyl.			
High-pressure sensor (CR system)	09.03→	0 281 002 706		
Yaw rate sensor, brake system				
Fg.no. →449999999	09.03→	0 265 005 262		
Fg.no. 54000001→549999999	09.03→	0 265 005 270		
Fg.no. 64000001→	09.03→	MBH	0 265 005 657	
		NBA	0 265 005 656	
Pressure sensor, ESP, (electronic stability program)	09.03→	0 265 005 303		
1.4 16V Twinport	1,4l 66 kW Z 14 XEP 4 Zyl.			
Throttle valve assembly	07.04→	0 280 750 133		
Air mass meter, gasoline injection	07.04→	0 280 218 119		
Phase sensor				
Fg.no. →449999999	07.04→	NOC	0 232 103 021	
Fg.no. 54000001→549999999	07.04→	NOC	0 232 103 052	
Fg.no. 64000001→	07.04→	NOC	0 232 103 067	
Speed sensor, ignition/injection	07.04→	FKW	0 261 210 151	
Knock sensor	07.04→	0 261 231 173		
Temperature sensor, coolant, injection system	07.04→	0 281 002 170		
Yaw rate sensor, brake system	07.04→	0 265 005 262		
Pressure sensor, ESP, (electronic stability program)	07.04→	0 265 005 303		
1.6 i	1,6l 64 kW Z 16 SE 4 Zyl.			
Yaw rate sensor, brake system	03.03-09.05	0 265 005 262		
1.6 i OPC Turbo	1,6l 132 kW Z 16 LET 4 Zyl.			
Air mass meter, gasoline injection	09.05→	0 280 218 142		
Phase sensor	09.05→	NOC	0 232 103 052	






Knock sensor	09.05→	0 261 231 173
Pressure sensor, intake manifold, gasoline	09.05→	0 281 002 137
Yaw rate sensor, brake system		
Fg.no. →44999999	09.05→	0 265 005 262
Fg.no. 54000001→54999999	09.05→	0 265 005 270
Fg.no. 64000001→	09.05→	MBH 0 265 005 657
		NBA 0 265 005 656
Pressure sensor, ESP, (electronic stability program)	09.05→	0 265 005 303
1.6 i 16V	1,6 l 74 kW Z 16 XE 4 Zyl.	
Yaw rate sensor, brake system	03.03-02.06	0 265 005 262
1.6 i 16V	1,6 l 77 kW Z 16 XEP 4 Zyl.	
Yaw rate sensor, brake system		
Fg.no. →44999999	01.06→	0 265 005 262
Fg.no. 54000001→54999999	01.06→	0 265 005 270
Fg.no. 64000001→	01.06→	MBH 0 265 005 657
		NBA 0 265 005 656
Pressure sensor, ESP, (electronic stability program)	01.06→	0 265 005 303
1.7 CDTi	1,7 l 74 kW Z 17 DTH 4 Zyl.	
Air mass meter, diesel	09.03-09.05	0 281 002 620
Yaw rate sensor, brake system	09.03-09.05	0 265 005 262
1.7 CDTi	1,7 l 92 kW A 17 ..., Z 17 ... 4 Zyl.	
Yaw rate sensor, brake system		
Fg.no. →44999999	09.06→	0 265 005 262
Fg.no. 54000001→54999999	09.06→	0 265 005 270
Fg.no. 64000001→	09.06→	MBH 0 265 005 657
		NBA 0 265 005 656
Pressure sensor, ESP, (electronic stability program)	09.06→	0 265 005 303
1.7 DTi	1,7 l 55 kW Y 17 DT 4 Zyl.	
Yaw rate sensor, brake system	03.03-09.05	0 265 005 262
1.8 i 16V	1,8 l 92 kW Z 18 XE 4 Zyl.	
Yaw rate sensor, brake system	03.03→	0 265 005 262

Nova

1.2 i	1,2 l 33 kW C 12 NZ 4 Zyl.	
Temperature sensor, coolant, injection system	09.90-08.94	0 280 130 107
1.4 i	1,4 l 44/60 kW C 14 NZ; C 14 SE 4 Zyl.	
Temperature sensor, coolant, injection system	01.90-08.94	0 280 130 107
1.6 i	1,6 l 55/74 kW C 16 NZ; E 16 SE 4 Zyl.	
Temperature sensor, coolant, injection system	05.88-08.94	0 280 130 107

Omega

2.0 DTi [B]	2,0 l 74 kW X 20 DTH Turbo 4 Zyl.	
Air mass meter, diesel	09.97-08.00	0 281 002 180
Speed sensor, diesel	09.97-08.00	0 281 002 138
Temperature sensor, coolant, diesel	09.97-08.00	0 281 002 169
Pedal position sensor, diesel		
Fg.no. →V1999999	09.97-08.00	0 205 001 039
2.0 i [B]	2,0 l 85 kW X 20 SE; 20 SE 4 Zyl.	
Throttle valve sensor	04.94-12.00	0 280 122 001
Air mass meter, gasoline injection	04.94-12.00	0 280 217 106
Knock sensor	04.94-12.00	0 261 231 006
Temperature sensor, intake air, injection system	04.94-12.00	0 280 130 073
Temperature sensor, coolant, injection system	04.94-12.00	0 280 130 107
2.0 i [B]	2,0 l 100 kW X 20 XEV 4 Zyl.	
Throttle valve sensor	09.93-08.99	0 280 122 001
2.2 DTi [B]	2,2 l 88 kW Y 22 DTH Turbo 4 Zyl.	
Air mass meter, diesel	06.00-09.03	0 281 002 428
Speed sensor, diesel	06.00-09.03	0 281 002 138
Pedal position sensor, diesel	06.00-09.03	0 280 752 027



2.5 i [B]	2,5 l 125 kW X 25 XE 6 Zyl.	
Throttle valve sensor		
Fg.no. V1000001→	04.94-09.04	0 280 122 014
Fg.no. →T1999999	04.94-09.04	0 280 122 001
Air mass meter, gasoline injection		
Mot.no. →01837540	04.94-09.04	0 280 217 503
Mot.no. 08137541→	04.94-09.04	0 280 217 519
Phase sensor	04.94-09.04	MTS 0 232 103 008
		OTS 0 232 103 001
Mot.no. →08149313	04.94-09.04	0 232 103 008
Mot.no. 08149314→	04.94-09.04	0 232 103 017
Knock sensor		
Mot.no. →08137540	04.94-09.04	0 261 231 079
Mot.no. 08137541→	04.94-09.04	0 261 231 116
Temperature sensor, intake air, injection system		
Mot.no. →08137540	04.94-09.04	0 280 130 073
Mot.no. 08137541→	04.94-09.04	0 280 130 092
Temperature sensor, coolant, injection system		
Mot.no. →08137540	04.94-09.04	0 280 130 107
Mot.no. 08137541→	04.94-09.04	0 280 130 093
2.5 TD [B]	2,5 l 96 kW U 25 TD -R6 Turbo 6 Zyl.	
Pedal position sensor, diesel		
Fg.no. S1155598→	04.94-02.01	LLE 0 205 001 039
Fg.no. S1156241→	04.94-02.01	RLE 0 205 001 039
Fg.no. →S1155597	04.94-02.01	LLE 0 205 001 019
Fg.no. →S1156240	04.94-02.01	RLE 0 205 001 019
2.5 TDi [B]	2,5 l 96 kW X 25 TD Turbo 6 Zyl.	
Pedal position sensor, diesel		
Fg.no. S1155598→	04.96-09.04	LLE 0 205 001 039
Fg.no. S1156241→	04.96-09.04	RLE 0 205 001 039
Fg.no. →S1155597	04.96-09.04	LLE 0 205 001 019
Fg.no. →S1156240	04.96-09.04	RLE 0 205 001 019
2.5 TDi [B]	2,5 l 110 kW Y 25 TD Turbo 6 Zyl.	
Air mass meter, diesel	09.01-09.04	0 281 002 564
2.6 i [B]	2,6 l 132 kW Y 26 SE 6 Zyl.	
Air mass meter, gasoline injection	09.00-09.04	0 281 002 184
Phase sensor	09.00-09.04	0 232 103 025
Speed sensor, ignition/injection		
Mot.no. 08149314→	09.00-09.04	0 261 210 131
Knock sensor		
Mot.no. 08137541→	09.00-09.04	0 261 231 116
3.0 i [B]	3,0 l 155 kW X 30 XE 6 Zyl.	
Throttle valve sensor		
Fg.no. V1000001→	04.94-02.01	0 280 122 014
Fg.no. →T1999999	04.94-02.01	0 280 122 001
Air mass meter, gasoline injection		
Mot.no. →01837540	04.94-02.01	0 280 217 503
Mot.no. 08137541→	04.94-02.01	0 280 217 519
Phase sensor	04.94-02.01	MTS 0 232 103 008
		OTS 0 232 103 001
Mot.no. →08149313	04.94-02.01	0 232 103 008
Mot.no. 08149314→	04.94-02.01	0 232 103 017
Speed sensor, ignition/injection		
Mot.no. 08149314→	04.94-02.01	0 261 210 131
Knock sensor		
Mot.no. →08137540	04.94-02.01	0 261 231 079
Mot.no. 08137541→	04.94-02.01	0 261 231 116
Temperature sensor, intake air, injection system		
Mot.no. →08137540	04.94-02.01	0 280 130 073
Mot.no. 08137541→	04.94-02.01	0 280 130 092
Temperature sensor, coolant, injection system		
Mot.no. →08137540	04.94-02.01	0 280 130 107
Mot.no. 08137541→	04.94-02.01	0 280 130 093



Product				

◀ Omega

3.2 i [B]	3,2 l 160 kW Y 32 SE 6 Zyl.
Air mass meter, gasoline injection	09.00-09.04 0 281 002 184
Phase sensor	09.00-09.04 0 232 103 025
Speed sensor, ignition/injection	
Mot.no. 08149314→	09.00-09.04 0 261 210 131
Knock sensor	
Mot.no. 08137541→	09.00-09.04 0 261 231 116

Senator

2.5 i [B]	2,5 l 103 kW 25 NE CIH 6 Zyl.
Air flow sensor, gasoline injection	09.87-10.90 0 280 202 053
Temperature sensor, coolant, injection system	09.87-10.90 0 280 130 069
2.6 i [B]	2,6 l 110 kW C 26 NE CIH 6 Zyl.
Air flow sensor, gasoline injection	09.90-08.93 0 280 202 207
Temperature sensor, coolant, injection system	09.90-08.93 0 280 130 107
3.0 i [B]	3,0 l 115 kW C 30 LE CIH 6 Zyl.
Air flow sensor, gasoline injection	09.87-08.93 0 280 202 201
Temperature sensor, coolant, injection system	09.87-08.93 0 280 130 107
3.0 i [B]	3,0 l 130 kW C 30 NE CIH 6 Zyl.
Air flow sensor, gasoline injection	01.88-08.93 0 280 203 032
	👉 0 986 280 074
Temperature sensor, coolant, injection system	01.88-08.93 0 280 130 107
3.0 i [B]	3,0 l 130 kW 30 NE CIH 6 Zyl.
Temperature sensor, coolant, injection system	01.88-09.90 0 280 130 069
3.0 i 24V [B]	3,0 l 150 kW C 30 SE 6 Zyl.
Air flow sensor, gasoline injection	09.89-08.93 0 280 203 032
	👉 0 986 280 074
Temperature sensor, coolant, injection system	09.89-08.93 0 280 130 107

Signum

1.9 CDTI	1,9 l 74 kW Z 19 DTL 4 Zyl.
Speed sensor, diesel	09.05→ 0 281 002 603
Phase sensor	09.05→ NOC 0 281 002 213
High-pressure sensor (CR system)	09.05→ 0 281 002 706
Boost pressure sensor, Diesel	09.05→ 0 281 002 437
1.9 CDTI	1,9 l 88 kW Z 19 DT 4 Zyl.
Speed sensor, diesel	04.04→ 0 281 002 603
Phase sensor	04.04→ NOC 0 281 002 213
Pressure sensor, intake manifold, diesel	04.04→ 0 281 002 437
1.9 CDTI	1,9 l 110 kW Z 19 DTH 4 Zyl.
High-pressure sensor (CR system)	04.04→ 0 281 002 706
Pressure sensor, intake manifold, diesel	04.04→ 0 281 002 437
2.0 DTI	2,0 l 74 kW Y 20 DTH 4 Zyl.
Air mass meter, diesel	05.03-09.05 0 281 002 479
Speed sensor, diesel	
Fg.no. →17G23740	05.03-09.05 FKW 0 281 002 138
Fg.no. 17G23741→	05.03-09.05 FKW 0 281 002 662
Temperature sensor, coolant, diesel	05.03-09.05 0 281 002 473
2.0 Turbo	2,0 l 129 kW Z 20 NET 4 Zyl.
Speed sensor, ignition/injection	05.03→ FKW 0 261 210 229
2.2 DTI	2,2 l 86-92 kW Y 22 DTR 4 Zyl.
Air mass meter, diesel	05.03→ 0 281 002 479
Speed sensor, diesel	05.03→ FKW 0 281 002 138
Temperature sensor, coolant, diesel	05.03→ 0 281 002 473
2.8 V6 Turbo	2,8 l 169/184 kW Z 28 NEL; Z 28 NET 6 Zyl.
Knock sensor	08.05→ 0 261 231 174
Pressure sensor, intake manifold, gasoline	08.05→ 0 261 230 101
Temperature sensor, coolant, injection system	08.05→ 0 280 130 122
3.0 CDTI	3,0 l 130-135 kW Y 30 DT 6 Zyl.
Air mass meter, diesel	05.03→ 0 281 002 605

Product				

3.0 CDTI	3,0 l 130-135 kW Z 30 DT 6 Zyl.
Air mass meter, diesel	09.05→ 0 281 002 773
3.2 i	3,2 l 155 kW Z 32 SE 6 Zyl.
Throttle valve assembly	05.03-09.05 0 280 750 119
Air mass meter, gasoline injection	05.03-09.05 0 280 218 087
Phase sensor	05.03-09.05 NOC 0 232 103 025
Speed sensor, ignition/injection	05.03-09.05 FKW 0 261 210 206
Knock sensor	05.03-09.05 0 261 231 116

Sintra

2.2 i 16V	2,2 l 104 kW X 22 XE 4 Zyl.
Throttle valve sensor	09.96-09.99 0 280 122 001
Phase sensor	09.96-09.99 0 232 103 015
Knock sensor	09.96-09.99 0 261 231 079
Pressure sensor, intake manifold, gasoline	09.96-09.99 0 261 230 009
Temperature sensor, intake air, injection system	
Fg.no. XD100001→	09.96-09.99 0 280 130 092
Fg.no. →WD199999	09.96-09.99 0 280 130 073
Temperature sensor, coolant, injection system	09.96-09.99 0 281 002 169
2.2 TD	2,2 l 85 kW X 22 DTH Turbo 4 Zyl.
Air mass meter, diesel	09.97-09.99 0 281 002 184
Speed sensor, diesel	09.97-09.99 0 281 002 138
Pressure sensor, intake manifold, diesel	09.97-09.99 0 281 002 137
Temperature sensor, coolant, injection system	09.97-09.99 0 280 130 107
Pedal position sensor, diesel	09.97-09.99 LLE 0 205 001 039
	RLE 0 205 001 042
3.0 i 24V	3,0 l 148 kW X 30 XE V6 6 Zyl.
Throttle valve sensor	09.96-09.99 0 280 122 001
Air mass meter, gasoline injection	09.96-09.99 0 280 217 503
Phase sensor	09.96-09.99 0 232 103 008
Knock sensor	09.96-09.99 0 261 231 079
Temperature sensor, intake air, injection system	09.96-09.99 0 280 130 092
Temperature sensor, coolant, injection system	09.96-09.99 0 281 002 169
Pedal position sensor, diesel	09.96-09.99 LLE 0 205 001 039
	RLE 0 205 001 042

Tigra

1.4 i	1,4 l 66 kW X 14 XE 4 Zyl.
Temperature sensor, coolant, injection system	
Fg.no. W3000001→	09.94-08.99 0 280 130 093
Fg.no. →V6999999	09.94-08.99 0 280 130 107
1.6 i	1,6 l 78 kW X 16 XE 4 Zyl.
Temperature sensor, coolant, injection system	
Fg.no. W3000001→	09.94-08.99 0 280 130 093
Fg.no. →V6999999	09.94-08.99 0 280 130 107

Tigra Twin Top


1.3 CDTI [B]	1,3 l 51 kW Z 13 DT 4 Zyl.
Air mass meter, diesel	06.04→ 0 281 002 549
High-pressure sensor (CR system)	06.04→ 0 281 002 534
Pressure sensor, intake manifold, diesel	06.04→ 0 281 002 510
Yaw rate sensor, brake system	06.04→ 0 265 005 270
Pressure sensor, ESP, (electronic stability program)	06.04→ 0 265 005 303
1.4 i [B]	1,4 l 66 kW Z 14 XEP 4 Zyl.
Throttle valve assembly	06.04→ 0 280 750 133
Air mass meter, gasoline injection	06.04→ 0 280 218 119
Phase sensor	
Fg.no. →4E999999	06.04→ NOC 0 232 103 021
Fg.no. 5E000001→5E999999	06.04→ NOC 0 232 103 052
Fg.no. 6E000001→	06.04→ NOC 0 232 103 067



Speed sensor, ignition/injection	06.04→	FKW	0 261 210 151
Knock sensor	06.04→		0 261 231 173
Temperature sensor, coolant, injection system	06.04→		0 281 002 170
Yaw rate sensor, brake system	06.04→		0 265 005 270
Pressure sensor, ESP, (electronic stability program)	06.04→		0 265 005 303
1.8i [B]		1,8l 92 kW Z 18 XE 4 Zyl.	
Yaw rate sensor, brake system	06.04→		0 265 005 270
Pressure sensor, ESP, (electronic stability program)	06.04→		0 265 005 303

Vectra

1.6i [B]		1,6l 55 kW X 16 SZR 4 Zyl.	
Temperature sensor, intake air, injection system			
Fg.no. →02GE3893,→V1999999, →V5999999,→V7999999	09.96-08.00		0 280 130 107
Temperature sensor, coolant, injection system			
Fg.no. 02GE3894→,W1000001→, W5000001→,W7000001→	09.96-08.00		0 280 130 093
1.6i [B]		1,6l 55 kW 16 L22 4 Zyl.	
Speed sensor, ignition/injection	09.95-08.00		0 261 210 030
Temperature sensor, coolant, injection system	09.95-08.00		0 280 130 107
1.6i 16V [B]		1,6l 74 kW X 16 XEL 4 Zyl.	
Temperature sensor, coolant, injection system	09.95-08.00		0 280 130 093
1.8i 16V [B]		1,8l 85 kW X 18 XE 4 Zyl.	
Throttle valve sensor	09.95-08.99		0 280 122 001
1.9 CDTi [C]		1,9l 74 kW Z 19 DTL 4 Zyl.	
Air mass meter, diesel	09.05→		0 281 002 479
Speed sensor, diesel	09.05→		0 281 002 603
Phase sensor	09.05→	NOC	0 281 002 213
High-pressure sensor (CR system)	09.05→		0 281 002 706
Boost pressure sensor, Diesel	09.05→		0 281 002 437
1.9 CDTi [C]		1,9l 88 kW Z 19 DT 4 Zyl.	
Air mass meter, diesel	04.04→		0 281 002 479
Speed sensor, diesel	04.04→		0 281 002 603
Phase sensor	04.04→	NOC	0 281 002 213
High-pressure sensor (CR system)	04.04→		0 281 002 534
Boost pressure sensor, Diesel	04.04→		0 281 002 437
1.9 CDTi [C]		1,9l 110 kW Z 19 DTH 4 Zyl.	
Air mass meter, diesel	04.04→		0 281 002 479
High-pressure sensor (CR system)	04.04→		0 281 002 534
Boost pressure sensor, Diesel	04.04→		0 281 002 437
2.0 Di [B]		2,0l 60 kW X 20 DTL 16V Turbo 4 Zyl.	
Air mass meter, diesel			
Fg.no. W1000001→	09.96-08.00		0 281 002 180
Fg.no. →V7999999	09.96-08.00		0 281 002 139
Speed sensor, diesel	09.96-08.00		0 281 002 138
Pressure sensor, intake manifold, diesel	09.96-08.00		0 281 002 137
Temperature sensor, coolant, diesel	09.96-08.00		0 281 002 169
Temperature sensor, intake air, diesel	09.96-08.00		0 280 130 073
Pedal position sensor, diesel			
Fg.no. W1285447→,W7154259→	09.96-08.00	LLE	0 281 002 476
Fg.no. →W1285446,→W5276825, →W7154258	09.96-08.00	LLE	0 205 001 042
		RLE	0 205 001 039
2.0 DTi [B]		2,0l 74 kW X 20 DTH 16V Turbo 4 Zyl.	
Air mass meter, diesel	09.97-08.00		0 281 002 180
Speed sensor, diesel	09.97-08.00		0 281 002 138
Pressure sensor, intake manifold, diesel	09.97-08.00	TW	0 281 002 137
			0 281 002 438
Temperature sensor, coolant, diesel	09.97-08.00		0 281 002 169
Pedal position sensor, diesel			
Fg.no. W1285447→,W7154259→	09.97-08.00	LLE	0 281 002 476
Fg.no. →W1285446,→W5276825, →W7154258	09.97-08.00	LLE	0 205 001 042
		RLE	0 205 001 039



2.0 DTi [B]		2,0l 74 kW Y 20 DTH 16V Turbo 4 Zyl.	
Air mass meter, diesel	09.00-08.01		0 281 002 428
Speed sensor, diesel	09.00-08.01		0 281 002 138
Pressure sensor, intake manifold, diesel	09.00-08.01		0 281 002 438
Temperature sensor, coolant, diesel	09.00-08.01		0 281 002 169
Pedal position sensor, diesel	09.00-08.01	LLE	0 281 002 476
2.0 DTi [C]		2,0l 74 kW Y 20 DTH 4 Zyl.	
Air mass meter, diesel	04.02-09.05		0 281 002 479
Speed sensor, diesel	04.02-09.05		0 281 002 138
Speed sensor, ignition/injection			
Mot.no. →17G23740	04.02-09.05	FKW	0 281 002 138
Mot.no. 17G23741→	04.02-09.05	FKW	0 281 002 662
2.0i [B]		2,0l 82 kW 20 NEJ 4 Zyl.	
Throttle valve sensor	09.95-08.01		0 280 122 001
Air mass meter, gasoline injection	09.95-08.01		0 280 217 106
Knock sensor	09.95-08.01		0 261 231 006
Temperature sensor, intake air, injection system	09.95-08.01		0 280 130 073
Temperature sensor, coolant, injection system	09.95-08.01		0 280 130 107
2.0i [B]		2,0l 100 kW C 20 SEL 4 Zyl.	
Throttle valve sensor	05.97-09.02		0 280 122 001
2.0i 16V [B]		2,0l 100 kW X 20 XEV 4 Zyl.	
Throttle valve sensor	09.95-08.01		0 280 122 001
2.0 Turbo [C]		2,0l 129 kW Z 20 NET 4 Zyl.	
Speed sensor, ignition/injection	03.03→	FKW	0 261 210 229
2.2 DTi [B]		2,2l 92 kW Y 22 DTR Turbo 4 Zyl.	
Air mass meter, diesel	09.00-08.01		0 281 002 428
Speed sensor, diesel	09.00-08.01		0 281 002 138
Pressure sensor, intake manifold, diesel	09.00-08.01		0 281 002 438
Temperature sensor, coolant, diesel	09.00-08.01		0 281 002 169
Pedal position sensor, diesel	09.00-08.01	LLE	0 281 002 476
2.2 DTi [C]		2,2l 86-92 kW Y 22 DTR 4 Zyl.	
Air mass meter, diesel	04.02-09.05		0 281 002 479
Speed sensor, diesel	04.02-09.05		0 281 002 138
Speed sensor, ignition/injection			
Mot.no. →17G23740	04.02-09.05	FKW	0 281 002 138
Mot.no. 17G23741→	04.02-09.05	FKW	0 281 002 662
2.2i [B]		2,2l 106 kW C 22 SEL 4 Zyl.	
Throttle valve sensor	10.99-08.01		0 280 122 001
2.5i V6 [B]		2,5l 125-143 kW X 25 XE 6 Zyl.	
Throttle valve sensor			
Fg.no. W1000001→	09.95-08.01		0 280 122 014
Fg.no. →V7999999	09.95-08.01		0 280 122 001
Air mass meter, gasoline injection			
Fg.no. W1000001→	09.95-08.01		0 280 217 519
Fg.no. →V7999999	09.95-08.01		0 280 217 503
Knock sensor	09.95-08.01		0 261 231 079
Temperature sensor, intake air, injection system			
Fg.no. W1000001→	09.95-08.01		0 280 130 092
Fg.no. →W1000001	09.95-08.01		0 280 130 073
Temperature sensor, coolant, injection system			
Fg.no. W1000001→,W5000001→, W7000001→,XL000001→	09.95-08.01		0 280 130 093
Fg.no. →V7999999	09.95-08.01		0 280 130 107
2.6 V6 [B]		2,6l 130 kW Y 26 SE 6 Zyl.	
Air mass meter, gasoline injection	09.00-08.01		0 281 002 184
Phase sensor	09.00-08.01		0 232 103 025
Speed sensor, ignition/injection	09.00-08.01	FKW	0 261 210 206
Knock sensor	09.00-08.01		0 261 231 116
Temperature sensor, coolant, injection system	09.00-08.01		0 281 002 169
2.8 GTS Turbo, Turbo [C]		2,8l 169/184-188 kW Z 28 NEL; Z 28 NET 6 Zyl.	
Knock sensor	09.05→		0 261 231 174
Pressure sensor, intake manifold, gasoline	09.05→		0 261 230 101
Temperature sensor, coolant, injection system	09.05→		0 280 130 122



◀ Vectra

3.0 CDTi [C]				3,0l 130-135 kW Y 30 DT 6 Zyl.
Air mass meter, diesel	03.03→			0 281 002 605
3.0 CDTi [C]				3,0l 130-135 kW Z 30 DT 6 Zyl.
Air mass meter, diesel	09.05→			0 281 002 773
3.2 i [C]				3,2l 155 kW Z 32 SE 6 Zyl.
Air mass meter, gasoline injection	08.02-09.05			0 280 218 087
Phase sensor	08.02-09.05	NOC		0 232 103 025
Speed sensor, ignition/injection	08.02-09.05	FKW		0 261 210 206
Knock sensor	08.02-09.05			0 261 231 116

Vectra Estate

1.6 i 16V [B]				1,6l 55 kW X 16 SZR 4 Zyl.
Temperature sensor, intake air, injection system				
Fg.no. →02GE3893,→V1999999,→V5999999,→V7999999	09.96-08.00			0 280 130 107
Temperature sensor, coolant, injection system				
Fg.no. 02GE3894→,W1000001→,W5000001→,W7000001→	09.96-08.00			0 280 130 093
1.6 i 16V [B]				1,6l 55 kW 16 LZ2 4 Zyl.
Speed sensor, ignition/injection	09.95-08.00			0 261 210 030
Temperature sensor, coolant, injection system	09.95-08.00			0 280 130 107
1.6 i 16V [B]				1,6l 74 kW X 16 XEL 4 Zyl.
Temperature sensor, coolant, injection system	09.95-08.00			0 280 130 093
1.8 i 16V [B]				1,8l 85 kW X 18 XE 4 Zyl.
Throttle valve sensor	09.95-08.99			0 280 122 001
1.9 CDTi [C]				1,9l 74 kW Z 19 DTL 4 Zyl.
Air mass meter, diesel	09.05→			0 281 002 479
Speed sensor, diesel	09.05→			0 281 002 603
Phase sensor	09.05→	NOC		0 281 002 213
High-pressure sensor (CR system)	09.05→			0 281 002 706
Boost pressure sensor, Diesel	09.05→			0 281 002 437
1.9 CDTi [C]				1,9l 88 kW Z 19 DT 4 Zyl.
Air mass meter, diesel	04.04→			0 281 002 479
Speed sensor, diesel	04.04→			0 281 002 603
Phase sensor	04.04→	NOC		0 281 002 213
High-pressure sensor (CR system)	04.04→			0 281 002 534
Boost pressure sensor, Diesel	04.04→			0 281 002 437
1.9 CDTi [C]				1,9l 110 kW Z 19 DTH 4 Zyl.
Air mass meter, diesel	04.04→			0 281 002 479
High-pressure sensor (CR system)	04.04→			0 281 002 534
Boost pressure sensor, Diesel	04.04→			0 281 002 437
2.0 Di [B]				2,0l 60 kW X 20 DTL 16V Turbo 4 Zyl.
Air mass meter, diesel				
Fg.no. W1000001→	09.96-08.00			0 281 002 180
Fg.no. →V7999999	09.96-08.00			0 281 002 139
Speed sensor, diesel	09.96-08.00			0 281 002 138
Pressure sensor, intake manifold, diesel	09.96-08.00			0 281 002 137
Temperature sensor, coolant, diesel	09.96-08.00			0 281 002 169
Temperature sensor, intake air, diesel	09.96-08.00			0 280 130 073
Pedal position sensor, diesel				
Fg.no. W1285447→,W7154259→	09.96-08.00	LLE		0 281 002 476
Fg.no. →W1285446,→W5276825,→W7154258	09.96-08.00	LLE		0 205 001 042
		RLE		0 205 001 039
2.0 DTi [B]				2,0l 74 kW X 20 DTH 16V Turbo 4 Zyl.
Air mass meter, diesel	09.97-08.00			0 281 002 180
Speed sensor, diesel	09.97-08.00			0 281 002 138
Pressure sensor, intake manifold, diesel	09.97-08.00	TW		0 281 002 137
				0 281 002 438
Temperature sensor, coolant, diesel	09.97-08.00			0 281 002 169
Pedal position sensor, diesel				
Fg.no. W1285447→,W7154259→	09.97-08.00	LLE		0 281 002 476



Pedal position sensor, diesel				
Fg.no. →W1285446,→W5276825,→W7154258	09.97-08.00	LLE		0 205 001 042
		RLE		0 205 001 039
2.0 DTi [B]				2,0l 74 kW Y 20 DTH 16V Turbo 4 Zyl.
Air mass meter, diesel	09.00-08.01			0 281 002 428
Speed sensor, diesel	09.00-08.01			0 281 002 138
Pressure sensor, intake manifold, diesel	09.00-08.01			0 281 002 438
Temperature sensor, coolant, diesel	09.00-08.01			0 281 002 169
Pedal position sensor, diesel	09.00-08.01	LLE		0 281 002 476
2.0 DTi [C]				2,0l 74 kW Y 20 DTH 4 Zyl.
Air mass meter, diesel	09.03-09.05			0 281 002 479
Speed sensor, diesel	09.03-09.05			0 281 002 138
Speed sensor, ignition/injection				
Mot.no. →17G23740	09.03-09.05	FKW		0 281 002 138
Mot.no. 17G23741→	09.03-09.05	FKW		0 281 002 662
Temperature sensor, coolant, diesel	09.03-09.05			0 281 002 473
2.0 i 16V [B]				2,0l 100 kW X 20 XEV 4 Zyl.
Throttle valve sensor	09.95-08.01			0 280 122 001
2.0 Turbo [C]				2,0l 129 kW Z 20 NET 4 Zyl.
Speed sensor, ignition/injection	09.03→	FKW		0 261 210 229
2.2 DTi [B]				2,2l 92 kW Y 22 DTR Turbo 4 Zyl.
Air mass meter, diesel	09.00-08.01			0 281 002 428
Speed sensor, diesel	09.00-08.01			0 281 002 138
Pressure sensor, intake manifold, diesel	09.00-08.01			0 281 002 438
Temperature sensor, coolant, diesel	09.00-08.01			0 281 002 169
Pedal position sensor, diesel	09.00-08.01	LLE		0 281 002 476
2.2 DTi [C]				2,2l 86-92 kW Y 22 DTR 4 Zyl.
Air mass meter, diesel	09.03-09.05			0 281 002 479
Speed sensor, diesel	09.03-09.05			0 281 002 138
Speed sensor, ignition/injection				
Mot.no. →17G23740	09.03-09.05	FKW		0 281 002 138
Mot.no. 17G23741→	09.03-09.05	FKW		0 281 002 662
Temperature sensor, coolant, diesel	09.03-09.05			0 281 002 473
2.5 i V6 [B]				2,5l 125-143 kW X 25 XE 6 Zyl.
Throttle valve sensor				
Fg.no. W1000001→	09.95-08.01			0 280 122 014
Fg.no. →V7999999	09.95-08.01			0 280 122 001
Air mass meter, gasoline injection				
Fg.no. W1000001→	09.95-08.01			0 280 217 519
Fg.no. →V7999999	09.95-08.01			0 280 217 503
Knock sensor	09.95-08.01			0 261 231 079
Temperature sensor, intake air, injection system				
Fg.no. W1000001→	09.95-08.01			0 280 130 092
Fg.no. →W1000001	09.95-08.01			0 280 130 073
Temperature sensor, coolant, injection system				
Fg.no. W1000001→,W5000001→,W7000001→,XL000001→	09.95-08.01			0 280 130 093
Fg.no. →V7999999	09.95-08.01			0 280 130 107
2.6 V6 [B]				2,6l 130 kW Y 26 SE 6 Zyl.
Air mass meter, gasoline injection	09.00-08.01			0 281 002 184
Phase sensor	09.00-08.01			0 232 103 025
Speed sensor, ignition/injection	09.00-08.01	FKW		0 261 210 206
Knock sensor	09.00-08.01			0 261 231 116
Temperature sensor, coolant, injection system	09.00-08.01			0 281 002 169
2.8 Turbo [C]				2,8l 169/184-188 kW Z 28 NEL; Z 28 NET 6 Zyl.
Knock sensor	09.05→			0 261 231 174
Pressure sensor, intake manifold, gasoline	09.05→			0 261 230 101
Temperature sensor, coolant, injection system	09.05→			0 280 130 122
3.0 CDTi [C]				3,0l 130-135 kW Y 30 DT 6 Zyl.
Air mass meter, diesel	09.03→			0 281 002 605
3.0 CDTi [C]				3,0l 130-135 kW Z 30 DT 6 Zyl.
Air mass meter, diesel	09.05→			0 281 002 773

**Product**

3.2i [C]		3,2l 155 kW Z 32 SE 6 Zyl.
Throttle valve assembly	09.03-09.05	0 280 750 119
Air mass meter, gasoline injection	09.03-09.05	0 280 218 087
Phase sensor	09.03-09.05 NOC	0 232 103 025
Speed sensor, ignition/injection	09.03-09.05 FKW	0 261 210 206
Knock sensor	09.03-09.05	0 261 231 116
Temperature sensor, coolant, injection system	09.03-09.05	0 281 002 170

Vivaro

1.9 DI		1,9l 59-60 kW F9Q-762 4 Zyl.
Wheel speed sensor, front		
Fg.no. 7V600001→,7Y000001→	03.01-10.06	0 265 008 077
1.9 TDI		1,9l 74 kW F9Q-760 4 Zyl.
Wheel speed sensor, front		
Fg.no. 7V600001→,7Y000001→	03.01-10.06	0 265 008 077
2.0 CDTi		2,0l 66/84 kW M9R-780 4 Zyl.
Wheel speed sensor, front		
Fg.no. 7V600001→,7Y000001→	08.06→	0 265 008 077
2.0 16V		2,0l 86-88 kW F4R... 4 Zyl.
Wheel speed sensor, front		
Fg.no. 7V600001→,7Y000001→	03.01→	0 265 008 077
2.5 CDTi		2,5l 84/107 kW ; G9U-630 4 Zyl.
Wheel speed sensor, front		
Fg.no. 7V600001→,7Y000001→	08.06→	0 265 008 077
2.5 DTi		2,5l 99 kW G9U-730 4 Zyl.
Wheel speed sensor, front		
Fg.no. 7V600001→,7Y000001→	04.04-10.06	0 265 008 077

VX 220


2.0 i 16V Turbo		2,0l 147 kW Z 20 LET 4 Zyl.
Air mass meter, gasoline injection	04.03-09.05	0 280 218 051
		0 986 280 231
Phase sensor	04.03-09.05 NOC	0 232 103 015
Speed sensor, ignition/injection	04.03-09.05 FKW	0 261 210 150
Knock sensor	04.03-09.05	0 261 231 116
Pressure sensor, intake manifold, diesel	04.03-09.05	0 281 002 137
Temperature sensor, coolant, injection system	04.03-09.05	0 281 002 169

Zafira

1.6i [A]		1,6l 74 kW X 16 XEL 4 Zyl.
Temperature sensor, coolant, injection system	09.98-08.99	0 281 002 169
Yaw rate sensor, brake system		
Fg.no. →12999999,→1H999999	09.98-08.99	0 265 005 262
Fg.no. 22000001→,2B000001→,2H000001→	09.98-08.99	0 265 005 262
Steering angle sensor, ESP (electronic stability program)		
Fg.no. →12999999,→1H999999	09.98-08.99 TW	0 265 005 434
Fg.no. 22000001→,2H000001→	09.98-08.99	0 265 005 435
1.6i [A]		1,6l 74 kW Z 16 XE 4 Zyl.
Yaw rate sensor, brake system		
Fg.no. →12999999,→1H999999	09.99-06.05	0 265 005 262
Fg.no. 22000001→,2B000001→,2H000001→	09.99-06.05	0 265 005 262
Steering angle sensor, ESP (electronic stability program)		
Fg.no. →12999999,→1H999999	09.99-06.05 TW	0 265 005 434
Fg.no. 22000001→,2H000001→	09.99-06.05	0 265 005 435

**Product**

1.6i CNG [A]		1,6l 69-73 kW Z 16 YNG 4 Zyl.
Yaw rate sensor, brake system		
Fg.no. 22000001→,2B000001→,2H000001→	09.01-06.05	0 265 005 262
Steering angle sensor, ESP (electronic stability program)		
Fg.no. 22000001→,2H000001→	09.01-06.05	0 265 005 435
1.6i Dualfuel [A]		1,6l 74 kW Z 16 XE 4 Zyl.
Yaw rate sensor, brake system		
Fg.no. →12999999,→1H999999	09.99-06.05	0 265 005 262
1.8i [A]		1,8l 85 kW X 18 XE1 4 Zyl.
Yaw rate sensor, brake system		
Fg.no. →12999999,→1H999999	03.99-09.00	0 265 005 262
Fg.no. 22000001→,2B000001→,2H000001→	03.99-09.00	0 265 005 262
Steering angle sensor, ESP (electronic stability program)		
Fg.no. →12999999,→1H999999	03.99-09.00 TW	0 265 005 434
Fg.no. 22000001→,2H000001→	03.99-09.00	0 265 005 435
1.8i i Dualfuel [A]		1,8l 92 kW Z 18 XE 4 Zyl.
Yaw rate sensor, brake system	09.00-06.05	0 265 005 262
Steering angle sensor, ESP (electronic stability program)	09.00-06.05	0 265 005 435
Pressure sensor, ESP, (electronic stability program)	09.00-06.05	0 265 005 303
1.9 CDTi [B]		1,9l 74 kW Z 19 DTL 4 Zyl.
Speed sensor, diesel	07.05→	0 281 002 603
Phase sensor	07.05→ NOC	0 281 002 213
High-pressure sensor (CR system)	07.05→	0 281 002 706
Pressure sensor, intake manifold, diesel	07.05→	0 281 002 437
1.9 CDTi [B]		1,9l 88 kW Z 19 DT 4 Zyl.
Speed sensor, diesel	07.05→	0 281 002 603
Phase sensor	07.05→ NOC	0 281 002 213
High-pressure sensor (CR system)	07.05→	0 281 002 706
Boost pressure sensor, Diesel	07.05→	0 281 002 437
Pressure sensor, intake manifold, diesel	07.05→	0 281 002 437
1.9 CDTi [B]		1,9l 110 kW Z 19 DTH 4 Zyl.
High-pressure sensor (CR system)	07.05→	0 281 002 706
Boost pressure sensor, Diesel	07.05→	0 281 002 437
Pressure sensor, intake manifold, diesel	07.05→	0 281 002 437
2.0 DI [A]		2,0l 60 kW X 20 DTL 4 Zyl.
Air mass meter, diesel		
Fg.no. →Y8999999,→YT999999	03.99-08.00	0 281 002 180
Mot.no. 12000001→,1T000001→	03.99-08.00	0 281 002 428
Speed sensor, diesel	03.99-08.00	0 281 002 138
Temperature sensor, coolant, diesel	03.99-08.00	0 281 002 169
Accelerator pedal module	03.99-08.00 LLE	0 281 002 298
	RLE	0 281 002 299
Yaw rate sensor, brake system		
Fg.no. →12999999,→1H999999	03.99-08.00	0 265 005 262
Fg.no. 22000001→,2B000001→,2H000001→	03.99-08.00	0 265 005 262
Steering angle sensor, ESP (electronic stability program)		
Fg.no. →12999999,→1H999999	03.99-08.00 TW	0 265 005 434
Fg.no. 22000001→,2H000001→	03.99-08.00	0 265 005 435
2.0 DTi [A]		2,0l 74 kW Y 20 DTH 4 Zyl.
Air mass meter, diesel		
Fg.no. →Y2999999,→Y5999999,→Y6999999,→Y8999999,→YH999999	04.99-06.05	0 281 002 180



</



Product				
2.2 [A] 2,2l 108 kW Z 22 SE 4 Zyl.				
Yaw rate sensor, brake system	09.00-06.05			0 265 005 262
Steering angle sensor, ESP (electronic stability program)	09.00-06.05			0 265 005 435
Pressure sensor, ESP, (electronic stability program)	09.00-06.05			0 265 005 303
2.2 DTi [A] 2,2l 92 kW Y 22 DTR 4 Zyl.				
Yaw rate sensor, brake system				
Fg.no. 22000001→,2B000001→, 2H000001→	03.02-06.05			0 265 005 262
Steering angle sensor, ESP (electronic stability program)				
Fg.no. 22000001→,2H000001→	03.02-06.05			0 265 005 435
VOLGA				
3110				
2.3 16V 2,3l 110 kW ZMZ 406 4 Zyl.				
Throttle valve sensor	01.95→			0 280 122 001
Air mass meter, gasoline injection	01.95→			0 280 212 014
				0 986 280 108
Phase sensor	01.95→			0 232 103 006
Speed sensor, ignition/injection	01.95→			0 261 210 113
Knock sensor	01.95→			0 261 231 046
Pressure sensor, intake manifold, gasoline	01.95→			0 261 230 004
VOLVO				
C30				
D5 2,4l 120/132 kW D5244T8; D5244T9 5 Zyl.				
Throttle valve assembly	10.06→			0 281 002 701
T5 2,5l 162/169 kW B5254T3; B5254T7 5 Zyl.				
Throttle valve assembly	10.06→			0 280 750 146
Air mass meter, gasoline injection	10.06→			0 280 218 134
Knock sensor	10.06→			0 261 231 178
Boost pressure sensor, gasoline	10.06→	UE		0 261 230 090
C70 Coupé				
2.0 T 2,0l 120 kW B 5204 T4 5 Zyl.				
Air mass meter, gasoline injection	08.99-07.02			0 280 218 108
Knock sensor	08.99-07.02			0 261 231 142
2.0 T 2,0l 132 kW B5204T2 5 Zyl.				
Throttle valve sensor	01.97-07.98			0 280 122 001
Air mass meter, gasoline injection	01.97-07.98			0 280 217 107
Phase sensor	01.97-07.98	NOC		0 232 101 030
Knock sensor	01.97-07.98			0 261 231 121
Pressure sensor, intake manifold, gasoline	01.97-07.98			0 261 230 018
2.0 T 2,0l 166 kW B 5204 T3 5 Zyl.				
Throttle valve sensor	01.97-07.00			0 280 122 001
Air mass meter, gasoline injection	01.97-07.98			0 280 217 107
	08.98-07.00			0 280 218 108
Phase sensor	01.97-07.98	NOC		0 232 101 030
Knock sensor	01.97-07.98			0 261 231 121
	08.98-07.00			0 261 231 142
Pressure sensor, intake manifold, gasoline	01.97-07.00			0 261 230 018
2.3 T5 2,3l 176 kW B5234T3 5 Zyl.				
Throttle valve sensor	09.97-07.02			0 280 122 001
Air mass meter, gasoline injection	09.97-07.98			0 280 217 107
	08.98-07.02			0 280 218 108
Phase sensor	09.97-07.98	NOC		0 232 101 030



Knock sensor	09.97-07.98	0 261 231 121
	08.98-07.02	0 261 231 142
Pressure sensor, intake manifold, gasoline	09.97-07.02	0 261 230 018
2.4 20V	2,4l 121 kW B5244S 5 Zyl.	
Throttle valve sensor	03.99-07.00	0 280 122 001
2.5 LPT	2,4l 142 kW B5254T 5 Zyl.	
Throttle valve sensor	01.98-07.99	0 280 122 001
Air mass meter, gasoline injection	01.98-07.98	0 280 217 107
	08.98-07.99	0 280 218 108
Phase sensor	01.98-07.98 NOC	0 232 101 030
Knock sensor	01.98-07.98	0 261 231 121
	08.98-07.99	0 261 231 142
Pressure sensor, intake manifold, gasoline	01.98-07.99	0 261 230 018
2.5 T	2,4l 142 kW B5244T 5 Zyl.	
Air mass meter, gasoline injection	08.99-07.02	0 280 218 108
Knock sensor	08.99-07.02	0 261 231 142
2.5 20V	2,4l 125 kW B5254S 5 Zyl.	
Throttle valve sensor	08.99-07.00	0 280 122 001

C70 I Cabrio

2.0 T	2,0l 120 kW B5204T4 5 Zyl.	
Air mass meter, gasoline injection	08.02-03.06	0 280 218 088
	08.99-07.02	0 280 218 108
Knock sensor	08.99-03.06	0 261 231 142
2.0 T	2,0l 132 kW B5204T2 5 Zyl.	
Throttle valve sensor	03.98-07.98	0 280 122 001
Air mass meter, gasoline injection	03.98-07.98	0 280 217 107
Phase sensor	03.98-07.98 NOC	0 232 101 030
Knock sensor	03.98-07.98	0 261 231 121
2.0 T	2,0l 166 kW B5204T3 5 Zyl.	
Air mass meter, gasoline injection	08.98-07.00	0 280 218 108
Knock sensor	08.98-07.00	0 261 231 142
2.3 T5	2,3l 176 kW B5234T3 5 Zyl.	
Throttle valve sensor	02.98-07.02	0 280 122 001
Air mass meter, gasoline injection	02.98-07.98	0 280 217 107
	08.98-07.02	0 280 218 108
Phase sensor	02.98-07.98 NOC	0 232 101 030
Knock sensor	02.98-07.98	0 261 231 121
	08.98-07.02	0 261 231 142
Pressure sensor, intake manifold, gasoline	02.98-07.02	0 261 230 018
2.3 T5	2,3l 180 kW B5234T9 5 Zyl.	
Throttle valve sensor	08.02-03.06	0 280 122 001
Air mass meter, gasoline injection	08.02-03.06	0 280 218 088
Knock sensor	08.02-03.06	0 261 231 142
Pressure sensor, intake manifold, gasoline	08.02-03.06	0 261 230 018
2.4	2,4l 103 kW B5244S 5 Zyl.	
Throttle valve sensor	03.99-07.00	0 280 122 001
2.4 T	2,4l 142 kW B5244T 5 Zyl.	
Air mass meter, gasoline injection	08.99-07.02	0 280 218 108
Knock sensor	08.99-07.02	0 261 231 142
2.4 T	2,4l 142 kW B5254T 5 Zyl.	
Throttle valve sensor	08.98-07.99	0 280 122 001
Air mass meter, gasoline injection	08.98-07.99	0 280 218 108
Knock sensor	08.98-07.99	0 261 231 142
Pressure sensor, intake manifold, gasoline	08.98-07.99	0 261 230 018
2.4 T5	2,4l 147 kW B5244T7 5 Zyl.	
Throttle valve sensor	08.02-03.06	0 280 122 001
Air mass meter, gasoline injection	08.02-03.06	0 280 218 088
Knock sensor	08.02-03.06	0 261 231 142
Pressure sensor, intake manifold, gasoline	08.02-03.06	0 261 230 018



C70 II Cabrio

2.4	2,4l 103 kW B5244S4 5 Zyl.	
Temperature sensor, fuel	03.06→	0 261 230 109
2.4 D	2,4l 120 kW D5244T9 5 Zyl.	
Phase sensor	08.06→ NOC	0 232 103 063
Boost pressure sensor, Diesel	08.06→	0 261 230 105
2.4 D5	2,4l 132 kW D5244T8 5 Zyl.	
Phase sensor	08.06→ NOC	0 232 103 063
Boost pressure sensor, Diesel	08.06→	0 261 230 105
2.4 i	2,4l 125 kW B5244S5 5 Zyl.	
Temperature sensor, fuel	03.06→	0 261 230 109
2.5 T5	2,5l 162 kW B5254T3 5 Zyl.	
Throttle valve assembly	03.06→	0 280 750 146
Air mass meter, gasoline injection	03.06→	0 280 218 134
Knock sensor	03.06→	0 261 231 178
Boost pressure sensor, gasoline	03.06-07.07	0 261 230 090
	08.07→	0 261 230 105
Temperature sensor, fuel	03.06→	0 261 230 110
2.5 T5	2,5l 169 kW B5254T7 5 Zyl.	
Throttle valve assembly	08.07→	0 280 750 146
Air mass meter, gasoline injection	08.07→	0 280 218 134
Knock sensor	08.07→	0 261 231 178
Boost pressure sensor, gasoline	08.07→	0 261 230 105
Temperature sensor, fuel	08.07→	0 261 230 110

S40 I

1.6 16V	1,6l 77 kW B4164S 4 Zyl.	
Phase sensor	01.97-07.99 NOC	0 232 101 029
Wheel speed sensor, front	09.97-07.99	0 265 006 425
	01.97-08.97 LAB	0 265 006 224
	RAB	0 265 006 223
Wheel speed sensor, rear	01.97-07.99	0 265 006 366
1.6 16V	1,6l 80 kW B4164S2 4 Zyl.	
Wheel speed sensor, front	08.99-01.04	0 265 006 425
Wheel speed sensor, rear		
Fg.no. →985261	08.99-01.04	0 265 006 366
Fg.no. 985262→	08.99-01.04	0 265 006 698
1.8 16V	1,8l 85 kW B4184S 4 Zyl.	
Phase sensor	09.95-07.99 NOC	0 232 101 029
Knock sensor	09.95-07.99	0 261 231 046
Wheel speed sensor, front	09.97-07.99	0 265 006 425
	09.95-08.97 LAB	0 265 006 224
	RAB	0 265 006 223
Wheel speed sensor, rear	09.95-07.99	0 265 006 366
1.8 16V	1,8l 90 kW B4184SJ; B4184S2; B4184S3; B4184S9; B4184S10 4 Zyl.	
Wheel speed sensor, front	08.99-01.04	0 265 006 425
Wheel speed sensor, rear		
Fg.no. →985261	08.99-01.04	0 265 006 366
Fg.no. 985262→	08.99-01.04	0 265 006 698
1.8 16V	1,8l 92 kW B4184SM 4 Zyl.	
Wheel speed sensor, front	09.97-07.00	0 265 006 425
Wheel speed sensor, rear	09.97-07.00	0 265 006 366
1.9 D	1,9l 66 kW D4192T 4 Zyl.	
Speed sensor, diesel	05.96-07.99	0 281 002 349
Wheel speed sensor, front	09.97-07.99	0 265 006 425
	05.96-08.97 LAB	0 265 006 224
	RAB	0 265 006 223
Wheel speed sensor, rear	05.96-07.99	0 265 006 366
1.9 D	1,9l 70 kW D4192T2 4 Zyl.	
Wheel speed sensor, front	03.98-07.00	0 265 006 425
Wheel speed sensor, rear	03.98-07.00	0 265 006 366

Product				
◀ S40 I				
1.9 D	1,9 l	75/85 kW	D4192T3/DI; D4192T4/DI	4 Zyl.
Wheel speed sensor, front		08.00-01.04		0 265 006 425
Wheel speed sensor, rear				
Fg.no. →985261		08.00-01.04		0 265 006 366
Fg.no. 985262→		08.00-01.04		0 265 006 698
1.9 T4	1,9 l	147 kW	B4194T	4 Zyl.
Phase sensor		05.97-07.99	NOC	0 232 101 029
Wheel speed sensor, front		09.97-07.99		0 265 006 425
		05.97-08.97	LAB	0 265 006 224
			RAB	0 265 006 223
Wheel speed sensor, rear		05.97-07.99		0 265 006 366
1.9 T4	1,9 l	147 kW	B4194T2	4 Zyl.
Wheel speed sensor, front		08.99-07.00		0 265 006 425
Wheel speed sensor, rear		08.99-07.00		0 265 006 366
2.0 T	1,9 l	120/121 kW	B4204T3	4 Zyl.
Pressure sensor, intake manifold, gasoline		08.00-01.04		0 261 230 029
Wheel speed sensor, front		08.00-01.04		0 265 006 425
Wheel speed sensor, rear				
Fg.no. →985261		08.00-01.04		0 265 006 366
Fg.no. 985262→		08.00-01.04		0 265 006 698
2.0 T 16V	1,9 l	118 kW	B4204T2	4 Zyl.
Wheel speed sensor, front		08.99-07.00		0 265 006 425
Wheel speed sensor, rear		08.99-07.00		0 265 006 366
2.0 T 16V	2,0 l	118 kW	B4204T	4 Zyl.
Phase sensor		04.98-07.99	NOC	0 232 101 029
Wheel speed sensor, front		04.98-07.99		0 265 006 425
Wheel speed sensor, rear		04.98-07.99		0 265 006 366
2.0 T4	1,9 l	147 kW	B4204T5	4 Zyl.
Pressure sensor, intake manifold, gasoline		08.00-01.04		0 261 230 029
Wheel speed sensor, front		08.00-01.04		0 265 006 425
Wheel speed sensor, rear				
Fg.no. →985261		08.00-01.04		0 265 006 366
Fg.no. 985262→		08.00-01.04		0 265 006 698
2.0 16V	2,0 l	100 kW	B4204S2	4 Zyl.
Wheel speed sensor, front		08.99-01.04		0 265 006 425
Wheel speed sensor, rear				
Fg.no. →985261		08.99-01.04		0 265 006 366
Fg.no. 985262→		08.99-01.04		0 265 006 698
2.0 16V	2,0 l	103 kW	B4204S	4 Zyl.
Phase sensor		09.95-07.99	NOC	0 232 101 029
Knock sensor		09.95-07.99		0 261 231 046
Wheel speed sensor, front		09.97-07.99		0 265 006 425
		09.95-08.97	LAB	0 265 006 224
			RAB	0 265 006 223
Wheel speed sensor, rear		09.95-07.99		0 265 006 366
S40 II				
D5 [P 11]	2,4 l	120/132 kW	D5244T8; D5244T9	5 Zyl.
Throttle valve assembly		03.06→		0 281 002 701
Phase sensor		03.06→	NOC	0 232 103 063
High-pressure sensor (CR system)		03.06→		0 281 002 706
Boost pressure sensor, Diesel		03.06→		0 261 230 105
1.8 [P 11]	1,8 l	92 kW	B4184S11	4 Zyl.
Pressure sensor, intake manifold, gasoline		04.04→		0 261 230 044
1.8 F [P 11]	1,8 l	92 kW	B4184S8	4 Zyl.
Pressure sensor, intake manifold, gasoline		04.06→		0 261 230 044
2.0 [P 11]	2,0 l	107 kW	B4204S3	4 Zyl.
Pressure sensor, intake manifold, gasoline		10.06→		0 261 230 044
2.4 [P 11]	2,4 l	103/125 kW	B5244S4; B5244S5	5 Zyl.
Temperature sensor, fuel		12.03→		0 261 230 109
2.4 i [P 11]	2,4 l	125 kW	B5244S7	5 Zyl.
Temperature sensor, fuel		08.05→		0 261 230 109



Product				
2.5 T5	2,5 l	162 kW	B 5254 T3	5 Zyl.
Throttle valve assembly		12.03→		0 280 750 146
Air mass meter, gasoline injection		12.03→		0 280 218 134
Knock sensor		12.03→		0 261 231 178
2.5 T5 [P 11]	2,5 l	162 kW	B5254T3	5 Zyl.
Throttle valve assembly		12.03→		0 280 750 146
Air mass meter, gasoline injection		12.03→		0 280 218 134
Knock sensor		12.03→		0 261 231 178
Pressure sensor, intake manifold, gasoline		12.03→		0 261 230 110
Boost pressure sensor, gasoline		12.03-07.07		0 261 230 090
		08.07→		0 261 230 105
Temperature sensor, fuel		12.03→		0 261 230 110
2.5 T5 [P 11]	2,5 l	169 kW	B5254T7	5 Zyl.
Throttle valve assembly		08.07→		0 280 750 146
Air mass meter, gasoline injection		08.07→		0 280 218 134
Knock sensor		08.07→		0 261 231 178
Pressure sensor, intake manifold, gasoline		08.07→		0 261 230 110
Boost pressure sensor, gasoline		08.07→		0 261 230 105
Temperature sensor, fuel		08.07→		0 261 230 110
2.5 T5 AWD [P 11]	2,5 l	162 kW	B5254T3	5 Zyl.
Throttle valve assembly		04.04→		0 280 750 146
Air mass meter, gasoline injection		04.04→		0 280 218 134
Knock sensor		04.04→		0 261 231 178
Pressure sensor, intake manifold, gasoline		04.04→		0 261 230 110
Boost pressure sensor, gasoline		04.04-07.07		0 261 230 090
		08.07→		0 261 230 105
Temperature sensor, fuel		04.04→		0 261 230 110
2.5 T5 AWD [P 11]	2,5 l	169 kW	B5254T7	5 Zyl.
Throttle valve assembly		08.07→		0 280 750 146
Air mass meter, gasoline injection		08.07→		0 280 218 134
Knock sensor		08.07→		0 261 231 178
Pressure sensor, intake manifold, gasoline		08.07→		0 261 230 110
Boost pressure sensor, gasoline		08.07→		0 261 230 105
Temperature sensor, fuel		08.07→		0 261 230 110
S60				
D [P 24]	2,4 l	93 kW	D5244T7	5 Zyl.
Throttle valve assembly		08.05→		0 281 002 701
Phase sensor		08.05→	NOC	0 232 103 063
High-pressure sensor (CR system)		08.05→		0 281 002 706
Boost pressure sensor, Diesel		08.05→		0 261 230 105
Temperature sensor, fuel		08.05→		0 281 002 623
D5 [P 24]	2,4 l	136 kW	D5244T4	5 Zyl.
Throttle valve assembly		08.05→		0 281 002 701
Phase sensor		08.05→	NOC	0 232 103 063
High-pressure sensor (CR system)		08.05→		0 281 002 706
Boost pressure sensor, Diesel		08.05→		0 261 230 105
Temperature sensor, fuel		08.05→		0 281 002 623
R [P 24]	2,5 l	220 kW	B5254T4	5 Zyl.
Throttle valve assembly		03.03-07.07		0 280 750 131
Air mass meter, gasoline injection		03.03-07.07		0 280 218 089
Knock sensor		03.03-07.07		0 261 231 142
Pressure sensor, intake manifold, gasoline		03.03-07.07		0 261 230 110
Boost pressure sensor, gasoline		03.03-07.07		0 261 230 105
Temperature sensor, fuel		03.03-07.07		0 261 230 110
2.0 T [P 24]	2,0 l	132 kW	B5204T5	5 Zyl.
Throttle valve assembly		08.01→		0 280 750 131
Air mass meter, gasoline injection		08.01→		0 280 218 088
		11.00-07.01		0 280 218 108
Knock sensor		11.00→		0 261 231 142
Pressure sensor, intake manifold, gasoline		11.00→		0 261 230 110



Boost pressure sensor, gasoline	08.02→	0 261 230 090
Temperature sensor, fuel	11.00→	0 261 230 110
2.3 T5 [P 24]	2,3l 184-195 kW B5234T3 5 Zyl.	
Throttle valve assembly	08.01-03.04	0 280 750 131
Air mass meter, gasoline injection	08.01-03.04	0 280 218 088
	11.00-07.01	0 280 218 108
Knock sensor	11.00-03.04	0 261 231 142
Pressure sensor, intake manifold, gasoline	11.00-03.04	0 261 230 110
Boost pressure sensor, gasoline	08.02-03.04	0 261 230 090
Temperature sensor, fuel	11.00-03.04	0 261 230 110
2.4 [P 24]	2,4l 103/125 kW B5244S; B5244S2 5 Zyl.	
Temperature sensor, fuel	08.02→	0 261 230 109
2.4 Bi-Fuel CNG [P 24]	2,4l 103 kW B5244SG 5 Zyl.	
Temperature sensor, fuel	08.02→	0 261 230 109
2.4 Bi-Fuel LPG [P 24]	2,4l 103 kW B5244SG2 5 Zyl.	
Temperature sensor, fuel	08.02→	0 261 230 109
2.4 D [P 24]	2,4l 96/120 kW D5244T; D5244T2 5 Zyl.	
Air mass meter, diesel	08.01-07.06	0 280 218 088
Phase sensor	08.01-07.06 NOC	0 232 103 042
Boost pressure sensor, Diesel	08.01-07.06	0 261 230 090
2.4 D [P 24]	2,4l 120 kW D5244T5 5 Zyl.	
Throttle valve assembly	08.06→	0 281 002 701
Phase sensor	08.06→ NOC	0 232 103 063
High-pressure sensor (CR system)	08.06→	0 281 002 706
Boost pressure sensor, Diesel	08.06→	0 261 230 105
Temperature sensor, fuel	08.06→	0 281 002 623
2.4 T [P 24]	2,4l 147 kW B5244T3 5 Zyl.	
Throttle valve assembly	08.01-07.03	0 280 750 131
Air mass meter, gasoline injection	08.01-07.03	0 280 218 088
	11.00-07.01	0 280 218 108
Knock sensor	11.00-07.03	0 261 231 142
Pressure sensor, intake manifold, gasoline	11.00-07.03	0 261 230 110
Boost pressure sensor, gasoline	08.02-07.03	0 261 230 090
Temperature sensor, fuel	11.00-07.03	0 261 230 110
2.4 T [P 24]	2,4l 147 kW B5244T4 5 Zyl.	
Throttle valve assembly	08.03→	0 280 750 131
Air mass meter, gasoline injection	08.03→	0 280 218 089
Knock sensor	08.03→	0 261 231 142
Boost pressure sensor, gasoline	08.03→	0 261 230 090
Temperature sensor, fuel	08.03→	0 261 230 110
2.4 T AWD [P 24]	2,4l 147 kW B5244T3 5 Zyl.	
Throttle valve assembly	11.01-07.03	0 280 750 131
Air mass meter, gasoline injection	11.01-07.03	0 280 218 088
Knock sensor	11.01-07.03	0 261 231 142
Pressure sensor, intake manifold, gasoline	11.01-07.03	0 261 230 110
Boost pressure sensor, gasoline	08.02-07.03	0 261 230 090
Temperature sensor, fuel	11.01-07.03	0 261 230 110
2.4 T AWD [P 24]	2,4l 147 kW B5244T4 5 Zyl.	
Throttle valve assembly	08.03→	0 280 750 131
Air mass meter, gasoline injection	08.03→	0 280 218 089
Knock sensor	08.03→	0 261 231 142
Boost pressure sensor, gasoline	08.03→	0 261 230 090
Temperature sensor, fuel	08.03→	0 261 230 110
2.4 T5 [P 24]	2,4l 191 kW B5244T5 5 Zyl.	
Throttle valve assembly	04.04→	0 280 750 131
Air mass meter, gasoline injection	04.04→	0 280 218 089
Knock sensor	04.04→	0 261 231 142
Pressure sensor, intake manifold, gasoline	04.04→	0 261 230 110
Boost pressure sensor, gasoline	04.04→	0 261 230 105
Temperature sensor, fuel	04.04→	0 261 230 110
2.5 T, TAWD [P 24]	2,5l 154 kW B5254T2 5 Zyl.	
Throttle valve assembly	04.04→	0 280 750 131
Air mass meter, gasoline injection	04.04→	0 280 218 088



Knock sensor	04.04→	0 261 231 142
Pressure sensor, intake manifold, gasoline	04.04→	0 261 230 110
Boost pressure sensor, gasoline	04.04→	0 261 230 090
Temperature sensor, fuel	04.04→	0 261 230 110

S70

R 2.3 T, TAWD	2,3l 184 kW B5234T4 5 Zyl.	
Throttle valve sensor	01.97-07.98	0 280 122 001
Air mass meter, gasoline injection	01.97-07.98	0 280 217 107
Phase sensor	01.97-07.98 NOC	0 232 101 030
Knock sensor	01.97-07.98	0 261 231 121
2.0	2,0l 93 kW B5202 S 5 Zyl.	
Throttle valve sensor	01.97-07.99	0 280 122 001
Phase sensor	01.97-07.99 NOC	0 232 101 030
Knock sensor	01.97-07.99	0 261 231 121
2.0	2,0l 105 kW B 5204 S 5 Zyl.	
Throttle valve sensor	01.97-07.98	0 280 122 001
Air mass meter, gasoline injection	01.97-07.98	0 280 217 107
Phase sensor	01.97-07.98 NOC	0 232 101 030
Knock sensor	01.97-07.98	0 261 231 121
2.0 T	2,0l 132/155 kW B5204T; B5204T2 5 Zyl.	
Throttle valve sensor	01.97-07.98	0 280 122 001
Air mass meter, gasoline injection	01.97-07.98	0 280 217 107
Phase sensor	01.97-07.98 NOC	0 232 101 030
Knock sensor	01.97-07.98	0 261 231 121
2.0 T	2,0l 166 kW B 5204 T3 5 Zyl.	
Throttle valve sensor	08.98-07.00	0 280 122 001
Air mass meter, gasoline injection	08.98-07.00	0 280 218 108
Knock sensor	08.98-07.00	0 261 231 142
Pressure sensor, intake manifold, gasoline	08.98-07.00	0 261 230 018
2.0 T AWD	2,0l 166 kW B5204T3 5 Zyl.	
Throttle valve sensor	08.98-07.00	0 280 122 001
Air mass meter, gasoline injection	08.98-07.00	0 280 218 108
Knock sensor	08.98-07.00	0 261 231 142
Pressure sensor, intake manifold, gasoline	08.98-07.00	0 261 230 018
2.0 T 20V	2,0l 120 kW B5204T4 5 Zyl.	
Throttle valve sensor	08.98-07.00	0 280 122 001
Air mass meter, gasoline injection	08.98-07.00	0 280 218 108
Knock sensor	08.98-07.00	0 261 231 142
Pressure sensor, intake manifold, gasoline	08.98-07.00	0 261 230 018
2.3	2,3l 120 kW B5234S 5 Zyl.	
Throttle valve sensor	01.97-07.99	0 280 122 001
Air mass meter, gasoline injection	01.97-07.98	0 280 217 107
Phase sensor	01.97-07.98 NOC	0 232 101 030
Knock sensor	01.97-07.98	0 261 231 121
	08.98-07.99	0 261 231 142
2.3	2,3l 140 kW B5234T7 5 Zyl.	
Throttle valve sensor	08.98-07.00	0 280 122 001
Air mass meter, gasoline injection	08.98-07.00	0 280 218 108
Knock sensor	08.98-07.00	0 261 231 142
Pressure sensor, intake manifold, gasoline	08.98-07.00	0 261 230 018
2.3	2,3l 160 kW B5234T2 5 Zyl.	
Throttle valve sensor	01.97-07.98	0 280 122 001
Air mass meter, gasoline injection	01.97-07.98	0 280 217 107
Phase sensor	01.97-07.98 NOC	0 232 101 030
Knock sensor	01.97-07.98	0 261 231 121
Pressure sensor, intake manifold, gasoline	01.97-07.98	0 261 230 018
2.3 T-5	2,3l 176 kW B5234T3 5 Zyl.	
Throttle valve sensor	01.97-07.00	0 280 122 001
Air mass meter, gasoline injection	01.97-07.98	0 280 217 107
	08.98-07.00	0 280 218 108
Phase sensor	01.97-07.98 NOC	0 232 101 030

Product				
◀ S70				
Knock sensor	01.97-07.98	0 261 231 121		
	08.98-07.00	0 261 231 142		
Pressure sensor, intake manifold, gasoline	01.97-07.00	0 261 230 018		
2.4	2,4l 103/125 kW B5244S; B5244S2	5 Zyl.		
Throttle valve sensor	08.99-07.00	0 280 122 001		
Knock sensor	08.99-07.00	0 261 231 142		
2.4	2,4l 142 kW B5244T	5 Zyl.		
Throttle valve sensor	01.99-07.00	0 280 122 001		
Air mass meter, gasoline injection	01.99-07.00	0 280 218 108		
Knock sensor	01.99-07.00	0 261 231 142		
Pressure sensor, intake manifold, gasoline	01.99-07.00	0 261 230 018		
2.4 AWD	2,4l 125 kW B5244S	5 Zyl.		
Throttle valve sensor	08.99-07.00	0 280 122 001		
Knock sensor	08.99-07.00	0 261 231 142		
2.5	2,4l 106 kW B5252S	5 Zyl.		
Throttle valve sensor	01.97-07.99	0 280 122 001		
Phase sensor	01.97-07.99 NOC	0 232 101 030		
Knock sensor	01.97-07.99	0 261 231 121		
2.5 BI-FUEL	2,4l 106 kW B5252S	5 Zyl.		
Throttle valve sensor	08.98-07.99	0 280 122 001		
Phase sensor	08.98-07.99 NOC	0 232 101 030		
2.5 T	2,4l 142 kW B5254T	5 Zyl.		
Throttle valve sensor	01.97-07.99	0 280 122 001		
Air mass meter, gasoline injection	01.97-07.98	0 280 217 107		
	08.98-07.99	0 280 218 108		
Phase sensor	01.97-07.98 NOC	0 232 101 030		
Knock sensor	01.97-07.98	0 261 231 121		
	08.98-07.99	0 261 231 142		
Pressure sensor, intake manifold, gasoline	01.97-07.99	0 261 230 018		
2.5 T AWD	2,4l 142 kW B5254T	5 Zyl.		
Throttle valve sensor	08.98-07.99	0 280 122 001		
Air mass meter, gasoline injection	08.98-07.99	0 280 218 108		
Knock sensor	08.98-07.99	0 261 231 142		
Pressure sensor, intake manifold, gasoline	08.98-07.99	0 261 230 018		
2.5 TDI	2,5l 103 kW D5252 T	5 Zyl.		
Air flow sensor, diesel				
Fg.no. →596595	01.97-07.00	0 281 002 155		
Air mass meter, diesel				
Fg.no. 596596→	01.97-07.00	0 280 218 108		
2.5 20V	2,4l 121 kW B5254S	5 Zyl.		
Throttle valve sensor	01.97-07.99	0 280 122 001		
Air mass meter, gasoline injection	01.97-07.98	0 280 217 107		
Phase sensor	01.97-07.98 NOC	0 232 101 030		
Knock sensor	01.97-07.98	0 261 231 121		
	08.98-07.99	0 261 231 142		
S80 I				
D5 [P 23]	2,4l 120 kW D5244T	5 Zyl.		
Air mass meter, diesel	08.01-07.06	0 280 218 088		
Phase sensor	08.01-07.06 NOC	0 232 103 042		
Boost pressure sensor, Diesel	08.01-07.06 UE	0 261 230 090		
2.0 T [P 23]	2,0l 120 kW B5204T4	5 Zyl.		
Air mass meter, gasoline injection	08.98-07.00	0 280 218 108		
Knock sensor	08.98-07.00	0 261 231 142		
Pressure sensor, intake manifold, gasoline	08.98-07.00	0 261 230 110		
	OE	0 261 230 029		
Boost pressure sensor, gasoline	08.98-07.00 UE	0 261 230 090		
Temperature sensor, fuel	08.98-07.00	0 261 230 110		
2.0 T [P 23]	2,0l 132 kW B5204T5	5 Zyl.		
Throttle valve assembly	08.02-07.06	0 280 750 131		
Air mass meter, gasoline injection	08.01-07.06	0 280 218 088		
	08.99-07.01	0 280 218 108		

Product				
Knock sensor	08.99-07.06	0 261 231 142		
Pressure sensor, intake manifold, gasoline	08.99-07.02	0 261 230 110		
	OE	0 261 230 029		
Boost pressure sensor, gasoline	08.99-07.06 UE	0 261 230 090		
Temperature sensor, fuel	08.99-07.06	0 261 230 110		
2.0 T5 [P 23]	2,0l 166 kW B5204T3	5 Zyl.		
Air mass meter, gasoline injection	08.98-07.00	0 280 218 108		
Knock sensor	08.98-07.00	0 261 231 142		
Pressure sensor, intake manifold, gasoline	08.98-07.00	0 261 230 110		
	OE	0 261 230 029		
Boost pressure sensor, gasoline	08.98-07.00 UE	0 261 230 090		
Temperature sensor, fuel	08.98-07.00	0 261 230 110		
2.3 R [P 23]	2,3l 195 kW B5234T7	5 Zyl.		
Throttle valve assembly	08.01-07.05	0 280 750 131		
Air mass meter, gasoline injection	08.01-07.05	0 280 218 088		
	04.00-07.01	0 280 218 108		
Knock sensor	04.00-07.05	0 261 231 142		
Pressure sensor, intake manifold, gasoline	04.00-07.02	0 261 230 110		
	OE	0 261 230 029		
Boost pressure sensor, gasoline	04.00-07.05 UE	0 261 230 090		
Temperature sensor, fuel	04.00-07.05	0 261 230 110		
2.4 D [P 23]	2,4l 96 kW D5244T2	5 Zyl.		
Air mass meter, diesel	10.01-07.06	0 280 218 088		
Phase sensor	10.01-07.06 NOC	0 232 103 042		
Boost pressure sensor, Diesel	10.01-07.06 UE	0 261 230 090		
2.4 T, T AWD [P 23]	2,4l 147 kW B5244T3	5 Zyl.		
Throttle valve assembly	08.01-07.03	0 280 750 131		
Air mass meter, gasoline injection	08.01-07.03	0 280 218 088		
	08.00-07.01	0 280 218 108		
Knock sensor	08.00-07.03	0 261 231 142		
Pressure sensor, intake manifold, gasoline	08.00-07.02	0 261 230 110		
	OE	0 261 230 029		
Boost pressure sensor, gasoline	08.00-07.03 UE	0 261 230 090		
Temperature sensor, fuel	08.00-07.03	0 261 230 110		
2.5 , AWD [P 23]	2,5l 154 kW B5254T2	5 Zyl.		
Throttle valve assembly	08.03-07.06	0 280 750 131		
Air mass meter, gasoline injection	08.03-07.06	0 280 218 088		
Knock sensor	08.03-07.06	0 261 231 142		
Boost pressure sensor, gasoline	08.03-07.06 UE	0 261 230 090		
Temperature sensor, fuel	08.03-07.06	0 261 230 110		
2.5 TDI [P 23]	2,5l 103 kW D5252T	5 Zyl.		
Air mass meter, diesel	08.98-07.01	0 280 218 108		
2.8 T6 [P 23]	2,8l 200 kW B6284 T; B6284T	6 Zyl.		
Air mass meter, gasoline injection	06.98-07.01	0 280 218 109		
Knock sensor	06.98-07.01	0 261 231 142		
Boost pressure sensor, gasoline	06.98-07.01 UE	0 261 230 090		
2.9 [P 23]	2,9l 147/150 kW B6294S; B6304 S3; B6304S3	6 Zyl.		
Air mass meter, gasoline injection	06.98-07.01	0 280 218 108		
Knock sensor	06.98-07.01	0 261 231 142		
3.0 [P 23]	2,9l 144 kW B6294S2	6 Zyl.		
Throttle valve assembly	08.01-07.06	0 280 750 131		
Air mass meter, gasoline injection	08.01-07.06	0 280 218 088		
Knock sensor	08.01-07.06	0 261 231 142		
3.0 T6 [P 23]	2,9l 200 kW B6294T	6 Zyl.		
Throttle valve assembly	08.02-07.06	0 280 750 131		
Air mass meter, gasoline injection	08.01-07.06	0 280 218 089		
Knock sensor	08.01-07.06	0 261 231 142		
Boost pressure sensor, gasoline	08.01-07.06 UE	0 261 230 090		





S80 II			
2.4 D	2,4l 120 kW D5244T5 5 Zyl.		
Throttle valve assembly	08.06→		0 281 002 701
Phase sensor	08.06→	NOC	0 232 103 063
Boost pressure sensor, Diesel	08.06→		0 261 230 105
2.4 D5, D5 AWD	2,4l 136 kW D5244T4 5 Zyl.		
Throttle valve assembly	03.06→		0 281 002 701
Phase sensor	03.06→	NOC	0 232 103 063
Boost pressure sensor, Diesel	03.06→		0 261 230 105
2.5 T	2,5l 147 kW B5254T6 5 Zyl.		
Throttle valve assembly	03.06→		0 280 750 146
Air mass meter, gasoline injection	03.06→		0 280 218 134
Knock sensor	03.06→		0 261 231 178
Boost pressure sensor, gasoline	03.06→		0 261 230 105
Temperature sensor, fuel	03.06→		0 261 230 110
3.0 T6 AWD	3,0l 210 kW B6304T2 6 Zyl.		
Boost pressure sensor, gasoline	01.07→		0 261 230 105
Temperature sensor, fuel	01.07→		0 261 230 110
3.2, AWD	3,2l 175 kW B6324S 6 Zyl.		
Pressure sensor, intake manifold, gasoline	08.06→		0 261 230 110
Temperature sensor, fuel	08.06→		0 261 230 110
4.4 V8 AWD	4,4l 232 kW B8444S 8 Zyl.		
Temperature sensor, fuel	03.06→		0 261 230 110

S90			
2.4	2,4l 120 kW B6244S 6 Zyl.		
Throttle valve sensor	05.97-12.99		0 280 122 001
Air mass meter, gasoline injection	05.97-12.99		0 280 217 511
2.9	2,9l 132 kW B6304S 6 Zyl.		
Throttle valve sensor	01.97-05.98		0 280 122 001
Air mass meter, gasoline injection	01.97-05.98		0 280 217 511
2.9, Exekutive, Exekutive Plus	2,9l 150 kW B6304S 6 Zyl.		
Throttle valve sensor	01.97-05.98		0 280 122 001
Air mass meter, gasoline injection	01.97-05.98		0 280 217 511
Phase sensor	01.97-05.98	NOC	0 232 101 030
Knock sensor	01.97-05.98		0 261 231 046

V40			
1.6 16V	1,6l 77 kW B4164S 4 Zyl.		
Phase sensor	01.97-07.99	NOC	0 232 101 029
Wheel speed sensor, front	09.97-07.99		0 265 006 425
	01.97-08.97	LAB	0 265 006 224
		RAB	0 265 006 223
Wheel speed sensor, rear	01.97-07.99		0 265 006 366
1.6 16V	1,6l 80 kW B4164S2 4 Zyl.		
Wheel speed sensor, front	08.99-04.04		0 265 006 425
Wheel speed sensor, rear			
	Fg.no. →985261		0 265 006 366
	Fg.no. 985262→		0 265 006 698
1.8 16V	1,8l 85 kW B4184S 4 Zyl.		
Phase sensor	01.95-07.99	NOC	0 232 101 029
Wheel speed sensor, front	09.97-07.99		0 265 006 425
	09.95-08.97	LAB	0 265 006 224
		RAB	0 265 006 223
Wheel speed sensor, rear	01.95-07.99		0 265 006 366
1.8 16V	1,8l 90 kW B4184SJ; B4184S2; B4184S3; B4184S9 4 Zyl.		
Wheel speed sensor, front	08.99-04.04		0 265 006 425
Wheel speed sensor, rear			
	Fg.no. →985261		0 265 006 366
	Fg.no. 985262→		0 265 006 698



1.8 16V	1,8l 90 kW B4184S10 4 Zyl.		
Phase sensor	04.99-08.99	NOC	0 232 101 029
Wheel speed sensor, front	04.99-06.04		0 265 006 425
Wheel speed sensor, rear			
	Fg.no. →985261		0 265 006 366
	Fg.no. 985262→		0 265 006 698
1.8 16V	1,8l 92 kW B4184SM 4 Zyl.		
Wheel speed sensor, front	09.97-07.00		0 265 006 425
Wheel speed sensor, rear			
	Fg.no. →985261		0 265 006 366
	Fg.no. 985262→		0 265 006 698
1.9 D	1,9l 66 kW D4192T 4 Zyl.		
Speed sensor, diesel	01.96-07.99		0 281 002 349
Wheel speed sensor, front	09.97-07.99		0 265 006 425
	01.96-08.97	LAB	0 265 006 224
		RAB	0 265 006 223
Wheel speed sensor, rear	01.96-07.99		0 265 006 366
1.9 D	1,9l 70/75/85 kW D4192T2; D4192T3/DI; D4192T4/DI 4 Zyl.		
Wheel speed sensor, front	08.98-04.04		0 265 006 425
Wheel speed sensor, rear			
	Fg.no. →985261		0 265 006 366
	Fg.no. 985262→		0 265 006 698
1.9 T4	1,9l 147 kW B4194T 4 Zyl.		
Phase sensor	05.97-07.99	NOC	0 232 101 029
Wheel speed sensor, front	09.97-07.99		0 265 006 425
	05.97-08.97	LAB	0 265 006 224
		RAB	0 265 006 223
Wheel speed sensor, rear	05.97-07.99		0 265 006 366
1.9 T4	1,9l 147 kW B4194T2 4 Zyl.		
Wheel speed sensor, front	08.99-07.00		0 265 006 425
Wheel speed sensor, rear			
	Fg.no. →985261		0 265 006 366
	Fg.no. 985262→		0 265 006 698
2.0	2,0l 103 kW B4204S 4 Zyl.		
Phase sensor	01.96-07.99	NOC	0 232 101 029
Wheel speed sensor, front	09.97-07.99		0 265 006 425
	01.96-08.97	LAB	0 265 006 224
		RAB	0 265 006 223
Wheel speed sensor, rear	01.96-07.99		0 265 006 366
2.0 T	1,9l 120 kW B4204T3 4 Zyl.		
Pressure sensor, intake manifold, gasoline	08.01-04.04		0 261 230 029
Wheel speed sensor, front	08.01-04.04		0 265 006 425
Wheel speed sensor, rear			
	Fg.no. →985261		0 265 006 366
	Fg.no. 985262→		0 265 006 698
2.0 T	2,0l 121 kW B4204T3 4 Zyl.		
Pressure sensor, intake manifold, gasoline	08.00-07.01		0 261 230 029
Wheel speed sensor, front	08.00-07.01		0 265 006 425
Wheel speed sensor, rear			
	Fg.no. →985261		0 265 006 366
	Fg.no. 985262→		0 265 006 698
2.0 T4 T	2,0l 147 kW B4204T5 4 Zyl.		
Pressure sensor, intake manifold, gasoline	08.00-04.04		0 261 230 029
Wheel speed sensor, front	08.00-04.04		0 265 006 425
Wheel speed sensor, rear			
	Fg.no. →985261		0 265 006 366
	Fg.no. 985262→		0 265 006 698
2.0 16V	2,0l 100 kW B4204S2 4 Zyl.		
Wheel speed sensor, front	08.99-04.04		0 265 006 425
Wheel speed sensor, rear			
	Fg.no. →985261		0 265 006 366
	Fg.no. 985262→		0 265 006 698



Product				

◀ V40

2.0 16V T	1,9l 118 kW B4204T2 4 Zyl.
Wheel speed sensor, front	08.99-07.00 0 265 006 425
Wheel speed sensor, rear	
Fg.no. 985262→	08.99-07.00 0 265 006 698
2.0 16V T	2,0l 118 kW B4204T 4 Zyl.
Phase sensor	04.98-07.99 NOC 0 232 101 029
Wheel speed sensor, front	04.98-07.99 0 265 006 425
Wheel speed sensor, rear	04.98-07.99 0 265 006 366

V50

D5 [P 12]	2,4l 120/132 kW D5244T8; D5244T9 5 Zyl.
Throttle valve assembly	04.06→ 0 281 002 701
Phase sensor	04.06→ NOC 0 232 103 063
High-pressure sensor (CR system)	04.06→ 0 281 002 706
Boost pressure sensor, Diesel	04.06→ 0 261 230 105
T5 [P 12]	2,5l 162 kW B5254T3 5 Zyl.
Throttle valve assembly	04.04→ 0 280 750 146
Air mass meter, gasoline injection	04.04→ 0 280 218 134
Knock sensor	04.04→ 0 261 231 178
Boost pressure sensor, gasoline	04.04-07.07 0 261 230 090
	08.07→ 0 261 230 105
Temperature sensor, fuel	04.04→ 0 261 230 110
T5 [P 12]	2,5l 169 kW B5254T7 5 Zyl.
Throttle valve assembly	08.07→ 0 280 750 146
Air mass meter, gasoline injection	08.07→ 0 280 218 134
Knock sensor	08.07→ 0 261 231 178
Boost pressure sensor, gasoline	08.07→ 0 261 230 105
Temperature sensor, fuel	08.07→ 0 261 230 110
T5 AWD [P 12]	2,5l 162 kW B5254T3 5 Zyl.
Throttle valve assembly	04.04→ 0 280 750 146
Air mass meter, gasoline injection	04.04→ 0 280 218 134
Knock sensor	04.04→ 0 261 231 178
Boost pressure sensor, gasoline	04.04-07.07 0 261 230 090
	08.07→ 0 261 230 105
Temperature sensor, fuel	04.04→ 0 261 230 110
T5 AWD [P 12]	2,5l 169 kW B5254T7 5 Zyl.
Throttle valve assembly	08.07→ 0 280 750 146
Air mass meter, gasoline injection	08.07→ 0 280 218 134
Knock sensor	08.07→ 0 261 231 178
Boost pressure sensor, gasoline	08.07→ 0 261 230 105
Temperature sensor, fuel	08.07→ 0 261 230 110
1.8 [P 12]	1,8l 92 kW B4184S11 4 Zyl.
Pressure sensor, intake manifold, gasoline	04.04→ 0 261 230 044
1.8 F [P 12]	1,8l 92 kW B4184S8 4 Zyl.
Pressure sensor, intake manifold, gasoline	04.06→ 0 261 230 044
2.0 [P 12]	2,0l 107 kW B4204S3 4 Zyl.
Pressure sensor, intake manifold, gasoline	10.06→ 0 261 230 044
2.4 [P 12]	2,4l 103 kW B5244S5 5 Zyl.
Temperature sensor, fuel	04.04→ 0 261 230 109
2.4 i [P 12]	2,4l 125 kW B5244S4; B5244S7 5 Zyl.
Temperature sensor, fuel	04.04→ 0 261 230 109

V70 I

2.0	2,0l 93 kW B5202FS 5 Zyl.
Phase sensor	01.97-07.98 NOC 0 232 101 030
Knock sensor	01.97-07.98 0 261 231 121
	08.98-07.99 0 261 231 142
2.0	2,0l 105 kW B5204S 5 Zyl.
Throttle valve sensor	01.97-07.98 0 280 122 001
Air mass meter, gasoline injection	01.97-07.98 0 280 217 107

Product				

Phase sensor	01.97-07.98 NOC 0 232 101 030
Knock sensor	01.97-07.98 0 261 231 121
2.0 AWD Turbo	2,0l 166 kW B5204T3 5 Zyl.
Throttle valve sensor	01.97-07.99 0 280 122 001
Air mass meter, gasoline injection	01.97-07.98 0 280 217 107
	08.98-07.99 0 280 218 108
Phase sensor	01.97-07.98 NOC 0 232 101 030
Knock sensor	01.97-07.98 0 261 231 121
	08.98-07.99 0 261 231 142
Pressure sensor, intake manifold, gasoline	01.97-07.99 0 261 230 018
2.0 T 20V	2,0l 120 kW B5204T4 5 Zyl.
Throttle valve sensor	08.98-03.00 0 280 122 001
Air mass meter, gasoline injection	08.98-03.00 0 280 218 108
Knock sensor	08.98-03.00 0 261 231 142
Pressure sensor, intake manifold, gasoline	08.98-03.00 0 261 230 018
2.0 Turbo	2,0l 132 kW B5204T2 5 Zyl.
Throttle valve sensor	01.97-07.98 0 280 122 001
Air mass meter, gasoline injection	01.97-07.98 0 280 217 107
Phase sensor	01.97-07.98 NOC 0 232 101 030
Knock sensor	01.97-07.98 0 261 231 121
2.0 Turbo	2,0l 155 kW B5204T 5 Zyl.
Throttle valve sensor	01.97-03.00 0 280 122 001
Air mass meter, gasoline injection	01.97-07.98 0 280 217 107
	08.98-03.00 0 280 218 108
Phase sensor	01.97-07.98 NOC 0 232 101 030
Knock sensor	01.97-07.98 0 261 231 121
	08.98-03.00 0 261 231 142
2.0 Turbo	2,0l 166 kW B5204T3 5 Zyl.
Throttle valve sensor	01.97-07.99 0 280 122 001
Air mass meter, gasoline injection	01.97-07.98 0 280 217 107
	08.98-07.99 0 280 218 108
Phase sensor	01.97-07.98 NOC 0 232 101 030
Knock sensor	01.97-07.98 0 261 231 121
	08.98-07.99 0 261 231 142
Pressure sensor, intake manifold, gasoline	01.97-07.99 0 261 230 018
2.3	2,3l 160 kW B5234T2 5 Zyl.
Throttle valve sensor	01.97-07.98 0 280 122 001
Air mass meter, gasoline injection	01.97-07.98 0 280 217 107
Phase sensor	01.97-07.98 NOC 0 232 101 030
Knock sensor	01.97-07.98 0 261 231 121
Pressure sensor, intake manifold, gasoline	01.97-07.98 0 261 230 018
2.3 AWD	2,3l 195 kW B5234T8 5 Zyl.
Throttle valve sensor	12.98-03.00 0 280 122 001
Air mass meter, gasoline injection	12.98-03.00 0 280 218 108
Knock sensor	12.98-03.00 0 261 231 142
Pressure sensor, intake manifold, gasoline	12.98-03.00 0 261 230 018
2.3 R	2,3l 184 kW B5234T4 5 Zyl.
Throttle valve sensor	01.97-07.98 0 280 122 001
Air mass meter, gasoline injection	01.97-07.98 0 280 217 107
Phase sensor	01.97-07.98 NOC 0 232 101 030
Knock sensor	01.97-07.98 0 261 231 121
2.3 R AWD	2,3l 184 kW B5234T4 5 Zyl.
Throttle valve sensor	08.97-07.98 0 280 122 001
Air mass meter, gasoline injection	08.97-07.98 0 280 217 107
Phase sensor	08.97-07.98 NOC 0 232 101 030
Knock sensor	08.97-07.98 0 261 231 121
Pressure sensor, intake manifold, gasoline	08.97-07.98 0 261 230 018
2.3 T-5	2,3l 176 kW B5234T3 5 Zyl.
Throttle valve sensor	01.97-03.00 0 280 122 001
Air mass meter, gasoline injection	01.97-07.98 0 280 217 107
	08.98-03.00 0 280 218 108
Phase sensor	01.97-07.98 NOC 0 232 101 030



Knock sensor	01.97-07.98	0 261 231 121
	08.98-03.00	0 261 231 142
Pressure sensor, intake manifold, gasoline	01.97-03.00	0 261 230 018
2.3 T-5 AWD	2,3l 176 kW B5234T6 5 Zyl.	
Throttle valve sensor	01.97-03.00	0 280 122 001
Air mass meter, gasoline injection	01.97-07.98	0 280 217 107
	08.98-03.00	0 280 218 108
Phase sensor	01.97-07.98 NOC	0 232 101 030
Knock sensor	01.97-07.98	0 261 231 121
	08.98-03.00	0 261 231 142
Pressure sensor, intake manifold, gasoline	01.97-03.00	0 261 230 018
2.5	2,4l 106 kW B5252S 5 Zyl.	
Phase sensor	01.97-07.98 NOC	0 232 101 030
Knock sensor	01.97-07.98	0 261 231 121
	08.98-03.00	0 261 231 142
2.5 AWD	2,4l 195 kW B5244T2 5 Zyl.	
Throttle valve sensor	03.99-03.00	0 280 122 001
Air mass meter, gasoline injection	03.99-03.00	0 280 218 108
Knock sensor	03.99-03.00	0 261 231 142
Pressure sensor, intake manifold, gasoline	03.99-03.00	0 261 230 018
2.5 BI-FUEL	2,4l 103 kW GB5252S 5 Zyl.	
Phase sensor	08.97-07.98 NOC	0 232 101 030
Knock sensor	08.97-07.98	0 261 231 121
2.5 T	2,4l 142 kW B5254T 5 Zyl.	
Throttle valve sensor	01.97-03.00	0 280 122 001
Air mass meter, gasoline injection	01.97-07.98	0 280 217 107
	08.98-03.00	0 280 218 108
Phase sensor	01.97-07.98 NOC	0 232 101 030
Knock sensor	01.97-07.98	0 261 231 121
	08.98-03.00	0 261 231 142
Pressure sensor, intake manifold, gasoline	01.97-03.00	0 261 230 018
2.5 T XC, T XC AWD	2,4l 142 kW B5254T 5 Zyl.	
Air mass meter, gasoline injection	01.97-07.98	0 280 217 107
	08.98-03.00	0 280 218 108
Knock sensor	01.97-07.98	0 261 231 121
	08.98-03.00	0 261 231 142
2.5 TDI	2,5l 103 kW D5252T 5 Zyl.	
Air flow sensor, diesel		
Fg.no. →587536	01.97-03.00	0 281 002 155
Air mass meter, diesel		
Fg.no. 587537→	01.97-03.00	0 280 218 108
2.5 20V	2,4l 121 kW B5254S 5 Zyl.	
Throttle valve sensor	01.97-07.98	0 280 122 001
Air mass meter, gasoline injection	01.97-07.98	0 280 217 107
Phase sensor	01.97-07.98 NOC	0 232 101 030
Knock sensor	01.97-07.98	0 261 231 121
V70 II		
2.0 T	2,0l 132 kW B5204T5 5 Zyl.	
Throttle valve assembly	08.01-07.02	0 280 750 103
	08.02-07.07	0 280 750 131
Air mass meter, gasoline injection	08.01-07.07	0 280 218 088
	03.00-07.01	0 280 218 108
Knock sensor	03.00-07.07	0 261 231 142



Boost pressure sensor, gasoline	08.02-07.07	0 261 230 090
Temperature sensor, fuel	03.00-07.07	0 261 230 110
2.3 T5	2,3l 184 kW B5234T3 5 Zyl.	
Throttle valve assembly	08.01-07.02	0 280 750 103
	08.02-07.04	0 280 750 131
Air mass meter, gasoline injection	08.01-07.04	0 280 218 088
	03.00-07.01	0 280 218 108
Knock sensor	03.00-07.04	0 261 231 142
Boost pressure sensor, gasoline	08.02-07.04	0 261 230 090
Temperature sensor, fuel	03.00-07.04	0 261 230 110
2.4	2,4l 103/125 kW B5244S; B5244S2; B5244S6 5 Zyl.	
Temperature sensor, fuel	08.02-07.07	0 261 230 109
2.4 D	2,4l 90/93 kW D5244T6; D5244T7 5 Zyl.	
Phase sensor	08.06-07.07 NOC	0 232 103 063
2.4 D	2,4l 96/120 kW D5244T; D5244T2 5 Zyl.	
Air mass meter, diesel	08.01-07.06	0 280 218 088
Phase sensor	08.01-07.06 NOC	0 232 103 042
2.4 D	2,4l 120 kW D5244T5 5 Zyl.	
Phase sensor	08.06-07.07 NOC	0 232 103 063
2.4 D AWD	2,4l 120 kW D5244T 5 Zyl.	
Air mass meter, diesel	08.02-07.06	0 280 218 088
Phase sensor	08.02-07.06 NOC	0 232 103 042
2.4 D5	2,4l 136 kW D5244T3 5 Zyl.	
Air mass meter, diesel	12.05-07.06	0 280 218 088
Phase sensor	12.05-07.06 NOC	0 232 103 042
2.4 D5	2,4l 136 kW D5244T4 5 Zyl.	
Phase sensor	08.06-07.07 NOC	0 232 103 063
2.4 D5 AWD	2,4l 136 kW D5244T3 5 Zyl.	
Air mass meter, diesel	12.05-07.06	0 280 218 088
Phase sensor	12.05-07.06 NOC	0 232 103 042
2.4 D5 AWD	2,4l 136 kW D5244T4 5 Zyl.	
Phase sensor	08.06-07.07 NOC	0 232 103 063
2.4 T	2,4l 147 kW B5244T3 5 Zyl.	
Throttle valve assembly	08.01-07.02	0 280 750 103
	08.02-07.03	0 280 750 131
Air mass meter, gasoline injection	08.01-07.03	0 280 218 088
	03.00-07.01	0 280 218 108
Knock sensor	03.00-07.03	0 261 231 142
Boost pressure sensor, gasoline	08.02-07.03	0 261 230 090
Temperature sensor, fuel	03.00-07.03	0 261 230 110
2.4 T5	2,4l 191 kW B5244T5 5 Zyl.	
Throttle valve assembly	04.04-07.07	0 280 750 131
Air mass meter, gasoline injection	04.04-07.07	0 280 218 089
Knock sensor	04.04-07.07	0 261 231 142
Boost pressure sensor, gasoline	04.04-07.07	0 261 230 090
Temperature sensor, fuel	04.04-07.07	0 261 230 110
2.4 XC, XC AWD	2,4l 147 kW B5244T3 5 Zyl.	
Throttle valve assembly	08.01-07.02	0 280 750 103
Air mass meter, gasoline injection	08.01-07.02	0 280 218 088
	09.00-07.01	0 280 218 108
Knock sensor	09.00-07.02	0 261 231 142
Temperature sensor, fuel	09.00-07.02	0 261 230 110
2.5 BI-FUEL CNG	2,5l 103 kW B5244SG 5 Zyl.	
Temperature sensor, fuel	08.02-07.07	0 261 230 109
2.5 BI-FUEL LPG	2,5l 103 kW B5244SG2 5 Zyl.	
Temperature sensor, fuel	08.02-07.06	0 261 230 109
2.5 D	2,5l 103 kW D5252T 5 Zyl.	
Air mass meter, diesel	03.00-07.01	0 280 218 108
2.5 T	2,5l 154 kW B5254T2 5 Zyl.	
Throttle valve assembly	04.04-07.07	0 280 750 131
Air mass meter, gasoline injection	04.04-07.07	0 280 218 088
Knock sensor	04.04-07.07	0 261 231 142

Product				

◀ V70 II

Boost pressure sensor, gasoline	04.04-07.07	0 261 230 090
Temperature sensor, fuel	04.04-07.07	0 261 230 110
2.5 T AWD	2,5 l 154 kW B5254T2 5 Zyl.	
Throttle valve assembly	08.02-07.07	0 280 750 131
Air mass meter, gasoline injection	08.02-07.07	0 280 218 088
Knock sensor	08.02-07.07	0 261 231 142
Boost pressure sensor, gasoline	08.02-07.07	0 261 230 090
Temperature sensor, fuel	08.02-07.07	0 261 230 110
2.5 T AWD R	2,5 l 220 kW B5254T4 5 Zyl.	
Throttle valve assembly	03.03-07.07	0 280 750 131
Air mass meter, gasoline injection	03.03-07.07	0 280 218 089
Knock sensor	03.03-07.07	0 261 231 142
Pressure sensor, intake manifold, gasoline	03.03-07.07	0 261 230 105
Temperature sensor, fuel	03.03-07.07	0 261 230 110

V70 III

2.4 D	2,4 l 120 kW D5244T4 5 Zyl.	
Throttle valve assembly	08.07→	0 281 002 701
Phase sensor	08.07→ NOC	0 232 103 063
Boost pressure sensor, Diesel	08.07→	0 261 230 105
2.4 D5	2,4 l 136 kW D5244T5 5 Zyl.	
Throttle valve assembly	08.07→	0 281 002 701
Phase sensor	08.07→ NOC	0 232 103 063
Boost pressure sensor, Diesel	08.07→	0 261 230 105
2.5 T	2,5 l 147 kW B5254T6 5 Zyl.	
Throttle valve assembly	08.07→	0 280 750 146
Air mass meter, gasoline injection	08.07→	0 280 218 134
Knock sensor	08.07→	0 261 231 178
Boost pressure sensor, gasoline	08.07→	0 261 230 105
Temperature sensor, fuel	08.07→	0 261 230 110
3.0 T6 AWD	3,0 l 210 kW B6304T2 6 Zyl.	
Temperature sensor, fuel	08.07→	0 261 230 110
3.2, AWD	3,2 l 175 kW B6324S 6 Zyl.	
Temperature sensor, fuel	08.07→	0 261 230 110

V90

3.0	2,9 l 132 kW 6 Zyl.	
Throttle valve sensor	01.97-07.98	0 280 122 001
Air mass meter, gasoline injection	01.97-07.98	0 280 217 511
Phase sensor	01.97-07.98 NOC	0 232 101 030
3.0	2,9 l 150 kW B6304S 6 Zyl.	
Throttle valve sensor	01.97-07.98	0 280 122 001
Air mass meter, gasoline injection	01.97-07.98	0 280 217 511
Phase sensor	01.97-07.98 NOC	0 232 101 030
Knock sensor	01.97-07.98	0 261 231 046

XC70 I

2.3 T	2,3 l 140 kW B5234T7 5 Zyl.	
Throttle valve assembly	08.02-07.04	0 280 750 131
Air mass meter, gasoline injection	08.02-07.04	0 280 218 088
Knock sensor	08.02-07.04	0 261 231 142
Boost pressure sensor, gasoline	08.02-07.04 UE	0 261 230 090
Temperature sensor, fuel	08.02-07.04	0 261 230 110
2.4 D	2,4 l 120 kW D5244T 5 Zyl.	
Air mass meter, diesel	08.02-07.06	0 280 218 088
Phase sensor	08.02-07.06 NOC	0 232 103 063
Boost pressure sensor, Diesel	08.02-07.06 UE	0 261 230 090

Product				

2.4 D5	2,4 l 136 kW D5244T4 5 Zyl.	
Throttle valve assembly	12.05-07.07	0 281 002 701
Phase sensor	12.05-07.07 NOC	0 232 103 063
Boost pressure sensor, Diesel	12.05-07.07	0 261 230 105
2.4 T	2,4 l 147 kW B5244T4 5 Zyl.	
Throttle valve assembly	08.04-07.07	0 280 750 131
Air mass meter, gasoline injection	08.04-07.07	0 280 218 089
Knock sensor	08.04-07.07	0 261 231 142
Boost pressure sensor, gasoline	08.04-07.07	0 261 230 105
Temperature sensor, fuel	08.04-07.07	0 261 230 110
2.5 T	2,5 l 154 kW B5254T2 5 Zyl.	
Throttle valve assembly	08.02-07.07	0 280 750 131
Air mass meter, gasoline injection	08.02-07.07	0 280 218 088
Knock sensor	08.02-07.07	0 261 231 142
Boost pressure sensor, gasoline	08.02-07.07 UE	0 261 230 090
Temperature sensor, fuel	08.02-07.07	0 261 230 110

XC70 II

2.4 D5	2,4 l 136 kW D5244T4 5 Zyl.	
Phase sensor	08.07→ NOC	0 232 103 063
Boost pressure sensor, Diesel	08.07→	0 261 230 105
3.2	3,2 l 175 kW B6324S 6 Zyl.	
Temperature sensor, fuel	08.07→	0 261 230 110

XC90

D5	2,4 l 120 kW D5244T 5 Zyl.	
Air mass meter, diesel	01.03-07.06	0 280 218 088
Phase sensor	01.03-07.06 NOC	0 232 103 042
Boost pressure sensor, Diesel	01.03-07.06 UE	0 261 230 090
D5	2,4 l 136 kW D5244T4 5 Zyl.	
Throttle valve assembly	05.05→	0 281 002 701
Phase sensor	05.05→ NOC	0 232 103 042
Boost pressure sensor, Diesel	05.05→	0 261 230 105
T6	2,9 l 200 kW B6294T 6 Zyl.	
Throttle valve assembly	01.03-07.06	0 280 750 131
Air mass meter, gasoline injection	01.03-07.06	0 280 218 089
Knock sensor	01.03-07.06	0 261 231 142
Boost pressure sensor, gasoline	01.03-07.06	0 261 230 090
V8	4,4 l 232 kW B8444S 8 Zyl.	
Temperature sensor, fuel	03.05→	0 261 230 110
2.5 T, T AWD	2,5 l 154 kW B5254T2 5 Zyl.	
Throttle valve assembly	01.03→	0 280 750 131
Air mass meter, gasoline injection	01.03→	0 280 218 088
Knock sensor	01.03→	0 261 231 142
Boost pressure sensor, gasoline	01.03→ UE	0 261 230 090
Temperature sensor, fuel	01.03→	0 261 230 110
3.2	3,2 l 175 kW B6324S 6 Zyl.	
Temperature sensor, fuel	08.06→	0 261 230 110

240

2.0 Injection	2,0 l 82 kW B200F Kat. 4 Zyl.	
Throttle valve sensor	04.91-07.92	0 280 120 325
Air mass meter, gasoline injection	04.91-07.92	0 280 212 016
		0 986 280 101
Knock sensor	04.91-07.92	0 261 231 046
Temperature sensor, coolant, injection system	04.91-07.92	0 280 130 032
Wheel speed sensor, front	08.91-07.92	0 265 001 332
2.0 Injection	2,0 l 82-86 kW B200E 4 Zyl.	
Air flow sensor, gasoline injection	08.84-07.92	0 438 120 076
Wheel speed sensor, front	08.91-07.92	0 265 001 332





V



Product			
2.1 Injection Turbo 2,1l 114 kW B21ET 4 Zyl.			
Air flow sensor, gasoline injection	08.80-07.86		0 438 120 134
2.3 2,3l 78-81 kW B230K 4 Zyl.			
Knock sensor	08.84-07.90		0 261 231 006
2.3 Injection 2,3l 84 kW B230F Kat. 4 Zyl.			
Throttle valve sensor	08.88-07.93		0 280 120 325
Air mass meter, gasoline injection			
Fg.no. →334099	08.88-07.93	LIM	0 280 212 007 0 986 280 102
Fg.no. →808999	08.88-07.93	KOB	0 280 212 007 0 986 280 102
Fg.no. 334100→	08.88-07.93	LIM	0 280 212 016 0 986 280 101
Fg.no. 809000→	08.88-07.93	KOB	0 280 212 016 0 986 280 101
Knock sensor	08.88-07.93		0 261 231 046
Temperature sensor, coolant, injection system	08.88-07.92		0 280 130 032
Wheel speed sensor, front	08.91-07.93		0 265 001 332
2.3 Injection 2,3l 85 kW B230F Kat. 4 Zyl.			
Throttle valve sensor	08.84-07.87		0 280 120 301
	08.87-07.88		0 280 120 325
Air mass meter, gasoline injection			
Fg.no. →334099	08.84-07.88	LIM	0 280 212 007 0 986 280 102
Fg.no. →808999	08.84-07.88	KOB	0 280 212 007 0 986 280 102
Fg.no. 334100→	08.87-07.88	LIM	0 280 212 016 0 986 280 101
Fg.no. 809000→	08.87-07.88	KOB	0 280 212 016 0 986 280 101
Temperature sensor, coolant, injection system	08.84-07.88		0 280 130 032
2.3 Injection 2,3l 95-96 kW B230E 4 Zyl.			
Air flow sensor, gasoline injection	08.84-07.92		0 438 120 203
Wheel speed sensor, front	08.91-07.92		0 265 001 332
2.3 Injection 2,3l 100 kW B230F 4 Zyl.			
Throttle valve sensor	08.92-07.93		0 280 120 325
Air mass meter, gasoline injection			
Fg.no. →334099	08.92-07.93	LIM	0 280 212 007 0 986 280 102
Fg.no. →808999	08.92-07.93	KOB	0 280 212 007 0 986 280 102
Fg.no. 334100→	08.92-07.93	LIM	0 280 212 016 0 986 280 101
Fg.no. 809000→	08.92-07.93	KOB	0 280 212 016 0 986 280 101
Knock sensor	08.92-07.93		0 261 231 046
Temperature sensor, coolant, injection system	08.92-07.93		0 280 130 032
Wheel speed sensor, front	08.92-07.93		0 265 001 332
2.4D 2,4l 58-60 kW D24 6 Zyl.			
Wheel speed sensor, front	08.91-07.93		0 265 001 332

340

2.0i 2,0l 86 kW B200E 4 Zyl.			
Throttle valve sensor	08.84-07.87		0 280 120 301
	08.87-07.88		0 280 120 325
Air flow sensor, gasoline injection	08.84-07.88		0 280 202 034 0 986 280 059
Temperature sensor, coolant, injection system	08.84-07.88		0 280 130 032
Relay, Jetronic	08.84-07.88		0 280 230 005

**360**

2.0i 2,0l 80 kW B200F Kat. 4 Zyl.			
Throttle valve sensor	01.86-07.87		0 280 120 301
	08.87-07.90		0 280 120 325
Air flow sensor, gasoline injection	01.86-07.89		0 280 202 096
Temperature sensor, coolant, injection system	01.86-07.90		0 280 130 026
Relay, Jetronic	01.86-07.90		0 280 230 005
2.0i 2,0l 86 kW B200E 4 Zyl.			
Throttle valve sensor	08.84-07.87		0 280 120 301
	08.87-07.89		0 280 120 325
Air flow sensor, gasoline injection	08.84-07.89		0 280 202 034 0 986 280 059
Temperature sensor, coolant, injection system	08.84-07.89		0 280 130 026
Relay, Jetronic	08.84-07.89		0 280 230 005

440

1.6i 1,6l 61 kW B16F Kat. 4 Zyl.			
Throttle valve sensor	09.93-07.97		0 280 122 001
1.7i 1,7l 70-75 kW B18F Kat. 4 Zyl.			
Throttle valve sensor	09.88-07.91		0 280 120 301
Air mass meter, gasoline injection	09.88-07.91		0 280 212 007 0 986 280 102
Knock sensor	09.88-07.91		0 261 231 006
Temperature sensor, coolant, injection system	09.88-07.91		0 280 130 032
1.7i 1,7l 75 kW B18FP Kat. 4 Zyl.			
Throttle valve sensor	09.89-07.91		0 280 122 001
Knock sensor	09.89-07.91		0 261 231 006
1.7i 1,7l 78-80 kW B18EP 4 Zyl.			
Throttle valve sensor	09.88-07.94		0 280 120 301
Knock sensor	09.88-07.94		0 261 231 006
1.7T 1,7l 88 kW B18FT Kat. 4 Zyl.			
Throttle valve sensor	09.88-07.96		0 280 120 400
Air mass meter, gasoline injection	09.88-12.90		0 280 212 007 0 986 280 102
	01.91-07.96		0 280 212 021 0 986 280 107
Knock sensor	09.88-07.96		0 261 231 006
Temperature sensor, coolant, injection system	09.88-07.96		0 280 130 032
1.8i 1,8l 66 kW B18U Kat. 4 Zyl.			
Knock sensor	09.91-07.97		0 261 231 006
2.0i 2,0l 80 kW B20F Kat. 4 Zyl.			
Throttle valve sensor	09.92-12.96		0 280 122 001
Knock sensor	09.92-12.96		0 261 231 006

460

1.7i 1,7l 75 kW B18FP Kat. 4 Zyl.			
Throttle valve sensor	03.90-07.93		0 280 122 001
Knock sensor	03.90-07.93		0 261 231 006
Temperature sensor, coolant, injection system	03.90-07.93		0 280 130 032
1.7iT 1,7l 88 kW B18FT Kat. 4 Zyl.			
Throttle valve sensor	03.90-07.96		0 280 120 400
Air mass meter, gasoline injection	03.90-12.90		0 280 212 007 0 986 280 102
	01.91-07.96		0 280 212 021 0 986 280 107
Knock sensor	03.90-07.96		0 261 231 006
Temperature sensor, coolant, injection system	03.90-07.96		0 280 130 032

Product				

◀ 460

1.8 i	1,8 l 66 kW B18U Kat. 4 Zyl.
Knock sensor	09.91-07.97 0 261 231 006
2.0 i	2,0 l 80 kW B20F Kat. 4 Zyl.
Throttle valve sensor	09.92-12.96 0 280 122 001
Knock sensor	09.92-12.96 0 261 231 006

480

1.7 i [E 12]	1,7 l 70-75 kW B18F Kat. 4 Zyl.
Throttle valve sensor	05.87-07.89 0 280 120 319
Knock sensor	05.87-07.89 0 261 231 006
Temperature sensor, coolant, injection system	05.87-07.89 0 280 130 032
1.7 i [E 12]	1,7 l 75 kW B18FP Kat. 4 Zyl.
Throttle valve sensor	08.89-12.93 0 280 122 001
Knock sensor	08.89-12.93 0 261 231 006
1.7 i [E 12]	1,7 l 78-80 kW B18E 4 Zyl.
Throttle valve sensor	04.86-07.89 0 280 120 301
Knock sensor	04.86-07.89 0 261 231 006
1.7 i T [E 12]	1,7 l 88-90 kW B18FT Kat. 4 Zyl.
Throttle valve sensor	08.88-07.95 0 280 120 400
Air mass meter, gasoline injection	
Fg.no. →567599	08.88-07.95 0 280 212 007
	0 986 280 102
Fg.no. 567600→	08.88-07.95 0 280 212 021
	0 986 280 107
Knock sensor	08.88-07.95 0 261 231 006
Temperature sensor, coolant, injection system	08.88-07.95 0 280 130 032
2.0 i [E 12]	2,0 l 81 kW B20F Kat. 4 Zyl.
Throttle valve sensor	09.92-12.96 0 280 122 001
Knock sensor	09.92-12.96 0 261 231 006

740

2.0	2,0 l 76 kW B200K 4 Zyl.
Air mass meter, gasoline injection	08.88-07.89 0 280 212 016
	0 986 280 101
Knock sensor	08.84-07.89 0 261 231 006
Wheel speed sensor, front	08.84-08.87 0 265 001 064
Fg.no. →176799	08.87-07.89 KOB 0 265 001 184
Fg.no. →294099	08.87-07.89 LIM 0 265 001 184
Fg.no. 176800→	08.87-07.89 KOB 0 265 001 231
Fg.no. 294100→	08.87-07.89 LIM 0 265 001 231
Wheel speed sensor, rear	08.84-07.87 0 265 001 065
	08.87-07.88 0 265 001 185
2.0 i	2,0 l 80 kW B200G 4 Zyl.
Throttle valve sensor	08.91-07.94 0 280 120 325
Air mass meter, gasoline injection	08.91-07.94 0 280 212 021
	0 986 280 107
Knock sensor	08.91-07.94 0 261 231 006
Temperature sensor, coolant, injection system	08.91-07.94 0 280 130 032
Wheel speed sensor, front	
Fg.no. →176799	08.91-07.94 KOB 0 265 001 184
Fg.no. →294099	08.91-07.94 LIM 0 265 001 184
Fg.no. 176800→	08.91-07.94 KOB 0 265 001 231
Fg.no. 294100→	08.91-07.94 LIM 0 265 001 231
2.0 i	2,0 l 82 kW B200F Kat. 4 Zyl.
Throttle valve sensor	08.89-07.93 0 280 120 325
Air mass meter, gasoline injection	08.89-07.93 0 280 212 016
	0 986 280 101
Knock sensor	08.89-07.93 0 261 231 006
Temperature sensor, coolant, injection system	08.89-07.93 0 280 130 032

Product				

Wheel speed sensor, front			
Fg.no. →176799	08.89-07.93 KOB	0 265 001 184	
Fg.no. →294099	08.89-07.93 LIM	0 265 001 184	
Fg.no. 176800→	08.89-07.93 KOB	0 265 001 231	
Fg.no. 294100→	08.89-07.93 LIM	0 265 001 231	
2.0 i	2,0 l 88 kW B200E 4 Zyl.		
Air flow sensor, gasoline injection	08.84-07.91	0 438 120 076	
Knock sensor	08.84-07.91	0 261 231 006	
Wheel speed sensor, front	08.84-08.87	0 265 001 064	
Fg.no. →176799	08.87-07.91 KOB	0 265 001 184	
Fg.no. →294099	08.87-07.91 LIM	0 265 001 184	
Fg.no. 176800→	08.87-07.91 KOB	0 265 001 231	
Fg.no. 294100→	08.87-07.91 LIM	0 265 001 231	
Wheel speed sensor, rear	08.84-07.87	0 265 001 065	
	08.87-07.88	0 265 001 185	
2.0 i T	2,0 l 114 kW B200FT Kat. 4 Zyl.		
Throttle valve sensor	08.90-07.92	0 280 120 325	
Air mass meter, gasoline injection	08.90-07.92	0 280 212 016	
		0 986 280 101	
Knock sensor	08.90-07.92	0 261 231 006	
Temperature sensor, coolant, injection system	08.90-07.92	0 280 130 032	
Wheel speed sensor, front			
Fg.no. →176799	08.90-07.92 KOB	0 265 001 184	
Fg.no. →294099	08.90-07.92 LIM	0 265 001 184	
Fg.no. 176800→	08.90-07.92 KOB	0 265 001 231	
Fg.no. 294100→	08.90-07.92 LIM	0 265 001 231	
2.0 i T	2,0 l 120-121 kW B200ET 4 Zyl.		
Throttle valve sensor	08.84-04.87	0 280 120 301	
	05.87-07.89	0 280 120 325	
Air flow sensor, gasoline injection	08.84-07.89	0 280 202 067	
Speed sensor, ignition/injection	08.84-07.89	0 261 210 003	
Knock sensor	08.84-07.89	0 261 231 006	
Temperature sensor, coolant, injection system	08.84-07.89	0 280 130 032	
Wheel speed sensor, front	08.84-08.87	0 265 001 064	
Fg.no. →176799	08.87-07.89 KOB	0 265 001 184	
Fg.no. →294099	08.87-07.89 LIM	0 265 001 184	
Fg.no. 176800→	08.87-07.89 KOB	0 265 001 231	
Fg.no. 294100→	08.87-07.89 LIM	0 265 001 231	
Wheel speed sensor, rear	08.84-07.87	0 265 001 065	
	08.87-07.88	0 265 001 185	
2.0 i 16V	2,0 l 100-103 kW B204E 4 Zyl.		
Throttle valve sensor	08.88-07.90	0 280 120 325	
Air mass meter, gasoline injection	08.88-07.90	0 280 212 007	
		0 986 280 102	
Knock sensor	08.88-07.90	0 261 231 006	
Temperature sensor, coolant, injection system	08.88-07.90	0 280 130 032	
Wheel speed sensor, front			
Fg.no. →176799	08.88-07.90 KOB	0 265 001 184	
Fg.no. →294099	08.88-07.90 LIM	0 265 001 184	
Fg.no. 176800→	08.88-07.90 KOB	0 265 001 231	
Fg.no. 294100→	08.88-07.90 LIM	0 265 001 231	
2.0 i 16V T	2,0 l 136/140 kW B204FT Kat.; B204GT 4 Zyl.		
Throttle valve sensor	08.89-07.90	0 280 120 400	
Air mass meter, gasoline injection	08.89-07.90	0 280 213 012	
		0 986 280 110	
Knock sensor	08.89-07.90	0 261 231 006	
Temperature sensor, coolant, injection system	08.89-07.90	0 280 130 032	
Wheel speed sensor, front			
Fg.no. →176799	08.89-07.90 KOB	0 265 001 184	
Fg.no. →294099	08.89-07.90 LIM	0 265 001 184	
Fg.no. 176800→	08.89-07.90 KOB	0 265 001 231	
Fg.no. 294100→	08.89-07.90 LIM	0 265 001 231	



Product			
2.3 2,3l 80-86 kW B230K 4 Zyl.			
Knock sensor	08.84-07.90		0 261 231 006
Wheel speed sensor, front	08.84-08.87		0 265 001 064
Fg.no. →176799	08.87-07.90	KOB	0 265 001 184
Fg.no. →294099	08.87-07.90	LIM	0 265 001 184
Fg.no. 176800→	08.87-07.90	KOB	0 265 001 231
Fg.no. 294100→	08.87-07.90	LIM	0 265 001 231
Wheel speed sensor, rear	08.84-07.87		0 265 001 065
	08.87-07.88		0 265 001 185
2.3 2,3l 82 kW B230A 4 Zyl.			
Knock sensor	08.84-07.87		0 261 231 006
Wheel speed sensor, front	08.84-07.87		0 265 001 064
Wheel speed sensor, rear	08.84-07.87		0 265 001 065
2.3i 2,3l 85 kW B230F Kat. 4 Zyl.			
Throttle valve sensor	08.84-07.88		0 280 120 301
	08.88-07.89		0 280 120 325
	08.88-07.95		0 280 120 325
Air mass meter, gasoline injection	08.84-07.88		0 280 212 007
			0 986 280 102
	08.88-07.89		0 280 212 016
			0 986 280 101
	08.88-07.95		0 280 212 016
	08.88-07.89		0 280 212 016
			0 986 280 101
Knock sensor	08.84-07.95		0 261 231 006
Temperature sensor, coolant, injection system	08.84-07.88		0 280 130 026
	08.88-07.95		0 280 130 032
Wheel speed sensor, front	08.84-08.87		0 265 001 064
Fg.no. →176799	08.87-07.95	KOB	0 265 001 184
Fg.no. →294099	08.87-07.95	LIM	0 265 001 184
Fg.no. 176800→	08.87-07.95	KOB	0 265 001 231
Fg.no. 294100→	08.87-07.95	LIM	0 265 001 231
Wheel speed sensor, rear	08.84-07.87		0 265 001 065
	08.87-07.88		0 265 001 185
2.3i 2,3l 94 kW B230G 4 Zyl.			
Air mass meter, gasoline injection	08.91-07.95		0 280 212 021
			0 986 280 107
Knock sensor	08.91-07.95		0 261 231 006
Temperature sensor, coolant, injection system	08.91-07.95		0 280 130 032
Wheel speed sensor, front			
Fg.no. →176799	08.91-07.95	KOB	0 265 001 184
Fg.no. →294099	08.91-07.95	LIM	0 265 001 184
Fg.no. 176800→	08.91-07.95	KOB	0 265 001 231
Fg.no. 294100→	08.91-07.95	LIM	0 265 001 231
2.3i 2,3l 96 kW B 230 FB Kat. 4 Zyl.			
Knock sensor	08.90-07.95		0 261 231 006
Wheel speed sensor, front			
Fg.no. →176799	08.90-07.95	KOB	0 265 001 184
Fg.no. →294099	08.90-07.95	LIM	0 265 001 184
Fg.no. 176800→	08.90-07.95	KOB	0 265 001 231
Fg.no. 294100→	08.90-07.95	LIM	0 265 001 231
2.3i 2,3l 96 kW B230E 4 Zyl.			
Air flow sensor, gasoline injection	08.84-07.91		0 438 120 203
Knock sensor	08.84-07.91		0 261 231 006
Wheel speed sensor, front	08.84-08.87		0 265 001 064
Fg.no. →176799	08.87-07.91	KOB	0 265 001 184
Fg.no. →294099	08.87-07.91	LIM	0 265 001 184
Fg.no. 176800→	08.87-07.91	KOB	0 265 001 231
Fg.no. 294100→	08.87-07.91	LIM	0 265 001 231
Wheel speed sensor, rear	08.84-07.87		0 265 001 065
	08.87-07.88		0 265 001 185



Product			
2.3i 2,3l 96 kW B230F Kat. 4 Zyl.			
Throttle valve sensor	08.90-07.92		0 280 120 325
Air mass meter, gasoline injection	08.90-07.92		0 280 212 016
			0 986 280 101
Knock sensor	08.90-07.92		0 261 231 006
Temperature sensor, coolant, injection system	08.90-07.92		0 280 130 032
Wheel speed sensor, front			
Fg.no. →176799	08.90-07.92	KOB	0 265 001 184
Fg.no. →294099	08.90-07.92	LIM	0 265 001 184
Fg.no. 176800→	08.90-07.92	KOB	0 265 001 231
Fg.no. 294100→	08.90-07.92	LIM	0 265 001 231
2.3iT 2,3l 114-119 kW B230FT Kat. 4 Zyl.			
Throttle valve sensor	08.84-04.87		0 280 120 301
	05.87-07.91		0 280 120 325
Air mass meter, gasoline injection	08.84-07.91		0 280 212 007
			0 986 280 102
	08.89-07.91		0 280 212 016
			0 986 280 101
Knock sensor	08.84-07.91		0 261 231 006
Temperature sensor, coolant, injection system	08.84-07.91		0 280 130 032
Wheel speed sensor, front	08.84-08.87		0 265 001 064
Fg.no. →176799	08.87-07.91	KOB	0 265 001 184
Fg.no. →294099	08.87-07.91	LIM	0 265 001 184
Fg.no. 176800→	08.87-07.91	KOB	0 265 001 231
Fg.no. 294100→	08.87-07.91	LIM	0 265 001 231
Wheel speed sensor, rear	08.84-07.87		0 265 001 065
	08.87-07.88		0 265 001 185
2.3iT 2,3l 120 kW B230GT 4 Zyl.			
Throttle valve sensor	08.89-07.90		0 280 120 325
Air mass meter, gasoline injection	08.89-07.90		0 280 212 016
			0 986 280 101
Knock sensor	08.89-07.90		0 261 231 006
Temperature sensor, coolant, injection system	08.89-07.90		0 280 130 032
Wheel speed sensor, front			
Fg.no. →176799	08.89-07.90	KOB	0 265 001 184
Fg.no. →294099	08.89-07.90	LIM	0 265 001 184
Fg.no. 176800→	08.89-07.90	KOB	0 265 001 231
Fg.no. 294100→	08.89-07.90	LIM	0 265 001 231
2.3iT 2,3l 130 kW B230ET 4 Zyl.			
Throttle valve sensor	08.84-04.87		0 280 120 301
	05.87-07.89		0 280 120 325
Air flow sensor, gasoline injection	08.84-07.89		0 280 202 035
			0 986 280 045
Speed sensor, ignition/injection	08.84-07.89		0 261 210 003
Knock sensor	08.84-07.89		0 261 231 006
Temperature sensor, coolant, injection system	08.84-07.89		0 280 130 032
Wheel speed sensor, front	08.84-08.87		0 265 001 064
Fg.no. →176799	08.87-07.89	KOB	0 265 001 184
Fg.no. →294099	08.87-07.89	LIM	0 265 001 184
Fg.no. 176800→	08.87-07.89	KOB	0 265 001 231
Fg.no. 294100→	08.87-07.89	LIM	0 265 001 231
Wheel speed sensor, rear	08.84-07.87		0 265 001 065
	08.87-07.88		0 265 001 185
2.3i 16V 2,3l 111-117 kW B234F Kat. 4 Zyl.			
Throttle valve sensor	04.88-07.90		0 280 120 325
Air mass meter, gasoline injection	08.88-07.90		0 280 212 016
			0 986 280 101
	04.88-07.88		0 280 213 010
			0 986 280 138
Knock sensor	04.88-07.90		0 261 231 006
Temperature sensor, coolant, injection system	04.88-07.90		0 280 130 032

Product				

◀ 740


Wheel speed sensor, front			
Fg.no. →176799	04.88-07.90	KOB	0 265 001 184
Fg.no. →294099	04.88-07.90	LIM	0 265 001 184
Fg.no. 176800→	04.88-07.90	KOB	0 265 001 231
Fg.no. 294100→	04.88-07.90	LIM	0 265 001 231
Wheel speed sensor, rear	04.88-07.88		0 265 001 185
2.3i16V	2,3l 114 kW B234G 4 Zyl.		
Throttle valve sensor	08.90-07.92		0 280 120 325
Air mass meter, gasoline injection	08.90-07.92		0 280 212 021
			0 986 280 107
Knock sensor	08.90-07.92		0 261 231 006
Temperature sensor, coolant, injection system	08.90-07.92		0 280 130 032
Wheel speed sensor, front			
Fg.no. →176799	08.90-07.92	KOB	0 265 001 184
Fg.no. →294099	08.90-07.92	LIM	0 265 001 184
Fg.no. 176800→	08.90-07.92	KOB	0 265 001 231
Fg.no. 294100→	08.90-07.92	LIM	0 265 001 231
2.4 D	2,4l 60 kW D24 6 Zyl.		
Wheel speed sensor, front	04.84-08.87		0 265 001 064
Fg.no. →176799	08.87-07.92	KOB	0 265 001 184
Fg.no. →294099	08.87-07.92	LIM	0 265 001 184
Fg.no. 176800→	08.87-07.92	KOB	0 265 001 231
Fg.no. 294100→	08.87-07.92	LIM	0 265 001 231
Wheel speed sensor, rear	04.84-07.87		0 265 001 065
	08.87-07.88		0 265 001 185
2.4 TD	2,4l 80 kW D24T 6 Zyl.		
Wheel speed sensor, front	04.85-08.87		0 265 001 064
Fg.no. →176799	08.87-07.92	KOB	0 265 001 184
Fg.no. →294099	08.87-07.92	LIM	0 265 001 184
Fg.no. 176800→	08.87-07.92	KOB	0 265 001 231
Fg.no. 294100→	08.87-07.92	LIM	0 265 001 231
Wheel speed sensor, rear	04.85-07.87		0 265 001 065
	08.87-07.88		0 265 001 185
2.4 TD	2,4l 85 kW D24TIC 6 Zyl.		
Wheel speed sensor, front			
Fg.no. →176799	08.87-07.92	KOB	0 265 001 184
Fg.no. →294099	08.87-07.92	LIM	0 265 001 184
Fg.no. 176800→	08.87-07.92	KOB	0 265 001 231
Fg.no. 294100→	08.87-07.92	LIM	0 265 001 231
Wheel speed sensor, rear	08.87-07.88		0 265 001 185

760

2.0iT	2,0l 120 kW B200ET 4 Zyl.		
Throttle valve sensor	08.84-04.87		0 280 120 301
	05.87-07.89		0 280 120 325
Air flow sensor, gasoline injection	08.84-07.89		0 280 202 067
Speed sensor, ignition/injection	08.84-07.89		0 261 210 003
Temperature sensor, coolant, injection system	08.84-07.89		0 280 130 032
Wheel speed sensor, front	08.84-07.87		0 265 001 064
Fg.no. →176799	08.87-07.89	KOB	0 265 001 184
Fg.no. →294099	08.87-07.89	LIM	0 265 001 184
Fg.no. 176800→	08.87-07.89	KOB	0 265 001 231
Fg.no. 294100→	08.87-07.89	LIM	0 265 001 231
Wheel speed sensor, rear	08.84-07.87		0 265 001 065
	08.87-07.89		0 265 001 185
2.3iT	2,3l 114-119 kW B230FT Kat. 4 Zyl.		
Throttle valve sensor	08.84-04.87		0 280 120 301
	05.87-07.92		0 280 120 325
Air mass meter, gasoline injection	08.84-07.89		0 280 212 007
			0 986 280 102
	08.89-07.92		0 280 212 016
			0 986 280 101

Product				

Knock sensor	08.84-03.86		0 261 231 001
	04.86-07.90		0 261 231 006
	08.90-07.92		0 261 231 046
Temperature sensor, coolant, injection system	08.84-07.92		0 280 130 032
Wheel speed sensor, front	08.84-07.87		0 265 001 064
Fg.no. →176799	08.87-07.92	KOB	0 265 001 184
Fg.no. →294099	08.87-07.92	LIM	0 265 001 184
Fg.no. 176800→	08.87-07.92	KOB	0 265 001 231
Fg.no. 294100→	08.87-07.92	LIM	0 265 001 231
Wheel speed sensor, rear	08.84-07.87		0 265 001 065
	08.87-07.92		0 265 001 185
2.3iT	2,3l 120 kW B230GT 4 Zyl.		
Throttle valve sensor	08.89-07.90		0 280 120 325
Air mass meter, gasoline injection	08.89-07.90		0 280 212 016
			0 986 280 101
Knock sensor	08.89-07.90		0 261 231 006
Temperature sensor, coolant, injection system	08.89-07.90		0 280 130 032
Wheel speed sensor, front			
Fg.no. →176799	08.89-07.90	KOB	0 265 001 184
Fg.no. →294099	08.89-07.90	LIM	0 265 001 184
Fg.no. 176800→	08.89-07.90	KOB	0 265 001 231
Fg.no. 294100→	08.89-07.90	LIM	0 265 001 231
Wheel speed sensor, rear	08.89-07.90		0 265 001 185
2.3iT	2,3l 134 kW B230ET 4 Zyl.		
Throttle valve sensor	08.84-04.87		0 280 120 301
	05.87-07.89		0 280 120 325
Air flow sensor, gasoline injection	08.84-07.89		0 280 202 035
			0 986 280 045
Speed sensor, ignition/injection	08.84-07.89		0 261 210 003
Temperature sensor, coolant, injection system	08.84-07.89		0 280 130 032
Wheel speed sensor, front	08.84-07.87		0 265 001 064
Fg.no. →176799	08.87-07.89	KOB	0 265 001 184
Fg.no. →294099	08.87-07.89	LIM	0 265 001 184
Fg.no. 176800→	08.87-07.89	KOB	0 265 001 231
Fg.no. 294100→	08.87-07.89	LIM	0 265 001 231
Wheel speed sensor, rear	08.84-07.87		0 265 001 065
	08.87-07.89		0 265 001 185
2.4 D	2,4l 60 kW D24 6 Zyl.		
Wheel speed sensor, front	08.83-07.87		0 265 001 064
Wheel speed sensor, rear	08.83-07.87		0 265 001 065
2.4 TD	2,4l 79/80 kW D24T 6 Zyl.		
Wheel speed sensor, front	08.83-07.87		0 265 001 064
Wheel speed sensor, rear	08.83-07.87		0 265 001 065
2.4 TD	2,4l 85 kW D24TIC 6 Zyl.		
Wheel speed sensor, front			
Fg.no. →176799	08.87-07.92	KOB	0 265 001 184
Fg.no. →294099	08.87-07.92	LIM	0 265 001 184
Fg.no. 176800→	08.87-07.92	KOB	0 265 001 231
Fg.no. 294100→	08.87-07.92	LIM	0 265 001 231
Wheel speed sensor, rear	08.87-07.92		0 265 001 185
2.8	2,8l 95-96 kW B28A 6 Zyl.		
Wheel speed sensor, front	08.83-07.86		0 265 001 064
Wheel speed sensor, rear	08.83-07.86		0 265 001 065
2.8i	2,8l 100 kW B28F Kat. 6 Zyl.		
Air flow sensor, gasoline injection	08.82-04.86		0 438 120 132
Temperature sensor, coolant, injection system	08.82-04.86		0 280 130 028
Wheel speed sensor, front	08.83-04.86		0 265 001 064
Wheel speed sensor, rear	08.83-04.86		0 265 001 065
2.8i	2,8l 105/108-125 kW B280E; B280F Kat. 6 Zyl.		
Throttle valve sensor	05.86-04.87		0 280 120 301
	05.87-07.91		0 280 120 325
Air mass meter, gasoline injection	05.86-07.91		0 280 213 006
			0 986 280 115



Speed sensor, ignition/injection	05.86-07.91	0 261 210 029
Knock sensor	05.86-07.91	0 261 231 007
Temperature sensor, coolant, injection system	05.86-07.91	0 280 130 032
Wheel speed sensor, front	05.86-07.87	0 265 001 064
Fg.no. →176799	08.87-07.91 KOB	0 265 001 184
Fg.no. →294099	08.87-07.91 LIM	0 265 001 184
Fg.no. 176800→	08.87-07.91 KOB	0 265 001 231
Fg.no. 294100→	08.87-07.91 LIM	0 265 001 231
Wheel speed sensor, rear	05.86-07.87	0 265 001 065
	08.87-07.91	0 265 001 185

2.8i	2,8l 115 kW B28E 6 Zyl.
Air flow sensor, gasoline injection	02.82-04.86 0 438 120 065
Temperature sensor, coolant, injection system	08.83-04.86 0 280 130 028
Wheel speed sensor, front	08.83-04.86 0 265 001 064
Wheel speed sensor, rear	08.83-04.86 0 265 001 065

780

2.0iT	2,0l 120 kW B200ET 4 Zyl.
Throttle valve sensor	01.86-07.87 0 280 120 301
	08.87-07.89 0 280 120 325
Air flow sensor, gasoline injection	01.86-07.89 0 280 202 067
Speed sensor, ignition/injection	01.86-07.89 0 261 210 003
Temperature sensor, coolant, injection system	01.86-07.89 0 280 130 032
Wheel speed sensor, front	01.86-07.87 0 265 001 064
Fg.no. →6499	08.87-07.89 0 265 001 184
Fg.no. 6500→	08.87-07.89 0 265 001 231
Wheel speed sensor, rear	01.86-07.87 0 265 001 065
2.0i16VT	2,0l 136 kW B204GT 4 Zyl.
Throttle valve sensor	08.89-07.90 0 280 120 400
Air mass meter, gasoline injection	08.89-07.90 0 280 213 012

	0 986 280 110
Knock sensor	08.89-07.90 0 261 231 006
Temperature sensor, coolant, injection system	08.89-07.90 0 280 130 032
Wheel speed sensor, front	
Fg.no. →6499	08.89-07.90 0 265 001 184
Fg.no. 6500→	08.89-07.90 0 265 001 231

2.4TD	2,4l 85 kW D24TIC 6 Zyl.
Wheel speed sensor, front	08.85-07.87 0 265 001 064
Fg.no. →6499	08.87-07.91 0 265 001 184
Fg.no. 6500→	08.87-07.91 0 265 001 231
Wheel speed sensor, rear	08.85-07.87 0 265 001 065
	08.87-07.88 0 265 001 186

2.8i	2,8l 108-125 kW B280E; B280F Kat. 6 Zyl.
Throttle valve sensor	05.86-07.87 0 280 120 301
	08.87-07.91 0 280 120 325
Air mass meter, gasoline injection	05.86-07.91 0 280 213 006
	0 986 280 115

Speed sensor, ignition/injection	05.86-07.91 0 261 210 029
Knock sensor	05.86-07.91 0 261 231 007
Temperature sensor, coolant, injection system	05.86-07.91 0 280 130 032
Wheel speed sensor, front	05.86-07.87 0 265 001 064
Fg.no. →6499	08.87-07.91 0 265 001 184
Fg.no. 6500→	08.87-07.91 0 265 001 231
Wheel speed sensor, rear	05.86-07.87 0 265 001 065
	08.87-07.88 0 265 001 186

850

R	2,3l 184 kW B5234T4 Kat. 5 Zyl.
Throttle valve sensor	08.95-07.97 0 280 122 001
Air mass meter, gasoline injection	08.95-07.97 0 280 217 107
Phase sensor	08.95-07.97 NOC 0 232 101 030



Knock sensor	08.95-08.96 0 261 231 046
	09.96-07.97 0 261 231 121

TDI	2,5l 103 kW D5252T 5 Zyl.
Air flow sensor, diesel	05.96-07.97 0 281 002 155

T-5	2,0l 155 kW B5204FT Kat. 5 Zyl.
Throttle valve sensor	01.94-07.96 0 280 122 001

Air mass meter, gasoline injection	01.94-07.96 0 280 217 107
Phase sensor	01.94-07.96 NOC 0 232 101 030
Knock sensor	01.94-07.96 0 261 231 046

T-5	2,3l 166 kW B5234FT Kat. 5 Zyl.
Throttle valve sensor	09.93-07.96 0 280 122 001

Air mass meter, gasoline injection	09.93-07.96 0 280 217 107
Phase sensor	09.93-07.96 NOC 0 232 101 030
Knock sensor	09.93-07.96 0 261 231 046

T-5R	2,3l 177 kW B5234T Kat. 5 Zyl.
Throttle valve sensor	09.94-07.97 0 280 122 001

Air mass meter, gasoline injection	09.94-07.97 0 280 217 107
Phase sensor	09.94-07.97 NOC 0 232 101 030
Knock sensor	09.94-08.96 0 261 231 046

	09.96-07.97 0 261 231 121
2.0	2,0l 93 kW B5202S Kat. 5 Zyl.

Throttle valve sensor	09.94-12.96 0 280 122 001
Phase sensor	09.94-12.96 NOC 0 232 101 030
Knock sensor	09.96-12.96 0 261 231 121

2.0	2,0l 105 kW B5204S Kat. 5 Zyl.
Throttle valve sensor	09.91-12.96 0 280 122 001

Air mass meter, gasoline injection	08.96-12.96 0 280 217 107
Phase sensor	09.91-12.96 NOC 0 232 101 030
Knock sensor	09.91-08.96 0 261 231 046

	09.96-12.96 0 261 231 121
2.0 GLT	2,0l 129-132 kW B5204T2 Kat. 5 Zyl.

Throttle valve sensor	01.96-07.97 0 280 122 001
Air mass meter, gasoline injection	01.96-07.97 0 280 217 107
Phase sensor	01.96-07.97 NOC 0 232 101 030

Knock sensor	01.96-08.96 0 261 231 046
	09.96-07.97 0 261 231 121

2.0 Turbo	2,0l 155 kW B5204T Kat. 5 Zyl.
Throttle valve sensor	01.95-07.97 0 280 122 001

Air mass meter, gasoline injection	01.95-07.97 0 280 217 107
Phase sensor	01.95-07.97 NOC 0 232 101 030
Knock sensor	01.95-08.96 0 261 231 046

	09.96-07.97 0 261 231 121
2.3	2,3l 120 kW B5234S Kat. 5 Zyl.

Throttle valve sensor	09.97-07.98 0 280 122 001
Air mass meter, gasoline injection	09.97-07.98 0 280 217 107
Phase sensor	09.97-07.98 NOC 0 232 101 030

Knock sensor	09.97-07.98 0 261 231 121
Pressure sensor, intake manifold, gasoline	09.97-07.98 0 261 230 018

2.5 AWD	2,4l 140 kW B5254T Kat. 5 Zyl.
Throttle valve sensor	09.96-07.97 0 280 122 001

Air mass meter, gasoline injection	09.96-07.97 0 280 217 107
Phase sensor	09.96-07.97 NOC 0 232 101 030
Knock sensor	09.96-07.97 0 261 231 121

Pressure sensor, intake manifold, gasoline	09.96-07.97 0 261 230 018
2.5 GLE	2,5l 103-106 kW B5252S Kat. 5 Zyl.

Throttle valve sensor	09.92-07.97 0 280 122 001
Phase sensor	09.92-07.97 NOC 0 232 101 030
Knock sensor	09.96-07.97 0 261 231 121

2.5 GLT	2,4l 125 kW B5254S Kat. 5 Zyl.
Throttle valve sensor	09.93-07.97 0 280 122 001

Air mass meter, gasoline injection	08.96-07.97 0 280 217 107
Phase sensor	09.93-07.97 NOC 0 232 101 030

Product



◀ 850

Knock sensor	09.93-08.96	0 261 231 046
	09.96-07.97	0 261 231 121
Pressure sensor, intake manifold, gasoline	09.93-07.97	0 261 230 006
2.5 GLT	2,5l 125 kW B5254S Kat. 5 Zyl.	
Throttle valve sensor	09.91-07.97	0 280 122 001
Air mass meter, gasoline injection	08.96-07.97	0 280 217 107
Phase sensor	09.91-07.97 NOC	0 232 101 030
Knock sensor	09.91-08.96	0 261 231 046
	09.96-07.97	0 261 231 121
Pressure sensor, intake manifold, gasoline	09.95-07.97	0 261 230 006
2.5 Turbo	2,4l 140 kW B5254T Kat. 5 Zyl.	
Throttle valve sensor	09.96-07.97	0 280 122 001
Air mass meter, gasoline injection	09.96-07.97	0 280 217 107
Phase sensor	09.96-07.97 NOC	0 232 101 030
Knock sensor	09.96-07.97	0 261 231 121
Pressure sensor, intake manifold, gasoline	09.96-07.97	0 261 230 018
2.5 Turbo	2,5l 140-142 kW B5254T Kat. 5 Zyl.	
Throttle valve sensor	09.96-07.97	0 280 122 001
Air mass meter, gasoline injection	09.96-07.97	0 280 217 107
Phase sensor	09.96-07.97 NOC	0 232 101 030
Knock sensor	09.96-07.97	0 261 231 121
Pressure sensor, intake manifold, gasoline	09.96-07.97	0 261 230 018



850 Kombi

R	2,3l 184 kW B5234T4 Kat. 5 Zyl.	
Throttle valve sensor	08.95-07.97	0 280 122 001
Air mass meter, gasoline injection	08.95-07.97	0 280 217 107
Phase sensor	08.95-07.97 NOC	0 232 101 030
Knock sensor	08.95-08.96	0 261 231 046
	09.96-07.97	0 261 231 121
TDI	2,5l 103 kW D5252T 5 Zyl.	
Air flow sensor, diesel	05.96-07.97	0 281 002 155
T-5	2,0l 155 kW B5204FT Kat. 5 Zyl.	
Throttle valve sensor	01.94-07.96	0 280 122 001
Air mass meter, gasoline injection	01.94-07.96	0 280 217 107
Phase sensor	01.94-07.96 NOC	0 232 101 030
Knock sensor	01.94-07.96	0 261 231 046
T-5	2,3l 166 kW B5234FT Kat. 5 Zyl.	
Throttle valve sensor	09.93-07.96	0 280 122 001
Air mass meter, gasoline injection	09.93-07.96	0 280 217 107
Phase sensor	09.93-07.96 NOC	0 232 101 030
Knock sensor	09.93-07.96	0 261 231 046
T-5R	2,3l 177 kW B5234T Kat. 5 Zyl.	
Throttle valve sensor	09.94-07.97	0 280 122 001
Air mass meter, gasoline injection	09.94-07.97	0 280 217 107
Phase sensor	09.94-07.97 NOC	0 232 101 030
Knock sensor	09.94-08.96	0 261 231 046
	09.96-07.97	0 261 231 121
2.0	2,0l 93 kW B5202S Kat. 5 Zyl.	
Throttle valve sensor	09.94-12.96	0 280 122 001
Phase sensor	09.94-12.96 NOC	0 232 101 030
Knock sensor	09.96-12.96	0 261 231 121
2.0	2,0l 105 kW B5204S Kat. 5 Zyl.	
Throttle valve sensor	03.92-12.96	0 280 122 001
Air mass meter, gasoline injection	08.96-12.96	0 280 217 107
Phase sensor	03.92-12.96 NOC	0 232 101 030
Knock sensor	03.92-08.96	0 261 231 046
	09.96-12.96	0 261 231 121
2.0 GLT	2,0l 129-132 kW B5204T2 Kat. 5 Zyl.	
Throttle valve sensor	01.96-07.97	0 280 122 001
Air mass meter, gasoline injection	01.96-07.97	0 280 217 107
Phase sensor	01.96-07.97 NOC	0 232 101 030

Product



Knock sensor	01.96-08.96	0 261 231 046
	09.96-07.97	0 261 231 121
2.0 Turbo	2,0l 155 kW B5204T Kat. 5 Zyl.	
Throttle valve sensor	01.95-07.97	0 280 122 001
Air mass meter, gasoline injection	01.95-07.97	0 280 217 107
Phase sensor	01.95-07.97 NOC	0 232 101 030
Knock sensor	01.95-08.96	0 261 231 046
	09.96-07.97	0 261 231 121
2.3	2,3l 120 kW B5234S Kat. 5 Zyl.	
Throttle valve sensor	09.93-07.96	0 280 122 001
	09.97-07.98	0 280 122 001
Air mass meter, gasoline injection	09.97-07.98	0 280 217 107
Phase sensor	09.93-07.96 NOC	0 232 101 030
	09.97-07.98 NOC	0 232 101 030
Knock sensor	09.93-07.96	0 261 231 046
	09.97-07.98	0 261 231 121
Pressure sensor, intake manifold, gasoline	09.97-07.98	0 261 230 018
2.5 AWD	2,5l 140 kW B5254T Kat. 5 Zyl.	
Throttle valve sensor	09.96-07.97	0 280 122 001
Air mass meter, gasoline injection	09.96-07.97	0 280 217 107
Phase sensor	09.96-07.97 NOC	0 232 101 030
Knock sensor	09.96-07.97	0 261 231 121
Pressure sensor, intake manifold, gasoline	09.96-07.97	0 261 230 018
2.5 GLE	2,5l 103-106 kW B5252S Kat. 5 Zyl.	
Throttle valve sensor	09.92-07.97	0 280 122 001
Phase sensor	09.92-07.97 NOC	0 232 101 030
Knock sensor	09.96-07.97	0 261 231 121
2.5 GLT	2,4l 125 kW B5254S Kat. 5 Zyl.	
Throttle valve sensor	09.93-07.97	0 280 122 001
Air mass meter, gasoline injection	08.96-07.97	0 280 217 107
Phase sensor	09.93-07.97 NOC	0 232 101 030
Knock sensor	09.93-08.96	0 261 231 046
	09.96-07.97	0 261 231 121
Pressure sensor, intake manifold, gasoline	09.93-07.97	0 261 230 006
2.5 GLT	2,5l 125 kW B5254S Kat. 5 Zyl.	
Throttle valve sensor	09.91-07.97	0 280 122 001
Air mass meter, gasoline injection	08.96-07.97	0 280 217 107
Phase sensor	09.91-07.97 NOC	0 232 101 030
Knock sensor	09.91-08.96	0 261 231 046
	09.96-07.97	0 261 231 121
Pressure sensor, intake manifold, gasoline	09.95-07.97	0 261 230 006
2.5 Turbo	2,5l 140-142 kW B5254T Kat. 5 Zyl.	
Throttle valve sensor	09.96-07.97	0 280 122 001
Air mass meter, gasoline injection	09.96-07.97	0 280 217 107
Phase sensor	09.96-07.97 NOC	0 232 101 030
Knock sensor	09.96-07.97	0 261 231 121
Pressure sensor, intake manifold, gasoline	09.96-07.97	0 261 230 018

940

2.0	2,0l 80-89 kW B200G 4 Zyl.	
Throttle valve sensor	09.91-07.95	0 280 120 325
Air mass meter, gasoline injection	09.91-07.95	0 280 212 021
		🔧 0 986 280 107
Knock sensor	09.91-07.95	0 261 231 046
Temperature sensor, coolant, injection system	09.91-07.95	0 280 130 032
Wheel speed sensor, front	09.91-07.95	0 265 001 231
2.0	2,0l 82 kW B200F Kat. 4 Zyl.	
Throttle valve sensor	01.92-07.95	0 280 120 325
Air mass meter, gasoline injection	01.92-07.95	0 280 212 016
		🔧 0 986 280 101
Knock sensor	01.92-07.95	0 261 231 046




Temperature sensor, coolant, injection system	01.92-07.95	0 280 130 032
Wheel speed sensor, front	01.92-07.95	0 265 001 231
2.0	2,0l 88 kW B200E 4 Zyl.	
Air flow sensor, gasoline injection	09.90-07.91	0 438 120 076
Knock sensor	09.90-07.91	0 261 231 046
Wheel speed sensor, front	09.90-07.91	0 265 001 231
2.0 Turbo	2,0l 114 kW B200GT. 4 Zyl.	
Throttle valve sensor	04.96-09.98	0 280 120 325
Air mass meter, gasoline injection	04.96-09.98	0 280 212 016
		0 986 280 101
Knock sensor	04.96-09.98	0 261 231 046
Temperature sensor, coolant, injection system	04.96-09.98	0 280 130 032
Wheel speed sensor, front	04.96-09.98	0 265 001 231
2.0 Turbo Interc.	2,0l 114 kW B200FT Kat. 4 Zyl.	
Throttle valve sensor	09.91-07.97	0 280 120 325
Air mass meter, gasoline injection	09.91-07.97	0 280 212 016
		0 986 280 101
Knock sensor	09.91-07.97	0 261 231 046
Temperature sensor, coolant, injection system	09.91-07.97	0 280 130 032
Wheel speed sensor, front	09.91-07.97	0 265 001 231
2.0 16V	2,0l 100-103 kW B204E 4 Zyl.	
Throttle valve sensor	09.90-07.91	0 280 120 325
Air mass meter, gasoline injection	09.90-07.91	0 280 212 007
		0 986 280 102
Knock sensor	09.90-07.91	0 261 231 046
Temperature sensor, coolant, injection system	09.90-07.91	0 280 130 032
Wheel speed sensor, front	09.90-07.91	0 265 001 231
2.3	2,3l 84 kW B230F Kat.; B230FD Kat. 4 Zyl.	
Throttle valve sensor	09.92-07.95	0 280 120 325
Air mass meter, gasoline injection	09.92-07.95	0 280 212 016
		0 986 280 101
Knock sensor	09.92-07.95	0 261 231 046
Temperature sensor, coolant, injection system	09.92-07.95	0 280 130 032
Wheel speed sensor, front	09.92-07.95	0 265 001 231
2.3	2,3l 96 kW B230G 4 Zyl.	
Throttle valve sensor	09.91-07.95	0 280 120 325
Air mass meter, gasoline injection	09.91-07.95	0 280 212 021
		0 986 280 107
Knock sensor	09.91-07.95	0 261 231 046
Temperature sensor, coolant, injection system	09.91-07.95	0 280 130 032
Wheel speed sensor, front	09.91-07.95	0 265 001 231
2.3	2,3l 96-99 kW B230F Kat. 4 Zyl.	
Throttle valve sensor	06.91-07.95	0 280 120 325
Air mass meter, gasoline injection	06.91-07.95	0 280 212 016
		0 986 280 101
Knock sensor	06.91-07.95	0 261 231 046
Temperature sensor, coolant, injection system	06.91-07.95	0 280 130 032
Wheel speed sensor, front	06.91-07.95	0 265 001 231
2.3 Turbo	2,3l 99 kW B230FK Kat. 4 Zyl.	
Air mass meter, gasoline injection	09.94-07.98	0 280 212 016
		0 986 280 101
Knock sensor	09.94-07.98	0 261 231 046
Temperature sensor, coolant, injection system	09.94-07.98	0 280 130 032
Wheel speed sensor, front	09.94-07.98	0 265 001 231
2.3 Turbo Interc.	2,3l 104 kW B230GK 4 Zyl.	
Throttle valve sensor	09.91-07.97	0 280 120 325
Air mass meter, gasoline injection	09.91-07.97	0 280 212 021
		0 986 280 107
Knock sensor	09.91-07.97	0 261 231 046
Temperature sensor, coolant, injection system	09.91-07.97	0 280 130 032
Wheel speed sensor, front	09.91-07.97	0 265 001 231



2.3 Turbo Interc.	2,3l 113-121 kW B230FT Kat.; B230FT4 4 Zyl.	
Throttle valve sensor	09.90-10.98	0 280 120 325
Air mass meter, gasoline injection	09.90-10.98	0 280 212 016
		0 986 280 101
Knock sensor	09.90-10.98	0 261 231 046
Temperature sensor, coolant, injection system	09.90-10.98	0 280 130 032
Wheel speed sensor, front	09.90-10.98	0 265 001 231
2.3 16V	2,3l 114 kW B234F Kat. 4 Zyl.	
Throttle valve sensor	09.90-07.92	0 280 120 325
Air mass meter, gasoline injection	09.90-07.92	0 280 212 016
		0 986 280 101
Knock sensor	09.90-07.92	0 261 231 046
Temperature sensor, coolant, injection system	09.90-07.92	0 280 130 032
Wheel speed sensor, front	09.90-07.92	0 265 001 231
2.3 16V	2,3l 114 kW B234G 4 Zyl.	
Throttle valve sensor	09.90-07.92	0 280 120 325
Air mass meter, gasoline injection	09.90-07.92	0 280 212 021
		0 986 280 107
Knock sensor	09.90-07.92	0 261 231 046
Temperature sensor, coolant, injection system	09.90-07.92	0 280 130 032
Wheel speed sensor, front	09.90-07.92	0 265 001 231
2.4 D	2,4l 60 kW D24 4 Zyl.	
Wheel speed sensor, front	09.90-07.93	0 265 001 231
2.4 TD	2,4l 80/90 kW D24T; D24TIC 6 Zyl.	
Wheel speed sensor, front	09.90-07.97	0 265 001 231

960

2.0 T	2,0l 103 kW B204E 4 Zyl.	
Throttle valve sensor	09.91-07.94	0 280 120 325
Air mass meter, gasoline injection	09.91-07.94	0 280 212 016
		0 986 280 101
Knock sensor	09.91-07.94	0 261 231 046
Temperature sensor, coolant, injection system	09.91-07.94	0 280 130 032
Wheel speed sensor, front	09.91-07.94	0 265 001 231
Wheel speed sensor, rear	09.91-07.94	0 265 001 187
2.0 T 16V	2,0l 140 kW B204FT Kat. 4 Zyl.	
Throttle valve sensor	09.91-07.94	0 280 120 400
Air mass meter, gasoline injection	09.91-07.94	0 280 213 012
		0 986 280 110
Knock sensor	09.91-07.94	0 261 231 046
Temperature sensor, coolant, injection system	09.91-07.94	0 280 130 032
Wheel speed sensor, front	09.91-07.94	0 265 001 231
Wheel speed sensor, rear	09.91-07.94	0 265 001 187
2.3 T	2,3l 121 kW B230FT Kat. 4 Zyl.	
Throttle valve sensor	03.93-07.93	0 280 120 325
Air mass meter, gasoline injection	03.93-07.93	0 280 212 016
		0 986 280 101
Knock sensor	03.93-07.93	0 261 231 046
Temperature sensor, coolant, injection system	03.93-07.93	0 280 130 032
Wheel speed sensor, front	03.93-07.93	0 265 001 231
Wheel speed sensor, rear	03.93-07.93	0 265 001 187
2.3 T	2,3l 125 kW B230GK 4 Zyl.	
Throttle valve sensor	09.91-07.97	0 280 120 325
Air mass meter, gasoline injection	09.91-07.97	0 280 212 021
		0 986 280 107
Knock sensor	09.91-07.97	0 261 231 046
Temperature sensor, coolant, injection system	09.91-07.97	0 280 130 032
Wheel speed sensor, front	09.91-08.94	0 265 001 231
	09.94-07.97	0 265 001 380
Wheel speed sensor, rear	09.91-07.97	0 265 001 187





Product

◀ 960

2.4	2,4l 120 kW B6244S Kat. 6 Zyl.
Phase sensor	09.94-07.97 NOC 0 232 101 030
Wheel speed sensor, front	09.94-07.97 0 265 001 380
Wheel speed sensor, rear	09.94-07.97 0 265 001 187
2.4TD	2,4l 85 kW D24TIC 6 Zyl.
Wheel speed sensor, front	08.90-08.94 0 265 001 231
	09.94-07.97 0 265 001 380
Wheel speed sensor, rear	08.90-07.97 0 265 001 187
2.5	2,5l 125 kW B6254S 6 Zyl.
Throttle valve sensor	09.94-07.97 0 280 122 001
Air mass meter, gasoline injection	09.94-08.95 0 280 213 026
	09.95-07.97 0 280 217 511
Phase sensor	09.94-07.97 NOC 0 232 101 030
Knock sensor	09.94-07.97 0 261 231 046
Wheel speed sensor, front	09.94-07.97 0 265 001 380
Wheel speed sensor, rear	09.94-07.97 0 265 001 187
2.5	2,5l 125 kW B6254S Kat. 6 Zyl.
Throttle valve sensor	09.94-07.97 0 280 122 001
Air mass meter, gasoline injection	09.95-07.97 0 280 213 025
	09.94-08.95 0 280 213 025
	09.95-07.97 0 280 217 511
Phase sensor	09.94-07.97 NOC 0 232 101 030
Knock sensor	09.94-07.97 0 261 231 046
Wheel speed sensor, front	09.94-07.97 0 265 001 380
Wheel speed sensor, rear	09.94-07.97 0 265 001 187
2.8	2,8l 110/125 kW B280E; B280F Kat. 6 Zyl.
Throttle valve sensor	09.90-07.91 0 280 120 325
Air mass meter, gasoline injection	09.90-07.91 0 280 213 006
	0 986 280 115
Speed sensor, ignition/injection	09.90-07.91 0 261 210 029
Knock sensor	09.90-07.91 0 261 231 007
Temperature sensor, coolant, injection system	09.90-07.91 0 280 130 032
Wheel speed sensor, front	09.90-07.91 0 265 001 231
Wheel speed sensor, rear	09.90-07.91 0 265 001 187
3.0	3,0l 150 kW B6304FS Kat. 6 Zyl.
Throttle valve sensor	09.90-07.98 0 280 122 001
Air mass meter, gasoline injection	09.94-08.95 0 280 213 002
	0 986 280 118
	09.90-08.94 0 280 213 012
	0 986 280 110
	09.95-07.98 0 280 217 511
Phase sensor	09.90-07.98 NOC 0 232 101 030
Knock sensor	09.90-07.98 0 261 231 046
Wheel speed sensor, front	09.90-08.94 0 265 001 231
	09.94-07.97 0 265 001 380
Wheel speed sensor, rear	09.90-07.97 0 265 001 187
3.0	3,0l 150 kW B6304GS 6 Zyl.
Throttle valve sensor	09.91-07.97 0 280 122 001
Air mass meter, gasoline injection	09.91-08.94 0 280 213 020
	0 986 280 132
	09.94-08.95 0 280 213 026
	09.95-07.97 0 280 217 511
Phase sensor	09.91-07.97 NOC 0 232 101 030
Knock sensor	09.91-07.97 0 261 231 046
Wheel speed sensor, front	09.91-08.94 0 265 001 231
	09.94-07.97 0 265 001 380
Wheel speed sensor, rear	09.91-07.97 0 265 001 187
3.0	3,0l 150 kW B6304S Kat. 6 Zyl.
Throttle valve sensor	09.94-07.95 0 280 122 001
Air mass meter, gasoline injection	09.94-07.95 0 280 213 025
	0 986 280 114

Product

Phase sensor	09.94-07.95 NOC 0 232 101 030
Knock sensor	09.94-07.95 0 261 231 046
Wheel speed sensor, front	09.94-07.95 0 265 001 380
Wheel speed sensor, rear	09.94-07.95 0 265 001 187

VW (VOLKSWAGEN)

Bora


1.4 [1J2]	1,4l 55 kW AHW 4 Zyl.
Knock sensor	09.98-04.01 0 261 231 045
	05.01-05.05 0 261 231 146
Accelerator pedal module	05.01-05.05 GS, LLE 0 280 752 214
Fg.no. 1J..Y..000 001→	05.99-05.05 AG, RLE 0 280 752 213
	GS, RLE 0 280 752 210
1.4 [1J2]	1,4l 55 kW AKQ 4 Zyl.
Speed sensor, ignition/injection	
Mot.no. 001 001→001 068	09.98-05.00 0 261 210 194
Knock sensor	09.98-05.00 0 261 231 045
Accelerator pedal module	
Fg.no. 1J..Y..000 001→	05.99-05.00 AG, RLE 0 280 752 213
	GS, RLE 0 280 752 210
1.4 [1J2]	1,4l 55 kW APE 4 Zyl.
Knock sensor	01.99-05.00 0 261 231 146
Pressure sensor, intake manifold, gasoline	01.99-05.00 0 261 230 031
Accelerator pedal module	
Fg.no. 1J..Y..000 001→	05.99-05.00 AG, RLE 0 280 752 213
	GS, RLE 0 280 752 210
1.4 [1J2]	1,4l 55 kW AXP 4 Zyl.
Knock sensor	05.00-10.01 0 261 231 146
Pressure sensor, intake manifold, gasoline	05.00-10.01 0 261 230 031
Accelerator pedal module	
	05.00-10.01 AG, RLE 0 280 752 213
	05.01-10.01 GS, LLE 0 280 752 214
	05.00-10.01 GS, RLE 0 280 752 210
1.4 [1J2]	1,4l 55 kW BCA 4 Zyl.
Pressure sensor, intake manifold, gasoline	10.01-05.05 0 261 230 031
Accelerator pedal module	10.01-05.05 AG, RLE 0 280 752 213
	GS, LLE 0 280 752 214
	GS, RLE 0 280 752 210
1.6 [1J2]	1,6l 74 kW AEH; AKL 4 Zyl.
Phase sensor	09.98-05.05 0 232 101 031
Speed sensor, ignition/injection	09.98-05.05 0 261 210 147
Accelerator pedal module	05.01-05.05 GS, LLE 0 280 752 214
Fg.no. 1J..Y..000 001→	05.99-05.05 AG, RLE 0 280 752 213
	GS, RLE 0 280 752 210
1.6 [1J2]	1,6l 74 kW APF 4 Zyl.
Phase sensor	05.99-09.00 0 232 101 031
Speed sensor, ignition/injection	05.99-09.00 0 261 210 199
Accelerator pedal module	05.99-09.00 AG, RLE 0 280 752 213
	GS, RLE 0 280 752 210
1.6 [1J2]	1,6l 75 kW AVU 4 Zyl.
Phase sensor	09.00-05.05 0 232 101 038
Speed sensor, ignition/injection	09.00-05.05 0 261 210 199
Accelerator pedal module	09.00-05.05 AG, RLE 0 280 752 213
	05.01-05.05 GS, LLE 0 280 752 214
	09.00-05.05 GS, RLE 0 280 752 210
1.6 [1J2]	1,6l 75 kW BFQ 4 Zyl.
Speed sensor, ignition/injection	05.02-05.03 0 261 210 199
Knock sensor	05.02-05.03 0 261 231 146
Accelerator pedal module	05.02-05.03 AG, RLE 0 280 752 213
	GS, LLE 0 280 752 214
	GS, RLE 0 280 752 210



1.6 [1J2]	1,6l 77 kW ATN 4 Zyl.
Throttle valve assembly	08.99-05.00 0 280 750 049
Speed sensor, ignition/injection	08.99-05.00 0 261 210 194
Knock sensor	08.99-05.00 0 261 231 045
Accelerator pedal module	08.99-05.00 AG,RLE 0 280 752 213 GS,RLE 0 280 752 210
1.6 [1J2]	1,6l 77 kW AUS 4 Zyl.
Throttle valve assembly	05.00-10.00 0 280 750 049
Knock sensor	05.00-10.00 0 261 231 045
Accelerator pedal module	05.00-10.00 AG,RLE 0 280 752 213 GS,RLE 0 280 752 210
1.6 [1J2]	1,6l 77 kW AZD 4 Zyl.
Throttle valve assembly	09.00-11.01 0 280 750 049
Speed sensor, ignition/injection	09.00-11.01 0 261 210 194
Knock sensor	09.00-11.01 0 261 231 146
Accelerator pedal module	09.00-11.01 AG,RLE 0 280 752 213 05.01-11.01 GS,LLE 0 280 752 214 09.00-11.01 GS,RLE 0 280 752 210
1.6 [1J2]	1,6l 77 kW BCB 4 Zyl.
Speed sensor, ignition/injection	11.01-05.05 0 261 210 213
Knock sensor	11.01-05.05 0 261 231 146
Accelerator pedal module	11.01-05.05 AG,RLE 0 280 752 213 GS,LLE 0 280 752 214 GS,RLE 0 280 752 210
1.6 FSI [1J2]	1,6l 81 kW BAD 4 Zyl.
Throttle valve assembly	08.01-05.05 0 280 750 059
Air mass meter, gasoline injection	08.01-05.05 0 280 218 060 0 986 280 216
Knock sensor	08.01-05.05 0 261 231 146
Pressure sensor, intake manifold, gasoline	08.01-05.05 0 261 230 079
Accelerator pedal module	08.01-05.05 AG,RLE 0 280 752 213 GS,LLE 0 280 752 214 GS,RLE 0 280 752 210
1.6 i	1,6l 78 kW AWB 4 Zyl.
Air mass meter, gasoline injection	06.02-02.07 0 280 218 060 0 986 280 216
Speed sensor, ignition/injection	06.02-02.07 0 261 210 254
1.6 4 Motion [1J2]	1,6l 77 kW AZD 4 Zyl.
Throttle valve assembly	09.00-11.01 0 280 750 049
Speed sensor, ignition/injection	09.00-11.01 0 261 210 194
Knock sensor	09.00-11.01 0 261 231 146
Accelerator pedal module	09.00-11.01 AG,RLE 0 280 752 213 05.01-11.01 GS,LLE 0 280 752 214 09.00-11.01 GS,RLE 0 280 752 210
1.8 [1J2]	1,8l 92 kW AGN 4 Zyl.
Air mass meter, gasoline injection	09.98-10.00 0 280 218 002 0 986 280 205
Phase sensor	09.98-10.00 0 232 101 024
Speed sensor, ignition/injection	09.98-10.00 0 261 210 147
Accelerator pedal module	Fg.no. 1J..Y..000 001→ 05.99-10.00 AG,RLE 0 280 752 213
1.8 i	1,8l 92 kW BAF 4 Zyl.
Throttle valve assembly	08.01-03.03 0 280 750 026 04.03→ 0 280 750 159
Phase sensor	08.01→ 0 232 101 024
Speed sensor, ignition/injection	08.01→ 0 261 210 147
1.8 i Turbo	1,8l 110 kW BAE 4 Zyl.
Throttle valve assembly	08.01-01.06 0 280 750 036
Air mass meter, gasoline injection	08.01-01.06 0 280 218 063 0 986 280 217
Phase sensor	08.01-01.06 0 232 101 024
Speed sensor, ignition/injection	08.01-01.06 0 261 210 147



Knock sensor	08.01-01.06 ZE 0 261 231 146
Temperature sensor, intake air, injection system	08.01-01.06 0 280 130 085
1.8 T [1J2]	1,8l 110 kW AGU 4 Zyl.
Air mass meter, gasoline injection	05.00-05.05 0 280 217 117 0 986 280 201
Speed sensor, ignition/injection	05.00-05.05 0 261 210 199
Boost pressure sensor, gasoline	Fg.no. →1J..3..525 000 05.00-03.03 0 281 002 177 Fg.no. 1J..3..525 001→ 04.03-05.05 0 281 002 399
Temperature sensor, intake air, injection system	Fg.no. →1J..3D013 548,→1J..3W335 000 05.00-09.02 0 280 130 085 Fg.no. 1J..3D013 549→,1J..3W335 001→ 10.02-05.05 0 280 130 116
Accelerator pedal module	05.00-05.05 AG,RLE 0 280 752 213 05.01-05.05 GS,LLE 0 280 752 214 05.00-05.05 GS,RLE 0 280 752 210
1.8 T [1J2]	1,8l 110 kW ARX 4 Zyl.
Accelerator pedal module	09.00-04.01 AG,RLE 0 280 752 213 GS,RLE 0 280 752 210
1.8 T [1J2]	1,8l 110 kW AUM 4 Zyl.
Throttle valve assembly	09.00-05.05 0 280 750 036
Air mass meter, gasoline injection	09.00-05.05 0 280 218 063 0 986 280 217
Phase sensor	09.00-05.05 0 232 101 024
Speed sensor, ignition/injection	09.00-05.05 0 261 210 199
Knock sensor	09.00-05.05 0 261 231 146
Boost pressure sensor, gasoline	Fg.no. →1J..3..525 000 09.00-03.03 0 281 002 177 Fg.no. 1J..3..525 001→ 04.03-05.05 0 281 002 399
Temperature sensor, intake air, injection system	Fg.no. →1J..3D013 548,→1J..3W335 000 09.00-09.02 0 280 130 085 Fg.no. 1J..3D013 549→,1J..3W335 001→ 10.02-05.05 0 280 130 116
Accelerator pedal module	09.00-05.05 AG,RLE 0 280 752 213 05.01-05.05 GS,LLE 0 280 752 214 09.00-05.05 GS,RLE 0 280 752 210
1.8 T [1J2]	1,8l 132 kW AUQ 4 Zyl.
Throttle valve assembly	05.02-05.03 0 280 750 036
Air mass meter, gasoline injection	05.02-05.03 0 280 218 063 0 986 280 217
Phase sensor	05.02-05.03 0 232 101 024
Speed sensor, ignition/injection	05.02-05.03 0 261 210 199
Boost pressure sensor, gasoline	Fg.no. →1J..3..525 000 05.02-03.03 0 281 002 177 Fg.no. 1J..3..525 001→ 04.03-05.03 0 281 002 399
Temperature sensor, intake air, injection system	Fg.no. →1J..3D013 548,→1J..3W335 000 05.02-09.02 0 280 130 085 Fg.no. 1J..3D013 549→,1J..3W335 001→ 10.02-05.03 0 280 130 116
Accelerator pedal module	05.02-05.03 AG,RLE 0 280 752 213 GS,LLE 0 280 752 214 GS,RLE 0 280 752 210
1.8 4 Motion [1J2]	1,8l 92 kW AGN 4 Zyl.
Air mass meter, gasoline injection	02.99-10.00 0 280 218 002 0 986 280 205
Phase sensor	02.99-10.00 0 232 101 024
Speed sensor, ignition/injection	02.99-10.00 0 261 210 147
Accelerator pedal module	Fg.no. 1J..Y..000 001→ 05.99-10.00 AG,RLE 0 280 752 213
1.9 TDI	1,9l 74 kW ATD 4 Zyl.
Air mass meter, diesel	Fg.no. 1J..2..380 001→,1J..2D420 000→ 02.04-06.06 0 281 002 531 0 986 284 009
Boost pressure sensor, Diesel	Fg.no. 1J..3..525 001→ 02.04-06.06 0 281 002 399



Product				
◀ Bora				
1.9 TDI [1J2]	1,9l 66 kW AGR; ALH 4 Zyl.			
Air mass meter, diesel	09.98-05.05	0 281 002 757		
	WW	0 280 217 121		
		0 986 280 202		
Boost pressure sensor, Diesel				
Fg.no. →1J..3..525 000	09.98-03.03	0 281 002 177		
Fg.no. 1J..3..525 001→	04.03-05.05	0 281 002 399		
1.9 TDI [1J2]	1,9l 74 kW ATD; AXR 4 Zyl.			
Air mass meter, diesel				
Fg.no. →1J..2..380 000,→1J..2D420 000	01.00-10.01	0 281 002 757		
	WW	0 280 217 121		
		0 986 280 202		
Fg.no. 1J..2..380 001→,1J..2D420 000→	11.01-05.05	0 281 002 531		
		0 986 284 009		
Boost pressure sensor, Diesel				
Fg.no. →1J..3..525 000	01.00-03.03	0 281 002 177		
Fg.no. 1J..3..525 001→	04.03-05.05	0 281 002 399		
1.9 TDI [1J2]	1,9l 81 kW AHF; ASV 4 Zyl.			
Air mass meter, diesel	09.98-05.05	0 281 002 757		
	WW	0 280 217 121		
		0 986 280 202		
Boost pressure sensor, Diesel				
Fg.no. →1J..3..525 000	09.98-03.03	0 281 002 177		
Fg.no. 1J..3..525 001→	04.03-05.05	0 281 002 399		
1.9 TDI [1J2]	1,9l 85 kW AJM; AUY 4 Zyl.			
Air mass meter, diesel	09.98-05.01	0 281 002 757		
	WW	0 280 217 121		
		0 986 280 202		
Boost pressure sensor, Diesel	09.98-05.01	0 281 002 177		
1.9 TDI [1J2]	1,9l 96 kW ASZ 4 Zyl.			
Air mass meter, diesel				
Fg.no. →1J..2..600 000	01.01-04.02	0 280 217 529		
		0 986 280 204		
Fg.no. 1J..2..600 001→	05.02-05.05	0 281 002 461		
		0 986 284 007		
Boost pressure sensor, Diesel	01.01-05.05	0 281 002 177		
1.9 TDI [1J2]	1,9l 110 kW ARL 4 Zyl.			
Air mass meter, diesel				
Fg.no. →1J..2..600 000	01.00-04.02	0 280 217 529		
		0 986 280 204		
Fg.no. 1J..2..600 001→	05.02-05.05	0 281 002 461		
		0 986 284 007		
Boost pressure sensor, Diesel	01.00-05.05	0 281 002 394		
1.9 TDI 4 Motion [1J2]	1,9l 66 kW AGR 4 Zyl.			
Air mass meter, diesel	01.99-05.05	0 281 002 757		
	WW	0 280 217 121		
		0 986 280 202		
Boost pressure sensor, Diesel				
Fg.no. →1J..3..525 000	01.99-03.03	0 281 002 177		
Fg.no. 1J..3..525 001→	04.03-05.05	0 281 002 399		
1.9 TDI 4 Motion [1J2]	1,9l 74 kW ATD 4 Zyl.			
Air mass meter, diesel				
Fg.no. →1J..2..380 000,→1J..2D420 000	01.00-10.01	0 281 002 757		
	WW	0 280 217 121		
		0 986 280 202		
Fg.no. 1J..2..380 001→,1J..2D420 000→	11.01-05.05	0 281 002 531		
		0 986 284 009		
Boost pressure sensor, Diesel				
Fg.no. →1J..3..525 000	01.00-03.03	0 281 002 177		
Fg.no. 1J..3..525 001→	04.03-05.05	0 281 002 399		



Product				
1.9 TDI 4 Motion [1J2]	1,9l 85 kW AJM; AUY 4 Zyl.			
Air mass meter, diesel	02.99-04.01	0 281 002 757		
	WW	0 280 217 121		
		0 986 280 202		
Boost pressure sensor, Diesel	02.99-04.01	0 281 002 177		
1.9 TDI 4 Motion [1J2]	1,9l 96 kW ASZ 4 Zyl.			
Air mass meter, diesel				
Fg.no. →1J..2..600 000	01.01-04.02	0 280 217 529		
		0 986 280 204		
Fg.no. 1J..2..600 001→	05.02-05.05	0 281 002 461		
		0 986 284 007		
Boost pressure sensor, Diesel	01.01-05.05	0 281 002 177		
1.9 TDI 4 Motion [1J2]	1,9l 110 kW ARL 4 Zyl.			
Air mass meter, diesel				
Fg.no. →1J..2..600 000	09.00-04.02	0 280 217 529		
		0 986 280 204		
Fg.no. 1J..2..600 001→	05.02-05.05	0 281 002 461		
		0 986 284 007		
Boost pressure sensor, Diesel	09.00-05.05	0 281 002 394		
2.0	2,0l 85 kW APK 4 Zyl.			
Phase sensor	12.00-06.03	0 232 101 031		
Speed sensor, ignition/injection	12.00-06.03	0 261 210 147		
Knock sensor	12.00-06.03	0 261 231 146		
2.0	2,0l 85 kW BER 4 Zyl.			
Throttle valve assembly	09.02→	0 280 750 061		
Air mass meter, gasoline injection	09.02→	0 280 218 060		
		0 986 280 216		
Speed sensor, ignition/injection	09.02→	0 261 210 147		
Knock sensor	09.02→	0 261 231 146		
2.0 [1J2]	2,0l 85 kW APK; AQY 4 Zyl.			
Air mass meter, gasoline injection	09.98-05.05	0 280 218 002		
		0 986 280 205		
Phase sensor	09.98-05.05	0 232 101 031		
Speed sensor, ignition/injection	09.98-05.05	0 261 210 147		
Knock sensor	09.98-04.01	0 261 231 045		
	05.01-05.05	0 261 231 146		
Accelerator pedal module	05.01-05.05	GS,LLE 0 280 752 214		
Fg.no. 1J..Y..000 001→	05.99-05.05	AG,RLE 0 280 752 213		
		GS,RLE 0 280 752 210		
2.0 [1J2]	2,0l 85 kW AZH 4 Zyl.			
Throttle valve assembly	04.00-06.01	0 280 750 061		
Air mass meter, gasoline injection	04.00-06.01	0 280 218 002		
		0 986 280 205		
Speed sensor, ignition/injection	04.00-06.01	0 261 210 147		
Knock sensor	04.00-06.01	0 261 231 146		
Accelerator pedal module	04.00-06.01	AG,RLE 0 280 752 213		
	05.01-06.01	GS,LLE 0 280 752 214		
	04.00-06.01	GS,RLE 0 280 752 210		
2.0 [1J2]	2,0l 85 kW AZJ 4 Zyl.			
Throttle valve assembly	05.01-05.05	0 280 750 059		
Air mass meter, gasoline injection	05.01-05.05	0 280 218 060		
		0 986 280 216		
Phase sensor	05.01-05.05	0 232 101 031		
Speed sensor, ignition/injection	05.01-05.05	0 261 210 199		
Knock sensor	05.01-05.05	0 261 231 146		
Accelerator pedal module	05.01-05.05	AG,RLE 0 280 752 213		
		GS,LLE 0 280 752 214		
		GS,RLE 0 280 752 210		
2.0 4 Motion [1J2]	2,0l 85 kW AZH 4 Zyl.			
Throttle valve assembly	04.00-06.01	0 280 750 061		
Air mass meter, gasoline injection	04.00-06.01	0 280 218 002		
		0 986 280 205		
Speed sensor, ignition/injection	04.00-06.01	0 261 210 147		

Product



Knock sensor	04.00-06.01		0 261 231 146
Accelerator pedal module	04.00-06.01	AG,RLE	0 280 752 213
	05.01-06.01	GS,LLE	0 280 752 214
	04.00-06.01	GS,RLE	0 280 752 210
2.0 4 Motion [1J2] 2,0l 85 kW AZJ 4 Zyl.			
Throttle valve assembly	05.01-05.05		0 280 750 059
Air mass meter, gasoline injection	05.01-05.05		0 280 218 060
			0 986 280 216
Phase sensor	05.01-05.05		0 232 103 031
Speed sensor, ignition/injection	05.01-05.05		0 261 210 199
Knock sensor	05.01-05.05		0 261 231 146
Accelerator pedal module	05.01-05.05	AG,RLE	0 280 752 213
		GS,LLE	0 280 752 214
		GS,RLE	0 280 752 210
2.3 [1J2] 2,3l 110 kW AGZ 5 Zyl.			
Air mass meter, gasoline injection	09.98-02.01		0 280 217 529
			0 986 280 204
Phase sensor	09.98-02.01		0 232 103 019
Speed sensor, ignition/injection	09.98-02.01		0 261 210 177
Knock sensor	09.98-02.01		0 261 231 146
Temperature sensor, intake air, injection system	09.98-02.01		0 280 130 085
Accelerator pedal module			
Fg.no. 1J..Y..000 001→	05.99-02.01	AG,RLE	0 280 752 213
		GS,RLE	0 280 752 210
2.3 [1J2] 2,3l 125 kW AQN 5 Zyl.			
Throttle valve assembly	09.00-05.05		0 280 750 097
Air mass meter, gasoline injection	09.00-05.05		0 280 218 017
			0 986 280 208
Phase sensor	09.00-05.05		0 232 103 019
Knock sensor	09.00-05.05	OHL	0 261 231 146
Accelerator pedal module	09.00-05.05	AG,RLE	0 280 752 213
	05.01-05.05	GS,LLE	0 280 752 214
	09.00-05.05	GS,RLE	0 280 752 210
2.3 4 Motion [1J2] 2,3l 110 kW AGZ 5 Zyl.			
Air mass meter, gasoline injection	01.99-02.01		0 280 217 529
			0 986 280 204
Phase sensor	01.99-02.01		0 232 103 019
Speed sensor, ignition/injection	01.99-02.01		0 261 210 177
Knock sensor	01.99-02.01		0 261 231 146
Temperature sensor, intake air, injection system	01.99-02.01		0 280 130 085
Accelerator pedal module			
Fg.no. 1J..Y..000 001→	05.99-02.01	AG,RLE	0 280 752 213
		GS,RLE	0 280 752 210
2.3 4 Motion [1J2] 2,3l 125 kW AQN 5 Zyl.			
Throttle valve assembly	09.00-05.05		0 280 750 097
Air mass meter, gasoline injection	09.00-05.05		0 280 218 017
			0 986 280 208
Phase sensor	09.00-05.05		0 232 103 019
Knock sensor	09.00-05.05	OHL	0 261 231 146
Accelerator pedal module	09.00-05.05	AG,RLE	0 280 752 213
	05.01-05.05	GS,LLE	0 280 752 214
	09.00-05.05	GS,RLE	0 280 752 210
2.8 4 Motion [1J2] 2,8l 150 kW AQP; AUE 6 Zyl.			
Throttle valve assembly			
Fg.no. →1J..Y..620 000	05.99-01.00	LLE	0 280 750 086
		RLE	0 280 750 097
Fg.no. 1J..Y..620 001→	02.00-04.01		0 280 750 097
Air mass meter, gasoline injection	05.99-04.01		0 280 218 017
			0 986 280 208
Phase sensor	05.99-04.01		0 232 103 019
Knock sensor	05.99-04.01	OHL	0 261 231 146
Accelerator pedal module	05.99-04.01	AG,RLE	0 280 752 213
		GS,RLE	0 280 752 210


Product




2.8 4 Motion [1J2]		2,8l 150 kW BDE 6 Zyl.
Throttle valve assembly	05.01-05.05	0 280 750 097
Air mass meter, gasoline injection	05.01-05.05	0 280 218 017
		0 986 280 208
Phase sensor	05.01-05.05	0 232 103 019
Knock sensor	05.01-05.05	OHL 0 261 231 146
Accelerator pedal module	05.01-05.05	AG,RLE 0 280 752 213
		GS,LLE 0 280 752 214
		GS,RLE 0 280 752 210

Bora Variant

1.4 [1J6]		1,4l 55 kW AHW 4 Zyl.
Knock sensor	05.00-04.01	0 261 231 045
	05.01-05.05	0 261 231 146
Accelerator pedal module	05.00-05.05	AG,RLE 0 280 752 213
	05.01-05.05	GS,LLE 0 280 752 214
	05.00-05.05	GS,RLE 0 280 752 210
1.4 [1J6]		1,4l 55 kW AXP 4 Zyl.
Knock sensor	05.00-10.01	0 261 231 146
Pressure sensor, intake manifold, gasoline	05.00-10.01	0 261 230 031
Accelerator pedal module	05.00-10.01	AG,RLE 0 280 752 213
	05.01-10.01	GS,LLE 0 280 752 214
	05.00-10.01	GS,RLE 0 280 752 210
1.4 [1J6]		1,4l 55 kW BCA 4 Zyl.
Pressure sensor, intake manifold, gasoline	10.01-05.05	0 261 230 031
Accelerator pedal module	10.01-05.05	AG,RLE 0 280 752 213
		GS,LLE 0 280 752 214
		GS,RLE 0 280 752 210
1.6 [1J6]		1,6l 74 kW AEH 4 Zyl.
Phase sensor	05.99-04.01	0 232 101 031
Speed sensor, ignition/injection	05.99-04.01	0 261 210 147
Accelerator pedal module	05.99-04.01	AG,RLE 0 280 752 213
		GS,RLE 0 280 752 210
1.6 [1J6]		1,6l 74 kW AKL 4 Zyl.
Phase sensor	05.99-05.05	0 232 101 031
Speed sensor, ignition/injection	05.99-05.05	0 261 210 147
Accelerator pedal module	05.99-05.05	AG,RLE 0 280 752 213
	05.01-05.05	GS,LLE 0 280 752 214
	05.99-05.05	GS,RLE 0 280 752 210
1.6 [1J6]		1,6l 74 kW APF 4 Zyl.
Phase sensor	05.99-09.00	0 232 101 031
Speed sensor, ignition/injection	05.99-09.00	0 261 210 199
Accelerator pedal module	05.99-09.00	AG,RLE 0 280 752 213
		GS,RLE 0 280 752 210
1.6 [1J6]		1,6l 75 kW AVU 4 Zyl.
Phase sensor	09.00-05.05	0 232 101 038
Speed sensor, ignition/injection	09.00-05.05	0 261 210 199
Accelerator pedal module	09.00-05.05	AG,RLE 0 280 752 213
	05.01-05.05	GS,LLE 0 280 752 214
	09.00-05.05	GS,RLE 0 280 752 210
1.6 [1J6]		1,6l 75 kW BFQ 4 Zyl.
Speed sensor, ignition/injection	05.02-05.03	0 261 210 199
Knock sensor	05.02-05.03	0 261 231 146
Accelerator pedal module	05.02-05.03	AG,RLE 0 280 752 213
		GS,LLE 0 280 752 214
		GS,RLE 0 280 752 210
1.6 [1J6]		1,6l 77 kW ATN 4 Zyl.
Throttle valve assembly	08.99-05.00	0 280 750 049
Speed sensor, ignition/injection	08.99-05.00	0 261 210 194
Knock sensor	08.99-05.00	0 261 231 045
Accelerator pedal module	08.99-05.00	AG,RLE 0 280 752 213
		GS,RLE 0 280 752 210





◀ Bora Variant

1.6 [1J6]		1,6l 77 kW AUS 4 Zyl.	
Throttle valve assembly	05.00-10.00		0 280 750 049
Knock sensor	05.00-10.00		0 261 231 045
Accelerator pedal module	05.00-10.00	AG,RLE	0 280 752 213
		GS,RLE	0 280 752 210
1.6 [1J6]		1,6l 77 kW AZD 4 Zyl.	
Throttle valve assembly	09.00-11.01		0 280 750 049
Speed sensor, ignition/injection	09.00-11.01		0 261 210 194
Knock sensor	09.00-11.01		0 261 231 146
Accelerator pedal module	09.00-11.01	AG,RLE	0 280 752 213
	05.01-11.01	GS,LLE	0 280 752 214
	09.00-11.01	GS,RLE	0 280 752 210
1.6 [1J6]		1,6l 77 kW BCB 4 Zyl.	
Speed sensor, ignition/injection	11.01-05.05		0 261 210 213
Knock sensor	11.01-05.05		0 261 231 146
Accelerator pedal module	11.01-05.05	AG,RLE	0 280 752 213
		GS,LLE	0 280 752 214
		GS,RLE	0 280 752 210
1.6 FSI [1J6]		1,6l 81 kW BAD 4 Zyl.	
Throttle valve assembly	08.01-05.05		0 280 750 059
Air mass meter, gasoline injection	08.01-05.05		0 280 218 060
			0 986 280 216
Knock sensor	08.01-05.05		0 261 231 146
Pressure sensor, intake manifold, gasoline	08.01-05.05		0 261 230 079
Accelerator pedal module	08.01-05.05	AG,RLE	0 280 752 213
		GS,LLE	0 280 752 214
		GS,RLE	0 280 752 210
1.6 4 Motion [1J6]		1,6l 77 kW AUS 4 Zyl.	
Throttle valve assembly	05.00-10.00		0 280 750 049
Knock sensor	05.00-10.00		0 261 231 045
Accelerator pedal module	05.00-10.00	AG,RLE	0 280 752 213
		GS,RLE	0 280 752 210
1.6 4 Motion [1J6]		1,6l 77 kW AZD 4 Zyl.	
Throttle valve assembly	09.00-11.01		0 280 750 049
Speed sensor, ignition/injection	09.00-11.01		0 261 210 194
Knock sensor	09.00-11.01		0 261 231 146
Accelerator pedal module	09.00-11.01	AG,RLE	0 280 752 213
	05.01-11.01	GS,LLE	0 280 752 214
	09.00-11.01	GS,RLE	0 280 752 210
1.8 T [1J6]		1,8l 110 kW AGU 4 Zyl.	
Air mass meter, gasoline injection	05.00-05.05		0 280 217 117
			0 986 280 201
Speed sensor, ignition/injection	05.00-05.05		0 261 210 199
Boost pressure sensor, gasoline			
Fg.no. →1J..3..525 000	05.00-03.03		0 281 002 177
Fg.no. 1J..3..525 001→	04.03-05.05		0 281 002 399
Temperature sensor, intake air, injection system			
Fg.no. →1J..3D013 548,→1J..3W335 000	05.00-09.02		0 280 130 085
Fg.no. 1J..3D013 549→,1J..3W335 001→	10.02-05.05		0 280 130 116
Accelerator pedal module	05.00-05.05	AG,RLE	0 280 752 213
	05.01-05.05	GS,LLE	0 280 752 214
	05.00-05.05	GS,RLE	0 280 752 210
1.8 T [1J6]		1,8l 110 kW ARX 4 Zyl.	
Accelerator pedal module	09.00-04.01	AG,RLE	0 280 752 213
		GS,RLE	0 280 752 210
1.8 T [1J6]		1,8l 110 kW AUM 4 Zyl.	
Throttle valve assembly	09.00-05.05		0 280 750 036
Air mass meter, gasoline injection	09.00-05.05		0 280 218 063
			0 986 280 217
Phase sensor	09.00-05.05		0 232 101 024
Speed sensor, ignition/injection	09.00-05.05		0 261 210 199
Knock sensor	09.00-05.05		0 261 231 146




Boost pressure sensor, gasoline		
Fg.no. →1J..3..525 000	09.00-03.03	0 281 002 177
Fg.no. 1J..3..525 001→	04.03-05.05	0 281 002 399
Temperature sensor, intake air, injection system		
Fg.no. →1J..3D013 548,→1J..3W335 000	09.00-09.02	0 280 130 085
Fg.no. 1J..3D013 549→,1J..3W335 001→	10.02-05.05	0 280 130 116
Accelerator pedal module	09.00-05.05	AG,RLE 0 280 752 213
	05.01-05.05	GS,LLE 0 280 752 214
	09.00-05.05	GS,RLE 0 280 752 210
1.8 T [1J6] 1,8l 132 kW AUQ 4 Zyl.		
Throttle valve assembly	05.02-05.03	0 280 750 036
Air mass meter, gasoline injection	05.02-05.03	0 280 218 063
		0 986 280 217
Phase sensor	05.02-05.03	0 232 101 024
Speed sensor, ignition/injection	05.02-05.03	0 261 210 199
Boost pressure sensor, gasoline		
Fg.no. →1J..3..525 000	05.02-03.03	0 281 002 177
Fg.no. 1J..3..525 001→	04.03-05.03	0 281 002 399
Temperature sensor, intake air, injection system		
Fg.no. →1J..3D013 548,→1J..3W335 000	05.02-09.02	0 280 130 085
Fg.no. 1J..3D013 549→,1J..3W335 001→	10.02-05.03	0 280 130 116
Accelerator pedal module	05.02-05.03	AG,RLE 0 280 752 213
		GS,LLE 0 280 752 214
		GS,RLE 0 280 752 210
1.8 4 Motion [1J6] 1,8l 92 kW AGN 4 Zyl.		
Air mass meter, gasoline injection	05.99-10.00	0 280 218 002
		0 986 280 205
Phase sensor	05.99-10.00	0 232 101 024
Speed sensor, ignition/injection	05.99-10.00	0 261 210 147
Accelerator pedal module	05.99-10.00	AG,RLE 0 280 752 213
		GS,RLE 0 280 752 210
1.9 TDI [1J6] 1,9l 66 kW AGR 4 Zyl.		
Air mass meter, diesel	09.98-05.05	0 281 002 757
		0 280 217 121
		0 986 280 202
Boost pressure sensor, Diesel		
Fg.no. →1J..3..525 000	09.98-03.03	0 281 002 177
Fg.no. 1J..3..525 001→	04.03-05.05	0 281 002 399
1.9 TDI [1J6] 1,9l 74 kW ATD; AXR 4 Zyl.		
Air mass meter, diesel	05.00-10.01	0 281 002 757
		0 280 217 121
		0 986 280 202
Fg.no. 1J..2..380 001→,1J..2D420 000→	11.01-05.05	0 281 002 531
		0 986 284 009
Boost pressure sensor, Diesel		
Fg.no. →1J..3..525 000	05.00-03.03	0 281 002 177
Fg.no. 1J..3..525 001→	04.03-05.05	0 281 002 399
1.9 TDI [1J6] 1,9l 81 kW AHF; ASV 4 Zyl.		
Air mass meter, diesel	05.99-05.05	0 281 002 757
		0 280 217 121
		0 986 280 202
Boost pressure sensor, Diesel		
Fg.no. →1J..3..525 000	05.99-03.03	0 281 002 177
Fg.no. 1J..3..525 001→	04.03-05.05	0 281 002 399
1.9 TDI [1J6] 1,9l 85 kW AJM; AUY 4 Zyl.		
Air mass meter, diesel	05.99-04.01	0 281 002 757
		0 280 217 121
		0 986 280 202
Boost pressure sensor, Diesel		
Fg.no. →1J..3..525 000	05.99-04.01	0 281 002 177



1.9 TDI [1J6]		1,9l 96 kW ASZ 4 Zyl.
Air mass meter, diesel		
Fg.no. →1J..2..600 000	01.01-04.02	0 280 217 529
		0 986 280 204
Fg.no. 1J..2..600 001→	05.02-05.05	0 281 002 461
		0 986 284 007
Boost pressure sensor, Diesel	01.01-05.05	0 281 002 177
1.9 TDI [1J6]		1,9l 110 kW ARL 4 Zyl.
Air mass meter, diesel	05.02-05.05	0 281 002 461
		0 986 284 007
Boost pressure sensor, Diesel	05.02-05.05	0 281 002 394
1.9 TDI 4 Motion [1J6]		1,9l 74 kW ATD 4 Zyl.
Air mass meter, diesel		
Fg.no. →1J..2..380 000,→1J..2D420 000	05.00-10.01	0 281 002 757
	WW	0 280 217 121
		0 986 280 202
Fg.no. 1J..2..380 001→,1J..2D420 000→	11.01-05.05	0 281 002 531
		0 986 284 009
Boost pressure sensor, Diesel		
Fg.no. →1J..3..525 000	05.00-03.03	0 281 002 177
Fg.no. 1J..3..525 001→	04.03-05.05	0 281 002 399
1.9 TDI 4 Motion [1J6]		1,9l 85 kW AJM; AUY 4 Zyl.
Air mass meter, diesel	05.99-04.01	0 281 002 757
	WW	0 280 217 121
		0 986 280 202
Boost pressure sensor, Diesel	05.99-04.01	0 281 002 177
1.9 TDI 4 Motion [1J6]		1,9l 96 kW ASZ 4 Zyl.
Air mass meter, diesel		
Fg.no. →1J..2..600 000	01.01-04.02	0 280 217 529
		0 986 280 204
Fg.no. 1J..2..600 001→	05.02-05.05	0 281 002 461
		0 986 284 007
Boost pressure sensor, Diesel	01.01-05.05	0 281 002 177
1.9 TDI 4 Motion [1J6]		1,9l 110 kW ARL 4 Zyl.
Air mass meter, diesel	05.02-05.05	0 281 002 461
		0 986 284 007
Boost pressure sensor, Diesel	05.02-05.05	0 281 002 394
2.0 [1J6]		2,0l 85 kW APK; AQY 4 Zyl.
Air mass meter, gasoline injection	05.99-05.05	0 280 218 002
		0 986 280 205
Phase sensor	05.99-05.05	0 232 101 031
Speed sensor, ignition/injection	05.99-05.05	0 261 210 147
Knock sensor	05.99-04.01	0 261 231 045
	05.01-05.05	0 261 231 146
Accelerator pedal module	05.99-05.05 AG,RLE	0 280 752 213
	05.01-05.05 GS,LL	0 280 752 214
	05.99-05.05 GS,RLE	0 280 752 210
2.0 [1J6]		2,0l 85 kW AZG 4 Zyl.
Throttle valve assembly	05.01-05.05	0 280 750 061
Air mass meter, gasoline injection	05.01-05.05	0 280 218 060
		0 986 280 216
Speed sensor, ignition/injection	05.01-05.05	0 261 210 199
Accelerator pedal module	05.01-05.05 AG,RLE	0 280 752 213
	GS,LL	0 280 752 214
	GS,RLE	0 280 752 210
2.0 [1J6]		2,0l 85 kW AZH 4 Zyl.
Throttle valve assembly	04.00-06.01	0 280 750 061
Air mass meter, gasoline injection	04.00-06.01	0 280 218 002
		0 986 280 205
Speed sensor, ignition/injection	04.00-06.01	0 261 210 147
Knock sensor	04.00-06.01	0 261 231 146



Accelerator pedal module	04.00-06.01 AG,RLE	0 280 752 213
	05.01-06.01 GS,LL	0 280 752 214
	04.00-06.01 GS,RLE	0 280 752 210
2.0 [1J6]		2,0l 85 kW AZJ 4 Zyl.
Throttle valve assembly	05.01-05.05	0 280 750 059
Air mass meter, gasoline injection	05.01-05.05	0 280 218 060
		0 986 280 216
Phase sensor	05.01-05.05	0 232 101 031
Speed sensor, ignition/injection	05.01-05.05	0 261 210 199
Knock sensor	05.01-05.05	0 261 231 146
Accelerator pedal module	05.01-05.05 AG,RLE	0 280 752 213
	GS,LL	0 280 752 214
	GS,RLE	0 280 752 210
2.0 4 Motion [1J6]		2,0l 85 kW AZH 4 Zyl.
Throttle valve assembly	04.00-06.01	0 280 750 061
Air mass meter, gasoline injection	04.00-06.01	0 280 218 002
		0 986 280 205
Speed sensor, ignition/injection	04.00-06.01	0 261 210 147
Knock sensor	04.00-06.01	0 261 231 146
Accelerator pedal module	04.00-06.01 AG,RLE	0 280 752 213
	05.01-06.01 GS,LL	0 280 752 214
	04.00-06.01 GS,RLE	0 280 752 210
2.0 4 Motion [1J6]		2,0l 85 kW AZJ 4 Zyl.
Throttle valve assembly	05.01-05.05	0 280 750 059
Air mass meter, gasoline injection	05.01-05.05	0 280 218 060
		0 986 280 216
Phase sensor	05.01-05.05	0 232 101 031
Speed sensor, ignition/injection	05.01-05.05	0 261 210 199
Knock sensor	05.01-05.05	0 261 231 146
Accelerator pedal module	05.01-05.05 AG,RLE	0 280 752 213
	GS,LL	0 280 752 214
	GS,RLE	0 280 752 210
2.3 [1J6]		2,3l 110 kW AGZ 5 Zyl.
Air mass meter, gasoline injection	05.99-02.01	0 280 217 529
		0 986 280 204
Phase sensor	05.99-02.01	0 232 103 019
Speed sensor, ignition/injection	05.99-02.01	0 261 210 177
Knock sensor	05.99-02.01	0 261 231 146
Temperature sensor, intake air, injection system	05.99-02.01	0 280 130 085
Accelerator pedal module	05.99-02.01 AG,RLE	0 280 752 213
	GS,RLE	0 280 752 210
2.3 [1J6]		2,3l 125 kW AQN 5 Zyl.
Throttle valve assembly	09.00-05.05	0 280 750 097
Air mass meter, gasoline injection	09.00-05.05	0 280 218 017
		0 986 280 208
Phase sensor	09.00-05.05	0 232 103 019
Knock sensor	09.00-05.05 OHL	0 261 231 146
Accelerator pedal module	09.00-05.05 AG,RLE	0 280 752 213
	05.01-05.05 GS,LL	0 280 752 214
	09.00-05.05 GS,RLE	0 280 752 210
2.3 4 Motion [1J6]		2,3l 110 kW AGZ 5 Zyl.
Air mass meter, gasoline injection	05.00-02.01	0 280 217 529
		0 986 280 204
Phase sensor	05.00-02.01	0 232 103 019
Speed sensor, ignition/injection	05.00-02.01	0 261 210 177
Knock sensor	05.00-02.01	0 261 231 146
Temperature sensor, intake air, injection system	05.00-02.01	0 280 130 085
Accelerator pedal module	05.00-02.01 AG,RLE	0 280 752 213
	GS,RLE	0 280 752 210
2.3 4 Motion [1J6]		2,3l 125 kW AQN 5 Zyl.
Throttle valve assembly	09.00-05.05	0 280 750 097
Air mass meter, gasoline injection	09.00-05.05	0 280 218 017
		0 986 280 208



Product

◀ Bora Variant

Phase sensor	09.00-05.05		0 232 103 019
Knock sensor	09.00-05.05	OHL	0 261 231 146
Accelerator pedal module	09.00-05.05	AG,RLE	0 280 752 213
	05.01-05.05	GS,LLE	0 280 752 214
	09.00-05.05	GS,RLE	0 280 752 210
2.8 4 Motion [1J6]		2,8 l	150 kW AQP; AUE 6 Zyl.
Throttle valve assembly			
Fg.no. →1J..Y..620 000	05.99-01.00	LLE	0 280 750 086
		RLE	0 280 750 097
Fg.no. 1J..Y..620 001→	02.00-04.01		0 280 750 097
Air mass meter, gasoline injection	05.99-04.01		0 280 218 017
			0 986 280 208
Phase sensor	05.99-04.01		0 232 103 019
Knock sensor	05.99-04.01	OHL	0 261 231 146
Accelerator pedal module	05.99-04.01	AG,RLE	0 280 752 213
		GS,RLE	0 280 752 210
2.8 4 Motion [1J6]		2,8 l	150 kW BDE 6 Zyl.
Throttle valve assembly	05.01-05.05		0 280 750 097
Air mass meter, gasoline injection	05.01-05.05		0 280 218 017
			0 986 280 208
Phase sensor	05.01-05.05		0 232 103 019
Knock sensor	05.01-05.05	OHL	0 261 231 146
Accelerator pedal module	05.01-05.05	AG,RLE	0 280 752 213
		GS,LLE	0 280 752 214
		GS,RLE	0 280 752 210

V



Bus

1.6 D [24, 25]		1,6 l	37 kW	CS 4 Zyl.
Wheel speed sensor, front	08.85-07.87			0 265 001 149
Wheel speed sensor, rear	08.85-07.87			0 265 001 151
1.6 D Turbo [24, 25]		1,6 l	51 kW	JX 4 Zyl.
Wheel speed sensor, front	08.85-07.92			0 265 001 149
Wheel speed sensor, rear	08.85-07.92			0 265 001 151
1.6 D Turbo Syncro [24, 25]		1,6 l	51 kW	JX 4 Zyl.
Wheel speed sensor, front	03.86-07.92	LAB		0 265 001 196
		RAB		0 265 001 198
Wheel speed sensor, rear	03.86-07.92			0 265 001 149
1.7 D [24, 25]		1,7 l	42 kW	KY 4 Zyl.
Wheel speed sensor, front	10.86-07.92			0 265 001 149
Wheel speed sensor, rear	10.86-07.92			0 265 001 151
1.9 [24, 25]		1,9 l	40 kW	EY 4 Zyl.
Wheel speed sensor, rear	08.85-05.88			0 265 001 151
1.9 [24, 25]		1,9 l	44 kW	DF 4 Zyl.
Wheel speed sensor, front	08.85-07.92			0 265 001 149
Wheel speed sensor, rear	08.85-07.92			0 265 001 151
1.9 [24, 25]		1,9 l	54 kW	SP 4 Zyl.
Wheel speed sensor, rear	08.86-10.88			0 265 001 151
1.9 [24, 25]		1,9 l	57 kW	DG 4 Zyl.
Wheel speed sensor, front	08.85-07.92			0 265 001 149
Wheel speed sensor, rear	08.85-07.92			0 265 001 151
1.9 Syncro [24, 25]		1,9 l	54 kW	SP 4 Zyl.
Wheel speed sensor, front	10.86-10.88	LAB		0 265 001 196
		RAB		0 265 001 198
Wheel speed sensor, rear	10.86-10.88			0 265 001 149
2.1 [24, 25]		2,1 l	64/68/70 kW	MV; SR; SS 4 Zyl.
Air flow sensor, gasoline injection	08.85-07.92			0 280 202 079
				0 986 280 011
Wheel speed sensor, rear	08.85-07.92			0 265 001 151
2.1 [24, 25]		2,1 l	82 kW	DJ 4 Zyl.
Air flow sensor, gasoline injection	08.85-07.92			0 280 202 079
				0 986 280 011

Product				
Wheel speed sensor, front	08.85-07.92			0 265 001 149
Wheel speed sensor, rear	08.85-07.92			0 265 001 151
2.1 Syncro [24, 25]			2,1l	64 kW SR 4 Zyl.
Wheel speed sensor, front	10.86-07.92	LAB		0 265 001 196
		RAB		0 265 001 198
Wheel speed sensor, rear	10.86-07.92			0 265 001 149
2.1 Syncro [24, 25]		2,1l	70/82 kW DJ; MV	4 Zyl.
Air flow sensor, gasoline injection	08.85-07.92			0 280 202 079
				0 986 280 011
Wheel speed sensor, front	08.85-07.92	LAB		0 265 001 196
		RAB		0 265 001 198
Wheel speed sensor, rear	08.85-07.92			0 265 001 149
Caddy				
1.4 [2KA,2KB]			1,4l	55 kW BCA 4 Zyl.
Knock sensor	02.04-05.06			0 261 231 146
Pressure sensor, intake manifold, gasoline	02.04-05.06			0 261 230 095
1.4 [9K9]		1,4l	44 kW AEX; AKV; APQ	4 Zyl.
Knock sensor	11.95-06.03	KZA		0 261 231 045
Pressure sensor, intake manifold, gasoline	11.95-06.03			0 261 230 011
1.4 [9K9]			1,4l	44 kW AUD 4 Zyl.
Throttle valve assembly				
Mot.no. AUD 020 028→	06.01-06.03			0 280 750 095
Mot.no. →AUD 020 027	09.00-05.01			0 280 750 049
Speed sensor, ignition/injection	09.00-06.03			0 261 210 188
Knock sensor	09.00-06.03	KZA		0 261 231 045
Pressure sensor, intake manifold, gasoline	09.00-06.03			0 261 230 031
		WW		0 261 230 011
1.4 [9K9]			1,4l	55 kW AUA 4 Zyl.
Knock sensor	09.00-06.03	KZA		0 261 231 045
Pressure sensor, intake manifold, gasoline	09.00-06.03			0 261 230 011
1.6 [2KA,2KB]		1,6l	75 kW BGU; BSE; BSF	4 Zyl.
Speed sensor, ignition/injection	04.04→			0 261 210 199
Knock sensor	04.04→			0 261 231 146
Pressure sensor, intake manifold, gasoline	04.04→			0 261 230 031
1.6 [9K9]			1,6l	55 kW AEE 4 Zyl.
Knock sensor	06.97-09.00	KZA		0 261 231 045
1.7 SDI [9K9]			1,7l	42 kW AHB 4 Zyl.
Pedal position sensor, diesel	07.96-09.00			0 205 001 032
1.9 SDI [9K9]			1,9l	47 kW AEY 4 Zyl.
Pedal position sensor, diesel	11.95-09.00			0 205 001 032
1.9 SDI [9K9]			1,9l	47 kW AYQ 4 Zyl.
Pedal position sensor, diesel	09.00-06.03			0 281 002 269
1.9 TDI [2KA,2KB]		1,9l	55/77 kW BJB; BLS; BSU	4 Zyl.
Air mass meter, diesel	02.04→			0 281 002 531
				0 986 284 009
Boost pressure sensor, Diesel	02.04→			0 281 002 399
1.9 TDI [9K9]			1,9l	66 kW AHU; ALE 4 Zyl.
Pressure sensor, intake manifold, diesel	12.96-09.00			0 261 230 037
Pedal position sensor, diesel	12.96-09.00			0 205 001 032
1.9 TDI [9K9]			1,9l	66 kW ALH 4 Zyl.
Air mass meter, diesel	09.00-06.03			0 281 002 216
				0 986 284 001
Boost pressure sensor, Diesel	09.00-06.03			0 281 002 177
Pedal position sensor, diesel	09.00-06.03			0 281 002 269
1.9 TDI [9K9]			1,9l	66 kW 1Z 4 Zyl.
Pressure sensor, intake manifold, diesel	10.96-03.97			0 261 230 037
Pedal position sensor, diesel	10.96-03.97			0 205 001 032
2.0 Eco Fuel [2KA,2KB]			2,0l	80 kW BSX 4 Zyl.
Phase sensor	04.06→			0 232 101 031
Speed sensor, ignition/injection	04.06→			0 261 210 199



Knock sensor	04.06→	0 261 231 146
Pressure sensor, intake manifold, gasoline	04.06→	0 261 230 095
2.0 SDI [2KA,2KB]	2,0l 51 kW BDJ 4 Zyl.	
Pressure sensor, intake manifold, diesel	02.04→	0 281 002 399
2.0 SDI [2KA,2KB]	2,0l 51 kW BST 4 Zyl.	
Air mass meter, diesel	06.05→	0 281 002 531
		0 986 284 009
Pressure sensor, intake manifold, diesel	06.05→	0 281 002 399

Caddy Pickup


1.6 [9U7]	1,6l 55 kW AEE 4 Zyl.	
Temperature sensor, coolant, injection system	06.96-12.00	0 280 130 026
1.8 [14, 1A]	1,8l 70 kW JH 4 Zyl.	
Air flow sensor, gasoline injection	08.85-07.92	0 438 120 162
1.9 D [9U7]	1,9l 47 kW AEF 4 Zyl.	
Temperature sensor, coolant, diesel	06.96-12.00	0 280 130 026

California T4

1.8 [70]	1,8l 49 kW PD 4 Zyl.	
Duo sensor, acceleration and yaw rate, brake system	12.90-07.92	0 265 005 214
Wheel speed sensor, front	12.90-07.92	0 265 006 407
Wheel speed sensor, rear	12.90-07.92	LAB,MVB 0 265 006 508 MVB,RAB 0 265 006 510
1.9 D [70]	1,9l 45 kW 1X 4 Zyl.	
Duo sensor, acceleration and yaw rate, brake system	09.90-04.97	0 265 005 214
Wheel speed sensor, front	09.90-04.97	0 265 006 407
Wheel speed sensor, rear	09.90-04.97	LAB,MVB 0 265 006 508 MVB,RAB 0 265 006 510
Fg.no. 70..T..200 001→	01.96-04.97	LAB,OBG 0 265 006 408 OBB,RAB 0 265 006 409
1.9 D Turbo [70]	1,9l 50 kW ABL 4 Zyl.	
Duo sensor, acceleration and yaw rate, brake system	10.92-06.03	0 265 005 214
Wheel speed sensor, front	10.92-06.03	0 265 006 407
Wheel speed sensor, rear	10.92-06.03	LAB,MVB 0 265 006 508 MVB,RAB 0 265 006 510
Fg.no. 70..T..200 001→	01.96-06.03	LAB,OBG 0 265 006 408 OBB,RAB 0 265 006 409
2.0 [70]	2,0l 62 kW AAC 4 Zyl.	
Duo sensor, acceleration and yaw rate, brake system	09.90-06.03	0 265 005 214
Wheel speed sensor, front	09.90-06.03	0 265 006 407
Wheel speed sensor, rear	09.90-06.03	LAB,MVB 0 265 006 508 MVB,RAB 0 265 006 510
Fg.no. 70..T..200 001→	01.96-06.03	LAB,OBG 0 265 006 408 OBB,RAB 0 265 006 409
2.4 D [70]	2,4l 55 kW AJA 5 Zyl.	
Duo sensor, acceleration and yaw rate, brake system	05.97-06.03	0 265 005 214
Wheel speed sensor, front	05.97-06.03	0 265 006 407
Wheel speed sensor, rear	05.97-06.03	LAB,MVB 0 265 006 508 LAB,OBG 0 265 006 408 MVB,RAB 0 265 006 510 OBB,RAB 0 265 006 409
2.4 D [70]	2,4l 57 kW AAB 5 Zyl.	
Duo sensor, acceleration and yaw rate, brake system	09.90-05.98	0 265 005 214
Wheel speed sensor, front	09.90-05.98	0 265 006 407



Wheel speed sensor, rear	09.90-05.98	LAB,MVB 0 265 006 508 MVB,RAB 0 265 006 510
Fg.no. 70..T..200 001→	01.96-05.98	LAB,OBG 0 265 006 408 OBB,RAB 0 265 006 409
2.4 D Syncro [7D]	2,4l 57 kW AAB 5 Zyl.	
Duo sensor, acceleration and yaw rate, brake system	11.92-09.98	0 265 005 214
Wheel speed sensor, front	11.92-09.98	0 265 006 407
Wheel speed sensor, rear	11.92-09.98	LAB,MVB 0 265 006 508 MVB,RAB 0 265 006 510
Fg.no. 70..T..200 001→	01.96-09.98	LAB,OBG 0 265 006 408 OBB,RAB 0 265 006 409
2.5 [70]	2,5l 81 kW AAF 5 Zyl.	
Duo sensor, acceleration and yaw rate, brake system	11.90-12.93	0 265 005 214
Wheel speed sensor, front	11.90-12.93	0 265 006 407
Wheel speed sensor, rear	11.90-12.93	LAB,MVB 0 265 006 508 MVB,RAB 0 265 006 510
2.5 [70]	2,5l 81 kW ACU 5 Zyl.	
Knock sensor	07.94-10.96	L30 0 261 231 066 L34 0 261 231 077
Duo sensor, acceleration and yaw rate, brake system	07.94-10.96	0 265 005 214
Wheel speed sensor, front	07.94-10.96	0 265 006 407
Wheel speed sensor, rear	07.94-10.96	LAB,MVB 0 265 006 508 MVB,RAB 0 265 006 510
Fg.no. 70..T..200 001→	01.96-10.96	LAB,OBG 0 265 006 408 OBB,RAB 0 265 006 409
2.5 [70]	2,5l 81 kW AEN 5 Zyl.	
Duo sensor, acceleration and yaw rate, brake system	09.95-12.95	0 265 005 214
Wheel speed sensor, front	09.95-12.95	0 265 006 407
Wheel speed sensor, rear	09.95-12.95	LAB,MVB 0 265 006 508 MVB,RAB 0 265 006 510
2.5 [70]	2,5l 81 kW AEU 5 Zyl.	
Duo sensor, acceleration and yaw rate, brake system	08.96-06.03	0 265 005 214
Wheel speed sensor, front	08.96-06.03	0 265 006 407
Wheel speed sensor, rear	08.96-06.03	LAB,MVB 0 265 006 508 LAB,OBG 0 265 006 408 MVB,RAB 0 265 006 510 OBB,RAB 0 265 006 409
2.5 [70]	2,5l 85 kW AET; APL; AVT 5 Zyl.	
Knock sensor	08.96-06.03	L30 0 261 231 066 L34 0 261 231 077
Duo sensor, acceleration and yaw rate, brake system	08.96-06.03	0 265 005 214
Wheel speed sensor, front	08.96-06.03	0 265 006 407
Wheel speed sensor, rear	08.96-06.03	LAB,MVB 0 265 006 508 LAB,OBG 0 265 006 408 MVB,RAB 0 265 006 510 OBB,RAB 0 265 006 409
2.5 Syncro [7D]	2,5l 81 kW AAF 5 Zyl.	
Duo sensor, acceleration and yaw rate, brake system	11.92-12.93	0 265 005 214
Wheel speed sensor, front	11.92-12.93	0 265 006 407
Wheel speed sensor, rear	11.92-12.93	LAB,MVB 0 265 006 508 MVB,RAB 0 265 006 510
2.5 Syncro [7D]	2,5l 81 kW ACU 5 Zyl.	
Knock sensor	01.94-10.96	L30 0 261 231 066 L34 0 261 231 077
Duo sensor, acceleration and yaw rate, brake system	01.94-10.96	0 265 005 214



Product



◀ California T4

Wheel speed sensor, front	01.94-10.96		0 265 006 407
Wheel speed sensor, rear	01.94-10.96	LAB,MVB	0 265 006 508
		MVB,RAB	0 265 006 510
Fg.no. 70..T..200 001→	01.96-10.96	LAB,OBB	0 265 006 408
		OBB,RAB	0 265 006 409

2.5 Syncro [7D] 2,5l 81 kW AEU 5 Zyl.

Duo sensor, acceleration and yaw rate, brake system	06.97-11.01		0 265 005 214
Wheel speed sensor, front	06.97-11.01		0 265 006 407
Wheel speed sensor, rear	06.97-11.01	LAB,MVB	0 265 006 508
		LAB,OBB	0 265 006 408
		MVB,RAB	0 265 006 510
		OBB,RAB	0 265 006 409

2.5 Syncro [7D] 2,5l 85 kW AET; APL; AVT 5 Zyl.

Knock sensor	08.96-06.03	L30	0 261 231 066
		L34	0 261 231 077
Duo sensor, acceleration and yaw rate, brake system	08.96-06.03		0 265 005 214
Wheel speed sensor, front	08.96-06.03		0 265 006 407
Wheel speed sensor, rear	08.96-06.03	LAB,MVB	0 265 006 508
		LAB,OBB	0 265 006 408
		MVB,RAB	0 265 006 510
		OBB,RAB	0 265 006 409

2.5 TDI [70] 2,5l 65 kW AJT 5 Zyl.

Air mass meter, diesel			
Fg.no. →70..1H048 284, →70..1X047 893	05.98-08.00		0 281 002 216
			0 986 284 001
Fg.no. 70..1H048 285→, 70..1X047 894→	09.00-06.03		0 281 002 463
			0 986 284 008

Boost pressure sensor, Diesel			
Fg.no. →70..1..200 000	05.98-04.01		0 281 002 177
Fg.no. 70..1..200 001→	05.01-06.03		0 281 002 399

Pedal position sensor, diesel			
Fg.no. →70..Y..000 940	05.98-05.99	GS	0 205 001 020

Duo sensor, acceleration and yaw rate, brake system	05.98-06.03		0 265 005 214
Wheel speed sensor, front	05.98-06.03		0 265 006 407
Wheel speed sensor, rear	05.98-06.03	LAB,MVB	0 265 006 508
		LAB,OBB	0 265 006 408
		MVB,RAB	0 265 006 510
		OBB,RAB	0 265 006 409

2.5 TDI [70] 2,5l 65 kW AYY 5 Zyl.

Air mass meter, diesel	10.01-06.03		0 281 002 463
			0 986 284 008

Boost pressure sensor, Diesel	10.01-06.03		0 281 002 399
Duo sensor, acceleration and yaw rate, brake system	10.01-06.03		0 265 005 214
Wheel speed sensor, front	10.01-06.03		0 265 006 407
Wheel speed sensor, rear	10.01-06.03	LAB,MVB	0 265 006 508
		LAB,OBB	0 265 006 408
		MVB,RAB	0 265 006 510
		OBB,RAB	0 265 006 409

2.5 TDI [70] 2,5l 75 kW ACV 5 Zyl.

Air mass meter, diesel			
Fg.no. →70..1H048 284, →70..1X047 893	05.98-08.00		0 281 002 216
			0 986 284 001
Fg.no. 70..1H048 285→, 70..1X047 894→	09.00-06.03		0 281 002 463
			0 986 284 008

Boost pressure sensor, Diesel			
Fg.no. →70..1..200 000	01.95-04.01		0 281 002 177
Fg.no. 70..1..200 001→	05.01-06.03		0 281 002 399

Pedal position sensor, diesel			
Fg.no. →70..Y..000 940	01.95-05.99	GS	0 205 001 020

Product



Duo sensor, acceleration and yaw rate, brake system	01.95-06.03		0 265 005 214

Wheel speed sensor, front	01.95-06.03		0 265 006 407
Wheel speed sensor, rear	01.95-06.03	LAB,MVB	0 265 006 508
		MVB,RAB	0 265 006 510
Fg.no. 70..T..200 001→	01.96-06.03	LAB,OBB	0 265 006 408
		OBB,RAB	0 265 006 409

2.5 TDI [70] 2,5l 75 kW AUF 5 Zyl.

Air mass meter, diesel			
Fg.no. →70..1H048 284, →70..1X047 893	05.99-08.00		0 281 002 216
			0 986 284 001
Fg.no. 70..1H048 285→, 70..1X047 894→	09.00-06.03		0 281 002 463
			0 986 284 008

Boost pressure sensor, Diesel			
Fg.no. →70..1..200 000	05.99-04.01		0 281 002 177
Fg.no. 70..1..200 001→	05.01-06.03		0 281 002 399

Duo sensor, acceleration and yaw rate, brake system	05.99-06.03		0 265 005 214
Wheel speed sensor, front	05.99-06.03		0 265 006 407
Wheel speed sensor, rear	05.99-06.03	LAB,MVB	0 265 006 508
		LAB,OBB	0 265 006 408
		MVB,RAB	0 265 006 510
		OBB,RAB	0 265 006 409

2.5 TDI [70] 2,5l 75 kW AXL 5 Zyl.

Duo sensor, acceleration and yaw rate, brake system	04.01-06.03		0 265 005 214
Wheel speed sensor, front	04.01-06.03		0 265 006 407
Wheel speed sensor, rear	04.01-06.03	LAB,MVB	0 265 006 508
		LAB,OBB	0 265 006 408
		MVB,RAB	0 265 006 510
		OBB,RAB	0 265 006 409

2.5 TDI [70] 2,5l 75 kW AYC 5 Zyl.

Air mass meter, diesel	04.01-06.03		0 281 002 463
			0 986 284 008

Duo sensor, acceleration and yaw rate, brake system	04.01-06.03		0 265 005 214
Wheel speed sensor, front	04.01-06.03		0 265 006 407
Wheel speed sensor, rear	04.01-06.03	LAB,MVB	0 265 006 508
		LAB,OBB	0 265 006 408
		MVB,RAB	0 265 006 510
		OBB,RAB	0 265 006 409

2.5 TDI [70] 2,5l 111 kW AHY 5 Zyl.

Air mass meter, diesel			
Fg.no. →70..1..001 319	05.98-05.00		0 280 217 529
			0 986 280 204
Fg.no. 70..1..001 320→	06.00-09.00		0 281 002 461
			0 986 284 007

Boost pressure sensor, Diesel	05.98-09.00		0 281 002 177

Pedal position sensor, diesel			
Fg.no. →70..Y..000 940	05.98-05.99	GS	0 205 001 020

Duo sensor, acceleration and yaw rate, brake system	05.98-09.00		0 265 005 214
Wheel speed sensor, front	05.98-09.00		0 265 006 407
Wheel speed sensor, rear	05.98-09.00	LAB,MVB	0 265 006 508
		LAB,OBB	0 265 006 408
		MVB,RAB	0 265 006 510
		OBB,RAB	0 265 006 409

2.5 TDI [70] 2,5l 111 kW AXG 5 Zyl.

Air mass meter, diesel	09.00-06.03		0 281 002 461
			0 986 284 007

Boost pressure sensor, Diesel			
Fg.no. →70..1..200 000	09.00-04.01		0 281 002 177
Fg.no. 70..1..200 001→	05.01-06.03		0 281 002 399



V



Duo sensor, acceleration and yaw rate, brake system	09.00-06.03		0 265 005 214
Wheel speed sensor, front	09.00-06.03		0 265 006 407
Wheel speed sensor, rear	09.00-06.03	LAB,MVB	0 265 006 508
		LAB,OB	0 265 006 408
		MVB,RAB	0 265 006 510
		OBB,RAB	0 265 006 409
2.5 TDI Syncro [7D]	2,5l 75 kW ACV 5 Zyl.		
Air mass meter, diesel			
Fg.no. →70..1H048 284, →70..1X047 893	05.98-08.00		0 281 002 216
			0 986 284 001
Fg.no. 70..1H048 285→,70..1X047 894→	09.00-06.03		0 281 002 463
			0 986 284 008
Boost pressure sensor, Diesel			
Fg.no. →70..1..200 000	03.98-04.01		0 281 002 177
Fg.no. 70..1..200 001→	05.01-06.03		0 281 002 399
Pedal position sensor, diesel			
Fg.no. →70..Y..000 940	03.98-05.99	GS	0 205 001 020
Duo sensor, acceleration and yaw rate, brake system	03.98-06.03		0 265 005 214
Wheel speed sensor, front	03.98-06.03		0 265 006 407
Wheel speed sensor, rear	03.98-06.03	LAB,MVB	0 265 006 508
		LAB,OB	0 265 006 408
		MVB,RAB	0 265 006 510
		OBB,RAB	0 265 006 409
2.5 TDI Syncro [7D]	2,5l 75 kW AXL 5 Zyl.		
Duo sensor, acceleration and yaw rate, brake system	04.01-06.03		0 265 005 214
Wheel speed sensor, front	04.01-06.03		0 265 006 407
Wheel speed sensor, rear	04.01-06.03	LAB,MVB	0 265 006 508
		LAB,OB	0 265 006 408
		MVB,RAB	0 265 006 510
		OBB,RAB	0 265 006 409
2.8 [70]	2,8l 103 kW AES 6 Zyl.		
Air mass meter, gasoline injection	05.96-05.00		0 280 217 512
			0 986 280 203
Phase sensor			
Mot.no. AES 010 241→	12.97-05.00		0 232 103 019
Speed sensor, ignition/injection	05.96-05.00		0 261 210 107
Temperature sensor, intake air, injection system	05.96-05.00		0 280 130 039
Duo sensor, acceleration and yaw rate, brake system	05.96-05.00		0 265 005 214
Wheel speed sensor, front	05.96-05.00		0 265 006 407
Wheel speed sensor, rear	05.96-05.00	LAB,MVB	0 265 006 508
		LAB,OB	0 265 006 408
		MVB,RAB	0 265 006 510
		OBB,RAB	0 265 006 409
2.8 [70]	2,8l 150 kW AMV 6 Zyl.		
Throttle valve assembly	05.00-06.03		0 280 750 086
Air mass meter, gasoline injection	05.00-06.03		0 280 218 017
			0 986 280 208
Phase sensor	05.00-06.03		0 232 103 019
Duo sensor, acceleration and yaw rate, brake system	05.00-06.03		0 265 005 214
Wheel speed sensor, front	05.00-06.03		0 265 006 407
Wheel speed sensor, rear	05.00-06.03	LAB,MVB	0 265 006 508
		LAB,OB	0 265 006 408
		MVB,RAB	0 265 006 510
		OBB,RAB	0 265 006 409




California T5

1.9 TDI [7H]	1,9l 62/63/75/77 kW AXB;AXC;BRR;BRS 4 Zyl.		
Air mass meter, diesel	04.03→		0 281 002 531
			0 986 284 009
Boost pressure sensor, Diesel	04.03→		0 281 002 399
2.0 [7H]	2,0l 85 kW AXA 4 Zyl.		
Throttle valve assembly	06.03→		0 280 750 167
Air mass meter, gasoline injection	06.03→		0 280 218 060
			0 986 280 216
Phase sensor	06.03→		0 232 101 031
Knock sensor	06.03→	OHL	0 261 231 146
2.5 TDI [7H]	2,5l 96/120/128 kW AXD;AXE;BLJ 5 Zyl.		
Air mass meter, diesel	02.03→		0 281 002 461
			0 986 284 007
Boost pressure sensor, Diesel	02.03→		0 281 002 401
2.5 TDI 4Motion [7H]	2,5l 96/128 kW AXD;AXE 5 Zyl.		
Air mass meter, diesel	07.04→		0 281 002 461
			0 986 284 007
Boost pressure sensor, Diesel	07.04→		0 281 002 401
3.2 [7H]	3,2l 170/173 kW BDL;BKK 6 Zyl.		
Throttle valve assembly	02.03→		0 280 750 086
Air mass meter, gasoline injection	02.03→		0 280 218 073
			0 986 280 222
Phase sensor	02.03→		0 232 103 019
Knock sensor	02.03→	OHL	0 261 231 146
3.2 4 Motion [7H]	3,2l 173 kW BKK 6 Zyl.		
Throttle valve assembly	07.04→		0 280 750 086
Air mass meter, gasoline injection	07.04→		0 280 218 073
			0 986 280 222
Phase sensor	07.04→		0 232 103 019
Knock sensor	07.04→	OHL	0 261 231 146

Caravelle T4

1.8 [70]	1,8l 49 kW PD 4 Zyl.		
Duo sensor, acceleration and yaw rate, brake system	12.90-07.92		0 265 005 214
Wheel speed sensor, front	12.90-07.92		0 265 006 407
Wheel speed sensor, rear	12.90-07.92	LAB,MVB	0 265 006 508
		MVB,RAB	0 265 006 510
1.9 D [70]	1,9l 45 kW 1X 4 Zyl.		
Duo sensor, acceleration and yaw rate, brake system	10.90-04.97		0 265 005 214
Wheel speed sensor, front	10.90-04.97		0 265 006 407
Wheel speed sensor, rear	10.90-04.97	LAB,MVB	0 265 006 508
		MVB,RAB	0 265 006 510
Fg.no. 70..T..200 001→	01.96-04.97	LAB,OB	0 265 006 408
		OBB,RAB	0 265 006 409
1.9 D Turbo [70]	1,9l 50 kW ABL 4 Zyl.		
Duo sensor, acceleration and yaw rate, brake system	10.92-06.03		0 265 005 214
Wheel speed sensor, front	10.92-06.03		0 265 006 407
Wheel speed sensor, rear	10.92-06.03	LAB,MVB	0 265 006 508
		MVB,RAB	0 265 006 510
Fg.no. 70..T..200 001→	01.96-06.03	LAB,OB	0 265 006 408
		OBB,RAB	0 265 006 409
2.0 [70]	2,0l 62 kW AAC 4 Zyl.		
Duo sensor, acceleration and yaw rate, brake system	09.90-06.03		0 265 005 214
Wheel speed sensor, front	09.90-06.03		0 265 006 407



◀ Caravelle T4

Wheel speed sensor, rear	09.90-06.03	LAB,MVB	0 265 006 508
		MVB,RAB	0 265 006 510
Fg.no. 70..T..200 001→	01.96-06.03	LAB,OBB	0 265 006 408
		OBB,RAB	0 265 006 409
2.4 D [70]		2,4l 55 kW AJA 5 Zyl.	
Duo sensor, acceleration and yaw rate, brake system	05.97-06.03		0 265 005 214
Wheel speed sensor, front	05.97-06.03		0 265 006 407
Wheel speed sensor, rear	05.97-06.03	LAB,MVB	0 265 006 508
		LAB,OBB	0 265 006 408
		MVB,RAB	0 265 006 510
		OBB,RAB	0 265 006 409
2.4 D [70]		2,4l 57 kW AAB 5 Zyl.	
Duo sensor, acceleration and yaw rate, brake system	09.90-05.98		0 265 005 214
Wheel speed sensor, front	09.90-05.98		0 265 006 407
Wheel speed sensor, rear	09.90-05.98	LAB,MVB	0 265 006 508
		MVB,RAB	0 265 006 510
Fg.no. 70..T..200 001→	01.96-05.98	LAB,OBB	0 265 006 408
		OBB,RAB	0 265 006 409
2.4 D Syncro [7D]		2,4l 57 kW AAB 5 Zyl.	
Duo sensor, acceleration and yaw rate, brake system	11.92-09.98		0 265 005 214
Wheel speed sensor, front	11.92-09.98		0 265 006 407
Wheel speed sensor, rear	11.92-09.98	LAB,MVB	0 265 006 508
		MVB,RAB	0 265 006 510
Fg.no. 70..T..200 001→	01.96-09.98	LAB,OBB	0 265 006 408
		OBB,RAB	0 265 006 409
2.5 [70]		2,5l 81 kW AAF 5 Zyl.	
Duo sensor, acceleration and yaw rate, brake system	11.90-12.93		0 265 005 214
Wheel speed sensor, front	11.90-12.93		0 265 006 407
Wheel speed sensor, rear	11.90-12.93	LAB,MVB	0 265 006 508
		MVB,RAB	0 265 006 510
2.5 [70]		2,5l 81 kW ACU 5 Zyl.	
Knock sensor	07.94-10.96	L30	0 261 231 066
		L34	0 261 231 077
Duo sensor, acceleration and yaw rate, brake system	07.94-10.96		0 265 005 214
Wheel speed sensor, front	07.94-10.96		0 265 006 407
Wheel speed sensor, rear	07.94-10.96	LAB,MVB	0 265 006 508
		MVB,RAB	0 265 006 510
Fg.no. 70..T..200 001→	01.96-10.96	LAB,OBB	0 265 006 408
		OBB,RAB	0 265 006 409
2.5 [70]		2,5l 81 kW AEN 5 Zyl.	
Duo sensor, acceleration and yaw rate, brake system	09.95-12.95		0 265 005 214
Wheel speed sensor, front	09.95-12.95		0 265 006 407
Wheel speed sensor, rear	09.95-12.95	LAB,MVB	0 265 006 508
		MVB,RAB	0 265 006 510
2.5 [70]		2,5l 81 kW AEU 5 Zyl.	
Duo sensor, acceleration and yaw rate, brake system	08.96-06.03		0 265 005 214
Wheel speed sensor, front	08.96-06.03		0 265 006 407
Wheel speed sensor, rear	08.96-06.03	LAB,MVB	0 265 006 508
		LAB,OBB	0 265 006 408
		MVB,RAB	0 265 006 510
		OBB,RAB	0 265 006 409
2.5 [70]		2,5l 85 kW AET; APL; AVT 5 Zyl.	
Knock sensor	08.96-06.03	L30	0 261 231 066
		L34	0 261 231 077
Duo sensor, acceleration and yaw rate, brake system	08.96-06.03		0 265 005 214



Wheel speed sensor, front	08.96-06.03		0 265 006 407
Wheel speed sensor, rear	08.96-06.03	LAB,MVB	0 265 006 508
		LAB,OBB	0 265 006 408
		MVB,RAB	0 265 006 510
		OBB,RAB	0 265 006 409
2.5 Syncro [7D]		2,5l 81 kW AAF 5 Zyl.	
Duo sensor, acceleration and yaw rate, brake system	11.92-12.93		0 265 005 214
Wheel speed sensor, front	11.92-12.93		0 265 006 407
Wheel speed sensor, rear	11.92-12.93	LAB,MVB	0 265 006 508
		MVB,RAB	0 265 006 510
2.5 Syncro [7D]		2,5l 81 kW ACU 5 Zyl.	
Knock sensor	01.94-10.96	L30	0 261 231 066
		L34	0 261 231 077
Duo sensor, acceleration and yaw rate, brake system	01.94-10.96		0 265 005 214
Wheel speed sensor, front	01.94-10.96		0 265 006 407
Wheel speed sensor, rear	01.94-10.96	LAB,MVB	0 265 006 508
		MVB,RAB	0 265 006 510
Fg.no. 70..T..200 001→	01.96-10.96	LAB,OBB	0 265 006 408
		OBB,RAB	0 265 006 409
2.5 Syncro [7D]		2,5l 81 kW AEU 5 Zyl.	
Duo sensor, acceleration and yaw rate, brake system	06.97-11.01		0 265 005 214
Wheel speed sensor, front	06.97-11.01		0 265 006 407
Wheel speed sensor, rear	06.97-11.01	LAB,MVB	0 265 006 508
		LAB,OBB	0 265 006 408
		MVB,RAB	0 265 006 510
		OBB,RAB	0 265 006 409
2.5 Syncro [7D]		2,5l 85 kW AET; APL; AVT 5 Zyl.	
Knock sensor	08.96-06.03	L30	0 261 231 066
		L34	0 261 231 077
Duo sensor, acceleration and yaw rate, brake system	08.96-06.03		0 265 005 214
Wheel speed sensor, front	08.96-06.03		0 265 006 407
Wheel speed sensor, rear	08.96-06.03	LAB,MVB	0 265 006 508
		LAB,OBB	0 265 006 408
		MVB,RAB	0 265 006 510
		OBB,RAB	0 265 006 409
2.5 TDI [70]		2,5l 65 kW AJT 5 Zyl.	
Air mass meter, diesel			
Fg.no. →70..1H048 284, →70..1X047 893	05.98-08.00		0 281 002 216
			0 986 284 001
Fg.no. 70..1H048 285→,70..1X047 894→	09.00-06.03		0 281 002 463
			0 986 284 008
Boost pressure sensor, Diesel			
Fg.no. →70..1..200 000	05.98-04.01		0 281 002 177
Fg.no. 70..1..200 001→	05.01-06.03		0 281 002 399
Pedal position sensor, diesel			
Fg.no. →70..Y..000 940	05.98-05.99	GS	0 205 001 020
Duo sensor, acceleration and yaw rate, brake system	05.98-06.03		0 265 005 214
Wheel speed sensor, front	05.98-06.03		0 265 006 407
Wheel speed sensor, rear	05.98-06.03	LAB,MVB	0 265 006 508
		LAB,OBB	0 265 006 408
		MVB,RAB	0 265 006 510
		OBB,RAB	0 265 006 409
2.5 TDI [70]		2,5l 65 kW AYY 5 Zyl.	
Air mass meter, diesel	10.01-06.03		0 281 002 463
			0 986 284 008
Boost pressure sensor, Diesel	10.01-06.03		0 281 002 399
Duo sensor, acceleration and yaw rate, brake system	10.01-06.03		0 265 005 214



Wheel speed sensor, front	10.01-06.03		0 265 006 407
Wheel speed sensor, rear	10.01-06.03	LAB,MVB	0 265 006 508
		LAB,OBV	0 265 006 408
		MVB,RAB	0 265 006 510
		OBV,RAB	0 265 006 409
2.5 TDI [70]		2,5l 75 kW ACV 5 Zyl.	
Air mass meter, diesel			
Fg.no. →70..1H048 284,→70..1X047 893	05.98-08.00		0 281 002 216
			0 986 284 001
Fg.no. 70..1H048 285→,70..1X047 894→	09.00-06.03		0 281 002 463
			0 986 284 008
Boost pressure sensor, Diesel			
Fg.no. →70..1..200 000	01.95-04.01		0 281 002 177
Fg.no. 70..1..200 001→	05.01-06.03		0 281 002 399
Pedal position sensor, diesel			
Fg.no. →70..Y..000 940	01.95-05.99	GS	0 205 001 020
Duo sensor, acceleration and yaw rate, brake system	01.95-06.03		0 265 005 214
Wheel speed sensor, front	01.95-06.03		0 265 006 407
Wheel speed sensor, rear	01.95-06.03	LAB,MVB	0 265 006 508
		MVB,RAB	0 265 006 510
Fg.no. 70..T..200 001→	01.96-06.03	LAB,OBV	0 265 006 408
		OBV,RAB	0 265 006 409
2.5 TDI [70]		2,5l 75 kW AUF 0 Zyl.	
Air mass meter, diesel			
Fg.no. →70..1H048 284,→70..1X047 893	05.99-08.00		0 281 002 216
			0 986 284 001
Fg.no. 70..1H048 285→,70..1X047 894→	09.00-06.03		0 281 002 463
			0 986 284 008
Boost pressure sensor, Diesel			
Fg.no. →70..1..200 000	05.99-04.01		0 281 002 177
Fg.no. 70..1..200 001→	05.01-06.03		0 281 002 399
Duo sensor, acceleration and yaw rate, brake system	05.99-06.03		0 265 005 214
Wheel speed sensor, front	05.99-06.03		0 265 006 407
Wheel speed sensor, rear	05.99-06.03	LAB,MVB	0 265 006 508
		LAB,OBV	0 265 006 408
		MVB,RAB	0 265 006 510
		OBV,RAB	0 265 006 409
2.5 TDI [70]		2,5l 75 kW AXL 5 Zyl.	
Duo sensor, acceleration and yaw rate, brake system	04.01-06.03		0 265 005 214
Wheel speed sensor, front	04.01-06.03		0 265 006 407
Wheel speed sensor, rear	04.01-06.03	LAB,MVB	0 265 006 508
		LAB,OBV	0 265 006 408
		MVB,RAB	0 265 006 510
		OBV,RAB	0 265 006 409
2.5 TDI [70]		2,5l 75 kW AYC 5 Zyl.	
Air mass meter, diesel	04.01-06.03		0 281 002 463
			0 986 284 008
Duo sensor, acceleration and yaw rate, brake system	04.01-06.03		0 265 005 214
Wheel speed sensor, front	04.01-06.03		0 265 006 407
Wheel speed sensor, rear	04.01-06.03	LAB,MVB	0 265 006 508
		LAB,OBV	0 265 006 408
		MVB,RAB	0 265 006 510
		OBV,RAB	0 265 006 409
2.5 TDI [70]		2,5l 111 kW AHY 5 Zyl.	
Air mass meter, diesel			
Fg.no. →70..1..001 319	05.98-05.00		0 280 217 529
			0 986 280 204
Fg.no. 70..1..001 320→	06.00-09.00		0 281 002 461
			0 986 284 007



Boost pressure sensor, Diesel	05.98-09.00		0 281 002 177
Pedal position sensor, diesel			
Fg.no. →70..Y..000 940	05.98-05.99	GS	0 205 001 020
Duo sensor, acceleration and yaw rate, brake system	05.98-09.00		0 265 005 214
Wheel speed sensor, front	05.98-09.00		0 265 006 407
Wheel speed sensor, rear	05.98-09.00	LAB,MVB	0 265 006 508
		LAB,OBV	0 265 006 408
		MVB,RAB	0 265 006 510
		OBV,RAB	0 265 006 409
2.5 TDI [70]		2,5l 111 kW AXG 5 Zyl.	
Air mass meter, diesel	09.00-06.03		0 281 002 461
			0 986 284 007
Boost pressure sensor, Diesel			
Fg.no. →70..1..200 000	09.00-04.01		0 281 002 177
Fg.no. 70..1..200 001→	05.01-06.03		0 281 002 399
Duo sensor, acceleration and yaw rate, brake system	09.00-06.03		0 265 005 214
Wheel speed sensor, front	09.00-06.03		0 265 006 407
Wheel speed sensor, rear	09.00-06.03	LAB,MVB	0 265 006 508
		LAB,OBV	0 265 006 408
		MVB,RAB	0 265 006 510
		OBV,RAB	0 265 006 409
2.5 TDI Syncro [7D]		2,5l 75 kW ACV 5 Zyl.	
Air mass meter, diesel			
Fg.no. →70..1H048 284,→70..1X047 893	05.98-08.00		0 281 002 216
			0 986 284 001
Fg.no. 70..1H048 285→,70..1X047 894→	09.00-06.03		0 281 002 463
			0 986 284 008
Boost pressure sensor, Diesel			
Fg.no. →70..1..200 000	03.98-04.01		0 281 002 177
Fg.no. 70..1..200 001→	05.01-06.03		0 281 002 399
Pedal position sensor, diesel			
Fg.no. →70..Y..000 940	03.98-05.99	GS	0 205 001 020
Duo sensor, acceleration and yaw rate, brake system	03.98-06.03		0 265 005 214
Wheel speed sensor, front	03.98-06.03		0 265 006 407
Wheel speed sensor, rear	03.98-06.03	LAB,MVB	0 265 006 508
		LAB,OBV	0 265 006 408
		MVB,RAB	0 265 006 510
		OBV,RAB	0 265 006 409
2.5 TDI Syncro [7D]		2,5l 75 kW AXL 5 Zyl.	
Duo sensor, acceleration and yaw rate, brake system	04.01-06.03		0 265 005 214
Wheel speed sensor, front	04.01-06.03		0 265 006 407
Wheel speed sensor, rear	04.01-06.03	LAB,MVB	0 265 006 508
		LAB,OBV	0 265 006 408
		MVB,RAB	0 265 006 510
		OBV,RAB	0 265 006 409
2.8 [70]		2,8l 103 kW AES 6 Zyl.	
Air mass meter, gasoline injection	01.96-05.00		0 280 217 512
			0 986 280 203
Phase sensor			
Mot.no. AES 010 241→	12.97-05.00		0 232 103 019
Speed sensor, ignition/injection	01.96-05.00		0 261 210 107
Temperature sensor, intake air, injection system	01.96-05.00		0 280 130 039
Duo sensor, acceleration and yaw rate, brake system	01.96-05.00		0 265 005 214
Wheel speed sensor, front	01.96-05.00		0 265 006 407
Wheel speed sensor, rear	01.96-05.00	LAB,MVB	0 265 006 508
		LAB,OBV	0 265 006 408
		MVB,RAB	0 265 006 510
		OBV,RAB	0 265 006 409



Product				
◀ Caravelle T4				
2.8 [70]	2,8l 150 kW AMV 6 Zyl.			
Throttle valve assembly	05.00-06.03			0 280 750 086
Air mass meter, gasoline injection	05.00-06.03			0 280 218 017 🔌 0 986 280 208
Phase sensor	05.00-06.03			0 232 103 019
Duo sensor, acceleration and yaw rate, brake system	05.00-06.03			0 265 005 214
Wheel speed sensor, front	05.00-06.03			0 265 006 407
Wheel speed sensor, rear	05.00-06.03	LAB,MVB		0 265 006 508
		LAB,OB		0 265 006 408
		MVB,RAB		0 265 006 510
		OB		0 265 006 409

Caravelle T5				
1.9 TDI [7H]	1,9l 62/63/75/77 kW AXB; AXC; BRR; BRS 4 Zyl.			
Air mass meter, diesel	04.03→			0 281 002 531 🔌 0 986 284 009
Boost pressure sensor, Diesel	04.03→			0 281 002 399
2.0 [7H]	2,0l 85 kW AXA 4 Zyl.			
Throttle valve assembly	06.03→			0 280 750 167
Air mass meter, gasoline injection	06.03→			0 280 218 060 🔌 0 986 280 216
Phase sensor	06.03→			0 232 101 031
Knock sensor	06.03→	OHL		0 261 231 146
2.5 TDI [7H]	2,5l 96/120/128 kW AXD; AXE; BLJ 5 Zyl.			
Air mass meter, diesel	02.03→			0 281 002 461 🔌 0 986 284 007
Boost pressure sensor, Diesel	02.03→			0 281 002 401
2.5 TDI 4 Motion [7H]	2,5l 96/128 kW AXD; AXE 5 Zyl.			
Air mass meter, diesel	07.04→			0 281 002 461 🔌 0 986 284 007
Boost pressure sensor, Diesel	07.04→			0 281 002 401
3.2 [7H]	3,2l 170/173 kW BDL; BKK 6 Zyl.			
Throttle valve assembly	02.03→			0 280 750 086
Air mass meter, gasoline injection	02.03→			0 280 218 073 🔌 0 986 280 222
Phase sensor	02.03→			0 232 103 019
Knock sensor	02.03→	OHL		0 261 231 146
3.2 4 Motion [7H]	3,2l 173 kW BKK 6 Zyl.			
Throttle valve assembly	07.04→			0 280 750 086
Air mass meter, gasoline injection	07.04→			0 280 218 073 🔌 0 986 280 222
Phase sensor	07.04→			0 232 103 019
Knock sensor	07.04→	OHL		0 261 231 146

Corrado				
1.8 G60 [50]	1,8l 118 kW PG 4 Zyl.			
Knock sensor	09.88-09.93	KZG		0 261 231 038
1.8 16V [50]	1,8l 98-102 kW KR 4 Zyl.			
Air flow sensor, gasoline injection	09.88-07.92			F 026 TX2 050 🔌 0 986 280 050
2.0 [50]	2,0l 85 kW 2E 4 Zyl.			
Knock sensor	04.93-09.94	KZA		0 261 231 064
2.0 16V [50]	2,0l 100 kW 9A 4 Zyl.			
Throttle valve sensor	08.91-07.95	AG		0 280 120 433
		GS		0 280 120 426
Air flow sensor, gasoline injection				
Fg.no. →50-N-035 000	08.91-07.92			0 438 121 076 🔌 0 986 439 376

Product				
Air flow sensor, gasoline injection				
Fg.no. 50-P-000 001→	08.91-07.95		0 986 439 389 🔌 F 026 TX2 059 🔌 0 986 439 389	
Pulse generator, ignition/Jetronic	08.91-07.95		0 356 914 213	
Temperature sensor, intake air, injection system	08.91-07.95		0 280 130 040	
2.8 [50]		2,8l 128 kW AAA 6 Zyl.		
Air mass meter, gasoline injection				
Fg.no. →50-P-020 000	08.91-07.93		0 280 213 021 🔌 0 986 280 122	
Fg.no. 50-R-000 001→	07.93-07.95		0 280 217 504	
Temperature sensor, intake air, injection system	08.91-07.95		0 280 130 039	
2.9 [50]		2,9l 140 kW ABV 6 Zyl.		
Air mass meter, gasoline injection				
Fg.no. →50-P-020 000	08.91-07.93		0 280 213 021 🔌 0 986 280 122	
Fg.no. 50-R-000 001→	07.93-07.95		0 280 217 504	
Speed sensor, ignition/injection	08.91-07.95		0 261 210 080	
Knock sensor	08.91-07.95	KZA	0 261 231 064	
		KZW	0 261 231 047	
Temperature sensor, intake air, injection system	08.91-07.95		0 280 130 039	

Crafter 30				
2.5 TDI [2E]	2,5l 65/80/100/120 kW BJJ; BJK; BJL; BJM 5 Zyl.			
Boost pressure sensor, Diesel	04.06→			0 281 002 401
Duo sensor, acceleration and yaw rate, brake system	04.06→			0 265 005 628

Crafter 35				
2.5 TDI [2E]	2,5l 65/80/100/120 kW BJJ; BJK; BJL; BJM 5 Zyl.			
Boost pressure sensor, Diesel	04.06→			0 281 002 401
Duo sensor, acceleration and yaw rate, brake system	04.06→			0 265 005 628

Crafter 50				
2.5 TDI [2E]	2,5l 80/100/120 kW BJK; BJL; BJM 5 Zyl.			
Boost pressure sensor, Diesel	04.06→			0 281 002 401
Duo sensor, acceleration and yaw rate, brake system	04.06→			0 265 005 628

Eos				
1.6 FSI [1F7]	1,6l 85 kW BLF 4 Zyl.			
Speed sensor, ignition/injection	05.06→	AG		0 261 210 250
Knock sensor	05.06→			0 261 231 146
Pressure sensor, intake manifold, gasoline	05.06→			0 261 230 095
2.0 FSI [1F7]	2,0l 110 kW BVY; BVZ 4 Zyl.			
Knock sensor	05.06→	OHL		0 261 231 146
Pressure sensor, intake manifold, gasoline	05.06→			0 261 230 031
2.0 TDI [1F7]	2,0l 103 kW BMM 4 Zyl.			
Air mass meter, diesel	05.06→			0 281 002 461 🔌 0 986 284 007
Boost pressure sensor, Diesel	05.06→			0 281 002 401
2.0 TFSI [1F7]	2,0l 147 kW BWA 4 Zyl.			
Boost pressure sensor, gasoline	05.06→			0 261 230 073
3.2 [1F7]	3,2l 184 kW BUB 6 Zyl.			
Air mass meter, gasoline injection	05.06→			0 280 218 073 🔌 0 986 280 222
Phase sensor	05.06→			0 232 103 019
Knock sensor	05.06→	OHL		0 261 231 146



Product

Eurovan

2.5 [70]		2,5l 81 kW AAF 5 Zyl.	
Wheel speed sensor, front			
Fg.no. →70-H-199 999	09.91-12.93		0 265 006 407
2.5 [70]		2,5l 81 kW ACU 5 Zyl.	
Knock sensor	01.94-05.96	KZA	0 261 231 077
		KZS	0 261 231 066
Wheel speed sensor, front			
Fg.no. →70-H-199 999	01.94-12.95		0 265 006 407
2.8 [70]		2,8l 103 kW AES 6 Zyl.	
Speed sensor, ignition/injection	05.96-05.00		0 261 210 107
Temperature sensor, intake air, injection system	05.96-05.00		0 280 130 039
Wheel speed sensor, rear			
Fg.no. 70-T-200 001→	05.96-05.00	OVA,RAB	0 265 006 409

Fox

1.2 [521]		1,2l 40 kW BMD 3 Zyl.	
Knock sensor	04.05→		0 261 231 146
Accelerator pedal module			
Fg.no. →5Z..70030 000,→5Z..74051 000	04.05-03.07	LLE	0 280 752 214
Duo sensor, acceleration and yaw rate, brake system	04.05→		0 265 005 601
1.4 [521]		1,4l 55 kW BKR 4 Zyl.	
Knock sensor	04.05→		0 261 231 146
Pressure sensor, intake manifold, gasoline	04.05→		0 261 230 095
Accelerator pedal module			
Fg.no. →5Z..70030 000,→5Z..74051 000	04.05-03.07	LLE	0 280 752 214
Duo sensor, acceleration and yaw rate, brake system	04.05→		0 265 005 601
1.4 TDI [521]		1,4l 51 kW BNM 3 Zyl.	
Air mass meter, diesel	04.05→		0 281 002 531
			0 986 284 009
Boost pressure sensor, Diesel	04.05→		0 281 002 177
Duo sensor, acceleration and yaw rate, brake system	04.05→		0 265 005 601

Gol II

1.0 Mi 16V		1,0l 51 kW AZP 4 Zyl.	
Knock sensor	09.97-04.99		0 261 231 122
2.0 Mi 16V GTI		2,0l 107 kW AJE 4 Zyl.	
Knock sensor	10.95-07.98		0 261 231 075
	10.95-07.00	KZA	0 261 231 077
Temperature sensor, coolant, injection system	10.95-07.00		0 280 130 040

Gol III

1.0 Mi		1,0l 40 kW AZN 4 Zyl.	
Knock sensor	05.99-07.01		0 261 231 066
Pressure sensor, intake manifold, gasoline	05.99-01.01		0 261 230 011
	02.01-07.01		0 261 230 031
1.0 Mi		1,0l 48 kW AZN 4 Zyl.	
Speed sensor, ignition/injection	08.01-01.02		0 261 210 207
Knock sensor	08.01-02.05		0 261 231 146
Pressure sensor, intake manifold, gasoline	08.01-05.02		0 261 230 031
	06.02-02.05		0 261 230 095



Product

Golf

1.8 [1G1]		1,8l 79 kW PF 4 Zyl.	
Air flow sensor, gasoline injection	12.88-12.91		0 280 202 106
			0 986 280 008
Knock sensor	12.88-12.91	KZB	0 261 231 036
		KZG	0 261 231 038
1.8 [19]		1,8l 63 kW GX 4 Zyl.	
Air flow sensor, gasoline injection	08.84-07.87		0 438 120 162
1.8 [19]		1,8l 74-77 kW HT, RD 4 Zyl.	
Air flow sensor, gasoline injection	11.84-12.86		F 026 TX2 063
			0 986 284 063
Knock sensor	11.84-12.86		0 261 231 002
Temperature sensor, coolant, injection system	11.84-12.86		0 280 130 040
1.8 16V [1G1]		1,8l 95 kW PL 4 Zyl.	
Air flow sensor, gasoline injection	12.88-07.89		F 026 TX2 063
			0 986 284 063
Knock sensor	12.88-07.89	KZG	0 261 231 038
Temperature sensor, coolant, injection system	12.88-07.89		0 280 130 040
2.0 16V [1G1]		2,0l 100 kW 9A 4 Zyl.	
Air flow sensor, gasoline injection	01.90-12.91		0 438 121 076
			0 986 439 376
Knock sensor	01.90-12.91	KZB	0 261 231 036
Temperature sensor, coolant, injection system	01.90-12.91		0 280 130 040

Golf Cabriolet

2.0 [1E, 1V]		2,0l 85 kW ABA 4 Zyl.	
Air mass meter, gasoline injection			
Fg.no. →1E..X..899 000	01.96-07.99		0 280 217 117
			0 986 280 201
Fg.no. 1V..Y..800 001→	08.99-06.02		0 280 218 023
			0 986 280 209
Knock sensor	01.96-06.02		0 261 231 036
Temperature sensor, intake air, injection system	01.96-06.02		0 280 130 039
2.0 [1E, 1V]		2,0l 85 kW ADC 4 Zyl.	
Knock sensor	08.96-09.98		0 261 231 036

Golf I

1.6 i [15, 16]		1,6l 74 kW AFX 4 Zyl.	
Knock sensor	09.98→	KZA	0 261 231 077
Pressure sensor, intake manifold, gasoline	09.98→		0 261 230 011
Temperature sensor, intake air, injection system	09.98→		0 280 130 039
1.8 [15, 16]		1,8l 70 kW HV 4 Zyl.	
Knock sensor	01.88-12.97	KZA	0 261 231 045
1.8 i [15, 16]		1,8l 82 kW DX 4 Zyl.	
Air flow sensor, gasoline injection	01.83-12.95		F 026 TX2 051
			0 986 284 051

Golf I Cabriolet

1.8 [15]		1,8l 70 kW JH 4 Zyl.	
Air flow sensor, gasoline injection	08.83-08.93		0 438 120 162
1.8 [15]		1,8l 72 kW 2H 4 Zyl.	
Air flow sensor, gasoline injection	08.89-08.93		0 280 202 106
			0 986 280 008
Knock sensor	08.89-04.90	KZG	0 261 231 014
	05.90-08.93	KZG	0 261 231 038
1.8 [15]		1,8l 82 kW DX;KT 4 Zyl.	
Air flow sensor, gasoline injection	01.86-07.92		F 026 TX2 051
			0 986 284 051



Product

Golf II			
1.3 [19, 1G] 1,3l 40 kW NZ 4 Zyl.			
Air flow sensor, gasoline injection	08.85-07.92	0 280 200 048	
		0 986 280 030	
1.6 [19, 1G] 1,6l 51-53 kW EZ, EZA; PN; RF 4 Zyl.			
Temperature sensor, coolant, injection system	08.83-07.92	0 280 130 040	
1.8 [19, 1G] 1,8l 62/66 kW GU; RH 4 Zyl.			
Temperature sensor, coolant, injection system	11.83-10.91	0 280 130 040	
1.8 [19, 1G] 1,8l 66 kW GX 4 Zyl.			
Air flow sensor, gasoline injection	01.84-07.88	F 026 TX2 063	
		F 026 TX2 063	
	08.86-07.88	0 438 120 162	
Temperature sensor, coolant, injection system	01.84-07.88	0 280 130 040	
1.8 [19, 1G] 1,8l 77/79 kW PF; RV 4 Zyl.			
Air flow sensor, gasoline injection	01.87-11.92	0 280 202 106	
		0 986 280 008	
Knock sensor	08.88-11.92	0 261 231 036	
	01.87-07.88	0 261 231 038	
1.8 [19, 1G] 1,8l 79 kW RD 4 Zyl.			
Air flow sensor, gasoline injection	08.85-10.87	F 026 TX2 063	
		F 026 TX2 063	
Knock sensor	08.85-10.87	0 261 231 038	
Temperature sensor, coolant, injection system	08.85-10.87	0 280 130 040	
1.8 [19, 1G] 1,8l 79 kW RG 4 Zyl.			
Air flow sensor, gasoline injection	08.86-07.87	F 026 TX2 051	
		F 026 TX2 051	
1.8 [19, 1G] 1,8l 82 kW EV; GZ 4 Zyl.			
Air flow sensor, gasoline injection			
Fg.no. →19..G..640 000	01.84-03.86	0 438 120 189	
Fg.no. 16..G..640 001→	04.86-07.87	F 026 TX2 051	FOB
		F 026 TX2 051	
1.8 [19, 1G] 1,8l 82 kW PB 4 Zyl.			
Air flow sensor, gasoline injection	01.87-10.91	0 280 202 106	
		0 986 280 008	
Knock sensor	08.88-10.91	0 261 231 036	
	01.87-07.88	0 261 231 038	
1.8 [19, 1G] 1,8l 95 kW PL 4 Zyl.			
Throttle valve sensor	02.86-10.91	0 280 120 426	
Air flow sensor, gasoline injection	02.86-10.91	F 026 TX2 063	
		F 026 TX2 063	
Knock sensor	08.88-10.91	0 261 231 036	
	02.86-07.88	0 261 231 038	
1.8 [19, 1G] 1,8l 102 kW KR 4 Zyl.			
Throttle valve sensor	02.86-10.91	0 280 120 426	
Air flow sensor, gasoline injection	02.86-10.91	F 026 TX2 050	
		F 026 TX2 050	
1.8 G60 [19, 1G] 1,8l 118 kW PG 4 Zyl.			
Knock sensor	04.90-07.91	0 261 231 036	
1.8 G60 syncro [19, 1G1, 1G4] 1,8l 118 kW PG 4 Zyl.			
Knock sensor	01.90-07.91	0 261 231 036	KZB
Temperature sensor, coolant, injection system	01.90-07.91	0 280 130 040	
1.8 G60 syncro [19, 1G1, 1G4] 1,8l 118 kW 1H 4 Zyl.			
Knock sensor	04.89-07.89	0 261 231 038	KZG
Temperature sensor, coolant, injection system	04.89-12.89	0 280 130 040	
1.8 i 1,8l 82 kW EV 4 Zyl.			
Air flow sensor, gasoline injection			
Fg.no. 19..G..6400.000→	11.84-12.92	0 438 120 189	
Fg.no. 19..G..6400.001→	11.84-12.92	F 026 TX2 051	
		F 026 TX2 051	
1.8 i 1,8l 102 kW KR 16V 4 Zyl.			
Air flow sensor, gasoline injection	09.86-12.90	F 026 TX2 050	
		F 026 TX2 050	

Product

1.8 syncro [19, 1G1, 1G4] 1,8l 66 kW GX 4 Zyl.	
Air flow sensor, gasoline injection	02.86-07.88
	F 026 TX2 063
1.8 syncro [19, 1G1, 1G4] 1,8l 66-72 kW 1P 4 Zyl.	
Air flow sensor, gasoline injection	08.88-07.91
	0 280 202 106
	0 986 280 008
Knock sensor	08.88-07.91
	0 261 231 038
2.0 i 2,0l 110 kW AAL 4 Zyl.	
Air flow sensor, gasoline injection	08.89-10.92
	F 026 TX2 050
	F 026 TX2 050

Golf III			
1.4 [1H1] 1,4l 40-44 kW AEX 4 Zyl.			
Knock sensor	07.95-12.97	KZA	0 261 231 045
Pressure sensor, intake manifold, gasoline	07.95-12.97		0 261 230 011
1.6 [1H1] 1,6l 55 kW AEE 4 Zyl.			
Knock sensor	07.95-12.97	KZA	0 261 231 045
1.6 [1H1] 1,6l 74 kW AEK 4 Zyl.			
Air mass meter, gasoline injection	10.94-12.95		0 280 217 103
Knock sensor	10.94-12.95	KZB	0 261 231 036
Temperature sensor, intake air, injection system	10.94-12.95		0 280 130 039
1.6 [1H1] 1,6l 74 kW AFT; AKS 4 Zyl.			
Knock sensor	12.95-12.97	KZB	0 261 231 036
Temperature sensor, intake air, injection system	12.95-12.97		0 280 130 039
1.6 i [1H4] 1,6l 74 kW AFX 4 Zyl.			
Pressure sensor, intake manifold, gasoline	11.96-12.99		0 261 230 011
1.8 i [1H4] 1,8l 82 kW AFV 4 Zyl.			
Pressure sensor, intake manifold, gasoline	11.96-12.99		0 261 230 011
1.8 syncro [1H1] 1,8l 66 kW ABS 4 Zyl.			
Temperature sensor, coolant, injection system	01.93-09.94		0 280 130 040
1.9 SDI [1H1] 1,9l 47 kW AEY 4 Zyl.			
Pedal position sensor, diesel	01.95-12.97	AG	0 205 001 031
		GS	0 205 001 032
1.9 TDI [1H1] 1,9l 66 kW AHU; ALE 4 Zyl.			
Pedal position sensor, diesel	08.96-12.97	AG	0 205 001 031
		GS	0 205 001 032
1.9 TDI [1H1] 1,9l 66 kW 1Z 4 Zyl.			
Pressure sensor, intake manifold, diesel			
Fg.no. →1H..SP078 090,→1H..SK009 001	09.93-09.94		0 261 230 037
Pedal position sensor, diesel	08.95→	AG	0 205 001 031
		GS	0 205 001 032
1.9 TDI [1H1] 1,9l 81 kW AFN 4 Zyl.			
Pedal position sensor, diesel	03.96-12.97	AG	0 205 001 031
		GS	0 205 001 032
1.9 TDI syncro [1H1] 1,9l 66 kW 1Z 4 Zyl.			
Pedal position sensor, diesel	03.95-07.96	LLE	0 205 001 024
		RLE	0 205 001 023
2.0 [1H1] 2,0l 79 kW AEP 4 Zyl.			
Knock sensor	01.95-12.97	KZA	0 261 231 077
2.0 [1H1] 2,0l 85 kW ABA 4 Zyl.			
Air mass meter, gasoline injection	01.94-12.97		0 280 217 103
Pulse generator, ignition/Jetronic			
Fg.no. →1H-P-999 000	10.92-08.93		0 261 210 094
Knock sensor	10.92-10.97	KZB	0 261 231 036
Temperature sensor, intake air, injection system	01.94-12.97		0 280 130 039
2.0 [1H1] 2,0l 85/110 kW ABF; ADY; AGG; 2E 4 Zyl.			
Knock sensor	11.91-12.97	KZA	0 261 231 077
2.0 i 2,0l 71 kW AEP 4 Zyl.			
Knock sensor	01.95-12.97	KZA	0 261 231 077
2.0 i [1H4] 2,0l 85 kW AFW 4 Zyl.			
Pressure sensor, intake manifold, gasoline	11.96-12.99		0 261 230 011



2.0i [1H4]	2,0l 85 kW 2E 4 Zyl.
Knock sensor	11.92-12.96 KZA 0 261 231 077
2.0 Mi	2,0l 85 kW 4 Zyl.
Knock sensor	01.94-07.98 0 261 231 036
Temperature sensor, intake air, injection system	01.94-07.98 0 280 130 039
2.0 syncro [1H1]	2,0l 85 kW AGG 4 Zyl.
Knock sensor	07.95-12.97 KZA 0 261 231 077
2.8 [1H1]	2,8l 120 kW AAA 6 Zyl.
Air mass meter, gasoline injection	07.94-05.96 0 280 217 504
	06.96-12.97 0 280 217 512
	0 986 280 203
Speed sensor, ignition/injection	07.94-12.97 0 261 210 080
Knock sensor	07.94-12.97 KZA 0 261 231 077
	KZW 0 261 231 047
Temperature sensor, intake air, injection system	07.94-12.97 0 280 130 039
2.8 [1H1]	2,8l 128 kW AAA 6 Zyl.
Air mass meter, gasoline injection	01.92-06.92 0 280 213 021
	0 986 280 122
	08.94-07.95 0 280 217 504
	07.92-05.96 0 280 217 504
	06.96-12.97 0 280 217 512
	0 986 280 203
Fg.no. 1H-T-000 001→	07.95→ 0 280 217 512
	0 986 280 203
Speed sensor, ignition/injection	01.92→ 0 261 210 080
Knock sensor	01.92→ KZA 0 261 231 077
	KZW 0 261 231 047
Temperature sensor, intake air, injection system	01.92→ 0 280 130 039
2.8i VR6	2,8l 120 kW AAA 6 Zyl.
Air mass meter, gasoline injection	07.94-05.96 0 280 217 504
	06.96-12.97 0 280 217 512
	0 986 280 203
Speed sensor, ignition/injection	07.94-12.97 0 261 210 080
Knock sensor	07.94-12.97 KZA 0 261 231 077
	KZW 0 261 231 047
Temperature sensor, intake air, injection system	07.94-12.97 0 280 130 039
2.8i VR6 [1H4]	2,8l 128 kW AAA 6 Zyl.
Air mass meter, gasoline injection	10.93-06.94 0 280 213 021
	0 986 280 122
	07.94-05.96 0 280 217 504
	06.96-12.99 0 280 217 512
	0 986 280 203
Knock sensor	10.93-12.99 KZA 0 261 231 077
Temperature sensor, intake air, injection system	10.93-12.99 0 280 130 039
2.9 syncro [1H1]	2,9l 140 kW ABV 6 Zyl.
Air mass meter, gasoline injection	01.94-12.97 0 280 217 504
Speed sensor, ignition/injection	
Fg.no. →1H-S-990 000	01.94-07.95 0 261 210 080
Fg.no. 1H-T-000 001→	07.95-12.97 0 261 210 107
Knock sensor	01.94-12.97 KZA 0 261 231 077
	KZW 0 261 231 047
Temperature sensor, intake air, injection system	01.94-12.97 0 280 130 039

Golf III Cabriolet

1.6 [1E7]	1,6l 74 kW AEK 4 Zyl.
Air mass meter, gasoline injection	10.94-12.95 0 280 217 103
Temperature sensor, intake air, injection system	10.94-12.95 0 280 130 039
1.6 [1E7]	1,6l 74 kW AFT; AKS 4 Zyl.
Temperature sensor, intake air, injection system	12.95-04.98 0 280 130 039
1.9 TDI [1E7]	1,9l 66 kW AHU; 1Z 4 Zyl.
Pedal position sensor, diesel	08.95-04.98 AG 0 205 001 031
	GS 0 205 001 032




1.9 TDI [1E7]	1,9l 81 kW AFN 4 Zyl.
Pedal position sensor, diesel	09.96-04.98 0 205 001 032
2.0 [1E7]	2,0l 85 kW ADY; AGG; AKR 4 Zyl.
Knock sensor	10.94-04.98 KZA 0 261 231 077
2.0 [1E7]	2,0l 85 kW 2E 4 Zyl.
Pulse generator, ignition/Jetronic	09.93-09.94 0 356 914 213
Knock sensor	09.93-09.94 KZA 0 261 231 077

Golf III Variant

1.4 [1H5]	1,4l 44 kW AEX; APQ 4 Zyl.
Knock sensor	07.95-02.99 0 261 231 045
Pressure sensor, intake manifold, gasoline	07.95-02.99 0 261 230 011
1.6 [1H5]	1,6l 74 kW AEK 4 Zyl.
Air mass meter, gasoline injection	10.94-12.95 0 280 217 103
Knock sensor	10.94-12.95 0 261 231 036
Temperature sensor, intake air, injection system	10.94-12.95 0 280 130 039
1.6 [1H5]	1,6l 74 kW AFT; AKS 4 Zyl.
Knock sensor	12.95-02.99 0 261 231 036
Temperature sensor, intake air, injection system	12.95-02.99 0 280 130 039
1.9 SDI [1H5]	1,9l 47 kW AEY 4 Zyl.
Pedal position sensor, diesel	01.95-02.99 AG 0 205 001 031
	GS 0 205 001 032
1.9 TDI [1H5]	1,9l 66 kW AHU; ALE 4 Zyl.
Pedal position sensor, diesel	08.96-02.99 AG 0 205 001 031
	GS 0 205 001 032
1.9 TDI [1H5]	1,9l 66 kW 1Z 4 Zyl.
Boost pressure sensor, Diesel	07.93-07.96 0 261 230 037
Pedal position sensor, diesel	07.93-06.96 LLE 0 205 001 024
	RLE 0 205 001 023
1.9 TDI [1H5]	1,9l 81 kW AFN 4 Zyl.
Pedal position sensor, diesel	02.96-02.99 AG 0 205 001 031
	GS 0 205 001 032
1.9 TDI syncro [1H5]	1,9l 66 kW 1Z 4 Zyl.
Pedal position sensor, diesel	10.94-07.96 LLE 0 205 001 024
	RLE 0 205 001 023
2.0 [1H5]	2,0l 85 kW ADY; AGG; AKR 4 Zyl.
Knock sensor	10.94-02.99 0 261 231 077
2.0 [1H5]	2,0l 85 kW 2E 4 Zyl.
Pulse generator, ignition/Jetronic	07.93-09.94 0 356 914 213
Knock sensor	07.93-09.94 0 261 231 077
2.0 syncro [1H5]	2,0l 85 kW AGG 4 Zyl.
Knock sensor	07.95-12.97 KZA 0 261 231 077
2.9 syncro [1H5]	2,9l 140 kW ABV 6 Zyl.
Air mass meter, gasoline injection	
Fg.no. →1H-S-990 000	07.95-07.95 0 280 217 504
Fg.no. 1H-T-000 001→	08.95-12.97 0 280 217 512
	0 986 280 203
Speed sensor, ignition/injection	07.95-12.97 0 261 210 107
Knock sensor	07.95-12.97 KZA 0 261 231 077
	KZW 0 261 231 047
Temperature sensor, intake air, injection system	07.95-12.97 0 280 130 039

Golf IV

1.4 [1J1]	1,4l 55 kW AHW 4 Zyl.
Knock sensor	10.97-05.04 0 261 231 045
	WW 0 261 231 146
Accelerator pedal module	05.02-05.04 GS,LLE 0 280 752 214
Fg.no. 1J..Y..000 001→	05.99-04.02 AG,RLE 0 280 752 213
	05.99-05.04 RLE 0 280 752 210





Product				

◀ Golf IV

1.4 [1J1]		1,4l 55 kW AKQ 4 Zyl.	
Speed sensor, ignition/injection			
Mot.no. 001 001→001 068	10.97-05.00		0 261 210 194
Knock sensor	10.97-05.00		0 261 231 045
Accelerator pedal module			
Fg.no. 1J..Y..000 001→	05.99-05.00	AG,RLE	0 280 752 213
		GS,RLE	0 280 752 210
1.4 [1J1]		1,4l 55 kW APE; AXP 4 Zyl.	
Knock sensor	05.99-10.01		0 261 231 146
Pressure sensor, intake manifold, gasoline	05.99-10.01		0 261 230 031
Accelerator pedal module	05.99-10.01	AG,RLE	0 280 752 213
		GS,RLE	0 280 752 210
1.4 [1J1]		1,4l 55 kW BCA 4 Zyl.	
Speed sensor, ignition/injection	10.01-05.04		0 261 210 213
Knock sensor	10.01-05.04		0 261 231 146
Pressure sensor, intake manifold, gasoline	10.01-05.04		0 261 230 031
Accelerator pedal module	10.01-04.02	AG,RLE	0 280 752 213
	05.02-05.04	GS,LLE	0 280 752 214
	10.01-05.04	GS,RLE	0 280 752 210
1.6 [1J1]		1,6l 74 kW AEH 4 Zyl.	
Phase sensor	01.98-05.04		0 232 101 031
Speed sensor, ignition/injection	01.98-05.04		0 261 210 147
Accelerator pedal module			
Fg.no. 1J..Y..000 001→	05.99-04.02	AG,RLE	0 280 752 213
	05.99-04.01	GS,RLE	0 280 752 210
1.6 [1J1]		1,6l 74 kW AKL 4 Zyl.	
Phase sensor	10.97-05.04		0 232 101 031
Speed sensor, ignition/injection	10.97-05.04		0 261 210 147
Accelerator pedal module	05.02-05.04	GS,LLE	0 280 752 214
Fg.no. 1J..Y..000 001→	05.99-04.02	AG,RLE	0 280 752 213
	05.99-05.04	RLE	0 280 752 210
1.6 [1J1]		1,6l 74 kW APF 4 Zyl.	
Phase sensor	05.99-08.00		0 232 101 031
Speed sensor, ignition/injection	05.99-08.00		0 261 210 199
Accelerator pedal module	05.99-08.00	AG,RLE	0 280 752 213
		GS,RLE	0 280 752 210
1.6 [1J1]		1,6l 75 kW AVU 4 Zyl.	
Phase sensor	09.00-05.04		0 232 101 038
Speed sensor, ignition/injection	09.00-05.04		0 261 210 199
Accelerator pedal module	09.00-04.02	AG,RLE	0 280 752 213
	05.02-05.04	GS,LLE	0 280 752 214
	09.00-05.04	GS,RLE	0 280 752 210
1.6 [1J1]		1,6l 75 kW BFQ 4 Zyl.	
Speed sensor, ignition/injection	05.02-05.04		0 261 210 199
Knock sensor	05.02-05.04		0 261 231 146
Accelerator pedal module	05.02-05.04	GS,LLE	0 280 752 214
		GS,RLE	0 280 752 210
1.6 [1J1]		1,6l 77 kW ATN; AUS 4 Zyl.	
Speed sensor, ignition/injection	11.99-10.00		0 261 210 194
Knock sensor	11.99-10.00		0 261 231 045
Temperature sensor, intake air, injection system	11.99-10.00		0 280 130 085
Accelerator pedal module	11.99-10.00	AG,RLE	0 280 752 213
		GS,RLE	0 280 752 210
1.6 [1J1]		1,6l 77 kW AZD 4 Zyl.	
Speed sensor, ignition/injection	09.00-04.01		0 261 210 194
Knock sensor	09.00-11.01		0 261 231 146
Temperature sensor, intake air, injection system	09.00-11.01		0 280 130 085
Accelerator pedal module	09.00-11.01	AG,RLE	0 280 752 213
		GS,RLE	0 280 752 210

Product				


1.6 [1J1]		1,6l 77 kW BCB 4 Zyl.	
Knock sensor	11.01-05.04		0 261 231 146
Accelerator pedal module	11.01-04.02	AG,RLE	0 280 752 213
	05.02-05.04	GS,LLE	0 280 752 214
	11.01-05.04	GS,RLE	0 280 752 210
1.6 [9B1]		1,6l 74 kW AKL 4 Zyl.	
Speed sensor, ignition/injection	08.99-06.01		0 261 210 147
1.6 [9B1]		1,6l 74 kW BAH 4 Zyl.	
Speed sensor, ignition/injection	02.01-09.02		0 261 210 188
Knock sensor	02.01-03.07		0 261 231 146
Pressure sensor, intake manifold, gasoline	02.01-03.07		0 261 230 095
Boost pressure sensor, Diesel	02.01-03.07		0 261 230 095
1.6 FSI [1J1]		1,6l 81 kW BAD 4 Zyl.	
Throttle valve assembly	08.01-05.04		0 280 750 059
Air mass meter, gasoline injection	08.01-05.04		0 280 218 060
			0 986 280 216
Knock sensor	08.01-05.04		0 261 231 146
Pressure sensor, intake manifold, gasoline	08.01-05.04		0 261 230 079
Accelerator pedal module	08.01-04.02	AG,RLE	0 280 752 213
	05.02-05.04	GS,LLE	0 280 752 214
	08.01-05.04	GS,RLE	0 280 752 210
1.6 i		1,6l 75 kW BFQ 4 Zyl.	
Speed sensor, ignition/injection	07.03-02.07		0 261 210 199
Knock sensor	07.03-02.07		0 261 231 146
1.6 i		1,6l 78 kW AWB 4 Zyl.	
Air mass meter, gasoline injection	07.03→		0 280 218 060
			0 986 280 216
Speed sensor, ignition/injection	07.03→		0 261 210 254
1.6 i [1J1]		1,6l 74 kW AEH; AKL 4 Zyl.	
Speed sensor, ignition/injection	10.97-12.05	AG5,GS	0 261 210 147
Accelerator pedal module	04.99-12.05	AG,RLE	0 280 752 213
Fg.no. 1J-Y-000 001→	05.99-12.05	GS,RLE	0 280 752 210
1.8 [1J1]		1,8l 92 kW AGN 4 Zyl.	
Air mass meter, gasoline injection	10.97-10.00		0 280 218 002
			0 986 280 205
Phase sensor	10.97-10.00		0 232 101 024
Speed sensor, ignition/injection	10.97-10.00		0 261 210 147
Temperature sensor, intake air, injection system	10.97-10.00		0 280 130 085
Accelerator pedal module			
Fg.no. 1J..Y..000 001→	05.99-10.00	AG,RLE	0 280 752 213
		GS,RLE	0 280 752 210
1.8 GTI Turbo [9B1]		1,8l 110 kW AGU 4 Zyl.	
Air mass meter, gasoline injection	08.99-06.02		0 280 217 117
			0 986 280 201
Speed sensor, ignition/injection	08.99-06.01		0 261 210 147
	07.01-06.02		0 261 210 199
Boost pressure sensor, gasoline	08.99-06.02		0 281 002 177
Temperature sensor, intake air, injection system	08.99-06.02		0 280 130 085
1.8 GTI Turbo [9B1]		1,8l 132 kW AUQ 4 Zyl.	
Throttle valve assembly	07.02-03.07		0 280 750 036
Air mass meter, gasoline injection	07.02-03.07		0 280 218 063
			0 986 280 217
Speed sensor, ignition/injection	07.02-03.07		0 261 210 199
Knock sensor	07.02-03.07		0 261 231 146
Boost pressure sensor, gasoline	07.02-03.07		0 281 002 177
Temperature sensor, intake air, injection system	07.02-03.07		0 280 130 085
1.8 i		1,8l 92 kW BAF 4 Zyl.	
Throttle valve assembly	07.03→		0 280 750 159
Phase sensor	07.03→		0 232 101 024
Speed sensor, ignition/injection	07.03→		0 261 210 147



1.8i [1J1]		1,8l 92 kW AGN 4 Zyl.	
Air mass meter, gasoline injection	02.99-08.00		0 280 218 002
			0 986 280 205
Speed sensor, ignition/injection	02.99-08.00	AG5,GS	0 261 210 147
Accelerator pedal module	04.99-08.00	AG,RLE	0 280 752 213
Fg.no. 1J-Y-000 001→	05.99-08.00	GS,RLE	0 280 752 210
1.8T [1J1]		1,8l 110 kW AGU 4 Zyl.	
Air mass meter, gasoline injection	10.97-12.05		0 280 217 117
			0 986 280 201
Phase sensor	10.97-05.03		0 232 101 024
Speed sensor, ignition/injection	10.97-05.03		0 261 210 147
	02.99-12.05	AG5,GS	0 261 210 147
		TW	0 261 210 199
	10.97-05.03	WW	0 261 210 199
Boost pressure sensor, gasoline	10.97-05.03		0 281 002 177
Temperature sensor, intake air, injection system	02.99-12.05		0 280 130 085
Fg.no. →1J..3B065 915,→1J..3D013 548, →1J..3P064 809,→1J..3U201 122, →1J..3W335 000	10.97-09.02		0 280 130 085
Fg.no. 1J..3B065 916→,1J..3D013 549→, 1J..3P064 810→,1J..3U201 123→, 1J..3W335 001→	10.02-05.03		0 280 130 116
Accelerator pedal module	04.99-12.05	AG,RLE	0 280 752 213
	05.02-05.03	GS,LLE	0 280 752 214
Fg.no. 1J..Y..000 001→	05.99-04.02	AG,RLE	0 280 752 213
	05.99-05.03	RLE	0 280 752 210
Fg.no. 1J-Y-000 001→	05.99-12.05	GS,RLE	0 280 752 210
1.8T [1J1]		1,8l 110 kW ARZ 4 Zyl.	
Throttle valve assembly	05.99-09.00		0 280 750 036
Air mass meter, gasoline injection	05.99-09.00		0 280 218 032
			0 986 280 210
Speed sensor, ignition/injection	05.99-09.00		0 261 210 147
Boost pressure sensor, gasoline	05.99-09.00		0 281 002 177
Temperature sensor, intake air, injection system	05.99-09.00		0 280 130 085
Accelerator pedal module	05.99-09.00	AG,RLE	0 280 752 213
		GS,RLE	0 280 752 210
1.8T [1J1]		1,8l 110 kW AUM 4 Zyl.	
Throttle valve assembly	09.00-05.03		0 280 750 036
Air mass meter, gasoline injection	09.00-05.03		0 280 218 063
			0 986 280 217
Phase sensor	09.00-05.03		0 232 101 024
Speed sensor, ignition/injection	09.00-05.03		0 261 210 199
Knock sensor	09.00-05.03		0 261 231 146
Boost pressure sensor, gasoline	09.00-05.03		0 281 002 177
Temperature sensor, intake air, injection system			
Fg.no. →1J..3B065 915,→1J..3D013 548, →1J..3P064 809,→1J..3U201 122, →1J..3W335 000	09.00-09.02		0 280 130 085
Fg.no. 1J..3B065 916→,1J..3D013 549→, 1J..3P064 810→,1J..3U201 123→, 1J..3W335 001→	10.02-05.03		0 280 130 116
Accelerator pedal module	09.00-04.02	AG,RLE	0 280 752 213
	05.02-05.03	GS,LLE	0 280 752 214
	09.00-05.03	GS,RLE	0 280 752 210
1.8T [1J1]		1,8l 132 kW AUQ 4 Zyl.	
Throttle valve assembly	06.01-05.04		0 280 750 036
Air mass meter, gasoline injection	06.01-12.05		0 280 218 063
			0 986 280 217
Phase sensor	06.01-05.04		0 232 101 024
Speed sensor, ignition/injection	06.01-05.04		0 261 210 199
	05.03-12.05	TW	0 261 210 199
Knock sensor	06.01-12.05		0 261 231 146
Pressure sensor, intake manifold, gasoline	05.03-12.05		0 280 101 001



Boost pressure sensor, gasoline	06.01-05.04		0 281 002 177
Temperature sensor, intake air, injection system			
Fg.no. →1J..3B065 915,→1J..3D013 548, →1J..3P064 809,→1J..3U201 122, →1J..3W335 000	06.01-09.02		0 280 130 085
Fg.no. 1J..3B065 916→,1J..3D013 549→, 1J..3P064 810→,1J..3U201 123→, 1J..3W335 001→	10.02-05.04		0 280 130 116
Accelerator pedal module	06.01-04.02	AG,RLE	0 280 752 213
	05.02-05.04	GS,LLE	0 280 752 214
	06.01-05.04	GS,RLE	0 280 752 210
1.8 4 Motion [1J1]		1,8l 92 kW AGN 4 Zyl.	
Air mass meter, gasoline injection	07.98-10.00		0 280 218 002
			0 986 280 205
Phase sensor	07.98-10.00		0 232 101 024
Speed sensor, ignition/injection	07.98-10.00		0 261 210 147
Temperature sensor, intake air, injection system	07.98-10.00		0 280 130 085
Accelerator pedal module			
Fg.no. 1J..Y..000 001→	05.99-10.00	AG,RLE	0 280 752 213
		GS,RLE	0 280 752 210
1.9 SDI [1J1]		1,9l 50 kW AGP 4 Zyl.	
Pedal position sensor, diesel			
Fg.no. →1J..XB044 157,→1J..XD091 223, →1J..XP072 544,→1J..XW180 709	10.97-07.98	GS,LLE	0 281 002 269
1.9 TDI [1J1]		1,9l 66 kW AGR 4 Zyl.	
Air mass meter, diesel			
Fg.no. 1J..XB045 001→,1J..XD092 001→, 1J..XP073 001→,1J..XW181 001→	08.98-09.02		0 281 002 757
	10.97-07.98	WW	0 280 217 121
			0 986 280 202
Boost pressure sensor, Diesel	10.97-09.02		0 281 002 177
Pedal position sensor, diesel			
Fg.no. →1J..XB044 157,→1J..XD091 223, →1J..XP072 544,→1J..XW180 709	10.97-07.98	GS,LLE	0 281 002 269
1.9 TDI [1J1]		1,9l 66 kW ALH 4 Zyl.	
Air mass meter, diesel	10.97-05.04		0 281 002 757
		WW	0 280 217 121
			0 986 280 202
Boost pressure sensor, Diesel			
Fg.no. →1J..3W385 000,→1J..3P278 330, →1J..3D390 630,→1J..3B139 990, →1J..3U346 620	10.97-11.02		0 281 002 177
Fg.no. 1J..3W385 001→,1J..3P278 331→, 1J..3D390 631→,1J..3B139 991→, 1J..3U346 621→	12.02-05.04		0 281 002 399
Pedal position sensor, diesel			
Fg.no. →1J..XB044 157,→1J..XD091 223, →1J..XP072 544,→1J..XW180 709	10.97-07.98	GS,LLE	0 281 002 269
1.9 TDI [1J1]		1,9l 74 kW ATD 4 Zyl.	
Air mass meter, diesel			
Fg.no. →1J..2B088 000,→1J..2D420 000, →1J..2P055 000,→1J..2U030 000, →1J..2W350 000	02.00-11.01	WW	0 281 002 757
			0 280 217 121
			0 986 280 202
Fg.no. 1J..2B088 001→,1J..2D420 001→, 1J..2P055 001→,1J..2U030 001→, 1J..2W350 001→	12.01-05.04		0 281 002 531
			0 986 284 009
Boost pressure sensor, Diesel			
Fg.no. →1J..3W385 000,→1J..3P278 330, →1J..3D390 630,→1J..3B139 990, →1J..3U346 620	02.00-11.02		0 281 002 177
Fg.no. 1J..3W385 001→,1J..3P278 331→, 1J..3D390 631→,1J..3B139 991→, 1J..3U346 621→	12.02-05.04		0 281 002 399



Product				

◀ Golf IV

1.9 TDI [1J1]	1,9l 74 kW AXR 4 Zyl.			
Air mass meter, diesel				
Fg.no. →1J..2B088 000,→1J..2D420 000, →1J..2P055 000,→1J..2U030 000, →1J..2W350 000	05.01-11.01			0 281 002 757
	WW			0 280 217 121
				 0 986 280 202
Fg.no. 1J..2B088 001→,1J..2D420 001→, 1J..2P055 001→,1J..2U030 001→, 1J..2W350 001→	12.01-05.04			0 281 002 531
				 0 986 284 009
Boost pressure sensor, Diesel	05.01-05.04			0 281 002 399
1.9 TDI [1J1]	1,9l 81 kW AHF 4 Zyl.			
Air mass meter, diesel				
	05.00-12.05			0 281 002 757
	WW			0 280 217 121
				 0 986 280 202
Fg.no. 1J..XB045 001→,1J..XD092 001→, 1J..XP073 001→,1J..XW181 001→	08.98-05.04			0 281 002 757
	WW			0 280 217 121
				 0 986 280 202
Boost pressure sensor, Diesel	05.00-12.05			0 281 002 177
Fg.no. →1J..3W385 000,→1J..3P278 330, →1J..3D390 630,→1J..3B139 990, →1J..3U346 620	10.97-11.02			0 281 002 177
Fg.no. 1J..3W385 001→,1J..3P278 331→, 1J..3D390 631→,1J..3B139 991→, 1J..3U346 621→	12.02-05.04			0 281 002 399
Pedal position sensor, diesel				
Fg.no. →1J..XB044 157,→1J..XD091 223, →1J..XP072 544	05.00-12.05	GS,LLE		0 281 002 269
Fg.no. →1J..XB044 157,→1J..XD091 223, →1J..XP072 544,→1J..XW180 709	10.97-07.98	GS,LLE		0 281 002 269
Fg.no. →1J..XW180 709	05.00-12.05	GS,LLE		0 281 002 269
1.9 TDI [1J1]	1,9l 81 kW ASV 4 Zyl.			
Air mass meter, diesel				
	05.00-05.04			0 281 002 757
	WW			0 280 217 121
				 0 986 280 202
Boost pressure sensor, Diesel				
Fg.no. →1J..3W385 000,→1J..3P278 330, →1J..3D390 630,→1J..3B139 990, →1J..3U346 620	05.00-11.02			0 281 002 177
Fg.no. 1J..3W385 001→,1J..3P278 331→, 1J..3D390 631→,1J..3B139 991→, 1J..3U346 621→	12.02-05.04			0 281 002 399
1.9 TDI [1J1]	1,9l 85 kW AJM; AUY 4 Zyl.			
Air mass meter, diesel				
	05.99-07.01			0 281 002 757
	WW			0 280 217 121
				 0 986 280 202
Boost pressure sensor, Diesel	05.99-07.01			0 281 002 177
1.9 TDI [1J1]	1,9l 96 kW ASZ 4 Zyl.			
Air mass meter, diesel				
Fg.no. →1J..2..600 000	04.01-04.02			0 280 217 529
				 0 986 280 204
Fg.no. 1J..2..600 001→	05.02-05.04			0 281 002 461
				 0 986 284 007
Boost pressure sensor, Diesel	04.01-05.04			0 281 002 177
1.9 TDI [1J1]	1,9l 110 kW ARL 4 Zyl.			
Air mass meter, diesel				
Fg.no. →1J..2..600 000	09.00-04.02			0 280 217 529
				 0 986 280 204
Fg.no. 1J..2..600 001→	05.02-05.04			0 281 002 461
				 0 986 284 007
Boost pressure sensor, Diesel	09.00-05.04			0 281 002 177
	WW			0 281 002 394

Product				


1.9 TDI [9B1]	1,9l 66 kW AGR; ALH 4 Zyl.			
Air mass meter, diesel				
	07.01-03.07			0 281 002 757
	WW			0 280 217 121
				 0 986 280 202
1.9 TDI 4 Motion [1J1]	1,9l 66 kW AGR 4 Zyl.			
Air mass meter, diesel				
Fg.no. 1J..XB045 001→,1J..XD092 001→, 1J..XP073 001→,1J..XW181 001→	08.98-04.02			0 281 002 757
	WW			0 280 217 121
				 0 986 280 202
Boost pressure sensor, Diesel	07.98-04.02			0 281 002 177
Pedal position sensor, diesel				
Fg.no. →1J..XB044 157,→1J..XD091 223, →1J..XP072 544,→1J..XW180 709	07.98-07.98	GS,LLE		0 281 002 269
1.9 TDI 4 Motion [1J1]	1,9l 74 kW ATD 4 Zyl.			
Air mass meter, diesel				
Fg.no. →1J..2B088 000,→1J..2D420 000, →1J..2P055 000,→1J..2U030 000, →1J..2W350 000	02.00-11.01			0 281 002 757
	WW			0 280 217 121
				 0 986 280 202
Fg.no. 1J..2B088 001→,1J..2D420 001→, 1J..2P055 001→,1J..2U030 001→, 1J..2W350 001→	12.01-06.05			0 281 002 531
				 0 986 284 009
Boost pressure sensor, Diesel				
Fg.no. →1J..3W385 000,→1J..3P278 330, →1J..3D390 630,→1J..3B139 990, →1J..3U346 620	02.00-11.02			0 281 002 177
Fg.no. 1J..3W385 001→,1J..3P278 331→, 1J..3D390 631→,1J..3B139 991→, 1J..3U346 621→	12.02-06.05			0 281 002 399
1.9 TDI 4 Motion [1J1]	1,9l 85 kW AJM; AUY 4 Zyl.			
Air mass meter, diesel				
	05.99-07.01			0 281 002 757
	WW			0 280 217 121
				 0 986 280 202
Boost pressure sensor, Diesel	05.99-07.01			0 281 002 177
1.9 TDI 4 Motion [1J1]	1,9l 96 kW ASZ 4 Zyl.			
Air mass meter, diesel				
Fg.no. →1J..2..600 000	04.01-04.02			0 280 217 529
				 0 986 280 204
Fg.no. 1J..2..600 001→	05.02-06.05			0 281 002 461
				 0 986 284 007
Boost pressure sensor, Diesel	04.01-06.05			0 281 002 177
1.9 TDI 4 Motion [1J1]	1,9l 110 kW ARL 4 Zyl.			
Air mass meter, diesel				
Fg.no. →1J..2..600 000	09.00-04.02			0 280 217 529
				 0 986 280 204
Fg.no. 1J..2..600 001→	05.02-06.05			0 281 002 461
				 0 986 284 007
Boost pressure sensor, Diesel	09.00-06.05			0 281 002 177
	WW			0 281 002 394
2.0 [1J1]	2,0l 85 kW APK; AQY 4 Zyl.			
Air mass meter, gasoline injection				
	08.98-05.04			0 280 218 002
				 0 986 280 205
Phase sensor	08.98-05.04			0 232 101 031
Speed sensor, ignition/injection	08.98-05.04			0 261 210 147
Knock sensor	08.98-05.04			0 261 231 045
	WW			0 261 231 146
Accelerator pedal module				
Fg.no. 1J..Y..000 001→	05.02-05.04	GS,LLE		0 280 752 214
	05.99-04.02	AG,RLE		0 280 752 213
	05.99-05.04	RLE		0 280 752 210



2.0 [1J1]			2,0l 85 kW AZG 4 Zyl.
Throttle valve assembly	05.01-04.02		0 280 750 061
Air mass meter, gasoline injection	05.01-04.02		0 280 218 060
			0 986 280 216
Phase sensor	05.01-04.02		0 232 101 031
Speed sensor, ignition/injection	05.01-04.02		0 261 210 199
Accelerator pedal module	05.01-04.02	AG,RLE	0 280 752 213
		GS,RLE	0 280 752 210
2.0 [1J1]			2,0l 85 kW AZJ 4 Zyl.
Throttle valve assembly	05.01-05.04		0 280 750 061
Air mass meter, gasoline injection	05.01-05.04		0 280 218 060
			0 986 280 216
Phase sensor	05.01-05.04		0 232 101 031
Speed sensor, ignition/injection	05.01-05.04		0 261 210 199
Knock sensor	05.01-05.04		0 261 231 146
Accelerator pedal module	05.01-04.02	AG,RLE	0 280 752 213
	05.02-05.04	GS,LLE	0 280 752 214
	05.01-05.04	GS,RLE	0 280 752 210
2.0 [1J1]			2,0l 85 kW BEH 4 Zyl.
Throttle valve assembly	05.02-05.03		0 280 750 061
Air mass meter, gasoline injection	05.02-05.03		0 280 218 060
			0 986 280 216
Phase sensor	05.02-05.03		0 232 101 031
Speed sensor, ignition/injection	05.02-05.03		0 261 210 199
Knock sensor	05.02-05.03		0 261 231 146
Accelerator pedal module	05.02-05.03	GS,LLE	0 280 752 214
		GS,RLE	0 280 752 210
2.0 [9B1]			2,0l 85 kW APK 4 Zyl.
Air mass meter, gasoline injection	08.99-06.02		0 280 218 002
			0 986 280 205
Speed sensor, ignition/injection	08.99-06.02		0 261 210 147
Knock sensor	08.99-09.00		0 261 231 045
	10.00-06.02		0 261 231 146
2.0 [9B1]			2,0l 85 kW BER 4 Zyl.
Throttle valve assembly	03.02-03.07		0 280 750 061
Air mass meter, gasoline injection	03.02-06.02		0 280 218 060
			0 986 280 216
Phase sensor	03.02-03.07		0 232 101 031
Speed sensor, ignition/injection	03.02-03.07		0 261 210 147
Knock sensor	03.02-03.07		0 261 231 146
Pressure sensor, intake manifold, gasoline	03.02-11.02		0 261 230 031
	12.02-03.07		0 261 230 095
2.0 i			2,0l 85 kW APK 4 Zyl.
Speed sensor, ignition/injection	07.03-02.04		0 261 210 147
Knock sensor	07.03-02.04	ZE	0 261 231 146
2.0 i [1J1]			2,0l 85 kW APK 4 Zyl.
Throttle valve assembly	02.99-12.05	FMP	0 280 750 061
Air mass meter, gasoline injection	02.99-12.05		0 280 218 002
			0 986 280 205
Speed sensor, ignition/injection	02.99-12.05	AG5,GS	0 261 210 147
Knock sensor	02.99-12.05	KZA	0 261 231 045
		WW	0 261 231 146
Accelerator pedal module	04.99-12.05	AG,RLE	0 280 752 213
Fg.no. 1J-Y-000 001→	05.99-12.05	GS,RLE	0 280 752 210
2.0 4 Motion [1J1]			2,0l 85 kW AZH 4 Zyl.
Throttle valve assembly	04.00-06.01		0 280 750 061
Air mass meter, gasoline injection	04.00-06.01		0 280 218 002
			0 986 280 205
Phase sensor	04.00-06.01		0 232 101 031
Speed sensor, ignition/injection	04.00-06.01		0 261 210 147
Knock sensor	04.00-06.01		0 261 231 045
		WW	0 261 231 146



Accelerator pedal module	04.00-06.01	AG,RLE	0 280 752 213
		GS,RLE	0 280 752 210
2.0 4 Motion [1J1]			2,0l 85 kW AZJ 4 Zyl.
Throttle valve assembly	05.01-06.05		0 280 750 061
Air mass meter, gasoline injection	05.01-06.05		0 280 218 060
			0 986 280 216
Phase sensor	05.01-06.05		0 232 101 031
Speed sensor, ignition/injection	05.01-06.05		0 261 210 199
Knock sensor	05.01-06.05		0 261 231 146
Accelerator pedal module	05.01-04.02	AG,RLE	0 280 752 213
	05.02-06.05	GS,LLE	0 280 752 214
	05.01-06.05	GS,RLE	0 280 752 210
2.3 [1J1]			2,3l 110 kW AGZ 5 Zyl.
Air mass meter, gasoline injection	10.97-02.01		0 280 217 529
			0 986 280 204
Phase sensor	10.97-02.01		0 232 103 019
Speed sensor, ignition/injection	10.97-02.01		0 261 210 177
Knock sensor	10.97-02.01		0 261 231 146
Temperature sensor, intake air, injection system	10.97-02.01		0 280 130 085
Accelerator pedal module			
Fg.no. 1J..Y..000 001→	05.99-02.01	AG,RLE	0 280 752 213
		GS,RLE	0 280 752 210
2.3 [1J1]			2,3l 125 kW AQN 5 Zyl.
Throttle valve assembly	09.00-05.04		0 280 750 097
Air mass meter, gasoline injection	09.00-05.04		0 280 218 017
			0 986 280 208
Phase sensor	09.00-05.04		0 232 103 019
Knock sensor	09.00-05.04		0 261 231 146
Accelerator pedal module	09.00-04.02	AG,RLE	0 280 752 213
	05.02-05.04	GS,LLE	0 280 752 214
	09.00-05.04	GS,RLE	0 280 752 210
2.3 4 Motion [1J1]			2,3l 110 kW AGZ 5 Zyl.
Air mass meter, gasoline injection	07.98-02.01		0 280 217 529
			0 986 280 204
Phase sensor	07.98-02.01		0 232 103 019
Speed sensor, ignition/injection	07.98-02.01		0 261 210 177
Knock sensor	07.98-02.01		0 261 231 146
Temperature sensor, intake air, injection system	07.98-02.01		0 280 130 085
Accelerator pedal module			
Fg.no. 1J..Y..000 001→	05.99-02.01	AG,RLE	0 280 752 213
		GS,RLE	0 280 752 210
2.3 4 Motion [1J1]			2,3l 125 kW AQN 5 Zyl.
Throttle valve assembly	09.00-06.05		0 280 750 097
Air mass meter, gasoline injection	09.00-06.05		0 280 218 017
			0 986 280 208
Phase sensor	09.00-06.05		0 232 103 019
Knock sensor	09.00-06.05		0 261 231 146
Accelerator pedal module	09.00-04.02	AG,RLE	0 280 752 213
	05.02-06.05	GS,LLE	0 280 752 214
	09.00-06.05	GS,RLE	0 280 752 210
2.8 [1J1]			2,8l 130 kW AFP 6 Zyl.
Throttle valve assembly	12.98-09.00		0 205 003 053
2.8 VR6 [9B1]			2,8l 147 kW BDF 6 Zyl.
Throttle valve assembly	07.02-07.03		0 280 750 097
Air mass meter, gasoline injection	07.02-07.03		0 280 218 017
			0 986 280 208
Phase sensor	07.02-07.03		0 232 103 019
Knock sensor	07.02-07.03		0 261 231 146
2.8 4 Motion [1J1]			2,8l 150 kW AQP;AUE 6 Zyl.
Throttle valve assembly			
Fg.no. →1J..Y..620 000	05.99-01.00	LLE	0 280 750 086
		RLE	0 280 750 097
Fg.no. 1J..Y..620 001→	02.00-04.01		0 280 750 097





1.6 FSI [1J5]		1,6l 81 kW BAD 4 Zyl.	
Throttle valve assembly	08.01-06.06		0 280 750 059
Air mass meter, gasoline injection	08.01-06.06		0 280 218 060 👉 0 986 280 216
Knock sensor	08.01-06.06		0 261 231 146
Pressure sensor, intake manifold, gasoline	08.01-06.06		0 261 230 079
Accelerator pedal module	08.01-04.02	AG,RLE	0 280 752 213
	05.02-06.06	GS,LLE	0 280 752 214
	08.01-06.06	GS,RLE	0 280 752 210
1.8 T [1J5]		1,8l 110 kW AGU 4 Zyl.	
Air mass meter, gasoline injection	05.00-05.03		0 280 217 111 👉 0 986 280 201
Phase sensor	05.00-05.03		0 232 101 024
Speed sensor, ignition/injection	05.00-05.03		0 261 210 147
		WW	0 261 210 199
Boost pressure sensor, gasoline	05.00-05.03		0 281 002 177
Temperature sensor, intake air, injection system			
Fg.no. →1J..3B065 915,→1J..3D013 548, →1J..3P064 809,→1J..3U201 122, →1J..3W335 000	05.00-09.02		0 280 130 085
Fg.no. 1J..3B065 916→,1J..3D013 549→, 1J..3P064 810→,1J..3U201 123→, 1J..3W335 001→	10.02-05.03		0 280 130 116
Accelerator pedal module	05.00-04.02	AG,RLE	0 280 752 213
	05.02-05.03	GS,LLE	0 280 752 214
	05.00-05.03	GS,RLE	0 280 752 210
1.8 T [1J5]		1,8l 110 kW ARZ 4 Zyl.	
Throttle valve assembly	05.99-09.00		0 280 750 036
Air mass meter, gasoline injection	05.99-09.00		0 280 218 032 👉 0 986 280 210
Speed sensor, ignition/injection	05.99-09.00		0 261 210 147
Boost pressure sensor, gasoline	05.99-09.00		0 281 002 177
Temperature sensor, intake air, injection system	05.99-09.00		0 280 130 085
Accelerator pedal module	05.99-09.00	AG,RLE	0 280 752 213
		GS,RLE	0 280 752 210
1.8 T [1J5]		1,8l 110 kW AUM 4 Zyl.	
Throttle valve assembly	09.00-05.03		0 280 750 036
Air mass meter, gasoline injection	09.00-05.03		0 280 218 063 👉 0 986 280 217
Phase sensor	09.00-05.03		0 232 101 024
Speed sensor, ignition/injection	09.00-05.03		0 261 210 199
Knock sensor	09.00-05.03		0 261 231 146
Boost pressure sensor, gasoline	09.00-05.03		0 281 002 177
Temperature sensor, intake air, injection system			
Fg.no. →1J..3B065 915,→1J..3D013 548, →1J..3P064 809,→1J..3U201 122, →1J..3W335 000	09.00-09.02		0 280 130 085
Fg.no. 1J..3B065 916→,1J..3D013 549→, 1J..3P064 810→,1J..3U201 123→, 1J..3W335 001→	10.02-05.03		0 280 130 116
Accelerator pedal module	09.00-04.02	AG,RLE	0 280 752 213
	05.02-05.03	GS,LLE	0 280 752 214
	09.00-05.03	GS,RLE	0 280 752 210
1.8 4 Motion [1J5]		1,8l 92 kW AGN 4 Zyl.	
Air mass meter, gasoline injection	05.99-10.00		0 280 218 002 👉 0 986 280 205
Phase sensor	05.99-10.00		0 232 101 024
Speed sensor, ignition/injection	05.99-10.00		0 261 210 147
Temperature sensor, intake air, injection system	05.99-10.00		0 280 130 085
Accelerator pedal module	05.99-10.00	AG,RLE	0 280 752 213
		GS,RLE	0 280 752 210



1.9 TDI [1J5]		1,9l 66 kW AGR 4 Zyl.	
Air mass meter, diesel	05.99-09.02		0 281 002 757
		WW	0 280 217 121 0 986 280 202
Boost pressure sensor, Diesel	05.99-09.02		0 281 002 177
1.9 TDI [1J5]		1,9l 66 kW ALH 4 Zyl.	
Air mass meter, diesel	05.99-06.06		0 281 002 757
		WW	0 280 217 121 0 986 280 202
Boost pressure sensor, Diesel			
Fg.no. →1J..3W385 000→,1J..3P278 330, →1J..3D390 630→,1J..3B139 990, →1J..3U346 620	05.99-11.02		0 281 002 177
Fg.no. 1J..3W385 001→,1J..3P278 331→, 1J..3D390 631→,1J..3B139 991→, 1J..3U346 621→	12.02-06.06		0 281 002 399
1.9 TDI [1J5]		1,9l 74 kW ATD 4 Zyl.	
Air mass meter, diesel			0 281 002 757
			Fg.no. →1J..2B088 000→,1J..2D420 000, →1J..2P055 000→,1J..2U030 000, →1J..2W350 000
Fg.no. 1J..2B088 001→,1J..2D420 001→, 1J..2P055 001→,1J..2U030 001→, 1J..2W350 001→	01.00-11.01 02.00-11.01	WW	0 280 217 121 0 986 280 202
Fg.no. 1J..2B088 001→,1J..2D420 001→, 1J..2P055 001→,1J..2U030 001→, 1J..2W350 001→	12.01-06.06		0 281 002 531 0 986 284 009
Boost pressure sensor, Diesel			
Fg.no. →1J..3W385 000→,1J..3P278 330, →1J..3D390 630→,1J..3B139 990, →1J..3U346 620	01.00-11.02		0 281 002 177
Fg.no. 1J..3W385 001→,1J..3P278 331→, 1J..3D390 631→,1J..3B139 991→, 1J..3U346 621→	12.02-06.06		0 281 002 399
1.9 TDI [1J5]		1,9l 74 kW AXR 4 Zyl.	
Air mass meter, diesel			0 281 002 757
		WW	0 280 217 121 0 986 280 202
Fg.no. →1J..2B088 000→,1J..2D420 000, →1J..2P055 000→,1J..2U030 000, →1J..2W350 000	05.01-11.01		0 281 002 531 0 986 284 009
Fg.no. 1J..2B088 001→,1J..2D420 001→, 1J..2P055 001→,1J..2U030 001→, 1J..2W350 001→	12.01-06.06		0 281 002 531 0 986 284 009
Boost pressure sensor, Diesel	05.01-06.06		0 281 002 399
1.9 TDI [1J5]		1,9l 81 kW AHF; ASV 4 Zyl.	
Air mass meter, diesel	05.99-06.06		0 281 002 757
		WW	0 280 217 121 0 986 280 202
Boost pressure sensor, Diesel			
Fg.no. →1J..3W385 000→,1J..3P278 330, →1J..3D390 630→,1J..3B139 990, →1J..3U346 620	05.99-11.02		0 281 002 177
Fg.no. 1J..3W385 001→,1J..3P278 331→, 1J..3D390 631→,1J..3B139 991→, 1J..3U346 621→	12.02-06.06		0 281 002 399
1.9 TDI [1J5]		1,9l 85 kW AJM; AUY 4 Zyl.	
Air mass meter, diesel	05.99-07.01		0 281 002 757
		WW	0 280 217 121 0 986 280 202
Boost pressure sensor, Diesel	05.99-07.01		0 281 002 177
1.9 TDI [1J5]		1,9l 96 kW ASZ 4 Zyl.	
Air mass meter, diesel			0 280 217 529 0 986 280 204
			Fg.no. →1J..2..600 000
Fg.no. 1J..2..600 001→	04.01-04.02 05.02-06.06		0 281 002 461 0 986 284 007
Boost pressure sensor, Diesel	04.01-06.06		0 281 002 177





Product				

◀ Golf IV Variant

1.9 TDI 4 Motion [1J5]		1,9l 66 kW AGR 4 Zyl.
Air mass meter, diesel	05.99-04.02	0 281 002 757
		WW 0 280 217 121
		🔌 0 986 280 202
Boost pressure sensor, Diesel	05.99-04.02	0 281 002 177
1.9 TDI 4 Motion [1J5]		1,9l 74 kW ATD 4 Zyl.
Air mass meter, diesel	02.00-11.01	0 281 002 757
		WW 0 280 217 121
		🔌 0 986 280 202
Fg.no. →1J..2B088 000,→1J..2D420 000,→1J..2P055 000,→1J..2U030 000,→1J..2W350 000	12.01-06.06	0 281 002 531
		🔌 0 986 284 009
Boost pressure sensor, Diesel		
Fg.no. →1J..3W385 000,→1J..3P278 330,→1J..3D390 630,→1J..3B139 990,→1J..3U346 620	02.00-11.02	0 281 002 177
Fg.no. 1J..3W385 001→,1J..3P278 331→,1J..3D390 631→,1J..3B139 991→,1J..3U346 621→	12.02-06.06	0 281 002 399
1.9 TDI 4 Motion [1J5]		1,9l 85 kW AJM; AUY 4 Zyl.
Air mass meter, diesel	05.99-07.01	0 281 002 757
		WW 0 280 217 121
		🔌 0 986 280 202
Boost pressure sensor, Diesel	05.99-07.01	0 281 002 177
1.9 TDI 4 Motion [1J5]		1,9l 96 kW ASZ 4 Zyl.
Air mass meter, diesel	04.01-04.02	0 280 217 529
		🔌 0 986 280 204
Fg.no. 1J..2..600 000	05.02-06.06	0 281 002 461
		🔌 0 986 284 007
Boost pressure sensor, Diesel	04.01-06.06	0 281 002 177
2.0 [1J5]		2,0l 85 kW APK; AQY 4 Zyl.
Air mass meter, gasoline injection	05.99-06.06	0 280 218 002
		🔌 0 986 280 205
Phase sensor	05.99-06.06	0 232 101 031
Speed sensor, ignition/injection	05.99-06.06	0 261 210 147
Knock sensor	05.99-06.06	0 261 231 045
		WW 0 261 231 146
Accelerator pedal module	05.99-04.02	AG,RLE 0 280 752 213
	05.02-06.06	GS,LLE 0 280 752 214
	05.99-06.06	GS,RLE 0 280 752 210
2.0 [1J5]		2,0l 85 kW AZJ 4 Zyl.
Throttle valve assembly	05.01-06.06	0 280 750 061
Air mass meter, gasoline injection	05.01-06.06	0 280 218 060
		🔌 0 986 280 216
Phase sensor	05.01-06.06	0 232 101 031
Speed sensor, ignition/injection	05.01-06.06	0 261 210 199
Knock sensor	05.01-06.06	0 261 231 146
Accelerator pedal module	05.01-04.02	AG,RLE 0 280 752 213
	05.02-06.06	GS,LLE 0 280 752 214
	05.01-06.06	GS,RLE 0 280 752 210
2.0 Bi-Fuel [1J5]		2,0l 85 kW BEH 4 Zyl.
Throttle valve assembly	05.02-06.06	0 280 750 061
Air mass meter, gasoline injection	05.02-06.06	0 280 218 060
		🔌 0 986 280 216
Phase sensor	05.02-06.06	0 232 101 031
Speed sensor, ignition/injection	05.02-06.06	0 261 210 199
Knock sensor	05.02-06.06	0 261 231 146
Accelerator pedal module	05.02-06.06	GS,LLE 0 280 752 214
		GS,RLE 0 280 752 210

Product				

2.0 4 Motion [1J5]		2,0l 85 kW AZH 4 Zyl.	
Throttle valve assembly	04.00-06.01	0 280 750 061	
Air mass meter, gasoline injection	04.00-06.01	0 280 218 002 🔌 0 986 280 205	
Phase sensor	04.00-06.01	0 232 101 031	
Speed sensor, ignition/injection	04.00-06.01	0 261 210 147	
Knock sensor	04.00-06.01		0 261 231 045
		WW	0 261 231 146
Accelerator pedal module	04.00-06.01	AG,RLE	0 280 752 213
		GS,RLE	0 280 752 210
2.0 4 Motion [1J5]		2,0l 85 kW AZJ 4 Zyl.	
Throttle valve assembly	05.01-06.06	0 280 750 061	
Air mass meter, gasoline injection	05.01-06.06	0 280 218 060 🔌 0 986 280 216	
Phase sensor	05.01-06.06	0 232 101 031	
Speed sensor, ignition/injection	05.01-06.06	0 261 210 199	
Knock sensor	05.01-06.06	0 261 231 146	
Accelerator pedal module	05.01-04.02	AG,RLE	0 280 752 213
	05.02-06.06	GS,LLE	0 280 752 214
	05.01-06.06	GS,RLE	0 280 752 210
2.3 [1J5]		2,3l 110 kW AGZ 5 Zyl.	
Air mass meter, gasoline injection	05.99-02.01	0 280 217 529 🔌 0 986 280 204	
Phase sensor	05.99-02.01	0 232 103 019	
Speed sensor, ignition/injection	05.99-02.01	0 261 210 177	
Knock sensor	05.99-02.01	0 261 231 146	
Temperature sensor, intake air, injection system	05.99-02.01	0 280 130 085	
Accelerator pedal module	05.99-02.01	AG,RLE	0 280 752 213
		GS,RLE	0 280 752 210
2.3 [1J5]		2,3l 125 kW AQN 5 Zyl.	
Throttle valve assembly	09.00-06.06	0 280 750 097	
Air mass meter, gasoline injection	09.00-06.06	0 280 218 017 🔌 0 986 280 208	
Phase sensor	09.00-06.06	0 232 103 019	
Knock sensor	09.00-06.06	0 261 231 146	
Accelerator pedal module	09.00-04.02	AG,RLE	0 280 752 213
	05.02-06.06	GS,LLE	0 280 752 214
	05.01-06.06	GS,RLE	0 280 752 210
2.3 4 Motion [1J5]		2,3l 110 kW AGZ 5 Zyl.	
Air mass meter, gasoline injection	05.99-02.01	0 280 217 529 🔌 0 986 280 204	
Phase sensor	05.99-02.01	0 232 103 019	
Speed sensor, ignition/injection	05.99-02.01	0 261 210 177	
Knock sensor	05.99-02.01	0 261 231 146	
Temperature sensor, intake air, injection system	05.99-02.01	0 280 130 085	
Accelerator pedal module	05.99-02.01	AG,RLE	0 280 752 213
		GS,RLE	0 280 752 210
2.3 4 Motion [1J5]		2,3l 125 kW AQN 5 Zyl.	
Throttle valve assembly	09.00-06.06	0 280 750 097	
Air mass meter, gasoline injection	09.00-06.06	0 280 218 017 🔌 0 986 280 208	
Phase sensor	09.00-06.06	0 232 103 019	
Knock sensor	09.00-06.06	0 261 231 146	
Accelerator pedal module	09.00-04.02	AG,RLE	0 280 752 213
	05.02-06.06	GS,LLE	0 280 752 214
	09.00-06.06	GS,RLE	0 280 752 210
2.8 4 Motion [1J5]		2,8l 150 kW AQP; AUE 6 Zyl.	
Throttle valve assembly			
Fg.no. →1J..Y..620 000	05.99-01.00	LLE	0 280 750 086
		RLE	0 280 750 097
Fg.no. 1J..Y..620 001→	02.00-04.01		0 280 750 097
Air mass meter, gasoline injection	05.99-04.01		0 280 218 017 🔌 0 986 280 208



Phase sensor	05.99-04.01		0 232 103 019
Knock sensor	05.99-04.01		0 261 231 146
Accelerator pedal module	05.99-04.01	AG,RLE	0 280 752 213
2.8 4 Motion [1J5]		2,8l 150 kW BDE 6 Zyl.	
Throttle valve assembly	05.01-06.06		0 280 750 097
Air mass meter, gasoline injection	05.01-06.06		0 280 218 017
			0 986 280 208
Phase sensor	05.01-06.06		0 232 103 019
Knock sensor	05.01-06.06		0 261 231 146
Accelerator pedal module	05.01-04.02	AG,RLE	0 280 752 213
	05.02-06.06	GS,LLE	0 280 752 214
	05.01-06.06	GS,RLE	0 280 752 210

Golf Plus

1.4 [5M1]		1,4l 55/59 kW BCA; BUD 4 Zyl.	
Speed sensor, ignition/injection	01.05-07.07	TW	0 261 210 199
			0 261 210 250
Knock sensor	01.05-07.07		0 261 231 146
Pressure sensor, intake manifold, gasoline	01.05-07.07		0 261 230 095
1.4 FSI [5M1]		1,4l 66 kW BLN 4 Zyl.	
Speed sensor, ignition/injection	07.05-05.06	TW	0 261 210 199
			0 261 210 250
Knock sensor	07.05-05.06		0 261 231 146
Pressure sensor, intake manifold, gasoline	07.05-05.06		0 261 230 095
1.4 TSI [5M1]		1,4l 90 kW CAXA 4 Zyl.	
Knock sensor	07.07→		0 261 231 146
Boost pressure sensor, gasoline	07.07→		0 281 002 399
1.4 TSI [5M1]		1,4l 103/125 kW BLG; BMY 4 Zyl.	
Speed sensor, ignition/injection	05.06→	TW	0 261 210 199
			0 261 210 250
Knock sensor	05.06→		0 261 231 146
Pressure sensor, intake manifold, gasoline	05.06→		0 261 230 081
Boost pressure sensor, gasoline	05.06→		0 281 002 401
1.6 [5M1]		1,6l 75 kW BSE; BSF 4 Zyl.	
Speed sensor, ignition/injection	05.05→	TW	0 261 210 199
			0 261 210 250
Knock sensor	05.05→		0 261 231 146
Pressure sensor, intake manifold, gasoline	05.05→		0 261 230 031
1.6 [5M1]		1,6l 75 kW CCSA 4 Zyl.	
Speed sensor, ignition/injection	11.07→		0 261 210 199
Knock sensor	11.07→		0 261 231 146
Pressure sensor, intake manifold, gasoline	11.07→		0 261 230 031
1.6 FSI [5M1]		1,6l 85 kW BLF 4 Zyl.	
Speed sensor, ignition/injection	01.05→	TW	0 261 210 199
			0 261 210 250
Knock sensor	01.05→		0 261 231 146
Pressure sensor, intake manifold, gasoline	01.05→		0 261 230 095
1.9 TDI [5M1]		1,9l 66/77 kW BKC; BLS; BRU; BXE; BXF 4 Zyl.	
Air mass meter, diesel	01.05→		0 281 002 531
			0 986 284 009
Speed sensor, diesel	01.05→	TW	0 261 210 233
			0 261 210 250
Boost pressure sensor, Diesel	01.05→		0 281 002 399
2.0 FSI [5M1]		2,0l 110 kW BLR; BLY; BVY; BVZ 4 Zyl.	
Speed sensor, ignition/injection	05.05→	TW	0 261 210 199
			0 261 210 250
Knock sensor	05.05→	OHL	0 261 231 146
Pressure sensor, intake manifold, gasoline	05.05→		0 261 230 031
2.0 TDI [5M1]		2,0l 96/100/103 kW AZV; BEE; BKD 4 Zyl.	
Air mass meter, diesel	01.05→		0 281 002 461
			0 986 284 007



Speed sensor, diesel	01.05→	TW	0 261 210 233
			0 261 210 250
Boost pressure sensor, Diesel	01.05→		0 281 002 401
2.0 TDI [5M1]		2,0l 103 kW BMM 4 Zyl.	
Speed sensor, diesel	12.05→	TW	0 261 210 233
			0 261 210 250
Boost pressure sensor, Diesel	12.05→		0 281 002 401

Golf V

1.4 [1K1]		1,4l 55 kW BCA 4 Zyl.	
Knock sensor	10.03-05.06		0 261 231 146
Pressure sensor, intake manifold, gasoline	10.03-05.06		0 261 230 095
1.4 [1K1]		1,4l 59 kW BUD 4 Zyl.	
Knock sensor	05.07→		0 261 231 146
Pressure sensor, intake manifold, gasoline	05.07→		0 261 230 095
1.4 FSI [1K1]		1,4l 59/66 kW BKG; BLN; BUD 4 Zyl.	
Knock sensor	10.03-11.06		0 261 231 146
Pressure sensor, intake manifold, gasoline	10.03-11.06		0 261 230 095
1.4 FSI [1K1]		1,4l 88 kW CAXA 4 Zyl.	
Knock sensor	07.07→		0 261 231 146
Boost pressure sensor, gasoline	07.07→		0 281 002 399
1.4 TSI [1K1]		1,4l 103/125 kW BLG; BMY 4 Zyl.	
Knock sensor	11.05→		0 261 231 146
Boost pressure sensor, gasoline	11.05→		0 281 002 401
1.6 [1K1]		1,6l 75 kW BGU; BSE; BSF; CCSA 4 Zyl.	
Speed sensor, ignition/injection	01.04→		0 261 210 199
Knock sensor	01.04→		0 261 231 146
Pressure sensor, intake manifold, gasoline	01.04→		0 261 230 031
1.6 FSI [1K1]		1,6l 85 kW BAG; BLF; BLP 4 Zyl.	
Speed sensor, ignition/injection	10.03→	AG	0 261 210 250
Knock sensor	10.03→		0 261 231 146
Pressure sensor, intake manifold, gasoline	10.03→		0 261 230 095
1.9 TDI [1K1]		1,9l 66 kW BRU 4 Zyl.	
Air mass meter, diesel	05.04-02.06		0 281 002 531
			0 986 284 009
Boost pressure sensor, Diesel	05.04-02.06		0 281 002 399
Pressure sensor, intake manifold, diesel	05.04-02.06		0 281 002 399
1.9 TDI [1K1]		1,9l 66 kW BXF 4 Zyl.	
Air mass meter, diesel	02.06→		0 281 002 531
			0 986 284 009
Boost pressure sensor, Diesel	02.06→		0 281 002 399
1.9 TDI [1K1]		1,9l 66 kW BXJ 4 Zyl.	
Boost pressure sensor, Diesel	05.07→		0 281 002 399
1.9 TDI [1K1]		1,9l 77 kW BKC 4 Zyl.	
Air mass meter, diesel	10.03-02.06		0 281 002 531
			0 986 284 009
Boost pressure sensor, Diesel	10.03-02.06		0 281 002 399
Pressure sensor, intake manifold, diesel	10.03-02.06		0 281 002 399
1.9 TDI [1K1]		1,9l 77 kW BLS; BXE 4 Zyl.	
Air mass meter, diesel	08.05→		0 281 002 531
			0 986 284 009
Boost pressure sensor, Diesel	08.05→		0 281 002 399
1.9 TDI 4 Motion [1K1]		1,9l 77 kW BKC 4 Zyl.	
Air mass meter, diesel	10.03-02.06		0 281 002 531
			0 986 284 009
Boost pressure sensor, Diesel	10.03-02.06		0 281 002 399
Pressure sensor, intake manifold, diesel	10.03-02.06		0 281 002 399
1.9 TDI 4 Motion [1K1]		1,9l 77 kW BLS; BXE 4 Zyl.	
Air mass meter, diesel	08.05→		0 281 002 531
			0 986 284 009
Boost pressure sensor, Diesel	08.05→		0 281 002 399

Product



◀ Golf V

2.0 FSI [1K1]	2,0l 110 kW	AXW; BLR; BLX; BLY; BVX	4 Zyl.
Knock sensor	01.04→	OHL	0 261 231 146
Pressure sensor, intake manifold, gasoline	01.04→		0 261 230 031
2.0 FSI [1K1]	2,0l 110 kW	BVY; BVZ	4 Zyl.
Knock sensor	11.05→	OHL	0 261 231 146
Pressure sensor, intake manifold, gasoline	11.05→		0 261 230 031
2.0 FSI 4 Motion [1K1]	2,0l 110 kW	AXW; BLR; BLX; BLY; BVX	4 Zyl.
Knock sensor	01.04→	OHL	0 261 231 146
Pressure sensor, intake manifold, gasoline	01.04→		0 261 230 031
2.0 FSI 4 Motion [1K1]	2,0l 110 kW	BVY; BVZ	4 Zyl.
Knock sensor	11.05→	OHL	0 261 231 146
Pressure sensor, intake manifold, gasoline	11.05→		0 261 230 031
2.0 GTI [1K1]	2,0l 147 kW	AXX; BPY; BWA	4 Zyl.
Speed sensor, ignition/injection	09.04→		0 261 210 199
Boost pressure sensor, gasoline	09.04→		0 261 230 073
2.0 GTI [1K1]	2,0l 169 kW	BYD	4 Zyl.
Speed sensor, ignition/injection	09.06→		0 261 210 199
Boost pressure sensor, gasoline	09.06→		0 281 002 401
2.0 SDI [1K1]	2,0l 55 kW	BDK	4 Zyl.
Air mass meter, diesel	01.04→		0 281 002 531  0 986 284 009
Pressure sensor, intake manifold, diesel	01.04→		0 281 002 399
2.0 TDI [1K1]	2,0l 100/103 kW	AZV; BKD	4 Zyl.
Air mass meter, diesel	10.03→		0 281 002 461  0 986 284 007
Boost pressure sensor, Diesel	10.03→		0 281 002 401
Pressure sensor, intake manifold, diesel	10.03→		0 281 002 401
2.0 TDI [1K1]	2,0l 103/125 kW	BMM; BMN	4 Zyl.
Air mass meter, diesel	12.04→		0 281 002 461  0 986 284 007
Boost pressure sensor, Diesel	12.04→		0 281 002 401
2.0 TDI 4 Motion [1K1]	2,0l 103 kW	BKD	4 Zyl.
Air mass meter, diesel	10.03→		0 281 002 461  0 986 284 007
Boost pressure sensor, Diesel	10.03→		0 281 002 401
Pressure sensor, intake manifold, diesel	10.03→		0 281 002 401
2.0 TDI 4 Motion [1K1]	2,0l 103 kW	BMM	4 Zyl.
Air mass meter, diesel	12.04→		0 281 002 461  0 986 284 007
Boost pressure sensor, Diesel	12.04→		0 281 002 401
3.2 R32 4 Motion [1K1]	3,2l 184 kW	BUB	6 Zyl.
Air mass meter, gasoline injection	11.05→		0 280 218 073  0 986 280 222
Phase sensor	11.05→		0 232 103 019
Knock sensor	11.05→	OHL	0 261 231 146

Golf V Variant

1.4 FSI [1K5]	1,4l 59 kW	BUD	4 Zyl.
Knock sensor	08.07→		0 261 231 146
Pressure sensor, intake manifold, gasoline	08.07→		0 261 230 095
1.4 FSI [1K5]	1,4l 88 kW	CAXA	4 Zyl.
Boost pressure sensor, gasoline	08.07→		0 281 002 399
1.4 TSI [1K5]	1,4l 103/125 kW	BLG; BMY	4 Zyl.
Knock sensor	05.07→		0 261 231 146
Boost pressure sensor, gasoline	05.07→		0 281 002 401
1.6 [1K5]	1,6l 75 kW	BSE; BSF	4 Zyl.
Speed sensor, ignition/injection	05.07→		0 261 210 199
Knock sensor	05.07→		0 261 231 146
Pressure sensor, intake manifold, gasoline	05.07→		0 261 230 031

Product



1.9 TDI [1K5]	1,9l 77 kW	BLS	4 Zyl.
Air mass meter, diesel	05.07→		0 281 002 531  0 986 284 009
Boost pressure sensor, Diesel	05.07→		0 281 002 401
1.9 TDI [1K5]	1,9l 77 kW	BXE	4 Zyl.
Air mass meter, diesel	05.07→		0 281 002 531  0 986 284 009
Boost pressure sensor, Diesel	05.07→		0 281 002 399
2.0 GTI [1K5]	2,0l 147 kW	BWA	4 Zyl.
Speed sensor, ignition/injection	05.07→		0 261 210 199
Boost pressure sensor, gasoline	05.07→		0 261 230 073
2.0 TDI [1K5]	2,0l 100/103 kW	AZV; BKD	4 Zyl.
Air mass meter, diesel	05.07→		0 281 002 461  0 986 284 007
Boost pressure sensor, Diesel	05.07→		0 281 002 401
Pressure sensor, intake manifold, diesel	05.07→		0 281 002 401
2.0 TDI [1K5]	2,0l 103 kW	BMM	4 Zyl.
Air mass meter, diesel	05.07→		0 281 002 461  0 986 284 007
Boost pressure sensor, Diesel	05.07→		0 281 002 401

Jetta

1.3 [1G2, 19E]	1,3l 40 kW	NZ	4 Zyl.
Air flow sensor, gasoline injection	02.87-07.92		0 280 200 048  0 986 280 030
1.4 TSI [1K2]	1,4l 103/125 kW	BLG; BMY	4 Zyl.
Boost pressure sensor, gasoline	07.06→		0 281 002 401
1.6 [1G2, 19E]	1,6l 51-55 kW	ABN; EZ, EZA; PN; RF	4 Zyl.
Temperature sensor, coolant, injection system	01.84-07.92		0 280 130 040
1.6 [1K2]	1,6l 75 kW	BSE; BSF	4 Zyl.
Speed sensor, ignition/injection	10.05→		0 261 210 199
Knock sensor	10.05→		0 261 231 146
Pressure sensor, intake manifold, gasoline	10.05→		0 261 230 031
1.6 CEX, GEX	1,6l 53 kW	ANL	4 Zyl.
Speed sensor, ignition/injection	10.98-12.99		0 261 210 145
Knock sensor	10.98-12.99	ZE	0 261 231 045
1.6 FSI [1K2]	1,6l 85 kW	BLF	4 Zyl.
Knock sensor	09.05→		0 261 231 146
Pressure sensor, intake manifold, gasoline	09.05→		0 261 230 095
1.6 i CI, GI, CIX, GIX	1,6l 64 kW	ATK	4 Zyl.
Phase sensor	10.99-02.07		0 232 101 031
Speed sensor, ignition/injection	10.99-02.07		0 261 210 145
Knock sensor	10.99-02.07		0 261 231 146
Temperature sensor, intake air, injection system	10.99-02.07		0 280 130 039
1.6 i King GT, GTX, AT	1,6l 74 kW	AHP	4 Zyl.
Air mass meter, gasoline injection	05.98-01.02		0 281 002 757 WW 0 280 217 121  0 986 280 202
Phase sensor	05.98-01.02		0 232 101 024
Speed sensor, ignition/injection	05.98-01.02		0 261 210 145
Knock sensor	05.98-01.02		0 261 231 045
Temperature sensor, intake air, injection system	05.98-01.02		0 280 130 039
1.8 [1G2, 19E]	1,8l 66 kW	GU	4 Zyl.
Temperature sensor, coolant, injection system	01.84-10.91		0 280 130 040
1.8 [1G2, 19E]	1,8l 66 kW	GX	4 Zyl.
Air flow sensor, gasoline injection	08.84-10.87	KAT	F 026 TX2 063  F 026 TX2 063
		OKA	0 438 120 162
1.8 [1G2, 19E]	1,8l 77/79 kW	PF; RV	4 Zyl.
Knock sensor	08.89-07.92	KZB	0 261 231 036
	02.87-07.92	KZG	0 261 231 038



1.8 [1G2, 19E]			1,8l 79 kW RD 4 Zyl.
Air flow sensor, gasoline injection	08.85-10.87		F 026 TX2 063 🔌 F 026 TX2 063
Knock sensor	08.85-10.87	KZG	0 261 231 038
1.8 [1G2, 19E]			1,8l 79 kW RG 4 Zyl.
Air flow sensor, gasoline injection	08.86-07.87		F 026 TX2 051 🔌 F 026 TX2 051
1.8 [1G2, 19E]			1,8l 82 kW EV; GZ 4 Zyl.
Air flow sensor, gasoline injection			
Fg.no. →16..G..640 000	01.84-03.86		0 438 120 189
Fg.no. 16..G..640 001→	04.86-07.87	FOB	F 026 TX2 051 🔌 F 026 TX2 051
1.8 [1G2, 19E]			1,8l 82 kW PB 4 Zyl.
Knock sensor	08.89-10.91	KZB	0 261 231 036
	02.87-10.91	KZG	0 261 231 038
1.8 [1H2]			1,8l 77 kW RV 4 Zyl.
Air flow sensor, gasoline injection	07.89-12.91		0 280 202 106 🔌 0 986 280 008
Knock sensor	07.89-12.91		0 261 231 004
		KZG	0 261 231 038
1.8 [16]			1,8l 79 kW PF 4 Zyl.
Air flow sensor, gasoline injection	12.88-12.91		0 280 202 106 🔌 0 986 280 008
Knock sensor	12.88-12.91		0 261 231 004
		KZG	0 261 231 038
1.8 syncro [1G2, 19E]			1,8l 66 kW GX 4 Zyl.
Air flow sensor, gasoline injection	08.87-07.88		F 026 TX2 063 🔌 F 026 TX2 063
1.8 syncro [1G2, 19E]			1,8l 72 kW 1P 4 Zyl.
Air flow sensor, gasoline injection	08.88-07.92		0 280 202 106 🔌 0 986 280 008
Knock sensor	08.88-07.92	KZG	0 261 231 038
1.8 16V [1G2, 19E]			1,8l 95 kW PL 4 Zyl.
Air flow sensor, gasoline injection	08.86-10.91		F 026 TX2 063 🔌 F 026 TX2 063
Knock sensor	08.89-10.91	KZB	0 261 231 036
	08.86-10.91	KZG	0 261 231 038
1.8 16V [1G2, 19E]			1,8l 102 kW KR 4 Zyl.
Air flow sensor, gasoline injection	08.86-10.91		F 026 TX2 050 🔌 F 026 TX2 050
1.9 TDI [1H2]			1,9l 66 kW 1Z 4 Zyl.
Pedal position sensor, diesel	08.95→	AG	0 205 001 031
		GS	0 205 001 018
1.9 TDI [1K2]			1,9l 74 kW BRM 4 Zyl.
Air mass meter, diesel	01.05→		0 281 002 531 🔌 0 986 284 009
1.9 TDI [1K2]			1,9l 77 kW BKC; BLS 4 Zyl.
Air mass meter, diesel	09.05→		0 281 002 531 🔌 0 986 284 009
Boost pressure sensor, Diesel	09.05→		0 281 002 399
2.0 [1H2]			2,0l 85 kW ABA 4 Zyl.
Knock sensor	10.92→	KZB	0 261 231 036
2.0 FSI [1K2]			2,0l 110 kW BLR; BLY; BVY; BVZ 4 Zyl.
Knock sensor	08.05→	OHL	0 261 231 146
Pressure sensor, intake manifold, gasoline	08.05→		0 261 230 031
2.0 GTI [1K2]			2,0l 147 kW BWA 4 Zyl.
Speed sensor, ignition/injection	09.05→		0 261 210 199
Boost pressure sensor, gasoline	09.05→		0 261 230 073
2.0 TDI [1K2]			2,0l 100/103 kW AZV; BKD; BMM 4 Zyl.
Air mass meter, diesel	08.05→		0 281 002 531 🔌 0 986 284 009
Boost pressure sensor, Diesel	08.05→		0 281 002 401



2.8 [1H2]			2,8l 128 kW AAA 6 Zyl.
Air mass meter, gasoline injection			
Fg.no. →1H-S-999 000	01.94-07.95		0 280 217 504
Fg.no. 1H-T-000 001→	08.95→		0 280 217 512 🔌 0 986 280 203
Speed sensor, ignition/injection	01.94→		0 261 210 080
Knock sensor	01.94→	KZA	0 261 231 077
		KZW	0 261 231 047
Temperature sensor, intake air, injection system	01.94→		0 280 130 039

Jetta I

1.8 i			1,8l 82 kW DX 4 Zyl.
Air flow sensor, gasoline injection	05.83-12.95		F 026 TX2 051 🔌 F 026 TX2 051

Jetta II

1.8 i			1,8l 82 kW EV 4 Zyl.
Air flow sensor, gasoline injection	08.85-11.90		F 026 TX2 051 🔌 F 026 TX2 051
1.8 i			1,8l 102 kW KR 16V 4 Zyl.
Air flow sensor, gasoline injection	06.87-12.90		F 026 TX2 050 🔌 F 026 TX2 050

Jetta III


1.6 i [1H8]			1,6l 74 kW AFX 4 Zyl.
Pressure sensor, intake manifold, gasoline	11.96-12.99		0 261 230 011
1.8 i [1H8]			1,8l 82 kW AFV 4 Zyl.
Pressure sensor, intake manifold, gasoline	11.96-12.99		0 261 230 011
2.8 i VR6 [1H8]			2,8l 128 kW AAA 6 Zyl.
Speed sensor, ignition/injection	10.93-12.99		0 261 210 080
Knock sensor	10.93-12.99	KZW	0 261 231 047

Jetta IV

1.6 i			1,6l 74 kW AKL 4 Zyl.
Phase sensor	09.99-12.05		0 232 101 031
Speed sensor, ignition/injection	09.99-12.05		0 261 210 147
1.8 T			1,8l 110 kW AGU 4 Zyl.
Air mass meter, gasoline injection	09.03-12.05		0 280 218 023 🔌 0 986 280 209
Phase sensor	09.03-12.05		0 232 101 024
Temperature sensor, intake air, injection system	09.03-12.05		0 280 130 085 0 280 130 116
2.0 i			2,0l 85 kW APK 4 Zyl.
Air mass meter, gasoline injection	09.99-12.05		0 280 218 002 🔌 0 986 280 205
Phase sensor	09.99-12.05		0 232 101 031
Speed sensor, ignition/injection	09.99-12.05		0 261 210 147

Jetta V

1.9 TDI [1K6]			1,9l 77 kW BKC 4 Zyl.
Air mass meter, diesel	03.06→		0 281 002 531 🔌 0 986 284 009
2.0 T FSI [1K6]			2,0l 147 kW BWA 4 Zyl.
Speed sensor, ignition/injection	03.06→		0 261 210 199
2.0 TDI [1K6]			2,0l 103 kW BKD 4 Zyl.
Air mass meter, diesel	03.06→		0 281 002 461 🔌 0 986 284 007





Product				

LT			
28 2.3 [2D, 2H] 2,3l 105 kW AGL 4 Zyl.			
Wheel speed sensor, front	01.97-11.01	H01	0 265 004 009
Wheel speed sensor, rear	05.96-11.01	H01	0 265 004 010
28 2.5 SDI [2D, 2H] 2,5l 55 kW AGX 5 Zyl.			
Air mass meter, diesel			
Fg.no. 2D..X..027 194→	03.99-04.01		0 281 002 216 0 986 284 001
Wheel speed sensor, front	01.97-04.01	H01	0 265 004 009
Wheel speed sensor, rear	05.96-04.01	H01	0 265 004 010
28 2.5 TDI [2D, 2H] 2,5l 61 kW BBE 5 Zyl.			
Air mass meter, diesel			
	04.01-04.06		0 281 002 463 0 986 284 008
Boost pressure sensor, Diesel	04.01-04.06		0 281 002 399
Wheel speed sensor, front	04.01-04.06	H01	0 265 004 009
Wheel speed sensor, rear	04.01-04.06	H01	0 265 004 010
28 2.5 TDI [2D, 2H] 2,5l 66 kW APA 5 Zyl.			
Air mass meter, diesel			
	05.99-04.01		0 281 002 216 0 986 284 001
Wheel speed sensor, front	05.99-04.01	H01	0 265 004 009
Wheel speed sensor, rear	05.99-04.01	H01	0 265 004 010
28 2.5 TDI [2D, 2H] 2,5l 70 kW BBF 5 Zyl.			
Air mass meter, diesel			
	04.01-04.06		0 281 002 463 0 986 284 008
Boost pressure sensor, Diesel	04.01-04.06		0 281 002 399
Wheel speed sensor, front	04.01-04.06	H01	0 265 004 009
Wheel speed sensor, rear	04.01-04.06	H01	0 265 004 010
28 2.5 TDI [2D, 2H] 2,5l 75 kW AHD 5 Zyl.			
Wheel speed sensor, front			
	01.97-05.99	H01	0 265 004 009
Wheel speed sensor, rear			
	05.96-05.99	H01	0 265 004 010
28 2.5 TDI [2D, 2H] 2,5l 80 kW ANJ 5 Zyl.			
Air mass meter, diesel			
Fg.no. →2D..1..013 334	05.99-08.00		0 281 002 216 0 986 284 001
Fg.no. 2D..1..013 335→	09.00-04.06		0 281 002 463 0 986 284 008
Boost pressure sensor, Diesel			
Fg.no. →2D..1..040 000	05.99-04.01		0 281 002 177
Fg.no. 2D..1..040 001→	05.01-04.06		0 281 002 399
Wheel speed sensor, front	05.99-04.06	H01	0 265 004 009
Wheel speed sensor, rear	05.99-04.06	H01	0 265 004 010
28 2.5 TDI [2D, 2H] 2,5l 80 kW AVR 5 Zyl.			
Air mass meter, diesel			
	12.02-04.06		0 281 002 463 0 986 284 008
Boost pressure sensor, Diesel	12.02-04.06		0 281 002 399
Wheel speed sensor, front	12.02-04.06	H01	0 265 004 009
Wheel speed sensor, rear	12.02-04.06	H01	0 265 004 010
28 2.8 D Turbo [2D, 2H] 2,8l 92/96 kW AGK; ATA 4 Zyl.			
Air mass meter, diesel			
	07.97-01.02		0 281 002 461 0 986 284 007
Wheel speed sensor, front	07.97-01.02	H01	0 265 004 009
Wheel speed sensor, rear	07.97-01.02	H01	0 265 004 010
28 2.8 TDI [2D, 2H] 2,8l 116 kW AUH; BCQ 4 Zyl.			
Air mass meter, diesel			
	02.02-04.06		0 281 002 461 0 986 284 007
Boost pressure sensor, Diesel	06.03-04.06		0 281 002 177
Wheel speed sensor, front	02.02-04.06	H01	0 265 004 009
Wheel speed sensor, rear	02.02-04.06	H01	0 265 004 010
35 2.3 [2D, 2H] 2,3l 105 kW AGL 4 Zyl.			
Wheel speed sensor, front			
	01.97-11.01	H01	0 265 004 009
Wheel speed sensor, rear			
	05.96-11.01	H01	0 265 004 010

Product				

35 2.5 SDI [2D, 2H] 2,5l 55 kW AGX 5 Zyl.			
Air mass meter, diesel			
Fg.no. 2D..X..027 194→	03.99-04.01		0 281 002 216 0 986 284 001
Wheel speed sensor, front	01.97-04.01	H01	0 265 004 009
Wheel speed sensor, rear	05.96-04.01	H01	0 265 004 010
35 2.5 TDI [2D, 2H] 2,5l 61 kW BBE 5 Zyl.			
Air mass meter, diesel			
	04.01-04.06		0 281 002 463 0 986 284 008
Boost pressure sensor, Diesel	04.01-04.06		0 281 002 399
Wheel speed sensor, front	04.01-04.06	H01	0 265 004 009
Wheel speed sensor, rear	04.01-04.06	H01	0 265 004 010
35 2.5 TDI [2D, 2H] 2,5l 66 kW APA 5 Zyl.			
Air mass meter, diesel			
	05.99-04.01		0 281 002 216 0 986 284 001
Wheel speed sensor, front	05.99-04.01	H01	0 265 004 009
Wheel speed sensor, rear	05.99-04.01	H01	0 265 004 010
35 2.5 TDI [2D, 2H] 2,5l 70 kW BBF 5 Zyl.			
Air mass meter, diesel			
	04.01-04.06		0 281 002 463 0 986 284 008
Boost pressure sensor, Diesel	04.01-04.06		0 281 002 399
Wheel speed sensor, front	04.01-04.06	H01	0 265 004 009
Wheel speed sensor, rear	04.01-04.06	H01	0 265 004 010
35 2.5 TDI [2D, 2H] 2,5l 75 kW AHD 5 Zyl.			
Wheel speed sensor, front			
	01.97-05.99	H01	0 265 004 009
Wheel speed sensor, rear			
	05.96-05.99	H01	0 265 004 010
35 2.5 TDI [2D, 2H] 2,5l 80 kW ANJ 5 Zyl.			
Air mass meter, diesel			
Fg.no. →2D..1..013 334	05.99-08.00		0 281 002 216 0 986 284 001
Fg.no. 2D..1..013 335→	09.00-04.06		0 281 002 463 0 986 284 008
Boost pressure sensor, Diesel			
Fg.no. →2D..1..040 000	05.99-04.01		0 281 002 177
Fg.no. 2D..1..040 001→	05.01-04.06		0 281 002 399
Wheel speed sensor, front	05.99-04.06	H01	0 265 004 009
Wheel speed sensor, rear	05.99-04.06	H01	0 265 004 010
35 2.5 TDI [2D, 2H] 2,5l 80 kW AVR 5 Zyl.			
Air mass meter, diesel			
	12.02-04.06		0 281 002 463 0 986 284 008
Boost pressure sensor, Diesel	12.02-04.06		0 281 002 399
Wheel speed sensor, front	12.02-04.06	H01	0 265 004 009
Wheel speed sensor, rear	12.02-04.06	H01	0 265 004 010
35 2.8 D Turbo [2D, 2H] 2,8l 92/96 kW AGK; ATA 4 Zyl.			
Air mass meter, diesel			
	07.97-01.02		0 281 002 461 0 986 284 007
Wheel speed sensor, front	07.97-01.02	H01	0 265 004 009
Wheel speed sensor, rear	07.97-01.02	H01	0 265 004 010
35 2.8 TDI [2D, 2H] 2,8l 116 kW AUH; BCQ 4 Zyl.			
Air mass meter, diesel			
	02.02-04.06		0 281 002 461 0 986 284 007
Boost pressure sensor, Diesel	06.03-04.06		0 281 002 177
Wheel speed sensor, front	02.02-04.06	H01	0 265 004 009
Wheel speed sensor, rear	02.02-04.06	H01	0 265 004 010
46 2.3 [2D, 2H] 2,3l 105 kW AGL 4 Zyl.			
Wheel speed sensor, front			
	01.97-11.01	H01	0 265 004 009
Wheel speed sensor, rear			
	05.96-11.01	H01	0 265 004 010
46 2.5 SDI [2D, 2H] 2,5l 55 kW AGX 5 Zyl.			
Air mass meter, diesel			
Fg.no. 2D..X..027 194→	03.99-04.01		0 281 002 216 0 986 284 001
Wheel speed sensor, front	01.97-04.01	H01	0 265 004 009
Wheel speed sensor, rear	05.96-04.01	H01	0 265 004 010




Product		
46 2.5 TDI [2D, 2H]	2,5l 61 kW BBE 5 Zyl.	
Air mass meter, diesel	04.01-04.06	0 281 002 463 0 986 284 008
Boost pressure sensor, Diesel	04.01-04.06	0 281 002 399
Wheel speed sensor, front	04.01-04.06 H01	0 265 004 009
Wheel speed sensor, rear	04.01-04.06 H01	0 265 004 010
46 2.5 TDI [2D, 2H]	2,5l 66 kW APA 5 Zyl.	
Air mass meter, diesel	05.99-04.01	0 281 002 216 0 986 284 001
Wheel speed sensor, front	05.99-04.01 H01	0 265 004 009
Wheel speed sensor, rear	05.99-04.01 H01	0 265 004 010
46 2.5 TDI [2D, 2H]	2,5l 70 kW BBF 5 Zyl.	
Air mass meter, diesel	04.01-04.06	0 281 002 463 0 986 284 008
Boost pressure sensor, Diesel	04.01-04.06	0 281 002 399
Wheel speed sensor, front	04.01-04.06 H01	0 265 004 009
Wheel speed sensor, rear	04.01-04.06 H01	0 265 004 010
46 2.5 TDI [2D, 2H]	2,5l 75 kW AHD 5 Zyl.	
Wheel speed sensor, front	01.97-05.99 H01	0 265 004 009
Wheel speed sensor, rear	05.96-05.99 H01	0 265 004 010
46 2.5 TDI [2D, 2H]	2,5l 80 kW ANJ 5 Zyl.	
Air mass meter, diesel		
Fg.no. →2D..1..013 334	05.99-08.00	0 281 002 216 0 986 284 001
Fg.no. 2D..1..013 335→	09.00-04.06	0 281 002 463 0 986 284 008
Boost pressure sensor, Diesel		
Fg.no. →2D..1..040 000	05.99-04.01	0 281 002 177
Fg.no. 2D..1..040 001→	05.01-04.06	0 281 002 399
Wheel speed sensor, front	05.99-04.06 H01	0 265 004 009
Wheel speed sensor, rear	05.99-04.06 H01	0 265 004 010
46 2.5 TDI [2D, 2H]	2,5l 80 kW AVR 5 Zyl.	
Air mass meter, diesel	12.02-04.06	0 281 002 463 0 986 284 008
Boost pressure sensor, Diesel	12.02-04.06	0 281 002 399
Wheel speed sensor, front	12.02-04.06 H01	0 265 004 009
Wheel speed sensor, rear	12.02-04.06 H01	0 265 004 010
46 2.8 D Turbo [2D, 2H]	2,8l 92/96 kW AGK; ATA 4 Zyl.	
Air mass meter, diesel	07.97-01.02	0 281 002 461 0 986 284 007
Wheel speed sensor, front	07.97-01.02 H01	0 265 004 009
Wheel speed sensor, rear	07.97-01.02 H01	0 265 004 010
46 2.8 TDI [2D, 2H]	2,8l 116 kW AUH 4 Zyl.	
Air mass meter, diesel	02.02-04.06	0 281 002 461 0 986 284 007
Boost pressure sensor, Diesel	06.03-04.06	0 281 002 177
Wheel speed sensor, front	02.02-04.06 H01	0 265 004 009
Wheel speed sensor, rear	02.02-04.06 H01	0 265 004 010

Lupo

1.0 [6X1]	1,0l 37 kW AER 4 Zyl.	
Pressure sensor, intake manifold, gasoline	10.98-05.00	0 261 230 011
1.0 [6X1]	1,0l 37 kW ALD 4 Zyl.	
Throttle valve assembly		
Fg.no. →6E..Y..007 000,→6X..Y..060 000	10.98-03.00	0 280 750 049
Fg.no. 6E..Y..007 001→,6X..Y..060 001→	04.00-07.05	0 280 750 095
Speed sensor, ignition/injection		
Fg.no. →6X..1..020 000	10.98-07.00	0 261 210 188
Fg.no. 6X..1..020 001→	08.00-07.05	0 261 210 213
Knock sensor	10.98-07.05	0 261 231 045
Pressure sensor, intake manifold, gasoline	10.98-07.05	0 261 230 031
Accelerator pedal module	06.03-07.05 GS	0 280 752 214



1.0 [6X1]	1,0l 37 kW ALL 4 Zyl.	
Knock sensor	10.98-05.00	0 261 231 045
Pressure sensor, intake manifold, gasoline	10.98-05.00	0 261 230 011
1.0 [6X1]	1,0l 37 kW ANV 4 Zyl.	
Throttle valve assembly		
Fg.no. →6E..Y..007 000,→6X..Y..060 000	10.98-03.00	0 280 750 049
Fg.no. 6E..Y..007 001→,6X..Y..060 001→	04.00-05.00	0 280 750 095
Speed sensor, ignition/injection	10.98-05.00	0 261 210 188
Knock sensor	10.98-05.00	0 261 231 045
Pressure sensor, intake manifold, gasoline	10.98-05.00	0 261 230 031
1.0 [6X1]	1,0l 37 kW AUC 4 Zyl.	
Throttle valve assembly	05.00-07.05	0 280 750 095
Speed sensor, ignition/injection		
Fg.no. →6X..1..020 000	05.00-07.00	0 261 210 188
Fg.no. 6X..1..020 001→	08.00-07.05	0 261 210 213
Knock sensor	05.00-07.05	0 261 231 045
Pressure sensor, intake manifold, gasoline	05.00-07.05	0 261 230 031
Accelerator pedal module	06.03-07.05 GS	0 280 752 214
1.2 TDI 3L [6X1]	1,2l 45 kW ANY 3 Zyl.	
Air mass meter, diesel	10.98-11.00	0 280 218 002 0 986 280 205
Boost pressure sensor, Diesel	10.98-11.00	0 281 002 177
Pedal position sensor, diesel		
Fg.no. 6X..X..200 001→	05.99-11.00 RLE	0 281 002 269
1.2 TDI 3L [6X1]	1,2l 45 kW AYZ 3 Zyl.	
Air mass meter, diesel	11.00-07.05	0 280 218 002 0 986 280 205
Boost pressure sensor, Diesel		
Fg.no. →6E..3..002 000,→6X..3..008 000	11.00-10.02	0 281 002 177
Fg.no. 6E..3..002 000→,6X..3..008 000→	11.02-07.05	0 281 002 399
Pedal position sensor, diesel	11.00-07.05 RLE	0 281 002 269
1.4 [6X1]	1,4l 44 kW AUD 4 Zyl.	
Throttle valve assembly	09.00-07.05	0 280 750 095
Speed sensor, ignition/injection	09.00-07.05	0 261 210 213
Knock sensor	09.00-07.05	0 261 231 045
Pressure sensor, intake manifold, gasoline	09.00-07.05	0 261 230 031
Accelerator pedal module	06.03-07.05 GS	0 280 752 214
1.4 [6X1]	1,4l 55 kW AHW 4 Zyl.	
Knock sensor	10.98-05.04	0 261 231 045
Accelerator pedal module	06.03-05.04 GS	0 280 752 214
1.4 [6X1]	1,4l 55 kW AKQ 4 Zyl.	
Knock sensor	10.98-05.99	0 261 231 045
Pedal position sensor, EMS (electronic engine management)	10.98-05.99 AG,RLE	0 280 752 018
1.4 [6X1]	1,4l 55 kW APE; AUA 4 Zyl.	
Knock sensor	05.99-04.02	0 261 231 045
1.4 [6X1]	1,4l 55 kW BBY 4 Zyl.	
Knock sensor	11.01-07.05	0 261 231 045
Accelerator pedal module	06.03-07.05 GS	0 280 752 214
1.4 [6X1]	1,4l 74 kW AQQ 4 Zyl.	
Knock sensor	05.99-05.00	0 261 231 045
1.4 [6X1]	1,4l 74 kW AUB 4 Zyl.	
Knock sensor	05.00-07.05	0 261 231 045
Accelerator pedal module	06.03-07.05 GS	0 280 752 214
1.4 FSI [6X1]	1,4l 77 kW ARR 4 Zyl.	
Throttle valve assembly	09.00-11.03	0 280 750 059
Air mass meter, gasoline injection	09.00-11.03	0 280 218 056 0 986 280 214
Speed sensor, ignition/injection	09.00-11.03	0 261 210 213
Knock sensor	09.00-11.03	0 261 231 146
Pressure sensor, intake manifold, gasoline	09.00-11.03	0 261 230 071
Accelerator pedal module	06.03-11.03 GS	0 280 752 214





Product

◀ Lupo

1.4 TDI [6X1]		1,4l 55 kW AMF 3 Zyl.
Air mass meter, diesel	06.98-07.05	0 281 002 318 0 986 284 002
Boost pressure sensor, Diesel		
Fg.no. →6E..3..002 000,→6X..3..008 000	06.98-10.02	0 281 002 177
Fg.no. 6E..3..002 000→,6X..3..008 000→	11.02-07.05	0 281 002 399
Pedal position sensor, diesel		
Fg.no. 6X..X..200 001→	05.99-07.05 RLE	0 281 002 269
1.6 GTI [6X1]		1,6l 92 kW AVY 4 Zyl.
Speed sensor, ignition/injection		
Fg.no. →6X..1..020 000	05.00-07.00	0 261 210 188
Fg.no. 6X..1..020 001→	08.00-07.05	0 261 210 213
Knock sensor	05.00-07.05	0 261 231 045
Accelerator pedal module	05.00-07.05 GS,LLE	0 280 752 214
Pedal position sensor, EMS (electronic engine management)	05.00-07.05 AG,RLE	0 280 752 018
1.7 SDI [6X1]		1,7l 42 kW AKU 4 Zyl.
Pedal position sensor, diesel		
Fg.no. 6X..X..200 001→	05.99-07.05 RLE	0 281 002 269

Multivan T4

1.8 [70]		1,8l 49 kW PD 4 Zyl.
Duo sensor, acceleration and yaw rate, brake system	12.90-07.92	0 265 005 214
Wheel speed sensor, front	12.90-07.92	0 265 006 407
Wheel speed sensor, rear	12.90-07.92 LAB,MVB	0 265 006 508
	MVB,RAB	0 265 006 510
1.9 D [70]		1,9l 45 kW 1X 4 Zyl.
Duo sensor, acceleration and yaw rate, brake system	09.90-04.97	0 265 005 214
Wheel speed sensor, front	09.90-04.97	0 265 006 407
Wheel speed sensor, rear	09.90-04.97 LAB,MVB	0 265 006 508
	MVB,RAB	0 265 006 510
Fg.no. 70..T..200 001→	01.96-04.97 LAB,OB	0 265 006 408
	BB,RAB	0 265 006 409
1.9 D Turbo [70]		1,9l 50 kW ABL 4 Zyl.
Duo sensor, acceleration and yaw rate, brake system	10.92-06.03	0 265 005 214
Wheel speed sensor, front	10.92-06.03	0 265 006 407
Wheel speed sensor, rear	10.92-06.03 LAB,MVB	0 265 006 508
	MVB,RAB	0 265 006 510
Fg.no. 70..T..200 001→	01.96-06.03 LAB,OB	0 265 006 408
	BB,RAB	0 265 006 409
2.0 [70]		2,0l 62 kW AAC 4 Zyl.
Duo sensor, acceleration and yaw rate, brake system	09.90-06.03	0 265 005 214
Wheel speed sensor, front	09.90-06.03	0 265 006 407
Wheel speed sensor, rear	09.90-06.03 LAB,MVB	0 265 006 508
	MVB,RAB	0 265 006 510
Fg.no. 70..T..200 001→	01.96-06.03 LAB,OB	0 265 006 408
	BB,RAB	0 265 006 409
2.4 D [70]		2,4l 55 kW AJA 5 Zyl.
Duo sensor, acceleration and yaw rate, brake system	05.97-06.03	0 265 005 214
Wheel speed sensor, front	05.97-06.03	0 265 006 407
Wheel speed sensor, rear	05.97-06.03 LAB,MVB	0 265 006 508
	LAB,OB	0 265 006 408
	MVB,RAB	0 265 006 510
	OB	0 265 006 409

Product

2.4 D [70]		2,4l 57 kW AAB 5 Zyl.
Duo sensor, acceleration and yaw rate, brake system	09.90-05.98	0 265 005 214
Wheel speed sensor, front	09.90-05.98	0 265 006 407
Wheel speed sensor, rear	09.90-05.98 LAB,MVB	0 265 006 508
	MVB,RAB	0 265 006 510
Fg.no. 70..T..200 001→	01.96-05.98 LAB,OB	0 265 006 408
	BB,RAB	0 265 006 409
2.4 D Syncro [7D]		2,4l 57 kW AAB 5 Zyl.
Duo sensor, acceleration and yaw rate, brake system	11.92-09.98	0 265 005 214
Wheel speed sensor, front	11.92-09.98	0 265 006 407
Wheel speed sensor, rear	11.92-09.98 LAB,MVB	0 265 006 508
	MVB,RAB	0 265 006 510
Fg.no. 70..T..200 001→	01.96-09.98 LAB,OB	0 265 006 408
	BB,RAB	0 265 006 409
2.5 [70]		2,5l 81 kW AAF 5 Zyl.
Duo sensor, acceleration and yaw rate, brake system	11.90-12.93	0 265 005 214
Wheel speed sensor, front	11.90-12.93	0 265 006 407
Wheel speed sensor, rear	11.90-12.93 LAB,MVB	0 265 006 508
	MVB,RAB	0 265 006 510
2.5 [70]		2,5l 81 kW ACU 5 Zyl.
Knock sensor	07.94-10.96 L30	0 261 231 066
	L34	0 261 231 077
Duo sensor, acceleration and yaw rate, brake system	07.94-10.96	0 265 005 214
Wheel speed sensor, front	07.94-10.96	0 265 006 407
Wheel speed sensor, rear	07.94-10.96 LAB,MVB	0 265 006 508
	MVB,RAB	0 265 006 510
Fg.no. 70..T..200 001→	01.96-10.96 LAB,OB	0 265 006 408
	BB,RAB	0 265 006 409
2.5 [70]		2,5l 81 kW AEN 5 Zyl.
Duo sensor, acceleration and yaw rate, brake system	09.95-12.95	0 265 005 214
Wheel speed sensor, front	09.95-12.95	0 265 006 407
Wheel speed sensor, rear	09.95-12.95 LAB,MVB	0 265 006 508
	MVB,RAB	0 265 006 510
2.5 [70]		2,5l 81 kW AEU 5 Zyl.
Duo sensor, acceleration and yaw rate, brake system	08.96-06.03	0 265 005 214
Wheel speed sensor, front	08.96-06.03	0 265 006 407
Wheel speed sensor, rear	08.96-06.03 LAB,MVB	0 265 006 508
	LAB,OB	0 265 006 408
	MVB,RAB	0 265 006 510
	OB	0 265 006 409
2.5 [70]		2,5l 85 kW AET; APL; AVT 5 Zyl.
Knock sensor	08.96-06.03 L30	0 261 231 066
	L34	0 261 231 077
Duo sensor, acceleration and yaw rate, brake system	08.96-06.03	0 265 005 214
Wheel speed sensor, front	08.96-06.03	0 265 006 407
Wheel speed sensor, rear	08.96-06.03 LAB,MVB	0 265 006 508
	LAB,OB	0 265 006 408
	MVB,RAB	0 265 006 510
	OB	0 265 006 409
2.5 Syncro [7D]		2,5l 81 kW AAF 5 Zyl.
Duo sensor, acceleration and yaw rate, brake system	11.92-12.93	0 265 005 214
Wheel speed sensor, front	11.92-12.93	0 265 006 407
Wheel speed sensor, rear	11.92-12.93 LAB,MVB	0 265 006 508
	MVB,RAB	0 265 006 510



2.5 Syncro [7D]		2,5l 81 kW ACU 5 Zyl.	
Knock sensor	01.94-10.96	L30	0 261 231 066
		L34	0 261 231 077
Duo sensor, acceleration and yaw rate, brake system	01.94-10.96		0 265 005 214
Wheel speed sensor, front	01.94-10.96		0 265 006 407
Wheel speed sensor, rear	01.94-10.96	LAB,MVB	0 265 006 508
		MVB,RAB	0 265 006 510
Fg.no. 70..T..200 001→	01.96-10.96	LAB,OBB	0 265 006 408
		OBB,RAB	0 265 006 409

2.5 Syncro [7D]		2,5l 81 kW AEU 5 Zyl.	
Duo sensor, acceleration and yaw rate, brake system	06.97-11.01		0 265 005 214
Wheel speed sensor, front	06.97-11.01		0 265 006 407
Wheel speed sensor, rear	06.97-11.01	LAB,MVB	0 265 006 508
		LAB,OBB	0 265 006 408
		MVB,RAB	0 265 006 510
		OBB,RAB	0 265 006 409

2.5 Syncro [7D]		2,5l 85 kW AET; APL; AVT 5 Zyl.	
Knock sensor	08.96-06.03	L30	0 261 231 066
		L34	0 261 231 077
Duo sensor, acceleration and yaw rate, brake system	08.96-06.03		0 265 005 214
Wheel speed sensor, front	08.96-06.03		0 265 006 407
Wheel speed sensor, rear	08.96-06.03	LAB,MVB	0 265 006 508
		LAB,OBB	0 265 006 408
		MVB,RAB	0 265 006 510
		OBB,RAB	0 265 006 409

2.5 TDI [70]		2,5l 65 kW AJT 5 Zyl.	
Air mass meter, diesel			
Fg.no. →70..1H048 284,→70..1X047 893	05.98-08.00		0 281 002 216
			0 986 284 001
Fg.no. 70..1H048 285→,70..1X047 894→	09.00-06.03		0 281 002 463
			0 986 284 008

Boost pressure sensor, Diesel			
Fg.no. →70..1..200 000	05.98-04.01		0 281 002 177
Fg.no. 70..1..200 001→	05.01-06.03		0 281 002 399
Pedal position sensor, diesel			
Fg.no. →70..Y..000 940	05.98-05.99	GS	0 205 001 020
Duo sensor, acceleration and yaw rate, brake system	05.98-06.03		0 265 005 214
Wheel speed sensor, front	05.98-06.03		0 265 006 407
Wheel speed sensor, rear	05.98-06.03	LAB,MVB	0 265 006 508
		LAB,OBB	0 265 006 408
		MVB,RAB	0 265 006 510
		OBB,RAB	0 265 006 409

2.5 TDI [70]		2,5l 65 kW AYY 5 Zyl.	
Air mass meter, diesel	10.01-06.03		0 281 002 463
			0 986 284 008

Boost pressure sensor, Diesel	10.01-06.03		0 281 002 399
Duo sensor, acceleration and yaw rate, brake system	10.01-06.03		0 265 005 214
Wheel speed sensor, front	10.01-06.03		0 265 006 407
Wheel speed sensor, rear	10.01-06.03	LAB,MVB	0 265 006 508
		LAB,OBB	0 265 006 408
		MVB,RAB	0 265 006 510
		OBB,RAB	0 265 006 409

2.5 TDI [70]		2,5l 75 kW ACV 5 Zyl.	
Air mass meter, diesel			
Fg.no. →70..1H048 284,→70..1X047 893	05.98-08.00		0 281 002 216
			0 986 284 001
Fg.no. 70..1H048 285→,70..1X047 894→	09.00-06.03		0 281 002 463
			0 986 284 008

Boost pressure sensor, Diesel			
Fg.no. →70..1..200 000	05.99-04.01		0 281 002 177
Fg.no. 70..1..200 001→	05.01-06.03		0 281 002 399
Duo sensor, acceleration and yaw rate, brake system	05.99-06.03		0 265 005 214
Wheel speed sensor, front	05.99-06.03		0 265 006 407
Wheel speed sensor, rear	05.99-06.03	LAB,MVB	0 265 006 508
		LAB,OBB	0 265 006 408
		MVB,RAB	0 265 006 510
		OBB,RAB	0 265 006 409



Boost pressure sensor, Diesel			
Fg.no. →70..1..200 000	01.95-04.01		0 281 002 177
Fg.no. 70..1..200 001→	05.01-06.03		0 281 002 399

Pedal position sensor, diesel			
Fg.no. →70..Y..000 940	01.95-05.99	GS	0 205 001 020
Duo sensor, acceleration and yaw rate, brake system	01.95-06.03		0 265 005 214

Wheel speed sensor, front	01.95-06.03		0 265 006 407
Wheel speed sensor, rear	01.95-06.03	LAB,MVB	0 265 006 508
		MVB,RAB	0 265 006 510
Fg.no. 70..T..200 001→	01.96-06.03	LAB,OBB	0 265 006 408
		OBB,RAB	0 265 006 409

2.5 TDI [70]		2,5l 75 kW AUF 5 Zyl.	
Air mass meter, diesel			
Fg.no. →70..1H048 284,→70..1X047 893	05.99-08.00		0 281 002 216
			0 986 284 001
Fg.no. 70..1H048 285→,70..1X047 894→	09.00-06.03		0 281 002 463
			0 986 284 008

Boost pressure sensor, Diesel			
Fg.no. →70..1..200 000	05.99-04.01		0 281 002 177
Fg.no. 70..1..200 001→	05.01-06.03		0 281 002 399
Duo sensor, acceleration and yaw rate, brake system	05.99-06.03		0 265 005 214
Wheel speed sensor, front	05.99-06.03		0 265 006 407
Wheel speed sensor, rear	05.99-06.03	LAB,MVB	0 265 006 508
		LAB,OBB	0 265 006 408
		MVB,RAB	0 265 006 510
		OBB,RAB	0 265 006 409


2.5 TDI [70]		2,5l 75 kW AXL 5 Zyl.	
Duo sensor, acceleration and yaw rate, brake system	04.01-06.03		0 265 005 214
Wheel speed sensor, front	04.01-06.03		0 265 006 407
Wheel speed sensor, rear	04.01-06.03	LAB,MVB	0 265 006 508
		LAB,OBB	0 265 006 408
		MVB,RAB	0 265 006 510
		OBB,RAB	0 265 006 409

2.5 TDI [70]		2,5l 75 kW AYC 5 Zyl.	
Air mass meter, diesel	04.01-06.03		0 281 002 463
			0 986 284 008

Duo sensor, acceleration and yaw rate, brake system	04.01-06.03		0 265 005 214
Wheel speed sensor, front	04.01-06.03		0 265 006 407
Wheel speed sensor, rear	04.01-06.03	LAB,MVB	0 265 006 508
		LAB,OBB	0 265 006 408
		MVB,RAB	0 265 006 510
		OBB,RAB	0 265 006 409

2.5 TDI [70]		2,5l 111 kW AHY 5 Zyl.	
Air mass meter, diesel			
Fg.no. →70..1..001 319	05.98-05.00		0 280 217 529
			0 986 280 204
Fg.no. 70..1..001 320→	06.00-09.00		0 281 002 461
			0 986 284 007

Boost pressure sensor, Diesel	05.98-09.00		0 281 002 177
Pedal position sensor, diesel			
Fg.no. →70..Y..000 940	05.98-05.99	GS	0 205 001 020
Duo sensor, acceleration and yaw rate, brake system	05.98-09.00		0 265 005 214
Wheel speed sensor, front	05.98-09.00		0 265 006 407
Wheel speed sensor, rear	05.98-09.00	LAB,MVB	0 265 006 508
		LAB,OBB	0 265 006 408
		MVB,RAB	0 265 006 510
		OBB,RAB	0 265 006 409



Product					
◀ Multivan T4					
2.5 TDI [70]		2,5l 111 kW AXG 5 Zyl.			
Air mass meter, diesel	09.00-06.03	0 281 002 461  0 986 284 007			
Boost pressure sensor, Diesel					
Fg.no. →70..1..200 000	09.00-04.01	0 281 002 177			
Fg.no. 70..1..200 001→	05.01-06.03	0 281 002 399			
Duo sensor, acceleration and yaw rate, brake system	09.00-06.03	0 265 005 214			
Wheel speed sensor, front	09.00-06.03	0 265 006 407			
Wheel speed sensor, rear	09.00-06.03	LAB,MVB	0 265 006 508		
		LAB,OBG	0 265 006 408		
		MVB,RAB	0 265 006 510		
		OBG,RAB	0 265 006 409		
2.5 TDI Syncro [7D]		2,5l 75 kW ACV 5 Zyl.			
Air mass meter, diesel					
Fg.no. →70..1H048 284,→70..1X047 893	05.98-08.00	0 281 002 216  0 986 284 001			
Fg.no. 70..1H048 285→,70..1X047 894→	09.00-06.03	0 281 002 463  0 986 284 008			
Boost pressure sensor, Diesel					
Fg.no. →70..1..200 000	03.98-04.01	0 281 002 177			
Fg.no. 70..1..200 001→	05.01-06.03	0 281 002 399			
Pedal position sensor, diesel					
Fg.no. →70..Y..000 940	03.98-05.99	GS	0 205 001 020		
Duo sensor, acceleration and yaw rate, brake system	03.98-06.03	0 265 005 214			
Wheel speed sensor, front	03.98-06.03	0 265 006 407			
Wheel speed sensor, rear	03.98-06.03	LAB,MVB	0 265 006 508		
		LAB,OBG	0 265 006 408		
		MVB,RAB	0 265 006 510		
		OBG,RAB	0 265 006 409		
2.5 TDI Syncro [7D]		2,5l 75 kW AXL 5 Zyl.			
Duo sensor, acceleration and yaw rate, brake system	04.01-06.03	0 265 005 214			
Wheel speed sensor, front	04.01-06.03	0 265 006 407			
Wheel speed sensor, rear	04.01-06.03	LAB,MVB	0 265 006 508		
		LAB,OBG	0 265 006 408		
		MVB,RAB	0 265 006 510		
		OBG,RAB	0 265 006 409		
2.8 [70]		2,8l 103 kW AES 6 Zyl.			
Air mass meter, gasoline injection	01.96-05.00	0 280 217 512  0 986 280 203			
Phase sensor					
Mot.no. AES 010 241→	12.97-05.00	0 232 103 019			
Speed sensor, ignition/injection	01.96-05.00	0 261 210 107			
Temperature sensor, intake air, injection system	01.96-05.00	0 280 130 039			
Duo sensor, acceleration and yaw rate, brake system	01.96-05.00	0 265 005 214			
Wheel speed sensor, front	01.96-05.00	0 265 006 407			
Wheel speed sensor, rear	01.96-05.00	LAB,MVB	0 265 006 508		
		LAB,OBG	0 265 006 408		
		MVB,RAB	0 265 006 510		
		OBG,RAB	0 265 006 409		
2.8 [70]		2,8l 150 kW AMV 6 Zyl.			
Throttle valve assembly	05.00-06.03	0 280 750 086			
Air mass meter, gasoline injection	05.00-06.03	0 280 218 017  0 986 280 208			
Phase sensor					
	05.00-06.03	0 232 103 019			
Duo sensor, acceleration and yaw rate, brake system	05.00-06.03	0 265 005 214			
Wheel speed sensor, front	05.00-06.03	0 265 006 407			



Product				
Wheel speed sensor, rear	05.00-06.03	LAB,MVB	0 265 006 508	
		LAB,OBG	0 265 006 408	
		MVB,RAB	0 265 006 510	
		OBG,RAB	0 265 006 409	
Multivan T5				
1.9 TDI [7H]	1,9l 62/63/75/77 kW	AXB; AXC; BRR; BRS	4 Zyl.	
Air mass meter, diesel	04.03→		0 281 002 531	
			 0 986 284 009	
Boost pressure sensor, Diesel	04.03→		0 281 002 399	
2.0 [7H]		2,0l 85 kW	AXA	4 Zyl.
Throttle valve assembly	06.03→		0 280 750 167	
Air mass meter, gasoline injection	06.03→		0 280 218 060	
			 0 986 280 216	
Phase sensor	06.03→		0 232 101 031	
Knock sensor	06.03→	OHL	0 261 231 146	
2.5 TDI [7H]	2,5l 96/120/128 kW	AXD; AXE; BLJ	5 Zyl.	
Air mass meter, diesel	02.03→		0 281 002 461	
			 0 986 284 007	
Boost pressure sensor, Diesel	02.03→		0 281 002 401	
2.5 TDI 4 Motion [7H]		2,5l 96/128 kW	AXD; AXE	5 Zyl.
Air mass meter, diesel	07.04→		0 281 002 461	
			 0 986 284 007	
Boost pressure sensor, Diesel	07.04→		0 281 002 401	
3.2 [7H]	3,2l 170/173 kW	BDL; BKK	6 Zyl.	
Throttle valve assembly	02.03→		0 280 750 086	
Air mass meter, gasoline injection	02.03→		0 280 218 073	
			 0 986 280 222	
Phase sensor	02.03→		0 232 103 019	
Knock sensor	02.03→	OHL	0 261 231 146	
3.2 4 Motion [7H]		3,2l 173 kW	BKK	6 Zyl.
Throttle valve assembly	07.04→		0 280 750 086	
Air mass meter, gasoline injection	07.04→		0 280 218 073	
			 0 986 280 222	
Phase sensor	07.04→		0 232 103 019	
Knock sensor	07.04→	OHL	0 261 231 146	
New Beetle				
1.4 [1C1/9C1]		1,4l 55 kW	BCA	4 Zyl.
Knock sensor	11.01→		0 261 231 146	
Pressure sensor, intake manifold, gasoline	11.01→		0 261 230 031	
Accelerator pedal module	11.01→	GS,RLE	0 280 752 210	
Fg.no. 1C..3..433 666→,9C..3..621 302→	02.03→	GS,LLE	0 280 752 214	
1.6 [1C1/9C1]		1,6l 74 kW	AWH	4 Zyl.
Phase sensor	10.99-10.00		0 232 101 031	
Speed sensor, ignition/injection	10.99-10.00		0 261 210 199	
Accelerator pedal module	10.99-10.00	AG,RLE	0 280 752 213	
		GS,RLE	0 280 752 210	
1.6 [1C1/9C1]		1,6l 75 kW	AYD	4 Zyl.
Phase sensor	06.00-06.05		0 232 101 038	
Speed sensor, ignition/injection	06.00-06.05		0 261 210 199	
Accelerator pedal module	06.00-05.01	AG,RLE	0 280 752 213	
	06.00-06.05	GS,RLE	0 280 752 210	
1.6 [1C1/9C1]		1,6l 75 kW	BFS	4 Zyl.
Phase sensor	06.02→		0 232 101 038	
Speed sensor, ignition/injection	06.02→		0 261 210 199	
Knock sensor	06.02→		0 261 231 146	
Accelerator pedal module	06.02→	GS,RLE	0 280 752 210	
Fg.no. 1C..3..433 666→,9C..3..621 302→	02.03→	GS,LLE	0 280 752 214	

Product




1.8 T [1C1/9C1]		1,8l 110 kW AGU 4 Zyl.	
Accelerator pedal module	01.98-07.99	AG,RLE	0 280 752 213
		GS,RLE	0 280 752 210
1.8 T [1C1/9C1]		1,8l 110 kW APH 4 Zyl.	
Throttle valve assembly	11.98-05.01		0 280 750 036
Air mass meter, gasoline injection	11.98-05.01		0 280 218 002
			0 986 280 205
Phase sensor	11.98-05.01		0 232 101 024
Speed sensor, ignition/injection	11.98-05.01		0 261 210 147
Knock sensor			
Fg.no. →1C..Y..499 000,→9C..Y..699 000	11.98-04.00		0 261 231 045
Fg.no. 1C..1..400 001→,9C..1..600 001→	05.00-05.01		0 261 231 146
Boost pressure sensor, gasoline	11.98-05.01		0 281 002 177
Temperature sensor, intake air, injection system	11.98-05.01		0 280 130 085
Accelerator pedal module	11.98-05.01	AG,RLE	0 280 752 213
		GS,RLE	0 280 752 210
1.8 T [1C1/9C1]		1,8l 110 kW AVC 4 Zyl.	
Throttle valve assembly	05.99-10.00		0 280 750 036
Air mass meter, gasoline injection	05.99-10.00		0 280 218 002
			0 986 280 205
Speed sensor, ignition/injection	05.99-10.00		0 261 210 147
Knock sensor			
Fg.no. →1C..Y..499 000,→9C..Y..699 000	05.99-04.00		0 261 231 045
Fg.no. 1C..1..400 001→,9C..1..600 001→	05.00-10.00		0 261 231 146
Boost pressure sensor, gasoline	05.99-10.00		0 281 002 177
Temperature sensor, intake air, injection system	05.99-10.00		0 280 130 085
Accelerator pedal module	05.99-10.00	AG,RLE	0 280 752 213
		GS,RLE	0 280 752 210
1.8 T [1C1/9C1]		1,8l 110 kW AWU 4 Zyl.	
Throttle valve assembly	10.00→		0 280 750 099
Air mass meter, gasoline injection	10.00→		0 280 218 063
			0 986 280 217
Phase sensor	10.00→		0 232 101 024
Speed sensor, ignition/injection	10.00→		0 261 210 147
Knock sensor	10.00→		0 261 231 146
Boost pressure sensor, gasoline	10.00→		0 281 002 177
Temperature sensor, intake air, injection system			
Fg.no. →9C..3..608 500	10.00-09.02		0 280 130 085
Fg.no. 9C..3..608 501→9C..4..622 249	10.02-06.04		0 280 130 116
Accelerator pedal module	10.00-05.01	AG,RLE	0 280 752 213
	10.00→	GS,RLE	0 280 752 210
Fg.no. 1C..3..433 666→,9C..3..621 302→	02.03→	GS,LLE	0 280 752 214
1.8 T [1C1/9C1]		1,8l 110 kW AWW 4 Zyl.	
Throttle valve assembly	06.00-06.04		0 280 750 099
Air mass meter, gasoline injection	06.00-06.04		0 280 218 063
			0 986 280 217
Phase sensor	06.00-06.04		0 232 101 024
Knock sensor	06.00-06.04		0 261 231 146
Boost pressure sensor, gasoline	06.00-06.04		0 281 002 177
Temperature sensor, intake air, injection system			
Fg.no. →9C..3..608 500	06.00-09.02		0 280 130 085
Fg.no. 9C..3..608 501→	10.02-06.04		0 280 130 116
Accelerator pedal module	06.00-05.01	AG,RLE	0 280 752 213
	06.00-06.04	GS,RLE	0 280 752 210
Fg.no. 1C..3..433 666→,9C..3..621 302→	02.03-06.04	GS,LLE	0 280 752 214
1.8 T [1C1/9C1]		1,8l 110 kW BKF 4 Zyl.	
Throttle valve assembly	07.04-06.05		0 280 750 099
Air mass meter, gasoline injection	07.04-06.05		0 280 218 060
			0 986 280 216
Phase sensor	07.04-06.05		0 232 101 024
Boost pressure sensor, gasoline	07.04-06.05		0 281 002 177
Accelerator pedal module	07.04-06.05	GS,LLE	0 280 752 214
		GS,RLE	0 280 752 210

Product



1.8 T [1C1/9C1]		1,8l 132 kW AWP 4 Zyl.	
Throttle valve assembly	06.01-06.05		0 280 750 099
Air mass meter, gasoline injection	06.01-06.05		0 280 218 063
			0 986 280 217
Phase sensor	06.01-06.05		0 232 101 024
Speed sensor, ignition/injection	06.01-06.05		0 261 210 199
Knock sensor	06.01-06.05		0 261 231 146
Boost pressure sensor, gasoline	06.01-06.05		0 281 002 177
Temperature sensor, intake air, injection system			
Fg.no. →9C..3..608 500	06.01-09.02		0 280 130 085
Fg.no. 9C..3..608 501→9C..4..622 249	10.02-06.04		0 280 130 116
Accelerator pedal module	06.01-06.05	GS,RLE	0 280 752 210
Fg.no. 1C..3..433 666→,9C..3..621 302→	02.03-06.05	GS,LLE	0 280 752 214
1.8 T [1C1/9C1]		1,8l 132 kW BNU 4 Zyl.	
Throttle valve assembly	07.04-06.05		0 280 750 099
Air mass meter, gasoline injection	07.04-06.05		0 280 218 060
			0 986 280 216
Phase sensor	07.04-06.05		0 232 101 024
Boost pressure sensor, gasoline	07.04-06.05		0 281 002 177
Accelerator pedal module	07.04-06.05	GS,LLE	0 280 752 214
		GS,RLE	0 280 752 210
1.9 TDI [1C1/9C1]		1,9l 66 kW ALH 4 Zyl.	
Air mass meter, diesel	01.98-06.04		0 281 002 757
		WW	0 280 217 121
			0 986 280 202
Boost pressure sensor, Diesel	01.98-06.04		0 281 002 177
Accelerator pedal module	06.01-06.04	AG,RLE	0 280 752 213
		GS,RLE	0 280 752 210
Pedal position sensor, diesel			
Fg.no. →1C..W..499 000	01.98-07.98	GS,LLE	0 281 002 269
1.9 TDI [1C1/9C1]		1,9l 74 kW ATD 4 Zyl.	
Air mass meter, diesel	10.00-06.05		0 281 002 531
			0 986 284 009
Boost pressure sensor, Diesel	10.00-06.05		0 281 002 399
Accelerator pedal module	06.01-06.05	AG,RLE	0 280 752 213
		GS,RLE	0 280 752 210
1.9 TDI [1C1/9C1]		1,9l 74 kW BEW 4 Zyl.	
Air mass meter, diesel	07.03→		0 281 002 531
			0 986 284 009
Boost pressure sensor, Diesel	07.05→		0 281 002 177
	07.03-06.05		0 281 002 399
Accelerator pedal module	07.03→	AG,RLE	0 280 752 213
		GS,RLE	0 280 752 210
1.9 TDI [1C1/9C1]		1,9l 77 kW BSW 4 Zyl.	
Air mass meter, diesel	07.05→		0 281 002 531
			0 986 284 009
Boost pressure sensor, Diesel	07.05→		0 281 002 177
Accelerator pedal module	07.05→	AG,RLE	0 280 752 213
		GS,RLE	0 280 752 210
2.0 [1C1/9C1]		2,0l 85 kW AEG 4 Zyl.	
Air mass meter, gasoline injection	01.98-10.01		0 280 218 002
			0 986 280 205
Phase sensor	01.98-10.01		0 232 101 031
Speed sensor, ignition/injection	01.98-10.01		0 261 210 147
Knock sensor	01.98-10.01		0 261 231 146
Accelerator pedal module	01.98-05.01	AG,RLE	0 280 752 213
	01.98-10.01	GS,RLE	0 280 752 210
2.0 [1C1/9C1]		2,0l 85 kW APK 4 Zyl.	
Air mass meter, gasoline injection	06.00-06.05		0 280 218 002
			0 986 280 205
Phase sensor	06.00-06.05		0 232 101 031
Speed sensor, ignition/injection	06.00-06.05		0 261 210 147
Knock sensor	06.00-06.05		0 261 231 146





Product

◀ New Beetle

Accelerator pedal module	06.00-05.01	AG,RLE	0 280 752 213
	06.00-06.05	GS,RLE	0 280 752 210
Fg.no. 1C...3..433 666→,9C...3..621 302→	02.03-06.05	GS,LLE	0 280 752 214
2.0 [1C1/9C1]		2,0l 85 kW AQY 4 Zyl.	
Air mass meter, gasoline injection	11.98-06.05		0 280 218 002
			0 986 280 205
Phase sensor	11.98-06.05		0 232 101 031
Speed sensor, ignition/injection	11.98-06.05		0 261 210 147
Knock sensor	11.98-05.01		0 261 231 045
	06.01-06.05		0 261 231 146
Accelerator pedal module	11.98-05.01	AG,RLE	0 280 752 213
	11.98-06.05	GS,RLE	0 280 752 210
Fg.no. 1C...3..433 666→,9C...3..621 302→	02.03-06.05	GS,LLE	0 280 752 214
2.0 [1C1/9C1]		2,0l 85 kW AVH 4 Zyl.	
Throttle valve assembly	09.00-06.05		0 280 750 061
Air mass meter, gasoline injection	09.00-06.05		0 280 218 060
			0 986 280 216
Phase sensor	09.00-06.05		0 232 101 031
Speed sensor, ignition/injection	09.00-06.05		0 261 210 199
Knock sensor	09.00-06.05		0 261 231 146
Accelerator pedal module	09.00-05.01	AG,RLE	0 280 752 213
	09.00-06.05	GS,RLE	0 280 752 210
Fg.no. 1C...3..433 666→,9C...3..621 302→	02.03-06.05	GS,LLE	0 280 752 214
2.0 [1C1/9C1]		2,0l 85 kW AZG 4 Zyl.	
Throttle valve assembly	08.00-06.05		0 280 750 061
Air mass meter, gasoline injection	08.00-06.05		0 280 218 060
			0 986 280 216
Phase sensor	08.00-06.05		0 232 101 031
Accelerator pedal module	08.00-05.01	AG,RLE	0 280 752 213
	08.00-06.05	GS,RLE	0 280 752 210
Fg.no. 1C...3..433 666→,9C...3..621 302→	02.03-06.05	GS,LLE	0 280 752 214
2.0 [1C1/9C1]		2,0l 85 kW AZJ 4 Zyl.	
Throttle valve assembly	06.01→		0 280 750 061
Air mass meter, gasoline injection	06.01→		0 280 218 060
			0 986 280 216
Phase sensor	06.01→		0 232 101 031
Speed sensor, ignition/injection	06.01→		0 261 210 199
Knock sensor	06.01→		0 261 231 146
Accelerator pedal module	06.01→	GS,RLE	0 280 752 210
	02.03→	GS,LLE	0 280 752 214
2.0 [1C1/9C1]		2,0l 85 kW BBW 4 Zyl.	
Accelerator pedal module	06.02-06.04	GS,RLE	0 280 752 210
Fg.no. 1C...3..433 666→,9C...3..621 302→	02.03-06.04	GS,LLE	0 280 752 214
2.0 [1C1/9C1]		2,0l 85 kW BEJ 4 Zyl.	
Throttle valve assembly	11.01-06.05		0 280 750 061
Air mass meter, gasoline injection	11.01-06.05		0 280 218 060
			0 986 280 216
Phase sensor	01.03→		0 232 101 031
Speed sensor, ignition/injection	11.01-06.05		0 261 210 199
			0 261 210 178
Knock sensor	01.03→		0 261 231 146
Pressure sensor, intake manifold, gasoline	01.03→		0 261 230 095
Accelerator pedal module	01.03→	GS,RLE	0 280 752 210
	02.03→	GS,LLE	0 280 752 214
2.0 [1C1/9C1]		2,0l 85 kW BER 4 Zyl.	
Throttle valve assembly	01.03→	NOR	0 280 750 061
Air mass meter, gasoline injection	01.03→		0 280 218 060
			0 986 280 216
Phase sensor	01.03→		0 232 101 031
Speed sensor, ignition/injection	01.03-11.06		0 261 210 147
			0 261 210 178
Knock sensor	01.03→		0 261 231 146
Pressure sensor, intake manifold, gasoline	01.03→		0 261 230 095
Accelerator pedal module	01.03→	GS,RLE	0 280 752 210
	02.03→	GS,LLE	0 280 752 214

Product

2.0 [1C1/9C1]		2,0l 85 kW BEV 4 Zyl.	
Throttle valve assembly	07.04-06.05	NOR	0 280 750 061
Air mass meter, gasoline injection	07.04-06.05		0 280 218 060 🔌 0 986 280 216
Phase sensor	07.04-06.05		0 232 101 031
Speed sensor, ignition/injection	07.04-06.05		0 261 210 199
Accelerator pedal module	07.04-06.05	GS,LLE GS,RLE	0 280 752 214 0 280 752 210
2.0 [1C1/9C1]		2,0l 85 kW BHP 4 Zyl.	
Throttle valve assembly	07.03→	NOR	0 280 750 061
Air mass meter, gasoline injection	07.03→		0 280 218 060 🔌 0 986 280 216
Phase sensor	07.03→		0 232 101 031
Speed sensor, ignition/injection			
Fg.no. →1C..7..512 080,→9C..7..555 760	07.03-11.06		0 261 210 147
Fg.no. 1C..7..512 081→,9C..7..555 761→	12.06→		0 261 210 178
Knock sensor	07.03→		0 261 231 146
Pressure sensor, intake manifold, gasoline	07.03→		0 261 230 095
Accelerator pedal module	07.03→	GS,LLE GS,RLE	0 280 752 214 0 280 752 210
2.3 [1C1/9C1]		2,3l 125 kW AQN 5 Zyl.	
Throttle valve assembly	10.00-06.05		0 280 750 097
Air mass meter, gasoline injection	10.00-06.05		0 280 218 017 🔌 0 986 280 208
Phase sensor	10.00-06.05		0 232 103 019
Knock sensor	10.00-06.05		0 261 231 146
Accelerator pedal module	10.00-05.01	AG,RLE	0 280 752 213
	10.00-06.05	GS,RLE	0 280 752 210
Fg.no. 1C..3..433 666→,9C..3..621 302→	02.03-06.05	GS,LLE	0 280 752 214
2.5 [1C1/9C1]		2,5l 110 kW BPR; BPS 5 Zyl.	
Air mass meter, gasoline injection	07.05→		0 280 218 071 🔌 0 986 280 221
Pressure sensor, intake manifold, gasoline	07.05→		0 261 230 081
Accelerator pedal module	07.05→	GS,LLE GS,RLE	0 280 752 214 0 280 752 210
3.2 RSI [1C1/9C1]		3,2l 165 kW AXJ 6 Zyl.	
Throttle valve assembly	10.00-05.01		0 280 750 086
Air mass meter, gasoline injection	10.00-05.01		0 280 218 017 🔌 0 986 280 208
Phase sensor	10.00-05.01		0 232 103 019
Accelerator pedal module	10.00-05.01	AG,RLE GS,RLE	0 280 752 213 0 280 752 210

New Beetle Cabriolet

1.4 [1Y7]		1,4l 55 kW BCA 4 Zyl.	
Knock sensor	01.03→	0 261 231 146	
Pressure sensor, intake manifold, gasoline	01.03→	0 261 230 031	
Accelerator pedal module	01.03→	FMT,RLE	0 280 752 213
		FOT,RLE	0 280 752 210
1.6 [1Y7]		1,6l 75 kW BFS 4 Zyl.	
Speed sensor, ignition/injection	01.03→	0 261 210 199	
Knock sensor	01.03→	0 261 231 146	
Accelerator pedal module	01.03→	FMT,RLE	0 280 752 213
		FOT,RLE	0 280 752 210
1.8 T [1Y7]		1,8l 110 kW AWU 4 Zyl.	
Throttle valve assembly	12.03→	0 280 750 099	
Air mass meter, gasoline injection	12.03→	0 280 218 063	
		🔌 0 986 280 217	
Phase sensor	12.03→	0 232 101 024	
Speed sensor, ignition/injection	12.03→	0 261 210 147	
Knock sensor	12.03→	0 261 231 146	
Boost pressure sensor, gasoline	12.03→	0 281 002 177	



Accelerator pedal module	12.03→	FMT,RLE	0 280 752 213
		FOT,RLE	0 280 752 210
1.8 T [1Y7]		1,8l 110 kW AWV 4 Zyl.	
Throttle valve assembly	01.03-06.04		0 280 750 099
Air mass meter, gasoline injection	01.03-06.04		0 280 218 063
			0 986 280 217
Phase sensor	01.03-06.04		0 232 101 024
Speed sensor, ignition/injection	01.03-06.04		0 261 210 199
Knock sensor	01.03-06.04		0 261 231 146
Boost pressure sensor, gasoline	01.03-06.04		0 281 002 177
Temperature sensor, intake air, injection system			
Fg.no. →1Y..4..309 197	01.03-08.03		0 280 130 116
Accelerator pedal module	01.03-06.04	FMT,RLE	0 280 752 213
		FOT,RLE	0 280 752 210
1.8 T [1Y7]		1,8l 110 kW BKF 4 Zyl.	
Throttle valve assembly	07.04-06.05		0 280 750 099
Air mass meter, gasoline injection	07.04-06.05		0 280 218 060
			0 986 280 216
Speed sensor, ignition/injection	07.04-06.05		0 261 210 199
Boost pressure sensor, gasoline	07.04-06.05		0 281 002 177
Accelerator pedal module	07.04-06.05	FMT,RLE	0 280 752 213
		FOT,RLE	0 280 752 210
1.9 TDI [1Y7]		1,9l 74 kW AXR 4 Zyl.	
Air mass meter, diesel	06.03-06.05		0 281 002 531
			0 986 284 009
Boost pressure sensor, Diesel	06.03-06.05	TW	0 281 002 177
			0 281 002 399
1.9 TDI [1Y7]		1,9l 77 kW BSW 4 Zyl.	
Air mass meter, diesel	07.05→		0 281 002 531
			0 986 284 009
Boost pressure sensor, Diesel	07.05→		0 281 002 177
Pressure sensor, intake manifold, diesel	07.05→		0 281 002 399
2.0 [1Y7]		2,0l 85 kW AZJ; BDC 4 Zyl.	
Throttle valve assembly	01.03→		0 280 750 061
Air mass meter, gasoline injection	01.03→		0 280 218 060
			0 986 280 216
Phase sensor	01.03→		0 232 101 031
Speed sensor, ignition/injection	01.03→		0 261 210 199
Knock sensor	01.03→		0 261 231 146
Pressure sensor, intake manifold, gasoline	01.03→		0 281 002 177
Accelerator pedal module	01.03→	FMT,RLE	0 280 752 213
		FOT,RLE	0 280 752 210
2.0 [1Y7]		2,0l 85 kW BEV 4 Zyl.	
Speed sensor, ignition/injection	07.04→		0 261 210 147
Pressure sensor, intake manifold, gasoline	07.04→		0 281 002 177
Accelerator pedal module	07.04→	FMT,RLE	0 280 752 213
		FOT,RLE	0 280 752 210
2.0 [1Y7]		2,0l 85 kW BGD 4 Zyl.	
Air mass meter, gasoline injection	01.03-06.05		0 280 218 060
			0 986 280 216
Phase sensor	01.03-06.05		0 232 101 031
Speed sensor, ignition/injection	01.03-06.05		0 261 210 199
Knock sensor	01.03-06.05		0 261 231 146
Pressure sensor, intake manifold, gasoline	01.03-06.05		0 281 002 177
Accelerator pedal module	01.03-06.05	FMT,RLE	0 280 752 213
		FOT,RLE	0 280 752 210
2.5 [1Y7]		2,5l 110 kW BPR; BPS 5 Zyl.	
Air mass meter, gasoline injection	07.05→		0 280 218 071
			0 986 280 221
Pressure sensor, intake manifold, gasoline	07.05→		0 261 230 081
Accelerator pedal module	07.05→	FMT,RLE	0 280 752 213
		FOT,RLE	0 280 752 210



Parati III

1.8 Mi		1,8l 72 kW UDH 4 Zyl.
Knock sensor	08.99-08.05	0 261 231 146
Pressure sensor, intake manifold, gasoline	08.99-08.05	0 261 230 095
Wheel speed sensor, front	08.99-08.05	0 265 006 218
Wheel speed sensor, rear	08.99-08.05	LAB,TU2 0 265 006 222
		LAB,TU4 0 265 006 410
		RAB,TU2 0 265 006 221
		RAB,TU4 0 265 006 411

Passat

1.6 [3B2]		1,6l 74 kW ADP 4 Zyl.
Knock sensor	10.96-11.00	KZG 0 261 231 038
Temperature sensor, intake air, injection system	10.96-11.00	0 280 130 085
Duo sensor, acceleration and yaw rate, brake system	10.96-11.00	6PO 0 265 005 214
Yaw rate sensor, brake system	10.96-11.00	5PO 0 265 005 207
1.6 [3B2]		1,6l 74 kW AHL 4 Zyl.
Phase sensor	10.96-11.00	0 232 103 019
Speed sensor, ignition/injection	10.96-11.00	AG5,GS 0 261 210 147
Knock sensor	10.96-11.00	KZG 0 261 231 038
Temperature sensor, intake air, injection system	10.96-11.00	0 280 130 085
Duo sensor, acceleration and yaw rate, brake system	10.96-11.00	6PO 0 265 005 214
Yaw rate sensor, brake system	10.96-11.00	5PO 0 265 005 207
1.6 [3B2]		1,6l 74 kW ANA; ARM 4 Zyl.
Speed sensor, ignition/injection	01.99-11.00	AG5,GS 0 261 210 147
Knock sensor	01.99-11.00	KZG 0 261 231 038
Duo sensor, acceleration and yaw rate, brake system	01.99-11.00	6PO 0 265 005 214
Yaw rate sensor, brake system	01.99-11.00	5PO 0 265 005 207
1.6 [3B3]		1,6l 75 kW ALZ 4 Zyl.
Phase sensor		
Fg.no. →3B..2..240 126	10.00-10.01	0 232 101 038
Speed sensor, ignition/injection	10.00-05.05	0 281 002 222
Duo sensor, acceleration and yaw rate, brake system		
Fg.no. →3B..1..400 000	10.00-04.01	0 265 005 214
Fg.no. 3B..1..400 001→	05.01-05.05	0 265 005 252
Pressure sensor, ESP, (electronic stability program)	10.00-05.05	0 265 005 303
Wheel speed sensor, front	10.00-05.05	FMS 0 265 006 578
Wheel speed sensor, rear	10.00-05.05	ALR,LAB 0 265 006 575
		ALR,RAB 0 265 006 573
1.6 [3C2]		1,6l 75 kW BSE; BSF 4 Zyl.
Speed sensor, ignition/injection	03.05→	0 261 210 199
Knock sensor	03.05→	0 261 231 146
Pressure sensor, intake manifold, gasoline	03.05→	0 261 230 031
1.6 [31, 35, 3A..]		1,6l 55 kW 1F 4 Zyl.
Temperature sensor, coolant, injection system	08.88-07.90	0 280 130 040
1.6 [31, 35, 3A..]		1,6l 74 kW AEK 4 Zyl.
Air mass meter, gasoline injection	10.94-12.95	0 280 217 103
Knock sensor	10.94-12.95	KZB 0 261 231 036
1.6 [31, 35, 3A..]		1,6l 74 kW AFT 4 Zyl.
Knock sensor	12.95-03.97	KZB 0 261 231 036
Temperature sensor, intake air, injection system	12.95-03.97	0 280 130 039
1.6 FSI [3C2]		1,6l 85 kW BLF 4 Zyl.
Speed sensor, ignition/injection	03.05→	AG 0 261 210 250
Knock sensor	03.05→	0 261 231 146
Pressure sensor, intake manifold, gasoline	03.05→	0 261 230 095

Product					
◀ Passat					
1.8 [B5]		1,8l 92 kW ANQ 4 Zyl.			
Air mass meter, gasoline injection	11.99-02.03	0 280 218 013			
		🔌 0 986 280 206			
Phase sensor	11.99-02.03	0 232 101 024			
Speed sensor, ignition/injection	11.99-02.03	0 261 210 147			
Knock sensor	11.99-02.03	KZB	0 261 231 036		
		KZG	0 261 231 038		
Temperature sensor, intake air, injection system	11.99-02.03	0 280 130 085			
1.8 [3B2]		1,8l 85 kW AFY 4 Zyl.			
Temperature sensor, intake air, injection system	01.97-11.00	0 280 130 085			
Duo sensor, acceleration and yaw rate, brake system	01.97-11.00	6PO	0 265 005 214		
Yaw rate sensor, brake system	01.97-11.00	5PO	0 265 005 207		
1.8 [3B2]		1,8l 92 kW ADR 4 Zyl.			
Air mass meter, gasoline injection		0 280 218 013			
Fg.no. 3B..X..400 001→	01.99-01.99	🔌 0 986 280 206			
Phase sensor	12.96-01.99	0 232 101 024			
Knock sensor	12.96-01.99	KZB	0 261 231 036		
		KZG	0 261 231 038		
Temperature sensor, intake air, injection system	12.96-01.99	0 280 130 085			
Duo sensor, acceleration and yaw rate, brake system	12.96-01.99	6PO	0 265 005 214		
Yaw rate sensor, brake system	12.96-01.99	5PO	0 265 005 207		
1.8 [3B2]		1,8l 92 kW APT; ARG 4 Zyl.			
Throttle valve assembly		0 280 750 080			
Fg.no. 3B..X..550 001→	05.99-11.00	0 280 750 080			
Air mass meter, gasoline injection	01.99-11.00	0 280 218 013			
		🔌 0 986 280 206			
Knock sensor	01.99-11.00	KZB	0 261 231 036		
		KZG	0 261 231 038		
Temperature sensor, intake air, injection system	01.99-11.00	0 280 130 085			
Duo sensor, acceleration and yaw rate, brake system	01.99-11.00	6PO	0 265 005 214		
Yaw rate sensor, brake system	01.99-11.00	5PO	0 265 005 207		
1.8 [3B3]		1,8l 110 kW AWT 4 Zyl.			
Throttle valve assembly	10.00-05.05	0 280 750 009			
Air mass meter, gasoline injection		0 280 218 063			
Fg.no. →3B..2..100 000	10.00-06.01	🔌 0 986 280 217			
Fg.no. 3B..2..100 001→	07.01-05.05	0 280 218 100			
		🔌 0 986 280 223			
Phase sensor	10.00-05.05	0 232 101 024			
Speed sensor, ignition/injection	10.00-05.05	0 281 002 222			
Boost pressure sensor, gasoline		0 281 002 177			
Fg.no. →3B..3..350 000	10.00-02.03	0 281 002 177			
Fg.no. 3B..3..350 001→	03.03-05.05	0 261 230 073			
Temperature sensor, intake air, injection system	10.00-05.05	0 280 130 085			
Duo sensor, acceleration and yaw rate, brake system		0 265 005 214			
Fg.no. →3B..1..400 000	10.00-04.01	0 265 005 214			
Fg.no. 3B..1..400 001→	05.01-05.05	0 265 005 252			
Pressure sensor, ESP, (electronic stability program)	10.00-05.05	0 265 005 303			
Wheel speed sensor, front	10.00-05.05	FMS	0 265 006 578		
Wheel speed sensor, rear	10.00-05.05	ALR,LAB	0 265 006 575		
		ALR,RAB	0 265 006 573		
1.8 [3B3]		1,8l 125 kW AWM 4 Zyl.			
Throttle valve assembly	10.00-05.05	0 280 750 009			
Air mass meter, gasoline injection		0 280 218 063			
Fg.no. →3B..2..100 000	10.00-06.01	🔌 0 986 280 217			
Fg.no. 3B..2..100 001→	07.01-05.05	0 280 218 100			
		🔌 0 986 280 223			


Product				
Boost pressure sensor, gasoline				
Fg.no. →3B..3..350 000	10.00-02.03			0 281 002 177
Fg.no. 3B..3..350 001→	03.03-05.05			0 261 230 073
Temperature sensor, intake air, injection system	10.00-05.05			0 280 130 085
Duo sensor, acceleration and yaw rate, brake system				
Fg.no. →3B..1..400 000	10.00-04.01			0 265 005 214
Fg.no. 3B..1..400 001→	05.01-05.05			0 265 005 252
Pressure sensor, ESP, (electronic stability program)	10.00-05.05			0 265 005 303
Wheel speed sensor, front	10.00-05.05	FMS		0 265 006 578
Wheel speed sensor, rear	10.00-05.05	ALR,LAB		0 265 006 575
		ALR,RAB		0 265 006 573
1.8 [31, 35, 3A..]	1,8l 55/66 kW	AAM; ABS	4 Zyl.	
Temperature sensor, coolant, injection system	08.90-03.97			0 280 130 040
1.8 [31, 35, 3A..]	1,8l 66 kW	RP	4 Zyl.	
Knock sensor	08.88-07.91	KZG		0 261 231 004
Temperature sensor, coolant, injection system	04.88-07.91			0 280 130 040
1.8 [31, 35, 3A..]	1,8l 79 kW	PF	4 Zyl.	
Air flow sensor, gasoline injection	04.88-07.90			0 280 202 106
				0 986 280 008
Knock sensor	08.88-07.90	KZG		0 261 231 004
1.8 [31, 35, 3A..]	1,8l 82 kW	PB	4 Zyl.	
Air flow sensor, gasoline injection	04.88-07.90			0 280 200 041
Knock sensor	04.88-07.90			0 261 231 038
1.8 [31, 35, 3A..]	1,8l 100 kW	KR	4 Zyl.	
Air flow sensor, gasoline injection	04.88-07.92			F 026 TX2 050
				F 026 TX2 050
1.8 [32B]	1,8l 66 kW	JN	4 Zyl.	
Air flow sensor, gasoline injection	08.84-03.88			F 026 TX2 063
				F 026 TX2 063
1.8 G60 syncro [312,315,3A5]	1,8l 118 kW	PG	4 Zyl.	
Knock sensor	09.89-07.93	KZG		0 261 231 038
1.8 syncro [3B2]	1,8l 92 kW	ADR	4 Zyl.	
Throttle valve assembly				
Fg.no. 3B..X..550 001→	05.99-11.00			0 280 750 080
Air mass meter, gasoline injection				
Fg.no. 3B..X..400 001→	02.99-11.00			0 280 218 013
				0 986 280 206
Phase sensor	06.97-11.00			0 232 101 024
Knock sensor	06.97-11.00	KZG		0 261 231 038
Temperature sensor, intake air, injection system	06.97-11.00			0 280 130 085
Duo sensor, acceleration and yaw rate, brake system	06.97-11.00	6PO		0 265 005 214
Yaw rate sensor, brake system	06.97-11.00	5PO		0 265 005 207
Wheel speed sensor, rear	06.97-11.00	ALR,LAB,		0 265 006 575
		MFD		
		ALR,MFD,		0 265 006 573
		RAB		
		MFD,OLW		0 265 006 573
Fg.no. 3B..X..338 107→	11.98-11.00	ALR,LAB,		0 265 006 575
		OFD		
		ALR,OFD,		0 265 006 573
		RAB		
		OFD,OLW		0 265 006 573
1.8 syncro [3B2]	1,8l 92 kW	APT	4 Zyl.	
Throttle valve assembly				
Fg.no. 3B..X..550 001→	05.99-11.00			0 280 750 080
Air mass meter, gasoline injection	01.99-11.00			0 280 218 013
				0 986 280 206
Phase sensor	01.99-11.00			0 232 101 024
Knock sensor	01.99-11.00	KZG		0 261 231 038
Duo sensor, acceleration and yaw rate, brake system	01.99-11.00	6PO		0 265 005 214
system				



Yaw rate sensor, brake system	01.99-11.00	5PO	0 265 005 207
Wheel speed sensor, rear	01.99-11.00	ALR, LAB, MFD	0 265 006 575
		ALR, LAB, OFD	0 265 006 575
		ALR, MFD, RAB	0 265 006 573
		ALR, OFD, RAB	0 265 006 573
		MFD, OLW	0 265 006 573
		OFD, OWR	0 265 006 573
1.8 syncro [3B2]			1,8l 92 kW ARG 4 Zyl.
Throttle valve assembly			
Fg.no. 3B..X..550 001→	05.99-11.00		0 280 750 080
Air mass meter, gasoline injection	02.99-11.00		0 280 218 013
			0 986 280 206
Phase sensor	02.99-11.00		0 232 101 024
Knock sensor	02.99-11.00	KZG	0 261 231 038
Temperature sensor, intake air, injection system	02.99-11.00		0 280 130 085
Duo sensor, acceleration and yaw rate, brake system	02.99-11.00	6PO	0 265 005 214
Yaw rate sensor, brake system	02.99-11.00	5PO	0 265 005 207
Wheel speed sensor, rear	02.99-11.00	ALR, LAB, MFD	0 265 006 575
		ALR, LAB, OFD	0 265 006 575
		ALR, MFD, RAB	0 265 006 573
		ALR, OFD, RAB	0 265 006 573
		MFD, OLW	0 265 006 573
		OFD, OWR	0 265 006 573
1.8 Turbo [B5]			1,8l 110 kW AWL 4 Zyl.
Throttle valve assembly	10.01→		0 280 750 009
Air mass meter, gasoline injection	10.01-07.02		0 280 218 063
			0 986 280 217
	08.02→		0 280 218 100
			0 986 280 223
Phase sensor	10.01→		0 232 101 024
Speed sensor, ignition/injection	10.01→		0 281 002 222
Knock sensor	10.01→	KZB	0 261 231 036
		KZG	0 261 231 038
Temperature sensor, intake air, injection system	10.01→		0 280 130 085
1.8 Turbo [3B2]			1,8l 110 kW AEB 4 Zyl.
Air mass meter, gasoline injection			
Fg.no. WE175000/WP150000→	09.97-11.00		0 280 217 117
			0 986 280 201
Fg.no. →WE175000/WP150000	10.96-08.97		0 280 217 112
Phase sensor	10.96-11.00		0 232 101 024
Knock sensor	10.96-11.00	KZG	0 261 231 038
Pressure sensor, intake manifold, gasoline	10.96-11.00		0 280 101 001
Temperature sensor, intake air, injection system	10.96-11.00		0 280 130 085
Duo sensor, acceleration and yaw rate, brake system	10.96-11.00	6PO	0 265 005 214
Yaw rate sensor, brake system	10.96-11.00	5PO	0 265 005 207
1.8 Turbo [3B2]			1,8l 110 kW ANB; APU 4 Zyl.
Throttle valve assembly	08.98-11.00		0 280 750 009
Air mass meter, gasoline injection	08.98-11.00		0 280 218 023
			0 986 280 209
Knock sensor	08.98-11.00	KZG	0 261 231 038
Duo sensor, acceleration and yaw rate, brake system	08.98-11.00	6PO	0 265 005 214
Yaw rate sensor, brake system	08.98-11.00	5PO	0 265 005 207



1.9 TDI [3B2]			1,9l 66 kW AHH 4 Zyl.
Air mass meter, diesel	08.97-11.00		0 281 002 216
			0 986 284 001
Boost pressure sensor, Diesel	08.97-11.00		0 281 002 177
Pedal position sensor, diesel			
Fg.no. →3B..W..140 000	08.97-08.97	AG	0 205 001 031
		GS	0 205 001 032
Fg.no. 3B..W..140 001→3B..W..222 092	08.97-10.97	AG	0 281 002 254
		GS	0 281 002 229
Fg.no. 3B..W..222 093→3B..X..600 000	10.97-04.99	AG	0 281 002 289
		GS	0 281 002 286
Duo sensor, acceleration and yaw rate, brake system	08.97-11.00	6PO	0 265 005 214
Yaw rate sensor, brake system	08.97-11.00	5PO	0 265 005 207
1.9 TDI [3B2]			1,9l 66 kW AHU 4 Zyl.
Air mass meter, diesel			
Fg.no. WE118001/WP100001→	09.97-11.00		0 281 002 216
			0 986 284 001
Boost pressure sensor, Diesel	10.96-11.00		0 281 002 177
Pedal position sensor, diesel			
Fg.no. →3B..W..140 000	10.96-08.97	AG	0 205 001 031
		GS	0 205 001 032
Fg.no. 3B..W..140 001→3B..W..222 092	08.97-10.97	AG	0 281 002 254
		GS	0 281 002 229
Fg.no. 3B..W..222 093→3B..X..600 000	10.97-04.99	AG	0 281 002 289
		GS	0 281 002 286
Duo sensor, acceleration and yaw rate, brake system	10.96-11.00	6PO	0 265 005 214
Yaw rate sensor, brake system	10.96-11.00	5PO	0 265 005 207
1.9 TDI [3B2]			1,9l 74 kW AVB 4 Zyl.
Air mass meter, diesel	02.00-11.00		0 281 002 216
			0 986 284 001
Yaw rate sensor, brake system	02.00-11.00		0 265 005 207
		5PO	0 265 005 207
1.9 TDI [3B2]			1,9l 81 kW AFN 4 Zyl.
Air mass meter, diesel			
Fg.no. WE118001/WP100001→	09.97-11.00		0 281 002 216
			0 986 284 001
Boost pressure sensor, Diesel	10.96-11.00		0 281 002 177
Pedal position sensor, diesel			
Fg.no. →3B..W..140 000	10.96-08.97	AG	0 205 001 031
		GS	0 205 001 032
Fg.no. 3B..W..140 001→3B..W..222 092	08.97-10.97	AG	0 281 002 254
		GS	0 281 002 229
Fg.no. 3B..W..222 093→3B..X..600 000	10.97-04.99	AG	0 281 002 289
		GS	0 281 002 286
Duo sensor, acceleration and yaw rate, brake system	10.96-11.00	6PO	0 265 005 214
Yaw rate sensor, brake system	10.96-11.00	5PO	0 265 005 207
1.9 TDI [3B2]			1,9l 81 kW AVG 4 Zyl.
Air mass meter, diesel	08.99-11.00		0 281 002 216
			0 986 284 001
Boost pressure sensor, Diesel	08.99-11.00		0 281 002 177
Duo sensor, acceleration and yaw rate, brake system	08.99-11.00	6PO	0 265 005 214
Yaw rate sensor, brake system	08.99-11.00	5PO	0 265 005 207
1.9 TDI [3B2]			1,9l 85 kW AJM 4 Zyl.
Air mass meter, diesel	01.98-11.00		0 281 002 216
			0 986 284 001
Boost pressure sensor, Diesel	01.98-11.00		0 281 002 177
Pedal position sensor, diesel			
Fg.no. →3B..X..600 000	01.98-04.99	AG	0 281 002 289
		GS	0 281 002 286





Product				
◀ Passat				
Duo sensor, acceleration and yaw rate, brake system	01.98-11.00	6PO	0 265 005 214	
Yaw rate sensor, brake system	01.98-11.00	5PO	0 265 005 207	
1.9 TDI [3B2]		1,9l 85 kW ATJ 4 Zyl.		
Air mass meter, diesel	12.99-11.00		0 281 002 216	
			0 986 284 001	
Boost pressure sensor, Diesel	12.99-11.00		0 281 002 177	
Duo sensor, acceleration and yaw rate, brake system	12.99-11.00	6PO	0 265 005 214	
Yaw rate sensor, brake system	12.99-11.00	5PO	0 265 005 207	
1.9 TDI [3B3]		1,9l 74 kW AVB 4 Zyl.		
Air mass meter, diesel				
Fg.no. →3B..2P241 613,→3B..2P240 805,→3B..2E262 022	10.00-10.01		0 281 002 216	
			0 986 284 001	
Fg.no. 3B..2P241 614→,3B..2P240 806→,3B..2E262 023→	11.01-05.05		0 281 002 463	
			0 986 284 008	
Boost pressure sensor, Diesel				
Fg.no. →3B..2..250 000	10.00-10.01		0 281 002 177	
Fg.no. 3B..2..250 000→	11.01-05.05		0 281 002 399	
Duo sensor, acceleration and yaw rate, brake system				
Fg.no. →3B..1..400 000	10.00-04.01		0 265 005 214	
Fg.no. 3B..1..400 001→	05.01-05.05		0 265 005 252	
Pressure sensor, ESP, (electronic stability program)	10.00-05.05		0 265 005 303	
Wheel speed sensor, front	10.00-05.05	FMS	0 265 006 578	
Wheel speed sensor, rear	10.00-05.05	ALR,LAB	0 265 006 575	
		ALR,RAB	0 265 006 573	
1.9 TDI [3B3]		1,9l 96 kW AVF; AWX 4 Zyl.		
Air mass meter, diesel				
Fg.no. →3B..1..400 000	10.00-04.01		0 280 217 529	
			0 986 280 204	
Fg.no. 3B..2..000 001→	05.01-05.05		0 281 002 461	
			0 986 284 007	
Boost pressure sensor, Diesel	10.00-05.05		0 281 002 401	
Duo sensor, acceleration and yaw rate, brake system				
Fg.no. →3B..1..400 000	10.00-04.01		0 265 005 214	
Fg.no. 3B..1..400 001→	05.01-05.05		0 265 005 252	
Pressure sensor, ESP, (electronic stability program)	10.00-05.05		0 265 005 303	
Wheel speed sensor, front	10.00-05.05	FMS	0 265 006 578	
Wheel speed sensor, rear	10.00-05.05	ALR,LAB	0 265 006 575	
		ALR,RAB	0 265 006 573	
1.9 TDI [3C2]		1,9l 77 kW BKC; BLS; BXE 4 Zyl.		
Air mass meter, diesel	03.05→		0 281 002 531	
			0 986 284 009	
Boost pressure sensor, Diesel	03.05→		0 281 002 399	
1.9 TDI [31, 35, 3A..]		1,9l 66 kW AHU 4 Zyl.		
Pedal position sensor, diesel	08.96-12.96	LLE	0 205 001 032	
		RLE	0 205 001 024	
1.9 TDI [31, 35, 3A..]		1,9l 66 kW IZ 4 Zyl.		
Pressure sensor, intake manifold, diesel				
Fg.no. →3A..SE085 001,→3A..SB012 818,→3A..RE027 690	10.93-09.94		0 261 230 037	
Pedal position sensor, diesel				
Fg.no. →3A..S..192 818	10.93-04.95	LLE	0 205 001 024	
		RLE	0 205 001 023	
Fg.no. 3A..S..192 819→	05.95-07.96	AG	0 205 001 031	
		GS	0 205 001 032	
1.9 TDI syncro [3B2]		1,9l 81 kW AFN 4 Zyl.		
Air mass meter, diesel				
Fg.no. WE 106 001→,WP 090 001→	08.97-11.00		0 281 002 216	
			0 986 284 001	
Boost pressure sensor, Diesel	06.97-11.00		0 281 002 177	

Product				
Pedal position sensor, diesel				
Fg.no. →3B..W..140 000	06.97-08.97	AG	0 205 001 031	
		GS	0 205 001 032	
Fg.no. 3B..W..140 001→3B..W..222 092	09.97-10.97	GS	0 281 002 229	
Fg.no. 3B..W..140 001→3B..X..600 000	09.97-04.99	AG	0 281 002 289	
Fg.no. 3B..W..222 093→3B..X..600 000	11.97-04.99	GS	0 281 002 286	
Duo sensor, acceleration and yaw rate, brake system	06.97-11.00	6PO	0 265 005 214	
Yaw rate sensor, brake system	06.97-11.00	5PO	0 265 005 207	
Wheel speed sensor, rear	06.97-11.00	ALR,LAB, MFD	0 265 006 575	
		ALR,MFD, RAB	0 265 006 573	
		MFD,OLW	0 265 006 573	
Fg.no. 3B..X..338 107→	11.98-11.00	ALR,LAB, OFD	0 265 006 575	
		ALR,OFD, RAB	0 265 006 573	
		OFD,OLW	0 265 006 573	
1.9 TDI syncro [3B2]		1,9l 81 kW AVG 4 Zyl.		
Air mass meter, diesel	08.99-08.00		0 281 002 216	
			0 986 284 001	
Boost pressure sensor, Diesel				
Fg.no. 3B..W..040 001→	08.99-08.00		0 281 002 177	
Duo sensor, acceleration and yaw rate, brake system	08.99-08.00	6PO	0 265 005 214	
Yaw rate sensor, brake system	08.99-08.00	5PO	0 265 005 207	
Wheel speed sensor, rear	08.99-08.00	ALR,LAB, MFD	0 265 006 575	
		ALR,LAB, OFD	0 265 006 575	
		ALR,MFD, RAB	0 265 006 573	
		ALR,OFD, RAB	0 265 006 573	
		MFD,OLW	0 265 006 573	
		OFD,OWR	0 265 006 573	
1.9 TDI syncro [3B2]		1,9l 85 kW AJM 4 Zyl.		
Pedal position sensor, diesel				
Fg.no. →3B..X..600 000	11.97-04.99	AG	0 281 002 289	
		GS	0 281 002 286	
Duo sensor, acceleration and yaw rate, brake system	11.97-11.00	6PO	0 265 005 214	
Yaw rate sensor, brake system	11.97-11.00	5PO	0 265 005 207	
Wheel speed sensor, rear	11.97-11.00	ALR,LAB, MFD	0 265 006 575	
		ALR,MFD, RAB	0 265 006 573	
		MFD,OLW	0 265 006 573	
Fg.no. 3B..X..338 107→	11.98-11.00	ALR,LAB, OFD	0 265 006 575	
		ALR,OFD, RAB	0 265 006 573	
		OFD,OLW	0 265 006 573	
1.9 TDI 4 Motion [3B3]		1,9l 96 kW AVF; AWX 4 Zyl.		
Air mass meter, diesel				
Fg.no. →3B..1..400 000	10.00-04.01		0 280 217 529	
			0 986 280 204	
Fg.no. 3B..2..000 001→	05.01-05.05		0 281 002 461	
			0 986 284 007	
Pressure sensor, intake manifold, diesel	10.00-05.05		0 281 002 401	



Duo sensor, acceleration and yaw rate, brake system		
Fg.no. →3B..1..400 000	10.00-04.01	0 265 005 214
Fg.no. 3B..1..400 001→	05.01-05.05	0 265 005 252
Pressure sensor, ESP, (electronic stability program)	10.00-05.05	0 265 005 303
Wheel speed sensor, front	10.00-05.05 FMS	0 265 006 578
Wheel speed sensor, rear	10.00-05.05	0 265 006 573
2.0 [3B2]	2,0l 88 kW ASU; AUZ 4 Zyl.	
Duo sensor, acceleration and yaw rate, brake system	01.00-08.00 6PO	0 265 005 214
Yaw rate sensor, brake system	01.00-08.00 5PO	0 265 005 207
2.0 [3B3]	2,0l 85 kW AZM 4 Zyl.	
Phase sensor	10.00-05.05	0 232 101 031
Speed sensor, ignition/injection	10.00-05.05	0 261 210 147
Duo sensor, acceleration and yaw rate, brake system		
Fg.no. →3B..1..400 000	10.00-04.01	0 265 005 214
Fg.no. 3B..1..400 001→	05.01-05.05	0 265 005 252
Pressure sensor, ESP, (electronic stability program)	10.00-05.05	0 265 005 303
Wheel speed sensor, front	10.00-05.05 FMS	0 265 006 578
Wheel speed sensor, rear	10.00-05.05 ALR, LAB	0 265 006 575
	ALR, RAB	0 265 006 573
2.0 [3B3]	2,0l 95 kW ALT 4 Zyl.	
Throttle valve assembly	11.01-05.05	0 280 750 088
Air mass meter, gasoline injection	11.01-05.05	0 280 218 058
		0 986 280 215
Phase sensor	11.01-05.05	0 232 101 024
Speed sensor, ignition/injection	11.01-05.05	0 281 002 222
Pressure sensor, ESP, (electronic stability program)	11.01-05.05	0 265 005 303
Wheel speed sensor, front	11.01-05.05 FMS	0 265 006 578
Wheel speed sensor, rear	11.01-05.05 ALR, LAB	0 265 006 575
	ALR, RAB	0 265 006 573
2.0 [31, 35, 3A..]	2,0l 85 kW ADY 4 Zyl.	
Knock sensor	10.94-07.95 KZG	0 261 231 004
2.0 [31, 35, 3A..]	2,0l 85 kW AGG 4 Zyl.	
Knock sensor	07.95-03.97 KZG	0 261 231 038
2.0 [31, 35, 3A..]	2,0l 85 kW 2E 4 Zyl.	
Knock sensor	03.90-09.94 KZB	0 261 231 036
2.0 [31, 35, 3A..]	2,0l 100 kW 9A 4 Zyl.	
Throttle valve sensor	08.88-09.93 AG	0 280 120 433
	GS	0 280 120 426
Air flow sensor, gasoline injection		
Fg.no. →31-N-400 000	08.88-07.92	0 438 121 076
		0 986 439 376
Fg.no. 31-P-000 001→	07.92-09.93	0 986 439 389
		F 026 TX2 059
		0 986 439 389
Knock sensor	08.88-09.93 KZG	0 261 231 004
Temperature sensor, coolant, injection system	08.88-09.93	0 280 130 040
2.0 [31, 35, 3A..]	2,0l 110 kW ABF 4 Zyl.	
Knock sensor	01.94-03.97 KZG	0 261 231 004
2.0 [32B]	2,0l 85 kW HP; JS 5 Zyl.	
Air flow sensor, gasoline injection	08.83-01.86 MZF	0 438 121 005
2.0 FSI [3C2]	2,0l 110 kW BLR; BLY; BVY; BVZ 4 Zyl.	
Knock sensor	03.05→ OHL	0 261 231 146
Pressure sensor, intake manifold, gasoline	03.05→	0 261 230 031
2.0 FSI 4 Motion [3C2]	2,0l 110 kW BLX; BLY; BVX 4 Zyl.	
Knock sensor	09.05→ OHL	0 261 231 146
Pressure sensor, intake manifold, gasoline	09.05→	0 261 230 031
2.0 i [B5]	2,0l 85 kW BFF 4 Zyl.	
Air mass meter, gasoline injection	03.03-02.07	0 280 218 132
Phase sensor	03.03-02.07	0 232 101 094



Speed sensor, ignition/injection	03.03-02.07	0 261 210 241
Knock sensor	03.03-02.07	0 261 231 146
2.0 syncro [312,315,3A5]	2,0l 85 kW 2E 4 Zyl.	
Air flow sensor, gasoline injection	10.90-09.94	0 280 202 106
		0 986 280 008
Knock sensor	10.90-09.94 KZB	0 261 231 036
2.0 TDI [3B3]	2,0l 100 kW BGW 4 Zyl.	
Air mass meter, diesel	11.03-05.05	0 281 002 461
		0 986 284 007
Boost pressure sensor, Diesel	11.03-05.05	0 281 002 401
Pressure sensor, ESP, (electronic stability program)	11.03-05.05	0 265 005 303
Wheel speed sensor, front	11.03-05.05 FMS	0 265 006 578
Wheel speed sensor, rear	11.03-05.05 ALR, LAB	0 265 006 575
	ALR, RAB	0 265 006 573
2.0 TDI [3C2]	2,0l 88/90/100/103 kW BKP; BMA; BVD; BVE; BWV 4 Zyl.	
Air mass meter, diesel	03.05→	0 281 002 461
		0 986 284 007
Boost pressure sensor, Diesel	03.05→	0 281 002 401
2.0 TDI [3C2]	2,0l 103/120/125 kW BMP; BMR; BUZ 4 Zyl.	
Air mass meter, diesel	03.05→	0 281 002 461
		0 986 284 007
Boost pressure sensor, Diesel	03.05→	0 281 002 401
2.0 TDI 4 Motion [3C2]	2,0l 103 kW BKP; BMP 4 Zyl.	
Air mass meter, diesel	03.05→	0 281 002 461
		0 986 284 007
Boost pressure sensor, Diesel	03.05→	0 281 002 401
2.0 TFSI [3C2]	2,0l 147 kW AXX; BPY; BWA 4 Zyl.	
Speed sensor, ignition/injection	03.05→	0 261 210 199
Boost pressure sensor, gasoline	03.05→	0 261 230 073
2.0 4 Motion [3B3]	2,0l 85 kW AZM 4 Zyl.	
Phase sensor	10.00-05.05	0 232 101 031
Speed sensor, ignition/injection	10.00-05.05	0 261 210 147
Duo sensor, acceleration and yaw rate, brake system		
Fg.no. →3B..1..400 000	10.00-04.01	0 265 005 214
Fg.no. 3B..1..400 001→	05.01-05.05	0 265 005 252
Pressure sensor, ESP, (electronic stability program)	10.00-05.05	0 265 005 303
Wheel speed sensor, front	10.00-05.05 FMS	0 265 006 578
Wheel speed sensor, rear	10.00-05.05	0 265 006 573
2.2 [32B]	2,2l 85 kW KX 5 Zyl.	
Air flow sensor, gasoline injection	08.85-03.88	F 026 TX2 064
		F 026 TX2 064
Pressure sensor, intake manifold, gasoline	08.85-03.88	0 280 101 001
Temperature sensor, coolant, injection system	08.85-03.88	0 280 130 037
2.2 [32B]	2,2l 100 kW HY 5 Zyl.	
Air flow sensor, gasoline injection	02.86-03.88	0 438 120 211
	01.85-01.86 MZF	0 438 121 005
2.2 [32B]	2,2l 100 kW KV 5 Zyl.	
Air flow sensor, gasoline injection	01.85-01.86 MZF	0 438 121 005
2.3 [3B2]	2,3l 110 kW AGZ 5 Zyl.	
Air mass meter, gasoline injection	10.96-11.00	0 280 217 529
		0 986 280 204
Phase sensor	10.96-11.00	0 232 103 019
Speed sensor, ignition/injection	10.96-11.00 AG5, GS	0 261 210 139
Temperature sensor, intake air, injection system		
Fg.no. →3B..X..030 000	10.96-05.98	0 280 130 039
Fg.no. 3B..X..030 001→	05.98-11.00	0 280 130 085
Duo sensor, acceleration and yaw rate, brake system	10.96-11.00 6PO	0 265 005 214
Yaw rate sensor, brake system	10.96-11.00 5PO	0 265 005 207



Product

◀ Passat

2.3 [3B3]		2,3l 125 kW AZX 5 Zyl.	
Throttle valve assembly	10.00-05.05		0 280 750 097
Air mass meter, gasoline injection	10.00-05.05		0 280 218 017
			0 986 280 208
Phase sensor	10.00-05.05		0 232 103 019
Speed sensor, ignition/injection	10.00-05.05		0 261 210 177
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →3B..1..400 000	10.00-04.01		0 265 005 214
Fg.no. 3B..1..400 001→	05.01-05.05		0 265 005 252
Pressure sensor, ESP, (electronic stability program)	10.00-05.05		0 265 005 303
Wheel speed sensor, front	10.00-05.05	FMS	0 265 006 578
Wheel speed sensor, rear	10.00-05.05	ALR,LAB	0 265 006 575
		ALR,RAB	0 265 006 573
2.3 syncro [3B2]		2,3l 110 kW AGZ 5 Zyl.	
Air mass meter, gasoline injection	06.97-11.00		0 280 217 529
			0 986 280 204
Phase sensor	06.97-11.00		0 232 103 019
Speed sensor, ignition/injection	06.97-11.00		0 261 210 139
Temperature sensor, intake air, injection system			
Fg.no. →3B..X..132 000	06.97-08.98		0 280 130 039
Fg.no. 3B..X..132 001→	09.98-11.00		0 280 130 085
Duo sensor, acceleration and yaw rate, brake system	06.97-11.00	6PO	0 265 005 214
Yaw rate sensor, brake system	06.97-11.00	5PO	0 265 005 207
Wheel speed sensor, rear	06.97-11.00	ALR,LAB, MFD	0 265 006 575
		ALR,MFD, RAB	0 265 006 573
		MFD,OLW	0 265 006 573
Fg.no. 3B..X..338 107→	11.98-11.00	ALR,LAB, OFD	0 265 006 575
		ALR,OFD, RAB	0 265 006 573
		OFD,OLW	0 265 006 573
2.3 4 Motion [3B3]		2,3l 125 kW AZX 5 Zyl.	
Throttle valve assembly	01.01-05.05		0 280 750 097
Air mass meter, gasoline injection	01.01-05.05		0 280 218 017
			0 986 280 208
Phase sensor	01.01-05.05		0 232 103 019
Speed sensor, ignition/injection	01.01-05.05		0 261 210 177
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →3B..1..400 000	01.01-04.01		0 265 005 214
Fg.no. 3B..1..400 001→	05.01-05.05		0 265 005 252
Pressure sensor, ESP, (electronic stability program)	01.01-05.05		0 265 005 303
Wheel speed sensor, front	01.01-05.05	FMS	0 265 006 578
Wheel speed sensor, rear	01.01-05.05		0 265 006 573
2.5 TDI [3B2]		2,5l 110 kW AFB; AKN 6 Zyl.	
Air mass meter, diesel	08.98-11.00		0 281 002 224
Speed sensor, diesel	08.98-11.00		0 281 002 222
Boost pressure sensor, Diesel	08.98-11.00		0 281 002 177
Duo sensor, acceleration and yaw rate, brake system	08.98-11.00	6PO	0 265 005 214
Yaw rate sensor, brake system	08.98-11.00	5PO	0 265 005 207
2.5 TDI [3B3]		2,5l 110 kW AKN 6 Zyl.	
Speed sensor, diesel	10.00-05.03		0 281 002 222
Boost pressure sensor, Diesel	10.00-05.03		0 281 002 177
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →3B..1..400 000	10.00-04.01		0 265 005 214
Fg.no. 3B..1..400 001→	05.01-05.03		0 265 005 252
Pressure sensor, ESP, (electronic stability program)	10.00-05.03		0 265 005 303
Wheel speed sensor, front	10.00-05.03	FMS	0 265 006 578
Wheel speed sensor, rear	10.00-05.03		0 265 006 573
2.5 TDI 4 Motion [3B3]		2,5l 132 kW BAU; BDH 6 Zyl.	
Speed sensor, diesel	01.03-05.05		0 281 002 222
Boost pressure sensor, Diesel	01.03-05.05		0 281 002 399
Pressure sensor, ESP, (electronic stability program)	01.03-05.05		0 265 005 303

Product


Wheel speed sensor, front	10.00-05.03	FMS	0 265 006 578
Wheel speed sensor, rear	10.00-05.03	ALR,LAB	0 265 006 575
		ALR,RAB	0 265 006 573
2.5 TDI [3B3]		2,5l 120 kW BDG 6 Zyl.	
Speed sensor, diesel	05.03-05.05		0 281 002 222
Boost pressure sensor, Diesel	05.03-05.05		0 281 002 399
Pressure sensor, ESP, (electronic stability program)	05.03-05.05		0 265 005 303
Wheel speed sensor, front	05.03-05.05	FMS	0 265 006 578
Wheel speed sensor, rear	05.03-05.05	ALR,LAB	0 265 006 575
		ALR,RAB	0 265 006 573
2.5 TDI syncro [3B2]		2,5l 110 kW AFB 6 Zyl.	
Air mass meter, diesel	08.98-11.00		0 281 002 224
Speed sensor, diesel	08.98-04.99		0 261 210 178
	05.99-11.00		0 281 002 222
Pedal position sensor, diesel			
Fg.no. →3B..X..600 000	08.98-04.99	AG	0 281 002 289
Duo sensor, acceleration and yaw rate, brake system	08.98-11.00	6PO	0 265 005 214
Yaw rate sensor, brake system	08.98-11.00	5PO	0 265 005 207
Wheel speed sensor, rear	08.98-11.00	ALR,LAB, MFD	0 265 006 575
		ALR,MFD, RAB	0 265 006 573
		MFD,OLW	0 265 006 573
Fg.no. 3B..X..338 107→	11.98-11.00	ALR,LAB, OFD	0 265 006 575
		ALR,OFD, RAB	0 265 006 573
		OFD,OLW	0 265 006 573
2.5 TDI syncro [3B2]		2,5l 110 kW AKN 6 Zyl.	
Air mass meter, diesel			
Fg.no. →3B..Y..200 000	08.98-11.99		0 281 002 224
Fg.no. 3B..Y..200 001→	12.99-11.00		0 281 002 403
			0 986 284 004
Speed sensor, diesel	08.98-04.99		0 261 210 178
	05.99-11.00		0 281 002 222
Duo sensor, acceleration and yaw rate, brake system	08.98-11.00	6PO	0 265 005 214
Yaw rate sensor, brake system	08.98-11.00	5PO	0 265 005 207
Wheel speed sensor, rear	08.98-11.00	ALR,LAB, MFD	0 265 006 575
		ALR,MFD, RAB	0 265 006 573
		MFD,OLW	0 265 006 573
Fg.no. 3B..X..338 107→	11.98-11.00	ALR,LAB, OFD	0 265 006 575
		ALR,OFD, RAB	0 265 006 573
		OFD,OLW	0 265 006 573
2.5 TDI 4 Motion [3B3]		2,5l 110 kW AKN 6 Zyl.	
Speed sensor, diesel	10.00-01.03		0 281 002 222
Boost pressure sensor, Diesel	10.00-01.03		0 281 002 177
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →3B..1..400 000	10.00-04.01		0 265 005 214
Fg.no. 3B..1..400 001→	05.01-01.03		0 265 005 252
Pressure sensor, ESP, (electronic stability program)	10.00-01.03		0 265 005 303
Wheel speed sensor, front	10.00-01.03	FMS	0 265 006 578
Wheel speed sensor, rear	10.00-01.03		0 265 006 573



Wheel speed sensor, front	01.03-05.05	FMS	0 265 006 578
Wheel speed sensor, rear	01.03-05.05		0 265 006 573
2.8 [B5]		2,8l 140 kW BBG 6 Zyl.	
Throttle valve assembly	01.02-02.07		0 280 750 030
Phase sensor	01.02-02.07		0 232 101 024
Speed sensor, ignition/injection	01.02-02.07		0 281 002 222
Temperature sensor, intake air, injection system	01.02-02.07		0 280 130 085
2.8 [3B2]		2,8l 132 kW AGE 6 Zyl.	
Phase sensor	01.97-11.00		0 232 101 024
Speed sensor, ignition/injection			
Fg.no. →3B..W..055 000	01.97-06.97	AG5,GS	0 261 210 134
Fg.no. 3B..W..055 001→	06.97-11.00	AG5,GS	0 261 210 178
Knock sensor	01.97-11.00	KZB	0 261 231 036
Temperature sensor, intake air, injection system	01.97-11.00		0 280 130 085
Duo sensor, acceleration and yaw rate, brake system	01.97-11.00	6PO	0 265 005 214
Yaw rate sensor, brake system	01.97-11.00	5PO	0 265 005 207
2.8 [3B2]		2,8l 140 kW ATX 6 Zyl.	
Throttle valve assembly	10.99-11.00		0 280 750 030
Duo sensor, acceleration and yaw rate, brake system	10.99-11.00	6PO	0 265 005 214
Yaw rate sensor, brake system	10.99-11.00	5PO	0 265 005 207
2.8 [3B2]		2,8l 142 kW ACK 6 Zyl.	
Phase sensor	01.97-11.00		0 232 101 024
Speed sensor, ignition/injection			
Fg.no. →3B..W..055 000	01.97-06.97	AG5,GS	0 261 210 134
Fg.no. 3B..W..055 001→	06.97-11.00	AG	0 261 210 147
		AG5,GS	0 261 210 178
Knock sensor	01.97-11.00	KZB	0 261 231 036
Temperature sensor, intake air, injection system	01.97-11.00		0 280 130 085
Duo sensor, acceleration and yaw rate, brake system	01.97-11.00	6PO	0 265 005 214
Yaw rate sensor, brake system	01.97-11.00	5PO	0 265 005 207
2.8 [3B2]		2,8l 142 kW APR 6 Zyl.	
Phase sensor	01.99-11.00		0 232 101 024
Speed sensor, ignition/injection	01.99-11.00	AG5	0 261 210 147
		GS	0 261 210 178
Knock sensor	01.99-11.00	KZB	0 261 231 036
Temperature sensor, intake air, injection system	01.99-11.00		0 280 130 085
Duo sensor, acceleration and yaw rate, brake system	01.99-11.00	6PO	0 265 005 214
Yaw rate sensor, brake system	01.99-11.00	5PO	0 265 005 207
2.8 [3B2]		2,8l 142 kW AQD 6 Zyl.	
Throttle valve assembly	01.99-11.00		0 280 750 030
Temperature sensor, intake air, injection system	01.99-11.00		0 280 130 085
Duo sensor, acceleration and yaw rate, brake system	01.99-11.00	6PO	0 265 005 214
Yaw rate sensor, brake system	01.99-11.00	5PO	0 265 005 207
2.8 [3B3]		2,8l 140/142 kW AMX;BBG 6 Zyl.	
Throttle valve assembly	10.00-05.05		0 280 750 030
Phase sensor	10.00-05.05		0 232 101 024
Speed sensor, ignition/injection	10.00-05.05	AG	0 261 210 147
		GS	0 261 210 178
Temperature sensor, intake air, injection system	10.00-05.05		0 280 130 085
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →3B..1..400 000	10.00-04.01		0 265 005 214
Fg.no. 3B..1..400 001→	05.01-05.05		0 265 005 252
Pressure sensor, ESP, (electronic stability program)	10.00-05.05		0 265 005 303
Wheel speed sensor, front	10.00-05.05	FMS	0 265 006 578
Wheel speed sensor, rear	10.00-05.05	ALR,LAB	0 265 006 575
		ALR,RAB	0 265 006 573



2.8 [3B3]		2,8l 142 kW ATQ 6 Zyl.	
Throttle valve assembly	10.00-05.05		0 280 750 030
Phase sensor	10.00-05.05		0 232 101 024
Temperature sensor, intake air, injection system	10.00-05.05		0 280 130 085
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →3B..1..400 000	10.00-04.01		0 265 005 214
Fg.no. 3B..1..400 001→	05.01-05.05		0 265 005 252
Pressure sensor, ESP, (electronic stability program)	10.00-05.05		0 265 005 303
Wheel speed sensor, front	10.00-05.05	FMS	0 265 006 578
Wheel speed sensor, rear	10.00-05.05	ALR,LAB	0 265 006 575
		ALR,RAB	0 265 006 573
2.8 [31, 35, 3A..]		2,8l 128 kW AAA 6 Zyl.	
Air mass meter, gasoline injection	06.91-07.93		0 280 213 021
			0 986 280 122
	08.93-03.97		0 280 217 504
Speed sensor, ignition/injection			
Fg.no. →3A-S-300 000	06.91-07.95		0 261 210 080
Fg.no. 3A-T-000 001→	07.95-03.97		0 261 210 107
Knock sensor	06.91-03.97	KZG	0 261 231 004
		KZS	0 261 231 064
		KZW	0 261 231 047
Temperature sensor, intake air, injection system	06.91-03.97		0 280 130 039
2.8 syncro [3B2]		2,8l 142 kW ACK 6 Zyl.	
Phase sensor	01.97-11.00		0 232 101 024
Speed sensor, ignition/injection			
Fg.no. →3B..W..055 000	01.97-06.98		0 261 210 134
Fg.no. 3B..W..055 001→	07.98-11.00	AG	0 261 210 147
		GS	0 261 210 178
Knock sensor	01.97-11.00	KZB	0 261 231 036
Temperature sensor, intake air, injection system	01.97-11.00		0 280 130 085
Duo sensor, acceleration and yaw rate, brake system	01.97-11.00	6PO	0 265 005 214
Yaw rate sensor, brake system	01.97-11.00	5PO	0 265 005 207
Wheel speed sensor, rear	01.97-11.00	ALR,LAB	0 265 006 575
		MFD	
		ALR,MFD	0 265 006 573
		RAB	
		MFD,OLW	0 265 006 573
Fg.no. 3B..X..338 107→	11.98-11.00	ALR,LAB	0 265 006 575
		OFD	
		ALR,OFD	0 265 006 573
		RAB	
		OFD,OLW	0 265 006 573
2.8 syncro [3B2]		2,8l 142 kW ALG 6 Zyl.	
Phase sensor	06.97-11.00		0 232 101 024
Speed sensor, ignition/injection	06.97-11.00	AG	0 261 210 147
		GS	0 261 210 178
Knock sensor	06.97-11.00	KZB	0 261 231 036
Temperature sensor, intake air, injection system	06.97-11.00		0 280 130 085
Duo sensor, acceleration and yaw rate, brake system	06.97-11.00	6PO	0 265 005 214
Yaw rate sensor, brake system	06.97-11.00	5PO	0 265 005 207
Wheel speed sensor, rear	06.97-11.00	ALR,LAB	0 265 006 575
		MFD	
		ALR,MFD	0 265 006 573
		RAB	
		MFD,OLW	0 265 006 573
Fg.no. 3B..X..338 107→	11.98-11.00	ALR,LAB	0 265 006 575
		OFD	
		ALR,OFD	0 265 006 573
		RAB	
		OFD,OLW	0 265 006 573



Product				
◀ Passat				
2.8 syncro [3B2]		2,8l 142 kW APR 6 Zyl.		
Throttle valve assembly	01.99-11.00	0 280 750 030		
Phase sensor	01.99-11.00	0 232 101 024		
Speed sensor, ignition/injection	01.99-11.00	AG	0 261 210 147	
Knock sensor				
Fg.no. →3B..X..600 000	01.99-04.99	KZB	0 261 231 036	
Temperature sensor, intake air, injection system	01.99-11.00	0 280 130 085		
Duo sensor, acceleration and yaw rate, brake system	01.99-11.00	6PO	0 265 005 214	
Yaw rate sensor, brake system	01.99-11.00	5PO	0 265 005 207	
Wheel speed sensor, rear	01.99-11.00	ALR,LAB, MFD	0 265 006 575	
		ALR,LAB, OFD	0 265 006 575	
		ALR,MFD, RAB	0 265 006 573	
		ALR,OFD, RAB	0 265 006 573	
		MFD,OLW	0 265 006 573	
		OFD,OWR	0 265 006 573	
2.8 syncro [3B2]		2,8l 142 kW AQD 6 Zyl.		
Throttle valve assembly	01.99-11.00	0 280 750 030		
Phase sensor	01.99-11.00	0 232 101 024		
Speed sensor, ignition/injection	01.99-11.00	AG	0 261 210 147	
		GS	0 261 210 178	
Knock sensor				
Fg.no. →3B..X..600 000	01.99-04.99	KZB	0 261 231 036	
Temperature sensor, intake air, injection system	01.99-11.00	0 280 130 085		
Duo sensor, acceleration and yaw rate, brake system	01.99-11.00	6PO	0 265 005 214	
Yaw rate sensor, brake system	01.99-11.00	5PO	0 265 005 207	
Wheel speed sensor, rear	01.99-11.00	ALR,LAB, MFD	0 265 006 575	
		ALR,LAB, OFD	0 265 006 575	
		ALR,MFD, RAB	0 265 006 573	
		ALR,OFD, RAB	0 265 006 573	
		MFD,OLW	0 265 006 573	
		OFD,OWR	0 265 006 573	
2.8 syncro [3B2]		2,8l 142 kW ATX 6 Zyl.		
Throttle valve assembly	10.99-11.00	0 280 750 030		
Temperature sensor, intake air, injection system	10.99-11.00	0 280 130 085		
Duo sensor, acceleration and yaw rate, brake system	10.99-11.00	6PO	0 265 005 214	
Yaw rate sensor, brake system	10.99-11.00	5PO	0 265 005 207	
Wheel speed sensor, rear	10.99-11.00	ALR,LAB, MFD	0 265 006 575	
		ALR,LAB, OFD	0 265 006 575	
		ALR,MFD, RAB	0 265 006 573	
		ALR,OFD, RAB	0 265 006 573	
		MFD,OLW	0 265 006 573	
		OFD,OWR	0 265 006 573	
2.8 4 Motion [3B3]		2,8l 140/142 kW AMX; BBG 6 Zyl.		
Throttle valve assembly	10.00-05.05	0 280 750 030		
Phase sensor	10.00-05.05	0 232 101 024		
Speed sensor, ignition/injection	10.00-05.05	AG	0 261 210 147	
		GS	0 261 210 178	
Temperature sensor, intake air, injection system	10.00-05.05	0 280 130 085		

Product				
Duo sensor, acceleration and yaw rate, brake system				
Fg.no. →3B..1..400 000	10.00-04.01			0 265 005 214
Fg.no. 3B..1..400 001→	05.01-05.05			0 265 005 252
Pressure sensor, ESP, (electronic stability program)	10.00-05.05			0 265 005 303
Wheel speed sensor, front	10.00-05.05	FMS		0 265 006 578
Wheel speed sensor, rear	10.00-05.05			0 265 006 573
2.8 4 Motion [3B3]		2,8l	142 kW ATQ 6 Zyl.	
Throttle valve assembly	10.00-05.05			0 280 750 030
Phase sensor	10.00-05.05			0 232 101 024
Temperature sensor, intake air, injection system	10.00-05.05			0 280 130 085
Duo sensor, acceleration and yaw rate, brake system				
Fg.no. →3B..1..400 000	10.00-04.01			0 265 005 214
Fg.no. 3B..1..400 001→	05.01-05.05			0 265 005 252
Pressure sensor, ESP, (electronic stability program)	10.00-05.05			0 265 005 303
Wheel speed sensor, front	10.00-05.05	FMS		0 265 006 578
Wheel speed sensor, rear	10.00-05.05			0 265 006 573
3.2 FSI 4 Motion [3C2]		3,2l	184 kW AXZ 6 Zyl.	
Air mass meter, gasoline injection	09.05→			0 280 218 175
Knock sensor	09.05→	OHL		0 261 231 146
3.6 FSI, FSI 4 Motion [3C2]		3,6l	206 kW BLV 6 Zyl.	
Air mass meter, gasoline injection	09.05→			0 280 218 175
Knock sensor	09.05→	TW		0 261 231 146
4.0 [3B3]		4,0l	202 kW BDN; BDP 8 Zyl.	
Air mass meter, gasoline injection	05.02-09.04			0 280 218 073
				0 986 280 222
Phase sensor	05.02-09.04			0 232 103 019
Pressure sensor, ESP, (electronic stability program)	05.02-09.04			0 265 005 303
Wheel speed sensor, front	05.02-09.04	FMS		0 265 006 578
Wheel speed sensor, rear	05.02-09.04	ALR,LAB		0 265 006 575
		ALR,RAB		0 265 006 573
4.0 4 Motion [3B3]		4,0l	202 kW BDN; BDP 8 Zyl.	
Air mass meter, gasoline injection	09.01-09.04			0 280 218 073
				0 986 280 222
Phase sensor	09.01-09.04			0 232 103 019
Duo sensor, acceleration and yaw rate, brake system	09.01-09.04			0 265 005 252
Pressure sensor, ESP, (electronic stability program)	09.01-09.04			0 265 005 303
Wheel speed sensor, front	09.01-09.04	FMS		0 265 006 578
Wheel speed sensor, rear	09.01-09.04			0 265 006 573
Passat Variant				
1.6 [3B5]			1,6l	74 kW ADP 4 Zyl.
Temperature sensor, intake air, injection system	01.97-11.00			0 280 130 085
Duo sensor, acceleration and yaw rate, brake system	01.97-11.00	6PO		0 265 005 214
Yaw rate sensor, brake system	01.97-11.00	5PO		0 265 005 207
1.6 [3B5]			1,6l	74 kW AHL 4 Zyl.
Phase sensor	05.97-11.00			0 232 103 019
Speed sensor, ignition/injection	05.97-11.00	AG5,GS		0 261 210 147
Knock sensor	05.97-11.00	KZG		0 261 231 038
Temperature sensor, intake air, injection system	05.97-11.00			0 280 130 085
Duo sensor, acceleration and yaw rate, brake system	05.97-11.00	6PO		0 265 005 214
Yaw rate sensor, brake system	05.97-11.00	5PO		0 265 005 207
1.6 [3B5]			1,6l	74 kW ANA; ARM 4 Zyl.
Speed sensor, ignition/injection	01.99-11.00	AG5,GS		0 261 210 147
Knock sensor	01.99-11.00	KZG		0 261 231 038
Duo sensor, acceleration and yaw rate, brake system	01.99-11.00	6PO		0 265 005 214
Yaw rate sensor, brake system	01.99-11.00	5PO		0 265 005 207





Product		
1.6 [3B6]	1,6l 75 kW ALZ 4 Zyl.	
Phase sensor		
Fg.no. →3B..2..240 126	10.00-10.01	0 232 101 038
Speed sensor, ignition/injection	10.00-05.05	0 281 002 222
Duo sensor, acceleration and yaw rate, brake system		
Fg.no. →3B..1..400 000	10.00-04.01	0 265 005 214
Fg.no. 3B..1..400 001→	05.01-05.05	0 265 005 252
Pressure sensor, ESP, (electronic stability program)	10.00-05.05	0 265 005 303
Wheel speed sensor, front	10.00-05.05 FMS	0 265 006 578
Wheel speed sensor, rear	10.00-05.05 ALR,LAB	0 265 006 575
	ALR,RAB	0 265 006 573
1.6 [3C5]	1,6l 75 kW BSE;BSF 4 Zyl.	
Speed sensor, ignition/injection	08.05→	0 261 210 199
Knock sensor	08.05→	0 261 231 146
Pressure sensor, intake manifold, gasoline	08.05→	0 261 230 031
1.6 [31, 35, 3A..]	1,6l 55 kW 1F 4 Zyl.	
Temperature sensor, coolant, injection system	08.88-07.90	0 280 130 040
1.6 [31, 35, 3A..]	1,6l 74 kW AEK 4 Zyl.	
Air mass meter, gasoline injection	10.94-12.95	0 280 217 103
Knock sensor	10.94-12.95 KZB	0 261 231 036
1.6 [31, 35, 3A..]	1,6l 74 kW AFT 4 Zyl.	
Knock sensor	12.95-03.97 KZB	0 261 231 036
Temperature sensor, intake air, injection system	12.95-03.97	0 280 130 039
1.6 FSI [3C5]	1,6l 85 kW BLF 4 Zyl.	
Speed sensor, ignition/injection	08.05→ AG	0 261 210 250
Knock sensor	08.05→	0 261 231 146
Pressure sensor, intake manifold, gasoline	08.05→	0 261 230 095
1.8 [3B5]	1,8l 85 kW AFY 4 Zyl.	
Temperature sensor, intake air, injection system	05.97-11.00	0 280 130 085
Duo sensor, acceleration and yaw rate, brake system	05.97-11.00 6PO	0 265 005 214
Yaw rate sensor, brake system	05.97-11.00 5PO	0 265 005 207
1.8 [3B5]	1,8l 92 kW ADR 4 Zyl.	
Throttle valve assembly		
Fg.no. 3B..X..550 001→	05.99-11.00	0 280 750 080
Air mass meter, gasoline injection		
Fg.no. 3B..X..400 001→	01.99-11.00	0 280 218 013
		0 986 280 206
Phase sensor	05.97-11.00	0 232 101 024
Knock sensor	05.97-11.00 KZG	0 261 231 038
Temperature sensor, intake air, injection system	05.97-11.00	0 280 130 085
Duo sensor, acceleration and yaw rate, brake system	05.97-11.00 6PO	0 265 005 214
Yaw rate sensor, brake system	05.97-11.00 5PO	0 265 005 207
1.8 [3B5]	1,8l 92 kW APT;ARG 4 Zyl.	
Throttle valve assembly		
Fg.no. 3B..X..550 001→	05.99-11.00	0 280 750 080
Air mass meter, gasoline injection		
Fg.no. 3B..X..400 001→	01.99-11.00	0 280 218 013
		0 986 280 206
Knock sensor	01.99-11.00 KZG	0 261 231 038
Temperature sensor, intake air, injection system	01.99-11.00	0 280 130 085
Duo sensor, acceleration and yaw rate, brake system	01.99-11.00 6PO	0 265 005 214
Yaw rate sensor, brake system	01.99-11.00 5PO	0 265 005 207
1.8 [3B6]	1,8l 110 kW AWT 4 Zyl.	
Throttle valve assembly	10.00-05.05	0 280 750 009
Air mass meter, gasoline injection		
Fg.no. →3B..2..100 000	10.00-06.01	0 280 218 063
		0 986 280 217
Fg.no. 3B..2..100 001→	07.01-05.05	0 280 218 100
		0 986 280 223
Phase sensor	10.00-05.05	0 232 101 024



Speed sensor, ignition/injection	10.00-05.05	0 281 002 222
Boost pressure sensor, gasoline		
Fg.no. →3B..3..350 000	10.00-02.03	0 281 002 177
Fg.no. 3B..3..350 001→	03.03-05.05	0 261 230 073
Temperature sensor, intake air, injection system	10.00-05.05	0 280 130 085
Duo sensor, acceleration and yaw rate, brake system		
Fg.no. →3B..1..400 000	10.00-04.01	0 265 005 214
Fg.no. 3B..1..400 001→	05.01-05.05	0 265 005 252
Pressure sensor, ESP, (electronic stability program)	10.00-05.05	0 265 005 303
Wheel speed sensor, front	10.00-05.05 FMS	0 265 006 578
Wheel speed sensor, rear	10.00-05.05 ALR,LAB	0 265 006 575
	ALR,RAB	0 265 006 573
1.8 [31, 35, 3A..]	1,8l 55/66 kW AAM;ABS 4 Zyl.	
Temperature sensor, coolant, injection system	08.90-03.97	0 280 130 040
1.8 [31, 35, 3A..]	1,8l 66 kW RP 4 Zyl.	
Knock sensor	08.88-07.91 KZG	0 261 231 004
Temperature sensor, coolant, injection system	04.88-07.91	0 280 130 040
1.8 [31, 35, 3A..]	1,8l 79 kW PF 4 Zyl.	
Air flow sensor, gasoline injection	04.88-07.90	0 280 202 106
		0 986 280 008
Knock sensor	08.88-07.90 KZG	0 261 231 004
1.8 [31, 35, 3A..]	1,8l 82 kW PB 4 Zyl.	
Air flow sensor, gasoline injection	04.88-07.90	0 280 200 041
Knock sensor	08.88-07.90 KZG	0 261 231 038
1.8 [31, 35, 3A..]	1,8l 100 kW KR 4 Zyl.	
Air flow sensor, gasoline injection	04.88-07.92	F 026 TX2 050
		F 026 TX2 050
1.8 [32B]	1,8l 66 kW JN 4 Zyl.	
Air flow sensor, gasoline injection	08.84-03.88	F 026 TX2 063
		F 026 TX2 063
1.8 G60 syncro [312,315,3A5]	1,8l 118 kW PG 4 Zyl.	
Knock sensor	09.89-07.93	0 261 231 038
1.8 syncro [3B5]	1,8l 92 kW ADR 4 Zyl.	
Throttle valve assembly		
Fg.no. 3B..X..550 001→	05.99-11.00	0 280 750 080
Air mass meter, gasoline injection		
Fg.no. 3B..X..400 001→	02.99-11.00	0 280 218 013
		0 986 280 206
Phase sensor	08.97-11.00	0 232 101 024
Knock sensor	08.97-11.00 KZG	0 261 231 038
Temperature sensor, intake air, injection system	08.97-11.00	0 280 130 085
Duo sensor, acceleration and yaw rate, brake system	08.97-11.00 6PO	0 265 005 214
Yaw rate sensor, brake system	08.97-11.00 5PO	0 265 005 207
Wheel speed sensor, rear	08.97-11.00 ALR,LAB	0 265 006 575
		MFD
		ALR,MFD, 0 265 006 573
		RAB
		MFD,OLW 0 265 006 573
Fg.no. 3B..X..338 107→	11.98-11.00 ALR,LAB	0 265 006 575
		OFD
		ALR,OFD, 0 265 006 573
		RAB
		OFD,OLW 0 265 006 573
1.8 syncro [3B5]	1,8l 92 kW APT 4 Zyl.	
Throttle valve assembly		
Fg.no. 3B..X..550 001→	05.99-11.00	0 280 750 080
Air mass meter, gasoline injection		
Fg.no. 3B..X..400 001→	01.99-11.00	0 280 218 013
		0 986 280 206
Phase sensor	01.99-11.00	0 232 101 024
Knock sensor	01.99-11.00 KZG	0 261 231 038



◀ Passat Variant

Duo sensor, acceleration and yaw rate, brake system	01.99-11.00	6PO	0 265 005 214
Yaw rate sensor, brake system	01.99-11.00	5PO	0 265 005 207
Wheel speed sensor, rear	01.99-11.00	ALR,LAB, MFD	0 265 006 575
		ALR,LAB, OFD	0 265 006 575
		ALR,MFD, RAB	0 265 006 573
		ALR,OFD, RAB	0 265 006 573
		MFD,OLW	0 265 006 573
		OFD,OWR	0 265 006 573
1.8 syncro [3B5]		1,8l 92 kW ARG 4 Zyl.	
Throttle valve assembly			
Fg.no. 3B..X..550 001→	05.99-11.00		0 280 750 080
Air mass meter, gasoline injection	02.99-11.00		0 280 218 013
			0 986 280 206
Phase sensor	02.99-11.00		0 232 101 024
Knock sensor	02.99-11.00	KZG	0 261 231 038
Temperature sensor, intake air, injection system	02.99-11.00		0 280 130 085
Duo sensor, acceleration and yaw rate, brake system	02.99-11.00	6PO	0 265 005 214
Yaw rate sensor, brake system	02.99-11.00	5PO	0 265 005 207
Wheel speed sensor, rear	02.99-11.00	ALR,LAB, MFD	0 265 006 575
		ALR,LAB, OFD	0 265 006 575
		ALR,MFD, RAB	0 265 006 573
		ALR,OFD, RAB	0 265 006 573
		MFD,OLW	0 265 006 573
		OFD,OWR	0 265 006 573
1.8 syncro [32B]		1,8l 68 kW JN 4 Zyl.	
Air flow sensor, gasoline injection	01.86-03.88		F 026 TX2 063
			0 986 280 206
1.8 Turbo [3B5]		1,8l 110 kW AEB 4 Zyl.	
Air mass meter, gasoline injection			
Fg.no. WE175000/WP150000→	09.97-11.00		0 280 217 117
			0 986 280 201
Fg.no. →WE175000/WP150000	05.97-11.00		0 280 217 112
Phase sensor	05.97-11.00		0 232 101 024
Knock sensor	05.97-11.00	KZG	0 261 231 038
Pressure sensor, intake manifold, gasoline	05.97-11.00		0 280 101 001
Temperature sensor, intake air, injection system	05.97-11.00		0 280 130 085
Duo sensor, acceleration and yaw rate, brake system	05.97-11.00	6PO	0 265 005 214
Yaw rate sensor, brake system	05.97-11.00	5PO	0 265 005 207
1.8 Turbo [3B5]		1,8l 110 kW ANB; APU 4 Zyl.	
Throttle valve assembly	01.99-11.00		0 280 750 009
Air mass meter, gasoline injection	01.99-11.00		0 280 218 032
			0 986 280 210
Knock sensor	01.99-11.00	KZG	0 261 231 038
Duo sensor, acceleration and yaw rate, brake system	01.99-11.00	6PO	0 265 005 214
Yaw rate sensor, brake system	01.99-11.00	5PO	0 265 005 207
1.9 TDI [3B5]		1,9l 66 kW AHH 4 Zyl.	
Air mass meter, diesel	05.98-11.00		0 281 002 216
			0 986 284 001
Boost pressure sensor, Diesel	05.98-11.00		0 281 002 177




Pedal position sensor, diesel			
Fg.no. →3B..X..600 000	05.98-04.99	AG	0 281 002 289
		GS	0 281 002 286
Yaw rate sensor, brake system	05.98-11.00	5PO	0 265 005 207
1.9 TDI [3B5]		1,9l 66 kW AHU 4 Zyl.	
Air mass meter, diesel			
Fg.no. WE118001/WP100001→	09.97-11.00		0 281 002 216
			0 986 284 001
Boost pressure sensor, Diesel	05.97-11.00		0 281 002 177
Pedal position sensor, diesel			
Fg.no. →3B..W..140 000	05.97-08.97	AG	0 205 001 031
		GS	0 205 001 032
Fg.no. 3B..W..140 001→3B..W..222 092	08.97-10.97	AG	0 281 002 254
		GS	0 281 002 229
Fg.no. 3B..W..222 093→3B..X..600 000	10.97-04.99	AG	0 281 002 289
		GS	0 281 002 286
Yaw rate sensor, brake system	05.97-11.00	5PO	0 265 005 207
1.9 TDI [3B5]		1,9l 74 kW AVB 4 Zyl.	
Air mass meter, diesel	02.00-11.00		0 281 002 216
			0 986 284 001
Yaw rate sensor, brake system	02.00-11.00	5PO	0 265 005 207
1.9 TDI [3B5]		1,9l 81 kW AFN 4 Zyl.	
Air mass meter, diesel			
Fg.no. WE118001/WP100001→	09.97-11.00		0 281 002 216
			0 986 284 001
Boost pressure sensor, Diesel	05.97-11.00		0 281 002 177
Pedal position sensor, diesel			
Fg.no. →3B..W..140 000	05.97-08.97	AG	0 205 001 031
		GS	0 205 001 032
Fg.no. 3B..W..140 001→3B..W..222 092	08.97-10.97	AG	0 281 002 254
		GS	0 281 002 229
Fg.no. 3B..W..222 093→3B..X..600 000	10.97-04.99	AG	0 281 002 289
		GS	0 281 002 286
Yaw rate sensor, brake system	05.97-11.00	5PO	0 265 005 207
1.9 TDI [3B5]		1,9l 81 kW AVG 4 Zyl.	
Air mass meter, diesel	08.99-11.00		0 281 002 216
			0 986 284 001
Boost pressure sensor, Diesel	08.99-11.00		0 281 002 177
Yaw rate sensor, brake system	08.99-11.00	5PO	0 265 005 207
1.9 TDI [3B5]		1,9l 85 kW AJM 4 Zyl.	
Air mass meter, diesel	03.99-11.00		0 281 002 216
			0 986 284 001
Boost pressure sensor, Diesel	03.99-11.00		0 281 002 177
Pedal position sensor, diesel			
Fg.no. →3B..X..600 000	03.99-04.99	AG	0 281 002 289
		GS	0 281 002 286
Yaw rate sensor, brake system	03.99-11.00	5PO	0 265 005 207
1.9 TDI [3B5]		1,9l 85 kW ATJ 4 Zyl.	
Air mass meter, diesel	12.99-11.00		0 281 002 216
			0 986 284 001
Boost pressure sensor, Diesel	12.99-11.00		0 281 002 177
Yaw rate sensor, brake system	12.99-11.00	5PO	0 265 005 207
1.9 TDI [3B6]		1,9l 74 kW AVB 4 Zyl.	
Air mass meter, diesel			
Fg.no. →3B..2P241 613,→3B..2P240 805,→3B..2E262 022	10.00-10.01		0 281 002 216
			0 986 284 001
Fg.no. 3B..2P241 614→,3B..2P240 806→,3B..2E262 023→	11.01-05.05		0 281 002 463
			0 986 284 008
Boost pressure sensor, Diesel			
Fg.no. →3B..2..250 000	10.00-10.01		0 281 002 177
Fg.no. 3B..2..250 000→	11.01-05.05		0 281 002 399



Duo sensor, acceleration and yaw rate, brake system		
Fg.no. →3B..1..400 000	10.00-04.01	0 265 005 214
Fg.no. 3B..1..400 001→	05.01-05.05	0 265 005 252
Pressure sensor, ESP, (electronic stability program)	10.00-05.05	0 265 005 303
Wheel speed sensor, front	10.00-05.05 FMS	0 265 006 578
Wheel speed sensor, rear	10.00-05.05 ALR,LAB	0 265 006 575
	ALR,RAB	0 265 006 573
1.9 TDI [3B6] 1,9l 96 kW AVF; AWX 4 Zyl.		
Air mass meter, diesel		
Fg.no. →3B..1..400 000	10.00-04.01	0 280 217 529
		0 986 280 204
Fg.no. 3B..2..000 001→	05.01-05.05	0 281 002 461
		0 986 284 007
Boost pressure sensor, Diesel	10.00-05.05	0 281 002 401
Duo sensor, acceleration and yaw rate, brake system		
Fg.no. →3B..1..400 000	10.00-04.01	0 265 005 214
Fg.no. 3B..1..400 001→	05.01-05.05	0 265 005 252
Pressure sensor, ESP, (electronic stability program)	10.00-05.05	0 265 005 303
Wheel speed sensor, front	10.00-05.05 FMS	0 265 006 578
Wheel speed sensor, rear	10.00-05.05 ALR,LAB	0 265 006 575
	ALR,RAB	0 265 006 573
1.9 TDI [3C5] 1,9l 77 kW BKC; BLS; BXE 4 Zyl.		
Air mass meter, diesel		
	08.05→	0 281 002 531
		0 986 284 009
Boost pressure sensor, Diesel	08.05→	0 281 002 399
1.9 TDI [31, 35, 3A..] 1,9l 66 kW AHU 4 Zyl.		
Pedal position sensor, diesel	08.96-03.97 LLE	0 205 001 032
	RLE	0 205 001 024
1.9 TDI [31, 35, 3A..] 1,9l 66 kW 12 4 Zyl.		
Pressure sensor, intake manifold, diesel		
Fg.no. →3A..SE085 001,→3A..SB012 818,→3A..RE027 690	10.93-09.94	0 261 230 037
Pedal position sensor, diesel		
Fg.no. →3A..S..192 818	10.93-04.95 LLE	0 205 001 024
	RLE	0 205 001 023
Fg.no. 3A..S..192 819→	05.95-07.96 AG	0 205 001 031
	GS	0 205 001 032
1.9 TDI syncro [3B5] 1,9l 81 kW AFN 4 Zyl.		
Air mass meter, diesel		
Fg.no. WE 106 001→,WP 090 001→	08.97-11.00	0 281 002 216
		0 986 284 001
Boost pressure sensor, Diesel	06.97-11.00	0 281 002 177
Pedal position sensor, diesel		
Fg.no. →3B..W..140 000	06.97-08.97 AG	0 205 001 031
	GS	0 205 001 032
Fg.no. 3B..W..140 001→3B..W..222 092	09.97-10.97 GS	0 281 002 229
Fg.no. 3B..W..140 001→3B..X..600 000	09.97-04.99 AG	0 281 002 289
Fg.no. 3B..W..222 093→3B..X..600 000	11.97-04.99 GS	0 281 002 286
Duo sensor, acceleration and yaw rate, brake system	06.97-11.00 6PO	0 265 005 214
Yaw rate sensor, brake system		
	06.97-11.00 5PO	0 265 005 207
Wheel speed sensor, rear		
	06.97-11.00 ALR,LAB,	0 265 006 575
	MFD	
	ALR,MFD,	0 265 006 573
	RAB	
	MFD,OLW	0 265 006 573
Fg.no. 3B..X..338 107→	11.98-11.00 ALR,LAB,	0 265 006 575
	OFD	
	ALR,OFD,	0 265 006 573
	RAB	
	OFD,OLW	0 265 006 573



1.9 TDI syncro [3B5] 1,9l 81 kW AVG 4 Zyl.		
Air mass meter, diesel		
	08.99-08.00	0 281 002 216
		0 986 284 001
Boost pressure sensor, Diesel	08.99-08.00	0 281 002 177
Duo sensor, acceleration and yaw rate, brake system	08.99-08.00 6PO	0 265 005 214
Yaw rate sensor, brake system		
	08.99-08.00 5PO	0 265 005 207
Wheel speed sensor, rear		
	08.99-08.00 ALR,LAB,	0 265 006 575
	MFD	
	ALR,LAB,	0 265 006 575
	OFD	
	ALR,MFD,	0 265 006 573
	RAB	
	ALR,OFD,	0 265 006 573
	RAB	
	MFD,OLW	0 265 006 573
	OFD,OWR	0 265 006 573
1.9 TDI syncro [3B5] 1,9l 85 kW AJM 4 Zyl.		
Pedal position sensor, diesel		
Fg.no. →3B..X..600 000	01.99-04.99 AG	0 281 002 289
	GS	0 281 002 286
Duo sensor, acceleration and yaw rate, brake system	01.99-11.00 6PO	0 265 005 214
Yaw rate sensor, brake system		
	01.99-11.00 5PO	0 265 005 207
Wheel speed sensor, rear		
	01.99-11.00 ALR,LAB,	0 265 006 575
	MFD	
	ALR,LAB,	0 265 006 575
	OFD	
	ALR,MFD,	0 265 006 573
	RAB	
	ALR,OFD,	0 265 006 573
	RAB	
	MFD,OLW	0 265 006 573
	OFD,OWR	0 265 006 573
1.9 TDI syncro [3B5] 1,9l 85 kW ATJ 4 Zyl.		
Duo sensor, acceleration and yaw rate, brake system		
	01.00-11.00 6PO	0 265 005 214
Yaw rate sensor, brake system		
	01.00-11.00 5PO	0 265 005 207
Wheel speed sensor, rear		
	01.00-11.00 ALR,LAB,	0 265 006 575
	MFD	
	ALR,LAB,	0 265 006 575
	OFD	
	ALR,MFD,	0 265 006 573
	RAB	
	ALR,OFD,	0 265 006 573
	RAB	
	MFD,OLW	0 265 006 573
	OFD,OWR	0 265 006 573
1.9 TDI 4 Motion [3B6] 1,9l 96 kW AVF; AWX 4 Zyl.		
Air mass meter, diesel		
Fg.no. →3B..1..400 000	10.00-04.01	0 280 217 529
		0 986 280 204
Fg.no. 3B..2..000 001→	05.01-05.05	0 281 002 461
		0 986 284 007
Pressure sensor, intake manifold, diesel	10.00-05.05	0 281 002 401
Duo sensor, acceleration and yaw rate, brake system		
Fg.no. →3B..1..400 000	10.00-04.01	0 265 005 214
Fg.no. 3B..1..400 001→	05.01-05.05	0 265 005 252
Pressure sensor, ESP, (electronic stability program)	10.00-05.05	0 265 005 303
Wheel speed sensor, front	10.00-05.05 FMS	0 265 006 578
Wheel speed sensor, rear	10.00-05.05	0 265 006 573





Product

◀ Passat Variant

2.0 [3B6]		2,0l 85 kW AZM 4 Zyl.	
Phase sensor	10.00-05.05		0 232 101 031
Speed sensor, ignition/injection	10.00-05.05		0 261 210 147
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →3B..1..400 000	10.00-04.01		0 265 005 214
Fg.no. 3B..1..400 001→	05.01-05.05		0 265 005 252
Pressure sensor, ESP, (electronic stability program)	10.00-05.05		0 265 005 303
Wheel speed sensor, front	10.00-05.05	FMS	0 265 006 578
Wheel speed sensor, rear	10.00-05.05	ALR,LAB	0 265 006 575
		ALR,RAB	0 265 006 573
2.0 [3B6]		2,0l 95 kW ALT 4 Zyl.	
Throttle valve assembly	11.01-05.05		0 280 750 088
Air mass meter, gasoline injection	11.01-05.05		0 280 218 058
			0 986 280 215
Phase sensor	11.01-05.05		0 232 101 024
Speed sensor, ignition/injection	11.01-05.05		0 281 002 222
Pressure sensor, ESP, (electronic stability program)	11.01-05.05		0 265 005 303
Wheel speed sensor, front	11.01-05.05	FMS	0 265 006 578
Wheel speed sensor, rear	11.01-05.05	ALR,LAB	0 265 006 575
		ALR,RAB	0 265 006 573
2.0 [31, 35, 3A..]		2,0l 85 kW ADY 4 Zyl.	
Knock sensor	10.94-07.95	KZG	0 261 231 004
2.0 [31, 35, 3A..]		2,0l 85 kW AGG 4 Zyl.	
Knock sensor	07.95-03.97	KZG	0 261 231 038
2.0 [31, 35, 3A..]		2,0l 85 kW 2E 4 Zyl.	
Knock sensor	03.90-09.94	KZB	0 261 231 036
2.0 [31, 35, 3A..]		2,0l 100 kW 9A 4 Zyl.	
Throttle valve sensor	08.88-09.93	AG	0 280 120 433
		GS	0 280 120 426
Air flow sensor, gasoline injection			
Fg.no. →31-N-400 000	08.88-07.92		0 438 121 076
			0 986 439 376
Fg.no. 31-P-000 001→	07.92-09.93		0 986 439 389
			F 026 TX2 059
			0 986 439 389
Knock sensor	08.88-09.93	KZG	0 261 231 004
Temperature sensor, coolant, injection system	08.88-09.93		0 280 130 040
2.0 [31, 35, 3A..]		2,0l 110 kW ABF 4 Zyl.	
Knock sensor	01.94-03.97	KZG	0 261 231 004
2.0 [32B]		2,0l 85 kW HP; JS 5 Zyl.	
Air flow sensor, gasoline injection	08.83-01.86	MZF	0 438 121 005
2.0 FSI [3C5]		2,0l 110 kW BLR; BLY; BVY; BVZ 4 Zyl.	
Knock sensor	08.05→	OHL	0 261 231 146
Pressure sensor, intake manifold, gasoline	08.05→		0 261 230 031
2.0 FSI 4 Motion [3C5]		2,0l 110 kW BLX; BLY; BVX 4 Zyl.	
Knock sensor	09.05→	OHL	0 261 231 146
Pressure sensor, intake manifold, gasoline	09.05→		0 261 230 031
2.0 syncro [32B]		2,0l 85 kW HP 5 Zyl.	
Air flow sensor, gasoline injection	02.86-03.88		0 438 120 211
2.0 syncro [312,315,3A5]		2,0l 85 kW 2E 4 Zyl.	
Air flow sensor, gasoline injection	10.90-09.94		0 280 202 106
			0 986 280 008
Knock sensor	10.90-09.94	KZB	0 261 231 036
2.0 TDI [3B6]		2,0l 100 kW BGW 4 Zyl.	
Air mass meter, diesel	11.03-05.05		0 281 002 461
			0 986 284 007
Boost pressure sensor, Diesel	11.03-05.05		0 281 002 401
Pressure sensor, ESP, (electronic stability program)	11.03-05.05		0 265 005 303
Wheel speed sensor, front	11.03-05.05	FMS	0 265 006 578
Wheel speed sensor, rear	11.03-05.05	ALR,LAB	0 265 006 575
		ALR,RAB	0 265 006 573

Product


2.0 TDI [3C5]		2,0l 88/100/103/120 kW BKP; BMA; BMP; BUZ; BWV 4 Zyl.	
Air mass meter, diesel	08.05→		0 281 002 461
			0 986 284 007
Boost pressure sensor, Diesel	08.05→		0 281 002 401
2.0 TDI [3C5]		2,0l 90/125 kW BMR; BVD; BVE 4 Zyl.	
Air mass meter, diesel	08.05→		0 281 002 461
			0 986 284 007
Boost pressure sensor, Diesel	08.05→		0 281 002 401
2.0 TDI 4 Motion [3C5]		2,0l 103 kW BKP; BMP 4 Zyl.	
Air mass meter, diesel	08.05→		0 281 002 461
			0 986 284 007
Boost pressure sensor, Diesel	08.05→		0 281 002 401
2.0 TFSI [3C5]		2,0l 147 kW AXX; BWA 4 Zyl.	
Speed sensor, ignition/injection	08.05→		0 261 210 199
Boost pressure sensor, gasoline	08.05→		0 261 230 073
2.0 4 Motion [3B6]		2,0l 85 kW AZM 4 Zyl.	
Phase sensor	10.00-05.05		0 232 101 031
Speed sensor, ignition/injection	10.00-05.05		0 261 210 147
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →3B..1..400 000	10.00-04.01		0 265 005 214
Fg.no. 3B..1..400 001→	05.01-05.05		0 265 005 252
Pressure sensor, ESP, (electronic stability program)	10.00-05.05		0 265 005 303
Wheel speed sensor, front	10.00-05.05	FMS	0 265 006 578
Wheel speed sensor, rear	10.00-05.05		0 265 006 573
2.2 [32B]		2,2l 85 kW KX 5 Zyl.	
Air flow sensor, gasoline injection	08.85-03.88		F 026 TX2 064
			F 026 TX2 064
Pressure sensor, intake manifold, gasoline	08.85-03.88		0 280 101 001
Temperature sensor, coolant, injection system	08.85-03.88		0 280 130 037
2.2 [32B]		2,2l 100 kW HY 5 Zyl.	
Air flow sensor, gasoline injection	02.86-03.88		0 438 120 211
	01.85-01.86	MZF	0 438 121 005
2.2 [32B]		2,2l 100 kW KV 5 Zyl.	
Air flow sensor, gasoline injection	01.85-01.86	MZF	0 438 121 005
2.2 syncro [32B]		2,2l 85 kW KX 5 Zyl.	
Air flow sensor, gasoline injection	08.85-03.88		F 026 TX2 064
			F 026 TX2 064
Pressure sensor, intake manifold, gasoline	08.85-03.88		0 280 101 001
Temperature sensor, coolant, injection system	08.85-03.88		0 280 130 037
2.2 syncro [32B]		2,2l 88 kW JT 5 Zyl.	
Air flow sensor, gasoline injection	08.85-03.88		F 026 TX2 064
			F 026 TX2 064
Temperature sensor, coolant, injection system	08.85-03.88		0 280 130 037
2.2 syncro [32B]		2,2l 100 kW HY 5 Zyl.	
Air flow sensor, gasoline injection	02.86-03.88		0 438 120 211
2.3 [3B5]		2,3l 110 kW AGZ 5 Zyl.	
Air mass meter, gasoline injection	09.97-11.00		0 280 217 529
			0 986 280 204
Phase sensor	09.97-11.00		0 232 103 019
Speed sensor, ignition/injection	09.97-11.00	AG5,GS	0 261 210 139
Temperature sensor, intake air, injection system			
Fg.no. →3B..X..030 000	09.97-05.98		0 280 130 039
Fg.no. 3B..X..030 001→	05.98-11.00		0 280 130 085
Duo sensor, acceleration and yaw rate, brake system	09.97-11.00	6PO	0 265 005 214
Yaw rate sensor, brake system	09.97-11.00	5PO	0 265 005 207
2.3 [3B6]		2,3l 125 kW AXZ 5 Zyl.	
Throttle valve assembly	10.00-05.05		0 280 750 097
Air mass meter, gasoline injection	10.00-05.05		0 280 218 017
			0 986 280 208
Phase sensor	10.00-05.05		0 232 103 019
Speed sensor, ignition/injection	10.00-05.05		0 261 210 177



Duo sensor, acceleration and yaw rate, brake system		
Fg.no. →3B..1..400 000	10.00-04.01	0 265 005 214
Fg.no. 3B..1..400 001→	05.01-05.05	0 265 005 252
Pressure sensor, ESP, (electronic stability program)	10.00-05.05	0 265 005 303
Wheel speed sensor, front	10.00-05.05 FMS	0 265 006 578
Wheel speed sensor, rear	10.00-05.05 ALR,LAB	0 265 006 575
	ALR,RAB	0 265 006 573
2.3 syncro [3B5]	2,3l 110 kW AGZ 5 Zyl.	
Air mass meter, gasoline injection	09.97-11.00	0 280 217 529
		0 986 280 204
Phase sensor	09.97-11.00	0 232 103 019
Speed sensor, ignition/injection	09.97-11.00	0 261 210 139
Temperature sensor, intake air, injection system		
Fg.no. →3B..X..132 000	09.97-08.98	0 280 130 039
Fg.no. 3B..X..132 001→	09.98-11.00	0 280 130 085
Duo sensor, acceleration and yaw rate, brake system	09.97-11.00 6PO	0 265 005 214
Yaw rate sensor, brake system	09.97-11.00 5PO	0 265 005 207
Wheel speed sensor, rear	09.97-11.00 ALR,LAB,	0 265 006 575
	MFD	
	ALR,MFD,	0 265 006 573
	RAB	
	MFD,OLW	0 265 006 573
Fg.no. 3B..X..338 107→	11.98-11.00 ALR,LAB,	0 265 006 575
	OFD	
	ALR,OFD,	0 265 006 573
	RAB	
	OFD,OLW	0 265 006 573
2.3 4 Motion [3B6]	2,3l 125 kW AZX 5 Zyl.	
Throttle valve assembly	01.01-05.05	0 280 750 097
Air mass meter, gasoline injection	01.01-05.05	0 280 218 017
		0 986 280 208
Phase sensor	01.01-05.05	0 232 103 019
Speed sensor, ignition/injection	01.01-05.05	0 261 210 177
Duo sensor, acceleration and yaw rate, brake system		
Fg.no. →3B..1..400 000	01.01-04.01	0 265 005 214
Fg.no. 3B..1..400 001→	05.01-05.05	0 265 005 252
Pressure sensor, ESP, (electronic stability program)	01.01-05.05	0 265 005 303
Wheel speed sensor, front	01.01-05.05 FMS	0 265 006 578
Wheel speed sensor, rear	01.01-05.05	0 265 006 573
2.5 TDI [3B5]	2,5l 110 kW AFB; AKN 6 Zyl.	
Air mass meter, diesel	08.98-11.00	0 281 002 224
Speed sensor, diesel	08.98-11.00	0 281 002 222
Boost pressure sensor, Diesel	08.98-11.00	0 281 002 177
Yaw rate sensor, brake system	08.98-11.00 5PO	0 265 005 207
2.5 TDI [3B6]	2,5l 110 kW AKN 6 Zyl.	
Speed sensor, diesel	10.00-05.03	0 281 002 222
Boost pressure sensor, Diesel	10.00-05.03	0 281 002 177
Duo sensor, acceleration and yaw rate, brake system		
Fg.no. →3B..1..400 000	10.00-04.01	0 265 005 214
Fg.no. 3B..1..400 001→	05.01-05.03	0 265 005 252
Pressure sensor, ESP, (electronic stability program)	10.00-05.03	0 265 005 303
Wheel speed sensor, front	10.00-05.03 FMS	0 265 006 578
Wheel speed sensor, rear	10.00-05.03 ALR,LAB	0 265 006 575
	ALR,RAB	0 265 006 573
2.5 TDI [3B6]	2,5l 120 kW BDG 6 Zyl.	
Speed sensor, diesel	05.03-05.05	0 281 002 222
Boost pressure sensor, Diesel	05.03-05.05	0 281 002 399
Pressure sensor, ESP, (electronic stability program)	05.03-05.05	0 265 005 303



Wheel speed sensor, front	05.03-05.05 FMS	0 265 006 578
Wheel speed sensor, rear	05.03-05.05 ALR,LAB	0 265 006 575
	ALR,RAB	0 265 006 573
2.5 TDI syncro [3B5]	2,5l 110 kW AFB 6 Zyl.	
Air mass meter, diesel	02.99-11.00	0 281 002 224
Speed sensor, diesel	02.99-04.99	0 261 210 178
	05.99-11.00	0 281 002 222
Pedal position sensor, diesel		
Fg.no. →3B..X..600 000	02.99-04.99 AG	0 281 002 289
Duo sensor, acceleration and yaw rate, brake system	02.99-11.00 6PO	0 265 005 214
Yaw rate sensor, brake system	02.99-11.00 5PO	0 265 005 207
Wheel speed sensor, rear	02.99-11.00 ALR,LAB,	0 265 006 575
	MFD	
	ALR,MFD,	0 265 006 573
	RAB	
	MFD,OLW	0 265 006 573
Fg.no. 3B..X..338 107→	02.99-11.00 ALR,LAB,	0 265 006 575
	OFD	
	ALR,OFD,	0 265 006 573
	RAB	
	OFD,OLW	0 265 006 573
2.5 TDI syncro [3B5]	2,5l 110 kW AKN 6 Zyl.	
Air mass meter, diesel		
Fg.no. →3B..Y..200 000	05.99-11.99	0 281 002 224
Fg.no. 3B..Y..200 001→	12.99-11.00	0 281 002 403
		0 986 284 004
Speed sensor, diesel	05.99-11.00	0 281 002 222
Duo sensor, acceleration and yaw rate, brake system	05.99-11.00 6PO	0 265 005 214
Yaw rate sensor, brake system	05.99-11.00 5PO	0 265 005 207
Wheel speed sensor, rear	05.99-11.00 ALR,LAB,	0 265 006 575
	MFD	
	ALR,LAB,	0 265 006 575
	OFD	
	ALR,MFD,	0 265 006 573
	RAB	
	ALR,OFD,	0 265 006 573
	RAB	
	MFD,OLW	0 265 006 573
	OFD,OWR	0 265 006 573
2.5 TDI 4 Motion [3B6]	2,5l 110 kW AKN 6 Zyl.	
Speed sensor, diesel	10.00-01.03	0 281 002 222
Boost pressure sensor, Diesel	10.00-01.03	0 281 002 177
Duo sensor, acceleration and yaw rate, brake system		
Fg.no. →3B..1..400 000	10.00-04.01	0 265 005 214
Fg.no. 3B..1..400 001→	05.01-01.03	0 265 005 252
Pressure sensor, ESP, (electronic stability program)	10.00-01.03	0 265 005 303
Wheel speed sensor, front	10.00-01.03 FMS	0 265 006 578
Wheel speed sensor, rear	10.00-01.03	0 265 006 573
2.5 TDI 4 Motion [3B6]	2,5l 132 kW BAU; BDH 6 Zyl.	
Speed sensor, diesel	01.03-05.05	0 281 002 222
Boost pressure sensor, Diesel	01.03-05.05	0 281 002 399
Pressure sensor, ESP, (electronic stability program)	01.03-05.05	0 265 005 303
Wheel speed sensor, front	01.03-05.05 FMS	0 265 006 578
Wheel speed sensor, rear	01.03-05.05	0 265 006 573
2.8 [3B5]	2,8l 140 kW ATX 6 Zyl.	
Duo sensor, acceleration and yaw rate, brake system	10.99-11.00 6PO	0 265 005 214
Yaw rate sensor, brake system	10.99-11.00 5PO	0 265 005 207





Product

◀ Passat Variant

2.8 [3B5]		2,8l 142 kW ACK 6 Zyl.	
Phase sensor	06.97-11.00		0 232 101 024
Speed sensor, ignition/injection			
Fg.no. →3B..W..055 000	06.97-06.97	AG5,GS	0 261 210 134
Fg.no. 3B..W..055 001→	06.97-11.00	AG	0 261 210 147
		AG5,GS	0 261 210 178
Knock sensor	06.97-11.00	KZB	0 261 231 036
Temperature sensor, intake air, injection system	06.97-11.00		0 280 130 085
Duo sensor, acceleration and yaw rate, brake system	06.97-11.00	6PO	0 265 005 214
Yaw rate sensor, brake system	06.97-11.00	5PO	0 265 005 207
2.8 [3B5]		2,8l 142 kW APR 6 Zyl.	
Phase sensor	01.99-11.00		0 232 101 024
Speed sensor, ignition/injection	01.99-11.00	AG5	0 261 210 147
		GS	0 261 210 178
Knock sensor	01.99-11.00	KZB	0 261 231 036
Temperature sensor, intake air, injection system	01.99-11.00		0 280 130 085
Duo sensor, acceleration and yaw rate, brake system	01.99-11.00	6PO	0 265 005 214
Yaw rate sensor, brake system	01.99-11.00	5PO	0 265 005 207
2.8 [3B5]		2,8l 142 kW AQD 6 Zyl.	
Throttle valve assembly	05.99-11.00		0 280 750 030
Temperature sensor, intake air, injection system	05.99-11.00		0 280 130 085
Duo sensor, acceleration and yaw rate, brake system	05.99-11.00	6PO	0 265 005 214
Yaw rate sensor, brake system	05.99-11.00	5PO	0 265 005 207
2.8 [3B6]		2,8l 140/142 kW AMX; BBG 6 Zyl.	
Throttle valve assembly	10.00-05.05		0 280 750 030
Phase sensor	10.00-05.05		0 232 101 024
Speed sensor, ignition/injection	10.00-05.05	AG	0 261 210 147
		GS	0 261 210 178
Temperature sensor, intake air, injection system	10.00-05.05		0 280 130 085
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →3B..1..400 000	10.00-04.01		0 265 005 214
Fg.no. 3B..1..400 001→	05.01-05.05		0 265 005 252
Pressure sensor, ESP, (electronic stability program)	10.00-05.05		0 265 005 303
Wheel speed sensor, front	10.00-05.05	FMS	0 265 006 578
Wheel speed sensor, rear	10.00-05.05	ALR,LAB	0 265 006 575
		ALR,RAB	0 265 006 573
2.8 [3B6]		2,8l 142 kW ATQ 6 Zyl.	
Throttle valve assembly	10.00-05.05		0 280 750 030
Phase sensor	10.00-05.05		0 232 101 024
Temperature sensor, intake air, injection system	10.00-05.05		0 280 130 085
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →3B..1..400 000	10.00-04.01		0 265 005 214
Fg.no. 3B..1..400 001→	05.01-05.05		0 265 005 252
Pressure sensor, ESP, (electronic stability program)	10.00-05.05		0 265 005 303
Wheel speed sensor, front	10.00-05.05	FMS	0 265 006 578
Wheel speed sensor, rear	10.00-05.05	ALR,LAB	0 265 006 575
		ALR,RAB	0 265 006 573
2.8 [31, 35, 3A..]		2,8l 128 kW AAA 6 Zyl.	
Air mass meter, gasoline injection			
	06.91-07.93		0 280 213 021
	08.93-03.97		0 986 280 122
			0 280 217 504
Speed sensor, ignition/injection			
Fg.no. →3A-S-300 000	06.91-07.95		0 261 210 080
Fg.no. 3A-T-000 001→	07.95-03.97		0 261 210 107
Knock sensor	06.91-03.97	KZG	0 261 231 004
		KZS	0 261 231 064
		KZW	0 261 231 047
Temperature sensor, intake air, injection system	06.91-03.97		0 280 130 039

Product

2.8 syncro [3B5]		2,8l 142 kW ACK 6 Zyl.	
Phase sensor	01.97-11.00		0 232 101 024
Speed sensor, ignition/injection			
Fg.no. →3B..W..055 000	01.97-06.98		0 261 210 134
Fg.no. 3B..W..055 001→	07.98-11.00	AG	0 261 210 147
		GS	0 261 210 178
Knock sensor	01.97-11.00	KZB	0 261 231 036
Temperature sensor, intake air, injection system	01.97-11.00		0 280 130 085
Duo sensor, acceleration and yaw rate, brake system	01.97-11.00	6PO	0 265 005 214
Yaw rate sensor, brake system	01.97-11.00	5PO	0 265 005 207
Wheel speed sensor, rear			
	01.97-11.00	ALR,LAB,	0 265 006 575
		MFD	
		ALR,MFD,	0 265 006 573
		RAB	
		MFD,OLW	0 265 006 573
Fg.no. 3B..X..338 107→	11.98-11.00	ALR,LAB,	0 265 006 575
		OFD	
		ALR,OFD,	0 265 006 573
		RAB	
		OFD,OLW	0 265 006 573
2.8 syncro [3B5]		2,8l 142 kW AHA 6 Zyl.	
Duo sensor, acceleration and yaw rate, brake system	10.94-12.95	6PO	0 265 005 214
Yaw rate sensor, brake system	10.94-12.95	5PO	0 265 005 207
2.8 syncro [3B5]		2,8l 142 kW ALG 6 Zyl.	
Phase sensor	06.97-11.00		0 232 101 024
Speed sensor, ignition/injection	06.97-11.00	AG	0 261 210 147
		GS	0 261 210 178
Knock sensor	06.97-11.00	KZB	0 261 231 036
Temperature sensor, intake air, injection system	06.97-11.00		0 280 130 085
Duo sensor, acceleration and yaw rate, brake system	06.97-11.00	6PO	0 265 005 214
Yaw rate sensor, brake system	06.97-11.00	5PO	0 265 005 207
Wheel speed sensor, rear			
	06.97-11.00	ALR,LAB,	0 265 006 575
		MFD	
		ALR,MFD,	0 265 006 573
		RAB	
		MFD,OLW	0 265 006 573
Fg.no. 3B..X..338 107→	11.98-11.00	ALR,LAB,	0 265 006 575
		OFD	
		ALR,OFD,	0 265 006 573
		RAB	
		OFD,OLW	0 265 006 573
2.8 syncro [3B5]		2,8l 142 kW APR 6 Zyl.	
Throttle valve assembly	01.99-11.00		0 280 750 030
Phase sensor	01.99-11.00		0 232 101 024
Speed sensor, ignition/injection	01.99-11.00	AG	0 261 210 147
Knock sensor			
Fg.no. →3B..X..600 000	01.99-04.99	KZB	0 261 231 036
Temperature sensor, intake air, injection system	01.99-11.00		0 280 130 085
Duo sensor, acceleration and yaw rate, brake system	01.99-11.00	6PO	0 265 005 214
system			
Yaw rate sensor, brake system	01.99-11.00	5PO	0 265 005 207
Wheel speed sensor, rear			
	01.99-11.00	ALR,LAB,	0 265 006 575
		MFD	
		ALR,LAB,	0 265 006 575
		OFD	
		ALR,MFD,	0 265 006 573
		RAB	
		ALR,OFD,	0 265 006 573
		RAB	
		MFD,OLW	0 265 006 573
		OFD,OWR	0 265 006 573

Product



2.8 syncro [3B5]			2,8l 142 kW AQD 6 Zyl.
Throttle valve assembly	01.99-11.00		0 280 750 030
Phase sensor	01.99-11.00		0 232 101 024
Speed sensor, ignition/injection	01.99-11.00	AG	0 261 210 147
		GS	0 261 210 178
Knock sensor			
Fg.no. →3B..X..600 000	01.99-04.99	KZB	0 261 231 036
Temperature sensor, intake air, injection system	01.99-11.00		0 280 130 085
Duo sensor, acceleration and yaw rate, brake system	01.99-11.00	6PO	0 265 005 214
Yaw rate sensor, brake system	01.99-11.00	5PO	0 265 005 207
Wheel speed sensor, rear	01.99-11.00	ALR,LAB,	0 265 006 575
		MFD	
		ALR,LAB,	0 265 006 575
		OFD	
		ALR,MFD,	0 265 006 573
		RAB	
		ALR,OFD,	0 265 006 573
		RAB	
		MFD,OLW	0 265 006 573
		OFD,OWR	0 265 006 573
2.8 syncro [3B5]			2,8l 142 kW ATX 6 Zyl.
Throttle valve assembly	10.99-11.00		0 280 750 030
Temperature sensor, intake air, injection system	10.99-11.00		0 280 130 085
Duo sensor, acceleration and yaw rate, brake system	10.99-11.00	6PO	0 265 005 214
Yaw rate sensor, brake system	10.99-11.00	5PO	0 265 005 207
Wheel speed sensor, rear	10.99-11.00	ALR,LAB,	0 265 006 575
		MFD	
		ALR,LAB,	0 265 006 575
		OFD	
		ALR,MFD,	0 265 006 573
		RAB	
		ALR,OFD,	0 265 006 573
		RAB	
		MFD,OLW	0 265 006 573
		OFD,OWR	0 265 006 573
2.8 4 Motion [3B6]			2,8l 140/142 kW AMX; BBG 6 Zyl.
Throttle valve assembly	10.00-05.05		0 280 750 030
Phase sensor	10.00-05.05		0 232 101 024
Speed sensor, ignition/injection	10.00-05.05	AG	0 261 210 147
		GS	0 261 210 178
Temperature sensor, intake air, injection system	10.00-05.05		0 280 130 085
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →3B..1..400 000	10.00-04.01		0 265 005 214
Fg.no. 3B..1..400 001→	05.01-05.05		0 265 005 252
Pressure sensor, ESP, (electronic stability program)	10.00-05.05		0 265 005 303
Wheel speed sensor, front	10.00-05.05	FMS	0 265 006 578
Wheel speed sensor, rear	10.00-05.05		0 265 006 573
2.8 4 Motion [3B6]			2,8l 142 kW ATQ 6 Zyl.
Throttle valve assembly	10.00-05.05		0 280 750 030
Phase sensor	10.00-05.05		0 232 101 024
Temperature sensor, intake air, injection system	10.00-05.05		0 280 130 085
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →3B..1..400 000	10.00-04.01		0 265 005 214
Fg.no. 3B..1..400 001→	05.01-05.05		0 265 005 252
Pressure sensor, ESP, (electronic stability program)	10.00-05.05		0 265 005 303
Wheel speed sensor, front	10.00-05.05	FMS	0 265 006 578
Wheel speed sensor, rear	10.00-05.05		0 265 006 573


Product



2.9 syncro [312,315,3A5]		2,9l 135 kW ABV 6 Zyl.	
Air mass meter, gasoline injection	01.94-03.97	0 280 217 504	
Speed sensor, ignition/injection			
Fg.no. →3A-S-300 000	01.94-07.95	0 261 210 080	
Fg.no. 3A-T-000 001→	07.95-03.97	0 261 210 107	
Knock sensor	01.94-03.97	KZS	0 261 231 064
		KZW	0 261 231 047
Temperature sensor, intake air, injection system	01.94-03.97	0 280 130 039	
3.2 FSI 4 Motion [3C5]		3,2l 184 kW AXZ 6 Zyl.	
Air mass meter, gasoline injection	11.05→	0 280 218 175	
Knock sensor	11.05→	OHL	0 261 231 146
3.6 FSI, FSI 4 Motion [3C5]		3,6l 206 kW BLV 6 Zyl.	
Air mass meter, gasoline injection	09.05→	0 280 218 175	
Knock sensor	09.05→	TW	0 261 231 146
4.0 [3B6]		4,0l 202 kW BDN; BDP 8 Zyl.	
Air mass meter, gasoline injection	05.02-09.04	0 280 218 073	
		🚗 0 986 280 222	
Phase sensor	05.02-09.04	0 232 103 019	
Pressure sensor, ESP, (electronic stability program)	05.02-09.04	0 265 005 303	
Wheel speed sensor, front	05.02-09.04	FMS	0 265 006 578
Wheel speed sensor, rear	05.02-09.04	ALR,LAB	0 265 006 575
		ALR,RAB	0 265 006 573
4.0 4 Motion [3B6]		4,0l 202 kW BDN; BDP 8 Zyl.	
Air mass meter, gasoline injection	09.01-09.04	0 280 218 073	
		🚗 0 986 280 222	
Phase sensor	09.01-09.04	0 232 103 019	
Duo sensor, acceleration and yaw rate, brake system	09.01-09.04	0 265 005 252	
Pressure sensor, ESP, (electronic stability program)	09.01-09.04	0 265 005 303	
Wheel speed sensor, front	09.01-09.04	FMS	0 265 006 578
Wheel speed sensor, rear	09.01-09.04	0 265 006 573	

Phaeton

3.0 TDI 4 Motion [3D]		3,0l 165 kW BMK 6 Zyl.	
Speed sensor, diesel	09.04-05.07		0 261 210 145
Boost pressure sensor, Diesel	09.04-05.07		0 281 002 401
Duo sensor, acceleration and yaw rate, brake system	09.04-05.07		0 265 005 252
Pressure sensor, ESP, (electronic stability program)	09.04-05.07		0 265 005 303
Wheel speed sensor, front	09.04-05.07	LAB	0 265 007 728
Fg.no. →3D..5..003 200	09.04-11.04	RAB	0 265 007 406
Fg.no. 3D..5..003 201→	12.04-05.07	RAB	0 265 007 726
Wheel speed sensor, rear	09.04-05.07	RAB	0 265 007 728
Fg.no. →3D..5..003 200	09.04-11.04	LAB	0 265 007 406
Fg.no. 3D..5..003 201→	12.04-05.07	LAB	0 265 007 726
3.0 TDI 4 Motion [3D]		3,0l 171 kW CARA 6 Zyl.	
Speed sensor, diesel	06.07→		0 261 210 145
Boost pressure sensor, Diesel	06.07→		0 281 002 401
Duo sensor, acceleration and yaw rate, brake system	06.07→		0 265 005 252
Wheel speed sensor, front	06.07→	LAB	0 265 007 930
		RAB	0 265 007 928
Wheel speed sensor, rear	06.07→	LAB	0 265 007 928
		RAB	0 265 007 930
3.2 [3D]		3,2l 177 kW AYT; BKL 6 Zyl.	
Air mass meter, gasoline injection	05.02-05.05		0 280 218 073
			0 986 280 222
Phase sensor	05.02-05.05		0 232 103 019
Knock sensor	05.02-05.05	OHL	0 261 231 146
Duo sensor, acceleration and yaw rate, brake system	05.02-05.05		0 265 005 252
Pressure sensor, ESP, (electronic stability program)	05.02-05.05		0 265 005 303



Product				
◀ Phaeton				
Wheel speed sensor, front	05.02-05.05	LAB	0 265 007 728	
Fg.no. →3D..5..003 200	05.02-11.04	RAB	0 265 007 406	
Fg.no. 3D..5..003 201→	12.04-05.05	RAB	0 265 007 726	
Wheel speed sensor, rear	05.02-05.05	RAB	0 265 007 728	
Fg.no. →3D..5..003 200	05.02-11.04	LAB	0 265 007 406	
Fg.no. 3D..5..003 201→	12.04-05.05	LAB	0 265 007 726	
3.2 4 Motion [3D]	3,2 l	177 kW BKL; BRK	6 Zyl.	
Air mass meter, gasoline injection	02.04→		0 280 218 073	
			0 986 280 222	
Phase sensor	02.04→		0 232 103 019	
Knock sensor	02.04→	OHL	0 261 231 146	
Duo sensor, acceleration and yaw rate, brake system	02.04→		0 265 005 252	
Pressure sensor, ESP, (electronic stability program)	02.04→		0 265 005 303	
Wheel speed sensor, front	02.04→	LAB	0 265 007 728	
Fg.no. →3D..5..003 200	02.04-11.04	RAB	0 265 007 406	
Fg.no. 3D..5..003 201→	12.04→	RAB	0 265 007 726	
Wheel speed sensor, rear	02.04→	RAB	0 265 007 728	
Fg.no. →3D..5..003 200	02.04-11.04	LAB	0 265 007 406	
Fg.no. 3D..5..003 201→	12.04→	LAB	0 265 007 726	
4.2 4 Motion [3D]	4,2 l	246 kW BGH; BGJ	8 Zyl.	
Throttle valve assembly	05.03→		0 280 750 047	
Air mass meter, gasoline injection	05.03→		0 280 218 060	
			0 986 280 216	
Phase sensor	05.03→		0 232 101 024	
Speed sensor, ignition/injection	05.03→		0 261 210 264	
Duo sensor, acceleration and yaw rate, brake system	05.03→		0 265 005 252	
Pressure sensor, ESP, (electronic stability program)	05.03→		0 265 005 303	
Wheel speed sensor, front	05.03→	LAB	0 265 007 728	
Fg.no. →3D..5..003 200	05.03-11.04	RAB	0 265 007 406	
Fg.no. 3D..5..003 201→	12.04→	RAB	0 265 007 726	
Wheel speed sensor, rear	05.03→	RAB	0 265 007 728	
Fg.no. →3D..5..003 200	05.03-11.04	LAB	0 265 007 406	
Fg.no. 3D..5..003 201→	12.04→	LAB	0 265 007 726	
5.0 TDI 4 Motion [3D]	5,0 l	230 kW AJS	10 Zyl.	
Air mass meter, diesel	11.02-10.06		0 281 002 461	
			0 986 284 007	
Boost pressure sensor, Diesel	11.02-10.06		0 281 002 401	
Duo sensor, acceleration and yaw rate, brake system	11.02-10.06		0 265 005 252	
Pressure sensor, ESP, (electronic stability program)	11.02-10.06		0 265 005 303	
Wheel speed sensor, front	11.02-10.06	LAB	0 265 007 728	
Fg.no. →3D..5..003 200	11.02-11.04	RAB	0 265 007 406	
Fg.no. 3D..5..003 201→	12.04-10.06	RAB	0 265 007 726	
Wheel speed sensor, rear	11.02-10.06	RAB	0 265 007 728	
Fg.no. →3D..5..003 200	11.02-11.04	LAB	0 265 007 406	
Fg.no. 3D..5..003 201→	12.04-10.06	LAB	0 265 007 726	
6.0 4 Motion [3D]	6,0 l	309 kW BAN	12 Zyl.	
Throttle valve assembly	05.02-05.05		0 280 750 107	
Air mass meter, gasoline injection	05.02-05.05		0 280 218 071	
			0 986 280 221	
Phase sensor	05.02-05.05		0 232 103 019	
Duo sensor, acceleration and yaw rate, brake system	05.02-05.05		0 265 005 252	
Pressure sensor, ESP, (electronic stability program)	05.02-05.05		0 265 005 303	
Wheel speed sensor, front	05.02-05.05	LAB	0 265 007 728	
Fg.no. →3D..5..003 200	05.02-11.04	RAB	0 265 007 406	
Fg.no. 3D..5..003 201→	12.04-05.05	RAB	0 265 007 726	
Wheel speed sensor, rear	05.02-05.05	RAB	0 265 007 728	
Fg.no. →3D..5..003 200	05.02-11.04	LAB	0 265 007 406	
Fg.no. 3D..5..003 201→	12.04-05.05	LAB	0 265 007 726	

Product				
6.0 4 Motion [3D]		6,0l 309 kW BAP 12 Zyl.		
Throttle valve assembly	07.03-05.05	0 280 750 107		
Air mass meter, gasoline injection	07.03-05.05	0 280 218 071		
		🔊 0 986 280 221		
6.0 4 Motion [3D]		6,0l 331 kW BRN; BTT 12 Zyl.		
Throttle valve assembly	05.05→	0 280 750 107		
Air mass meter, gasoline injection	05.05→	0 280 218 071		
		🔊 0 986 280 221		
Phase sensor	05.05→	0 232 103 019		
Duo sensor, acceleration and yaw rate, brake system	05.05→	0 265 005 252		
Pressure sensor, ESP, (electronic stability program)	05.05→	0 265 005 303		
Wheel speed sensor, front	05.05→	LAB	0 265 007 728	
		RAB	0 265 007 726	
Wheel speed sensor, rear	05.05→	LAB	0 265 007 726	
		RAB	0 265 007 728	
Polo				
1.0 [6N1]		1,0l 37 kW AER; ALL 4 Zyl.		
Knock sensor	03.96-12.99	KZA	0 261 231 045	
Pressure sensor, intake manifold, gasoline	03.96-12.99	0 261 230 011		
1.0 [6N2]		1,0l 37 kW ALD; AUC 4 Zyl.		
Speed sensor, ignition/injection	07.98-09.01	0 261 210 188		
Knock sensor	07.98-09.01	KZA	0 261 231 045	
Pressure sensor, intake manifold, gasoline	07.98-09.01	0 261 230 031		
1.0 16V		1,0l 43 kW ARA 4 Zyl.		
Knock sensor	07.02-05.05	0 261 231 146		
Pressure sensor, intake manifold, gasoline	07.02-05.05	0 261 230 095		
Accelerator pedal module	07.02-05.05	GS	0 280 752 214	
1.2 [9N1]		1,2l 40 kW AWY 3 Zyl.		
Accelerator pedal module	11.01-05.04	GS, LLE	0 280 752 214	
Duo sensor, acceleration and yaw rate, brake system				
Fg.no. →9N..4..250 000	11.01-04.04	0 265 005 252		
Fg.no. 9N..5..000 001→	05.04-05.04	0 265 005 601		
Pressure sensor, ESP, (electronic stability program)	11.01-05.04	0 265 005 303		
1.2 [9N1]		1,2l 40 kW BMD 3 Zyl.		
Accelerator pedal module	05.04-05.05	GS, LLE	0 280 752 214	
Duo sensor, acceleration and yaw rate, brake system	05.04-05.05	0 265 005 601		
1.2 [9N1]		1,2l 47 kW AZQ 3 Zyl.		
Pressure sensor, intake manifold, gasoline	11.01-05.04	0 261 230 031		
Accelerator pedal module	11.01-05.04	GS, LLE	0 280 752 214	
Duo sensor, acceleration and yaw rate, brake system				
Fg.no. →9N..4..250 000	11.01-04.04	0 265 005 252		
Fg.no. 9N..5..000 001→	05.04-05.04	0 265 005 601		
Pressure sensor, ESP, (electronic stability program)	11.01-05.04	0 265 005 303		
1.2 [9N1]		1,2l 47 kW BME 3 Zyl.		
Pressure sensor, intake manifold, gasoline	11.04-05.05	0 261 230 031		
Accelerator pedal module	11.04-05.05	GS, LLE	0 280 752 214	
Duo sensor, acceleration and yaw rate, brake system	11.04-05.05	0 265 005 601		
1.2 [9N3]		1,2l 40 kW BMD 3 Zyl.		
Knock sensor	04.05-05.07	0 261 231 146		
Accelerator pedal module				
Fg.no. →9N..6..300 000	04.05-05.06	AG, RLE	0 280 752 220	
		GS, LLE	0 280 752 214	
Duo sensor, acceleration and yaw rate, brake system	04.05-05.07	0 265 005 601		






Product			
1.2 [9N3]	1,2l 44 kW BBM 3 Zyl.		
Duo sensor, acceleration and yaw rate, brake system	05.07→		0 265 005 692
1.2 [9N3]	1,2l 47 kW BME 3 Zyl.		
Pressure sensor, intake manifold, gasoline	04.05→		0 261 230 031
Accelerator pedal module			
Fg.no. →9N..6..300 000	04.05-05.06	AG,RLE	0 280 752 220
		GS,LLE	0 280 752 214
Duo sensor, acceleration and yaw rate, brake system	04.05→		0 265 005 601
1.2 [9N3]	1,2l 51 kW BZG 3 Zyl.		
Pressure sensor, intake manifold, gasoline	05.07→		0 261 230 031
Duo sensor, acceleration and yaw rate, brake system	05.07→		0 265 005 692
1.3 [6N1]	1,3l 40 kW ADX 4 Zyl.		
Knock sensor	07.96-12.99	KZA	0 261 231 045
	10.94-07.95	KZA	0 261 231 045
1.3 [80]	1,3l 40/56-59 kW NZ; 3F 4 Zyl.		
Air flow sensor, gasoline injection	10.90-09.94		0 280 200 048
			0 986 280 030
1.3 [86,87]	1,3l 40 kW NZ 4 Zyl.		
Air flow sensor, gasoline injection	12.86-08.90		0 280 200 048
			0 986 280 030
1.3 [86,87]	1,3l 56-59 kW 3F 4 Zyl.		
Air flow sensor, gasoline injection	10.89-08.90		0 280 200 048
			0 986 280 030
Temperature sensor, coolant, injection system	10.89-08.90		0 280 130 037
1.4 [6N1]	1,4l 40-44 kW AEX 4 Zyl.		
Knock sensor	07.95-12.99	KZA	0 261 231 045
Pressure sensor, intake manifold, gasoline	07.95-12.99		0 261 230 011
1.4 [6N1]	1,4l 44 kW AKV; ANX; APQ 4 Zyl.		
Pressure sensor, intake manifold, gasoline	05.97-12.99		0 261 230 011
1.4 [6N1]	1,4l 74 kW AFH 4 Zyl.		
Knock sensor	04.96-12.99	KZA	0 261 231 045
1.4 [6N2]	1,4l 40/44 kW AKK; AKP; AUD 4 Zyl.		
Speed sensor, ignition/injection	09.98-09.01		0 261 210 188
Knock sensor	09.98-09.01	KZA	0 261 231 045
Pressure sensor, intake manifold, gasoline	09.98-09.01		0 261 230 031
1.4 [9N1]	1,4l 55 kW AUA 4 Zyl.		
Knock sensor	09.01-01.02		0 261 231 146
Accelerator pedal module	09.01-01.02	GS,LLE	0 280 752 214
Duo sensor, acceleration and yaw rate, brake system	09.01-01.02		0 265 005 252
Pressure sensor, ESP, (electronic stability program)	09.01-01.02		0 265 005 303
1.4 [9N1]	1,4l 55 kW BBY 4 Zyl.		
Speed sensor, ignition/injection			
Fg.no. 9N..3..170 001→	04.03-05.04	GS	0 261 210 257
Knock sensor	09.01-05.04		0 261 231 146
Pressure sensor, intake manifold, gasoline			
Fg.no. 9N..4..000 001→	06.03-05.04		0 261 230 095
Accelerator pedal module	09.01-05.04	GS,LLE	0 280 752 214
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →9N..4..250 000	09.01-04.04		0 265 005 252
Fg.no. 9N..5..000 001→	05.04-05.04		0 265 005 601
Pressure sensor, ESP, (electronic stability program)	09.01-05.04		0 265 005 303
1.4 [9N1]	1,4l 55 kW BKY 4 Zyl.		
Pressure sensor, intake manifold, gasoline	05.04-05.05		0 261 230 095
Accelerator pedal module	05.04-05.05	GS,LLE	0 280 752 214
Duo sensor, acceleration and yaw rate, brake system	05.04-05.05		0 265 005 601



1.4 [9N1]	1,4l 74 kW AUB 4 Zyl.		
Knock sensor	11.01-04.02		0 261 231 146
Accelerator pedal module	11.01-04.02	GS,LLE	0 280 752 214
Duo sensor, acceleration and yaw rate, brake system	11.01-04.02		0 265 005 252
Pressure sensor, ESP, (electronic stability program)	11.01-04.02		0 265 005 303
1.4 [9N1]	1,4l 74 kW BBZ 4 Zyl.		
Knock sensor	09.01-04.05		0 261 231 146
Accelerator pedal module	09.01-04.05	GS,LLE	0 280 752 214
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →9N..4..250 000	09.01-04.04		0 265 005 252
Fg.no. 9N..5..000 001→	05.04-04.05		0 265 005 601
Pressure sensor, ESP, (electronic stability program)	09.01-04.05		0 265 005 303
1.4 [9N2]	1,4l 55 kW BBY; BKY 4 Zyl.		
Speed sensor, ignition/injection	07.03→	GS	0 261 210 257
Knock sensor	07.03→		0 261 231 146
Pressure sensor, intake manifold, gasoline	07.03→		0 261 230 095
Accelerator pedal module	07.03→	GS	0 280 752 214
Duo sensor, acceleration and yaw rate, brake system	07.03→	TW	0 265 005 252
			0 265 005 601
1.4 [9N2]	1,4l 63/74 kW BBZ; BLM 4 Zyl.		
Knock sensor	11.03→		0 261 231 146
Pressure sensor, intake manifold, gasoline	11.03→		0 261 230 095
Accelerator pedal module	11.03→	GS	0 280 752 214
Duo sensor, acceleration and yaw rate, brake system	11.03→	TW	0 265 005 252
			0 265 005 601
1.4 [9N3]	1,4l 55 kW BKY 4 Zyl.		
Knock sensor	04.05-07.07		0 261 231 146
Pressure sensor, intake manifold, gasoline	04.05-07.07		0 261 230 095
Accelerator pedal module	04.05-07.07	AG,RLE	0 280 752 220
		GS,LLE	0 280 752 214
Duo sensor, acceleration and yaw rate, brake system	04.05-07.07		0 265 005 601
1.4 [9N3]	1,4l 74 kW BBZ 4 Zyl.		
Knock sensor	04.05-05.07		0 261 231 146
Accelerator pedal module	04.05-05.07	AG,RLE	0 280 752 220
		GS,LLE	0 280 752 214
Duo sensor, acceleration and yaw rate, brake system	04.05-05.07		0 265 005 601
1.4 FSI [9N1]	1,4l 63 kW AXU 3 Zyl.		
Knock sensor	09.01-05.05		0 261 231 146
Pressure sensor, intake manifold, gasoline	09.01-05.05		0 261 230 095
Accelerator pedal module	09.01-05.05	GS,LLE	0 280 752 214
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →9N..4..250 000	09.01-04.04		0 265 005 252
Fg.no. 9N..5..000 001→	05.04-05.05		0 265 005 601
Pressure sensor, ESP, (electronic stability program)	09.01-05.05		0 265 005 303
1.4 FSI [9N3]	1,4l 59 kW BUD 4 Zyl.		
Pressure sensor, intake manifold, gasoline	05.06→		0 261 230 095
Accelerator pedal module			
Fg.no. →9N..6..300 000	05.06-05.06	AG,RLE	0 280 752 220
		GS,LLE	0 280 752 214
Duo sensor, acceleration and yaw rate, brake system	05.06→		0 265 005 601
1.4 FSI [9N3]	1,4l 63 kW AXU 3 Zyl.		
Knock sensor	04.05-07.06		0 261 231 146
Pressure sensor, intake manifold, gasoline	04.05-07.06		0 261 230 095
Accelerator pedal module	04.05-07.06	AG,RLE	0 280 752 220
		GS,LLE	0 280 752 214
Duo sensor, acceleration and yaw rate, brake system	04.05-07.06		0 265 005 601





Product				

◀ Polo

1.4 i		1,4 l 55 kW BCC 4 Zyl.	
Knock sensor	06.03→	0 261 231 146	
1.4 i [9N5]		1,4 l 55 kW BBY 4 Zyl.	
Speed sensor, ignition/injection	10.02-05.05 FKW,GS	0 261 210 257	
Knock sensor	10.02-05.05	0 261 231 146	
1.4 i [9N5/9N6]		1,4 l 55 kW BKY 4 Zyl.	
Knock sensor	06.04→	0 261 231 146	
Pressure sensor, intake manifold, gasoline	06.04→	0 261 230 095	
Duo sensor, acceleration and yaw rate, brake system	06.04→	0 265 005 252	
1.4 TDI [6N2]		1,4 l 55 kW AMF 3 Zyl.	
Air mass meter, diesel	10.99-09.01	0 281 002 318	
		0 986 284 002	
Boost pressure sensor, Diesel	10.99-09.01	0 281 002 177	
Accelerator pedal module	10.99-09.01 GS,LLE	0 281 002 321	
1.4 TDI [9N1]		1,4 l 55 kW AMF; BAY 3 Zyl.	
Air mass meter, diesel			
Fg.no. →9N..2..120 000	09.01-04.02	0 281 002 757	
	WW	0 280 217 121	
		0 986 280 202	
Fg.no. 9N..3..000 001→	05.02-05.05	0 281 002 531	
		0 986 284 009	
Boost pressure sensor, Diesel	09.01-05.05 TW	0 281 002 177	
		0 281 002 399	
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →9N..4..250 000	09.01-04.04	0 265 005 252	
Fg.no. 9N..5..000 001→	05.04-05.05	0 265 005 601	
Pressure sensor, ESP, (electronic stability program)	09.01-05.05	0 265 005 303	
1.4 TDI [9N2]		1,4 l 55 kW BAY 3 Zyl.	
Air mass meter, diesel	07.03→	0 281 002 531	
		0 986 284 009	
Boost pressure sensor, Diesel	07.03→	0 281 002 399	
Duo sensor, acceleration and yaw rate, brake system	07.03→ TW	0 265 005 252	
		0 265 005 601	
1.4 TDI [9N3]		1,4 l 51/58/59 kW BMS; BNM; BNV; BWB 3 Zyl.	
Air mass meter, diesel	04.05→	0 281 002 531	
		0 986 284 009	
Boost pressure sensor, Diesel	04.05→	0 281 002 399	
Duo sensor, acceleration and yaw rate, brake system	04.05→	0 265 005 601	
1.4 TDI [9N5]		1,4 l 55 kW AMF 3 Zyl.	
Air mass meter, diesel	10.02-12.03	0 281 002 757	
Boost pressure sensor, Diesel	10.02-12.03	0 281 002 177	
1.4 TDI [9N5/9N6]		1,4 l 55 kW AMF 3 Zyl.	
Air mass meter, diesel	10.03-05.05	0 281 002 757	
	WW	0 280 217 121	
		0 986 280 202	
Boost pressure sensor, Diesel	10.03-05.05	0 281 002 177	
	TW	0 281 002 399	
1.4 8V		1,4 l 61 kW BLM 4 Zyl.	
Knock sensor	05.02-07.06	0 261 231 146	
Pressure sensor, intake manifold, gasoline	05.02-07.06	0 261 230 095	
1.4 16V		1,4 l 55 kW BBY 4 Zyl.	
Knock sensor	09.02-02.05	0 261 231 146	
Pressure sensor, intake manifold, gasoline	09.02-02.05	0 261 230 095	
Accelerator pedal module	09.02-02.05 GS	0 280 752 214	
1.4 16V		1,4 l 55 kW BKY 4 Zyl.	
Knock sensor	08.06→	0 261 231 146	
Pressure sensor, intake manifold, gasoline	08.06→	0 261 230 095	
1.4 16V [6N2]		1,4 l 55/74 kW AFK; AHW; AUA; AUB 4 Zyl.	
Knock sensor	09.98-09.01 KZA	0 261 231 045	

Product				

1.6		1,6 l 74 kW BAH 4 Zyl.	
Speed sensor, ignition/injection	05.02-07.06	0 261 210 188	
Knock sensor	05.02→	0 261 231 146	
Pressure sensor, intake manifold, gasoline	05.02→	0 261 230 095	
Accelerator pedal module	05.02-07.06 GS	0 280 752 214	
1.6 [6N1]		1,6 l 55/88 kW AEA; AEE; AHS; AJV 4 Zyl.	
Knock sensor	10.94-12.99 KZA	0 261 231 045	
1.6 [6N2]		1,6 l 92 kW ARC 4 Zyl.	
Knock sensor	11.99-09.01 KZA	0 261 231 045	
1.6 [9N2]		1,6 l 74 kW BAH 4 Zyl.	
Knock sensor	07.03→	0 261 231 146	
Pressure sensor, intake manifold, gasoline	07.03→	0 261 230 095	
Accelerator pedal module	07.03→ GS	0 280 752 214	
Duo sensor, acceleration and yaw rate, brake system	07.03→ TW	0 265 005 252	
		0 265 005 601	
1.6 [9N3]		1,6 l 77 kW BTS 4 Zyl.	
Pressure sensor, intake manifold, gasoline	05.06→	0 261 230 095	
Accelerator pedal module			
Fg.no. →9N..6..300 000	05.06-05.06 AG,RLE	0 280 752 220	
	GS,LLE	0 280 752 214	
Duo sensor, acceleration and yaw rate, brake system	05.06→	0 265 005 601	
1.6 i		1,6 l 74 kW BCD 4 Zyl.	
Speed sensor, ignition/injection	06.03→	0 261 210 199	
Knock sensor	06.03→	0 261 231 146	
Pressure sensor, intake manifold, gasoline	06.03→	0 261 230 031	
Accelerator pedal module	06.03→	0 280 752 214	
1.6 i [9N5/9N6]		1,6 l 74 kW BAH 4 Zyl.	
Knock sensor	10.03→	0 261 231 146	
Pressure sensor, intake manifold, gasoline	10.03→	0 261 230 095	
1.7 SDI [6N1]		1,7 l 42 kW AHG 4 Zyl.	
Pedal position sensor, diesel			
Fg.no. →6N-WW 045 000,→6N-WY 066 000	04.97-07.97	0 205 001 032	
1.7 SDI [6N2]		1,7 l 42/44 kW AHG; AKU 4 Zyl.	
Accelerator pedal module	10.99-09.01 GS,LLE	0 281 002 321	
1.8 GTI [9N3]		1,8 l 110/132 kW BBU; BJX 4 Zyl.	
Throttle valve assembly	08.05→	0 280 750 115	
Air mass meter, gasoline injection	08.05→	0 280 218 063	
		0 986 280 217	
Phase sensor	08.05→	0 232 101 024	
Speed sensor, ignition/injection	08.05→	0 261 210 199	
Knock sensor	08.05→	0 261 231 146	
Boost pressure sensor, gasoline	08.05→	0 281 002 399	
Accelerator pedal module			
Fg.no. →9N..6..300 000	08.05-05.06 AG,RLE	0 280 752 220	
	GS,LLE	0 280 752 214	
Duo sensor, acceleration and yaw rate, brake system	08.05→	0 265 005 601	
1.9 D [6N1]		1,9 l 47 kW AGD 4 Zyl.	
Pedal position sensor, diesel			
Fg.no. →6N-WW 045 000,→6N-WY 066 000	07.96-07.97	0 205 001 032	
1.9 SDI [6N2]		1,9 l 47 kW AGD; ASX 4 Zyl.	
Accelerator pedal module	10.99-09.01 GS,LLE	0 281 002 321	
1.9 SDI [9N1]		1,9 l 47 kW ASY 4 Zyl.	
Duo sensor, acceleration and yaw rate, brake system			
Fg.no. →9N..4..250 000	09.01-04.04	0 265 005 252	
Fg.no. 9N..5..000 001→	05.04-05.05	0 265 005 601	
Pressure sensor, ESP, (electronic stability program)	09.01-05.05	0 265 005 303	
1.9 SDI [9N2]		1,9 l 47 kW ASY 4 Zyl.	
Duo sensor, acceleration and yaw rate, brake system	11.03→ TW	0 265 005 252	
		0 265 005 601	




1.9 SDI [9N3]	1,9l 47 kW ASY 4 Zyl.
Duo sensor, acceleration and yaw rate, brake system	04.05→ 0 265 005 601
1.9 TDi [9N5/9N6]	1,9l 96 kW ASZ 4 Zyl.
Air mass meter, diesel	10.03→ 0 281 002 461 0 986 284 007 0 281 002 531 0 986 284 009
Boost pressure sensor, Diesel	10.03→ 0 281 002 401
1.9 TDi [9N6]	1,9l 74 kW ATD 4 Zyl.
Air mass meter, diesel	10.04→ 0 281 002 531 0 986 284 009
Boost pressure sensor, Diesel	10.04→ TW 0 281 002 399
1.9 TDi [9N1]	1,9l 74 kW ATD; AXR 4 Zyl.
Air mass meter, diesel	Fg.no. →9N..2..120 000 09.01-04.02 0 281 002 757 WW 0 280 217 121 0 986 280 202
Fg.no. 9N..3..000 001→	05.02-05.05 0 281 002 531 0 986 284 009
Boost pressure sensor, Diesel	09.01-05.05 TW 0 281 002 177 0 281 002 399
Duo sensor, acceleration and yaw rate, brake system	Fg.no. →9N..4..250 000 09.01-04.04 0 265 005 252 Fg.no. 9N..5..000 001→ 05.04-05.05 0 265 005 601
Pressure sensor, ESP, (electronic stability program)	09.01-05.05 0 265 005 303
1.9 TDi [9N1]	1,9l 96 kW ASZ 4 Zyl.
Air mass meter, diesel	11.03-05.05 0 281 002 461 0 986 284 007
Boost pressure sensor, Diesel	11.03-05.05 0 281 002 401
Duo sensor, acceleration and yaw rate, brake system	Fg.no. →9N..4..250 000 11.03-04.04 0 265 005 252 Fg.no. 9N..5..000 001→ 05.04-05.05 0 265 005 601
Pressure sensor, ESP, (electronic stability program)	11.03-05.05 0 265 005 303
1.9 TDi [9N1]	1,9l 96 kW BLT 4 Zyl.
Air mass meter, diesel	05.04-05.05 0 281 002 461 0 986 284 007
Boost pressure sensor, Diesel	05.04-05.05 0 281 002 401
Duo sensor, acceleration and yaw rate, brake system	05.04-05.05 0 265 005 601
Pressure sensor, ESP, (electronic stability program)	05.04-05.05 0 265 005 303
1.9 TDi [9N2]	1,9l 74 kW ATD 4 Zyl.
Duo sensor, acceleration and yaw rate, brake system	07.03→ TW 0 265 005 252 0 265 005 601
1.9 TDi [9N3]	1,9l 74 kW ATD; AXR; BMT 4 Zyl.
Air mass meter, diesel	04.05→ 0 281 002 531 0 986 284 009
Boost pressure sensor, Diesel	04.05→ 0 281 002 399
Duo sensor, acceleration and yaw rate, brake system	04.05→ 0 265 005 601
1.9 TDi [9N3]	1,9l 96 kW ASZ; BLT 4 Zyl.
Air mass meter, diesel	04.05→ 0 281 002 461 0 986 284 007
Boost pressure sensor, Diesel	04.05→ 0 281 002 401
Duo sensor, acceleration and yaw rate, brake system	04.05→ 0 265 005 601
2.0	2,0l 85 kW BBX 4 Zyl.
Throttle valve assembly	05.02-07.06 0 280 750 061
Air mass meter, gasoline injection	05.02-07.06 0 280 218 060 0 986 280 216
Speed sensor, ignition/injection	05.02-07.06 0 261 210 199



Knock sensor	05.02-07.06 0 261 231 146
Pressure sensor, intake manifold, gasoline	Fg.no. F 9A-3-033 710→ 03.03-07.06 0 261 230 095 Fg.no. →F 9A-3-033 709 05.02-02.03 0 261 230 031
Accelerator pedal module	05.02-07.06 GS 0 280 752 214
2.0 [9N2]	2,0l 85 kW BBX 4 Zyl.
Throttle valve assembly	07.03→ 0 280 750 061
Speed sensor, ignition/injection	07.03→ 0 261 210 199
Knock sensor	07.03→ 0 261 231 146
Pressure sensor, intake manifold, gasoline	07.03→ 0 261 230 095
Accelerator pedal module	07.03→ GS 0 280 752 214
Duo sensor, acceleration and yaw rate, brake system	07.03→ TW 0 265 005 252 0 265 005 601

Polo Classic

1.3 [80]	1,3l 40/56-59 kW NZ; 3F 4 Zyl.
Air flow sensor, gasoline injection	10.90-09.94 0 280 200 048 0 986 280 030
1.3 [86,87]	1,3l 40 kW NZ 4 Zyl.
Air flow sensor, gasoline injection	12.86-08.90 0 280 200 048 0 986 280 030
1.3 [86,87]	1,3l 56-59 kW 3F 4 Zyl.
Air flow sensor, gasoline injection	10.89-08.90 0 280 200 048 0 986 280 030
Temperature sensor, coolant, injection system	10.89-08.90 0 280 130 037
1.4 [6V2]	1,4l 44 kW AEX 4 Zyl.
Knock sensor	05.96-12.97 0 261 231 045
Pressure sensor, intake manifold, gasoline	05.96-12.97 0 261 230 011
1.4 [6V2]	1,4l 44 kW AKK 4 Zyl.
Throttle valve assembly	10.99-09.01 0 280 750 049
Speed sensor, ignition/injection	Fg.no. →6K..1..529 200 10.99-10.00 BM6 0 261 210 188 Fg.no. 6K..1..529 201→ 11.00-09.01 BM6 0 261 210 213
Knock sensor	10.99-09.01 0 261 231 045
Pressure sensor, intake manifold, gasoline	10.99-09.01 0 261 230 031
1.4 [6V2]	1,4l 44 kW AKV 4 Zyl.
Knock sensor	12.97-08.99 0 261 231 045
Pressure sensor, intake manifold, gasoline	12.97-08.99 0 261 230 011
1.4 [6V2]	1,4l 44 kW ANW 4 Zyl.
Throttle valve assembly	Mot.no. ANW 051 561→ 10.99-08.00 0 280 750 095 Mot.no. →ANW 051 560 10.99-08.00 0 280 750 049
Speed sensor, ignition/injection	10.99-08.00 BM6 0 261 210 188
Knock sensor	10.99-08.00 0 261 231 045
Pressure sensor, intake manifold, gasoline	10.99-08.00 0 261 230 031
1.4 [6V2]	1,4l 44 kW ANX; APQ 4 Zyl.
Knock sensor	12.97-08.99 0 261 231 045
Pressure sensor, intake manifold, gasoline	12.97-08.99 0 261 230 011
1.4 [6V2]	1,4l 44 kW AUD 4 Zyl.
Throttle valve assembly	Mot.no. AUD 020 028→ 06.00-09.01 0 280 750 095 Mot.no. →AUD 020 027 06.00-09.01 0 280 750 049
Speed sensor, ignition/injection	Fg.no. →6K..1..529 200 06.00-10.00 BM6 0 261 210 188 Fg.no. 6K..1..529 201→ 11.00-09.01 BM6 0 261 210 213
Knock sensor	06.00-09.01 0 261 231 045
Pressure sensor, intake manifold, gasoline	06.00-09.01 0 261 230 031
1.4 [6V2]	1,4l 55 kW APE; AUA 4 Zyl.
Knock sensor	10.99-09.01 0 261 231 045
1.4 i	1,4l 62 kW AGY 0 Zyl.
Knock sensor	12.94-10.03 KZA 0 261 231 045
Temperature sensor, intake air, injection system	12.94-10.03 0 280 130 039





Product				

◀ Polo Classic

1.6 [6V2]	1,6l 55 kW AEE; ALM 4 Zyl.
Knock sensor	04.97-09.01 0 261 231 045
1.6 [6V2]	1,6l 74 kW AEH 4 Zyl.
Phase sensor	10.99-09.01 0 232 101 031
Speed sensor, ignition/injection	10.99-09.01 0 261 210 147
1.6 [6V2]	1,6l 74 kW AFT 4 Zyl.
Knock sensor	12.95-08.99 0 261 231 036
Temperature sensor, intake air, injection system	12.95-08.99 0 280 130 039
1.6 [6V2]	1,6l 74 kW AKL 4 Zyl.
Phase sensor	10.99-09.01 0 232 101 031
Speed sensor, ignition/injection	10.99-09.01 0 261 210 147
1.6 [6V2]	1,6l 74 kW APF; AUR 4 Zyl.
Phase sensor	03.00-09.01 0 232 101 031
Speed sensor, ignition/injection	03.00-09.01 0 261 210 199
1.6 i	1,6l 74 kW AFX 0 Zyl.
Knock sensor	12.94-10.03 KZA 0 261 231 045
Temperature sensor, intake air, injection system	12.94-10.03 0 280 130 039
1.7 SDI [6V2]	1,7l 44 kW AKW 4 Zyl.
Pedal position sensor, diesel	11.97-08.99 0 205 001 032
1.9 SDI [6V2]	1,9l 47 kW AEY 4 Zyl.
Pedal position sensor, diesel	12.95-08.99 0 205 001 032
1.9 SDI [6V2]	1,9l 50 kW AGP; AQM 4 Zyl.
Pedal position sensor, diesel	10.99-09.01 0 281 002 269
1.9 TDI	1,9l 66 kW AGR 4 Zyl.
Air mass meter, diesel	09.00→ 0 281 002 216 0 986 284 001
Pedal position sensor, diesel	09.00→ 0 281 002 269
1.9 TDI [6V2]	1,9l 66 kW AGR 4 Zyl.
Air mass meter, diesel	10.99-09.01 0 281 002 216 0 986 284 001
Boost pressure sensor, Diesel	10.99-09.01 0 281 002 177
Pedal position sensor, diesel	10.99-09.01 0 281 002 269
1.9 TDI [6V2]	1,9l 66 kW AHU; ALE 4 Zyl.
Pressure sensor, intake manifold, diesel	07.96-08.99 0 261 230 037
Pedal position sensor, diesel	07.96-08.99 0 205 001 032
1.9 TDI [6V2]	1,9l 66 kW ALH 4 Zyl.
Air mass meter, diesel	10.99-09.01 0 281 002 216 0 986 284 001
Boost pressure sensor, Diesel	10.99-09.01 0 281 002 177
Pedal position sensor, diesel	10.99-09.01 0 281 002 269
1.9 TDI [6V2]	1,9l 81 kW AFN 4 Zyl.
Pressure sensor, intake manifold, diesel	08.98-08.99 0 261 230 037
Pedal position sensor, diesel	08.98-08.99 0 205 001 032
1.9 TDI [6V2]	1,9l 81 kW ASV 4 Zyl.
Air mass meter, diesel	10.99-09.01 0 281 002 216 0 986 284 001
Boost pressure sensor, Diesel	10.99-09.01 0 281 002 177
Pedal position sensor, diesel	10.99-09.01 0 281 002 269
2.0 [6V2]	2,0l 85 kW ADC 4 Zyl.
Knock sensor	08.99-09.01 0 261 231 036
Temperature sensor, intake air, injection system	08.99-09.01 0 280 130 039

Polo Coupé

1.3 [80]	1,3l 40/56-59 kW NZ; 3F 4 Zyl.
Air flow sensor, gasoline injection	10.90-09.94 0 280 200 048 0 986 280 030
1.3 [86,87]	1,3l 40 kW NZ 4 Zyl.
Air flow sensor, gasoline injection	12.86-08.90 0 280 200 048 0 986 280 030

Product				

1.3 [86,87]	1,3l 56-59 kW 3F 4 Zyl.
Air flow sensor, gasoline injection	10.89-08.90 0 280 200 048 0 986 280 030
Temperature sensor, coolant, injection system	10.89-08.90 0 280 130 037
1.3 G40 [80]	1,3l 85 kW PY 4 Zyl.
Air flow sensor, gasoline injection	10.90-09.94 0 280 200 041
Knock sensor	10.90-12.90 0 261 231 004
	KZG 0 261 231 038
	12.90-09.94 KZS 0 261 231 066
1.3 G40 [86,87]	1,3l 85 kW PY 4 Zyl.
Air flow sensor, gasoline injection	01.87-08.90 0 280 200 041

Polo Hatchback

1.4 i	1,4l 55 kW BCC 4 Zyl.
Knock sensor	04.02→ 0 261 231 146
1.6 i	1,6l 74 kW BCD 4 Zyl.
Speed sensor, ignition/injection	09.02→ 0 261 210 199
Knock sensor	09.02→ 0 261 231 146
Pressure sensor, intake manifold, gasoline	09.02→ 0 261 230 031
Accelerator pedal module	09.02→ 0 280 752 214

Polo Playa

1.4 i	1,4l 62 kW AGY 4 Zyl.
Knock sensor	10.98-10.02 KZA 0 261 231 045
Temperature sensor, intake air, injection system	10.98-10.02 0 280 130 039
1.6 i	1,6l 74 kW AFX 4 Zyl.
Knock sensor	10.98-10.02 KZA 0 261 231 045
Temperature sensor, intake air, injection system	10.98-10.02 0 280 130 039
1.8 i	1,8l 82 kW AFV 4 Zyl.
Knock sensor	10.98-10.02 KZA 0 261 231 045
Temperature sensor, intake air, injection system	10.98-10.02 0 280 130 039

Polo Sedan

1.4 TDI	1,4l 55 kW BAY 3 Zyl.
Pressure sensor, intake manifold, diesel	06.03-03.05 0 281 002 399
1.4 8V	1,4l 61 kW BLM 4 Zyl.
Knock sensor	05.02-07.06 0 261 231 146
Pressure sensor, intake manifold, gasoline	05.02-07.06 0 261 230 095
1.4 16V	1,4l 55 kW BBY 4 Zyl.
Speed sensor, ignition/injection	11.02-02.05 GS 0 261 210 257
Knock sensor	11.02-02.05 0 261 231 146
Pressure sensor, intake manifold, gasoline	11.02-02.05 0 261 230 095
Accelerator pedal module	11.02-02.05 GS 0 280 752 214
1.6	1,6l 74 kW BAH 4 Zyl.
Speed sensor, ignition/injection	11.02-07.06 0 261 210 188
Knock sensor	11.02-07.06 0 261 231 146
Pressure sensor, intake manifold, gasoline	11.02-07.06 0 261 230 095
Accelerator pedal module	11.02-07.06 GS 0 280 752 214

Polo Variant

1.4 [6V5]	1,4l 44 kW AEX 4 Zyl.
Knock sensor	05.97-12.97 0 261 231 045
Pressure sensor, intake manifold, gasoline	05.97-12.97 0 261 230 011
1.4 [6V5]	1,4l 44 kW AKK 4 Zyl.
Throttle valve assembly	10.99-09.01 0 280 750 049
Speed sensor, ignition/injection	
Fg.no. →6K..1..529 200	10.99-10.00 BM6 0 261 210 188
Fg.no. 6K..1..529 201→	11.00-09.01 BM6 0 261 210 213



Knock sensor	10.99-09.01	0 261 231 045
Pressure sensor, intake manifold, gasoline	10.99-09.01	0 261 230 031
1.4 [6V5]	1,4l 44 kW AKV 4 Zyl.	
Knock sensor	12.97-08.99	0 261 231 045
Pressure sensor, intake manifold, gasoline	12.97-08.99	0 261 230 011
1.4 [6V5]	1,4l 44 kW ANW 4 Zyl.	
Throttle valve assembly		
Mot.no. ANW 051 561→	10.99-08.00	0 280 750 095
Mot.no. →ANW 051 560	10.99-08.00	0 280 750 049
Speed sensor, ignition/injection	10.99-08.00 BM6	0 261 210 188
Knock sensor	10.99-08.00	0 261 231 045
Pressure sensor, intake manifold, gasoline	10.99-08.00	0 261 230 031
1.4 [6V5]	1,4l 44 kW ANX; APQ 4 Zyl.	
Knock sensor	12.97-08.99	0 261 231 045
Pressure sensor, intake manifold, gasoline	12.97-08.99	0 261 230 011
1.4 [6V5]	1,4l 55 kW APE; AUA 4 Zyl.	
Knock sensor	10.99-09.01	0 261 231 045
1.6 [6V5]	1,6l 55 kW AEE; ALM 4 Zyl.	
Knock sensor	09.97-09.01	0 261 231 045
1.6 [6V5]	1,6l 74 kW AEH 4 Zyl.	
Phase sensor	10.99-09.01	0 232 101 031
Speed sensor, ignition/injection	10.99-09.01	0 261 210 147
1.6 [6V5]	1,6l 74 kW AFT 4 Zyl.	
Knock sensor	05.97-08.99	0 261 231 036
Temperature sensor, intake air, injection system	05.97-08.99	0 280 130 039
1.6 [6V5]	1,6l 74 kW AKL 4 Zyl.	
Phase sensor	10.99-09.01	0 232 101 031
Speed sensor, ignition/injection	10.99-09.01	0 261 210 147
1.6 [6V5]	1,6l 74 kW APF; AUR 4 Zyl.	
Phase sensor	03.00-09.01	0 232 101 031
Speed sensor, ignition/injection	03.00-09.01	0 261 210 199
1.7 SDI [6V5]	1,7l 44 kW AKW 4 Zyl.	
Pedal position sensor, diesel	11.97-08.99	0 205 001 032
1.9 SDI [6V5]	1,9l 47 kW AEY 4 Zyl.	
Pedal position sensor, diesel	06.97-08.99	0 205 001 032
1.9 SDI [6V5]	1,9l 50 kW AGP; AQM 4 Zyl.	
Pedal position sensor, diesel	10.99-09.01	0 281 002 269
1.9 TDI [6V5]	1,9l 66 kW AGR 4 Zyl.	
Air mass meter, diesel	10.99-09.01	0 281 002 216 0 986 284 001
Boost pressure sensor, Diesel	10.99-09.01	0 281 002 177
Pedal position sensor, diesel	10.99-09.01	0 281 002 269
1.9 TDI [6V5]	1,9l 66 kW AHU; ALE 4 Zyl.	
Pressure sensor, intake manifold, diesel	06.97-08.99	0 261 230 037
Pedal position sensor, diesel	06.97-08.99	0 205 001 032
1.9 TDI [6V5]	1,9l 66 kW ALH 4 Zyl.	
Air mass meter, diesel	10.99-09.01	0 281 002 216 0 986 284 001
Boost pressure sensor, Diesel	10.99-09.01	0 281 002 177
Pedal position sensor, diesel	10.99-09.01	0 281 002 269
1.9 TDI [6V5]	1,9l 81 kW AFN 4 Zyl.	
Pressure sensor, intake manifold, diesel	06.98-08.99	0 261 230 037
Pedal position sensor, diesel	06.98-08.99	0 205 001 032
1.9 TDI [6V5]	1,9l 81 kW ASV 4 Zyl.	
Air mass meter, diesel	10.99-09.01	0 281 002 216 0 986 284 001
Boost pressure sensor, Diesel	10.99-09.01	0 281 002 177
Pedal position sensor, diesel	10.99-09.01	0 281 002 269



Santana

1.6 i	1,6l 64 kW AYF 4 Zyl.	
Knock sensor	12.00→	0 261 231 036
Pressure sensor, intake manifold, gasoline	12.00→	0 261 230 011
Temperature sensor, coolant, injection system	12.00→	0 280 130 040
2.0 [32]	2,0l 85 kW JS 5 Zyl.	
Air flow sensor, gasoline injection	02.86-03.88	0 438 120 211
	06.85-01.86 MZF	0 438 121 005

Saveiro III

1.9 D	1,9l 47 kW 4 Zyl.	
Wheel speed sensor, front	06.98-05.02	0 265 006 218
Wheel speed sensor, rear	06.98-05.02	LAB, TU2 0 265 006 222 LAB, TU4 0 265 006 410 RAB, TU2 0 265 006 221 RAB, TU4 0 265 006 411

Scirocco II

1.8 [53]	1,8l 68-70 kW JH 4 Zyl.	
Air flow sensor, gasoline injection	05.83-07.92	0 438 120 162
1.8 [53]	1,8l 82 kW DX; KT 4 Zyl.	
Air flow sensor, gasoline injection	01.86-07.92	F 026 TX2 051 0 986 284 001
1.8 16V [53]	1,8l 95 kW PL 4 Zyl.	
Air flow sensor, gasoline injection	02.86-07.92	0 438 121 046
Knock sensor	02.86-07.92 KZG	0 261 231 038

Sharan

1.8 T [7M8]	1,8l 110 kW AJH 4 Zyl.	
Air mass meter, gasoline injection	11.97-02.00	0 280 217 117 0 986 280 201
Phase sensor	11.97-02.00	0 232 101 024
Speed sensor, ignition/injection	11.97-02.00	0 261 210 147
Temperature sensor, intake air, injection system	11.97-02.00	0 280 130 085
1.8 T [7M9, 7M6]	1,8l 110 kW AWC 4 Zyl.	
Throttle valve assembly	05.00→	0 280 750 065
Air mass meter, gasoline injection	05.00→	0 280 218 060 0 986 280 216
Phase sensor	05.00→	0 232 101 024
Knock sensor	05.00→	0 261 231 146
Boost pressure sensor, gasoline		
Fg.no. →7M..2..014 000	05.00-06.01	0 281 002 177
Fg.no. 7M..2..014 001→	07.01→	0 281 002 399
Temperature sensor, intake air, injection system	05.00→	0 280 130 085
1.9 TDI [7M8]	1,9l 66 kW AHU 4 Zyl.	
Air mass meter, diesel		
Fg.no. 7M..W..020 001→	08.97-02.00	0 281 002 757 WW 0 280 217 121 0 986 280 202
Pedal position sensor, diesel		
Fg.no. →7M..W..020 000	07.96-08.97	AG 0 205 001 031 GS 0 205 001 032
1.9 TDI [7M8]	1,9l 66 kW ANU 4 Zyl.	
Air mass meter, diesel	03.99-02.00	0 281 002 757 WW 0 280 217 121 0 986 280 202
Boost pressure sensor, Diesel	03.99-02.00	0 281 002 177

Product				
◀ Sharan				
1.9 TDI [7M8]		1,9l 66 kW 1Z 4 Zyl.		
Pedal position sensor, diesel	09.95-07.96	AG	0 205 001 031	
		GS	0 205 001 032	
1.9 TDI [7M8]		1,9l 81 kW AFN 4 Zyl.		
Air mass meter, diesel				
Fg.no. 7M..W..020 001→	08.97-02.00		0 281 002 757	
		WW	0 280 217 121	
			0 986 280 202	
Pedal position sensor, diesel				
Fg.no. →7M..W..020 000	09.96-08.97	AG	0 205 001 031	
		GS	0 205 001 032	
1.9 TDI [7M8]		1,9l 81 kW AVG 4 Zyl.		
Air mass meter, diesel	08.99-02.00		0 281 002 757	
		WW	0 280 217 121	
			0 986 280 202	
1.9 TDI [7M9, 7M6]		1,9l 66/85 kW ANU; AUY 4 Zyl.		
Air mass meter, diesel	04.00→		0 281 002 757	
		WW	0 280 217 121	
			0 986 280 202	
Boost pressure sensor, Diesel				
Fg.no. →7M..2..014 000	04.00-06.01		0 281 002 177	
Fg.no. 7M..2..014 001→	07.01→		0 281 002 399	
1.9 TDI [7M9, 7M6]		1,9l 85 kW BVK 4 Zyl.		
Air mass meter, diesel	11.05→		0 281 002 531	
			0 986 284 009	
Boost pressure sensor, Diesel	11.05→		0 281 002 399	
1.9 TDI [7M9, 7M6]		1,9l 96/110 kW ASZ; BTB 4 Zyl.		
Air mass meter, diesel	11.02→		0 281 002 461	
			0 986 284 007	
Boost pressure sensor, Diesel	11.02→		0 281 002 401	
1.9 TDI 4 Motion [7M9, 7M6]		1,9l 85 kW AUY 4 Zyl.		
Air mass meter, diesel	05.00→		0 281 002 757	
		WW	0 280 217 121	
			0 986 280 202	
Boost pressure sensor, Diesel				
Fg.no. →7M..2..014 000	05.00-06.01		0 281 002 177	
Fg.no. 7M..2..014 001→	07.01→		0 281 002 399	
2.0 [7M8]		2,0l 85 kW ADY 4 Zyl.		
Knock sensor	09.95-02.00		0 261 231 077	
Temperature sensor, intake air, injection system	09.95-02.00		0 280 130 073	
2.0 [7M9, 7M6]		2,0l 85 kW ATM 4 Zyl.		
Throttle valve assembly	05.00→		0 280 750 057	
Air mass meter, gasoline injection	05.00→		0 280 218 060	
			0 986 280 216	
Phase sensor	05.00→		0 232 101 031	
Knock sensor	05.00→		0 261 231 146	
2.0 TDI [7M9, 7M6]		2,0l 100/103 kW BRT; BVH 4 Zyl.		
Air mass meter, diesel	11.05→		0 281 002 461	
			0 986 284 007	
Boost pressure sensor, Diesel	11.05→		0 281 002 401	
2.8 [7M8]		2,8l 128 kW AAA 6 Zyl.		
Air mass meter, gasoline injection	09.95-02.00		0 280 217 512	
			0 986 280 203	
Phase sensor				
Mot.no. AAA 263 000→	12.97-02.00		0 232 103 019	
Speed sensor, ignition/injection	09.95-02.00		0 261 210 107	
Knock sensor	09.95-02.00	KZA	0 261 231 077	
		KZW	0 261 231 047	
Temperature sensor, intake air, injection system	09.95-02.00		0 280 130 039	
2.8 [7M8]		2,8l 128 kW AMY 6 Zyl.		
Air mass meter, gasoline injection	04.98-02.00		0 280 217 512	
			0 986 280 203	
Phase sensor	04.98-02.00		0 232 103 019	



Product				
Speed sensor, ignition/injection	04.98-02.00		0 261 210 107	
Knock sensor	04.98-02.00	KZA	0 261 231 077	
		KZW	0 261 231 047	
Temperature sensor, intake air, injection system	04.98-02.00		0 280 130 039	
2.8 [7M9, 7M6]		2,8l 150 kW AYL 6 Zyl.		
Throttle valve assembly	05.00→		0 280 750 086	
Air mass meter, gasoline injection	05.00→		0 280 218 017	
			0 986 280 208	
Phase sensor	05.00→		0 232 103 019	
Knock sensor	05.00→	OHL	0 261 231 146	
2.8 syncro [7M8]		2,8l 128 kW AAA 6 Zyl.		
Air mass meter, gasoline injection	07.96-02.00		0 280 217 512	
			0 986 280 203	
Phase sensor				
Mot.no. AAA 263 000→	12.97-02.00		0 232 103 019	
Speed sensor, ignition/injection	07.96-02.00		0 261 210 107	
Knock sensor	07.96-02.00	KZA	0 261 231 077	
		KZW	0 261 231 047	
Temperature sensor, intake air, injection system	07.96-02.00		0 280 130 039	
2.8 syncro [7M8]		2,8l 128 kW AMY 6 Zyl.		
Air mass meter, gasoline injection	04.98-02.00		0 280 217 512	
			0 986 280 203	
Phase sensor	04.98-02.00		0 232 103 019	
Speed sensor, ignition/injection	04.98-02.00		0 261 210 107	
Knock sensor	04.98-02.00	KZA	0 261 231 077	
		KZW	0 261 231 047	
Temperature sensor, intake air, injection system	04.98-02.00		0 280 130 039	
2.8 4 Motion [7M9, 7M6]		2,8l 150 kW AYL 6 Zyl.		
Throttle valve assembly	05.00→		0 280 750 086	
Air mass meter, gasoline injection	05.00→		0 280 218 017	
			0 986 280 208	
Phase sensor	05.00→		0 232 103 019	
Knock sensor	05.00→	OHL	0 261 231 146	
Tiguan				
1.4 TSI [5N1]		1,4l 110 kW BWK 4 Zyl.		
Knock sensor	11.07→		0 261 231 146	
Boost pressure sensor, gasoline	11.07→		0 281 002 401	
2.0 TDI [5N1]		2,0l 100/103 kW CBAA; CBAB 4 Zyl.		
Boost pressure sensor, Diesel	11.07→		0 281 002 401	
Touareg				
2.5 TDI [7LA]		2,5l 120 kW BLK 5 Zyl.		
Air mass meter, diesel	07.03-11.06		0 281 002 461	
			0 986 284 007	
Boost pressure sensor, Diesel	07.03-11.06		0 281 002 401	
2.5 TDI [7LA]		2,5l 120 kW BPD 5 Zyl.		
Boost pressure sensor, Diesel	01.06-11.06		0 281 002 401	
2.5 TDI [7LA]		2,5l 128 kW BAC 5 Zyl.		
Air mass meter, diesel	01.03-11.06		0 281 002 461	
			0 986 284 007	
Boost pressure sensor, Diesel	01.03-11.06		0 281 002 401	
2.5 TDI [7LA]		2,5l 128 kW BPE 5 Zyl.		
Boost pressure sensor, Diesel	01.06-11.06		0 281 002 401	
2.5 TDI [7L6]		2,5l 120/128 kW BPD; BPE 5 Zyl.		
Boost pressure sensor, Diesel	12.06→		0 281 002 401	
3.0 TDI [7LA]		3,0l 155 kW BUN 6 Zyl.		
Boost pressure sensor, Diesel	04.06-11.06		0 281 002 401	
3.0 TDI [7LA]		3,0l 165 kW BKS 6 Zyl.		
Speed sensor, diesel	11.04-11.06	AG	0 261 210 261	
Boost pressure sensor, Diesel	11.04-11.06		0 281 002 401	



Product			
3.0 TDI [7L6]	3,0l	155/165 kW	BKS; BUN 6 Zyl.
Speed sensor, diesel	12.06→	AG	0 261 210 261
3.2 [7LA]	3,2l	162 kW	AZZ; BAA; BKJ; BMV; BRJ 6 Zyl.
Air mass meter, gasoline injection	11.02-11.06		0 280 218 073 0 986 280 222
Phase sensor	11.02-11.06		0 232 103 019
Knock sensor	11.02-11.06	OHL	0 261 231 146
3.6 FSI [7LA]	3,6l	206 kW	BHK 6 Zyl.
Air mass meter, gasoline injection	08.05-11.06		0 280 218 175
Knock sensor	08.05-11.06	OHL	0 261 231 146
3.6 FSI [7LA]	3,6l	206 kW	BHL 6 Zyl.
Knock sensor	10.05-11.06	OHL	0 261 231 146
3.6 FSI [7L6]	3,6l	206 kW	BHK 6 Zyl.
Air mass meter, gasoline injection	12.06→		0 280 218 175
Knock sensor	12.06→	OHL	0 261 231 146
4.2 [7LA]	4,2l	228 kW	AXQ 8 Zyl.
Throttle valve assembly	12.02-11.06		0 280 750 047
Air mass meter, gasoline injection	12.02-11.06		0 280 218 060 0 986 280 216
Phase sensor	12.02-11.06		0 232 101 024
Speed sensor, ignition/injection	12.02-05.05		0 261 210 192
	06.05-11.06		0 261 210 261
Knock sensor	12.02-11.06		0 261 231 038
4.2 [7LA]	4,2l	228 kW	BHX 8 Zyl.
Throttle valve assembly	04.03-11.06		0 280 750 047
Air mass meter, gasoline injection	04.03-11.06		0 280 218 060 0 986 280 216
4.2 FSI [7LA]	4,2l	257 kW	BAR 8 Zyl.
Throttle valve assembly	06.06-11.06		0 280 750 047
Air mass meter, gasoline injection	06.06-11.06		0 280 218 060 0 986 280 216
4.2 FSI [7L6]	4,2l	257 kW	BAR 8 Zyl.
Throttle valve assembly	12.06→		0 280 750 047
Air mass meter, gasoline injection	12.06→		0 280 218 060 0 986 280 216
Speed sensor, ignition/injection	12.06→		0 261 210 192
5.0 TDI [7LA]	5,0l	230 kW	AYH; BLE 10 Zyl.
Air mass meter, diesel	11.02-11.06		0 281 002 461 0 986 284 007
Boost pressure sensor, Diesel	11.02-11.06		0 281 002 401
5.0 TDI [7L6]	5,0l	230 kW	BLE 10 Zyl.
Air mass meter, diesel	12.06→		0 281 002 461 0 986 284 007
Boost pressure sensor, Diesel	12.06→		0 281 002 401
6.0 [7LA]	6,0l	331 kW	BJN 12 Zyl.
Air mass meter, gasoline injection	08.04-11.06		0 280 218 073 0 986 280 222
Phase sensor	08.04-11.06		0 232 103 019
6.0 [7L6]	6,0l	331 kW	BJN 12 Zyl.
Air mass meter, gasoline injection	12.06→		0 280 218 073 0 986 280 222
Phase sensor	12.06→		0 232 103 019

Touran

1.4 TSI [1T1]	1,4l	103 kW	BMV 4 Zyl.
Speed sensor, ignition/injection	02.06-11.06		0 261 210 250
Boost pressure sensor, gasoline	02.06-11.06		0 281 002 401
1.4 TSI [1T2]	1,4l	103 kW	BMV 4 Zyl.
Speed sensor, ignition/injection	11.06→		0 261 210 250
Boost pressure sensor, gasoline	11.06→		0 281 002 401



1.6 [1T1]	1,6l	75 kW	BGU; BSE; BSF 4 Zyl.
Speed sensor, ignition/injection	07.03-11.06		0 261 210 199
Knock sensor	07.03-11.06		0 261 231 146
Pressure sensor, intake manifold, gasoline	07.03-11.06		0 261 230 031
1.6 [1T2]	1,6l	75 kW	BSE; BSF 4 Zyl.
Speed sensor, ignition/injection	11.06→		0 261 210 199
Knock sensor	11.06→		0 261 231 146
Pressure sensor, intake manifold, gasoline	11.06→		0 261 230 031
1.6 FSI [1T1]	1,6l	85 kW	BAG 4 Zyl.
Speed sensor, ignition/injection	02.03-05.04	AG	0 261 210 250
Knock sensor	02.03-05.04		0 261 231 146
Pressure sensor, intake manifold, gasoline	02.03-05.04		0 261 230 095
1.6 FSI [1T1]	1,6l	85 kW	BLF 4 Zyl.
Speed sensor, ignition/injection	02.05-11.06	AG	0 261 210 250
Knock sensor	02.05-11.06		0 261 231 146
Pressure sensor, intake manifold, gasoline	02.05-11.06		0 261 230 095
1.6 FSI [1T1]	1,6l	85 kW	BLP 4 Zyl.
Speed sensor, ignition/injection	05.04-05.05	AG	0 261 210 250
Pressure sensor, intake manifold, gasoline	05.04-05.05		0 261 230 095
1.6 FSI [1T2]	1,6l	85 kW	BLF 4 Zyl.
Speed sensor, ignition/injection	11.06→	AG	0 261 210 250
Knock sensor	11.06→		0 261 231 146
Pressure sensor, intake manifold, gasoline	11.06→		0 261 230 095
1.9 TDI [1T1]	1,9l	66 kW	BRU; BXF 4 Zyl.
Air mass meter, diesel	06.05-11.06		0 281 002 531 0 986 284 009
Boost pressure sensor, Diesel	06.05-11.06		0 281 002 399
1.9 TDI [1T1]	1,9l	66 kW	BJX 4 Zyl.
Air mass meter, diesel	07.06-11.06		0 281 002 531 0 986 284 009
1.9 TDI [1T1]	1,9l	74/77 kW	AVQ; BKC; BLS; BXE 4 Zyl.
Air mass meter, diesel	02.03-11.06		0 281 002 531 0 986 284 009
Boost pressure sensor, Diesel	02.03-11.06		0 281 002 399
1.9 TDI [1T2]	1,9l	66 kW	BXF 4 Zyl.
Air mass meter, diesel	11.06→		0 281 002 531 0 986 284 009
Boost pressure sensor, Diesel	11.06→		0 281 002 399
1.9 TDI [1T2]	1,9l	66 kW	BJX 4 Zyl.
Air mass meter, diesel	11.06→		0 281 002 461 0 986 284 007
1.9 TDI [1T2]	1,9l	77 kW	BLS; BXE 4 Zyl.
Air mass meter, diesel	11.06→		0 281 002 531 0 986 284 009
Boost pressure sensor, Diesel	11.06→		0 281 002 399
2.0 Eco Fuel [1T1]	2,0l	80 kW	BSX 4 Zyl.
Phase sensor	02.06-11.06		0 232 101 031
Speed sensor, ignition/injection	02.06-11.06		0 261 210 199
Knock sensor	02.06-11.06		0 261 231 146
Pressure sensor, intake manifold, gasoline	02.06-11.06		0 261 230 095
2.0 Eco Fuel [1T2]	2,0l	80 kW	BSX 4 Zyl.
Phase sensor	11.06→		0 232 101 031
Speed sensor, ignition/injection	11.06→		0 261 210 199
Knock sensor	11.06→		0 261 231 146
Pressure sensor, intake manifold, gasoline	11.06→		0 261 230 095
2.0 FSI [1T1]	2,0l	110 kW	AXW; BLR; BLX; BLY; BVY 4 Zyl.
Knock sensor	10.03-11.06	OHL	0 261 231 146
Pressure sensor, intake manifold, gasoline	10.03-11.06		0 261 230 031
2.0 FSI [1T1]	2,0l	110 kW	BVZ 4 Zyl.
Knock sensor	11.05-11.06	OHL	0 261 231 146
Pressure sensor, intake manifold, gasoline	11.05-11.06		0 261 230 031

Product



◀ Touran

2.0 FSI [1T2]		2,0l 110 kW BVY; BVZ 4 Zyl.
Knock sensor	11.06→	OHL 0 261 231 146
Pressure sensor, intake manifold, gasoline	11.06→	0 261 230 031
2.0 i		2,0l 85 kW BJZ 4 Zyl.
Phase sensor	11.04→	0 232 101 094
Speed sensor, ignition/injection	11.04→	0 261 210 254
Knock sensor	11.04→	0 261 231 146
Pressure sensor, intake manifold, gasoline	11.04→	0 261 230 095
2.0 TDI [1T1]		2,0l 100/103/125 kW AZV; BKD; BMM; BMN 4 Zyl.
Air mass meter, diesel	02.03-11.06	0 281 002 461 0 986 284 007
Boost pressure sensor, Diesel	02.03-11.06	0 281 002 401
2.0 TDI [1T2]		2,0l 100/103/125 kW AZV; BKD; BMM; BMN 4 Zyl.
Air mass meter, diesel	11.06→	0 281 002 461 0 986 284 007
Boost pressure sensor, Diesel	11.06→	0 281 002 401

Transporter

2.1 Syncro [24, 25]		2,1l 64 kW SR 4 Zyl.
Wheel speed sensor, front	10.86-07.92	LAB 0 265 001 196
		RAB 0 265 001 198
Wheel speed sensor, rear	10.86-07.92	0 265 001 149
2.1 Syncro [24, 25]		2,1l 70/82 kW DJ; MV 4 Zyl.
Air flow sensor, gasoline injection	08.85-07.92	0 280 202 079 0 986 280 011
Wheel speed sensor, front	08.85-07.92	LAB 0 265 001 196
		RAB 0 265 001 198
Wheel speed sensor, rear	08.85-07.92	0 265 001 149

Transporter T3

1.6 D [24, 25]		1,6l 37 kW CS 4 Zyl.
Wheel speed sensor, front	08.85-07.87	0 265 001 149
Wheel speed sensor, rear	08.85-07.87	0 265 001 151
1.6 D Turbo [24, 25]		1,6l 51 kW JX 4 Zyl.
Wheel speed sensor, front	08.85-07.92	0 265 001 149
Wheel speed sensor, rear	08.85-07.92	0 265 001 151
1.6 D Turbo Syncro [24, 25]		1,6l 51 kW JX 4 Zyl.
Wheel speed sensor, front	03.86-07.92	LAB 0 265 001 196
		RAB 0 265 001 198
Wheel speed sensor, rear	03.86-07.92	0 265 001 149
1.7 D [24, 25]		1,7l 42 kW KY 4 Zyl.
Wheel speed sensor, front	10.86-07.92	0 265 001 149
Wheel speed sensor, rear	10.86-07.92	0 265 001 151
1.9 [24, 25]		1,9l 40 kW EY 4 Zyl.
Wheel speed sensor, rear	08.85-05.88	0 265 001 151
1.9 [24, 25]		1,9l 44 kW DF 4 Zyl.
Wheel speed sensor, front	08.85-07.92	0 265 001 149
Wheel speed sensor, rear	08.85-07.92	0 265 001 151
1.9 [24, 25]		1,9l 54 kW SP 4 Zyl.
Wheel speed sensor, rear	08.86-10.88	0 265 001 151
1.9 [24, 25]		1,9l 57 kW DG 4 Zyl.
Wheel speed sensor, front	08.85-07.92	0 265 001 149
Wheel speed sensor, rear	08.85-07.92	0 265 001 151
1.9 Syncro [24, 25]		1,9l 54/57 kW DG; SP 4 Zyl.
Wheel speed sensor, front	08.85-07.92	LAB 0 265 001 196
		RAB 0 265 001 198
Wheel speed sensor, rear	08.85-07.92	0 265 001 149
2.1 [24, 25]		2,1l 64/68/70 kW MV; SR; SS 4 Zyl.
Air flow sensor, gasoline injection	08.85-07.92	0 280 202 079 0 986 280 011
Wheel speed sensor, rear	08.85-07.92	0 265 001 151

Product



2.1 [24, 25]		2,1l 82 kW DJ 4 Zyl.
Air flow sensor, gasoline injection	07.85-07.92	0 280 202 079 0 986 280 011
Wheel speed sensor, front	08.85-07.92	0 265 001 149
Wheel speed sensor, rear	08.85-07.92	0 265 001 151

Transporter T4


1.8 [70]		1,8l 49 kW PD 4 Zyl.	
Duo sensor, acceleration and yaw rate, brake system	12.90-07.92	0 265 005 214	
Wheel speed sensor, front	12.90-07.92	0 265 006 407	
Wheel speed sensor, rear	12.90-07.92	LAB,MVB	0 265 006 508
		MVB,RAB	0 265 006 510
1.9 D [70]		1,9l 45 kW 1X 4 Zyl.	
Duo sensor, acceleration and yaw rate, brake system	09.90-04.97	0 265 005 214	
Wheel speed sensor, front	09.90-04.97	0 265 006 407	
Wheel speed sensor, rear	09.90-04.97	LAB,MVB	0 265 006 508
		MVB,RAB	0 265 006 510
Fg.no. 70..T..200 001→	01.96-04.97	LAB,OB	0 265 006 408
		OB	0 265 006 409
1.9 D Turbo [70]		1,9l 50 kW ABL 4 Zyl.	
Duo sensor, acceleration and yaw rate, brake system	10.92-06.03	0 265 005 214	
Wheel speed sensor, front	10.92-06.03	0 265 006 407	
Wheel speed sensor, rear	10.92-06.03	LAB,MVB	0 265 006 508
		MVB,RAB	0 265 006 510
Fg.no. 70..T..200 001→	01.96-06.03	LAB,OB	0 265 006 408
		OB	0 265 006 409
2.0 [70]		2,0l 62 kW AAC 4 Zyl.	
Duo sensor, acceleration and yaw rate, brake system	09.90-06.03	0 265 005 214	
Wheel speed sensor, front	09.90-06.03	0 265 006 407	
Wheel speed sensor, rear	09.90-06.03	LAB,MVB	0 265 006 508
		MVB,RAB	0 265 006 510
Fg.no. 70..T..200 001→	01.96-06.03	LAB,OB	0 265 006 408
		OB	0 265 006 409
2.4 D [70]		2,4l 55 kW AJA 5 Zyl.	
Duo sensor, acceleration and yaw rate, brake system	05.97-06.03	0 265 005 214	
Wheel speed sensor, front	05.97-06.03	0 265 006 407	
Wheel speed sensor, rear	05.97-06.03	LAB,MVB	0 265 006 508
		LAB,OB	0 265 006 408
		MVB,RAB	0 265 006 510
		OB	0 265 006 409
2.4 D [70]		2,4l 57 kW AAB 5 Zyl.	
Duo sensor, acceleration and yaw rate, brake system	09.90-05.98	0 265 005 214	
Wheel speed sensor, front	09.90-05.98	0 265 006 407	
Wheel speed sensor, rear	09.90-05.98	LAB,MVB	0 265 006 508
		MVB,RAB	0 265 006 510
Fg.no. 70..T..200 001→	01.96-05.98	LAB,OB	0 265 006 408
		OB	0 265 006 409
2.4 D Syncro [7D]		2,4l 57 kW AAB 5 Zyl.	
Duo sensor, acceleration and yaw rate, brake system	11.92-09.98	0 265 005 214	
Wheel speed sensor, front	11.92-09.98	0 265 006 407	
Wheel speed sensor, rear	11.92-09.98	LAB,MVB	0 265 006 508
		MVB,RAB	0 265 006 510
Fg.no. 70..T..200 001→	01.96-09.98	LAB,OB	0 265 006 408
		OB	0 265 006 409



Product			
2.5 [70]	2,5l 81 kW AAF 5 Zyl.		
Duo sensor, acceleration and yaw rate, brake system	11.90-12.93		0 265 005 214
Wheel speed sensor, front	11.90-12.93		0 265 006 407
Wheel speed sensor, rear	11.90-12.93	LAB,MVB	0 265 006 508
		MVB,RAB	0 265 006 510
2.5 [70]	2,5l 81 kW ACU 5 Zyl.		
Knock sensor	01.94-10.96	L30	0 261 231 066
		L34	0 261 231 077
Duo sensor, acceleration and yaw rate, brake system	01.94-10.96		0 265 005 214
Wheel speed sensor, front	01.94-10.96		0 265 006 407
Wheel speed sensor, rear	01.94-10.96	LAB,MVB	0 265 006 508
		MVB,RAB	0 265 006 510
Fg.no. 70..T..200 001→	01.96-10.96	LAB,OB	0 265 006 408
		BB,RAB	0 265 006 409
2.5 [70]	2,5l 81 kW AEN 5 Zyl.		
Duo sensor, acceleration and yaw rate, brake system	09.95-12.95		0 265 005 214
Wheel speed sensor, front	09.95-12.95		0 265 006 407
Wheel speed sensor, rear	09.95-12.95	LAB,MVB	0 265 006 508
		MVB,RAB	0 265 006 510
2.5 [70]	2,5l 81 kW AEU 5 Zyl.		
Duo sensor, acceleration and yaw rate, brake system	08.96-06.03		0 265 005 214
Wheel speed sensor, front	08.96-06.03		0 265 006 407
Wheel speed sensor, rear	08.96-06.03	LAB,MVB	0 265 006 508
		LAB,OB	0 265 006 408
		MVB,RAB	0 265 006 510
		OB,RAB	0 265 006 409
2.5 [70]	2,5l 85 kW AET; APL; AVT 5 Zyl.		
Knock sensor	08.96-06.03	L30	0 261 231 066
		L34	0 261 231 077
Duo sensor, acceleration and yaw rate, brake system	08.96-06.03		0 265 005 214
Wheel speed sensor, front	08.96-06.03		0 265 006 407
Wheel speed sensor, rear	08.96-06.03	LAB,MVB	0 265 006 508
		LAB,OB	0 265 006 408
		MVB,RAB	0 265 006 510
		OB,RAB	0 265 006 409
2.5 Syncro [7D]	2,5l 81 kW AAF 5 Zyl.		
Duo sensor, acceleration and yaw rate, brake system	11.92-12.93		0 265 005 214
Wheel speed sensor, front	11.92-12.93		0 265 006 407
Wheel speed sensor, rear	11.92-12.93	LAB,MVB	0 265 006 508
		MVB,RAB	0 265 006 510
2.5 Syncro [7D]	2,5l 81 kW ACU 5 Zyl.		
Knock sensor	01.94-10.96	L30	0 261 231 066
		L34	0 261 231 077
Duo sensor, acceleration and yaw rate, brake system	01.94-10.96		0 265 005 214
Wheel speed sensor, front	01.94-10.96		0 265 006 407
Wheel speed sensor, rear	01.94-10.96	LAB,MVB	0 265 006 508
		MVB,RAB	0 265 006 510
Fg.no. 70..T..200 001→	01.96-10.96	LAB,OB	0 265 006 408
		BB,RAB	0 265 006 409
2.5 Syncro [7D]	2,5l 81 kW AEU 5 Zyl.		
Duo sensor, acceleration and yaw rate, brake system	06.97-11.01		0 265 005 214
Wheel speed sensor, front	06.97-11.01		0 265 006 407



Wheel speed sensor, rear	06.97-11.01	LAB,MVB	0 265 006 508
		LAB,OB	0 265 006 408
		MVB,RAB	0 265 006 510
		OB,RAB	0 265 006 409
2.5 Syncro [7D]	2,5l 85 kW AET; APL; AVT 5 Zyl.		
Knock sensor	05.96-06.03	L30	0 261 231 066
		L34	0 261 231 077
Duo sensor, acceleration and yaw rate, brake system	05.96-06.03		0 265 005 214
Wheel speed sensor, front	05.96-06.03		0 265 006 407
Wheel speed sensor, rear	05.96-06.03	LAB,MVB	0 265 006 508
		LAB,OB	0 265 006 408
		MVB,RAB	0 265 006 510
		OB,RAB	0 265 006 409
2.5 TDI [70]	2,5l 65 kW AJT 5 Zyl.		
Air mass meter, diesel			
Fg.no. →70..1H048 284,→70..1X047 893	05.98-08.00		0 281 002 216
			0 986 284 001
Fg.no. 70..1H048 285→,70..1X047 894→	09.00-06.03		0 281 002 463
			0 986 284 008
Boost pressure sensor, Diesel			
Fg.no. →70..1..200 000	05.98-04.01		0 281 002 177
Fg.no. 70..1..200 001→	05.01-06.03		0 281 002 399
Pedal position sensor, diesel			
Fg.no. →70..Y..000 940	05.98-05.99	GS	0 205 001 020
Duo sensor, acceleration and yaw rate, brake system	05.98-06.03		0 265 005 214
Wheel speed sensor, front	05.98-06.03		0 265 006 407
Wheel speed sensor, rear	05.98-06.03	LAB,MVB	0 265 006 508
		LAB,OB	0 265 006 408
		MVB,RAB	0 265 006 510
		OB,RAB	0 265 006 409
2.5 TDI [70]	2,5l 65 kW AYY 5 Zyl.		
Air mass meter, diesel	10.01-06.03		0 281 002 463
			0 986 284 008
Boost pressure sensor, Diesel	10.01-06.03		0 281 002 399
Duo sensor, acceleration and yaw rate, brake system	10.01-06.03		0 265 005 214
Wheel speed sensor, front	10.01-06.03		0 265 006 407
Wheel speed sensor, rear	10.01-06.03	LAB,MVB	0 265 006 508
		LAB,OB	0 265 006 408
		MVB,RAB	0 265 006 510
		OB,RAB	0 265 006 409
2.5 TDI [70]	2,5l 75 kW ACV 5 Zyl.		
Air mass meter, diesel			
Fg.no. →70..1H048 284,→70..1X047 893	05.98-08.00		0 281 002 216
			0 986 284 001
Fg.no. 70..1H048 285→,70..1X047 894→	09.00-06.03		0 281 002 463
			0 986 284 008
Boost pressure sensor, Diesel			
Fg.no. →70..1..200 000	01.95-04.01		0 281 002 177
Fg.no. 70..1..200 001→	05.01-06.03		0 281 002 399
Pedal position sensor, diesel			
Fg.no. →70..Y..000 940	01.95-05.99	GS	0 205 001 020
Duo sensor, acceleration and yaw rate, brake system	01.95-06.03		0 265 005 214
Wheel speed sensor, front	01.95-06.03		0 265 006 407
Wheel speed sensor, rear	01.95-06.03	LAB,MVB	0 265 006 508
		MVB,RAB	0 265 006 510
Fg.no. 70..T..200 001→	01.96-06.03	LAB,OB	0 265 006 408
		OB,RAB	0 265 006 409





Product

◀ Transporter T4			
2.5 TDI [70]		2,5l 75 kW AUF 5 Zyl.	
Air mass meter, diesel			
Fg.no. →70..1H048 284, →70..1X047 893	05.99-08.00	0 281 002 216	
		🚗 0 986 284 001	
Fg.no. 70..1H048 285→,70..1X047 894→	09.00-06.03	0 281 002 463	
		🚗 0 986 284 008	
Boost pressure sensor, Diesel			
Fg.no. →70..1..200 000	05.99-04.01	0 281 002 177	
Fg.no. 70..1..200 001→	05.01-06.03	0 281 002 399	
Duo sensor, acceleration and yaw rate, brake system	05.99-06.03	0 265 005 214	
Wheel speed sensor, front	05.99-06.03	0 265 006 407	
Wheel speed sensor, rear	05.99-06.03	LAB,MVB	0 265 006 508
		LAB,OB	0 265 006 408
		MVB,RAB	0 265 006 510
		OB	0 265 006 409
2.5 TDI [70]		2,5l 75 kW AXL 5 Zyl.	
Duo sensor, acceleration and yaw rate, brake system	04.01-06.03	0 265 005 214	
Wheel speed sensor, front	04.01-06.03	0 265 006 407	
Wheel speed sensor, rear	04.01-06.03	LAB,MVB	0 265 006 508
		LAB,OB	0 265 006 408
		MVB,RAB	0 265 006 510
		OB	0 265 006 409
2.5 TDI [70]		2,5l 75 kW AYC 5 Zyl.	
Air mass meter, diesel	04.01-06.03	0 281 002 463	
		🚗 0 986 284 008	
Duo sensor, acceleration and yaw rate, brake system	04.01-06.03	0 265 005 214	
Wheel speed sensor, front	04.01-06.03	0 265 006 407	
Wheel speed sensor, rear	04.01-06.03	LAB,MVB	0 265 006 508
		LAB,OB	0 265 006 408
		MVB,RAB	0 265 006 510
		OB	0 265 006 409
2.5 TDI [70]		2,5l 111 kW AHY 5 Zyl.	
Air mass meter, diesel			
Fg.no. →70..1..001 319	05.98-05.00	0 280 217 529	
		🚗 0 986 280 204	
Fg.no. 70..1..001 320→	06.00-09.00	0 281 002 461	
		🚗 0 986 284 007	
Boost pressure sensor, Diesel	05.98-09.00	0 281 002 177	
Pedal position sensor, diesel			
Fg.no. →70..Y..000 940	05.98-05.99	GS	0 205 001 020
Duo sensor, acceleration and yaw rate, brake system	05.98-09.00	0 265 005 214	
Wheel speed sensor, front	05.98-09.00	0 265 006 407	
Wheel speed sensor, rear	05.98-09.00	LAB,MVB	0 265 006 508
		LAB,OB	0 265 006 408
		MVB,RAB	0 265 006 510
		OB	0 265 006 409
2.5 TDI [70]		2,5l 111 kW AXG 5 Zyl.	
Air mass meter, diesel	09.00-06.03	0 281 002 461	
		🚗 0 986 284 007	
Boost pressure sensor, Diesel			
Fg.no. →70..1..200 000	09.00-04.01	0 281 002 177	
Fg.no. 70..1..200 001→	05.01-06.03	0 281 002 399	
Duo sensor, acceleration and yaw rate, brake system	09.00-06.03	0 265 005 214	
Wheel speed sensor, front	09.00-06.03	0 265 006 407	
Wheel speed sensor, rear	09.00-06.03	LAB,MVB	0 265 006 508
		LAB,OB	0 265 006 408
		MVB,RAB	0 265 006 510
		OB	0 265 006 409

Product

2.5 TDI Syncro [7D]			2,5l 75 kW ACV 5 Zyl.
Air mass meter, diesel			
Fg.no. →70..1H048 284, →70..1X047 893	05.98-08.00		0 281 002 216 🚗 0 986 284 001
Fg.no. 70..1H048 285→,70..1X047 894→	09.00-06.03		0 281 002 463 🚗 0 986 284 008
Boost pressure sensor, Diesel			
Fg.no. →70..1..200 000	03.98-04.01		0 281 002 177
Fg.no. 70..1..200 001→	05.01-06.03		0 281 002 399
Pedal position sensor, diesel			
Fg.no. →70..Y..000 940	03.98-05.99	GS	0 205 001 020
Duo sensor, acceleration and yaw rate, brake system	03.98-06.03		0 265 005 214
Wheel speed sensor, front	03.98-06.03		0 265 006 407
Wheel speed sensor, rear	03.98-06.03	LAB,MVB	0 265 006 508
		LAB,OB	0 265 006 408
		MVB,RAB	0 265 006 510
		OB	0 265 006 409
2.5 TDI Syncro [7D]			2,5l 75 kW AXL 5 Zyl.
Duo sensor, acceleration and yaw rate, brake system	04.01-06.03		0 265 005 214
Wheel speed sensor, front	04.01-06.03		0 265 006 407
Wheel speed sensor, rear	04.01-06.03	LAB,MVB	0 265 006 508
		LAB,OB	0 265 006 408
		MVB,RAB	0 265 006 510
		OB	0 265 006 409
2.8 [70]			2,8l 103 kW AES 6 Zyl.
Air mass meter, gasoline injection	01.96-05.00		0 280 217 512 🚗 0 986 280 203
Phase sensor			
Mot.no. AES 010 241→	12.97-05.00		0 232 103 019
Speed sensor, ignition/injection	01.96-05.00		0 261 210 107
Temperature sensor, intake air, injection system	01.96-05.00		0 280 130 039
Duo sensor, acceleration and yaw rate, brake system	01.96-05.00		0 265 005 214
Wheel speed sensor, front	01.96-05.00		0 265 006 407
Wheel speed sensor, rear	01.96-05.00	LAB,MVB	0 265 006 508
		LAB,OB	0 265 006 408
		MVB,RAB	0 265 006 510
		OB	0 265 006 409
2.8 [70]			2,8l 150 kW AMV 6 Zyl.
Throttle valve assembly	05.00-06.03		0 280 750 086
Air mass meter, gasoline injection	05.00-06.03		0 280 218 017 🚗 0 986 280 208
Phase sensor			
Fg.no. →70..1..001 319	05.00-06.03		0 232 103 019
Duo sensor, acceleration and yaw rate, brake system	05.00-06.03		0 265 005 214
Wheel speed sensor, front	05.00-06.03		0 265 006 407
Wheel speed sensor, rear	05.00-06.03	LAB,MVB	0 265 006 508
		LAB,OB	0 265 006 408
		MVB,RAB	0 265 006 510
		OB	0 265 006 409
Transporter T5			
1.9 TDI [7H]			1,9l 62/63/75/77 kW AXB; AXC; BRR; BRS 4 Zyl.
Air mass meter, diesel	04.03→		0 281 002 531 🚗 0 986 284 009
Boost pressure sensor, Diesel	04.03→		0 281 002 399
1.9 TDI [7J]			1,9l 62/63/75/77 kW AXB; AXC; BRR; BRS 4 Zyl.
Air mass meter, diesel	04.03→		0 281 002 531 🚗 0 986 284 009
Boost pressure sensor, Diesel	04.03→		0 281 002 399



2.0 [7H]		2,0l 85 kW AXA 4 Zyl.
Throttle valve assembly	06.03→	0 280 750 167
Air mass meter, gasoline injection	06.03→	0 280 218 060
		0 986 280 216
Phase sensor	06.03→	0 232 101 031
Knock sensor	06.03→ OHL	0 261 231 146
2.0 [7J]		2,0l 85 kW AXA 4 Zyl.
Throttle valve assembly	06.03→	0 280 750 167
Air mass meter, gasoline injection	06.03→	0 280 218 060
		0 986 280 216
Phase sensor	06.03→	0 232 101 031
Knock sensor	06.03→ OHL	0 261 231 146
2.5 TDI [7H]	2,5l 96/120/128 kW AXD; AXE; BLJ 5 Zyl.	
Air mass meter, diesel	02.03→	0 281 002 461
		0 986 284 007
Boost pressure sensor, Diesel	02.03→	0 281 002 401
2.5 TDI [7J]	2,5l 96 kW AXD 5 Zyl.	
Air mass meter, diesel	04.03→	0 281 002 461
		0 986 284 007
Boost pressure sensor, Diesel	04.03→	0 281 002 401
2.5 TDI [7J]	2,5l 96 kW BNZ 5 Zyl.	
Boost pressure sensor, Diesel	06.06→	0 281 002 401
2.5 TDI [7J]	2,5l 128 kW AXE 5 Zyl.	
Air mass meter, diesel	01.04→	0 281 002 461
		0 986 284 007
Boost pressure sensor, Diesel	01.04→	0 281 002 401
2.5 TDI [7J]	2,5l 128 kW BPC 5 Zyl.	
Boost pressure sensor, Diesel	06.06→	0 281 002 401
2.5 TDI 4 Motion [7H]	2,5l 96/128 kW AXD; AXE 5 Zyl.	
Air mass meter, diesel	07.04→	0 281 002 461
		0 986 284 007
Boost pressure sensor, Diesel	07.04→	0 281 002 401
2.5 TDI 4 Motion [7J]	2,5l 96 kW AXD 5 Zyl.	
Air mass meter, diesel	07.04→	0 281 002 461
		0 986 284 007
Boost pressure sensor, Diesel	07.04→	0 281 002 401
2.5 TDI 4 Motion [7J]	2,5l 96 kW BNZ 5 Zyl.	
Boost pressure sensor, Diesel	06.06→	0 281 002 401
2.5 TDI 4 Motion [7J]	2,5l 128 kW AXE 5 Zyl.	
Air mass meter, diesel	07.04→	0 281 002 461
		0 986 284 007
Boost pressure sensor, Diesel	07.04→	0 281 002 401
2.5 TDI 4 Motion [7J]	2,5l 128 kW BPC 5 Zyl.	
Boost pressure sensor, Diesel	06.06→	0 281 002 401
3.2 [7H]	3,2l 170/173 kW BDL; BKK 6 Zyl.	
Throttle valve assembly	02.03→	0 280 750 086
Air mass meter, gasoline injection	02.03→	0 280 218 073
		0 986 280 222
Phase sensor	02.03→	0 232 103 019
Knock sensor	02.03→ OHL	0 261 231 146
3.2 [7J]	3,2l 170 kW BDL 6 Zyl.	
Throttle valve assembly	02.04→	0 280 750 086
Air mass meter, gasoline injection	02.04→	0 280 218 073
		0 986 280 222
Phase sensor	02.04→	0 232 103 019
Knock sensor	02.04→ OHL	0 261 231 146
3.2 4 Motion [7H]	3,2l 173 kW BKK 6 Zyl.	
Throttle valve assembly	07.04→	0 280 750 086
Air mass meter, gasoline injection	07.04→	0 280 218 073
		0 986 280 222



Phase sensor	07.04→	0 232 103 019
Knock sensor	07.04→ OHL	0 261 231 146
3.2 4 Motion [7J]	3,2l 170 kW BDL 6 Zyl.	
Throttle valve assembly	07.04→	0 280 750 086
Air mass meter, gasoline injection	07.04→	0 280 218 073
		0 986 280 222
Phase sensor	07.04→	0 232 103 019
Knock sensor	07.04→ OHL	0 261 231 146

Vanagon

2.1, Syncro [24-27]	2,1l 70 kW MV 4 Zyl.
Air flow sensor, gasoline injection	08.85-07.92
	0 280 202 079
	0 986 280 011

Vento

1.4 [1H2]	1,4l 44 kW AEX 4 Zyl.
Knock sensor	07.95-12.97 KZA
Pressure sensor, intake manifold, gasoline	07.95-12.97
1.6 [1H2]	1,6l 55 kW AEA; AEE 4 Zyl.
Knock sensor	10.94-12.97 KZA
1.6 [1H2]	1,6l 74 kW AEK 4 Zyl.
Air mass meter, gasoline injection	10.94-12.95
Knock sensor	10.94-12.95
Temperature sensor, intake air, injection system	10.94-12.95
1.6 [1H2]	1,6l 74 kW AFT; AKS 4 Zyl.
Knock sensor	12.95-12.97
Temperature sensor, intake air, injection system	12.95-12.97
1.8 [1H2]	1,8l 55/66 kW AAM; ABS 4 Zyl.
Temperature sensor, coolant, injection system	11.91-12.97
1.9 SDI [1H2]	1,9l 47 kW AEY 4 Zyl.
Pedal position sensor, diesel	01.95-12.97 AG
	GS
1.9 TDI [1H2]	1,9l 66 kW AHU; ALE 4 Zyl.
Pedal position sensor, diesel	08.96-12.97 AG
	GS
1.9 TDI [1H2]	1,9l 66 kW 1Z 4 Zyl.
Pressure sensor, intake manifold, diesel	
Fg.no. →1H..SP078 090, →1H..SK009 001	09.93-07.94
Pedal position sensor, diesel	07.95-07.96 AG
	GS
	09.93-06.95 LLE
	RLE
1.9 TDI [1H2]	1,9l 81 kW AFN 4 Zyl.
Pedal position sensor, diesel	02.96-12.97 AG
	GS
2.0 [1H2]	2,0l 79/85 kW ADY; AEP; AGG; AKR 4 Zyl.
Knock sensor	10.94-12.97 KZA
2.0 [1H2]	2,0l 85 kW 2E 4 Zyl.
Pulse generator, ignition/Jetronic	11.91-09.94
Knock sensor	11.91-09.94 KZA
2.8 [1H2]	2,8l 120 kW AAA 6 Zyl.
Air mass meter, gasoline injection	07.94-04.96
	05.96-12.97
	0 986 280 203
Speed sensor, ignition/injection	07.94-06.95
	07.95-12.97
Knock sensor	07.94-12.97 KZA
	KZW
Temperature sensor, intake air, injection system	07.94-12.97



Product



◀ Vento

2.8 [1H2]	2,8 l 128 kW AAA 6 Zyl.
Air mass meter, gasoline injection	01.92-06.94 0 280 213 021
	 0 986 280 122
	07.94-04.96 0 280 217 504
	05.96-12.97 0 280 217 512
	 0 986 280 203

Product



Speed sensor, ignition/injection	01.92-06.95 0 261 210 080
	07.95-12.97 0 261 210 107
Knock sensor	01.92-12.97 KZA 0 261 231 077
	KZW 0 261 231 047
Temperature sensor, intake air, injection system	01.92-12.97 0 280 130 039

de

Gegenüberstellung

en

Cross-reference

fr

**Table de
correspondance**

it

Comparazione

es

Equivalencias**Benutzerhinweise**

Im nachfolgenden Katalogteil sind Bestellnummern von Herstellern anderer Marken, für die es einbaugleiche Bosch-Erzeugnisse oder -Teile gibt, aufgeführt. Da die verschiedenartigsten Bezeichnungssysteme angewendet werden, konnten die fremden Bestellnummern nur in einer einheitlichen, alphanumerischen Sortierfolge geordnet werden. Sie weicht bei einigen Herstellern von der dort üblichen Sortierfolge ab. Eine Rückumschlüsselung von Bosch- zu Fremdnummern ist nicht zulässig.

Notes for users

The following catalog section lists part numbers of non-Bosch equipment for which there are interchangeable Bosch products or components available. Since a wide range of different designation systems are used, we were forced to arrange the non-Bosch part numbers in a uniform alphanumerical order. This differs from the customary order employed by some manufacturers. Reconversion of Bosch numbers back to the numbers of other manufacturers is not permitted.

**A l'attention
de l'utilisateur**

Cette section du catalogue reprend les références des fabricants d'autres marques pour lesquelles il existe des produits ou des composants Bosch de montage identique. De multiples systèmes de codage étant utilisés, les références des produits d'autres marques ne peuvent être reprises que suivant un classement alphanumérique uniforme. Pour certains fabricants, ce classement peut différer de celui qu'ils utilisent habituellement. La reconversion de références Bosch en références d'autres marques n'est pas autorisée.

**Avvertenze per
la consultazione**

Nella seguente parte del catalogo vengono riportati i numeri di ordinazione di costruttori di prodotti d'altra marca, per i quali sono disponibili prodotti o parti di prodotti Bosch di corrispondente applicazione. Dato che vengono utilizzati i più diversi sistemi di denominazione, si è potuto ordinare i numeri di ordinazione di altra marca solo in una sequenza di classificazione unitaria ed alfanumerica. Per alcune case costruttrici si differenzia perciò dalla sequenza di classificazione normalmente usata. In questo confronto le sigle Bosch vanno considerate come dati indicativi. Non è ammessa una ricodificazione da numeri di ordinazione Bosch a numeri di altra marca.

**Indicaciones
para el usuario**

A continuación se han relacionado números de pedido de fabricantes de otras marcas para los que existen productos o piezas Bosch de iguales características. Dado que se utilizan los más diversos sistemas de designación, los números de pedido ajenos han podido relacionarse tan sólo en un orden unificado, alfanumérico. En el caso de algunos fabricantes, el orden de esta clasificación difiere del que utilizan habitualmente. No es admisible la recodificación de los números de Bosch en números ajenos.

Hinweis

Aus wettbewerbsrechtlichen Gründen dürfen gegenüber Endkunden zur Kennzeichnung von Bosch-Teilen nur die Bosch-Teilenummern verwendet werden.

Note

The laws governing competition stipulate that only Bosch type numbers may be used vis-à-vis the final customer for the identification of Bosch parts.

Remarque


En raison des dispositions légales concernant la concurrence seules les références Bosch peuvent être utilisées vis-à-vis des clients finaux pour l'identification des pièces Bosch.

Avvertenza

Per motivi legati ai diritti che regolano la concorrenza, per l'identificazione dei componenti Bosch destinati all'utente finale, possono essere impiegati solo i codici Bosch.

Nota

Por aspectos legales relativos a la competencia, de cara a los clientes finales únicamente deben utilizarse los números de piezas tipo Bosch para identificar piezas Bosch.




ALFA ROMEO	
112 68 5	0 232 103 052
113 05 05 015 00	0 335 530 031
113 10 11 021 00	0 280 101 001
113 56 05 018 00	0 261 211 003
115 44 05 013 00	0 261 210 001
115 44 05 013 00	0 261 210 002
115 44 05 013 00/00	0 261 210 001
115 44 05 014 00	0 261 230 001
116 00 65 135 24	0 332 204 101
116 08 01 633 00	0 335 541 002
116 10 65 135 07	0 332 014 151
116 10 65 135 14	0 332 204 101
116 46 11 013 00	0 280 202 013
116 46 11 013 00/00	0 280 202 013
116 46 11 022 00	0 280 120 302
116 85 11 013 00	0 280 202 027
116 85 11 013 00	0 986 280 078
116 85 11 022 00	0 280 120 304
116 85 11 043 00	0 280 230 001
116 96 51 350 00	0 332 014 151
119 11 11 010 00	0 280 130 023
119 11 11 013 00	0 280 202 010
119 11 11 043 00	0 332 514 105
119 11 11 043 01	0 332 514 127
119 11 11 043 01/00	0 332 514 121
130 74 33 080	0 204 154 020
131 53 52 080	0 204 154 044
131 53 52 080	0 204 154 045
132 03 27 080	0 265 006 427
132 03 28 080	0 265 006 406
164 00 45 136 00	0 265 001 156
164 00 45 137 00	0 265 001 074
164 00 45 138 00	0 265 001 073
164 20 45 136 01	0 265 001 156
164 20 45 136 02	0 265 001 156
164 76 11 135 00	0 280 230 006
195 00 11 013 00	0 280 202 045
195 00 11 022 00	0 280 120 300
195 05 05 017 00	0 261 231 001
195 05 05 017 01	0 261 231 006
195 05 05 018 00	0 261 211 004
195 05 11 010 00	0 280 130 032
195 05 11 013 00	0 280 202 058
195 05 11 043 00	0 280 230 009
195 26 11 013 00	0 280 202 078
195 32 11 010 00	0 280 130 026
195 32 11 013 01	0 280 202 201
195 32 11 013 01	0 986 280 069
195 32 11 019 00	0 261 210 036
195 36 11 013 02	0 280 202 202
195 36 11 022 00	0 280 120 311
195 46 11 013 00	0 280 202 105
195 50 11 013 00	0 280 202 108

195 50 11 013 00	0 986 280 067
195 63 11 013 00	0 280 202 113
195 64 11 013 00	0 280 203 034
195 70 11 013 00	0 280 202 060
195 70 11 013 00	0 986 280 046
233 59 11	0 265 007 079
464 07 008	0 280 217 111
464 11 675	0 281 002 144
464 16 748	0 280 217 514
464 21 112	0 265 006 238
464 32 103	0 281 002 213
464 33 053	0 281 002 137
464 34 529	0 265 006 164
464 34 53	0 265 006 163
464 37 264	0 281 002 214
464 42 040	0 204 120 946
464 44 280	0 280 752 005
464 44 287	0 280 217 531
464 46 873	0 281 002 214
464 47 503	0 280 218 019
464 47 503	0 986 280 236
464 50 545	0 265 006 325
464 51 1118	0 265 006 212
464 56 661	0 265 006 163
464 56 796	0 205 001 010
464 57 537	0 265 006 164
464 60 544	0 265 006 364
464 60 545	0 265 006 365
464 63 384	0 204 120 987
464 64 9280	0 280 217 102
464 66 175	0 205 003 052
464 68 682	0 281 002 137
464 68 682	0 281 002 215
464 69 867	0 261 231 131
464 69 917	0 280 218 001
464 69 917	0 986 280 234
46472687	0 261 210 163
46473033	0 265 006 540
46473049	0 265 006 539
46474583	0 261 210 161
46474585	0 261 230 035
46475007	0 280 750 013
46477973	0 261 210 167
46478160	0 280 752 004
46481638	0 281 002 210
46481639	0 281 002 214
46481640	0 281 002 213
46512475	0 204 127 122
46512475	0 281 002 203
46519886	0 265 007 039
46519916	0 265 007 036
46519917	0 265 007 037
46520005	0 265 007 038
46522739	0 232 101 037
46522957	0 204 127 379

46522958	0 204 127 353
46525288	0 261 231 144
46530202	0 265 007 043
46530204	0 265 007 045
46531418	0 265 007 072
46531419	0 265 007 070
46532105	0 204 127 412
46533308	0 280 218 004
46533308	0 986 280 235
46533518	0 261 230 030
46539830	0 265 007 034
46539831	0 265 007 035
46539832	0 265 007 032
46539833	0 265 007 033
46540022	0 265 007 050
46540023	0 265 007 049
46540024	0 265 007 055
46540025	0 265 007 054
46541253	0 280 218 019
46541253	0 986 280 236
46542976	0 281 002 260
46542976	0 281 002 405
46544765	0 265 007 075
46544766	0 265 007 076
46545467	0 265 007 051
46545468	0 265 007 053
46545469	0 265 007 052
46546935	0 265 007 044
46547231	0 265 007 024
46547232	0 265 007 025
46547233	0 265 007 026
46547234	0 265 007 027
46550482	0 204 127 413
46550582	0 204 127 413
46553045	0 261 230 030
46559804	0 281 002 309
46559804	0 986 284 113
46736164	0 281 002 380
46736962	0 204 127 463
46737767	0 265 007 063
46737768	0 265 007 064
46737769	0 265 007 065
46737770	0 265 007 066
46750234	0 204 127 480
46752064	0 265 007 072
46761337	0 265 007 098
46761338	0 265 007 099
46770138	0 265 007 093
46770139	0 265 007 091
467831830	0 265 007 102
467831840	0 265 007 103
46806128	0 280 002 474
46808221	0 281 002 533
46808221	0 986 284 114
46823093	0 265 007 486

46823094	0 265 007 487
46823095	0 265 007 488
46838209	0 265 007 126
50011475	0 265 006 164
50011475	0 265 006 537
50011476	0 265 006 163
50011476	0 265 006 538
51493180	0 265 006 325
533 702	0 332 014 151
533 71 10 000 00/00	0 335 530 012
542 645	0 335 530 029
542 64 50 000 00/00	0 335 530 012
549 182	0 280 202 206
549 182	0 986 280 065
55187973	0 232 103 052
59469230	0 280 230 006
59680800	0 280 202 059
59680800	0 986 280 044
59680820	0 280 202 060
59680820	0 986 280 046
60500571	0 280 202 211
60500571	0 986 280 091
6050 05 710	0 280 202 204
6050 05 710	0 986 280 055
605082500	0 265 001 074
605082510	0 265 001 073
605117510	0 265 001 156
60512672	0 280 120 300
60512698	0 261 231 006
6051 320 060	0 986 280 069
6051 32 060	0 280 202 201
6051 32 080	0 261 210 036
6051 33 360	0 280 202 202
6051 33 370	0 280 120 315
6051 81 350	0 280 101 001
6051 86 940	0 261 210 002
6051 86 950	0 261 230 001
6052 28 730	0 280 202 027
6052 28 730	0 986 280 078
6052 28 750	0 280 120 304
6052 28 760	0 280 230 001
6052 33 830	0 280 130 023
6052 33 860	0 280 202 010
6052 33 900	0 332 514 127
60534263	0 261 231 006
60534264	0 261 211 004
6053 43 130	0 280 202 058
60534316	0 280 230 009
6053 47 060	0 280 202 078
6053 48 380	0 280 202 105
6053 49 590	0 280 202 108
6053 49 590	0 986 280 067
6053 78 350	0 280 202 206
6053 78 350	0 986 280 065
60545800	0 265 001 251



◀ BMW

12 11 1 274 666	0 335 541 016
12 11 1 276 100	0 335 541 017
12 11 1 276 212	0 335 541 018
12 11 1 277 125	0 335 541 019
12 11 1 279 527	0 335 530 025

12 11 1 285 090	0 335 530 030
12 11 1 341 030	0 232 101 034
12 11 1 341 030	0 232 101 093
12 11 1 361 879	0 335 541 002
12 11 1 364 299	0 335 541 010

12 11 1 364 301	0 335 541 010
12 11 1 459 028	0 232 101 002
12 11 1 459 033	0 232 101 002
12 11 1 465 063	0 232 101 033
12 11 1 465 077	0 232 101 033

12 11 7 673 277	0 232 101 093
12 12 1 274 644	0 261 210 002
12 12 1 286 148	0 356 914 209
12 12 1 286 149	0 356 914 212
12 12 1 747 630	0 132 009 319

12 12 1 748 081	0 132 009 318
12 14 1 247 993	0 261 231 112
12 14 1 269 286	0 261 210 001
12 14 1 274 644	0 261 210 002
12 14 1 279 734	0 261 231 001

12 14 1 401 187	0 261 231 094
12 14 1 401 237	0 261 231 093
12 14 1 401 238	0 261 231 092
12 14 1 435 502	0 261 231 113
12 14 1 702 163	0 261 231 096

12 14 1 709 316	0 261 231 135
12 14 1 709 317	0 261 231 136
12 14 1 709 317	0 261 231 200
12 14 1 710 519	0 261 210 035
12 14 1 710 699	0 261 210 028

12 14 1 713 007	0 261 210 060
12 14 1 713 583	0 261 210 044
12 14 1 713 584	0 261 210 045
12 14 1 714 763	0 261 210 061
12 14 1 715 028	0 261 210 035

12 14 1 715 030	0 261 210 062
12 14 1 715 711	0 261 210 044
12 14 1 720 096	0 261 210 092
12 14 1 720 105	0 261 210 091
12 14 1 720 517	0 261 231 008

12 14 1 721 504	0 261 210 057
12 14 1 721 705	0 261 210 058
12 14 1 721 861	0 261 210 058
12 14 1 721 968	0 261 210 047
12 14 1 721 968	0 261 210 057

12 14 1 726 063	0 261 210 054
12 14 1 726 519	0 261 210 053
12 14 1 726 590	0 261 210 053
12 14 1 727 511	0 261 210 082
12 14 1 729 599	0 261 210 063

12 14 1 734 580	0 261 231 072
12 14 1 734 581	0 261 231 073
12 14 1 734 817	0 261 210 097
12 14 1 736 303	0 261 231 074
12 14 1 738 667	0 261 231 090

12 14 1 738 667	0 261 231 195
12 14 1 739 368	0 261 231 097
12 14 1 740 959	0 232 103 003
12 14 1 741 131	0 261 231 107
12 14 1 741 648	0 261 231 113

12 14 1 748 082	0 132 010 453
12 14 1 748 400	0 232 103 003
12 14 2 241 236	0 261 210 032
12 14 7 519 647	0 261 231 171
12 14 7 519 648	0 261 231 170

12 52 1 279 695	0 261 210 028
12 62 1 288 158	0 280 130 037
12 62 1 288 158	0 280 130 056
12 62 1 288 158	0 280 130 089
12 63 1 267 456	0 335 530 019

12 63 1 269 668	0 335 530 021
12 63 1 270 914	0 335 530 020
12 63 1 285 090	0 335 530 020
12 72 1 705 724	0 132 009 301
12 72 1 712 009	0 281 002 291

12 72 1 720 418	0 132 009 319
12 72 1 722 013	0 132 009 318
12 72 1 722 520	0 132 009 318
12 72 1 730 478	0 132 009 318
12 72 1 730 907	0 132 009 318

12 72 1 731 965	0 132 009 319
12 72 1 733 022	0 132 009 319
12 72 1 747 630	0 132 009 319
12 72 1 748 081	0 132 009 318
13 26 1 273 239	0 280 202 039

13 26 1 273 239	0 986 280 001
13 51 1 265 317	0 438 120 018
13 51 1 266 341	0 438 120 030
13 51 1 266 342	0 438 120 039
13 51 1 268 548	F 026 TX2 062

13 51 1 268 548	0 438 120 086
13 51 1 270 647	0 438 120 111
13 51 1 271 776	0 438 120 110
13 51 1 274 134	0 438 120 148
13 51 1 274 943	0 438 120 140

13 51 1 278 735	0 438 120 158
13 51 1 460 447	0 280 200 040
13 51 1 460 447	0 986 280 083
13 53 2 247 581	0 281 002 260
13 53 7 500 221	0 261 545 005

13 53 7 781 486	0 281 002 405
13 53 7 781 486	0 281 002 475
13 53 7 787 167	0 281 002 497
13 53 7 788 164	0 281 002 475
13 53 7 794 758	0 281 002 672

13 53 7 798 079	0 281 002 868
13 53 7 800 602	0 281 002 948
13 53 7 801 987	0 281 002 869
13 53 7 94 758	0 281 002 671
13 54 1 710 560	0 280 120 404

13 54 1 717 603	0 280 120 316
13 54 1 725 815	0 205 003 001
13 54 1 733 023	0 205 003 001
13 54 1 736 856	0 205 003 001
13 61 7 788 788	0 281 002 567

13 62 1 268 105	0 280 203 007
13 62 1 268 105	0 280 203 011
13 62 1 268 105	0 986 280 034
13 62 1 269 264	0 280 203 008
13 62 1 269 304	0 280 203 010

13 62 1 271 704	0 280 203 011
13 62 1 271 704	0 986 280 034
13 62 1 272 101	0 280 202 025
13 62 1 272 101	0 986 280 018
13 62 1 273 117	0 280 203 012

13 62 1 273 238	0 280 202 029
13 62 1 273 238	0 986 280 032
13 62 1 273 277	0 280 120 301
13 62 1 274 673	0 280 203 022
13 62 1 274 673	0 986 280 082

13 62 1 274 697	0 280 203 013
13 62 1 276 113	0 280 203 014
13 62 1 276 202	0 280 202 040
13 62 1 277 564	0 280 203 016
13 62 1 277 564	0 986 280 015

13 62 1 279 519	0 280 203 017
13 62 1 279 664	0 280 202 039
13 62 1 279 664	0 986 280 001
13 62 1 279 704	0 280 203 018
13 62 1 279 704	0 986 280 072

13 62 1 284 397	0 280 130 026
13 62 1 284 407	0 280 202 031
13 62 1 284 407	0 986 280 035
13 62 1 285 052	0 280 202 050
13 62 1 285 052	0 986 280 005

13 62 1 286 064	0 280 203 027
13 62 1 286 064	0 986 280 002
13 62 1 286 615	0 280 202 082
13 62 1 286 615	0 986 280 003
13 62 1 286 679	0 280 101 001

13 62 1 287 731	0 261 211 001
13 62 1 307 019	0 280 203 025
13 62 1 307 019	0 986 280 043
13 62 1 307 486	0 280 203 028
13 62 1 307 486	0 986 280 049

13 62 1 311 950	0 280 214 001
13 62 1 311 950	0 986 280 124
13 62 1 315 541	0 280 214 006
13 62 1 316 166	0 280 212 026
13 62 1 316 167	0 280 212 026

13 62 1 341 500	0 280 130 076
13 62 1 341 550	0 280 130 076
13 62 1 353 329	0 280 130 014
13 62 1 353 331	0 280 130 006
13 62 1 357 414	0 280 130 023

13 62 1 358 915	0 280 203 001
13 62 1 359 641	0 280 203 002
13 62 1 359 641	0 986 280 066
13 62 1 362 296	0 280 203 003
13 62 1 362 648	0 280 203 004

13 62 1 362 648	0 986 280 036
13 62 1 403 123	0 280 217 806
13 62 1 407 446	0 280 752 023
13 62 1 432 244	0 280 217 812
13 62 1 433 565	0 280 217 124

13 62 1 433 566	0 280 217 533
13 62 1 433 567	0 280 217 814
13 62 1 438 687	0 280 218 075
13 62 1 465 108	0 280 130 101
13 62 1 702 078	0 280 217 800

13 62 1 705 721	0 280 202 066
13 62 1 705 721	0 986 280 016
13 62 1 707 366	0 280 130 056
13 62 1 709 937	0 280 101 006
13 62 1 709 966	0 280 130 026

13 62 1 710 539	0 280 202 083
13 62 1 710 539	0 986 280 009
13 62 1 710 543	0 280 202 092
13 62 1 710 544	0 280 202 091
13 62 1 710 544	0 986 280 006

13 62 1 710 545	0 280 202 093
13 62 1 710 546	0 280 202 090
13 62 1 710 546	0 986 280 068
13 62 1 711 338	0 280 101 005
13 62 1 711 371	0 280 130 039

13 62 1 714 502	0 280 202 204
13 62 1 714 502	0 986 280 055
13 62 1 714 503	0 280 202 203
13 62 1 714 503	0 280 202 209
13 62 1 715 888	0 280 214 001

13 62 1 715 888	0 986 280 124
13 62 1 716 013	0 132 009 307
13 62 1 718 521	0 280 212 010
13 62 1 718 521	0 986 280 130
13 62 1 718 736	0 280 130 060

13 62 1 718 749	0 132 009 313
13 62 1 722 489	0 280 213 011
13 62 1 722 489	0 986 280 116
13 62 1 730 074	0 280 213 011
13 62 1 730 074	0 986 280 116

13 62 1 733 258	0 280 217 502
13 62 1 733 262	0 280 217 800
13 62 1 733 678	0 280 212 025
13 62 1 733 678	0 986 280 111
13 62 1 734 314	0 280 202 203

13 62 1 734 316	0 280 202 209
13 62 1 734 651	0 280 200 204
13 62 1 734 651	0 986 280 029
13 62 1 734 653	0 280 200 205
13 62 1 734 653	0 986 280 040

13 62 1 734 655	0 280 202 134
13 62 1 734 655	0 986 280 007
13 62 1 734 655	0 986 280 092
13 62 1 734 657	0 280 202 135
13 62 1 734 657	0 986 280 033

13 62 1 736 224	0 280 217 110
13 62 1 738 908	0 280 217 502
13 62 1 747 155	0 280 217 502
13 62 1 747 156	0 280 217 800
13 62 2 228 011	0 280 752 001

13 62 2 240 756	0 132 009 310
13 62 2 241 599	0 281 002 018
13 62 2 242 184	0 280 130 055
13 62 2 242 250	0 132 009 315
13 62 2 242 290	0 132 009 310

13 62 2 242 330	0 132 009 316
13 62 2 243 864	0 281 002 063
13 62 2 244 132	0 205 001 006
13 62 2 245 690	0 205 001 040
13 62 2 247 074	0 928 400 314

13 62 2 247 074	0 928 400 519
13 62 2 247 074	0 928 400 527
13 62 2 306 215	0 280 130 076
13 62 7 501 554	0 280 218 077
13 62 7 502 055	0 280 218 076

13 62 7 524 136	0 280 218 135
13 62 7 527 518	0 986 280 116
13 62 7 527 525	0 986 280 111
13 62 7 531 702	0 280 218 159
13 62 7 533 853	0 280 218 165

13 62 7 535 069	0 261 230 134
13 62 7 537 488	0 280 218 169
13 62 7 539 811	0 261 230 136
13 62 7 540 508	0 261 230 135
13 62 7 542 418	0 280 218 205

13 62 7 542 418	0 280 218 206
13 62 7 547 975	0 280 200 204
13 62 7 547 975	0 986 280 029
13 62 7 547 976	0 280 202 050
13 62 7 547 976	0 986 280 005

13 62 7 547 977	0 280 202 082
13 62 7 547 977	0 986 280 003
13 62 7 547 978	0 280 202 083
13 62 7 547 978	0 986 280 009
13 62 7 547 979	0 986 280 007

13 62 7 547 979	0 986 280 092
13 62 7 547 980	0 280 202 135
13 62 7 547 980	0 986 280 033
13 62 7 547 981	0 280 203 027
13 62 7 547 981	0 986 280 002

13 62 7 547 982	0 280 203 028
13 62 7 547 982	0 986 280 049
13 62 7 548 103	0 280 218 189
13 62 7 548 103	0 280 218 197
13 62 7 552 114	0 261 230 198

13 62 7 552 114	0 261 231 198
13 62 7 558 785	0 986 280 092
13 62 7 566 052	0 232 103 064
13 62 7 566 986	0 280 218 075
13 62 7 566 987	0 280 218 076

13 62 7 566 988	0 280 218 135
13 62 7 566 989	0 280 218 159
13 62 7 566 990	0 280 218 169
13 62 7 568 421	0 261 231 136
13 62 7 568 421	0 261 231 200

13 62 7 570 191	0 232 103 064
13 62 7 787 076	0 928 400 468
13 62 7 787 076	0 928 400 527
13 62 7 788 743	0 281 002 567
13 62 7 788 744	0 928 400 504

13 62 7 788 744	0 928 400 529
13 62 7 790 657	0 281 002 621
13 62 7 791 347	0 281 002 621
13 62 7 793 633	0 281 002 713
13 62 7 801 951	0 281 002 849

13 62 7 805 415	0 281 002 936
13 62 7 830 359	0 280 218 062
13 62 7 833 561	0 261 230 115
13 62 7 839 014	0 280 218 062
13 63 1 272 131	0 332 514 121

13 63 1 273 139	0 332 514 120
13 63 1 273 265	0 280 120 320
13 63 1 273 277	0 280 120 301
13 63 1 274 662	0 335 530 022
13 63 1 276 264	0 280 230 001

13 63 1 352 716	0 280 120 014
13 63 1 358 436	0 280 120 035
13 63 1 358 473	0 280 120 206
13 63 1 360 678	0 280 100 030
13 63 1 460 455	0 280 120 302

13 63 1 461 852	0 280 122 201
13 63 1 707 320	0 280 120 402
13 63 1 708 605	0 280 120 406
13 63 1 710 559	0 280 120 310
13 63 1 714 196	0 280 230 011

13 63 1 720 503	0 280 120 416
13 63 1 720 505	0 280 120 414
13 71 2 247 002	0 928 400 314
13 71 2 247 002	0 928 400 519
13 71 2 247 002	0 928 400 527

13 71 2 247 592	0 928 400 357
13 71 2 247 592	0 928 400 520
1 705 724	0 132 009 308
1 734 314	0 280 200 201
2 241 235	0 261 210 032

32 43 6 762 235	0 265 005 285
32 43 6 774 040	0 265 005 285
34 17 6 990	0 265 005 680
34 50 3 417 699	0 265 005 644
34 51 1 156 396	0 265 005 003

34 51 1 164 213	0 265 005 302
34 51 1 164 245	0 265 005 203
34 51 1 165 467	0 265 005 303
34 52 1 154 043	0 265 001 023
34 52 1 154 044	0 265 001 029

34 52 1 154 045	0 265 001 027
34 52 1 154 046	0 265 001 025
34 52 1 154 064	0 265 001 038
34 52 1 155 037	0 265 001 058
34 52 1 155 037	0 265 001 191

34 52 1 155 038	0 265 001 057
34 52 1 155 041	0 265 001 059
34 52 1 155 505	0 265 001 137
34 52 1 155 506	0 265 001 136
34 52 1 155 645	0 265 001 135

34 52 1 155 645	0 265 001 339
34 52 1 155 709	0 265 001 168
34 52 1 155 710	0 265 001 167
34 52 1 164 018	0 265 005 202
34 52 1 165 292	0 265 005 215

34 52 1 165 292	0 265 005 248
34 52 1 178 788	0 265 001 113
34 52 1 178 981	0 265 001 058
34 52 1 178 982	0 265 001 057
34 52 1 179 762	0 265 001 199

34 52 1 179 830	0 265 001 205
34 52 1 179 981	0 265 001 038
34 52 1 180 228	0 265 001 135
34 52 1 180 228	0 265 001 339
34 52 1 180 649	0 265 001 301

34 52 1 180 651	0 265 001 303
34 52 1 180 652	0 265 001 302
34 52 1 181 490	0 265 001 205
34 52 1 181 491	0 265 001 339
34 52 1 181 808	0 265 001 340

34 52 1 181 839	0 265 001 339
34 52 1 182 333	0 265 001 205
34 52 1 182 335	0 265 001 340
34 52 2 294 362	0 265 001 244
34 52 2 345 844	0 265 007 077

34 52 2 345 845	0 265 007 078
34 52 3 405 906	0 265 007 621
34 52 3 405 907	0 265 007 622
34 52 3 420 330	0 265 007 854
34 52 3 420 331	0 265 007 855

34 52 6 753 694	0 265 005 248
34 52 6 757 406	0 265 005 249
34 52 6 757 406	0 265 005 285
34 52 6 758 289	0 265 007 461
34 52 6 758 290	0 265 007 462

34 52 6 758 290	0 265 007 845
34 52 6 758 750	0 265 005 266
34 52 6 759 886	0 265 007 615
34 52 6 759 887	0 265 007 616
34 52 6 760 045	0 265 007 471

34 52 6 760 046	0 265 007 472
34 52 6 760 047	0 265 007 623
34 52 6 760 533	0 265 007 619
34 52 6 760 534	0 265 007 620
34 52 6 760 534	0 265 007 853

34 52 6 761 650	0 265 007 592
34 52 6 761 651	0 265 007 593
34 52 6 761 651	0 265 007 845
34 52 6 761 800	0 265 007 592
34 52 6 761 801	0 265 007 593

34 52 6 761 801	0 265 007 845
34 52 6 762 733	0 265 007 617
34 52 6 764 858	0 265 007 669
34 52 6 764 859	0 265 007 670
34 52 6 767 578	0 265 007 655

34 52 6 767 578	0 265 007 850
34 52 6 768 578	0 265 005 610
34 52 6 768 680	0 265 005 615
34 52 6 769 535	0 265 005 622
34 52 6 770 137	0 265 005 622

34 52 6 770 137	0 265 005 679
34 52 6 771 700	0 265 007 850
34 52 6 771 701	0 265 007 851
34 52 6 771 702	0 265 007 848
34 52 6 771 703	0 265 007 849


34 52 6 771 704	0 265 007 852
34 52 6 771 705	0 265 007 853
34 52 6 771 708	0 265 007 844
34 52 6 771 709	0 265 007 845
34 52 6 771 710	0 265 007 846

34 52 6 771 711	0 265 007 847
34 52 6 771 712	0 265 007 856
34 52 6 771 713	0 265 007 857
34 52 6 773 019	0 265 007 807
34 52 6 773 020	0 265 007 808

34 52 6 774 039	0 265 005 266
34 52 6 774 435	0 265 005 285
34 52 6 774 602	0 265 005 678
34 52 6 774 602	0 265 005 681
34 52 677 509	0 265 007 960

34 52 677 510	0 265 007 961
34 52 6 777 435	0 265 005 285
34 52 6 779 913	0 265 005 721
34 52 6 779 913	0 265 005 761
34 52 7 651 951	0 265 007 082

34 52 7 651 951	0 265 007 421
34 52 7 657 454	0 265 007 420
34 52 7 657 454	0 265 007 440
34 52 7 657 455	0 265 007 421
34 52 7 665 742	0 265 007 418



34527665743	0265007419
34527687528	0265007684
61121365275	0265001005
61121365276	0265002003
61311267455	0335530018

61 31 1 364 480	0 332 514 105
61 31 1 459 197	0 280 130 032
61 35 7 834 411	0 261 230 127
66 20 6 922 779	0 263 003 244
66 20 6 922 998	0 263 003 244

9 209 9890	0 280 130 121
9 209 9892	0 261 231 163
9 324 3251	0 261 210 150
9 339 0192	0 261 230 116

141 048 21 C	0 265 001 228
141 048 22 C	0 265 001 227
93 211 367	9 280 082 000
93 232 333	9 280 082 001
93 268 054	F 000 DVO 100

93 358 883	0 280 130 107
93 363 378	F 000 DV0 103
93 366 231	F 000 DV0 104
93 395 682	F 000 DV1 057

05033 109 AA	0 281 002 503
05033 109 AB	0 281 002 503
05033 109 AB	0 281 002 571

05293 155 AB	0 281 002 451
4 363 738	0 265 001 159
4 383 800	0 265 001 161
4 383 801	0 265 001 162
4 612 698	0 281 002 132

5 226 504	0 280 130 058
5 226 504	0 280 130 063
53 013 009	0 281 002 279
53 013 009 AA	0 281 002 501
53 013 109 AA	0 281 002 433

A 040 296	0 261 211 003
DX 144 119 A	0 280 100 023
DX 144 224 A	0 280 120 011

V7 535 069	0 261 230 134
V7 540 508	0 261 230 135
V7 552 114	0 261 231 197
V7 552 114	0 261 231 198
0242 46	0 280 130 026

1452 10	0 280 230 010
14 808 450	0 265 006 426
14 808 460 80	0 265 006 388
14 888 410	0 265 007 083
14 916 610	0 265 006 730

14 916 620	0 265 006 731
14 938 820	0 265 007 083
1601 G4	0 280 755 019
1601 G5	0 280 755 039
1601 K7	0 280 752 235

1601 N4	0 280 752 247
1601 N5	0 280 752 241
1601 N6	0 280 752 242
1601 N7	0 280 752 260
1601 N7	0 280 755 029

1601 P5	0 280 755 015
1601 P6	0 280 752 283
1601 P7	0 280 755 016
1601 P8	0 280 755 007
1601 Q0	0 280 755 005

1601 Q4	0 280 755 012
1601 Q5	0 280 755 013
1601 Q6	0 280 755 018
1601 Q8	0 280 755 040
1601 R2	0 280 755 046

1601 T1	0 280 755 074
1601 T2	0 280 755 075
1601 T3	0 280 755 076
1601 T4	0 280 755 077
1601 T6	0 280 755 041

1601 X6	0 280 755 078
1601 X7	0 280 755 079
1601 X7	0 280 755 080
1601 X8	0 280 755 095
1601 X9	0 280 755 097

1621 28	0 261 211 003
1622 C9	0 205 001 015
1625 90	0 280 230 101
1628 A3	0 280 120 310
1628 C5	0 281 002 029

1628 1F	0 280 122 005
1628 27	0 280 120 305
1628 50	0 280 120 301
1628 54	0 281 002 008
1628 8V	0 280 122 009

1920 AC	0 261 230 041
1920 AC	0 261 230 058
1920 AJ	0 261 230 043
1920 AN	0 261 230 057
1920 C5	0 280 130 039

1920 H9	9 465 160 006
1920 KZ	0 261 230 135
1920 K8	0 261 230 004
1920 K8	0 261 230 037
1920 LA	0 261 230 131

1920 PY	0 261 230 156
1920 T7	0 281 002 063
1920 T7	0 281 002 063
1920 Z1	0 281 002 128
1920 OE	0 261 230 012

1920 3L	0 281 002 122
1920 34	0 280 202 051
1920 34	0 986 280 051
1920 46	0 280 202 056
1920 46	0 986 280 028

1920 49	0 280 202 057
1920 50	0 280 101 001
1920 55	0 438 120 200
1920 66	0 280 202 070
1920 68	0 280 202 098

1920 7R	0 281 002 283
1920 7R	0 281 002 592
1920 70	0 280 202 097
1920 70	0 986 280 070
1920 76	0 280 213 006

1920 76	0 986 280 115
1920 80	0 280 202 109
1920 80	0 986 280 013
1920 9H	0 261 230 012
1920 91	0 280 202 602

1920 91	0 986 280 019
1920 93	0 280 202 202
1920 93	0 280 202 210
1920 93	0 986 280 063
1921 01	0 438 120 120

1921 10	0 438 120 099
1921 24	0 438 120 119
1921 33	0 438 120 153
1921 42	0 438 120 161
1921 96	0 438 120 068

1922 R6	0 261 230 134
1929 03	0 132 009 305
1929 03	0 281 002 031
20 100 255	0 263 003 267
20 100 257	0 263 003 266

20 100 258	0 263 003 268
20 100 259	0 263 003 274
20 100 260	0 263 003 271
20 100 261	0 263 003 272
20 100 263	0 263 003 273

20 100 264	0 263 003 263
20 100 265	0 263 003 264
20 100 266	0 263 003 265
20 100 267	0 263 003 269
20 100 758	0 263 003 246

35 429 03	0 263 003 246
4472 80	0 280 750 085
4545 A4	0 265 006 732
4545 A8	0 265 006 793
4545 C2	0 265 007 664

4545 C3	0 265 007 663
4545 C3	0 265 007 780
4545 C4	0 265 007 645
4545 C4	0 265 007 779
4545 C7	0 265 007 665

4545 C8	0 265 007 666
4545 C9	0 265 007 668
4545 E0	0 265 007 667
4545 E1	0 265 007 687
4545 E2	0 265 007 688

4545 E3	0 265 005 486
4545 E5	0 265 007 707
4545 E6	0 265 007 883
4545 E7	0 265 007 788
4545 E8	0 265 007 789

4545 E9	0 265 007 790
4545 F0	0 265 007 791
4545 F6	0 265 008 017
4545 F7	0 265 008 018
4545 F8	0 265 008 018

4545 F9	0 265 005 486
4545 G9	0 265 007 130
4545 H0	0 265 007 131
4545 H7	0 265 008 018
4545 H8	0 265 005 517

4545 04	0 204 154 008
4545 04	0 204 154 008
4545 05	0 204 154 003
4545 05	0 204 154 003
4545 06	0 204 154 002

4545 06	0 204 154 002
4545 09	0 204 154 028
4545 09	0 204 154 028
4545 10	0 204 154 011
4545 10	0 204 154 011

4545 11	0 265 003 064
4545 12	0 265 003 065
4545 13	0 204 154 018
4545 13	0 204 154 018
4545 14	0 204 154 014

4545 14	0 204 154 014
4545 15	0 204 154 007
4545 15	0 204 154 007
4545 16	0 204 154 009
4545 16	0 204 154 009

4545 17	0 204 154 015
4545 17	0 204 154 015
4545 19	0 204 154 013
4545 19	0 204 154 013
4545 21	0 265 003 072

4545 21	0 265 003 126
4545 21	0 265 003 126
4545 21	0 265 006 207
4545 22	0 265 003 073
4545 22	0 265 003 127

4545 22	0 265 006 208
4545 23	0 265 003 080
4545 23	0 265 003 123
4545 23	0 265 006 314
4545 24	0 265 003 081

4545 24	0 265 003 125
4545 25	0 265 005 105
4545 25	0 265 005 111
4545 26	0 204 154 016
4545 26	0 204 154 016

4545 27	0 204 150 083
4545 27	0 204 150 083
4545 27	0 204 154 040
4545 27	0 204 154 040
4545 28	0 265 003 100

4545 28	0 265 003 124
4545 28	0 265 003 124
4545 28	0 265 006 315
4545 29	0 204 154 017
4545 29	0 204 154 017

4545 30	0 204 154 029
4545 30	0 204 154 029
4545 31	0 265 003 099
4545 31	0 265 003 131
4545 31	0 265 006 201

4545 32	0 265 003 130
4545 32	0 265 006 200
4545 33	0 265 003 079
4545 33	0 265 003 129
4545 33	0 265 006 202

4545 34	0 265 003 106
4545 34	0 265 003 106
4545 34	0 265 006 204
4545 35	0 265 003 128
4545 35	0 265 006 199

4545 36	0 265 003 129
4545 36	0 265 006 202
4545 37	0 265 003 123
4545 37	0 265 006 314
4545 38	0 204 154 024

4545 38	0 204 154 024
4545 39	0 204 154 025
4545 39	0 204 154 025
4545 40	0 204 154 020
4545 41	0 204 154 027

4545 41	0 204 154 027
4545 42	0 204 154 026
4545 44	0 265 006 201
4545 44	0 265 006 201
4545 45	0 265 006 200

4545 46	0 265 006 202
4545 47	0 265 006 199
4545 48	0 265 006 205
4545 49	0 265 006 206
4545 50	0 265 006 203

4545 51	0 265 006 204
4545 55	0 265 006 207
4545 56	0 265 006 202
4545 56	0 265 006 208
4545 60	0 265 006 314

4545 60	0 265 006 314
4545 61	0 265 006 315
4545 61	0 265 006 315
4545 62	0 265 006 209
4545 63	0 204 154 038

4545 63	0 204 154 038
4545 66	0 265 006 389
4545 67	0 265 006 388
4545 67	0 265 006 388
4545 68	0 265 006 426

4545 68	0 265 006 426
4545 69	0 265 006 441
4545 69	0 265 006 441
4545 70	0 265 006 427
4545 70	0 265 006 427

4545 71	0 265 006 405
4545 72	0 265 006 406
4545 75	0 265 006 504
4545 78	0 265 006 389
4545 82	0 265 006 544

4545 83	0 265 006 545
4545 84	0 265 005 404
4545 85	0 265 006 659
4545 88	0 265 007 423
4545 89	0 265 007 424

4545 92	0 265 006 730
4545 93	0 265 006 731
4545 94	0 265 007 083
4545 95	0 265 007 084
4549 05	0 265 005 211

4549 05	0 265 005 290
4549 07	0 265 005 253
4549 07	0 265 005 290
4549 16	0 265 005 290
4549 17	0 265 005 606

4549 21	0 265 005 715
4549 26	0 265 005 291
4549 26	0 265 005 714
4549 27	0 265 005 292
4549 28	0 265 005 629


4549 33	0 265 005 629
4549 39	0 265 005 714
4549 41	0 265 005 703
4549 43	0 265 005 724
4574 03	0 261 230 058

4649 28	0 265 005 629
4676 80	0 261 230 043
4679 80	0 261 231 169
5007 99	0 280 122 003
5 412 358	0 280 130 014

5 412 360	0 280 130 006
5 412 361	0 280 120 011
5 412 361	0 280 120 018
5 413 479	0 280 100 036
5 422 133	0 332 003 021

5 429 448	0 280 100 048
5 472 928	0 332 514 103
5 489 066	0 280 202 005
5 500 350	0 280 120 200
5 502 644	0 280 130 023

5918 73	0 281 002 030
5918 79	0 261 210 029
5918 80	0 261 210 043
5918 84	0 261 210 029
5946 03	0 261 231 006



5946 05	0 261 231 007
5946 15	0 261 231 071
5946 17	0 261 231 071
5946 18	0 261 231 070
5946 21	0 261 231 045

6405 C0	1 397 212 000
6405 E8	1 397 212 002
6405 G0	1 397 212 001
6405 G5	1 397 212 006
6405 HK	1 397 212 132

6405 W9	1 397 212 109
6405 Y4	1 397 212 112
6405 Y5	1 397 212 086
6505 Q5	1 397 212 076
6505 Q6	1 397 212 076

72 408 254	0 280 120 400
72 408 654	0 280 122 011
72 408 744	0 280 122 009
72 408 754	0 280 122 010
74 013 460 30	0 280 130 032

91 000 407 80	0 280 202 051
91 000 407 80	0 986 280 051
91 000 409	0 280 230 006
91 000 409 80	0 280 230 006
91 040 296 80	0 261 211 003

91 508 771 80	0 280 230 101
91 508 772 80	0 280 230 100
91 512 716	0 280 230 101
91 512 716 80	0 280 230 101
91 513 886 80	0 280 230 104

91 518 194 80	0 280 202 057
91 519 925	0 280 120 310
91 519 925 80	0 280 120 310
91 520 606 80	0 280 202 075
91 527 047	0 281 002 018

91 537 516	0 281 002 029
9153 751 680	0 281 002 029
91 538 877	0 280 202 097
91 538 877	0 986 280 070
91 539 005 80	0 280 202 098

92 526 538	0 332 014 151
92 526 538 80	0 332 014 151
93 011 154	0 281 002 008
93 327 326	0 265 006 389
95 496 103	0 280 202 047

95 572 333	0 332 514 130
95 598 944	0 280 202 073
95 605 079	0 280 202 061
95 605 079	0 280 202 064
95 605 079	0 986 280 041

95 635 040	0 280 202 100
95 635 043	0 280 202 101
95 635 045	0 280 120 318
95 637 307	0 265 001 157
95 637 307	0 265 001 245

96 039 179	0 280 202 118
96 039 179	0 986 280 057
96 046 811	0 204 154 012
96 056 021	0 280 120 323
96 067 683	0 204 154 010

9608 631 980	0 265 005 105
96 087 509	0 265 003 078
96 087 509	0 265 003 128
96 087 509	0 265 006 199
96 089 629	0 265 003 079

96 105 849	0 265 006 207
96 105 850	0 265 003 073
96 105 850	0 265 006 208
96 105 926	9 456 160 006
96 105 926	9 465 160 006

96 107 893	0 261 230 004
96 109 509	0 281 002 063
96 127 657	0 261 231 071
96 127 657	0 261 231 106
96 127 658	0 261 231 070

96 131 470	0 280 130 084
96 140 648	0 265 003 099
96 140 648	0 265 003 131
96 140 648	0 265 006 201
96 149 640	0 205 001 015

96 181 977	0 265 006 200
96 181 977	0 265 006 201
96 181 978	0 265 003 130
96 181 978	0 265 006 200
96 181 979	0 265 003 130

96 183 217	0 265 006 205
96 183 261	0 265 006 206
96 191 116	0 281 002 063
96 195 593	0 281 002 119
96 195 593	0 281 002 122

96 217 752	0 265 006 200
96 217 753	0 265 006 202
96 217 755	0 265 006 204
96 217 756	0 265 006 203
96 217 759	0 265 006 199

96 252 846	0 265 006 205
96 255 387	0 265 006 315
96 255 404	0 265 006 314
96 272 628	0 265 006 205
96 275 932	0 261 231 128

96 295 910	0 280 750 041
96 297 255	0 265 006 441
96 300 147	0 265 005 404
96 303 414	0 265 005 211
96 303 414	0 265 005 290

96 305 913	1 397 212 002
96 317 068	0 265 006 544
96 317 069	0 265 006 545
96 318 136	0 261 230 057
96 337 132	1 397 212 004

96 343 935	1 397 212 002
96 343 935	1 397 212 006
96 353 847	0 265 007 423
96 353 848	0 265 007 424
96 354 934	0 261 230 058

96 358 840	0 280 750 085
96 365 830	0 261 230 043
96 382 908	0 265 006 659
96 384 235	0 261 231 128
96 386 487	0 265 007 423

96 393 814	0 261 230 043
96 394 188	0 261 230 057
96 394 189	0 261 230 058
96 394 190	0 261 230 057
96 394 191	0 261 230 058

96 411 890	1 397 212 004
96 411 890	1 397 212 039
96 411 890	1 397 212 060
96 415 250	0 265 005 253
96 415 250	0 265 005 290

96 430 590	0 280 752 235
96 430 591	0 280 752 247
96 430 592	0 280 752 236
96 430 732	0 280 752 238
96 430 847	0 280 752 237

96 430 848	0 280 752 248
96 430 934	0 280 752 240
96 431 704	0 265 006 732
96 434 731	0 280 752 243
96 436 596	0 265 007 423

96 436 605	0 265 007 424
96 436 880	0 265 007 424
96 436 977	0 265 007 423
96 440 934	0 280 752 240
96 442 063	0 261 230 085

96 442 066	0 261 230 085
96 449 305	0 280 752 242
96 449 396	0 280 752 241
96 449 667	0 265 007 423
96 449 668	0 265 007 424

96 453 114	0 261 231 169
96 454 477	0 265 005 253
96 454 477	0 265 005 290
96 458 515	0 280 752 235
96 458 522	0 280 752 237

96 461 258	0 265 007 645
96 461 258	0 265 007 779
96 464 045	0 280 755 016
96 466 196	1 397 212 050
96 467 021	0 280 752 251

96 467 555	1 397 212 039
96 468 373	1 397 212 050
96 469 709	0 265 007 668
96 469 711	0 265 007 667
96 469 712	0 265 007 665

96 469 725	0 265 007 666
96 471 352	0 280 752 279
96 475 755	0 280 752 258
96 476 944	1 397 212 060
96 477 813	0 280 752 259

96 477 813	0 280 752 260
96 477 813	0 280 755 029
96 477 814	0 280 752 262
96 477 967	0 280 752 264
96 477 967	0 280 755 028

96 480 873	0 265 006 793
96 488 392	0 280 755 029
96 489 571	0 280 755 006
96 489 571	0 280 755 007
96 494 001	0 265 005 291

96 494 001	0 265 005 714
96 495 100	0 280 750 164
96 49 614 177	0 263 003 476
96 497 761	0 265 005 606
96 498 334	1 397 212 064

96 499 043	0 265 005 292
96 502 357	0 265 005 290
96 502 361	0 265 005 486
96 503 417	0 280 755 012
96 503 418	0 280 755 013

96 504 521	0 265 005 290
96 508 818	0 280 755 000
96 508 818	0 280 755 001
96 508 891	0 280 755 001
96 508 892	0 280 755 018

96 509 352	0 263 003 263
96 511 983	0 280 755 019
96 511 984	0 280 755 039
96 512 701	0 280 755 041
96 515 042	0 280 755 010

96 515 107	0 280 755 004
96 515 107	0 280 755 005
96 515 372	0 280 755 017
96 517 022	1 397 212 073
96 517 023	1 397 212 074

96 518 352	1 397 212 083
96 519 693	0 265 007 707
96 524 902	1 397 212 050
96 524 903	1 397 212 076
96 526 967	0 265 007 664

96 526 969	0 265 007 663
96 526 969	0 265 007 780
96 527 700	0 280 755 015
96 528 436	0 280 752 282
96 528 436	0 280 752 283

96 529 212	0 280 755 030
96 531 052	0 280 755 036
96 531 058	0 280 755 038
96 531 059	0 280 755 032
96 535 678	0 280 755 083

96 536 631	0 265 007 789
96 544 055	0 280 755 040
96 544 061	0 280 755 042
96 544 063	0 280 755 082
96 546 648	1 397 212 050

96 547 253	0 280 755 044
96 547 453	0 280 755 045
96 547 545 80	0 280 755 039
96 548 774	0 280 755 026
96 548 775	0 280 755 027

96 552 700	0 265 007 788
96 554 671	0 280 755 035
96 554 673	0 280 755 037
96 555 024	0 280 755 031
96 555 025	0 280 755 033

96 570 548	1 397 212 083
96 571 232	0 265 005 629
96 573 958	0 280 755 046
96 573 958 VV	0 280 755 046
96 573 958 77	0 280 755 046

96 575 584	1 397 212 109
96 578 716	1 397 212 108
96 578 717	1 397 212 106
96 578 723	1 397 212 107
96 583 737	1 397 212 105

96 583 825	1 397 212 113
96 584 207	0 265 007 645
96 584 207	0 265 007 779
96 585 998	0 265 007 883
96 586 439	0 280 755 075

96 586 529	0 280 755 079
96 588 691	1 397 212 112
96 588 692	1 397 212 086
96 594 498	0 280 755 074
96 594 499	0 280 755 078

96 594 854	1 397 212 116
96 594 857	1 397 212 117
96 600 591	1 397 212 118
96 600 591	1 397 212 124
96 600 592	1 397 212 119

96 600 652	1 397 212 118
96 605 913	1 397 212 002
96 803 275	1 397 212 124
96 803 276	1 397 212 125
96 807 568	0 280 755 084

9999 163 554	0 280 230 006

DACIA	
60 00 581 611	0 280 130 107
60 00 581 616	0 261 210 152
60 01 538 842	0 280 130 107

82 00 195 825	0 265 007 596
82 00 254 687	0 265 007 583
82 00 254 688	0 265 007 582

DAEWOO	
949530 /065559	0 261 210 153
96205922	0 265 006 414
96205924	0 265 006 415

96253827	0 265 006 404
96283017	0 265 006 593
96283018	0 265 006 594
96283019	0 265 006 595
96283020	0 265 006 596

96549712	0 265 006 752
96549713	0 265 006 751

DAF	
1261071	0 281 002 256
1292636	0 280 122 001
1315657	0 281 002 258


1315659	0 280 130 039
1326649	0 281 002 257
1339008	0 281 002 301
1339009	0 281 002 302
1365737	0 281 002 409


1365738	0 281 002 408
1398467	0 281 002 511
1398468	0 281 002 316
1408346	0 281 002 472
1426321	0 281 002 412

1607435	0 281 002 675
1607436	0 281 002 676
1697325	0 281 002 655
1698686	0 281 002 316
233066	0 331 101 001

269783	0 335 530 011
291696	0 335 530 017
292959	0 335 530 016
532114	0 331 101 002
693056	0 331 100 023

DAIHATSU	
89420 97209 000	0 261 230 044
89420 97209 000	0 261 230 088
89420 97209 000	0 261 230 089





FERRARI	
000237886	0 280 218 224
110355	0 332 204 101
114291	0 335 322 003
118789	0 280 230 007
121517	0 280 120 310
121720	0 280 130 032
121738	0 280 101 001
124717	0 280 230 006
125769	0 280 130 026
126058	0 265 001 092
126059	0 265 001 093
126112	0 265 001 090
126113	0 265 001 091
128019	0 280 120 314
130395	0 280 120 302
130974	0 280 120 311
130975	0 261 210 029
131403	0 280 120 312
134808	0 280 101 003
136374	0 280 212 018
137266	0 232 101 006
137823	0 280 120 315
138403	0 280 213 023
142434	0 280 122 001
146 233	0 232 101 016
146312	0 232 101 006
150866	0 232 103 006
152262	0 261 210 106
154916	0 280 213 012
154916	0 986 280 110
158170	0 280 122 004
159266	0 265 006 116
159267	0 265 006 117
162397	0 280 217 800
162419	0 280 130 039
162530	0 280 217 521
162916	0 261 210 126
163145	0 265 006 252
163146	0 265 006 253
164082	0 261 210 152
164 937	0 261 210 182
170038	0 280 752 028
170592	0 265 006 429
170593	0 265 006 430
171707	0 280 218 012
171716	0 280 750 038
172750	0 280 122 005
172750	0 280 130 026
172771	0 261 231 145
177672	0 261 231 145
177673	0 232 103 026
179137	0 261 230 015
180045	0 280 218 084

180137	0 281 002 170
181120	0 280 218 085
181809	0 261 231 158
182194	0 261 210 198
182266	0 261 231 159
187739	0 261 231 166
187740	0 261 231 167
188171	0 265 005 241
188171	0 265 005 248
188171	0 265 005 428
188172	0 265 005 241
188172	0 265 005 428
189394	0 265 005 418
189540	0 261 210 237
190276	0 261 230 015
190405	0 265 005 411
196819	0 280 752 285
196899	0 280 752 284
205297	0 280 752 284
206070	0 265 005 616
217446	0 261 231 211
217453	0 261 231 212
363802105	0 265 006 213
383700102	0 280 752 005
40 13 01 06	0 332 204 101
60 68 49 44	1 397 212 011
61 76 63 00	0 280 230 012
62 37 06 00	0 280 230 009
94002644	0 265 005 411
94002648	0 265 005 241
FIAT	
100496101	0 281 002 456
112685	0 232 103 052
112685	0 281 002 844
1307433080	0 204 154 020
1307437080	0 204 154 026
1307438080	0 204 154 027
1315352080	0 204 154 044
1315353080	0 204 154 045
1320327080	0 265 006 427
1320328080	0 265 006 406
1320329080	0 265 006 405
13243690	0 281 002 184
1324369080	0 281 002 184
1324369080	0 986 284 112
133732208	0 281 002 565
1349820080	0 280 755 049
1350038080	0 280 755 050
1471884080	0 204 154 024
1472087080	0 204 154 025
1480845080	0 265 006 426
1480846080	0 265 006 388
1482480080	0 265 006 504
1493882080	0 265 007 083

1493883080	0 265 007 084
2335911	0 265 007 079
3547833	0 280 217 005
42357800	0 280 202 018
4339372	0 332 014 151
4383066	0 332 015 011
4393598	0 280 120 215
4393601	0 280 130 023
4420994	0 332 514 105
4421251	0 280 202 017
4429201	0 280 202 019
4429207	0 280 200 024
4429207	0 280 200 034
4429207	0 986 280 075
4430292	0 280 202 012
4430294	0 280 120 300
4430298	0 332 514 121
4430298	0 332 514 127
46125769	0 280 130 026
46130395	0 280 120 302
46132195	0 438 121 066
46137823	0 280 120 315
46401855	0 265 005 030
46401856	0 265 005 030
46401856	0 265 005 031
46404401	0 265 006 210
46404402	0 265 006 211
46406454	0 261 210 117
46407008	0 280 217 111
46411135	0 261 210 129
46411427	0 261 210 127
46411675	0 281 002 144
46416748	0 280 217 514
46419399	0 261 210 130
464211118	0 265 006 212
46421112	0 265 006 238
46421118	0 265 003 074
46421118	0 265 006 212
46421122	0 265 006 138
46422412	0 265 006 197
46426391	0 265 006 346
46427958	0 265 006 262
46432103	0 281 002 213
46433052	0 280 130 039
46433053	0 281 002 122
46433053	0 281 002 137
46433054	0 261 230 009
46434529	0 265 006 164
4643453	0 265 006 163
46434532	0 265 006 166
46437264	0 281 002 214
46441787	0 281 002 160
46442040	0 204 120 946
46444280	0 280 752 004
46444280	0 280 752 005

46444287	0 280 217 531
46444287	0 986 280 233
464457881	0 265 006 347
46446873	0 281 002 159
46446873	0 281 002 214
46447503	0 280 218 019
46447503	0 986 280 236
46447508	0 281 002 199
46450545	0 265 006 325
46456661	0 265 006 163
46456796	0 205 001 010
46457537	0 265 006 164
46457881	0 265 006 347
46460544	0 265 006 364
46460545	0 265 006 365
46463384	0 204 120 987
46464928	0 280 217 102
46466175	0 205 003 052
46467348	0 265 006 124
46468682	0 281 002 137
46468682	0 281 002 215
46469784	0 265 006 249
46469866	0 261 210 160
46469867	0 261 231 131
46469867	0 261 231 148
46469917	0 280 218 001
46469917	0 986 280 234
46470477	0 261 210 160
46472179	0 281 002 209
46472180	0 281 002 203
46472182	0 281 002 199
46472687	0 261 210 160
46472687	0 261 210 163
46473033	0 265 006 539
46473033	0 265 006 540
46473049	0 265 006 539
46473049	0 265 006 540
46474583	0 261 210 161
46474585	0 261 230 035
46475007	0 280 750 013
46475007	3 437 010 459
46477973	0 261 210 167
46478160	0 280 752 004
46481638	0 281 002 210
46481639	0 281 002 214
46481640	0 281 002 213
46512475	0 204 127 122
46512475	0 281 002 203
46519886	0 265 007 039
46519916	0 265 007 036
46519917	0 265 007 037
46520005	0 265 007 038
46522739	0 232 101 037
46522957	0 204 127 379
46522958	0 204 127 353

46525288	0 261 231 144
46530202	0 265 007 043
46530204	0 265 007 045
46531417	0 265 007 071
46531418	0 265 007 072

46531419	0 265 007 070
46531420	0 265 007 069
46532105	0 204 127 412
46533308	0 280 218 004
46533308	0 986 280 235

46533515	0 280 750 042
46533518	0 261 230 030
46539830	0 265 007 034
46539831	0 265 007 035
46539832	0 265 007 032

46539833	0 265 007 033
46540022	0 265 007 050
46540023	0 265 007 049
46540024	0 265 007 055
46540025	0 265 007 054

46541253	0 280 218 019
46541253	0 986 280 236
46542976	0 281 002 260
46542976	0 281 002 405
46544765	0 265 007 075

46544766	0 265 007 076
46545467	0 265 007 051
46545468	0 265 007 053
46545469	0 265 007 052
46546238	0 281 002 386

46546935	0 265 007 044
46547231	0 265 007 024
46547232	0 265 007 025
46547233	0 265 007 026
46547234	0 265 007 027

46550482	0 204 127 413
46550582	0 204 127 413
46552950	0 232 103 035
465529510	0 261 231 148
46553045	0 261 230 030

46557523	0 265 005 225
46557523	0 265 005 241
46557523	0 265 005 277
46557534	0 265 007 086
46557535	0 265 007 085

46557536	0 265 007 089
46557537	0 265 007 089
46559804	0 281 002 309
46559804	0 986 284 113
4655982	0 281 002 308

4655982	0 986 284 117
46559828	0 986 284 117
46736164	0 281 002 380
46736962	0 204 127 463
46737767	0 265 007 063

46737768	0 265 007 064
46737769	0 265 007 065
46737770	0 265 007 066
46739156	0 265 007 059
46739157	0 265 007 061

46743211	0 261 545 010
46745961	0 281 002 320
46749246	0 280 218 054
46749246	0 986 280 238
46750234	0 204 127 480

46750422	F 009 D00 252
46752063	0 265 007 071
46752064	0 265 007 072
46753680	0 265 005 418
467545380	0 261 210 219

467545390	0 261 210 219
46755863	0 281 002 380
46761337	0 265 007 098
46761338	0 265 007 099
46763852	0 265 007 073

46763853	0 265 007 074
46766873	0 281 002 379
46769978	0 261 230 042
46769979	0 261 230 052
46770138	0 265 007 093

46770139	0 265 007 091
46772456	0 265 007 101
46772459	0 265 007 100
46772460	0 265 007 101
46776188	0 265 006 673

46778586	0 281 002 415
46778965	0 265 005 428
46779078	0 280 752 227
46779352	0 261 210 220
46779638	0 281 002 405

467831830	0 265 007 102
467831840	0 265 007 103
46784470	0 265 007 400
46784471	0 265 007 401
46784582	0 281 002 613

46784582	0 986 284 116
467860490	0 232 103 039
46788928	0 265 007 059
46796114	0 265 007 061
46798352	0 281 002 603

46798363	0 261 210 227
46798367	0 232 103 046
46798368	0 232 103 048
46798369	0 232 103 046
46798480	0 281 002 386

46800065	F 009 D00 255
46803379	0 265 005 241
46803400	0 280 752 231
46804400	0 280 752 231
46806128	0 280 002 474

468061280	0 281 002 474
46808221	0 281 002 533
46808221	0 986 284 114
46808734	0 261 210 203
46809773	0 265 006 689

46809774	0 265 006 688
46809930	0 280 752 277
46810176	F 009 D00 258
46810176	0 204 127 462
46811121	0 232 103 043

46811121	0 232 103 048
46811122	0 280 218 120
46811122	0 986 280 240
46811123	0 232 103 024
46811235	0 281 002 160

46811235	0 281 002 510
46811312	0 280 218 113
46811312	0 986 280 239
46812910	0 281 002 534
4681516	0 261 210 238

46816928	0 265 007 401
46816929	0 265 007 400
46823093	0 265 007 486
46823093	0 265 007 487
46823094	0 265 007 486

46823094	0 265 007 487
46823095	0 265 007 488
46824377	0 281 002 598
46824377	0 986 284 115
46825442	0 281 002 506

46826211	0 265 007 113
46826474	0 265 007 111
46826474	0 265 007 112
46826475	0 265 007 111
46826475	0 265 007 112

468278580	1 397 212 047
46828247	0 265 007 640
46828247	0 265 008 006
46831064	0 265 005 277
46837685	0 265 007 518

46837686	0 265 007 610
46837687	0 265 007 519
46837688	0 265 007 520
46837689	0 265 007 611
46837690	0 265 007 521

46838209	0 265 007 126
46838609	0 265 007 543
46838609	0 265 007 551
46838609	0 265 007 563
46838610	0 265 007 550

46839673	0 265 007 544
46839673	0 265 008 007
46840338	0 265 001 195
46842227	0 265 007 542
46842228	0 265 007 543

46844825	0 265 007 564
46844826	0 265 007 565
46844827	0 265 007 566
46844828	0 265 007 567
46845597	0 265 007 485

46846931	0 265 007 510
46846932	0 265 007 511
46846933	0 265 007 512
46846934	0 265 007 513
47752064	0 265 007 072

4897501	0 281 002 398
50010522	0 265 006 402
50010523	0 265 006 403
50011475	0 265 006 164
50011475	0 265 006 537

50011476	0 265 006 163
50011476	0 265 006 538
500372234	0 281 002 405
500374763	0 281 002 513
50093165	0 265 001 336

504048261	0 281 002 667
504081877	0 281 002 733
504245257	0 281 002 845
504247741	0 281 002 903
50504914	0 280 755 051

50504914	0 280 755 053
50505939	0 280 752 228
50510340	0 265 008 218
506812	0 265 005 411
51493180	0 265 006 325


51702279	0 265 007 503
51702279	0 265 008 049
51702646	0 265 007 636
51705195	0 265 007 561
51705196	0 265 007 560

51705197	0 265 007 563
51705198	0 265 007 562
51706546	0 265 007 126
51713211	0 265 007 449
51713211	0 265 008 005

51715557	0 280 752 250
51718056	0 265 007 448
51725099	0 265 007 685
51725100	0 265 007 686
51727705	0 265 007 129

51732518	0 265 007 629
51737851	0 265 007 611
51737851	0 265 007 831
51737852	0 265 007 521
51739391	0 265 007 774

51739392	0 265 007 773
51742256	0 265 007 678
51743697	0 265 007 771
51743697	0 265 007 772
51743698	0 265 007 771



FIAT

517436980	0 265 007 772
51745715	0 265 007 639
51746232	0 265 005 616
51748608	0 265 007 691
51753528	0 265 007 711

51759243	0 265 007 678
51759244	0 265 007 629
51759509	0 265 007 830
51761978	0 265 007 795
51761985	0 265 007 796

51764254	0 265 007 833
51768620	0 265 007 678
51770449	0 265 007 969
51774023	0 281 002 369
51774531	0 281 002 613

51774531	0 986 284 116
51775574	0 281 002 325
51775576	0 281 002 369
51780555	0 280 755 053
51782033	0 281 002 861

51782034	0 281 002 980
51782035	0 281 002 860
51782787	0 265 007 833
51783168	0 280 752 295
51785640	0 280 755 052

51785683	0 280 752 232
51785804	0 281 002 506
51787268	0 265 008 035
51787753	0 265 007 686
51787753	0 265 007 980

51791153	0 265 008 005
51791154	0 265 008 006
51791156	0 265 007 544
51791156	0 265 008 007
51792165	0 265 008 002

51792166	0 265 008 003
51792707	0 281 002 963
51796983	0 265 007 134
51796984	0 265 007 132
51797783	0 261 230 173

51797945	0 265 008 049
51799347	0 265 008 055
51799348	0 265 008 056
51801310	0 265 007 833
51808334	0 265 008 288

51812551	0 265 008 188
51989980	0 265 007 135
55183650	0 281 002 792
55183650	0 281 002 793
55183651	0 281 002 618

55184544	0 281 002 777
55184549	0 281 002 617
55186669	0 261 231 176
55187316	0 280 750 137
55187332	0 261 210 266

55187718	0 281 002 549
55187722	0 280 218 164
55187722	0 986 280 241
55187820	0 261 231 173
55187973	0 232 103 052

55189517	0 261 210 114
55190587	0 281 002 763
551905870	0 281 002 764
55190763	0 281 002 568
55192238	0 261 545 011

55193048	0 281 002 309
55193048	0 986 284 113
55193049	0 280 218 054
55193049	0 986 280 238
55194195	0 280 120 015

55194788	0 281 002 784
551947880	0 281 002 716
55195077	0 281 002 568
55195077	0 281 002 734
55195078	0 281 002 706

551963850	0 280 218 182
55198717	0 281 002 770
55198717	0 281 002 771
55200301	0 281 002 783
55200301	0 281 002 784

55206757	0 281 002 980
552067590	0 281 002 917
55206796	0 281 002 844
55206797	0 281 002 845
55216291	0 281 006 004

553500480	0 281 002 618
55700425	0 265 007 671
55700426	0 265 007 769
55701387	0 265 007 768
557019510	0 265 005 607

55703974	0 265 007 896
55775576	0 281 002 369
5893108	0 280 202 602
5893108	0 986 280 019
5893599	0 280 200 602

5894034	0 280 202 601
5894034	0 986 280 076
5920385	0 280 202 023
5920385	0 986 280 017
5920388	0 280 200 024

5920388	0 986 280 075
5929385	0 280 202 023
5929385	0 986 280 017
5945040	0 280 202 038
5946923	0 280 230 006

5968080	0 280 202 059
5968080	0 986 280 044
59680802	0 280 202 059
59680802	0 986 280 044
5968082	0 280 202 060

5968082	0 986 280 046
5972332	0 280 130 026
5991955	0 280 120 311
5991956	0 280 120 312
5997041	0 280 101 001

5999235	0 280 230 114
60472180	0 281 002 320
60500571	0 280 202 204
60500571	0 280 202 211
60500571	0 986 280 055

60500571	0 986 280 091
60507061	0 332 204 101
6050825	0 265 001 074
60508251	0 265 001 073
60511751	0 265 001 156

60512672	0 280 120 300
60512698	0 261 231 006
60513205	0 280 130 026
60513206	0 280 202 201
60513206	0 986 280 069

60513208	0 261 210 036
60513336	0 280 202 202
60513336	0 280 202 210
60513336	0 986 280 063
60513337	0 280 120 315

60513747	0 280 120 435
60513882	0 280 203 026
60513882	0 986 280 042
605138820	0 280 203 026
605138820	0 986 280 042

60518135	0 280 101 001
60518377	0 261 211 003
60518694	0 261 210 001
60518695	0 261 230 001
60522010	0 280 202 013

60522875	0 280 120 304
60522876	0 280 230 001
60523383	0 280 130 023
60523386	0 280 202 010
60523390	0 332 514 127

60534263	0 261 231 006
60534264	0 261 211 004
60534312	0 280 130 032
60534313	0 280 202 058
60534316	0 280 230 009

60534706	0 280 202 078
60534838	0 280 202 105
60534959	0 280 202 108
60534959	0 986 280 067
60535033	0 280 202 113

60537835	0 280 202 206
60537835	0 986 280 065
60545849	0 265 001 250
6054585	0 265 001 251
60547113	0 280 202 205

60548743	0 261 231 007
60549359	0 280 122 001
60550042	0 280 203 035
60555613	0 261 220 001
60555613	0 261 220 002

60557363	0 265 003 061
60557409	0 265 003 062
60558015	0 265 001 268
60559269	0 265 003 066
60559406	0 265 001 267

60560715	0 261 210 047
60565464	0 265 003 101
60565464	0 265 006 119
60565479	0 265 003 102
60565479	0 265 006 118

60565836	0 356 914 213
60565836	0 356 914 224
60565837	0 280 203 034
60569060	0 261 210 096
60569704	0 280 202 208

60569704	0 280 202 213
60569704	0 986 280 024
60569704	0 986 280 025
60572382	0 280 202 207
60573739	0 261 210 090

60574615	0 280 130 039
60576483	0 265 005 109
60577321	0 265 003 096
60577321	0 265 006 162
6057940	0 280 202 207


6057940	0 280 202 212
6057940	0 986 280 081
60579846	0 280 203 034
60586655	0 232 103 009
60588375	0 265 001 355

60588419	0 280 217 106
60589472	0 280 217 503
60591616	0 281 002 085
60591909	0 280 130 073
60592752	0 261 231 007

60592752	0 261 231 095
60593506	0 205 001 009
6059481	0 205 001 009
60595754	0 261 210 113
60599278	0 265 005 110

60601097	0 265 006 118
60601098	0 265 006 119
60601099	0 265 006 120
6060217	0 280 203 026
6060217	0 986 280 042

60602177	0 280 203 026
60602177	0 986 280 042
60605410	0 232 103 010
60615270	0 265 006 162
60615953	0 265 006 260




60615954	0 265 006 261
60622632	0 265 006 325
60622633	0 265 006 326
60628356	0 281 002 202
60629558	0 204 127 126
60630438	0 204 127 273
60630466	0 204 127 127
60652012	0 265 007 016
60652013	0 265 007 017
60652016	0 265 007 018
60652439	0 280 750 012
60652439	0 280 750 023
60652443	0 280 750 011
60652776	0 265 007 021
60652777	0 265 007 022
60652874	0 265 007 020
60654043	0 280 750 053
60654043	0 280 750 073
60654314	0 280 750 012
60654900	0 204 127 376
60654900	0 281 002 203
60654946	0 280 750 073
60656290	0 265 007 040
60656291	0 265 007 041
60656301	0 265 007 042
60657874	0 280 750 023
60659263	0 265 007 046
60659264	0 265 007 047
60659265	0 265 007 018
60659265	0 265 007 048
60659531	0 204 127 456
60660039	1 397 212 011
60660054	0 280 750 053
60661479	0 204 127 462
60662165	0 204 127 377
60662823	0 261 231 152
60662824	0 261 231 153
60662825	0 232 103 024
60662826	0 261 210 203
60663029	0 280 218 036
60663029	0 986 280 237
60665711	0 280 752 224
60671190	0 280 750 121
60675805	F 009 D00 257
60679537	0 280 752 249
60684944	1 397 212 011
60699853	0 265 005 499
60700045	0 280 202 045
60722873	0 280 202 027
60722873	0 986 280 078
60755045	0 280 200 601
60755045	0 986 280 061
60755046	0 280 200 001
60755046	0 280 200 002
60800132	0 280 230 006

60800163	0 280 202 060
60800163	0 986 280 046
60800167	0 280 130 026
60800522	0 280 130 032
60802028	0 280 218 113
60802028	0 986 280 239
60802037	0 986 284 115
60805107	0 280 202 060
60805107	0 986 280 046
60805373	0 280 101 001
60806252	0 265 003 074
60806252	0 265 006 212
60806254	0 265 003 063
60806254	0 265 006 197
60807526	0 265 001 301
60808142	0 280 130 026
60808397	0 265 003 075
60808904	0 261 210 096
60808986	0 261 210 090
6080915	0 280 202 212
6080915	0 986 280 081
60809658	0 280 202 211
60809658	0 986 280 091
60810394	0 265 005 030
60810394	0 265 005 031
60810692	0 261 210 113
60810695	0 232 103 009
60810774	0 265 003 096
60810774	0 265 006 162
60810791	0 261 231 095
60810813	0 280 217 111
60811021	0 281 002 085
60811201	0 232 101 026
6081145	0 280 217 514
6081220	0 280 130 055
6081224	0 280 130 055
60812394	0 265 006 212
60812395	0 265 006 162
60812644	0 265 006 197
60813773	0 265 006 238
60814589	0 261 210 160
60814715	0 281 002 209
60814769	0 281 002 214
60814770	0 281 002 213
60814852	0 280 218 019
60814852	0 986 280 236
60815022	0 281 002 202
60815340	0 205 003 052
60815463	0 204 127 122
60815616	0 280 217 531
60815616	0 986 280 233
60815816	0 204 127 462
60816027	0 265 007 073
60816028	0 265 007 074
60816137	0 281 002 309

60816137	0 986 284 113
60816293	0 280 217 531
60816293	0 986 280 233
6081644	0 281 002 308
6081644	0 986 284 117
60816448	0 986 284 117
60816463	0 204 127 480
60816553	0 281 002 474
60816693	0 280 218 054
60816693	0 986 280 238
60816746	0 261 210 203
7084986	0 261 230 030
71713685	F 00C 1G6 969
71715149	3 437 010 452
71719014	0 265 006 197
71728869	0 265 005 428
71730275	0 265 005 303
717359980	0 281 002 184
71738374	3 437 010 459
71738437	3 437 010 460
71749476	0 281 006 004
71787951	0 986 280 239
71787955	0 986 284 117
71787959	0 986 280 238
71787967	0 986 284 113
71787996	0 986 284 115
71788000	0 986 280 233
71788004	0 986 280 236
71788020	0 986 280 234
71788023	0 986 280 235
71788026	0 986 280 237
71788032	0 986 284 112
71788038	0 986 284 114
71788047	0 986 280 240
71788050	0 986 284 116
71788743	0 986 280 241
71788746	0 986 284 113
71789488	0 986 284 116
73502778	0 281 002 617
73503657	0 281 002 437
735036570	0 281 002 437
7354478650	0 263 003 645
7354478660	0 263 003 646
7354478670	0 263 003 647
7354478680	0 263 003 648
7354478690	0 263 003 649
7354478700	0 263 003 650
7354478710	0 263 003 651
7354478720	0 263 003 652
7354478730	0 263 003 653
7354478740	0 263 003 654
7354478750	0 263 003 655
7354478760	0 263 003 656
7354478770	0 263 003 657
7354481400	0 263 003 677

740134603	0 280 130 032
75204203	0 331 101 004
7529274	0 261 230 004
7540622	0 280 120 314
7546795	0 280 200 046
7553412	0 280 202 081
7555126	0 280 202 102
7555126	0 986 280 054
7555127	0 280 202 103
7555128	0 280 200 051
7576067	0 280 230 009
7597692	0 280 120 323
7612317	0 280 202 114
7612317	0 986 280 080
7612319	0 280 202 115
7612320	0 280 213 006
7612320	0 986 280 115
7616269	0 261 210 029
7628059	0 280 230 009
7629856	0 280 101 003
7630317	0 265 001 215
7630318	0 265 001 216
7630319	0 265 001 217
7636642	0 280 120 328
7637025	0 280 122 001
7640095	0 280 120 307
7644804	0 280 120 307
7647004	0 280 130 032
7647004	0 280 130 069
7648065	0 280 213 025
7648065	0 986 280 114
7648113	0 280 120 313
7651951	0 265 007 082
7651951	0 265 007 421
7668164	0 280 202 204
7668164	0 280 202 211
7668164	0 986 280 055
7668164	0 986 280 091
76691230	0 261 231 007
7669143	0 280 130 066
7686033	0 280 202 060
7686033	0 986 280 046
7686599	0 280 130 060
7690200	0 280 200 055
7693640	0 280 202 013
7693640	0 280 202 103
7694623	0 280 120 331
7706073	0 280 202 128
7706577	0 280 120 328
7706578	0 280 120 314
7706579	0 280 120 307
7706580	0 280 120 300
77065804	0 280 120 300
7706581	0 280 120 331
7706582	0 280 120 323



FIAT

77065830	0 280 120 313
7706584	0 280 120 312
7706585	0 280 120 311
7709815	0 232 102 004
77118780	0 280 212 024

77118780	0 986 280 123
7712078	0 265 001 338
7717686	0 280 230 005
7718934	0 265 001 337
7718935	0 265 001 336

7721274	0 281 002 089
7721274	0 281 002 093
7724096	0 281 002 088
7724097	0 205 001 010
7731633	0 261 210 098

77362294	0 281 002 412
77363439	1 287 213 612
77364543	F 01C 600 085
7738223	0 280 130 055
7739430	0 261 210 093

7739431	0 232 101 018
7746949	0 261 210 100
7750753	0 280 230 014
7750754	0 280 230 018
7756924	0 261 210 103

7756925	0 261 210 102
7757923	0 281 002 087
77579230	0 281 002 087
7763718	0 280 217 106
7763719	0 280 130 073

7764102	0 265 003 109
7764102	0 265 006 402
7765599	0 261 231 102
7766248	0 265 006 140
7766249	0 265 006 139

77662510	0 281 002 102
7766252	0 261 210 104
7767750	0 281 002 185
7770239	0 280 130 107
77773440	0 232 101 026

7779229	0 280 122 005
77825160	0 265 001 387
7787256	0 261 210 124
77872560	0 261 210 124
7788905	0 281 002 108

7790917	0 261 210 119
77942200	0 265 006 161
7798691	0 261 210 114
7799032	0 261 210 118
7799033	0 261 210 115

8133931	0 265 008 037
82277331	0 280 100 024
82277332	0 280 121 001
82277333	0 280 130 006
82277334	0 280 130 014

82277344	0 332 003 023
82281564	0 280 120 031
82308690	0 280 120 213
82348191	0 280 202 014
82357799	0 280 202 015

82357800	0 280 202 018
82365378	0 332 514 121
82369630	0 335 530 023
82390387	0 280 202 015
82401252	0 265 001 073

82406063	0 265 001 072
82407679	0 265 001 074
82434700	0 265 005 017
82434700	0 265 005 030
8243566	0 265 001 248

82435661	0 265 001 249
82435662	0 265 001 246
82435663	0 265 001 247
82442723	0 265 001 209
824451370	0 265 001 210

82448464	0 265 001 304
82450141	0 265 005 014
82450141	0 265 005 031
82455274	0 265 001 261
82458587	0 265 003 074

82458587	0 265 006 212
82458588	0 265 003 063
82458954	0 265 003 071
82458954	0 265 006 262
82458956	0 265 003 075

8246063	0 265 001 072
82467204	0 265 003 075
82472241	0 265 001 216
82472242	0 265 001 217
82472243	0 265 003 063

82472243	0 265 006 197
82485111	0 265 003 121
82485111	0 265 006 238
82485174	0 265 006 160
82485175	0 265 006 300

9009423	0 331 101 001
92308690	0 280 120 213
960389388	0 280 122 001
9610592680	9 456 160 006
9617220680	0 280 122 003

9618261580	0 261 230 012
9621334480	0 261 231 109
9628648280	0 261 231 130
9631813680	0 261 230 057
9633310080	0 281 002 283

9639418880	0 261 230 057
9645447780	0 265 005 211
9645447780	0 265 005 290
9650452180	0 265 005 290
9923794	0 331 101 003

9927593	0 331 101 004
9934319	0 331 101 008
9944334	0 332 014 411
99455420	0 281 002 170
9946862	0 280 122 001

FORD	
AUC 2C190 A	0 265 006 543
AU2 2C204 A	0 265 006 627
AU2 2C205 A	0 265 006 626

A95GX 13K236 MA	0 263 003 004
A95VWX 13K236 EA	0 263 009 016
A95VWX 13K236 FA	0 263 009 017
BAT 6S701 A	0 261 230 029
BA 12A699 A	0 261 231 045

BA 9F479 A	0 261 230 098
BG5X 10884 AA	0 281 002 471
BG5X 6C315 AA	0 281 002 411
BG5X 6C315 BA	0 281 002 410
BG5X 9D290 AA	0 281 002 316

BG5X 9F479 AA	0 281 002 398
BG6X 9F479 CA	0 281 002 851
EA 12A648 A	0 280 130 049
ED E5EF 12B529 BA	0 280 202 121
ED E5EF 12B529 BA	0 986 280 039

EL 2C204 A	0 265 006 230
ERR 7354	0 261 210 158
ER 2C190 A	0 265 006 484
ER 2C190 A	0 265 006 485
ER 2C190 C	0 265 006 485

ER 2C204 A	0 265 006 482
ER 2C205 A	0 265 006 481
ER 6B288 1	0 261 210 168
E3GF 12B529 B1	0 280 200 037
E3SF 12B529 AA	0 280 202 042

E3SF 12B529 BA	0 280 202 055
E42X 12B529 AA	0 280 203 024
E5EF 12B529 BA	0 280 202 072
E5ZF 121B529 AA	0 280 202 071
E7SF 12B529 AA	0 280 203 030

E7SF 12B529 AA	0 280 203 031
E9EF 12B529 AA	0 280 202 122
E9EF 12B529 AA	0 986 280 039
F3XY 2C204 BA	0 265 006 560
F4ZZ 2C190 BB	0 265 006 431

F4ZZ 2C190 CB	0 265 006 432
F5RZ 2C190 A	0 204 154 021
F5RZ 2C190 A	0 204 154 032
F6DZ 2C190 B	0 265 006 150
F6RZ 2C182 AA	0 204 154 030

F6RZ 2C182 BA	0 204 154 021
F6RZ 2C182 BA	0 204 154 032
F7DZ 2C190 AA	0 265 006 149
F7DZ 2C190 CB	0 265 006 159
F7DZ 2C216 BB	0 265 006 158

F7RZ 2C190 BA	0 204 154 036
F7RZ 2C204 AA	0 204 154 035
F7ZZ 2C204 AB	0 265 006 287
F7ZZ 2C205 AB	0 265 006 286
F77F 12A669 BB	0 261 231 119

F77F 12A699 AB	0 261 231 114
F77F 12A699 BA	0 261 231 114
F77F 12A699 BA	0 261 231 119
F77F 12A699 BC	0 261 231 119
F8DZ 2C204 AA	0 265 006 147

H81AG 9P843 AA	0 438 120 174
M9100391	0 261 230 146
M9100473	0 261 230 132
M9100487	0 261 230 172
NSC 500 600	0 261 231 185

NSC 500600	0 261 231 186
SR0 500140	0 265 005 654
VP1S7W 2B372 AD	0 265 007 879
VP6CZU 12B579 AA	0 280 218 144
V1C15 2B372 AA	0 265 007 125

V1C15 2B372 AB	0 265 007 125
V83AB 12B532 AA	0 280 230 103
V83AB 9P841 AA	0 438 120 199
V83AB 9P916 AA	0 438 120 174
V85AB 9P704 AA	0 280 230 006

V85SF 12A648 AA	0 280 130 037
V85SF 12B527 AA	0 280 120 302
V86AB 12A648 AA	0 280 130 049
V90SF 12A697 AA	0 280 130 067
V97GB 12B579 AA	0 281 002 164


V97GB 9F479 AB	0 281 002 122
WR2A 2C190 AA	0 265 006 484
WR2A 2C190 AC	0 265 006 484
WR2A 2C190 CB	0 265 006 485
WR2A 2C204 AD	0 265 006 482


WR2A 2C204/5 AA	0 265 006 481
WR2A 2C205 AD	0 265 006 481
WR2A 2C2190 A	0 265 006 483
WR2A 2C2190 AA	0 265 006 483
WR2A 6B288 AA	0 261 210 168

WR2A 9H535 AA	F 005 T00 001
WR2A 9H535 AA	F 005 T00 002
XBZF 9F479 AA	0 261 230 060
XB2F 9F479 AA	0 261 230 059
XE 12A646 A	0 280 230 006

XF1Z 2C204 BB	0 265 006 148
XF 12B529 A	0 280 202 077
XF3F 12A699 AA	0 261 231 139
XF5Z 2C190 AB	0 265 006 454
XF5Z 2C204 AC	0 265 006 456

XF5Z 2C204 AD	0 265 006 457
XF5Z 2C216 AB	0 265 006 455
XL3F 12A699 AA	0 261 231 137
XL3F 12A699 BA	0 261 231 138
XL 3F 12A699 CA	0 261 231 143





XR33 2C218 AA	0 265 006 433
XS6F 9F479 AA	0 261 230 027
XS6F 9F479 AA	0 261 230 028
XS6F 9F479 AB	0 261 230 027
XS6F 9F479 AB	0 261 230 028

XW4H 17D547 AB	1 397 212 003
XW4H 17D547 AC	1 397 212 003
XW4T 17D547 AC	1 397 212 003
XW4T 17D547 A1	1 397 212 003
X230 00004 XX	0 265 005 236

YC15 2B352 BA	0 265 006 460
YC15 2B372 AB	0 265 006 458
YC15 2B372 AC	0 265 006 458
YC15 2B372 AD	0 265 006 458
YC15 2B372 AE	0 265 006 458

YC15 2B372 AF	0 265 006 458
YC15 2B372 BA	0 265 004 460
YC15 2B372 BA	0 265 006 460
YC15 2B372 BB	0 265 006 460
YC15 2B372 BC	0 265 006 811

YC15 2B372 CA	0 265 006 461
YC15 2B372 CB	0 265 006 812
YC15 2B372 DA	0 265 006 464
YC15 2B372 DB	0 265 006 464
YC15 2B372 DC	0 265 006 813

YC15 2B372 EA	0 265 006 465
YC15 2B372 EB	0 265 006 465
YC15 2B372 EC	0 265 006 814
YC15 2B372 FA	0 265 006 725
YF1Z 2C190 AB	0 265 006 505

YF1Z 2C190 BB	0 265 006 506
YM21 12B529 AB	0 280 218 061
YM21 12B529 BA	0 280 218 018
YR23 2C190 AA	0 265 006 543
YR23 2C190 AC	0 265 006 543

YS6G 12A366 AA	0 261 210 031
YS6G 12A699 AA	0 261 231 151
YS6G 12B579 AA	0 280 218 050
YS6G 12K073 AA	0 232 103 021
YS6G 12K073 AA	0 232 103 031

YS6G 2C444 AB	0 261 230 055
YS6G 2C444 AB	0 261 230 056
YS6G 6C315 AA	0 261 210 097
YS6G 9E296 AA	0 280 750 072
YS6G 9E926 AA	0 280 750 071

YS6G 9E926 AA	0 280 750 072
YS6G 9F472 BA	0 261 545 002
YS6G 9F832 BB	0 280 752 030
YS6G 9F832 BC	0 280 752 030
YW4T 17D547 AA	1 397 212 003

053 906301 1	0 280 202 126
053 906301 4	0 280 202 136
091 003 AA00	0 265 006 798
091 004 AA00	0 265 006 801
091 005 AA00	0 265 006 799

094 003 AA00	0 265 006 697
1C15 2B372 AA	0 265 006 541
1C15 2B372 AB	0 265 006 541
1C15 2B372 AC	0 265 006 815
1C15 2B372 BA	0 265 006 542

1C15 2B372 BB	0 265 006 816
1C15 2B372 CA	0 265 006 687
1C15 2B372 CB	0 265 006 687
1C15 2B372 CC	0 265 006 817
1C15 2B372 CD	0 265 006 817

1C15 2B372 DA	0 265 006 686
1C15 2B372 DB	0 265 006 818
1C15 2B372 DC	0 265 006 818
1F1Z 2C190 AB	0 265 006 649
1F1Z 2C190 BB	0 265 006 651

1F1Z 2C190 CB	0 265 006 648
1F1Z 2C190 DB	0 265 006 650
1F1Z 2C204 AB	0 265 006 646
1F1Z 2C204 BB	0 265 006 647
1L2A 12A699 AA	0 261 231 154

1R1E 9E926 AA	0 280 750 156
1R23 2C204 AA	0 265 006 627
1R23 2C205 AA	0 265 006 626
1S7A 9F479 AB	0 261 230 044
1S7A 9F479 AB	0 261 230 045

1S7A 9F479 AC	0 261 230 044
1S7A 9F479 AC	0 261 230 045
1S7T 14B296 AB	0 265 005 236
1S7T 14B296 AC	0 265 005 236
1S7T 14B296 AC	0 265 005 414

1S7T 14B296 AD	0 265 005 236
1S7T 2B372 AB	0 265 007 087
1S7T 2B372 AB	0 265 007 417
1S7T 2B372 AC	0 265 007 087
1S7T 2B372 AC	0 265 007 879

1S7T 2B372 AD	0 265 007 879
1S7T 2M118 AA	0 265 005 303
1S7T 3F818 AA	0 265 005 414
1S7T 3F818 AC	0 265 005 414
1S7T 3F818 AD	0 265 005 414

1S71 14B286 AC	0 265 005 236
1U1L 9E979 BA	0 280 750 138
1U1L 9E979 CA	0 280 750 140
1W1Z 2C190 AB	0 265 006 600
1X43 2B372 AB	0 265 007 404

1X43 2B372 AB	0 265 007 417
1X43 2B372 AC	0 265 007 404
1X43 2B372 AD	0 265 007 404
1X43 2B372 AE	0 265 007 404
1X43 2B372 AF	0 265 007 404

1X43 2B372 AG	0 265 007 404
1X43 2B372 BB	0 265 007 417
1X43 2B372 BC	0 265 007 417
1X43 2B372 BD	0 265 007 417
1X43 2B372 BF	0 265 007 417

1X43 2B372 BG	0 265 007 417
1003 759	0 280 217 512
1012 021	0 204 154 030
1012 022	0 204 154 021
1012 022	0 204 154 032

1017 547	0 204 154 022
1023 255	0 263 009 016
1025 012	0 204 154 035
1025 014	0 204 154 036
1028 457	0 204 154 031

1036 449	0 204 154 039
1041 355	0 281 002 122
1041 359	0 281 002 164
1051 396	0 280 217 121
1051 396	0 281 002 757

1051 396	0 986 280 202
1054 014	0 261 231 124
1087 424	0 261 230 027
1087 424	0 261 230 028
1115 018	0 265 007 087

1115 528	0 265 005 236
1117 731	0 265 005 414
1118 425	0 265 005 414
1119 026	0 265 005 303
1119 939	0 261 230 044

1119 939	0 261 230 045
1128 924	0 265 005 236
1144 400	0 261 231 162
1144 924	0 265 007 125
1146 400	0 265 007 087

1209 109	0 281 002 461
1209 109	0 281 002 462
1222 569	0 261 210 221
1222 569	0 261 210 222
1222 677	0 232 103 040

1222 677	0 232 103 041
1223 521	0 280 218 104
1223 521	0 280 218 105
1223 690	0 261 230 068
1223 690	0 261 230 069

1223 701	0 280 750 110
1223 701	0 280 750 111
1225 306	0 261 545 006
1319 158	0 232 103 052
1319 158	0 232 103 053

1319 285	0 261 230 122
1319 285	0 261 230 180
1320 734	0 261 231 160
1320 734	0 261 231 161
1321 042	0 280 750 110

1338 678	0 261 230 119
1338 678	0 261 230 120
1346 641	0 265 005 617
1346 641	0 265 005 639
1367 813	0 261 230 090

1367 827	0 280 218 134
1372 511	0 261 230 131
1372 511	0 261 230 132
1379 704	0 261 230 105
1379 704	0 261 230 106

1384 275	0 280 217 121
1384 275	0 281 002 757
1384 275	0 986 280 202
1385 800	0 265 007 817
1386 268	0 265 007 879

1428 448	0 280 217 121
1428 448	0 281 002 757
1428 448	0 986 280 202
1439 251	0 261 230 122
1439 251	0 261 230 123

1439 251	0 261 230 180
1439 900	0 261 230 044
1439 900	0 261 230 045
1440 437	0 261 230 171
1440 437	0 261 230 172

1446 702	0 261 230 180
1446 702	0 261 230 181
1478 729	0 261 230 068
1478 729	0 261 230 069
1478 730	0 261 545 006

1485 435	0 265 005 722
1503 280	0 261 230 225
1604 628	0 335 530 024
1613 116	0 438 120 174
1626 473	0 280 130 037

1626 474	0 280 120 302
1639 020	0 280 130 049
2C46 12A697 AA	0 281 002 576
2C46 6C315 AA	0 281 002 660
2C46 9T305 AA	0 281 002 704

2M5T 17D547 A	1 397 212 020
2M5T 17D547 AA	1 397 212 020
2S61 12A699 AA	0 262 231 162
2S61 12A699 AB	0 261 231 161
2S61 12A699 AB	0 261 231 162

2S7A 12B579 CA	0 280 218 104
2S7A 12B579 CA	0 280 218 105
2S7A 2C444 AA	0 261 230 083
2S7A 2C444 AA	0 261 230 084
2S7G 12A699 AB	0 261 231 161

2S7G 12A699 AC	0 261 231 161
2S7G 12A699 AD	0 261 231 160
2S7G 12A699 AD	0 261 231 161
2S7G 12K073 AA	0 232 103 040
2S7G 12K073 AA	0 232 103 041

2S7G 6C315 AC	0 261 210 221
2S7G 6C315 AC	0 261 210 222
2S7G 9E926 AB	0 280 750 110
2S7G 9E926 AB	0 280 750 111
2S7G 9E926 AC	0 280 750 110


◀ FORD

2S7G 9E926 AC	0 280 750 111
2S7G 9F479 AA	0 261 230 068
2S7G 9F479 AA	0 261 230 069
2S7G 9F479 AB	0 261 230 068
2S7G 9F479 AB	0 261 230 069
2S7G 9F972 AC	0 261 545 006
2S7G 9F972 AC	0 261 545 007
2S7G 9F972 AD	0 261 545 006
2S7G 9F972 AD	0 261 545 007
2U1L 9F479 AA	0 261 230 099
2U1L 9F479 AA	0 261 230 100
27 906301	0 280 202 140
3C11 2B372 AA	0 265 006 784
3C11 2B372 AB	0 265 006 784
3C11 2B372 AC	0 265 006 784
3F2E 9G756 AA	0 261 230 093
3F2E 9G756 AA	0 261 230 094
3F2E 9G756 AD	0 261 230 093
3F2E 9G756 AD	0 261 230 094
3F2E 9G756 AD	0 261 230 097
3F2E 9G756 DA	0 261 230 094
3M21 12B529 AA	0 281 002 461
3M21 12B529 AA	0 281 002 462
3R23 12A699 AB	0 261 231 045
3R23 2C204 AB	0 265 006 821
3R23 2C205 AB	0 265 006 822
3R23 9F479 AA	0 261 230 097
3R23 9F479 AA	0 261 230 098
3R23 9U434 AA	0 261 230 029
3R3Z 2C190 BA	0 265 006 534
3R3Z 2C190 CA	0 265 006 535
3S7T 17D547 AA	1 397 212 021
3S7T 17D547 AB	1 397 212 021
3W1T 17D547 AC	1 397 212 033
3W1Z 2C190 AB	0 265 006 660
3W4T 17D547 AA	1 397 212 054
3 027 144	0 261 231 143
305 906 059 1	0 280 230 016
325 927807 3	0 265 006 220
325 927807 4	0 265 006 219
34906161	0 280 130 053
377 927807	0 265 006 218
3 943 759	0 261 231 119
3 991 033	0 261 231 138
4F13 2C190 AA	0 265 007 589
4F13 2C190 BA	0 265 007 591
4F13 2C216 BA	0 265 007 590
4L3A 12A699 AA	0 261 231 183
4M5G 12K073 AA	0 232 103 052
4M5G 12K073 AA	0 232 103 053
4M51 9F479 AA	0 261 230 119
4M51 9F479 AA	0 261 230 120
4N11 12B579 AA	0 280 218 137
4N11 12B579 AA	0 280 218 138
4S4G 9F472 AA	0 261 230 122

4S4G 9F472 AA	0 261 230 123
4S4G 9F472 AA	0 261 230 180
4S4G 9F479 AA	0 261 230 122
4S4G 9F479 AA	0 261 230 123
4S4G 9F479 AA	0 261 230 180
4S4G 9F479 AB	0 261 230 122
4S4G 9F479 AB	0 261 230 123
4S4G 9F479 AB	0 261 230 180
4S4G 9F479 AC	0 261 230 180
4S4G 9F479 AC	0 261 230 181
4S7T 14B296 AA	0 265 005 617
4S7T 14B296 AA	0 265 005 639
4 041 998	0 265 006 541
4 041 999	0 265 006 542
4 042 001	0 265 006 458
4 042 002	0 265 004 460
4042004	0 265 006 461
4 053 304	0 265 006 464
4 053 305	0 265 006 465
4 095 197	0 265 006 686
4 099 156	0 265 006 458
4 099 157	0 265 006 460
4 109 876	0 265 006 687
4 131 399	0 265 006 541
4 131 400	0 265 006 687
4 446 245	0 265 006 458
4 476 762	0 261 231 183
4 490 313	0 261 230 093
4 522 490	0 265 006 811
4 522 491	0 265 006 812
4 533 632	0 265 006 814
4 533 633	0 265 006 813
4 537 234	0 265 006 815
4 537 235	0 265 006 816
4 537 236	0 265 006 817
4 537 237	0 265 006 818
4 537 240	0 265 006 784
4 540 494	0 265 006 458
4 577 323	0 265 006 817
4 583 026	0 265 006 818
5M5T 17D547 JRA	1 397 212 110
5M5T 17D547 JRB	1 397 212 110
5 167 503	0 281 002 104
6C11 2B372 AA	0 265 007 816
6C11 2B372 AB	0 265 007 816
6C11 2B372 BB	0 265 007 818
6C11 2B372 BC	0 265 007 818
6C11 2B372 BD	0 265 007 818
6C11 2B372 CB	0 265 007 817
6C11 2B372 CC	0 265 007 817
6C11 2B372 CD	0 265 007 817
6C11 3C190 AA	0 265 005 626
6C11 3C190 AB	0 265 005 626
6C11 3C190 AB	0 265 005 690
6C11 9F479 AA	0 261 230 131

6C11 9F479 AA	0 261 230 132
6C11 9F479 AB	0 261 230 225
6G9N 12B676 AA	0 261 230 105
6G9N 12B676 AA	0 261 230 106
6G9N 17D547 AA	1 397 212 104
6G9N 17D547 AB	1 397 212 104
6G9N 17D547 AC	1 397 212 103
6G9N 17D547 AC	1 397 212 104
6G9N 17D547 AD	1 397 212 103
6G9N 9G760 AA	0 280 218 134
6M5Y 9F479 AA	0 261 230 090
6M5Y 9F479 AA	0 261 230 091
6X43 14B296 AA	0 265 005 653
6X71 9F479 AA	0 261 230 171
6X71 9F479 AA	0 261 230 172
6 118 548	0 438 120 069
6 127 294	0 280 200 044
6 127 295	0 280 202 063
6 127 295	0 986 280 031
6 136 431	0 261 220 001
6 140 070	0 280 230 113
6 140 071	0 280 230 109
6 140 460	0 438 120 199
6 142 551	0 280 200 047
6 142 551	0 986 280 056
6 142 552	0 986 280 056
6 152 883	0 261 231 001
6 152 883	0 261 231 006
6 153 146	0 280 130 050
6 156 847	F 026 TX2 066
6 156 847	0 438 121 055
6 158 434	0 335 530 033
6 160 234	0 280 202 094
6 169 571	0 261 231 006
6 173 066	0 280 230 116
6 177 822	0 280 230 117
618 2129	0 280 230 118
7 045 374	0 204 154 021
7 045 374	0 204 154 032
7 045 375	0 204 154 023
7 701 966	0 265 006 482
78GG 13K082 CA	0 335 530 024
8A0 143 71Y	0 204 154 035
8A0 243 71Y	0 204 154 036
8A6T 17D547 AA	1 397 212 142
8C11 3C190 AA	0 265 005 722
8X23 14B296 AB	0 265 005 704
80TF 9C968 CA	0 438 120 069
80TF 9P916 AA	0 438 120 069
81AB 9L463 BA	0 335 530 024
81DB 15K235 RA	0 332 204 101
82AB 9L463 BA	0 335 530 027
83AB 12B528 AB	0 280 230 113
83BB 12B528 AB	0 280 230 109
83DA 12B529 AA	0 280 202 048

83SF 9P916 AA	0 438 120 199
84DA 9H535 AA	0 280 202 077
84DA 9H535 AA	0 986 280 023
85BB 9L463 AA	0 335 530 033
85GB 12B529 AA	0 280 200 044
85GB 12B529 BA	0 280 202 063
85GB 12B529 BA	0 986 280 031
86AB 12A648 AA	0 280 130 050
86AB 12A697 AA	0 261 220 001
86AB 12B528 AA	0 280 230 116
86GB 12B529 AA	0 280 200 047
86GB 12B529 AA	0 986 280 056
86SF 12A648 AA	0 280 130 050
86SF 12A699 AA	0 261 231 001
86SF 12A699 AB	0 261 231 006
86SF 9P916 AA	F 026 TX2 066
86SF 9P916 AA	0 438 121 055
87BB 12B528 AA	0 280 230 117
87GB 12B529 AA	0 280 202 094
88BB 12B528 BA	0 280 230 118
88GB 12B529 AA	0 281 002 029
88GB 6C315 AA	0 281 002 030
88GB 9B989 AA	0 132 009 305
88GB 9F479 AA	0 281 002 018
90SF 12A697 AA	0 280 130 060
92SX 12B528 AA	0 280 230 119
92TF 12K073 AB	0 232 102 005
93BB 2B372 AH	0 204 154 019
93BB 2B372 AH	0 204 154 030
93BB 2B372 BF	0 204 154 021
93BB 2B372 BF	0 204 154 032
93BB 2B372 CF	0 204 154 022
93BB 2B372 DF	0 204 154 023
94DA 19E642 AA	9 141 064 423
95VW 12A697 CA	0 280 130 073
95VW 12A697 CA	0 280 130 078
95VW 12B529 BB	0 280 217 121
95VW 12B529 BB	0 280 217 122
95VW 12B529 BB	0 281 002 757
95VW 12B529 BB	0 986 280 202
95VW 12B529 BC	0 280 217 121
95VW 12B529 BC	0 281 002 757
95VW 12B529 BC	0 281 002 758
95VW 12B529 BC	0 986 280 202
95VW 12B529 DA	0 280 217 504
95VW 12B529 DA	0 280 217 505
95VW 12B529 DB	0 280 217 512
95VW 12B573 AA	0 261 230 007
95VW 12B573 AA	0 261 230 008
95VW 12B573 AA	0 261 230 037
95VW 9B949 DA	0 205 001 024
95VW 9B949 DB	0 205 001 032
95VW 9B949 EA	0 205 001 032
95VW 9B949 EA	0 205 001 041
95VW 9B949 EB	0 205 001 044



95VW 9P986 BA	0 232 103 019
96BG 2B372 AA	0 204 154 019
96BG 2B372 AA	0 204 154 030
96BG 2B372 BA	0 204 154 021
96BG 2B372 BA	0 204 154 032

96BG 2B372 CA	0 204 154 022
96DA 2C204 AA	0 265 006 230
97BB 2C285 AB	0 204 154 038
97BG 2B372 AA	0 204 154 030
97BG 2B372 AA	0 204 154 035

97BG 2B372 BA	0 204 154 036
97BG 2B372 CA	0 204 154 031
97BG 2B372 EA	0 204 154 039
97BX 13K236 BA	0 263 003 015
97JF 9F593 BA	0 280 122 005

97VW 9B949 BA	0 205 001 031
97VW 9B949 BB	0 281 002 226
98VW 12B529 BA	0 280 217 117
98VW 12B529 BA	0 280 217 118
98VW 9P791 AA	0 280 101 001

98VW 9P791 AA	0 280 101 002
98VW 9P971 AA	0 280 101 001
98VW 9P971 AA	0 280 101 002
988F 12A699 BB	0 261 231 124
988F 12A699 BC	0 261 231 124

GMC (GENERAL MOTORS CORP.)	
1 017 8691	0 265 003 090
1 017 8692	0 265 003 089

1 020 4740	0 265 001 379
1 033 5962	0 263 003 275
1 033 5963	0 263 003 260
1 041 5656	0 265 005 410
1 041 5656	0 265 005 411

1 043 7635	0 265 005 223
1 256 6778	0 280 130 122
1 256 6845	0 261 231 174
1 256 6846	0 280 218 114
1 256 6846	0 280 218 115

1 256 8929	0 261 230 030
1 256 8929	0 261 230 075
1 257 1081	0 280 750 136
1 257 4130	0 280 750 163
1 257 5467	0 261 230 101

1 258 9447	0 261 545 019
1 259 0194	0 261 231 182
1 259 0991	0 261 210 274
1 259 0991	0 261 210 290
1 261 3030	0 261 210 290

1 261 4935	0 261 545 031
1 350 2779	0 261 230 162
1 519 7080	0 265 005 624
2 199 450	0 280 218 177
2 442 0587	0 261 230 101

2 574 2495	0 263 003 279
2 574 2893	0 263 003 277
2 574 5708	0 263 003 278
2 574 7658	0 263 003 261
2 576 0243	0 263 003 276

5 433 329	0 261 210 263
5 520 0301	0 281 002 784
9 015 435	0 261 231 209
9 018 3892	0 280 130 032
9 041 0792	0 280 130 068

9 041 0792	0 280 130 107
9 041 1538	0 280 130 073
9 044 8771	0 261 231 079
9 049 9610	0 261 230 009
9 050 6101	0 232 103 015

9 054 0188	0 281 002 138
9 058 9767	0 281 002 285
9 118 150	0 281 002 285
9 204 3128	0 265 001 325
9 209 9888	0 261 210 230

9 209 9892	0 261 231 163
9 317 7371	0 281 002 510
9 317 9850	0 281 002 662
9 318 0268	0 281 002 617
9 318 1944	0 281 002 716

9 318 9955	0 281 002 830
9 320 3180	0 261 231 004
9 321 1367	9 280 082 000
9 321 6076	0 280 217 506
9 321 6076	0 280 217 507

9 321 6076	0 280 217 525
9 321 6076	0 280 217 526
9 321 6079	0 261 210 083
9 321 6451	0 232 103 006
9 323 2333	9 280 082 001

9 323 2413	0 261 210 128
9 323 2415	0 261 230 013
9 323 6338	0 261 210 138
9 324 3251	0 261 210 150
9 325 9413	0 261 230 022

9 326 1954	0 261 231 046
9 326 2063	F 000 DV0 101
9 326 8054	F 000 DV0 100
9 331 0500	0 232 103 067
9 336 3456	F 000 DV0 105

9 336 8719	F 000 DV0 101
9 336 8720	F 000 DV0 102

HOLDEN	
VS 194 59	0 280 212 015
VS 194 62	0 280 120 326
12 566 845	0 261 231 174

12 566 846	0 280 218 115
12 566 847	0 232 103 047
12 566 848	0 261 210 247
12 582 232	0 261 230 112
12 582 652	0 261 210 247

12 598 948	0 261 545 011
21 994 504	0 280 218 177
90 287 309	0 265 001 206
90 346 045	0 265 001 233
90 346 046	0 265 001 232

90 399 364	0 280 202 213
90 410 792	0 280 130 107
90 423 088	0 280 130 039
90 451 441	0 261 210 030
90 490 185	0 280 130 093

90 510 152	0 280 213 024
90 510 154	0 280 217 106
90 510 156	0 280 217 503
90 510 281	0 261 231 006
90 510 884	0 265 003 070

90 530 439	0 280 122 014
90 541 502	0 280 122 014
90 541 520	0 280 130 093
90 541 591	0 280 217 519
92 017 805	0 280 130 026

92 017 809	0 280 202 052
92 017 810	0 280 120 307
92 023 996	0 280 202 074
92 024 661	0 280 212 008
92 024 661	0 986 280 104

92 043 129	0 265 001 331
92 045 770	0 265 001 356
92 045 771	0 265 001 344
92 050 125	0 265 006 227
92 050 126	0 265 006 228

92 050 127	0 265 006 229
92 061 896	9 430 060 020
92 062 198	9 430 060 022
92 062 490	0 261 210 128
92 605 959	0 265 006 810

92 606 805	0 265 006 810

HONDA	
1640A PWE G000	0 280 750 141
1640A PWE G01	0 280 750 141
16400 PDD X00	0 280 218 012

16400 PLZ E01	0 281 002 482
16400 PLZ E011 M5	0 281 002 482
16400 PWE G00	0 280 750 141
16400 P5T G00	0 281 002 120
17815 S37G0	0 281 002 370

17815 S37 G00	0 205 001 028
30530 PWE G01	0 261 231 120
37500 RBD E010	0 281 002 659
37500 RBD E010 M5	0 281 002 659
37830 PDD X00	0 281 002 389

37830PDFE01	0 261 230 020
37830PWEG01	0 261 230 099
37830 RBD E011 M4	0 281 002 680
37830 RBD E012 M4	0 281 002 680
37830 RBD E013 M4	0 281 002 680

37840 PDF E01	0 232 103 022
37840 PDF E010	0 232 103 023
37840 RBDA E010	0 281 002 659
37841 RBD E010	0 281 002 406
37841 RBD E010 M4	0 281 002 406

37841 RSRE010 M4	0 281 002 906
37841 RSRZ E010 M4	0 281 002 906
37870 PDF E00	0 280 130 107
37870 PDF E01	0 280 130 107
37870 P5T G00	0 280 130 026

37870 RBDA E010	0 281 002 659
37870 RBD E011	0 281 002 209
37870 RBD E011 M4	0 281 002 209
37880 PDF E00	0 280 130 073
37880 PDF E01	0 280 130 073

37880 PDF E11	0 280 130 092
37880 P5T G00	0 280 130 039
37970 PFT E01	0 281 002 370
37970 PLZ E00	0 281 002 577
37970 PLZ G00	0 281 002 578


37971 PLZ E000	0 281 002 484
37971 PLZ E01	0 281 002 484
37971 PLZ E010	0 281 002 484
37971 PLZ E011	0 281 002 484
37971 PLZ E012	0 281 002 484

37971 PLZ E012 M6	0 281 002 484
37980 RBDA E000	0 281 002 658
39960 SMG 0031	0 265 005 649
39960 STK A010 M1	0 265 005 683
57450 S74 E00	0 265 006 259

57455 S74 E00	0 265 006 258
57470 S74 E00	0 265 006 268
57475 S74 E00	0 265 006 267
78420 P5T G00	0 281 002 121

HYUNDAI	
M28164 3A001	0 281 002 798
M28164 3A001	0 281 002 799
M39250-2B000	0 261 231 190

28100 35400	0 280 218 029
28100 35400	0 280 218 030
28100 39000	0 280 218 029
28100 39450	0 280 218 090
28100 39450	0 280 218 091



28100 39500	0 280 218 160
28100 39500	0 280 218 161
28164 22051	0 280 217 102
28164 22060	0 280 217 102
28164 22110	0 280 212 024

28164 26700	0 280 218 126
28164 26700	0 280 218 127
28164 27050	0 281 002 669
28164 27050	0 281 002 670
28164 27500	0 281 002 528

28164 38210	0 280 218 111
28164 4A000	0 281 002 554
28164 4A000	0 281 002 555
31402 27010	0 281 002 732
32705 17050	0 281 002 543

32705 26010	0 281 002 557
32710 25810	0 281 002 545
32710 25810	0 281 002 546
32710 25830	0 281 002 546
35170 22001	0 280 122 001

39180 22040	0 261 210 099
39220 21310	0 280 130 062
39220 22000	0 280 130 026
39250 22003	0 261 231 091
39330 26300	0 261 230 013

8 9434 3307 0	9 461 614 499
8 9440 3289 0	9 461 611 810
8 9440 3289 1	9 461 611 810

8 97241 083 0	0280 218 079
8 97306 560 1	0281 002 406
8 97361 397 0	0280 218 146
8 97376 977 0	0281 002 717
8 97378 846 0	0281 002 486

1056458	0 206 001 001
1304579	0 331 100 023
1367644	0 261 231 046

42056583	0 206 001 014
42056585	0 206 001 001
42100525	0 265 050 010
42100525	0 265 050 108
42105225	0 265 050 010

4430298	0 332 514 121
4843498	0 263 300 908
4890189	0 281 002 410
4890190	0 281 002 411
4893924	0 281 002 316

500334956	0 281 002 453
500342090	0 265 004 025
500343018	0 281 002 332
500343090	0 486 000 079
500344802	0 281 002 359

500372234	0281002405
500374763	0281002513
500382599	0281002209
500388702	0205001204
5010207164	0206001019

504026069	0 281 002 565
504036803	0 281 002 602
504048261	0 281 002 667
504049164	0 281 002 630
504051082	0 281 002 184

504061735	0 281 002 633
504064370	0 261 230 042
504073323	0 281 002 576
504074171	0 280 218 084
504088431	0 281 002 437

504123163	0 281 002 755
504129943	0 281 002 778
504136035	0 281 002 764
504152959	0 281 002 706
504229208	0 281 002 788

5893108	0 986 280 019
5893599	0 280 200 602
5894034	0 280 202 601
5894034	0 986 280 076
5920385	0 280 202 023

5968080	0 986 280 044
5968082	0 280 202 060
5968082	0 986 280 046
5972332	0 280 130 026
5991955	0 280 120 311

5991956	0 280 120 312
5997041	0 280 101 001
60191922	0 205 001 204
69191922	0 205 001 204
7168821	0 265 050 002

7555128	0 280 200 051
7597692	0 280 120 323
7612317	0 280 202 114
7612317	0 986 280 080
7612319	0 280 202 115

7630317	0 265 001 215
7647004	0 280 130 032
7648065	0 280 213 025
7648065	0 986 280 114
76691230	0 261 231 007

7706073	0 280 202 128
7706577	0 280 120 328
7706578	0 280 120 314
7706579	0 280 120 307
7706580	0 280 120 300

7712078	0 265 001 338
7718934	0 265 001 337
7718935	0 265 001 336
7724097	0 205 001 010
7731633	0 261 210 098

7756925	0 261 210 102
7765599	0 261 231 102
7766248	0 265 006 140
7766249	0 265 006 139
7766251	0 281 002 102

7766252	0 261 210 104
77773440	0 232 101 026
7779229	0 280 122 005
7788905	0 281 002 108
7790917	0 261 210 119

7798691	0 261 210 114
77990320	0 261 210 118
7799033	0 261 210 115
8010000554	0 206 001 016
8024221	0 280 217 503

8024223	0 261 210 113
8024224	0 232 103 009
8024226	0 280 130 073
8025562	0 280 217 813
8025562	0 280 217 817

8029510	0 280 122 001
8038558	0 280 217 817
80891268	0 281 002 667
82434700	0 265 005 017
82434700	0 265 005 030

93159374	0 281 002 471
93190723	0 281 002 056
98412656	0 281 002 046
98412657	0 281 002 011
98420607	0 281 002 023

98420742	0 205 001 200
98424639	0 281 002 087
98424793	0 280 130 026
9842482	0 281 002 089
98432254	0 265 050 026

98432255	0 265 050 012
98432255	0 265 050 025
98432255	0 265 050 030
98432255	0 265 050 129
98439687	0 205 001 201

98439687	0 280 217 503
98480585	0 205 001 202
98496568	0 281 002 227
99450797	0 281 002 165
99451024	0 281 002 166

99455420	0 281 002 170
99455421	0 281 002 205
99455422	0 261 210 113
99460474	0 281 002 260
99465103	0 265 050 108

99465103	0 265 050 147
99465104	0 265 050 129
99476427	0 265 050 152
99645104	0 265 050 129

JAGUAR	
C2S 17482	0 265 007 087
C2S 17482	0 265 007 879
C2S 17728	0 265 007 404

C2S 17729	0 265 007 417
C2S 20882	0 265 007 404
C2S 20883	0 265 007 417
C2S 2340	0 265 007 087
C2S 2341	0 265 007 404

C2S 2342	0 265 007 417
C2S 43216	0 265 007 879
C2S 4696	0 265 005 414
C2S 4701	0 265 005 236
C 43031	0 280 120 046

DAC 4737	0 280 130 055
DAC 7253	0 265 001 270
DAC 7254	0 265 001 269
DAC 7255	0 265 001 272
DAC 7277	0 265 001 271

DAC 8519	0 261 210 001
DBC 1546	0 265 001 094
DBC 1547	0 265 001 096
DBC 1557	0 265 001 095
DBC 2144	0 261 210 003

DBC 3647	0 265 001 096
DBC 5981	0 265 005 014
DBC 5981	0 265 005 031
EAC 1849	0 280 203 006
EAC 1849	0 986 280 022

EAC 5606	0 280 213 001
EAC 5713	0 280 130 032
EAC 9811	0 280 130 061
RKC 3634	0 280 202 016
TKC 5083	0 332 514 121

UKC 2525	0 280 130 023
ULC 1763	0 280 120 211
ULC 3117	0 280 120 301
XW4H 17D547 AC	1 397 212 003
XW4T 17D547 AC	1 397 212 003

YW4T 17D547 AA	1 397 212 003
1S7T 14B296 AC	0 265 005 236
1S7T 14B296 AD	0 265 005 236
1S7T 2B372 AB	0 265 007 087
1S7T 3F818 AC	0 265 005 414

1S7T 3F818 AD	0 265 005 414
1X43 2B372 AB	0 265 007 404
1X43 2B372 AE	0 265 007 404
1X43 2B372 BB	0 265 007 417
1X43 2B372 BE	0 265 007 417

6X43 14B296 AA	0 265 005 653
73171 A	0 280 203 005
73171 A	0 986 280 047
8X23 14B296 AB	0 265 005 704
8X23 14B296 AB	0 265 005 707

KARMANN	
300648	0 261 210 145
300648	0 261 210 146
303146	0 265 005 618

303146	0 265 007 618
303147	0 265 005 620
303147	0 265 007 620
303147	0 265 007 853
304084	0 265 006 825

304085	0 265 006 827
304086	0 265 006 823
313754	0 261 210 147
313760	0 261 210 178
318349	0 261 210 190

410091	0 261 210 065
410200	0 261 210 154
415678	0 281 002 727
415678	0 281 002 762
417217	0 280 218 174

434670	0 280 218 191
437003	0 280 218 181
437818	0 280 218 174
442218	0 281 002 823
525428	0 280 217 114

KIA	
KK387 43 70X	0 265 006 297
KK387 43 71Y	0 265 006 299
KK387 43 72Y	0 265 006 298

KK387 43 73X	0 265 006 296
K2A1 18 891	0 261 210 154
OK 53C 416 00	0 281 002 540
OK 53C 416 00	0 281 002 541
OK0AA 132 10	0 280 218 092

OK0AA 13 210	0 280 218 093
OK01A 18 211	0 261 230 004
OK01C 18 211	0 261 230 015
OK01C 18 921	0 261 210 065
OK01C 18 921	0 261 231 046

OK011 13 210B	0 280 217 105
OK011 18 911	0 280 122 001
OK04G 18 891	0 261 210 154
OK2A5 18 891	0 261 210 162
OK2B2 18 891	0 261 210 185

OK2B4 18 891	0 261 210 186
OK2NC 13 210	0 280 218 086
OK737 18 840	0 280 130 026
OK9A0 18 891	0 261 210 104
OK9A2 13 210	0 280 217 116

OK9A2-18-911	0 280 122 012
OK9A4-18-911	0 280 122 013
OK934-18-131	0 356 914 224
OK934-18-891	0 261 210 065
OK937-13-210	0 280 202 125

OK937-18-911	0 280 120 316
OK95A 43 701	0 265 006 352
OK95A 43 701A	0 265 006 352
OK95A 43 711A	0 265 006 353
OK95A 43 731	0 265 006 351

OK95A 43 731A	0 265 006 351
OK99D 43 430	0 265 005 012
28100 39450	0 280 218 090
28164 38 080	0 280 218 106
28164 38 080	0 280 218 107

28164 38210	0 280 218 111
28164 4A000	0 281 002 554
39350 2B010	0 232 103 074
39350 2B010	0 232 103 075
96000 4D 000	1 397 212 079

96000 4D 100	1 397 212 079
96000 4D 100	1 397 212 087

KIA MOTORS SLOVAKIA	
28164 2A401	0 281 002 724
28164 27800	0 281 002 721

28164 27900	0 281 002 601
39300 2A400	0 281 002 901
39300 2A400	0 281 002 902
39300 27400	0 281 002 902
39300 27400	0 281 002 904

39300 27400	0 281 002 905

LANCIA	
1307433080	0 204 154 020
1307438080	0 204 154 027
1315352080	0 204 154 044

1315353080	0 204 154 045
1320327080	0 265 006 427
1320328080	0 265 006 406
1320329080	0 265 006 405
2335911	0 265 007 079

3547833	0 280 217 005
42357800	0 280 202 018
4339372	0 332 014 151
4383066	0 332 015 011
4393598	0 280 120 215

4393601	0 280 130 023
4420994	0 332 514 105
4421251	0 280 202 017
4429201	0 280 202 019
4429207	0 280 200 024

4429207	0 280 200 034
4429207	0 986 280 075
4430292	0 280 202 012
4430294	0 280 120 300
4430298	0 332 514 121

4430298	0 332 514 127
46125769	0 280 130 026
46130395	0 280 120 302
46132195	0 438 121 066
46137823	0 280 120 315

◀ LANCIA

46401855	0 265 005 030
46401856	0 265 005 030
46401856	0 265 005 031
46404401	0 265 006 210
46404402	0 265 006 211

46406454	0 261 210 117
46407008	0 280 217 111
46411135	0 261 210 129
46411427	0 261 210 127
46411675	0 281 002 144

46416748	0 280 217 514
46419399	0 261 210 130
464211118	0 265 006 212
46421112	0 265 006 238
46421118	0 265 003 074

46421118	0 265 006 212
46421122	0 265 006 138
46422412	0 265 006 197
46427958	0 265 006 262
46432103	0 281 002 213

46433052	0 280 130 039
46433053	0 281 002 122
46433053	0 281 002 137
46433054	0 261 230 009
46434529	0 265 006 164

4643453	0 265 006 163
46434532	0 265 006 166
46437264	0 281 002 214
46441787	0 281 002 160
46442040	0 204 120 946

46444280	0 280 752 005
46444287	0 280 217 531
464457881	0 265 006 347
46446873	0 281 002 159
46446873	0 281 002 214

46447503	0 280 218 019
46447503	0 986 280 236
46450545	0 265 006 325
46456661	0 265 006 163
46456796	0 205 001 010

46457537	0 265 006 164
46457881	0 265 006 347
46460544	0 265 006 364
46460545	0 265 006 365
46463384	0 204 120 987

464649280	0 280 217 102
46466175	0 205 003 052
46467348	0 265 006 124
46468682	0 281 002 137
46468682	0 281 002 215

46469784	0 265 006 249
46469867	0 261 231 131
46469917	0 280 218 001
46469917	0 986 280 234
46472180	0 281 002 203

46472687	0 261 210 163
46473033	0 265 006 540
46473049	0 265 006 539
46474583	0 261 210 161
46474585	0 261 230 035

46475007	0 280 750 013
46477973	0 261 210 167
46478160	0 280 752 004
46481638	0 281 002 210
46481639	0 281 002 214

46481640	0 281 002 213
46512475	0 204 127 122
46512475	0 281 002 203
46519886	0 265 007 039
46519916	0 265 007 036

46519917	0 265 007 037
46520005	0 265 007 038
46522739	0 232 101 037
46522957	0 204 127 379
46522958	0 204 127 353

46525288	0 261 231 144
46530202	0 265 007 043
46530204	0 265 007 045
46531418	0 265 007 072
46531419	0 265 007 070

46532105	0 204 127 412
46533308	0 280 218 004
46533308	0 986 280 235
46533518	0 261 230 030
46539830	0 265 007 034

46539831	0 265 007 035
46539832	0 265 007 032
46539833	0 265 007 033
46540022	0 265 007 050
46540023	0 265 007 049

46540024	0 265 007 055
46540025	0 265 007 054
46541253	0 280 218 019
46541253	0 986 280 236
46542976	0 281 002 260

46542976	0 281 002 405
46544765	0 265 007 075
46544766	0 265 007 076
46545467	0 265 007 051
46545468	0 265 007 053

46545469	0 265 007 052
46546935	0 265 007 044
46547231	0 265 007 024
46547232	0 265 007 025
46547233	0 265 007 026

46547234	0 265 007 027
46550482	0 204 127 413
46550582	0 204 127 413
46553045	0 261 230 030
46559804	0 281 002 309

46559804	0 986 284 113
46736164	0 281 002 380
46736962	0 204 127 463
46737767	0 265 007 063
46737768	0 265 007 064

46737769	0 265 007 065
46737770	0 265 007 066
46750234	0 204 127 480
46752064	0 265 007 072
46761337	0 265 007 098

46761338	0 265 007 099
46770138	0 265 007 093
46770139	0 265 007 091
467831830	0 265 007 102
467831840	0 265 007 103

46798368	0 232 103 048
46806128	0 280 002 474
46823093	0 265 007 486
46823094	0 265 007 487
46823095	0 265 007 488

46838209	0 265 007 126
50011475	0 265 006 164
50011475	0 265 006 537
50011476	0 265 006 163
50011476	0 265 006 538

50093165	0 265 001 336
51493180	0 265 006 325
55189517	0 261 210 114
5893108	0 280 202 602
5893108	0 986 280 019

5893599	0 280 200 602
5894034	0 280 202 601
5894034	0 986 280 076
5920385	0 280 202 023
5920385	0 986 280 017

5920388	0 280 200 024
5920388	0 986 280 075
5929385	0 280 202 023
5929385	0 986 280 017
5945040	0 280 202 038

5946923	0 280 230 006
5968080	0 280 202 059
5968080	0 986 280 044
59680802	0 280 202 059
59680802	0 986 280 044

5968082	0 280 202 060
5968082	0 986 280 046
5972332	0 280 130 026
5991955	0 280 120 311
5991956	0 280 120 312

5997041	0 280 101 001
5999235	0 280 230 114
60500571	0 280 202 204
60500571	0 280 202 211
60500571	0 986 280 055

60500571	0 986 280 091
60507061	0 332 204 101
6050825	0 265 001 074
60508251	0 265 001 073
60511751	0 265 001 156

60512672	0 280 120 300
60512698	0 261 231 006
60513205	0 280 130 026
60513206	0 280 202 201
60513206	0 986 280 069

60513208	0 261 210 036
60513336	0 280 202 202
60513336	0 280 202 210
60513336	0 986 280 063
60513337	0 280 120 315

60513747	0 280 120 435
60513882	0 280 203 026
60513882	0 986 280 042
605138820	0 280 203 026
605138820	0 986 280 042

60518135	0 280 101 001
60518377	0 261 211 003
60518694	0 261 210 001
60518695	0 261 230 001
60522010	0 280 202 013

60522875	0 280 120 304
60522876	0 280 230 001
60523383	0 280 130 023
60523386	0 280 202 010
60523390	0 332 514 127


60534263	0 261 231 006
60534264	0 261 211 004
60534312	0 280 130 032
60534313	0 280 202 058
60534316	0 280 230 009

60534706	0 280 202 078
60534838	0 280 202 105
60534959	0 280 202 108
60534959	0 986 280 067
60535033	0 280 202 113

60537835	0 280 202 206
60537835	0 986 280 065
60545849	0 265 001 250
6054585	0 265 001 251
60547113	0 280 202 205

60548743	0 261 231 007
60550042	0 280 203 035
60555613	0 261 220 001
60555613	0 261 220 002
60557363	0 265 003 061

60557409	0 265 003 062
60558015	0 265 001 268
60559269	0 265 003 066
60559406	0 265 001 267
60560715	0 261 210 047



60565464	0 265 003 101
60565479	0 265 003 102
60565479	0 265 006 118
60565836	0 356 914 224
60565837	0 280 203 034

60569060	0 261 210 096
60569704	0 280 202 208
60569704	0 280 202 213
60569704	0 986 280 024
60569704	0 986 280 025

60572382	0 280 202 207
60573739	0 261 210 090
60574615	0 280 130 039
60576483	0 265 005 109
60577321	0 265 003 096

60577321	0 265 006 162
6057940	0 280 202 207
6057940	0 280 202 212
6057940	0 986 280 081
60579846	0 280 203 034

60588375	0 265 001 355
60588419	0 280 217 106
60589472	0 280 217 503
60591616	0 281 002 085
60591909	0 280 130 073

60592752	0 261 231 095
60593506	0 205 001 009
6059481	0 205 001 009
60595754	0 261 210 113
60599278	0 265 005 110

60601097	0 265 006 118
60601098	0 265 006 119
60601099	0 265 006 120
6060217	0 280 203 026
6060217	0 986 280 042

60602177	0 280 203 026
60602177	0 986 280 042
60605410	0 232 103 010
60615270	0 265 006 162
60615953	0 265 006 260

60615954	0 265 006 261
60622632	0 265 006 325
60622633	0 265 006 326
60628356	0 281 002 202
60629558	0 204 127 126

60630438	0 204 127 273
60630466	0 204 127 127
60652012	0 265 007 016
60652013	0 265 007 017
60652016	0 265 007 018

60652439	0 280 750 012
60652443	0 280 750 011
60652776	0 265 007 021
60652777	0 265 007 022
60652874	0 265 007 020

60654314	0 280 750 012
60654900	0 204 127 376
60656290	0 265 007 040
60656291	0 265 007 041
60656301	0 265 007 042

60659263	0 265 007 046
60659264	0 265 007 047
60659265	0 265 007 018
60659265	0 265 007 048
60659531	0 204 127 456

60660039	1 397 212 011
60660054	0 280 750 053
60662165	0 204 127 377
60662823	0 261 231 152
60663029	0 280 218 036

60663029	0 986 280 237
60684944	1 397 212 011
60700045	0 280 202 045
60722873	0 280 202 027
60722873	0 986 280 078

60755045	0 280 200 601
60755045	0 986 280 061
60755046	0 280 200 002
60800132	0 280 230 006
60800163	0 280 202 060

60800163	0 986 280 046
60800167	0 280 130 026
60800522	0 280 130 032
60805107	0 280 202 060
60805107	0 986 280 046

60805373	0 280 101 001
60806252	0 265 003 074
60806252	0 265 006 212
60806254	0 265 003 063
60806254	0 265 006 197

60807526	0 265 001 301
60808142	0 280 130 026
60808397	0 265 003 075
60808904	0 261 210 096
60808986	0 261 210 090

6080915	0 280 202 212
6080915	0 986 280 081
60809658	0 280 202 211
60809658	0 986 280 091
60810394	0 265 005 030

60810394	0 265 005 031
60810692	0 261 210 113
60810774	0 265 003 096
60810774	0 265 006 162
60810791	0 261 231 095

60810813	0 280 217 111
60811021	0 281 002 085
60811201	0 232 101 026
6081145	0 280 217 514
6081220	0 280 130 055

6081224	0 280 130 055
60812394	0 265 006 212
60812395	0 265 006 162
60812644	0 265 006 197
60813773	0 265 006 238

60814769	0 281 002 214
60814852	0 280 218 019
60814852	0 986 280 236
60815022	0 281 002 202
60815340	0 205 003 052

60815463	0 204 127 122
71713685	F 00C 1G6 969
71715149	3 437 010 452
71788020	0 986 280 234
740134603	0 280 130 032

75204203	0 331 101 004
7540622	0 280 120 314
7546795	0 280 200 046
7553412	0 280 202 081
7555126	0 280 202 102

7555126	0 986 280 054
7555127	0 280 202 103
7555128	0 280 200 051
7576067	0 280 230 009
7597692	0 280 120 323

7612317	0 280 202 114
7612317	0 986 280 080
7612319	0 280 202 115
7612320	0 280 213 006
7612320	0 986 280 115

7616269	0 261 210 029
7628059	0 280 230 009
7629856	0 280 101 003
7630317	0 265 001 215
7630318	0 265 001 216

7630319	0 265 001 217
7636642	0 280 120 328
7640095	0 280 120 307
7644804	0 280 120 307
7647004	0 280 130 032

7647004	0 280 130 069
7648065	0 280 213 025
7648065	0 986 280 114
7648113	0 280 120 313
7651951	0 265 007 082

7668164	0 280 202 204
7668164	0 280 202 211
7668164	0 986 280 055
7668164	0 986 280 091
76691230	0 261 231 007

7669143	0 280 130 066
7686033	0 280 202 060
7686033	0 986 280 046
7686599	0 280 130 060
7690200	0 280 200 055

7693640	0 280 202 013
7693640	0 280 202 103
7694623	0 280 120 331
7706073	0 280 202 128
7706577	0 280 120 328

7706578	0 280 120 314
7706579	0 280 120 307
7706580	0 280 120 300
77065804	0 280 120 300
7706581	0 280 120 331

7706582	0 280 120 323
77065830	0 280 120 313
7706584	0 280 120 312
7706585	0 280 120 311
7709815	0 232 102 004

77118780	0 280 212 024
77118780	0 986 280 123
7712078	0 265 001 338
7717686	0 280 230 005
7718934	0 265 001 337

7718935	0 265 001 336
7721274	0 281 002 089
7721274	0 281 002 093
7724096	0 281 002 088
7724097	0 205 001 010

7731633	0 261 210 098
7738223	0 280 130 055
7739430	0 261 210 093
7739431	0 232 101 018
7746949	0 261 210 100


7750753	0 280 230 014
7750754	0 280 230 018
7756924	0 261 210 103
7756925	0 261 210 102
77579230	0 281 002 087

7763718	0 280 217 106
7763719	0 280 130 073
7764102	0 265 003 109
7765599	0 261 231 102
7766248	0 265 006 140

7766249	0 265 006 139
7766251	0 281 002 102
7766252	0 261 210 104
7767750	0 281 002 185
7770239	0 280 130 107

77773440	0 232 101 026
7779229	0 280 122 005
77825160	0 265 001 387
77872560	0 261 210 124
7788905	0 281 002 108

7790917	0 261 210 119
77942200	0 265 006 161
7798691	0 261 210 114
77990320	0 261 210 118
7799033	0 261 210 115



↔
L

82277331	0 280 100 024
82277332	0 280 121 001
82277333	0 280 130 006
82277334	0 280 130 014
82277344	0 332 003 023
82281564	0 280 120 031
82308690	0 280 120 213
82348191	0 280 202 014
82357799	0 280 202 015
82357800	0 280 202 018
82365378	0 332 514 121
82369630	0 335 530 023
82390387	0 280 202 015
82401252	0 265 001 073
82406063	0 265 001 072
82407679	0 265 001 074
82434700	0 265 005 017
82434700	0 265 005 030
8243566	0 265 001 248
82435661	0 265 001 249
82435662	0 265 001 246
82435663	0 265 001 247
82442723	0 265 001 209
824451370	0 265 001 210
82448464	0 265 001 304
82450141	0 265 005 014
82450141	0 265 005 031
82455274	0 265 001 261
82458587	0 265 003 074
82458587	0 265 006 212
82458588	0 265 003 063
82458954	0 265 003 071
82458954	0 265 006 262
82458956	0 265 003 075
8246063	0 265 001 072
82467204	0 265 003 075
82472241	0 265 001 216
82472242	0 265 001 217
82472243	0 265 003 063
82472243	0 265 006 197
82485111	0 265 003 121
82485174	0 265 006 160
82485175	0 265 006 300
9009423	0 331 101 001
92308690	0 280 120 213
9617220680	0 280 122 003
9618261580	0 261 230 012
9633310080	0 281 002 283
9923794	0 331 101 003
9927593	0 331 101 004
9934319	0 331 101 008
9944334	0 332 014 411

LEYLAND-DAF	
545190001	0 265 006 832
545190003	0 265 006 833

LOTUS	
A116E6059F	0 280 218 051
A116E6059F	0 986 280 231
A116E6063F	0 261 230 042

A116E6066F	0 261 230 009

MAGIRUS-DEUTZ	
4206 1635	0 265 050 002
9841 2656	0 281 002 046
9841 2657	0 281 002 011

9842 0607	0 281 002 023
9842 0742	0 205 001 200

MAHINDRA	
0315CC0031N	0 281 002 756

MAN	
N1 01101 8687	0 206 001 013
11 99013 0478	0 261 231 019
39 15270 909	0 281 002 217

51 09413 7001	0 281 002 421
51 09413 7002	0 281 002 421
51 13105 6003	0 280 750 094
51 13105 6005	0 280 750 129
51 27120 0005	0 281 002 105

51 27120 0006	0 281 002 106
51 27120 0008	0 281 002 270
51 27120 0009	0 281 002 271
51 27120 0013	0 232 103 006
51 27120 0014	0 281 002 426

51 27120 0015	0 281 002 427
51 27120 0017	0 281 002 599
51 27120 7037	0 281 002 315
51 27120 7038	0 281 002 662
51 27421 0077	0 281 002 046

51 27421 0078	0 281 002 011
51 27421 0079	0 281 002 023
51 27421 0102	0 281 002 109
51 27421 0113	0 281 002 232
51 27421 0128	0 281 002 233

51 27421 0142	0 281 002 418
51 27421 0178	0 281 002 534
51 27421 0182	0 281 002 631
51 27421 0198	0 281 002 655
51 27421 0213	0 281 002 011

51 27421 0216	0 281 002 655
51 27421 0229	0 281 002 706
51 27421 0230	0 281 002 706
51 27421 0236	0 281 002 706
51 57421 0229	0 281 002 706

81 25920 6067	0 206 001 020
81 25920 6068	0 206 001 015
81 25920 6069	0 206 001 011
81 25920 6072	0 205 001 206
81 25920 6076	0 206 001 017

81 25970 6012	0 132 009 309
81 25970 6017	0 132 009 312
81 25970 6017	0 132 009 321
81 25970 6021	0 206 001 005
81 25970 6022	0 206 001 003

81 25970 6034	0 206 001 008
81 25970 6040	0 132 009 321
81 25970 6067	0 206 001 020
81 25970 6072	0 205 001 206
81 25970 6076	0 206 001 017

81 25970 6079	0 281 002 350
81 25970 6095	0 281 002 587
81 26212 0002	0 331 101 002
81 26212 0003	0 331 101 001
81 26212 0008	0 331 101 004

81 27120 0018	0 265 050 002
81 27120 0025	0 265 050 012
81 27120 0027	0 265 050 010
81 27120 0028	0 265 050 015
81 27120 0031	0 265 050 034

81 27120 0035	0 265 050 108
81 27120 0036	0 265 050 129
81 27120 0037	0 265 050 140
81 27120 6060	0 486 001 003
81 27120 6061	0 486 001 004

81 27120 6067	0 486 000 052
81 27120 6068	0 486 000 053
81 27120 6070	0 486 000 047
81 27120 6071	0 486 000 045
81 27120 6072	0 486 000 046

81 27120 6073	0 486 000 044
81 27120 6075	0 486 000 048
81 27120 6076	0 486 000 050
81 27120 6077	0 486 000 049
81 27120 6078	0 486 000 051

81 27421 0202	0 484 205 006
90 81616 0366	0 331 101 002
90 81616 0367	0 331 101 001

MASERATI	
112135	0 261 231 167
170592	0 265 006 429
180045	0 280 218 084

180137	0 281 002 170
182194	0 261 210 198
187739	0 261 231 166
187740	0 261 231 167
188172	0 265 005 241

196819	0 280 752 285
206070	0 265 005 616
208444	0 280 218 217
363802105	0 265 006 213

MAZDA	
F153 43 7Y1	0 265 005 254
GD7E 43 701	0 265 006 316
GD7E 43 711	0 265 006 318

GD7E 43 721	0 265 006 319
GD7E 43 73XD	0 265 006 317
GD7E 43 731	0 265 006 317
L3K9-18-211	0 261 230 128
L3K9-18-211	0 261 230 129

L3K9-18-211A	0 261 230 128
L3K9-18-211A	0 261 230 129
L301-18-211	0 261 230 122
L301 18 211	0 261 230 123
L301 18 211	0 261 230 180

L807-18-211	0 261 545 006
L807-18-921	0 261 231 160
PN46-13-TS0	9 461 614 120
WE01-18-211	0 281 002 680
WE01-18-221	0 281 002 729

WLBD 18 221	0 281 002 820
WLE7-1-3TS0	9 443 611 749
0265006313	0 265 006 313
4S4G 9F479 AC	0 261 230 180
4S4G 9F479 AC	0 261 230 181

MERCEDES-BENZ	
B6 782 38 02	0 263 003 013
Q00031 21V003	0 261 230 049
Q00094 93V000	0 265 005 698

000 074 00 14	0 438 120 014
000 074 01 14	0 438 120 026
000 074 02 14	0 438 120 081
000 074 03 14	0 438 120 062
000 074 03 14	0 438 120 083


000 074 04 14	0 438 120 114
000 074 05 14	0 438 120 075
000 074 06 14	0 438 120 074
000 074 07 14	0 438 120 115
000 074 08 14	0 438 120 116

000 074 09 14	0 438 120 135
000 074 10 14	0 438 120 154
000 074 11 14	0 438 120 170
000 074 12 14	F 026 TX2 060
000 074 12 14	0 438 121 001
000 074 12 14	0 986 439 301
000 074 13 14	F 026 TX2 052
000 074 13 14	0 438 121 009
000 074 13 14	0 438 121 010
000 074 15 14	0 438 121 022
000 074 16 14	0 438 121 019
000 074 18 14	0 438 121 020
000 074 20 14	0 438 121 033
000 074 20 14	0 986 439 333
000 074 20 14 0080	0 986 439 333
000 074 21 14	0 438 121 043
000 074 21 14	0 986 439 343
000 074 21 14 0080	0 986 439 343
000 074 23 14	F 026 TX2 053
000 074 23 14	0 438 121 044
000 074 24 14	0 438 121 037
000 074 24 14	0 986 439 337
000 074 25 14	0 438 121 036
000 074 27 14	0 438 121 075
000 074 28 14	0 438 121 082
000 074 28 14	0 986 439 382
000 074 28 14 0080	0 986 439 382
000 074 29 14	F 026 TX2 055
000 074 29 14	0 438 121 072
000 074 30 14	F 026 TX2 057
000 074 30 14	0 438 121 080
000 094 00 48	0 280 217 100
000 094 00 48	0 280 217 101
000 094 01 48	0 280 214 004
000 094 01 48	0 280 214 005
000 094 01 48	0 986 280 121
000 094 01 48	0 986 280 134
000 094 01 48 0080	0 986 280 121
000 094 01 48 0080	0 986 280 134
000 094 02 48	0 280 213 015
000 094 02 48	0 280 213 016
000 094 02 48	0 986 280 126
000 094 02 48	0 986 280 129
000 094 02 48 0080	0 986 280 126
000 094 02 48 0080	0 986 280 129
000 094 04 48	0 280 213 018
000 094 04 48	0 280 213 019
000 094 04 48	0 986 280 125
000 094 04 48	0 986 280 136
000 094 05 48	0 280 217 500
000 094 05 48	0 280 217 501
000 094 06 48	0 280 213 018
000 094 06 48	0 280 213 019
000 094 06 48	0 986 280 125
000 094 06 48	0 986 280 136

000 094 06 48 0080	0 986 280 125
000 094 06 48 0080	0 986 280 136
000 094 07 48	0 280 217 807
000 094 07 48	0 280 217 808
000 094 08 48	0 280 217 509
000 094 08 48	0 280 217 510
000 094 09 48	0 280 217 114
000 094 09 48	0 280 217 115
000 094 10 48	0 280 217 517
000 094 10 48	0 280 217 518
000 094 12 48	0 281 002 152
000 094 12 48	0 281 002 153
000 094 13 48	0 280 217 523
000 094 13 48	0 280 217 524
000 094 14 48	0 281 002 384
000 094 14 48	0 281 002 385
000 094 18 48	0 280 218 080
000 094 19 48	0 280 218 081
000 094 20 48	0 281 002 585
000 094 20 48	0 281 002 586
000 094 22 48	0 281 002 656
000 094 22 48	0 281 002 657
000 094 32 48	0 281 002 896
000 094 32 48	0 281 002 897
000 141 25 25	0 205 003 007
000 141 26 25	0 205 003 009
000 141 38 25	0 205 003 006
000 141 39 25	0 205 003 008
000 141 39 25	0 205 003 019
000 141 39 25	0 205 003 020
000 141 45 25	0 205 003 012
000 141 46 25	0 205 003 014
000 141 55 25	0 205 003 012
000 141 55 25	0 205 003 021
000 141 55 25	0 205 003 022
000 141 56 25	0 205 003 014
000 141 56 25	0 205 003 023
000 141 56 25	0 205 003 024
000 141 72 25	0 205 003 006
000 141 72 25	0 205 003 017
000 141 72 25	0 205 003 018
000 141 87 25	0 205 003 017
000 141 87 25	0 205 003 018
000 141 87 25	0 205 003 027
000 141 87 25	0 205 003 028
000 141 87 25	0 205 003 034
000 141 88 25	0 205 003 019
000 141 88 25	0 205 003 020
000 141 88 25	0 205 003 029
000 141 88 25	0 205 003 030
000 141 88 25	0 205 003 036
000 152 08 10	0 331 101 001
000 152 09 10	0 331 101 002
000 152 39 10	0 331 101 004
000 152 44 10	0 331 101 003

000 152 48 10	0 331 100 023
000 153 84 28	0 335 541 001
000 153 88 20	0 261 210 022
000 158 07 19	0 261 210 156
000 158 07 19	0 261 210 157
000 540 04 17	0 265 001 203
000 540 04 17	0 265 001 240
000 540 05 17	0 265 001 201
000 540 10 17	0 265 001 239
000 540 11 17	0 265 001 240
000 542 65 18	0 265 005 200
000 542 65 18	0 265 005 201
000 542 69 18	0 486 000 016
000 542 87 19	0 332 008 002
000 542 92 14	0 281 002 024
000 542 92 14	0 281 002 028
000 542 93 14	0 281 002 034
000 542 93 14	0 281 002 035
000 542 96 14	0 281 002 077
000 542 96 14	0 281 002 078
000 800 71 75	0 928 400 068
000 800 75 75	0 928 400 086
000 800 80 75	0 928 400 095
000 821 01 63	0 332 204 101
000 994 07 01	0 204 220 153
000 998 47 01	0 204 220 153
001 094 35 03	0 281 002 273
001 153 09 28	0 335 541 002
001 408 7V 00 1	0 265 005 303
001 540 44 17	0 265 005 219
001 540 44 17	0 265 005 220
001 540 44 17	0 265 005 246
001 540 44 17	0 265 005 258
001 540 45 17	0 265 005 230
001 540 45 17	0 265 005 231
001 540 45 17	0 265 005 246
001 540 45 17	0 265 005 258
001 542 04 18	0 486 000 001
001 542 05 18	0 486 000 002
001 542 07 18	0 486 001 001
001 542 08 18	0 486 001 002
001 542 24 17	0 281 002 011
001 542 25 18	0 486 001 001
001 542 32 19	0 332 014 151
001 542 34 18	0 486 000 001
001 542 35 18	0 486 001 001
001 542 42 18	0 265 004 011
001 542 43 18	0 265 004 012
001 542 45 18	0 265 004 013
001 542 45 18	0 265 004 015
001 542 46 18	0 265 004 014
001 542 47 19	0 332 014 453
001 542 59 18	0 263 003 013
001 542 76 18	0 486 000 034
001 542 77 18	0 486 001 013

001 542 82 18	0 486 000 035
001 542 84 18	0 486 001 014
001 542 85 18	0 486 001 015
001 542 87 17	0 280 130 009
001 542 88 17	0 280 130 006
001 542 90 18	0 265 005 219
001 542 90 18	0 265 005 220
001 542 90 18	0 265 005 246
001 542 90 18	0 265 005 258
001 542 91 17	0 280 100 006
001 545 46 18	0 265 004 016
001 545 91 32	0 265 001 008
002 153 17 28	0 261 210 009
002 153 17 28	0 261 210 010
002 153 26 28	0 261 210 007
002 153 26 28	0 261 210 008
002 153 33 28	0 261 210 014
002 153 33 28	0 261 210 015
002 153 34 28	0 261 210 020
002 153 34 28	0 261 210 021
002 153 35 28	0 261 210 022
002 153 35 28	0 261 210 023
002 153 40 28	0 261 210 025
002 153 41 28	0 261 210 026
002 153 41 28	0 261 210 027
002 153 43 28	0 261 210 016
002 153 43 28	0 261 210 017
002 153 45 28	0 261 210 018
002 153 45 28	0 261 210 019
002 153 55 28	0 261 210 033
002 153 55 28	0 261 210 034
002 153 59 28	0 261 210 037
002 153 59 28	0 261 210 038
002 153 60 28	0 261 210 039
002 153 60 28	0 261 210 040
002 153 62 28	0 261 231 009
002 153 62 28	0 261 231 010
002 153 74 28	0 261 231 024
002 153 74 28	0 261 231 025
002 153 83 28	0 261 231 028
002 153 83 28	0 261 231 029
002 153 84 28	0 261 231 026
002 153 84 28	0 261 231 027
002 153 91 28	0 261 210 049
002 153 91 28	0 261 210 050
002 153 92 28	0 261 210 051
002 153 92 28	0 261 210 052
002 540 09 17	0 265 005 303
002 540 09 17	0 265 005 307
002 542 04 18	0 486 000 043
002 542 16 17	0 280 100 012
002 542 21 17	0 280 130 014
002 542 22 17	0 280 100 025
002 542 22 18	0 486 000 084
002 542 23 18	0 486 001 020



◀ MERCEDES-BENZ

002 542 24 18	0 486 001 022
002 542 28 17	0 280 100 100
002 542 29 18	0 265 004 015
002 542 30 18	0 265 004 016
002 542 32 17	0 280 100 112

002 542 33 17	0 280 100 111
002 542 37 18	0 486 001 024
002 542 66 18	0 265 005 246
002 542 66 18	0 265 005 258
002 545 02 45	0 332 204 001

002 545 19 05	0 332 015 011
002 545 80 24	0 280 120 004
002 820 55 10	0 928 400 070
003 153 01 28	0 261 210 018
003 153 01 28	0 261 210 055

003 153 01 28	0 261 210 056
003 153 08 28	0 261 210 066
003 153 08 28	0 261 210 067
003 153 13 28	0 261 210 072
003 153 13 28	0 261 210 073

003 153 14 28	0 261 210 074
003 153 14 28	0 261 210 075
003 153 15 28	0 261 210 068
003 153 15 28	0 261 210 069
003 153 16 28	0 261 210 070

003 153 16 28	0 261 210 071
003 153 23 28	0 261 210 076
003 153 23 28	0 261 210 077
003 153 24 28	0 261 210 078
003 153 24 28	0 261 210 079

003 153 27 28	0 261 210 170
003 153 27 28	0 261 210 171
003 153 33 28	0 261 231 050
003 153 33 28	0 261 231 051
003 153 34 28	0 261 231 052

003 153 34 28	0 261 231 053
003 153 35 28	0 261 231 058
003 153 35 28	0 261 231 059
003 153 36 28	0 261 231 060
003 153 36 28	0 261 231 061

003 153 46 28	0 261 231 054
003 153 46 28	0 261 231 055
003 153 47 28	0 261 231 062
003 153 47 28	0 261 231 063
003 153 48 28	0 261 231 056

003 153 48 28	0 261 231 057
003 153 50 28	0 261 210 085
003 153 50 28	0 261 210 086
003 153 55 28	0 261 210 087
003 153 55 28	0 261 210 088

003 153 60 28	0 261 231 080
003 153 60 28	0 261 231 081
003 153 61 28	0 261 231 082
003 153 61 28	0 261 231 083
003 153 66 28	0 261 231 084

003 153 66 28	0 261 231 085
003 153 67 28	0 261 231 086
003 153 67 28	0 261 231 087
003 153 74 28	0 281 002 123
003 153 74 28	0 281 002 124

003 153 75 28	0 261 210 122
003 153 75 28	0 261 210 123
003 153 78 28	0 261 231 100
003 153 78 28	0 261 231 101
003 153 80 28	0 261 231 098

003 153 80 28	0 261 231 099
003 153 81 28	0 281 002 100
003 153 83 28	0 232 103 012
003 153 83 28	0 232 103 013
003 153 83 28	0 232 103 037

003 153 86 28	0 261 231 110
003 153 86 28	0 261 231 111
003 153 95 28	0 261 210 141
003 153 95 28	0 261 210 142
003 542 03 18	0 265 005 267

003 542 03 18	0 265 005 298
003 542 05 18	0 265 005 303
003 542 78 17	0 280 100 122
003 545 11 24	0 280 120 018
003 545 49 24	0 280 120 035

003 545 61 24	0 280 120 015
003 545 66 24	0 280 120 029
004 094 34 48	0 281 002 978
004 094 34 48	0 281 002 979
004 153 06 28	0 281 002 281

004 153 06 28	0 281 002 282
004 153 07 28	0 232 103 022
004 153 07 28	0 232 103 023
004 153 07 28	0 232 103 027
004 153 07 28	0 232 103 028

004 153 07 28	0 232 103 037
004 153 09 28	0 261 231 133
004 153 09 28	0 261 231 134
004 153 15 28	0 281 002 238
004 153 15 28	0 281 002 239

004 153 18 28	0 281 002 244
004 153 18 28	0 281 002 245
004 153 22 28	0 261 220 001
004 153 22 28	0 261 220 002
0041533128	0 281 002 498

004 153 62 28	0 261 231 128
004 153 67 28	0 281 002 504
004 153 67 28	0 281 002 505
004 153 69 28	0 232 103 037
004 153 69 28	0 232 103 038

004 153 70 28	0 261 002 469
004 153 70 28	0 281 002 468
004 153 70 28	0 281 002 469
004 153 73 28	0 281 002 489
004 153 73 28	0 281 002 490

004 153 75 28	0 281 002 499
004 153 82 28	0 281 002 456
004 153 90 28	0 261 231 188
004 153 90 28	0 261 231 189
004 153 95 28	0 261 230 104

004 153 96 28	0 232 103 050
004 153 96 28	0 232 103 051
004 153 97 28	0 232 103 051
004 545 43 24	0 280 120 044
004 545 44 24	0 280 120 045

005 153 56 28	0 261 230 154
005 153 56 28	0 261 545 012
005 153 56 28	0 261 545 013
005 153 58 28	0 281 002 700
005 153 58 28	0 281 002 703

005 153 61 28	0 261 230 118
005 153 74 28	0 281 002 726
005 153 74 28	0 281 002 727
005 153 77 28	0 281 002 761
005 153 77 28	0 281 002 762

005 542 21 18	0 265 005 752
005 542 26 18	0 265 005 735
005 542 26 18	0 265 007 735
005 542 27 18	0 265 005 752
005 542 27 18	0 265 005 753

006 153 07 28	0 232 103 085
006 153 13 28	0 261 230 139
006 153 13 28	0 261 230 140
006 153 14 28	0 261 230 141
006 153 14 28	0 261 230 142

006 153 15 28	0 261 230 143
006 153 15 28	0 261 230 144
006 153 16 28	0 261 230 153
006 153 16 28	0 261 230 154
006 153 17 28	0 232 103 070

006 153 17 28	0 232 103 071
006 153 18 28	0 232 103 072
006 153 18 28	0 232 103 073
006 153 24 28	0 232 103 066
006 153 33 28	0 281 002 672

006 153 42 28	0 281 002 892
006 153 42 28	0 281 002 893
006 153 47 28	0 261 230 118
006 153 49 28	0 281 002 822
006 153 49 28	0 281 002 823

006 153 53 28	0 281 002 884
006 153 53 28	0 281 002 885
006 153 54 28	0 281 002 888
006 153 54 28	0 281 002 889
006 153 55 28	0 281 002 890

006 153 55 28	0 281 002 891
006 153 56 28	0 281 002 886
006 153 56 28	0 281 002 887
006 153 61 28	0 232 103 077
006 153 61 28	0 232 103 078

006 153 61 28	0 232 103 086
006 153 65 28	0 281 002 842
006 153 65 28	0 281 002 843
006 153 71 28	0 232 103 086
006 153 71 28	0 232 103 087

006 153 72 28	0 281 002 882
006 153 72 28	0 281 002 883
006 153 77 28	0 232 103 081
006 153 77 28	0 232 103 082
006 153 78 28	0 281 002 926

006 153 78 28	0 281 002 927
006 153 95 28	0 281 002 925
006 542 02 17	0 280 130 030
006 542 34 17	0 280 130 035
006 542 34 17	0 280 130 036

006 542 50 17	0 280 101 003
006 542 50 17	0 280 101 004
006 542 56 17	0 280 130 042
006 542 56 17	0 280 130 043
006 542 77 17	0 280 130 044

006 542 77 17	0 280 130 045
007 153 05 28	0 261 230 227
007 153 06 28	0 281 002 967
007 153 06 28	0 281 002 968
007 153 07 28	0 232 103 085

007 153 31 28	0 261 230 229
007 542 02 17	0 281 002 025
007 542 16 17	0 132 009 304
007 542 21 17	0 280 130 047
007 542 21 17	0 280 130 048

007 542 24 17	0 281 002 011
007 542 27 17	0 281 002 023
008 152 00 10	0 331 101 003
009 542 31 17	0 281 002 058
009 542 31 17	0 281 002 059

009 542 62 17	0 265 002 039
009 542 62 17	0 265 002 040
009 542 62 17	0 265 002 075
009 542 62 17	0 265 002 076
009 542 62 17	0 265 002 229

009 542 62 17	0 265 002 230
009 542 62 17	0 265 005 016
009 542 62 17	0 265 005 039
009 542 62 17	0 265 005 040
009 542 88 17	0 205 001 008

010 542 49 17	0 265 005 018
010 542 51 17	0 265 005 102
010 542 51 17	0 265 005 106
010 542 51 17	0 265 005 107
010 542 51 17	0 265 005 150

011 542 46 17	0 265 005 106
011 542 46 17	0 265 005 107
011 542 46 17	0 265 005 150
011 542 71 17	0 265 005 044
011 542 86 17	0 205 001 029




011 542 86 17	0 205 001 030
011 542 87 17	0 205 001 302
011 542 87 17	0 205 001 303
012 542 04 17	0 265 005 113
012 542 04 17	0 265 005 114
012 542 04 17	0 265 005 151
012 542 43 17	0 265 005 040
013 542 14 17	0 265 006 515
013 542 31 17	0 206 001 018
013 542 55 17	0 265 006 619
026 520 21 09	0 265 005 300
050 331 09 AA	0 281 002 502
050 331 09 AA	0 281 002 503
050 333 20 AA	0 281 002 779
050 333 20 AA	0 281 002 780
102 074 03 14	0 438 121 009
102 074 03 14	0 438 121 010
104 141 00 25	0 205 003 042
104 141 00 25	0 205 003 043
107 540 00 17	0 265 001 012
107 540 00 17	0 265 001 013
107 540 02 17	0 265 001 128
107 540 02 17	0 265 001 129
107 540 03 17	0 265 001 126
107 540 03 17	0 265 001 127
107 540 04 17	0 265 002 019
107 540 04 17	0 265 002 255
107 540 04 17	0 265 002 256
111 098 01 09	0 280 750 045
111 141 00 25	0 205 003 044
111 141 00 25	0 205 003 045
111 141 01 25	0 280 750 021
111 141 02 25	0 280 750 067
111 141 02 25	0 280 750 068
111 141 03 25	0 280 750 074
111 141 03 25	0 280 750 075
112 094 00 48	0 280 217 515
112 094 00 48	0 280 217 516
112 094 01 48	0 280 218 082
112 141 00 25	0 205 003 046
112 141 00 25	0 205 003 047
113 094 00 48	0 280 217 810
113 094 00 48	0 280 217 811
113 094 01 48	0 280 218 083
113 141 00 25	0 205 003 048
113 141 00 25	0 205 003 049
116 540 06 17	0 265 002 001
116 540 06 17	0 265 002 002
116 540 08 17	0 265 001 001
116 540 08 17	0 265 001 002
116 540 09 17	0 265 001 003
116 540 09 17	0 265 001 004
119 141 00 25	0 205 003 037
119 141 00 25	0 205 003 038
120 141 00 25	0 205 003 039

120 141 00 25	0 205 003 040
124 540 00 17	0 265 002 010
124 540 01 17	0 265 001 111
124 540 01 17	0 265 001 112
124 540 02 17	0 265 001 109
124 540 02 17	0 265 001 110
124 540 02 17	0 265 001 281
124 540 02 17	0 265 001 282
124 540 04 17	0 265 002 021
124 540 04 17	0 265 002 207
124 540 04 17	0 265 002 208
124 540 06 17	0 265 001 154
124 540 06 17	0 265 001 155
124 540 07 17	0 265 001 152
124 540 07 17	0 265 001 153
124 540 10 17	0 265 002 045
124 540 11 17	0 265 002 047
124 540 12 17	0 265 002 049
124 540 14 17	0 265 001 299
124 540 14 17	0 265 001 300
124 540 15 17	0 265 001 297
124 540 15 17	0 265 001 298
124 540 16 17	0 265 001 283
124 540 16 17	0 265 001 284
124 540 17 17	0 265 001 281
124 540 17 17	0 265 001 282
124 540 19 17	0 265 002 079
124 540 19 17	0 265 002 080
124 540 19 17	0 265 002 207
124 540 19 17	0 265 002 208
124 540 20 17	0 265 002 081
124 540 20 17	0 265 002 082
124 540 20 17	0 265 002 209
124 540 20 17	0 265 002 210
124 540 21 17	0 265 002 085
124 540 21 17	0 265 002 086
124 540 21 17	0 265 002 205
124 540 21 17	0 265 002 206
124 540 22 17	0 265 002 083
124 540 22 17	0 265 002 084
124 540 22 17	0 265 002 203
124 540 22 17	0 265 002 204
124 540 23 17	0 265 002 109
124 540 23 17	0 265 002 110
124 540 23 17	0 265 002 237
124 540 23 17	0 265 002 238
124 540 24 17	0 265 002 107
124 540 24 17	0 265 002 108
124 540 24 17	0 265 002 235
124 540 24 17	0 265 002 236
124 540 25 17	0 265 002 115
124 540 25 17	0 265 002 116
124 540 25 17	0 265 002 243
124 540 25 17	0 265 002 244
124 540 27 17	0 265 002 117


124 540 27 17	0 265 002 118
124 540 27 17	0 265 002 245
124 540 27 17	0 265 002 246
124 540 29 17	0 265 006 127
124 540 29 17	0 265 006 128
124 540 30 17	0 265 006 125
124 540 30 17	0 265 006 126
124 540 31 17	0 265 006 110
124 540 31 17	0 265 006 111
124 540 32 17	0 265 006 108
124 540 32 17	0 265 006 109
124 540 34 17	0 265 002 131
124 540 34 17	0 265 002 132
124 540 34 17	0 265 002 253
124 540 34 17	0 265 002 254
124 540 36 17	0 265 001 399
124 540 36 17	0 265 001 400
124 540 37 17	0 265 001 397
124 540 37 17	0 265 001 398
124 800 36 75	0 928 400 237
124 800 37 75	0 928 400 238
126 540 00 17	0 265 002 004
126 540 00 17	0 265 002 005
126 540 01 17	0 265 001 032
126 540 01 17	0 265 001 033
126 540 02 17	0 265 001 020
126 540 02 17	0 265 001 030
126 540 02 17	0 265 001 031
126 540 04 09	0 265 001 009
126 540 04 17	0 265 001 016
126 540 04 17	0 265 001 017
126 540 05 09	0 265 001 011
126 540 05 17	0 265 001 018
126 540 05 17	0 265 001 019
126 540 13 17	0 265 002 012
126 540 15 17	0 265 002 014
126 540 15 17	0 265 002 015
126 540 16 17	0 265 001 015
126 540 16 17	0 265 001 021
126 540 17 17	0 265 001 014
126 540 17 17	0 265 001 020
126 540 18 17	0 265 002 030
126 540 19 17	0 265 002 028
126 540 25 17	0 265 001 279
126 540 25 17	0 265 001 280
126 540 26 17	0 265 001 277
126 540 26 17	0 265 001 278
126 540 30 17	0 265 002 089
126 540 30 17	0 265 002 090
126 540 30 17	0 265 002 259
126 540 30 17	0 265 002 260
126 540 32 17	0 265 002 087
126 540 32 17	0 265 002 088
126 540 32 17	0 265 002 257
126 540 32 17	0 265 002 258

129 540 04 17	0 265 002 035
129 540 05 17	0 265 002 033
129 540 06 17	0 265 002 037
129 540 07 17	0 265 002 032
129 540 08 17	0 265 001 223
129 540 09 17	0 265 001 221
129 540 13 17	0 265 002 069
129 540 13 17	0 265 002 223
129 540 13 17	0 265 002 224
129 540 14 17	0 265 002 067
129 540 14 17	0 265 002 221
129 540 14 17	0 265 002 222
129 540 15 17	0 265 002 051
129 540 15 17	0 265 002 052
129 540 15 17	0 265 002 201
129 540 15 17	0 265 002 202
129 540 16 17	0 265 002 053
129 540 16 17	0 265 002 054
129 540 16 17	0 265 002 213
129 540 16 17	0 265 002 214
129 540 20 17	0 265 002 113
129 540 20 17	0 265 002 114
129 540 20 17	0 265 002 241
129 540 20 17	0 265 002 242
129 540 21 17	0 265 002 111
129 540 21 17	0 265 002 112
129 540 21 17	0 265 002 239
129 540 21 17	0 265 002 240
129 540 26 17	0 265 006 131
129 540 26 17	0 265 006 132
129 540 27 17	0 265 006 129
129 540 27 17	0 265 006 130
129 540 29 17	0 265 006 185
129 540 29 17	0 265 006 186
129 540 30 17	0 265 006 183
129 540 30 17	0 265 006 184
129 540 35 17	0 265 006 279
129 540 35 17	0 265 006 280
129 540 36 17	0 265 006 291
129 540 36 17	0 265 006 292
129 830 00 72	1 147 212 064
130 030 08	0 265 007 717
130 030 09	0 265 007 716
130 030 19	0 265 007 715
130 037 94	0 265 008 044
130 037 95	0 265 008 043
131 098 00 09	0 280 750 039
131 098 00 09	0 280 750 040
131 141 00 25	0 280 750 001
131 141 00 25	0 280 750 002
140 440 07 10	0 265 001 351
140 440 07 32	0 265 001 405
140 440 07 32	0 265 001 406
140 440 08 32	0 265 001 403
140 440 08 32	0 265 001 404



◀ MERCEDES-BENZ

140 440 09 32	0 265 001 401	169 540 04 17	0 265 007 478	202 540 01 17	0 265 002 211	210 540 90 08	0 265 006 190
140 440 09 32	0 265 001 402	169 540 08 17	0 265 007 479	202 540 01 17	0 265 002 212	210 540 91 08	0 265 006 187
140 540 02 17	0 265 002 065	169 540 08 17	0 265 007 480	202 540 02 17	0 265 002 123	210 540 91 08	0 265 006 188
140 540 02 17	0 265 002 219	169 540 11 17	0 265 007 840	202 540 02 17	0 265 002 124	210 540 92 08	0 265 006 175
140 540 02 17	0 265 002 220	169 540 12 17	0 265 007 841	202 540 03 17	0 265 001 359	210 540 92 08	0 265 006 176
140 540 03 17	0 265 002 119	169 540 14 17	0 265 008 064	202 540 03 17	0 265 001 360	211 540 00 17	0 265 007 429
140 540 03 17	0 265 002 120	169 540 15 17	0 265 008 065	202 540 04 17	0 265 001 357	211 540 00 17	0 265 007 433
140 540 03 17	0 265 002 247	201 540 00 17	0 265 002 008	202 540 04 17	0 265 001 358	211 540 04 17	0 265 007 430
140 540 03 17	0 265 002 248	201 540 00 17	0 265 002 009	202 540 05 17	0 265 001 369	211 540 04 17	0 265 007 434
140 540 04 17	0 265 002 097	201 540 01 17	0 265 001 046	202 540 05 17	0 265 001 370	211 540 12 17	0 265 007 496
140 540 07 17	0 265 002 093	201 540 01 17	0 265 001 051	202 540 06 17	0 265 001 367	211 540 12 17	0 265 007 500
140 540 07 17	0 265 002 233	201 540 01 17	0 265 001 128	202 540 06 17	0 265 001 368	211 540 13 17	0 265 007 495
140 540 07 17	0 265 002 234	201 540 02 17	0 265 001 044	202 540 09 17	0 265 001 391	211 540 13 17	0 265 007 499
140 540 08 17	0 265 002 061	201 540 02 17	0 265 001 049	202 540 10 17	0 265 001 389	211 540 18 17	0 265 007 697
140 540 08 17	0 265 002 215	201 540 02 17	0 265 001 114	202 540 12 17	0 265 006 191	211 540 18 17	0 265 007 698
140 540 08 17	0 265 002 216	201 540 07 17	0 265 001 051	202 540 12 17	0 265 006 192	211 540 18 17	0 265 007 720
140 540 09 17	0 265 002 101	201 540 07 17	0 265 001 052	202 540 13 17	0 265 006 171	211 540 19 17	0 265 007 699
140 540 11 17	0 265 002 063	201 540 07 17	0 265 001 117	202 540 13 17	0 265 006 172	211 540 19 17	0 265 007 700
140 540 11 17	0 265 002 217	201 540 07 17	0 265 001 128	202 540 15 17	0 265 006 243	211 540 19 17	0 265 007 721
140 540 11 17	0 265 002 218	201 540 08 17	0 265 001 049	202 540 15 17	0 265 006 244	211 540 23 17	0 265 007 720
140 540 12 09	0 265 001 295	201 540 08 17	0 265 001 050	202 540 16 17	0 265 006 241	211 540 23 17	0 265 007 745
140 540 12 09	0 265 001 296	201 540 08 17	0 265 001 114	202 540 16 17	0 265 006 242	211 540 24 17	0 265 007 721
140 540 13 09	0 265 001 293	201 540 08 17	0 265 001 115	202 540 17 17	0 265 006 247	211 540 24 17	0 265 007 746
140 540 13 09	0 265 001 294	201 540 09 17	0 265 002 023	202 540 17 17	0 265 006 248	211 540 29 17	0 265 008 061
140 540 14 09	0 265 001 307	201 540 10 17	0 265 002 025	202 540 18 17	0 265 006 245	211 540 29 17	0 265 008 097
140 540 15 09	0 265 001 347	201 540 13 17	0 265 002 039	202 540 18 17	0 265 006 246	211 540 30 17	0 265 008 062
140 540 15 09	0 265 001 348	201 540 13 17	0 265 002 040	202 540 20 17	0 265 006 265	211 540 30 17	0 265 008 098
140 540 16 09	0 265 001 345	201 540 13 17	0 265 002 075	202 540 20 17	0 265 006 266	211 540 31 17	0 265 008 063
140 540 16 09	0 265 001 349	201 540 13 17	0 265 002 076	202 540 21 17	0 265 006 263	211 821 19 58	0 265 004 011
140 540 16 09	0 265 001 350	201 540 13 17	0 265 002 229	202 540 21 17	0 265 006 264	212 540 01 17	0 265 008 046
140 540 17 09	0 265 001 349	201 540 13 17	0 265 002 230	202 540 34 17	0 265 006 684	212 540 02 17	0 265 008 045
140 540 17 09	0 265 001 350	201 540 14 17	0 265 002 041	202 540 34 17	0 265 006 685	212 540 03 17	0 265 008 047
140 540 20 17	0 265 006 181	201 540 14 17	0 265 002 231	202 540 71 10	0 265 006 173	212 540 05 17	0 265 008 048
140 540 20 17	0 265 006 182	201 540 15 17	0 265 001 287	202 540 71 10	0 265 006 174	212 540 21 17	0 265 008 047
140 540 21 17	0 265 006 179	201 540 15 17	0 265 001 288	202 540 78 08	0 265 002 125	216 542 00 18	0 265 005 623
140 540 21 17	0 265 006 180	201 540 16 17	0 265 001 285	202 540 78 08	0 265 002 126	216 542 00 18	0 265 005 642
140 540 28 17	0 265 001 409	201 540 16 17	0 265 001 286	202 540 78 08	0 265 002 251	216 542 01 18	0 265 005 640
140 540 28 17	0 265 001 410	201 540 19 17	0 265 002 073	202 540 78 08	0 265 002 252	220 540 01 17	0 265 007 001
140 540 29 17	0 265 001 407	201 540 19 17	0 265 002 074	202 540 79 08	0 265 002 123	220 540 01 17	0 265 007 002
140 540 29 17	0 265 001 408	201 540 19 17	0 265 002 227	202 540 79 08	0 265 002 249	220 540 02 17	0 265 007 001
140 540 34 17	0 265 006 275	201 540 19 17	0 265 002 228	202 540 79 08	0 265 002 250	220 540 02 17	0 265 007 002
140 540 34 17	0 265 006 276	201 540 20 17	0 265 002 071	202 830 04 72	1 147 212 072	220 540 04 17	0 265 007 007
140 540 35 17	0 265 006 273	201 540 20 17	0 265 002 072	207 540 00 17	0 265 008 137	220 540 04 17	0 265 007 008
140 540 35 17	0 265 006 274	201 540 20 17	0 265 002 225	207 540 03 17	0 265 008 139	220 540 05 17	0 265 007 005
156 153 00 28	0 261 230 137	201 540 20 17	0 265 002 226	210 540 06 17	0 265 006 177	220 540 05 17	0 265 007 006
156 153 00 28	0 261 230 138	201 540 22 17	0 265 002 075	210 540 06 17	0 265 006 178	220 540 09 17	0 265 007 105
157 153 00 28	0 261 230 099	201 540 22 17	0 265 002 076	210 540 07 17	0 265 006 193	220 540 10 17	0 265 007 104
157 153 01 28	0 281 002 437	201 540 22 17	0 265 002 229	210 540 07 17	0 265 006 194	220 540 14 17	0 265 007 107
168 540 00 17	0 265 006 369	201 540 22 17	0 265 002 230	210 540 10 17	0 265 006 239	220 540 14 17	0 265 007 108
168 540 00 17	0 265 006 370	201 540 23 17	0 265 002 077	210 540 10 17	0 265 006 240	220 540 17 17	0 265 007 120
168 540 01 17	0 265 006 367	201 540 23 17	0 265 002 078	210 540 48 10	0 265 006 357	220 540 17 17	0 265 007 121
168 540 01 17	0 265 006 368	201 540 23 17	0 265 002 231	210 540 48 10	0 265 006 358	220 540 18 17	0 265 007 122
168 540 03 17	0 265 006 371	201 540 23 17	0 265 002 232	210 540 49 10	0 265 006 355	220 540 18 17	0 265 007 123
168 540 03 17	0 265 006 372	202 540 01 17	0 265 002 121	210 540 49 10	0 265 006 356	220 540 20 17	0 265 007 127
169 540 04 17	0 265 007 477	202 540 01 17	0 265 002 122	210 540 90 08	0 265 006 189	220 540 20 17	0 265 007 128



230 540 01 17	0 265 007 081
230 540 01 17	0 265 007 584
230 540 04 17	0 265 007 080
230 540 04 17	0 265 007 497
230 540 04 17	0 265 007 501

230 540 07 17	0 265 007 497
230 540 07 17	0 265 007 501
230 540 08 17	0 265 007 498
230 540 08 17	0 265 007 502
230 540 08 17	0 265 007 584

230 540 08 17	0 265 007 585
230 540 10 17	0 265 007 584
230 540 10 17	0 265 007 585
230 540 11 17	0 265 007 634
230 540 11 17	0 265 007 635

230 540 12 17	0 265 007 693
230 540 12 17	0 265 007 694
230 540 12 17	0 265 007 695
230 540 12 17	0 265 007 719
230 540 13 17	0 265 007 693

230 540 13 17	0 265 007 695
230 540 13 17	0 265 007 696
230 540 13 17	0 265 007 718
230 540 15 17	0 265 007 718
230 540 15 17	0 265 007 743

230 540 16 17	0 265 007 719
230 540 16 17	0 265 007 744
230 540 19 17	0 265 008 057
230 540 20 17	0 265 008 058
240 540 03 17	0 265 007 435

240 540 05 17	0 265 007 437
240 540 05 17	0 265 007 467
240 540 08 17	0 265 007 701
240 540 09 17	0 265 007 703
240 540 10 17	0 265 008 059

240 540 11 17	0 265 008 060
266 141 05 25	0 280 750 175
266 141 05 25	0 280 750 176
271 141 00 25	0 280 750 076
271 141 00 25	0 280 750 077

273 094 02 48	0 280 218 140
273 094 03 48	0 280 218 139
273 094 03 48	0 280 218 140
273 094 05 48	0 280 218 147
273 094 05 48	0 280 218 148

273 094 05 48	0 280 218 190
273 094 06 48	0 280 218 173
273 094 06 48	0 280 218 174
273 094 06 48	0 280 218 190
273 094 07 48	0 280 218 174

273 094 07 48	0 280 218 180
273 094 07 48	0 280 218 181
273 094 07 48	0 280 218 191
273 094 08 48	0 280 218 180
273 094 08 48	0 280 218 181

273 094 08 48	0 280 218 191
273 094 09 48	0 280 218 190
273 094 09 48	0 280 218 191
275 141 02 25	0 280 750 126
275 141 05 25	0 280 750 125

275 141 06 25	0 280 750 125
275 141 06 25	0 280 750 126
334 039 51	0 265 007 717
334 039 52	0 265 007 716
334 039 63	0 265 007 715

357 540 13 17	0 265 050 120
357 540 14 17	0 265 050 121
408 540 00 17	0 265 002 129
408 540 00 17	0 265 002 275
418 540 00 17	0 265 002 127

418 540 00 17	0 265 002 273
418 540 01 17	0 265 002 128
418 540 01 17	0 265 002 274
427 540 00 17	0 265 002 103
427 540 00 17	0 265 002 269

427 540 01 17	0 265 002 271
437 540 00 17	0 265 002 104
437 540 00 17	0 265 002 270
437 540 01 17	0 265 002 272
451 540 00 17	0 265 007 814

451 540 01 17	0 265 007 815
451 540 02 17	0 265 007 812
451 542 00 18	0 265 005 646
451 542 00 18	0 265 005 688
451 542 01 18	0 265 005 625

451 542 01 18	0 265 005 687
451 542 07 18	0 265 005 789
454 540 02 17	0 265 005 485
454 542 03 18	0 265 007 638
454 542 04 18	0 265 005 289

454 542 04 18	0 265 005 600
454 542 05 18	0 265 007 637
454 542 06 18	0 265 007 683
463 540 01 17	0 265 001 291
463 540 02 17	0 265 001 289

463 540 02 17	0 265 001 290
463 540 03 17	0 265 002 043
463 540 03 17	0 265 002 261
463 540 19 17	0 265 008 015
463 540 20 17	0 265 007 984

463 540 21 17	0 265 007 985
530 130 09 AA	0 281 002 501
602 090 04 66	0 928 400 285
638 540 00 17	0 265 007 422
638 540 01 17	0 265 007 455

638 540 02 17	0 265 007 456
638 542 01 17	0 265 006 196
638 542 02 17	0 265 006 214
638 542 03 17	0 265 006 195
638 542 04 17	0 265 006 215

638 542 07 17	0 265 006 515
639 300 03 04	0 281 002 560
639 300 03 04	0 281 002 561
639 300 04 04	0 281 002 562
639 300 04 04	0 281 002 563

639 300 06 04	0 281 002 561
639 300 07 04	0 281 002 563
639 540 00 17	0 265 007 422
639 540 01 17	0 265 007 455
639 540 02 17	0 265 007 456

639 540 04 17	0 265 007 422
639 540 08 17	0 265 007 643
639 540 09 17	0 265 007 644
639 540 10 17	0 265 007 715
639 540 12 17	0 265 007 717

639 540 13 17	0 265 007 716
639 540 22 17	0 265 008 044
639 540 23 17	0 265 008 043
639 542 00 18	0 265 005 429
642 094 00 48	0 281 002 653

642 094 00 48	0 281 002 654
642 094 01 48	0 281 002 695
642 094 01 48	0 281 002 696
643 540 20 17	0 265 007 984
645 540 05 17	0 265 050 101

646 094 00 48	0 281 002 535
646 094 00 48	0 281 002 536
650 540 01 17	0 265 050 102
650 540 02 17	0 265 050 103
650 540 03 17	0 265 050 122

650 540 04 17	0 265 050 123
650 540 06 17	0 486 000 003
650 540 07 17	0 486 000 004
664 542 77 17	0 206 001 012
677 540 10 17	0 265 050 115

677 540 11 17	0 265 050 116
677 540 12 17	0 265 050 117
677 540 13 17	0 265 050 118
677 540 14 17	0 265 050 119
7 787 023 000	0 206 001 010

7 787 023 000	0 206 001 011
7 787 072 000 0	0 205 001 206
7 787 076 000	0 206 001 012
901 300 04 04	0 281 002 334
901 300 04 04	0 281 002 335

901 300 05 04	0 281 002 336
901 300 05 04	0 281 002 337
901 542 05 18	0 265 004 019
901 542 05 18	0 265 004 022
901 542 08 17	0 265 004 008

901 542 08 17	0 265 004 009
901 542 10 17	0 265 004 007
901 542 11 17	0 265 004 010
901 542 13 18	0 265 004 028
901 542 14 18	0 265 004 029

901 542 15 18	0 265 005 453
901 542 17 17	0 265 004 009
906 300 03 04	0 280 755 025
906 300 04 04	0 280 755 022
906 300 04 04	0 280 755 023

906 540 01 17	0 265 007 659
906 540 02 17	0 265 007 660
906 540 03 17	0 265 007 657
906 540 04 17	0 265 007 979
906 540 11 17	0 265 007 661

906 540 12 17	0 265 007 662
906 540 19 17	0 265 007 880
906 540 20 17	0 265 007 881
906 542 05 18	0 265 005 628

MITSUBISHI	
AW311467	0 280 130 026
CW720411	0 265 006 421
CW720412	0 265 006 422

CW720413	0 265 006 423
CW721199	0 265 006 447
CW721200	0 265 006 448
CW722401	0 265 006 445
CW722402	0 265 006 446

CW725334	0 265 006 520
CW725335	0 265 006 521
CW725336	0 265 006 522
CW725337	0 265 006 523
CW726419	0 265 006 604


CW726420	0 265 006 603
CW743157	F 01G 09F 000
CW743160	F 01G 09F 001
MA 826089	0 265 006 514
MB 928934 V	0 265 006 390

MB 950343	0 265 006 224
MB 950344	0 265 006 223
MB 950345	0 265 006 328
MB 950346	0 265 006 225
ME 016373	9 411 610 560

ME 222926	0 281 002 692
ME 225366	0 281 002 807
ME 226971	0 281 002 928
MN 101778	0 280 755 021
MN 102857	0 265 007 637

MN 116462	0 265 007 683
MN 116637	0 265 007 674
MN 116638	0 265 007 675
MN 116639	0 265 007 676
MN 116640	0 265 007 677

MN 163706	0 261 231 187
MN 180306	0 261 230 125
MN 180306	0 261 230 126
MN 180307	0 232 103 060
MN 180307	0 232 103 061



↕
M

◀ MITSUBISHI	
MN 180314	0 261 231 191
MN 180314	0 261 231 192
MN 180316	0 281 002 704
MN 195775	0 261 230 118
MR 205395	0 265 006 327
MR 205396	0 265 006 294
MR 205397	0 265 006 329
MR 205398	0 265 006 360
MR 249983	0 265 006 513
MR 370932	0 265 006 511
MR 370933	0 265 006 512
MR407654	0 265 006 552
MR407655	0 265 006 553
MR 47523	0 265 006 617
MR 475233 V	0 265 006 617
MR 475234 V	0 265 006 618
MR 47524	0 265 006 618
MR569093	0 265 006 720
MR569094	0 265 006 721
MR 587456	0 265 005 485
MR 955037	0 265 007 638
MR 955352	0 265 005 289
MR 955352	0 265 005 600
MR 977019	F 005 X00 000
MR 985032	0 261 230 118
1525A005	0 280 218 162
1525A005	0 280 218 163
4670 A228	0 265 005 625
530621300	0 265 006 698
8651 A026	0 265 005 504
NISSAN	
16119 1F700	0 280 750 051
16119 1F700	0 280 750 052
16119 1F710	0 280 750 117
16119 1F710	0 280 750 118
16119 25750 2	0 280 750 051
16119 25750 2	0 280 750 052
18002 JK60C	0 280 755 093
18002 1BA0A	0 280 755 109
18002 2X800	0 281 002 590
18002 2X800	0 281 002 591
18919 2J620	0 281 002 250
18919 5M300	0 281 002 425
18919 7F400	0 206 001 022
18919 7F401	0 206 001 022
22365 BN701	0 281 002 552
22365 9X700	0 281 002 456
22620 1F700	0 280 122 014
22630 V9400	0 280 130 057
22630 V9400	0 280 130 063
22630 0M200	0 280 130 081
22630 0M200	0 280 130 082
22630 37950	0 280 130 064
22630 37950	0 280 130 065

22630 70J00	0 280 130 064
22630 70J00	0 280 130 065
22630 99B00	0 280 130 072
22630 99B10	0 280 130 071
22630 99B10	0 280 130 072
22680 AU300	0 280 218 117
22680 AU300	0 280 218 118
22680 F425	0 281 002 208
22680 J5002	0 280 212 012
22680 J7000	0 280 212 012
22680 J7000	0 986 280 128
22680 J7100	0 280 202 111
22680 V5002	0 280 212 012
22680 V5002	0 986 280 128
22680 07F00	0 280 202 111
22680 36550	0 280 218 005
22680 36550	0 280 218 006
22680 36550	0 986 280 232
22680 40F00	0 280 212 012
22680 5M000	0 280 218 152
22680 5M020	0 280 218 171
22680 5U400	0 280 218 094
22680 5U400	0 280 218 095
22680 6N210	0 280 218 096
22680 6N210	0 280 218 097
22680 69T60	0 281 002 466
22680 69T60	0 281 002 467
22680 69T61	0 281 002 663
22680 69T61	0 281 002 664
22680 7F400	0 281 002 176
22680 7F400	0 281 002 207
22680 7F400	0 281 002 208
22680 7F400	0 986 284 012
22680 7F405	0 281 002 595
22680 7F406	0 281 002 596
22680 7F406	0 281 002 597
22680 7F411	0 281 002 440
22680 7F411	0 281 002 441
22680 7F425	0 281 002 207
22680 7F425	0 281 002 208
22680 7J500	0 280 218 025
22680 7J500	0 280 218 026
22680 7J500	0 280 218 096
22680 7J500	0 280 218 097
22680 7J600	0 280 218 005
22680 7J600	0 280 218 006
22680 7J600	0 986 280 232
22680 8J000	0 280 218 154
22680 8J020	0 280 218 172
22680 8U301	0 280 218 150
22680 8U320	0 280 218 170
22731 1F710	0 232 103 033
22731 1F710	0 232 103 034
22771 JG70A	0 281 002 772
23731 1F700	0 261 210 201

23731 1F700	0 261 210 202
23731 1F710	0 232 103 033
23731 1F710	0 232 103 044
23731 1F710	0 232 103 045
23731 9X800	0 281 002 138
25068 89TA0	9 461 614 499
25977 7F405	0 281 002 191
28556 9F207	0 265 001 194
47600 1U200	0 265 214 206
47660 1U600	0 265 025 043
47900 AV700	0 265 007 466
47900 AV710	0 265 007 633
47900 AX600	0 265 007 539
47900 BM500	0 265 006 794
47900 BN800	0 265 007 554
47900 BN805	0 265 007 554
47900 BU800	0 265 007 558
47900 BU805	0 265 007 558
47900 JD000	0 265 007 908
47900 JD600	0 265 007 909
47900 NB805	0 265 007 554
47900-0B101	0 265 001 318
47900 0X800	0 265 006 778
47900 0X900	0 265 006 779
47900-1E400	0 265 003 087
47900 1U200	0 265 006 256
47900 2F000	0 265 006 378
47900 2F001	0 265 006 378
47900 3F001	0 265 006 378
47900 3J310	0 265 006 236
47900 5F600	0 265 006 256
47900 5F605	0 265 006 489
47900 6F005	0 265 006 382
47900 6F605	0 265 001 382
47900 6F605	0 265 006 382
47900 7F000	0 265 006 281
47900 7F200	0 265 006 285
47900 7Z310	0 265 006 607
47900 70J00	0 265 001 275
47900-71J00	0 265 001 314
47900 8B700	0 265 006 450
47900 9F500	0 265 006 709
47900 9X200	0 265 006 718
47900 9X201	0 265 006 719
47900 9X400	0 265 006 716
47900 9X401	0 265 006 717
47900 9X500	0 265 006 819
47900 9X501	0 265 006 820
47901 AV700	0 265 007 465
47901 AV710	0 265 007 632
47901 AX600	0 265 007 538
47901 AX610	0 265 007 538
47901 BM500	0 265 006 795
47901 BN800	0 265 007 555
47901 BN805	0 265 007 555

47901 BU800	0 265 007 559
47901 BU805	0 265 007 559
47901-0B101	0 265 001 319
47901-1E400	0 265 003 088
47901 2F000	0 265 006 379
47901 2F001	0 265 006 379
47901 3J310	0 265 006 237
47901 70J00	0 265 001 276
47901-71J00	0 265 001 315
47901 9F500	0 265 006 708
47910 AV700	0 265 007 464
47910 AX600	0 265 007 537
47910 AX610	0 265 007 537
47910 BM400	0 265 006 703
47910 BN800	0 265 007 522
47910 BN800	0 265 007 552
47910 BU800	0 265 007 556
47910 JD000	0 265 007 905
47910-0B700	0 265 001 393
47910-0B000	0 265 001 316
47910 0X800	0 265 006 755
47910 1B000	0 265 001 415
47910-1E400	0 265 003 085
47910 1F510	0 265 006 715
47910 1U200	0 265 006 254
47910 3J300	0 265 006 232
47910 3J301	0 265 006 232
47910 4U100	0 265 006 633
47910 5F600	0 265 006 254
47910 5M300	0 265 006 606
47910 7B700	0 265 006 608
47910 7F000	0 265 001 413
47910 7F000	0 265 006 671
47910 7F001	0 265 006 671
47910 70J00	0 265 001 273
47910 71J00	0 265 001 312
47911 AV700	0 265 007 463
47911 BM400	0 265 006 702
47911 BN800	0 265 007 553
47911 BU000	0 265 006 704
47911 BU800	0 265 007 557
47911-0B000	0 265 001 317
47911 0L732	0 265 006 524
47911 0M032	0 265 006 449
47911 0X800	0 265 006 756
47911-1E400	0 265 003 086
47911 1F500	0 265 006 658
47911 1F510	0 265 006 714
47911 1U200	0 265 006 255
47911 3J300	0 265 006 233
47911 3J301	0 265 006 233
47911 4U100	0 265 006 632
47911 5F600	0 265 006 255
47911 5M300	0 265 006 605
47911 7B710	0 265 006 536

47911 7F000	0 265 001 414
47911 7F000	0 265 006 670
47911 7F001	0 265 006 670
47911 70J00	0 265 001 274
47911-71J00	0 265 001 313

47911 8B700	0 265 006 453
47930 AV400	0 265 005 265
47930 AX700	0 265 005 259
47930 AX700	0 265 005 263
47930 JD000	0 265 005 156

47930 7F000	0 265 005 037
47930 7F001	0 265 005 037
47930 70J00	0 265 005 019
47931 BC40A	0 265 005 265
47931 JD00A	0 265 005 665

47941 7P100	0 265 005 209
47941 78100	0 265 005 210
47945AS500-C106	F 005 B00 400
47945 JD000	0 265 005 514
47945 7P100	0 265 005 403

82004 17006	1 397 212 084
82005 83498	0 265 008 077
82007 24127	0 265 008 078
92017805	0 280 130 026

OPEL	
X0 501 817	0 280 750 006
08 36 566	0 986 280 140
08 36 574	0 986 280 140

08 36 623	0 986 280 113
08 36 642	0 986 280 113
08 36 643	0 986 280 140
08 958 416	0 280 202 009
08 983 631	0 280 130 023

08 983 636	0 280 120 200
09 118 368	0 261 210 151
09 129 036	0 261 230 026
09 199 636	0 265 005 435
09 281 886	0 280 120 039

10 415 656	0 265 005 410
10 415 656	0 265 005 411
10 456 098	0 261 210 084
12 36 310	0 265 005 425
12 36 310	0 265 005 434

12 38 246	0 265 005 430
12 38 246	0 265 005 435
12 38 247	0 265 005 255
12 38 247	0 265 005 262
12 38 345	0 261 231 006

12 38 358	0 261 210 030
12 38 364	0 261 210 031
12 38 399	0 265 008 089
12 38 410	0 265 003 050
12 38 410	0 265 006 488

12 38 411	0 265 001 236
12 38 412	0 265 001 235
12 38 413	0 265 001 238
12 38 414	0 265 001 237
12 38 557	0 332 514 124

12 38 574	0 332 015 012
12 38 609	0 332 003 023
12 38 627	0 332 514 103
12 38 631	0 332 014 453
12 38 643	0 332 514 109

12 38 782	0 261 210 048
12 38 784	0 265 003 070
12 38 985	0 265 003 094
12 38 986	0 265 003 093
12 38 987	0 265 003 092

12 38 987	0 265 006 487
12 38 988	0 265 003 091
12 38 988	0 265 006 486
12 38 998	0 265 006 488
12 566 845	0 261 231 174

12 580 977	0 280 218 136
12 591 290	0 261 230 146
12 592 525	0 261 230 185
12 789 959	0 261 210 229
12 81 218	0 332 014 453

12 81 797	0 332 514 123
13 103 434	0 265 005 269
13 107 414	0 265 005 448
13 107 803	1 397 212 058
13 107 803	1 697 212 058

13 107 804	1 397 212 056
13 153 362	1 397 212 072
13 153 363	1 397 212 071
13 221 030	0 265 005 608
13 221 030	0 265 005 656

13 241 771	0 280 218 209
13 241 771	0 280 218 210
13 260 662	0 265 008 089
13 261 544	0 280 218 227
13 262 124	0 280 218 208

13 38 440	0 280 130 007
13 38 441	0 280 130 014
13 38 442	0 280 130 014
13 38 443	0 280 130 023
13 38 444	0 280 130 026

13 38 446	0 280 130 032
13 38 451	0 280 130 107
13 38 452	0 280 130 032
14 094 712	0 280 213 004
14 094 712	0 986 280 103

15 875 837	0 280 218 219
17 76 155	0 332 014 151
21 994 504	0 280 218 177
24 402 747	1 397 212 007
24 402 747	1 397 212 009

24 402 747	1 397 212 019
24 402 747	1 397 212 040
24 402 748	1 397 212 007
24 402 748	1 397 212 043
24 402 749	1 397 212 045

24 402 752	1 397 212 007
24 402 861	0 280 218 052
24 413 377	0 265 005 255
24 414 665	0 281 002 428
24 420 400	0 261 210 206

24 420 536	0 280 750 133
24 420 614	0 280 218 119
24 420 696	0 261 231 173
24 420 761	0 281 002 438
24 428 295	0 265 005 415

24 428 295	0 265 005 433
24 430 462	0 265 005 425
24 430 462	0 265 005 434
24 435 990	0 281 002 476
24 437 502	0 281 002 478

24 437 503	0 281 002 479
24 437 651	0 280 218 087
24 439 252	0 281 002 549
24 441 567	0 265 005 430
24 446 586	0 280 750 119

24 456 424	1 397 212 042
24 456 425	1 397 212 044
24 456 426	1 397 212 025
24 456 427	1 397 212 026
24 456 428	1 397 212 046

24 456 764	0 281 002 605
24 459 853	0 281 002 437
24 462 266	0 281 002 564
30 561 772	0 261 210 133
35 25 994	0 265 001 241

40 08 022	0 280 202 020
40 12 053	0 332 014 151
43 63 738	0 265 001 159
5 30 400	0 265 001 056
5 30 401	0 265 001 055

5 30 402	0 265 001 097
5 30 403	0 265 001 143
5 30 404	0 265 001 144
5 30 405	0 265 001 147
5 30 406	0 265 001 145

5 30 408	0 265 001 220
5 30 433	0 265 001 134
5 30 436	0 265 001 206
5 30 437	0 265 001 226
5 30 438	0 265 001 213

5 30 439	0 265 001 207
5 30 440	0 265 001 208
5 30 442	0 265 001 232
5 30 491	0 265 001 233
55 182 636	0 261 231 174

55 182 640	0 261 231 174
55 184 549	0 281 002 617
55 190 587	0 281 002 764
55 194 788	0 281 002 716
55 198 717	0 281 002 771

55 200 301	0 281 002 784
55 30 107	0 265 005 303
55 350 045	0 281 002 619
55 350 047	0 281 002 620
55 350 048	0 281 002 618

55 350 048	0 281 002 683
55 350 433	0 280 218 121
55 351 974	0 280 218 142
55 353 127	0 280 218 121
55 354 601	0 281 002 662

55 557 064	0 281 002 773
55 557 619	0 280 218 164
55 557 619	0 986 280 241
55 558 417	0 281 002 789
55 558 417	0 281 002 802

55 559 313	0 280 218 142
55 559 358	0 261 230 145
55 561 301	0 281 002 832
55 561 301	0 281 002 833
55 561 304	0 281 002 830

55 561 304	0 281 002 831
55 561 912	0 280 218 208
55 561 912	0 281 002 940
55 561 912	0 281 002 941
55 562 389	0 280 218 211


55 562 426	0 281 002 912
55 562 426	0 281 002 913
55 700 425	0 265 007 671
55 700 426	0 265 007 669
55 700 426	0 265 007 769

55 701 387	0 265 007 768
55 702 812	0 265 005 609
55 702 812	0 265 005 657
62 35 620	0 265 005 269
62 35 620	0 265 005 270

62 35 722	0 265 005 608
62 35 722	0 265 005 656
62 357 23	0 265 005 609
62 35 723	0 265 005 657
62 38 162	0 265 005 229

62 38 162	0 265 005 255
62 38 162	0 265 005 261
62 38 162	0 265 005 262
62 38 163	0 265 005 415
62 38 163	0 265 005 433

62 38 255	0 265 005 448
62 38 255	0 265 005 449
62 38 393	0 261 210 048
73 174 462	0 986 280 063
8 12 071	0 280 120 200



◀ OPEL

8 15 615	0 280 202 084
8 15 651	0 280 202 084
8 15 700	0 280 101 001
8 25 463	0 280 122 004
8 26 280	0 280 120 003

8 26 281	0 280 120 039
8 26 282	0 280 120 019
8 26 283	0 280 120 039
8 26 284	0 280 120 200
8 26 285	0 280 120 301

8 26 285	0 280 120 319
8 26 287	0 280 120 405
8 26 288	0 280 120 316
8 26 289	0 280 120 412
8 26 290	0 280 120 326

8 26 291	0 280 120 436
8 26 924	0 280 122 001
8 34 360	0 280 130 006
8 36 401	0 280 130 073
8 36 561	0 280 202 207

8 36 562	0 280 202 208
8 36 562	0 280 202 213
8 36 562	0 986 280 024
8 36 562	0 986 280 025
8 36 565	0 280 217 003

8 36 566	0 280 213 024
8 36 567	0 280 217 106
836 574	0 280 213 024
836584	0 280 218 031
8 36 588	0 280 218 051

836588	0 986 280 231
8 36 592	0 281 002 180
8 36 601	0 280 200 003
8 36 602	0 280 200 003
8 36 603	0 280 202 006

8 36 604	0 280 202 007
8 36 605	0 280 202 009
8 36 606	0 280 202 024
8 36 607	0 280 202 030
8 36 608	0 280 202 033

8 36 609	0 280 202 037
8 36 610	0 280 202 054
8 36 610	0 280 202 074
8 36 611	0 280 202 068
8 36 612	0 280 202 076

8 36 613	0 280 202 053
8 36 614	0 280 202 086
8 36 615	0 280 202 089
8 36 616	0 280 202 084
8 36 617	0 280 202 201

8 36 617	0 986 280 069
8 36 618	0 280 202 202
8 36 620	0 280 202 602
8 36 620	0 986 280 019
8 36 621	0 280 203 032

8 36 621	0 986 280 074
8 36 622	0 280 200 603
8 36 623	0 280 212 015
8 36 624	0 280 202 204
8 36 624	0 986 280 055

8 50 075	0 280 100 005
8 50 077	0 280 100 013
8 50 078	0 280 100 105
8 50 080	0 280 100 124
8 52 185	0 280 130 032

88 960 665	F 00H W00 002
88 960 666	F 00H W00 001
88 960 667	F 00H W00 000
90 003 095	0 332 003 023
90 003 448	0 280 130 014

90 006 052	0 280 202 054
90 008 806	0 280 202 076
90 016 570	0 280 202 007
90 018 835	0 280 130 026
90 019 927	0 280 202 006

90 020 809	0 280 200 003
90 042 050	0 265 003 050
90 042 050	0 265 006 488
90 061 276	0 265 001 097
90 061 297	0 265 001 097

90 062 407	0 265 001 055
90 062 408	0 265 001 056
90 080 939	0 280 130 026
90 094 357	0 280 202 053
90 140 378	0 280 202 024

90 141 745	0 280 120 301
90 187 326	0 280 130 032
90 187 501	0 332 015 012
90 194 931	0 280 202 068
90 210 450	0 265 001 144

90 210 495	0 265 001 147
90 213 477	0 265 001 143
90 213 515	0 261 210 030
90 220 944	0 280 202 202
90 220 944	0 280 202 210

90 220 944	0 986 280 063
90 220 968	0 280 202 202
90232732	0 261 210 031
90 264 609	0 280 202 089
90 264 759	0 280 202 211

90 264 759	0 986 280 091
90 271 067	0 280 202 084
90 272 153	0 280 202 210
90 272 153	0 986 280 063
90 272 154	0 280 202 201

90 272 154	0 986 280 069
90 273 089	0 280 120 405
90 281 021	0 280 101 007
90281818	0 280 202 602
90 281 818	0 986 280 019

90 287 309	0 265 001 206
90 287 310	0 265 001 208
90 287 311	0 265 001 207
90 296 182	0 332 014 151
90 296 998	0 280 200 603

90 298 201	0 261 231 006
90 299 240	0 280 120 326
90 307 088	0 265 001 226
90 307 089	0 265 001 213
90 323 510	0 280 120 412

90 323 839	0 280 122 001
90 337 650	0 261 210 048
90 341 204	0 265 001 235
90 341 206	0 265 001 237
90 346 045	0 265 001 233

90 346 046	0 265 001 232
90 347 697	0 265 003 070
90 350 520	0 280 202 204
90 350 520	0 280 202 211
90 350 520	0 986 280 055

90 350 520	0 986 280 091
90 357 231	0 265 003 094
90 357 232	0 265 003 093
90 357 232	0 265 003 094
90 357 233	0 265 003 092

90 357 233	0 265 006 487
90 357 480	0 232 103 001
90 360 342	0 265 003 095
90 399 364	0 280 202 208
90 399 364	0 280 202 213

90 399 364	0 986 280 024
90 399 364	0 986 280 025
90 399 392	0 280 202 207
90 399 392	0 280 202 212
90 399 392	0 986 280 081

90 401 965	0 232 103 008
90 409 524	0 280 202 208
90 409 524	0 280 202 213
90 409 524	0 986 280 024
90 409 524	0 986 280 025

90 409 525	0 280 202 211
90 409 525	0 986 280 091
90 409 526	0 280 202 207
90 409 526	0 280 202 212
90 409 526	0 986 280 081

90 410 792	0 280 130 107
90 410 793	0 280 130 032
90 410 793	0 280 130 069
90 411 537	0 280 217 503
90 423 088	0 280 130 039

90 423 637	0 261 230 042
90 423 761	0 280 218 051
90 423 761	0 280 218 061
90 423 761	0 986 280 231
90 423 807	0 280 750 084

90 442 182	0 280 130 073
90 443 390	0 265 001 236
90 443 391	0 265 003 050
90 443 391	0 265 006 488
90 448 661	0 205 001 019

90 448 964	0 280 217 106
90 449 573	0 232 103 002
90 449 573	0 232 103 016
90 451 441	0 261 210 030
90 459 666	0 265 001 220

90 464 741	0 281 002 138
90483739	0 261 210 048
90 486 133	0 280 122 004
90 487 306	0 280 212 015
90 487 306	0 986 280 113

90 490 042	0 261 231 115
90 490 043	0 261 210 132
90 490 166	0 232 103 016
90 490 185	0 280 130 093
90 490 496	0 261 210 169

90 491 965	0 232 103 008
90 494 182	0 261 210 131
90 499 610	0 261 230 009
90 501 816	0 205 001 039
90 502 544	0 205 001 042

90 502 696	0 261 230 015
90 505 794	0 232 103 007
90 505 794	0 232 103 021
90 505 795	0 232 103 011
90 506 101	0 232 103 015


90 509 164	0 205 001 019
90 510 127	0 232 103 002
90 510 127	0 232 103 016
90 510 151	0 280 203 032
90 510 151	0 986 280 074


90 510 152	0 280 213 024
90 510 152	0 986 280 140
90 510 153	0 280 217 003
90 510 154	0 280 217 106
90 510 156	0 280 217 503

90 510 182	0 280 130 032
90 510 182	0 280 130 069
90 510 183	0 280 130 068
90 510 183	0 280 130 107
90 510 188	0 265 003 094

90 510 188	0 265 006 466
90 510 189	0 265 003 092
90 510 189	0 265 006 487
90 510 190	0 265 001 134
90 510 208	0 265 001 220

90 510 275	0 265 003 091
90 510 275	0 265 006 486
90 510 281	0 261 231 006
90 510 656	0 232 103 011
90 510 657	0 232 103 007





90 510 667	0 232 103 008
90 510 884	0 265 003 070
90 511 177	0 261 231 079
90 512 567	0 205 001 039
90 528 254	0 281 002 139

90 528 435	0 281 002 184
90 529 471	0 205 003 050
90 529 673	0 280 217 123
90 530 434	0 261 231 116
90 530 439	0 280 122 014

90 530 442	0 280 217 519
90 530 767	0 281 002 180
90 530 838	0 281 002 236
90 530 839	0 281 002 237
90 532 619	0 261 210 151

90 540 188	0 281 002 138
90 540 695	0 205 001 042
90 540 743	0 261 210 131
90 540 744	0 232 103 017
90 540 931	0 281 002 139

90 541 290	0 265 003 093
90 541 298	0 261 231 115
90 541 409	0 281 002 137
90 541 502	0 280 122 014
90 541 520	0 280 130 093

90 541 521	0 261 231 116
90 541 577	0 280 130 039
90 541 590	0 280 130 092
90 541 591	0 280 217 519
90 541 609	0 261 230 015

90 542 063	0 281 002 170
90 543 282	0 280 217 123
90 543 463	0 281 002 180
90 543 510	0 261 231 120
90 560 111	0 232 103 021

90 563 161	0 232 103 017
90 570 185	0 281 002 170
90 571 550	0 280 752 007
90 572 503	0 261 231 120
90 573 217	0 281 002 259

90 581 208	0 281 002 298
90 581 208 AQ	0 281 002 298
90 581 216	0 281 002 299
91 153 350	0 205 001 055
91 153 352	0 205 001 054

91 153 783	0 281 002 144
91 153 947	0 232 103 016
91 17 449	0 281 002 259
91 17 763	0 261 230 009
91 17 961	0 281 002 278

91 17 962	0 281 002 236
91 17 963	0 281 002 277
91 17 964	0 281 002 237
91 18 140	0 232 103 025
91 18 150	0 281 002 285

91 18 160	0 281 002 298
91 18 161	0 281 002 299
91 18 368	0 261 210 151
91 18 374	0 232 103 021
91 18 549	0 265 006 488

91 18 849	0 280 750 006
91 19 062	0 281 002 296
91 19 063	0 281 002 297
91 19 075	0 280 752 006
91 28 412	0 280 750 006

91 28 434	0 280 752 006
91 28 851	0 281 002 278
91 28 852	0 281 002 277
91 29 106	0 281 002 297
91 29 107	0 281 002 296

91 34 756	0 261 210 183
91 46 032	0 232 103 025
91 57 512	0 280 750 044
91 58 595	0 281 002 437
91 81 239	0 265 005 229

91 81 239	0 265 005 255
91 81 239	0 265 005 261
91 81 239	0 265 005 262
91 81 240	0 265 005 415
91 81 240	0 265 005 433

91 93 119	0 265 005 415
91 93 119	0 265 005 433
91 93 149	0 280 218 031
91 93 149	0 986 280 230
91 93 276	0 280 752 027

91 93 277	0 281 002 604
91 93 533	0 281 002 184
91 95 066	0 280 130 094
91 95 630	0 265 005 229
91 95 630	0 265 005 255

91 95 630	0 265 005 261
91 95 630	0 265 005 262
91 95 631	0 265 005 415
91 95 631	0 265 005 433
91 95 729	0 281 002 428

91 95 883	0 261 210 183
91 95 885	0 261 210 169
91 96 400	0 265 005 303
91 96 671	0 281 002 437
91 96 724	0 281 002 476

91 98 639	0 261 210 206
91 99 636	0 265 005 430
91 99 636	0 265 005 435
91 99 886	1 397 212 007
92 00 584	0 265 005 425

92 00 584	0 265 005 434
92 01 175	0 280 750 084
92 01 425	0 280 218 051
92 01 425	0 986 280 231
92 017 809	0 280 202 052

92 02 252	0 280 752 027
92 02 253	0 281 002 604
92 04 425	0 280 218 051
92 04 425	0 986 280 231
92 061 913	0 261 231 007

92 27 760	0 280 218 031
92 27 760	0 986 280 230
92 28 959	1 397 212 009
92 92 698	0 280 120 021
92 92 698	0 280 120 022

93 170 202	1 397 212 040
93 170 245	1 397 212 043
93 170 246	1 397 212 044
93 170 309	0 261 230 042
93 170 362	0 265 005 255

93 170 362	0 265 005 262
93 171 176	0 281 002 437
93 171 184	1 397 212 042
93 171 185	1 397 212 025
93 171 355	0 281 002 428

93 171 356	0 281 002 180
93 171 527	0 281 002 478
93 171 627	0 281 002 478
93 171 748	1 397 212 009
93 171 749	1 397 212 026

93 171 760	0 281 002 184
93 172 012	0 263 003 208
93 172 747	0 280 218 087
93 172 949	0 265 005 448
93 172 949	0 265 005 449

93 173 727	0 281 002 479
93 174 460	0 986 280 091
93 174 461	0 986 280 024
93 174 462	0 986 280 064
93 174 464	0 986 280 024

93 174 465	0 986 280 063
93 174 628	0 281 002 564
93 176 039	0 232 103 015
93 176 086	0 281 002 605
93 177 171	0 261 231 173

93 177 196	0 265 005 269
93 177 196	0 265 005 270
93 177 365	0 281 002 534
93 177 414	0 281 002 510
93 177 718	0 281 002 549

93 178 050	0 281 002 620
93 178 243	0 281 002 618
93 178 244	0 281 002 619
93 178 598	0 986 280 113
93 178 599	0 986 280 113

93 178 600	0 986 280 140
93 178 601	0 986 280 140
93 178 788	1 397 212 056
93 179 433	0 281 002 603
93 179 513	0 281 002 213

93 179 850	0 281 002 662
93 179 927	0 280 218 119
93 180 105	0 261 231 181
93 180 268	0 261 002 617
93 180 268	0 281 002 617

93 180 405	0 261 231 181
93 180 922	0 280 218 142
93 180 992	0 280 218 142
93 181 025	0 280 750 133
93 181 894	0 280 218 211

93 181 944	0 281 002 716
93 183 528	0 232 103 052
93 183 599	1 397 212 072
93 183 600	1 397 212 071
93 185 444	0 281 002 773

93 185 455	0 280 218 136
93 185 556	0 281 002 784
93 185 626	0 281 002 706
93 186 084	0 280 218 164
93 186 084	0 986 280 241

93 186 483	0 281 002 789
93 186 840	0 232 103 067
93 187 126	0 265 005 608
93 187 126	0 265 005 656
93 187 247	0 281 002 771

93 188 239	0 265 005 609
93 188 239	0 265 005 656
93 188 239	0 265 005 657
93 188 724	0 281 002 833
93 189 202	0 261 231 174

93 189 275	0 265 007 671
93 189 276	0 265 007 768
93 189 276	0 265 007 896
93 189 277	0 265 007 769
93 189 506	0 263 003 472

93 189 955	0 281 002 831
93 190 052	0 281 002 844
93 191 478	0 265 008 089
93 192 107	0 261 230 146
93 192 439	0 265 008 077

93193710	0 261 231 201
93194121	0 281 002 770
93194121	0 281 002 771
93194419	0 261 230 197
93 194 900	0 265 008 078

93 232 413	0 261 210 128
93 243 251	0 261 210 150
93 245 824	0 280 217 525
93 245 824	0 280 217 526
93 294 467	0 265 006 488

93 310 500	0 232 103 067
93 328 218	0 281 002 579
93 388 248	0 280 750 153
93 399 801	0 261 230 099
93 399 899	0 261 231 176

◀ OPEL

93 857 508	1 397 212 084
93 857 938	0 281 002 566
93 858 411	0 265 008 077
93 860 619	0 265 008 078

PEUGEOT

A 040 296	0 261 211 003
DX 144 119 A	0 280 100 023
DX 144 224 A	0 280 120 011

DX 144 228 A	0 280 130 009
DX 144 228 A	0 280 130 014
DX 144 263 A	0 280 100 011
DX 144 263 B	0 280 100 023
DX 524 101 A	0 332 003 021

V7 535 069	0 261 230 134
V7 540 508	0 261 230 135
V7 552 114	0 261 231 197
V7 552 114	0 261 231 198
0242 46	0 280 130 026

0242 62	0 280 130 032
1066 63	0 280 755 046
1192 W5	0 281 002 184
1452 05	0 280 230 006
1452 10	0 280 230 010

14 808 450	0 265 006 426
14 808 460 80	0 265 006 388
14 888 410	0 265 007 083
14 916 610	0 265 006 730
14 916 620	0 265 006 731

14 938 820	0 265 007 083
1601 G4	0 280 755 019
1601 G5	0 280 755 039
1601 K7	0 280 752 235
1601 K7	0 280 752 251

1601 K8	0 280 752 236
1601 K9	0 280 752 237
1601 L1	0 280 752 240
1601 L4	0 280 752 243
1601 N4	0 280 752 247

1601 N5	0 280 752 241
1601 N6	0 280 752 242
1601 N7	0 280 752 260
1601 N7	0 280 755 029
1601 N8	0 280 755 030

1601 N9	0 280 752 258
1601 P3	0 280 755 000
1601 P3	0 280 755 001
1601 P4	0 280 752 279
1601 P5	0 280 755 015

1601 P6	0 280 752 283
1601 P7	0 280 755 016
1601 P8	0 280 755 007
1601 Q0	0 280 755 005
1601 Q1	0 280 755 010

1601 Q1	0 280 755 011
1601 Q2	0 280 755 026
1601 Q3	0 280 755 027
1601 Q3	0 280 755 044
1601 Q4	0 280 755 012

1601 Q5	0 280 755 013
1601 Q6	0 280 755 018
1601 Q8	0 280 755 040
1601 R2	0 280 755 046
1601 S0	0 280 755 031

1601 S1	0 280 755 032
1601 S2	0 280 755 033
1601 S3	0 280 755 044
1601 S4	0 280 755 045
1601 T1	0 280 755 074

1601 T2	0 280 755 075
1601 T3	0 280 755 076
1601 T4	0 280 755 077
1601 T6	0 280 755 041
1601 T7	0 280 755 081

1601 T8	0 280 755 035
1601 T9	0 280 755 037
1601 V0	0 280 755 036
1601 V1	0 280 755 038
1601 X6	0 280 755 078

1601 X7	0 280 755 079
1601 X7	0 280 755 080
1601 X8	0 280 755 095
1601 X9	0 280 755 097
1621 28	0 261 211 003

1622 C9	0 205 001 015
1625 90	0 280 230 101
1628 A3	0 280 120 310
1628 C5	0 281 002 029
1628 C6	0 281 002 018

1628 G4	0 280 120 327
1628 K9	0 280 120 323
1628 L1	0 280 122 001
1628 1E	0 280 122 003
1628 1F	0 280 122 005

1628 27	0 280 120 305
1628 50	0 280 120 301
1628 54	0 281 002 008
1628 8V	0 280 122 009
1635 P3	0 280 750 041

1635 Q9	0 280 750 085
1635 28	0 280 750 164
1636 37	0 280 750 164
18 593 070	0 263 003 246
1920 AC	0 261 230 041

1920 AC	0 261 230 058
1920 AJ	0 261 230 043
1920 AN	0 261 230 057
1920 C6	0 280 202 118
1920 C6	0 986 280 057

1920 FK	0 281 002 492
1920 FR	0 261 231 168
1920 FR	0 261 231 169
1920 H9	9 465 160 006
1920 KZ	0 261 230 135

1920 K8	0 261 230 004
1920 K8	0 261 230 037
1920 LA	0 261 230 131
1920 LA	0 261 230 132
1920 LS	0 232 103 064

1920 LT	0 261 231 197
1920 LT	0 261 231 198
1920 LW	0 261 230 136
1920 PY	0 261 230 156
1920 T7	0 281 002 063

1920 T7	0 281 002 063
1920 Z1	0 281 002 128
1920 OE	0 261 230 012
1920 OG	0 280 122 011
1920 1K	0 261 230 034

1920 1K	0 261 230 057
1920 27	0 438 120 065
1920 29	0 280 202 044
1920 3L	0 281 002 122
1920 34	0 280 202 051

1920 34	0 986 280 051
1920 46	0 280 202 056
1920 46	0 986 280 028
1920 49	0 280 202 057
1920 50	0 280 101 001

1920 55	0 438 120 200
1920 66	0 280 202 070
1920 68	0 280 202 098
1920 7R	0 281 002 283
1920 7R	0 281 002 592

1920 70	0 280 202 097
1920 70	0 986 280 070
1920 76	0 280 213 006
1920 76	0 986 280 115
1920 80	0 280 202 109

1920 80	0 986 280 013
1920 9H	0 261 230 012
1920 91	0 280 202 602
1920 91	0 986 280 019
1920 93	0 280 202 202

1920 93	0 280 202 210
1920 93	0 986 280 063
1921 01	0 438 120 120
1921 10	0 438 120 099
1921 24	0 438 120 119

1921 33	0 438 120 153
1921 42	0 438 120 161
1921 96	0 438 120 068
1922 R6	0 261 230 134
1929 03	0 132 009 305

1929 03	0 281 002 031
20 100 255	0 263 003 267
20 100 257	0 263 003 266
20 100 258	0 263 003 268
20 100 259	0 263 003 274

20 100 260	0 263 003 271
20 100 261	0 263 003 272
20 100 263	0 263 003 273
20 100 264	0 263 003 263
20 100 265	0 263 003 264

20 100 266	0 263 003 265
20 100 267	0 263 003 269
20 100 758	0 263 003 246
20 100 975	0 263 003 334
35 429 03	0 263 003 246

4472 80	0 280 750 085
4545 A4	0 265 006 732
4545 A8	0 265 006 793
4545 C2	0 265 007 664
4545 C3	0 265 007 663

4545 C3	0 265 007 780
4545 C4	0 265 007 645
4545 C4	0 265 007 779
4545 C7	0 265 007 665
4545 C8	0 265 007 666

4545 C9	0 265 007 668
4545 E0	0 265 007 667
4545 E1	0 265 007 687
4545 E2	0 265 007 688
4545 E3	0 265 005 486


4545 E5	0 265 007 707
4545 E6	0 265 007 883
4545 E7	0 265 007 788
4545 E8	0 265 007 789
4545 E9	0 265 007 790

4545 F0	0 265 007 791
4545 F6	0 265 008 017
4545 F7	0 265 008 018
4545 F8	0 265 008 018
4545 F9	0 265 005 486


4545 G9	0 265 007 130
4545 H0	0 265 007 131
4545 H7	0 265 008 018
4545 H8	0 265 005 517
4545 04	0 204 154 008


4545 04	0 204 154 008
4545 05	0 204 154 003
4545 05	0 204 154 003
4545 06	0 204 154 002
4545 06	0 204 154 002

4545 09	0 204 154 028
4545 09	0 204 154 028
4545 10	0 204 154 011
4545 10	0 204 154 011
4545 11	0 265 003 064



4545 12	0 265 003 065	4545 36	0 265 006 202	4549 05	0 265 005 290	6405 Y4	1 397 212 112
4545 13	0 204 154 018	4545 37	0 265 003 123	4549 07	0 265 005 253	6405 Y5	1 397 212 086
4545 13	0 204 154 018	4545 37	0 265 006 314	4549 07	0 265 005 290	6505 Q5	1 397 212 076
4545 14	0 204 154 014	4545 38	0 204 154 024	4549 16	0 265 005 290	6505 Q6	1 397 212 076
4545 14	0 204 154 014	4545 38	0 204 154 024	4549 17	0 265 005 606	6555 20	0 280 230 112
4545 15	0 204 154 007	4545 39	0 204 154 025	4549 21	0 265 005 715	6555 22	0 280 230 009
4545 15	0 204 154 007	4545 39	0 204 154 025	4549 26	0 265 005 291	6555 47	0 280 230 014
4545 16	0 204 154 009	4545 40	0 204 154 020	4549 26	0 265 005 714	6590 A5	0 263 003 246
4545 16	0 204 154 009	4545 41	0 204 154 027	4549 27	0 265 005 292	72 408 124	0 280 122 001
4545 17	0 204 154 015	4545 41	0 204 154 027	4549 28	0 265 005 629	72 408 254	0 280 120 400
4545 17	0 204 154 015	4545 42	0 204 154 026	4549 33	0 265 005 629	72 408 654	0 280 122 011
4545 19	0 204 154 013	4545 44	0 265 006 201	4549 39	0 265 005 714	72 408 744	0 280 122 009
4545 19	0 204 154 013	4545 44	0 265 006 201	4549 41	0 265 005 703	72 408 754	0 280 122 010
4545 21	0 265 003 072	4545 45	0 265 006 200	4549 43	0 265 005 724	74 013 460 30	0 280 130 032
4545 21	0 265 003 126	4545 46	0 265 006 202	4574 03	0 261 230 058	74 013 676 43	0 261 231 007
4545 21	0 265 003 126	4545 47	0 265 006 199	4649 28	0 265 005 629	74 013 676 45	0 261 210 029
4545 21	0 265 006 207	4545 48	0 265 006 205	5007 99	0 280 122 003	77 002 672 69	0 280 230 112
4545 22	0 265 003 073	4545 49	0 265 006 206	5 412 358	0 280 130 014	77 007 723 10	0 265 001 068
4545 22	0 265 003 127	4545 50	0 265 006 203	5 412 360	0 280 130 006	82 001 893 85	0 280 750 155
4545 22	0 265 006 208	4545 51	0 265 006 204	5 412 361	0 280 120 011	8334 57	0 281 002 804
4545 23	0 265 003 080	4545 55	0 265 006 207	5 412 361	0 280 120 018	8334 57	0 281 002 919
4545 23	0 265 003 123	4545 56	0 265 006 202	5 413 479	0 280 100 036	91 000 407 80	0 280 202 051
4545 23	0 265 006 314	4545 56	0 265 006 208	5 422 133	0 332 003 021	91 000 407 80	0 986 280 051
4545 24	0 265 003 081	4545 60	0 265 006 314	5 429 448	0 280 100 048	91 000 409	0 280 230 006
4545 24	0 265 003 125	4545 60	0 265 006 314	5 472 928	0 332 514 103	91 000 409 80	0 280 230 006
4545 25	0 265 005 105	4545 61	0 265 006 315	5 489 066	0 280 202 005	91 040 296 80	0 261 211 003
4545 25	0 265 005 111	4545 61	0 265 006 315	5 500 350	0 280 120 200	91 040 370	0 280 130 026
4545 26	0 204 154 016	4545 62	0 265 006 209	5 502 644	0 280 130 023	91 040 398	0 281 002 030
4545 26	0 204 154 016	4545 63	0 204 154 038	5918 73	0 281 002 030	91 166 609	1 397 212 039
4545 27	0 204 150 083	4545 63	0 204 154 038	5918 79	0 261 210 029	91 207 837	0 281 002 018
4545 27	0 204 150 083	4545 66	0 265 006 389	5918 80	0 261 210 043	91 414 549	0 280 130 026
4545 27	0 204 154 040	4545 67	0 265 006 388	5918 84	0 261 210 029	91 508 771 80	0 280 230 101
4545 27	0 204 154 040	4545 67	0 265 006 388	5946 03	0 261 231 006	91 508 772 80	0 280 230 100
4545 28	0 265 003 100	4545 68	0 265 006 426	5946 05	0 261 231 007	91 512 716	0 280 230 101
4545 28	0 265 003 124	4545 68	0 265 006 426	5946 15	0 261 231 071	91 512 716 80	0 280 230 101
4545 28	0 265 003 124	4545 69	0 265 006 441	5946 17	0 261 231 071	91 513 886 80	0 280 230 104
4545 28	0 265 006 315	4545 69	0 265 006 441	5946 18	0 261 231 070	91 514 547 80	0 280 202 044
4545 29	0 204 154 017	4545 70	0 265 006 427	5946 21	0 261 231 045	91 514 878 80	0 261 231 001
4545 29	0 204 154 017	4545 70	0 265 006 427	5946 22	0 261 231 109	91 514 880	0 261 231 006
4545 30	0 204 154 029	4545 71	0 265 006 405	5946 25	0 261 231 125	91 516 985	0 280 202 056
4545 30	0 204 154 029	4545 72	0 265 006 406	5946 28	0 261 231 128	91 516 985	0 986 280 028
4545 31	0 265 003 099	4545 75	0 265 006 504	5946 30	0 261 231 130	91 517 923 80	0 280 230 010
4545 31	0 265 003 131	4545 78	0 265 006 389	6401 L3	1 397 212 039	91 517 932	0 280 230 010
4545 31	0 265 006 201	4545 82	0 265 006 544	6405 C0	1 397 212 000	91 517 932 80	0 280 230 010
4545 32	0 265 003 130	4545 83	0 265 006 545	6405 C0	1 397 212 000	91 518 192	0 280 101 001
4545 32	0 265 006 200	4545 84	0 265 005 404	6405 E8	1 397 212 002	91 518 192 80	0 280 101 001
4545 33	0 265 003 079	4545 85	0 265 006 659	6405 G0	1 397 212 001	91 518 194 80	0 280 202 057
4545 33	0 265 003 129	4545 88	0 265 007 423	6405 G5	1 397 212 006	91 519 925	0 280 120 310
4545 33	0 265 006 202	4545 89	0 265 007 424	6405 HK	1 397 212 132	91 519 925 80	0 280 120 310
4545 34	0 265 003 106	4545 89	0 265 007 424	6405 L3	1 397 212 039	91 520 606 80	0 280 202 075
4545 34	0 265 003 106	4545 92	0 265 006 730	6405 Q2	1 397 212 064	91 527 047	0 281 002 018
4545 34	0 265 006 204	4545 93	0 265 006 731	6405 Q3	1 397 212 060	91 536 076	0 280 202 602
4545 35	0 265 003 128	4545 94	0 265 007 083	6405 Q7	1 397 212 074	91 536 076	0 986 280 019
4545 35	0 265 006 199	4545 95	0 265 007 084	6405 R9	1 397 212 083	91 537 218 80	0 280 202 070
4545 36	0 265 003 129	4549 05	0 265 005 211	6405 W9	1 397 212 109	91 537 485	0 132 009 305





◀ PEUGEOT

91 537 485 80	0 132 009 305
91 537 516	0 281 002 029
91 537 516 80	0 281 002 029
91 538 877	0 280 202 097
91 538 877	0 986 280 070

91 539 005 80	0 280 202 098
91 540 545 80	0 280 202 109
91 540 545 80	0 986 280 013
91 541 027	0 261 210 043
91 541 738	0 280 202 202

91 548 738	0 261 210 043
92 526 538	0 332 014 151
92 526 538 80	0 332 014 151
93 011 154	0 281 002 008
93 327 326	0 265 006 389

95 496 103	0 280 202 047
95 496 375	0 280 202 021
95 496 621	0 280 230 009
95 567 200	0 280 120 301
95 567 200 80	0 280 120 310

95 572 330	0 332 514 130
95 572 333	0 332 514 130
95 598 944	0 280 202 073
95 605 079	0 280 202 061
95 605 079	0 280 202 064

95 605 079	0 986 280 041
95 605 084	0 280 120 313
95 610 350	0 265 001 098
95 635 036	0 280 202 099
95 635 037	0 280 120 312

95 635 037	0 280 120 317
95 635 040	0 280 202 100
95 635 043	0 280 202 101
95 635 045	0 280 120 318
95 637 307	0 265 001 157

95 637 307	0 265 001 245
95 638 095	0 265 001 158
95 640 366	0 281 002 037
96 000 118	0 204 154 010
96 013 294	0 280 230 014

96 015 940	0 280 120 327
96 035 417	0 280 202 118
96 035 417	0 986 280 057
96 037 065	0 261 231 034
96 037 068	0 261 231 033

96 038 938	0 280 122 001
96 039 179	0 280 202 118
96 039 179	0 986 280 057
96 046 811	0 204 154 012
96 056 021	0 280 120 323

96 067 683	0 204 154 010
96 067 694	0 204 154 012
96 071 329	0 265 003 065
96 075 741	0 204 154 010
96 081 740	0 280 120 327

96 086 319	0 265 005 111
96 086 319 80	0 265 005 105
96 087 509	0 265 003 078
96 087 509	0 265 003 128
96 087 509	0 265 006 199

96 089 629	0 265 003 079
96 089 629	0 265 003 129
96 089 629	0 265 006 202
96 099 080	0 204 154 016
96 105 849	0 265 003 072

96 105 849	0 265 003 126
96 105 849	0 265 006 207
96 105 850	0 265 003 073
96 105 850	0 265 003 127
96 105 850	0 265 006 208

96 105 926	9 456 160 006
96 105 926	9 465 160 006
96 106 029	0 265 003 081
96 106 029	0 265 003 125
96 106 095	0 265 003 080

96 106 095	0 265 003 123
96 106 095	0 265 006 314
96 107 893	0 261 230 004
96 109 509	0 281 002 063
96 127 657	0 261 231 071

96 127 657	0 261 231 106
96 127 658	0 261 231 070
96 127 658	0 261 231 105
96 128 155	0 265 003 064
96 128 156	0 265 003 080

96 128 156	0 265 003 123
96 128 156	0 265 006 314
96 131 470	0 280 130 084
96 140 648	0 265 003 099
96 140 648	0 265 003 131

96 140 648	0 265 006 201
96 149 640	0 205 001 015
96 161 385	0 204 154 010
96 165 516	0 265 003 105
96 165 516	0 265 003 130

96 165 516	0 265 003 130
96 165 516	0 265 006 200
96 168 084	0 261 231 045
96 180 488	0 265 003 128
96 180 488	0 265 006 199

96 181 977	0 265 003 130
96 181 977	0 265 003 131
96 181 977	0 265 006 200
96 181 977	0 265 006 201
96 181 978	0 265 003 130

96 181 978	0 265 006 200
96 181 979	0 265 003 130
96 181 979	0 265 003 131
96 181 979	0 265 006 200
96 181 979	0 265 006 201

96 182 000	0 265 003 125
96 182 615	0 261 230 012
96 183 217	0 265 006 205
96 183 261	0 265 006 206
96 191 116	0 281 002 063

96 195 593	0 281 002 119
96 195 593	0 281 002 122
96 210 452	0 265 005 111
96 210 838	1 397 212 000
96 211 621	0 281 002 128

96 217 750	0 265 006 201
96 217 752	0 265 006 200
96 217 753	0 265 006 202
96 217 755	0 265 006 204
96 217 756	0 265 006 203

96 217 759	0 265 006 199
96 217 763	0 265 006 207
96 217 765	0 265 006 208
96 218 046	0 265 006 209
96 227 489	0 265 006 203

96 252 846	0 265 006 205
96 255 387	0 265 006 315
96 255 404	0 265 006 314
96 272 628	0 265 006 205
96 275 932	0 261 231 128

96 280 713	0 265 006 389
96 286 482	0 261 231 130
96 286 483	0 261 231 127
96 286 484	0 261 231 125
96 286 689	1 397 212 001

96 295 910	0 280 750 041
96 297 255	0 265 006 441
96 300 147	0 265 005 404
96 303 414	0 265 005 211
96 303 414	0 265 005 290

96 305 913	1 397 212 002
96 317 068	0 265 006 544
96 317 069	0 265 006 545
96 318 136	0 261 230 057
96 337 132	1 397 212 004

96 343 935	1 397 212 002
96 343 935	1 397 212 006
96 353 847	0 265 007 423
96 353 848	0 265 007 424
96 354 934	0 261 230 058

96 358 840	0 280 750 085
96 365 830	0 261 230 043
96 382 908	0 265 006 659
96 384 235	0 261 231 128
96 386 487	0 265 007 423

96 393 814	0 261 230 043
96 394 188	0 261 230 057
96 394 189	0 261 230 058
96 394 190	0 261 230 057
96 394 191	0 261 230 058

96 411 890	1 397 212 004
96 411 890	1 397 212 039
96 411 890	1 397 212 060
96 415 250	0 265 005 253
96 415 250	0 265 005 290

96 430 590	0 280 752 235
96 430 591	0 280 752 247
96 430 592	0 280 752 236
96 430 732	0 280 752 238
96 430 847	0 280 752 237

96 430 848	0 280 752 248
96 430 934	0 280 752 240
96 431 704	0 265 006 732
96 434 731	0 280 752 243
96 436 596	0 265 007 423

96 436 605	0 265 007 424
96 436 880	0 265 007 424
96 436 977	0 265 007 423
96 440 934	0 280 752 240
96 442 063	0 261 230 085

96 442 066	0 261 230 085
96 449 305	0 280 752 242
96 449 396	0 280 752 241
96 449 667	0 265 007 423
96 449 668	0 265 007 424

96 453 114	0 261 231 169
96 454 477	0 265 005 253
96 454 477	0 265 005 290
96 458 515	0 280 752 235
96 458 522	0 280 752 237

96 461 258	0 265 007 645
96 461 258	0 265 007 779
96 464 045	0 280 755 016
96 466 196	1 397 212 050
96 467 021	0 280 752 251

96 467 555	1 397 212 039
96 468 373	1 397 212 050
96 469 709	0 265 007 668
96 469 711	0 265 007 667
96 469 712	0 265 007 665

96 469 725	0 265 007 666
96 471 352	0 280 752 279
96 475 755	0 280 752 258
96 476 944	1 397 212 060
96 477 813	0 280 752 259

96 477 813	0 280 752 260
96 477 813	0 280 755 029
96 477 814	0 280 752 262
96 477 967	0 280 752 264
96 477 967	0 280 755 028

96 480 873	0 265 006 793
96 488 392	0 280 755 029
96 489 571	0 280 755 006
96 489 571	0 280 755 007
96 494 001	0 265 005 291

96 494 001	0 265 005 714
96 495 100	0 280 750 164
96 496 14 1 77	0 263 003 476
96 497 761	0 265 005 606
96 498 334	1 397 212 064

96 499 043	0 265 005 292
96 502 357	0 265 005 290
96 502 361	0 265 005 486
96 503 417	0 280 755 012
96 503 418	0 280 755 013

96 504 521	0 265 005 290
96 508 818	0 280 755 000
96 508 818	0 280 755 001
96 508 891	0 280 755 000
96 508 891	0 280 755 001

96 508 892	0 280 755 018
96 509 352	0 263 003 263
96 511 983	0 280 755 019
96 511 984	0 280 755 039
96 512 701	0 280 755 041

96 515 042	0 280 755 010
96 515 107	0 280 755 004
96 515 107	0 280 755 005
96 515 372	0 280 755 017
96 515 428	0 280 755 011

96 517 022	1 397 212 073
96 517 023	1 397 212 074
96 518 352	1 397 212 083
96 519 693	0 265 007 707
96 524 902	1 397 212 050

96 524 903	1 397 212 076
96 526 967	0 265 007 664
96 526 969	0 265 007 663
96 526 969	0 265 007 780
96 527 700	0 280 755 015

96 528 436	0 280 752 282
96 528 436	0 280 752 283
96 529 212	0 280 755 030
96 531 052	0 280 755 036
96 531 058	0 280 755 038

96 531 059	0 280 755 032
96 535 678	0 280 755 083
96 536 631	0 265 007 789
96 544 055	0 280 755 040
96 544 061	0 280 755 042

96 544 063	0 280 755 082
96 546 648	1 397 212 050
96 547 253	0 280 755 044
96 547 453	0 280 755 045
96 547 545 80	0 280 755 039

96 548 774	0 280 755 026
96 548 775	0 280 755 027
96 552 700	0 265 007 788
96 554 671	0 280 755 035
96 554 673	0 280 755 037

96 555 024	0 280 755 031
96 555 025	0 280 755 033
96 570 548	1 397 212 083
96 571 232	0 265 005 629
96 573 958	0 280 755 046

96 573 958 VV	0 280 755 046
96 573 958 77	0 280 755 046
96 575 584	1 397 212 109
96 578 716	1 397 212 108
96 578 717	1 397 212 106

96 578 723	1 397 212 107
96 583 737	1 397 212 105
96 583 825	1 397 212 113
96 584 207	0 265 007 645
96 584 207	0 265 007 779

96 585 998	0 265 007 883
96 586 439	0 280 755 075
96 586 529	0 280 755 079
96 588 691	1 397 212 112
96 588 692	1 397 212 086

96 594 498	0 280 755 074
96 594 499	0 280 755 078
96 594 854	1 397 212 116
96 594 857	1 397 212 117
96 598 794 77	0 280 755 076

96 598 795 77	0 280 755 080
96 600 591	1 397 212 118
96 600 591	1 397 212 124
96 600 592	1 397 212 119
96 600 652	1 397 212 118

96 605 913	1 397 212 002
96 803 275	1 397 212 124
96 803 276	1 397 212 125
96 805 660	0 280 755 081
96 807 568	0 280 755 084

9999 163 554	0 280 230 006

PIAGGIO	
638562	0 261 230 101
639366	0 261 210 151
640134	0 281 002 825

640600	0 281 002 511
8133932	0 265 007 684
832029	0 261 210 240

PININFARINA	
M28MN 116462	0 265 007 683
M28MR955037	0 265 007 638
M28MR955352	0 265 005 289

M28M01102857	0 265 007 637
M288651A026	0 265 005 504
084036	1 397 212 021
102857	0 265 005 637
116462	0 265 007 683

284670A228	0 265 005 625
465598040	0 281 002 309
551905870	0 281 002 764
551987170	0 281 002 771
552003010	0 281 002 784

8133931	0 265 008 037
93946739156	0 265 007 059
93951759244	0 265 007 629
93951768620	0 265 007 678
93951797783	0 261 230 173

93951799347	0 265 008 055
93951799348	0 265 008 056
93955187722	0 280 218 164
93955187722	0 986 280 241
93955190587	0 281 002 764

93955196385	0 280 218 182
93955198717	0 281 002 771
93955200301	0 281 002 784
93960684944	1 397 212 011

PORSCHE	
022 906 301	0 280 200 001
039 906 051	0 280 100 043
039 906 111 A	0 280 120 032

124 540 231 7	0 265 002 109
3B0 955 559	1 397 212 028
473 906 301	0 280 201 002
7L0 955 559	1 397 212 031
7L0 955 559 A	1 397 212 028

7L0 955 559 B	1 397 212 030
7L0 955 559 C	1 397 212 027
7L0 955 559 C	1 397 212 028
7L5 905 381	0 261 210 239
7L5 905 381 A	0 261 210 292

7L5 906 461 A	0 280 218 141
7L5 919 275	0 263 003 685
7L5 919 275 M2Z	0 263 003 683
7L5 919 275 M3E	0 263 003 684
7L5 919 275 R7M	0 263 003 725

9A1 606 112 00	0 261 210 300
901 615 113 00	0 336 611 006
902 615 113 00	0 336 611 004
911 110 360 00	0 438 120 004
911 110 938 00	0 438 120 004

911 110 949 00	0 438 120 004
911 110 951 00	0 438 120 002
911 110 965 00	0 438 120 070
911 110 973 00	0 438 120 118
911 110 975 00	0 438 120 143

911 110 979 00	0 438 120 149
911 606 141 00	0 261 231 008
911 606 151 00	0 280 101 001
911 606 151 00	0 280 101 002
911 606 215 00	0 261 210 002

911 606 215 01	0 261 210 005
911 606 217 00	0 261 210 125
911 606 217 01	0 261 210 046
911 606 217 02	0 261 210 046
911 606 217 03	0 261 210 059

923 606 111 00	0 280 201 006
923 606 111 00	0 986 280 060
923 615 101 00	0 332 514 103
928 110 905 00	0 438 120 049
928 110 905 01	0 438 120 107

928 110 905 02	0 438 120 142
928 606 121 BX	0 986 280 064
928 606 121 01	0 280 203 009
928 606 121 01	0 280 203 015
928 606 121 01	0 986 280 064

928 606 121 02	0 280 203 015
928 606 121 02	0 986 280 064
928 606 125 01	0 280 130 023
928 606 126 00	0 280 130 032
928 606 141	0 986 280 124

928 606 141 X	0 280 214 001
928 606 141 00	0 280 214 001
928 606 141 00	0 986 280 124
928 606 143 00	0 280 130 039
928 606 144 00	0 261 231 036


928 606 153 00	0 265 005 100
928 606 157 00	0 280 120 322
928 606 157 01	0 280 120 437
928 606 402 00	0 265 001 053
928 606 402 01	0 265 001 118

928 606 404 0	0 265 001 054
928 606 404 00	0 265 001 053
928 606 404 01	0 265 001 119
928 606 404 01	0 265 006 141
928 606 404 02	0 265 006 141

930 110 803 00	0 438 120 024
930 110 803 00	0 438 120 024
930 110 805 00	0 438 120 017
930 110 907 00	0 438 120 085
930 110 924 00	0 438 120 205

930 606 013 00	0 280 130 034
930 606 013 01	0 280 130 059
930 606 013 02	0 280 130 059
930 606 119 00	0 280 120 214
930 606 119 01	0 280 120 216

930 606 119 02	0 280 120 309
930 606 123 X	0 280 203 023
930 606 123 X	0 986 280 026
930 606 123 00	0 280 203 023
930 606 123 00	0 986 280 026



930 606 915 00	0 280 130 070
931 110 906 00	0 438 120 091
931 110 906 01	0 438 120 092
931 110 906 02	0 438 120 141
931 110 906 03	0 438 120 152

944 606 116 01	0 280 122 004
944 606 121 AX	0 280 202 064
944 606 121 AX	0 986 280 041
944 606 121 X	0 280 202 028
944 606 121 X	0 986 280 037

944 606 124 X	0 986 280 048
944 606 124 00	0 280 203 029
944 606 124 00	0 986 280 048
944 606 125 00	0 280 130 026
944 606 129 00	0 261 220 001

944 606 401 02	0 265 006 142
944 609 121 00	0 280 202 028
944 609 121 00	0 986 280 037
948 605 115 02	0 280 750 114
948 605 115 03	0 280 750 114

951 606 121 01	0 986 280 042
951 606 125 01	0 280 213 017
951 606 125 01	0 986 280 139
951 606 125 02	0 280 213 017
951 606 125 02	0 986 280 139

955 606 123 00	0 280 218 072
955 606 123 00	0 986 280 221
955 606 123 31	0 281 002 435
955 606 123 35	0 280 218 141
955 606 123 40	0 280 218 198

955 618 506 11	1 397 212 097
955 618 507 00	1 397 212 027
955 618 507 01	1 397 212 094
955 618 507 10	1 397 212 030
955 618 507 11	1 397 212 096

956 606 125 00	0 280 218 055
959 606 173 00	0 265 005 004
964 110 910 00	0 438 120 221
964 606 115 00	0 280 120 416
964 606 115 00	0 280 120 417

964 606 404 01	0 265 001 229
964 606 404 02	0 265 006 144
965 606 116 00	0 261 220 001
965 606 116 00	0 261 220 002
986 606 112 00	0 261 210 149

986 606 125 01	0 280 218 055
987 606 125 00	0 280 218 145
987 606 165 00	0 280 218 218
993 606 013 00	0 280 130 097
993 606 113 00	0 280 130 073

993 606 141 00	0 261 231 118
993 606 153 00	0 265 005 108
993 606 217 00	0 261 210 125
993 606 217 01	0 261 210 136
993 606 402 00	0 265 006 101

996 606 106 02	0 232 103 022
996 606 106 03	0 232 103 040
996 606 108 00	0 265 005 122
996 606 109 00	0 265 005 450
996 606 109 01	0 265 005 450

996 606 112 01	0 261 210 149
996 606 112 01	0 261 210 204
996 606 113 00	0 280 130 092
996 606 113 01	0 280 130 123
996 606 115 00	0 280 752 010

996 606 123 00	0 280 217 007
996 606 124 00	0 280 218 009
996 606 125 00	0 261 231 148
996 606 145 00	0 265 005 250
996 606 147 00	0 265 005 247

996 606 406 00	0 265 006 344
996 606 407 02	0 265 007 439
997 605 115 00	0 280 750 008
997 606 106 00	0 232 103 057
997 606 106 01	0 232 103 057

997 606 145 05	0 265 005 746
997 606 203 00	0 261 230 147
997 606 203 01	0 261 230 147
997 606 407 00	0 265 007 624
997 606 407 01	0 265 007 624

E8163	0 280 217 112
V7 535 06980	0 261 230 134
V7 539 81180	0 261 230 136

14 008 99580	0 265 007 791
14 009 68980	0 265 007 130
14 009 69180	0 265 007 131
14 009 71980	0 265 007 791
14 010 40880	0 265 007 791

1601 Y9	0 280 755 126
1601 Z0	0 280 755 125
1601 Z1	0 280 755 127
91 5410 2780	0 261 210 043
96 286 48280	0 261 231 130

96 430 93280	0 280 752 241
96 449 39680	0 280 752 241
96 453 11480	0 261 231 169
96 467 02180	0 280 752 251
96 494 00180	0 265 005 291

96 503 41880	0 280 755 018
96 504 52180	0 265 005 290
96 511 98380	0 280 755 019
96 512 70180	0 280 755 041
96 512 70280	0 280 755 043

96 531 05880	0 280 755 038
96 531 05980	0 280 755 032
96 535 67880	0 280 755 083
96 536 63180	0 265 007 789
96 544 05580	0 280 755 040

96 544 05980	0 280 755 099
96 544 06180	0 280 755 042
96 544 06380	0 280 755 082
96 544 38180	0 280 755 019
96 547 25380	0 280 755 044

96 547 45380	0 280 755 045
96 548 77480	0 280 755 026
96 552 70080	0 265 007 788
96 554 67180	0 280 755 035
96 554 67380	0 280 755 037

96 555 02480	0 280 755 031
96 555 02580	0 280 755 033
96 571 23280	0 265 005 629
96 583 73780	1 397 212 105
96 584 20780	0 265 007 779

96 585 99880	0 265 007 883
96 586 43980	0 280 755 075
96 586 52980	0 280 755 079
96 586 84180	0 265 005 517
96 588 69180	1 397 212 112

96 588 69280	1 397 212 086
96 590 59580	0 261 230 156
96 594 49880	0 280 755 074
96 594 49980	0 280 755 078
96 594 85480	1 397 212 116

96 594 85780	1 397 212 117
96 598 78780	0 280 755 077
96 598 79480	0 280 755 076
96 598 79580	0 280 755 080
96 600 59180	1 397 212 118

96 600 59280	1 397 212 119
96 606 03480	0 261 230 131
96 606 03480	0 261 230 132
96 615 03980	0 280 755 095
96 615 04180	0 280 755 097

96 618 09080	0 280 750 164
96 619 74980	0 265 008 017
96 619 75080	0 265 008 018
96 622 89780	0 265 005 629
96 629 37380	0 265 005 486

96 631 38180	0 265 005 715
96 631 87680	0 265 005 714
96 634 67180	1 397 212 132
96 639 32180	0 265 005 724
96 803 27580	1 397 212 124

96 803 27680	1 397 212 125
96 805 05280	1 397 212 126
96 805 65880	0 280 755 041
96 805 66080	0 280 755 081
96 807 56880	0 280 755 084

96 808 21780	1 397 212 127
96 808 21980	1 397 212 128
96 811 24880	0 280 755 100
96 814 34380	0 280 755 102
96 819 90080	0 280 755 103

96 821 96080	1 397 212 136
96 821 96180	1 397 212 137
96 826 22980	0 280 755 094
96 826 48580	0 280 755 096
96 830 01580	0 280 755 122

96 830 01780	0 280 755 123
96 832 02380	1 397 212 134
96 839 72880	1 397 212 143
96 843 78880	0 280 755 120
96 843 79280	0 280 755 121

96 848 34480	0 280 755 117
96 848 34580	0 280 755 118

RENAULT	
00 03 586 006	0 331 101 014
00 11 068 986	0 261 210 055
08 70 399 600	0 331 101 002

18 00 500 01R	0 280 755 085
18 00 500 02R	0 280 755 088
18 00 500 03R	0 280 755 087
18 00 500 04R	0 280 755 089
50 00 409 318	0 332 204 101

50 00 790 462	0 204 154 001
50 01 824 508	0 331 101 016
50 01 853 014	0 281 002 405
50 01 853 015	0 281 002 311
50 01 867 660	0 281 002 534

50 10 143 029	0 265 050 109
50 10 143 030	0 265 050 110
50 10 143 031	0 265 050 141
50 10 143 032	0 265 050 142
50 10 143 084	0 484 205 004

50 10 143 519	0 205 001 205
50 10 151 547	0 265 050 011
50 10 190 356	0 206 001 007
50 10 207 164	0 206 001 019
50 10 236 261	0 281 002 087

50 10 236 265	0 281 002 089
50 10 236 266	0 205 001 201
50 10 412 448	0 281 002 316
50 10 412 449	0 261 210 151
50 10 412 449	0 281 002 315

50 10 412 450	0 281 002 209
50 10 437 074	0 281 002 206
50 10 437 653	0 281 002 576
50 10 437 746	0 281 002 614
50 10 450 894	0 281 002 576

50 10 512 742	0 205 001 204
51 00 101 976	0 331 101 004
58 21 051 500	1 397 212 077
60 00 581 611	0 280 130 107
60 00 581 616	0 261 210 152

60 01 020 677	0 265 001 170
60 01 020 678	0 265 001 169
60 01 020 679	0 265 001 171
60 01 020 680	0 265 001 172
60 01 021 402	0 265 005 004

60 01 021 402	0 265 005 041
60 01 024 812	0 265 001 311
60 01 024 813	0 265 001 310
60 01 024 814	0 265 001 309
60 01 052 003	0 332 014 411

60 25 303 224	0 265 006 284
60 25 304 654	0 265 006 282
60 25 304 655	0 265 006 283
60 25 402 447	0 265 005 416
60 40 000 691	0 265 006 711

60 40 002 862	0 265 006 744
60 40 002 893	0 265 006 745
60 40 002 895	0 265 006 746
60 40 002 896	0 265 006 747
60 40 004 524	0 265 007 529

60 40 004 527	0 265 007 528
60 40 004 542	0 265 007 583
60 40 004 543	0 265 007 582
60 40 004 808	0 265 007 534
60 40 004 809	0 265 007 533

60 40 004 810	0 265 007 532
60 40 004 811	0 265 007 531
60 40 005 449	0 265 007 606
60 40 005 450	0 265 007 607
60 40 005 494	0 265 007 597

67 00 001 748	0 265 005 529
74 00 269 548	0 335 541 006
74 01 306 024	0 280 130 028
74 01 367 645	0 261 210 029
74 03 507 697	0 280 217 107

74 20 452 258	0 281 002 575
74 39 146 108	0 232 101 030
77 00 100 572	0 280 217 107
77 00 100 572	0 281 002 195
77 00 100 650	0 281 002 175

77 00 104 747	0 281 002 221
77 00 107 123	0 281 002 255
77 00 110 571	0 281 002 349
77 00 267 269	0 280 230 112
77 00 267 388	0 280 130 026

77 00 271 090	0 261 231 006
77 00 272 242	0 265 003 118
77 00 272 242	0 265 006 735
77 00 272 243	0 265 003 120
77 00 272 243	0 265 006 737

77 00 272 244	0 265 003 119
77 00 272 244	0 265 006 736
77 00 301 311	0 265 006 400
77 00 301 312	0 265 006 401
77 00 301 315	0 265 006 386

77 00 301 316	0 265 006 387
77 00 305 115	0 265 006 157
77 00 305 116	0 265 006 156
77 00 305 117	0 265 006 155
77 00 305 118	0 265 006 154

77 00 306 256	0 281 002 093
77 00 308 256	0 205 001 208
77 00 313 681	0 265 006 528
77 00 377 184	0 261 210 113
77 00 411 745	0 265 006 384

77 00 411 746	0 265 006 385
77 00 411 747	0 265 006 383
77 00 413 230	0 206 001 021
77 00 415 681	0 265 006 383
77 00 415 682	0 265 006 384

77 00 415 683	0 265 006 385
77 00 417 967	0 265 006 363
77 00 417 968	0 265 006 361
77 00 417 969	0 265 006 362
77 00 419 589	0 281 002 274

77 00 421 068	0 265 006 442
77 00 421 069	0 265 006 443
77 00 421 070	0 265 006 444
77 00 434 097	0 265 005 417
77 00 545 776	0 280 100 031

77 00 545 777	0 280 120 011
77 00 545 778	0 280 130 006
77 00 545 779	0 280 130 014
77 00 545 853	0 332 003 027
77 00 569 162	0 280 120 018


77 00 582 688	0 280 130 023
77 00 582 696	0 280 201 001
77 00 582 697	0 280 120 203
77 00 586 529	0 332 514 101
77 00 586 529	0 332 514 103


77 00 679 443	0 280 200 027
77 00 680 341	0 280 120 301
77 00 682 115	0 332 514 121
77 00 683 389	0 332 015 012
77 00 708 958	0 280 200 036

77 00 708 960	0 280 230 001
77 00 708 960	0 280 230 005
77 00 709 620	0 280 200 035
77 00 715 635	0 280 202 049
77 00 715 635	0 986 280 053

77 00 715 675	0 280 230 005
77 00 717 549	0 265 001 071
77 00 717 550	0 265 001 069
77 00 720 786	0 280 101 001
77 00 721 268	0 280 230 006

77 00 723 330	0 280 200 043
77 00 730 103	0 280 230 115
77 00 739 427	0 280 130 032
77 00 749 185	0 265 001 242
77 00 749 187	0 265 001 243





◀ RENAULT

77 00 749 188	0 265 005 012
77 00 749 188	0 265 005 038
77 00 755 370	0 265 001 070
77 00 755 371	0 265 001 068
77 00 772 309	0 265 001 069

77 00 772 310	0 265 001 068
77 00 794 541	0 204 154 005
77 00 794 542	0 204 154 006
77 00 796 159	0 204 154 004
77 00 806 172	0 265 003 067

77 00 806 172	0 265 006 442
77 00 806 173	0 265 003 069
77 00 806 173	0 265 006 443
77 00 806 174	0 265 003 068
77 00 806 174	0 265 006 444

77 00 807 607	0 265 003 067
77 00 807 608	0 265 003 068
77 00 807 609	0 265 003 069
77 00 810 688	0 265 003 082
77 00 810 688	0 265 006 361

77 00 810 689	0 265 003 083
77 00 810 689	0 265 006 362
77 00 810 690	0 265 003 084
77 00 810 690	0 265 006 363
77 00 815 767	0 265 005 104

77 00 815 767	0 265 005 111
77 00 859 31	0 261 210 137
77 00 871 678	0 261 231 046
77 01 024 622	0 438 120 120
77 01 026 739	0 438 120 133

77 01 030 600	0 438 121 021
77 01 032 558	0 438 121 048
77 01 047 921	0 280 122 001
77 01 048 994	0 281 002 405
77 01 055 704	0 281 002 534

77 01 056 064	0 281 002 568
77 01 056 064	0 281 002 865
77 01 062 395	0 281 002 740
77 01 068 374	0 281 002 865
77 01 068 387	0 281 002 522

77 01 069 617	0 281 002 867
77 02 218 698	0 280 130 068
77 02 218 698	0 280 130 107
77 02 218 699	0 261 210 137
77 11 120 019	0 280 750 154

82 00 001 914	1 397 212 001
82 00 001 914	1 397 212 004
82 00 001 914	1 397 212 015
82 00 014 888	1 397 212 018
82 00 026 737	0 265 005 417

82 00 026 739	0 265 005 232
82 00 026 739	0 265 005 259
82 00 026 739	0 265 005 263
82 00 026 739	0 265 005 264
82 00 043 135	0 265 007 467

82 00 043 136	0 265 007 468
82 00 058 186	0 265 006 710
82 00 058 187	0 265 006 711
82 00 063 060	1 397 212 018
82 00 071 210	1 397 212 018

82 00 071 210	1 397 212 035
82 00 071 290	1 397 212 035
82 00 074 266	0 265 005 259
82 00 074 266	0 265 005 263
82 00 120 636	0 265 005 441

82 00 124 508	0 280 218 079
82 00 146 271	0 281 002 573
82 00 155 613	0 281 002 552
82 00 168 253	0 281 002 566
82 00 173 959	0 265 006 746

82 00 173 960	0 265 006 747
82 00 173 963	0 265 006 744
82 00 173 966	0 265 006 745
82 00 186 294	0 265 007 527
82 00 186 298	0 265 007 535

82 00 186 299	0 265 007 536
82 00 189 385	0 280 750 154
82 00 189 385	0 280 750 155
82 00 189 766	0 281 002 588
82 00 194 432	0 281 002 573

82 00 195 825	0 265 007 596
82 00 195 828	0 265 007 606
82 00 195 830	0 265 007 607
82 00 195 832	0 265 007 527
82 00 195 832	0 265 007 597

82 00 206 489	0 281 002 589
82 00 212 693	0 265 007 534
82 00 212 695	0 265 007 532
82 00 212 696	0 265 007 533
82 00 212 698	0 265 007 531

82 00 225 971	0 281 002 593
82 00 233 831	0 281 002 616
82 00 254 681	0 265 007 529
82 00 254 685	0 265 007 528
82 00 254 687	0 265 007 583

82 00 254 688	0 265 007 582
82 00 254 688	0 266 007 582
82 00 292 433	0 281 002 740
82 00 310 109	0 281 002 589
82 00 346 992	0 265 007 467

82 00 356 172	0 281 002 945
82 00 375 080	0 281 002 709
82 00 391 398	0 281 002 796
82 00 391 398	0 281 002 921
82 00 415 812	0 265 007 792

82 00 415 812	0 265 007 890
82 00 417 006	1 397 212 084
82 00 417 006	1 397 212 140
82 00 418 270	0 281 002 920
82 00 418 820	0 281 002 834

82 00 419 177	0 265 007 742
82 00 440 544	0 265 007 809
82 00 440 551	0 265 007 810
82 00 440 561	0 265 007 811
82 00 441 401	0 265 007 936

82 00 441 403	0 265 007 937
82 00 441 404	0 265 007 938
82 00 441 620	0 265 007 939
82 00 441 622	0 265 007 940
82 00 457 357	0 265 007 793

82 00 457 357	0 265 007 891
82 00 457 358	0 265 007 794
82 00 457 358	0 265 007 892
82 00 469 905	0 281 002 772
82 00 485 061	0 265 005 701

82 00 576 683	0 281 002 836
82 00 600 208	0 281 002 867
82 00 703 127	0 281 002 915
82 00 703 127	0 281 002 916
82 00 703 127	0 281 002 944

82 00 750 883	0 281 002 573
82 00 781 987	0 265 005 529
82 00 804 554	0 265 005 416
96 12 765 880	0 261 231 070
96 28 648 480	0 261 231 125

96 31 813 680	0 261 230 034
96 35 493 480	0 261 230 041

ROLLS-ROYCE

PB 100609 PC	0 261 231 165
PB 107265 PA	0 280 130 093
PB 115625 PA	0 280 130 086

PF 100607 PA	0 261 210 147
PF 100607 PA	0 261 210 148
PF 100607 PB	0 261 210 252
PF 100607 PB	0 261 210 253
PF 100607 PB	0 261 210 254

PF 100607 PB	0 261 210 256
PF 100608 PA	0 232 103 026
PF 100636 PB	0 281 002 400
PF 100765 PA	0 280 750 127
PF 100765 PA	0 280 750 128

PF 101317 PA	0 280 218 074
PF 101318 PA	0 280 752 037
PF 107942	0 280 752 037
PF 107942 PA	0 280 752 037
UD 22452	0 332 204 101

UE 45749	0 280 120 300
UE 70074	0 281 002 018
UE 71609	0 261 210 029
UE 71610	0 280 130 026
UE 72296	0 261 210 047

UE 73585	0 280 120 407
UE 74159	0 280 217 801
UE 74490	0 280 130 039
UE 74654	0 280 122 007
UE 75265	0 261 230 004

UR 27227	0 265 001 140
UR 27227	0 265 006 350
UR 27419	0 265 001 139
UR 27419	0 265 006 348
UR 27420	0 265 001 138

UR 27420	0 265 006 349
UT 12022	0 280 130 060
UT 14052 PA	0 265 006 349
UT 14053	0 265 006 348
UT 14053 PA	0 265 006 348

UT 14054	0 265 006 350
UT 14505 PB	0 265 006 350
036 906 051 C	0 261 230 054
038 906 051 B	0 281 002 400
06A 905 161 A	0 232 103 020

07C 133 062 A	0 280 750 157
07C 133 062 A	0 280 750 158
07C 906 018 H	0 261 210 047
077 133 062 C	0 280 750 128
1U0 919 275	0 263 003 187

3B0 955 559 A	1 397 212 012
3D0 919 275 B	0 263 003 224
3D0 919 275 B	0 263 003 244
3W0 955 559	1 397 212 078
3W0 955 559 A	1 397 212 078

3W5 955 559 B	1 397 212 012
3W5 955 559 B	1 397 212 120
3W5 955 559 C	1 397 212 121
3W7 920 840 D	0 265 001 138
3Z0 963 535	0 280 130 093

8E0 907 637 A	0 265 005 245
8E0 907 637 B	0 265 005 618

ROVER

AMR 5707	0 281 002 182
ERR 2079	0 261 210 028
ERR 2079	0 281 002 104

ERR 2080	0 205 001 011
ERR 2080	0 205 001 021
ERR 2081	0 280 130 026
ERR 2082	0 280 130 039
ERR 2082A	0 280 130 039

ERR 2083	0 281 002 063
ERR 2708	0 205 001 006
ERR 4645	0 281 002 107
ERR 7107	0 205 001 040
ERR 7171	0 280 217 532

ERR 7322	0 280 122 016
ERR 7352	0 261 210 155
ERR 7354	0 261 210 158
LR 000467	1 397 212 103
LR 000467	1 397 212 104

LR 000524	0 261 230 108
LR 000634	0 232 103 052
LR 000634	0 232 103 053
LR 005490	0 261 230 108
LR 005493	0 261 230 108

MHK 000230	0 280 217 814
MHK 100360	0 281 002 120
MHK 100410	0 281 002 119
MHK 100410	0 281 002 389
MHK 100410 L	0 281 002 389

MHK 100640	0 281 002 205
MHK 100800	0 280 218 010
MHK 100850	0 281 002 182
MHK 101070	0 280 218 012
MHK 101130	0 928 400 357

MHK 101130	0 928 400 520
MHK 101190	0 281 002 389
MHK 101190 A	0 281 002 389
MJC 100031	0 281 002 329
MSJ 100070	0 281 002 370

MVK 000010	0 281 002 291
NSC 100110	0 281 002 121
NSC 100430	0 281 002 145
NSC 100650	0 261 231 140
NSC 500600	0 261 231 186

SLC 100180	0 281 002 310
SRB 000010	0 265 005 248
SRO 000010	0 265 005 248
SRO 000020	0 265 005 283
SRO 000020	0 265 005 639

SRO 500140	0 265 005 654
SRO 500140	0 265 005 655
SSB 000140	0 265 005 303
SSB 10002	0 265 003 057
SSB 10002	0 265 006 473

SSB 10003	0 265 003 058
SSB 10003	0 265 006 474
SSB 10006	0 265 003 059
SSB 10006	0 265 006 475
SSB 10007	0 265 003 060

SSB 10007	0 265 006 473
SSB 10007	0 265 006 476
SSB 10008	0 265 001 320
SSB 10022	0 265 006 103
SSB 10023	0 265 006 104

SSB 10024	0 265 006 105
SSB 10025	0 265 006 106
SSB 100640	0 265 006 307
SSB 10066	0 265 006 167
SSB 10067	0 265 006 170

SSB 100670	0 265 006 168
SSB 100680	0 265 006 169
SSB 10069	0 265 006 168
SSB 100690	0 265 006 170
SSB 100700	0 265 006 259

SSB 100710	0 265 006 258
SSB 100720	0 265 006 268
SSB 100730	0 265 006 267
SSB 10075	0 265 006 305
SSB 100780	0 265 006 167

SSB 100790	0 265 006 269
SSB 100881	0 265 006 270
SSB 100891	0 265 006 271
SSB 10092	0 265 006 306
SSB 100920	0 265 006 305

SSB 100930	0 265 006 306
SSB 500090	0 265 007 650
SSB 500091	0 265 007 738
SSB 500092	0 265 007 923
SSB 500100	0 265 007 651

SSB 500100	0 265 007 922
SSB 500102	0 265 007 922
SSB 500132	0 265 007 778
SSB 500133	0 265 007 924
STC 4768	0 281 002 909

WKW 000070	0 261 230 046
2 A M 73243 A	0 280 202 046
2 A M 73243 A	0 986 280 027
3991033	0 261 231 138

RVI (RENAULT VEHICULES IND.)	
00 08 670 113	0 280 218 109
26 505 010 9031	0 265 050 109

50 10 412 449	0 261 210 151
50 10 412 449	0 281 002 315
50 10 437 653	0 281 002 576
74 20 374 282	0 281 002 459
74 20 374 299	0 281 002 450

74 20 513 340	0 281 002 744
74 20 513 343	0 281 002 742
74 20 524 936	0 281 002 743
74 207 745	0 280 218 089
74 20 774 533	0 280 218 089

74 20 993 000	0 261 230 150

SAAB (SAAB AUTOMOBILE AB)	
750 161	0 280 120 300
75 01 612	0 280 120 300

75 38 655	0 280 212 013
75 38 655	0 986 280 109
75 38 663	0 280 212 011
75 38 663	0 986 280 131
756 356	0 280 130 055

75 63 562	0 280 130 055
75 68 655	0 280 212 013
75 68 655	0 986 280 109
75 68 800	0 261 231 006
75 68 801	0 261 231 006

75 91 183	0 280 212 014
75 91 183	0 986 280 108
78 72 385	0 280 212 022
78 72 385	0 986 280 133
78 72 393	0 280 212 018

83 22 497	0 438 120 009
83 33 288	0 438 120 046
83 37 701	0 438 120 050
835 069	0 280 120 030
83 50 696	0 280 120 030

83 50 712	0 280 100 115
83 54 938	0 280 100 118
83 76 022	0 280 100 009
83 76 030	0 280 120 010
83 76 030	0 280 120 036

83 76 105	0 332 003 021
837 611	0 280 130 006
83 76 113	0 280 130 006
837 612	0 280 130 009
837 612	0 280 130 014

83 76 121	0 280 130 014
83 80 701	0 280 100 018
83 88 076	0 438 120 003
83 88 076	0 438 120 013
87 88 200	0 280 130 032

88 17 967	0 280 212 017
88 17 967	0 986 280 119
88 17 975	0 280 212 011
88 17 975	0 986 280 131
88 18 296	0 280 212 005

88 18 296	0 986 280 112
88 18 304	0 280 212 009
88 18 304	0 986 280 135
88 23 221	0 280 212 013
88 23 221	0 986 280 109

88 23 239	0 280 212 014
88 23 239	0 986 280 108
88 26 778	0 280 212 019
88 26 778	0 986 280 117
88 27 429	0 280 213 012

88 27 429	0 986 280 110
88 27 453	0 280 212 018
88 27 461	0 280 212 022
88 27 461	0 986 280 133
88 27 479	0 280 213 012

88 27 479	0 986 280 110
88 57 195	0 280 122 001
89 78 280	0 280 212 017
89 78 280	0 986 280 119
89 81 573	0 438 120 219

90 202 252	0 281 002 539
90 202 252	0 281 002 605
90 423 637	0 261 230 042
90 490 496	0 261 210 169
90 494 182	0 261 210 131

90 543 282	0 280 217 123
91 13 838	0 280 212 019
91 13 838	0 986 280 117
91 13 846	0 280 213 012
91 13 846	0 986 280 110

91 153 782	0 261 210 132
91 18 368	0 261 210 151
91 28 304	0 281 002 277
91 28 919	0 280 217 105
913 780	0 280 130 065

91 37 803	0 280 130 075
914 241	0 261 231 046
91 42 415	0 261 231 046
91 77 213	0 280 130 094
91 77 221	0 261 210 133

91 77 221	0 261 210 269
91 81 538	0 280 122 014
91 85 232	0 261 210 169
93 02 944	0 438 120 071
93 15 276	0 438 120 073


93171176	0 281 002 437
93171356	0 281 002 180
93 17 272	0 438 120 087
93180268	0 281 002 617
93187247	0 281 002 771

93189275	0 265 007 671
93189276	0 265 007 896
93189277	0 265 007 769
93189955	0 281 002 831
93192107	0 261 230 146

93 42 122	0 438 120 139
93 45 786	0 438 120 159
935 702	0 280 130 026
93 57 021	0 280 130 026
935 803	0 261 230 001

935 803	0 261 231 001
93 58 037	0 261 231 001
93 75 643	0 280 212 005
93 75 643	0 986 280 112
93 857 938	0 281 002 566

93 90 428	0 280 212 002
93 90 428	0 280 212 009
93 90 428	0 986 280 135
93 93 463	0 280 120 300
95 43 901	0 281 002 437



◀ SAAB

95 44 560	0 281 002 138
99 83 636	0 335 541 002

SCANIA	
12580977	0 280 218 136
12608424	0 232 103 079
12785535	1 397 212 017

12787793	0 263 003 208
12789959	0 261 210 229
12803629	1 397 212 017
13107803	1 397 212 058
1326136	0 265 050 025

1326141	0 265 050 027
1350462	0 265 050 112
1355368	0 281 002 129
1356604	0 265 050 112
1356605	0 265 050 113

1358967	0 281 002 130
1362168	0 484 205 003
1365526	0 265 050 143
1365527	0 265 050 144
1365529	0 265 050 145

1365530	0 265 050 146
1377926	0 281 002 129
1381247	0 281 002 190
1383578	0 281 002 174
1386289	0 486 001 007

1386290	0 486 001 006
1393992	0 486 000 025
1393993	0 486 000 026
1393994	0 486 000 027
1400674	0 486 000 023

1411764	0 486 000 069
1761044	F 00B H60 025
1789353	0 281 002 421
1789354	0 280 750 129
1789360	0 261 231 173

1789364	0 281 002 655
220260	0 331 101 014
238924	0 331 101 009
24437503	0 281 002 479
24456764	0 281 002 605

30539175	0 280 213 012
30561772	0 261 210 133
30561772	0 261 210 269
30589495	0 261 230 086
332533	0 265 050 035

3325340	0 265 050 002
3325340	0 265 050 006
367265	0 281 002 046
367266	0 281 002 011
4227203	0 261 210 030

4239034	0 280 217 503
4239067	0 280 130 073
4243408	0 265 003 070
4300562	0 280 217 506
4300562	0 280 217 508

4300562	0 280 217 525
4300562	0 280 217 526
4300729	0 261 231 115
4300737	0 261 210 132
4400404	0 265 006 295

4444758	0 261 230 014
4621363	0 232 103 007
4660122	0 281 002 211
4660452	0 232 103 016
4660593	0 280 130 092

4660809	0 280 217 119
4660817	0 280 217 520
4661062	0 280 122 004
4661062	0 280 122 008
4661070	0 280 217 521

4662888	0 281 002 212
4686648	0 265 006 337
4727186	0 261 230 015
4772232	0 281 002 138
4773800	0 281 002 137

4779161	0 265 006 295
4779161	0 265 006 359
4780177	0 280 217 519
4780185	0 280 217 120
4780193	0 280 217 522

483423	0 486 000 028
483424	0 486 000 029
483548	0 486 000 105
483549	0 486 000 106
4909966	0 265 006 337

5057468	0 265 006 331
5060702	0 265 005 424
5060710	0 265 005 251
5149869	1 397 212 013
5166293	0 281 002 444

5166434	0 261 230 030
5166541	0 281 002 443
5167879	0 281 002 443
5167895	0 261 230 020
5196365	0 261 230 086

5196365	0 261 260 317
5233283	0 265 005 303
5340005	0 281 002 538
5340112	0 281 002 539
5342951	0 281 002 605

5390752	0 265 006 743
55184549	0 281 002 716
55190587	0 281 002 764
55194788	0 281 002 716
55200301	0 281 002 784

55557326	0 261 210 133
55557326	0 261 210 269
5584883	1 397 212 013
58807A	0 263 003 208
58807B	0 263 003 208

SEAT	
038 906 461 D	0 281 002 768
038 906 461 D	0 281 002 769
270 600 001	0 261 230 020

278 001 016	0 280 130 100
6K0 906 301	0 280 202 142
6K0 906 301	0 280 202 143
6K2 721 727 B	0 281 002 338

SISU	
8370 70189	0 281 002 808

SMART (MCC)	
R00 7749 V006	0 280 752 274
R01 2590 V001	0 280 752 272
000 1459 V002	0 281 002 238

000 1459 V002	0 281 002 239
000 1459 V002	0 281 002 499
000 2173 V003	0 265 006 373
000 2173 V003	0 265 006 478
000 2202 V001	0 265 006 375

000 2202 V001	0 265 006 557
000 2202 V002	0 265 006 375
000 2202 V002	0 265 006 557
000 2245 T012	0 280 752 205
000 2245 V010	0 280 752 204

000 2245 V010	0 280 752 205
000 2245 V011	0 280 752 205
000 2245 V012	0 280 752 205
000 2245 V014	0 280 752 205
000 2245 V015	0 280 752 222

000 2245 V016	0 280 752 225
000 2245 V016	0 280 752 226
000 2245 V017	0 280 752 225
000 2245 V017	0 280 752 226
000 2245 V018	0 280 752 230

000 2245 V019	0 280 752 253
000 2245 V019	0 280 752 254
000 2245 V020	0 280 752 269
000 2245 V020	0 280 752 270
000 2245 V021	0 280 752 270

000 2247 V001	0 265 006 374
000 2247 V001	0 265 006 556
000 2247 V002	0 265 006 374
000 2247 V002	0 265 006 556
000 2472 V003	0 265 006 373

000 2473 V003	0 265 006 478
000 3094 V004	0 205 003 055
000 3094 V004	0 205 003 056
000 3094 V006	0 205 003 055
000 3094 V006	0 205 003 056

000 3094 V007	0 205 003 055
000 3094 V007	0 205 003 056
000 3117 V002	0 261 210 141
000 3117 V002	0 261 210 142
000 3120 V002	0 261 231 133

000 3120 V002	0 261 231 134
000 3121 V002	0 281 002 137
000 3121 V003	0 261 230 049
000 4419 V004	0 280 752 246
000 4740 T003	0 265 006 556

000 4740 V004	0 265 006 556
000 4742 T003	0 265 006 557
000 4742 V003	0 265 006 557
000 4742 V004	0 265 006 557
000 7749 V004	0 280 752 245

000 7749 V004	0 280 752 246
000 7749 V005	0 280 752 246
000 7749 V006	0 280 752 273
000 7749 V006	0 280 752 274
000 9493 V001	0 265 005 279

000 9493 V002	0 265 005 279
000 9493 V003	0 265 005 671
000 9493 V003	0 265 005 698
000 9493 V004	0 265 005 698
001 0743 V001	0 265 006 753


001 0743 V002	0 265 006 753
001 2227 V001	0 265 006 748
001 2227 V003	0 265 006 788
001 2589 V001	0 280 752 267
001 2589 V001	0 280 752 268

001 2590 V001	0 280 752 271
001 2590 V001	0 280 752 272
001 2590 V002	0 280 755 002
001 2590 V002	0 280 755 003
001 3784 V001	0 280 752 280

001 3784 V001	0 280 752 281
001 3784 V002	0 280 752 281
001 4087 V001	0 265 005 303
001 6146 V001	0 261 230 141
001 6146 V001	0 261 230 142

SSANGYONG	
A6650943048	0 280 218 131
000 094 00 48	0 280 217 100
000 094 05 48	0 280 217 517

000 094 05 48	0 280 217 518
216144	0 265 005 125
48920 05000	0 265 006 134
48920 05000X	0 265 006 134
48920 11000	0 265 006 397



48930 05000	0 265 006 135
48930 05001	0 265 006 135
48930 06000	0 265 006 343
48930 06001	0 265 006 343
48940 11000	0 265 006 398

48950 11000	0 265 006 399
48970 11000	0 265 006 396
66154 03217	0 265 006 341
66154 03317	0 265 006 338
66154 03417	0 265 006 339

86750 05000	0 265 005 038
86750-05000	0 265 005 045
86750-06000	0 265 005 115

STEYR FAHRZEUGTECHNIK	
001 540 45 17	0 265 005 230
002 542 66 18	0 265 005 246

002 545 19 05	0 332 015 011
003 542 03 18	0 265 005 267
006 153 49 28	0 281 002 823
113 094 00 48	0 280 217 810
113 094 00 48	0 280 217 811

125 809 77	0 280 218 136
13107803	1 397 212 058
210 540 48 10	0 265 006 357
210 540 49 10	0 265 006 355
210 540 91 08	0 265 006 187

211 540 10 17	0 265 007 469
211 540 12 17	0 265 007 496
211 540 13 17	0 265 007 495
211 540 20 17	0 265 007 705
211 540 24 17	0 265 007 721

216 542 00 18	0 265 005 623
220 540 11 17	0 265 007 107
273 094 05 48	0 280 218 148
273 094 07 48	0 280 218 174
273 094 07 48	0 280 218 186

273 094 08 48	0 280 218 181
273 094 09 48	0 280 218 181
273 094 09 48	0 280 218 191
3417699	0 265 005 644
463 540 19 17	0 265 008 015

463 540 20 17	0 265 007 984
463 540 21 17	0 265 007 985
55190587	0 281 002 764
55198717	0 281 002 771
55200301	0 281 002 784

55350048	0 281 002 618
6762235	0 265 005 285
6774040	0 265 005 285
6777435	0 265 005 285
7531702	0 280 218 159

7 533 853	0 280 218 165
7566989	0 280 218 159
7801951	0 281 002 849
906 542 05 18	0 265 005 628

SUBARU	
27542 AE000	0 265 005 216

SUZUKI	
127603	0 281 002 619
13800 T79J5 000	0 281 002 770
13800 T7950 001	0 281 002 618

13800 79J50	0 281 002 618
13800 84E50	0 281 002 619
13800 86J00	0 281 002 862
15736 67G00	0 281 002 592
15760-66K70	0 261 545 042

18590 T79J5 000	0 281 002 770
18590 73KA0	0 261 230 197
18590-79G61-000	0 281 002 845
18590 79J50	0 281 002 771
18590 82K00	0 261 230 198

18590 82K50	0 261 230 200
18590 84E50	0 281 002 510
18640 73KA0	0 261 231 201
33945 T79J0	0 265 005 636
37520 10B3	0 261 231 036

37620 30B3	0 280 130 037
56200 T79J00	0 265 007 954
56210 T79J00	0 265 007 955
56220 T79J00	0 265 007 954
56310 T79J00	0 265 007 957

56320 T79J00	0 265 007 956

TALBOT	
A 040 296	0 261 211 003
A 514 296	0 261 211 003
A 514 548 80	0 280 120 305

A 514 549 80	0 280 130 026
A 514 880 80	0 261 231 001
91 040 398 80	0 281 002 030
91 207 837 80	0 281 002 018
91 414 549 80	0 280 130 026

91 514 548 80	0 280 120 305
91 514 549 80	0 280 130 026
91 514 880 80	0 261 231 006
91 516 985 80	0 280 202 056
91 516 985 80	0 986 280 028

91 537 485 80	0 132 009 305
91 537 516 80	0 281 002 029
91 538 877 80	0 280 202 097
91 538 877 80	0 986 280 070
91 540 545 80	0 280 202 109

91 540 545 80	0 986 280 013
91 541 027 80	0 261 210 043
91 541 738 80	0 280 202 202
95 640 366 80	0 281 002 037
96 087 509 80	0 265 003 078

96 089 629 80	0 265 003 079
96 107 893 80	0 261 230 004
96 140 648 80	0 265 003 099
96 165 516 80	0 265 003 130
96 165 516 80	0 265 006 200

96 180 488 80	0 265 003 128
96 181 977 80	0 265 003 131
96 181 977 80	0 265 006 201
96 181 978 80	0 265 003 130
96 181 978 80	0 265 006 200

TATA (TELCO)	
269915409948	0 261 230 133
269954219944	0 265 005 146
279715209903	0 280 218 183

TOYOTA	
47900 6F605	0 265 001 417
67000 01062	0 265 005 432
78010 YV010	0 280 755 019

78010 YV020	0 280 755 039
84307 02080	0 265 005 519
84307 02090	0 265 005 520
89183 0H010	0 265 005 703
89183 0W010	0 265 005 208

89183 02010	0 265 005 260
89183 02020	0 265 005 297
89183 05010	0 265 005 239
89183 05010	0 265 005 273
89183 05010	0 265 005 297

89183 05020	0 265 005 273
89183 05020	0 265 005 297
89183 06010	0 265 005 633
89183 06010	0 265 005 650
89183 07010	0 265 005 226

89183 07020	0 265 005 274
89183 08010	0 265 005 239
89183 08010	0 265 005 243
89183 08010	0 265 005 273
89183 08010	0 265 005 297

89245 0W010	0 265 005 402
89245 02010	0 265 005 432
89245 02020	0 265 005 487
89245 02040	0 265 005 518
89245 05010	0 265 005 426

89245 07010	0 265 005 412
89422-0W010	0 280 130 105
89422 05010	0 280 130 077
89422 05010	0 280 130 104
89422 05020	0 280 130 104

89441 0W010	0 265 005 119
89452 05010	0 280 122 008
89458 0D010	0 281 002 628
89458 02011	0 281 002 871
89458 52010	0 281 002 521

89465 0H020	0 280 755 019
89542 0D010	0 265 006 675
89542 0H010	0 265 007 687
89542 02020	0 265 006 516
89542 02040	0 265 006 677

89542 02060	0 265 007 805
89542 02110	0 265 007 803
89542 05010	0 265 001 381
89542 05010	0 265 001 416
89542 05020	0 265 001 416

89542 05030	0 265 006 333
89542 05030	0 265 006 666
89542 05040	0 265 006 666
89542 340NM	0 265 006 677
89542 990DL	0 265 001 381

89542 990DL	0 265 001 416
89543 0D010	0 265 006 674
89543 0D011	0 265 006 674
89543 02020	0 265 006 517
89543 02040	0 265 006 676


89543 02060	0 265 007 806
89543 02110	0 265 007 804
89543 05010	0 265 001 382
89543 05010	0 265 001 417
89543 05020	0 265 001 417


89543 05030	0 265 006 334
89543 05030	0 265 006 665
89543 05040	0 265 006 665
89543 340NM	0 265 006 676
89544 0H010	0 265 007 688

89544 02040	0 265 007 802
89545 02010	0 265 006 518
89545 05010	0 265 001 383
89545 05010	0 265 001 418
89545 05020	0 265 001 418

89545 05030	0 265 006 335
89545 05030	0 265 006 336
89545 05030	0 265 006 668
89545 05040	0 265 006 668
89546 02010	0 265 006 519

89546 05010	0 265 001 384
89546 05010	0 265 001 419
89546 05020	0 265 001 419
89546 05030	0 265 006 335
89546 05030	0 265 006 336





◀ TOYOTA

89546 05030	0 265 006 667
89546 05040	0 265 006 667
89615 0H010	0 261 231 193
89615 02010	0 261 231 149
89615 05010	0 261 231 045

89615 05010	0 261 231 103
89637 07010	0 265 005 303
90080 19018	0 232 103 029
90080 19020	0 232 103 036
90080 19026	0 281 002 406

90919 W5001	0 232 103 069
90919 W5003	0 232 103 069
96430 73280	0 280 752 238

VOLVO

1011926	0 261 230 108
1079477	0 281 002 251
11987137	0 332 204 101

1219678	0 335 541 004
1219680	0 335 541 005
1235013	0 332 015 012
1235020	0 332 015 009
1259925	0 332 014 151

1259926	0 332 204 101
1266408	0 438 120 025
1266426	0 438 120 043
1266545	0 438 120 043
1266808	0 438 120 076

1266810	0 438 120 077
1269028	0 438 120 027
1269029	0 438 120 031
1269144	0 438 120 080
1269146	0 438 120 056

1269148	0 438 120 079
1269332	0 438 120 065
1269794	0 438 120 132
1270259	0 280 218 008
1270492	0 261 231 121

1270501	0 261 230 019
1271004	0 280 120 300
1271861	0 280 213 025
1271861	0 986 280 114
1271862	0 280 213 026

1275173	0 205 001 047
1275245	0 281 002 075
1275245	0 281 002 155
1275245	0 986 280 089
1275245	0 986 280 090

1275342	0 261 230 018
1275749	0 280 217 107
1276509	0 438 120 100
1306024	0 280 130 028
1306937	0 280 130 023

1306938	0 280 120 301
1306938	0 280 130 006
1306939	0 280 212 001
1306964	0 280 202 034
1306964	0 986 280 059

1306967	0 280 202 035
1306967	0 986 280 045
1317030	0 261 210 001
1317030	0 261 210 003
1317273	0 261 220 001

1317273	0 261 220 002
1317546	0 438 120 138
1317551	0 438 120 134
1317867	0 438 120 125
1324080	0 265 001 064

1324081	0 265 001 065
1326065	0 280 212 002
1326065	0 986 280 106
1326658	0 261 231 001
1326730	0 280 230 005

1332396	0 280 130 026
1336354	0 280 213 006
1336354	0 986 280 115
1336385	0 280 122 001
1336534	0 280 213 006

1336534	0 986 280 115
1346645	0 280 212 007
1346645	0 986 280 102
1346698	0 280 202 067
1357451	0 438 120 202

1357666	0 438 120 203
1363557	0 265 001 186
1363558	0 265 001 185
1363559	0 265 001 184
1366220	0 280 217 002

1367643	0 261 231 007
1367644	0 261 231 006
1367644	0 261 231 046
1367645	0 261 210 029
1367970	0 280 202 096

1398781	0 265 001 064
1398781	0 265 001 065
1501832	0 332 014 151
1504952	0 332 204 101
1620170	0 132 009 320

1620170	0 281 002 396
1650865	0 281 002 023
20153340	0 281 002 744
20374282	0 281 002 458
20374282	0 281 002 459

20374299	0 281 002 449
20374299	0 281 002 450
20452258	0 281 002 574
20452258	0 281 002 575
20513340	0 281 002 744

20513343	0 261 210 151
20513343	0 281 002 742
20524936	0 281 002 576
20524936	0 281 002 743
20774533	0 280 218 089

20792328	0 281 002 706
20885267	0 281 002 946
20993000	0 261 230 150
241722	0 280 120 012
241725	0 280 100 010

241726	0 280 130 014
241810	0 280 130 006
241812	0 332 003 021
243028	0 332 003 025
243181	0 331 100 023

243183	0 280 100 015
243316	0 280 100 035
243366	0 280 120 026
243715	0 331 101 008
243847	0 331 101 004

243896	0 438 120 005
243897	0 438 120 006
244228	0 438 120 016
269548	0 335 541 006
285227	0 280 230 005

30621300	0 265 006 698
30622083	0 261 230 105
30622083	0 261 230 106
30637412	0 281 002 612
30649885	1 397 212 067

30649886	1 397 212 034
30650013	0 280 750 103
30650013	0 280 750 104
30650014	0 261 230 092
30650014	0 261 230 109

30650015	0 261 230 108
30650015	0 261 230 110
30650561	0 280 750 132
3065338	1 397 212 104
3065388	1 397 212 104

30655308	1 397 212 104
30655338	1 397 212 103
30655338	1 397 212 104
30658184	0 261 230 044
30677251	0 281 002 730

30677251	0 281 002 731
30677300	0 281 002 706
30677300	0 281 002 707
30677999	0 281 002 731
30711552	0 280 750 146

30711552	0 280 750 147
30711553	0 280 750 103
30711553	0 280 750 104
30711554	0 280 750 131
30711554	0 280 750 132

30756097	0 261 230 108
30756098	0 261 230 092
30756098	0 261 230 109
30814716	0 265 006 226
30814716	0 265 006 366

30850024	0 265 006 366
30854299	0 265 006 425
30862697	0 206 001 021
30870894	0 265 006 224
30870895	0 265 006 223

3090470	0 331 101 016
3093845	2 427 233 004
31214359	1 397 212 103
31251446	0 261 230 237
31251447	0 261 230 239

3172774	0 281 002 382
3172774	0 281 002 383
3173630	0 484 205 007
3198232	0 281 002 450
3198232	0 281 002 455

3285227	0 280 230 005
3292959	0 335 530 016
3343029	0 280 120 319
3411906	0 280 212 007
3411906	0 986 280 102

3433347	0 261 231 006
3433477	0 280 130 032
3450030	0 280 122 001
3454442	0 280 212 021
3454442	0 986 280 107

346030	0 280 130 032
3501987	0 280 213 010
3501987	0 986 280 138
3507697	0 280 217 107
3515092	0 265 001 231

3515093	0 265 001 187
3517020	0 280 212 016
3517020	0 986 280 101
3517068	0 280 120 325
3517569	0 280 213 012

3517569	0 986 280 110
3517763	0 280 213 020
3517763	0 986 280 132
3517772	0 280 120 400
3517881	0 280 217 001

3534814	0 280 213 026
3540601	0 265 001 332
3547266	0 280 212 021
3547266	0 986 280 107
3843012	0 261 230 147

3843100	0 281 002 706
3843100	0 281 002 864
3944124	0 281 002 248
3944124	0 281 002 249
39649886	1 397 212 068

3985596	0 281 002 263
3985596	0 281 002 264
3987882	0 281 002 292
3987882	0 281 002 293
43065338	1 397 212 103

43065338	1 397 212 104
460835	0 280 100 053
460866	0 280 100 054
461560	0 280 120 039
461583	0 280 100 059

461666	0 280 100 066
462567	0 280 100 056
462793	0 438 120 003
48648049	1 397 212 052
58807B	0 263 003 208

6603575	0 331 101 001
6777707	0 204 154 022
6793386	0 204 154 021
6793386	0 204 154 032
6842536	0 261 230 006

6900118	0 204 154 023
6950953	0 204 154 019
6950953	0 204 154 030
6950954	0 204 154 022
77756	0 331 101 002

811959	0 261 230 021
8119598	0 261 230 021
8141475	0 281 002 086
8251496	0 986 280 102
8251497	0 986 280 101

8251498	0 986 280 110
8251499	0 986 280 114
8251500	0 986 280 115
8251501	0 986 280 107
8251502	0 986 280 138

8251503	0 986 280 090
8251504	0 986 280 106
831725	0 332 204 101
8360979	0 335 530 032
839367	0 332 014 151

850024	0 265 006 366
8602391	0 280 218 045
8602791	0 280 212 007
8602791	0 986 280 102
8602792	0 280 212 016

8602792	0 986 280 101
8602793	0 280 213 012
8602793	0 986 280 110
8602794	0 280 213 025
8602794	0 986 280 114

8602795	0 280 213 006
8602795	0 986 280 115
8602796	0 280 212 021
8602796	0 986 280 107
8602797	0 280 213 010

8602797	0 986 280 138
8602798	0 281 002 155
8602798	0 986 280 090
8602803	0 280 212 002
8602803	0 986 280 106

8627279	0 261 230 067
8627296	0 280 218 088
8627297	0 280 218 089
8631533	0 232 103 042
8631588	0 281 002 398

8631588	0 281 002 527
8648049	1 397 212 052
8653171	0 261 231 178
8658497	0 280 750 146
8658497	0 280 750 147

8658536	0 261 230 092
8658536	0 261 230 109
8658726	0 232 103 063
8662738	1 397 212 034
86627386	1 397 212 034

8670112	0 280 218 045
8670112	0 280 218 108
8670113	0 280 218 046
8670113	0 280 218 109
8670114	0 280 218 089

8670115	0 280 218 088
8670115	0 280 218 089
8670263	0 280 218 108
8670398	0 280 218 088
8677288	0 261 230 090

8677288	0 261 230 091
8677657	0 280 750 103
8677657	0 280 750 104
8677658	0 280 750 131
8677658	0 280 750 132

8677866	0 280 750 103
8677866	0 280 750 104
8677867	0 280 750 131
8677867	0 280 750 132
8687927	0 280 750 146

8687927	0 280 750 147
8692624	0 280 218 134
8699448	0 261 230 092
8699448	0 261 230 109
8699449	0 261 230 108

874241	0 281 002 576
874556	0 281 002 534
9125462	0 261 230 029
9125569	0 261 230 021
9127410	0 265 001 380

9143648	0 232 101 029
9146108	0 232 101 030
9146483	0 280 217 511
9432570	0 261 231 142
9434287	0 205 001 049

9438757	0 280 218 045
9445148	0 280 218 007
9447055	0 205 001 046
9470640	0 280 218 045
9470776	0 280 218 046

9474059	0 205 001 048
9483937	1 397 212 008
9488047	0 280 750 103
9488047	0 280 750 104
9545148	0 280 218 007

VOLVO CAR

MB 950344	0 265 006 223
MN 902991	0 281 002 762
MN 903266	0 281 002 823

RA8 651A026	0 265 005 504
SMN 102857	0 265 007 637
SMN 116462	0 265 007 683
SMN 116562	0 265 007 683
SMN 163706	0 261 231 187

SMN 195775	0 261 230 118
SMR 587456	0 265 005 485
SMR 955037	0 265 007 638
SMR 955352	0 265 005 289
SMR 985032	0 261 230 118

S46 70A228	0 265 005 625
S86 51A026	0 265 005 504
467 0A228	0 265 005 625
865 1A026	0 265 005 504

VW (VOLKSWAGEN)

X03 952 633	0 280 200 045
X03 952 640	0 280 130 026
X03 952 671	0 280 230 009

X03 961 006	0 280 200 050
X03 972 830	0 280 200 052
X03 972 830	0 986 280 058
X03 976 245	0 280 200 053
0B8 927 321	0 232 103 037

0B8 927 321	0 232 103 038
000 VT5 077	0 281 002 461
000 VT5 077	0 281 002 462
000 395 2633	0 280 200 045
000 395 2640	0 280 130 026

000 395 2671	0 280 230 009
000 397 2830	0 280 200 052
000 397 2830	0 986 280 058
004 153 82 28	0 281 002 456
004 165 008	0 261 210 064

013 001 224	0 263 003 475
021 133 062	0 205 003 053
021 133 062	0 205 003 054
021 905 377	0 261 231 044
021 905 377	0 261 231 047

021 905 377	0 261 231 048
021 905 377 A	0 261 231 064
021 905 377 A	0 261 231 065
021 906 433	0 261 210 080
021 906 433	0 261 210 081

021 906 433 A	0 261 210 080
021 906 433 A	0 261 210 081
021 906 433 C	0 261 210 107
021 906 433 C	0 261 210 108
021 906 433 D	0 261 210 156

021 906 433 D	0 261 210 157
021 906 445	0 261 210 044
021 906 461	0 280 213 021
021 906 461	0 280 213 022
021 906 461	0 986 280 122

021 906 461	0 986 280 127
021 906 462	0 280 217 504
021 906 462	0 280 217 505
021 906 462 A	0 280 217 512
021 906 462 A	0 280 217 513

021 906 462 A	0 986 280 203
021 906 462 A	0 986 280 303
021 906 462 AX	0 986 280 203
021 906 462 AX	0 986 280 303
021 907 317 A	0 261 210 120

021 907 317 A	0 261 210 121
021 907 319	0 261 210 094
021 907 319	0 261 210 095
021 907 319 A	0 261 210 120
021 907 319 A	0 261 210 121


021 907 475 D	0 280 752 016
021 907 475 D	0 280 752 017
021 907 475 E	0 280 752 018
021 907 475 E	0 280 752 019
022 133 062 AB	0 280 750 086

022 133 062 AB	0 280 750 087
022 133 062 AC	0 280 750 097
022 133 062 AC	0 280 750 098
022 133 062 AF	0 280 750 008
022 133 062 T	0 280 750 086

022 133 062 T	0 280 750 087
022 906 041	0 280 130 012
022 906 041	0 280 130 013
022 906 041 A	0 280 130 017
022 906 041 A	0 280 130 018

022 906 051	0 280 100 003
022 906 051 A	0 280 100 019
022 906 051 B	0 280 100 027
022 906 051 C	0 280 100 037
022 906 051 E	0 280 100 049

022 906 059	0 332 514 101
022 906 059	0 332 514 103
022 906 111 A	0 280 120 042
022 906 111 A	0 280 120 043
022 906 111 B	0 280 120 021



◀ VW

022 906 111 B	0 280 120 022
022 906 111 D	0 280 120 201
022 906 111 E	0 280 120 103
022 906 111 E	0 280 120 104
022 906 111 G	0 280 120 207

022 906 301	0 280 200 001
022 906 301	0 280 200 002
022 906 301 A	0 280 200 012
022 906 301 A	0 280 200 013
022 906 301 A	0 986 280 071

022 906 301 B	0 280 200 018
022 906 301 B	0 280 200 019
022 906 301 B	0 986 280 050
022 906 301 D	0 280 200 020
022 906 301 D	0 280 200 021

022 906 301 D	0 986 280 038
025 906 041	0 280 130 026
025 906 041	0 280 130 033
025 906 301	0 280 200 038
025 906 301	0 280 200 039

025 906 301	0 986 280 012
025 906 301 A	0 280 200 041
025 906 301 A	0 280 200 042
025 906 301 C	0 280 202 079
025 906 301 C	0 280 202 080

025 906 301 C	0 986 280 011
025 906 301 C	0 986 280 085
026 133 353	0 438 121 011
026 133 353	0 438 121 012
026 133 353 C	0 438 121 057

026 133 353 C	0 438 121 058
026 133 471	F 026 TX2 063
026 133 471	0 438 121 011
026 133 471	0 438 121 012
026 133 471 A	0 438 121 047

026 133 471 B	F 026 TX2 051
026 133 471 B	0 438 120 208
026 133 471 B	0 438 120 209
026 133 471 C	0 438 121 057
026 133 471 C	0 438 121 058

026 133 471 D	0 438 121 070
026 133 471 D	0 438 121 071
026 133 471 D	0 986 439 370
026 133 593	0 261 230 016
026 133 593	0 261 230 017

026 133 593	0 261 230 116
026 133 593	0 261 230 117
026 905 359 2	1 237 031 296
026 905 377	0 261 231 002
026 905 377	0 261 231 003

026 906 161	0 280 130 026
026 906 161	0 280 130 040
026 906 161	0 280 130 041
026 906 161 A	0 280 130 127
026 906 161 A	0 280 130 128

027 133 471	F 026 TX2 050
027 133 471	0 438 120 195
027 133 471	0 438 120 196
027 998 041 1	0 261 230 095
028 130 301	0 281 002 073

028 130 301	0 986 280 088
028 906 301	0 281 002 072
028 906 301	0 281 002 073
028 906 301	0 986 280 088
028 906 461	0 281 002 216

028 906 461	0 281 002 217
028 906 461	0 986 284 001
028 906 461 X	0 986 284 001
028 907 475	0 205 001 023
028 907 475 A	0 205 001 024

028 907 475 AA	0 281 002 253
028 907 475 AB	0 281 002 254
028 907 475 AC	0 280 752 002
028 907 475 AC	0 280 752 003
028 907 475 AJ	0 281 002 286

028 907 475 AL	0 281 002 289
028 907 475 AM	0 280 752 020
028 907 475 AP	0 281 002 339
028 907 475 B	0 205 001 018
028 907 475 B	0 205 001 032

028 907 475 BC	0 281 002 331
028 907 475 BD	0 280 752 022
028 907 475 C	0 205 001 031
028 907 475 P	0 281 002 275
028 907 475 S	0 281 002 229

028 907 475 T	0 280 752 002
028 907 475 T	0 280 752 003
028 907 568	0 205 001 023
028 907 568 A	0 205 001 024
03C 906 051	0 261 230 095

03C 906 051	0 261 230 096
03C 906 051 F	0 261 230 148
03C 906 051 F	0 261 230 149
03C 906 433	0 261 210 250
03C 906 433	0 261 210 251

03C 957 147	0 261 210 250
03C 957 147	0 261 210 251
03G 906 051 F	0 281 002 837
03G 906 051 F	0 281 002 838
03G 906 461 C	0 281 002 735

03G 906 461 C	0 281 002 736
03H 906 461	0 280 218 175
03H 906 461	0 280 218 176
030 133 062	0 280 750 049
030 133 062	0 280 750 050

030 133 062 A	0 280 750 049
030 133 062 A	0 280 750 050
030 133 062 B	0 280 750 095
030 133 062 B	0 280 750 096
030 133 062 C	0 280 750 095

030 133 062 C	0 280 750 096
030 905 065	1 237 031 296
030 905 377	0 261 231 066
030 905 377	0 261 231 067
030 905 377 A	0 261 231 045

030 905 377 A	0 261 231 108
030 905 377 C	0 261 231 146
030 905 377 C	0 261 231 147
030 905 377.1	0 261 231 122
030 905 377 1	0 261 231 126

030 906 051	0 261 230 010
030 906 051	0 261 230 011
030 906 051 A	0 261 230 010
030 906 051 A	0 261 230 011
030 906 301	0 280 200 048

030 906 301	0 280 200 049
030 906 301	0 986 280 030
030 906 301	0 986 280 084
030 906 433 D	0 261 210 172
030 906 433 D	0 261 210 173

030 906 433 E	0 261 210 174
030 906 433 E	0 261 210 175
030 906 433 K	0 261 210 207
030 906 433 K	0 261 210 208
030 957 147 C	0 261 210 174

030 957 147 C	0 261 210 175
030 957 147 D	0 261 210 172
030 957 147 D	0 261 210 173
030 957 147 E	0 261 210 174
030 957 147 E	0 261 210 175

030 957 147 F	0 261 210 194
030 957 147 F	0 261 210 195
030 957 147 F	0 261 210 215
030 957 147 F	0 261 210 216
030 957 147 G	0 261 210 188

030 957 147 G	0 261 210 189
030 957 147 K	0 261 210 215
030 957 147 K	0 261 210 216
030 957 147 L	0 261 210 213
030 957 147 L	0 261 210 214

030 957 147 R	0 261 210 223
030 957 147 R	0 261 210 224
030 957 147 R	0 261 210 225
030 957 147 R	0 261 210 226
030 957 147 S	0 261 210 257

030 957 147 S	0 261 210 258
031 906 041	0 280 130 014
031 906 081	0 280 130 006
034 133 154 C	0 280 120 410
034 133 154 C	0 280 120 411

034 133 154 E	0 280 120 420
034 133 154 E	0 280 120 421
034 133 353 J	0 438 121 059
034 133 353 J	0 438 121 060
034 133 353 M	0 438 121 067

034 133 353 M	0 438 121 068
034 133 353 P	0 438 120 218
034 133 353 R	0 438 121 083
034 133 353 R	0 438 121 084
034 133 471	F 026 TX2 064

034 133 471	0 438 121 013
034 133 471	0 438 121 014
034 133 471 B	0 438 121 041
034 133 471 C	0 438 121 053
034 133 471 C	0 438 121 054

034 133 471 D	0 280 213 005
034 133 471 D	0 280 213 007
034 133 471 D	0 280 213 008
034 133 471 D	0 986 280 120
034 133 471 D	0 986 280 137

034 133 471 E	0 438 120 210
034 133 471 E	0 438 120 211
034 133 471 F	0 438 121 059
034 133 471 F	0 438 121 060
034 133 471 G	F 026 TX2 054

034 133 471 G	0 438 121 049
034 133 471 G	0 438 121 050
034 133 471 H	0 438 121 073
034 133 471 H	0 438 121 074
034 133 471 J	0 438 121 068

034 133 471 K	0 280 213 008
034 133 471 K	0 986 280 120
034 133 471 K	0 986 280 137
034 133 471 L	0 438 121 064
034 133 471 L	0 438 121 065


034 133 471 M	0 438 121 083
034 133 471 N	0 280 213 017
034 133 471 N	0 986 280 139
034 905 161	0 232 101 020
034 905 161	0 232 101 021

034 905 215	0 232 101 014
034 905 215	0 232 101 015
034 905 215 B	0 232 101 015
034 905 215 B	0 232 102 002
034 905 215 B	0 232 102 003

034 905 377 A	0 261 231 004
034 905 377 A	0 261 231 005
034 905 377 C	0 261 231 016
034 905 377 C	0 261 231 017
034 905 377 D	0 261 231 014

034 905 377 D	0 261 231 015
034 905 377 H	0 261 231 031
034 905 377 H	0 261 231 032
034 906 161	0 280 130 053
034 906 161	0 280 130 054

035 133 353 AA	0 438 120 183
035 133 353 AC	0 438 121 003
035 133 353 AC	0 438 121 004
035 133 353 AD	0 438 120 194
035 133 353 AE	0 438 121 023



035 133 353 AE	0 438 121 024
035 133 353 AG	0 438 121 017
035 133 353 AG	0 438 121 018
035 133 353 AS	0 438 121 061
035 133 353 AS	0 438 121 062

035 133 353 T	0 438 120 179
035 133 471	0 438 120 040
035 133 471	0 438 120 041
035 133 471 A	0 438 120 112
035 133 471 A	0 438 120 113

035 133 471 AA	0 438 121 007
035 133 471 AA	0 438 121 008
035 133 471 AB	0 438 121 018
035 133 471 AC	0 280 214 001
035 133 471 AC	0 986 280 124

035 133 471 AD	0 438 121 030
035 133 471 AE	0 438 121 023
035 133 471 AF	0 438 121 052
035 133 471 B	0 438 120 121
035 133 471 B	0 438 120 122

035 133 471 C	0 438 120 052
035 133 471 C	0 438 120 053
035 133 471 D	0 438 120 044
035 133 471 D	0 438 120 045
035 133 471 E	0 438 120 136

035 133 471 E	0 438 120 137
035 133 471 F	0 438 120 146
035 133 471 F	0 438 120 147
035 133 471 G	0 438 120 144
035 133 471 H	0 438 120 169

035 133 471 K	0 438 120 177
035 133 471 L	0 438 120 185
035 133 471 L	0 438 120 186
035 133 471 N	0 438 120 181
035 133 471 N	0 438 120 182

035 133 471 P	0 438 120 193
035 133 471 Q	0 438 120 178
035 133 471 Q	0 438 120 197
035 133 471 Q	0 438 120 198
035 133 471 R	0 438 120 180

035 133 471 S	0 438 121 004
035 133 471 T	0 438 121 005
035 133 471 T	0 438 121 006
035 906 111	0 280 120 300
035 919 369 M	0 280 130 037

035 919 369 M	0 280 130 038
036 133 062 B	0 280 750 057
036 133 062 B	0 280 750 058
036 133 062 C	0 280 750 059
036 133 062 C	0 280 750 063

036 133 062 C	0 280 750 064
036 133 062 D	0 280 750 059
036 133 062 D	0 280 750 060
036 133 062 J	0 280 750 112
036 133 062 J	0 280 750 113

036 906 051 C	0 261 230 053
036 906 051 C	0 261 230 054
036 906 051 E	0 261 230 071
036 906 051 E	0 261 230 072
036 906 051 F	0 261 230 079

036 906 051 F	0 261 230 080
036 906 051 G	0 261 230 081
036 906 051 G	0 261 230 082
036 906 433	0 261 210 110
036 906 433 B	0 261 210 233

036 906 433 B	0 261 210 234
036 906 461	0 280 217 108
036 906 461	0 280 217 109
036 906 461 A	0 280 218 056
036 906 461 A	0 280 218 057

036 906 461 A	0 986 280 214
036 906 461 A	0 986 280 314
036 906 461 AX	0 986 280 214
036 906 461 AX	0 986 280 314
037 905 377	0 261 231 075

037 905 377	0 261 231 076
037 905 377 A	0 261 231 077
037 905 377 A	0 261 231 078
037 906 301	0 280 202 106
037 906 301	0 280 202 107

037 906 301	0 986 280 008
037 906 301	0 986 280 086
037 906 301 B	0 280 202 130
037 906 301 B	0 280 202 131
037 906 301 B	0 280 202 138

037 906 301 B	0 280 202 139
037 906 301 B	0 986 280 010
037 906 301 B	0 986 280 077
037 906 301 B	0 986 280 087
037 906 301 C	0 280 202 130

037 906 301 C	0 280 202 131
037 906 301 C	0 986 280 010
037 906 301 C	0 986 280 087
037 906 461	0 280 217 103
037 906 461	0 280 217 104

037 906 461 A	0 280 217 103
037 906 461 A	0 280 217 104
037 906 461 C	0 280 217 117
037 906 461 C	0 280 217 118
037 906 461 C	0 986 280 201

037 906 461 C	0 986 280 301
037 906 461 CX	0 986 280 201
037 906 461 CX	0 986 280 301
037 906 462	0 280 217 505
038 906 051	0 281 002 177

038 906 051	0 281 002 178
038 906 051 A	0 281 002 394
038 906 051 A	0 281 002 395
038 906 051 B	0 281 002 399
038 906 051 B	0 281 002 400

038 906 051 C	0 281 002 401
038 906 051 C	0 281 002 402
038 906 051 D	0 261 230 073
038 906 051 D	0 261 230 074
038 906 051 E	0 261 230 209

038 906 051 F	0 261 230 202
038 906 051 G	0 261 230 207
038 906 051 H	0 261 230 215
038 906 051 J	0 261 230 215
038 906 461	0 281 002 463

038 906 461	0 281 002 464
038 906 461	0 986 284 008
038 906 461 B	0 281 002 531
038 906 461 B	0 281 002 532
038 906 461 B	0 986 284 009

038 906 461 BX	0 986 284 009
038 906 461 C	0 280 217 121
038 906 461 C	0 281 002 757
038 906 461 C	0 281 002 758
038 906 461 C	0 986 280 202

038 906 461 D	0 281 002 768
038 906 461 D	0 281 002 769
038 906 461 D	0 986 284 011
038 906 461 DX	0 986 284 011
038 906 461 X	0 986 284 008

039 906 051	0 280 100 043
039 906 051	0 280 100 044
039 906 059	0 332 514 108
039 906 111 A	0 280 120 032
039 906 111 A	0 280 120 033

039 906 301	0 280 200 022
039 906 301	0 280 200 023
040 906 161 4	0 280 130 039
043 906 111	0 280 120 105
043 906 111	0 280 120 106

043 906 301	0 280 200 006
043 906 301	0 280 200 007
043 906 301	0 986 280 014
045 906 461	0 281 002 318
045 906 461	0 281 002 319

045 906 461	0 986 284 002
045 906 461 X	0 986 284 002
046 130 385	0 281 002 018
046 905 379	0 280 130 039
046 905 379	0 280 130 078

046 905 379 A	0 280 130 078
046 907 475	0 132 009 316
046 907 475 A	0 205 001 001
046 907 475 B	0 205 001 001
046 907 475 D	0 205 001 007

046 907 475 E	0 205 001 013
046 907 475 F	0 205 001 017
046 907 475 G	0 205 001 018
047 133 471	0 438 120 022
047 133 471 A	0 438 120 060

047 133 471 B	0 438 120 066
047 133 471 B	0 438 120 067
047 133 471 C	0 438 120 108
048 133 154	0 280 120 334
048 133 154	0 280 120 335

048 133 154	0 280 120 426
048 133 154	0 280 120 427
048 133 471	0 438 121 087
048 133 471	0 438 121 088
048 133 471	0 986 439 387

048 905 161	0 232 102 006
048 905 161	0 232 102 007
049 133 353 AB	0 438 121 027
049 133 353 AB	0 438 121 028
049 133 471	0 438 120 008

049 133 471 A	0 438 120 020
049 133 471 B	0 438 120 028
049 133 471 B	0 438 120 029
049 133 471 D	0 438 120 090
049 133 471 F	0 438 120 054

049 133 471 F	0 438 120 055
049 133 471 G	0 438 120 105
049 133 471 G	0 438 120 106
049 133 471 H	0 438 120 128
049 133 471 H	0 438 120 129

049 133 471 J	0 438 120 155
049 133 471 J	0 438 120 156
049 133 471 K	0 438 120 130
049 133 471 K	0 438 120 131
049 133 471 L	0 438 120 162


049 133 471 L	0 438 120 163
049 133 471 M	0 438 120 189
049 133 471 M	0 438 120 190
049 133 471 N	0 438 121 027
049 133 471 N	0 438 121 028

050 906 433 B	0 261 210 134
050 906 433 B	0 261 210 135
051 133 154 A	0 280 120 422
051 133 154 A	0 280 120 423
051 133 471	0 438 121 076

051 133 471	0 438 121 077
051 133 471	0 986 439 376
051 133 471 A	F 026 TX2 059
051 133 471 A	0 438 121 089
051 133 471 A	0 438 121 090

051 133 471 A	0 986 439 389
051 905 377	0 261 231 021
051 905 377 B	0 261 231 022
051 905 381	0 356 914 213
051 905 381	0 356 914 214

053 905 377	0 261 231 013
053 905 381	0 356 914 222
053 905 381	0 356 914 223
053 906 301 1	0 280 202 126
053 906 301 4	0 280 202 136



◀ VW

054 133 154 F	0 280 120 433
054 133 154 F	0 280 120 434
054 133 471 B	F 026 TX2 058
054 133 471 B	0 438 121 085
054 133 471 B	0 438 121 086

054 133 471 B	0 986 439 386
054 133 471 BX	F 026 TX2 058
054 905 377	0 261 231 036
054 905 377	0 261 231 037
054 905 377 A	0 261 231 038

054 905 377 A	0 261 231 039
054 905 377 G	0 261 231 036
054 905 377 G	0 261 231 037
054 905 377 H	0 261 231 037
054 905 377 H	0 261 231 038

054 905 377 H	0 261 231 039
057 130 758	0 281 002 238
057 130 758	0 281 002 354
057 130 758 B	0 281 002 606
057 130 758 B	0 281 002 607

057 130 767	0 281 002 406
057 130 767	0 281 002 407
057 906 461	0 281 002 355
057 906 461	0 281 002 356
057 906 461	0 986 284 003

057 906 461 B	0 281 002 436
057 906 461 C	0 281 002 435
057 906 461 C	0 281 002 436
057 906 461 C	0 986 284 006
057 906 461 CX	0 986 284 006

057 906 461 X	0 986 284 003
058 133 063 P	0 280 750 009
058 133 063 P	0 280 750 010
058 133 471 A	0 280 217 112
058 133 471 A	0 280 217 113

058 905 161 A	0 232 101 004
058 905 161 B	0 232 101 024
058 905 161 B	0 232 101 025
058 905 161 C	0 232 101 091
058 905 279	0 280 130 086

058 905 379	0 280 130 085
058 905 379	0 280 130 086
059 130 758	0 281 002 504
059 130 758	0 281 002 691
059 906 051	0 281 002 326

059 906 051	0 281 002 327
059 906 461 A	0 281 002 224
059 906 461 A	0 281 002 225
059 906 461 B	0 281 002 403
059 906 461 B	0 281 002 404

059 906 461 B	0 986 284 004
059 906 461 BX	0 986 284 004
059 906 461 E	0 281 002 429
059 906 461 E	0 281 002 430
059 906 461 E	0 986 284 005

059 906 461 EX	0 986 284 005
06A 133 062 AA	0 280 750 167
06A 133 062 AA	0 280 750 168
06A 133 062 B	0 280 750 057
06A 133 062 B	0 280 750 058

06A 133 062 D	0 280 750 061
06A 133 062 D	0 280 750 062
06A 133 062 E	0 280 750 065
06A 133 062 E	0 280 750 066
06A 133 062 G	0 280 750 115

06A 133 062 G	0 280 750 116
06A 133 062 J	0 280 750 099
06A 133 062 P	0 280 750 057
06A 133 062 P	0 280 750 058
06A 133 062 Q	0 280 750 061

06A 133 062 Q	0 280 750 062
06A 133 062 R	0 280 750 159
06A 133 062 R	0 280 750 160
06A 133 471 X	0 986 280 206
06A 905 161	0 232 101 032

06A 905 161 A	0 232 103 019
06A 905 161 A	0 232 103 020
06A 905 161 B	0 232 101 031
06A 905 161 B	0 232 101 032
06A 905 161 C	0 232 101 038

06A 905 161 C	0 232 101 039
06A 905 161 D	0 232 101 094
06A 905 161 D	0 232 101 095
06A 906 433 A	0 261 210 145
06A 906 433 A	0 261 210 146

06A 906 433 B	0 261 210 254
06A 906 433 C	0 261 210 147
06A 906 433 C	0 261 210 148
06A 906 433 E	0 261 210 145
06A 906 433 E	0 261 210 146

06A 906 433 F	0 261 210 165
06A 906 433 F	0 261 210 166
06A 906 433 L	0 261 210 199
06A 906 433 L	0 261 210 200
06A 906 433 M	0 261 210 275

06A 906 433 M	0 261 210 276
06A 906 433 N	0 261 210 254
06A 906 433 N	0 261 210 255
06A 906 461	0 280 217 121
06A 906 461	0 280 217 122

06A 906 461	0 281 002 757
06A 906 461	0 986 280 202
06A 906 461	0 986 280 302
06A 906 461 A	0 280 218 002
06A 906 461 A	0 280 218 003

06A 906 461 A	0 986 280 205
06A 906 461 A	0 986 280 305
06A 906 461 AC	0 280 218 212
06A 906 461 AC	0 280 218 213
06A 906 461 AX	0 986 280 205

06A 906 461 AX	0 986 280 305
06A 906 461 C	0 280 218 023
06A 906 461 C	0 280 218 024
06A 906 461 C	0 986 280 209
06A 906 461 C	0 986 280 309

06A 906 461 CX	0 986 280 209
06A 906 461 CX	0 986 280 309
06A 906 461 D	0 280 218 032
06A 906 461 D	0 280 218 033
06A 906 461 D	0 986 280 210

06A 906 461 D	0 986 280 310
06A 906 461 DX	0 986 280 210
06A 906 461 DX	0 986 280 310
06A 906 461 E	0 280 218 034
06A 906 461 E	0 280 218 035

06A 906 461 E	0 986 280 211
06A 906 461 E	0 986 280 311
06A 906 461 EX	0 986 280 211
06A 906 461 EX	0 986 280 311
06A 906 461 G	0 280 218 060

06A 906 461 G	0 280 218 061
06A 906 461 G	0 986 280 216
06A 906 461 G	0 986 280 316
06A 906 461 GX	0 986 280 216
06A 906 461 GX	0 986 280 316

06A 906 461 L	0 280 218 063
06A 906 461 L	0 280 218 064
06A 906 461 L	0 986 280 217
06A 906 461 L	0 986 280 317
06A 906 461 LX	0 986 280 217

06A 906 461 LX	0 986 280 317
06A 906 461 M	0 280 218 065
06A 906 461 M	0 280 218 066
06A 906 461 M	0 986 280 218
06A 906 461 M	0 986 280 318

06A 906 461 MX	0 986 280 218
06A 906 461 MX	0 986 280 318
06A 906 461 N	0 280 218 100
06A 906 461 N	0 280 218 101
06A 906 461 N	0 986 280 223

06A 906 461 N	0 986 280 323
06A 906 461 NX	0 986 280 223
06A 906 461 NX	0 986 280 323
06A 906 461 R	0 280 218 102
06A 906 461 R	0 280 218 103

06A 906 461 T	0 280 218 124
06A 906 461 T	0 280 218 125
06A 906 461 X	0 986 280 202
06A 906 461 X	0 986 280 302
06A 906 473	0 280 218 193

06A 906 473	0 280 218 194
06A 906 473 A	0 280 218 195
06A 906 473 A	0 280 218 196
06B 133 062 B	0 280 750 009
06B 133 062 B	0 280 750 010

06B 133 062 E	0 280 750 080
06B 133 062 E	0 280 750 081
06B 133 062 H	0 280 750 088
06B 133 062 H	0 280 750 089
06B 133 062 M	0 280 750 009

06B 133 062 M	0 280 750 010
06B 133 471	0 280 218 013
06B 133 471	0 280 218 014
06B 133 471	0 986 280 206
06B 133 471	0 986 280 306

06B 133 471 A	0 280 218 058
06B 133 471 A	0 280 218 059
06B 133 471 A	0 986 280 215
06B 133 471 A	0 986 280 315
06B 133 471 AX	0 986 280 215

06B 133 471 AX	0 986 280 315
06B 133 471X	0 986 280 306
06B 905 377 B	0 261 231 202
06B 905 377 B	0 261 231 203
06B 905 379	0 280 130 116

06B 905 379	0 280 130 117
06B 906 051	0 261 230 031
06B 906 051	0 261 230 032
06B 906 461	0 280 218 132
06B 906 461	0 280 218 133

06D 133 062	0 280 750 134
06D 133 062	0 280 750 135
06D 906 051	0 261 545 008
06D 906 051	0 261 545 009
06D 906 051	0 261 545 036


06D 906 051	0 261 545 037
06D 906 051 A	0 261 545 009
06D 906 051 A	0 261 545 036
06D 906 051 A	0 261 545 037
06D 906 051 C	0 261 545 017

06D 906 051 C	0 261 545 018
06H 906 051	0 261 545 024
06H 906 051	0 261 545 025
06H 906 051 A	0 261 545 036
06H 906 051 A	0 261 545 037

06J 906 051	0 261 545 015
06J 906 051	0 261 545 016
06J 906 051 A	0 261 545 022
06J 906 051 A	0 261 545 023
06J 906 051 B	0 261 545 035

063 133 471	0 438 120 007
07C 133 062	0 280 750 107
07C 133 062	0 280 750 108
07C 133 062 A	0 280 750 157
07C 133 062 A	0 280 750 158

07C 133 062 C	0 280 750 158
07C 906 018 H	0 261 210 047
07C 906 051	0 261 230 167
07C 906 051	0 261 230 168
07C 906 461	0 280 218 071



07C 906 461	0 280 218 072
07C 906 461	0 986 280 221
07C 906 461	0 986 280 321
07C 906 461 A	0 280 218 143
07C 906 461 A	0 280 218 144

07C 906 461 X	0 986 280 221
07C 906 461 X	0 986 280 321
07D 906 461	0 280 218 073
07D 906 461	0 280 218 074
07D 906 461	0 986 280 222

07D 906 461	0 986 280 322
07D 906 461 X	0 986 280 222
07D 906 461 X	0 986 280 322
07E 133 062	0 280 750 177
07E 133 062	0 280 750 178

07Z 906 051	0 281 002 558
07Z 906 051	0 281 002 559
07Z 906 051 A	0 281 002 710
07Z 906 051 A	0 281 002 711
07Z 906 051 B	0 281 002 759

07Z 906 051 B	0 281 002 760
071 906 059	0 332 514 129
071 906 059 A	0 332 514 125
071 906 301	0 280 200 025
071 906 301 A	0 280 200 028

071 906 301 A	0 280 200 029
071 906 301 B	0 280 200 030
071 906 301 B	0 280 200 031
071 906 301 C	0 280 200 032
071 906 301 C	0 280 200 033

071 906 461	0 280 217 523
071 906 461	0 280 217 524
071 906 461 A	0 280 217 529
071 906 461 A	0 280 217 530
071 906 461 A	0 986 280 204

071 906 461 A	0 986 280 304
071 906 461 AX	0 986 280 204
071 906 461 AX	0 986 280 304
071 906 461 B	0 280 218 017
071 906 461 B	0 280 218 018

071 906 461 B	0 986 280 208
071 906 461 B	0 986 280 308
071 906 461 BX	0 986 280 208
071 906 461 BX	0 986 280 308
071 957 147	0 261 210 177

074 906 461 B	0 281 002 461
074 906 461 B	0 281 002 462
074 906 461 B	0 986 284 007
074 906 461 BX	0 986 284 007
074 906 461 C	0 281 002 805

074 906 461 C	0 281 002 806
074 907 475	0 205 001 030
077 133 062 C	0 280 750 127
077 133 062 C	0 280 750 128
077 133 154 A	0 280 120 408

077 133 154 B	0 280 120 424
077 133 154 B	0 280 120 425
077 133 154 D	0 280 120 428
077 133 154 D	0 280 120 429
077 133 471 C	0 280 216 001

077 133 471 C	0 280 216 002
077 133 471 D	0 280 217 804
077 133 471 D	0 280 217 805
077 133 471 E	0 280 217 813
077 133 471 E	0 280 217 817

077 133 471 G	0 280 218 015
077 133 471 G	0 280 218 016
077 133 471 G	0 986 280 207
077 133 471 G	0 986 280 307
077 133 471 GX	0 986 280 207

077 133 471 GX	0 986 280 307
077 133 471 H	0 280 218 047
077 133 471 H	0 280 218 048
077 133 471 H	0 986 280 213
077 133 471 H	0 986 280 313

077 133 471 HX	0 986 280 213
077 133 471 HX	0 986 280 313
077 133 471 J	0 280 218 069
077 133 471 J	0 280 218 070
077 133 471 J	0 986 280 220

077 133 471 J	0 986 280 320
077 133 471 JX	0 986 280 220
077 133 471 JX	0 986 280 320
077 133 471 K	0 280 218 067
077 133 471 K	0 280 218 068

077 133 471 K	0 986 280 219
077 133 471 K	0 986 280 319
077 133 471 KX	0 986 280 219
077 133 471 KX	0 986 280 319
077 133 471 M	0 280 218 187

077 133 471 M	0 280 218 188
077 905 375	0 261 210 271
077 905 375	0 261 210 272
077 905 377	0 261 231 019
077 905 377	0 261 231 020

077 905 377 A	0 261 231 005
077 905 377 A	0 261 231 040
077 905 377 A	0 261 231 041
077 905 381 C	0 261 210 143
077 905 381 D	0 261 210 111

077 905 381 D	0 261 210 112
077 905 381 E	0 261 210 143
077 905 381 E	0 261 210 144
077 905 381 F	0 261 210 190
077 905 381 F	0 261 210 191

077 905 381 G	0 261 210 192
077 905 381 G	0 261 210 193
077 905 381 H	0 261 210 243
077 905 381 H	0 261 210 244
077 905 381 J	0 261 210 245

077 905 381 J	0 261 210 246
077 905 381 K	0 261 210 261
077 905 381 K	0 261 210 262
077 905 381 L	0 261 210 264
077 905 381 L	0 261 210 265

077 905 381 N	0 261 210 299
077 906 461	0 280 218 067
077 906 461	0 280 218 068
077 906 461	0 986 280 319
077 919 501 B	0 280 130 095

077 919 501 B	0 280 130 096
077 919 501 C	0 280 130 098
077 919 501 C	0 280 130 099
078 133 062	0 280 750 003
078 133 062	0 280 750 004

078 133 062 C	0 280 750 003
078 133 062 C	0 280 750 004
078 133 154	0 280 120 431
078 133 154	0 280 120 432
078 905 155	0 232 101 010

078 905 155	0 232 101 011
078 905 155	0 232 101 027
078 905 155	0 232 101 028
078 905 161 A	0 232 101 010
078 905 161 A	0 232 101 011

078 905 161 A	0 232 101 027
078 905 161 A	0 232 101 028
078 905 161 C	0 232 101 027
078 905 161 C	0 232 101 028
078 905 379 A	0 280 130 102

078 905 379 A	0 280 130 103
078 906 051	0 261 230 023
078 906 161	0 280 130 060
078 906 161	0 280 130 083
078 906 433	0 261 210 139

078 906 433	0 261 210 140
078 906 433 A	0 281 002 222
078 906 433 A	0 281 002 223
078 906 433 B	0 261 210 178
078 906 433 B	0 261 210 179

078 906 433 F	0 261 210 217
078 906 433 F	0 261 210 218
078 906 433 J	0 261 210 277
078 906 433 J	0 261 210 278
078 906 461	0 280 217 815

078 906 461	0 280 217 816
078 906 461 B	0 280 218 038
078 906 461 B	0 280 218 039
078 906 461 B	0 986 280 212
078 906 461 B	0 986 280 312

078 906 461 BX	0 986 280 212
078 906 461 BX	0 986 280 312
078 906 461 K	0 280 218 068
078 906 461 K	0 986 280 319
079 133 471	0 280 218 214

079 133 471	0 280 218 215
079 905 381	0 261 210 235
079 905 381	0 261 210 236
1H1 721 568	0 205 001 014
1H1 721 568 A	0 205 001 014

1H1 721 568 B	0 205 001 034
1H1 721 568 N	0 205 001 014
1H1 723 568	0 205 001 022
1H1 723 568 A	0 205 001 022
1H1 723 568 A	0 205 001 033

1H2 721 727	0 205 001 025
1H2 721 727 A	0 205 001 035
1H2 723 727	0 205 001 026
1H2 723 727 A	0 205 001 036
1JD 906 433	0 261 210 241

1JD 906 433	0 261 210 242
1JD 906 433 A	0 261 210 288
1JD 906 433 A	0 261 210 289
1JD 906 461	0 280 218 060
1JD 906 461	0 280 218 061

1JD 906 461	0 986 280 216
1JD 906 461	0 986 280 316
1JO 919 275	0 263 003 169
1JO 919 275 A	0 263 003 189
1JO 919 275 B	0 263 003 218

1J1 721 503 AB	0 281 002 342
1J1 721 503 AC	0 280 752 201
1J1 721 503 B	0 281 002 342
1J1 721 503 H	0 281 002 342
1J1 721 503 K	0 281 002 342


1J1 721 503 L	0 280 752 201
1J1 721 503 M	0 281 002 341
1J1 721 503 M	0 281 002 342
1J1 721 503 N	0 280 752 201
1J1 721 503 Q	0 280 752 203

1J1 721 727	0 205 001 043
1J1 721 727 A	0 281 002 219
1J1 721 727 B	0 281 002 269
1J1 721 727 D	0 281 002 269
1J1 723 503 AA	0 280 752 203

1J1 723 503 AF	0 281 002 344
1J1 723 503 AG	0 280 752 203
1J1 723 503 AK	0 281 002 344
1J1 723 503 AL	0 280 752 203
1J1 723 503 M	0 281 002 343

1J1 723 503 M	0 281 002 344
1J1 723 503 N	0 280 752 203
1J1 723 503 Q	0 280 752 203
1J1 723 503 R	0 281 002 344
1J1 723 503 T	0 281 002 344

1J1 723 727	0 205 001 045
1J1 723 727 A	0 205 001 045
1J1 723 727 A	0 281 002 220
1J1 723 727 B	0 281 002 266
1J1 907 469	0 281 002 193



◀ VW

1J1 907 469 A	0 281 002 194
1J2 721 503	0 281 002 345
1J2 721 503	0 281 002 346
1J2 721 503 A	0 280 752 210
1J2 721 503 A	0 280 752 211

1J2 721 503 B	0 281 002 346
1J2 721 503 C	0 280 752 210
1J2 721 503 C	0 280 752 211
1J2 721 503 H	0 281 002 346
1J2 721 503 J	0 280 752 210

1J2 721 503 J	0 280 752 211
1J2 721 503 K	0 280 752 275
1J2 721 503 K	0 280 752 276
1J2 721 503 L	0 280 752 266
1J2 721 503 M	0 281 002 622

1J2 721 568 B	0 205 001 051
1J2 721 568 C	0 205 001 050
1J2 721 568 D	0 205 001 051
1J2 721 568 D	0 281 002 230
1J2 721 568 E	0 281 002 267

1J2 721 568 F	0 280 752 012
1J2 721 568 F	0 280 752 013
1J2 721 568 G	0 281 002 267
1J2 723 503	0 281 002 347
1J2 723 503	0 281 002 348

1J2 723 503 A	0 280 752 213
1J2 723 503 B	0 281 002 348
1J2 723 503 C	0 280 752 213
1J2 723 503 D	0 281 002 348
1J2 723 503 E	0 280 752 213

1J2 723 503 H	0 281 002 348
1J2 723 503 J	0 280 752 213
1J2 723 503 K	0 281 002 348
1J2 723 503 L	0 280 752 213
1J2 723 568 B	0 205 001 050

1J2 723 568 C	0 205 001 051
1J2 723 568 D	0 205 001 050
1J2 723 568 D	0 281 002 231
1J2 723 568 E	0 281 002 268
1J2 723 568 F	0 280 752 014

1J2 723 568 F	0 280 752 015
1J2 723 568 G	0 281 002 268
1K0 906 207 A	0 261 230 169
1K0 906 207 A	0 261 230 170
1K0 955 549 R	1 397 212 082

1K0 955 559	1 397 212 059
1K0 955 559 AA	1 397 212 114
1K0 955 559 AB	1 397 212 129
1K0 955 559 AD	1 397 212 114
1K0 955 559 AE	1 397 212 114

1K0 955 559 AE	1 397 212 129
1K0 955 559 H	1 397 212 080
1K0 955 559 K	1 397 212 059
1K0 955 559 L	1 397 212 081
1K0 955 559 M	1 397 212 089

1K0 955 559 N	1 397 212 090
1K0 955 559 O	1 397 212 100
1K0 955 559 P	1 397 212 099
1K0 955 559 Q	1 397 212 100
1K0 955 559 R	1 397 212 082

1K0 955 559 S	1 397 212 102
1K0 955 559 T	1 397 212 115
1U0 919 275	0 263 003 187
2D0 907 469	0 205 001 030
2D0 927 807	0 265 004 009

2D0 927 807 A	0 265 004 010
2D0 927 808	0 265 004 008
2D0 927 808 A	0 265 004 010
2D0 963 141	0 332 015 011
2E0 721 507 B	0 280 755 025

2E0 721 507 C	0 280 755 023
2E0 906 461	0 281 002 586
2E0 906 461 C	0 281 002 897
2E0 907 637	0 265 005 628
2E0 927 748 B	0 265 007 661

2E0 927 748 C	0 265 007 662
2E0 927 748 F	0 265 007 880
2E0 927 748 G	0 265 007 881
2E0 927 801	0 265 007 659
2E0 927 801 A	0 265 007 660

2E0 927 801 B	0 265 007 657
2E0 927 801 B	0 265 007 661
2K0 906 052	0 261 545 020
2K0 906 052	0 261 545 021
2P0 133 491	0 281 002 667

2P0 906 051	0 281 002 514
2R0 906 051 C	0 281 002 437
2R0 906 433	0 281 002 410
2R0 906 433 C	0 281 002 411
2R0 906 433 D	0 281 002 214

2R0 919 081 D	0 281 002 472
2R0 919 501	0 281 002 316
2R0 919 501 A	0 281 002 471
2R0 919 501 B	0 281 002 209
2S0 906 051	0 281 002 576

2T2 906 051 B	0 281 002 851
2T2 919 333	0 281 002 534
20103332	0 263 003 683
20103758	0 263 003 685
20103759	0 263 003 725

237 906 311 1	0 261 230 004
237 906 311 1	0 261 230 008
251 907 388	0 265 005 009
251 927 807	0 265 001 148
251 927 807	0 265 001 149

251 927 807 A	0 265 001 150
251 927 807 B	0 265 001 195
251 927 807 B	0 265 001 196
251 927 807 D	0 265 001 195
251 927 808	0 265 001 197

251 927 808	0 265 001 198
261 230 138	0 261 230 138
270 600 001	0 261 230 020
281 927 807	0 265 003 097
281 927 807 A	0 265 001 330

281 927 807 B	0 265 003 141
291 927 807	0 265 003 098
3A0 906 051	0 261 230 007
3A0 906 051	0 261 230 008
3A0 906 051	0 261 230 037

3A1 721 568 B	0 205 001 037
3A1 723 568	0 205 001 027
3A1 723 568 A	0 205 001 038
3B0 927 807 G	0 265 006 572
3B0 927 807 G	0 265 006 573

3B0 927 807 H	0 265 006 574
3B0 927 807 H	0 265 006 575
3B0 955 559	1 397 212 014
3B0 955 559	1 397 212 028
3B0 955 559	1 397 212 029

3B0 955 559	1 397 212 038
3B0 955 559 A	1 397 212 012
3B0 955 559 B	1 397 212 091
3B0 955 559 C	1 397 212 098
3D0 919 275 B	0 263 003 224

3D0 919 275 B	0 263 003 244
3D0 919 275 B	0 263 003 552
3D0 919 275 C	0 263 003 526
3D0 919 275 D	0 263 003 525
3D0 927 804	0 265 007 409

3D0 927 807	0 265 007 409
3D0 955 559	1 397 212 032
3D0 955 559 A	1 397 212 038
3D0 955 559 B	1 397 212 093
3D0 955 559 C	1 397 212 092

3W0 955 559	1 397 212 078
3W0 955 559 A	1 397 212 078
3W0 955 559 A	1 397 212 085
3W0 955 559 B	1 397 212 120
3W5 955 559 C	1 397 212 121

3W5 955 559 D	1 397 212 122
3W5 955 559 E	1 397 212 123
3W5 955 559 F	1 397 212 130
3W5 955 559 G	1 397 212 131
305 906 059 1	0 280 230 016

311 906 041 A	0 280 130 003
311 906 041 A	0 280 130 004
311 906 051 B	0 280 100 001
311 906 051 C	0 280 100 007
311 906 051 D	0 280 100 101

311 906 051 E	0 280 100 106
311 906 051 E	0 280 100 116
311 906 061	0 332 003 021
311 906 061	0 332 003 022
311 906 081	0 280 130 001

311 906 081 B	0 280 130 015
311 906 111 B	0 280 120 001
311 906 111 B	0 280 120 002
311 906 111 C	0 280 120 040
311 906 111 C	0 280 120 041

311 906 111 D	0 280 120 019
311 906 111 D	0 280 120 020
311 906 111 E	0 280 120 024
311 906 111 E	0 280 120 025
325 927 807 3	0 265 006 220

325 927 807 4	0 265 006 219
33D 906 461	0 280 218 204
331 927 807	0 265 001 107
331 927 807 A	0 265 001 105
347 927 803 A	0 265 001 007

357 721 568	0 205 001 012
357 721 568 A	0 205 001 012
376 927 807	0 265 006 642
376 927 807	0 265 006 643
376 927 807 A	0 265 006 644

376 927 807 A	0 265 006 645
377 906 051	0 261 230 037
377 906 051	0 261 230 038
377 906 461	0 280 218 053
377 927 807	0 265 006 218

377 927 807 B	0 265 006 222
377 927 807 C	0 265 006 221
377 927 807 D	0 265 006 410
377 927 807 F	0 265 006 411
4A0 133 471	0 281 002 074


4A0 133 471	0 281 002 075
4A0 133 471	0 986 280 089
4B0 907 637	0 265 005 214
4B0 907 637 A	0 265 005 213
4B0 907 637 A	0 265 005 214

4B0 927 803 B	0 265 006 577
4B0 927 803 B	0 265 006 578
4B0 927 803 E	0 265 006 764
4B0 927 803 E	0 265 006 765
4B0 927 803 F	0 265 006 654

4B0 927 803 F	0 265 006 655
4B0 927 807 E	0 265 006 564
4B0 927 807 E	0 265 006 565
4B0 927 807 F	0 265 006 566
4B0 927 807 F	0 265 006 567

4B0 927 807 J	0 265 006 564
4B0 927 807 J	0 265 006 565
4B0 927 807 J	0 265 006 583
4B0 927 807 J	0 265 006 584
4B0 927 807 K	0 265 006 566

4B0 927 807 K	0 265 006 567
4B0 927 807 K	0 265 006 585
4B0 927 807 K	0 265 006 586
4B0 927 807 M	0 265 006 663
4B0 927 807 M	0 265 006 664



4B0 927 807 N	0 265 006 764
4B0 927 807 N	0 265 006 766
4B0 927 807 N	0 265 006 767
4B0 927 807 P	0 265 006 768
4B0 927 807 P	0 265 006 769

4B0 927 807 Q	0 265 006 760
4B0 927 807 Q	0 265 006 761
4B0 927 807 R	0 265 006 762
4B0 927 807 R	0 265 006 763
4B0 927 807 S	0 265 006 770

4B0 927 807 S	0 265 006 771
4D0 907 571	0 265 005 401
4D0 907 657	0 265 005 206
4D0 907 657	0 265 005 207
4D0 927 803 B	0 265 006 579

4D0 927 803 B	0 265 006 580
4D0 927 803 C	0 265 006 579
4D0 927 803 C	0 265 006 580
4D0 927 803 D	0 265 006 579
4D0 927 803 D	0 265 006 580

4D0 927 803 E	0 265 006 661
4D0 927 803 E	0 265 006 662
4D0 927 807 B	0 265 006 587
4D0 927 807 B	0 265 006 588
4E0 927 803	0 265 007 407

4E0 927 803	0 265 007 408
4E0 927 803	0 265 007 727
4E0 927 803	0 265 007 728
4E0 927 803 A	0 265 007 407
4E0 927 803 A	0 265 007 727

4E0 927 803 A	0 265 007 728
4E0 927 803 D	0 265 007 929
4E0 927 803 D	0 265 007 930
4E0 927 804	0 265 007 405
4E0 927 804	0 265 007 406

4E0 927 804 A	0 265 007 405
4E0 927 804 A	0 265 007 725
4E0 927 804 A	0 265 007 726
4E0 927 804 D	0 265 007 927
4E0 927 804 D	0 265 007 928

4E5 927 807	0 265 007 729
4F0 907 637	0 265 005 278
4F0 907 637	0 265 005 601
4Z0 927 803 B	0 265 006 772
4Z0 927 803 B	0 265 006 773

4Z7 927 803 A	0 265 006 652
4Z7 927 803 B	0 265 006 772
4Z7 927 807 C	0 265 006 654
4Z7 927 807 C	0 265 006 655
4Z7 927 807 E	0 265 006 656

4Z7 927 807 E	0 265 006 657
4Z7 927 807 F	0 265 006 780
4Z7 927 807 F	0 265 006 781
4Z7 927 807 G	0 265 006 782
4Z7 927 807 G	0 265 006 783

411 906 271	0 335 530 004
437 927 803 B	0 265 001 047
437 927 803 B	0 265 001 048
437 927 803 H	0 265 001 007
443 907 388	0 265 005 007

443 927 803	0 265 001 042
443 927 803 A	0 265 001 039
443 927 803 A	0 265 001 040
443 927 803 B	0 265 004 001
443 927 807	0 265 001 041

443 927 807	0 265 001 042
443 927 807 A	0 265 001 060
443 927 807 A	0 265 001 061
443 927 807 B	0 265 001 088
443 927 807 B	0 265 001 089

443 927 807 C	0 265 001 120
473 906 301	0 280 201 002
539 063 015	0 280 202 137
539 906 301 5	0 280 202 137
6K2 721 727 A	0 280 752 025

6K2 721 727 B	0 281 002 338
6N1 721 503 B	0 281 002 321
6N1 721 503 B	0 281 002 322
6N1 721 503 D	0 281 002 322
6N1 721 503 F	0 261 002 322

6N1 721 503 F	0 280 752 206
6N1 721 503 F	0 280 752 207
6N1 721 503 F B41	0 281 002 322
6N1 721 503 G	0 280 752 206
6N1 721 503 G	0 280 752 207

6N1 723 503	0 281 002 324
6N1 723 503 B	0 281 002 323
6N1 723 503 B	0 281 002 324
6N1 723 503 F	0 281 002 324
6N1 723 503 G	0 280 752 209

6N1 723 503 H	0 281 002 324
6N1 723 503 J	0 280 752 209
6N1 723 503 K	0 281 002 324
6N1 723 503 L	0 280 752 209
6N1 723 503 M	0 281 002 324

6N1 723 503 N	0 280 752 209
6Q0 907 637 A	0 265 005 691
6Q0 907 637 A	0 265 005 692
6Q1 721 503	0 281 002 377
6Q1 721 503	0 281 002 378

6Q1 721 503 A	0 280 752 214
6Q1 721 503 A	0 280 752 215
6Q1 721 503 D	0 281 002 378
6Q1 721 503 E	0 280 752 214
6Q1 721 503 E	0 280 752 215

6Q1 721 503 F	0 280 755 063
6Q1 721 503 H	0 280 755 055
6Q1 723 503	0 281 002 371
6Q1 723 503	0 281 002 372
6Q1 723 503 B	0 281 002 372

6Q1 723 503 C	0 280 752 217
6Q1 723 503 E	0 280 752 214
6Q1 723 503 F	0 281 002 372
6Q1 723 503 G	0 280 752 217
6Q1 723 503 H	0 281 002 372

6Q1 723 503 J	0 280 752 217
6Q1 723 503 K	0 280 755 064
6Q1 723 503 K	0 280 755 065
6Q1 723 503 L	0 280 755 057
6Q2 721 503	0 281 002 374

6Q2 721 503 B	0 281 002 374
6Q2 721 503 C	0 280 752 219
6Q2 721 503 E	0 280 755 066
6Q2 721 503 E	0 280 755 067
6Q2 721 503 F	0 281 002 374

6Q2 721 503 G	0 280 752 219
6Q2 721 503 H	0 280 755 058
6Q2 721 503 H	0 280 755 059
6Q2 723 503	0 281 002 375
6Q2 723 503	0 281 002 376

6Q2 723 503 B	0 281 002 376
6Q2 723 503 C	0 280 752 221
6Q2 723 503 D	0 281 002 376
6Q2 723 503 E	0 280 752 221
6Q2 723 503 F	0 281 002 376

6Q2 723 503 G	0 280 752 220
6Q2 723 503 G	0 280 752 221
6Q2 723 503 H	0 280 755 068
6Q2 723 503 H	0 280 755 069
6Q2 723 503 J	0 280 755 061

6U0 919 501	0 280 130 026
6W0 906 081	0 280 130 073
672 046	1 237 031 296
7D0 721 727	0 205 001 020
7D0 723 727	0 205 001 052

7D0 927 807	0 265 006 507
7D0 927 807	0 265 006 508
7D0 927 808	0 265 006 509
7D0 927 808	0 265 006 510
7L0 955 559	1 397 212 031

7L0 955 559 A	1 397 212 028
7L0 955 559 B	1 397 212 030
7L0 955 559 B	1 397 212 032
7L0 955 559 C	1 397 212 027
7L0 955 559 C	1 397 212 028

7L0 955 559 C	1 397 212 029
7L0 955 559 D	1 397 212 097
7L0 955 559 E	1 397 212 095
7L0 955 559 F	1 397 212 096
7L0 955 559 G	1 397 212 094

7L5 905 381	0 261 210 239
7L5 905 381 A	0 261 210 292
7L5 906 461 A	0 280 218 141
7L5 906 461 B	0 280 218 198
7L5 919 041	0 263 003 487

7L5 919 275	0 263 003 487
7L5 919 275	0 263 003 492
7L5 919 275	0 263 003 685
7L5 919 275	0 263 003 725
7L5 919 275 A7W	0 263 003 490

7L5 919 275 C9Z	0 263 003 491
7L5 919 275 D5Q	0 263 003 488
7L5 919 275 M1W	0 263 003 495
7L5 919 275 M3W	0 263 003 494
7L5 919 275 M6U	0 263 003 496

7L5 919 275 M6X	0 263 003 493
7L5 919 275 R9A	0 263 003 489
7L6 919 275	0 263 003 577
7M0 907 469	0 205 001 041
701 721 727	0 205 001 020

701 721 727 A	0 205 001 020
701 723 727 A	0 205 001 052
701 927 807	0 265 003 077
701 927 807	0 265 003 107
701 927 807 A	0 265 003 076

701 927 807 A	0 265 006 301
701 927 807 A	0 265 006 407
701 927 807 C	0 265 003 107
701 927 807 D	0 265 006 303
701 927 807 D	0 265 006 409

701 927 807 E	0 265 006 304
701 927 807 E	0 265 006 408
701 927 807 F	0 265 006 301
701 927 807 F	0 265 006 407
8A0 143 71Y	0 204 154 035


8A0 243 71Y	0 204 154 036
8D0 927 807 F	0 265 006 568
8D0 927 807 F	0 265 006 569
8D0 927 807 G	0 265 006 570
8D0 927 807 G	0 265 006 571

8D0 927 807 H	0 265 006 692
8D0 927 807 H	0 265 006 693
8D0 927 807 J	0 265 006 694
8D0 927 807 J	0 265 006 695
8E0 907 597	0 265 005 303

8E0 907 637 A	0 265 005 245
8E0 907 637 A	0 265 005 252
8E0 907 637 B	0 265 005 618
8E0 907 637 B	0 265 005 619
8E0 907 637 B	0 265 007 618

8E0 907 637 C	0 265 005 620
8E0 907 637 C	0 265 005 621
8E0 907 637 C	0 265 007 620
8E0 907 637 C	0 265 007 853
8E0 927 803	0 265 006 682

8E0 927 803 A	0 265 006 682
8E0 927 803 A	0 265 006 683
8E0 927 803 B	0 265 006 808
8E0 927 803 B	0 265 006 809
8E0 927 807 B	0 265 006 680



8E0 927 807 B	0 265 006 681
8E0 927 807 C	0 265 006 706
8E0 927 807 C	0 265 006 707
8E0 927 807 E	0 265 006 825
8E0 927 807 E	0 265 006 826
8E0 927 807 F	0 265 006 827
8E0 927 807 F	0 265 006 828
8E0 927 807 G	0 265 006 823
8E0 927 807 G	0 265 006 824
8K0 907 637 A	0 265 005 667
8K0 907 637 A	0 265 005 668
8K0 907 637 B	0 265 005 669
8K0 907 637 B	0 265 005 670
8K0 907 637 C	0 265 005 738
8N2 721 503	0 280 752 233
8N2 721 503	0 280 752 234
8N2 721 503 A	0 280 752 233
8N2 721 503 A	0 280 752 234
8N2 721 503 C	0 280 752 233
8N2 721 503 C	0 280 752 234
8N2 721 503 D	0 280 752 233
8N2 721 503 D	0 280 752 234
8N2 723 503 A	0 280 752 233
8N2 723 503 A	0 280 752 234
8N2 723 503 B	0 280 752 255
8N2 723 503 B	0 280 752 256
8Z0 906 461	0 281 002 610
8Z0 906 461	0 281 002 611
8Z0 959 643	0 285 002 071
800 000 140	0 281 002 477
811 927 807	0 265 001 099
811 927 807	0 265 001 100
853 919 562	0 280 101 001
853 919 562	0 280 101 002
853 919 562 A	0 280 101 010
853 919 562 A	0 280 101 011
857 927 807 A	0 265 001 062
857 927 807 A	0 265 001 063
859 907 388	0 265 005 001
859 907 388	0 265 005 002
859 927 807	0 265 001 083
859 927 808	0 265 001 082
893 927 807	0 265 001 182
893 927 807	0 265 001 183
893 927 807 B	0 265 001 180
893 927 807 B	0 265 001 181
ZASTAVA (YUGO)	
466 427 71	0 261 230 025

[illegible]

[illegible]